# Safety Instructions Levelflex FMP54/56/57

PROFIBUS PA, FOUNDATION Fieldbus

II 1 D Ex ta IIIC  $T_{200}$  114°C Da II 1/2 D Ex ta/tb IIIC T85°C Da/Db







# Levelflex FMP54/56/57

# PROFIBUS PA, FOUNDATION Fieldbus

# Table of contents

Associated documentation
Supplementary documentation
Manufacturer's certificates
Manufacturer address
Other standards5
Extended order code5
Safety instructions: General 8
Safety instructions: Special conditions 8
Safety instructions: Installation
Temperature tables
Connection data

# Associated documentation

This document is an integral part of the following Operating Instructions:

#### PROFIBUS PA

- BA01006F/00 (FMP51, FMP52, FMP54)
- BA01009F/00 (FMP56, FMP57)

#### FOUNDATION Fieldbus

- BA01052F/00 (FMP51, FMP52, FMP54)
- BA01055F/00 (FMP56, FMP57)

# Supplementary documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available:

- In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Brochures and Catalogs -> Text Search: CP00021Z
- On the CD for devices with CD-based documentation

# Manufacturer's certificates

#### **UK Declaration of Conformity**

Declaration Number: UK00043

The UK Declaration of Conformity is available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Declaration -> Type: UKCA Declaration -> Product Code: ...

#### UKCA type-examination certificate

Certificate number: CML 21UKEX2355X

List of applied standards: See UK Declaration of Conformity.

# Manufacturer address

Endress+Hauser SE+Co. KG Hauptstraße 1 79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

#### Other standards

Among other things, the following standards shall be observed in their current version for proper installation:

- IEC/EN 60079-14: "Explosive atmospheres Part 14: Electrical installations design, selection and erection"
- EN 1127-1: "Explosive atmospheres Explosion prevention and protection - Part 1: Basic concepts and methodology"

# Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

#### Structure of the extended order code

FMP5x	-	*****	+	A*B*C*D*E*F*G*
(Device		(Basic		(Optional
type)		specifications)		specifications)

\* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

### Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available.

The selected option of a feature can consist of several positions.

# Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

#### Extended order code: Levelflex



The following specifications reproduce an extract from the product structure and are used to assign:

- This documentation to the device (using the extended order code on the nameplate).
- The device options cited in the document.

Device type

FMP54, FMP56, FMP57

Basic specifications

Position 1, 2 (Approval)							
Selected option Description							
FMP5x	MP5x UE <sup>1)</sup> UK Ex II 1 D Ex ta IIIC T <sub>200</sub> 114°C Da						
UF <sup>2)</sup> UK Ex II 1/2 D Ex ta/tb IIIC T85°C Da/Db							

- 1) The designation changes in connection with Position 4 = L, M, N: II 1 D Ex ta [ia] IIIC  $T_{200}$  114°C Da
- 2) The designation changes in connection with Position 4 = L, M, N: II 1/2 D Ex ta/tb [ia Da] IIIC T85°C Da/Db

Position 3 (Power Supply, Output)							
Selected option Description							
FMP5x	Е	2-wire, FOUNDATION Fieldbus, switch output (PFS)					
G 2-wire, PROFIBUS PA, switch output (PFS)							

Position 4 (Display, Operation)							
Selected option		Description					
FMP5x	А	Without, via communication					
	С	SD02, 4-line, push buttons + data backup function					
	Е	SD03, 4-line, illum., touch control + data backup function					
L <sup>1)</sup> M <sup>1)</sup>		Prepared for display FHX50 + M12 connection					
		Prepared for display FHX50 + custom connection					
	N 1)	Prepared for display FHX50 + NPT1/2"					


1) UK Ex approved version of FHX50

Position 5 (Housing)						
Selected op	ption	Description				
FMP5x	B GT18 dual compartment, 316L					
	С	GT20 dual compartment, Alu coated				

Position 6 (Electrical Connection)							
Selected option		Description					
FMR5x	A 1)	Gland M20, IP66/68 NEMA4X/6P					
	В	Thread M20, IP66/68 NEMA4X/6P					
	С	Thread G1/2, IP66/68 NEMA4X/6P					
	D	Thread NPT1/2, IP66/68 NEMA4X/6P					

1) Only in connection with Position 1, 2 = UF

Position 9, 10 (Seal)							
Selected o	ption	Description					
FMP54	D1	Graphite, −196280 °C (XT)					
	D2	Graphite, −196450 °C (HT)					
FMP56	AB	Viton, −30120 °C					
	В3	EPDM, -40120 °C					
FMP57	A4	Viton, −30150 °C					
	В3	EPDM, -40120 °C					
	C5	Kalrez, −5185 °C					
78	wn in the mplary as	temperature tables follows:					



#### Optional specifications

ID Mx (Probe Design)							
Selected option		Description					
FMP5x	MB	Sensor remote, 3 m/9 ft cable, detachable + mounting bracket					
	MC	Sensor remote, 6 m/18 ft cable, detachable + mounting bracket					
	MD	Sensor remote, 9 m/27 ft cable, detachable + mounting bracket					

#### Safety instructions: General


- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
  - Be suitably qualified for their role and the tasks they perform
  - Be trained in explosion protection
  - Be familiar with national regulations
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.
- Only use the device in media to which the wetted materials have sufficient durability.
- Avoid electrostatic charging:
  - Of plastic surfaces (e.g. enclosure, sensor element, special varnishing, attached additional plates, ..)
  - Of isolated capacities (e.g. isolated metallic plates)
- Modifications to the device can affect the explosion protection and must be carried out by staff authorized to perform such work by Endress+Hauser.
- Refer to the temperature tables for the relationship between the permitted ambient temperature for the sensor and/or transmitter, depending on the range of application and the temperature class.
- When replacing the probe electronics or opening the connection between the remote cable and the probe, a jumper plug must be used or a short-circuit must be established between the probe contact and the potential equalization conductor to avoid electrostatically charging the probe.

### Safety instructions: Special conditions

Permitted ambient temperature range at the electronics enclosure:  $-40\,^{\circ}\text{C} \le T_a \le +80\,^{\circ}\text{C}$ 

- Observe the information in the temperature tables.
- In the case of process connections made of polymeric material or with polymeric coatings, avoid electrostatic charging of the plastic surfaces.
- To avoid electrostatic charging: Do not rub surfaces with a dry cloth.
- In the event of additional or alternative special varnishing on the enclosure or other metal parts or for adhesive plates:
  - Observe the danger of electrostatic charging and discharge.
  - Do not install in the vicinity of processes (≤ 0.5 m) generating strong electrostatic charges.
- Secure probes against swinging: e.g by fixing them to the wall or floor or by installing them in the ground tube.

#### Safety instructions: Installation



A0025537

- A Zone 20, Zone 21
- 1 Tank; Zone 20, Zone 21
- 2 Electronics compartment Ex ia; Electronic insert
- 3 Connection compartment Ex tb
- 4 Power supply
- 5 Potential equalization line
- 6 Potential equalization
- After aligning (rotating) the enclosure, retighten the fixing screw (see Operating Instructions).
- Install the device to exclude any mechanical damage or friction during the application. Pay particular attention to flow conditions and tank fittings.
- Only use certified cable entries or sealing plugs. The metal sealing plugs supplied meet this requirement.

- Before operation:
  - Screw in the cover all the way.
  - Tighten the securing clamp on the cover.
- After mounting and connecting the probe, ingress protection of the enclosure must be at least IP65.
- Perform the following to achieve the degree of protection:
  - Screw the cover tight.
  - Mount the cable entry correctly.
- Continuous service temperature of the connecting cable: -40 °C to  $\ge +85$  °C; in accordance with the range of service temperature taking into account additional influences of the process conditions  $(T_{a,min})$ ,  $(T_{a,max} + 20 \text{ K})$ .

Basic specification, Position 4 = N

Observe the requirements according to IEC/EN 60079-14 for conduit systems and the wiring- and installation instructions of the suitable Safety Instructions (XA). In addition, observe national regulations and standards for conduit systems.

#### Intrinsic safety

The device can be connected to the Endress+Hauser FXA291 service tool: refer to the Operating Instructions.

# Temperature tables

- → Safety Instructions: XA02258F/00
- The Safety Instructions for temperature tables are available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Manuals and Datasheets ->
- Observe the permitted temperature range at the probe.

Type: Ex Safety Instructions (XA) -> Text Search: ...

### Explanation of how to use the temperature tables

Unless otherwise indicated, the positions always refer to the basic specification.

Basic specification, Position 1, 2 = UE

1st column: Position 5 = A, B, ...

2nd column: Position 3 = A, B, ...

**■** (1): 1 channel used

• (2): 2 channels used

3rd column: Calculation of temperature values and maximum permissible ambient temperature in  ${}^{\circ}\text{C}$ 

4th column: Maximum surface temperature in °C

#### Example table

= B, C	(1)		
	E, G	$\begin{split} T &= T_a + 5 \text{ K} & T_a = 80 \\ T_{200} &= T_a + 21 \text{ K} & T_a = 64 \end{split}$	114



T<sub>a</sub>: Ambient temperature in °C

 $T_{200}$ : Deposited material with a layer of 200 mm

Basic specification, Position 1, 2 = UF

1st column: Position 5 = A, B, ...

2nd column: Position 3 = A, B, ...

(1): 1 channel used(2): 2 channels used

3rd column: Process temperature

Column P1 to P5: Position (temperature value) on the axes of the derating  $\$ 


■ T<sub>a</sub>: Ambient temperature in °C

lacktriangle  $T_p$ : Process temperature in  ${}^{\circ}$ C

# Example table

	(1)		P1		P2		P3		P4		P5	
= C			Tp	Ta	T <sub>p</sub>	Ta	Tp	Ta	T <sub>p</sub>	Ta	Tp	Ta
	E, G	135	-40	80	80	80	135	67	135	-40	-40	-40
		200	-40	80	80	80	200	51	200	-40	-40	-40

### Example diagrams of possible deratings



40033052

#### Connection data

# **Cable entry: Connection compartment**

#### Ex ta

Basic specification, Position 1, 2 = UE Cable gland: No cable gland available.

#### Ex tb

Basic specification, Position 1, 2 = UFCable gland: Basic specification, Position 6 = ABasic specification, Position 5 = B, C

### preferably for Position 5 = B

Thread Clamping range		Material	Sealing insert	O-ring	
M20x1,5	ø 7 to 12 mm	1.4404	NBR	EPDM (ø 17x2)	

# preferably for Position 5 = C

Thread	Clamping range	Material	Sealing insert	O-ring
M20x1,5	ø 8 to 10.5 mm <sup>1)</sup> (ø 6.5 to 13 mm) <sup>2)</sup>	Ms, nickel-plated	Silicone	EPDM (ø 17x2)

- 1) Standard
- 2) Separate clamping inserts available



- The tightening torque refers to cable glands installed by the manufacturer:
  - Recommended: 3.5 Nm
  - Maximum: 10 Nm
  - This value may be different depending on the type of cable. However, the maximum value must not be exceeded.
- Only suitable for fixed installation. The operator must pay attention to a suitable strain relief of the cable.
- The cable glands are suitable for a low risk of mechanical danger (4 Joule) and must be mounted in a protected position if larger impact energy levels are expected.
- To maintain the ingress protection of the enclosure: Install the enclosure cover, cable glands and blind plugs correctly.

#### Cable entry: Electronics compartment

Cable gland: Basic specification, Position 4 = M

Basic specification, Position 5 = B, C

preferably for Position 5 = B

Thread	Clamping range	Material	Sealing insert	O-ring
M16x1,5	ø 5 to 10 mm	1.4404	PA/NBR	NBR (ø 13x2)

#### preferably for Position 5 = C

Thread	Clamping range	Material	Sealing insert	O-ring	
M16x1,5	ø 5 to 10 mm	Ms, nickel-plated	PA/NBR	NBR (ø 13x2)	



- The tightening torque refers to cable glands installed by the manufacturer:
  - Recommended: 3.5 Nm
  - Maximum: 5 Nm
- This value may be different depending on the type of cable. However, the maximum value must not be exceeded.
- Only suitable for fixed installation. The operator must pay attention to a suitable strain relief of the cable.
- The cable glands are suitable for a low risk of mechanical danger (4 Joule) and must be mounted in a protected position if larger impact energy levels are expected.
- To maintain the ingress protection of the enclosure: Install the enclosure cover, cable glands and blind plugs correctly.

#### **Terminals: Connection compartment**

#### Ex ta

Basic specification, Position 3 = E, G

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)
Power supply	Switch output (PFS) 1)
$ \begin{array}{c} U_{N}=20\ V_{DC} \\ U_{m}=250\ V \end{array} $	$\begin{array}{l} U_N = 35 \ V_{DC} \\ U_m = 250 \ V \end{array}$

1) Observe "Power limitation Switch output (PFS)",  $\rightarrow$   $\stackrel{ riangle}{ riangle}$  14

#### Power limitation Switch output (PFS)

Basic specification, Position 3 = E, G

To limit the temperature rise it is necessary to limit the power consumption of the Switch output (PFS).

This is achieved by:

- using a supply voltage by consideration of Ri<sub>Fault</sub> and terminal voltage U = 19.5 V.
- using a power supply with power limitation:
  - $I_{max} = 51.3 \text{ mA} \text{ and } 19.5 \text{ V}$
  - Basic specification, Position 3 = E, G:  $U \le 35 \text{ V}$
- using an external resistor.
- lacktriangle reducing the maximum voltage at the terminals of the device depending on  $U_N$  and the channel used (by using a suitable power supply, a limiting resistor or both).
- The limiting resistor is installed outside the device and may be a load/communication resistor or a relay coil. When using it, pay attention to correct load and temperature effects.

# Table of external resistors depending on power load and supply voltage:

Power load	1.0 W
Terminal voltage U	19.5 V
I <sub>Fault</sub>	0.0513 A
Ri <sub>Fault</sub>	380.3 Ω

U <sub>N</sub> [V]	R <sub>V</sub> min
35	302 Ω
34	283 Ω
33	263 Ω
32	244 Ω
31	224 Ω
30	205 Ω
29	185 Ω
28	166 Ω
27	146 Ω
26	127 Ω
25	107 Ω
24	88 Ω
23	68 Ω
22	49 Ω
21	29 Ω
20	10 Ω
19	ΟΩ

#### Ex tb

Basic specification, Position 3 = E, G

The power consumption of I/O modules with passive PFS output can be limited for certain applications.

- Recommended: Power consumption = 1 W. This is obtained for a supply voltage at the terminals of 27 V<sub>DC</sub>.
- For higher supply voltages  $(U_{max})$ : Insert a serial resistance  $(R_V)$  in order to limit the power consumption, see table below.

# Table for the PFS serial resitance ( $R_V$ ):

Power consumption	1.0 W
Total power consumption	1.88 W
Internal resistance R <sub>I</sub>	760 Ω

U <sub>max</sub> [V]	R <sub>V</sub> min
35	205 Ω
34	177 Ω
33	150 Ω
32	122 Ω
31	95 Ω
30	67 Ω
29	39 Ω
28	12 Ω
27	0 Ω

For values associated with a higher or lower internal power consumption please contact Endress+Hauser.

Terminal 1 (+), 2 (-)	Terminal 3 (+), 4 (-)		
Power supply	Switch output (PFS)		
	$U_{N} = 35 V_{DC}$ $U_{m} = 250 V$		

### **Terminals: Electronics compartment**

#### Ex ia

### Service interface (CDI)

Taking the following values into consideration, the device can be connected to the certified Endress+Hauser FXA291 service tool or a similar interface:

#### Service interface

 $U_i = 7.3 \text{ V}$ 

effective inner inductance  $L_i$  = negligible effective inner capacitance  $C_i$  = negligible

 $U_0 = 7.3 \text{ V}$ 

 $I_0 = 100 \text{ mA}$ 

 $P_0 = 160 \text{ mW}$ 

L <sub>o</sub> (mH) =	5.00	2.00	1.00	0.50	0.20	0.15	0.10	0.05	0.02	0.01	0.005	0.002	0.001
$C_o (\mu F)^{-1} =$	0.73	1.20	1.60	2.00	2.60	-	3.20	4.00	5.50	7.30	10.00	12.70	12.70
C <sub>o</sub> (µF) <sup>2)</sup> =	-	0.49	0.90	1.40	-	2.00	-	-	-	-	-	-	-

- Values according to PTB "ispark" program
- 2) Values according to IEC/EN 60079-25, Annex C





www.addresses.endress.com