


Appendix to the operating manual




**ASP 2000
DP-Slave-Module _is Pro Gate[®]
("Profibus coupler")**

**Connecting the ASP 2000 to Profibus DP
using the serial interface and the
_is Pro Gate[®] from ifak system GmbH**

Endress+Hauser

Unser Maßstab ist die Praxis



1 General	2
1.1 <i>Transport damage</i>	2
1.2 <i>Delivery contents</i>	2
1.3 <i>Abbreviation index/phraseology explanation</i>	2
2 Installation	3
2.1 <i>Conditions</i>	3
2.2 <i>Terminations/connection diagram</i>	3
2.3 <i>System description</i>	3
2.4 <i>Block diagram</i>	3
3 Commissioning.....	4
3.1 <i>Commissioning</i>	4
3.2 <i>Control of Profibus couplers availability/status information</i>	4
3.3 <i>Set-up</i>	5
3.4 <i>Analogue input</i>	5
3.5 <i>Sampling using Profibus</i>	6
3.6 <i>Bottle position using Profibus</i>	6
3.7 <i>Relay output using Profibus</i>	6
3.8 <i>Changeover programme using Profibus</i>	7
3.9 <i>Event programme using Profibus</i>	7
3.10 <i>External Stop using Profibus</i>	7
3.11 <i>Automatic programme Start/Stop using Profibus</i>	7
4 Data transmission	7
4.1 <i>General</i>	7
4.2 <i>Data construction</i>	8
5 Connection to the Simatic S7	10
5.1 <i>Network overview</i>	10
5.2 <i>Hardware projecting</i>	10
5.2.1 Installation and preparation	10
5.2.1.1 GSD File.....	10
5.2.2 Projecting the ASP 2000 as a slave	11
5.2.3 Configuration transmission	12
5.3 <i>Programme example</i>	12
5.3.1 Address connections	12
5.3.2 Programme lines in function block.....	12
5.4 <i>Monitor measured values/status</i>	13
5.5 <i>Status codes</i>	13
6 Problem solving.....	14

1 General

1.1 Transport damage

Please inform both your local sales office as well as the transportation company

1.2 Delivery contents

- These instructions
- The DP-Slave module _is Pro Gate with our manual



- Serial connection cable for the ASP station 2000
- Diskette containing the GSD file and bitmaps

If some components are found to be missing please immediately inform your supplier!

Please take note of the following characters:

Note:  suggestions for better commissioning

Attention:  if this advice is not followed it could lead to malfunction or even damage to the unit!

1.3 Abbreviation index/phraseology explanation

Profibus coupler: The phrase **Profibus coupler** will be used instead of **_is Pro Gate**.

Profibus master: All units such as PLCs, PC cards that are used in a Profibus-DP master function are called **Profibus master** in these instructions.

2 Installation

2.1 Conditions

This option can only be used when:

- ASP 2000 software version 4.10 /Profibus coupler firmware V1.51 or newer is used
- Together with the 7 programme software



Note: The Profibus coupler is connected to the RS232 serial interface of the ASP 2000.

In order that the ASP 2000 recognises the coupler the ASP 2000 Baudrate must be set to 9600.

If the ASP 2000 interface is to be used for set-up or for a software update then the jack plug must be changed at the controller and the Baudrate matched whether in ReadWin 2000 or at the unit. Also the Profibus function must be deactivated at the controller.

2.2 Terminations/connection diagram



Note: Always leave non terminated connections free

RS232 interface:

Profibus coupler
GND
RxD
TxD

Colour Jack plug
Copper
Red
White

RS485 interface:

Profibus coupler	
3	Data B
8	Data A
5	GND

Operation power supply: 24 V DC / 100 mA

The Profibus coupler is connected to the terminal PCB in the ASP 2000.

For a connection diagram of the terminal PCB see the ASP Station 2000 operating manual.


Profibus coupler	ASP 2000 socket X2
GND	Ground (housing)
+	U+
-	Gnd

2.3 System description

The Profibus coupler is a connection between the ASP 2000 and Profibus DP, with the functionality of a DP slaves for cyclic data transmission.

Baudrates supported 45.45k, 93.75k, 187.5k, 500k, 1.5M, 3M, 6M and 12MBaud.

2.4 Block diagram



3 Commissioning

3.1 Commissioning



If the functions for a data serial interface are not accessible in the Set-up then a **one time** initialisation phase must be run.

1. Completely switch off the ASP 2000
2. Connect the Profibus coupler to the serial RS232 interface
3. Switch on the ASP 2000

From this time on the ASP 2000 controller releases the Profibus menu in the set-up. This is independent whether the Profibus coupler is connected in the future or not. Only then does this functionality appear in the ReadWin® PC software package. „ASP 0 PB“ is then displayed in the second line of the display and the Profibus coupler immediately tries to run cyclic data transfer with the PLC.




The availability of the Profibus coupler is only recognised during the commissioning of the ASP 2000. If the Profibus coupler is not recognised then a programme can be transmitted using the serial interface

or the unit can be set up. If the Profibus coupler is recognised and the unit is to be set up then the Profibus function must be deactivated.

3.2 Control of Profibus couplers availability/status information

The Profibus status can be found in the second line of the display.

Status	Meaning
ASP PB	Profibus coupler is recognised
ASP 0 PB	Profibus coupler is released and initialised
ASP <= PB ASP => PB	Der Profibus coupler is operating cyclic data transmission with the PLC (see Fig.)
ASP <> PB	The ASP 2000 has received faulty data from the Profibus coupler (BCC error). This data was not analysed.



3.3 Set-up

Once the ASP 2000 is switched on the Profibus coupler is initialised using the RS232 interface (slave address, etc.).



If one of the Profibus parameters is changed later using Set/Basic Settings/Profibus/Settings then the coupler is initialised again.

Result: The Profibus coupler removes itself from the DP-Bus, in order to call again a few seconds later. This causes a “Module failure” in the PLC. The PLC, for example the Simatic S7, goes into a STOP mode and must be manually reset into the RUN mode. It is now possible by transmitting the module failure –OBs 86 to the PLC to catch the interruption. The PLC then no longer goes into the STOP mode, all that happens is that the red LED illuminates for a short period of time and the PLC continues in the RUN mode.

The set up settings can only be changed if the initialisation phase has been operated.

Using Set/Basic Settings/Profibus/Settings the Profibus parameters slave address, Profibus baudrate und time-out can be set. The Profibus coupler is initialised new after each change to the set up. Time-out is the maximum time that the ASP 2000 will wait for an answer from the Profibus coupler.



If a Profibus coupler is recognised then the Profibus function is automatically released. With this release further parameters that enable Profibus control of the sampling cycle are also released. **If the serial interface is to be used for other functions such as programme transmission or unit set up then the Profibus function must be “deactivated“ with active = “No“, the Baudrate must then be changed to suit the selected function and the jack plug changed.** If data is only read out then the Profibus function can be released again with “Yes“ after changing the jack plug (if required reset the serial interface Baudrate (not that from Profibus!!) back to 9600). If a programme or programme data have been transmitted to the unit then the jack plug must be changed, the serial interface transmission rate reset to 9600 and the unit must be switched off and then back on in order to complete the initialisation.

3.4 Analogue input

The signal used in the ASP 2000 controller is always transmitted to the PLC and can be monitored there. It is possible to use the controller analogue input for control purposes or to transmit the analogue signal to the ASP 2000 using the Profibus. If the analogue signal is required by Profibus the option “profibus” must be set up in the parameter „analogue“ in Set/Basic Settings/Profibus/Functions.



3.5 Sampling using Profibus

In order to release a sampling sequence using Profibus the sampling mode must be set to „profibus“ in either the Quick- or Standard set-up.



If the ASP 2000 is fitted with the option flow proportional sampling then a flow proportional sampling cycle can be initiated by Profibus using the sampling mode "flow pb".



3.6 Bottle position using Profibus

In order to change bottle position using Profibus then the Distribution mode must be set to „profibus“ in either the Quick- or Standard set-up.



3.7 Relay output using Profibus

If a relay is to be activated using Profibus the respective output must be set up using the function „profibus“.



3.8 Changeover programme using Profibus

The option „profibus“ must be selected in the parameter „switch“ in the programme selection.



3.9 Event programme using Profibus

If an event programme is to be activated using Profibus, The parameter "Event" in Set/Basic Settings/Profibus/Functions must be set to the option „profibus“.



3.10 External Stop using Profibus

There are no changes to the set up of the ASP 2000 required for this function.

3.11 Automatic programme Start/Stop using Profibus

There are no changes required to the set up of the ASP 2000 required for this function.

4 Data transmission

4.1 General

The following can be transmitted or controlled by the Profibus-Master to the ASP 2000:

- Analogue value
- Relay output
- Sample cycle
- Initiation of bottle change and the bottle position
- Changeover programme
- Event programme
- External stop
- Programme start
- Programme stop

The following can be transmitted to the Profibus-Master from the ASP 2000:

- Analogue value
- Analogue value status (ok/cable open circuit)
- Actual bottle position
- Distribution tap (active/inactive)
- Sample cycle status (active/inactive)
- Overflow security (active/inactive)
- Digital input condition
- Relay output condition
- Fault and type
- Programme status (off, active, internal hold, external hold, end, end request, single hold)
- Unit status (off, on, automatic active, fault)
- Name of actual programme
- Actual sample compartment temperature
- Actual electronic compartment temperature

4.2 Data construction

Input/Output(SPS)	ASP 2000 -> Profibus-Master Input	Profibus-Master -> ASP 2000 Output
60/60 Byte	60 Byte	60 Byte

Data is exchanged from the ASP 2000 and the Profibus coupler in a cycle of 1 second.

Content of the data string is constructed in the following sequence:

From ASP 2000 to Profibus-Master:

Group	Function/value	Address (0-59)	Bytes	Bit
				MSB LSB
Status	General <ul style="list-style-type: none"> - Sampling active - Fault occurred (see fault type) - Dist. Tap moving - Main programme is active - Changeover programme is active - Event programme is active - Overflow security (bottle is full) - Fault type ⁽¹⁾ - Actual bottle position Unit status <ul style="list-style-type: none"> - Unit is switched off - Unit is switched on - Unit is in automatic mode Programme status <ul style="list-style-type: none"> - Programme is off - Programme is active - Stop in Start/Stop mode - Prog. stopped due to pause or dig input - Programme has been ended - Programme end follows - Start time has been activated - Sample compartment temperature - Upper compartment temperature 	0 0 0 0 0 0 0 3 7 8 8 8 9 9 9 9 9 9 9 10 12	1 1 1 1 1 1 1 4 1 1 1 1 1 1 1 1 1 1 1 2 2	0000000X 000000X0 00000X00 0000X000 000X0000 00X00000 0X000000 0000000X 000000X0 0000X000 0000000X 000000X0 00000X00 0000X000 000X0000 00X00000 0X000000 0000000X 000000X0 00000X00 0000000X 000000X0 00000X00
In/outputs	<ul style="list-style-type: none"> - Digital input 1 - Digital input 2 - Digital input 3 - Relay output 1 - Relay output 2 - Relay output 3 - Analogue input ⁽²⁾ (with 1Byte status see 5.5) 	16 16 16 18 18 18 20	1 1 1 1 1 1 3	0000000X 000000X0 00000X00 0000000X 000000X0 00000X00
Programme name	Name of actual programme	32	10	
BCC (XOR over all Bytes transmitted) ⁽⁰⁾		59	1	

From Profibus-Master to ASP 2000:

Group	Function/value	Address (0- 59)	Bytes	Bit
				MSB LSB
Commands	<ul style="list-style-type: none"> - Start programme (automatic cycle)⁽⁴⁾ - Stop programme (automatic cycle)⁽⁴⁾ - Start sampling⁽⁴⁾ - Start bottle change⁽⁴⁾ - Start changeover programme⁽³⁾ - Start event programme⁽³⁾ - ext. stop (stops active programme)⁽³⁾ - Bottle position for bottle change 	0 0 0 0 0 0 0 3	1 1 1 1 1 1 1 1	0000000X 000000X0 00000X00 0000X000 00X00000 00X00000 0X000000 0-7
In/outputs	<ul style="list-style-type: none"> - Relay output 1⁽³⁾ - Relay output 2⁽³⁾ - Relay output 3⁽³⁾ - Analogue input⁽²⁾ (with 1 Byte status see 5.4) 	16 16 16 18	1 1 1 3	0000000X 000000X0 00000X00
BCC (XOR over all Bytes transmitted) ⁽⁰⁾		59	1	

⁽⁰⁾ The XOR over all transmitted Bytes (except Byte 59) is necessary because there is an RS 232 connection between the Profibus coupler and the ASP 2000 and a „tilted“ Bit should not lead to a faulty operation of the water sampler. If the BCC received at the ASP 2000 does not correspond to the internally calculated BCC then the command is not initiated and „ASP <|> PB“ appears on the display!

⁽¹⁾

Fault type:

RAM error	1
Clock error	2
EEPROM error	4
Fault Conductivity sensor 1	8
Fault Conductivity sensor 2	16
Fault Air manager	32
Fault Distribution tap zero position	64
Fault Distribution missing	128
Fault Analogue open circuit	256
Fault Sample compartment temperature > 60°C	512
Fault Electronic compartment temperature > 90°C (Cable O.C.)	1024
Fault Dosing motor zero position	4096
Fault Profibus (see Ifak module operating manual)	8192
Fault Distribution must not be installed when using comp. container	16384
Fault Electronic compartment temperature > 70°C	32768
Fault Alternative switch off	65536


⁽²⁾The analogue input is transmitted as a scaled value from 0- 2000. Whereby 0 is the lower value (e.g. 4mA if the unit is set up to 4-20mA, or 0V if 0-1V has been set up).

⁽³⁾Control value must be active so long as the function is required to be active.

⁽⁴⁾Control value must only be connected as long as it takes for the status to change. The function is then active and remains so.

5 Connection to the Simatic S7

5.1 Network overview




5.2 Hardware projecting

5.2.1 Installation and preparation

5.2.1.1 GSD File

In HW Config:

- Copy the GSD- and BMP- files into the selected directory of the software STEP 7.
e.g.: c:\...\Siemens\Step7\S7data\GSD
 c:\...\Siemens\Step7\S7data\NSBMP
-




5.2.2 Projecting the ASP 2000 as a slave

In the hardware configuration:


- Extract the unit out of the hardware catalogue
-> PROFIBUS DP -> Further field units -> General
in the Profibus DP net work, distribute a user address.

Result:



Note: The projected unit address must correspond with the actual preset hardware address.

- Select the data combination (60/60) and place this on socket 0.



- The input- or output addresses for the data are listed as I-address or O-address, seen here is the hardware address 4 are the I-addresses 0...59 and O-addresses 0...59.

5.2.3 Configuration transmission

- Save and translate the configuration.
- Transmit the configuration to the controller using the menu Target system -> Load.

If the LED "BUSF" lights up after transmission of the configuration then the projected network does not correspond with the one physically available. Check the project and look for differences.

5.3 Programme example

5.3.1 Address connections

Begin the in-/output data address area:

I-address: 0
O-address: 0

ASP 2000 set up: (see section 3)

5.3.2 Programme lines in function block

```
FC1:                                // Read status

    L      EB     0          // 1 Byte collect general status
    T      MB     0          // Transfer to marker 0
    L      EB     9          // 1 Byte collect programme status
    T      MB     1          // Transfer to marker 1
    L      EB     7          // 1 Byte collect bottle position
    T      MB     2          // Transfer to marker 2
    L      EW     20         // 2 Byte collect analogue input
    T      MW     3          // Transfer to marker 3
    L      EB     22         // 1 Byte collect analogue input status
    T      MB     5          // Transfer to marker 5

FC2:                                // Control

    L      MB     6          // Command from marker 6 will be transmitted by address 0
    T      AB     0          // e.g. change bottle Bit 4 = 1
    L      MB     7          // Position, to which the distribution tap is to move.

                                         // BCC (XOR over all output Bytes except the last Byte, in
                                         // which the BCC is positioned)
    L      B#16#0
    T      MB     50         // Marker for XOR status
    L      MB     6
    L      MB     50
    XOD
    T      MB     50         // XOR
    L      MB     7
    L      MB     50
    XOD
    T      AB     59         // Write result in to the last output Byte
                           // It is taken for granted that the rest of the 60 output Bytes
                           // are 0!
```


Call functions in OB1:

```
CALL    FC1
CALL    FC2
```

5.4 Monitor measured values/status

The measured values can be read out of the markers and displayed using the variables editor. First create a new variables table and reference the respective marker addresses. Values can be written into the ASP 2000 data sets.

Example:



In this example the main programme is active and the distribution tap is moved to bottle 5. Analogue value status is OK. Programme status is programme active. The actual control value must be connected of only approx. 1 sec. Until the status changes (address 0: Bit 3 = 1).

5.5 Status codes

Status	Code	Description
Bad, Sensor failure	0x10	Sensor fault, incorrect measured value, cable open circuit
Good, ok	0x80	No sensor fault

6 Problem solving

Problem	Cause	Cure
Even though connected the Profibus coupler is not recognised when the ASP 2000 is switched on. (Hint "DP ASP" does not appear in the header):	Connection to the Profibus coupler cannot be made.	ASP 2000 serial interface transmission rate must be 9600 Baud.
	Serial connection between ASP 2000 and Profibus coupler incorrectly connected	Please check connections. Take special note of the colour coding (section 2.2).
	No 7 programme software	Upgrade
Profibus menu not available	One off initialisation phase not run.	Run one off initialisation phase.
	No 7 programme software	Upgrade
Profibus available but the Profibus parameters e.g. on sampling mode cannot be set up	Profibus not released	Release Profibus in the Profibus menu
„ASP 0 PB“ appears on the display but there is no cycle data transfer („ASP <=> PB“ on the display)	PROFIBUS master not active on the DP side.	Activate PROFIBUS master
	Baud rate does not correspond	Make sure Baudrate corresponds
	Incorrect slave address	The ASP 2000 slave address must correspond with the projected DP slave address. (< 126)



Error codes in the acknowledgeable Profibus fault messages in the ASP 2000 display are described in the operating manual of the Profibus couplers.

Additional fault:

- 0x1 Frame Error
- 0x2 No signal from the Profibus coupler

Europe

Austria

Endress+Hauser Ges.m.b.H.

Wien

Tel. ++43 (1) 88056-0, Fax (1) 88056-35

Belarus

Belorizonte

Minsk

Tel. ++375 (172) 263166, Fax (172) 263111

Belgium / Luxembourg

Endress+Hauser S.A./N.V.

Brussels

Tel. ++32 (2) 2480600, Fax (2) 2480553

Bulgaria

INTERTECH-AUTOMATION

Sofia

Tel. ++359 (2) 664869, Fax (2) 9631389

Croatia

Endress+Hauser GmbH+Co.

Zagreb

Tel. ++385 (1) 6637785, Fax (1) 6637823

Cyprus

I+G Electrical Services Co. Ltd.

Nicosia

Tel. ++357 (2) 484788, Fax (2) 484690

Czech Republic

Endress+Hauser GmbH+Co.

Praha

Tel. ++420 (26) 6784200, Fax (26) 6784179

Denmark

Endress+Hauser A/S

Søborg

Tel. ++45 (70) 131132, Fax (70) 132133

Estonia

Elvi-Aqua

Tartu

Tel. ++372 (7) 422726, Fax (7) 422727

Finland

Endress+Hauser Oy

Espoo

Tel. ++358 (9) 8596155, Fax (9) 8596055

France

Endress+Hauser

Huningue

Tel. ++33 (3) 89696768, Fax (3) 89694802

Germany

Endress+Hauser Meßtechnik GmbH+Co.

Weil am Rhein

Tel. ++49 (7621) 97501, Fax (7621) 975555

Great Britain

Endress+Hauser Ltd.

Manchester

Tel. ++44 (161) 2865000, Fax (161) 9981841

Greece

I & G Building Services Automation S.A.

Athens

Tel. ++30 (1) 9241500, Fax (1) 9221714

Hungary

Mile Ipari-Elektro

Budapest

Tel. ++36 (1) 2615535, Fax (1) 2615535

Iceland

Vatnshreinsun HF

Reykjavík

Tel. ++354 (5) 619616, Fax (5) 619617

Ireland

Floomeaco Company Ltd.

Kildare

Tel. ++353 (45) 868615, Fax (45) 868182

Italy

Endress+Hauser Italia S.p.A.

Cernusco s/N Milano

Tel. ++39 (02) 92106421, Fax (02) 92107153

Latvia

Raita Ltd.

Riga

Tel. ++371 (7) 312897, Fax (7) 312894

Lithuania

Agava Ltd.

Kaunas

Tel. ++370 (7) 202410, Fax (7) 207414

Netherlands

Endress+Hauser B.V.

Naarden

Tel. ++31 (35) 6958611, Fax (35) 6958825

Norway

Endress+Hauser A/S

Tranby
Tel. ++47 (32) 859850, Fax (32) 859851

Poland

Endress+Hauser Polska Sp. z o.o.
Warszawa
Tel. ++48 (22) 7201090, Fax (22) 7201085

Portugal

Técnis - Técnica de Sistemas Industriais
Linda-a-Velha
Tel. ++351 (1) 4172637, Fax (1) 4185278

Romania

Romconseng SRL
Bucharest
Tel. ++40 (1) 4101634, Fax (1) 4101634

Russia

Endress+Hauser Moscow Office
Moscow
Tel. ++709 (5) 1587571, Fax (5) 1589864

Slovak Republic

Transcom Technik s.r.o.
Bratislava
Tel. ++421 (74) 4888684, Fax (74) 4887112

Slovenia

Endress+Hauser D.O.O.
Ljubljana
Tel. ++386 (61) 1592217, Fax (61) 1592298

Spain

Endress+Hauser S.A.
Barcelona
Tel. ++34 (93) 4803366, Fax (93) 4733839

Sweden

Endress+Hauser AB
Sollentuna
Tel. ++46 (8) 55511600, Fax (8) 55511600

Switzerland

Endress+Hauser Metso AG
Reinach/BL 1
Tel. ++41 (61) 7157575, Fax (61) 7111650

Turkey

Intek Endüstriyel Ölçü ve Kontrol Sistemleri
İstanbul
Tel. ++90 (212) 2751355, Fax (212) 2662775

Ukraine

Industria Ukraina
Kiev
Tel. ++380 (44) 26881, Fax (44) 26908

Yugoslavia

Meris d.o.o.

Beograd

Tel. ++381 (11) 4446164, Fax (11) 4441966

Africa

Egypt

Anasia
Heliopolis/Cairo
Tel. ++20 (2) 417900, Fax (2) 417900

Morocco

Oussama S.A.
Casablanca
Tel. ++212 (2) 241338, Fax (2) 402657

Nigeria

J F Technical Invest. Nig. Ltd.
Lagos
Tel. ++234 (1) 62234546, Fax (1) 62234548

South Africa

Endress+Hauser Pty. Ltd.
Sandton
Tel. ++27 (11) 4441386, Fax (11) 4441977

Tunisia

Controle, Maintenance et Regulation
Tunis
Tel. ++216 (1) 793077, Fax (1) 788595

America

Argentina

Endress+Hauser Argentina S.A.
Buenos Aires
Tel. ++54 (1) 145227970, Fax (1) 145227909

Bolivia

Tritec S.R.L.
BOL - Cochabamba
Tel. ++591 (42) 56993, Fax (42) 50981

Brazil

Samson Endress+Hauser Ltda.
Sao Paulo
Tel. ++55 (11) 50313455, Fax (11) 50313067

Canada

Endress+Hauser Ltd.
Burlington, Ontario
Tel. ++1 (905) 6819292, Fax (905) 6819444

Chile

Endress+Hauser Chile Ltd.
Las Condes - Santiago
Tel. ++56 (2) 321 3009, Fax (2) 321 3025

Colombia

Colsein Ltd.
Bogota D.C.
Tel. ++57 (1) 2367659, Fax (1) 6107868

Costa Rica

EURO-TEC S.A.
San Jose
Tel. ++506 (2) 961542, Fax (2) 961542

Ecuador

Insetec Cia. Ltda.
Quito
Tel. ++593 (2) 269148, Fax (2) 461833

Guatemala

ACISA Automatizacion Y Control Industrial S.A.
Ciudad de Guatemala, C.A.
Tel. ++502 (3) 345985, Fax (2) 327431

Mexico

Endress+Hauser I.I.
Mexico City
Tel. ++52 (5) 568965, Fax (5) 568418

Paraguay

Incoel S.R.L.
Asuncion
Tel. ++595 (21) 213989, Fax (21) 226583

Uruguay

Circular S.A.
Montevideo
Tel. ++598 (2) 925785, Fax (2) 929151

USA

Endress+Hauser Inc.
Greenwood, Indiana
Tel. ++1 (317) 5357138, Fax (317) 5358489

Venezuela

H. Z. Instrumentos C.A.
Caracas
Tel. ++58 (2) 9440966, Fax (2) 9444554

Asia

China

Endress+Hauser Shanghai
Instrumentation Co. Ltd.
Shanghai
Tel. ++86 (21) 54902300, Fax (21) 54902303

India

Endress+Hauser Beijing Office
Beijing
Tel. ++86 (10) 68344058, Fax (10) 68344068

Indonesia

PT Grama Bazita
Jakarta
Tel. ++62 (21) 7975083, Fax (21) 7975089

Japan

Sakura Endress Co., Ltd.
Tokyo
Tel. ++81 (422) 540611, Fax (422) 550275

Malaysia

Endress+Hauser (M) Sdn. Bhd.
Petaling Jaya, Selangor Darul Ehsan
Tel. ++60 (3) 7334848, Fax (3) 7338800

Pakistan

Speedy Automation
Karachi
Tel. ++92 (21) 7722953, Fax (21) 7736884

Papua New Guinea

SBS Electrical Pty Limited
Port Moresby
Tel. ++675 (3) 251188, Fax (3) 259556

Philippines

Brenton Industries Inc.
Makati Metro Manila
Tel. ++63 (2) 6388041, Fax (2) 6388042

Singapore

Endress+Hauser (S.E.A.) Pte., Ltd.
Singapore
Tel. ++65 (5) 668222, Fax (2) 666848

South Korea

Endress+Hauser (Korea) Co., Ltd.
Seoul
Tel. ++82 (2) 6587200, Fax (2) 6592838

Taiwan

Kingjar Corporation
Taipei R.O.C.
Tel. ++868 (2) 27183938, Fax (2) 27134190

Thailand

Endress+Hauser Ltd.
Bangkok
Tel. ++66 (2) 996781120, Fax (2) 9967810

Vietnam

Tan Viet Bao Co. Ltd.
Ho Chi Minh City
Tel. ++84 (8) 8335225, Fax (8) 8335227

Iran

Telephone Technical Services Co. Ltd.
Tehran
Tel. ++98 (21) 8746750, Fax (21) 8737295

Israel

Instrumetrics Industrial Control Ltd.
Tel-Aviv
Tel. ++972 (3) 6480205, Fax (3) 6471992

Jordan

A.P. Parpas Engineering S.A.
Amman
Tel. ++962 (6) 4643246, Fax (6) 4645707

Kingdom of Saudi Arabia

Anasis
Jeddah
Tel. ++966 (2) 6710014, Fax (2) 6725929

Kuwait

Kuwait Maritime & Mercantile Co. K.S.C.
Safat
Tel. ++965 (2) 441481, Fax (2) 441486

Lebanon

Nabil Ibrahim
Jbeil
Tel. ++961 (3) 254052, Fax (9) 548038

Sultanate of Oman

Mustafa & Jawad Science & Industry Co.
L.L.C.
Ruwi
Tel. ++968 (60) 2009, Fax (60) 7066

United Arab Emirates

Descon Trading EST.
Dubai
Tel. ++971 (4) 653651, Fax (4) 653264

Yemen

Yemen Company for Ghee and Soap Industry
Taiz
Tel. ++976 (4) 230664, Fax (4) 212338

Australia + New Zealand

Australia

ALSTOM Australia Ltd.
Sydney
Tel. ++61 (2) 97224777, Fax (2) 97224888

New Zealand

EMC Industrial Group Ltd.
Auckland
Tel. ++64 (9) 4155110, Fax (9) 4155115

All other countries

Endress+Hauser GmbH+Co.
Instruments International
D-Weil am Rhein
Germany
Tel. ++49 (7621) 97502,
Fax (7621) 975345

