



BA 020D/06/en/06.98
No. 50077298
CV 4.2

Valid as of software version
02.00.XX

compart DXF 351 Flow Computer

Operating Manual



Endress+Hauser

Nothing beats know-how





Warning!

Safety Instructions

The following instructions must be carefully observed!

Correct Usage

- The Compact DXF 351 is a flow computer which combines signals from flowmeters with those from pressure, temperature and density sensors.
- The manufacturer assumes no liability for damage caused by incorrect use of the instrument. Modifications and changes to the instrument may not be carried out.
- The Compact DXF 351 flowcomputer is designed and checked according to the regulations in force EN 60950 "Safety of information technology equipment, including electrical business equipment".

A hazardous situation may occur if the flowmeter is not used for the purpose it was designed for or is used incorrectly. Please carefully note the information provided in this Operating Manual indicated by the pictograms:



Note!

Note!

A 'note' indicates actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned.



Caution!

Caution!

A 'caution' indicates actions or procedures which, if not performed correctly, may lead to personal injury or incorrect function of the instrument.



Warning!

Warning!

A 'warning' indicates actions or procedures which, if not performed correctly, may lead to personal injury, a safety hazard or destruction of the instrument.

Personnel for Installation, Start-up and Operation

- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorised by the operator of the facility. Personnel must read and understand this Operating Manual before carrying out its instructions.
- The instrument may only be operated by personnel who are authorised and trained by the operator of the facility. All instructions in this manual are to be observed.
- Ensure that the measuring system is correctly wired up according to the wiring diagrams. Protection against accidental contact is no longer assured when the housing cover is removed (danger from electric shock). The housing may only be opened by trained personnel.

Repairs

Before the flow computer is sent to Endress+Hauser for repair, a note must always be enclosed containing a description of the fault and the application.

Technical Improvements

The manufacturer reserves the right to modify technical data without prior notice. Your local E+H Sales Office will supply you with all current information and any updates to this Operating Manual.

Contents

Safety Instructions	2
1. System Description	5
2. Mounting and Installation	7
3. Electrical Connection	9
3.1 Terminal designation	9
3.2 Connecting other instruments (non-hazardous area)	10
3.3 RS 232 Interface	12
4. Operation	13
4.1 Display and Operating Elements	14
4.2 First Steps in Programming – “Quick Setup”	15
4.3 Programming with the E+H Programming Matrix	18
5. Functions	19
Function group PROCESS VARIABLE	20
Function group TOTALIZERS	22
Function group SYSTEM PARAMETERS	23
Function group DISPLAY	27
Function group SYSTEM UNITS	29
Function group FLUID DATA	34
Function group FLOW INPUT	38
Function group COMPENSATION INPUT	45
Function group PULSE OUTPUT	47
Function group CURRENT OUTPUT	50
Function group RELAYS	52
Function group COMMUNICATION	57
Function group SERVICE & ANALYSIS	60
6. Troubleshooting and Remedies	61
6.1 Instructions for troubleshooting	61
6.2 Error messages	62
7. Flow equations / Applications	67
8. Technical Data	81
8.1 Technical data: Flow computer	81
8.2 Dimensions	82
Programming at a Glance	84
Programming matrix	85
Functions, parameters, settings	86
Index	91

1. System Description

Function and Fields of Application

The Compart DXF 351 flow computer combines signals from flowmeters with those from pressure, temperature and density sensors. Using various flow equations, the computer is able to calculate variables for industrial measurement and control:

- Mass, operating volume and standard volumetric flow
- Heat flow
- Delta heat
- Combustion heat

All data required for steam and water such as saturated steam curves, density- and specific heat tables are permanently stored in the flow computer. For various other fluids, such as air, natural gas and other fuels, default data is stored and can be modified by the user according to individual process conditions. This eliminates time consuming searches in reference manuals.

Measured and calculated variables can be displayed in selected engineering units, assigned to various outputs and printed out either automatically at programmed intervals or by pressing a key (see table on page 67).




Fig. 1:
A typical application for the
flow computer

Operation

The “Quick Setup” function and the three function keys permit fast commissioning, especially for standard applications. For special applications the flow computer offers a wide range of functions which the user can individually set, thereby tailoring the unit to the process conditions (see page 13). All functions can be configured using the E+H programming matrix (see page 84).

Display

The flow computer is equipped with a two-line backlit display. Process data, error messages as well as dialogue text for programming can be displayed in three different languages: English – German – French.

Inputs and Outputs

The flow computer has configurable inputs for flowmeters as well as pressure, temperature and density transmitters. The flow input processes linear signals as well as signals from differential pressure flowmeters (with or without internal square root extraction). The flow signal can also be processed using an internal 16 point linearisation table. Measured or calculated variables are available at the outputs as current or pulse signals. In addition, the flow computer has two configurable relays which can be set to indicate limit or alarm conditions, or to supply low-frequency pulses to totalisers or process control systems.

All inputs and outputs can be configured using the E+H programming matrix:

- Input signal type
- Assignment of outputs
- Pulse output signal type
- Range scaling

The serial interface (RS 232) enables a printer to be connected for recording process data and configured parameters in the selected language.




Fig. 2:
Possible connections:
inputs and outputs

2. Mounting and Installation

The Compart DXF 351 is available in two versions:

- Panel mount housing (see Fig. 3)
- Wall mount housing (see Fig. 4)

Caution!


The instructions given in this section are to be observed at all times to ensure correct operation of the measuring system:

- There must be no vibration where the instrument is mounted.
- Observe the permissible ambient temperature (0...+50 °C) during operation.
Mount the instrument in a shaded area. Direct sunlight can be prevented by fitting a protective cover.
- Install the instrument only in a place which is clean and dry.
- Front panel protection type (panel mount housing):
To maintain protection type IP65/NEMA 4X, the unit has to be mounted with the bezel adaptor and the gasket (supplied with the mounting kit). The bezel has to be glued to the unit with silicon (see Figure below).



Procedure for mounting in a control panel (standard mounting)

- 1 Prepare the opening for the installation in the control panel (see below).
- 2 Slide the housing through the control panel cut-out from the front.
Depth of instrument = 163 mm. Reserve additional space for wiring!
- 3 Hold the instrument horizontal and slide the mounting bracket over the housing from behind until the clip snaps into the groove in the housing.
- 4 Tighten the screws until the housing of the flow computer is attached firmly to the panel control.




ba020y08

Fig. 3:
Control panel mounting




Note!

Fig. 4:
Wall mounting:
dimensions and minimum
spacing



3. Electrical Connection

3.1 Terminal designation



Terminal designation

Inputs/outputs

1.	+24 V DC supply (int. connected with terminal 8)	
2.	Pulse or voltage input (active+, passive-) * or high-range current input for split range DP transmitters. Flow input	
3.	Current input (active+, passive-) * or low-range current input for split range DP transmitters.	
4.	(-) Ground connection, 24 V DC supply	Active inputs *
5.	(+) Pt100	Pt100 or
6.	(+) Pt100	Current input 1
7.	Pt100 (-) or current input (active+, passive-) *	
8.	+24 V DC power (int. connected with terminal 1)	Current inputs
9.	(+) Pt100	Pt100 or
10.	(+) Pt100	Current input 2
11.	Pt100 (-) or current input (active+, passive-) *	
12.	(+) active or passive	Pulse output
13.	(-) active or passive	
14.	(+) Current output 1	Current outputs
15.	(+) Current output 2	
16.	(-) Ground connection	
17.	Function: Normally Open contact (NO)	Relay output 1
18.	Relay 1 wiper	
19.	Function: Normally Closed contact (NC)	
20.	Function: Normally Closed contact (NC)	Relay output 2
21.	Relay 2 wiper	
22.	Function: Normally Open contact (NO)	
23.	L1 for AC L+ for DC	Power supply
24.	N for AC L- for DC	

—— galvanic isolation

The three inputs share a common ground connection. The two current outputs also share a separate ground connection. If complete separation is required between the two current outputs, then external galvanic isolators must be used.

* *active*: Transmitter with own power supply (4-wire)
passive: Transmitter supplied by the flow computer (2-wire)

Fig. 5:
Designation of connecting
terminals
(see "Technical data", page 81
for output specifications)


3.2 Connecting other instruments (non-hazardous area)

Input → Flow	
<div><p>Flowmeter with PFM output</p><div><div><div>Dosimag</div><div>1+ 2-</div></div><div><div>Prowirl 70/77 PFM</div><div>1+ 2-</div></div><div><div>Swingwirl DV 631</div><div>1+ 4-</div></div><div><div>1 2</div><div>+ -</div></div></div><p>Switching threshold PFM = 12 mA</p><p>Note! Prowirl must be set to PFM output (→ F u 2 0: ON, PF).</p><div><div><div>Flowmeters with Open Collector outputs</div><div><div><div></div><div></div></div><div><div>Swingwirl DMV 6331</div><div>14+ 11-</div></div><div><div>Promag 30</div><div>20+ 21-</div></div><div><div>1 2</div><div>+ -</div></div></div><p>Voltage pulses: >10 mV, >100 mV, >2.5 V, $U_{max} = 50\text{ V DC}$, $I_{max} = 25\text{ mA}$ $f_{max} = 20\text{ kHz}$</p><p>Note! Set "Promag" as flow-meter and set input signal to 2.5 V digital.</p></div><div><p>Flowmeter with passive current output (4...20 mA)</p><div><div><div>Swingwirl DMV 6336</div><div>1+ 4-</div></div><div><div>Prowirl 70/77 4...20 mA</div><div>1+ 2-</div></div><div><div>Dp</div><div>+ - 3</div></div><div><div>1 2 3</div><div>+ - -</div></div></div><p>$R_{in} = 100\ \Omega$</p></div><div><p>Flowmeter with active current output (0/4...20 mA)</p><div><div><div>Deltabar</div><div>1+ 2-</div></div><div><div>Promag 30</div><div>26+ 27-</div></div><div><div>Swingwirl DMV 6331</div><div>13+ 12-</div></div><div><div>FXN 671</div><div>d12+ d14-</div></div><div><div>3 4</div><div>+ -</div></div></div><p>$U_{max} = 24\text{ V DC}$</p></div><div><p>Split range DP transmitters</p><div><div><div>H</div><div>+ -</div></div><div><div>L</div><div>+ -</div></div><div><div>1 2 3</div><div>+ - -</div></div><p>passive current output</p><div><div>H</div><div>+ -</div></div><div><div>L</div><div>+ -</div></div><div><div>2 3 4</div><div>+ - -</div></div><p>active current output</p><p>H = High-range DP transmitter L = Low-range DP transmitter</p><p>passive: $R_{in} = 100\ \Omega$ active: $U_{max} = 24\text{ V DC}$</p></div></div></div></div>	
Compensation Input 1 → Temperature	
<div><p>Temperature signal at input 1 (active/passive)</p><div><div><div><div>RTD PT 100 3-wire *</div><div><div>5 6 7</div><div>+ - -</div></div></div><div><div>current input active signal</div><div><div>4 7</div><div>- +</div></div></div><div><div>current input passive signal</div><div><div>7 8</div><div>- +</div></div></div></div><p>$U_{max} = 24\text{ V DC}$ $R_{in} = 100\ \Omega$</p><p>* 2-wire RTD connection is possible but causes an additional inaccuracy.</p></div><div></div></div>	

Compensation Input 2 → Temperature 2, pressure or density	
<p>Temperature, pressure or density signal at input 2 (active/passive)</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>RTD PT 100 3-wire</p> </div> <div style="text-align: center;"> <p>current input active signal</p> </div> <div style="text-align: center;"> <p>current input passive signal</p> </div> </div> <p>Cerabar or Omnigrad at input 2 (passive)</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Cerabar</p> </div> <div style="text-align: center;"> <p>PT 100, 3-wire *</p> </div> </div>	<p>$U_{\max} = 24 \text{ V DC}$ $R_{\text{in}} = 100 \Omega$</p> <p>$U_{\max} = 24 \text{ V DC}$ $R_{\text{in}} = 100 \Omega$</p> <p>* 2-wire RTD connection is possible but causes an additional inaccuracy.</p>
Outputs	
<p>Pulse output</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>passive</p> </div> <div style="text-align: center;"> <p>active</p> </div> </div> <p>Current output 1 / 2</p> <p>Relay output 1 / 2 (de-energized)</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> </div> <p>Power supply connection</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>AC</p> </div> <div style="text-align: center;"> <p>DC</p> </div> </div>	<p>Active: internal power supply = +24 V DC $I_{\max} = 15 \text{ mA}$, $R_{\text{Lmax}} = 960 \Omega$</p> <p>Passive: external power supply $U_{\max} = 30 \text{ V}$, $I_{\max} = 25 \text{ mA}$</p> <p>0/4...20 mA common ground Load: max. 1 kΩ</p> <p>Max. load = 240 V (1 A · cos ϕ · 0.7)</p> <p>85...260 V AC (50/60 Hz) 20... 55 V AC (50/60 Hz) 16... 62 V DC</p>

3.3 RS 232 Interface

The flow computer can be connected either directly to a personal computer (PC) or to a printer via the serial RS 232 interface.





4. Operation

Important Information for Operating the Instrument

- The flow computer offers a wide range of functions and features. The following sections *must* be read carefully prior to operation.
- Start configuration using the “Quick Setup” function. This enables the flow computer to be quickly configured for its *initial* start-up in a short time.
- For further configuration (for example current- and pulse outputs), enter the E+H programming matrix.


Caution!

Note that the 'Quick Setup' will change all parameters in other functions of the E+H programming matrix to default values. Values previously programmed by the user will be overwritten or deleted!




Display and operating elements

page 14




“QUICK SETUP”
Start the configuration

page 15



Detailed configuration with the
“E+H programming matrix”

page 18




Description of functions

page 19



Selections / Factory settings
at a glance

page 86



Flow equations / applications

page 67

4.1 Display and Operating Elements




Fig. 7:
Display and operating elements

4.2 First Steps in Programming – “Quick Setup”

The Compart DXF 351 flow computer makes programming easier and quicker using the three functions keys F1, F2, F3. This is important for *simple* standard applications where only a few functions are to be configured. For more complex applications additional functions need to be configured. These can be selected using the E+H programming matrix (see page 84).


Caution!

All configuration data will be reset to factory defaults when starting the quick setup function. Reprogramming of the function keys F1–F3 at the end of the “Quick Setup” is strongly recommended.



F1 key

Factory setting: “LANGUAGE”



Select the required language in which the dialogue text is to appear on the display:


ENGLISH
DEUTSCH
FRANCAIS



Store entry, automatic return to the HOME position

F2 key

Factory setting: “UNITS” *



Select the required system of units:

ENGLISH
METRIC

(All units are therefore set to defaults of the selected system)




Store entry, automatic return to the HOME position

* This function can only be called up using the function key and not with the E+H programming matrix).

F3 key

Factory setting: “QUICK SETUP”



The display will show the prompt:
QUICK SETUP? NO
PAUSE COMPUTATIONS *

Warning message *

During ‘Quick Setup’, all flow calculations are stopped, the current outputs return to 0 mA, the pulse output stops and both relays de-energise (corresponding to a power failure).



Select ‘QUICK SETUP? YES’



Confirm entry. The display automatically shows the first function: “FLOW EQUATION”



Select the required flow equation, e.g. ‘STEAM MASS’.



Store selection.

Subsequent functions appearing on the display depend on the flow equation selected.



Enter numerical values or settings.





Store entry (automatic return to the HOME position after the last function).


Quick Programming Menu “Quick Setup”

using ‘STEAM MASS’ as an example flow equation
and ‘PROWIRL’ (vortex) as an example flowmeter.

Procedure:

Press Function Key F3. The display will show “QUICK SETUP? NO”.

Select ‘YES’ by pressing  and then  to confirm entry. All flow equations are stopped and the configuration parameters reset to default value.

Continue with  :



Note!

FLOW EQUATION

The basic *functionality* of the Compart DXF 351 flowcomputer is defined using the flow equation for your particular application.

Note!

- In this example STEAM MASS is selected as flow equation.
- For flow equation selections see page 24.

FLUID TYPE

Select the fluid type:



SATURATED STEAM – SUPERHEATED STEAM

‘Quick Setup’ configures only *one* compensation input if “SATURATED STEAM” is selected (Input 2, pressure). The temperature is not measured but calculated using the pressure input and the steam tables (saturated steam curve).

Note!

- In this example ‘SUPERHEATED STEAM’ is selected as fluid.
- For more fluid selections see page 34



Note!

FLOWMETER TYPE

Select the flowmeter for your application.

Note!

- In this example ‘Prowirl’ (vortex) is selected as flowmeter type.
- For meter selections see page 38.
- Selections: ORIFICE, NOZZLE and PITOT with 16 point linearization are not available in the Quick Setup. For these selections go to ‘Flowmeter selection’ cell in the matrix (page 38).



Note!

INPUT SIGNAL (Flow)

Enter the type of measuring signal supplied by the flowmeter.

Note!

- PFM signal is used as an example selection.
- For signal selections see page 39.



Note!

K-FACTOR

Enter the flowmeter K-Factor. The K-factor describes how many vortices (pulses per dm^3) occur as a function of the flow velocity and nominal diameter.

This K-factor definition refers to vortex flowmeters. For other flowmeters see page 40.



Number with floating decimal point:
0.001...999999; incl. units [P/dm^3]

(continued next page)

Quick Programming Menu “Quick Setup”

(continued)

INPUT SIGNAL (Temperature)	<p>Select the type of signal coming from the temperature sensor. This function is only displayed if a temperature input is used.</p> <div><div><div>+</div><div>-</div></div><div>4-20 TEMPERATURE – 0-20 TEMPERATURE – MANUAL TEMPERATURE * – RTD TEMPERATURE</div></div> <p>* see page 46 for details</p>
LOW SCALE VALUE (Temperature)	<p>Assign the low scale temperature value to the 0/4 mA current signal.</p> <p>This function is displayed only with the following configuration: Function “INPUT SIGNAL” → Setting ‘4-20 TEMPERATURE’ or ‘0-20 TEMPERATURE’.</p> <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point (minimum 20 K or equivalent)</div></div>
FULL SCALE VALUE (Temperature)	<p>Assign the full-scale temperature value to the 20 mA current signal. This function is displayed only if the setting ‘4-20 TEMPERATURE’ or ‘0-20 TEMPERATURE’ is selected in the function “INPUT SIGNAL”.</p> <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point (minimum 20 K or equivalent)</div></div>
INPUT SIGNAL (Pressure)	<p>Select the type of signal coming from the pressure sensor.</p> <div><div><div>+</div><div>-</div></div><div>4-20 PRESSURE (G) – 0-20 PRESSURE (G) – MANUAL PRESSURE * – 4-20 PRESSURE (ABS.) – 0-20 PRESSURE (ABS.)</div></div> <p>* see page 46 for details</p>
FULL SCALE VALUE (Pressure)	<p>Assign the full-scale pressure value to the 20 mA current. This function is not displayed if the setting ‘INPUT 2 NOT USED’ or ‘MANUAL PRESSURE’ is selected in the function “INPUT SIGNAL”.</p> <p>Note! ‘Quick Setup’ automatically sets the starting pressure value to 0.000.</p> <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point: 0...+10000 (incl. pressure units)</div></div>
F1 Key Function	<p>On the front panel are three function keys F1, F2, F3 which can be assigned to various functions as required. Functions often used can be called up immediately without the need to enter the matrix.</p> <p>Note!</p> <ul style="list-style-type: none">• The assigned functions are not protected by code entry.• Starting the Quick Setup function will overwrite or delete all previously configured data. For this reason, immediately after using Quick Setup, assign another function to the „Quick Setup“ function key.• For selections: see page 25
F2 Key Function	
F3 Key Function	
<p>After the entry has been saved in the last function with <div><div>E</div></div>, it automatically returns to the HOME position. The ‘Quick Setup’ programming is completed and the flow computations are resumed.</p>	



Note!



Note!

4.3 Programming with the E+H Programming Matrix

The Compart DXF 351 flow computer offers many functions – beyond the 'Quick Setup' – that can be individually set up and adapted to specific process conditions. The E+H programming matrix guides the user through the functions.

F1

F2

F3

E

4

1

Function groups

Functions

2

3

E

E

E

E

E

E

Access to the programming matrix (>GROUP SELECT<)

Select individual functions within the function group

Store the data or settings

Leave the programming matrix

Store the data or settings

Select various function groups

Select parameters and numerical values (when + or – key is held down, the number on the display will change at increasing speed)

Diagnostic function

Help function
Displays additional information during programming

Enable / Lock programming

• Enable: Enter the code number (Factory setting = '351')

• Lock: After returning to the HOME position, programming is locked after 60 seconds if no operating element is pressed.

Fig. 8:
Selecting functions within the E+H programming matrix

18


Endress+Hauser

5. Functions

This section lists in detail a description, as well as all information required for the individual functions of the flow computer. Factory settings are shown in ***bold italics***.

Function groups	{	PROCESS VARIABLE	→	page 20
		TOTALIZERS	→	page 22
		SYSTEM PARAMETERS	→	page 23
		DISPLAY	→	page 27
		SYSTEM UNITS	→	page 29
		FLUID DATA	→	page 34
		FLOW INPUT	→	page 38
		COMPENSATION INPUT	→	page 45
		PULSE OUTPUT	→	page 47
		CURRENT OUTPUT	→	page 50
		RELAYS	→	page 52
		COMMUNICATION	→	page 57
		SERVICE & ANALYSIS	→	page 60

Caution! Important when programming



Caution!

- The selected flow equation affects almost all functions of the flow computer! It is important to select the flow equation before setting other parameters. For this we recommend you use the 'Quick Setup' function. Thoroughly read the appropriate description and instructions given on page 23.
- Depending on previous selections, some functions or options may not appear on the display:

Example 1:

The flow equation is set to 'LIQ. CORRECTED VOLUME'. Therefore in the function group "PROCESS VARIABLE" only the following functions appear on the display: COR. VOLUME FLOW, VOLUME FLOW, TEMPERATURE, PROCESS PRESSURE, DATE & TIME.

Example 2:

The relay mode is set to 'RELAY PULSE OUTPUT'. Consequently irrelevant functions such as "LIMIT SETPOINT", "HYSTERESIS" and "RESET ALARM" are not shown.

- While programming certain parameters and functions, flow computations are paused. The flow computer changes to 'standby' mode after displaying the following safety prompt:

"FLOW COMPUTATIONS PAUSED NO" → Select 'YES', and confirm by pressing **E** → The message "FLOW COMPUTATIONS RESUMED" is then shown.

All flow calculations are then stopped, the current outputs return to 0 mA, the pulse output stops and both relays de-energise (corresponding to a power failure). Parameters can now be changed and numerical values entered. After returning to the HOME position flow computations resume.
The message "FLOW COMPUTATIONS RESUMED" is displayed.



Note!



Note!



Note!



Note!

Function group PROCESS VARIABLE	
<p>With this group of functions, actual process variables such as flowrate, temperature, pressure or dependent variables can be directly read off the display.</p> <p>Note!</p> <ul style="list-style-type: none"> • A selection of the following functions are available corresponding to the selected flow equation (see page 24), flowmeter (see page 38) and fluid (see page 34). • The maximum numerical display is 999 999; larger values are displayed as 'INF'. 	
HEAT FLOW	Display of current calculated energy flow (heat, combustion heat). The heat flow is determined using the stored fluid properties and the actual volumetric flow, including a temperature or pressure compensation.
MASS FLOW	Display of current calculated mass flowrate. The mass flowrate is determined using the stored fluid properties and the actual volumetric flow, including a temperature or pressure compensation.
COR. VOLUME FLOW	<p>Display of corrected volumetric flowrate of liquids and gases (→ see section "GAS CORRECTED VOLUME", page 72 and "LIQ. CORRECTED VOLUME", page 75).</p> <p><i>Corrected volume</i> = Volume under reference conditions, e.g. at 0 °C and 1.013 bar abs. Reference temperature T_{ref} and reference pressure p_{ref} can be freely selected (see function "STP REFERENCE", page 46).</p>
VOLUME FLOW	<p>Display of actual volumetric (uncorrected) flowrate measured by the sensor under operating conditions. With differential pressure measurement devices the volumetric flowrate is calculated using a temperature or pressure compensation.</p> <p>Note!</p> <p>This function is always available and is not dependent on the flow equation selected.</p>
TEMPERATURE 1	<p>Display of process temperature used for calculations.</p> <p>Note!</p> <ul style="list-style-type: none"> • Normally the value shown is the measuring signal from the temperature sensor connected to analogue input 1. • With saturated steam the temperature shown is calculated from the saturated steam curve if measurement is <i>only</i> carried out using a pressure sensor. • If the flow computer uses fixed temperature values which have been pre-programmed, then these values will be shown here (see function "DEFAULT VALUE", page 46).
TEMPERATURE 2	<p>Display of process temperature from a <i>second</i> temperature sensor, e.g. for calculating delta heat.</p> <p>Note!</p> <ul style="list-style-type: none"> • Normally the value shown is the measuring signal from the temperature sensor connected to analogue input 2. • If the flow computer uses fixed temperature values which have been pre-programmed, then these values will be shown here (see function "DEFAULT VALUE", page 46).

Function group PROCESS VARIABLE	
DELTA TEMPERATURE	<p>Display of the temperature difference between Temperature 1 and Temperature 2.</p> <p>Note! This function is only shown with 'delta heat' flow equations.</p>
PROCESS PRESSURE	<p>Display of the process pressure used for the calculation.</p> <p>Note!</p> <ul style="list-style-type: none"> • Normally the value shown is the measuring signal from the pressure sensor connected to other input 2. • With saturated steam the pressure shown is calculated from the saturated steam curve if measurement is <i>only</i> carried out using a temperature sensor. • If the flow computer uses fixed pressure values which have been pre-programmed, then these values will be shown here (see function "DEFAULT VALUE", page 46).
DIFF. PRESSURE	<p>Display of the pressure drop measured by a differential pressure flowmeter, e.g. with the E+H 'Deltabar S'.</p> <p>ENGLISH units → units always in [inch H₂O] METRIC units → units always in [mbar]</p>
DENSITY	<p>Display of the fluid density. The density is either directly measured using a density sensor or calculated from measured process pressure and/or temperature values, using stored fluid data.</p>
SPEC. ENTHALPY	<p>Display of the specific enthalpy of steam. The value shown is determined from steam tables using the measured process variables of pressure and temperature.</p> <p>Note! This function is only shown with thermal steam flow equations.</p>
DATE & TIME	<p>Display of the actual date and time. The real time clock can be set in the functions "ENTER DATE" and "ENTER TIME" (see page 24).</p> <p>Note!</p> <ul style="list-style-type: none"> • After short breaks in the power supply the clock continues to operate normally. • After longer breaks in the power supply (several days) or with initial start-up of the instrument the date and time must be reset.
VISCOSITY	<p>Display of the fluid viscosity in units of centistokes. The viscosity is calculated from measured process temperature using stored fluid data and equations.</p> <p>Note! This function is only shown with DP-flowmeters with 16 point linearisation table and needed for calculating the Reynolds number.</p>
REYNOLDS NUMBER	<p>Display of the calculated Reynolds number under actual process conditions.</p> <p>Note! This function is only shown with DP-flowmeters with 16 point linearisation table</p>



Note!



Note!



Note!



Note!



Note!



Note!



Note!





Note!



Note!

Function group TOTALIZERS	
Note! <ul style="list-style-type: none"> • A selection of the following functions are available corresponding to the selected flow equation (see function "FLOW EQUATION", page 24) • The totaliser contents are saved in the EEPROM on power loss. • Grand totals cannot be reset. 	
RESET TOTALIZER	This function resets all resettable totalisers simultaneously to 'zero'. Note! Grand totals cannot be reset. <div> <div>+</div> <div>-</div> </div> NO – YES
HEAT TOTAL	Display of total energy (heat quantity, combustion heat) since the last reset of the totaliser.
HEAT GRAND TOTAL	Display of total energy (heat quantity, combustion heat) since initial start-up.
MASS TOTAL	Display of the total mass since the last reset of the totaliser.
MASS GRAND TOTAL	Display of total mass since initial start-up.
COR. VOLUME TOTAL	Display of the total corrected volume since the last reset of the totaliser.
COR. VOL. GRND TOT.	Display of total corrected volume since initial start-up.
VOLUME TOTAL	Display of the total uncorrected volume under operating conditions since the last reset of the totaliser. Note! This function is always accessible independent of the flow equation selected (see page 24).
VOL. GRAND TOTAL	Display of the total uncorrected volume under operating conditions since initial start-up.

Function group SYSTEM PARAMETERS	
QUICK SETUP	<p>The 'Quick Setup' function allows fast configuration of all important parameters and process functions. The F3 function key is set at the factory so that the "Quick-Setup" can be directly activated.</p> <p>Caution!</p> <ul style="list-style-type: none">• A "QUICK-SETUP" automatically sets all parameters except 'language' (F1) and 'unit system' (F2), back to their default values.• To avoid unintentional loss of configuration data the F3 function key should be assigned another function as offered at the end of "Quick-Setup".• For more detailed information on the "Quick Setup" → see page 15 <div><div><div>+</div><div>-</div></div><div><div>QUICK SETUP? NO</div><div>PAUSE COMPUTATIONS *</div></div><div><div>QUICK SETUP? YES</div><div>PAUSE COMPUTATIONS *</div></div></div> <p>Option 'YES' → INITIALIZING MEMORY ** PLEASE WAIT</p> <p>The various functions are shown one after another. Select option with , enter numerical value and store with .</p> <p>* Warning message "PAUSE COMPUTATIONS": All calculations are then stopped, the current outputs return to 0 mA, the pulse output stops and both relays de-energise (corresponding to a power failure).</p> <p>** All parameters are reset to their default values.</p>





Note!



Caution!






Note!



Note!












Function group SYSTEM PARAMETERS	
FLOW EQUATION	<p>The <i>Basic functionality</i> of the Compart DXF 351 flow computer is defined using the flow equation for <i>your</i> particular application!</p> <p>Note! Various functions of the E+H programming matrix (see page 85) are only available depending on the flow equation selected. The flow equation also determines the assignment of flow computer inputs.</p> <p>Caution!</p> <ul style="list-style-type: none">• Select the flow equation as the first step. You should use 'Quick Setup' to change the flow equation.• Detailed descriptions to the individual flow equations and applications are found on page 67. <div><div><div>+</div><div>-</div></div><p>STEAM MASS – STEAM HEAT – STEAM NET HEAT – STEAM DELTA HEAT – GAS CORRECTED VOLUME – GAS MASS – GAS COMBUSTION HEAT – LIQ. CORRECTED VOLUME – LIQUID MASS – LIQ. COMBUSTION HEAT – LIQUID SENSIBLE HEAT – LIQUID DELTA HEAT</p></div>
ENTER DATE	<p>Enter the actual date: <i>Day – Month – Year</i>. An integrated clock in the flow computer changes the date accordingly.</p> <p>Note! After prolonged breaks in the power supply (several days) or with initial start-up of the instrument the date and time must be reset.</p> <div><div><div>+</div><div>-</div></div><p>Flashing positions can be changed. Confirm entries with E.</p></div>
ENTER TIME	<p>Entering the actual time: <i>Hours – Minutes</i></p> <p>Note! After prolonged breaks in the power supply (several days) or with initial start-up of the instrument, the date and time must be reset.</p> <div><div><div>+</div><div>-</div></div><p>Flashing positions can be changed. Confirm entries with E.</p></div>
















Function group SYSTEM PARAMETERS																							
F1 KEY FUNCTION	On the front panel are three function keys F1, F2 and F3 which can be assigned various functions as required. Functions often used can be called up immediately <i>without</i> the need to enter the programming matrix.																						
F2 KEY FUNCTION	Note! The function keys are not protected by a code number (see function "ACCESS CODE", page 26), so the functions assigned to them are freely accessible.																						
F3 KEY FUNCTION	<div style="text-align: center;">  Note! </div> <div style="margin-top: 20px;">  </div> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="vertical-align: top;">LANGUAGE *</td><td>Define language (see page 28) * available with F1 key only</td></tr> <tr> <td style="vertical-align: top;">MEASURING SYSTEM **</td><td>Define system units ** available with F2 key only</td></tr> <tr> <td style="vertical-align: top;">QUICK SETUP ***</td><td>Start quick programming menu (see page 15), *** available with F3 key only</td></tr> <tr> <td style="vertical-align: top;">RATE + TOTAL</td><td>Display of flowrate and totaliser</td></tr> <tr> <td style="vertical-align: top;">TOTAL + GRAND TOTAL</td><td>Display of totaliser and grand total</td></tr> <tr> <td style="vertical-align: top;">CLEAR TOTALIZERS</td><td>Reset totaliser to zero</td></tr> <tr> <td style="vertical-align: top;">PRINT TRANSACTION</td><td>Start printout (see page 60)</td></tr> <tr> <td style="vertical-align: top;">ACK. + CLEAR ALARMS</td><td>Confirm alarm message (see page 56)</td></tr> <tr> <td style="vertical-align: top;">CHANGE SETPOINT 1</td><td>Define switchpoint Relay 1 (see page 53)</td></tr> <tr> <td style="vertical-align: top;">CHANGE SETPOINT 2</td><td>Define switchpoint Relay 2 (see page 53)</td></tr> <tr> <td style="vertical-align: top;"> TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP. 2 DELTA TEMP. + VOL.FLOW DIFF.PRES. + VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS </td><td style="vertical-align: middle;">) Display of process variables </td></tr> </table>	LANGUAGE *	Define language (see page 28) * available with F1 key only	MEASURING SYSTEM **	Define system units ** available with F2 key only	QUICK SETUP ***	Start quick programming menu (see page 15), *** available with F3 key only	RATE + TOTAL	Display of flowrate and totaliser	TOTAL + GRAND TOTAL	Display of totaliser and grand total	CLEAR TOTALIZERS	Reset totaliser to zero	PRINT TRANSACTION	Start printout (see page 60)	ACK. + CLEAR ALARMS	Confirm alarm message (see page 56)	CHANGE SETPOINT 1	Define switchpoint Relay 1 (see page 53)	CHANGE SETPOINT 2	Define switchpoint Relay 2 (see page 53)	TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP. 2 DELTA TEMP. + VOL.FLOW DIFF.PRES. + VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS) Display of process variables
LANGUAGE *	Define language (see page 28) * available with F1 key only																						
MEASURING SYSTEM **	Define system units ** available with F2 key only																						
QUICK SETUP ***	Start quick programming menu (see page 15), *** available with F3 key only																						
RATE + TOTAL	Display of flowrate and totaliser																						
TOTAL + GRAND TOTAL	Display of totaliser and grand total																						
CLEAR TOTALIZERS	Reset totaliser to zero																						
PRINT TRANSACTION	Start printout (see page 60)																						
ACK. + CLEAR ALARMS	Confirm alarm message (see page 56)																						
CHANGE SETPOINT 1	Define switchpoint Relay 1 (see page 53)																						
CHANGE SETPOINT 2	Define switchpoint Relay 2 (see page 53)																						
TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP. 2 DELTA TEMP. + VOL.FLOW DIFF.PRES. + VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS) Display of process variables																						
PRIVATE CODE	A personal code number can be selected in order to enable programming. Note! <ul style="list-style-type: none"> Changing the code number is only possible after programming has been enabled. If the programming is locked then this function is not available and access to the personal code number is denied to other persons. Selecting a private code number of '0' will always enable programming. The functions assigned to keys F1, F2 and F3 are freely accessible. <div style="margin-top: 20px;">  max. 4-figure number: 0...9999 Factory setting: 351 </div>																						



Note!









Function group SYSTEM PARAMETERS	
ACCESS CODE	<p>All the data in the flow computer is protected against unauthorised access. Programming is enabled by entering the “Private code number” in this function. The settings of the instrument can then be altered. If the  keys are pressed in any function, then this function is automatically called up and the prompt to enter the code number is shown on the display (with locked programming only):</p> <p>➔ Enter code number 351 (Factory setting) or if redefined by user, ➔ Enter personal code number (see page 25, “PRIVATE CODE”)</p> <p>Note!</p> <ul style="list-style-type: none">• Locking programming: After returning to the HOME position, programming is automatically locked after 60 seconds if no keys are pressed. Programming can also be locked by entering any number (except the code number).• If you can no longer find your personal code number, then the Endress+Hauser service organisation will be pleased to help you.• The function keys F1, F2 and F3 are freely accessible without entering a code number. <p> max. 4-figure number: 0...9999  Factory setting: 0</p>
TAG NUMBER	<p>A freely selectable tag for your measuring point can be entered (max. 10 characters).</p> <p> Alphanumeric character for each of the ten positions: 1, 2, ...,9; A, B,Z; , <, =, > ?, etc.</p> <p>Flashing positions can be changed. Confirm entry with  and with an automatic jump to the next position (altogether 10). Spaces are also considered characters and are to be confirmed by pressing .</p>
SERIAL-NO. SENSOR	<p>The serial number or tag number of the connected flowmeter can be entered (max. 10 characters).</p> <p> Alphanumeric characters for each of the ten positions: 1, 2, ...,9; A, B,Z; , <, =, > ?, etc.</p> <p>Flashing positions can be changed. Confirm entry with  and with an automatic jump to the next position (altogether 10). Spaces are also considered characters and are to be confirmed by pressing .</p>

Function group DISPLAY																											
DISPLAY LIST	<p>Selecting those variables which are to appear on the display in the 'HOME position' during normal operation. Each option shows two variables simultaneously (→ see following list). If more than one option is selected, then each option appears on the display one after the other for 3 to 4 seconds each.</p> <p> CHANGE? NO  CHANGE? YES</p> <p>'YES' → display of measured values tube indicated:</p> <table> <tr> <td></td><td> </td></tr> <tr> <td>Save option → next option</td><td>Display?</td></tr> </table> <table> <tr><td>DATE + TIME?</td><td>NO (YES)</td></tr> <tr><td>MASS FLOW + TOTAL?</td><td>NO (YES)</td></tr> <tr><td>VOL.FLOW + TOTAL?</td><td>NO (YES)</td></tr> <tr><td>TEMP.1 + PRESSURE?</td><td>NO (YES)</td></tr> <tr><td>TEMP.1 + DENSITY?</td><td>NO (YES)</td></tr> <tr><td>HEAT FLOW + TOTAL?</td><td>NO (YES)</td></tr> <tr><td>DENS. + SPEC.ENTH?</td><td>NO (YES)</td></tr> <tr><td>COR.VOL. + TOTAL?</td><td>NO (YES)</td></tr> <tr><td>TEMP.1 + TEMP.2?</td><td>NO (YES)</td></tr> <tr><td>DELTA T + VOL. FLOW?</td><td>NO (YES)</td></tr> <tr><td>VISC. + REYNOLDS NO.</td><td>NO (YES)</td></tr> </table> <p>'YES' +  → Both variables are shown on the display. 'NO' +  → The variables do not appear on the display.</p> <p>There is an automatic jump to the next function after the last option is selected.</p>		 	Save option → next option	Display?	DATE + TIME?	NO (YES)	MASS FLOW + TOTAL?	NO (YES)	VOL.FLOW + TOTAL?	NO (YES)	TEMP.1 + PRESSURE?	NO (YES)	TEMP.1 + DENSITY?	NO (YES)	HEAT FLOW + TOTAL?	NO (YES)	DENS. + SPEC.ENTH?	NO (YES)	COR.VOL. + TOTAL?	NO (YES)	TEMP.1 + TEMP.2?	NO (YES)	DELTA T + VOL. FLOW?	NO (YES)	VISC. + REYNOLDS NO.	NO (YES)
	 																										
Save option → next option	Display?																										
DATE + TIME?	NO (YES)																										
MASS FLOW + TOTAL?	NO (YES)																										
VOL.FLOW + TOTAL?	NO (YES)																										
TEMP.1 + PRESSURE?	NO (YES)																										
TEMP.1 + DENSITY?	NO (YES)																										
HEAT FLOW + TOTAL?	NO (YES)																										
DENS. + SPEC.ENTH?	NO (YES)																										
COR.VOL. + TOTAL?	NO (YES)																										
TEMP.1 + TEMP.2?	NO (YES)																										
DELTA T + VOL. FLOW?	NO (YES)																										
VISC. + REYNOLDS NO.	NO (YES)																										
DISPLAY DAMPING	<p>By entering a 'damping constant' the display bounce can be reduced (high constant) or increased (low constant). This ensures that reading off measured values can still be carried out even with quickly changing process conditions (reading off the 'mean value').</p> <p> max. 2-figure number: 0...99  Factory setting: 1</p>																										



Function group DISPLAY	
LCD CONTRAST	<p>The contrast of the display can be adjusted to local operating conditions e.g. ambient temperature and lighting conditions.</p> <p>Caution! Note that the permissible ambient temperature for the flow computer is 0...+50 °C. The visibility of the LC display may no longer be guaranteed for temperatures below 0 °C.</p> <div><div><div>+</div><div>-</div></div><div><div>■■■■■■■■■■</div><div>.....</div></div><div>A change in contrast can immediately be seen with the bar display.</div></div>
MAX. DEC. POINT	<p>Determine the number of decimal places for numerical values.</p> <p>Note!</p> <ul style="list-style-type: none">• The number of decimal places applies to all displayed variables and totalisers.• The number of decimal places is automatically reduced if there is insufficient space on the display for large numbers.• The value set here does not affect the functions in the E+H programming matrix. <div><div><div>+</div><div>-</div></div><div>0 – 1 – 2 – 3 (decimal places)</div></div>
LANGUAGE	<p>The language can be selected in which all text, parameters and operating messages are to be displayed.</p> <div><div><div>+</div><div>-</div></div><div>ENGLISH – DEUTSCH – FRANCAIS</div></div>

Function group SYSTEM UNITS	
Definitions of common system units: bbl 1 barrel (Defintion → see function "DEFINITION bbl", page 32) gal 1 US Gallon (equals 3.7854 liters) igal 1 Imperial Gallon (equals 4.5609 liters) l 1 liter hl 1 hectoliter = 100 liters dm ³ 1 dm ³ = 1 liter ft ³ 1 ft ³ = 28.37 liters m ³ 1 m ³ = 1000 liters acf Actual cubic foot (equals 'ft ³ ' under operating conditions) scf Standard cubic foot (equals 'ft ³ ' under reference conditions) Nm ³ Standard cubic meter (equals 'm ³ ' under reference conditions) NI Standard liter (equals one liter under reference conditions) tons (US) 1 US ton, equals 2000 lbs (= 907.2 kg) tons (long) 1 long ton, equals 2240 lbs (= 1016 kg) tons 1 tons, equals 200 Btu/min tonh 1 tonh, equals 1200 Btu	
TIME BASE	<p>One unit of time is selected as a reference for all measured or derived and time-dependent process variables and functions such as:</p> <ul style="list-style-type: none"> • flowrate (volume/time; mass/time), • heat flow (amount of energy/time) etc. <p>  /s (per second) – /m (per minute) – /h (per hour) –  /d (per day) </p>
HEAT FLOW UNIT	<p>Select the unit for heat flow (amount of energy, combustion heat). The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Full-scale value for current • Relay switchpoints <p>  kBtu/unit of time – kW – MJ/unit of time – kcal/unit of time –  MW – tons – GJ/unit of time – Mcal/unit of time – Gcal/unit of time – MBtu/unit of time – GBtu/unit of time </p>
HEAT TOTAL UNIT	<p>Select the unit of heat (amount of energy, combustion heat) for the particular totaliser. The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Pulse value (kCal → kCal/p) • Relay switchpoints <p>  kBtu – kWh – MJ – kcal – MWh – tonh – GJ – Mcal –  Gcal – MBtu – GBtu </p>

Function group SYSTEM UNITS	
MASS FLOW UNIT	<p>Select the unit for mass flowrate (mass/unit of time).</p> <p>The unit selected here also applies to the following:</p> <ul style="list-style-type: none">• Full-scale value for current output• Relay switchpoints <div><div><div>+</div><div>-</div></div><div>lbs/unit of time – kg/unit of time – g/unit of time – t/unit of time – tons(US)/unit of time – tons (long)/unit of time</div></div>
MASS TOTAL UNIT	<p>Select the units of mass for the totaliser.</p> <p>The unit selected here also applies to the following:</p> <ul style="list-style-type: none">• Pulse value (kg → kg/p)• Relay switchpoints <div><div><div>+</div><div>-</div></div><div>lbs – kg – g – t – tons (US) – tons (long)</div></div>
COR. VOL. FLOW UNIT	<p>Select the unit for corrected volumetric flowrate (corrected volume/unit of time).</p> <p>The unit selected here also applies to the following:</p> <ul style="list-style-type: none">• Full-scale value for current• Relay switchpoints <p><i>Corrected volume</i> = volume measured under operating conditions converted to volume under reference conditions. (see also pg. 72 and 75: flowequations “CORRECTED GAS VOLUME” and “CORRECTED LIQUID VOLUME” respectively).</p> <p><i>Reference conditions:</i> see page 46</p> <p>Depending on the selected flow equation, not all of the following units are available:</p> <div><div><div>+</div><div>-</div></div><div>bbl/unit of time – gal/unit of time – l/unit of time – hl/unit of time – dm³/unit of time* – ft³/unit of time – m³/unit of time – scf/unit of time – Nm³/unit of time** – NI/unit of time – igal/unit of time Factory setting: * for liquids, ** for gas</div></div> <p>Definitions for the units given above → see page 29 All units listed here apply to corrected volume. Additionally, the unit nomenclature scf, Nm³ or NI points this out.</p>

Function group SYSTEM UNITS	
COR. VOL. TOTAL UNIT	<p>Select the unit for the appropriate totaliser. The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Pulse value (bbl → bbl/p) • Relay switchpoints <p><i>Corrected volume</i> = volume measured at operating conditions converted to volume at reference conditions. (see also page 72 and 75: flow equations "CORRECTED GAS VOLUME" and "CORRECTED LIQUID VOLUME" respectively).</p> <p>Depending on the selected flow equation, not all of the following units are available:</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="text-align: center;">+</div> <div style="text-align: center;">-</div> </div> <div> bbl – gal – l – hl – dm³* – ft³ – m³** – scf – Nm³ – NI – ical Factory setting: *for liquids, **for gas </div> </div> <p>Definitions for the units given above → see page 29. All units listed here apply to corrected volume. Additionally, the unit nomenclature scf, Nm³ or NI points this out.</p>
VOLUME FLOW UNIT	<p>Select the unit for volumetric flowrate. The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Full-scale value for current • Relay switchpoints <p>Depending on the selected flow equation, not all of the following units are available:</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="text-align: center;">+</div> <div style="text-align: center;">-</div> </div> <div> bbl/unit of time – gal/unit of time – l/unit of time – hl/unit of time – dm³/unit of time* – ft³/unit of time – m³/unit of time** – acf/unit of time – ical/time Factory setting: *for liquids, **for gas </div> </div> <p>Definitions for the units given above → see page 29. All units given above refer to the actual volume measured under operating conditions.</p>




Function group SYSTEM UNITS	
VOLUME TOTAL UNIT	<p>Select the unit for uncorrected volumetric flowrate and for the totaliser.</p> <p>The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Pulse value (bbl → bbl/p) • Relay switchpoints <p>Depending on the selected flow equation, not all of the following units are available:</p> <p> <input type="checkbox"/> + bbl – gal – l – hl – dm³* – ft³ – m³** – acf – igal <input type="checkbox"/> – Factory setting: * for liquids, ** for gas </p> <p>Definitions for the units given above → see page 29. All units given above refer to the actual volume measured under operating conditions.</p>
DEFINITION bbl	<p>In certain countries the ratio of barrels (bbl) to gallons (gal) can vary according to the fluid used and the specific industry. Select one of the following definitions:</p> <ul style="list-style-type: none"> • US or imperial gallons • Ratio gallons/barrel <p> <input type="checkbox"/> + US: 31.0 gal/bbl for beer (brewing) <input type="checkbox"/> – US: 31.5 gal/bbl for liquids (used in normal cases) US: 42.0 gal/bbl for oil (petrochemicals) US: 55.0 gal/bbl for filling tanks </p> <p> Imp: 36.0 gal/bbl for beer (brewing) Imp: 42.0 gal/bbl for oil (petrochemicals) </p>
TEMPERATURE UNIT	<p>Select the unit for the fluid temperature.</p> <p>The unit selected here also applies to the following:</p> <ul style="list-style-type: none"> • Zero and full-scale value for current • Relay switchpoints • Reference conditions • Specific heat <p> <input type="checkbox"/> + °C (CELSIUS) – °F (FAHRENHEIT) – K (KELVIN) – <input type="checkbox"/> – °R (RANKINE) </p>

Function group SYSTEM UNITS																			
PRESSURE UNIT	<p>Select the unit for process pressure.</p> <p>The unit selected here applies to the following:</p> <ul style="list-style-type: none">• Zero and full-scale value for current• Relay switchpoints• Reference conditions <div><div><div>+</div><div>-</div></div><div>bara – kPaa – kc2a – psia – barg – psig – kPag – kc2g</div></div> <p>Definitions:</p> <table><tr><td>bara</td><td>bar</td><td rowspan="4">} Absolute pressure ('a' for absolute)</td></tr><tr><td>kPaa</td><td>kPa</td></tr><tr><td>kc2a</td><td>kg/cm²</td></tr><tr><td>psia</td><td>psi</td></tr><tr><td>barg</td><td>bar</td><td rowspan="4">} Gauge pressure compared to atmospheric pressure ('g' for gauge)</td></tr><tr><td>psig</td><td>psi</td></tr><tr><td>kPag</td><td>kPa</td></tr><tr><td>kc2g</td><td>kg/cm²</td></tr></table> <p>Gauge pressure differs from absolute pressure by the atmospheric pressure, which can be set in the function "BAROMETRIC PRESS." (see page 46).</p>	bara	bar	} Absolute pressure ('a' for absolute)	kPaa	kPa	kc2a	kg/cm ²	psia	psi	barg	bar	} Gauge pressure compared to atmospheric pressure ('g' for gauge)	psig	psi	kPag	kPa	kc2g	kg/cm ²
bara	bar	} Absolute pressure ('a' for absolute)																	
kPaa	kPa																		
kc2a	kg/cm ²																		
psia	psi																		
barg	bar	} Gauge pressure compared to atmospheric pressure ('g' for gauge)																	
psig	psi																		
kPag	kPa																		
kc2g	kg/cm ²																		
DENSITY UNIT	<p>Select the unit for density of the fluid.</p> <p>The units selected here also define those for all corresponding functions, e.g.</p> <ul style="list-style-type: none">• Zero and full-scale value for current• Relay switchpoints <div><div><div>+</div><div>-</div></div><div>kg/m³ – kg/dm³ – #/gal – #/ft³ (# = lbs = 0.4536 kg)</div></div>																		
SPEC. ENTHALPY UNIT	<p>Select the unit for the combustion value (= spec. enthalpy).</p> <p>The units selected here are also used for the specific thermal capacity (kWh/kg → kWh/kg → °C)</p> <div><div><div>+</div><div>-</div></div><div>Btu/# * – kWh/kg – MJ/kg ** – kcal/kg (# = lbs = 0.4536 kg)</div></div> <p>Factory settings:</p> <ul style="list-style-type: none">* for english units** for metric units																		
LENGTH UNIT	<p>Select the pipe diameter unit.</p> <div><div><div>+</div><div>-</div></div><div>mm** – in*</div></div> <p>Factory setting:</p> <ul style="list-style-type: none">* for english unit system** for metric unit system																		

Function group FLUID DATA	
FLUID TYPE	<p>Select the fluid. There are three different types:</p> <p>1. Steam / Water All information required for steam and water such as the saturated steam curve, density and thermal capacity are permanently stored in the flow computer.</p> <p>2. Fluid displayed (see below) For other fluids, such as air, natural gas and various fuels (see below) are <i>preset values</i> already stored in the flow computer which can be directly adopted by the user. If these preset values are to be changed to fit your specific process conditions, then proceed as follows: Select fluid → press [E] → Reselect function "FLUID TYPE" → Select 'GENERIC' fluid → Press [E]. The characteristics of any 'Generic fluid' can now be defined by the user in the following functions. This procedure can also be used to view the default settings of the previously selected fluid.</p> <p>3. Generic fluid Select the setting 'GENERIC'. The characteristics of any fluid can now be defined by the user in the following functions.</p> <div><div><div></div><div></div></div><div>GENERIC – WATER – SATURATED STEAM – SUPERHEATED STEAM – AIR – NATURAL GAS – AMMONIA – CARBON DIOXIDE – PROPANE – OXYGEN – ARGON – METHANE – NITROGEN – GASOLINE – NO.2 FUEL OIL – KEROSENE – NATURAL GAS (NX-19)</div></div> <p>Factory setting: dependent on the flow equation selected</p> <p>Note!</p> <ul style="list-style-type: none">• A detailed description of all applications and flow equations are found on page 67.• For Natural Gas (NX-19) selection the gas operating conditions and composition must lie within the following specifications: Temperature –40...+116 °C Pressure < 345 bar Mole % CO₂ 0...15% Mole % Nitrogen 0...15%
REF. DENSITY	<p>Enter the density for a generic fluid at reference temperature and pressure (see also function "STP REFERENCE", page 46).</p> <div><div><div></div><div></div></div><div>Number with floating decimal point: 0.0001...10000.0 Factory setting: dependent on fluid</div></div>






Note!

Function group FLUID DATA	
THERM. EXP. COEF.	<p>Enter the thermal expansion coefficient for a generic fluid. This coefficient is required for the temperature compensation of volume with various flow equations, e.g. for 'LIQUID MASS' or 'CORRECTED LIQUID VOLUME' (see page 67).</p> <p> Number with floating decimal point: 0.000...100000 (e-6) Factory setting: dependent on fluid [e-6/temperature unit]</p> <p>Calculate the thermal expansion coefficient as follows:</p> $\alpha = \frac{1 - \sqrt{\frac{\rho(T_1)}{\rho(T_0)}}}{T_1 - T_0} \cdot 10^6$ <p>α Thermal expansion coefficient T_0, T_1 Reference temperatures (see below) in units selected for temperature in the "SYSTEM UNITS" function group. $\rho(T_0, T_1)$ Density of the liquid at temperature T_0 or T_1.</p> <p>For optimum accuracy, choose the reference temperatures as follows: T_0: ca. 10% above minimum process temperature T_1: ca. 10% below maximum process temperature The percentage refers to the span between minimum and maximum process temperatures.</p> <p>10^6 The value entered is internally multiplied by a factor of 10^{-6} (display: "e-6/temperature unit") since the value to be entered is very small.</p>
COMBUSTION HEAT	<p>Enter the specific combustion heat for generic fuels (gas or liquid).</p> <p> Number with floating decimal point: 0.00000...100000 Factory setting: dependent on fluid</p>
SPECIFIC HEAT	<p>Enter the specific heat capacity for generic fluids. This value is required for calculating the delta heat of liquids (see page 78: flow equation "LIQUID DELTA HEAT").</p> <p> Number with floating decimal point: 0.00000...100000 Factory setting: dependent on fluid (units e.g. [MJ/t·°C])</p>



Function group FLUID DATA	
FLOW Z-FACTOR	<p>Enter a Z-factor (compressibility factor) for the gas <i>at operating conditions</i>. The Z-factor indicates how different a 'real' gas behaves from an 'ideal gas' which exactly obeys the 'general gas law' ($P \times V / T = \text{const.}; Z = 1$). The further the real gas is from its condensation point, the closer the Z-Factor approaches '1'.</p> <p>Note!</p> <ul style="list-style-type: none">• The Z-factor is used for all gas flow equations.• Enter the Z-factor for the average process conditions (pressure and temperature). <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point: 0.1000...10.0000 Factory setting: dependent on fluid</div></div>
REF. Z-FACTOR	<p>Enter a Z-factor (compressibility factor) for gases <i>at reference conditions</i>. The Z-factor is an indication of how different a 'real' gas differs from an 'ideal gas' which exactly obeys the 'general gas law' ($P \times V / T = \text{constant}; Z = 1$). The further the real gas is from its condensation point, the closer the Z-Factor approaches '1'.</p> <p>Note!</p> <ul style="list-style-type: none">• The Z-factor is used for all gas flow equations.• Define the standard conditions in the function "STP REFERENCE" (see page 46). <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point: 0.1000...10.0000 Factory setting: 1.0000</div></div>
ISENTROPIC EXP.	<p>Enter the isentropic exponent of the fluid. The isentropic exponent describes the behaviour of the fluid when measuring the flow using a differential pressure flowmeter. The isentropic exponent is a fluid property dependent on operating conditions.</p> <div><div><div>+</div><div>-</div></div><div>Number with fixed decimal point: 0.1000...10.0000 Factory setting: 1.4000</div></div>


Function group FLUID DATA	
MOLE % NITROGEN	<p>Enter the MOLE % Nitrogen in the expected natural gas mixture. This information is needed by the NX-19 computation.</p> <p> Number with fixed decimal point: 00.000...15.000 Factory setting: 00.000</p>
MOLE % CO₂	<p>Enter the MOLE % CO₂ in the expected natural gas mixture. This information is needed by the NX-19 computation.</p> <p> Number with fixed decimal point: 00.000...15.000 Factory setting: 00.000</p>
VISCOSITY COEF. A	<p>For the fluid type "GENERIC" this information is needed for the calculation of the Reynolds number and to calculate the viscosity of the fluid. These coefficients can be derived from two known temperature/viscosity pairs. This information can be obtained from tables for the specific fluid.</p> <p>Note!</p> <ul style="list-style-type: none"> • Always use centipoise (cP) as unit for the viscosity. • Metric unit system → "Kelvin" must be used as unit for T₁ and T₂. English system → "Rankine" must be used as unit for T₁ and T₂. <p>The viscosity coefficient A and B can then be computed by using the following equations based on the fluid state:</p> <p>Liquids:</p> $B = \frac{(T_1 + 273.15) \cdot (T_2 + 273.15) \cdot \ln [\eta_1 / \eta_2]}{(T_2 + 273.15) - (T_1 + 273.15)}$ $A = \frac{\eta_1}{\exp [B / (T_1 + 273.15)]}$ <p>Gas:</p> $B = \frac{\ln [\eta_2 / \eta_1]}{\ln [(T_2 + 273.15) / (T_1 + 273.15)]}$ $A = \frac{\eta_1}{(T_1 + 273.15)^B}$ <p>T₁ Temperature of pair 1 (Kelvin or Rankin, see Note!) T₂ Temperature of pair 2 (Kelvin or Rankin, see Note!) η₁ Viscosity of pair 1 (centipoise) η₂ Viscosity of pair 2 (centipoise)</p> <p> Number with fixed decimal point: 000.000...100000 Factory setting: 1.000</p>
VISCOSITY COEF. B	






Note!



Note!

Function group FLOW INPUT																													
The settings selected in both functions "FLOWMETER TYPE" and "INPUT SIGNAL" determine the functions and selections available in this group.																													
FLOWMETER TYPE	<p>Select the flowmeter. The flow equation (see page 24) and the flowmeter selected here determine the basic operation of the flow computer.</p> <p>Note! For differential pressure applications the "BASIC SQUARE LAW" option is the simplest equation. For applications with changing process conditions (further away from sizing sheet conditions) the equations ORIFICE / NOZZLE / PITOT can be used for higher accuracies, but they also require more process data to be entered.</p> <p></p> <table> <tr> <td>PROWIRL</td><td>Vortex flowmeter with linear pulse or analogue output, e.g. E+H 'Prowirl' or 'Swingwirl' vortex flowmeters</td></tr> <tr> <td>PROMAG</td><td>Electromagnetic flowmeter with linear pulse or analogue output, e.g. E+H 'Promag' flowmeter</td></tr> <tr> <td>LINEAR</td><td>Volumetric flowmeter with linear pulse or analogue output</td></tr> <tr> <td>LINEAR 16 PT *</td><td>Volumetric flowmeter with linear pulse or analogue output; with 16-point linearisation table.</td></tr> <tr> <td>BASIC SQUARE LAW</td><td>Generic differential pressure device without integrated square root extraction.</td></tr> <tr> <td>BASIC SQUARE W/SQRT</td><td>Generic differential pressure device with integrated square root extraction.</td></tr> <tr> <td>ORIFICE</td><td>Orifice plate flowmeter without integrated square root extraction and with analogue output</td></tr> <tr> <td>ORIFICE W/SQRT</td><td>Orifice plate flowmeter with integrated square root extraction and with analog output.</td></tr> <tr> <td>ORIFICE 16 PT*</td><td>Orifice plate flowmeter without integrated square root extraction, with analog output and 16 point linearisation table.</td></tr> <tr> <td>ORIFICE 16 PT* W/SQRT</td><td>Orifice plate flowmeter with integrated square root extraction, with analog output and 16 point linearisation table.</td></tr> <tr> <td>NOZZLE</td><td>Nozzle, venturi and other contoured flowmeters without integrated square root extraction and with analog output.</td></tr> <tr> <td>NOZZLE W/SQRT</td><td>Nozzle, venturi and other contoured flowmeters with integrated square root extraction and with analog output.</td></tr> <tr> <td>NOZZLE 16 PT*</td><td>Nozzle, venturi and other contoured flowmeters without integrated square root extraction, with analog output and 16 point linearisation table.</td></tr> <tr> <td>NOZZLE 16 PT* W/SQRT</td><td>Nozzle, venturi and other contoured flowmeters with integrated square root extraction, analog output and 16 point linearisation table.</td></tr> </table> <p>(Continued next page)</p>	PROWIRL	Vortex flowmeter with linear pulse or analogue output, e.g. E+H 'Prowirl' or 'Swingwirl' vortex flowmeters	PROMAG	Electromagnetic flowmeter with linear pulse or analogue output, e.g. E+H 'Promag' flowmeter	LINEAR	Volumetric flowmeter with linear pulse or analogue output	LINEAR 16 PT *	Volumetric flowmeter with linear pulse or analogue output; with 16-point linearisation table.	BASIC SQUARE LAW	Generic differential pressure device without integrated square root extraction.	BASIC SQUARE W/SQRT	Generic differential pressure device with integrated square root extraction.	ORIFICE	Orifice plate flowmeter without integrated square root extraction and with analogue output	ORIFICE W/SQRT	Orifice plate flowmeter with integrated square root extraction and with analog output.	ORIFICE 16 PT*	Orifice plate flowmeter without integrated square root extraction, with analog output and 16 point linearisation table.	ORIFICE 16 PT* W/SQRT	Orifice plate flowmeter with integrated square root extraction, with analog output and 16 point linearisation table.	NOZZLE	Nozzle, venturi and other contoured flowmeters without integrated square root extraction and with analog output.	NOZZLE W/SQRT	Nozzle, venturi and other contoured flowmeters with integrated square root extraction and with analog output.	NOZZLE 16 PT*	Nozzle, venturi and other contoured flowmeters without integrated square root extraction, with analog output and 16 point linearisation table.	NOZZLE 16 PT* W/SQRT	Nozzle, venturi and other contoured flowmeters with integrated square root extraction, analog output and 16 point linearisation table.
PROWIRL	Vortex flowmeter with linear pulse or analogue output, e.g. E+H 'Prowirl' or 'Swingwirl' vortex flowmeters																												
PROMAG	Electromagnetic flowmeter with linear pulse or analogue output, e.g. E+H 'Promag' flowmeter																												
LINEAR	Volumetric flowmeter with linear pulse or analogue output																												
LINEAR 16 PT *	Volumetric flowmeter with linear pulse or analogue output; with 16-point linearisation table.																												
BASIC SQUARE LAW	Generic differential pressure device without integrated square root extraction.																												
BASIC SQUARE W/SQRT	Generic differential pressure device with integrated square root extraction.																												
ORIFICE	Orifice plate flowmeter without integrated square root extraction and with analogue output																												
ORIFICE W/SQRT	Orifice plate flowmeter with integrated square root extraction and with analog output.																												
ORIFICE 16 PT*	Orifice plate flowmeter without integrated square root extraction, with analog output and 16 point linearisation table.																												
ORIFICE 16 PT* W/SQRT	Orifice plate flowmeter with integrated square root extraction, with analog output and 16 point linearisation table.																												
NOZZLE	Nozzle, venturi and other contoured flowmeters without integrated square root extraction and with analog output.																												
NOZZLE W/SQRT	Nozzle, venturi and other contoured flowmeters with integrated square root extraction and with analog output.																												
NOZZLE 16 PT*	Nozzle, venturi and other contoured flowmeters without integrated square root extraction, with analog output and 16 point linearisation table.																												
NOZZLE 16 PT* W/SQRT	Nozzle, venturi and other contoured flowmeters with integrated square root extraction, analog output and 16 point linearisation table.																												






Function group FLOW INPUT	
FLOWMETER TYPE (Continued)	<p>PITOT without integrated square root extraction and with analog output</p> <p>PITOT W/SQRT with integrated square root extraction and analog output</p> <p>PITOT 16 PT * without integrated square root extraction, with analog output and 16 point linearisation table.</p> <p>PITOT 16 PT * W/SQRT with square root extraction, analog output and 16 point linearisation table.</p> <p>Note! * For selections with 16 PT, a linearisation table must be constructed → see function "LINEARIZATION", page 43.</p>
INPUT SIGNAL	<p>Enter the type of measuring signal supplied by the flowmeter.</p> <p> PFM PFM → Pulse output signal of E+H vortex flowmeters (current pulses, trigger threshold ca. 10 mA)</p> <p>DIGITAL, 10 mV level Voltage pulses, trigger threshold 10 mV DIGITAL, 100 mV level Voltage pulses, trigger threshold 100 mV DIGITAL, 2.5 V level Voltage pulses, trigger threshold 2.5 V</p> <p>4–20 mA SPLIT) analog current signal 0–20 mA SPLIT) for split range DP transmitters.</p> <p>4–20 mA) analog current signal 0–20 mA)</p> <p>0–5 V) analog voltage signal 1–5 V) 0–10 V)</p>
FULL SCALE	<p>Set the full scale value for the analog input signal. The value entered here must be identical to the value set in the flowmeter.</p> <p>Note!</p> <ul style="list-style-type: none"> For flowmeters with analog/linear output the flow computer uses the selected system units for volumetric flowrate. Differential pressure flowmeters → The units for differential pressure are dependent on the unit system selected: <ul style="list-style-type: none"> Imperial units → [inches H₂O] Metric units → [mbar] For use of split range (stacking) the full scale value of the lower range analogue signal should be entered here. <p> Number with floating decimal point: 0.000...+999999 Factory setting: dependent on the selected unit and flow equation</p>
FULL SCALE – HI RANGE	<p>For use of split range (stacking) the full scale value of the higher range analogue signal should be entered here. The value entered here must be equal to the value set in the flowmeter.</p> <p> Number with floating decimal point: 0.000...+999999 Factory setting: dependent on the selected unit and flow equation</p>




Note!



Note!

Function group FLOW INPUT	
LOW FLOW CUTOFF	<p>Enter the switchpoint for creep suppression. The creep suppression setting can be used to prevent low flows from being registered.</p> <p> Number with floating decimal point: 0.000...999999 Factory setting: 0.000 [units]</p>
CALIBRATION DENSITY	<p>Enter the calibration density for the generic square law flowmeter (density on sizing sheet).</p> <p> Number with floating decimal point: 0.0001...10000 Factory setting: 1.0000 [units]</p>
K-FACTOR	<p>The K-factor is defined as number of pulses per dm³ flow. If a Prowirl with PFM output is used as flowmeter, the value shown on the meter body has to be entered as K-factor. If an Open Collector output is used, then – independent of the flowmeter type – the inverse of the pulse value (pulse scaling) has to be entered.</p> <p>Note! The flow computer always uses [pulses/liter] as units for the K-factor. A conversion must be carried out for instruments using different units.</p> <p> Number with floating decimal point: 0.001...999999 Factory setting: 1.000 [P/dm³]</p>
PIPE INNER DIAMETER	<p>Enter the inlet bore of the pipeline.</p> <p>Note! This value is required to calculate the Reynolds number, when a 16 point linearization is selected.</p> <p> Number with floating decimal point: 0.0001...1000.00 Factory setting: 1.0000 [units]</p>
ENTER BETA	<p>Enter the opening ratio (d/D) of the DP-flowmeter being used. This value is given by the manufacturer of the orifice plate.</p> <p>Note!</p> <ul style="list-style-type: none"> • 'Beta' is only required for measuring gas or steam with DP-flowmeters. • 'Beta' is used to calculate the expansion factor. It is not required when "generic DP-meter" is selected. <p> Number with fixed decimal point: 0.0000...1.0000 Factory setting: 0.0001</p>



Function group FLOW INPUT	
METER EXP. COEF.	<p>The flowmeter pipe expands depending on the temperature of the fluid which affects the calibration of the flowmeter.</p> <p>In this function an appropriate correction factor is entered which is given by the manufacturer of the flowmeter. This factor converts the changes in the measuring signal per degree variation from the calibration temperature. This calibration temperature is permanently set in the flow computer to 70 °F / 21 °C.</p> <p>Some manufacturers use a graph or a formula to show the influence of temperature on the calibration of the flowmeter. In this case use the following equation to calculate the meter expansion coefficient:</p> $K_{ME} = \frac{1 - \frac{Q(T)}{Q(T_{cal})}}{T - T_{cal}} \cdot 10^6$ <p> K_{ME} Meter expansion coefficient $Q(T)$ Volumetric flow at temperature T resp. T_{cal} T Average process temperature T_{cal} Calibration temperature 294 K (21 °C or 70 °F) </p> <p>Note!</p> <ul style="list-style-type: none"> • Note that this correction should be set either in the flowmeter or in the flow computer. • Entering the value '0.000' switches this function off. • The temperature T and T_{cal} should be entered in the units selected in the "SYSTEM UNITS" function group. <p>  Number with fixed decimal point: 0.000...999.900 (e-6/°X) Factory setting: dependent on the selected temperature unit and flowmeter. </p>
DP-FACTOR	<p>This factor gives the relationship between the flowrate and the measured differential pressure. The volume flowrate is computed according to one of the following equations. Additionally, one of the flow equations on page 68 to 79 is used to compute values of mass, heat or corrected volume.</p> <p>Steam (or gas) volume flow: $Q = \frac{K_{DP} \cdot \epsilon_1}{(1 - K_{ME} \cdot (T - T_{cal}))} \cdot \sqrt{\frac{2 \cdot \Delta p}{\rho}}$</p> <p>Liquid volume flow: $Q = \frac{K_{DP}}{(1 - K_{ME} \cdot (T - T_{cal}))} \cdot \sqrt{\frac{2 \cdot \Delta p}{\rho}}$</p> <p> Q Volumetric flow K_{DP} DP-Factor ϵ_1 Gas expansion factor T Operating temperature T_{cal} Calibration temperature 294 K (21 °C or 70 °F) Δp Differential pressure ρ Density K_{ME} Meter expansion coefficient </p> <p>The DP-Factor K_{DP} can be entered manually or the flowcomputer can calculate it for you with the help of the function "COMPUTE DP FACTOR". The information necessary for this calculation can be found on the sizing sheet from a DP-meter sizing program.</p> <p>(Continued next page)</p>



Note!





Function group FLOW INPUT	
DP-FACTOR (Continued)	<p>Note! The following data must be entered in the corresponding matrix functions before computing the DP-Factor:</p> <div><div>1. Flow equation</div><div>2. Fluid data</div><div>3. Beta (diameter ratio: d/D) *</div><div>4. Meter expansion coefficient</div><div>5. STP Reference temperature **</div><div>6. STP Reference pressure **</div></div> <div>see group "SYSTEM PARAMETER"</div> <div>see group "FLUID DATA"</div> <div>see group "FLOW INPUT"</div> <div>see group "FLOW INPUT"</div> <div>see group "COMPENSATION INPUT" (Input selection → 1)</div> <div>see group "COMPENSATION INPUT" (Input selection → 2)</div> <div>* only for orifice or nozzle</div> <div>** only for "GAS....." flow equations</div> <div><div><div><div>+</div><div>-</div></div></div><div>CHANGE FACTOR? NO CHANGE FACTOR? YES</div><div>If 'YES' → the flow computer will prompt you further:</div></div> <div><div><div><div>+</div><div>-</div></div></div><div>COMPUTE FACTOR? NO COMPUTE FACTOR? YES</div><div>If 'NO' → enter DP FACTOR</div><div>If 'YES' → the flow computer will prompt you for the following:</div></div> <div><div><div><div>+</div><div>-</div></div></div><div>ENTER DELTA P ENTER FLOWRATE ENTER DENSITY ENTER TEMPERATURE ENTER INLET PRESSURE ENTER ISENTROPIC EXP</div></div> <div>The flow computer first computes the gas expansion factor ϵ_1 using one of the following equations:</div> <div>Orifice plate</div> <div>$\epsilon_1 = 1 - (0.41 + 0.35 \beta^4) \cdot \frac{\Delta p}{\kappa \cdot p_1}$</div> <div>Flow nozzle or Venturi</div> <div>$\epsilon_1 = \sqrt{\frac{(1 - \beta^4) \cdot \frac{\kappa}{\kappa - 1} \cdot R^{2/\kappa} \cdot (1 - R^{(\kappa - 1)/\kappa})}{[(1 - (\beta^4 - R^{2/\kappa})) \cdot (1 - R)]}}$, with $R = 1 - \frac{\Delta p}{p_1}$</div> <div>Pitot tube</div> <div>$\epsilon_1 = 1.0$</div> <div>ϵ_1 Gas expansion factor β BETA (orifice plate opening ratio) Δp Differential pressure κ Isentropic Exponent p_1 Inlet pressure</div> <div>(Continued next page)</div>











Function group FLOW INPUT	
DP-FACTOR (Continued)	<p>The DP-Factor K_{DP} is then computed according to one of the three following equations, depending on the selected flow equation:</p> <p>Steam: $K_{DP} = \frac{M \cdot (1 - K_{ME} \cdot (T - T_{cal}))}{\epsilon_1 \cdot \sqrt{2 \cdot \Delta p \cdot \rho}}$</p> <p>Liquid: $K_{DP} = \frac{Q \cdot (1 - K_{ME} \cdot (T - T_{cal}))}{\sqrt{2 \cdot \Delta p} \cdot \rho}$</p> <p>Gas: $K_{DP} = \frac{Q_{ref} \cdot \rho_{ref} \cdot (1 - K_{ME} \cdot (T - T_{cal}))}{\epsilon_1 \cdot \sqrt{2 \cdot \Delta p \cdot \rho}}$</p> <p> K_{DP} DP-Factor M Mass flow Q Volumetric flow Q_{ref} Corrected volume flow ϵ_1 Gas expansion coefficient K_{ME} Meter expansion coefficient T Operating temperature T_{cal} Calibration temperature 294 K (21 °C or 70 °F) Δp Differential pressure ρ Density ρ_{ref} Reference density </p> <p>Note! The computation accuracy can be enhanced by entering up to 16 values for Reynolds number and DP-factor in a linearization table (see function "LINEARIZATION" below). Every single DP-factor can then be calculated using the above procedure. For every calculation a sizing sheet is required. The results have to be entered in the linearization table afterwards. </p>
LOW PASS FILTER	<p>Enter the maximum possible frequency of a flowmeter with PFM or digital signal type (see function "INPUT SIGNAL", page 39). Using the value entered here, the flow computer selects a suitable limiting frequency for the low-pass filter in order to suppress any higher frequency interference signals.</p> <p> <input type="text" value="+"/> max. 5-figure number: 10...40000 [Hz] <input type="text" value="-"/> Factory setting 40000 Hz </p>
LINEARIZATION	<p>With flowmeters the relationship between the flowrate and the output signal may deviate from an ideal curve – linear or squared. The flow computer is able to compensate for this deviation with an additional linearisation.</p> <p>The appearance of the linearisation table used for this is dependent on the particular flowmeter selected (see following sections):</p> <p>Linear flowmeters with pulse output The linearisation table enables up to 16 pairs of values to be entered (frequency/K-factor). The frequency [Hz] and the corresponding K-factor [pulse/dm³] are prompted for each pair of values. </p> <p>(Continued next page)</p>



Note!





Function group FLOW INPUT	
LINEARIZATION (Continued)	<p>Linear flowmeters with analogue output The linearization table enables up to 16 pairs of values to be entered (current/flowrate). The flowrate and the corresponding current signal are prompted for each pair of values.</p> <p>Linear/squared differential pressure transmitters with analogue output The linearisation table enables up to 16 pairs of values to be entered (Reynolds number/differential pressure factor). The Reynolds number and the corresponding differential pressure factor is prompted for each pair of values in ascending order of the first variable.</p> <p>Application hint: For the 16PT linearization table (Reynolds number/DP-factor), set the meter type to orifice/nozzle/pitot (without 16PT linearization). Then go into the DP factor cell and calculate it for all table points (max. 16 times), or calculate it by hand using the formula for DP factor, described on page 43. The information needed will be given on the sizing sheet (from the manufacturer of the DP-device) for the calculated process. Having done this set the flowmeter to Orifice/Nozzle or Pitot with 16PT linearization, and enter the calculated points into the linearization table.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>CHANGE TABLE? NO CHANGE TABLE? YES</p> <p>'YES' → Correction factors can be entered for up to 16 different input values.</p> <p><i>Example (for linear flowmeters with analogue output):</i> Entry of current value: INPUT mA 5.00 POINT 0</p> <p>Entry of corresponding flowrate: RATE m³/h 0.25 POINT 0</p> <p>Note! If the number '0' is entered as the first value for a pair of values, then all pairs of values entered so far are adopted and no more prompts are given.</p> </div> </div>
FLOWMETER LOCATION	<p>Select the location of the flowmeter in a 'delta heat' application</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>HOT – COLD</p> </div> </div>
VIEW INPUT SIGNAL	<p>Display of actual flow input signal. Depending on input signal this cell displays a frequency, current or a voltage.</p>
VIEW HI FLOW SIGNAL	<p>Display of actual flow input signal of the hi-range input signal of split range DP transmitter.</p>







Function group COMPENSATION INPUT	
SELECT INPUT	<p>In addition to the flow input, the flow computer provides two further inputs for temperature, density and/or pressure signals. In this function select the particular input which is to be configured in the following functions.</p> <p>  1 (Input 1: Temperature)  2 (Input 2: Pressure, Temperature 2, Density) </p>
INPUT SIGNAL	<p>Determine the type of measuring signal coming from the temperature, density or pressure sensor.</p> <p>Note! In case saturated steam is measured with only a pressure sensor, "INPUT 1 NOT USED" must be selected. If only a temperature sensor is used, "INPUT 2 NOT USED" must be selected.</p> <p><i>Input 1 (Temperature):</i></p> <p>  INPUT 1 NOT USED – RTD TEMPERATURE –  4-20 TEMPERATURE – 0-20 TEMPERATURE – MANUAL TEMPERATURE * </p> <p><i>Input 2 (Process pressure, Temperature 2, Density):</i></p> <p>  INPUT 2 NOT USED – 4-20 PRESSURE (G) –  0-20 PRESSURE (G) – MANUAL PRESSURE * – 4-20 PRESSURE (ABS.) – 0-20 PRESSURE (ABS.) – RTD TEMPERATURE 2 – 4-20 TEMPERATURE 2 – 0-20 TEMPERATURE 2 – MANUAL TEMPERATURE 2 * – 4-20 DENSITY – 0-20 DENSITY – MANUAL DENSITY * </p> <p>* Select this setting if a self-defined fixed value for the corresponding measuring variable is required (see function "DEFAULT VALUE"; page 46).</p> <p>Factory setting: dependent on flow equation and input selected (1 or 2)</p>
LOW SCALE VALUE	<p>Set the low scale value of the analogue current input signal (value for 0 or 4 mA input current). The value entered here must be identical with the one set in the pressure, temperature or density transmitter.</p> <p>  Number with fixed decimal point: -9999.99...+9999.99  Factory setting: dependent on flow equation and input selected (1 or 2). </p>
FULL SCALE VALUE	<p>Set the full-scale value of the analogue current input signal (value for 20 mA input current). The value entered here must be identical with the one set in the pressure, temperature or density transmitter.</p> <p>  Number with fixed decimal point: -9999.99...+9999.99  Factory setting: dependent on flow equation and input selected (1 or 2). </p>






Note!

Function group COMPENSATION INPUT	
DEFAULT VALUE	<p>A fixed value can be defined for the assigned variable (pressure, temperature or density) in the function "INPUT SIGNAL". The flow computer requires this value in the following cases:</p> <ul style="list-style-type: none"> • In cases of error, e.g. defective sensors, the flow computer continues to operate with the fixed value entered here, and indicates an error. • If in the function "INPUT SIGNAL" (see page 45) the setting 'MANUAL TEMPERATURE', 'MANUAL PRESSURE' or 'MANUAL DENSITY' has been selected. <p> Number with fixed decimal point: -9999.99...+9999.99</p> <p>Factory settings: Temperature → 21 °C Pressure → 1.013 bara Density → 998.9 kg/m³</p>
STP REFERENCE	<p>Define the STP reference conditions (standard temperature and pressure) for the variable assigned to the input. Standard conditions are at present defined differently according to the country and the application.</p> <p> Number with fixed decimal point: -9999.99...+9999.99</p> <p>Factory settings: Pressure → 1.013 bara Temperature → dependent on unit system and fluid selected:</p> <ul style="list-style-type: none"> • Metric unit system: <ul style="list-style-type: none"> – Gas → 0 °C – Liquid → 20 °C • English unit system: <ul style="list-style-type: none"> – Gas/Liquids → 70 °F (21 °C)
BAROMETRIC PRESS.	<p>Enter the actual atmospheric pressure. When using gauge pressure transmitters for determining gas pressure, the reduced atmospheric pressure above sea level is then taken into account.</p> <p> Number with floating decimal point: 0.0000...10000.0 Factory setting: 1.013 bara</p>
LOW DELTA T CUTOFF	<p>Enter the minimum value of temperature difference (ΔT), below which the energy flow is assumed to be zero and energy totalising stops.</p> <p> Number with fixed decimal point: 0.0...99.9 Factory setting: 0.0 [temperature unit]</p>
VIEW INPUT SIGNAL	<p>Display of actual input signal. Depending on input signal this cell displays a current or a resistance</p>

Function group PULSE OUTPUT	
ASSIGN PULSE OUTPUT	<p>A measured or calculated value can be assigned to the pulse output.</p> <div><div><div>+</div><div>-</div></div><div>HEAT TOTAL – MASS TOTAL – CORRECTED VOL. TOTAL – ACTUAL VOLUME TOTAL</div></div> <p>Factory setting/options: <i>dependent</i> on the flow equation selected</p>

Function group PULSE OUTPUT	
PULSE TYPE	<div><p>The pulse output of the flow computer can be configured as required for external instrument, such as totalisers, etc.</p><p>ACTIVE: Internal power supply used (+24 V). PASSIVE: External power supply required. POSITIVE: Fall-back value at 0 V ("active high") NEGATIVE: Fall-back value at 24 V ("active low") or external power supply</p><p><i>ACTIVE</i></p><div><p>Internal power supply 24 V DC</p><p>Push-Pull</p><p>Short circuit-resistant output</p><p>12</p><p>13</p><p>1 5 7 8 3</p><p>ba020y22</p></div><p>For continuous currents up to 15 mA</p><p><i>PASSIVE</i></p><div><p>Open Collector</p><p>Short circuit-resistant output</p><p>12</p><p>13</p><p>1 5 7 8 3</p><p>External power supply $U_{\max} = 30 \text{ V DC}$</p><p>ba0204y23</p></div><p>For continuous currents up to 25 mA</p><p><i>POSITIVE pulses</i></p><div><p>U [V]</p><p>24</p><p>0</p><p>t</p></div><p><i>NEGATIVE pulses</i></p><div><p>U [V]</p><p>24</p><p>0</p><p>t</p><p>ba0204y24</p></div><div><div><div>+</div><div>-</div></div><div>PASSIVE-NEGATIVE PASSIVE-POSITIVE ACTIVE-NEGATIVE ACTIVE-POSITIVE</div></div></div>











Function group PULSE OUTPUT	
PULSE VALUE	<p>Define the flow quantity per output pulse. By means of an external counter the sum of these pulses can be totalised and the total quantity determined since the start of measurement.</p> <p>Note! Ensure that the max. flowrate (full-scale value) and the pulse value selected here agree with one another. The max. possible output frequency is 50 Hz. The appropriate pulse value can be determined as follows:</p> $\text{Pulse value} > \frac{\text{estimated max. flowrate (full-scale value)}}{\text{required max. output frequency}}$ <p> Number with floating decimal point: 0.001...1000.0 Factory setting: 1.000 [units/pulse]</p>
PULSE WIDTH	<p>Set the pulse width required for external counters. The pulse width limits the max. possible output frequency of the pulse output. For a certain output frequency, the max. permissible pulse width can be calculated as follows:</p> $\text{Pulse width} < \frac{1}{2 \cdot \text{max. output frequency [Hz]}}$ <p> Number with floating decimal point: 0.01...10.00 s (seconds) Factory setting: 0.01 s</p>
SIMULATION FREQ.	<p>Frequency signals can be simulated in order to check any instruments which may be connected. The simulated signals are always symmetrical (pulse/pause ratio = 1:1).</p> <p>Note!</p> <ul style="list-style-type: none"> The simulation mode selected affects only the frequency output. The flowcomputer is fully operational during simulation, i.e. totaliser, flow display, etc. continue operating normally. Simulation mode is ended immediately after leaving this function. <p> OFF – 0.0 Hz – 0.1 Hz – 1.0 Hz – 10 Hz – 50 Hz</p>





Note!



Note!

Function group CURRENT OUTPUT	
SELECT OUTPUT	<p>Select the current output to be configured. <i>Two</i> current outputs are available.</p> <p>  1 (Current output 1)  2 (Current output 2) </p>
ASSIGN CURRENT OUT.	<p>Assign a variable to the current output.</p> <p>  HEAT FLOW – MASS FLOW – COR. VOLUME FLOW –  VOLUME FLOW – TEMPERATURE 1 – TEMPERATURE 2 – DELTA TEMPERATURE – PRESSURE – DENSITY – VISCOSITY – REYNOLDS NUMBER </p> <p>Factory setting/options: dependent on the flow equation</p>
CURRENT RANGE	<p>Define the 0/4-mA initial current value. The current for the scaled full-scale value is always 20 mA.</p> <p>  0–20 mA – 4–20 mA – NOT USED  </p>
LOW SCALE VALUE	<p>Assign the low scale value to the 0/4 mA current signal for the variable assigned to the current output.</p> <p>  Number with floating decimal point: –999999...+999999  Factory setting: 0.000 [units] </p>
FULL SCALE VALUE	<p>Assign the full-scale value to the 20 mA current signal for the variable assigned to the current output.</p> <p>  Number with floating decimal point: –999999...+999999  Factory setting: 50000 [units] </p>

Function group CURRENT OUTPUT	
TIME CONSTANT	<p>Select the time constant to determine whether the current output signal reacts quickly (small time constant) or slowly (large time constant) to rapidly changing variables, e.g. flowrate. The time constant does not affect the behaviour of the display.</p> <p>  max. 2-figure number: 0...99 Factory setting: 1 </p>
CURRENT OUT VALUE	<p>Display the actual value of the output current.</p> <p>Display: Actual current value in [mA]</p>
SIMULATION CURRENT	<p>Various output currents can be simulated in order to check any instruments which may be connected.</p> <p>Note!</p> <ul style="list-style-type: none"> • The simulation mode selected affects only the current output. The flowcomputer is fully operational during simulation, i.e. totaliser, flow display, etc. continue operating normally. • Simulation mode is ended immediately after leaving this function. <p>  OFF – 0 mA – 2 mA – 4 mA – 12 mA – 20 mA – 25 mA </p>



Note!

Function group RELAYS	
SELECT RELAY	<p>Select the relay output to be configured. <i>Two</i> relay outputs are available.</p> <div><div><div>+</div><div>-</div></div><div><div>1 (Relay 1)</div><div>2 (Relay 2)</div></div></div>
RELAY FUNCTION	<p>Both relays (1 and 2) can be assigned various functions as required:</p> <ul style="list-style-type: none">• Limit functions Exceeding limit switch points (see pages 53, 55). Freely assignable to measured or calculated variables or totalisers.• Malfunction For indication of instrument failure, power loss, etc. the relay de-energizes.• Wet steam alarm The flow computer can monitor pressure and temperature in superheated steam applications continuously and compare them to the saturated steam curve. When the degree of superheat (distance to the saturated steam curve) drops below 2 °C , the relay switches and the message "WET STEAM ALARM" is displayed.• Pulse output The relays can be defined as additional pulse outputs (see function "RELAY MODE", page 53) for totalised values such as heat, mass, volume or corrected volume. <p>Depending on the flow equation (see page 24) and type of transmitter <i>different</i> options are available:</p> <div><div><div>+</div><div>-</div></div><div><div>HEAT TOTAL – MASS TOTAL – CORRECTED VOL. TOTAL – ACTUAL VOLUME TOTAL – HEAT FLOW – MASS FLOW – COR. VOL. FLOW – VOLUME FLOW – TEMPERATURE 1 – TEMPERATURE 2 – DELTA TEMPERATURE – PRESSURE – DENSITY – WET STEAM ALARM – MALFUNCTION – VISCOSITY – REYNOLDS NUMBER</div></div><p>Factory setting/options: dependent on the flow equation</p></div>

Function group RELAYS	
RELAY MODE	<p>Sets when and how the relays are switched 'on' or 'off'. This defines both the alarm conditions and the time response of the alarm status (see page 55).</p> <p>Caution! See page 55 for relay behaviour for limit switches, malfunction or wet steam alarm.</p> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="text-align: center;">+</div> <div style="text-align: center;">-</div> </div> <div> <p>HI ALARM, FOLLOW</p> <p>LO ALARM, FOLLOW</p> <p>HI ALARM LATCH</p> <p>LO ALARM LATCH</p> <p>RELAY PULSE OUTPUT</p> </div> </div> <p>Note!</p> <ul style="list-style-type: none"> For relay functions "MALFUNCTION" and "WET STEAM ALARM" there is no difference between the modes "HI" and "LO": → HI ALARM FOLLOW = LO ALARM FOLLOW → HI ALARM LATCH = LO ALARM LATCH Relay mode "RELAY PULSE OUTPUT" defines the relay as additional pulse output: Set pulse value → see page 54 Set pulse width → see page 54
LIMIT SETPOINT	<p>After configuring a relay for 'Alarm indication' (limit value), the required switchpoint can be set in this function. If the variable reaches the set value, then the relay switches and the corresponding message is displayed.</p> <p>With the function "HYSTERESIS" (see page 54) continuous switching near the switchpoint can be prevented.</p> <p>Note!</p> <ul style="list-style-type: none"> Initially select the units (see page 29), before entering the switchpoint in this function. Normally open or normally closed contacts are determined by the type of wiring (see page 9). <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="border: 1px solid black; padding: 2px; margin-right: 10px;"> <div style="text-align: center;">+</div> <div style="text-align: center;">-</div> </div> <div> <p>Number with floating decimal point -999999...+999999</p> <p>Factory setting: 50000 [units] for variables</p> </div> </div>






Note!

Function group RELAYS	
PULSE VALUE	<p>Define the flow quantity per output pulse if the relay is configured to 'RELAY PULSE OUTPUT'.</p> <p>Note! Ensure that the max. flowrate and the pulse value selected here agree with one another. The max. possible output frequency is 5 Hz. The appropriate pulse value can be determined as follows:</p> <p>Pulse value > $\frac{\text{estimated max. flowrate (full-scale value)}}{\text{required max. output frequency}}$</p> <div><div><div>+</div><div>-</div></div><div>Number with floating decimal point: 0.001...+100,000,000 Factory setting: 1000 [units/pulse]</div></div>
PULSE WIDTH	<p>Enter the pulse width. Two cases are possible:</p> <p>Case A: Relay → Setting 'MALFUNCTION' or limit value The response of the relay during alarm status is determined by selecting the pulse width.</p> <ul style="list-style-type: none">• <i>Pulse width = 0.0 s (Normal case):</i> Alarm response as described on page 55.• <i>Pulse width = 0.1...9.9 s (Special case):</i> Relay remains de-energised for the selected duration (0.1...9.9 seconds) independent of the cause of the alarm. This setting is only used in special cases, e.g. for activating signal horns. <p>Case B: Relay → Setting 'RELAY PULSE OUTPUT' Set the pulse width required for the external totaliser. The pulse width entered here can be made to agree with the actual flow amount and pulse value (see above) by using the following equation:</p> <p>Pulse width < $\frac{1}{2 \cdot \text{max. output frequency [Hz]}}$</p> <div><div><div>+</div><div>-</div></div><div>2-figure number with fixed decimal point: 0.1...9.9 s ('RELAY PULSE OUTPUT') or 0.0...9.9 s (all other relay configurations) Factory setting: 0.0 s (0.1 s with 'RELAY PULSE OUTPUT')</div></div>
HYSTERESIS	<p>Enter a hysteresis value to ensure that the 'on' and 'off' switchpoints have different values and therefore prevent continual and undesired switching near the limit value (see page 53).</p> <p>Note! The arithmetic sign for the hysteresis value is determined by the following settings in the function "RELAY MODE": 'HI ALARM, FOLLOW' → negative hysteresis 'LO ALARM, FOLLOW' → positive hysteresis</p> <div><div><div>+</div><div>-</div></div><div>Number with floating decimal point: 0.000...999999 Factory setting: 0.000 [units]</div></div>



Note!


RELAY 1 / 2
Alarm response on “Limit value” (pulse width: 0.0 s)



HI ALARM, FOLLOW

When the measured value exceeds the limit switchpoint, the relay de-energises and the corresponding message is displayed. This status remains only as long as the following condition is met:


Measured value $M > (SP - H)$



HI ALARM LATCH

When the measured value exceeds the limit switchpoint, the relay de-energises and the corresponding message is displayed until the alarm is acknowledged by the operator:
→ see function “ALARM RESET” (page 56)
→ see function keys F1-3 (page 25)


If the measured value still exceeds the limit switchpoint ($M > SP$), the relay de-energises again immediately and the message reappears on the display. An alarm can only be reset permanently when its cause is rectified ($M < SP$).



LO ALARM, FOLLOW

When the measured value drops below the limit switchpoint, the relay de-energises and the corresponding message is displayed. This status remains only as long as the following condition is met:


Measured value $M < (SP + H)$



LO ALARM LATCH

When the measured value drops below the limit switchpoint, the relay de-energises and the corresponding message is displayed until the alarm is acknowledged by the operator:
→ see function “ALARM RESET” (page 56)
→ see function keys F1-3 (page 25)

If the measured value remains below the limit switchpoint ($M < SP$), the relay de-energises again immediately and the message reappears on the display. An alarm can only be reset permanently when its cause is rectified ($M > SP$).

 Relay de-energised
Alarm message on the display

SP = Limit set point
H = Hysteresis (only with “.... FOLLOW”)
M = Measured value
t = Time

Note!

- The above table is only valid for pulse width = 0.0 seconds.
For pulse widths 0.1...9.9 s → see page 54
- The above table also applies to relay functions “MALFUNCTION” and “WET STEAM ALARM” (see page 52), but then reactions are the same for “HI” and “LO”.







Note!






ba020y16



Function group RELAYS	
RELAY SIMULATION	<p>This cell may be used to simulate a relay status for test purposes.</p> <div><div><div>+</div><div>-</div></div><div>NO – Relay ON – Relay OFF</div></div>
RESET ALARM	<p>The alarm status for the particular relay can be cancelled here if for safety reasons the setting '....., LATCH' has been selected in the function "RELAY MODE". This ensures that the user is actively aware of the alarm message.</p> <p>Note!</p> <ul style="list-style-type: none">• If this function is used often, then one of the three function keys F1-F3 should be assigned to "ACK. + RESET ALARM" (see page 25).• The alarm status can only be permanently cancelled if the cause of the alarm is removed. <div><div><div>+</div><div>-</div></div><div><div>RESET ALARM? NO</div><div>RESET ALARM? YES</div></div></div>

Function group COMMUNICATION	
RS 232 USAGE	<p>The flow computer can be connected over a serial RS 232 interface to a personal computer or printer.</p> <p>  COMPUTER – PRINTER </p>
DEVICE ID	<p>Enter the instrument number for unique tagging of the flow computer if a number of flow computers are connected to the same interface.</p> <p>  max. 2-figure number: 0...99 Factory setting: 1 </p>
BAUD RATE	<p>In this function the 'baud rate' is entered for serial communication between the flow computer and personal computer or printer.</p> <p>  9600 – 2400 – 1200 – 300 </p>
PARITY	<p>Parity check can be switched on and off. The setting selected here must agree with that of the printer or personal computer.</p> <p>  NONE – ODD – EVEN </p>

Function group COMMUNICATION																																																									
HANDSHAKE	<p>The control of data flow can be defined. The setting required is determined by the personal computer or printer connected.</p> <div><div><div>+</div><div>-</div></div><div>NONE – HARDWARE</div></div>																																																								
PRINT LIST	<p>Select the variables or parameters which are to be printed via the RS232 interface.</p> <div><div><div>+</div><div>-</div></div><div>CHANGE? NO CHANGE? YES</div></div> <p>If 'YES' → The variables which can be printed are displayed one after the other. Depending on the selected flow equation (see page 24) only some of the following options are available:</p> <div><div><div>E</div><div><div>+</div><div>-</div></div></div><div><div>Storing option → next option</div><div>Print?</div></div><table><tr><td>PRINT HEADER?</td><td>NO (YES)</td></tr><tr><td>INSTRUMENT TAG?</td><td>NO (YES)</td></tr><tr><td>FLUID TYPE?</td><td>NO (YES)</td></tr><tr><td>TIME?</td><td>NO (YES)</td></tr><tr><td>DATE?</td><td>NO (YES)</td></tr><tr><td>TRANSACTION NO.?</td><td>NO (YES)</td></tr><tr><td>HEAT FLOW?</td><td>NO (YES)</td></tr><tr><td>HEAT TOTAL?</td><td>NO (YES)</td></tr><tr><td>HEAT GRAND TOTAL?</td><td>NO (YES)</td></tr><tr><td>MASS FLOW?</td><td>NO (YES)</td></tr><tr><td>MASS TOTAL?</td><td>NO (YES)</td></tr><tr><td>MASS GRAND TOTAL?</td><td>NO (YES)</td></tr><tr><td>COR. VOLUME FLOW?</td><td>NO (YES)</td></tr><tr><td>COR. VOLUME TOTAL?</td><td>NO (YES)</td></tr><tr><td>COR.VOL.GRAND TOTAL?</td><td>NO (YES)</td></tr><tr><td>VOLUME FLOW?</td><td>NO (YES)</td></tr><tr><td>VOLUME TOTAL?</td><td>NO (YES)</td></tr><tr><td>VOL. GRAND TOTAL?</td><td>NO (YES)</td></tr><tr><td>TEMPERATURE1?</td><td>NO (YES)</td></tr><tr><td>TEMPERATURE 2?</td><td>NO (YES)</td></tr><tr><td>DELTA TEMPERATURE?</td><td>NO (YES)</td></tr><tr><td>PROCESS PRESSURE?</td><td>NO (YES)</td></tr><tr><td>DENSITY?</td><td>NO (YES)</td></tr><tr><td>SPEC. ENTHALPY?</td><td>NO (YES)</td></tr><tr><td>VISCOSITY?</td><td>NO (YES)</td></tr><tr><td>REYNOLDS NUMBER?</td><td>NO (YES)</td></tr><tr><td>ERRORS?</td><td>NO (YES)</td></tr><tr><td>ALARMS?</td><td>NO (YES)</td></tr></table><p>'YES' + <div><div>E</div></div> → Parameter is added to the printer list. 'NO' + <div><div>E</div></div> → Parameter is not printed.</p><p>After the last option there is an automatic jump to the next function.</p></div>	PRINT HEADER?	NO (YES)	INSTRUMENT TAG?	NO (YES)	FLUID TYPE?	NO (YES)	TIME?	NO (YES)	DATE?	NO (YES)	TRANSACTION NO.?	NO (YES)	HEAT FLOW?	NO (YES)	HEAT TOTAL?	NO (YES)	HEAT GRAND TOTAL?	NO (YES)	MASS FLOW?	NO (YES)	MASS TOTAL?	NO (YES)	MASS GRAND TOTAL?	NO (YES)	COR. VOLUME FLOW?	NO (YES)	COR. VOLUME TOTAL?	NO (YES)	COR.VOL.GRAND TOTAL?	NO (YES)	VOLUME FLOW?	NO (YES)	VOLUME TOTAL?	NO (YES)	VOL. GRAND TOTAL?	NO (YES)	TEMPERATURE1?	NO (YES)	TEMPERATURE 2?	NO (YES)	DELTA TEMPERATURE?	NO (YES)	PROCESS PRESSURE?	NO (YES)	DENSITY?	NO (YES)	SPEC. ENTHALPY?	NO (YES)	VISCOSITY?	NO (YES)	REYNOLDS NUMBER?	NO (YES)	ERRORS?	NO (YES)	ALARMS?	NO (YES)
PRINT HEADER?	NO (YES)																																																								
INSTRUMENT TAG?	NO (YES)																																																								
FLUID TYPE?	NO (YES)																																																								
TIME?	NO (YES)																																																								
DATE?	NO (YES)																																																								
TRANSACTION NO.?	NO (YES)																																																								
HEAT FLOW?	NO (YES)																																																								
HEAT TOTAL?	NO (YES)																																																								
HEAT GRAND TOTAL?	NO (YES)																																																								
MASS FLOW?	NO (YES)																																																								
MASS TOTAL?	NO (YES)																																																								
MASS GRAND TOTAL?	NO (YES)																																																								
COR. VOLUME FLOW?	NO (YES)																																																								
COR. VOLUME TOTAL?	NO (YES)																																																								
COR.VOL.GRAND TOTAL?	NO (YES)																																																								
VOLUME FLOW?	NO (YES)																																																								
VOLUME TOTAL?	NO (YES)																																																								
VOL. GRAND TOTAL?	NO (YES)																																																								
TEMPERATURE1?	NO (YES)																																																								
TEMPERATURE 2?	NO (YES)																																																								
DELTA TEMPERATURE?	NO (YES)																																																								
PROCESS PRESSURE?	NO (YES)																																																								
DENSITY?	NO (YES)																																																								
SPEC. ENTHALPY?	NO (YES)																																																								
VISCOSITY?	NO (YES)																																																								
REYNOLDS NUMBER?	NO (YES)																																																								
ERRORS?	NO (YES)																																																								
ALARMS?	NO (YES)																																																								

Function group COMMUNICATION	
PRINT INITIATE	<p>Printing variables and parameters over the serial RS232 interface can either be at regular intervals (INTERVAL) or daily at a fixed time (TIME OF DAY).</p> <p>Note! Printing can always be initiated if assigned to the function keys (F1...3) independent of the selection made here.</p> <p> NONE – TIME OF DAY – INTERVAL</p>
PRINT INTERVAL	<p>Define a time interval after which variables and parameters are to be periodically printed. The setting '00:00' deactivates this function.</p> <p> Flashing positions can be changed. Confirm entries with .</p> <p>Factory setting: 00:00 (HH:MM)</p>
PRINT TIME	<p>Define the time at which variables and parameters are to be printed out daily.</p> <p> Flashing positions can be changed. Confirm entries with .</p> <p>Factory setting: 00:00 (HH:MM)</p>




Note!

Function group SERVICE & ANALYSIS	
EXAMINE AUDIT TRAIL	<p>Changes in important calibration and configuration data are registered and displayed ("electronic stamping"). Those displays cannot be reset, so that unauthorised changes can be identified.</p> <p><i>Example:</i> CAL 185 CFG 969</p>
ERROR LOG	<p>Display of logged system error message.</p> <p><i>Example:</i> POWER FAILURE</p>
SOFTWARE VERSION	<p>Display of the software version being used.</p> <p><i>Example:</i> 02.00.00</p>
PRINT SYSTEM SETUP	<p>This function allows the actual set parameters (set-up) to be printed on a connected printer.</p> <div><div><div>+</div><div>-</div></div><div>NO – YES</div></div>
SELF CHECK	<p>This function starts the self-test of the flow computer.</p> <div><div><div>+</div><div>-</div></div><div>RUN? NO RUN? YES</div></div>

6. Troubleshooting and Remedies

6.1 Instructions for troubleshooting

During manufacture, all units undergo quality control at numerous stages. To help you locate faults, some of their possible causes are given here.



6.2 Error messages

Error messages which occur during operation are shown on the display (HOME position) alternately with the measured variable.

System error messages Compart DXF 351		
Display	Cause	Remedy
COMMUNICATION ERROR	<ul style="list-style-type: none"> Faulty wiring between flow computer and connected PC/printer Incorrect use of connected PC or printer 	<ul style="list-style-type: none"> Check wiring (see page 9) Check settings in function group "COMMUNICATION" Check settings on the printer/PC
CALIBRATION ERROR	Faulty programming or loss of calibration data	Repeat programming, check settings. Inform your E+H Service Organisation, if the fault cannot be removed.
PRINT BUFFER FULL	<ul style="list-style-type: none"> Printer buffer of the connected printer is full (loss of data between flow computer and printer possible) 	<ul style="list-style-type: none"> Check connection to printer Check paper supply of printer
TOTALIZER ERROR	Totaliser contents lost	Reset totaliser. Inform your E+H Service Organisation, if the fault cannot be removed.

Process error messages Compart DXF 351		
Display	Cause	Remedy
WET STEAM ALARM	The steam condition (temperature and pressure) is close to the saturated steam curve.	Check the application. Ensure that all transmitters and sensors which are connected are working correctly. Change the relay function, if the "WET STEAM ALARM" is not required (see page 52).
OFF FLUID TABLE	Temperature and/or pressure input signals are <i>outside</i> the range of steam table values stored in the flow computer.	Check application and settings. Ensure that all transmitters and sensors which are connected are working correctly.
FLOW IN OVERRANGE	Current input signal of the flowmeter input exceeds 21.5 mA: <ul style="list-style-type: none"> • Incorrectly set full-scale value for the flowmeter • Function error in the flowmeter or faulty wiring 	<ul style="list-style-type: none"> • Check whether the programmed full-scale value of the connected flowmeter agrees with process conditions (see page 39). • Check the application conditions • Check wiring
INPUT 1 OVERRANGE	Current input signal of compensation input 1 exceeds 21.5 mA: <ul style="list-style-type: none"> • Incorrectly set full-scale value for transmitter • Function error in transmitter or faulty wiring 	<ul style="list-style-type: none"> • Check whether the programmed full-scale value of the connected transmitter agrees with process conditions (see page 45). • Check the application conditions • Check wiring
INPUT 2 OVERRANGE	Current input signal of compensation input 2 exceeds 21.5 mA: <ul style="list-style-type: none"> • Incorrectly set full-scale value for transmitter • Function error in transmitter or faulty wiring 	<ul style="list-style-type: none"> • Check whether the programmed full-scale value of the connected transmitter agrees with process conditions (see page 45). • Check the application conditions • Check wiring
FLOW LOOP BROKEN	Input current at flow input smaller than 3.6 mA: <ul style="list-style-type: none"> • Faulty wiring • Flowmeter not set to '4–20 mA' • Function error in flowmeter 	<ul style="list-style-type: none"> • Check wiring • Check calibration of flowmeter • Check function of flowmeter

Process error messages Compart DXF 351 (continued)		
Display	Cause	Remedy
LOOP 1 BROKEN	Input current at current input 1 smaller than 3.6 mA: <ul style="list-style-type: none"> Faulty wiring Transmitter not set to '4–20 mA' Function error in transmitter 	<ul style="list-style-type: none"> Check wiring Check calibration of transmitter Check function of transmitter
LOOP 2 BROKEN	Input current at current input 2 smaller than 3.6 mA: <ul style="list-style-type: none"> Faulty wiring Transmitter not set to '4–20 mA' Function error in transmitter 	<ul style="list-style-type: none"> Check wiring Check calibration of transmitter Check function of transmitter
RTD 1 OPEN	Input current at PT100 Input 1 too low: <ul style="list-style-type: none"> Faulty wiring PT100 sensor defective 	<ul style="list-style-type: none"> Check wiring Check function of PT100 sensor
RTD 1 SHORT	Resistance at PT100 Input 1 too low: <ul style="list-style-type: none"> Faulty wiring PT100 sensor defective 	<ul style="list-style-type: none"> Check wiring Check function of PT100 sensor
RTD 2 OPEN	Input current at PT100 Input 2 too low: <ul style="list-style-type: none"> Faulty wiring PT100 sensor defective 	<ul style="list-style-type: none"> Check wiring Check function of PT100 sensor
RTD 2 SHORT	Resistance at PT100 Input 2 too low: <ul style="list-style-type: none"> Faulty wiring PT100 sensor defective 	<ul style="list-style-type: none"> Check wiring Check function of PT100 sensor
PULSE OUT OVERRUN	Calculated pulse frequency too large: <ul style="list-style-type: none"> Pulse value too low Pulse width too large Assigned measured variable too large 	<ul style="list-style-type: none"> Adjust pulse value Adjust pulse width Check process conditions

Process error messages Compart DXF 351 (continued)		
Display	Cause	Remedy
lout 1 OUT OF RANGE	Calculated current for current output 1 larger than 21.5 mA: <ul style="list-style-type: none"> • Full-scale value too low • Assigned measured variable too large 	<ul style="list-style-type: none"> • Adjust full scale value • Check process conditions
lout 2 OUT OF RANGE	Calculated current for current output 2 larger than 21.5 mA: <ul style="list-style-type: none"> • Full-scale value too low • Assigned measured variable too large 	<ul style="list-style-type: none"> • Adjust full scale value • Check process conditions
RELAY 1 HI ALARM RELAY 1 LO ALARM	Limit value exceeded (see also page 53, 55)	<ul style="list-style-type: none"> • The alarm indication must be confirmed in the function "RESET ALARM" if the function "RELAY MODE" has been set to '....., LATCH.' (see page 56). • Check the application if necessary • Adjust the limit value if necessary
RELAY 2 HI ALARM RELAY 2 LO ALARM	Limit value exceeded (see also page 53, 55)	<ul style="list-style-type: none"> • The alarm indication must be confirmed in the function "RESET ALARM" if the function "RELAY MODE" has been set to '....., LATCH.' (see page 56). • Check application if necessary • Adjust the limit value if required

Self-monitoring messages Compart DXF 351		
Display	Cause	Remedy
A/D MALFUNCTION	Fault in analogue/digital converter has occurred.	Contact E+H Service
PROGRAM ERROR	Fault in program EPROM has occurred.	Contact E+H Service
SETUP DATA LOST	Stored data in EEPROM is destroyed or overwritten.	<ul style="list-style-type: none"> • Enter settings and numerical values again. • Inform your E+H Service Organisation, if this fault indication occurs again.
TIME CLOCK LOST	The correct time is no longer shown, e.g. after a long break in the power supply	Re-enter data and time (see page 24).
DISPLAY MALFUNCTION	Fault in display module has occurred.	Contact E+H Service
RAM MALFUNCTION	A part or all the data stored in the RAM has been destroyed.	Switch off the instrument and then switch on again. If this occurs often then inform your E+H Service Organisation.

7. Flow equations / Applications

- The **basic operation** is determined by the flow equation selected. Every flow equation requires certain measured variables such as pressure, temperature and density in order to be able to calculate and/or show other parameters (see following table).
- The following pages give detailed descriptions and instructions on the applications for every flow equation used. The figures show typical applications with vortex flowmeters.
- For use with differential pressure flowmeters the pressure sensor must be installed in front of the flowmeter. Detailed installation guidelines can be found in the flowmeter documentation.

<div>Measured variable Calculated variable</div> <div>Flow equation</div>	HEAT FLOW	MASS FLOW	COR. VOLUME FLOW	VOLUME FLOW	TEMPERATURE	TEMPERATURE 2	DELTA TEMPERATURE	PROCESS PRESSURE	DIFF. PRESSURE	DENSITY	SPEC. ENTHALPY	DATE & TIME	VISCOSITY *	REYNOLDS NUMBER *
STEAM MASS														
STEAM HEAT														
STEAM NET HEAT														
STEAM DELTA HEAT														
CORRECTED GAS VOLUME														
GAS MASS														
GAS COMBUSTION HEAT														
CORR. LIQUID VOLUME														
LIQUID MASS														
LIQUID COMBUSTION HEAT														
LIQUID SENSIBLE HEAT														
LIQUID DELTA HEAT														



Measured value available



Measured value available with differential pressure flow measurement

* only with 16 point linearization

STEAM MASS

Measured variables

Measures uncorrected volumetric flow, temperature and pressure in a steam line.

Calculated variables

- Calculates density and mass flow using the steam tables stored in the flow computer.
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.
- Saturated steam requires either a pressure or temperature measurement with the other variable calculated using the steam table.

Input variables

Superheated steam: Flow, temperature and pressure


Saturated steam: Flow, temperature or pressure

Output variables

- Mass flow, uncorrected volumetric flow, temperature, pressure and density
- Totaliser for mass and uncorrected volume
- If a relay is configured for "WET STEAM ALARM" (see page 52) and the superheated steam approaches the saturated steam curve, then this relay switches and an alarm is displayed (see Fig. page 55).

Applications

Calculate the mass flow in a steam line at the output of a steam generator or at individual consumers.



$$m = Q \cdot \rho(T, p)$$

m	Mass
Q	Uncorrected volume
ρ	Density
T	Temperature
p	Pressure

STEAM HEAT

Measured variables

Measures uncorrected volumetric flow, temperature and pressure in a steam line.

Calculated variables

- Calculates density, mass flow and heat flow using steam tables stored in the flow computer.
The heat is defined as the enthalpy of steam under actual conditions with reference to the enthalpy of water at $T = 0\text{ °C}$.
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.
- Saturated steam requires either a pressure or temperature measurement with the other variable calculated using the saturated steam curve.

Input variables

Superheated steam: Flow, temperature and pressure


Saturated steam: Flow, temperature or pressure

Output variables

- Heat flow, mass flow, uncorrected volumetric flow, temperature, pressure, density and specific enthalpy
- Totaliser for heat, mass and uncorrected volume
- If a relay is configured for "WET STEAM ALARM" (see page 52) and the superheated steam approaches the saturated steam curve, then this relay switches and an alarm is displayed (see Fig. page 55).

Applications

Calculates the mass flow and the thermal energy at the output of a steam generator or at individual consumers.



$$H = Q \cdot \rho(T, p) \cdot E_D(T, p)$$

H	Heat
Q	Uncorrected volume
ρ	Density
T	Temperature
p	Pressure
E_D	Specific enthalpy of steam

STEAM NET HEAT

Measured variables

Measures the uncorrected volumetric flow, temperature and pressure in a steam line upstream of a heat exchange.

Calculated variables

- Calculates density, mass flow and net heat flow using steam tables stored in the flow computer.
The net heat is defined as the difference between the heat of the steam and the heat of the condensate. For simplification it is assumed that the condensate (water) has a temperature which corresponds to the temperature of saturated steam at the pressure measured upstream of the heat exchanger.
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.
- Saturated steam requires either a pressure or temperature measurement with the other variable calculated using the saturated steam curve.

Input variables

Superheated steam:

Flow, temperature and pressure

Saturated steam:

Flow, temperature or pressure

Output variables

- Heat flow, mass flow, uncorrected volumetric flow, temperature, pressure, density and specific enthalpy
- Totaliser for heat, mass and uncorrected volume
- If a relay is configured for "WET STEAM ALARM" (see page 52) and the superheated steam approaches the saturated steam curve, then this relay switches and an alarm is displayed (see figure on page 55).

Applications

Calculate the mass flow and the thermal energy which can be extracted by a heat exchanger taking into account the thermal energy remaining in the returned condensate. For simplification it is assumed that the condensate (water) has a temperature which corresponds to the temperature of saturated steam at the pressure measured upstream of the heat exchanger.

$$H = Q \cdot \rho(T, p) \cdot [E_D(T, p) - E_w(T_s(p))]$$

H	Heat
Q	Uncorrected volume
ρ	Density
T	Temperature
p	Pressure
E_D	Specific enthalpy of steam
E_w	Specific enthalpy of water
$T_s(p)$	Calculated condensation temperature (= saturated steam temperature for the supply pressure)

ba020y41

70

Endress+Hauser

STEAM DELTA HEAT

Measured variables

Measures uncorrected volumetric flow and pressure of the saturated steam in the supply piping as well as the temperature of the condensate in the downstream piping of a heat exchanger.

Calculated variables

- Calculates the density and mass flow as well as the delta heat between the saturated steam (supply) and condensation (return) using physical characteristic tables of steam and water stored in the flow computer.
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.
- The saturated steam temperature in the supply piping is calculated from the pressure measured there.

Input variables


Supply: Flow and pressure (saturated steam)
Return: Temperature (condensation)

Output variables

- Heat flow, mass flow, uncorrected volumetric flow, temperature, pressure, density and specific enthalpy
- Totaliser for heat, mass and uncorrected volume

Applications

Calculate the saturated steam mass flow and the heat extracted by a heat exchanger taking into account the thermal energy remaining in the condensate.



$$H = Q \cdot \rho(p) \cdot [E_D(p) - E_W(T)]$$

H Heat
 Q Uncorrected volume
 ρ Density
 T_2 Return temperature
 p_1 Supply pressure
 E_D Specific enthalpy of steam
 E_W Specific enthalpy of water

CORRECTED GAS VOLUME


Measured variables
Measures uncorrected volumetric flow, temperature and pressure in a gas line.

- Calculated variables**
- Calculates the corrected volumetric gas flow using the gas characteristics stored in the flow computer (see function "FLUID DATA", page 34). The reference conditions for temperature and pressure can be defined in the function "STP REFERENCE" (see page 46).
 - With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.

Input variables
Flow, temperature and pressure

- Output variables**
- Corrected volumetric flow, uncorrected volumetric flow, temperature and pressure
 - Totaliser for corrected volume and uncorrected volume

Applications
Calculate the corrected volumetric flow of any gas such as compressed air, gaseous fuels, CO₂, etc.



$$Q_{ref} = Q \cdot \frac{p}{p_{ref}} \cdot \frac{T_{ref}}{T} \cdot \frac{Z_{ref}}{Z}$$

In this equation, T_{ref} and T are absolute values in K (Kelvin);
p and p_{ref} are also absolute values, e.g. 'bara' or 'psia'.

- Q_{ref} Corrected volume
- Q Uncorrected volume
- p_{ref} Reference pressure (see function, page 46)
- p Actual pressure
- T_{ref} Reference temperature (see function, page 46)
- T Actual temperature
- Z_{ref} Reference Z-factor (see function, page 36)
- Z Flowing Z-factor (see function, page 36)



Note!
For natural gas (NX-19) selection, the ratio $\frac{Z_{ref}}{Z}$ is calculated by the NX-19 equation of state.

ba020y48

GAS MASS

Measured variables

Measures the uncorrected volumetric flow, temperature and pressure in a gas line.

Calculated variables

- Calculates the density and mass flow using gas characteristics stored in the flow computer (see function "FLUID TYPE", page 34).
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.

Input variables


Flow, temperature and pressure

Output variables

- Mass flow, uncorrected volumetric flow, temperature, pressure and density
- Totaliser for mass and uncorrected volume

Applications

Calculate mass flow of any gas such as compressed air, gaseous fuels, CO₂, etc.



$$M = \rho_{ref} \cdot Q \cdot \frac{p}{p_{ref}} \cdot \frac{T_{ref}}{T} \cdot \frac{Z_{ref}}{Z}$$

In this equation, T_{ref} and T are absolute values in K (Kelvin);
 p and p_{ref} are also absolute values, e.g. 'bara' or 'psia'.

M	Mass
ρ_{ref}	Reference density (see page 34)
Q	Uncorrected volume
p_{ref}	Reference pressure (see page 46)
p	Actual pressure
T_{ref}	Reference temperature (see page 46)
T	Actual temperature
Z_{ref}	Reference Z-factor (see page 36)
Z	Flowing Z-factor (see page 36)

Note!

For natural gas (NX-19) selection, the ratio $\frac{Z_{ref}}{Z}$ is calculated by the NX-19 equation of state.



Note!

GAS COMBUSTION HEAT

Measured variables

Measures uncorrected volumetric flow, temperature and pressure in a gas line.

Calculated variables

- Calculates density, mass flow and combustion heat of gases using gas characteristics stored in the flow computer (see function "FLUID TYPE", page 34).
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature and pressure compensation.

Input variables


Flow, temperature and pressure

Output variables

- Combustion heat flow, mass flow, uncorrected volume, temperature, pressure and density
- Totaliser for combustion heat, mass and uncorrected volume

Applications

Calculate the energy released by combustion of gaseous fuels.



$$H = C \cdot \rho_{ref} \cdot Q \cdot \frac{p}{p_{ref}} \cdot \frac{T_{ref}}{T} \cdot \frac{Z_{ref}}{Z}$$

In this equation, T_{ref} and T are absolute values in K (Kelvin);
 p and p_{ref} are also absolute values, e.g. 'bara' or 'psia'.

- H Energy
- C Specific combustion heat (see function, page 35)
- ρ_{ref} Reference density (see function, page 34)
- Q Uncorrected volume
- p_{ref} Reference pressure (see function, page 46)
- p Actual pressure
- T_{ref} Reference temperature (see function, page 46)
- T Actual temperature
- Z_{ref} Reference Z-factor (see function, page 36)
- Z Flow Z-factor (see function, page 36)



Note!

Note!
For natural gas (NX-19) selection, the ratio $\frac{Z_{ref}}{Z}$ is calculated by the NX-19 equation of state.

ba020y48

CORR. LIQUID VOLUME

Measured variables

Measures uncorrected volume and temperature in a liquid line. A pressure transmitter can also be installed in order to show or monitor pressure. Pressure measurement does not affect the calculation.

Calculated variables

- Calculates corrected volumetric flow using thermal expansion coefficients stored in the flow-computer (see function group "FLUID TYPE", page 34). The reference temperature can be defined in the function "STP REFERENCE" (see page 46).
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature compensation.

Input variables


- Flow and temperature or,
- Flow and density (temperature is also used for calculating the meter expansion).

Output variables

- Corrected volumetric flow, uncorrected volumetric flow, temperature and pressure
- Totaliser for corrected volume and uncorrected volume

Applications

Calculate temperature compensated volumetric flow of any liquid if its thermal expansion coefficient is sufficiently constant within the entire temperature range.



$$Q_{ref} = Q \cdot (1 - \alpha \cdot (T - T_{ref}))^2$$

Q_{ref} Corrected volume
 Q Uncorrected volume
 α Thermal expansion coefficient (see function, page 35)
 T Actual temperature
 T_{ref} Reference temperature (see function, page 46)

if density is used:

$$Q_{ref} = Q \cdot \frac{\rho}{\rho_{ref}}$$

ρ operating density
 ρ_{ref} reference density

LIQUID MASS

Measured variables

Measures the uncorrected volumetric flow and temperature in a liquid line. A pressure transmitter can also be installed in order to show and monitor the pressure. Pressure measurement does not affect the calculation.

Calculated variables

- Calculates the density and mass flow using the reference density and the thermal expansion coefficient of the liquid (see function group "FLUID TYPE", page 34).
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account the temperature compensation.

Input variables


- Flow and temperature or,
- Flow and density (temperature is also used for calculating the meter expansion).

Output variables

- Mass flow, uncorrected volume, temperature, pressure and density
- Totaliser for mass and uncorrected volume

Applications

Calculate the mass flow of any liquid if its thermal expansion coefficient is sufficiently constant within the entire temperature range.



Water:

$$m = Q \cdot \delta(T)$$

Other liquids:

$$m = Q \cdot (1 - \alpha \cdot (T - T_{ref}))^2 \cdot \rho_{ref}$$

m Mass

Q Uncorrected volume

α Thermal expansion coefficient (see function, page 35)

T Actual temperature

T_{ref} Reference temperature (see function, page 46)

ρ_{ref} Reference density (see function, page 34)

$\delta(T)$ Density of water at temperature T

if density input:

$$m = Q \cdot \rho \quad (\rho = \text{operating density})$$

LIQUID COMBUSTION HEAT

Measured variables

Measures uncorrected volume and temperature in a liquid line. A pressure transmitter can also be installed in order to show or monitor the pressure. Pressure measurement does not affect the calculation.

Calculated variables

- Calculates density, mass flow and combustion heat using liquid characteristics stored in the flow computer (see function group "FLUID TYPE", page 34).
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature compensation.

Input variables


- Flow and temperature or,
- Flow and density (temperature is also used for calculating the meter expansion).

Output variables

- Combustion heat flow, mass flow, uncorrected volume, temperature, pressure and density
- Totaliser for combustion heat and mass, uncorrected volume

Applications

Calculate the energy released by combustion of liquid fuels.



$$H = C \cdot Q \cdot (1 - \alpha \cdot (T - T_{ref}))^2 \cdot \rho_{ref}$$

- C Specific combustion heat (see function, page 35)
 Q Uncorrected volume
 α Thermal expansion coefficient (see function, page 35)
 T Actual temperature
 T_{ref} Reference temperature (see function, page 46)
 ρ_{ref} Reference density (see function, page 34)

if density input:

$$H = C \cdot Q \cdot \rho \quad (\rho = \text{operating density})$$

LIQUID DELTA HEAT

Measured variables
Measures uncorrected volume and temperature of a heat carrying liquid in the supply line and the temperature in the return line of a heat exchanger.


- Calculated variables**
- Calculates density, mass flow and delta heat using values of the heat carrying liquid stored in the flow computer.
 - With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature compensation.

Note!
An accurate measurement of flow and temperature difference is essential.
The use of paired temperature sensors is recommended.
Temperature sensor 1 should be installed as close as possible to the flowmeter.

- Input variables**
- Flow and temperature 1
 - Temperature 2

- Output variables**
- Delta heat, mass flow, uncorrected volume, temperature 1, temperature 2, temperature difference and density
 - Totaliser for heat, mass and uncorrected volume

Applications
Calculate energy which is extracted by a heat exchanger from heat carrying liquids.



Water:

$$H = Q \cdot \rho(T_1) \cdot [h(T_2) - h(T_1)]$$

Other heat carrying liquids:

$$H = c \cdot Q \cdot (1 - \alpha \cdot (T_1 - T_{ref}))^2 \cdot \rho_{ref} \cdot (T_2 - T_1) *$$

Note! *
If the "FLOWMETER LOCATION" function (see page 44) is set to "HOT", then the last term of the equation is "T₁ - T₂" instead of "T₂ - T₁".

H	Heat
c	Specific heat (see function, page 35)
Q	Uncorrected volume
α	Thermal expansion coefficient (see function, page 35)
T ₁	Actual temperature (compensation input 1 of the flowcomputer)
T ₂	Actual temperature (compensation input 2 of the flowcomputer)
T _{ref}	Reference temperature (see function, page 46)
ρ _{ref}	Reference density (see function, page 34)
ρ(T ₁)	Density of water at temperature T ₁
h(T ₁)	Specific enthalpy of water at temperatur T ₁
h(T ₂)	Specific enthalpy of water at temperatur T ₂

ba020y45

LIQUID SENSIBLE HEAT

Measured variables

Measures uncorrected volume and temperature of water. A pressure transmitter can also be installed in order to show and monitor the pressure. Pressure measurement does not affect the calculation.

Calculated variables

- Calculates density, mass flow and heat flow in a water line using the characteristics of water stored in the flow computer.
- With DP-measurement the uncorrected volume is also calculated from the differential pressure taking into account temperature compensation.

Note!

An accurate measurement of flow and temperature is essential.



Note!

Input variables


Flow and temperature

Output variables

- Heat flow, mass flow, uncorrected volumetric flow, temperature, pressure and density
- Totaliser for heat, mass and uncorrected volume

Applications

Accurate calculation of energy in a flow of water. A typical application is the accurate determination of the residual heat in the return pipe of a heat exchanger.



$$H = Q \cdot \rho(T) \cdot h(T)$$

H Heat

Q Uncorrected volume

T Actual temperature

$\rho(T)$ Density of water at temperature T

$h(T)$ Specific enthalpy of water at temperature T

8. Technical Data

8.1 Technical data (flow computer)

Display	Two-line, backlit, liquid crystal, 20 characters per line
Housing material	Flameproof plastic
Electromagnetic compatibility	According to IEC 1000-4
Protection type	Panel mount: IP 20 (EN 60529), Front: IP 65/NEMA 4X Wall mount: IP 65 (EN 60529)/NEMA 4X
Ambient temperature	0...+50 °C
Storage temperature	−40...+85 °C
Power supply	85...260 V AC (50/60 Hz) or 20...55 V AC (50/60 Hz), 16...62 V DC
Power consumption	AC: <10 VA DC: <10 W

Flow Input

Analogue input	0/4...20 mA, 0...10 V, 0...5 V, 1...5 V Resolution: 18 bit, Automatic error recognition: signal overrange, current loop broken U_{\max} : 50 V DC, R_{in} : >25 k Ω (voltage input) U_{\max} : 24 V DC, R_{in} : 100 Ω (current input)
Pulse input	<ul style="list-style-type: none"> • Current pulse (Prowirl PFM): trigger level 12 mA • Voltage pulse: trigger level 10 mV, 100 mV, 2.5 V U_{\max} : 50 V DC, I_{\max} : 25 mA f_{\max} : 20 kHz

Compensation Inputs (Temperature, Pressure or Density)

Current input	0/4...20 mA Automatic error recognition: signal overrange, current loop broken
Pt100 input	3-wire connection Temperature resolution: 0.01 °C Internal linearisation Automatic error recognition: RTD short, RTD open

Outputs

Relay outputs	2 relays for: flow alarm, temperature alarm, pressure alarm, pulse output (f_{\max} : 5 Hz) Contacts: SPDT 240 V, 1 A Galvanically isolated
Current outputs	2 outputs: 0/4...20 mA Resolution: 16 bit Linearity: 0.05% o.f.s. (at 20 °C) Load: max. 1 k Ω Galvanically isolated
Pulse output	Selectable as open collector or as voltage pulses: <ul style="list-style-type: none"> • <i>Open collector</i> voltage <30 V DC, current <25 mA, U_{CE} <0.4 V • <i>Voltage pulses</i> voltage 24 V, current <15 mA, internal resistance 100 Ω f_{\max}: 50 Hz Galvanically isolated
Printer port	Serial interface RS 232 9-pin DSUB connector

8.2 Dimensions







Fig. 9:
Dimensions for panel mounting
and wall mounting





Programming at a Glance

- 1 Access to the programming matrix
 - 2 Select the function group (>GROUP SELECT.<)
 - 3 Select function (enter/select data with  and save with )
- Options / Factory settings → see page 86
Programming matrix → see page 85
Description of functions → see page 19 ff.
- 4 Return to HOME position from any matrix function



ba020y05

Operating elements

- | | |
|--|--|
|  Access to the programming matrix (>GROUP SELECT.<) |  Select various function groups |
| Select functions within the function groups | Set parameters and numerical values (when +/- are held down the number in the display will change at increasing speed) |
| Store the data or settings. | |
|  Leave the programming matrix |  Diagnostic function |
| Store the data or settings. | Help function
Displays additional information during programming. |

Enable / Lock programming

- Enable: Enter the code number (Factory setting = '351')
- Lock: After returning to the HOME position, programming is locked after 60 seconds if no operating element has been pressed.



Caution!

“Quick Setup” programming menu

Using the “QUICK-SETUP” programming menu the most important parameters and process functions can be quickly set for an initial start-up of the flow computer. Please read the instructions on pages 15 and 23!

PROCESS VARIABLE	HEAT FLOW (Display)	MASS FLOW (Display)	COR. VOLUME FLOW (Display)	VOLUME FLOW (Display)	TEMPERATURE 1 (Display)	TEMPERATURE 2 (Display)	DELTA TEMPERATURE (Display)	PROCESS PRESSURE (Display)	DIFF. PRESSURE (Display)	DENSITY (Display)	SPEC. ENTHALPY (Display)	DATE & TIME (Display)	VISCOSITY (Display)	REYNOLDS NUMBER (Display)
	RESET TOTALIZER	HEAT TOTAL (Display)	HEAT GRAND TOTAL (Display)	MASS TOTAL (Display)	MASS GRAND TOTAL (Display)	COR. VOLUME (Display)	COR. VOLUME GRAND TOTAL (Display)	VOLUME TOTAL (Display)	VOLUME GRAND TOTAL (Display)					
TOTALIZERS														
SYSTEM PARAMETER	QUICK SETUP	FLOW EQUATION	ENTER DATE	ENTER TIME	F1 KEY FUNCTION	F2 KEY FUNCTION	F3 KEY FUNCTION	PRIVATE CODE	ACCESS CODE	TAG NUMBER	SERIAL NO. SENSOR			
DISPLAY	DISPLAY LIST	DISPLAY DAMPING	LCD CONTRAST	MAX. DEC. POINT	LANGUAGE									
SYSTEM UNITS	TIME BASE	HEAT FLOW UNIT	HEAT TOTAL UNIT	MASS FLOW UNIT	MASS TOTAL UNIT	COR. VOL. FLOW UNIT	COR. VOL. TOTAL UNIT	VOLUME FLOW UNIT	VOLUME TOTAL UNIT	DEFINITION ID#	TEMPERATURE UNIT	PRESSURE UNIT	DENSITY UNIT	SPEC. ENTHALPY UNIT
FLUID DATA	FLUID TYPE	REF. DENSITY	THERM. EXP. COEFF.	COMBUSTION HEAT	SPECIFIC HEAT	FLOW Z-FACTOR	REF. Z-FACTOR	ISENTROPIC EXP.	MOLE % NITROGEN	MOLE % CO2	VISCOSITY COEF. A	VISCOSITY COEF. B		
FLOW INPUT	FLOWMETER TYPE	INPUT SIGNAL	FULL SCALE	FULL SCALE-HIGH RANGE	LOW FLOW CUTOFF	CALIBRATION DENSITY	K-FACTOR	PIPE INNER DIAMETER	ENTER BETA	METER EXP. COEF.	DP-FACTOR	LOW PASS FILTER	LINEARIZATION	FLOWMETER LOCATION
COMPENSATION INPUT	1	INPUT SIGNAL	LOW SCALE VALUE	FULL SCALE VALUE	DEFAULT VALUE	STP. REFERENCE	LOW DELTA T CUTOFF	VIEW INPUT SIGNAL						
	2	INPUT SIGNAL	LOW SCALE VALUE	FULL SCALE VALUE	DEFAULT VALUE	STP. REFERENCE	BAROMETRIC PRESS	VIEW INPUT SIGNAL						
PULSE OUTPUT	ASSIGN PULSE OUTPUT	PULSE TYPE	PULSE VALUE	PULSE WIDTH	SIMULATION FREQ.									
CURRENT OUTPUT	1	ASSIGN CURRENT OUT.	CURRENT RANGE	LOW SCALE VALUE	FULL SCALE VALUE	TIME CONSTANT	CURRENT OUT. VALUE (Display)	SIMULATION CURRENT						
	2	ASSIGN CURRENT OUT.	CURRENT RANGE	LOW SCALE VALUE	FULL SCALE VALUE	TIME CONSTANT	CURRENT OUT. VALUE (Display)	SIMULATION CURRENT						
RELAYS	1	RELAY FUNCTION	RELAY MODE	LIMIT SETPOINT	PULSE VALUE	PULSE WIDTH	HYSTERESIS	RELAY SIMULATION	RESET ALARM					
	2	RELAY FUNCTION	RELAY MODE	LIMIT SETPOINT	PULSE VALUE	PULSE WIDTH	HYSTERESIS	RELAY SIMULATION	RESET ALARM					
COMMUNICATION	RS232 USAGE	DEVICE ID	BAUD RATE	PARITY	HANDSHAKE	PRINT LIST	PRINT INITIATE	PRINT INTERVAL	PRINT TIME					
SERVICE & ANALYSIS	EXAMINE AUDIT TRAIL	ERROR LOG	SOFTWARE VERSION (Display)	PRINT SYSTEM SETUP	SELF CHECK									

These functions are displayed only with appropriate settings in other functions.


Note!

After commissioning and configuring the measuring point, please fill in the adjacent matrix with the values and settings you have selected.

Note!

VIEW HI FLOW SIGNAL

PROCESS VARIABLE	
HEAT FLOW (p. 20)	Display
MASS FLOW (p. 20)	Display
COR. VOLUME FLOW (p. 20)	Display
VOLUME FLOW (p. 20)	Display
TEMPERATURE 1 (p. 20)	Display
TEMPERATURE 2 (p. 20)	Display
DELTA TEMPERATURE (p. 21)	Display
PROCESS PRESSURE (p. 21)	Display
DIFF. PRESSURE (p. 21)	Display
DENSITY (p. 21)	Display
SPEC. ENTHALPY (p. 21)	Display
DATE & TIME (p. 21)	Display
VISCOSITY (p. 21)	Display
REYNOLDS NUMBER (p. 21)	Display
TOTALIZERS	
RESET TOTALIZER (p. 22)	Reset totalizers to 'zero' NO – YES
HEAT TOTAL (p. 22)	Display
HEAT GRAND TOTAL (p. 22)	Display (non resetable)
MASS TOTAL (p. 22)	Display
MASS GRAND TOTAL (p. 22)	Display (non resetable)
COR. VOLUME TOTAL (p. 22)	Display
COR. VOL. GRAND TOTAL (p. 22)	Display (non resetable)
VOLUME TOTAL (p. 22)	Display
VOL. GRAND TOTAL (p. 22)	Display (non resetable)
SYSTEM PARAMETERS	
QUICK SETUP (p. 23)	QUICK SETUP? NO QUICK SETUP? YES If 'YES' → Initializing memory (to factory defaults) → Several functions are shown on the display one after the other. Select options or enter numbers with $\frac{\text{E}}{\text{J}}$; store with $\frac{\text{E}}{\text{J}}$.
FLOW EQUATION (p. 24)	STEAM MASS STEAM HEAT STEAM NET HEAT STEAM DELTA HEAT GAS CORRECTED VOLUME GAS MASS GAS COMBUSTION HEAT LIQ. CORRECTED VOLUME LIQUID MASS LIQ.COMBUSTION HEAT LIQUID SENSIBLE HEAT LIQUID DELTA HEAT
ENTER DATE (p. 24)	The display flashes. Enter month, day and year with $\frac{\text{E}}{\text{J}}$; store with $\frac{\text{E}}{\text{J}}$.

SYSTEM PARAMETERS (Continued)	
ENTER TIME (p. 24)	The display flashes. Enter hours and minutes with $\frac{\text{E}}{\text{J}}$; store with $\frac{\text{E}}{\text{J}}$.
F1 KEY FUNCTION (p. 25)	LANGUAGE RATE + TOTAL TOTAL + GRAND TOTAL CLEAR TOTALIZERS PRINT TRANSACTION ACK. + CLEAR ALARMS CHANGE SETPOINT 1 CHANGE SETPOINT 2 TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP.2 DELTA TEMP.+ VOL.FLOW DIFF.PRES.+ VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS
F2 KEY FUNCTION (p. 25)	MEASURING SYSTEM RATE + TOTAL TOTAL + GRAND TOTAL CLEAR TOTALIZERS PRINT TRANSACTION ACK. + CLEAR ALARMS CHANGE SETPOINT 1 CHANGE SETPOINT 2 TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP.2 DELTA TEMP.+ VOL.FLOW DIFF.PRES.+ VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS
F3 KEY FUNCTION (p. 25)	QUICK SETUP RATE + TOTAL TOTAL + GRAND TOTAL CLEAR TOTALIZERS PRINT TRANSACTION ACK. + CLEAR ALARMS CHANGE SETPOINT 1 CHANGE SETPOINT 2 TEMP.1 + DENSITY TEMP.1 + PRESSURE TEMP.1 + TEMP.2 DELTA TEMP.+ VOL.FLOW DIFF.PRES.+ VOL.FLOW ENTHALPY + DENSITY VISCOSITY + REYNOLDS
PRIVATE CODE (p. 25)	max. 4-figure number: 0...9999 351
ACCESS CODE (p. 26)	max. 4-figure number: 0...9999 0
TAG NUMBER (p. 26)	Alphanumeric characters for each of the ten positions available: 1, 2,9; A, B,; _ , < , = , > , ? , etc.
SERIAL-NO. SENSOR (p. 26)	Alphanumeric characters for each of the ten positions: 1, 2,9; A, B,; _ , < , = , > , ? , etc.
DISPLAY	
DISPLAY LIST (p. 27)	CHANGE? NO CHANGE? YES If 'YES' → display of measured values to be indicated: $\frac{\text{E}}{\text{J}}$  Save options → next option: TIME/DATE? NO (YES) MASS FLOW/TOTAL? NO (YES) VOL.FLOW/TOTAL? NO (YES) TEMP.1/PRESSURE? NO (YES) TEMP.1/DENSITY? NO (YES) HEAT FLOW/TOTAL? NO (YES) DENS./SPEC.ENTH? NO (YES) COR.VOL./TOTAL? NO (YES) TEMP.1/TEMP.2? NO (YES) DELTA T/VOL. FLOW? NO (YES) VISC.+REYNOLDS? NO (YES)
DISPLAY DAMPING (p. 27)	max. 2-figure number: 0...99 1


DISPLAY (Continued)	
LCD CONTRAST (p. 28)	■■■■■■■■■■ Any change in contrast is immediately seen with the adjustable bar graph.
MAX.DEC. POINT (p. 28)	0 – 1 – 2 – 3 (decimal points)
LANGUAGE (p. 28)	ENGLISH – DEUTSCH – FRANCAIS
SYSTEM UNITS	
TIME BASE (p. 29)	s (per second) – m (per minute) – h (per hour) – d (per day)
HEAT FLOW UNIT (p. 29)	kBtu/unit of time – kW – MJ/unit of time – kcal/unit of time – MW – tons – GJ/unit of time – Mcal/unit of time – Gcal/unit of time
HEAT TOTAL UNIT (p. 29)	kBtu – kWh – MJ – kcal – MWh – tonh – GJ – Mcal – Gcal
MASS FLOW UNIT (p. 30)	lbs/time base – kg/time base – g/time base – t/time base – tons(US)/time base – tons(long)/time base
MASS TOTAL UNIT (p. 30)	lbs – kg – g – t – tons (US) – tons (long)
COR. VOL. FLOW UNIT (p. 30)	bbl/time base – gal/time base – l/time base – hl/time base – dm3/time base * – ft3/time base – m3/time base – scf/time base – Nm3/time base ** – NI/time base – igal/time base (* with liquids; ** with gas)
COR. VOL. TOTAL UNIT (p. 31)	bbl – gal – l – hl – dm3 * – ft3 – m3 ** – scf – Nm3 – NI – igal (* with liquids; ** with gas)
VOLUME FLOW UNIT (p. 31)	bbl/time base – gal/time base – l/time base – hl/time base – dm3/time base * – ft3/time base – m3/time base ** – acf/time base igal/time base (* with liquids; ** with gas)
VOLUME TOTAL UNIT (p. 32)	bbl – gal – l – hl – dm3 * – ft3 – m3 ** – ac – igal (* with liquids; ** with gas)
DEFINITION bbl (p. 32)	US: 31.0 gal/bbl – US: 31.5 gal/bbl – US: 42.0 gal/bbl – US: 55.0 gal/bbl – Imp: 36.0 gal/bbl – Imp: 42.0 gal/bbl
TEMPERATURE UNIT (p. 32)	°C (CELSIUS) – K (KELVIN) – °F (FAHRENHEIT) – °R (RANKINE)
PRESSURE UNIT (p. 33)	bara – kPaa – kc2a – psia – barg – psig – kPag – kc2g
DENSITY UNIT (p. 33)	kg/m3 – kg/dm3 – #/gal – #/ft3
SPEC. ENTHALPY UNIT (p. 33)	Btu/# * – kWh/kg – MJ/kg ** – kcal/kg (Unit system: * english; ** metric)
LENGTH UNIT (p. 33)	mm, in
FLUID DATA	
FLUID TYPE (p. 34)	GENERIC – WATER – SATURATED STEAM – SUPERHEATED STEAM – AIR – NATURAL GAS – AMMONIA – CARBON DIOXIDE – PROPANE – OXYGEN – ARGON – METHANE – NITROGEN – GASOLINE – NO.2 FUEL OIL – KEROSENE – NATURAL GAS (NX19) Factory setting: dependent on the flow equation selected
REF. DENSITY (p. 34)	Number with floating decimal point: 0.0001...10000.0; Factory setting: dependent on the fluid type
THERM. EXP.COEF. (p. 35)	Number with floating decimal point: 0.000...100000 (e-6); Factory setting: dependent on the fluid type

FLUID DATA (Continued)	
COMBUSTION HEAT (p. 35)	Number with floating decimal point: 0.00000...100000; Factory setting: dependent on the fluid type
SPECIFIC HEAT (p. 35)	Number with floating decimal point: 0.00000...10.0000; Factory setting: dependent on the fluid type
FLOW. Z-FACTOR (p. 36)	Number with fixed decimal point: 0.1000...10.0000; Factory setting: dependent on the fluid type
REF. Z-FACTOR (p. 36)	Number with fixed decimal point: 0.1000...10.0000; 1.0000
ISENTROPIC EXP. (p. 36)	Number with fixed decimal point: 0.1000...10.0000; 1.4000
MOLE % NITROGEN (p. 37)	Enter the MOLE % Nitrogen in the expected natural gas mixture. Number with fixed decimal point: 000.000...15.000; 00.000
MOLE % CO ₂ (p. 37)	Enter the MOLE % CO ₂ in the expected natural gas mixture. Number with fixed decimal point: 000.000...15.000; 00.000
VISCOSITY COEF. A (p.37)	Number with fixed decimal point: 0.00000...10000; 1.000
VISCOSITY COEF. B (p.37)	Number with fixed decimal point: 0.00000...10000; 1.000
FLOW INPUT	
FLOWMETER TYPE (p. 38)	PROWIRL – PROMAG – LINEAR – LINEAR 16PT – BASIC SQUARE LAW – BASIC SQUARE W/SQRT – ORIFICE – ORIFICE W/SQRT – ORIFICE 16 PT – ORIFICE 16 PT W/SQRT – NOZZLE – NOZZLE W/SQRT – NOZZLE 16 PT – NOZZLE 16 PT W/SQRT – PITOT – PITOT W/SQRT – PITOT 16 PT – PITOT 16 PT W/SQRT
INPUT SIGNAL (p. 39)	PFM – DIGITAL, 10 mV LEVEL – DIGITAL, 100 mV LEVEL – DIGITAL, 2.5 V LEVEL – 4–20 mA SPLIT – 0–20 mA SPLIT 4–20 mA – 0–20 mA – 0–5 Vdc – 1–5 Vdc – 0–10 Vdc
FULL SCALE (p. 39)	Number with floating decimal point: 0.000...999999; 0.000 [Unit] Factory setting: dependent on the selected unit and flow equation
FULL SCALE - HIGH RANGE (p.39)	Number with floating decimal point: 0.000...+999999; 0.000 [Unit] Factory setting: dependent on the selected unit and flow equation
LOW FLOW CUTOFF (p. 40)	Number with floating decimal point: 0.000...999999; 0.000 [Unit]
CALIBRATION DENSITY (p. 40)	Number with floating decimal point: 0.0001...10000; 1.0000 [Unit]
K - FACTOR (p. 40)	Number with floating decimal point: 0.001...999999; 1.000 [P/dm3]
PIPE INNER DIAMETER (p. 40)	Number with floating decimal point: 0.0001...1000.00; 1.0000 [unit]
ENTER BETA (p. 40)	Number with fixed decimal point: 0.0000...1.0000; 0.0001
METER EXP. COEF. (p. 41)	Number with fixed decimal point: 0.000...999.900 (e-6/ °X) dependent on the selected temperature unit and flowmeter

FLOW INPUT (Continued)	
DP - FACTOR (p. 41, 42)	<p>CHANGE FACTOR? NO CHANGE FACTOR? YES</p> <p>If 'YES' → further choice: COMPUTE FACTOR? NO COMPUTE FACTOR? YES</p> <p>If 'NO' → enter DP FACTOR directly</p> <p>If 'YES' → display of different parameters which can be entered or changed one after the other:</p> <p>ENTER DELTA PRESSURE ENTER FLOWRATE ENTER DENSITY ENTER TEMPERATURE ENTER INLET PRESSURE ENTER ISENTROPIC EXP</p>
LOW PASS FILTER (p. 43)	max. 5-figure number: 10...40000 [Hz] 40000 Hz
LINEARIZATION (p. 44)	<p>CHANGE TABLE? NO CHANGE TABLE? YES</p> <p>'YES' → correction factors can be entered for up to 16 different flow rates.</p> <p>Example: Entry of current value INPUT mA 5.00 POINT 0 Entry of corresponding flowrate: RATE 0.25 m³/h POINT 0</p>
FLOWMETER LOCATION (p. 44)	Select the location of the flowmeter in a 'delta heat' application HOT – COLD
VIEW INPUT SIGNAL (p. 44)	Display of actual flow input signal
VIEW HI FLOW SIGNAL (p. 44)	Display of actual flow input signal of the hi-range input signal of split range DP transmitter
COMPENSATION INPUT	
SELECT INPUT (p. 45)	<p>1 – 2</p> <p>Input 1: Temperature 1 Input 2: Pressure, Temperature 2, Density</p>
INPUT SIGNAL (p. 45)	<p><i>Input 1 (Temperature 1):</i></p> <p>INPUT 1 NOT USED RTD TEMPERATURE 4–20 TEMPERATURE 0–20 TEMPERATURE MANUAL TEMPERATURE</p> <p><i>Input 2 (Pressure, Temperature 2, Density):</i></p> <p>INPUT 2 NOT USED 4–20 PRESSURE (G) 0–20 PRESSURE (G) MANUAL PRESSURE 4–20 PRESSURE (ABS.) 0–20 PRESSURE (ABS.) RTD TEMPERATURE 2 4–20 TEMPERATURE 2 0–20 TEMPERATURE 2 MANUAL TEMPERATURE 2 4–20 DENSITY 0–20 DENSITY MANUAL DENSITY</p> <p>Factory setting: dependent on the flow equation and the input selected (1 or 2)</p>
LOW SCALE VALUE (p. 45)	Number with fixed decimal point: –9999.99...+9999.99 [unit] Factory setting: dependent on the flow equation and the input selected (1 or 2)

COMPENSATION INPUT (Continued)	
FULL SCALE VALUE (p. 45)	Number with fixed decimal point: –9999.99...+9999.99 [unit] Factory setting: dependent on the flow equation and the input selected (1 or 2)
DEFAULT VALUE (p. 46)	Number with fixed decimal point: –9999.99...+9999.99 [unit] Temperature → 21 °C Pressure → 0 psig (1.013 bara) Density → 62.358 #/ft³ (998.9 kg/m³)
STP REFERENCE (p. 46)	Number with fixed decimal point: –9999.99...+9999.99 [unit] Pressure → 1.013 bara Temperature → dependent on units: <ul style="list-style-type: none"> Metric unit system: Gas → 0 °C Liquid → 20 °C English unit system: Gas/Liquid → 70 °F
BAROMETRIC PRESS. (p. 46)	Number with floating decimal point: 0.0000...10000.0 14.696 psia (1.013 bara)
LOW DELTA T CUT-OFF (p. 46)	Number with fixed decimal point: 0.00...99.9; 0.0 [temperature unit]
VIEW INPUT SIGNAL (p. 46)	Display of actual input signal.
PULSE OUTPUT	
ASSIGN PULSE OUTPUT (p. 47)	HEAT TOTAL MASS TOTAL CORRECTED VOL. TOTAL ACTUAL VOLUME TOTAL Factory setting: dependent on the flow equation selected.
PULSE TYPE (p. 48)	PASSIVE / NEGATIVE PASSIVE / POSITIVE ACTIVE / NEGATIVE ACTIVE / POSITIVE
PULSE VALUE (p. 49)	Number with floating decimal point: 0.001...1000.00; 1.000 [Unit/pulse]
PULSE WIDTH (p. 49)	Number with floating decimal point: 0.01...10.00 s; 0.01 s
SIMULATION FREQ. (p. 49)	OFF – 0.0 Hz – 0.1 Hz – 1.0 Hz – 10 Hz – 50 Hz
CURRENT OUTPUT	
SELECT OUTPUT (p. 50)	1 – 2
ASSIGN CURRENT OUT. (p. 50)	HEAT FLOW – MASS FLOW – COR. VOLUME FLOW – VOLUME FLOW – TEMPERATURE 1 – TEMPERATURE 2 – DELTA TEMPERATURE – PRESSURE – DENSITY – VISCOSITY – REYNOLDS NUMBER Factory setting: dependent on the flow equation selected.
CURRENT RANGE (p. 50)	0–20 mA – 4–20 mA – NOT USED
LOW SCALE VALUE (p. 50)	Number with floating decimal point: –999999...+999999; 0.000 [unit]
FULL SCALE VALUE (p. 50)	Number with floating decimal point: –999999...+999999; 1.000 [unit]
TIME CONSTANT (p. 51)	max. 2-figure number: 0...99 1
CURRENT OUT VALUE (p. 51)	Display of current target value in [mA]
SIMULATION CURRENT (p. 51)	OFF – 0 mA – 2 mA – 4 mA – 12 mA – 20 mA – 25 mA

RELAYS	
SELECT RELAY (p. 52)	1 (Relay 1) – 2 (Relay 2)
RELAY FUNCTION (p. 52)	HEAT TOTAL – MASS TOTAL – CORRECTED VOL. TOTAL – ACTUAL VOLUME TOTAL – HEAT FLOW – MASS FLOW – COR. VOL.FLOW – VOLUME FLOW – TEMPERATURE 1 – TEMPERATURE 2 – DELTA TEMPERATURE – PRESSURE – DENSITY – WET STEAM ALARM – MALFUNCTION – VISCOSITY – REYNOLDS NUMBER Factory setting: dependent on the flow equation selected.
RELAY MODE (p. 53)	HI ALARM, FOLLOW LO ALARM, FOLLOW HI ALARM, LATCH LO ALARM, LATCH RELAY PULSE OUTPUT
LIMIT SETPOINT (p. 53)	Number with floating decimal point: –999999...+999999; 50000 [Unit] with process variables
PULSE VALUE (p. 54)	With 'RELAY PULSE OUTPUT' Number with floating decimal point: 0.001...100,000,000; 1000 [Unit]
PULSE WIDTH (p. 54)	Number with fixed dec. point: 0.1...9.9 s (RELAY PULSE OUTPUT) or 0.0...9.9 s (all other configurations) 0.0 s resp. 0.1 s with "RELAY PULSE OUTPUT"
HYSTERESIS (p. 54)	Number with floating decimal point: 0.000...999999; 0.000 [Unit]
RELAY SIMULATION (p. 56)	NO – Relay ON – Relay OFF
RESET ALARM (p. 56)	RESET ALARM? NO RESET ALARM? YES
COMMUNICATION	
RS232 USAGE (p. 57)	COMPUTER – PRINTER
DEVICE ID (p. 57)	max. 2-figure number: 0...99 1
BAUD RATE (p. 57)	9600 – 2400 – 1200 – 300
PARITY (p. 57)	NONE – ODD – EVEN
HANDSHAKE (p. 58)	NONE – HARDWARE

COMMUNICATION (Continued)	
PRINT LIST (p. 58)	CHANGE? NO CHANGE? YES If 'YES' → display of measured values to be printed: E  save option print → next option PRINT HEADER? NO (YES) INSTRUMENT TAG? NO (YES) FLUID TYPE? NO (YES) TIME? NO (YES) DATE? NO (YES) TRANSACTION NO.? NO (YES) HEAT FLOW? NO (YES) HEAT TOTAL? NO (YES) HEAT GRAND TOTAL? NO (YES) MASS FLOW? NO (YES) MASS TOTAL? NO (YES) MASS GRAND TOTAL? NO (YES) COR. VOLUME FLOW? NO (YES) COR. VOLUME TOTAL? NO (YES) COR.VOL.GRAND TOTAL? NO (YES) VOLUME FLOW? NO (YES) VOLUME TOTAL? NO (YES) VOL. GRAND TOTAL? NO (YES) TEMPERATURE 1? NO (YES) TEMPERATURE 2? NO (YES) DELTA TEMPERATURE NO (YES) PROCESS PRESSURE NO (YES) DENSITY NO (YES) SPEC. ENTHALPY NO (YES) VISCOSITY NO (YES) REYNOLDS NUMBER NO (YES) ERRORS NO (YES) ALARMS NO (YES)
PRINT INITIATE (p. 59)	NONE – TIME OF DAY – INTERVAL
PRINT INTERVAL (p. 59)	The display flashes. Enter values for hours and minutes. Store with E . 00:00
PRINT TIME (p. 59)	The display flashes. Enter values for hours and minutes. Store with E . 00:00
SERVICE & ANALYSIS	
EXAMINE AUDIT TRAIL (p. 60)	Display of changes of important calibration and configuration data ("electronic seal"). Example: CAL 185 CFG 969
ERROR LOG (p. 60)	Display of logged system error messages Example: POWER FAILURE
SOFTWARE VERSION (p. 60)	Display of actual software version: e.g. 02.00.00
PRINT SYSTEM SETUP (p. 60)	NO – YES 'YES' → Prints of actual parameter settings on the connected printer.
SELF CHECK (p. 60)	RUN? NO RUN? YES 'YES' → starts of internal checks

Index

A

Access code	26
Address (device identification)	57
Alarm reset (relays)	56
Alarm response (relays)	53, 55
Applications	5, 67
Audit trail	60

B

Barometric pressure	46
Barrels (bbl)	32
Baud rate	57

C

Code number	25
Combustion heat	35
Compensation input	45
Correct usage	2
Creep suppression (low flow cutoff)	40
Current output (1 or 2)	50
Current output (assign process variables)	50
Current range	50

D

Date & time (display)	21
Date / Time (setting)	24
Decimal point	28
Default value (temperature, pressure,)	46
Device identification	57
Dimensions	82
Display	14
Display (process variables)	20
Display configuration	27
Display contrast	28
Display damping	27
Display list (configuring)	27
DP-Factor (differential pressure)	41

E

Electrical connection (inputs/outputs)	9
Electrical connection (measuring instruments)	10
Electrical connection (RS 232 interface)	12
Error log	60
Error messages (display)	62
Expansion coefficient (flowmeter pipe)	41
Expansion coefficient (liquids)	35

F

Factory settings/Possible settings (overview)	86
Flow equation	24
Flow equations / Applications (description)	67
Flow input (electrical connection)	10
Flowmeter location	44

Flowmeter type	38
Fluid type	34
Full scale (current output)	50
Full scale (flow input)	39
Full scale (temperature, pressure, density)	45
Full scale - high range	39
Function group COMMUNICATION	57
Function group COMPENSATION INPUT	45
Function group CURRENT OUTPUT	50
Function group DISPLAY	27
Function group FLOW INPUT	38
Function group FLUID DATA	34
Function group PROCESS VARIABLE	20
Function group PULSE OUTPUT	47
Function group RELAYS	52
Function group SERVICE & ANALYSIS	60
Function group SYSTEM PARAMETERS	23
Function group SYSTEM UNITS	29
Function group TOTALIZERS	22
Function keys (F1, F2, F3)	14, 25
Functions (description)	19
Functions (overview)	86

G

Gallons (gal)	32
-------------------------	----

H

Handshake	58
Hysteresis (relays, limit setpoint)	54

I

Input (temperature, pressure, density)	45
Input signal (flow)	39
Input signal type	45
Inputs	6
Inputs (technical data)	81
Isentropic exponent	36

K

K-Factor	40
--------------------	----

L

Limit setpoint (relays)	53
Linearisation	43, 44
Low delta T cutoff	46
Low flow cutoff (creep)	40
Low pass filter	43
Low scale (current output)	50
Low scale (temperatur, pressure, density)	45

M

Mole % CO ₂	37
Mole % Nitrogen	37
Mounting and installation	7

N

Natural gas (NX-19)	34
-------------------------------	----

O

Operating elements	14
Operating language	28
Operation (Programming)	13
Operational safety	2
Orifice diameter ratio (beta)	40
Outputs	6
Outputs (technical data)	81

P

Panel mounted housing	7
Parity	57
Pipe inner diameter	40
Pressure input	45
Pressure input (electrical connection)	11
Print initiate	59
Print interval	59
Print list (variables to be printed)	58
Print system setup	60
Print time	59
Private code (personal code)	25
Process error messages	63
Process variables (display)	20
Programming (general information)	19
Programming at a glance	84
Programming with Quick Setup menu	15
Programming with the E+H matrix	18
Pulse output (assignment)	47
Pulse type	48
Pulse value	49
Pulse value (relays)	54
Pulse width	49
Pulse width (relays)	54

Q

Quick Setup	15, 23
-----------------------	--------

R

Reference density	34
Reference values (pressure, temperature)	46
Reference Z-Factor	36
Relay alarm response	55
Relay function	52
Relay limit setpoint	53
Relay mode (for alarm)	53
Relay output (1 or 2)	52
Relay simulation	56
Repairs	2

Reynolds number (display)	21
RS 232 interface (electrical connection)	12
RS 232 usage	57

S

Safety instructions	2
Self check	60
Serial Number (sensor)	26
Simulation (current output)	51
Simulation (pulse output)	49
Simulation (relay)	56
Software version	60
Specific heat	35
Switching point (relays)	53
System description	5
System error messages	62
System units	29, 87

T

Tag number	26
Technical data	81
Temperature input (electrical connection)	11
Terminal designation	9
Time / Date (setting)	24
Time base (for measuring variables)	29
Time constant (current output)	51
Totalizer (display)	22
Totalizer reset	22
Troubleshooting	61

U

Units	29, 87
-----------------	--------

V

View input signal	44, 46
Vortex flowmeter	38

W

Wall mounted housing	8
--------------------------------	---

Z

Z-Factor (operating conditions)	36
Z-Factor (reference conditions)	36

Europe		
Austria □ Endress+Hauser Ges.m.b.H. Wien Tel. (01) 88056-0, Fax (01) 88056-35		
Belarus □ Belorgsintez Minsk Tel. (0172) 508473, Fax (0172) 508583		
Belgium / Luxembourg □ Endress+Hauser N.V. Brussels Tel. (02) 2480600, Fax (02) 2480553		
Bulgaria INTERTECH-AUTOMATION Sofia Tel. (02) 664869, Fax (02) 9631389		
Croatia □ Endress+Hauser GmbH+Co. Zagreb Tel. (01) 6637785, Fax (01) 6637823		
Cyprus I+G Electrical Services Co. Ltd. Nicosia Tel. (02) 484788, Fax (02) 484690		
Czech Republic □ Endress+Hauser GmbH+Co. Praha Tel. (026) 6784200, Fax (026) 6784179		
Denmark □ Endress+Hauser A/S Søborg Tel. (70) 131132, Fax (70) 132133		
Estonia ELVI-Aqua Tartu Tel. (7) 441638, Fax (7) 441582		
Finland □ Endress+Hauser Oy Helsinki Tel. (0204) 83160, Fax (0204) 83161		
France □ Endress+Hauser S.A. Huningue Tel. (389) 696768, Fax (389) 694802		
Germany □ Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 975-01, Fax (07621) 975-555		
Great Britain □ Endress+Hauser Ltd. Manchester Tel. (0161) 2865000, Fax (0161) 9981841		
Greece I & G Building Services Automation S.A. Athens Tel. (01) 9241500, Fax (01) 9221714		
Hungary Mile Ipari-Elektro Budapest Tel. (01) 4319800, Fax (01) 4319817		
Iceland BIL ehf Reykjavik Tel. (05) 619616, Fax (05) 619617		
Ireland Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182		
Italy □ Endress+Hauser S.p.A. Cernusco s/N Milano Tel. (02) 921921, Fax (02) 92107153		
Latvia Rino TK Riga Tel. (07) 315087, Fax (07) 315084		
Lithuania UAB "Agava" Kaunas Tel. (07) 202410, Fax (07) 207414		
Netherland □ Endress+Hauser B.V. Naarden Tel. (035) 6958611, Fax (035) 6958825		
Norway □ Endress+Hauser A/S Tranby Tel. (032) 859850, Fax (032) 859851		
Poland □ Endress+Hauser Polska Sp. z o.o. Warszawy Tel. (022) 7201090, Fax (022) 7201085		
Portugal Tecnisis, Lda Cacém Tel. (21) 4267290, Fax (21) 4267299		
Romania Romconseng S.R.L. Bucharest Tel. (01) 4101634, Fax (01) 4112501		
Russia □ Endress+Hauser Moscow Office Moscow Tel. (095) 1587564, Fax (095) 1589871		
Slovakia Transcom Technik s.r.o. Bratislava Tel. (7) 44888684, Fax (7) 44887112		
Slovenia □ Endress+Hauser D.O.O. Ljubljana Tel. (061) 5192217, Fax (061) 5192298		
Spain □ Endress+Hauser S.A. Sant Just Desvern Tel. (93) 4803366, Fax (93) 4733839		
Sweden □ Endress+Hauser AB Sollentuna Tel. (08) 55511600, Fax (08) 55511655		
Switzerland □ Endress+Hauser Metso AG Reinach/BL 1 Tel. (071) 7157575, Fax (061) 7111650		
Turkey Intek Endüstriyel Ölçü ve Kontrol Sistemleri İstanbul Tel. (0212) 2751355, Fax (0212) 2662775		
Ukraine Photonika GmbH Kiev Tel. (44) 26881, Fax (44) 26908		
Yugoslavia Rep. Meris d.o.o. Beograd Tel. (11) 4441966, Fax (11) 4441966		
Africa		
Egypt Anasia Heliopolis/Cairo Tel. (02) 4179007, Fax (02) 4179008		
Morocco Oussama S.A. Casablanca Tel. (02) 241338, Fax (02) 402657		
South Africa □ Endress+Hauser Pty. Ltd. Sandton Tel. (011) 4441386, Fax (011) 4441977		
Tunisia Contrôle, Maintenance et Regulation Tunis Tel. (01) 793077, Fax (01) 788595		
America		
Argentina □ Endress+Hauser Argentina S.A. Buenos Aires Tel. (01) 145227970, Fax (01) 145227909		
Bolivia Tritec S.R.L. Cochabamba Tel. (042) 56993, Fax (042) 50981		
Brazil □ Samson Endress+Hauser Ltda. Sao Paulo Tel. (011) 50313455, Fax (011) 50313067		
Canada □ Endress+Hauser Ltd. Burlington, Ontario Tel. (905) 6819292, Fax (905) 6819444		
Chile □ Endress+Hauser Chile Ltd. Santiago Tel. (02) 3213009, Fax (02) 3213025		
Colombia Colsein Ltda. Bogota D.C. Tel. (01) 2367659, Fax (01) 6104186		
Costa Rica EURO-TEC S.A. San Jose Tel. (02) 961542, Fax (02) 961542		
Ecuador Insetec Cia. Ltda. Quito Tel. (02) 269148, Fax (02) 461833		
Guatemala ACISA Automatizacion Y Control Industrial S.A. Ciudad de Guatemala, C.A. Tel. (03) 345985, Fax (03) 327431		
Mexico □ Endress+Hauser S.A. de C.V. Mexico City Tel. (5) 5682405, Fax (5) 5687459		
Paraguay Incoel S.R.L. Asuncion Tel. (021) 213989, Fax (021) 226583		
Uruguay Circular S.A. Montevideo Tel. (02) 925785, Fax (02) 929151		
USA □ Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 535-7138, Fax (317) 535-8498		
Venezuela Contraval C.A. Caracas Tel. (02) 9440966, Fax (02) 9444554		
Asia		
China □ Endress+Hauser Shanghai Instrumentation Co. Ltd. Shanghai Tel. (021) 54902300, Fax (021) 54902303		
□ Endress+Hauser Beijing Office Beijing Tel. (010) 68344058, Fax (010) 68344068		
Hong Kong □ Endress+Hauser HK Ltd. Hong Kong Tel. 25283120, Fax 28654171		
India □ Endress+Hauser (India) Pvt Ltd. Mumbai Tel. (022) 8521458, Fax (022) 8521927		
Indonesia PT Grama Bazita Jakarta Tel. (21) 7975083, Fax (21) 7975089		
Japan □ Sakura Endress Co. Ltd. Tokyo Tel. (0422) 540613, Fax (0422) 550275		
Malaysia □ Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 7334848, Fax (03) 7338800		
Pakistan Speedy Automation Karachi Tel. (021) 7722953, Fax (021) 7736884		
Papua-Neuguinea SBS Electrical Pty Limited Port Moresby Tel. 3251188, Fax 3259556		
Philippines □ Endress+Hauser Philippines Inc. Metro Manila Tel. (2) 3723601-05, Fax (2) 4121944		
Singapore □ Endress+Hauser (S.E.A.) Pte., Ltd. Singapore Tel. 5668222, Fax 5666848		
South Korea □ Endress+Hauser (Korea) Co., Ltd. Seoul Tel. (02) 6587200, Fax (02) 6592838		
Taiwan Kingjari Corporation Taipei R.O.C. Tel. (02) 27183938, Fax (02) 27134190		
Thailand □ Endress+Hauser Ltd. Bangkok Tel. (2) 9967811-20, Fax (2) 9967810		
Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8335225, Fax (08) 8335227		
Iran PATSA Co. Tehran Tel. (021) 8754748, Fax (021) 8747761		
Israel Instrumetrics Industrial Control Ltd. Netanya Tel. (09) 8357090, Fax (09) 8350619		
Jordan A.P. Parpas Engineering S.A. Amman Tel. (06) 4643246, Fax (06) 4645707		
Kingdom of Saudi Arabia Anasia Ind. Agencies Jeddah Tel. (02) 6710014, Fax (02) 6725929		
Lebanon Network Engineering Jbeil Tel. (3) 944080, Fax (9) 548038		
Sultanate of Oman Mustafa Sultan Science & Industry Co. LLC. Ruwi Tel. 602009, Fax 607066		
United Arab Emirates Descon Trading EST. Dubai Tel. (04) 2653651, Fax (04) 2653264		
Yemen Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 230664, Fax (04) 212338		
Australia + New Zealand		
Australia ALSTOM Australia Limited Milperra Tel. (02) 97747444, Fax (02) 97744667		
New Zealand EMC Industrial Group Limited Auckland Tel. (09) 4155110, Fax (09) 4155115		
All other countries		
□ Endress+Hauser GmbH+Co. Instruments International D-Weil am Rhein Germany Tel. (07621) 975-02, Fax (07621) 975345		