

Description of Device Parameters

Dosimag

Electromagnetic flowmeter




Table of contents

1 Document information	4
1.1 Document function	4
1.2 Target group	4
1.3 Using this document	4
1.3.1 Information on the document structure	4
1.3.2 Structure of a parameter description	6
1.4 Symbols used	6
1.4.1 Symbols for certain types of information	6
1.4.2 Symbols in graphics	6
2 Overview of the Expert operating menu	7
3 Description of device parameters	9
3.1 "System" submenu	10
3.1.1 "Diagnostic handling" submenu	11
3.1.2 "Administration" submenu	13
3.2 "Sensor" submenu	14
3.2.1 "Measured values" submenu	15
3.2.2 "System units" submenu	19
3.2.3 "Process parameters" submenu	23
3.2.4 "Sensor adjustment" submenu	27
3.2.5 "Calibration" submenu	29
3.3 "Output" submenu	30
3.3.1 "Pulse/frequency/switch output 1 to 2" submenu	30
3.4 "Application" submenu	49
3.4.1 "Totalizer 1 to 3" submenu	49
3.5 "Diagnostics" submenu	53
3.5.1 "Diagnostic list" submenu	56
3.5.2 "Event logbook" submenu	61
3.5.3 "Device information" submenu	62
3.5.4 "Simulation" submenu	65
4 Country-specific factory settings ...	68
4.1 SI units	68
4.1.1 System units	68
4.1.2 On value low flow cut off	68
4.2 US units	68
4.2.1 System units	68
4.2.2 On value low flow cut off	68
5 Explanation of abbreviated units ...	70
5.1 SI units	70
5.2 US units	70
5.3 Imperial units	71
Index	72

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document


1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→  7).



 1 *Sample graphic*

 For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→  53), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter =
Navigation	Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are displayed in abbreviated format.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Options	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

» Expert	
Locking status	→ 9
Access status tooling	→ 10
Enter access code	→ 10
▶ System	→ 10
▶ Diagnostic handling	→ 11
▶ Administration	→ 13
▶ Sensor	→ 14
▶ Measured values	→ 15
▶ System units	→ 19
▶ Process parameters	→ 23
▶ Sensor adjustment	→ 27
▶ Calibration	→ 29
▶ Output	→ 30
▶ Pulse/frequency/switch output 1 to 2	→ 30
▶ Application	→ 49
Reset all totalizers	→ 49
▶ Totalizer 1 to 3	→ 49
▶ Diagnostics	→ 53
Actual diagnostics	→ 54
Timestamp	→ 54
Actual diagnostics	→ 54

Previous diagnostics	→ 55
Timestamp	→ 55
Previous diagnostics	→ 55
Operating time from restart	→ 56
Operating time	→ 56
► Diagnostic list	→ 56
► Event logbook	→ 61
► Device information	→ 62
► Simulation	→ 65

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the operating tool.

⚡ Expert	
Locking status	→ 9
Access status tooling	→ 10
Enter access code	→ 10
▶ System	→ 10
▶ Sensor	→ 14
▶ Output	→ 30
▶ Application	→ 49
▶ Diagnostics	→ 53

Locking status

Navigation  Expert → Locking status

Description Use this function to view the active write protection.

User interface Temporarily locked

Additional information *Display*

In the operating tool all active types of write protection are selected.

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→ 9).

"Temporarily locked" option (priority 3)

Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Access status tooling


Navigation	 Expert → Access stat.tool
Description	Use this function to view the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> The access authorization can be modified via the Enter access code parameter.</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  9).</p> <p><i>Display</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Enter access code

Navigation	 Expert → Ent. access code
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	0 to 9 999

3.1 "System" submenu

Navigation  Expert → System




3.1.1 "Diagnostic handling" submenu

Navigation



Expert → System → Diagn. handling



Alarm delay



Navigation



Expert → System → Diagn. handling → Alarm delay

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information

Description

This setting affects the following diagnostic messages:

- 004 Sensor
- 062 Sensor connection
- 082 Data storage
- 083 Memory content
- 242 Software incompatible
- 270 Main electronic failure
- 272 Main electronic failure
- 273 Main electronic failure
- 281 Electronic initialization
- 311 Electronic failure
- 322 Electronic drift
- 442 Frequency output 1 to 2
- 443 Pulse output 1 to 2
- 453 Flow override
- 500 Electrode difference voltage too high
- 832 Electronic temperature too high
- 833 Electronic temperature too low
- 834 Process temperature too high
- 835 Process temperature too low
- 937 EMC interference
- 938 EMC interference

"Diagnostic behavior" submenu

 For a list of all the diagnostic events, see the Operating Instructions for the device.

 Modifying the diagnostic behavior of a diagnostic event. Each diagnostic event is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostics events.

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

- **Off** option

The device continues to measure. The diagnostic event is ignored; it is neither entered into the Event logbook, nor is a diagnostic message generated.

- **Alarm** option

The device continues to measure. The signal outputs assume the specified alarm condition. A diagnostic message is generated.

- **Warning** option


The device continues to measure. A diagnostic message is generated.

- **Logbook entry only** option

The device continues to measure. The diagnostic message is only entered in the **Event logbook** submenu (→  61).

Navigation

 Expert → System → Diagn. handling → Diagn. behavior



Assign behavior of diagnostic no. 442 (Frequency output 1 to 2)



Navigation

 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the diagnostic message **442 Frequency output 1 to 2**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

 For a detailed description of the options available, see →  12

Assign behavior of diagnostic no. 443 (Pulse output 1 to 2)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 443 Pulse output 1 to 2 .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 12

Assign behavior of diagnostic no. 937 (EMC interference)




Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937
Description	Use this function to change the diagnostic behavior of the diagnostic message 937 EMC interference .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 12

3.1.2 "Administration" submenu

Navigation

Expert → System → Administration



Device reset**Navigation**

Expert → System → Administration → Device reset

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device

Factory setting

Cancel

Additional information

"Cancel" option

No action is executed and the user exits the parameter.

"To delivery settings" option

All the parameters are reset to their factory settings.

"Restart device" option

The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Permanent storage**Navigation**

Expert → System → Administration → Perm. storage

Description

Use this function to switch permanent storage on and off.

Selection

- Off
- On


Factory setting


On

3.2 "Sensor" submenu

Navigation

Expert → Sensor






3.2.1 "Measured values" submenu

Navigation



Expert → Sensor → Measured val.




"Process variables" submenu

Navigation



Expert → Sensor → Measured val. → Process variab.



Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow

Description

Use this function to view the volume flow currently measured.

User interface

Signed floating-point number

Additional information


Dependency

The unit is taken from the **Volume flow unit** parameter (→ 19)

Totalizer

Navigation

Diagram: Expert → Sensor → Measured val. → Totalizer



Totalizer value 1 to 3

Navigation

Diagram: Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3

Prerequisite

In the **Assign process variable** parameter (→ 50) of the **Totalizer 1 to 3** submenu, the **Volume flow** option is selected.

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information

Description

As it is only possible to display a maximum of 7 digits, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to 3** parameter if the display range is exceeded.

i In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 52).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 51).

i The unit of the selected process variable is specified for the totalizer in the **Assign process variable** parameter. If the following is selected in the **Assign process variable** parameter:
Volume flow option: **Volume flow unit** parameter (→ 19)

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 1 · 10⁷ (1 overflow) = 10 000 000 [m³]
- Current totalizer reading: 10 196 845.7 m³

Totalizer overflow 1 to 3

Navigation  Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to 3

Prerequisite In the **Assign process variable** parameter (→ [50](#)) of the **Totalizer 1 to 3** submenu, the **Volume flow** option is selected.

Description Displays the current totalizer overflow.

User interface Integer with sign

Additional information *Description*

If the current reading has more than 7 digits, which is the maximum value range that can be displayed, the value above this range is given as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to 3** parameter.

User interface

 The unit of the selected process variable is specified for the totalizer in the **Assign process variable** parameter. If the following is selected in the **Assign process variable** parameter:
Volume flow option: **Volume flow unit** parameter (→ [19](#))

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 2 · 10⁷ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 20 196 845.7 m³


"Output values" submenu

Navigation  Expert → Sensor → Measured val. → Output values

 Output values	
Pulse output 1	→ 18
Output frequency 1	→ 19
Switch status 1	→ 19
Output frequency 2	→ 19
Pulse output 2	→ 18
Switch status 2	→ 19

Pulse output

Navigation	█ Expert → Sensor → Measured val. → Output values → Pulse output 1 to 2
Prerequisite	One of the following options is selected in the Operating mode parameter (→ 31): ■ Pulse ■ Automatic pulse
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open emitter output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ■ The Value per pulse parameter (→ 34) and the Pulse width parameter (→ 35) (Operating mode (→ 31) Pulse) can be used to define the value (i.e. the amount of the measured value that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

0 Non-conductive
 1 Conductive
 NC Normally closed
 NO Normally opened

The output behavior can be inverted via the **Invert output signal** parameter (→ 48), i.e., the transistor is not conductive for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→ 36)) can be configured.

i The duration of the pulses must be defined as a function of the input card used. The pulse(s) must not exceed the maximum input frequency of the counter card.

Output frequency


Navigation	█ Expert → Sensor → Measured val. → Output values → Output freq. 1 to 2
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 10 000.0 Hz

Switch status

Navigation	█ Expert → Sensor → Measured val. → Output values → Switch status 1 to 2
Prerequisite	In the Operating mode parameter (→ 31), the Switch option is selected.
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ■ Open ■ Closed

3.2.2 "System units" submenu

Navigation █ Expert → Sensor → System units



Volume flow unit

Navigation	█ Expert → Sensor → System units → Volume flow unit
Description	Use this function to select the unit for the volume flow.

Selection

- | <i>SI units</i> | <i>US units</i> | <i>Imperial units</i> |
|------------------------|------------------------|-----------------------|
| ■ cm ³ /s | ■ af/s | ■ gal/s (imp) |
| ■ cm ³ /min | ■ af/min | ■ gal/min (imp) |
| ■ cm ³ /h | ■ af/h | ■ gal/h (imp) |
| ■ cm ³ /d | ■ af/d | ■ gal/d (imp) |
| ■ dm ³ /s | ■ ft ³ /s | ■ Mgal/s (imp) |
| ■ dm ³ /min | ■ ft ³ /min | ■ Mgal/min (imp) |
| ■ dm ³ /h | ■ ft ³ /h | ■ Mgal/h (imp) |
| ■ dm ³ /d | ■ ft ³ /d | ■ Mgal/d (imp) |
| ■ m ³ /s | ■ fl oz/s (us) | ■ bbl/s (imp;beer) |
| ■ m ³ /min | ■ fl oz/min (us) | ■ bbl/min (imp;beer) |
| ■ m ³ /h | ■ fl oz/h (us) | ■ bbl/h (imp;beer) |
| ■ m ³ /d | ■ fl oz/d (us) | ■ bbl/d (imp;beer) |
| ■ ml/s | ■ gal/s (us) | ■ bbl/s (imp;oil) |
| ■ ml/min | ■ gal/min (us) | ■ bbl/min (imp;oil) |
| ■ ml/h | ■ gal/h (us) | ■ bbl/h (imp;oil) |
| ■ ml/d | ■ gal/d (us) | ■ bbl/d (imp;oil) |
| ■ l/s | ■ kgal/s (us) | |
| ■ l/min | ■ kgal/min (us) | |
| ■ l/h | ■ kgal/h (us) | |
| ■ l/d | ■ kgal/d (us) | |
| ■ hl/s | ■ Mgal/s (us) | |
| ■ hl/min | ■ Mgal/min (us) | |
| ■ hl/h | ■ Mgal/h (us) | |
| ■ hl/d | ■ Mgal/d (us) | |
| ■ Ml/s | ■ bbl/s (us;liq.) | |
| ■ Ml/min | ■ bbl/min (us;liq.) | |
| ■ Ml/h | ■ bbl/h (us;liq.) | |
| ■ Ml/d | ■ bbl/d (us;liq.) | |
| | ■ bbl/s (us;beer) | |
| | ■ bbl/min (us;beer) | |
| | ■ bbl/h (us;beer) | |
| | ■ bbl/d (us;beer) | |
| | ■ bbl/s (us;oil) | |
| | ■ bbl/min (us;oil) | |
| | ■ bbl/h (us;oil) | |
| | ■ bbl/d (us;oil) | |
| | ■ bbl/s (us;tank) | |
| | ■ bbl/min (us;tank) | |
| | ■ bbl/h (us;tank) | |
| | ■ bbl/d (us;tank) | |

Custom-specific units

- User vol./s
- User vol./min
- User vol./h
- User vol./d

Factory setting

Country-specific:

- ml/s
- fl oz/s (us)

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  15)*Options*
 For an explanation of the abbreviated units: →  70

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→ 22).

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Custom-specific units

User vol.

Factory setting

Country-specific:

- ml
- fl oz (us)

Additional information*Options*

 For an explanation of the abbreviated units: → 70

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→ 22).

Date/time format**Navigation**

Expert → Sensor → System units → Date/time format

Description

Use this function to select the desired time format for calibration history.

Selection


- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*For an explanation of the abbreviated units: → [70](#)**"User-specific units" submenu***Navigation*

Expert → Sensor → System units → User-spec. units

**User volume text****Navigation**

Expert → Sensor → System units → User-spec. units → Volume text

Description

Use this function to enter a text for the user-specific unit of volume and volume flow. The corresponding time units (s, min, h, d) for volume flow are generated automatically.

User entry

Max. 10 characters such as letters, numbers or special characters (@, %, /)

Factory setting

User vol.

Additional information*Result*

The defined unit is shown as an option in the choose list of the following parameters:

- **Volume flow unit** parameter (→ [19](#))
- **Volume unit** parameter (→ [21](#))

Example

If the text GLAS is entered, the choose list of the **Volume flow unit** parameter (→ [19](#)) shows the following options:

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

User volume factor**Navigation**

Expert → Sensor → System units → User-spec. units → Volume factor

Description

Use this function to enter a quantity factor for the user-specific volume and volume flow unit.


User entry Signed floating-point number

Factory setting 1.0

3.2.3 "Process parameters" submenu

Navigation

Expert → Sensor → Process param.



Flow override

Navigation Expert → Sensor → Process param. → Flow override

Description Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection
■ Off
■ On

Factory setting Off

Additional information *Effect*

This setting affects all the functions of the measuring device.

Positive zero return is not relevant for most applications.

Description

The volume flow is set to **0**.

Flow override is active


- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: 0
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized

"Low flow cut off" submenu

Low flow cut off is an important function for many applications to shut out inherent noise from the measuring device and the application in the lower measuring range. If the flow drops below a certain minimum value, the value is set to **0** so that the flow signal can be kept at the zero point between two batches.

Navigation

Expert → Sensor → Process param. → Low flow cut off

**Assign process variable****Navigation**

Expert → Sensor → Process param. → Low flow cut off → Assign variable

Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow

Factory setting

Volume flow

On value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → On value

Prerequisite

In the **Assign process variable** parameter (→ 24), the **Volume flow** option is selected.

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → 25.

User entry

Signed floating-point number


Factory setting

Depends on country and nominal diameter → 68

Additional information*Dependency*

The unit depends on the process variable selected in the **Assign process variable** parameter (→ 24).

Off value low flow cutoff

Navigation	Expert → Sensor → Process param. → Low flow cut off → Off value																
Prerequisite	In the Assign process variable parameter (→ 24), the Volume flow option is selected.																
Description	Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value (→ 24).																
User entry	0 to 100.0 %																
Factory setting	50 %																
Additional information	<p><i>Example</i></p> <ul style="list-style-type: none"> ■ On value low flow cutoff parameter (→ 24): 2 g/s ■ Off value low flow cutoff parameter (→ 25): 50 % ■ Switch-off value: 3 g/s  <p>A0012887</p> <table border="0"> <tr> <td><i>Q</i></td> <td>Flow</td> </tr> <tr> <td><i>t</i></td> <td>Time</td> </tr> <tr> <td><i>H</i></td> <td>Hysteresis</td> </tr> <tr> <td><i>A</i></td> <td>Low flow cut off active</td> </tr> <tr> <td>1</td> <td>Low flow cut off is activated</td> </tr> <tr> <td>2</td> <td>Low flow cut off is deactivated</td> </tr> <tr> <td>3</td> <td>On value entered</td> </tr> <tr> <td>4</td> <td>Off value entered</td> </tr> </table>	<i>Q</i>	Flow	<i>t</i>	Time	<i>H</i>	Hysteresis	<i>A</i>	Low flow cut off active	1	Low flow cut off is activated	2	Low flow cut off is deactivated	3	On value entered	4	Off value entered
<i>Q</i>	Flow																
<i>t</i>	Time																
<i>H</i>	Hysteresis																
<i>A</i>	Low flow cut off active																
1	Low flow cut off is activated																
2	Low flow cut off is deactivated																
3	On value entered																
4	Off value entered																

Pressure shock suppression

Navigation	Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup.
Prerequisite	In the Assign process variable parameter (→ 24), the Volume flow option is selected.
Description	Use this function to enter the time interval for signal suppression (= active pressure shock suppression).
User entry	0 to 100 s
Factory setting	0 s

Additional information*Description***Pressure shock suppression is enabled**


- Prerequisite:
Flow rate < on-value of low flow cut off
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.




A0012888

<i>Q</i>	Flow
<i>t</i>	Time
A	Drip
B	Pressure shock
C	Pressure shock suppression active as specified by the time entered
D	Pressure shock suppression inactive
1	Valve closes
2	Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
3	The time entered has elapsed: pressure shock suppression is deactivated
4	The actual flow value is now displayed and output
5	On value for low flow cut off
6	Off value for low flow cut off

3.2.4 "Sensor adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm.



Installation direction**Navigation**

Expert → Sensor → Sensor adjustm. → Install. direct.

Description

Use this function to change the sign of the medium flow direction.

Selection

- Flow in arrow direction
- Flow against arrow direction

Factory setting

Flow in arrow direction

Additional information**Description**

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time**Navigation**

Expert → Sensor → Sensor adjustm. → Integration time

Description

Display the duration of an integration cycle.

User interface

1 to 65 ms

Factory setting

5 ms

Measuring period**Navigation**

Expert → Sensor → Sensor adjustm. → Measuring period

Description


Display the time of a full measuring period.

User interface 6 to 80 ms

Factory setting 12.5 ms

"Process variable adjustment" submenu

Navigation ☐ Expert → Sensor → Sensor adjustm. → Variable adjust



Volume flow offset



Navigation ☐ Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset

Description Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry Signed floating-point number

Factory setting 0 m³/s

Additional information *Description*

Corrected value = (factor × value) + offset

Volume flow factor



Navigation ☐ Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor

Description Use this function to enter a quantity factor for the volume flow. This multiplication factor is applied over the volume flow range.

User entry Positive floating-point number

Factory setting 1


Additional information *Description*

Corrected value = (factor × value) + offset

3.2.5 "Calibration" submenu

Navigation

Expert → Sensor → Calibration



Nominal diameter

Navigation

Expert → Sensor → Calibration → Nominal diameter

Description

Displays the nominal diameter of the sensor.

User interface

DNxx / x"

Factory setting

Depends on the size of the sensor

Additional information

Description

The value is also specified on the sensor nameplate.

Calibration factor

Navigation

Expert → Sensor → Calibration → Cal. factor

Description

Displays the current calibration factor for the sensor.

User interface

Positive floating-point number

Factory setting

Depends on nominal diameter and calibration.

Zero point

Navigation

Expert → Sensor → Calibration → Zero point

Description

This function shows the zero point correction value for the sensor.


User interface

Signed floating-point number

Factory setting Depends on nominal diameter and calibration


3.3 "Output" submenu

Navigation  Expert → Output



3.3.1 "Pulse/frequency/switch output 1 to 2" submenu

Navigation  Expert → Output → PFS output 1 to 2



Failure mode	→ 41
Failure frequency	→ 42
Output frequency	→ 42
Switch output function	→ 43
Assign diagnostic behavior	→ 43
Assign limit	→ 44
Switch-on value	→ 45
Switch-off value	→ 46
Assign flow direction check	→ 46
Assign status	→ 47
Failure mode	→ 47
Switch status	→ 48
Invert output signal	→ 48

Operating mode



Navigation

Expert → Output → PFS output 1 to 2 → Operating mode

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Off
- Pulse
- Automatic pulse
- Frequency
- Switch

Factory setting

- Pulse/freq./switch output 1: **Pulse** option
- Pulse/freq./switch output 2: **Switch** option

Additional information

"Off" option

The pulse/frequency/switch output is not used.

"Pulse" option

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.
- This option is used for most batching applications.
- Depending on the setting, when using this option it is important that the recorder can detect pulses that are output at a pulse rate of 10 kHz.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s




图 3 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered
P Pauses between the individual pulses

"Automatic pulse" option

Quantity-proportional pulse with on/off ratio of 1:1

- This is used if the duration of the active pulse is not known.
- Whenever a specific volume is reached (pulse value), a pulse with a pulse-off ratio of 1:1 is output.
- In this case, the pulse width is not relevant.
- When using this option, it is important that the recorder can detect pulses that are output at a pulse rate of 10 kHz.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Automatic pulse width
- Pulse rate approx. 1 000 Impuls/s




图 4 Quantity-proportional pulse (pulse value) with automatic pulse width

B Automatic pulse width
P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of the volume flow process variable.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz




 5 Flow-proportional frequency output

"Switch" option

Switch to indicate a state (e.g. alarm or warning if a limit value is reached)

Example


Alarm response without alarm



 6 No alarm, high level

Example

Alarm response in case of alarm



 7 Alarm, low level

Channel 2

**Navigation**

 Expert → Output → PFS output 1 to 2 → Channel 2

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→  31).

Description	Use this function to output a redundant pulse with or without a time delay. With this setting, switch output 2 can be used as a redundant output. This is used primarily in metrological applications.
Selection	<ul style="list-style-type: none">■ Off■ Redundant 0°■ Redundant 90°■ Redundant 180°
Factory setting	Off
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ Off Pulse output 2 is not used.■ Redundant 0° Redundant pulses are output without a time delay.■ Redundant 90° Redundant pulses are output with a time delay of half a pulse width.■ Redundant 180° Redundant pulses are output with a time delay of a full pulse width.

Assign pulse output



Navigation	Expert → Output → PFS output 1 to 2 → Assign pulse
Prerequisite	One of the following options is selected in the Operating mode parameter (→ 31): <ul style="list-style-type: none">■ Pulse■ Automatic pulse
Description	Use this function to select the process variable for the pulse output.
Selection	<ul style="list-style-type: none">■ Off■ Volume flow
Factory setting	Off

Value per pulse



Navigation	Expert → Output → PFS output 1 to 2 → Value per pulse
Prerequisite	One of the following options is selected in the Operating mode parameter (→ 31): <ul style="list-style-type: none">■ Pulse■ Automatic pulse In the Assign pulse output parameter (→ 34), the Volume flow option is selected.
Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
User entry	Signed floating-point number

Factory setting

- Depends on the nominal diameter:
- DN 4 ($\frac{1}{8}$ "): 0.005 ml (0.0002 fl oz)
 - DN 8 ($\frac{3}{8}$ "): 0.02 ml (0.001 fl oz)
 - DN 15 ($\frac{1}{2}$ "): 0.1 ml (0.004 fl oz)
 - DN 15K ($\frac{1}{2}K$ "): 0.1 ml (0.004 fl oz)
 - DN 25 (1"): 0.2 ml (0.007 fl oz)

Additional information*User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width**Navigation**

Diagram Expert → Output → PFS output 1 to 2 → Pulse width

Prerequisite

In the **Operating mode** parameter (→ 31), the **Pulse** option is selected and in the **Assign pulse output** parameter (→ 34), the **Volume flow** option is selected.

Description

Use this function to enter the duration of the output pulse.

User entry


0.05 to 3.75 ms

Factory setting

0.05 ms

Additional information*Description*

- Define how long a pulse is (duration).
- The duration must be defined depending on the input card used.
- The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to 2**.



B Pulse width entered

P Intervals between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max} = 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max} = 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

 The pulse width is not relevant for **Automatic pulse** option.

Measuring mode**Navigation**

 Expert → Output → PFS output 1 to 2 → Measuring mode

Prerequisite

One of the following options is selected in the **Operating mode** parameter (→ 31):

- Pulse
- Automatic pulse

In the **Assign pulse output** parameter (→ 34), the **Volume flow** option is selected.

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow

Factory setting

Forward flow

Additional information*Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.

 For a detailed description of the options available, see the **Measuring mode** parameter (→ 39)

Failure mode**Navigation**

 Expert → Output → PFS output 1 to 2 → Failure mode

Prerequisite

One of the following options is selected in the **Operating mode** parameter (→ 31):

- Pulse
- Automatic pulse

In the **Assign pulse output** parameter (→ 34), the **Volume flow** option is selected.


Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection	<ul style="list-style-type: none"> ■ Actual value ■ No pulses
Factory setting	Actual value
Additional information	<p><i>Description</i></p> <p>The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a fault.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> ■ Actual value In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored. ■ No pulses In the event of a device alarm, the pulse output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Pulse output

Navigation	 Expert → Output → PFS output 1 to 2 → Pulse output 1 to 2
Prerequisite	One of the following options is selected in the Operating mode parameter (→ 31): <ul style="list-style-type: none"> ■ Pulse ■ Automatic pulse
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open emitter output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ■ The Value per pulse parameter (→ 34) and the Pulse width parameter (→ 35) (Operating mode (→ 31) Pulse) can be used to define the value (i.e. the amount of the measured value that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 48), i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→ 36)) can be configured.

i The duration of the pulses must be defined as a function of the input card used. The pulse(s) must not exceed the maximum input frequency of the counter card.

Assign frequency output



Navigation

Expert → Output → PFS output 1 to 2 → Assign freq.

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 31).

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Volume flow

Factory setting

Off

Minimum frequency value



Navigation

Expert → Output → PFS output 1 to 2 → Min. freq. value

Prerequisite

In the **Operating mode** parameter (→ 31), the **Frequency** option is selected and in the **Assign frequency output** parameter (→ 38), the **Volume flow** option is selected.

Description

Use this function to enter the start value frequency.

User entry

0.0 to 10 000.0 Hz

Factory setting	0.0 Hz
-----------------	--------

Maximum frequency value



Navigation	 Expert → Output → PFS output 1 to 2 → Max. freq. value
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected and in the Assign frequency output parameter (→ 38), the Volume flow option is selected.
Description	Use this function to enter the end value frequency.
User entry	Signed floating-point number
Factory setting	10 000.0 Hz

Measuring value at maximum frequency



Navigation	 Expert → Output → PFS output 1 to 2 → Val. at max.freq
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected and in the Assign frequency output parameter (→ 38), the Volume flow option is selected.
Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<p><i>Description</i></p> <p>Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.</p> <p><i>Dependency</i></p> <p> The entry depends on the process variable selected in the Assign frequency output parameter (→ 38).</p>

Measuring mode



Navigation	 Expert → Output → PFS output 1 to 2 → Measuring mode
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected and in the Assign frequency output parameter (→ 38), the Volume flow option is selected.
Description	Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow

Factory setting

Forward flow

Additional information


"Forward flow" option

The frequency output signal is proportional to the measured variable assigned. The measuring range is defined by the value that is assigned to the Measuring value at maximum frequency (A). The measured value for the minimum frequency is implicitly 0.

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Measuring value at maximum frequency = 10kg/h

- If the effective flow exceeds the measured value A, the diagnostic message **△S442 Frequency output 1 to 2** is displayed. If the value is exceeded, the frequency remains at the maximum frequency, or at the failure frequency according to the configuration.
- If the value is undershot, i.e. flow is negative, 0 Hz is output and no diagnostic message is displayed.



A Measuring value at maximum frequency


"Forward/Reverse flow" option

The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The flow direction can be output via the configurable switch outputs.

The flow components outside the scaled measuring range are taken into account for signal output as follows:

If the effective flow exceeds the absolute value A, the diagnostic message

- △S442 Frequency output 1 to 2** is displayed. If the value is exceeded, the frequency remains at the maximum frequency, or at the failure frequency according to the configuration.




A Measuring value at maximum frequency

"Reverse flow" option

The flow components outside the scaled measuring range are taken into account for signal output as follows:

- If the effective flow drops below the value A (normally a negative value for reverse flow), the diagnostic message **△S442 Frequency output 1 to 2** is displayed. If the value is undershot, the frequency remains at the maximum frequency, or at the failure frequency according to the configuration.
- If the value is exceeded, i.e. flow is positive, 0 Hz is output and no diagnostic message is displayed.



A Measuring value at maximum frequency

Damping output**Navigation**

Expert → Output → PFS output 1 to 2 → Damping out.

Prerequisite

In the **Operating mode** parameter (→ 31), the **Frequency** option is selected and in the **Assign frequency output** parameter (→ 38), the **Volume flow** option is selected.

Description

Use this function to enter the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information*Description*

Use this function to enter a time constant (PT1 element) for frequency output damping. The frequency output is subject to separate damping that is independent of all preceding time constants.

i This damping is not recommended for applications with high-speed filling $t_{\text{fill}} < 5 \text{ s}$.

Failure mode**Navigation**

Expert → Output → PFS output 1 to 2 → Failure mode

Prerequisite

In the **Operating mode** parameter (→ 31), the **Frequency** option is selected and in the **Assign frequency output** parameter (→ 38), the **Volume flow** option is selected.

Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none">■ Actual value■ Defined value■ 0 Hz
Factory setting	0 Hz
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The fault is ignored.■ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. This Failure frequency (→ 42) replaces the current measured value and the alarm can be bypassed as a result. The actual measurement is switched off for the duration of the alarm.■ 0 Hz In the event of a device alarm, the frequency output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Failure frequency



Navigation	Expert → Output → PFS output 1 to 2 → Failure freq.
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected and in the Assign frequency output parameter (→ 38), the Volume flow option is selected.
Description	Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.
User entry	0.0 to 10 000.0 Hz
Factory setting	0.0 Hz

Output frequency

Navigation	Expert → Output → PFS output 1 to 2 → Output freq. 1 to 2
Prerequisite	In the Operating mode parameter (→ 31), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 10 000.0 Hz

Switch output function

Navigation	Expert → Output → PFS output 1 to 2 → Switch out funct
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 31).
Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none">▪ Off▪ On▪ Diagnostic behavior▪ Limit▪ Flow direction check▪ Status
Factory setting	Off
Additional information	<i>Options</i> <ul style="list-style-type: none">▪ Off The switch output is permanently switched off (open, non-conductive).▪ On The switch output is permanently switched on (closed, conductive).▪ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.▪ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.▪ Flow direction check Indicates the flow direction (forward or reverse flow).▪ Status Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior

Navigation	Expert → Output → PFS output 1 to 2 → Assign diag. beh
Prerequisite	<ul style="list-style-type: none">▪ The Switch option is selected in the Operating mode parameter (→ 31).▪ The Diagnostic behavior option is selected in the Switch output function parameter (→ 43).
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none">▪ Alarm▪ Alarm or warning▪ Warning
Factory setting	Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Options

■ Alarm

The switch output signals only diagnostic events in the alarm category.

■ Alarm or warning

The switch output signals diagnostic events in the alarm and warning category.

■ Warning

The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to 2 → Assign limit

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 31).
- The **Limit** option is selected in the **Switch output function** parameter (→ 43).

Description

Use this function to select a process variable for the limit function.

Selection

Volume flow


Factory setting

Volume flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:


- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive



- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output 1 to 2 → Switch-on value

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 31).
- The **Limit** option is selected in the **Switch output function** parameter (→ 43).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 ml/s
- 0 fl oz/s

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 44).

Switch-off value**Navigation**

Expert → Output → PFS output 1 to 2 → Switch-off value

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 31).
- The **Limit** option is selected in the **Switch output function** parameter (→ 43).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 ml/s
- 0 fl oz/s

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 44).

Assign flow direction check**Navigation**

Expert → Output → PFS output 1 to 2 → Assign dir.check

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 31).
- The **Flow direction check** option is selected in the **Switch output function** parameter (→ 43).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow

Factory setting

Volume flow

Additional information*Description*

If the value of the assigned process variable is ≥ 0 , the status output is conductive. Otherwise, the switch output is non-conductive.

Assign status**Navigation**

Expert → Output → PFS output 1 to 2 → Assign status

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 31).
- The **Status** option is selected in the **Switch output function** parameter (→ 43).

Description

Use this function to select a device status for the switch output.

Selection

Low flow cut off

Factory setting

Low flow cut off

Additional information*Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Failure mode**Navigation**

Expert → Output → PFS output 1 to 2 → Failure mode

Description

Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Options*

- Actual status

In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.

- Open

In the event of a device alarm, the switch output's transistor is set to **non-conductive**.

- Closed

In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status

Navigation  Expert → Output → PFS output 1 to 2 → Switch status 1 to 2

Prerequisite In the **Operating mode** parameter (→ [31](#)), the **Switch** option is selected.

Description Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information *Selection*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal



Navigation  Expert → Output → PFS output 1 to 2 → Invert outp.sig.

Description Use this function to select whether to invert the output signal.


Selection

- No
- Yes


Factory setting

- Pulse/freq./switch output 1: yes
- Pulse/freq./switch output 2: no

Additional information *Selection*
No option (passive - negative)




Yes option (passive - positive)



3.4 "Application" submenu

Navigation

Expert → Application



Reset all totalizers

Navigation

Expert → Application → Reset all tot.

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information


Selection

- Cancel
No action is executed and the user exits the parameter.
- Reset + totalize
All totalizers are reset to 0 and the totaling process is restarted.

3.4.1 "Totalizer 1 to 3" submenu

Navigation

Expert → Application → Totalizer 1 to 3



Preset value 1 to 3	→ 52
Failure mode	→ 52

Assign process variable



Navigation Expert → Application → Totalizer 1 to 3 → Assign variable

Description Use this function to select a process variable for totalizer 1-3.

Selection

- Off
- Volume flow

Factory setting Volume flow

Additional information *Description*
 If the option selected is changed, the device resets the totalizer to 0.

Options

If the **Off** option is selected, only **Assign process variable** parameter (→ 50) is displayed in the **Totalizer 1 to 3** submenu. All other parameters in the submenu are hidden.

Volume unit



Navigation Expert → Application → Totalizer 1 to 3 → Volume unit

Prerequisite The **Volume flow** option is selected in the **Assign process variable** parameter (→ 50) of the **Totalizer 1 to 3** submenu.

Description Use this function to select the unit for the volume.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	<ul style="list-style-type: none"> ▪ cm³ ▪ dm³ ▪ m³ ▪ ml ▪ l ▪ hl ▪ Ml Mega 	<ul style="list-style-type: none"> ▪ af ▪ ft³ ▪ fl oz (us) ▪ gal (us) ▪ kgal (us) ▪ Mgal (us) ▪ bbl (us;oil) ▪ bbl (us;liq.) ▪ bbl (us;beer) ▪ bbl (us;tank) 	<ul style="list-style-type: none"> ▪ gal (imp) ▪ Mgal (imp) ▪ bbl (imp;beer) ▪ bbl (imp;oil)

Custom-specific units

User vol.

Factory setting	Depending on country: ■ ml ■ fl oz (us)
------------------------	---

Totalizer operation mode

Navigation	 Expert → Application → Totalizer 1 to 3 → Operation mode
Prerequisite	In the Assign process variable parameter (→ 50) of the Totalizer 1 to 3 submenu, the Volume flow option is selected.
Description	Use this function to select how the totalizer summates the flow.
Selection	<ul style="list-style-type: none">■ Net flow total■ Forward flow total■ Reverse flow total
Factory setting	Net flow total
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ Net flow total Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.■ Forward flow total Only the flow in the forward flow direction is totalized.■ Reverse flow total Only the flow against the forward flow direction is totalized (= reverse flow total).

Control Totalizer 1 to 3

Navigation	 Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3
Prerequisite	In the Assign process variable parameter (→ 50) of the Totalizer 1 to 3 submenu, the Volume flow option is selected.
Description	Use this function to select the control of totalizer value 1-3.
Selection	<ul style="list-style-type: none">■ Totalize■ Reset + hold■ Preset + hold■ Reset + totalize■ Preset + totalize
Factory setting	Totalize

Additional information*Options*

- Totalize
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter (→ 52).
- Reset + totalize
The totalizer is reset to 0 and the totaling process is restarted.
- Preset + totalize
The totalizer is set to the defined start value in the **Preset value** parameter (→ 52) and the totaling process is restarted.

Preset value 1 to 3

Navigation

Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3

Prerequisite

In the **Assign process variable** parameter (→ 50) of the **Totalizer 1 to 3** submenu, the **Volume flow** option is selected.

Description

Use this function to enter a start value for totalizer 1-3.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³
- 0 ft³

Additional information*User entry*

i The unit of the selected process variable is specified for the totalizer in the **Assign process variable** parameter. If the following is selected in the **Assign process variable** parameter:
Volume flow option: **Volume flow unit** parameter (→ 19)

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode

**Navigation**

Expert → Application → Totalizer 1 to 3 → Failure mode

Prerequisite

In the **Assign process variable** parameter (→ 50) of the **Totalizer 1 to 3** submenu, the **Volume flow** option is selected.

Description

Use this function to select how a totalizer behaves in an alarm condition.

Selection	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value
Factory setting	Stop
Additional information	<p><i>Description</i></p> <p>i This setting does not affect the error response mode of other totalizers and the outputs. This is specified in separate parameters.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> ■ Stop Totalizing is stopped in an alarm condition. ■ Actual value The totalizer continues to count based on the actual measured value; the error is ignored. ■ Last valid value The totalizer continues to count based on the last valid measured value before the error occurred.

3.5 "Diagnostics" submenu

Navigation



Expert → Diagnostics

► **Diagnostics**

Actual diagnostics	→ 54
Timestamp	→ 54
Actual diagnostics	→ 54
Previous diagnostics	→ 55
Timestamp	→ 55
Previous diagnostics	→ 55
Operating time from restart	→ 56
Operating time	→ 56
► Diagnostic list	→ 56
► Event logbook	→ 61

▶ Device information	→ 62
▶ Simulation	→ 65

Actual diagnostics

Navigation	Expert → Diagnostics → Actual diagnos.
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i> Additional pending diagnostic messages can be shown in the Diagnostic list submenu (→ 56).
	<i>Example</i> For the display format: △S442 Frequency output

Timestamp

Navigation	Expert → Diagnostics → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The diagnostic message can be displayed via the Actual diagnostics parameter (→ 54).
	<i>Example</i> For the display format: 24d12h13m00s

Actual diagnostics

Navigation	Expert → Diagnostics → Actual diagnos.
Prerequisite	A diagnostic event has occurred.

Description Displays the service ID of the current diagnostic message.

User interface 0 to 65 535

Previous diagnostics

Navigation  Expert → Diagnostics → Prev.diagnostics

Prerequisite Two diagnostic events have already occurred.

Description Displays the diagnostic message that occurred before the current message.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Example*

For the display format:
△S442 Frequency output

Timestamp

Navigation  Expert → Diagnostics → Timestamp

Description Displays the operating time when the last diagnostic message before the current message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

 The diagnostic message can be displayed via the **Previous diagnostics** parameter (→  55).

Example

For the display format:
24d12h13m00s

Previous diagnostics

Navigation  Expert → Diagnostics → Prev.diagnostics

Prerequisite Two diagnostic events have already occurred.

Description Displays the service ID of the diagnostic message that occurred before the current diagnostic message.

User interface 0 to 65 535

Operating time from restart

Navigation	 Expert → Diagnostics → Time fr. restart
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation	 Expert → Diagnostics → Operating time
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.5.1 "Diagnostic list" submenu

Navigation  Expert → Diagnostics → Diagnostic list

 Diagnostic list	
Diagnostics 1	→  57
Diagnostics 1	→  57
Timestamp	→  57
Diagnostics 2	→  58
Diagnostics 2	→  58
Timestamp	→  58
Diagnostics 3	→  59
Diagnostics 3	→  59
Timestamp	→  59

Diagnostics 4	→ 59
Diagnostics 4	→ 60
Timestamp	→ 60
Diagnostics 5	→ 60
Diagnostics 5	→ 61
Timestamp	→ 61

Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1

Description

Use this function to display the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- Δ S442 Frequency output
- \times F276 I/O module failure

Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1

Description

Displays the service ID of the current diagnostic message with the highest priority.

User interface

0 to 65 535

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The diagnostic message can be displayed via the **Diagnostics 1** parameter (→ [57](#)).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2

Description

Use this function to display the current diagnostics message with the second-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2

Description

Displays the service ID of the current diagnostic message with the second-highest priority.

User interface

0 to 65 535

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The diagnostic message can be displayed via the **Diagnostics 2** parameter (→ [58](#)).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 3

Description

Use this function to display the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- S442 Frequency output
- F276 I/O module failure

Diagnostics 3

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 3

Description

Displays the service ID of the current diagnostic message with the third-highest priority.

User interface

0 to 65 535

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The diagnostic message can be displayed via the **Diagnostics 3** parameter (→ [59](#)).

Example

For the display format:
24d12h13m00s

Diagnostics 4

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 4

Description

Use this function to display the current diagnostics message with the fourth-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Examples*

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Diagnostics 4

Navigation  Expert → Diagnostics → Diagnostic list → Diagnostics 4

Description Displays the service ID of the current diagnostic message with the fourth-highest priority.

User interface 0 to 65 535

Timestamp

Navigation  Expert → Diagnostics → Diagnostic list → Timestamp

Description Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

 The diagnostic message can be displayed via the **Diagnostics 4** parameter (→  59).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation  Expert → Diagnostics → Diagnostic list → Diagnostics 5

Description Use this function to display the current diagnostics message with the fifth-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Examples*

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Diagnostics 5


Navigation	█ Expert → Diagnostics → Diagnostic list → Diagnostics 5
Description	Displays the service ID of the current diagnostic message with the fifth-highest priority.
User interface	0 to 65 535

Timestamp

Navigation	█ Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fifth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The diagnostic message can be displayed via the Diagnostics 5 parameter (→ 60). <i>Example</i> For the display format: 24d12h13m00s

3.5.2 "Event logbook" submenu

Navigation █ Expert → Diagnostics → Event logbook



Filter options

Navigation	█ Expert → Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the events list.
Selection	<ul style="list-style-type: none">■ All■ Failure (F)■ Function check (C)

- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting All

Additional information *Description*

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

3.5.3 "Device information" submenu

Navigation



Expert → Diagnostics → Device info

► Device information	
Device tag	→ 62
Serial number	→ 63
Firmware version	→ 63
Device name	→ 63
Order code	→ 63
Extended order code 1	→ 64
Extended order code 2	→ 64
Extended order code 3	→ 64
ENP version	→ 65
Configuration counter	→ 65

Device tag



Navigation



Expert → Diagnostics → Device info → Device tag

Description

Use this function to enter the unique name for the measuring point so that it can be identified quickly within the plant. The name is displayed in the header.

User entry A maximum of 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Dosimag

Serial number

Navigation  Expert → Diagnostics → Device info → Serial number

Description Displays the serial number of the measuring device.

 It can also be found on the nameplate.

User interface A maximum of 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation  Expert → Diagnostics → Device info → Firmware version

Description Displays the device firmware version installed.

User interface Character string in the format xx.yy.zz

Factory setting 03.00

Device name

Navigation  Expert → Diagnostics → Device info → Device name

Description Displays the device name. It can also be found on the nameplate.

User interface Dosimag

Order code

Navigation  Expert → Diagnostics → Device info → Order code

Description Displays the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information *Description*

 It can be found in the "Order code" field on the nameplate.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1

Navigation  Expert → Diagnostics → Device info → Ext. order cd. 1

Description Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface Character string

Additional information *Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

 It can be found in the "Ext. ord. cd." field on the nameplate.

Extended order code 2

Navigation  Expert → Diagnostics → Device info → Ext. order cd. 2

Description For displaying the second part of the extended order code.

User interface Character string

Additional information For additional information, see **Extended order code 1** parameter (→  64)

Extended order code 3

Navigation  Expert → Diagnostics → Device info → Ext. order cd. 3

Description For displaying the third part of the extended order code.

User interface Character string

Additional information For additional information, see **Extended order code 1** parameter (→  64)

ENP version

Navigation  Expert → Diagnostics → Device info → ENP version

Description Displays the version of the electronic nameplate.

User interface Character string

Factory setting 2.02.00

Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

Configuration counter


Navigation  Expert → Diagnostics → Device info → Config. counter

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

3.5.4 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation



Assign simulation process variable

Navigation	Expert → Diagnostics → Simulation → Assign proc.var.
Description	Use this function to select a process variable for the simulation process that is activated.
Selection	<ul style="list-style-type: none">▪ Off▪ Volume flow
Factory setting	Off
Additional information	<i>Description</i> The simulation value of the selected process variable is specified in the Value process variable parameter (→ 66).

Value process variable

Navigation	Expert → Diagnostics → Simulation → Value proc. var.
Prerequisite	In the Assign simulation process variable parameter (→ 66), the Volume flow option is selected.
Description	Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.
User entry	Depends on the process variable selected
Factory setting	0
Additional information	<i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 19).

Simulation device alarm

Navigation	Expert → Diagnostics → Simulation → Sim. alarm
Description	Use this function to switch the device alarm on and off.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off

Additional information*Description*

In this way, users can verify the correct function of downstream switching units.

4 Country-specific factory settings

4.1 SI units

i Not valid for USA and Canada.

4.1.1 System units

Volume	ml
Volume flow	ml/s

4.1.2 On value low flow cut off

i The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	On value low flow cut off (v ~ 0.04 m/s) [ml/s]
4	0.5
8	2
15K ¹⁾	7
15	7
25	16

1) Conical version (corresponds to DN 12)

4.2 US units

i Only valid for USA and Canada.

4.2.1 System units

Volume	fl oz (us)
Volume flow	fl oz/s (us)

4.2.2 On value low flow cut off

i The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	On value low flow cut off (v ~ 0.13 ft/s) [oz fl/s]
5/32	0.02
5/16	0.08
1/2K ¹⁾	0.25

Nominal diameter [in]	On value low flow cut off (v ~ 0.13 ft/s) [oz fl/s]
½	0.25
1	0.53

1) Conical version (corresponds to DN 12)

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Volume	$\text{cm}^3, \text{dm}^3, \text{m}^3$	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml	Milliliter, liter, hectoliter, megaliter
Volume flow	$\text{cm}^3/\text{s}, \text{cm}^3/\text{min}, \text{cm}^3/\text{h}, \text{cm}^3/\text{d}$	Cubic centimeter/time unit
	$\text{dm}^3/\text{s}, \text{dm}^3/\text{min}, \text{dm}^3/\text{h}, \text{dm}^3/\text{d}$	Cubic decimeter/time unit
	$\text{m}^3/\text{s}, \text{m}^3/\text{min}, \text{m}^3/\text{h}, \text{m}^3/\text{d}$	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
	Ml/s, Ml/min, Ml/h, Ml/d	Megaliter/time unit
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Volume	af	Acre foot
	ft^3	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	$\text{ft}^3/\text{s}, \text{ft}^3/\text{min}, \text{ft}^3/\text{h}, \text{ft}^3/\text{d}$	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

A

Access status tooling (Parameter)	10
Actual diagnostics (Parameter)	54
Administration (Submenu)	13
Alarm delay (Parameter)	11
Application (Submenu)	49
Assign behavior of diagnostic no. 442 (Parameter)	12
Assign behavior of diagnostic no. 443 (Parameter)	13
Assign behavior of diagnostic no. 937 (Parameter)	13
Assign diagnostic behavior (Parameter)	43
Assign flow direction check (Parameter)	46
Assign frequency output (Parameter)	38
Assign limit (Parameter)	44
Assign process variable (Parameter)	24, 50
Assign pulse output (Parameter)	34
Assign simulation process variable (Parameter)	66
Assign status (Parameter)	47

C

Calibration (Submenu)	29
Calibration factor (Parameter)	29
Channel 2 (Parameter)	33
Configuration counter (Parameter)	65
Control Totalizer 1 to 3 (Parameter)	51

D

Damping output (Parameter)	41
Date/time format (Parameter)	21
Device information (Submenu)	62
Device name (Parameter)	63
Device reset (Parameter)	14
Device tag (Parameter)	62
Diagnostic behavior (Submenu)	12
Diagnostic handling (Submenu)	11
Diagnostic list (Submenu)	56
Diagnostics (Submenu)	53
Diagnostics 1 (Parameter)	57
Diagnostics 2 (Parameter)	58
Diagnostics 3 (Parameter)	59
Diagnostics 4 (Parameter)	59, 60
Diagnostics 5 (Parameter)	60, 61

Document

Explanation of the structure of a parameter description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4

Document function

E

ENP version (Parameter)	65
Enter access code (Parameter)	10
Event logbook (Submenu)	61
Extended order code 1 (Parameter)	64

Extended order code 2 (Parameter)	64
Extended order code 3 (Parameter)	64

F

Factory settings	68
SI units	68
US units	68
Failure frequency (Parameter)	42
Failure mode (Parameter)	36, 41, 47, 52
Filter options (Parameter)	61
Firmware version (Parameter)	63
Flow override (Parameter)	23

Function

see Parameter

I

Installation direction (Parameter)	27
Integration time (Parameter)	27
Invert output signal (Parameter)	48

L

Locking status (Parameter)	9
Low flow cut off (Submenu)	24

M

Maximum frequency value (Parameter)	39
Measured values (Submenu)	15
Measuring mode (Parameter)	36, 39
Measuring period (Parameter)	27
Measuring value at maximum frequency (Parameter)	39
Minimum frequency value (Parameter)	38

N

Nominal diameter (Parameter)	29
--	----

O

Off value low flow cutoff (Parameter)	25
On value low flow cutoff (Parameter)	24
Operating mode (Parameter)	31
Operating time (Parameter)	56
Operating time from restart (Parameter)	56
Order code (Parameter)	63
Output (Submenu)	30
Output frequency 1 to 2 (Parameter)	19, 42
Output values (Submenu)	17

P

Parameter

Structure of a parameter description	6
Permanent storage (Parameter)	14
Preset value 1 to 3 (Parameter)	52
Pressure shock suppression (Parameter)	25
Previous diagnostics (Parameter)	55
Process parameters (Submenu)	23
Process variable adjustment (Submenu)	28
Process variables (Submenu)	15
Pulse output 1 to 2 (Parameter)	18, 37

Pulse width (Parameter)	35
Pulse/frequency/switch output 1 to 2 (Submenu)	30
R	
Reset all totalizers (Parameter)	49
S	
Sensor (Submenu)	14
Sensor adjustment (Submenu)	27
Serial number (Parameter)	63
Simulation (Submenu)	65
Simulation device alarm (Parameter)	66
Submenu	
Administration	13
Application	49
Calibration	29
Device information	62
Diagnostic behavior	12
Diagnostic handling	11
Diagnostic list	56
Diagnostics	53
Event logbook	61
Low flow cut off	24
Measured values	15
Output	30
Output values	17
Process parameters	23
Process variable adjustment	28
Process variables	15
Pulse/frequency/switch output 1 to 2	30
Sensor	14
Sensor adjustment	27
Simulation	65
System	10
System units	19
Totalizer	16
Totalizer 1 to 3	49
User-specific units	22
Switch output function (Parameter)	43
Switch status 1 to 2 (Parameter)	19, 48
Switch-off value (Parameter)	46
Switch-on value (Parameter)	45
System (Submenu)	10
System units (Submenu)	19
T	
Target group	4
Timestamp (Parameter)	54, 55, 57, 58, 59, 60, 61
Totalizer (Submenu)	16
Totalizer 1 to 3 (Submenu)	49
Totalizer operation mode (Parameter)	51
Totalizer overflow 1 to 3 (Parameter)	17
Totalizer value 1 to 3 (Parameter)	16
U	
User volume factor (Parameter)	22
User volume text (Parameter)	22
User-specific units (Submenu)	22

V	
Value per pulse (Parameter)	34
Value process variable (Parameter)	66
Volume flow (Parameter)	15
Volume flow factor (Parameter)	28
Volume flow offset (Parameter)	28
Volume flow unit (Parameter)	19
Volume unit (Parameter)	21, 50
Z	
Zero point (Parameter)	29

www.addresses.endress.com
