

Brief Operating Instructions

Deltapilot S FMB70

Hydrostatic level measurement




These Brief Operating Instructions are not a substitute for the Operating Instructions pertaining to the device.

Detailed information about the device can be found in the Operating Instructions and the additional documentation.

Available for all device versions via

- Internet: www.endress.com/deviceviewer
- Smartphone/tablet: *Endress+Hauser Operations app*

1 Associated documentation



A0023555

2 About this document

2.1 Document function

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

2.2 Symbols used

2.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

2.2.2 Electrical symbols



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

2.2.3 Symbols for certain types of information and graphics

Permitted

Procedures, processes or actions that are permitted

Forbidden

Procedures, processes or actions that are forbidden

Tip

Indicates additional information



Reference to documentation



Reference to page



Reference to graphic



Visual inspection



Notice or individual step to be observed

1, 2, 3, ...

Item numbers

A, B, C, ...

Views

2.3 Registered trademarks

KALREZ®

Trademark of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Trademark of Ladish & Co., Inc., Kenosha, USA

GORE-TEX®

Trademark of W.L. Gore & Associates, Inc., USA

FOUNDATION™ Fieldbus

Registered trademark of the FieldComm, Austin, USA

3 Basic safety instructions

3.1 Requirements for the personnel

Personnel must meet the following requirements for their tasks:

- ▶ Trained, qualified specialists must be suitably qualified to perform this function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application)
- ▶ Follow instructions and comply with basic conditions

3.2 Intended use

The Deltapilot S is a hydrostatic pressure sensor for measuring level and pressure.

3.2.1 Foreseeable incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

3.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.
- ▶ Switch off the supply voltage before connecting the device.

3.4 Operational safety

Risk of injury!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

Hazardous area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area.
- ▶ Observe the specifications in the separate supplementary documentation that is an integral part of these Instructions.

3.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which they are safe to operate.


It fulfills general safety requirements and legal requirements. It also conforms to the EC directives listed in the device-specific EC declaration of conformity. Endress+Hauser confirms this fact by applying the CE mark.

3.6 Functional safety SIL3 (optional)

The Functional Safety Manual must be strictly observed for devices that are used in functional safety applications.

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?
- Are the goods undamaged?
- Do the data on the nameplate correspond to the order specifications and the delivery note?
- Is the documentation available?
- If required (see nameplate): Are the safety instructions (XA) present?



If one of these conditions is not fulfilled, please contact your Endress+Hauser sales office.

4.2 Product identification

The device can be identified in the following ways:

- Nameplate specifications
- Extended order code with breakdown of the device features on the delivery note
- ▶ Enter serial number from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer)
 - ↳ All of the information on the measuring device and on the scope of the technical documentation pertaining to the device is displayed.
- ▶ Enter the serial number from the nameplate in the *Endress+Hauser Operations app* or scan the 2-D matrix code on the nameplate with the camera
 - ↳ All of the information on the measuring device and on the scope of the technical documentation pertaining to the device is displayed.

4.3 Storage and transport

4.3.1 Storage conditions

Use original packaging.

Store the measuring device in clean and dry conditions and protect from damage caused by shocks (EN 837-2).

5 Mounting

5.1 Mounting requirements


5.1.1

Dimensions → see the Technical Information for Deltapilot S TI00416P, "Mechanical construction" section.

5.1.2 General installation instructions

- Devices with a G 1 1/2 thread:
When screwing the device into the tank, the flat seal has to be positioned on the sealing surface of the process connection. To avoid additional strain on the process membrane, the thread should never be sealed with hemp or similar materials.
- Devices with NPT threads:
 - Wrap Teflon tape around the thread to seal it.
 - Tighten the device at the hexagonal bolt only. Do not turn at the housing.
 - Do not overtighten the thread when screwing. Max. tightening torque:
20 to 30 Nm (14.75 to 22.13 lbf ft)

5.2 Mounting the device

- Due to the orientation of the Deltapilot S, a zero point shift may occur, i.e. when the vessel is empty, the measured value does not display zero. You can correct this zero point shift either directly on the device via the  button or via remote operation.
- To ensure optimum readability of the local display, it is possible to rotate the housing by up to 380°.
- The local display can be rotated in 90° stages.
- Endress+Hauser offers a mounting bracket for installation on pipes or walls.


5.2.1 Installation instructions

NOTICE

Damage to the device!


If a heated device is cooled during a cleaning process (e.g. by cold water), a vacuum develops for a short time and, as a result, moisture can enter the sensor through the pressure compensation element (1).

- ▶ Mount the device with the pressure compensation element (1) pointing diagonally downwards or to the side as much as possible.



A0047494

- Keep the pressure compensation and GORE-TEX® filter (1) free from contamination and water.
- Do not clean or touch process membranes with hard or pointed objects.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



A0031805

Level measurement

- Always install the device below the lowest measuring point.
- Do not install the device at the following positions:
 - In the filling curtain
 - In the tank outlet
 - In the suction area of a pump
 - At a point in the tank which could be affected by pressure pulses from the agitator
- The adjustment and functional test can be carried out more easily if you mount the device downstream from a shutoff device.
- The Deltapilot S must also be insulated in the case of media that can harden when cold.

Pressure measurement in gases

Mount the Deltapilot S with shutoff device above the tapping point so that any condensate can flow into the process.

Pressure measurement in vapors


- Mount the Deltapilot S with the water pocket pipe above the tapping point.
- Fill the water pocket pipe with liquid before commissioning. The water pocket pipe reduces the temperature to almost ambient temperature.

Pressure measurement in liquids

Mount the Deltapilot S with the shutoff device below or at the same level as the tapping point.

5.2.2 Turning the housing

The housing can be rotated by up to 380° by loosening the setscrew.



A0019996

1. T14 and T15 housing: loosen the setscrew with a 2 mm (0.08 in) Allen key. T17 housing: loosen the setscrew with a 3 mm (0.12 in) Allen key.
2. Rotate the housing (max. up to 380°).
3. Retighten the setscrew with 1 mm (0.74 lbf ft) 1 Nm (0.74 lbf ft).

5.2.3 Closing the housing covers

NOTICE

Devices with EPDM cover seal - leaking transmitter!

Mineral-, animal- or plant-based lubricants cause the EPDM cover seal to swell and the transmitter to leak as a result.

- It is not necessary to grease the thread due to the coating applied to the thread at the factory.

NOTICE

The housing cover can no longer be closed.

Damaged thread!

- When closing the housing covers make sure that the threads on the covers and the housing are free from dirt, such as sand. If you encounter resistance when closing the covers, then check the threads again for dirt.

Closing the covers on the hygienic stainless steel housing (T17)

The covers for the terminal compartment and electronics compartment are hooked into the housing and closed with a screw in each case. These screws must be tightened finger-tight (2 Nm (1.48 lbf ft)) to the stop to ensure that the covers are securely seated and leak-tight.

6 Electrical connection

6.1 Connecting requirements

WARNING

Risk of electric shock!


If the operating voltage is > 35 VDC: Dangerous contact voltage at terminals.

- In a wet environment, do not open the cover if voltage is present.

⚠ WARNING

An incorrect connection compromises electrical safety!

- ▶ Risk of electric shock and/or explosion! Switch off the supply voltage before connecting the device.
- ▶ When using the measuring device in hazardous areas, installation must also comply with the applicable national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- ▶ Devices with integrated overvoltage protection must be grounded.
- ▶ Protective circuits against reverse polarity, HF influences and overvoltage peaks are integrated.
- ▶ The supply voltage must match the power supply on the nameplate, see Operating Instructions → 2.
- ▶ Switch off the supply voltage before connecting.
- ▶ Remove the housing cover of the terminal compartment.
- ▶ Guide the cable through the gland. Preferably use a twisted, shielded two-wire cable.
- ▶ Connect the device as indicated in the diagram.
- ▶ Screw down the housing cover.
- ▶ Switch on the supply voltage.




A0047210

1 FOUNDATION Fieldbus electrical connection

- 1 Housing
- 2 Internal ground terminal
- 3 External ground terminal
- 4 Minimum supply voltage, for version in the non-hazardous area = 9 to 32 V DC
- 5 Devices with integrated overvoltage protection are labeled "OVP" (overvoltage protection) here.

6.1.1 Connection of devices with 7/8" plug

	PIN	
 <small>A0011176</small>	1	Signal -
	2	Signal +
	3	Not assigned
	4	Ground

6.2 Connecting the measuring unit

For further information on the network structure and grounding and for further bus system components such as bus cables, see the relevant documentation, e.g. Operating Instructions BA00013S "FOUNDATION Fieldbus Overview" and the FOUNDATION Fieldbus Guideline.

6.2.1 Supply voltage

Version for non-hazardous areas: 9 to 32 V DC



WARNING

Supply voltage might be connected!

Risk of electric shock and/or explosion!

- ▶ When using the measuring device in hazardous areas, installation must also comply with the applicable national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- ▶ All explosion protection data are given in separate Ex documentation, which is available upon request. The Ex documentation is supplied as standard with all devices approved for use in explosion hazardous areas.

6.2.2 Current consumption

15.5 mA ± 1 mA, switch-on current corresponds to IEC 61158-2, Clause 21.

6.2.3 Terminals

- Supply voltage and internal ground terminal: 0.5 to 2.5 mm² (20 to 14 AWG)
- External ground terminal: 0.5 to 4 mm² (20 to 12 AWG)

6.2.4 Cable specification

- Endress+Hauser recommends using twisted, shielded two-wire cables.
- Cable diameter: 5 to 9 mm (0.2 to 0.35 in)

For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).

6.2.5 Grounding and shielding


The Deltapilot S must be grounded, for example by means of the external ground terminal.

Different grounding and shielding installation methods are available for FOUNDATION Fieldbus networks such as:

- Isolated installation (see also IEC 61158-2)
- Installation with multiple grounding
- Capacitance installation


7 Operation options

7.1 Operation without an operating menu


Operation options	Explanation	Graphic	Description
Local operation without device display	The device is operated using the operating keys and DIP switches on the electronic insert.		→ 2

7.1.1 Position of operating elements

In the case of the aluminum housing (T14/T15) and stainless steel housing (T14), the operating key is located either under the protective flap on the exterior of the device or inside on the electronic insert. In the case of the hygienic stainless steel housing (T17), the operating key is always inside on the electronic insert. In addition, there are three operating keys on the optional local display.



2 Operating keys, outside



A0020032

- 1 DIP switch for locking/unlocking parameters relevant to the measured value
- 2 DIP switch for switching damping on/off
- 3 Green LED to indicate value being accepted
- 4 Key for position adjustment and device reset
- 5 DIP switch for bus address
- 6 Slot for optional display
- 7 Slot for optional HistoROM®/M-DAT

Function of the DIP switches

To perform the corresponding function, press the key or key combination for at least 3 s. Press the key combination for at least 6 s for a reset.

	Meaning
	<ul style="list-style-type: none">Position adjustment (zero point correction): press key for at least 3 seconds. The LED on the electronic insert lights up briefly if the pressure applied has been accepted for position adjustment.Total reset: press key for at least 12 seconds. The LED on the electronic insert lights up briefly if a reset is being carried out.
	<ul style="list-style-type: none">DIP switch 1: to lock/unlock parameters relevant to the measured value. Factory setting: off (unlocked)DIP switch 2: damping on/off, factory setting: on (damping on)

7.1.2 FOUNDATION Fieldbus interface


Device identification and addressing

FOUNDATION Fieldbus identifies the device using its ID code and automatically assigns it a suitable field address. The identity code cannot be changed. The device appears in the network

display once you have started the FF configuration program and integrated the device into the network. The blocks available are displayed under the device name.

If the device description has not yet been loaded, the blocks report "Unknown" or "(UNK)".

The Deltapilot S reports as follows:




A0048530

7.2 Operation with device display (optional)

A 4-line liquid crystal display (LCD) is used for display and operation. The local display shows measured values, dialog texts, fault messages and notice messages. The device display can be turned in 90° steps. Depending on the installation position of the device, this makes it easy to operate the device and read the measured values.

Functions:

- 8-digit measured value display including sign and decimal point, unit display, bar graph for displaying current
- Simple and complete menu guidance due to breakdown of parameters into several levels and groups
- Each parameter is assigned a 3-digit ID number for easy navigation
- Possibility of configuring the display according to individual wishes and requirements e.g. language, alternating display, display of other measured values, such as sensor temperature, contrast setting
- Comprehensive diagnostic functions (fault and warning message, maximum/minimum indicators, etc.)
- Rapid and safe commissioning using Quick Setup menus










The following table illustrates the symbols that can appear on the local display. Four symbols may appear at the same time.

Symbol	Meaning
	Alarm symbol <ul style="list-style-type: none">Symbol flashing: warning, device continues measuringSymbol permanently lit: error, device does not continue measuring <i>Note: The alarm symbol may overlie the tendency symbol.</i>
	Lock symbol The operation of the device is locked. Unlock the device.
	Communication symbol Data transfer via communication.
	Tendency symbol (increasing) The measured value increases.
	Tendency symbol (decreasing) The measured value decreases.
	Tendency symbol (constant) The measured value has remained constant throughout the last few minutes.





7.2.1 Operating keys on the display and operating module

Operating key(s)	Meaning
	<ul style="list-style-type: none">Navigate up in the picklistEdit the numerical values or characters within a function
	<ul style="list-style-type: none">Navigate down in the picklistEdit the numerical values or characters within a function
	<ul style="list-style-type: none">Confirm entryJump to the next item

Operating key(s)	Meaning
 + 	Contrast setting of local display: darker
 + 	Contrast setting of local display: brighter
 + 	ESC functions: <ul style="list-style-type: none"> Exit the editing mode without saving the modified value You are in the menu within a function group: the first time you press the keys simultaneously, you go back one parameter in the function group. Every subsequent time you press the keys simultaneously, you go up one level in the menu. You are in the menu at a selection level: each time you press the keys simultaneously, you go up a level in the menu. <i>Note:</i> For the terms function group, level, selection level, see the "Menu structure".
	<ul style="list-style-type: none"> DIP switch 1: to lock/unlock parameters relevant to the measured value. Factory setting: off (unlocked) DIP switch 2: for the simulation mode, factory setting: off (simulation mode off)

7.2.2 Operating example: Parameters with a picklist


Example: selecting "Deutsch" as the language of the menu.











	Language	000	Operation
1	✓ English Deutsch		"English" is set as the menu language (default value). A ✓ in front of the menu text indicates the option that is currently active.
2	Deutsch ✓ English		Select "Deutsch" with  or  .
3	✓ Deutsch English		<ul style="list-style-type: none"> Select  to confirm. A ✓ in front of the menu text indicates the active option ("Deutsch" is now selected as the menu language). Use  to exit the edit mode for the parameter.

7.2.3 Operating example: User-definable parameters

Example: Setting the "Set URV (014)" parameter from 100 mbar (1.5 psi) to 50 mbar (0.75 psi).

Menu path: Setup → Extended setup → Current output → Set URV





	Set URV	014	Operation
1		mbar	The local display shows the parameter to be changed. The "mbar" unit is defined in another parameter and cannot be changed here.

	Set URV	014	Operation
2	<div><div>1 0 0 . 0 0 0</div>mbar</div>		Press  or  to enter the edit mode. The first digit is highlighted in black.
3	<div><div>5 0 0 . 0 0 0</div>mbar</div>		Use the  key to change "1" to "5". Press the  key to confirm "5". The cursor jumps to the next position (highlighted in black). Confirm "0" with  (second position).
4	<div><div>5 0 0 . 0 0 0</div>mbar</div>		The third digit is highlighted in black and can now be edited.
5	<div><div>5 0 ↵ . 0 0 0</div>mbar</div>		Use the  key to change to the "↵" symbol. Use  to save the new value and exit the edit mode. See next graphic.
6	<div><div>5 0 . 0 0 0</div>mbar</div>		The new value for the upper range value is 50 mbar (0.75 psi). Use  to exit the edit mode for the parameter. Use  or  to return to the edit mode.

7.2.4 **Operating example: Accepting the pressure present**

Example: Setting pos. zero adjustment.

Menu path: Main menu → Setup → Pos. zero adjust

	Pos. zero adjust	007	Operation
1	<div><div>✓ Cancel</div>Confirm</div>		The pressure for pos. zero adjustment is present at the device.
2	<div>Cancel</div> <div>✓ Confirm</div>		Use  or  to switch to the "Confirm" option. The active option is highlighted in black.
3	<div>Adjustment has been accepted!</div>		Use the  key to accept the applied pressure for pos. zero adjustment. The device confirms the adjustment and goes back to the "Pos. zero adjust" parameter.
4	<div>✓ Cancel</div> Confirm		Use  to exit the edit mode for the parameter.

8 Commissioning

The device is configured for the "Pressure" measuring mode as standard. The measuring range and the unit in which the measured value is transmitted correspond to the data on the nameplate.

WARNING

The permitted process pressure is exceeded!

Risk of injury if parts burst! Warnings are displayed if the pressure is too high

- ▶ If a pressure that is greater than the maximum permitted pressure is present at the device, messages "E115 sensor overpressure" and "E727 sensor pressure error - overrange" are output in succession. Only use the device within the sensor range limits!

NOTICE

The permitted process pressure is undershot!

Messages are displayed if the pressure is too low.

- ▶ If a pressure that is lower than the minimum permitted pressure is present at the device, messages "E120 sensor low pressure" and "E727 sensor pressure error - overrange" are output in succession. Only use the device within the sensor range limits!

8.1 Configuring messages

- The messages E727, E115 and E120 are "Error"-type messages and can be configured as a "Warning" or an "Alarm". The factory setting for these messages is "Warning". This setting prevents the current output from adopting the configured alarm current value in applications (e.g. cascade measurement) where the user knowingly accepts that the sensor range may be exceeded.
- We recommend setting messages E727, E115 and E120 to "Alarm" in the following instances:
 - It is not necessary to go outside the sensor range for the measuring application.
 - A position adjustment must be carried out that has to correct a large measured error as a result of the orientation of the device (e.g. devices with diaphragm seal).

8.2 Selecting the language and measuring mode

8.2.1 Local operation

The MEASURING MODE parameter is on the first selection level.

The following measuring modes are available:

- Pressure
- Level

8.3 Position adjustment

Due to the orientation of the device, there may be a shift in the measured value, i.e. when the vessel is empty or partly filled, the measured value does not display zero. There are two ways to perform position adjustment.

- Menu path on local display:
GROUP SELECTION → OPERATING MENU → SETTINGS → POSITION ADJUST
- Menu path in FieldCare:
OPERATING MENU → SETTINGS → POSITION ADJUST


8.3.1 Performing position adjustment via the local display or FieldCare

The parameters listed in the following table can be found in the POSITION ADJUST. group (menu path: OPERATING MENU → SETTINGS → POSITION ADJUST.).

Parameter name	Description
POS. ZERO ADJUST, Entry	<p>Pos. zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known</p> <p>Example:</p> <ul style="list-style-type: none"> MEASURED VALUE = 2.2 mbar (0.032 psi) You correct the MEASURED VALUE via the "POS. ZERO ADJUST" parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjustment) = 0.0 mbar The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Factory setting: 0.0</p>
POS. INPUT VALUE, Entry	<p>Pos. zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, a reference measurement value (e.g. from a reference device) is required.</p> <p>Example:</p> <ul style="list-style-type: none"> MEASURED VALUE = 0.5 mbar (0.0073 psi) For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, for example 2.0 mbar (0.029 psi). (The following applies: MEASURED VALUE_{new} = POS. INPUT VALUE) For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, for example 2.0 mbar (0.029 psi). (The following applies: MEASURED VALUE_{new} = POS. INPUT VALUE) The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. The following applies: CALIB. OFFSET = MEASURED VALUE_{old} – POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 bar (0.0073 psi) - 2.0 bar (0.029 psi) = 1.5 bar (0.022 psi) <p>Factory setting: 0.0</p>
CALIB. OFFSET, Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure is known.</p> <p>Example:</p> <ul style="list-style-type: none"> MEASURED VALUE = 2.2 mbar (0.032 psi) Via the CALIB. OFFSET parameter, enter the value by which the MEASURED VALUE should be corrected. To correct the MEASURED VALUE to 0.0 mbar, you must enter the value 2.2 here. (The following applies: MEASURED VALUE_{new} = MEASURED VALUE_{old} – CALIB. OFFSET) MEASURED VALUE (after entry for calib. offset) = 0.0 mbar <p>Factory setting: 0.0</p>

8.4 Pressure measurement

8.4.1 Information regarding pressure measurement

- A Quick Setup menu is available for both the "Pressure" and "Level" measuring modes and guides you through the most important basic functions. You specify which Quick Setup menu should be displayed with the setting in the MEASURING MODE parameter. See also the "Selecting the language and measuring mode" section →  19.
- For a detailed parameter description, see the Operating Instructions BA00303P "Cerabar S/ Deltabar S/ Deltapilot S, Description of Device Functions"
 - FF: Table, Pressure Transducer Block
 - FieldCare: Table, POSITION ADJUST.
 - FieldCare: Table, BASIC SETUP
 - FieldCare: Table, EXTENDED SETUP


WARNING

Changing the measuring mode affects the span (URV)!

This can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the operating menu "SETTINGS→ BASIC SETUP" and reconfigured if necessary!

8.5 Quick Setup menu for the "Pressure" measuring mode

Local operation	FieldCare
Measured value display Switch from the measured value display to the GROUP SELECTION with  .	Measured value display Select the QUICK SETUP menu.
GROUP SELECTION Select the MEASURING MODE parameter.	Measuring Mode Select the Primary Value Type parameter.
MEASURING MODE Select the "Pressure" option.	Primary Value Type Select the "Pressure" option.
GROUP SELECTION Select the QUICK SETUP menu.	
POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i.e. you assign the value 0.0 to the pressure present.	POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i.e. you assign the value 0.0 to the pressure present.
DAMPING VALUE Enter the damping time (time constant). The damping affects the speed at which all subsequent elements, such as the local display, measured value and OUT Value of the Analog Input Block, react to a change in the pressure.	DAMPING VALUE Enter the damping time (time constant). The damping affects the speed at which all subsequent elements, such as the local display, measured value and OUT Value of the Analog Input Block, react to a change in the pressure.



71563279

www.addresses.endress.com
