
01.00.zz (Device firmware)

Products Solutions Services

Description of Device Parameters **Micropilot FMR20B, FMR30B**

Radar HART







1 About this document

1.1 **Document function**

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 **Document structure**

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.

The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating** tool.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** ($\rightarrow \equiv 107$) they are logged in with. This document lists the submenus and their parameters that are available to the User role Maintenance.


The operating menu is dynamic and adapts the choice of parameters to the selected options.




For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:

Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols

▲ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of information


- 1 Indicates additional information
- Reference to documentation
- Operation via local display
- Operation via operating tool
- Write-protected parameter

1.6 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu



	Minimum flow value	→ 🖺 26
	Maximum flow value	→ 🖺 27
	Maximum draining speed	→ 🖺 27
	Maximum filling speed	→ 🖺 27
	Counter overfilling	→ 🖺 28
	Counter underfilling	→ 🖺 28
	Minimum sensor temperature	→ 🖺 28
	Time min. sensor temperature	→ 🖺 28
	Maximum sensor temperature	→ 🖺 29
	Time max. sensor temperature	→ 🖺 29
	Minimum terminal voltage	→ 🖺 29
	Maximum terminal voltage	→ 🖺 29
	Minimum electronics temperature	→ 🖺 29
	Maximum electronics temperature	→ 🖺 30
	Reset min./max.	→ 🖺 30
► Simulation		→ 🖺 30
	Simulation	→ 🖺 30
	Simulation distance	→ 🖺 31
	Process variable value	→ 🖺 31
	Value current output	→ 🖺 31
	Diagnostic event simulation	→ 🖺 31
	Simulated flow value	→ 🖺 33
► Heartbeat To	echnology	→ 🖺 33
	► Heartbeat Verification	→ 🖺 33
	Date/time Heartbeat Verification	→ 🖺 33

		Operating time (Ve	rification)	→ 🖺 34
		Verification result		→ 🖺 34
		Status		→ 🖺 34
► Echo curve				→ 🖺 35
	Save reference curve	e		→ 🖺 35
	Time reference curv	re		→ 🖺 35
	Reference curve acti	ive		→ 🖺 35
▶ Diagnostic settin	ngs			→ 🖺 36
	► Properties			→ 🖺 36
		▶ 941 Echo lost		→ 🖺 36
			941 Diagnostic behavior	→ 🖺 36
			941 Event category	→ 🖺 37
			Value echo lost	→ 🖺 37
			Ramp at echo lost	→ 🖺 37
			Delay time echo lost	→ 🗎 38
		▶ 942 In safety dis	stance	→ 🖺 40
			942 Diagnostic behavior	→ 🖺 40
			942 Event category	→ 🖺 41
			Safety distance	→ 🖺 41
			Acknowledge alarm	→ 🖺 41
	► Configuration]	→ 🖺 96
		▶ Process		→ 🖺 41
			941 Diagnostic behavior	→ 🖺 42
			941 Event category	→ 🖺 42

				942 Diagnostic behavior	→ 🖺 43
				942 Event category	→ 🖺 43
		1		> 12 Event category	
Application					→ 🖺 44
	► Measuring units	3			→ 🖺 44
		Level unit			→ 🖺 44
		Length unit			→ 🖺 44
		Temperature unit			→ 🖺 44
	► Measured value	s			→ 🖺 45
		Level linearized			→ 🖺 45
		Flow			→ 🖺 45
		Totalizer value			→ 🖺 45
		Totalizer overflow			→ 🖺 46
		Level			→ 🖺 46
		Terminal voltage 1			→ 🖺 46
		Terminal current			→ 🖺 47
		Electronics temperat	ture		→ 🖺 47
		Output current			→ 🖺 47
		Distance			→ 🖺 47
		Unfiltered distance			→ 🖺 48
		Sensor temperature			→ 🖺 48
	► Sensor				→ 🖺 48
		► Basic settings			→ 🖺 48
			Medium type		→ 🖺 48
		[Operating mode		→ 🖺 49
			Application		→ 🖺 49

Empty calibrati	on	→ 🖺 50
Full calibration		→ 🖺 50
► Advanced settings		→ 🖺 51
► Adjustment		→ 🖺 51
	Maximum draining speed solid	→ 🖺 51
	Maximum filling speed solid	→ 🖺 51
	Maximum draining speed liquid	→ 🖺 52
	Maximum filling speed liquid	→ 🖺 52
	Damping output	→ 🖺 53
	Evaluation sensitivity	→ 🖺 53
	First echo sensitivity	→ 🖺 54
	Frequency mode	→ 🖺 54
► Mapping		→ 🖺 55
	Active map	→ 🖺 55
	Distance	→ 🖺 55
	Confirm distance	→ 🖺 55
	Mapping end point	→ 🖺 56
	Record map	→ 🖺 58
► Distance		→ 🖺 58
	Maximum measuring distance	→ 🖺 58
	Upper blank out	→ 🖺 58
	Output mode	→ 🖺 59
	Level limit mode	→ 🖺 60
	High limit	→ 🖺 60

		Low limit	→ 🖺 60
		Level correction	→ 🖺 61
	► Echo evaluation		→ 🖺 62
		► Tank bottom evaluation	→ 🖺 66
		► Echo tracking	→ 🖺 67
► Linearization			→ 🖺 70
	Times		\ F3 .70
	Linearization type		→ 🖺 70
	Unit after linearizat	ion	→ 🖺 70
	Free text		→ 🖺 71
	Level linearized		→ 🖺 71
	Maximum value		→ 🖺 71
	Diameter		→ 🖺 71
	Intermediate heigh	t	→ 🖺 72
	Table mode		→ 🖺 72
	Table number		→ 🖺 72
	Level		→ 🖺 73
	Level		→ 🖺 73
	Customer value		→ 🖺 73
	Activate table		→ 🖺 73
	CRC linearization ta	ble	→ 🖺 74
▶ Flow settings			→ 🖺 74
	► Flow basic setting	ngs	→ 🖺 74
		Volume flow unit	→ 🖺 74
		Decimal places	→ 🖺 75
		Linearization type	→ 🖺 75

10

Table mode	→ 🗎 76
Flume type	→ 🖺 76
Weir type	→ 🖺 77
Khafagi Venturi flume	→ 🖺 77
Venturi flume	→ 🗎 77
Parshall flume	→ 🗎 78
Palmer Bowlus flume	→ 🖺 78
Approach width (B)	→ 🗎 79
Approach diameter (Da)	→ 🗎 79
Throat diameter (D)	→ 🖺 79
Throat width (b)	→ 🖺 79
Throat length (L)	→ 🖺 80
Hump height (p)	→ 🖺 80
Side slope (m)	→ 🖺 80
Leopold Lagco flume	→ 🖺 80
Flume length (L)	→ 🖺 81
Flume width (b)	→ 🖺 81
H flume	→ 🖺 82
Inner diameter (d)	→ 🖺 83
Roughness coefficient	→ 🖺 83
Slope (m)	→ 🖺 83
Alpha (α)	→ 🖺 83
Beta (β)	→ 🖺 84
Gamma (γ)	→ 🖺 84
С	→ 🖺 84

Maximum level (h_max)	→ 🖺 85
Flow exponent (x)	→ 🖺 85
Trapezoidal weir	→ 🖺 85
Weir width (b)	→ 🖺 85
Crest width (b)	→ 🖺 86
Crest height (p)	→ 🖺 86
Crest length (L)	→ 🖺 86
Notch angle (α)	→ 🖺 86
Validation	→ 🖺 87
Volume flow calculation	→ 🖺 87
► Flow advanced settings	→ 🖺 88
Maximum flow	→ 🖺 88
Low flow cutoff	→ 🖺 88
Low flow cutoff value	→ 🖺 89
► Totalizer settings	→ 🖺 89
Totalizer	→ 🖺 89
Totalizer unit	→ 🖺 89
Decimal places	→ 🗎 90
Failure behavior	→ 🖺 90
► Signal information	→ 🖺 90
Signal quality	→ 🖺 90
Absolute echo amplitude	→ 🗎 91
Relative echo amplitude	→ 🖺 91
► Current output	→ 🗎 92
Assign PV	→ 🖺 92

12

	Measuring mode cu	rrent output	→ 🖺 92
	Current range outp	at	→ 🖺 93
	Lower range value	output	→ 🖺 93
	Upper range value	output	→ 🖺 93
	Failure behavior cu	rrent output	→ 🖺 94
	Failure current		→ 🖺 94
	Output current		→ 🖺 94
	Terminal current		→ 🗎 94
► HART output]	→ 🖺 96
y rama sarpat	► Configuration		→ 🖺 96
	Configuration		
		HART address	→ 🖺 96
		HART short tag	→ 🖺 96
		Device tag	→ 🖺 96
		No. of preambles	→ 🖺 97
		Loop current mode	→ 🗎 97
	► HART output		→ 🖺 97
		Assign PV	→ 🖺 97
		Primary variable (PV)	→ 🖺 98
		Assign SV	→ 🖺 98
		Secondary variable (SV)	→ 🖺 98
		Assign TV	→ 🖺 99
		Tertiary variable (TV)	→ 🖺 99
		Assign QV	→ 🖺 99
		Quaternary variable (QV)	→ 🖺 100
		Zameerinary variable (21)	

$\begin{array}{c} \text{Burst mode 1} \\ \\ \text{Burst command 1} \\ \\ \text{Burst variable 0 3} \\ \\ \text{Burst variable 4 7} \\ \\ \text{Burst trigger mode} \\ \\ \\ \text{Burst trigger level} \\ \\ \end{array}$	100 101 101 102
Burst variable 0 3 $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ $	101 101 102 102
Burst variable $4 \dots 7$ $\Rightarrow riangleq riangleq$	101 102 102 102
Burst trigger mode → 🖺	102 102 102
	102
	102
33	102
Min. update period \rightarrow	
	105
► Information →	102
Device ID → 🖺	
Device type → 🖺	
Device revision → 🖺	103
HART short tag → 🗎	104
HART revision → 🖺	104
HART descriptor → 🖺	104
HART message → 🖺	105
HART date code → 🖺	105
System → 🖺	105
► Device management → 🖺	105
Device tag \rightarrow	105
Locking status \rightarrow	106
Configuration counter \rightarrow	106
Reset device → 🖺	106
► User management → 🖺	107

14

	► User management	→ 🖺 107
	User role	→ 🖺 107
	Delete password	→ 🖺 107
	Forgot password?	→ 🖺 108
	► Enter password	→ 🖺 108
	Password	→ 🖺 108
	Enter access code	→ 🖺 108
	Status password entry	→ 🖺 108
	▶ Define password	→ 🖺 109
	New password	→ 🖺 109
	Confirm new password	→ 🖺 109
	Status password entry	→ 🖺 109
	► Change password	→ 🖺 110
	P Change password	/ 🖹 110
	Old password	→ 🖺 110
	New password	→ 🖺 110
	Confirm new password	→ 🖺 110
	Status password entry	→ 🖺 111
	► Recover password	→ 🖺 111
	Reset password	→ 🖺 111
	Status password entry	→ 🖺 111
► Bluetooth config	guration	→ 🖺 112
	Bluetooth activation	→ 🖺 112
► Display		→ 🖺 112
	Language	→ 🖺 112
	Format display	→ 🗎 113

	Value 1 display	→ 🖺 113
	value 1 display	/ 目 11)
	Decimal places 1	→ 🖺 113
	Value 2 display	→ 🖺 114
	Decimal places 2	→ 🖺 114
	Decimal places 2	/ = 11 1
	Rotation display	→ 🗎 115
	Color scheme	→ 🖺 115
▶ Geol	location	→ 🗎 115
	Process Unit Tag	→ 🖺 115
	Location Description	→ 🖺 116
	Longitude	→ 🖺 116
	Latitude	→ 🖺 116
	Altitude	→ 🗎 116
	Location method	→ 🖺 117
▶ Infor	rmation	→ 🖺 117
	Device name	→ 🗎 117
	Manufacturer	→ 🗎 117
	Serial number	→ 🗎 118
	Order code	→ 🖺 118
	Firmware version	→ 🖺 118
	Hardware version	→ 🖺 118
	Extended order code 1 3	→ 🖺 119
	Checksum	→ 🖺 119
► Softv	ware configuration	→ 🖺 124
	CRC device configuration	→ 🖺 124
	Stored CRC device configuration	→ 🖺 124

Timestamp stored CRC device config.	→ 🖺 125
Activate SW option	→ 🖺 125
Software option overview	→ 🖺 125

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of guided wizards and cross-thematic special functions.

Navigation 🗐 🖹 Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology Heartbeat Verification
- Safety mode
- Proof test
- Import/Export
- Compare

3.1.2 Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.



If the wizard is canceled before all the necessary parameters have been configured, any settings already made are saved.

The device may be in an undefined state!

▶ Use these functions to reset the device to factory settings.

Navigation \square Guidance \rightarrow Commissioning

Parameters for "Commissioning" wizard

The following parameters are configured in this wizard:

- Device identification
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - HART short tag
 - HART date code
 - HART descriptor
 - HART message
 - HART address

Measurement adjustments

- Distance unit
- Temperature unit
- Level unit
- Medium type
- Operating mode
- Application
- Empty calibration
- Full calibration
- Level
- Displayed level/distance correct?
- Show possible signals in?
- Distance
- Level
- Linearization type
- Unit after linearization
- Maximum value
- Diameter
- Intermediate height
- Diameter
- Level linearized
- Table mode
- Table number
- Level
- Customer value
- Activate table
- Maximum value
- Flume type
- Weir type
- Volume flow unit
- Decimal places
- Khafaqi Venturi flume
- Venturi flume
- Parshall flume
- Palmer Bowlus flume
- Approach width (B)
- Throat width (b)
- Throat length (L)
- Hump height (p)
- Side slope (m)
- Validation
- Approach diameter (Da)
- Alpha (α)
- Beta (β)
- Gamma (γ)
- **■** C
- Maximum level (h_max)
- Flow exponent (x)
- Maximum flow
- Trapezoidal weir
- Weir width (b)
- Crest width (b)
- Crest height (p)
- Crest length (L)
- Notch angle (α)
- Totalizer
- Totalizer unit
- Failure behavior
- Totalizer value


- Totalizer overflow
- Low flow cutoff
- Low flow cutoff value
- Output settings
 - Process variable output current
 - Current range output
 - Lower range value output
 - Upper range value output
 - Failure behavior current output
 - Failure current
 - Loop current mode
 - Assign HART variables?

This function comprises several parameters, including the **Assign PV** parameter.

3.1.3 Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- In situ verification of measuring instruments in the application



Navigation \Box Guidance \rightarrow Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation \square Guidance \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

3.1.4 Safety mode

The write protection guards the device settings against overwriting. In addition, it is recommended for safety applications to confirm the safety relevant device settings. This ensures that the correct values have been entered and downloaded to device.

This input can be used as the confirmation sequence instead of manual checklists. After the safety relevant device settings have been confirmed, the device is marked with the property Safety-locked. This indicates that the safety relevant parameter settings have been checked and evaluated as correct.

To unlock the safety locking the sequence needs to be restarted. The safety locking is deactivated when the safety unlocking code (= safety locking code) is entered.

Navigation ☐ Guidance → Safety mode

3.1.5 Proof test

The proof test will simulate the current output.

The safety function is not guaranteed during proof test. Alternative process control in manual must be taken to ensure process safety.

Note: It is only possible to perform a proof test when the device has no alarm and the hardware write protection switch is off.

Navigation $\blacksquare \blacksquare$ Guidance \rightarrow Proof test

3.1.6 Import/Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create configuration report

Device documentation can be saved in PDF format under Create configuration report. This device documentation contains the following general device information:

- Information on device parameters
- Information on Linearization
- Echo curve
- Event list
- Diagnostic list

Navigation ☐ Guidance → Import/Export

3.1.7 Compare

Compare datasets

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import/Export
- Datasets with the configuration currently in the device

Navigation \square Guidance \rightarrow Compare

3.2 Diagnostics

3.2.1 Active diagnostics

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Active diagnos.

Active diagnostics

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Active diagnos.

Description Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.

23

User interface • Operating time of the device until the event occurs

Symbol for diagnostic behaviorCode for diagnostic behavior

■ Event text

Corrective measure

Additional information

Access:

Read access: Operator

■ Write access: -

Timestamp

Navigation □ Diagnostics → Active diagnos. → Timestamp

Description Displays the timestamp for the currently active diagnostic message.

User interface Days (d), hours (h), minutes (m), seconds (s)

Additional information Access:

■ Read access: Operator

■ Write access: -

Previous diagnostics

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Prev.diagnostics

Description Displays the diagnostic message for the last diagnostic event that has ended.

User interface ■ Symbol for event behavior

Code for diagnostic behaviorOperation time of occurrence

■ Event text

Factory setting (

■ Read access: Operator

Write access: -

Timestamp

Navigation □ Diagnostics → Active diagnos. → Timestamp

Description Displays the timestamp of the diagnostic message generated for the last diagnostic event

that has ended.

User interface Days (d), hours (h), minutes (m), seconds (s)

Additional information

Access:

■ Read access: Operator

■ Write access: -

Operating time from restart

Navigation \Box Diagnostics \rightarrow Active diagnos. \rightarrow Time fr. restart

Description Indicates how long the device has been in operation since the last time the device was

restarted.

User interface Days (d), hours (h), minutes (m), seconds (s)

■ Read access: Operator

■ Write access: -

Operating time

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Operating time

Description Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

■ Read access: Operator

■ Write access: -

3.2.2 Diagnostic list

Navigation \square Diagnostics \rightarrow Diagnostic list

3.2.3 Event logbook

Navigation \square Diagnostics \rightarrow Event logbook

 $Diagnostics \rightarrow Event logbook \rightarrow Clear event list$

Description Delete all entries of the event list.

Selection • Cancel

Clear event list

Navigation

■ Clear data

Factory setting Cancel

Read access: ExpertWrite access: Expert

3.2.4 Minimum/maximum values

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val.

Min. level value

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Min. level value

Description Minimum or maximum measured value by device.

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when device is reset.

User interface Signed floating-point number

Time min. level	
Navigation	
Description	Displays operating time at which the lowest level was measured.
	Note:
	This value can be reset via the "Reset min./max." parameter.
	This value is also reset when device is reset.
User interface	Character string comprising numbers, letters and special characters
Max. level value	
Navigation	☐ Diagnostics \rightarrow Min/max val. \rightarrow Max. level value
Description	Minimum or maximum measured value by device.
zeenption	Note: This value can be reset via the "Reset min./max." parameter. This value is also reset when device is reset.
User interface	Signed floating-point number
Time max. level	
Navigation	☐ Diagnostics → Min/max val. → Time max. level
Description	Displays operating time at which the highest level was measured.
	Note: This value can be reset via the "Reset min./max." parameter. This value is also reset when device is reset.
User interface	Character string comprising numbers, letters and special characters
Minimum flow value	
Navigation	☐ Diagnostics \rightarrow Min/max val. \rightarrow Min. flow value
Description	Displays the lowest volume flow measured since the last reset.
	Note: This value can be reset via the "Reset min./max." parameter.
	This value is also reset when "Operating mode" of the device is switched or the device is

reset.

User interface Signed floating-point number

Maximum flow value

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max. flow value

Description Displays the highest volume flow measured since the last reset.

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when "Operating mode" of the device is switched or the device is

reset.

User interface Signed floating-point number

Maximum draining speed

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max. drain speed

Description Displays highest draining speed measured since the last reset.

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when device is reset.

User interface Positive floating-point number

Maximum filling speed

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max. fill. speed

Description Displays highest filling speed measured since the last reset.

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when device is reset.

User interface Positive floating-point number

Counter	overfilling
Counter	Overmining

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Count overfill.

Description Displays the number of underfills (level < 0 %) or overfills (level > 100 %).

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when device is reset.

User interface 0 to 65 535

Factory setting 0

Counter underfilling

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Count underfill.

Description Displays the number of underfills (level < 0 %) or overfills (level > 100 %).

Note:

This value can be reset via the "Reset min./max." parameter.

This value is also reset when device is reset.

User interface 0 to 65 535

Factory setting 0

Minimum sensor temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Min. sensor temp

Description Displays lowest or highest sensor temperature measured so far.

User interface −150 to 200 °C

Time min. sensor temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Time min s. temp

Description Displays operating time at which the lowest sensor temperature was measured so far.

User interface Character string comprising numbers, letters and special characters

Maximum sensor temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max. sensor temp

Description Displays lowest or highest sensor temperature measured so far.

User interface $-150 \text{ to } 200 \,^{\circ}\text{C}$

Time max. sensor temperature

Navigation Diagnostics \rightarrow Min/max val. \rightarrow Time max s. temp

Description Displays operating time at which the highest sensor temperature was measured so far.

User interface Character string comprising numbers, letters and special characters

Minimum terminal voltage

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Min.term.volt.

Description Minimum or maximum measured terminal (supply) voltage.

User interface 0.0 to 50.0 V

Maximum terminal voltage

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max.term.voltage

Description Minimum or maximum measured terminal (supply) voltage.

User interface 0.0 to 50.0 V

Minimum electronics temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Min.electr.temp.

Description Minimum or maximum measured main electronics temperature.

User interface Signed floating-point number

Maximum electronics	temperature	
Navigation		
Description	Minimum or maximum measured main electronics temperature.	
User interface	Signed floating-point number	
Reset min./max.		A
Navigation	☐ Diagnostics → Min/max val. → Reset min/max	
Description	Resets the drag indicator of the selected process variable.	
Selection	 None Drain/fill speed Level Flow * Reset all 	
Factory setting	None	
	3.2.5 Simulation Navigation	
Simulation		۵
Navigation		
Description	Simulates one or more process variables and/or events. Warning: Output will reflect the simulated value or event.	

OffDistance

30

Selection

Level
 Level linearized *
 Flow *

Current output

Diagnostic event simulation

^{*} Visibility depends on order options or device settings

Factory setting

Simulation distance

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Sim distance

Prerequisite Simulation = Distance ($\rightarrow \triangleq 47$)

Off

User entry -999 900 to 999 900 mm

Factory setting 0 mm

Process variable value

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Proc. var. value

Prerequisite Simulation = Level linearized ($\rightarrow \triangleq 45$)

Description Defines the value of the selected variable.

The outputs assume values or states according to this value.

User entry Signed floating-point number

Factory setting 0

Value current output

Prerequisite Simulation = Current output ($\rightarrow \triangleq 92$)

Description Defines the value of the simulated output current.

User entry 3.59 to 23 mA

Factory setting 3.59 mA

Diagnostic event simulation

Navigation □ Diagnostics → Simulation → Diagnostic event

Prerequisite Simulation = Diagnostic event simulation

Description Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select "Off".

Selection 062 Sensor connection faulty

151 Sensor electronic failure

203 HART Device Malfunction

204 HART Electronic Defect

242 Firmware incompatible

252 Module incompatible

270 Main electronics defective

272 Main electronics faulty

273 Main electronics defective

282 Data storage inconsistent

283 Memory content inconsistent

287 Memory content inconsistent

388 Electronics and HistoROM defective

410 Data transfer failed

412 Processing download

420 HART Device Configuration Locked

421 HART Loop Current fixed

430 Configuration faulty

431 Trim required

435 Linearization faulty

437 Configuration incompatible

438 Dataset different

441 Current output 1 saturated

452 Calculation error detected

484 Failure mode simulation active

485 Process variable simulation active

491 Current output 1 simulation active

538 Configuration Sensor Unit invalid

585 Simulation distance

586 Record map

801 Supply voltage too low

802 Supply voltage too high

805 Loop current faulty

807 No Baseline due to insuf. volt. at 20 mA

825 Electronics temperature

826 Sensor temperature out of range

843 Process value above limit

844 Process value out of specification

846 HART Non-Primary Variable Out of Limit

847 HART Primary Variable Out of Limit

848 HART Device Variable Alert

941 Echo lost

942 In safety distance968 Level limited

Factory setting Off

Simulated flow value

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Sim. flow value

Description Simulates one or more process variables and/or events.

Warning:

Output will reflect the simulated value or event.

User entry Positive floating-point number

Factory setting 0 l/h

3.2.6 Heartbeat Technology

Navigation $\blacksquare \square$ Diagnostics \rightarrow Heartbeat Techn.

Heartbeat Verification

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

Date/time Heartbeat Verification

 $\textbf{Navigation} \hspace{1cm} \square \hspace{1cm} \text{Diagnostics} \rightarrow \text{Heartbeat Techn.} \rightarrow \text{Heartbeat Verif.} \rightarrow \text{Date/time Heartbeat}$

Verification

Description Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display,

"----" is shown.

User interface Character string comprising numbers, letters and special characters

Factory setting 01.01.1970 00:00:00

Operating time (Verific	Operating time (Verification)		
Navigation			
Description	Value of the operating hours counter at the time of verification.		
User interface	Days (d), hours (h), minutes (m), seconds (s)		
Verification result			
Navigation			
Description	Result of Heartbeat Verification.		
User interface	 Not done Passed Not done Failed 		
Factory setting	Not done		
Status			
Navigation	☐ Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status		
Description	Shows the actual status.		
User interface	 Done Busy Failed Not done 		

Factory setting

Not done

3.2.7 Echo curve

Navigation $\blacksquare \square$ Diagnostics \rightarrow Echo curve

Save reference curve

Navigation \square Diagnostics \rightarrow Echo curve \rightarrow Save ref. curve

Description Saves the currently measured echo curve as a reference curve in the device.

Note:

When the guided commissioning is executed the first time, the reference curve is

automatically saved at the end.

In the case of manual commissioning (menu), it is recommended to actively save the

reference curve immediately after commissioning.

Selection • Customer reference curve

Not active

Factory setting Not active

Read access: MaintenanceWrite access: Maintenance

Time reference curve

Navigation \Box Diagnostics \rightarrow Echo curve \rightarrow Time ref. curve

Description Displays the timestamp of the recording of the reference curve.

User interface Days (d), hours (h), minutes (m), seconds (s)

Additional information Timestamp of the recording of the reference curve.

Access:

■ Read access: Operator

■ Write access: -

Reference curve active

Navigation \square Diagnostics \rightarrow Echo curve \rightarrow Ref.curve active

Description Displays if a customer reference curve has been stored in the device.

User interface

- Delivery reference curve available
- Customer reference curve available

Factory setting

Customer reference curve available

Additional information

The delivery reference curve is recorded at the factory before delivery.

A customer reference curve is recorded as standard at the end of the Guidance

 \rightarrow Commissioning . These reference curves can be used for diagnosing problems when troubleshooting.

Access:

- Read access: Maintenance
- Write access: -

3.2.8 Diagnostic settings

Navigation \square Diagnostics \rightarrow Diag. settings

Properties

Navigation $\blacksquare \square$ Diagnostics \rightarrow Diag. settings \rightarrow Properties

941 Echo lost

Navigation $\blacksquare \blacksquare$ Diagnostics \Rightarrow Diag. settings \Rightarrow Properties \Rightarrow 941 Echo lost

941 Diagnostic behavior

Navigation

Description

Defines the behavior of the output in case of an echo loss.

"Last valid value"

Last valid value is kept.

"Ramp at echo lost"

Output value is continuously shifted towards 0 % or 100 %.

"Value echo lost"

Output assumes a defined value.

"Alarm"

Device generates an alarm.

Selection

- Last valid value
- Ramp at echo lost
- Value echo lost
- Alarm

Factory setting Last valid value

941 Event category

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow 941 Event categ.

Selection ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

■ No effect (N)

Factory setting Out of specification (S)

Value echo lost

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Value echo lost

Description Value of the output in case of an echo loss.

User entry Signed floating-point number

Factory setting 0 %

Ramp at echo lost

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Ramp echo lost

Description Slope of the ramp in the case of an echo loss.

Note:

If the slope is positive (+), the output increases until it reaches 100 %. If the slope is negative (-), the output decreases until it reaches 0 %.

User entry Signed floating-point number

Factory setting 0.0 %/min

Delay echo lost **Navigation** Diagnostics → Diag. settings → Properties → 941 Echo lost → Delay echo lost Description Activate or deactivate the delay time in case of echo loss. After an echo loss, the device allows the delay time to pass before the reaction defined in parameter "941 Diagnostic behavior" occurs. This way it can be avoided that temporary disturbances interrupt the measurement unnecessarily. Selection Off On **Factory setting** On Additional information Access: ■ Read access: Expert ■ Write access: Expert Delay time echo lost Diagnostics → Diag. settings → Properties → 941 Echo lost → DlyTimeEchoLost Navigation Description Enter the delay time in case of echo loss. After an echo loss, the device allows the delay time defined here to pass before the reaction defined in parameter "941 Diagnostic behavior" occurs. This way it can be avoided that temporary disturbances interrupt the measurement unnecessarily. 0 to 99 999.9 s User entry **Factory setting** 0sDelay time echo jump

Navigation Diagnostics → Diag. settings → Properties → 941 Echo lost → DlyTimeEchoJump

Description Enter the delay time for the echo jump.

0 to 99 999.9 s User entry

Factory setting 0 s

Additional information Access:

> Read access: Expert Write access: Expert

Echo lost window right

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Echo l.win.right

Description Enter the initial width of the extended search window in the direction of decreasing levels.

User entry 0 to 99 900 mm

Factory setting 4 000 mm

Read access: ExpertWrite access: Expert

Echo lost window left

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Echo l.win.left

Description Enter the initial width of the extended search window in the direction of increasing levels.

User entry 0 to 99 000 mm

Factory setting 4 000 mm

Read access: ExpertWrite access: Expert

Draining speed

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Draining speed

Description Enter the opening speed of the extended search window in the direction of decreasing

levels.

User entry Signed floating-point number

Factory setting 599 994 cm/min

Additional information Access:

■ Read access: Expert

■ Write access: Expert

Filling speed

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 941 Echo lost \rightarrow Filling speed

Description Enter the opening speed of the extended search window in the direction of increasing

levels.

User entry Signed floating-point number

Factory setting 599 994 cm/min

Read access: ExpertWrite access: Expert

942 In safety distance

Navigation $\blacksquare \Box$ Diagnostics \Rightarrow Diag. settings \Rightarrow Properties \Rightarrow 942 In saf. dist

942 Diagnostic behavior

Navigation $\blacksquare \blacksquare$ Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 942 In saf. dist \rightarrow 942Diag. behav.

Description Sets the behavior of the output when the safety distance is exceeded.

"Off"

No alarm or warning is generated.

"Alarm"

An alarm is generated.

"Warning"

A warning is generated.

"Self holding"

An alarm is generated. The alarm remains even if the signal is again outside the safety distance. To deactivate the alarm, the "Acknowledge alarm" parameter must be manually

set to "Yes".

Selection ■ Off

Alarm

Warning

Self holding

Factory setting Warning

942 Event category			
Navigation	□ Diagnostics → Diag. settings → Properties → 942 In saf. dist → 942Event categ.		
Selection	■ Failure (F) ■ Function check (C)		
	Out of specification (S)		
	Maintenance required (M)No effect (N)		
	- No chect (N)		
Factory setting	Out of specification (S)		
Safety distance			
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 942 In saf. dist \rightarrow Safety distance		
User entry	-200 000 to 125 000 mm		
Factory setting	0 mm		
Acknowledge alarm			
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 942 In saf. dist \rightarrow Acknowl. alarm		
Selection	■ No ■ Yes		
Factory setting	No		
	Configuration		
	Navigation		

Navigation

Additional information "941 Echo lost" submenu

941 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 941Diag. behav.

Description Defines the behavior of the output in case of an echo loss.

"Last valid value" Last valid value is kept. "Ramp at echo lost"

Output value is continuously shifted towards 0 % or 100 %.

"Value echo lost"

Output assumes a defined value.

"Alarm"

Device generates an alarm.

Selection • Last valid value

Ramp at echo lostValue echo lost

Alarm

Factory setting Last valid value

941 Event category

Navigation \Box Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 941Event categ.

Selection ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

■ No effect (N)

Factory setting Out of specification (S)

Navigation

Additional information

" 942 In safety distance" submenu

942 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 942Diag. behav.

Description Sets the behavior of the output when the safety distance is exceeded.

"Off"

No alarm or warning is generated.

"Alarm"

An alarm is generated.

"Warning"

A warning is generated.

"Self holding"

An alarm is generated. The alarm remains even if the signal is again outside the safety distance. To deactivate the alarm, the "Acknowledge alarm" parameter must be manually

set to "Yes".

Selection ■ Off

AlarmWarningSelf holding

Factory setting

Warning

942 Event category

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 942Event categ.

Selection ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

■ No effect (N)

Factory setting

Out of specification (S)

3.3 Application

3.3.1 Measuring units

Navigation $\blacksquare \square$ Application \rightarrow Measuring units

Level unit Navigation Application \rightarrow Measuring units \rightarrow Level unit Description Select unit for level measurement. Selection SI units US units **-** % ■ ft ■ in ■ m ■ mm **Factory setting** % Length unit Navigation Application \rightarrow Measuring units \rightarrow Length unit Description Select the length unit for distance measurement. It is used, e.g., for the basic calibration ("Empty calibration" or "Full calibration"). Selection SI units US units ■ mm ■ ft ■ in ■ m **Factory setting** mm Temperature unit Navigation Application → Measuring units → Temperature unit Description Select the temperature unit. Selection SI units **US** units ■ °C °F

44

■ K

Factory setting °C

3.3.2 Measured values

Navigation $\blacksquare \square$ Application \rightarrow Measured values

Level linearized **Navigation** Application \rightarrow Measured values \rightarrow Level linearized Description Displays the linearized level. User interface Signed floating-point number 0 % **Factory setting** Flow **Navigation** Application \rightarrow Measured values \rightarrow Flow Description Displays the current volume flow. User interface Signed floating-point number **Factory setting** 0 l/h Totalizer value Navigation Application → Measured values → Totalizer value Description Displays the current totalizer counter value.

Additional information:

If the current totalizer counter exceeds the operating tool's maximum numerical display range of 7 digits, the amount above this range is expressed as an overflow. The current totalizer counter therefore equals the sum of the overflow and the totalizer value displayed in the "Totalizer value" parameter.

Example of how to calculate the current totalizer counter when the value exceeds the 7 digit display limit of the operating tool:

- Value of "Totalizer value" parameter: 1,968,457 m³
- Value of "Totalizer overflow" parameter: $1 \times 10^7 \text{ m}^3 = 10,000,000 \text{ m}^3$
- Current totalizer reading: 11,968,457 m³

User interface Positive floating-point number

Factory setting 01

Totalizer overflow

Navigation \Box Application \rightarrow Measured values \rightarrow Tot. overflow

Description Displays the current totalizer overflow.

Additional information:

If the current totalizer counter exceeds the operating tool's maximum numerical display range of 7 digits, the amount above this range is expressed as an overflow. The current totalizer counter therefore equals the sum of the overflow and the totalizer value displayed in the "Totalizer value" parameter.

in the "Totalizer value" parameter.

Example of how to calculate the current totalizer counter when the value exceeds the 7

digit display limit of the operating tool:

- Value of "Totalizer value" parameter: 1,968,457 m³

- Value of "Totalizer overflow" parameter: $1 \times 10^7 \text{ m}^3 = 10,000,000 \text{ m}^3$

- Current totalizer reading: 11,968,457 m³

User interface Positive floating-point number

Factory setting 0

Level

Navigation \square Application \rightarrow Measured values \rightarrow Level

Description Displays the actual measured level.

User interface -99 999.9 to 200 000.0 %

Factory setting 0.0 %

Terminal voltage 1

Navigation \square Application \rightarrow Measured values \rightarrow Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V

Factory setting 0 V

Terminal current

Navigation \square Application \rightarrow Measured values \rightarrow Terminal curr.

Description Shows the current value of the current output which is currently measured

User interface 0 to 30 mA

Factory setting 0 mA

Electronics temperature

Navigation \Box Application \rightarrow Measured values \rightarrow Electronics temp

Description Displays the current temperature of the main electronics.

User interface Signed floating-point number

Factory setting $0 \,^{\circ}\text{C}$

Output current

Navigation \square Application \rightarrow Measured values \rightarrow Output curr.

Description Displays the value currently calculated for the current output

User interface 3.59 to 23 mA

Factory setting 3.59 mA

Distance

Navigation \Box Application \Rightarrow Measured values \Rightarrow Distance

Description Distance from reference point to medium surface.

Note:

The reference point is specified in the respective Operating Instructions.

User interface Signed floating-point number

Factory setting 0 mm

Unfiltered distance				
Navigation				
Description	Displays the distance from the reference point of the measurement to the medium surface without the influence of the signal filters.			
	Note: The reference point is specified in the respective Operating Instructions.			
User interface	Signed floating-point number			
Factory setting	0 mm			
Sensor temperature				
Navigation	\square Application \rightarrow Measured values \rightarrow Sensor temp.			
Description	Displays the current temperature of the sensor electronics.			
User interface	−150 to 200 °C			
Factory setting	−150 °C			
	3.3.3 Sensor			
	Navigation \square Application \rightarrow Sensor			
	Basic settings			
	<i>Navigation</i>			
Medium type				
Navigation				
Description	Select whether the measured medium is liquid or solid.			
Selection	LiquidSolid			
Factory setting	Liquid			

Operating mode				
Navigation				
Description	Select operating mode.			
Selection	Level linearizedFlow			
Factory setting	Level linearized			
Application				
Navigation				
Description	Select application type.			
Selection	 Stirred vessel Standard measurement Level measurement * Workbench test 			
Factory setting	Stirred vessel			
Additional information	 Stirred vessel: Vessel with agitator. Standard measurement: Standard measurement for liquid applications. Workbench test: All signal filters are deactivated. This mode should only be used for tempurposes. 			
Application				
Navigation				
Description	Select application type.			
Selection	 Silo Bunker (wide area) Stockpile/Profile measurement Crusher/belt Workbench test 			
Factory setting	Workbench test			

^{*} Visibility depends on order options or device settings

Additional information

- Silo: Silo for bulk material (tall and narrow)
- Bunker (wide area): Storage bunker for solids (wide area). Visibility depends on order options or device settings
- Stockpile/Profile measurement: Open stockpile or profile measurement of the stockpile. Visibility depends on order options or device settings
- Crusher/belt: Crusher or conveyor belt. Visibility depends on order options or device settings
- Workbench test: All signal filters are deactivated. This mode should only be used for test purposes.

Empty calibration	
Navigation	
Description	Enter the distance from the reference point of the measurement to the minimum level (0 %).
	Note: The reference point is specified in the respective Operating Instructions.
User entry	0 to 125 000 mm
Factory setting	20 000 mm
Full calibration	
Navigation	
Description	Distance between minimum level (0 %) and maximum level (100 %).
User entry	1 to 125 000 mm
Factory setting	20 000 mm

Advanced settings

Navigation \square Application \rightarrow Sensor \rightarrow Advanced set.

Adjustment

Navigation \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Adjustment

Maximum draining speed solid

Navigation

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- No filter/test *
- Very slow < 0.5 m (1.6 ft)/h*
- Slow < 1 m (3.3 ft)/h
- Medium < 2 m (6.5 ft)/h
- Standard < 4 m (13 ft)/h
- Fast < 8 m (26 ft)/h
- Very fast $> 8 \text{ m} (26 \text{ ft})/\text{h}^*$

Factory setting

Standard < 4 m (13 ft)/h

Maximum filling speed solid

Navigation

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/ test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Endress+Hauser

^{*} Visibility depends on order options or device settings

Selection

- No filter/test *
- Very slow $< 0.5 \text{ m} (1.6 \text{ ft})/\text{h}^*$
- Slow < 1 m (3.3 ft)/h
- Medium < 2 m (6.5 ft)/h*</p>
- Standard < 4 m (13 ft)/h*
- Fast < 8 m (26 ft)/h
- Very fast > 8 m (26 ft)/h*

Factory setting

Standard < 4 m (13 ft)/h

Maximum draining speed liquid

Navigation

 \exists Application → Sensor → Advanced set. → Adjustment → Max drain liquid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- No filter/test *
- Slow < 1 cm (0.4 in)/min *
- Medium < 10 cm (4 in)/min *</p>
- Standard < 1 m (40 in)/min
- Fast < 2 m (80 in)/min*
- Very fast > 2 m (80 in)/min *

Factory setting

Standard < 1 m (40 in)/min

Maximum filling speed liquid

Navigation

 \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Adjustment \rightarrow Max. fill liquid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Visibility depends on order options or device settings

Selection • No filter/test *

■ Slow < 1 cm (0.4 in)/min*

■ Medium < 10 cm (4 in)/min*

■ Standard < 1 m (40 in)/min

■ Fast < 2 m (80 in)/min³

Very fast > 2 m (80 in)/min *

Factory setting

Standard < 1 m (40 in)/min

Damping output

<u></u>

Navigation

 \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Adjustment \rightarrow Damping out.

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling

- Limit value monitoring

- Forwarding to display

- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own "Damping" parameter. In the measurement chain, only

one of the two attenuation parameters shall have a value other than $\boldsymbol{0}.$

Otherwise, the signal will be attenuated several times.

User entry 0.0 to 1200.0 s

Factory setting 0.0 s

Evaluation sensitivity

53

Navigation

Description

Selection of the evaluation sensitivity

Options to select from:

- "Low"

Interferers but also small level signals are not recognized. The weighting curve is located high.

- "Medium"

The weighting curve is in a medium region.

- "Hiah"

Small level signals but also interferers can be reliably detected. The weighting curve is located low.

Selection

Low

■ Medium

High

^{*} Visibility depends on order options or device settings

Factory setting

Medium

First echo sensitivity	
Navigation	
Description	This parameter describes the band for First Echo evaluation. Is measured / calculated down from the peak of the current level echo.
	Options to select from:
	"Low" The band for the first echo evaluation is very narrow. The evaluation stays longer at the found echo respectively does not jump to the next Echo or distortion signal.
	"Medium" The band for the first echo evaluation has an average width.
	"High" The band for the first echo evaluation is broad. The evaluation jumps earlier to the next echo or distortion signal.
Selection	LowMediumHigh
Factory setting	Medium

Frequency mode		
Navigation		
Description	Displays the device-specific measurement configuration.	
Selection	 Mode 1 Mode 2 Mode 3 Mode 4 Mode 5 	
Factory setting	Mode 2	

7. /			
Ma	nı	n11	пп
IVIU	r		19

 $\textit{Navigation} \hspace{1.5cm} \begin{tabular}{ll} \blacksquare & Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \\ \end{tabular}$

Active map			
Navigation			
Description	Select the mapping curve that is to be active. Alternatively, the option "No map" can be selected.		
Selection	Factory mapCustomer mapNo map		
Factory setting	Factory map		
Additional information	 Factory map: The device activates the mapping curve recorded in the factory. This curve cannot be edited or deleted. Customer map: If a customer map has been recorded, this can be activated in order to minimize distortions in the application. This curve can be edited. No map 		
Distance			
Navigation			
Description	Distance from reference point to medium surface.		
	Note: The reference point is specified in the respective Operating Instructions.		
User interface	Signed floating-point number		
Factory setting	0 mm		
Confirm distance			
Navigation			
Description	State whether the measured distance and the actual distance are the same.		
Selection	■ Modify map		

Endress+Hauser 55

Distance okDistance unknown

■ Level <=0

Factory setting

Distance unknown

Mapping start point

Navigation

 \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \rightarrow Map. start point

Description Enter the initial distance for the mapping.

User entry -999 900 to 999 900 mm

Factory setting -250 mm

Additional information

Access:

Read access: ExpertWrite access: Expert

Mapping end point

Navigation

Description

Defines up to which distance the new mapping has to be recorded. Remark: Make sure the level signal is not covered by the mapping.

User entry 0.1 to 125 mm

Factory setting 100 mm

Map gap

Navigation

Description

Enter the distance between the defined and the actual end of the map.

User entry

0 to 100 000 mm

Factory setting

190 mm

Additional information

Access:

Read access: ExpertWrite access: Expert

End of mapping

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \rightarrow End of mapping

Description Define the behavior of the mapping curve at the end of the map.

Selection ■ Adjustable

■ Last map value

Factory setting Adjustable

Read access: ExpertWrite access: Expert

End map. ampl.

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \rightarrow End map. ampl.

Description Enter the minimum amplitude of the mapping curve.

User entry -99 999.0 to 99 999.0 dB

Factory setting −100 dB

Read access: ExpertWrite access: Expert

Mapping overlay time

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \rightarrow Map overlay time

Description Enter the duration for which a map is recorded. During this time, the largest amplitude

values that occur are overlapped.

User entry 1 to 600 s

Factory setting 5 s

Read access: ExpertWrite access: Expert

Record map **Navigation** Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Mapping \rightarrow Record map Selection ■ No Overlay map ■ Delete cust map **Factory setting** No Distance Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance Maximum measuring distance **Navigation** Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance \rightarrow Max. meas. dist. Description If the preset measuring range differs significantly from the maximum measuring distance, it is recommended to enter the maximum measuring distance here. Example: Continuous level monitoring in the upper third of a tank/silo. For tanks or silos with a conical outlet, this parameter should not be changed, as in this type of applications Empty calibration is usually not much smaller than the tank/silo height. **User entry** 0 to 125 000 mm Factory setting 20000 mm Upper blank out **Navigation** Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance \rightarrow Upper blank out Description Displays the distance from the reference point to slightly above the maximum level (100 The value is calculated by the device to suppress signals in this range. The value can also be adjusted manually. No evaluation takes place in the upper blank out area. **User entry** 0 to 125 000 mm

Factory setting

0 mm

Output mode

Navigation

 \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance \rightarrow Output mode

Description

Select output mode between:

Ullage:

Displays the remaining ullage.

or

Level linearized:

Display the measured level.

Note: If linearization has been activated, the linearized level is displayed here.

Selection

Ullage

■ Level linearized

Factory setting

Level linearized

L max. drain speed

Navigation

Description

Enter the maximum draining speed.

User entry

0.0 to 50 000.0 %/min

Factory setting

0.0 %/min

Additional information

Access:

Read access: ExpertWrite access: Expert

L max. fill speed

Navigation

Description

Enter the maximum filling speed.

User entry

0.0 to 50000.0 %/min

Factory setting

0.0 %/min

Endress+Hauser

Additional information	Access:
------------------------	---------

Read access: ExpertWrite access: Expert

Level limit mode				
Navigation				
Description	Determines whether the output value is limited by an upper or lower limit (or by both).			
Selection	 Off Low limit High limit Low and High Limit 			
Factory setting	Low limit			
High limit				
Navigation				
Description	Defines the upper limit of the output value.			
User entry	Signed floating-point number			
Factory setting	0 %			
Low limit		a		
Navigation				
Description	Defines the lower limit of the output value.			
User entry	-200 000.0 to 200 000.0 %			

Factory setting

0.0 %

Level correction

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance \rightarrow Level correction

Description Value is added to the measured level to compensate for a constant level error.

Level correction > 0:

The level is increased by this value.

Level correction < 0:

The level is decreased by this value.

User entry -200 000.0 to 200 000.0 %

Factory setting 0.0 %

Antenna zero distance

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Distance \rightarrow Ant. zero dist.

Description Displays the zero point adjustment of the antenna at state of delivery.

Note:

This parameter is adjusted to the device at the factory and should not be changed.

User entry 0 to 10 000 mm

Factory setting 230 mm

Read access: ExpertWrite access: Expert

	Echo evaluation Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation Echo evaluation	
	Navigation	
Echo curve statistic		<u> </u>
Navigation		•
Description	Activate or deactivate the weighted echo curve statistics.	
Selection	■ Off ■ On	
Factory setting	On	
Additional information	Access: ■ Read access: Expert ■ Write access: Expert	
Echo curve statistics up	[A
Navigation		1•
Description	Enter the number of measuring cycles to define the weighting of the last echo curve for ascending signals.	
User entry	0 to 30	
Factory setting	1	
Additional information	Access:	

Read access: ExpertWrite access: Expert

Echo curve statistic down

Navigation riangleq Application riangleq Sensor riangleq Advanced set. riangleq Echo evaluation riangleq ECS

in down

Description Enter the number of measuring cycles to define the weighting of the last echo curve for

descending signals.

User entry 0 to 30

Factory setting 1

Read access: ExpertWrite access: Expert

Echo curve smoothing

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Echo evaluation \rightarrow EC.

smoothing

Description Enter window width for echo curve smoothing.

User entry 0 to 9 900 mm

Factory setting 35 mm

Additional information Access:

Read access: ExpertWrite access: Expert

Weighting curve offset

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation

→ WgthCurveOffset

Description Enter offset of the weighting curve.

User entry -9 999.0 to 9 999.0 dB

Factory setting 12 dB

Additional information Access:

Read access: ExpertWrite access: Expert

Window size weighting curve

Navigation

→ WindowWgthCurve

Description

Enter width of the weighting curve window.

User entry

0 to 9900 mm

Factory setting

800 mm

Additional information

Access:

Read access: ExpertWrite access: Expert

Maximum value weighting curve

Navigation

→ MaxValWghtCurve

Description

Enter maximum amplitude of the weighting curve.

User entry

-9999.0 to 9999.0 dB

Factory setting

100 dB

Additional information

Access:

Read access: ExpertWrite access: Expert

First echo band

Navigation

B Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Echo evaluation \rightarrow First

echo band

Description

Enter width of the first echo band.

User entry

0.0 to 100.0 dB

Factory setting

10 dB

Additional information

Access:

Read access: ExpertWrite access: Expert

DSC Mode

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Echo evaluation \rightarrow DSC

Mode

Description Select DSC mode.

Selection ■ Off

Manual

Auto

Factory setting Manual

Additional information • Off: The signal control is deactivated.

• Manual: The signal control is activated with a fixed value.

• Auto: The signal control operates automatically.

Access:

Read access: ExpertWrite access: Expert

DSC Factor

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Echo evaluation \rightarrow DSC

Factor

Description Displays the actual factor for signal control.

User entry 0 to 1

Factory setting 0.75

Additional information Access:

Read access: Expert

■ Write access: Expert

Actual DSC Factor

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation

→ ActualDSCFactor

Description Displays the actual factor for signal control.

User interface 0 to 1

Factory setting 0

tınnal	inform	nation

Access:

■ Read access: Expert

■ Write access: -

Tank bottom evaluation

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation

→ Tank bottom eval

Tank bottom range **Navigation** Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Tank bottom eval \rightarrow TB range Description Determines the range in which the physical bottom echo is searched for. The bottom range extends downwards and starts at level 0 % "Empty calibration". It ends at the entered value. Note: If the level 0 % "Empty calibration" is far above the physical bottom, the bottom range

starts at the entered "Maximum measuring distance".

0 to 312 500 mm **User entry**

15000 mm **Factory setting**

Min. amplitude TBD

Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Tank bottom eval Navigation

 \rightarrow Min. ampl. TBD

Enter the minimum amplitude for tank bottom detection. Description

-99 to 9999.0 dB **User entry**

Factory setting 10 dB

Additional information Access:

> Read access: Expert ■ Write access: Expert

Lower level area

Navigation riangleq Application riangleq Sensor riangleq Advanced set. riangleq Echo evaluation riangleq Tank bottom eval

→ Lower level area

Description Enter lower level area.

In this defined range, the first echo band is lowered to the weighting curve.

User entry 0 to 125 000 mm

Factory setting 400 mm

Read access: ExpertWrite access: Expert

Echo tracking

Navigation \square Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation

→ Echo tracking

Evaluation mode

Navigation Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation \rightarrow Echo tracking

→ Evaluation mode

Description Defines the evaluation mode for the echo tracking.

Selection ■ FlexTracking

■ FlexTracking - Weak signals

FixTracking

■ FixTracking - Weak signals

Factory setting FlexTracking

Reset evaluation

Navigation riangleq Application riangleq Sensor riangleq Advanced set. riangleq Echo evaluation riangleq Echo tracking riangleq Reset

evaluation

Description Restarts level determination.

Selection • Reset done

■ Yes

Factory setting

Reset done

Window size tracking

Navigation

Application → Sensor → Advanced set. → Echo evaluation → Echo tracking
 → Wind.size track.

, vviiiu.512C t.

User entry

0 to 20500 mm

Factory setting

250 mm

Additional information

Access:

Read access: ExpertWrite access: Expert

Debug

Navigation

Application \rightarrow Sensor \rightarrow Advanced set. \rightarrow Echo evaluation

→ Debug

Debug parameter index

Navigation

10

User entry 0 to 65 535

Factory setting 2

Additional information

Access:

Read access: ExpertWrite access: Expert

Debug array index

Navigation

man

User entry 0 to 255

Factory setting

Additional information

Access:

Read access: ExpertWrite access: Expert

Status

Navigation

User entry

0 to 255

Factory setting

0

Additional information

Access:

Read access: ExpertWrite access: Expert

Debug value

Navigation

User interface

Signed floating-point number

Factory setting

4.0

Additional information

Access:

Read access: ExpertWrite access: -

Debug value integer32

Navigation

int32

User interface Positive integer

Factory setting 0

Additional information

Access:

Read access: ExpertWrite access: -

Linearization

Navigation Application \rightarrow Sensor \rightarrow Linearization

Linearization type

Navigation Application \rightarrow Sensor \rightarrow Linearization \rightarrow Lineariz. type

Description Select type of linearization.

Selection None

- Linear Table
- Pyramid bottom Conical bottom Angled bottom ■ Horizontal cylinder
- Sphere

Factory setting

None

Unit after linearization

Navigation

Application \rightarrow Sensor \rightarrow Linearization \rightarrow Unit lineariz.

■ lb

■ ft

■ in

UsGal ■ ft³

Description

Defines the unit of the linearized value.

The selected unit is only used to be indicated on the display. The measured value is not transformed according to the selected unit.

If "Free text" is selected, an additional parameter "Free text" appears in which the designation of the unit can be defined.

Selection

SI units

- STon
- t
- kg
- cm³
- dm³
- m³
- hl
- **-** 1
- **-** %
- mm

Custom-specific units

Free text

Factory setting

%

US units Imperial units impGal

Free text

Navigation riangleq Application riangleq Sensor riangleq Linearization riangleq Free text

User entry Character string comprising numbers, letters and special characters (32)

Factory setting Free text

Level linearized

Navigation riangleq Application riangleq Sensor riangleq Linearization riangleq Level linearized

Description Displays the linearized level.

User interface Signed floating-point number

Factory setting 0 %

Maximum value

Navigation Application \rightarrow Sensor \rightarrow Linearization \rightarrow Maximum value

Description Linearized value corresponding to a level of 100 %.

User entry -200 000 to 200 000.0 %

Factory setting 100.0 %

Diameter

Navigation \square Application \rightarrow Sensor \rightarrow Linearization \rightarrow Diameter

Description Diameter of the spherical tank or horizontal cylinder tank.

User entry 0.001 to 125 000 mm

Factory setting 20 000 mm

Intermediate height	
Navigation	$\ \ \ \ \ \ \ \ \ \ \ \ \ $
Description	Height of the pyramid, conical or angled bottom
User entry	0 to 125 000 mm
Factory setting	0 mm
Table mode	
Navigation	
Description	Defines the editing mode of the linearization table. Note: DeviceCare and FieldCare contain a graphical tool for the easy creation of a linearization table. Device Care: "Additional functions" -> "Linearization table" FieldCare: "Device Operation" -> "Device Functions" -> "Additional functions" -> "Linearization table"
Selection	 Manual Semiautomatic* Clear table Sort table*
Factory setting	Manual
Table number	
Navigation	
Description	Enter or change the table point.
User entry	1 to 32
Factory setting	1

^{*} Visibility depends on order options or device settings

Level

Navigation riangleq Application riangleq Sensor riangleq Linearization riangleq Level

Description Enter level value of the table point (value before linearization).

User entry Signed floating-point number

Factory setting 0 %

Level

Navigation riangleq Application riangleq Sensor riangleq Linearization riangleq Level

Description Displays measured level (value before linearization). This value is transmitted to the table.

User interface Signed floating-point number

Factory setting 0.0 %

Customer value

 $\textbf{Navigation} \hspace{1.5cm} \hspace{.2cm} \hspace{.2c$

Description Enter linearized value for the table point.

User entry Signed floating-point number

Factory setting 0 %

Activate table

Navigation Application \rightarrow Sensor \rightarrow Linearization \rightarrow Activate table

Description Activate or deactivate table.

The table can only be activated if the table values:

- are present in at least 2 value pairs

- do not exceed the sensor limits

- represent a function which is monotonically ascending or descending

Selection • Disable

■ Enable

Factory setting Disable

CRC linearization table			
Navigation			
Description	CRC checksum based on the current parameter settings of the linearization table. Can be used to detect changes in the parameter settings.		
User interface	0 to 65 535		
Factory setting	0		
	Flow settings		
	Navigation \square Application \rightarrow Sensor \rightarrow Flow settings		
	Flow basic settings		
	<i>Navigation</i>		
Volume flow unit			
Navigation			

Select volume flow unit.

Description

Imperial units

qal/s (imp)

qal/h (imp)

■ gal/d (imp)

■ Mgal/d (imp)

gal/min (imp)

Selection

SI units

- cm^3/s
- cm³/min
- cm^3/h
- cm^3/d
- \bullet dm³/s
- dm³/min
- \bullet dm³/h
- dm^3/d
- m³/s
- m³/min
- m^3/h
- m³/d
- 1/s
- l/min
- 1/h
- 1/d
- hl/s
- hl/min
- hl/h ■ hl/d
- Ml/h ■ Ml/d

- US units
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- qal/s (us)
- qal/min (us)
- qal/h (us)
- qal/d (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;lig.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)

Other units

- \bullet in³/s
- in³/min
- in³/h
- \bullet in³/d

Factory setting

l/h

Decimal places

Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Decimal places

Selection

Navigation

■ X

- X.X
- X.XX X.XXX
- X.XXXX

Factory setting

X.XX

Linearization type

Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Lineariz. type

Description

Navigation

Select linearization type.

Endress+Hauser

Selection

■ Flume

Weir

Standard formula

■ Table

Factory setting

Flume

Table mode

Navigation

Description

Defines the editing mode of the linearization table.

Note:

DeviceCare and FieldCare contain a graphical tool for the easy creation of a linearization

table.

Device Care: "Additional functions" -> "Linearization table"

FieldCare: "Device Operation" -> "Device Functions" -> "Additional functions" ->

"Linearization table"

Selection

Manual

Semiautomatic *Clear table

■ Sort table

Factory setting

Manual

Flume type

Navigation

Description

Select flume type.

Selection

- Khafaqi Venturi flume
- Venturi flume
- Parshall flume
- Palmer Bowlus flume
- Trapezoidal flume (ISO 4359)
- Rectangular flume (ISO 4359)
- U-shaped flume (ISO 4359)

Factory setting

Khafaqi Venturi flume

^{*} Visibility depends on order options or device settings

Weir type		
Navigation		
Description	Select weir type.	
Selection	 Trapezoidal weir Rectang. broad-crested weir (ISO 3846) Thin-plate rectangular weir (ISO 1438) Thin-plate triangular weir (ISO 1438) 	
Factory setting	Trapezoidal weir	
Khafagi Venturi flume		
Navigation		
Description	Select a flume or weir type.	
	An overview of the flumes and weirs can be found in the Operating Instructions.	
Selection	 HQV302 HQV303 HQV304 HQV305 HQV306 HQV308 HQV310 HQV313 HQV316 	
Factory setting	HQV302	
Venturi flume		
Navigation		
Description	Select a flume or weir type.	
	An overview of the flumes and weirs can be found in the Operating Instructions.	
Selection	 HQI415 HQI425 HQI430 HQI440 HQI450 HQI480 	
Factory setting	HQI415	

Parshall flume Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Parshall Navigation Description Select a flume or weir type. An overview of the flumes and weirs can be found in the Operating Instructions. Selection ■ 1 in ■ 2 in ■ 3 in ■ 6 in ■ 9 in ■ 1 ft ■ 1.5 ft ■ 2 ft ■ 3 ft ■ 4 ft ■ 5 ft ■ 6 ft ■ 8 ft ■ 10 ft ■ 12 ft **Factory setting** 1 in Palmer Bowlus flume Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Palmer Bowlus Description Select a flume or weir type. An overview of the flumes and weirs can be found in the Operating Instructions. Selection ■ 6 in ■ 8 in ■ 10 in ■ 12 in ■ 15 in ■ 18 in ■ 21 in ■ 24 in ■ 27 in **30** in **Factory setting** 6 in

Approach width (B)

Navigation

Description Enter the approach width (B).

User entry Positive floating-point number

Factory setting 2 000 mm

Approach diameter (Da)

Navigation \Box Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Approach diam.

Description Enter the approach diameter (Da).

User entry Positive floating-point number

Factory setting 400 mm

Throat diameter (D)

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Throat diameter

Description Enter the throat diameter (D).

User entry Positive floating-point number

Factory setting 400 mm

Throat width (b)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Throat width

Description Enter the throat width (b).

User entry Positive floating-point number

Factory setting 500 mm

Throat length (L)		
Navigation		
Description	Enter the throat length (L).	
User entry	Positive floating-point number	
Factory setting	3 000 mm	
Hump height (p)		Â
Navigation		
Description	Enter hump height (p).	
User entry	Positive floating-point number	
Factory setting	150 mm	
Side slope (m)		
Navigation		
Description	Enter the side slope (m).	
User entry	0.0 to 1000	
Factory setting	1	
Leopold Lagco flume		
Navigation		
Description	Select a flume or weir type. An overview of the flumes and weirs can be found in the Operating Instructions.	
Selection	 6 in 8 in 10 in 12 in 15 in 18 in 21 in 	

24 in30 in4 in

Factory setting

4 in

Flume length (L)

Navigation riangleq Application riangleq Sensor riangleq Flow settings riangleq Basic settings riangleq Flume length

Description Select flume length (L).

Selection ■ 18 in ■ 36 in

■ 54 in ■ 108 in

Factory setting 18 in

Flume width (b)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Flume width

Description Select flume width (b).

Selection ■ 12 in

24 in48 in72 in

Factory setting 12 in

Flume width (b)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Flume width

Description Select flume width (b).

Selection ■ 1 in

2 in4 in8 in

Factory setting 1 in

Endress+Hauser

Flume width (b)		Â
Navigation		
Description	Select flume width (b).	
Selection	 2 in 4 in 8 in 16 in 	
Factory setting	2 in	
Flume width (b)		
Navigation		
Description	Select flume width (b).	
Selection	 3 in 6 in 12 in 24 in 	
Factory setting	3 in	
H flume		
Navigation		
Description	Select a flume or weir type. An overview of the flumes and weirs can be found in the Operating Instructions.	
Selection	 0.5 ft 0.75 ft 1 ft 1.5 ft 2 ft 2.5 ft 3 ft 4.5 ft 	
Factory setting	0.5 ft	

Inner diameter (d)

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Inner diameter

Description Enter the inner diameter (d).

User entry 100 to 100 000 mm

Factory setting 1000 mm

Roughness coefficient

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Roughness coeff.

Description Enter the roughness coefficient.

More information can be found in the Operating Instructions.

User entry 0 to 1

Factory setting 0.01

Slope (m)

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Slope

Description Enter the slope (m).

User entry 0 to 1

Factory setting 0.01

Alpha (α)

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Alpha (a)

Description Enter Alpha (α).

Note:

Regardless of the set volume flow rate unit, for the standard formula the device calculates

the volume flow rate Q in m^3/h .

The level h is in mm.

The values for alpha, beta, gamma and C are not converted and must be entered

accordingly.

User entry Positive floating-point number

1.5

Beta (β)

Navigation

Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Beta (β)

Description

Enter Beta (β) .

Note:

Regardless of the set volume flow rate unit, for the standard formula the device calculates

the volume flow rate O in m³/h.

The level h is in mm.

The values for alpha, beta, gamma and C are not converted and must be entered

accordingly.

User entry

Positive floating-point number

Factory setting

1

Gamma (y)

Navigation

Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Gamma (y)

Description

Enter Gamma (y).

Note:

Regardless of the set volume flow rate unit, for the standard formula the device calculates

the volume flow rate Q in m³/h.

The level h is in mm.

The values for alpha, beta, gamma and C are not converted and must be entered

accordingly.

User entry

Signed floating-point number

Factory setting

0

Navigation

C

Enter C.

Description

Note:

Regardless of the set volume flow rate unit, for the standard formula the device calculates

the volume flow rate Q in m³/h.

The level h is in mm.

The values for alpha, beta, gamma and C are not converted and must be entered

Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow C

accordingly.

User entry Positive floating-point number

Factory setting 1

Maximum level (h_max)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Maximum level

Description Enter the maximum level (h_max).

User entry Positive floating-point number

Factory setting 1000 mm

Flow exponent (x)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Flow exponent

Description Enter the flow exponent (x).

User entry Positive floating-point number

Factory setting 1

Trapezoidal weir

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Trapezoidal weir

Description Select a flume or weir type.

An overview of the flumes and weirs can be found in the Operating Instructions.

Selection ■ T0/H3

■ T0/T5

Factory setting T0/H3

Weir width (b)

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Weir width

Description Enter the weir width (b).

User entry Positive floating-point number

Factory setting	1000 mm
-----------------	---------

3

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Crest width

Description Enter crest or notch width (b).

User entry Positive floating-point number

Factory setting 500 mm

Crest height (p)

Navigation riangleq Application riangleq Sensor riangleq Flow settings riangleq Basic settings riangleq Crest height

Description Enter the crest height (p).

User entry Positive floating-point number

Factory setting 150 mm

Crest length (L)

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Crest length

Description Enter the crest length (L).

User entry Positive floating-point number

Factory setting 150 mm

Notch angle (α)

Navigation riangle Application riangle Sensor riangle Flow settings riangle Basic settings riangle Notch angle

Description Enter the notch angle (α) .

User entry 20 to 100 °

Factory setting 90°

Validation

Navigation riangleq Application riangleq Sensor riangleq Flow settings riangleq Basic settings riangleq Validation

Description Result of the validation of the entered parameters (plausibility check).

User interface ■ Validation pending

- Validation passedUnexpected errorInvalid angle
- Validation failed
- Full calibration too lowThroat wider than flume
- Crest width too small
- Invalid length
- Invalid Full calibration
- $\mbox{-}$ Invalid Full calibration to height ratio
- Invalid throat to approach ratio
- Throat width too small
- Invalid crest length to height ratio
- Invalid Full calib. to length ratio
- Invalid crest height
- Validation failed

Factory setting Validation pending

Volume flow calculation

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow Basic settings \rightarrow Flow calculation

Description If the function is activated, the measured value is converted into the corresponding volume

flow rate.

Selection • Disable

Enable

Factory setting Disable

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow AdvancedSettings

Maximum flow

Navigation Application \rightarrow Sensor \rightarrow Flow settings \rightarrow AdvancedSettings \rightarrow Max. flow

Description Maximum flow in the selected unit.

The maximum flow corresponds to an output current of 20 mA (factory settings).

An adjustable default value is preset for each curve.

Note:

- If the value is exceeded, the device generates a diagnostic message "844 Process value out

of specification".

- This parameter is available for the linearization types flume, weir and formula.

User entry Positive floating-point number

Factory setting 0 l/h

Flow correction factor

Navigation riangleq Application riangleq Sensor riangleq Flow settings riangleq AdvancedSettings riangleq CorrectionFactor

Description Enter correction factor for the volume flow rate.

The calculated volume flow rate is multiplied by this factor.

User entry 0.8 to 2.0

Factory setting 1.0

Additional information Access:

Read access: ExpertWrite access: Expert

Low flow cutoff

Navigation \square Application \rightarrow Sensor \rightarrow Flow settings \rightarrow AdvancedSettings \rightarrow Low flow cutoff

Description Activate or deactivate "Low flow cutoff".

Low flow cutoff prevents the detection of flow rates that drop below the specified low flow

cutoff value.

Selection ■ Disable

■ Enable

Factory	setting

Disable

Low flow cutoff value		<u> </u>	
Navigation		al a	
Description	Enter the low flow cutoff value in percent, based on the maximum flow rate.		
User entry	0 to 100.0 %		
Factory setting	0 %		
	Totalizer settings		
	<i>Navigation</i>		
Totalizer			
Navigation			
Description	Activate or deactivate the totalizer for volume flow.		
Selection	DisableEnable		
Factory setting	Disable		
Totalizer unit			
Navigation			
Description	Select the unit of the totalizer for the totalized volume flow.		
Selection	SI units □ cm³ □ ft³ □ gal (imp) □ dm³ □ in³ □ gal (us) □ l □ Mgal (us) □ hl □ bbl (us;liq.) □ bbl (us;beer) □ bbl (us;cil) □ bbl (us;tank)		

l

Factory	setting	
ractory	setung	

Decimal places		
Navigation		
Selection	• v	
Selection	■ X ■ X.X	
	■ X.X ■ X.XX	
	■ X.XXX	
	■ X.XXXX	
Factory setting	x.xx	
Failure behavior		
Navigation		
Description	Select the behavior of the totalizer in the event of an error.	
Selection	Pause totalizerContinue with last valid value	
Factory setting	Pause totalizer	
	Signal information	
	Navigation \square Application \rightarrow Sensor \rightarrow Signal inform.	
Signal quality		
Navigation		
Description	Displays the quality of the evaluated level signal.	
User interface	 Strong Medium Weak No signal 	
Factory setting	Strong	

Absolute echo amplitude

Navigation \square Application \rightarrow Sensor \rightarrow Signal inform. \rightarrow Abs. echo ampl.

Description Shows the absolute amplitude of the evaluated level signal.

User interface -150.0 to 32.0 dB

Factory setting 0.0 dB

Relative echo amplitude

Navigation \square Application \rightarrow Sensor \rightarrow Signal inform. \rightarrow Relat.echo ampl.

Description Shows the relative amplitude (i.e. the distance to the evaluation curve) of the evaluated

level signal.

User interface 0.0 to 150.0 dB

Factory setting 0.0 dB

Sensor cycle time

Navigation riangleq Application riangleq Sensor riangleq Signal inform. riangleq Sens. cycle time

Description Displays the cycle time of the measurement.

User interface 0 to 65 535 ms

Factory setting 0 ms

Additional information Access:

Read access: ExpertWrite access: -

Actual IF gain

Navigation riangleq Application riangleq Sensor riangleq Signal inform. riangleq Actual IF gain

Description Displays the actual gain of the intermediate frequency.

User interface 0 to 1000

Factory setting 0

A 1 10.0 1		
Additional	∣ınt∩rm	ation

Access:

■ Read access: Expert

■ Write access: -

3.3.4 Current output

Navigation $\blacksquare \blacksquare$ Application \rightarrow Curr.output

Navigation

Application → Curr.output → Assign PV

Description

Assign a measured variable to the primary dynamic variable (PV).

Additional information:

The assigned measured variable is also used by the current output.

Selection

Level linearized

■ Distance ■ Flow *

Factory setting Level linearized

Measuring mode current output

Navigation \square Application \rightarrow Curr.output \rightarrow Output mode

Description Select curve of current output.

Selection • Standard

■ Inverse

Factory setting Standard

^{*} Visibility depends on order options or device settings

Current range output

Navigation riangle Application riangle Curr.output riangle Current range

DescriptionDefines the current range used to transmit the measured or calculated value.
In brackets are indicated the "low saturation value" and the "high saturation value".

If Measured value <= "low saturation", the output current is set to "low saturation". If Measured value >= "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection • 4 ... 20 mA (4 ... 20.5 mA)

4 ... 20 mA NE (3.8 ... 20.5 mA)4 ... 20 mA US (3.9 ... 20.8 mA)

Factory setting 4 ... 20 mA NE (3.8 ... 20.5 mA)

Lower range value output

Navigation □ Application → Curr.output → Low.range outp

DescriptionDepending on which variable has been selected as "Process variable output current", define

the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Factory setting 0.0 %

Upper range value output

Navigation \square Application \rightarrow Curr.output \rightarrow Upp.range outp

Description Depending on which variable has been selected as "Process variable output current", define

the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Factory setting 100.0 %

Failure behavior current output **Navigation** Application \rightarrow Curr.output \rightarrow Failure behav. Description Defines which current the output assumes in the case of an error. Min.: < 3.6 mA Max.: > 21.5 mA Note: The hardware DIP Switch for alarm current (if available) has priority over software setting. Selection Min. Max. **Factory setting** Min. Failure current Navigation Application \rightarrow Curr.output \rightarrow Failure current Description Enter current output value in alarm condition. **User entry** 21.5 to 23 mA **Factory setting** 22.5 mA **Output current** Navigation Application \rightarrow Curr.output \rightarrow Output curr. Description Displays the value currently calculated for the current output User interface 3.59 to 23 mA 3.59 mA **Factory setting** Terminal current Navigation Application \rightarrow Curr.output \rightarrow Terminal curr. Description Shows the current value of the current output which is currently measured

94

User interface

Factory setting

0 to 30 mA

0 mA

4 mA trim value

Navigation \square Application \rightarrow Curr.output \rightarrow 4 mA trim value

Description Enter the trim value for the 4 mA current output.

Note:

Simulation must be active.

User entry 3 to 5 mA

Factory setting 4 mA

Read access: ExpertWrite access: Expert

20 mA trim value

Navigation Application \rightarrow Curr.output \rightarrow 20 mA trim value

Description Enter the trim value for the 20 mA current output.

Note:

Simulation must be active.

User entry 18 to 22 mA

Factory setting 20 mA

Read access: ExpertWrite access: Expert

Description

User entry

Factory setting

plant.

x0B

3.3.5 HART output

Navigation \blacksquare Application \rightarrow HART output

Configuration

Navigation $\blacksquare \Box$ Application \rightarrow HART output \rightarrow Configuration

HART address		
Navigation		
Description	Enter the address to exchange data via the HART protocol.	
User entry	0 to 63	
Factory setting	0	
HART short tag		
Navigation		
Description	Defines the short tag for the measuring point.	
	Maximum length: 8 characters. Allowed characters: A-Z, 0-9, certain special characters.	
User entry	Character string comprising numbers, letters and special characters (8)	
Factory setting	SHORTTAG	
Device tag		
Navigation		
D		

96 Endress+Hauser

Enter a unique name for the measuring point to identify the device quickly within the

Character string comprising numbers, letters and special characters (32)

97

No. of preambles		
Navigation		
Description	Defines the number of preambles in the HART telegram	
User entry	5 to 20	
Factory setting	5	
Loop current mode		
Navigation		
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop communication mode is a HART digital communication mode where multiple devices may share the sam wires for power and communications. In this mode the output current is fixed.	
Selection	DisableEnable	
Factory setting	Enable	
	HART output	
	Navigation \blacksquare Application \rightarrow HART output \rightarrow HART output	

	
Navigation	
Description	Assign a measured variable to the primary dynamic variable (PV).
	Additional information: The assigned measured variable is also used by the current output.
Selection	 Level linearized Distance Flow *
Factory setting	Level linearized

^{*} Visibility depends on order options or device settings

Assign PV

Primary variable (PV) Navigation Application → HART output → HART output → Primary var (PV) Description Shows the current measured value of the primary dynamic variable (PV) User interface Signed floating-point number Factory setting 100.0 %

Application \rightarrow HART output \rightarrow HART output \rightarrow Assign SV

Assign a measured variable to the second dynamic variable (SV).

Selection • Level linearized

Distance

Electronics temperature Sensor temperature

Absolute echo amplitude

Relative echo amplitude

Area of incoupling

Percent of rangeLoop current

■ Flow *

Totalizer value *

Not used

Factory setting Distance

Secondary variable (SV)

Navigation

Description

Navigation \square Application \rightarrow HART output \rightarrow HART output \rightarrow Second.var(SV)

Description Shows the current measured value of the secondary dynamic variable (SV)

User interface 0 to 410.10498687664 mm

Factory setting 0 mm

^{*} Visibility depends on order options or device settings

Assign TV **Navigation** Application \rightarrow HART output \rightarrow HART output \rightarrow Assign TV Description Assign a measured variable to the tertiary dynamic variable (TV). Selection Level linearized Distance Electronics temperature Sensor temperature Absolute echo amplitude ■ Relative echo amplitude Area of incoupling Percent of range ■ Loop current ■ Flow ■ Totalizer value * Not used **Factory setting** Absolute echo amplitude **Tertiary variable (TV) Navigation** Application \rightarrow HART output \rightarrow HART output \rightarrow Tertiary var(TV)

Description Shows the current measured value of the tertiary (third) dynamic variable (TV)

User interface -150.0 to 0.0 deciBel

Factory setting -150.0 deciBel

Assign QV

Navigation \square Application \rightarrow HART output \rightarrow HART output \rightarrow Assign QV

Description Assign a measured variable to the quaternary dynamic variable (QV).

Selection • Level linearized

Distance

Electronics temperature

Sensor temperature

■ Absolute echo amplitude

Relative echo amplitude

Area of incoupling

Percent of range

■ Loop current

Visibility depends on order options or device settings

- Flow *
- Totalizer value *
- Not used

Relative echo amplitude

Quaternary variable (QV)

Navigation \square Application \rightarrow HART output \rightarrow Quaterna.var(QV)

Description Shows the current measured value of the quaternary (fourth) dynamic variable (QV)

User interface −150.0 to 0.0 deciBel

Factory setting −150.0 deciBel

Burst configuration 1

Navigation $\blacksquare \square$ Application \rightarrow HART output \rightarrow Burst config. 1

Navigation Application \rightarrow HART output \rightarrow Burst config. $1 \rightarrow$ Burst mode 1

Description Switch HART burst mode for burst message on

Selection ■ Off ■ On

Factory setting Off

Burst command	
---------------	--

Navigation Application \rightarrow HART output \rightarrow Burst config. $1 \rightarrow$ Burst command 1

Description Select the HART command that is sent to the HART master

Selection • Primary variable (PV)

Loop Current and Percent of Range

Dynamic Variables

^{*} Visibility depends on order options or device settings

- Device variables with status
- Device variables
- Additional device status

Loop Current and Percent of Range

Burst variable 0 ... 3

Navigation Application \rightarrow HART output \rightarrow Burst config. $1 \rightarrow$ Burst variable 0

Description For HART command 9 and 33, assign a HART device variable or process variable to burst

variable

Selection • Level linearized

Distance

Electronics temperature

Sensor temperature

Absolute echo amplitude

■ Relative echo amplitude

Area of incoupling

Percent of range

Loop current

Primary variable (PV)

Secondary variable (SV)

Tertiary variable (TV)

Quaternary variable (QV)

■ Flow

■ Totalizer value *

Not used

Factory setting Level linearized

Burst variable 4 ... 7

Navigation Application \rightarrow HART output \rightarrow Burst config. 1 \rightarrow Burst variable 4

Description For HART command 33, assign a HART device variable or process variable to burst variable

Selection • Level linearized

Distance

Electronics temperature

Sensor temperature

Absolute echo amplitude

■ Relative echo amplitude

Area of incoupling

Percent of range

Loop current

■ Primary variable (PV)

^{*} Visibility depends on order options or device settings

- Secondary variable (SV)Tertiary variable (TV)
- Quaternary variable (QV)
 Flow *
- Totalizer value *
- Not used

Not used

Burst trigger mode		A
Navigation	B Application → HART output → Burst config. 1 → Trigger mode	
Description	Select the event that triggers the burst message	
Selection	 Continuous Window * Rising * Falling * On change 	
Factory setting	Continuous	
Burst trigger level		
Navigation	B Application \rightarrow HART output \rightarrow Burst config. 1 \rightarrow Trigger level	
Description	Enter the burst trigger value that determines together with the option selected in "Bu trigger mode" parameter the time of burst message	ırst
User entry	Signed floating-point number	
Factory setting	2.0E-38	
Min. update period		(a)
Navigation	B Application \rightarrow HART output \rightarrow Burst config. 1 \rightarrow Min. upd. per.	
Description	Enter the minimum time span between two burst responses of one burst message	
User entry	Positive integer	
Factory setting	1000 ms	

Visibility depends on order options or device settings

Max. update period	
Navigation	Burst config. 1 → Max. upd. per.
Description	Enter the maximum time span between two burst responses of one burst message
User entry	Positive integer
Factory setting	2 000 ms
	Information
	Navigation $\ \ $
Device ID	
Navigation	
Description	Shows the device ID for identifying the device in a HART network
User interface	Positive integer
Factory setting	123 456
Device type	
Navigation	
Description	Displays the device type with which the device is registered with the HART FieldComm Group.
User interface	0 to 65 535
Factory setting	4574
Device revision	
Navigation	
Description	Displays the device revision with which the device is registered with the HART FieldCom Group. $\label{eq:condition}$

User interface 0 to 255

Factory setting 1

HART short tag

Navigation Application \rightarrow HART output \rightarrow Information \rightarrow HART short tag

Description Defines the short tag for the measuring point.

Maximum length: 8 characters.

Allowed characters: A-Z, 0-9, certain special characters.

User entry Character string comprising numbers, letters and special characters (8)

Factory setting SHORTTAG

Description Displays the revision of the HART protocol for the device.

User interface 5 to 7

Factory setting 7

HART revision

Navigation

HART descriptor

Application \rightarrow HART output \rightarrow Information \rightarrow HART revision

Navigation riangleq Application riangleq HART output riangleq Information riangleq HART descriptor

Description Use this function to define a description for the measuring point.

Maximum length: 16 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry Character string comprising numbers, letters and special characters (16)

Factory setting x0B

HART date code

HART message

Navigation

Application → HART output → Information → HART message

Use this function to define a HART message which is sent via the HART protocol when requested by the master.

Maximum length: 32 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Character string comprising numbers, letters and special characters (32)

Factory setting

x0B

 Navigation
 □ Application → HART output → Information → HART date code

 Description
 Enter data for individual use

 User entry
 Character string comprising numbers, letters and special characters (10)

 Factory setting
 2009-07-20

3.4 System

Navigation 🗐 🖺 System

3.4.1 Device management

Navigation $\blacksquare \square$ System \rightarrow Device manag.

 Device tag

 Navigation
 System → Device manag. → Device tag

 Description
 Enter a unique name for the measuring point to identify the device quickly within the plant.

 User entry
 Character string comprising numbers, letters and special characters (32)

 Factory setting
 x0B

Locking status

Navigation

Description

Indicates the type of locking.

"Safety locked" (SW)

Unlock the device by entering the appropriate access code in "Enter safety unlocking code".

"Temporarily locked" (SW)

The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.

User interface

- Safety locked
- Temporarily locked

Configuration counter

Navigation

Description

Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65 535, it restarts at 0.

User interface

0 to 65 535

Factory setting

0

Reset device

Navigation

Description

Reset the device configuration - either entirely or in part - to a defined state

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

^{*} Visibility depends on order options or device settings

Factory setting Cancel

3.4.2 User management

Navigation \square System \rightarrow User manag.

3.4.3 User management

Navigation System \rightarrow User manag.

Navigation \square System \rightarrow User manag. \rightarrow User manag.

User role

Navigation \square System \rightarrow User manag. \rightarrow User manag. \rightarrow User role

Description Shows the access authorization to the parameters via the operating tool

User interface • Operator

Maintenance

■ Expert

Factory setting Maintenance

Delete password

Navigation \square System \rightarrow User manag. \rightarrow Delete password

Description Deletes the 'Maintenance' password.

After deleting, the 'Operator' role will be no more available.

All users have read/write access rights.

User entry Character string comprising numbers, letters and special characters (1)

Forgot password?	
Navigation	 System → User manag. → Forgot password? System → User manag. → Forgot password?
User entry	Character string comprising numbers, letters and special characters (1)
	Enter password
	Navigation \square System \rightarrow User manag. \rightarrow Enter password
Password	
Navigation	
Description	Enter the password for the "Maintenance" user role to get access to the functionality of this role.
User entry	Character string comprising numbers, letters and special characters (16)
Enter access code	
Navigation	
Description	For authorized service personnel only.
User entry	0 to 9 999
Factory setting	0
Status password entry	
Navigation	
Description	Use this function to display the status of the password verification.
User interface	 Wrong password Password rule violated Password accepted Permission denied Confirm PW mismatch

- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting

Define password

Navigation \square System \rightarrow User manag. \rightarrow Define password

New password			
Navigation			
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers.		
User entry	Character string comprising numbers, letters and special characters (16)		
Confirm new password		Â	
Navigation			
Description	Enter the new password again to confirm.		
User entry	Character string comprising numbers, letters and special characters (16)		
Status password entry			
Navigation			
Description	Use this function to display the status of the password verification.		
User interface	 Wrong password Password rule violated Password accepted Permission denied 		

Endress+Hauser 109

Confirm PW mismatch

Factory setting	 Reset password accepted Invalid user role Wrong sequence of entry 		
	Change password		
	Navigation		
Old password			
Navigation			
Description	Enter the current password, to subsequently change the existing password.		
User entry	Character string comprising numbers, letters and special characters (16)		
New password			
Navigation			
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers		
User entry	Character string comprising numbers, letters and special characters (16)		
Confirm new password		A	
Navigation			
Description	Enter the new password again to confirm.		
User entry	Character string comprising numbers, letters and special characters (16)		

Status password entry

Navigation System \rightarrow User manag. \rightarrow Change password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface -----

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting

Recover password

Navigation \square System \rightarrow User manag. \rightarrow Recover password

Reset password

Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Reset password

Description Enter a code to reset the current "Maintenance" password.

The code is delivered by your local support.

User entry Character string comprising numbers, letters and special characters (16)

Status password entry

Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Fa	ctor	v set	tina

3.4.4 Bluetooth configuration

Navigation $\blacksquare \square$ System \rightarrow Bluetooth conf.

Bluetooth activation

Navigation System \rightarrow Bluetooth conf. \rightarrow Bluetooth active

Description If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool.

Reactivating via the SmartBlue app is not possible.

Selection • Disable

■ Enable

Factory setting Enable

3.4.5 Display

Language

Navigation \square System \rightarrow Display \rightarrow Language

Description Set display language

Selection ■ English

- Deutsch *
- Français j
- Español ĵ
- Italiano ³
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian) *
- Svenska
- Türkçe
- 中文 (Chinese) *

^{*} Visibility depends on order options or device settings

■ 日本語 (Japanese)^{*}
■ 한국어 (Korean)^{*}
■ Bahasa Indonesia ^{*}
■ čeština (Czech)^{*}

Factory setting English

Format display

Navigation \square System \rightarrow Display \rightarrow Format display

Description Select how measured values are shown on the display

Selection ■ 1 value, max. size

Bargraph2 values

Factory setting 1 value, max. size

Value 1 display

Navigation \square System \rightarrow Display \rightarrow Value 1 display

Description Select the measured value that is shown on the local display

Selection • Level linearized

Distance

Absolute echo amplitudeRelative echo amplitude

Area of incoupling

Current output

■ Terminal voltage

■ Electronics temperature

Sensor temperature

■ Flow

■ Totalizer value

Unfiltered distance

Factory setting Level linearized

Decimal places 1 ... 4

Description

Navigation

This selection does not affect the measurement and calculation accuracy of the device.

^{*} Visibility depends on order options or device settings

Selection

■ X

■ X.X

x.xxx.xxx

X.XXXX

Factory setting

X.XX

Value 2 display

Navigation

Description

Select the measured value that is shown on the local display

Selection

- None
- Level linearized
- Distance
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Terminal voltage
- Electronics temperature
- Sensor temperature
- Flow
- Totalizer value
- Current output
- Unfiltered distance

Factory setting

Distance

Decimal places 2

Navigation

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

Х

Description

User entry

Rotation display		
Navigation		
Description	Select rotation angle of the display text to optimize local display readability.	
Selection	 Auto 0 degree 90 degree 180 degree 270 degree 	
Factory setting	0 degree	
Color scheme		
Navigation		
Description	Select the preferred color scheme.	
Selection	■ Light ■ Dark	
Factory setting	Dark	
	3.4.6 Geolocation	
	Navigation \square System \rightarrow Geolocation	
Process Unit Tag		
Navigation	System → Geolocation → Process Unit Tag	

Factory setting Process Unit Tag

Enter the process unit in which the device is installed.

Character string comprising numbers, letters and special characters (32)

Location Description			
Navigation			
Description	Use this function to enter a description of the location so that the device can be located in the plant.		
User entry	Character string comprising numbers, letters and special characters (32)		
Factory setting	somewhere		
Longitude		A	
Navigation			
Description	Use this function to enter the longitude coordinates that describe the device location.		
User entry	-180 to 180 °		
Factory setting	0°		
Latitude		A	
Navigation			
Description	Use this function to enter the latitude coordinates that describe the device location.		
User entry	–90 to 90 °		
Factory setting	0°		
Altitude		A	
Navigation			
Description	Use this function to enter the altitude data that describe the device location.		
User entry	Signed floating-point number		
Factory setting	0 m		

Factory setting

Location method Navigation System \rightarrow Geolocation \rightarrow Location method Description Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183. Selection No fix • GPS or Standard Positioning Service fix ■ Differential GPS fix • Precise positioning service (PPS) fix ■ Real Time Kinetic (RTK) fixed solution ■ Real Time Kinetic (RTK) float solution Estimated dead reckoning Manual input mode Simulation Mode **Factory setting** No fix

3.4.7 Information

Endress+Hauser

Navigation \square System \rightarrow Information

Device name		
Navigation		
Description	Use this function to display the device name. It can also be found on the nameplate.	
User interface	Character string comprising numbers, letters and special characters	
Factory setting	x0B	
Manufacturer		
Navigation		
Description	Displays the manufacturer.	
User interface	Character string comprising numbers, letters and special characters	

Serial number		
Navigation		
Description	The serial number is a unique alphanumerical code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.	
User interface	Character string comprising numbers, letters and special characters	
Factory setting	AAFFFAAFFF	
Order code		
Navigation		
Description	Shows the device order code.	
User interface	Character string comprising numbers, letters and special characters	
Factory setting	- none -	
Additional information	Access: Read access: Operator Write access: Expert	
Firmware version		
Navigation		
Description	Displays the device firmware version installed.	
User interface	Character string comprising numbers, letters and special characters	
Factory setting	01.00	
Hardware version		
Navigation		
User interface	Character string comprising numbers, letters and special characters	
Factory setting	01.00.00	

Extended order code 1 ... 3

Navigation System \rightarrow Information \rightarrow Ext. order cd. 1

Description The extended order code is an alphanumeric code containing all information to identify

the device and its options.

User interface Character string comprising numbers, letters and special characters

Read access: OperatorWrite access: Expert

XML build number

Navigation System \rightarrow Information \rightarrow XML build no.

User interface Positive integer

Factory setting 275

Additional information Access:

■ Read access: Expert

■ Write access: -

Checksum

Navigation $riangleq ext{System} o ext{Information} o ext{Checksum}$

Description Checksum for Firmware version.

User interface Positive integer

Factory setting 0

3.4.8 Additional information

Navigation \blacksquare System \rightarrow Additional info

Sensor

Navigation $\blacksquare \square$ System \rightarrow Additional info \rightarrow Sensor

Serial number

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Factory setting AAFFFAAFFF

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Factory setting 0

Read access: ExpertWrite access: -

Build no. software

Navigation $riangleq ext{System} o ext{Additional info} o ext{Sensor} o ext{Build no. softw}.$

Description Shows the build number of the module firmware

User interface 0 to 65 535

Factory setting 0

Additional information

Access:

■ Read access: Expert ■ Write access: -

Hardware version

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Factory setting - none -

Additional information

Access:

■ Read access: Expert ■ Write access: -

Checksum

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Checksum

Checksum for Firmware version. Description

User interface Positive integer

Factory setting

Additional information Access:

> ■ Read access: Expert ■ Write access: -

Electronics

Navigation

Serial number

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Factory setting AAFFFFAAFFF Additional information Access: ■ Read access: Expert ■ Write access: -Firmware version Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Firmware version Description Displays the firmware version of the module. User interface Positive integer **Factory setting** 0 Additional information Access: ■ Read access: Expert ■ Write access: -Build no. software **Navigation** System \rightarrow Additional info \rightarrow Electronics \rightarrow Build no. softw. Description Shows the build number of the module firmware User interface 0 to 65 535 **Factory setting** 0 Additional information Access: ■ Read access: Expert ■ Write access: -Hardware version Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Hardware version Description Displays the hardware version of the module.

Character string comprising numbers, letters and special characters

122

User interface

Factory setting

- none -

Additional information

Access:

■ Read access: Expert

■ Write access: -

Display/Bluetooth

Navigation \blacksquare System \rightarrow Additional info \rightarrow Displ./Bluetooth

Serial number

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Factory setting AAFFFAAFFF

Additional information Access:

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Factory setting 0

Additional information Access:

Read access: ExpertWrite access: -

Build no. software

Navigation \square System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Build no. softw.

Description Shows the build number of the module firmware

User interface 0 to 65 535

Factory setting 0

Read access: ExpertWrite access: -

Hardware version

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Factory setting - none -

Read access: ExpertWrite access: -

3.4.9 Software configuration

Navigation $\blacksquare \square$ System \rightarrow Softw. config.

CRC device configuration

Navigation System \rightarrow Softw. config. \rightarrow CRC device conf.

Description CRC device configuration based on current settings of safety relevant parameters.

The CRC device configuration is unique and can be used to detect changes in safety

relevant parameter settings.

User interface 0 to 65 535

Factory setting 65 535

Stored CRC device configuration

Navigation System \rightarrow Softw. config. \rightarrow Stored CRC conf.

Description Stored CRC after the last safety lock. Factory delivery is 65 535 means that the device has

not yet been safety locked.

User interface 0 to 65 535

Factory setting 65 535

Timestamp stored CRC device config.

Navigation \square System \rightarrow Softw. config. \rightarrow Time stored CRC

Description Gives the timestamp when the CRC was last stored following completion of the safety lock

wizard.

User interface Character string comprising numbers, letters and special characters

Activate SW option

Navigation $riangleq ext{System} o ext{Softw. config.} o ext{Activate SW opt.}$

Description Enter the application package code or code of another re-ordered functionality to enable it

User entry Positive integer

Factory setting 0

Software option overview

Navigation System \rightarrow Softw. config. \rightarrow SW option overv.

Description Shows all enabled software options

User interface ■ WHG

■ Heartbeat Verification

■ Bluetooth



www.addresses.endress.com