


Operating Instructions

Proline Promass E 500

Coriolis flowmeter
FOUNDATION Fieldbus



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser sales organization will supply you with current information and updates to this manual.

Table of contents

| | | | | | |
|----------|---|-----------|----------|---|-----------|
| 1 | About this document | 6 | 6 | Installation | 22 |
| 1.1 | Document function | 6 | 6.1 | Installation requirements | 22 |
| 1.2 | Symbols | 6 | 6.1.1 | Installation position | 22 |
| 1.2.1 | Safety symbols | 6 | 6.1.2 | Environmental and process requirements | 25 |
| 1.2.2 | Electrical symbols | 6 | 6.1.3 | Special installation instructions | 26 |
| 1.2.3 | Communication-specific symbols | 6 | 6.2 | Installing the device | 29 |
| 1.2.4 | Tool symbols | 7 | 6.2.1 | Required tools | 29 |
| 1.2.5 | Symbols for certain types of information | 7 | 6.2.2 | Preparing the measuring instrument | 29 |
| 1.2.6 | Symbols in graphics | 7 | 6.2.3 | Installing the measuring instrument | 29 |
| 1.3 | Documentation | 8 | 6.2.4 | Installing the transmitter housing: Proline 500 – digital | 30 |
| 1.4 | Registered trademarks | 8 | 6.2.5 | Installing the transmitter housing: Proline 500 | 32 |
| 2 | Safety instructions | 9 | 6.2.6 | Turning the transmitter housing: Proline 500 | 33 |
| 2.1 | Requirements for the personnel | 9 | 6.2.7 | Turning the display module: Proline 500 | 33 |
| 2.2 | Intended use | 9 | 6.3 | Post-installation check | 34 |
| 2.3 | Workplace safety | 10 | 7 | Electrical connection | 35 |
| 2.4 | Operational safety | 10 | 7.1 | Electrical safety | 35 |
| 2.5 | Product safety | 10 | 7.2 | Connecting requirements | 35 |
| 2.6 | IT security | 11 | 7.2.1 | Required tools | 35 |
| 2.7 | Device-specific IT security | 11 | 7.2.2 | Requirements for connection cable | 35 |
| 2.7.1 | Protecting access via hardware write protection | 11 | 7.2.3 | Terminal assignment | 39 |
| 2.7.2 | Protecting access via a password | 11 | 7.2.4 | Available device plugs for Proline 500 | 39 |
| 2.7.3 | Access via web server | 12 | 7.2.5 | Pin assignment of device plug | 40 |
| 2.7.4 | Access via service interface (port 2): CDI-RJ45 | 13 | 7.2.6 | Shielding and grounding | 40 |
| 3 | Product description | 14 | 7.2.7 | Preparing the device | 41 |
| 3.1 | Product design | 14 | 7.3 | Connecting the device: Proline 500 – digital | 42 |
| 3.1.1 | Proline 500 – digital | 14 | 7.3.1 | Connecting the connecting cable | 42 |
| 3.1.2 | Proline 500 | 15 | 7.3.2 | Connecting the signal cable and the supply voltage cable | 47 |
| 4 | Incoming acceptance and product identification | 16 | 7.4 | Connecting the device: Proline 500 | 49 |
| 4.1 | Incoming acceptance | 16 | 7.4.1 | Connecting the connecting cable | 49 |
| 4.2 | Product identification | 16 | 7.4.2 | Connecting the signal cable and the supply voltage cable | 53 |
| 4.2.1 | Transmitter nameplate | 17 | 7.5 | Potential equalization | 55 |
| 4.2.2 | Sensor nameplate | 19 | 7.5.1 | Requirements | 55 |
| 4.2.3 | Symbols on the device | 20 | 7.6 | Special connection instructions | 55 |
| 5 | Storage and transport | 21 | 7.6.1 | Connection examples | 55 |
| 5.1 | Storage conditions | 21 | 7.7 | Ensuring the degree of protection | 58 |
| 5.2 | Transporting the product | 21 | 7.8 | Post-connection check | 59 |
| 5.2.1 | Measuring devices without lifting lugs | 21 | 8 | Operation options | 60 |
| 5.2.2 | Measuring devices with lifting lugs | 22 | 8.1 | Overview of operation options | 60 |
| 5.2.3 | Transporting with a fork lift | 22 | 8.2 | Structure and function of the operating menu | 61 |
| 5.3 | Packaging disposal | 22 | 8.2.1 | Structure of the operating menu | 61 |
| | | | 8.2.2 | Operating philosophy | 62 |
| | | | 8.3 | Access to operating menu via local display | 63 |
| | | | 8.3.1 | Operational display | 63 |

| | | | | | |
|-----------|--|-----------|-----------|--|------------|
| 8.3.2 | Navigation view | 66 | 10.5.11 | Configuring the local display | 113 |
| 8.3.3 | Editing view | 68 | 10.5.12 | Configuring the low flow cut off | 116 |
| 8.3.4 | Operating elements | 70 | 10.5.13 | Partially filled pipe detection | 117 |
| 8.3.5 | Opening the context menu | 70 | 10.6 | Advanced settings | 118 |
| 8.3.6 | Navigating and selecting from list . . . | 72 | 10.6.1 | Using the parameter to enter the access code | 119 |
| 8.3.7 | Calling the parameter directly | 72 | 10.6.2 | Calculated process variables | 119 |
| 8.3.8 | Calling up help text | 73 | 10.6.3 | Carrying out a sensor adjustment . . . | 120 |
| 8.3.9 | Changing the parameters | 73 | 10.6.4 | Configuring the totalizer | 124 |
| 8.3.10 | User roles and related access authorization | 74 | 10.6.5 | Carrying out additional display configurations | 126 |
| 8.3.11 | Disabling write protection via access code | 74 | 10.6.6 | WLAN configuration | 129 |
| 8.3.12 | Enabling and disabling the keypad lock | 75 | 10.6.7 | Configuration management | 130 |
| 8.4 | Access to operating menu via web browser . . | 75 | 10.6.8 | Using parameters for device administration | 131 |
| 8.4.1 | Function range | 75 | 10.7 | Simulation | 133 |
| 8.4.2 | Requirements | 76 | 10.8 | Protecting settings from unauthorized access | 136 |
| 8.4.3 | Logging on | 77 | 10.8.1 | Write protection via access code . . . | 136 |
| 8.4.4 | User interface | 77 | 10.8.2 | Write protection via write protection switch | 138 |
| 8.4.5 | Disabling the Web server | 78 | 10.8.3 | Write protection via block operation | 140 |
| 8.4.6 | Logging out | 79 | | | |
| 8.5 | Operation via SmartBlue app | 79 | 11 | Operation | 141 |
| 8.6 | Access to the operating menu via the operating tool | 80 | 11.1 | Reading the device locking status | 141 |
| 8.6.1 | Connecting the operating tool | 80 | 11.2 | Adjusting the operating language | 141 |
| 8.6.2 | Field Xpert SFX350, SFX370 | 84 | 11.3 | Configuring the display | 141 |
| 8.6.3 | FieldCare | 84 | 11.4 | Reading off measured values | 141 |
| 8.6.4 | DeviceCare | 85 | 11.4.1 | "Measured variables" submenu | 142 |
| 8.6.5 | AMS Device Manager | 85 | 11.4.2 | "Totalizer" submenu | 152 |
| 8.6.6 | Field Communicator 475 | 85 | 11.4.3 | "Input values" submenu | 152 |
| | | | 11.4.4 | Output values | 154 |
| 9 | System integration | 86 | 11.5 | Adapting the measuring device to the process conditions | 156 |
| 9.1 | Overview of device description files | 86 | 11.6 | Performing a totalizer reset | 156 |
| 9.1.1 | Current version data for the device . . . | 86 | 11.6.1 | Function scope of "Control Totalizer" parameter | 156 |
| 9.1.2 | Operating tools | 86 | 11.6.2 | Function range of "Reset all totalizers" parameter | 157 |
| 9.2 | Cyclic data transmission | 86 | 11.7 | Displaying the measured value history | 157 |
| 9.2.1 | Block model | 86 | | | |
| 9.2.2 | Description of the modules | 87 | 12 | Diagnostics and troubleshooting . . | 160 |
| 9.2.3 | Execution times | 90 | 12.1 | General troubleshooting | 160 |
| 9.2.4 | Methods | 91 | 12.2 | Diagnostic information via LEDs | 162 |
| | | | 12.2.1 | Transmitter | 162 |
| 10 | Commissioning | 92 | 12.2.2 | Sensor connection housing | 163 |
| 10.1 | Post-installation and post-connection check . . | 92 | 12.3 | Diagnostic information on local display | 165 |
| 10.2 | Switching on the measuring instrument | 92 | 12.3.1 | Diagnostic message | 165 |
| 10.3 | Connecting via FieldCare | 92 | 12.3.2 | Calling up remedial actions | 167 |
| 10.4 | Setting the operating language | 92 | 12.4 | Diagnostic information in the web browser . . | 167 |
| 10.5 | Configuring the device | 93 | 12.4.1 | Diagnostic options | 167 |
| 10.5.1 | Defining the device tag | 94 | 12.4.2 | Calling up remedial actions | 168 |
| 10.5.2 | Setting the system units | 94 | 12.5 | Diagnostic information in FieldCare or DeviceCare | 168 |
| 10.5.3 | Selecting and setting the medium . . . | 97 | 12.5.1 | Diagnostic options | 168 |
| 10.5.4 | Configuring the analog inputs | 99 | 12.5.2 | Calling up remedy information | 169 |
| 10.5.5 | Displaying the I/O configuration | 99 | 12.6 | Adapting the diagnostic information | 170 |
| 10.5.6 | Configuring the current input | 100 | 12.6.1 | Adapting the diagnostic behavior . . . | 170 |
| 10.5.7 | Configuring the status input | 101 | 12.6.2 | Adapting the status signal | 170 |
| 10.5.8 | Configuring the current output | 102 | | | |
| 10.5.9 | Configuring the pulse/frequency/ switch output | 105 | | | |
| 10.5.10 | Configuring the relay output | 111 | | | |

| | | | | | |
|-----------|--|------------|--------------|----------------------------|------------|
| 12.7 | Overview of diagnostic information | 174 | 16.8 | Environment | 225 |
| 12.7.1 | Diagnostic of sensor | 175 | 16.9 | Process | 227 |
| 12.7.2 | Diagnostic of electronic | 177 | 16.10 | Mechanical construction | 229 |
| 12.7.3 | Diagnostic of configuration | 183 | 16.11 | User interface | 233 |
| 12.7.4 | Diagnostic of process | 190 | 16.12 | Certificates and approvals | 236 |
| 12.8 | Pending diagnostic events | 195 | 16.13 | Application packages | 239 |
| 12.9 | Diagnostic messages in the DIAGNOSTIC Transducer Block | 196 | 16.14 | Accessories | 241 |
| 12.10 | Diagnostic list | 196 | 16.15 | Documentation | 241 |
| 12.11 | Event logbook | 197 | | | |
| 12.11.1 | Reading out the event logbook | 197 | Index | | 243 |
| 12.11.2 | Filtering the event logbook | 198 | | | |
| 12.11.3 | Overview of information events | 198 | | | |
| 12.12 | Device reset | 199 | | | |
| 12.12.1 | Function scope of "Restart" parameter | 199 | | | |
| 12.12.2 | Function scope of "Service reset" parameter | 200 | | | |
| 12.13 | Device information | 200 | | | |
| 12.14 | Firmware history | 202 | | | |
| 13 | Maintenance | 203 | | | |
| 13.1 | Maintenance work | 203 | | | |
| 13.1.1 | Cleaning | 203 | | | |
| 13.2 | Measuring and test equipment | 203 | | | |
| 13.3 | Maintenance services | 203 | | | |
| 14 | Repair | 204 | | | |
| 14.1 | General notes | 204 | | | |
| 14.1.1 | Repair and conversion concept | 204 | | | |
| 14.1.2 | Notes for repair and conversion | 204 | | | |
| 14.2 | Spare parts | 204 | | | |
| 14.3 | Repair services | 204 | | | |
| 14.4 | Return | 204 | | | |
| 14.5 | Disposal | 205 | | | |
| 14.5.1 | Removing the measuring instrument | 205 | | | |
| 14.5.2 | Disposing of the measuring instrument | 205 | | | |
| 15 | Accessories | 206 | | | |
| 15.1 | Device-specific accessories | 206 | | | |
| 15.1.1 | For the transmitter | 206 | | | |
| 15.1.2 | For the sensor | 207 | | | |
| 15.2 | Communication-specific accessories | 207 | | | |
| 15.3 | Service-specific accessories | 208 | | | |
| 15.4 | System components | 209 | | | |
| 16 | Technical data | 210 | | | |
| 16.1 | Application | 210 | | | |
| 16.2 | Function and system design | 210 | | | |
| 16.3 | Input | 211 | | | |
| 16.4 | Output | 214 | | | |
| 16.5 | Power supply | 220 | | | |
| 16.6 | Performance characteristics | 221 | | | |
| 16.7 | Installation | 225 | | | |

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.






CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.



NOTICE



This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.2.2 Electrical symbols




| Symbol | Meaning |
|---|---|
|  | Direct current |
|  | Alternating current |
|  | Direct current and alternating current |
|  | Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system. |
|  | Protective earth (PE) Ground terminals that must be connected to ground prior to establishing any other connections. The ground terminals are located on the interior and exterior of the device: <ul style="list-style-type: none"> ▪ Interior ground terminal: protective earth is connected to the mains supply. ▪ Exterior ground terminal: device is connected to the plant grounding system. |

1.2.3 Communication-specific symbols













| Symbol | Meaning |
|---|---|
|  | Wireless Local Area Network (WLAN) Communication via a wireless, local area network |
|  | LED LED is off. |

| Symbol | Meaning |
|---|-----------------------------|
|  | LED LED is on. |
|  | LED LED flashing. |

1.2.4 Tool symbols

| Symbol | Meaning |
|---|----------------------|
|  | Torx screwdriver |
|  | Phillips screwdriver |
|  | Open-end wrench |

1.2.5 Symbols for certain types of information

| Symbol | Meaning |
|---|--|
|  | Permitted Procedures, processes or actions that are permitted. |
|  | Preferred Procedures, processes or actions that are preferred. |
|  | Forbidden Procedures, processes or actions that are forbidden. |
|  | Tip Indicates additional information. |
|  | Reference to documentation |
|  | Reference to page |
|  | Reference to graphic |
|  | Notice or individual step to be observed |
|  | Series of steps |
|  | Result of a step |
|  | Help in the event of a problem |
|  | Visual inspection |

1.2.6 Symbols in graphics

| Symbol | Meaning |
|---|-----------------|
| 1, 2, 3, ... | Item numbers |
|  | Series of steps |
| A, B, C, ... | Views |
| A-A, B-B, C-C, ... | Sections |
|  | Hazardous area |


| Symbol | Meaning |
|---|--------------------------------|
|  | Safe area (non-hazardous area) |
|  | Flow direction |

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the device version:

| Document type | Purpose and content of the document |
|--|--|
| Technical Information (TI) | Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device. |
| Brief Operating Instructions (KA) | Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning. |
| Operating Instructions (BA) | Your reference document The Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal. |
| Description of Device Parameters (GP) | Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations. |
| Safety instructions (XA) | Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. These are an integral part of the Operating Instructions.  The nameplate indicates which Safety Instructions (XA) apply to the device. |
| Supplementary device-dependent documentation (SD/FY) | Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is a constituent part of the device documentation. |

1.4 Registered trademarks

FOUNDATION™ fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring instrument described in this manual is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring instrument can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring instruments for use in hazardous areas, in hygienic applications, or where there is an increased risk due to pressure, are specially labeled on the nameplate.

To ensure that the measuring instrument remains in proper condition during the operating time:

- ▶ Only use the measuring instrument in full compliance with the data on the nameplate and the general conditions listed in the manual and supplementary documentation.
- ▶ Using the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring instrument only for media against which the materials in contact with the process are sufficiently resistant.
- ▶ Keep within the specified pressure and temperature range.
- ▶ Keep within the specified ambient temperature range.
- ▶ Protect the measuring instrument permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all wetted materials during the process.
- ▶ Keep within the specified pressure and temperature range.

NOTICE**Verification for borderline cases:**

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks**⚠ WARNING**

Risk of hot or cold burns! The use of media and electronics with high or low temperatures can produce hot or cold surfaces on the device.

- ▶ Mount suitable touch protection.

⚠ WARNING

Danger of housing breaking due to measuring tube breakage!

If a measuring tube ruptures, the pressure inside the sensor housing will rise according to the operating process pressure.

- ▶ Use a rupture disk.

⚠ WARNING

Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

- ▶ Take precautions to prevent injury and material damage if the rupture disk is actuated.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Damage to the device!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

- ▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

2.5 Product safety

This state-of-the-art device is designed and tested in accordance with good engineering practice to meet operational safety standards. It left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU declaration of conformity. The manufacturer confirms this by affixing the CE mark.






2.6 IT security

The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.


2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. The following list provides an overview of the most important functions:

| Function/interface | Factory setting | Recommendation |
|--|-----------------------|---|
| Write protection via hardware write protection switch →  11 | Not enabled | On an individual basis following risk assessment |
| Access code (also applies to web server login or FieldCare connection) →  12 | Not enabled (0000) | Assign a customized access code during commissioning |
| WLAN (order option in display module) | Enabled | On an individual basis following risk assessment |
| WLAN security mode | Enabled (WPA2-PSK) | Do not change |
| WLAN passphrase (Password) →  12 | Serial number | Assign an individual WLAN passphrase during commissioning |
| WLAN mode | Access point | On an individual basis following risk assessment |
| Web server →  12 | Enabled | On an individual basis following risk assessment |
| Service interface CDI-RJ45 →  13 | Enabled | - |

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered →  138.


2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.


- **User-specific access code**
Protect write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- **WLAN passphrase**
The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- **Infrastructure mode**
When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.


User-specific access code

Local display, web browser and operating tool (e.g. FieldCare, DeviceCare)

- Write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code →  136.
- When delivered, the device does not have an access code; the default value is 0000 (open).

WLAN passphrase: Operation as WLAN access point


A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface (→  82), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter (→  129).


Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning for security reasons.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see "Write protection via access code" →  136.

2.7.3 Access via web server

The integrated web server can be used to operate and configure the device via a web browser →  75. The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The web server is enabled when the device is delivered. The web server can be disabled if necessary via the **Web server functionality** parameter (e.g., after commissioning).

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.



For detailed information on device parameters, see: Description of Device Parameters.

2.7.4 Access via service interface (port 2): CDI-RJ45

The device can be connected to a network via the service interface. Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.



For detailed information on connecting transmitters with an Ex de approval, see separate document "Safety instructions" (XA) for the device.

3 Product description

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

3.1 Product design

Two versions of the transmitter are available.

3.1.1 Proline 500 – digital


Signal transmission: digital

Order code for "Integrated ISEM electronics", option **A** "Sensor"

For use in applications not required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the sensor, the device is ideal:
For simple transmitter replacement.

- A standard cable can be used as the connecting cable.
- Not sensitive to external EMC interference.



A0029593

1 Important components of a measuring device

- 1 Electronics compartment cover
- 2 Display module
- 3 Transmitter housing
- 4 Sensor connection housing with integrated ISEM electronics: connecting cable connection
- 5 Sensor

3.1.2 Proline 500


Signal transmission: analog

Order code for "Integrated ISEM electronics", option **B** "Transmitter"

For use in applications required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the transmitter, the device is ideal in the event of:

- Strong vibrations at the sensor.
- Sensor operation in underground installations.
- Permanent sensor immersion in water.



A0029589

2 Important components of a measuring device

- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing with integrated ISEM electronics
- 4 Electronics compartment cover
- 5 Sensor
- 6 Sensor connection housing: connecting cable connection
- 7 Connection compartment cover: connecting cable connection

4 Incoming acceptance and product identification

4.1 Incoming acceptance

On receipt of the delivery:

1. Check the packaging for damage.
 - ↳ Report all damage immediately to the manufacturer.
Do not install damaged components.
2. Check the scope of delivery using the delivery note.
3. Compare the data on the nameplate with the order specifications on the delivery note.
4. Check the technical documentation and all other necessary documents, e.g. certificates, to ensure they are complete.



If one of the conditions is not satisfied, contact the manufacturer.

4.2 Product identification

The device can be identified in the following ways:


- Nameplate
- Order code with details of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations app* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations app*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard device documentation" and "Supplementary device-dependent documentation" sections
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations app*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Transmitter nameplate


Proline 500 – digital



A0058873

3 Example of a transmitter nameplate

- 1 Name of the transmitter
- 2 Manufacturer/certificate holder
- 3 Space for approvals: Use in hazardous areas
- 4 Degree of protection
- 5 Electrical connection data: available inputs and outputs
- 6 Permitted ambient temperature (T_a)
- 7 2-D matrix code
- 8 Space for approvals and certificates: e.g. CE mark, RCM symbol
- 9 Permitted temperature range for cable
- 10 Manufacturing date: year-month
- 11 Firmware version (FW) and device revision (Dev. Rev.) from the factory
- 12 Document number of safety-related supplementary documentation
- 13 Space for additional information in the case of special products
- 14 Available inputs and outputs, supply voltage
- 15 Electrical connection data: supply voltage
- 16 Extended order code (Ext. ord. cd.)
- 17 Serial number (Ser. no.)
- 18 Order code


Proline 500

A0058872

 4 Example of a transmitter nameplate

- 1 Manufacturer/certificate holder
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Manufacturing date: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, RCM symbol
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev. Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature (T_a)
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage


4.2.2 Sensor nameplate



A0029206

5 Example of a sensor nameplate, part 1

- 1 Name of sensor
- 2 Manufacturer/certificate holder
- 3 Nominal diameter of the sensor; flange nominal diameter/nominal pressure; sensor test pressure; medium temperature range; material of measuring tube and manifold
- 4 Sensor-specific information
- 5 CE mark, RCM symbol
- 6 Order code
- 7 Serial number (Ser. no.)
- 8 Extended order code (Ext. ord. cd.)



A0029207

6 Example of a sensor nameplate, part 2

- 1 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 2 Permitted ambient temperature (T_a)
- 3 Document number of safety-related supplementary documentation
- 4 2-D matrix code
- 5 Flow direction
- 6 Manufacturing date: year-month






Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on the device

| Symbol | Meaning |
|---|---|
|  | WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. Please consult the documentation for the measuring instrument to discover the type of potential danger and measures to avoid it. |
|  | Reference to documentation Refers to the corresponding device documentation. |
|  | Protective ground connection A terminal that must be connected to the ground prior to establishing any other connections. |

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight. Avoid unacceptably high surface temperatures.
- ▶ Store in a dry and dust-free place.
- ▶ Do not store outdoors.


Storage temperature →  225

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0029252

 Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0029214

5.2.2 Measuring devices with lifting lugs

⚠ CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Outer packaging of device
 - Stretch wrap made of polymer in accordance with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wood crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62/EC, recyclability confirmed by Resy symbol
- Transport material and fastening fixtures
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material
 - Paper pads

6 Installation

6.1 Installation requirements

6.1.1 Installation position

Mounting location




A0028772

To avoid measurement errors caused by gas bubble formation in the measuring tube, avoid the following installation locations in the pipe:


- Highest point of a pipeline
- Directly upstream of a free pipe outlet in a down pipe

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A0028773









 7 Installation in a down pipe (e.g. for batching applications)







- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Filling container

| DN/NPS | | Ø orifice plate, pipe restriction | |
|--------|----------------|-----------------------------------|------|
| [mm] | [in] | [mm] | [in] |
| 8 | $\frac{3}{8}$ | 6 | 0.24 |
| 15 | $\frac{1}{2}$ | 10 | 0.40 |
| 25 | 1 | 14 | 0.55 |
| 40 | $1\frac{1}{2}$ | 22 | 0.87 |
| 50 | 2 | 28 | 1.10 |
| 80 | 3 | 50 | 1.97 |

Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).


| Orientation | | | Recommendation |
|-------------|--|--|--|
| A | Vertical orientation |  <small>A0015591</small> |   ¹⁾ |
| B | Horizontal orientation, transmitter at top |  <small>A0015589</small> |   ²⁾ Exception: →  8,  24 |

| Orientation | | | Recommendation |
|-------------|---|---|--|
| C | Horizontal orientation, transmitter at bottom |  <small>A0015590</small> |  ³⁾ Exception: →  8,  24 |
| D | Horizontal orientation, transmitter at side |  <small>A0015592</small> |  |


- 1) This orientation is recommended to ensure self-draining.
- 2) Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 3) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.


If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the medium properties.



-  8 *Orientation of sensor with curved measuring tube*
- 1 *Avoid this orientation for media with entrained solids: Risk of solids accumulating*
- 2 *Avoid this orientation for outgassing media: Risk of gas accumulating*

Inlet and outlet runs

No special precautions need to be taken for fittings that create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs →  25.





Installation dimensions

-  For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Environmental and process requirements

Ambient temperature range

| | |
|----------------------------------|---|
| Measuring instrument | <ul style="list-style-type: none"> ■ -40 to +60 °C (-40 to +140 °F) ■ Order code for "Test, certificate", option JP: -50 to +60 °C (-58 to +140 °F) |
| Readability of the local display | -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range. |

 Dependency of ambient temperature on medium temperature →  227

- ▶ If operating outdoors:
Avoid direct sunlight, particularly in warm climatic regions.

 You can order a weather protection cover from Endress+Hauser. →  206.

Static pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- ▶ Ensure the static pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



A0028777


Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.

NOTICE

Electronics overheating on account of thermal insulation!

- ▶ Recommended orientation: horizontal orientation, sensor connection housing pointing downwards.
- ▶ Do not insulate the sensor connection housing.
- ▶ Maximum permissible temperature at the lower end of the sensor connection housing: 80 °C (176 °F)
- ▶ Thermal insulation with exposed extension neck: We recommend that you do not insulate the extension neck in order to ensure optimum dissipation of heat.



A0034391

9 Thermal insulation with exposed extension neck

Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter.
- ▶ Depending on the medium temperature, take the device orientation requirements into account.

NOTICE

Danger of overheating when heating

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- ▶ Ensure that sufficient convection takes place at the transmitter neck.
- ▶ Ensure that a sufficiently large area of the transmitter neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
- ▶ Consider the behavior of the process diagnostics "830 Ambient temperature too high" and "832 Electronics temperature too high" if overheating cannot be avoided by a suitable system design.

Heating options

If a medium requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters ¹⁾
- Via pipes carrying hot water or steam
- Via heating jackets

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

6.1.3 Special installation instructions

Drainability

When installed vertically, the measuring tubes can be drained completely and protected against buildup.

1) The use of parallel electric band heaters is generally recommended (bidirectional electricity flow). Particular considerations must be made if a single-wire heating cable is to be used. Additional information is provided in the document EA01339D "Installation instructions for electrical trace heating systems".

Hygienic compatibility

i When installing in hygienic applications, please refer to the information in the "Certificates and approvals/hygienic compatibility" section → 237

Rupture disk

Process-related information: → 228.


⚠ WARNING

Danger from medium escaping!

Medium escaping under pressure can cause injury or material damage.

- ▶ Take precautions to prevent danger to persons and damage if the rupture disk is actuated.
- ▶ Observe the information on the rupture disk sticker.
- ▶ Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- ▶ Do not use a heating jacket.
- ▶ Do not remove or damage the rupture disk.
- ▶ After the rupture disk is actuated, do not operate the measuring instrument any more.

The position of the rupture disk is indicated on a sticker applied over it. If the rupture disk is triggered, the sticker is destroyed. The disk can therefore be visually monitored.



A0029956

1 Rupture disk label

Zero point verification and zero adjustment

All measuring instruments are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions → 221. Therefore, a zero adjustment in the field is generally not required.

Experience shows that zero adjustment is advisable only in special cases:

- To achieve maximum measurement accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity media).
- For gas applications with low pressure.

i To achieve the highest possible measurement accuracy at low flow rates, the installation must protect the sensor from mechanical stress during operation.

To get a representative zero point, ensure that


- any flow in the device is prevented during the adjustment
- the process conditions (e.g. pressure, temperature) are stable and representative

Verification and adjustment cannot be performed if the following process conditions are present:

- Gas pockets
Ensure that the system has been sufficiently flushed with the medium. Repeat flushing can help to eliminate gas pockets
- Thermal circulation
In the event of temperature differences (e.g. between the measuring tube inlet and outlet section), induced flow can occur even if the valves are closed due to thermal circulation in the device
- Leaks at the valves
If the valves are not leak-tight, flow is not sufficiently prevented when determining the zero point


If these conditions cannot be avoided, it is advisable to keep the factory setting for the zero point.

Protective cover



A0029552

10 Weather protection cover for Proline 500 – digital; unit mm (in)



A0029553

11 Weather protection cover for Proline 500 – unit mm (in)


Cover locking: Proline 500

NOTICE

Order code "Transmitter housing", option L "Cast, stainless": The covers of the transmitter housing are provided with a borehole to lock the cover.

The cover can be locked using screws and a chain or cable provided by the customer on site.

- ▶ The use of stainless steel chains or cables is recommended.
- ▶ If a protective coating is applied, it is recommended to use a heat shrink tube to protect the housing paint.



A0029799

- 1 Cover borehole for the securing screw
2 Securing screw to lock the cover

6.2 Installing the device

6.2.1 Required tools

For transmitter

For mounting on a post:

- Proline 500 – digital transmitter
 - Open-ended wrench AF 10
 - Torx screwdriver TX 25
- Proline 500 transmitter
 - Open-ended wrench AF 13

For wall mounting:

Drill with drill bit \varnothing 6.0 mm

For sensor

For flanges and other process connections: Use a suitable mounting tool.

6.2.2 Preparing the measuring instrument

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. If present, remove transport protection of the rupture disk.
4. Remove stick-on label on the electronics compartment cover.


6.2.3 Installing the measuring instrument

⚠ WARNING

Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the seals and sealing surfaces are clean and undamaged.
- ▶ Secure the seals correctly.

1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the medium.
2. Install the measuring instrument or turn the transmitter housing so that the cable entries do not point upwards.



A0029263

6.2.4 Installing the transmitter housing: Proline 500 – digital

NOTICE

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature.
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

NOTICE

Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

Pipe mounting

Required tools:


- Open-ended wrench AF 10
- Torx screwdriver TX 25

NOTICE

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- ▶ Tighten the fixing screws as per the tightening torque: 2.5 Nm (1.8 lbf ft)




A0029051

12 Unit mm (in)

Wall mounting

Required tools:

Drill with drill bit $\varnothing 6.0$ mm



A0029054

13 Unit mm (in)

L Depends on order code for "Transmitter housing"

Order code for "Transmitter housing"

- Option A, aluminum, coated: L = 14 mm (0.55 in)
- Option D, polycarbonate: L = 13 mm (0.51 in)

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw in the securing screws loosely.
4. Fit the transmitter housing over the securing screws and mount in place.

5. Tighten the securing screws.

6.2.5 Installing the transmitter housing: Proline 500

NOTICE

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature.
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

NOTICE

Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.


The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

Wall mounting

Required tools

Drill with drill bit \varnothing 6.0 mm




14 Unit mm (in)

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Lightly screw in the securing screws.
4. Fit the transmitter housing over the securing screws and hook into place.
5. Tighten the securing screws.

Pipe mounting

Required tools

Open-ended wrench AF 13




A0029057

15 Unit mm (in)

6.2.6 Turning the transmitter housing: Proline 500

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




A0043150

16 Ex housing

1. Loosen the fixing screws.
2. Turn the housing to the desired position.
3. Tighten the securing screws.

6.2.7 Turning the display module: Proline 500

The display module can be turned to optimize display readability and operability.



1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Turn the display module to the desired position: max. $8 \times 45^\circ$ in each direction.
4. Screw on the connection compartment cover.
5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.3 Post-installation check

| | |
|--|--------------------------|
| Is the device undamaged (visual inspection)? | <input type="checkbox"/> |
| Does the measuring instrument correspond to the measuring point specifications? For example: <ul style="list-style-type: none"> ■ Process temperature → 227 ■ Pressure (refer to the "Pressure-temperature ratings" section of the "Technical Information" document). ■ Ambient temperature ■ Measuring range | <input type="checkbox"/> |
| Has the correct orientation for the sensor been selected → 23? <ul style="list-style-type: none"> ■ According to sensor type ■ According to medium temperature ■ According to medium properties (outgassing, with entrained solids) | <input type="checkbox"/> |
| Does the arrow on the sensor match the direction of flow of the medium? → 23? | <input type="checkbox"/> |
| Is the tag name and labeling correct (visual inspection)? | <input type="checkbox"/> |
| Is the device sufficiently protected from precipitation and direct sunlight? | <input type="checkbox"/> |
| Are the securing screw and securing clamp tightened securely? | <input type="checkbox"/> |

7 Electrical connection

WARNING

Live parts! Incorrect work performed on the electrical connections can result in an electric shock.

- ▶ Set up a disconnecting device (switch or power-circuit breaker) to easily disconnect the device from the supply voltage.
- ▶ In addition to the device fuse, include an overcurrent protection unit with max. 10 A in the plant installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: use appropriate tool
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: flat blade screwdriver ≤ 3 mm (0.12 in)

7.2.2 Requirements for connection cable

The connecting cables provided by the customer must fulfill the following requirements.

Protective grounding cable for the outer ground terminal

Conductor cross-section $< 6 \text{ mm}^2$ (10 AWG)

Larger cross-sections can be connected using a cable lug.

The grounding impedance must be less than 2Ω .

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

4 to 20 mA current input

Standard installation cable is sufficient.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

FOUNDATION Fieldbus

Twisted, shielded two-wire cable.



For further information on planning and installing FOUNDATION Fieldbus networks see:


- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

Cable diameter

- Cable glands supplied:
M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules.
Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG)

Choice of connecting cable between the transmitter and sensor

Depends on the type of transmitter and the installation zones



A0032476

- 1 Proline 500 digital transmitter
- 2 Proline 500 transmitter
- 3 Sensor Promass
- 4 Non-hazardous area
- 5 Hazardous area: Zone 2; Class I, Division 2
- 6 Hazardous area: Zone 1; Class I, Division 1
- A Standard cable to 500 digital transmitter → 37
Transmitter installed in the non-hazardous area or hazardous area: Zone 2; Class I, Division 2/sensor installed in the hazardous area: Zone 2; Class I, Division 2
- B Standard cable to 500 digital transmitter → 37
Transmitter installed in the hazardous area: Zone 2; Class I, Division 2/sensor installed in the hazardous area: Zone 1; Class I, Division 1
- C Signal cable to 500 transmitter → 39
Transmitter and sensor installed in the hazardous area: Zone 2; Class I, Division 2 or Zone 1; Class I, Division 1

*A: Connecting cable between sensor and transmitter: Proline 500 – digital**Standard cable*

A standard cable with the following specifications can be used as the connecting cable.

| | |
|----------------------------|--|
| Design | 4 cores (2 pairs); uninsulated stranded CU wires; pair-stranded with common shield |
| Shield | Tin-plated copper braid, optical cover $\geq 85\%$ |
| Loop resistance | Power supply line (+, -): maximum $10\ \Omega$ |
| Cable length | Maximum 300 m (900 ft), see the following table. |
| Device plug, side 1 | M12 socket, 5-pin, A-coded. |
| Device plug, side 2 | M12 plug, 5-pin, A-coded. |
| Pins 1+2 | Connected cores as twisted pair. |
| Pins 3+4 | Connected cores as twisted pair. |

| Cross-section | Cable length [max.] |
|-------------------------------|---------------------|
| 0.34 mm ² (AWG 22) | 80 m (240 ft) |
| 0.50 mm ² (AWG 20) | 120 m (360 ft) |
| 0.75 mm ² (AWG 18) | 180 m (540 ft) |
| 1.00 mm ² (AWG 17) | 240 m (720 ft) |
| 1.50 mm ² (AWG 15) | 300 m (900 ft) |

Optionally available connecting cable




| | |
|---|--|
| Design | 2 × 2 × 0.34 mm ² (AWG 22) PVC cable ¹⁾ with common shield (2 pairs, uninsulated stranded CU wires; pair-stranded) |
| Flame resistance | According to DIN EN 60332-1-2 |
| Oil resistance | According to DIN EN 60811-2-1 |
| Shield | Tin-plated copper braid, optical cover $\geq 85\%$ |
| Continuous operating temperature | When mounted in a fixed position: -50 to +105 °C (-58 to +221 °F); when cable can move freely: -25 to +105 °C (-13 to +221 °F) |
| Available cable length | Fixed: 20 m (60 ft); variable: up to maximum 50 m (150 ft) |

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

*B: Connecting cable between sensor and transmitter: Proline 500 - digital**Standard cable*

A standard cable with the following specifications can be used as the connecting cable.

| | |
|--|--|
| Design | 4, 6, 8 cores (2, 3, 4 pairs); uninsulated stranded CU wires; pair-stranded with common shield |
| Shielding | Tin-plated copper braid, optical cover $\geq 85\%$ |
| Capacitance C | Maximum 760 nF IIC, maximum 4.2 μ F IIB |
| Inductance L | Maximum 26 μ H IIC, maximum 104 μ H IIB |
| Inductance/resistance ratio (L/R) | Maximum 8.9 μ H/ Ω IIC, maximum 35.6 μ H/ Ω IIB (e.g. according to IEC 60079-25) |
| Loop resistance | Power supply line (+, -): maximum $5\ \Omega$ |
| Cable length | Maximum 150 m (450 ft), see the following table. |

| Cross-section | Cable length [max.] | Termination |
|--|---------------------|---|
| 2 x 2 x 0.50 mm ² (AWG 20) | 50 m (150 ft) | 2 x 2 x 0.50 mm ² (AWG 20)  <ul style="list-style-type: none"> ■ +, - = 0.5 mm² ■ A, B = 0.5 mm² |
| 3 x 2 x 0.50 mm ² (AWG 20) | 100 m (300 ft) | 3 x 2 x 0.50 mm ² (AWG 20)  <ul style="list-style-type: none"> ■ +, - = 1.0 mm² ■ A, B = 0.5 mm² |
| 4 x 2 x 0.50 mm ² (AWG 20) | 150 m (450 ft) | 4 x 2 x 0.50 mm ² (AWG 20)  <ul style="list-style-type: none"> ■ +, - = 1.5 mm² ■ A, B = 0.5 mm² |

Optionally available connecting cable

| | |
|------------------------|--|
| Connecting cable for | Zone 1; Class I, Division 1 |
| Standard cable | 2 × 2 × 0.5 mm ² (AWG 20) PVC cable ¹⁾ with common shield (2 pairs, pair-stranded) |
| Flame resistance | According to DIN EN 60332-1-2 |
| Oil-resistance | According to DIN EN 60811-2-1 |
| Shielding | Tin-plated copper braid, optical cover ≥ 85 % |
| Operating temperature | When mounted in a fixed position: -50 to +105 °C (-58 to +221 °F); when cable can move freely: -25 to +105 °C (-13 to +221 °F) |
| Available cable length | Fixed: 20 m (60 ft); variable: up to maximum 50 m (150 ft) |

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

C: Connecting cable between sensor and transmitter: Proline 500

| | |
|--|--|
| Design | 6 × 0.38 mm ² PVC cable ¹⁾ with individual shielded cores and common copper shield |
| Conductor resistance | ≤ 50 Ω/km (0.015 Ω/ft) |
| Capacitance: core/shield | ≤ 420 pF/m (128 pF/ft) |
| Cable length (max.) | 20 m (60 ft) |
| Cable lengths (available for order) | 5 m (15 ft), 10 m (30 ft), 20 m (60 ft) |
| Cable diameter | 11 mm (0.43 in) ± 0.5 mm (0.02 in) |
| Continuous operating temperature | Max. 105 °C (221 °F) |

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

7.2.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.



| Supply voltage | | Input/output 1 (port 1) | | Input/output 2 | | Input/output 3 | | Input/output 4 ¹⁾ | | Service interface (Port 2) |
|--|-------|-------------------------|--------|----------------|--------|----------------|--------|------------------------------|--------|----------------------------|
| 1 (+) | 2 (-) | 26 (A) | 27 (B) | 24 (+) | 25 (-) | 22 (+) | 23 (-) | 20 (+) | 21 (-) | CDI-RJ45 |
| Device-specific terminal assignment: adhesive label in terminal cover. | | | | | | | | | | |

1) Input/output only available for Proline 500 - digital.


Transmitter and sensor connection housing: connecting cable

The sensor and transmitter, which are mounted in separate locations, are interconnected by a connecting cable. The cable is connected via the sensor connection housing and the transmitter housing.

Terminal assignment and connection of the connecting cable:

- Proline 500 – digital →  42
- Proline 500 →  49


7.2.4 Available device plugs for Proline 500

 Device plugs may not be used in hazardous areas!

Order code for "Input; output 1", option SA "FOUNDATION fieldbus"

| Order code for "Electrical connection" | Cable entry/connection | |
|--|------------------------|---|
| | 2 | 3 |
| M, 3, 4, 5 | 7/8" plug | – |

7.2.5 Pin assignment of device plug

|  | Pin | Assignment | | Coding | Plug/socket |
|---|--------------------|------------|---------------------------|--------|-------------|
| | 1 | + | Signal + | A | Plug |
| | 2 | - | Signal - | | |
| | 3 | | Cable shield ¹ | | |
| | 4 | | Not used | | |
| | Metal plug housing | | Cable shield | | |
| ¹ If a cable shield is used | | | | | |

7.2.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 % is ideal.

1. To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.


1. Observe national installation requirements and guidelines during installation.
2. Where there are large differences in potential between the individual grounding points, connect only one point of the shielding directly to the reference ground.
3. In systems without potential equalization, the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- Insulate the shield that is not connected.



A0028768

17 Connection example for FOUNDATION Fieldbus

- 1 Automation system (e.g. PLC)
- 2 Power conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring instrument
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

7.2.7 Preparing the device

Carry out the steps in the following order:

1. Mount the sensor and transmitter.
2. Sensor connection housing: Connect connecting cable.
3. Transmitter: Connect connecting cable.
4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.

1. Remove dummy plug if present.
2. If the measuring instrument is supplied without cable glands:
Provide suitable cable gland for corresponding connecting cable.
3. If the measuring instrument is supplied with cable glands:
Observe requirements for connecting cables → 35.

7.3 Connecting the device: Proline 500 – digital

NOTICE

An incorrect connection compromises electrical safety!

- ▶ Only properly trained specialist staff may perform electrical connection work.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ☹ before connecting additional cables.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.


7.3.1 Connecting the connecting cable

NOTICE

Risk of damaging the electronic components!

- ▶ Connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.

Connecting cable terminal assignment



- 1 Cable entry for cable on transmitter housing
- 2 Protective earth (PE)
- 3 Connecting cable ISEM communication
- 4 Grounding via ground connection; in the version with a device plug, grounding is ensured through the plug itself
- 5 Cable entry for cable or connection of device plug on sensor connection housing
- 6 Protective earth (PE)

Connecting the connecting cable to the sensor connection housing


- Connection via terminals with order code for "Sensor connection housing":
 - Option A "Aluminum, coated" → ☹ 43
 - Option B "Stainless" → ☹ 44
- Connection via connectors with order code for "Sensor connection housing":
 - Option C "Ultra-compact hygienic, stainless" → ☹ 45

Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals → ☹ 46.

Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing":
Option **A** "Aluminum coated"



1. Loosen the securing clamp of the housing cover.
2. Unscrew the housing cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
5. Connect the protective ground.
6. Connect the cable in accordance with the connecting cable terminal assignment.
7. Firmly tighten the cable glands.
 - This concludes the process for connecting the connecting cable.


⚠ WARNING

Housing degree of protection voided due to insufficient sealing of the housing.

- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
8. Screw on the housing cover.
 9. Tighten the securing clamp of the housing cover.

Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing":
Option **B** "Stainless"




A0029613

1. Release the securing screw of the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
5. Connect the protective ground.
6. Connect the cable in accordance with the connecting cable terminal assignment.
7. Firmly tighten the cable glands.
 - ➔ This concludes the process for connecting the connecting cable.
8. Close the housing cover.
9. Tighten the securing screw of the housing cover.

Connecting the sensor connection housing via the connector


For the device version with the order code for "Sensor connection housing":
Option C "Ultra-compact hygienic, stainless"



A0029615

1. Connect the protective ground.
2. Connect the connector.


Connecting the connecting cable to the transmitter



A0029597


1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Fold open the terminal cover.
4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
6. Connect the protective ground.
7. Connect the cable according to the terminal assignment for the connecting cable → 42.
8. Firmly tighten the cable glands.
 - ↳ The process for connecting the connecting cable is now complete.
9. Close the housing cover.
10. Tighten the securing screw of the housing cover.
11. After connecting the connecting cable:
 - Connect the signal cable and the supply voltage cable → 47.

7.3.2 Connecting the signal cable and the supply voltage cable



A0028200

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output
- 4 Terminal connection for connecting cable between sensor and transmitter
- 5 Terminal connection for signal transmission, input/output; optional: connection for external WLAN antenna
- 6 Protective earth (PE)



A0029597

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Fold open the terminal cover.
4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
6. Connect the protective ground.
7. Connect the cable according to the terminal assignment.
 - ↳ **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 - Supply voltage terminal assignment:** Adhesive label in the terminal cover or → 39.
8. Firmly tighten the cable glands.
 - ↳ This concludes the cable connection process.
9. Close the terminal cover.
10. Close the housing cover.

⚠ WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

- Screw in the screw without using any lubricant.

NOTICE

Excessive tightening torque applied to the fixing screws!


Risk of damaging the plastic transmitter.

- Tighten the fixing screws as per the tightening torque: 2.5 Nm (1.8 lbf ft)

11. Tighten the 4 fixing screws on the housing cover.

Removing a cable

To remove a cable from the terminal:



A0029598

18 Unit mm(in)

1. Use a flat-blade screwdriver to press down on the slot between the two terminal holes.
2. Remove the cable end from the terminal.

7.4 Connecting the device: Proline 500

NOTICE

An incorrect connection compromises electrical safety!

- ▶ Only properly trained specialist staff may perform electrical connection work.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ☹ before connecting additional cables.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.4.1 Connecting the connecting cable

NOTICE

Risk of damaging the electronic components!


- ▶ Connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.

⚠ CAUTION

Measurement error due to shortening of the connecting cable

- ▶ The connecting cable is ready for installation and must be used in the length supplied. Shortening the connecting cable can affect the sensor's measurement accuracy.

Connecting cable terminal assignment



A0028197

- 1 Protective earth (PE)
- 2 Cable entry for connecting cable on transmitter connection housing
- 3 Connecting cable
- 4 Cable entry for connecting cable on sensor connection housing
- 5 Protective earth (PE)


Connecting the connecting cable to the sensor connection housing

Connection via terminals with order code for "Housing":

- Option **A** "Aluminum coated" → ☹ 50
- Option **B** "Stainless" → ☹ 51

Connecting the sensor connection housing via terminals

For the device version with the order code for "Housing":
Option A "Aluminum coated"



A0029612

1. Loosen the securing clamp of the housing cover.
2. Unscrew the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
5. Connect the protective ground.
6. Connect the cable in accordance with the connecting cable terminal assignment.
7. Firmly tighten the cable glands.
 - ↳ The process for connecting the connecting cable is now complete.


⚠ WARNING

Housing degree of protection voided due to insufficient sealing of the housing.

- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
8. Screw on the housing cover.
 9. Tighten the securing clamp of the housing cover.

Connecting the sensor connection housing via terminals


For the device version with the order code for "Housing":
Option B "Stainless"



A0029613

1. Release the securing screw of the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
5. Connect the protective ground.
6. Connect the cable in accordance with the connecting cable terminal assignment.
7. Firmly tighten the cable glands.
 - This concludes the process for connecting the connecting cable.
8. Close the housing cover.
9. Tighten the securing screw of the housing cover.


Attaching the connecting cable to the transmitter



A0029592


1. Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the protective ground.
6. Connect the cable in accordance with the connecting cable terminal assignment
→ 49.
7. Firmly tighten the cable glands.
↳ This concludes the process for attaching the connecting cable.
8. Screw on the connection compartment cover.
9. Tighten the securing clamp of the connection compartment cover.
10. After connecting the connecting cable:
Connect the signal cable and the supply voltage cable → 53.

7.4.2 Connecting the signal cable and the supply voltage cable




A0026781

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45)
- 4 Protective earth (PE)




A0029813

- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.




A0029814

- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.



A0029815

- 7.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8.** Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9.** Connect the protective ground.




A0029816

- 10.** Connect the cable according to the terminal assignment.
 - ↳ **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 - Supply voltage connection terminal assignment:** Adhesive label in the terminal cover or → 39.
- 11.** Firmly tighten the cable glands.
 - ↳ This concludes the cable connection process.
- 12.** Close the terminal cover.
- 13.** Fit the display module holder in the electronics compartment.
- 14.** Screw on the connection compartment cover.
- 15.** Secure the securing clamp of the connection compartment cover.

Removing a cable

To remove a cable from the terminal:



A0029598

19 Unit mm(in)

1. Use a flat-blade screwdriver to press down on the slot between the two terminal holes.
2. Remove the cable end from the terminal.

7.5 Potential equalization

7.5.1 Requirements


For potential equalization:

- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Connect the medium, sensor and transmitter to the same electric potential
- Use a ground cable with a minimum cross-section of 6 mm² (10 AWG) and a cable lug for potential equalization connections

7.6 Special connection instructions

7.6.1 Connection examples


Current output 4 to 20 mA (without HART)



A0055851

20 Connection example for 4 to 20 mA current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Optional additional display unit: Observe maximum load
- 3 Flowmeter with current output (active)




A0055852

21 Connection example for 4 to 20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Optional additional display unit: Observe maximum load
- 4 Transmitter with current output (passive)

Current input 4 to 20 mA




A0055853

22 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 External measuring instrument with 4 to 20 mA passive current output, e.g. pressure or temperature
- 3 Transmitter with 4 to 20 mA current input


Pulse output/frequency output/switch output



A0055856

23 Connection example for pulse output/frequency output/switch output (active)

- 1 Automation system with pulse input/frequency input/switch input (e.g. PLC)
- 2 Transmitter with pulse output/frequency output/switch output (active)




A0055855

24 Connection example for pulse output/frequency output/switch output (passive)

- 1 Automation system with pulse input/frequency input/switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter with pulse output/frequency output/switch output (passive)

Relay output




A0055859

25 Connection example for relay output

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter with relay output

Status input




A0055860

26 Connection example for status input

- 1 Automation system with switch output passive e.g. PLC)
- 2 Power supply
- 3 Transmitter with status input

FOUNDATION Fieldbus



27 Connection example for FOUNDATION Fieldbus


- 1 Automation system (e.g. PLC)
- 2 Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring instrument
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

7.7 Ensuring the degree of protection

The measuring instrument fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To ensure degree of protection IP66/67, Type 4X enclosure, carry out the following steps after making the electrical connection:

1. Check that the housing seals are clean and fitted correctly.
2. Dry, clean or replace the seals if necessary.
3. Tighten all housing screws and screw covers.
4. Firmly tighten the cable glands.
5. To ensure that moisture does not enter the cable entry:
Route the cable so that it loops down before the cable entry ("water trap").



A0029278


6. The supplied cable glands and plastic dummy plugs used for the threaded cable entries do not ensure degree of protection IP66/67, Type 4X enclosure. To achieve this degree of protection, cable glands and plastic dummy plugs that are not used must be replaced by threaded dummy plugs with the degree of protection IP66/67, Type 4X enclosure.

7.8 Post-connection check

| | |
|--|--------------------------|
| Are the device and cable undamaged (visual inspection)? | <input type="checkbox"/> |
| Is the protective earthing established correctly? | <input type="checkbox"/> |
| Do the cables used meet the requirements ? | <input type="checkbox"/> |
| Are the mounted cables strain-relieved and fixed securely in place? | <input type="checkbox"/> |
| Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" → 58? | <input type="checkbox"/> |
| Is the terminal assignment correct ? | <input type="checkbox"/> |
| Are dummy plugs inserted in unused cable entries and have transportation plugs been replaced with dummy plugs? | <input type="checkbox"/> |

8 Operation options

8.1 Overview of operation options






A0034513


- 1 Local operation via display module
- 2 Computer with web browser or operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Automation system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device →  241



 28 Schematic structure of the operating menu

A0018237-EN

8.2.2 Operating philosophy


The individual parts of the operating menu are assigned to certain user roles (e.g. operator, maintenance etc.). Each user role contains typical tasks within the device life cycle.

| Menu/parameter | | User role and tasks | Content/meaning |
|----------------|---------------|--|---|
| Language | Task-oriented | Role "Operator", "Maintenance" Tasks during operation: <ul style="list-style-type: none"> ■ Configuring the operational display ■ Reading measured values | Defining the operating language |
| Operation | | | <ul style="list-style-type: none"> ■ Defining the operating language ■ Defining the web server operating language ■ Resetting and controlling totalizers ■ Configuring the operational display (e.g. display format, display contrast) ■ Resetting and controlling totalizers |
| Setup | | "Maintenance" role Commissioning: <ul style="list-style-type: none"> ■ Configuring the measurement ■ Configuring the inputs and outputs ■ Configuring the communication interface | Wizard for quick commissioning: <ul style="list-style-type: none"> ■ Configuring the system units ■ Configuring the communication interface ■ Defining the medium ■ Displaying the I/O configuration ■ Configuring the inputs ■ Configuring the outputs ■ Configuring the operational display ■ Configuring the low flow cut off ■ Configuring the detection of partially filled and empty pipes Advanced setup <ul style="list-style-type: none"> ■ For more customized configuration of the measurement (adaptation to special measuring conditions) ■ Calculated process variables ■ Sensor adjustment ■ Configuring totalizers ■ Configuring the display ■ Configuring the WLAN settings ■ Data backup ■ Administration (define access code, reset measuring instrument) |
| Diagnostics | | "Maintenance" role Troubleshooting: <ul style="list-style-type: none"> ■ Diagnostics and elimination of process and device errors ■ Measured value simulation | Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ■ Diagnostic list Contains up to 5 currently pending diagnostic messages. ■ Event logbook Contains event messages that have occurred. ■ Device information Contains information for identifying the device. ■ Measured values Contains all current measured values. ■ Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values ■ Heartbeat Technology The functionality of the device is checked on demand and the verification results are documented. ■ Simulation Used to simulate measured values or output values. ■ Testpoints |

| Menu/parameter | | User role and tasks | Content/meaning |
|----------------|-------------------|--|---|
| Expert | Function-oriented | <p>Tasks that require detailed knowledge of the function of the device:</p> <ul style="list-style-type: none">■ Commissioning measurements under difficult conditions■ Optimal adaptation of the measurement to difficult conditions■ Detailed configuration of the communication interface■ Error diagnostics in difficult cases | <p>Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:</p> <ul style="list-style-type: none">■ System Contains all higher-level device parameters that do not affect measurement or measured value communication.■ Sensor Configuring the measurement.■ Output Configure the pulse/frequency/switch output.■ Input Configuring the status input.■ Output Configuring the analog current outputs as well as the pulse/frequency and switch output.■ Communication Configuring the digital communication interface and the web server.■ Submenus for function blocks (e.g. "Analog Inputs") Configuring function blocks.■ Application Configuring the functions that go beyond the actual measurement (e.g. totalizer).■ Diagnostics Error detection and analysis of process and device errors and for device simulation and the Heartbeat Technology menu. |

8.3 Access to operating menu via local display

8.3.1 Operational display



A0029348

- 1 Operational display
- 2 Tag name
- 3 Status area
- 4 Display area for measured values (up to 4 lines)
- 5 Operating elements → 70

Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals→ 165
 - **F**: Failure
 - **C**: Function check
 - **S**: Out of specification
 - **M**: Maintenance required
- Diagnostic behavior→ 166
 - : Alarm
 - : Warning
- : Locking (the device is locked via the hardware)
- : Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured variables

| Symbol | Meaning |
|--------|---|
| | Mass flow |
| | <ul style="list-style-type: none">■ Volume flow■ Corrected volume flow |
| | <ul style="list-style-type: none">■ Density■ Reference density |
| | Temperature |

The number and display format of the measured variables can be configured via the **Format display** parameter (→ 114).

Totalizer

| Symbol | Meaning |
|--------|---|
| | Totalizer The measurement channel number indicates which of the three totalizers is displayed. |



Input


| Symbol | Meaning |
|--------|--------------|
| | Status input |

Measurement channel numbers


| Symbol | Meaning |
|--------|---|
| | Measurement channel 1 to 4 The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3). |

Diagnostic behavior

| Symbol | Meaning |
|---|---|
|  | Alarm <ul style="list-style-type: none">■ Measurement is interrupted.■ Signal outputs and totalizers assume the defined alarm condition.■ A diagnostic message is generated. |
|  | Warning <ul style="list-style-type: none">■ Measurement is resumed.■ The signal outputs and totalizers are not affected.■ A diagnostic message is generated. |

 The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.

8.3.2 Navigation view



Navigation path

The navigation path to the current position is displayed at the top left in the navigation view and consists of the following elements:

- The display symbol for the menu/submenu (▶) or the wizard (⚙).
- An omission symbol (/ ../) for operating menu levels in between.
- Name of the current submenu, wizard or parameter

| | | | |
|---------|----------------|-----------------|------------|
| | Display symbol | Omission symbol | Parameter |
| | ↓ | ↓ | ↓ |
| Example | ▶ | / ../ | Indication |

For more information about the icons in the menu, refer to the "Display area" section → 66

Status area

The following appears in the status area of the navigation view in the top right corner:




- In the submenu
 - The direct access code to the parameter (e.g., 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
 - If a diagnostic event is present, the diagnostic behavior and status signal

- For information on the diagnostic behavior and status signal → 165
- For information on the function and entry of the direct access code → 72





Display area

Menus


| Symbol | Meaning |
|--------|---|
| | Operation Is displayed: <ul style="list-style-type: none">▪ In the menu next to the "Operation" selection▪ At the left in the navigation path in the Operation menu |

| | |
|---|--|
|  | Setup Is displayed: <ul style="list-style-type: none"> ■ In the menu next to the "Setup" selection ■ At the left in the navigation path in the Setup menu |
|  | Diagnosis Is displayed: <ul style="list-style-type: none"> ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the Diagnostics menu |
|  | Expert Is displayed: <ul style="list-style-type: none"> ■ In the menu next to the "Expert" selection ■ At the left in the navigation path in the Expert menu |




Submenus, wizards, parameters

| Symbol | Meaning |
|---|--|
|  | Submenu |
|  | Wizards |
|  | Parameters within a wizard |
|  | No display symbol exists for parameters in submenus. |

Locking procedure


| Symbol | Meaning |
|---|---|
|  | Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> ■ By a user-specific access code ■ By the hardware write protection switch |

Wizards

| Symbol | Meaning |
|---|--|
|  | Switches to the previous parameter. |
|  | Confirms the parameter value and switches to the next parameter. |
|  | Opens the editing view of the parameter. |

8.3.3 Editing view

Numeric editor




A0034250

29 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 Operating elements

Text editor





A0034114

30 For entering text in parameters (e.g. device tag)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 Operating elements
- 5 Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

Using the operating elements in the editing view





| Operating key | Meaning |
|---------------|--|
| | Minus key Move the entry position to the left. |
| | Plus key Move the entry position to the right. |

| Operating key | Meaning |
|---|---|
|  | Enter key <ul style="list-style-type: none"> Pressing the key briefly confirms your selection. Pressing the key for 2 s confirms your entry. |
|  | Escape key combination (press keys simultaneously) Close the editing view without accepting a change. |






Input screens

| Symbol | Meaning |
|------------|---|
| A.. | Upper case |
| a.. | Lower case |
| 1.. | Numbers |
| +.. | Punctuation marks and special characters: = + - * / ² ³ ¼ ½ ¾ () [] < > { } |
| @.. | Punctuation marks and special characters: ' " ^ . , ; : ? ! % μ ° € \$ £ ¥ § @ # / \ ~ & _ |
| ä.. | Umlauts and accents |

Controlling data entries

| Symbol | Meaning |
|---|---|
|  | Move entry position |
|  | Reject entry |
|  | Confirm entry |
|  | Delete character immediately to the left of the entry position |
| del | Delete character immediately to the right of the entry position |
| C | Clear all the characters entered |

8.3.4 Operating elements

| Operating key | Meaning |
|---|--|
|  | Minus key <i>In menu, submenu</i> Moves the selection bar upwards in a picklist <i>In wizards</i> Goes to previous parameter <i>In the text and numeric editor</i> Move the entry position to the left. |
|  | Plus key <i>In menu, submenu</i> Moves the selection bar downwards in a picklist <i>In wizards</i> Goes to the next parameter <i>In the text and numeric editor</i> Move the entry position to the right. |
|  | Enter key <i>In the operational display</i> Pressing the key briefly opens the operating menu. <i>In menu, submenu</i> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter: <ul style="list-style-type: none"> If present, opens the help text for the function of the parameter. <i>In wizards</i> Opens the editing view of the parameter and confirms the parameter value <i>In the text and numeric editor</i> <ul style="list-style-type: none"> Pressing the key briefly confirms your selection. Pressing the key for 2 s confirms your entry. |
|  | Escape key combination (press keys simultaneously) <i>In menu, submenu</i> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). <i>In wizards</i> Exits the wizard and takes you to the next higher level <i>In the text and numeric editor</i> Exits the Editing view without applying the changes. |
|  | Minus/Enter key combination (press and hold down the keys simultaneously) <ul style="list-style-type: none"> If keypad lock is active: <ul style="list-style-type: none"> Pressing the key for 3 s deactivates the keypad lock. If keypad lock is not active: <ul style="list-style-type: none"> Pressing the key for 3 s opens the context menu including the option for activating the keypad lock. |



8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation



Calling up and closing the context menu

The user is in the operational display.



1. Press the  and  keys for longer than 3 seconds.
 - ↳ The context menu opens.



A0034608-EN

2. Press  +  simultaneously.
 - ↳ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


1. Open the context menu.
2. Press  to navigate to the desired menu.
3. Press  to confirm the selection.
 - ↳ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

 For an explanation of the navigation view with symbols and operating elements
→  66

Example: Setting the number of displayed measured values to "2 values"




A0029562-EN

8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path
Expert → Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter 00914 → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign process variable** parameter



For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press for 2 s.
↳ The help text for the selected parameter opens.



31 Example: Help text for parameter "Enter access code"

2. Press + simultaneously.
↳ The help text is closed.

8.3.9 Changing the parameters




Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.


A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

A0014049-EN

 For a description of the editing view - consisting of the text editor and numeric editor - with symbols →  68, for a description of the operating elements →  70

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access →  136.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
 - ↳ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.


Access authorization to parameters: "Maintenance" user role


| Access code status | Read access | Write access |
|--|-------------|-----------------|
| An access code has not yet been defined (factory setting). | ✓ | ✓ |
| After an access code has been defined. | ✓ | ✓ ¹⁾ |

1) The user only has write access after entering the access code.



Access authorization to parameters: "Operator" user role


| Access code status | Read access | Write access |
|--|-------------|-----------------|
| After an access code has been defined. | ✓ | – ¹⁾ |


1) Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection as they do not affect the measurement: write protection via access code →  136

 The user role with which the user is currently logged on is indicated by the **Access status** parameter. Navigation path: Operation → Access status


8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation →  136.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter (→  119) via the respective access option.

1. After you press , the input prompt for the access code appears.

2. Enter the access code.


- ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock



The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.


The keypad lock is switched on and off via the context menu.

Switching on the keypad lock



-  The keypad lock is switched on automatically:
- If the device has not been operated via the display for > 1 minute.
 - Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.
Press the  and  keys for 3 seconds.
 - ↳ A context menu appears.
2. In the context menu select the **Keylock on** option.
 - ↳ The keypad lock is switched on.

-  If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock


- ▶ The keypad lock is switched on.
Press the  and  keys for 3 seconds.
 - ↳ The keypad lock is switched off.

8.4 Access to operating menu via web browser

8.4.1 Function range

The integrated web server can be used to operate and configure the device via a web browser service interface (CDI-RJ45) or via WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; Operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

-  For additional information on the web server, see the Special Documentation for the device. →  242


8.4.2 Requirements

Computer hardware




| Hardware | Interface | |
|------------|---|--|
| | RJ45 | WLAN |
| Interface | The computer must have a RJ45 interface. ¹⁾ | The operating unit must have a WLAN interface. |
| Connection | | Connection via wireless local area network. |
| Screen | Recommended size: ≥12" (depends on the screen resolution) | |

- 1) Recommended cable: CAT5e, CAT6 or CAT7, with shielded plug (e.g. YAMAICHI product; part no. Y-ConProfixPlug63/Prod. ID: 82-006660)

Computer software



| Software | Interface | |
|-------------------------------|--|------|
| | RJ45 | WLAN |
| Recommended operating systems | <ul style="list-style-type: none"> Microsoft Windows 8 or higher. Mobile operating systems: <ul style="list-style-type: none"> iOS Android <p> Microsoft Windows XP and Windows 7 is supported.</p> | |
| Web browsers supported | <ul style="list-style-type: none"> Microsoft Edge Mozilla Firefox Google Chrome Safari | |

Computer settings



| Settings | Interface | |
|--|---|---|
| | RJ45 | WLAN |
| User rights | Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (e.g. for adjusting the IP address, subnet mask etc.). | |
| Proxy server settings of the web browser | The web browser's <i>Use a Proxy Server for Your LAN</i> setting must be deselected . | |
| JavaScript | <p>JavaScript must be enabled.</p> <p> If JavaScript cannot be enabled: Enter <code>http://192.168.1.212/servlet/basic.html</code> in the address bar of the web browser. A fully functional but simplified version of the operating menu structure starts in the web browser.</p> <p> When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) under Internet options in the web browser.</p> | <p>JavaScript must be enabled.</p> <p> The WLAN display requires JavaScript support.</p> |
| Network connections | Use only the active network connections for the measuring instrument. | |
| | Switch off all other network connections such as WLAN for example. | Switch off all other network connections. |

 In the event of connection problems: →  161

Measuring device: Via CDI-RJ45 service interface

| Device | CDI-RJ45 service interface |
|------------------|--|
| Measuring device | The measuring device has an RJ45 interface. |
| Web server | Web server must be enabled; factory setting: ON  For information on enabling the Web server →  78 |


Measuring device: via WLAN interface


| Device | WLAN interface |
|------------------|---|
| Measuring device | The measuring device has a WLAN antenna: <ul style="list-style-type: none"> Transmitter with integrated WLAN antenna Transmitter with external WLAN antenna |
| Web server | Web server and WLAN must be enabled; factory setting: ON  For information on enabling the Web server →  78 |

8.4.3 Logging on

1. Select the preferred operating language for the Web browser.
2. Enter the user-specific access code.
3. Press **OK** to confirm your entry.

| | |
|-------------|--|
| Access code | 0000 (factory setting); can be changed by customer |
|-------------|--|


 If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.4 User interface


- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal →  168
- Current measured values

Function row

| Functions | Meaning |
|-----------------|--|
| Measured values | Displays the measured values of the measuring instrument |
| Menu | <ul style="list-style-type: none"> Access to the operating menu from the measuring instrument The structure of the operating menu is the same as for the local display  Detailed information on the "Description of Device Parameters" operating menu |
| Device status | Displays the diagnostic messages currently pending, listed in order of priority |
| Data management | Data exchange between computer and measuring instrument: <ul style="list-style-type: none"> Device configuration: <ul style="list-style-type: none"> Load settings from the device (XML format, save configuration) Save settings to the device (XML format, restore configuration) Logbook - Export Event logbook (.csv file) Documents - Export documents: <ul style="list-style-type: none"> Export backup data record (.csv file, create documentation of the measuring point configuration) Verification report (PDF file, only available with the "Heartbeat Verification" application package) File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring instrument: FOUNDATION Fieldbus: DD file Firmware update - Flashing a firmware version |
| Network | Configuration and checking of all the parameters required for establishing the connection to the measuring instrument: <ul style="list-style-type: none"> Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version) |
| Logout | End the operation and call up the login page |

Navigation area

The menus, the associated submenus and parameters can be selected in the navigation area.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.5 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu → Communication → Web server

Parameter overview with brief description

| Parameter | Description | Selection |
|--------------------------|-----------------------------------|---|
| Web server functionality | Switch the Web server on and off. | <ul style="list-style-type: none"> Off HTML Off On |

Function scope of the "Web server functionality" parameter


| Option | Description |
|----------|---|
| Off | <ul style="list-style-type: none"> ■ The Web server is completely disabled. ■ Port 80 is locked. |
| HTML Off | The HTML version of the Web server is not available. |
| On | <ul style="list-style-type: none"> ■ The complete Web server functionality is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state. |

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.6 Logging out


 Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.
↳ The home page with the Login box appears.
2. Close the Web browser.
3. If no longer needed:
Reset the modified properties of the Internet protocol (TCP/IP) .


8.5 Operation via SmartBlue app

The device can be operated and configured with the SmartBlue App.

- The SmartBlue app must be downloaded onto a mobile device for this purpose
- For information on the compatibility of the SmartBlue app with mobile devices, see **Apple App Store (iOS devices)** or **Google Play Store (Android devices)**
- Incorrect operation by unauthorized persons is prevented by means of encrypted communication and password encryption.
- The Bluetooth® function can be deactivated after initial device setup.



A0033202

 32 QR code for free Endress+Hauser SmartBlue App

Download and installation:

1. Scan the QR code or enter **SmartBlue** in the search field of the Apple App Store (iOS) or Google Play Store (Android).
2. Install and start the SmartBlue app.
3. For Android devices: enable location tracking (GPS) (not required for iOS devices).

4. Select a device that is ready to receive from the device list displayed.

Login:

1. Enter the user name: admin
2. Enter the initial password: serial number of the device
3. Change the password after logging in for the first time



Information on password and reset code

For devices that meet the requirements of IEC 62443-4-1 "Secure product development lifecycle management" ("ProtectBlue"):

- If the user-defined password is lost: refer to the user management instructions and the reset button in the operating manual.
- Refer to the associated Security Manual (SD).

For all other devices (without "ProtectBlue"):

- If the user-defined password is lost, access can be restored via a reset code. The reset code is the serial number of the device in reverse. The original password is once again valid after the reset code has been entered.
- The reset code can also be changed in addition to the password.
- If the user-defined reset code is lost, the password can no longer be reset via the SmartBlue app. Contact Endress+Hauser Service in this case.


8.6 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.6.1 Connecting the operating tool

Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.



A0028837

33 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring instrument

Service interface


Via service interface (CDI-RJ45)

To configure the device on site, a point-to-point connection can be established. The connection is made with the housing open, directly via the device's service interface (CDI-RJ45).

i An adapter for the RJ45 to the M12 connector is optionally available for the non-hazardous area:

Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"


The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. The connection to the service interface can be established via an M12 connector without opening the device.

Proline 500 – digital transmitter

A0029163

34 Connection via service interface (CDI-RJ45)

- 1 Computer with web browser for accessing the integrated web server or computer with operating tool, e.g. "FieldCare", "DeviceCare" with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring instrument with access to the integrated web server

Proline 500 transmitter

A0027563


35 Connection via service interface (CDI-RJ45)

- 1 Computer with web browser for accessing integrated web server or with operating tool e.g. "FieldCare", "DeviceCare", with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring instrument with access to the integrated web server

Via WLAN interface

The optional WLAN interface is available on the following device version:

Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A0034569

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring instrument
- 4 LED flashing: WLAN connection established between operating unit and measuring instrument
- 5 Computer with WLAN interface and web browser for accessing integrated device web server or with operating tool e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and web browser for accessing integrated device web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smartphone or tablet (e.g. Field Xpert SMT70)

| | |
|------------------------------|---|
| Function | WLAN: IEEE 802.11 b/g (2.4 GHz) |
| Encryption | WPA2-PSK AES-128 (in accordance with IEEE 802.11i) |
| Configurable WLAN channels | 1 to 11 |
| Degree of protection | IP66/67 |
| Available antennas | <ul style="list-style-type: none"> ▪ Internal antenna ▪ External antenna (optional) <p>In the event of poor transmission/reception conditions at the place of installation.</p> <p>i Only 1 antenna is active at any one time!</p> |
| Range | <ul style="list-style-type: none"> ▪ Internal antenna: typically 10 m (32 ft) ▪ External antenna: typically 50 m (164 ft) |
| Materials (external antenna) | <ul style="list-style-type: none"> ▪ Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass ▪ Adapter: Stainless steel and nickel-plated brass ▪ Cable: Polyethylene ▪ Plug: Nickel-plated brass ▪ Angle bracket: Stainless steel |

Configuring the Internet protocol of the mobile device

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

- Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE**Please note the following to avoid a network conflict:**

- ▶ Avoid accessing the measuring instrument simultaneously from the same mobile device via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- ▶ Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH_Promass_500_A802000).
2. If necessary, select the WPA2 encryption method.
3. Enter the password:
Serial number of the measuring device ex-works (e.g. L100A802000).
 - ↳ The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.



The serial number can be found on the nameplate.



To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Terminating the WLAN connection

- ▶ After configuring the device:
Terminate the WLAN connection between the mobile terminal and measuring device.

8.6.2 Field Xpert SFX350, SFX370**Function scope**

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).



For details, see Operating Instructions BA01202S



Source for device description files

See information → 86

8.6.3 FieldCare**Function range**

FDT-based (Field Device Technology) plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- CDI-RJ45 service interface →  81
- WLAN interface →  82

Typical functions:

- Transmitter parameter configuration
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



- Operating Instructions BA00027S
- Operating Instructions BA00059S



Source for device description files →  86

8.6.4 DeviceCare

Function range

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



Innovation brochure IN01047S



Source for device description files →  86

8.6.5 AMS Device Manager

Function range

Program from Emerson Process Management for operating and configuring measuring devices via FOUNDATION Fieldbus H1 protocol.



Source for device description files →  86

8.6.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via FOUNDATION Fieldbus H1 protocol.

Source for device description files

See information →  86

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

| | | |
|----------------------------------|-------------------------------------|---|
| Firmware version | 01.00.zz | <ul style="list-style-type: none"> On the title page of the manual On the transmitter nameplate Firmware version Diagnostics → Device information → Firmware version |
| Release date of firmware version | 02.2017 | --- |
| Manufacturer ID | 0x452B48 (hex) | Manufacturer ID Diagnostics → Device information → Manufacturer ID |
| Device type code | 0x103B (hex) | Device type Diagnostics → Device information → Device type |
| Device revision | 1 | <ul style="list-style-type: none"> On the transmitter nameplate Device revision Diagnostics → Device information → Device revision |
| DD revision | Information and files available at: | |
| CFF revision | | |
| | | <ul style="list-style-type: none"> www.endress.com www.fieldbus.org |



For an overview of the various firmware versions for the device → 202

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

| Operating tool via FOUNDATION fieldbus | Sources for obtaining device descriptions |
|---|--|
| FieldCare | <ul style="list-style-type: none"> www.endress.com → Downloads area USB stick (contact Endress+Hauser) E-mail → Downloads area |
| DeviceCare | <ul style="list-style-type: none"> www.endress.com → Downloads area E-mail → Downloads area |
| <ul style="list-style-type: none"> Field Xpert SMT50 Field Xpert SMT70 Field Xpert SMT77 | Use update function of handheld terminal |
| AMS Device Manager (Emerson Process Management) | www.endress.com → Downloads area |
| Field Communicator 475 (Emerson Process Management) | Use update function of handheld terminal |

9.2 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

9.2.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a FOUNDATION Fieldbus master (Class 1), e.g. a control system etc.

| Display text (xxxx... = serial number) | Base index | Description |
|--|------------|---|
| RESOURCE_ xxxxxxxxxxxx | 400 | Resource block |
| SETUP_ xxxxxxxxxxxx | 600 | "Setup" Transducer block |
| TRDDISP_ xxxxxxxxxxxx | 800 | "Display" Transducer block |
| TRDHROM_ xxxxxxxxxxxx | 1000 | "HistoROM" Transducer block |
| TRDDIAG_ xxxxxxxxxxxx | 1200 | "Diagnostic" Transducer block |
| EXPERT_CONFIG_ xxxxxxxxxxxx | 1400 | "Expert configuration" Transducer block |
| SERVICE_SENSOR_ xxxxxxxxxxxx | 1600 | "Service sensor" Transducer block |
| TRDTIC_ xxxxxxxxxxxx | 1800 | "Totalizer" Transducer block |
| TRDHBT_ xxxxxxxxxxxx | 2000 | "Heartbeat results" Transducer block |
| ANALOG_INPUT_1_ xxxxxxxxxxxx | 3400 | Analog Input function block 1 (AI) |
| ANALOG_INPUT_2_ xxxxxxxxxxxx | 3600 | Analog Input function block 2 (AI) |
| ANALOG_INPUT_3_ xxxxxxxxxxxx | 3800 | Analog Input function block 3 (AI) |
| ANALOG_INPUT_4_ xxxxxxxxxxxx | 4000 | Analog Input function block 4 (AI) |
| ANALOG_INPUT_5_ xxxxxxxxxxxx | 4200 | Analog Input function block 5 (AI) |
| ANALOG_INPUT_6_ xxxxxxxxxxxx | 4400 | Analog Input function block 6 (AI) |
| ANALOG_INPUT_7_ xxxxxxxxxxxx | 4600 | Analog Input function block 7 (AI) |
| ANALOG_INPUT_8_ xxxxxxxxxxxx | 4800 | Analog Input function block 8 (AI) |
| MAO_ xxxxxxxxxxxx | 5000 | Multiple Analog Output block (MAO) |
| DIGITAL_INPUT_1_ xxxxxxxxxxxx | 5200 | Digital Input function block 1 (DI) |
| DIGITAL_INPUT_2_ xxxxxxxxxxxx | 5400 | Digital Input function block 2 (DI) |
| MDO_ xxxxxxxxxxxx | 5600 | Multiple Digital Output block (MDO) |
| PID_ xxxxxxxxxxxx | 5800 | PID function block (PID) |
| INTEGRATOR_ xxxxxxxxxxxx | 6000 | Integrator function block (INTG) |

9.2.2 Description of the modules

The input value of a module/function block is defined via the CHANNEL parameter.

AI module (Analog Input)

Eight Analog Input blocks are available.

| CHANNEL | Measured variable |
|---------|-------------------------------------|
| 0 | Uninitialized (factory setting) |
| 7 | Temperature |
| 9 | Volume flow |
| 10 | Concentration ¹⁾ |
| 11 | Mass flow |
| 13 | Corrected volume flow |
| 14 | Density |
| 15 | Reference density |
| 16 | Totalizer 1 |
| 17 | Totalizer 2 |
| 18 | Totalizer 3 |
| 33 | Oscillation frequency ¹⁾ |

| CHANNEL | Measured variable |
|---------|--|
| 43 | Frequency fluctuation ¹⁾ |
| 51 | Carrier pipe temperature ¹⁾ |
| 57 | Carrier mass flow ¹⁾ |
| 58 | Target mass flow ¹⁾ |
| 63 | Oscillation damping ¹⁾ |
| 65 | Electronic temperature |
| 66 | Tube damping fluctuation ¹⁾ |
| 68 | Exciter current ¹⁾ |
| 81 | HBSI ¹⁾ |
| 99 | Current input 1 ¹⁾ |

1) Visible depending on the order options or device settings

MAO module (Multiple Analog Output)

| Channel | Description |
|---------|-------------|
| 121 | Channel_0 |

Structure

| Channel_0 | | | | | | | |
|-----------|---------|---------|---------|---------|---------|---------|---------|
| Value 1 | Value 2 | Value 3 | Value 4 | Value 5 | Value 6 | Value 7 | Value 8 |

| Values | Measured variable |
|---------|--|
| Value 1 | External pressure ¹⁾ |
| Value 2 | External temperature ¹⁾ |
| Value 3 | External reference density ¹⁾ |
| Value 4 | Not assigned |
| Value 5 | Not assigned |
| Value 6 | Not assigned |
| Value 7 | Not assigned |
| Value 8 | Not assigned |

1) The external measured values must be transmitted to the device in the SI basic unit



The selection is made via: Expert → Sensor → External compensation

DI module (Discrete Input)

Two Discrete Input blocks are available.

| CHANNEL | Device function | Status |
|---------|---------------------------------|---------------------|
| 0 | Uninitialized (factory setting) | – |
| 101 | Switch output state | 0 = off, 1 = active |
| 103 | Low flow cut off | 0 = off, 1 = active |

| CHANNEL | Device function | Status |
|---------|-----------------------------------|--|
| 104 | Empty pipe detection | 0 = off, 1 = active |
| 105 | Verification status ¹⁾ | Overall result of verification Verification: <ul style="list-style-type: none"> ■ 16 = Failed ■ 32 = Passed ■ 64 = Not performed Verification status Verification: <ul style="list-style-type: none"> ■ 1 = Not performed ■ 2 = Failed ■ 4 = Being performed ■ 8 = Finished Status; result <ul style="list-style-type: none"> ■ 17 = Status: not performed; Result: failed ■ 18 = Status: failed; Result: failed ■ 20 = Status: being performed; Result: failed ■ 24 = Status: finished; Result: failed ■ 33 = Status: not performed; Result: passed ■ 34 = Status: failed; Result: passed ■ 36 = Status: being performed; Result: passed ■ 40 = Status: finished; Result: passed ■ 65 = Status: not performed; Result: not performed ■ 66 = Status: failed; Result: not performed ■ 68 = Status: being performed; Result: not performed ■ 72 = Status: finished; Result: not performed |

1) Only available with the Heartbeat Verification application package

MDO module (Multiple Discrete Output)

| Channel | Description |
|---------|-------------|
| 122 | Channel_DO |

Structure

| Channel_DO | | | | | | | |
|------------|---------|---------|---------|---------|---------|---------|---------|
| Value 1 | Value 2 | Value 3 | Value 4 | Value 5 | Value 6 | Value 7 | Value 8 |

| Value | Device function | Status |
|---------|--|----------------------|
| Value 1 | Reset totalizer 1 | 0 = off, 1 = execute |
| Value 2 | Reset totalizer 2 | 0 = off, 1 = execute |
| Value 3 | Reset totalizer 3 | 0 = off, 1 = execute |
| Value 4 | Flow override | 0 = off, 1 = active |
| Value 5 | Start Heartbeat Verification ¹⁾ | 0 = off, 1 = start |
| Value 6 | Status output | 0 = off, 1 = active |



| Value | Device function | Status |
|---------|-----------------|-----------------|
| Value 7 | Zero adjustment | 0 = off, 1 = on |
| Value 8 | Not used | – |

1) Only available with the Heartbeat Verification application package

9.2.3 Execution times

| Function block | Execution time (ms) |
|-------------------------------------|---------------------|
| Analog Input function block (AI) | 6 |
| Digital Input function block (DI) | 4 |
| PID function block (PID) | 5 |
| Multiple Analog Output block (MAO) | 4 |
| Multiple Digital Output block (MDO) | 4 |
| Integrator function block (INTG) | 5 |

9.2.4 Methods

| Method | Block | Navigation | Description |
|---|-----------------------------|--|--|
| Set to "AUTO" mode | Resource block | Via menu: Expert → Communication → Resource block → Target mode | This method sets the Resource Block and all the Transducer Blocks to the AUTO (Automatic) mode. |
| Set to "OOS" mode | Resource block | Via menu: Expert → Communication → Resource block → Target mode | This method sets the Resource Block and all the Transducer Blocks to the OOS (Out of service) mode. |
| Restart | Resource block | Via menu: Expert → Communication → Resource block → Restart | This method is used to select the configuration for the Restart parameter in the Resource Block. This resets device parameters to a specific value. The following options are supported: <ul style="list-style-type: none"> ■ Uninitialized ■ Run ■ Resource ■ Defaults ■ Processor ■ To delivery settings |
| ENP parameter | Resource block | Via menu: Actions → Methods → Calibrate → ENP parameter | This method is used to display and configure the parameters of the electronic nameplate (ENP). |
| Overview diagnostics - Remedy information | Diagnostic Transducer Block | Via link: Namur symbol | This method is used to display the diagnostic event with the highest priority that is currently active and the corresponding remedial measures. |
| Actual diagnostics - Remedy information | Diagnostic Transducer Block | Via menu: <ul style="list-style-type: none"> ■ Configure/Setup → Diagnostics → Actual diagnostics ■ Device/Diagnostics → Diagnostics | This method is used to display remedial measures for the diagnostic event with the highest priority that is currently active.  This method is available only if an appropriate diagnostic event has occurred. |
| Previous diagnostics - Remedy information | Diagnostic Transducer Block | Via menu: <ul style="list-style-type: none"> ■ Configure/Setup → Diagnostics → Previous diagnostics ■ Device/Diagnostics → Diagnostics | This method is used to display remedial measures for the previous diagnostic event.  This method is available only if an appropriate diagnostic event has occurred. |

10 Commissioning

10.1 Post-installation and post-connection check

Before commissioning the device:

- ▶ Make sure that the post-installation and post-connection checks have been performed successfully.
- Checklist for "Post-installation" check → 34
- Checklist for "Post-connection" check → 59

10.2 Switching on the measuring instrument

- ▶ Switch on the device upon successful completion of the post-mounting and post-connection check.
 - ↳ After a successful startup, the local display switches automatically from the startup display to the operational display.


If nothing appears on the local display or if a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" → 160.

10.3 Connecting via FieldCare

- For connecting FieldCare → 81
- For connecting via FieldCare
- For user interface of FieldCare

10.4 Setting the operating language

Factory setting: English or ordered local language




36 Taking the example of the local display

A0029420

10.5 Configuring the device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.



37 Navigation to the "Setup" menu using the example of the local display


i The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

| Setup | | |
|-----------------------------------|---|-----|
| Device tag | → | 94 |
| ▶ System units | → | 94 |
| ▶ Medium selection | → | 97 |
| ▶ Analog inputs | → | 99 |
| ▶ I/O configuration | → | 99 |
| ▶ Current input 1 | → | 100 |
| ▶ Status input 1 | → | 101 |
| ▶ Current output 1 | → | 102 |
| ▶ Pulse/frequency/switch output 1 | → | 105 |
| ▶ Relay output 1 | → | 111 |

| | |
|-----------------------------------|---------|
| ► Display | → ⓘ 113 |
| ► Low flow cut off | → ⓘ 116 |
| ► Partially filled pipe detection | → ⓘ 117 |
| ► Advanced setup | → ⓘ 118 |

10.5.1 Defining the device tag

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



A0029422

38 Header of the operational display with tag name

1 Tag name

i Enter the tag name in the "FieldCare" operating tool

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

| Parameter | Description | User entry |
|------------|---|---|
| Device tag | Enter the name for the measuring point. | Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /) |

10.5.2 Setting the system units









In the **System units** submenu the units of all the measured values can be set.

i The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").


Navigation

"Setup" menu → System units

| | |
|----------------|--------|
| ► System units | |
| Mass flow unit | → ⓘ 95 |
| Mass unit | → ⓘ 95 |

| | |
|----------------------------|--|
| Volume flow unit | →  95 |
| Volume unit | →  95 |
| Corrected volume flow unit | →  95 |
| Corrected volume unit | →  95 |
| Density unit | →  96 |
| Reference density unit | →  95 |
| Temperature unit | →  96 |
| Pressure unit | →  96 |

Parameter overview with brief description

| Parameter | Description | Selection | Factory setting |
|----------------------------|---|------------------|--|
| Mass flow unit | Select mass flow unit. <i>Effect</i> The selected unit applies to: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg/h lb/min |
| Mass unit | Select mass unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg lb |
| Volume flow unit | Select volume flow unit. <i>Effect</i> The selected unit applies to: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable | Unit choose list | Country-specific: <ul style="list-style-type: none"> l/h gal/min (us) |
| Volume unit | Select volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> l (DN > 150 (6"): m³ option) gal (us) |
| Corrected volume flow unit | Select corrected volume flow unit. <i>Effect</i> The selected unit applies to: Corrected volume flow parameter (→  144) | Unit choose list | Country-specific: <ul style="list-style-type: none"> NI/h Sft³/min |
| Corrected volume unit | Select corrected volume unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> NI Sft³ |
| Reference density unit | Select reference density unit. | Unit choose list | Country-specific <ul style="list-style-type: none"> kg/NI lb/Sft³ |

| Parameter | Description | Selection | Factory setting |
|------------------|---|------------------|--|
| Density unit | Select density unit. <i>Effect</i> The selected unit applies to: <ul style="list-style-type: none"> Output Simulation process variable Density adjustment (Expert menu) | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg/l lb/ft³ |
| Density 2 unit | Select second density unit. | Unit choose list | Country-specific: <ul style="list-style-type: none"> kg/l lb/ft³ |
| Temperature unit | Select temperature unit. <i>Effect</i> The selected unit applies to: <ul style="list-style-type: none"> Electronic temperature parameter (6053) Maximum value parameter (6051) Minimum value parameter (6052) Maximum value parameter (6108) Minimum value parameter (6109) Carrier pipe temperature parameter (6027) Maximum value parameter (6029) Minimum value parameter (6030) Reference temperature parameter (1816) Temperature parameter | Unit choose list | Country-specific: <ul style="list-style-type: none"> °C °F |
| Pressure unit | Select process pressure unit. <i>Effect</i> The unit is taken from: <ul style="list-style-type: none"> Pressure value parameter (→ ⓘ 98) External pressure parameter (→ ⓘ 98) Pressure value | Unit choose list | Country-specific: <ul style="list-style-type: none"> bar a psi a |

10.5.3 Selecting and setting the medium

The **Select medium** wizard submenu contains parameters that must be configured in order to select and set the medium.

Navigation

"Setup" menu → Medium selection

| ► Medium selection | |
|--|------|
| Select medium | → 97 |
| Select gas type | → 97 |
| Reference sound velocity | → 98 |
| Temperature coefficient sound velocity | → 98 |
| Pressure compensation | → 98 |
| Pressure value | → 98 |
| External pressure | → 98 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry / User interface |
|-----------------|--|--|--|
| Select medium | – | Use this function to select the type of medium: "Gas" or "Liquid". Select the "Other" option in exceptional cases in order to enter the properties of the medium manually (e.g. for highly compressive liquids such as sulfuric acid). | <ul style="list-style-type: none"> ■ Liquid ■ Gas |
| Select gas type | In the Medium selection submenu, the Gas option is selected. | Select measured gas type. | <ul style="list-style-type: none"> ■ Air ■ Ammonia NH₃ ■ Argon Ar ■ Sulfur hexafluoride SF₆ ■ Oxygen O₂ ■ Ozone O₃ ■ Nitrogen oxide NO_x ■ Nitrogen N₂ ■ Nitrous oxide N₂O ■ Methane CH₄ ■ Hydrogen H₂ ■ Helium He ■ Hydrogen chloride HCl ■ Hydrogen sulfide H₂S ■ Ethylene C₂H₄ ■ Carbon dioxide CO₂ ■ Carbon monoxide CO ■ Chlorine Cl₂ ■ Butane C₄H₁₀ ■ Propane C₃H₈ ■ Propylene C₃H₆ ■ Ethane C₂H₆ ■ Others |

| Parameter | Prerequisite | Description | Selection / User entry / User interface |
|--|---|--|---|
| Reference sound velocity | In the Select gas type parameter, the Others option is selected. | Enter sound velocity of gas at 0 °C (32 °F). | 1 to 99 999.9999 m/s |
| Reference sound velocity | In the Select medium type parameter, the Others option is selected. | Enter sound velocity of gas at 0 °C (32 °F). | Signed floating-point number |
| Temperature coefficient sound velocity | In the Select gas type parameter, the Others option is selected. | Enter temperature coefficient for the gas sound velocity. | Positive floating point number |
| Temperature coefficient sound velocity | In the Select medium type parameter, the Others option is selected. | Enter temperature coefficient for the gas sound velocity. | Signed floating-point number |
| Pressure compensation | – | Select pressure compensation type. | <ul style="list-style-type: none"> ■ Off ■ Fixed value ■ External value ■ Current input 1 * |
| Pressure value | In the Pressure compensation parameter, the Fixed value option is selected. | Enter process pressure to be used for pressure correction. | Positive floating-point number |
| External pressure | In the Pressure compensation parameter, the External value option or the Current input 1...n option is selected. | Shows the external process pressure value. | |

* Visibility depends on order options or device settings

10.5.4 Configuring the analog inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

Navigation

"Setup" menu → Analog inputs

► Analog inputs

Parameter overview with brief description

| Parameter | Description | User entry / Selection | Factory setting |
|---------------------------|--|---|------------------------------------|
| Block tag | Unique name of the measuring device. | Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /). | ANALOG_INPUT_1 ... 4_Serial number |
| Channel | Use this function to select the process variable. | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Target mass flow * ■ Carrier mass flow * ■ Density ■ Reference density ■ Concentration * ■ Temperature ■ Electronic temperature ■ Oscillation frequency 0 ■ Oscillation amplitude 0 ■ Frequency fluctuation 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 ■ Signal asymmetry ■ Exciter current 0 ■ HBSI * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Current input 1 * ■ Uninitialized | – |
| Process Value Filter Time | Enter the filter time specification for the filtering of the unconverted input value (PV). | Positive floating-point number | – |

* Visibility depends on order options or device settings

10.5.5 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu → I/O configuration

► I/O configuration

I/O module 1 to n terminal numbers

→ 100

| | |
|-------------------------------|---------|
| I/O module 1 to n information | → ⓘ 100 |
| I/O module 1 to n type | → ⓘ 100 |
| Apply I/O configuration | → ⓘ 100 |
| Conversion code | → ⓘ 100 |

Parameter overview with brief description

| Parameter | Description | User interface / Selection / User entry |
|-----------------------------|---|--|
| I/O module terminal numbers | Shows the terminal numbers used by the I/O module. | <ul style="list-style-type: none">▪ Not used▪ 26-27 (I/O 1)▪ 24-25 (I/O 2) |
| I/O module information | Shows information of the plugged I/O module. | <ul style="list-style-type: none">▪ Not plugged▪ Invalid▪ Not configurable▪ Configurable▪ Fieldbus |
| I/O module type | Shows the I/O module type. | <ul style="list-style-type: none">▪ Off▪ Current output▪ Current input▪ Status input▪ Pulse/frequency/switch output▪ Double pulse output▪ Relay output |
| Apply I/O configuration | Apply parameterization of the freely configurable I/O module. | <ul style="list-style-type: none">▪ No▪ Yes |
| Conversion code | Enter the code in order to change the I/O configuration. | Positive integer |





10.5.6 Configuring the current input

The "Current input" wizard guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation

"Setup" menu → Current input

| | |
|------------------------|---------|
| ► Current input 1 to n | |
| Current span | → ⓘ 101 |
| Terminal number | → ⓘ 101 |
| Signal mode | → ⓘ 101 |
| Terminal number | → ⓘ 101 |
| 0/4 mA value | → ⓘ 101 |
| 20 mA value | → ⓘ 101 |

| | |
|-----------------|---|
| Failure mode | →  101 |
| Terminal number | →  101 |
| Failure value | →  101 |
| Terminal number | →  101 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-----------------|---|---|---|---|
| Current span | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ■ 4...20 mA ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 0...20 mA | – |
| Terminal number | – | Shows the terminal numbers used by the current input module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 20-21 (I/O 4) * | – |
| Signal mode | The measuring device is not approved for use in the hazardous area with type of protection Ex-i. | Select the signal mode for the current input. | <ul style="list-style-type: none"> ■ Passive ■ Active | Active |
| 0/4 mA value | – | Enter 4 mA value. | Signed floating-point number | – |
| 20 mA value | – | Enter 20 mA value. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | – | Define input behavior in alarm condition. | <ul style="list-style-type: none"> ■ Alarm ■ Last valid value ■ Defined value | – |
| Failure value | In the Failure mode parameter, the Defined value option is selected. | Enter value to be used by the device if input value from external device is missing. | Signed floating-point number | – |




* Visibility depends on order options or device settings

10.5.7 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu → Status input 1 to n

| | |
|-----------------------|---|
| ► Status input 1 to n | |
| Assign status input | →  102 |
| Terminal number | →  102 |
| Active level | →  102 |

| | |
|----------------------------|-------|
| Terminal number | → 102 |
| Response time status input | → 102 |
| Terminal number | → 102 |

Parameter overview with brief description

| Parameter | Description | Selection / User interface / User entry |
|----------------------------|---|--|
| Assign status input | Select function for the status input. | <ul style="list-style-type: none">OffReset totalizer 1Reset totalizer 2Reset totalizer 3Reset all totalizersFlow override |
| Terminal number | Shows the terminal numbers used by the status input module. | <ul style="list-style-type: none">Not used24-25 (I/O 2)20-21 (I/O 4) * |
| Active level | Define input signal level at which the assigned function is triggered. | <ul style="list-style-type: none">HighLow |
| Response time status input | Define the minimum amount of time the input signal level must be present before the selected function is triggered. | 5 to 200 ms |









* Visibility depends on order options or device settings







10.5.8 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation








"Setup" menu → Current output

| | |
|------------------------------|---|
| ► Current output 1 to n | |
| Assign current output 1 to n | →  103 |
| Terminal number | →  103 |
| Current span | →  103 |
| Terminal number | →  103 |
| Signal mode | →  103 |
| Terminal number | →  103 |
| 0/4 mA value | →  104 |
| 20 mA value | →  104 |

| | |
|-----------------|---|
| Fixed current | →  104 |
| Terminal number | →  103 |
| Failure mode | →  104 |
| Terminal number | →  103 |
| Failure current | →  104 |
| Terminal number | →  103 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------------|--------------|---|---|---|
| Terminal number | – | Shows the terminal numbers used by the current output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 20-21 (I/O 4) * | – |
| Signal mode | – | Select the signal mode for the current output. | <ul style="list-style-type: none"> ■ Passive ■ Active | Active |
| Assign current output | – | Select process variable for current output. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Target mass flow * ■ Carrier mass flow * ■ Density ■ Reference density ■ Concentration * ■ Temperature ■ Electronic temperature ■ Oscillation frequency 0 ■ Oscillation amplitude 0 * ■ Frequency fluctuation 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 ■ Signal asymmetry ■ Exciter current 0 ■ HBSI * | – |
| Current span | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA ■ 0...20 mA ■ Fixed current | Depends on country: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US |

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------|--|--|---|---|
| 0/4 mA value | In Current span parameter (→  103), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA ■ 0...20 mA | Enter 4 mA value. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> ■ 0 kg/h ■ 0 lb/min |
| 20 mA value | In Current span parameter (→  103), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA ■ 0...20 mA | Enter 20 mA value. | Signed floating-point number | Depends on country and nominal diameter |
| Fixed current | The Fixed current option is selected in the Current span parameter (→  103). | Defines the fixed output current. | 0 to 22.5 mA | 22.5 mA |
| Damping output | A process variable is selected in the Assign current output parameter (→  103) and one of the following options is selected in the Current span parameter (→  103): <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA ■ 0...20 mA | Set reaction time for output signal to fluctuations in the measured value. | 0.0 to 999.9 s | – |
| Failure mode | A process variable is selected in the Assign current output parameter (→  103) and one of the following options is selected in the Current span parameter (→  103): <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA ■ 0...20 mA | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ■ Min. ■ Max. ■ Last valid value ■ Actual value ■ Defined value | – |
| Failure current | The Defined value option is selected in the Failure mode parameter. | Enter current output value in alarm condition. | 0 to 22.5 mA | 22.5 mA |

* Visibility depends on order options or device settings

10.5.9 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu → Advanced setup → Pulse/frequency/switch output

► Pulse/frequency/switch output
1 to n

Operating mode

→ 105

Parameter overview with brief description

| Parameter | Description | Selection |
|----------------|---|---|
| Operating mode | Define the output as a pulse, frequency or switch output. | <div>■ Pulse</div> <div>■ Frequency</div> <div>■ Switch</div> |

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/frequency/switch output
1 to n

Operating mode

Terminal number

Signal mode

Assign pulse output

Pulse scaling

Pulse width

Failure mode

Invert output signal

→ 106

→ 106

→ 106

→ 106

→ 106

→ 106

→ 106

→ 106

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|----------------------------|--|---|---|---|
| Operating mode | – | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | – |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 20-21 (I/O 4) * | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ■ Passive ■ Active | – |
| Assign pulse output 1 to n | The Pulse option is selected in the Operating mode parameter. | Select process variable for pulse output. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Target mass flow * ■ Carrier mass flow * | – |
| Value per pulse | The Pulse option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign pulse output parameter (→ 106). | Enter measured value at which a pulse is output. | Positive floating point number | Depends on country and nominal diameter |
| Pulse width | The Pulse option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign pulse output parameter (→ 106). | Define time width of the output pulse. | 0.05 to 2 000 ms | – |
| Failure mode | The Pulse option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign pulse output parameter (→ 106). | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ■ Actual value ■ No pulses | – |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ■ No ■ Yes | – |

* Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu → Pulse/frequency/switch output

▶ Pulse/frequency/switch output
1 to n

Operating mode









→ 107

Terminal number


→ 107

Signal mode

→ 107

| | |
|--------------------------------------|---|
| Assign frequency output | →  107 |
| Minimum frequency value | →  108 |
| Maximum frequency value | →  108 |
| Measuring value at minimum frequency | →  108 |
| Measuring value at maximum frequency | →  108 |
| Failure mode | →  108 |
| Failure frequency | →  108 |
| Invert output signal | →  108 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-------------------------|---|---|---|-----------------|
| Operating mode | – | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | – |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 20-21 (I/O 4) * | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ■ Passive ■ Active | – |
| Assign frequency output | The Frequency option is selected in Operating mode parameter (→  105). | Select process variable for frequency output. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow * ■ Density ■ Reference density * ■ Temperature ■ Concentration * ■ Target mass flow * ■ Carrier mass flow * ■ HBSI * ■ Exciter current 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 * ■ Oscillation frequency 0 ■ Frequency fluctuation 0 * ■ Oscillation amplitude 0 * ■ Signal asymmetry ■ Electronic temperature | – |















| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|--------------------------------------|---|--|---|---|
| Minimum frequency value | The Frequency option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign frequency output parameter (→ 107). | Enter minimum frequency. | 0.0 to 10 000.0 Hz | – |
| Maximum frequency value | The Frequency option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign frequency output parameter (→ 107). | Enter maximum frequency. | 0.0 to 10 000.0 Hz | – |
| Measuring value at minimum frequency | The Frequency option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign frequency output parameter (→ 107). | Enter measured value for minimum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Measuring value at maximum frequency | The Frequency option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign frequency output parameter (→ 107). | Enter measured value for maximum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | The Frequency option is selected in the Operating mode parameter (→ 105) and a process variable is selected in the Assign frequency output parameter (→ 107). | Define output behavior in alarm condition. | <ul style="list-style-type: none"> ■ Actual value ■ Defined value ■ 0 Hz | – |
| Failure frequency | In the Operating mode parameter (→ 105), the Frequency option is selected, in the Assign frequency output parameter (→ 107) a process variable is selected, and in the Failure mode parameter, the Defined value option is selected. | Enter frequency output value in alarm condition. | 0.0 to 12 500.0 Hz | – |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ■ No ■ Yes | – |

* Visibility depends on order options or device settings

Configuring the switch output

Navigation

"Setup" menu → Pulse/frequency/switch output

| ► Pulse/frequency/switch output 1 to n | | |
|---|---|-----|
| Operating mode | →  | 109 |
| Terminal number | →  | 109 |
| Signal mode | →  | 109 |
| Switch output function | →  | 110 |
| Assign diagnostic behavior | →  | 110 |
| Assign limit | →  | 110 |
| Assign flow direction check | →  | 110 |
| Assign status | →  | 110 |
| Switch-on value | →  | 110 |
| Switch-off value | →  | 110 |
| Switch-on delay | →  | 110 |
| Switch-off delay | →  | 111 |
| Failure mode | →  | 111 |
| Invert output signal | →  | 111 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-----------------|--------------|---|--|-----------------|
| Operating mode | – | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | – |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 20-21 (I/O 4) * | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ■ Passive ■ Active | – |

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-----------------------------|---|--|--|--|
| Switch output function | The Switch option is selected in the Operating mode parameter. | Select function for switch output. | <ul style="list-style-type: none"> Off On Diagnostic behavior Limit Flow direction check Status | – |
| Assign diagnostic behavior | <ul style="list-style-type: none"> In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. | Select diagnostic behavior for switch output. | <ul style="list-style-type: none"> Alarm Alarm or warning Warning | – |
| Assign limit | <ul style="list-style-type: none"> The Switch option is selected in Operating mode parameter. The Limit option is selected in Switch output function parameter. | Select process variable for limit function. | <ul style="list-style-type: none"> Mass flow Volume flow Corrected volume flow Target mass flow * Carrier mass flow * Density Reference density Concentration * Temperature Totalizer 1 Totalizer 2 Totalizer 3 Oscillation damping | – |
| Assign flow direction check | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. | Select process variable for flow direction monitoring. | | – |
| Assign status | <ul style="list-style-type: none"> The Switch option is selected in Operating mode parameter. The Status option is selected in Switch output function parameter. | Select device status for switch output. | <ul style="list-style-type: none"> Partially filled pipe detection Low flow cut off Digital output 6 | – |
| Switch-on value | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. | Enter measured value for the switch-on point. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> 0 kg/h 0 lb/min |
| Switch-off value | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. | Enter measured value for the switch-off point. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> 0 kg/h 0 lb/min |
| Switch-on delay | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. | Define delay for the switch-on of status output. | 0.0 to 100.0 s | – |

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|----------------------|---|---|---|-----------------|
| Switch-off delay | <ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. | Define delay for the switch-off of status output. | 0.0 to 100.0 s | – |
| Failure mode | – | Define output behavior in alarm condition. | <ul style="list-style-type: none"> Actual status Open Closed | – |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> No Yes | – |

* Visibility depends on order options or device settings

10.5.10 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu → Relay output 1 to n

► Relay output 1 to n

Terminal number

→ 112

Relay output function

→ 112

Assign flow direction check

→ 112

Assign limit

→ 112

Assign diagnostic behavior

→ 112

Assign status

→ 112

Switch-off value

→ 112

Switch-off delay

→ 112

Switch-on value

→ 112

Switch-on delay

→ 112

Failure mode

→ 112

Switch status

→ 112

Powerless relay status

→ 112

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------------------|---|---|--|--|
| Terminal number | – | Shows the terminal numbers used by the relay output module. | <ul style="list-style-type: none"> Not used 24-25 (I/O 2) | – |
| Relay output function | – | Select the function for the relay output. | <ul style="list-style-type: none"> Closed Open Diagnostic behavior Limit Flow direction check Digital Output | – |
| Assign flow direction check | The Flow direction check option is selected in the Relay output function parameter. | Select process variable for flow direction monitoring. | | – |
| Assign limit | The Limit option is selected in the Relay output function parameter. | Select process variable for limit function. | <ul style="list-style-type: none"> Mass flow Volume flow Corrected volume flow Target mass flow[*] Carrier mass flow[*] Density Reference density[*] Concentration[*] Temperature Totalizer 1 Totalizer 2 Totalizer 3 Oscillation damping | – |
| Assign diagnostic behavior | In the Relay output function parameter, the Diagnostic behavior option is selected. | Select diagnostic behavior for switch output. | <ul style="list-style-type: none"> Alarm Alarm or warning Warning | – |
| Assign status | In the Relay output function parameter, the Digital Output option is selected. | Select device status for switch output. | <ul style="list-style-type: none"> Partially filled pipe detection Low flow cut off Digital output 6 | – |
| Switch-off value | The Limit option is selected in the Relay output function parameter. | Enter measured value for the switch-off point. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> 0 kg/h 0 lb/min |
| Switch-off delay | In the Relay output function parameter, the Limit option is selected. | Define delay for the switch-off of status output. | 0.0 to 100.0 s | – |
| Switch-on value | The Limit option is selected in the Relay output function parameter. | Enter measured value for the switch-on point. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> 0 kg/h 0 lb/min |
| Switch-on delay | In the Relay output function parameter, the Limit option is selected. | Define delay for the switch-on of status output. | 0.0 to 100.0 s | – |
| Failure mode | – | Define output behavior in alarm condition. | <ul style="list-style-type: none"> Actual status Open Closed | – |
| Switch status | – | Shows the current relay switch status. | <ul style="list-style-type: none"> Open Closed | – |
| Powerless relay status | – | | <ul style="list-style-type: none"> Open Closed | – |










* Visibility depends on order options or device settings

10.5.11 Configuring the local display



The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.






Navigation

"Setup" menu → Display

| | | |
|-----------------------|---|---|
| ► Display | | |
| Format display | → |  114 |
| Value 1 display | → |  114 |
| 0% bargraph value 1 | → |  114 |
| 100% bargraph value 1 | → |  114 |
| Value 2 display | → |  114 |
| Value 3 display | → |  114 |
| 0% bargraph value 3 | → |  114 |
| 100% bargraph value 3 | → |  114 |
| Value 4 display | → |  115 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|---|---|---|--|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values | – |
| Value 1 display | A local display is provided. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow * ■ Density ■ Reference density * ■ Temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Concentration * ■ Target mass flow * ■ Carrier mass flow * ■ HBSI * ■ Exciter current 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 * ■ Oscillation frequency 0 ■ Frequency fluctuation 0 * ■ Oscillation amplitude 0 * ■ Signal asymmetry ■ Electronic temperature ■ Current output 1 ■ Current output 2 * ■ Current output 3 * ■ Current output 4 * | – |
| 0% bargraph value 1 | A local display is provided. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 kg/h ■ 0 lb/min |
| 100% bargraph value 1 | A local display is provided. | Enter 100% value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |
| Value 2 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Value 3 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| 0% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 kg/h ■ 0 lb/min |
| 100% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 100% value for bar graph display. | Signed floating-point number | – |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------|------------------------------|---|--|-----------------|
| Value 4 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Value 5 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Value 6 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Value 7 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Value 8 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |

* Visibility depends on order options or device settings

10.5.12 Configuring the low flow cut off


The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

Navigation


"Setup" menu → Low flow cut off

▶ Low flow cut off


Assign process variable

→  116


On value low flow cutoff

→  116




Off value low flow cutoff

→  116

Pressure shock suppression

→  116

Parameter overview with brief description





| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|----------------------------|---|--|--|---|
| Assign process variable | – | Select process variable for low flow cut off. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow | – |
| On value low flow cutoff | A process variable is selected in the Assign process variable parameter (→  116). | Enter on value for low flow cut off. | Positive floating-point number | Depends on country and nominal diameter |
| Off value low flow cutoff | A process variable is selected in the Assign process variable parameter (→  116). | Enter off value for low flow cut off. | 0 to 100.0 % | – |
| Pressure shock suppression | A process variable is selected in the Assign process variable parameter (→  116). | Enter time frame for signal suppression (= active pressure shock suppression). | 0 to 100 s | – |

10.5.13 Partially filled pipe detection




The **Partially filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

Navigation

"Setup" menu → Partially filled pipe detection

| | |
|--|---|
| ► Partially filled pipe detection | |
| Assign process variable | →  117 |
| Low value partial filled pipe detection | →  117 |
| High value partial filled pipe detection | →  117 |
| Response time part. filled pipe detect. | →  117 |


Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|--|---|--|---|---|
| Assign process variable | – | Select process variable for partially filled pipe detection. | <ul style="list-style-type: none"> ■ Off ■ Density ■ Reference density | Density |
| Low value partial filled pipe detection | A process variable is selected in the Assign process variable parameter (→  117). | Enter lower limit value for deactivating partialy filled pipe detection. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> ■ 200 kg/m³ ■ 12.5 lb/ft³ |
| High value partial filled pipe detection | A process variable is selected in the Assign process variable parameter (→  117). | Enter upper limit value for deactivating partialy filled pipe detection. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> ■ 6 000 kg/m³ ■ 374.6 lb/ft³ |
| Response time part. filled pipe detect. | A process variable is selected in the Assign process variable parameter (→  117). | Use this function to enter the minimum time (hold time) the signal must be present before diagnostic message S962 "Pipe only partly filled" is triggered in the event of a partially filled or empty measuring pipe. | 0 to 100 s | – |

10.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu



i The number of submenus and parameters can vary depending on the device version and the available application packages. These submenus and their parameters are explained in the Special Documentation for the device and not in Operating Instructions.

For detailed information on the parameter descriptions for application packages:
Special Documentation for the device → 242

Navigation

"Setup" menu → Advanced setup

| | | |
|---------------------|---|-----|
| ▶ Advanced setup | | |
| Enter access code | → | 119 |
| ▶ Calculated values | → | 119 |
| ▶ Sensor adjustment | → | 120 |

| | |
|------------------------|-------|
| ► Totalizer 1 to n | → 124 |
| ► Display | → 126 |
| ► Configuration backup | → 130 |
| ► Administration | → 131 |

10.6.1 Using the parameter to enter the access code

Navigation


"Setup" menu → Advanced setup

Parameter overview with brief description

| Parameter | Description | User entry |
|-------------------|--|---|
| Enter access code | Enter access code to disable write protection of parameters. | Max. 16-digit character string comprising numbers, letters and special characters |

10.6.2 Calculated process variables

The **Calculated values** submenu contains parameters for calculating the corrected volume flow.

 The **Calculated values** submenu is **not** available if one of the following options was selected in the **Petroleum mode** parameter in the "Application package", option **EJ "Petroleum": API referenced correction** option, **Net oil & water cut** option or **ASTM D4311** option

Navigation

"Setup" menu → Advanced setup → Calculated values




| | |
|-------------------------------------|-------|
| ► Calculated values | |
| ► Corrected volume flow calculation | → 119 |

"Corrected volume flow calculation" submenu

Navigation

"Setup" menu → Advanced setup → Calculated values → Corrected volume flow calculation

| | |
|--|-------|
| ► Corrected volume flow calculation | |
| Corrected volume flow calculation (1812) | → 120 |
| External reference density (6198) | → 120 |
| Fixed reference density (1814) | → 120 |

| | |
|-------------------------------------|---|
| Reference temperature (1816) | →  120 |
| Linear expansion coefficient (1817) | →  120 |
| Square expansion coefficient (1818) | →  120 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-----------------------------------|---|--|---|--|
| Corrected volume flow calculation | – | Select reference density for calculating the corrected volume flow. | <ul style="list-style-type: none"> Fixed reference density Calculated reference density Reference density by API table 53 External reference density Current input 1 * | – |
| External reference density | – | Shows external reference density. | Floating point number with sign | – |
| Fixed reference density | The Fixed reference density option is selected in the Corrected volume flow calculation parameter parameter. | Enter fixed value for reference density. | Positive floating-point number | – |
| Reference temperature | The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter. | Enter reference temperature for calculating the reference density. | –273.15 to 99 999 °C | Country-specific: <ul style="list-style-type: none"> +20 °C +68 °F |
| Linear expansion coefficient | The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter. | Enter linear, medium-specific expansion coefficient for calculating the reference density. | Signed floating-point number | – |
| Square expansion coefficient | The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter. | For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density. | Signed floating-point number | – |

* Visibility depends on order options or device settings

10.6.3 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment

| | |
|------------------------|---------|
| ► Sensor adjustment | |
| Installation direction | → ⓘ 121 |
| ► Zero verification | → ⓘ 121 |
| ► Zero adjustment | → ⓘ 123 |

Parameter overview with brief description


| Parameter | Description | Selection |
|------------------------|---|---|
| Installation direction | Set sign of flow direction to match the direction of the arrow on the sensor. | <ul style="list-style-type: none"> ■ Flow in arrow direction ■ Flow against arrow direction |

Zero verification and zero adjustment

All measuring instruments are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions → ⓘ 221. Therefore, a zero adjustment in the field is generally not required.

Experience shows that zero adjustment is advisable only in special cases:

- To achieve maximum measurement accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity media).
- For gas applications with low pressure.

 To achieve the highest possible measurement accuracy at low flow rates, the installation must protect the sensor from mechanical stress during operation.

To get a representative zero point, ensure that:

- any flow in the device is prevented during the adjustment
- the process conditions (e.g. pressure, temperature) are stable and representative

Zero verification and zero adjustment cannot be performed if the following process conditions are present:

- Gas pockets
Ensure that the system has been sufficiently flushed with the medium. Repeat flushing can help to eliminate gas pockets
- Thermal circulation
In the event of temperature differences (e.g. between the measuring tube inlet and outlet section), induced flow can occur even if the valves are closed due to thermal circulation in the device
- Leaks at the valves
If the valves are not leak-tight, flow is not sufficiently prevented when determining the zero point










If these conditions cannot be avoided, it is advisable to keep the factory setting for the zero point.

Zero point verification

The zero point can be verified with the **Zero verification** wizard.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment → Zero verification

| ► Zero verification | | |
|-------------------------------|---|---|
| Process conditions | → |  122 |
| Progress | → |  122 |
| Status | → |  122 |
| Additional information | → |  122 |
| Recommendation: | → |  122 |
| Root cause | → |  122 |
| Abort cause | → |  122 |
| Zero point measured | → |  123 |
| Zero point standard deviation | → |  123 |


Parameter overview with brief description

| Parameter | Description | Selection / User interface | Factory setting |
|------------------------------|---|--|-----------------|
| Process conditions | Ensure process conditions as follows. | <ul style="list-style-type: none"> ■ Tubes are completely filled ■ Process operational pressure applied ■ No-flow conditions (closed valves) ■ Process and ambient temperatures stable | – |
| Progress | Shows the progress of the process. | 0 to 100 % | – |
| Zero point adjustment status | | <ul style="list-style-type: none"> ■ Busy ■ Alarm ■ Ok | – |
| Additional information | Indicate whether to display additional information. | <ul style="list-style-type: none"> ■ Hide ■ Show | – |
| Recommendation: | Indicates whether an adjustment is recommended. Only recommended if the measured zero point deviates significantly from the current zero point. | <ul style="list-style-type: none"> ■ Do not adjust zero point ■ Adjust zero point | – |
| Abort cause | Indicates why the wizard was aborted. | <ul style="list-style-type: none"> ■ Check process conditions! ■ A technical issue has occurred | – |
| Root cause | Shows the diagnostic and remedy. | <ul style="list-style-type: none"> ■ Zero point too high. Ensure no-flow. ■ Zero point is unstable. Ensure no-flow. ■ Fluctuation high. Avoid 2-phase medium. | – |

| Parameter | Description | Selection / User interface | Factory setting |
|-------------------------------|--|--------------------------------|-----------------|
| Zero point measured | Shows the zero point measured for the adjustment. | Signed floating-point number | – |
| Zero point standard deviation | Shows the standard deviation of the zero point measured. | Positive floating-point number | – |













Zero adjust

The zero point can be adjusted with the **Zero adjustment** wizard.

- 
- A zero point verification should be performed before a zero adjustment.
 - The zero point can also be adjusted manually: Expert → Sensor → Calibration

Navigation

"Setup" menu → Advanced setup → Sensor adjustment → Zero adjustment

| ► Zero adjustment | | |
|------------------------------------|---|---|
| Process conditions | → |  124 |
| Progress | → |  124 |
| Status | → |  124 |
| Root cause | → |  124 |
| Abort cause | → |  124 |
| Root cause | → |  124 |
| Reliability of measured zero point | → |  124 |
| Additional information | → |  124 |
| Reliability of measured zero point | → |  124 |
| Zero point measured | → |  124 |
| Zero point standard deviation | → |  124 |
| Select action | → |  124 |

Parameter overview with brief description

| Parameter | Description | Selection / User interface | Factory setting |
|------------------------------------|--|---|-----------------|
| Process conditions | Ensure process conditions as follows. | <ul style="list-style-type: none">■ Tubes are completely filled■ Process operational pressure applied■ No-flow conditions (closed valves)■ Process and ambient temperatures stable | – |
| Progress | Shows the progress of the process. | 0 to 100 % | – |
| Zero point adjustment status | | <ul style="list-style-type: none">■ Busy■ Alarm■ Ok | – |
| Abort cause | Indicates why the wizard was aborted. | <ul style="list-style-type: none">■ Check process conditions!■ A technical issue has occurred | – |
| Root cause | Shows the diagnostic and remedy. | <ul style="list-style-type: none">■ Zero point too high. Ensure no-flow.■ Zero point is unstable. Ensure no-flow.■ Fluctuation high. Avoid 2-phase medium. | – |
| Reliability of measured zero point | Indicates the reliability of the zero point measured. | <ul style="list-style-type: none">■ Not done■ Good■ Uncertain | – |
| Additional information | Indicate whether to display additional information. | <ul style="list-style-type: none">■ Hide■ Show | – |
| Zero point measured | Shows the zero point measured for the adjustment. | Signed floating-point number | – |
| Zero point standard deviation | Shows the standard deviation of the zero point measured. | Positive floating-point number | – |
| Select action | Select the zero point value to apply. | <ul style="list-style-type: none">■ Keep current zero point■ Apply zero point measured■ Apply factory zero point* | – |

* Visibility depends on order options or device settings

10.6.4 Configuring the totalizer

In the "Totalizer 1 to n" submenu, you can configure the specific totalizer.

Navigation

"Setup" menu → Advanced setup → Totalizer 1 to n

► Totalizer 1 to n

Assign process variable

Unit totalizer 1 to n

Totalizer operation mode

Failure mode




→ 125

→ 125

→ 125

→ 125

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection | Factory setting |
|--------------------------|--|---|---|--|
| Assign process variable | – | Select process variable for totalizer. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow[*] ■ Target mass flow[*] ■ Carrier mass flow[*] | – |
| Unit totalizer 1 to n | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Select process variable totalizer unit. | Unit choose list | Depends on country: <ul style="list-style-type: none"> ■ kg ■ lb |
| Totalizer operation mode | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Select totalizer calculation mode. | <ul style="list-style-type: none"> ■ Net flow total ■ Forward flow total ■ Reverse flow total | – |
| Failure mode | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Define totalizer behavior in alarm condition. | <ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value | – |










* Visibility depends on order options or device settings

10.6.5 Carrying out additional display configurations


In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu → Advanced setup → Display

| | | |
|-----------------------|---|---|
| ► Display | | |
| Format display | → |  127 |
| Value 1 display | → |  127 |
| 0% bargraph value 1 | → |  127 |
| 100% bargraph value 1 | → |  127 |
| Decimal places 1 | → |  127 |
| Value 2 display | → |  127 |
| Decimal places 2 | → |  127 |
| Value 3 display | → |  128 |
| 0% bargraph value 3 | → |  128 |
| 100% bargraph value 3 | → |  128 |
| Decimal places 3 | → |  128 |
| Value 4 display | → |  128 |
| Decimal places 4 | → |  128 |
| Display language | → |  128 |
| Display interval | → |  128 |
| Display damping | → |  128 |
| Header | → |  128 |
| Header text | → |  128 |
| Separator | → |  129 |
| Backlight | → |  129 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|--|---|---|--|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values | – |
| Value 1 display | A local display is provided. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow * ■ Density ■ Reference density * ■ Temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Concentration * ■ Target mass flow * ■ Carrier mass flow * ■ HBSI * ■ Exciter current 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 * ■ Oscillation frequency 0 ■ Frequency fluctuation 0 * ■ Oscillation amplitude 0 * ■ Signal asymmetry ■ Electronic temperature ■ Current output 1 ■ Current output 2 * ■ Current output 3 * ■ Current output 4 * | – |
| 0% bargraph value 1 | A local display is provided. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: <ul style="list-style-type: none"> ■ 0 kg/h ■ 0 lb/min |
| 100% bargraph value 1 | A local display is provided. | Enter 100% value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |
| Decimal places 1 | A measured value is specified in the Value 1 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | – |
| Value 2 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→  114) | – |
| Decimal places 2 | A measured value is specified in the Value 2 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | – |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|---|---|--|---|
| Value 3 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 114) | – |
| 0% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 0% value for bar graph display. | Signed floating-point number | Country-specific: ■ 0 kg/h ■ 0 lb/min |
| 100% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 100% value for bar graph display. | Signed floating-point number | – |
| Decimal places 3 | A measured value is specified in the Value 3 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | – |
| Value 4 display | A local display is provided. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 114) | – |
| Decimal places 4 | A measured value is specified in the Value 4 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx | – |
| Display language | A local display is provided. | Set display language. | <ul style="list-style-type: none"> ■ English ■ Deutsch * ■ Français * ■ Español * ■ Italiano * ■ Nederlands * ■ Portuguesa * ■ Polski * ■ русский язык (Russian) * ■ Svenska * ■ Türkçe * ■ 中文 (Chinese) * ■ 日本語 (Japanese) * ■ 한국어 (Korean) * ■ tiếng Việt (Vietnamese) * ■ čeština (Czech) * | English (alternatively, the ordered language is preset in the device) |
| Display interval | A local display is provided. | Set time measured values are shown on display if display alternates between values. | 1 to 10 s | – |
| Display damping | A local display is provided. | Set display reaction time to fluctuations in the measured value. | 0.0 to 999.9 s | – |
| Header | A local display is provided. | Select header contents on local display. | <ul style="list-style-type: none"> ■ Device tag ■ Free text | – |
| Header text | The Free text option is selected in the Header parameter. | Enter display header text. | Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /) | – |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------|--|---|--|-----------------|
| Separator | A local display is provided. | Select decimal separator for displaying numerical values. | <ul style="list-style-type: none"> ■ . (point) ■ , (comma) | . (point) |
| Backlight | One of the following conditions is met: <ul style="list-style-type: none"> ■ Order code for "Display; operation", option F "4-line, illum.; touch control" ■ Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN" | Switch the local display backlight on and off. | <ul style="list-style-type: none"> ■ Disable ■ Enable | – |

* Visibility depends on order options or device settings

10.6.6 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu → Advanced setup → WLAN settings

▶ WLAN settings

WLAN IP address

Security type

WLAN passphrase

Assign SSID name

SSID name

Apply changes

→ ⓘ 129

→ ⓘ 129


→ ⓘ 129


→ ⓘ 130

→ ⓘ 130

→ ⓘ 130

Parameter overview with brief description

| Parameter | Prerequisite | Description | User entry / Selection | Factory setting |
|-----------------|---|--|--|--|
| WLAN IP address | – | Enter IP address of the device WLAN interface. | 4 octet: 0 to 255 (in the particular octet) | – |
| Security type | – | Select the security type of the WLAN interface. | <ul style="list-style-type: none"> ■ Unsecured ■ WPA2-PSK | – |
| WLAN passphrase | The WPA2-PSK option is selected in the Security type parameter. | Enter the network key (8 to 32 characters).  The network key supplied with the device should be changed during commissioning for security reasons. | 8 to 32-digit character string comprising numbers, letters and special characters (without spaces) | Serial number of the measuring device (e.g. L100A802000) |

| Parameter | Prerequisite | Description | User entry / Selection | Factory setting |
|------------------|--|--|--|---|
| Assign SSID name | – | Select which name will be used for SSID: device tag or user-defined name. | <ul style="list-style-type: none"> Device tag User-defined | – |
| SSID name | <ul style="list-style-type: none"> The User-defined option is selected in the Assign SSID name parameter. The WLAN access point option is selected in the WLAN mode parameter. | Enter the user-defined SSID name (max. 32 characters).  The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another. | Max. 32-digit character string comprising numbers, letters and special characters | EH_device designation_last 7 digits of the serial number (e.g. EH_Promass_500_A 802000) |
| Apply changes | – | Use changed WLAN settings. | <ul style="list-style-type: none"> Cancel Ok | – |

10.6.7 Configuration management

After commissioning, you can save the current device configuration or restore the previous device configuration. The device configuration is managed via the **Configuration management** parameter.

Navigation

"Setup" menu → Advanced setup → Configuration backup

| | |
|--------------------------|-------|
| ► Configuration backup | |
| Operating time | → 130 |
| Last backup | → 130 |
| Configuration management | → 130 |
| Backup state | → 131 |
| Comparison result | → 131 |

Parameter overview with brief description

| Parameter | Description | User interface / Selection |
|--------------------------|--|---|
| Operating time | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) |
| Last backup | Shows when the last data backup was saved to embedded HistoROM. | Days (d), hours (h), minutes (m) and seconds (s) |
| Configuration management | Select action for managing the device data in the embedded HistoROM. | <ul style="list-style-type: none"> Cancel Execute backup Restore Compare Clear backup data |

| Parameter | Description | User interface / Selection |
|-------------------|---|---|
| Backup state | Shows the current status of data saving or restoring. | <ul style="list-style-type: none"> ■ None ■ Backup in progress ■ Restoring in progress ■ Delete in progress ■ Compare in progress ■ Restoring failed ■ Backup failed |
| Comparison result | Comparison of current device data with embedded HistoROM. | <ul style="list-style-type: none"> ■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible |

Function range of "Configuration management" parameter

| Options | Description |
|-------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| Execute backup | A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device. |
| Restore | The last backup copy of the device configuration is restored from the display module from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device. |
| Compare | The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup. |
| Clear backup data | The backup copy of the device configuration is deleted from the memory of the device. |



HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.



While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.6.8 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu → Advanced setup → Administration

| | |
|----------------------|---------|
| ► Administration | |
| ► Define access code | → ⓘ 132 |
| ► Reset access code | → ⓘ 132 |
| Device reset | → ⓘ 133 |

Using the parameter to define the access code

Navigation

"Setup" menu → Advanced setup → Administration → Define access code

► Define access code

Define access code

→ 132

Confirm access code

→ 132

Parameter overview with brief description

| Parameter | Description | User entry |
|---------------------|---|---|
| Define access code | Restrict write-access to parameters to protect the configuration of the device against unintentional changes. | Max. 16-digit character string comprising numbers, letters and special characters |
| Confirm access code | Confirm the entered access code. | Max. 16-digit character string comprising numbers, letters and special characters |

Using the parameter to reset the access code

Navigation

"Setup" menu → Advanced setup → Administration → Reset access code

► Reset access code


Operating time

→ 132

Reset access code

→ 132

Parameter overview with brief description

| Parameter | Description | User interface / User entry |
|-------------------|--|---|
| Operating time | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) |
| Reset access code | <div>Reset access code to factory settings.</div> <div> For a reset code, contact your Endress+Hauser service organization.</div> <div>The reset code can only be entered via:</div> <div><ul style="list-style-type: none">▪ Web browser▪ DeviceCare, FieldCare (via CDI-RJ45 service interface)▪ Fieldbus</div> | Character string comprising numbers, letters and special characters |

Using the parameter to reset the device

Navigation

"Setup" menu → Advanced setup → Administration

Parameter overview with brief description

| Parameter | Description | Selection |
|--------------|---|---|
| Device reset | Reset the device configuration - either entirely or in part - to a defined state. | <ul style="list-style-type: none"> ■ Cancel ■ To delivery settings ■ Restart device ■ Restore S-DAT backup ■ ENP restart |

10.7 Simulation

Via the **Simulation** submenu, it is possible to simulate various process variables in the process and the device alarm mode and verify downstream signal chains (switching valves or closed-control loops). The simulation can be performed without a real measurement (no flow of medium through the device).

Activating and deactivating simulation mode via DIP switch

The following hardware settings can be made for the FOUNDATION Fieldbus via DIP switch 4 on the main electronics module:

- Enable/block simulation mode in the function blocks (e.g. **Analog Input** or **Discrete Output** function block)
- Simulation mode enabled (factory setting) = simulation in the **Analog Input** or **Discrete Output** function block possible
- Simulation mode blocked = simulation in the **Analog Input** or **Discrete Output** function block not possible


Proline 500 – digital

NOTICE

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- Tighten the fixing screws as per the tightening torque: 2.5 Nm (1.8 lbf ft)




A0046504

1. Open the housing cover.
2. Remove the display module.
3. Fold open the terminal cover.

4.
- Set the write protection switch (SIM) on the main electronics module to the **ON** position (factory setting):
↳ Simulation mode enabled.
5.
- Set the write protection switch (SIM) on the main electronics module to the **OFF** position:
↳ Simulation mode disabled.

Proline 500



- Set the write protection switch (SIM) on the main electronics module to the **ON** position (factory setting):
↳ Simulation mode enabled.
2.
- Set the write protection switch (SIM) on the main electronics module to the **OFF** position:
↳ Simulation mode disabled.

Navigation

"Diagnostics" menu → Simulation

► Simulation

Assign simulation process variable

→ 135

Process variable value

→ 135

Status input simulation

→ 136

Input signal level

→ 136

Current input 1 to n simulation

→ 136

Value current input 1 to n

→ 136

Current output 1 to n simulation

→ 135

Value current output 1 to n










→ 135

Frequency output simulation 1 to n




→ 135

Frequency value 1 to n

→ 135

| | |
|---------------------------------|---|
| Pulse output simulation 1 to n | →  135 |
| Pulse value 1 to n | →  135 |
| Switch output simulation 1 to n | →  136 |
| Switch status 1 to n | →  136 |
| Relay output 1 to n simulation | →  136 |
| Switch status 1 to n | →  136 |
| Device alarm simulation | →  136 |
| Diagnostic event category | →  136 |
| Diagnostic event simulation | →  136 |

Parameter overview with brief description





| Parameter | Prerequisite | Description | Selection / User entry |
|------------------------------------|--|--|---|
| Assign simulation process variable | – | Select a process variable for the simulation process that is activated. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Target mass flow * ■ Carrier mass flow * ■ Concentration * |
| Process variable value | A process variable is selected in the Assign simulation process variable parameter (→  135). | Enter the simulation value for the selected process variable. | Depends on the process variable selected |
| Current output simulation | – | Switch the simulation of the current output on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Value current output | In the Current output 1 to n simulation parameter, the On option is selected. | Enter the current value for simulation. | 3.59 to 22.5 mA |
| Frequency output simulation | In the Operating mode parameter, the Frequency option is selected. | Switch the simulation of the frequency output on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Frequency value | In the Frequency output simulation 1 to n parameter, the On option is selected. | Enter the frequency value for the simulation. | 0.0 to 12 500.0 Hz |
| Pulse output simulation | In the Operating mode parameter, the Pulse option is selected. | Set and switch off the pulse output simulation.  For Fixed value option: Pulse width parameter (→  106) defines the pulse width of the pulses output. | <ul style="list-style-type: none"> ■ Off ■ Fixed value ■ Down-counting value |
| Pulse value | In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected. | Enter the number of pulses for simulation. | 0 to 65 535 |

| Parameter | Prerequisite | Description | Selection / User entry |
|-----------------------------|---|---|---|
| Switch output simulation | In the Operating mode parameter, the Switch option is selected. | Switch the simulation of the switch output on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Switch status | – | Select the status of the status output for the simulation. | <ul style="list-style-type: none"> ■ Open ■ Closed |
| Relay output simulation | – | Switch simulation of the relay output on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Switch status | The On option is selected in the Switch output simulation 1 to n parameter parameter. | Select status of the relay output for the simulation. | <ul style="list-style-type: none"> ■ Open ■ Closed |
| Device alarm simulation | – | Switch the device alarm on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Diagnostic event category | – | Select a diagnostic event category. | <ul style="list-style-type: none"> ■ Sensor ■ Electronics ■ Configuration ■ Process |
| Diagnostic event simulation | – | Select a diagnostic event to simulate this event. | <ul style="list-style-type: none"> ■ Off ■ Diagnostic event picklist (depends on the category selected) |
| Current input simulation | – | Switch simulation of the current input on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Value current input | In the Current input 1 to n simulation parameter, the On option is selected. | Enter the current value for simulation. | 0 to 22.5 mA |
| Status input simulation | – | Switch simulation of the status input on and off. | <ul style="list-style-type: none"> ■ Off ■ On |
| Input signal level | In the Status input simulation parameter, the On option is selected. | Select the signal level for the simulation of the status input. | <ul style="list-style-type: none"> ■ High ■ Low |

* Visibility depends on order options or device settings

10.8 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:


- Protect access to parameters via access code →  136
- Protect access to local operation via key locking →  75
- Protect access to measuring device via write protection switch →  138
- Protect access to parameters via block operation →  140

10.8.1 Write protection via access code


The effects of the user-specific access code are as follows:





- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via the local display

1. Navigate to the **Define access code** parameter (→  132).
2. Maximum of 16-digit character string comprising numbers, letters and special characters as the access code.


3. Enter the access code again in the **Confirm access code** parameter (→  132) to confirm.

↳ The  symbol appears in front of all write-protected parameters.



- 
 - Disabling parameter write protection via access code →  74.
 - If the access code is lost: Resetting the access code →  137.
 - The user role with which the user is currently logged in is displayed in **Access status** parameter.
 - Navigation path: Operation → Access status
 - User roles and their access rights →  74
- The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view.
- The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

Parameters which can always be modified via the local display





Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the web browser

1. Navigate to the **Define access code** parameter (→  132).
2. Define a 16-digit (max.) numeric code as the access code.
3. Enter the access code again in the **Confirm access code** parameter (→  132) to confirm.

↳ The web browser switches to the login page.

- 
 - Disabling parameter write protection via access code →  74.
 - If the access code is lost: Resetting the access code →  137.
 - The **Access status** parameter shows which user role the user is currently logged in with.
 - Navigation path: Operation → Access status
 - User roles and their access rights →  74



If no action is performed for 10 minutes, the web browser automatically returns to the login page.

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

i You can only obtain a reset code from your local Endress+Hauser service organization. The code must be calculated explicitly for every device.

1. Note down the serial number of the device.
2. Read off the **Operating time** parameter.
3. Contact the local Endress+Hauser service organization and tell them the serial number and the operating time.
 - ↳ Get the calculated reset code.
4. Enter the reset code in the **Reset access code** parameter (→  132).
 - ↳ The access code has been reset to the factory setting **0000**. It can be redefined →  136.

i For IT security reasons, the calculated reset code is only valid for 96 hours from the specified operating time and for the specific serial number. If you cannot return to the device within 96 hours, you should either increase the operating time you read out by a few days or switch off the device.

10.8.2 Write protection via write protection switch


Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via FOUNDATION Fieldbus

Proline 500 – digital

Enable/disable write protection





A0029673

1. Open the housing cover.
2. Remove the display module.
3. Fold open the terminal cover.

4. Enable or disable write protection:

Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection/setting to **OFF** (factory setting) disables hardware write protection.

- In the **Locking status** parameter, the **Hardware locked** option is displayed
→ 141. When hardware write protection is enabled, the  symbol appears in the header of the measured value display and in the navigation view in front of the parameters.



A0029425

5. Insert the display module.

6. Close the housing cover.

7. NOTICE

Excessive tightening torque applied to the fixing screws!


Risk of damaging the plastic transmitter.

- ▶ Tighten the fixing screws as per the tightening torque: 2.5 Nm (1.8 lbf ft)

Tighten the fixing screws.


Proline 500


1.



A0029630


Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

- In the **Locking status** parameter, the **Hardware locked** option is displayed
→ 141. In addition, on the local display the  symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0029425

2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

- No option is displayed in the **Locking status** parameter → 141. On the local display, the  symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

10.8.3 Write protection via block operation

Locking via block operation:

- Block: **DISPLAY (TRDDISP)**; parameter: **Define access code**
- Block: **EXPERT_CONFIG (TRDEXP)**; parameter: **Enter access code**



11 Operation

11.1 Reading the device locking status

Device active write protection: **Locking status** parameter

Operation → Locking status



Function scope of the "Locking status" parameter

| Options | Description |
|--------------------|--|
| None | The access authorization displayed in the Access status parameter applies →  74. Only appears on local display. |
| Hardware locked | The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) →  138. |
| Temporarily locked | Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed again. |

11.2 Adjusting the operating language





Detailed information:

- To configure the operating language →  92
- For information on the operating languages supported by the measuring device →  233

11.3 Configuring the display

Detailed information:





- On the basic settings for the local display →  113
- On the advanced settings for the local display →  126

11.4 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu → Measured values





















| | |
|----------------------|---|
| ► Measured values | |
| ► Measured variables | →  142 |
| ► Input values | →  152 |
| ► Output values | →  154 |
| ► Totalizer | →  152 |

























11.4.1 "Measured variables" submenu

The **Measured variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation











"Diagnostics" menu → Measured values → Measured variables






| ► Measured variables | | |
|-------------------------------|---|---|
| Mass flow | → |  144 |
| Volume flow | → |  144 |
| Corrected volume flow | → |  144 |
| Density | → |  144 |
| Reference density | → |  144 |
| Temperature | → |  144 |
| Pressure | → |  144 |
| Concentration | → |  144 |
| Target mass flow | → |  145 |
| Carrier mass flow | → |  145 |
| Target corrected volume flow | → |  145 |
| Carrier corrected volume flow | → |  145 |
| Target volume flow | → |  145 |
| Carrier volume flow | → |  146 |
| CTL | → |  146 |
| CPL | → |  146 |
| CTPL | → |  146 |
| S&W volume flow | → |  147 |
| S&W correction value | → |  147 |
| Reference density alternative | → |  147 |




| | |
|------------------------------|---|
| GSV flow | →  147 |
| GSV flow alternative | →  147 |
| NSV flow | →  148 |
| NSV flow alternative | →  148 |
| Oil CTL | →  148 |
| Oil CPL | →  148 |
| Oil CTPL | →  148 |
| Water CTL | →  149 |
| CTL alternative | →  149 |
| CPL alternative | →  149 |
| CTPL alternative | →  149 |
| Oil reference density | →  149 |
| Water reference density | →  150 |
| Oil density | →  150 |
| Water density | →  150 |
| Water cut | →  150 |
| Oil volume flow | →  150 |
| Oil corrected volume flow | →  151 |
| Oil mass flow | →  151 |
| Water volume flow | →  151 |
| Water corrected volume flow | →  151 |
| Water mass flow | →  151 |
| Weighted density average | →  152 |
| Weighted temperature average | →  152 |






Parameter overview with brief description






| Parameter | Prerequisite | Description | User interface | Factory setting |
|-----------------------|--|---|------------------------------|-----------------|
| Mass flow | – | Displays the mass flow that is currently measured. <i>Dependency</i> The unit is taken from: Mass flow unit parameter (→  95) | Signed floating-point number | – |
| Volume flow | – | Displays the volume flow that is currently calculated. <i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  95). | Signed floating-point number | – |
| Corrected volume flow | – | Displays the corrected volume flow that is currently calculated. <i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter (→  95) | Signed floating-point number | – |
| Density | – | Shows the density currently measured. <i>Dependency</i> The unit is taken from the Density unit parameter (→  96). | Signed floating-point number | – |
| Reference density | – | Displays the reference density that is currently calculated. <i>Dependency</i> The unit is taken from: Reference density unit parameter (→  95) | Signed floating-point number | – |
| Temperature | – | Shows the medium temperature currently measured. <i>Dependency</i> The unit is taken from: Temperature unit parameter (→  96) | Signed floating-point number | – |
| Pressure value | – | Displays either a fixed or external pressure value. <i>Dependency</i> The unit is taken from the Pressure unit parameter (→  96). | Signed floating-point number | – |
| Concentration | For the following order code: Order code for "Application package", option ED "Concentration"  The software options currently enabled are displayed in the Software option overview parameter. | Displays the concentration that is currently calculated. <i>Dependency</i> The unit is taken from the Concentration unit parameter. | Signed floating-point number | – |






| Parameter | Prerequisite | Description | User interface | Factory setting |
|-------------------------------|--|--|------------------------------|-----------------|
| Target mass flow | <p>With the following conditions: Order code for "Application package", option ED "Concentration"</p> <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the mass flow that is currently measured for the target medium.</p> <p><i>Dependency</i> The unit is taken from: Mass flow unit parameter (→  95)</p> | Signed floating-point number | – |
| Carrier mass flow | <p>With the following conditions: Order code for "Application package", option ED "Concentration"</p> <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the mass flow of the carrier medium that is currently measured.</p> <p><i>Dependency</i> The unit is taken from: Mass flow unit parameter (→  95)</p> | Signed floating-point number | – |
| Target corrected volume flow | <p>With the following conditions:</p> <ul style="list-style-type: none"> Order code for "Application package", option ED "Concentration" The Ethanol in water option or %mass / %volume option is selected in the Liquid type parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the corrected volume flow that is currently measured for the target fluid.</p> <p><i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  95).</p> | Signed floating-point number | – |
| Carrier corrected volume flow | <p>With the following conditions:</p> <ul style="list-style-type: none"> Order code for "Application package", option ED "Concentration" In the Liquid type parameter, the Ethanol in water option or %mass / %volume option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the corrected volume flow currently measured for the carrier fluid.</p> <p><i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  95).</p> | Signed floating-point number | – |
| Target volume flow | <p>With the following conditions:</p> <ul style="list-style-type: none"> Order code for "Application package", option ED "Concentration" The Ethanol in water option or %mass / %volume option is selected in the Liquid type parameter. The %vol option is selected in the Concentration unit parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the volume flow currently measured for the target medium.</p> <p><i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  95).</p> | Signed floating-point number | – |






| Parameter | Prerequisite | Description | User interface | Factory setting |
|---------------------|--|--|--------------------------------|-----------------|
| Carrier volume flow | <p>With the following conditions:</p> <ul style="list-style-type: none"> ▪ Order code for "Application package", option ED "Concentration" ▪ The Ethanol in water option or %mass / %volume option is selected in the Liquid type parameter. ▪ The %vol option is selected in the Concentration unit parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the volume flow currently measured for the carrier medium.</p> <p><i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  95).</p> | Signed floating-point number | – |
| CTL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the calibration factor which represents the effect of temperature on the fluid. This is used to convert the measured volume flow and the measured density to values at reference temperature. | Positive floating-point number | – |
| CPL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the calibration factor which represents the effect of pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at reference pressure. | Positive floating-point number | – |
| CTPL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the combined calibration factor which represents the effect of temperature and pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at reference temperature and reference pressure. | Positive floating-point number | – |



| Parameter | Prerequisite | Description | User interface | Factory setting |
|-------------------------------|--|---|--------------------------------|-----------------|
| S&W volume flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the S&W volume flow which is calculated from the measured total volume flow minus the net volume flow.</p> <p><i>Dependency</i> The unit is taken from: Volume flow unit parameter</p> | Signed floating-point number | – |
| S&W correction value | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The External value option or Current input 1...n option is selected in the S&W input mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Shows the correction value for sediment and water. | Positive floating-point number | – |
| Reference density alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the fluid density at the alternative reference temperature.</p> <p><i>Dependency</i> The unit is taken from: Reference density unit parameter</p> | Signed floating-point number | – |
| GSV flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the measured total volume flow, corrected to the reference temperature and the reference pressure.</p> <p><i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter</p> | Signed floating-point number | – |
| GSV flow alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the measured total volume flow, corrected to the alternative reference temperature and the alternative reference pressure.</p> <p><i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter</p> | Signed floating-point number | – |

| Parameter | Prerequisite | Description | User interface | Factory setting |
|----------------------|---|---|--------------------------------|-----------------|
| NSV flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ The API referenced correction option is selected in Petroleum mode parameter. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the net volume flow which is calculated from the measured total volume flow minus the value for sediment & water and minus the shrinkage.</p> <p><i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter</p> | Signed floating-point number | – |
| NSV flow alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the net volume flow which is calculated from the measured alternative total volume minus the value for sediment & water and minus the shrinkage.</p> <p><i>Dependency</i> The unit is taken from: Corrected volume flow unit parameter</p> | Signed floating-point number | – |
| Oil CTL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the correction factor which represents the effect of temperature on the oil. This is used to convert the measured oil volume flow and the measured oil density to values at reference temperature.</p> | Positive floating-point number | – |
| Oil CPL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the correction factor which represents the effect of pressure on the oil. This is used to convert the measured oil volume flow and the measured oil density to values at reference pressure.</p> | Positive floating-point number | – |
| Oil CTPL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the combined correction factor which represents the effect of temperature and pressure on the oil. This is used to convert the measured oil volume flow and the measured oil density to values at reference temperature and reference pressure.</p> | Positive floating-point number | – |

| Parameter | Prerequisite | Description | User interface | Factory setting |
|-----------------------|--|--|--------------------------------|-----------------|
| Water CTL | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the correction factor which represents the effect of temperature on the water. This is used to convert the measured water volume flow and the measured water density to values at reference temperature. | Positive floating-point number | – |
| CTL alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the correction factor which represents the effect of temperature on the fluid. This is used to convert the measured volume flow and the measured density to values at the alternative reference temperature. | Positive floating-point number | – |
| CPL alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the correction factor which represents the effect of pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at the alternative reference pressure. | Positive floating-point number | – |
| CTPL alternative | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the combined correction factor which represents the effect of temperature and pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at the alternative reference temperature and the alternative reference pressure. | Positive floating-point number | – |
| Oil reference density | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | | Signed floating-point number | – |

| Parameter | Prerequisite | Description | User interface | Factory setting |
|-------------------------|--|---|------------------------------|-----------------|
| Water reference density | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | | Signed floating-point number | – |
| Oil density | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the density of the oil currently measured. | Signed floating-point number | – |
| Water density | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the density of the water currently measured. | Signed floating-point number | – |
| Water cut | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the API referenced correction option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Displays the percentage water volume flow in relation to the total volume flow of the fluid. | 0 to 100 % | – |
| Oil volume flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated volume flow of the oil.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Volume flow unit parameter | Signed floating-point number | – |

| Parameter | Prerequisite | Description | User interface | Factory setting |
|-----------------------------|---|---|------------------------------|-----------------|
| Oil corrected volume flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated volume flow of the oil, calculated to values at reference temperature and reference pressure.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Corrected volume flow unit parameter | Signed floating-point number | – |
| Oil mass flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated mass flow of the oil.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Mass flow unit parameter | Signed floating-point number | – |
| Water volume flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated volume flow of the water.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Volume flow unit parameter | Signed floating-point number | – |
| Water corrected volume flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated volume flow of the water, calculated to values at reference temperature and reference pressure.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Corrected volume flow unit parameter | Signed floating-point number | – |
| Water mass flow | <p>For the following order code:</p> <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ In the Petroleum mode parameter, the Net oil & water cut option is selected. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | <p>Displays the currently calculated mass flow of the water.</p> <p>Dependency:</p> <ul style="list-style-type: none"> ▪ Based on the value displayed in the Water cut parameter ▪ The unit is taken from: Mass flow unit parameter | Signed floating-point number | – |



| Parameter | Prerequisite | Description | User interface | Factory setting |
|------------------------------|--|--|------------------------------|-----------------|
| Weighted density average | For the following order code: <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ "Application package", option EM "Petroleum + Locking function"  The software options currently enabled are displayed in the Software option overview parameter. | Displays the weighted average for the density since the last time the density averages were reset. Dependency: <ul style="list-style-type: none"> ▪ The unit is taken from: Density unit parameter ▪ The value is reset to NaN (Not a Number) via the Reset weighted averages parameter | Signed floating-point number | – |
| Weighted temperature average | For the following order code: <ul style="list-style-type: none"> ▪ "Application package", option EJ "Petroleum" ▪ "Application package", option EM "Petroleum + Locking function"  The software options currently enabled are displayed in the Software option overview parameter. | Displays the weighted average for the temperature since the last time the temperature averages were reset. Dependency: <ul style="list-style-type: none"> ▪ The unit is taken from: Temperature unit parameter ▪ The value is reset to NaN (Not a Number) via the Reset weighted averages parameter | Signed floating-point number | – |

11.4.2 "Totalizer" submenu



The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer

| | |
|---------------------------|---|
| <div>► Totalizer</div> | |
| Totalizer value 1 to n | →  152 |
| Totalizer overflow 1 to n | →  152 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|---------------------------|--|---|------------------------------|
| Totalizer value 1 to n | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Displays the current totalizer counter value. | Signed floating-point number |
| Totalizer overflow 1 to n | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Displays the current totalizer overflow. | Integer with sign |

11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu → Measured values → Input values

► Input values

► Current input 1 to n

→ 153

► Status input 1 to n

→ 153

Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu → Measured values → Input values → Current input 1 to n

► Current input 1 to n

Measured values 1 to n

→ 153

Measured current 1 to n

→ 153

Parameter overview with brief description

| Parameter | Description | User interface |
|------------------|--|------------------------------|
| Measured values | Displays the current input value. | Signed floating-point number |
| Measured current | Displays the current value of the current input. | 0 to 22.5 mA |

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu → Measured values → Input values → Status input 1 to n

► Status input 1 to n

Value status input

→ 153

Parameter overview with brief description

| Parameter | Description | User interface |
|--------------------|---------------------------------------|--|
| Value status input | Shows the current input signal level. | <div><div>■ High</div><div>■ Low</div></div> |

11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values

► Output values

► Current output 1 to n

→ 154

► Pulse/frequency/switch output 1 to n

→ 154

► Relay output 1 to n

→ 155

Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu → Measured values → Output values → Value current output 1 to n

► Current output 1 to n

Output current 1 to n

→ 154

Measured current 1 to n

→ 154

Parameter overview with brief description

| Parameter | Description | User interface |
|------------------|---|-----------------|
| Output current 1 | Displays the current value currently calculated for the current output. | 3.59 to 22.5 mA |
| Measured current | Displays the current value currently measured for the current output. | 0 to 30 mA |

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu → Measured values → Output values → Pulse/frequency/switch output 1 to n

| | | |
|--|--|-------|
| ► Pulse/frequency/switch output 1 to n | | |
| Output frequency 1 to n | | → 155 |
| Pulse output 1 to n | | → 155 |
| Switch status 1 to n | | → 155 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|------------------|--|---|--|
| Output frequency | In the Operating mode parameter, the Frequency option is selected. | Displays the value currently measured for the frequency output. | 0.0 to 12 500.0 Hz |
| Pulse output | The Pulse option is selected in the Operating mode parameter. | Displays the pulse frequency currently output. | Positive floating-point number |
| Switch status | The Switch option is selected in the Operating mode parameter. | Displays the current switch output status. | <ul style="list-style-type: none"> ■ Open ■ Closed |

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu → Measured values → Output values → Relay output 1 to n



| | | |
|---------------------------|--|-------|
| ► Relay output 1 to n | | |
| Switch status | | → 155 |
| Switch cycles | | → 155 |
| Max. switch cycles number | | → 155 |

Parameter overview with brief description

| Parameter | Description | User interface |
|---------------------------|---|--|
| Switch status | Shows the current relay switch status. | <ul style="list-style-type: none"> ■ Open ■ Closed |
| Switch cycles | Shows number of all performed switch cycles. | Positive integer |
| Max. switch cycles number | Shows the maximal number of guaranteed switch cycles. | Positive integer |

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (→  93)
- Advanced settings using the **Advanced setup** submenu (→  118)




11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:





- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu → Totalizer handling

| | |
|--------------------------|---|
| ► Totalizer handling | |
| Control Totalizer 1 to n | →  156 |
| Preset value 1 to n | →  156 |
| Reset all totalizers | →  156 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|--------------------------|--|---|--|--|
| Control Totalizer 1 to n | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Control totalizer value. | <ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold | – |
| Preset value 1 to n | A process variable is selected in the Assign process variable parameter (→  125) of the Totalizer 1 to n submenu. | Specify start value for totalizer. <i>Dependency</i>  The unit of the selected process variable is defined in the Unit totalizer parameter (→  125) for the totalizer. | Signed floating-point number | Depends on country: <ul style="list-style-type: none"> ■ 0 kg ■ 0 lb |
| Reset all totalizers | – | Reset all totalizers to 0 and start. | <ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize | – |

11.6.1 Function scope of "Control Totalizer" parameter

| Options | Description |
|-----------------------------|---|
| Totalize | The totalizer is started or continues running. |
| Reset + hold | The totaling process is stopped and the totalizer is reset to 0. |
| Preset + hold ¹⁾ | The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter. |

| Options | Description |
|---------------------------------|---|
| Reset + totalize | The totalizer is reset to 0 and the totaling process is restarted. |
| Preset + totalize ¹⁾ | The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted. |
| Hold | Totalizing is stopped. |



1) Visible depending on the order options or device settings

11.6.2 Function range of "Reset all totalizers" parameter

| Options | Description |
|------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| Reset + totalize | Resets all totalizers to 0 and restarts the totaling process. This deletes all the previously aggregated flow values. |


11.7 Displaying the measured value history

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.


-  Data logging is also available via:
- Plant Asset Management Tool FieldCare →  84.
 - Web browser

Function scope


- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Displays the measured value trend for each logging channel in the form of a chart



A0016357


 39 Chart of a measured value trend


- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.











-  If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation



"Diagnostics" menu → Data logging







→  158

| | |
|-------------------------|---|
| Assign channel 2 | →  158 |
| Assign channel 3 | →  159 |
| Assign channel 4 | →  159 |
| Logging interval | →  159 |
| Clear logging data | →  159 |
| Data logging | →  159 |
| Logging delay | →  159 |
| Data logging control | →  159 |
| Data logging status | →  159 |
| Entire logging duration | →  159 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry / User interface |
|------------------|--|---|---|
| Assign channel 1 | The Extended HistoROM application package is available. | Assign process variable to logging channel. | <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow * ■ Density ■ Reference density * ■ Temperature ■ Concentration * ■ Target mass flow * ■ Carrier mass flow * ■ Oscillation amplitude ■ Current output 1 ■ Current output 2 * ■ Current output 3 * ■ Current output 4 * ■ HBSI * ■ Exciter current 0 ■ Oscillation damping 0 ■ Oscillation damping fluctuation 0 * ■ Oscillation frequency 0 ■ Frequency fluctuation 0 * ■ Oscillation amplitude ■ Oscillation amplitude 1 * ■ Signal asymmetry ■ Electronic temperature |
| Assign channel 2 | The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter. | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  158) |

| Parameter | Prerequisite | Description | Selection / User entry / User interface |
|-------------------------|--|--|---|
| Assign channel 3 | The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter. | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  158) |
| Assign channel 4 | The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter. | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  158) |
| Logging interval | The Extended HistoROM application package is available. | Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory. | 0.1 to 999.0 s |
| Clear logging data | The Extended HistoROM application package is available. | Clear the entire logging data. | <ul style="list-style-type: none"> ■ Cancel ■ Clear data |
| Data logging | – | Select the type of data logging. | <ul style="list-style-type: none"> ■ Overwriting ■ Not overwriting |
| Logging delay | In the Data logging parameter, the Not overwriting option is selected. | Enter the time delay for measured value logging. | 0 to 999 h |
| Data logging control | In the Data logging parameter, the Not overwriting option is selected. | Start and stop measured value logging. | <ul style="list-style-type: none"> ■ None ■ Delete + start ■ Stop |
| Data logging status | In the Data logging parameter, the Not overwriting option is selected. | Displays the measured value logging status. | <ul style="list-style-type: none"> ■ Done ■ Delay active ■ Active ■ Stopped |
| Entire logging duration | In the Data logging parameter, the Not overwriting option is selected. | Displays the total logging duration. | Positive floating-point number |

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

| Fault | Possible causes | Remedial action |
|---|---|---|
| Local display is dark, but signal output is within the valid range | The cable of the display module is not plugged in correctly. | Insert the plug correctly into the main electronics module and display module. |
| Local display dark and no output signals | Supply voltage does not match the voltage specified on the nameplate. | Apply the correct supply voltage → 53 → 47. |
| Local display dark and no output signals | Supply voltage has incorrect polarity. | Reverse polarity of supply voltage. |
| Local display dark and no output signals | No contact between connecting cables and terminals. | Check the electrical contact between the cable and terminals and correct if necessary. |
| Local display dark and no output signals | <ul style="list-style-type: none"> Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly. | Check terminals. |
| Local display dark and no output signals | <ul style="list-style-type: none"> I/O electronics module is defective. Main electronics module is defective. | Order spare part → 204. |
| Local display dark and no output signals | The connector between the main electronics module and display module is not plugged in correctly. | Check the connection and correct if necessary. |
| Local display cannot be read, but signal output is within the valid range | Display is set too bright or too dark. | <ul style="list-style-type: none"> Set the display brighter by simultaneously pressing \boxplus + \boxminus. Set the display darker by simultaneously pressing \boxminus + \boxplus. |
| Local display is dark, but signal output is within the valid range | Display module is defective. | Order spare part → 204. |
| Backlighting of local display is red | Diagnostic event with "Alarm" diagnostic behavior has occurred. | Take remedial actions → 174 |
| Text on local display appears in a language that cannot be understood. | The selected operating language cannot be understood. | <ol style="list-style-type: none"> Press \boxminus + \boxplus for 2 s ("home position"). Press \boxminus. Configure the required language in the Display language parameter (→ 128). |
| Message on local display: "Communication Error" "Check Electronics" | Communication between the display module and the electronics is interrupted. | <ul style="list-style-type: none"> Check the cable and the connector between the main electronics module and display module. Order spare part → 204. |

For output signals

| Fault | Possible causes | Remedial action |
|---|--|---|
| Signal output outside the valid range | Main electronics module is defective. | Order spare part → 204. |
| Device shows correct value on local display, but signal output is incorrect, though in the valid range. | Parameter configuration error | Check and adjust parameter configuration. |
| Device is measuring incorrectly. | Configuration error or device is operated outside the application. | <ol style="list-style-type: none"> Check and correct parameter configuration. Observe limit values specified in the "Technical Data". |

For access


| Fault | Possible causes | Remedial action |
|--|---|--|
| Write access to parameters is not possible. | Hardware write protection is enabled. | Set the write protection switch on the main electronics module to the OFF position → 138. |
| Write access to parameters is not possible. | Current user role has limited access authorization. | 1. Check user role → 74. 2. Enter correct customer-specific access code → 74. |
| Connection via FOUNDATION Fieldbus is not possible. | Device plug is connected incorrectly. | Check the pin assignment of the device plugs . |
| Connection to the web server is not possible. | Web server is disabled. | Use the "FieldCare" or "DeviceCare" operating tool to check if the web server of the device is enabled and enable if necessary → 78. |
| | The Ethernet interface on the PC is incorrectly configured. | <ul style="list-style-type: none"> ▶ Check the properties of the Internet protocol (TCP/IP). ▶ Check the network settings with the IT manager. |
| Connection to the web server is not possible. | The IP address on the PC is incorrectly configured. | Check the IP address: 192.168.1.212 |
| Connection to the web server is not possible. | WLAN access data are incorrect. | <ul style="list-style-type: none"> ▪ Check WLAN network status. ▪ Log on to the device again using WLAN access data. ▪ Check that WLAN is enabled on the measuring instrument and operating unit . |
| | WLAN communication is disabled. | – |
| Unable to connect to web server, FieldCare or DeviceCare. | WLAN network is not available. | <ul style="list-style-type: none"> ▪ Check if WLAN reception is present: LED on display module is lit blue. ▪ Check if WLAN connection is enabled: LED on display module flashes blue. ▪ Switch on instrument function. |
| Network connection not present or unstable | WLAN network is weak. | <ul style="list-style-type: none"> ▪ Operating unit outside reception range: Check network status on operating unit. ▪ To improve network performance, use an external WLAN antenna. |
| | Parallel WLAN and Ethernet communication | <ul style="list-style-type: none"> ▪ Check network settings. ▪ Temporarily enable only the WLAN as an interface. |
| Web browser is frozen and operation no longer possible | Data transfer is active. | Wait until data transfer or current action is finished. |
| | Connection lost | <ul style="list-style-type: none"> ▶ Check cable connection and power supply. ▶ Refresh the web browser and restart if necessary. |
| Display of web browser content is difficult to read or incomplete. | Web browser version used is not optimal. | <ul style="list-style-type: none"> ▶ Use correct web browser version → 76. ▶ Empty the web browser cache. ▶ Restart the web browser. |
| | Unsuitable view settings. | Change the font size/display ratio of the web browser. |
| Incomplete or no display of content in the web browser | <ul style="list-style-type: none"> ▪ JavaScript is not enabled. ▪ JavaScript cannot be enabled. | <ul style="list-style-type: none"> ▶ Enable JavaScript. ▶ Enter http://XXX.XXX.X.XX/servlet/basic.html as the IP address. |
| Operation with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000) is not possible. | Firewall of the PC or network is blocking communication. | Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access. |
| Flashing the firmware with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000 or TFTP ports) is not possible. | Firewall of the PC or network is blocking communication. | Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access. |

12.2 Diagnostic information via LEDs

12.2.1 Transmitter

Proline 500 – digital

Various LEDs in the transmitter provide information on the device status.




- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.

| LED | Color | Meaning |
|------------------------------------|---------------------|---|
| 1 Supply voltage | Green | Supply voltage is OK. |
| | Off | Supply voltage is off or too low. |
| 2 Device status (normal operation) | Red | Fault |
| | Flashing red | Warning |
| 2 Device status (during start-up) | Flashes red slowly | If > 30 seconds: problem with the boot loader. |
| | Flashes red quickly | If > 30 seconds: compatibility problem when reading the firmware. |
| 3 Not used | – | – |
| 4 Communication | White | Communication active. |
| 5 Service interface (CDI) | Yellow | Connection established. |
| | Flashing yellow | Communication active. |
| | Off | No connection. |

Proline 500

Various LEDs in the transmitter provide information on the device status.



A0029629


- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

| LED | Color | Meaning |
|------------------------------------|---------------------|---|
| 1 Supply voltage | Green | Supply voltage is OK. |
| | Off | Supply voltage is off or too low. |
| 2 Device status (normal operation) | Red | Fault |
| | Flashing red | Warning |
| 2 Device status (during start-up) | Flashes red slowly | If > 30 seconds: problem with the boot loader. |
| | Flashes red quickly | If > 30 seconds: compatibility problem when reading the firmware. |
| 3 Not used | – | – |
| 4 Communication | White | Communication active. |
| 5 Service interface (CDI) | Yellow | Connection established. |
| | Flashing yellow | Communication active. |
| | Off | No connection. |

12.2.2 Sensor connection housing

Proline 500 – digital

Various LEDs on the ISEM electronics unit (intelligent sensor electronics module) in the sensor connection housing provide information about the device status.



A0029699


- 1 Communication
- 2 Device status
- 3 Supply voltage

| LED | Color | Meaning |
|------------------------------------|---------------------|---|
| 1 Communication | White | Communication active. |
| 2 Device status (normal operation) | Red | Fault |
| | Flashing red | Warning |
| 2 Device status (during start-up) | Flashes red slowly | If > 30 seconds: problem with the boot loader. |
| | Flashes red quickly | If > 30 seconds: compatibility problem when reading the firmware. |
| 3 Supply voltage | Green | Supply voltage is OK. |
| | Off | Supply voltage is off or too low. |

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring instrument are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- i** Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
- Via parameter → 195
 - Via submenus → 196



Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required


| Symbol | Meaning |
|----------|---|
| F | Failure A device error has occurred. The measured value is no longer valid. |
| C | Function check The device is in the service mode (e.g. during a simulation). |
| S | Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) |
| M | Maintenance required Maintenance is required. The measured value remains valid. |

Diagnostic behavior



| Symbol | Meaning |
|---|---|
|  | Alarm <ul style="list-style-type: none"> ■ Measurement is interrupted. ■ Signal outputs and totalizers assume the defined alarm condition. ■ A diagnostic message is generated. |
|  | Warning <ul style="list-style-type: none"> ■ Measurement is resumed. ■ The signal outputs and totalizers are not affected. ■ A diagnostic message is generated. |

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

| Operating key | Meaning |
|---|--|
|  | Plus key <i>In menu, submenu</i> Opens the message about the remedial measures. |
|  | Enter key <i>In menu, submenu</i> Opens the operating menu. |

12.3.2 Calling up remedial actions



40 Message for remedial actions

- 1 Diagnostic information
- 2 Event text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operating time of occurrence
- 6 Remedial actions

1. The user is in the diagnostic message.
Press **+** (ⓘ symbol).
↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with **+** or **-** and press **E**.
↳ The message about the remedial measures opens.
3. Press **-** + **+** simultaneously.
↳ The message about the remedial measures closes.


The user is in the **Diagnostics** menu in the **Diagnostic list** submenu. A list of active diagnostics is displayed. The user can select a diagnostic event.

1. Press **E**.
↳ The message for the remedial actions for the selected diagnostic event opens.
2. Press **-** + **+** simultaneously.
↳ The message about the remedial actions closes.

12.4 Diagnostic information in the web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 195
- Via submenu → 196

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

| Symbol | Meaning |
|--------|---|
| | Failure A device error has occurred. The measured value is no longer valid. |
| | Function check The device is in service mode (e.g. during a simulation). |
| | Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) |
| | Maintenance required Maintenance is required. The measured value remains valid. |

i The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


12.4.2 Calling up remedial actions

Remedial actions are provided for each diagnostic event to ensure that problems can be rectified quickly. These actions are displayed along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



A0021799-EN


- 1 Status area with status signal → 165
- 2 Diagnostic information → 166
- 3 Remedial actions with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 195
- Via submenu → 196

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ↳ A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert → System → Diagnostic handling → Diagnostic behavior



A0014048-EN

41 Using the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

| Options | Description |
|--------------------|---|
| Alarm | The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red. |
| Warning | The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated. |
| Logbook entry only | The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (Event list submenu) and is not displayed in alternating sequence with the operational display. |
| Off | The diagnostic event is ignored, and no diagnostic message is generated or entered. |

12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic event category** submenu.

Expert → Communication → Diagnostic event category

Available status signals

Configuration as per FOUNDATION Fieldbus Specification (FF912), in accordance with NAMUR NE107.

| Symbol | Meaning |
|-------------------------------------|---|
| F <small>A0013956</small> | Failure A device error has occurred. The measured value is no longer valid. |
| C <small>A0013959</small> | Function check The device is in service mode (e.g. during a simulation). |

| Symbol | Meaning |
|----------------------|---|
| S A0013958 | Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) |
| M A0013957 | Maintenance required Maintenance is required. The measured value remains valid. |

Enabling the configuration of the diagnostic information according to FF912

For compatibility reasons, the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912 is not enabled when the device is delivered from the factory.

Enabling the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912

1. Open the Resource block.
2. In **Feature Selection** parameter, select **Multi-bit Alarm (Bit-Alarm) Support** option.
 - ↳ The diagnostic information can be configured according to FOUNDATION Fieldbus Specification FF912.


Grouping the diagnostic information

Diagnostic information is assigned to different groups. The groups differ depending on the weighting (severity) of the diagnostic event:



- Highest weighting
- High weighting
- Low weighting

Assignment of the diagnostic information (factory setting)

The assignment of the diagnostic information ex-works is indicated in the following tables.

The individual ranges of the diagnostic information can be assigned to another status signal →  172.

Some diagnostic information can be assigned individually, irrespective of their range →  173.

 Overview and description of all diagnostic information →  174

| Weighting | Status signal (factory setting) | Allocation | Diagnostic information range |
|-----------|---------------------------------|---------------|------------------------------|
| Highest | Failure (F) | Sensor | F000 to 199 |
| | | Electronics | F200 to 399 |
| | | Configuration | F400 to 700 |
| | | Process | F800 to 999 |


| Weighting | Status signal (factory setting) | Allocation | Diagnostic information range |
|-----------|---------------------------------|---------------|------------------------------|
| High | Function check (C) | Sensor | C000 to 199 |
| | | Electronics | C200 to 399 |
| | | Configuration | C400 to 700 |
| | | Process | C800 to 999 |

| Weighting | Status signal (factory setting) | Allocation | Diagnostic information range |
|-----------|---------------------------------|---------------|------------------------------|
| Low | Out of specification (S) | Sensor | S000 to 199 |
| | | Electronics | S200 to 399 |
| | | Configuration | S400 to 700 |
| | | Process | S800 to 999 |

| Weighting | Status signal (factory setting) | Allocation | Diagnostic information range |
|-----------|---------------------------------|---------------|------------------------------|
| Low | Maintenance required (M) | Sensor | M000 to 199 |
| | | Electronics | M200 to 399 |
| | | Configuration | M400 to 700 |
| | | Process | M800 to 999 |

Changing the assignment of the diagnostic information

The individual ranges of the diagnostic information can be assigned to another status signal. This is done by changing the bit in the associated parameter. The bit change always applies for the entire range of the diagnostic information.


 Some diagnostic information can be assigned individually, irrespective of their range
→  173

Each status signal has a parameter in the Resource Block in which it is possible to define the diagnostic event for which the status signal is transmitted:

- Failure (F): **FD_FAIL_MAP** parameter
- Function check (C): **FD_CHECK_MAP** parameter
- Out of specification (S): **FD_OFFSPEC_MAP** parameter
- Maintenance required (M): **FD_MAINT_MAP** parameter

Structure and assignment of the parameters for the status signals (factory setting)

| Weighting | Allocation | Bit | FD_FAIL_MAP | FD_CHECK_MAP | FD_OFFSPEC_MAP | FD_MAINT_MAP |
|-----------|---------------|-----|-------------|--------------|----------------|--------------|
| Highest | Sensor | 31 | 1 | 0 | 0 | 0 |
| | Electronics | 30 | 1 | 0 | 0 | 0 |
| | Configuration | 29 | 1 | 0 | 0 | 0 |
| | Process | 28 | 1 | 0 | 0 | 0 |
| High | Sensor | 27 | 0 | 1 | 0 | 0 |
| | Electronics | 26 | 0 | 1 | 0 | 0 |
| | Configuration | 25 | 0 | 1 | 0 | 0 |
| | Process | 24 | 0 | 1 | 0 | 0 |
| Low | Sensor | 23 | 0 | 0 | 1 | 0 |
| | Electronics | 22 | 0 | 0 | 1 | 0 |
| | Configuration | 21 | 0 | 0 | 1 | 0 |
| | Process | 20 | 0 | 0 | 1 | 0 |
| Low | Sensor | 19 | 0 | 0 | 0 | 1 |
| | Electronics | 18 | 0 | 0 | 0 | 1 |
| | Configuration | 17 | 0 | 0 | 0 | 1 |
| | Process | 16 | 0 | 0 | 0 | 1 |

| Weighting | Allocation | Bit | FD_FAIL_MAP | FD_CHECK_MAP | FD_OFFSPEC_MAP | FD_MAINT_MAP |
|--|------------|---------|-------------|--------------|----------------|--------------|
| Configurable range →  173 | | 15 to 1 | 0 | 0 | 0 | 0 |
| Reserved (Fieldbus Foundation) | | 0 | 0 | 0 | 0 | 0 |

Changing the status signal for a range of diagnostic information

Example: The status signal for the diagnostic information for electronics with the "Highest" weighting is to be changed from failure (F) to function check (C).

1. Set the Resource Block to the **OOS** block mode.
2. Open the **FD_FAIL_MAP** parameter in the Resource Block.
3. Change **Bit 30** to **0** in the parameter.
4. Open the **FD_CHECK_MAP** parameter in the Resource Block.
5. Change **Bit 26** to **1** in the parameter.
 - ↳ If a diagnostic event occurs for electronics with the "Highest weighting", the diagnostic information to this effect is displayed with the function check (C) status signal.
6. Set the Resource Block to the **AUTO** block mode.

NOTICE

No status signal is assigned to an area of diagnostic information.

If a diagnostic event occurs in this area, no status signal is transmitted to the control system.

- ▶ If you are changing the parameters, make sure that a status signal is assigned to all areas.




If FieldCare is used, the status signal is enabled and disabled using the check box of the particular parameter.

Assigning diagnostic information individually to a status signal

Some diagnostic information can be individually assigned to a status signal, irrespective of their original range.

Assigning diagnostic information individually to a status signal via FieldCare.

1. In the FieldCare navigation window: **Expert** → **Communication** → **Field diagnostics** → **Alarm detection enable**
2. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.
3. Press Enter to confirm.
4. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 2).
5. Press Enter to confirm.
 - ↳ The diagnostic event of the selected diagnostic information is recorded.
6. In the FieldCare navigation window: **Expert** → **Communication** → **Field diagnostics** → **Alarm broadcast enable**
7. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.
8. Press Enter to confirm.

9. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 7).
 10. Press Enter to confirm.
 - ↳ The selected diagnostic information is transmitted over the bus when a diagnostic event to this effect occurs.
-  A change in the status signal does not affect diagnostic information that already exists. The new status signal is only assigned if this error occurs again after the status signal has changed.

Transmitting the diagnostic information over the bus

Prioritizing diagnostic information for transmission over the bus

Diagnostic information is only transmitted over the bus if its priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Diagnostic information with priority 0 (factory setting) is ignored.




It is possible to change the priority individually for the different status signals. The following parameters of the Resource Block are used for this purpose:

- FD_FAIL_PRI
- FD_CHECK_PRI
- FD_OFFSPEC_PRI
- FD_MAINT_PRI

Suppressing certain diagnostic information

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare **Expert** → **Communication** → **Field diagnostics** → **Alarm broadcast enable**. The mask is a negative selection mask, i.e. if a field is selected the associated diagnostic information is not transmitted over the bus.

12.7 Overview of diagnostic information

-  The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- All of the measured variables affected in the entire Promass instrument family are always listed under "Measured variables affected". The measured variables available for the device in question depend on the device version. When assigning the measured variables to the device functions, for example to the individual outputs, all of the measured variables available for the device version in question are available for selection.
-  In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information →  170

12.7.1 Diagnostic of sensor

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 022 | Temperature sensor defective | | 1. Check or replace sensor electronic module (ISEM) 2. If available: Check connection cable between sensor and transmitter 3. Replace sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Sensor failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|--|---|--------------|---|---|
| No. | Short text | | | |
| 046 | Sensor limit exceeded | | 1. Inspect sensor 2. Check process condition | <div>▪ Empty pipe detection option</div> <div>▪ Low flow cut off option</div> <div>▪ Switch output status option</div> <div>▪ Pressure option</div> |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| Diagnostic behavior [from the factory] ³⁾ | Warning | | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 062 | Sensor connection faulty | | 1. Check or replace sensor electronic module (ISEM) 2. If available: Check connection cable between sensor and transmitter 3. Replace sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Sensor failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 063 | Exciter current faulty | | 1. Check or replace sensor electronic module (ISEM) 2. If available: Check connection cable between sensor and transmitter 3. Replace sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Sensor failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | S | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 082 | Data storage | | 1. Check module connections 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Sensor failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 083 | Memory content | | 1. Restart device 2. Restore HistoROM S-DAT backup ('Device reset' parameter) 3. Replace HistoROM S-DAT | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Sensor failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|--|---|--------------|--|---|
| No. | Short text | | | |
| 140 | Sensor signal asymmetrical | | 1. Check or replace sensor electronic module (ISEM) 2. If available: Check connection cable between sensor and transmitter 3. Replace sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| Diagnostic behavior [from the factory] ³⁾ | Alarm | | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|--|---|
| No. | Short text | | | |
| 144 | Measuring error too high | | 1. Check or change sensor 2. Check process conditions | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | F | | |
| | Diagnostic behavior [from the factory] ³⁾ | Alarm | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

12.7.2 Diagnostic of electronic

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 201 | Device failure | | 1. Restart device 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 242 | Software incompatible | | 1. Check software 2. Flash or change main electronics module | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 252 | Modules incompatible | | 1. Check electronic modules 2. Change electronic modules | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| Diagnostic behavior | Alarm | | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|--|
| No. | Short text | | | |
| 262 | Sensor electronic connection faulty | | 1. Check or replace connection cable between sensor electronic module (ISEM) and main electronics 2. Check or replace ISEM or main electronics | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| Diagnostic behavior | Alarm | | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|-------------------------------|---|
| No. | Short text | | | |
| 270 | Main electronic failure | | Change main electronic module | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 271 | Main electronic failure | | 1. Restart device 2. Change main electronic module | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|---|--|
| No. | Short text | | |
| 272 | Main electronic failure | 1. Restart device 2. Contact service | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|--|
| No. | Short text | | |
| 273 | Main electronic failure | Change electronic | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|--|
| No. | Short text | | |
| 275 | I/O module 1 to n defective | Change I/O module | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|---|--|
| No. | Short text | | |
| 276 | I/O module 1 to n faulty | 1. Restart device 2. Change I/O module | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 276 | I/O module 1 to n faulty | | 1. Restart device 2. Change I/O module | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---------------------------------------|---|
| No. | Short text | | | |
| 283 | Memory content | | 1. Reset device 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 302 | Device verification active | | Device verification active, please wait. | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 311 | Electronic failure | | 1. Do not reset device 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | M | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 332 | Writing in embedded HistoROM failed | | Replace user interface board Ex d/XP: replace transmitter | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 361 | I/O module 1 to n faulty | | 1. Restart device 2. Check electronic modules 3. Change I/O Modul or main electronics | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 372 | Sensor electronic (ISEM) faulty | | 1. Restart device 2. Check if failure recurs 3. Replace sensor electronic module (ISEM) | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 373 | Sensor electronic (ISEM) faulty | | 1. Transfer data or reset device 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|---|---|
| No. | Short text | | | |
| 374 | Sensor electronic (ISEM) faulty | | 1. Restart device 2. Check if failure recurs 3. Replace sensor electronic module (ISEM) | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|--|---|
| No. | Short text | | | |
| 375 | I/O- 1 to n communication failed | | 1. Restart device 2. Check if failure recurs 3. Replace module rack inclusive electronic modules | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|-------------------------------------|---|
| No. | Short text | | | |
| 382 | Data storage | | 1. Insert T-DAT 2. Replace T-DAT | <div><div>▪ Empty pipe detection option</div><div>▪ Low flow cut off option</div><div>▪ Pressure option</div></div> |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|---|---|
| No. | Short text | | | |
| 383 | Memory content | | 1. Restart device 2. Delete T-DAT via 'Reset device' parameter 3. Replace T-DAT | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|----------------|------------------------------|---|
| No. | Short text | | | |
| 387 | Embedded HistoROM failed | | Contact service organization | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Device failure | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

12.7.3 Diagnostic of configuration

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|---|-------------------------------|
| No. | Short text | | | |
| 303 | I/O 1 to n configuration changed | | 1. Apply I/O module configuration (parameter 'Apply I/O configuration') 2. Afterwards reload device description and check wiring | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | M | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|---|---|
| No. | Short text | | | |
| 330 | Flash file invalid | | 1. Update firmware of device 2. Restart device | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Configuration error | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | M | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|---|---|
| No. | Short text | | | |
| 331 | Firmware update failed | | 1. Update firmware of device 2. Restart device | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Configuration error | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| Diagnostic behavior | | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|---|---|
| No. | Short text | | | |
| 410 | Data transfer | | 1. Check connection 2. Retry data transfer | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Configuration error | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| Diagnostic behavior | Alarm | | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|------------------------------|---|
| No. | Short text | | | |
| 412 | Processing download | | Download active, please wait | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Uncertain | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|---------------------|-------------------------------|
| No. | Short text | | | |
| 431 | Trim 1 to n | | Carry out trim | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|---------------------|---|---|
| No. | Short text | | | |
| 437 | Configuration incompatible | | 1. Restart device 2. Contact service | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Configuration error | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|---|
| No. | Short text | | | |
| 438 | Dataset | | 1. Check data set file 2. Check device configuration 3. Up- and download new configuration | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Uncertain | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | M | | |
| Diagnostic behavior | Warning | | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|-------------------------------|
| No. | Short text | | | |
| 441 | Current output 1 to n | | 1. Check process 2. Check current output settings | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | S | | |
| | Diagnostic behavior [from the factory] ²⁾ | Warning | | |

1) Status signal can be changed.

2) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|--|--|--------------|--|-------------------------------|
| No. | Short text | | | |
| 442 | Frequency output 1 to n | | 1. Check process 2. Check frequency output settings | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | S | | |
| Diagnostic behavior [from the factory] ²⁾ | Warning | | | |

1) Status signal can be changed.

2) Diagnostic behavior can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|--|-------------------------------|
| No. | Short text | | |
| 443 | Pulse output 1 to n | 1. Check process 2. Check pulse output settings | – |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior [from the factory] ²⁾ | | |
| | Good | | |
| | Non specific | | |
| | S | | |
| | Warning | | |

1) Status signal can be changed.

2) Diagnostic behavior can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|---|-------------------------------|
| No. | Short text | | |
| 444 | Current input 1 to n | 1. Check process 2. Check current input settings | – |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior [from the factory] ²⁾ | | |
| | Good | | |
| | Non specific | | |
| | S | | |
| | Warning | | |

1) Status signal can be changed.

2) Diagnostic behavior can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------------------|--|
| No. | Short text | | |
| 453 | Flow override | Deactivate flow override | <ul style="list-style-type: none"> ■ Empty pipe detection option ■ Low flow cut off option ■ Switch output status option ■ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |
| | Good | | |
| | Non specific | | |
| | C | | |
| | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|--|--|
| No. | Short text | | |
| 463 | Analog input 1 to n selection invalid | 1. Check module/channel configuration 2. Check I/O module configuration | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|-----------------------|--|
| No. | Short text | | |
| 484 | Failure mode simulation | Deactivate simulation | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|-----------------------|--|
| No. | Short text | | |
| 485 | Measured variable simulation | Deactivate simulation | <ul style="list-style-type: none"> ▪ Empty pipe detection option ▪ Low flow cut off option ▪ Switch output status option ▪ Pressure option |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | Remedy instructions | Influenced measured variables |
|------------------------|--|-----------------------|-------------------------------|
| No. | Short text | | |
| 486 | Current input 1 to n simulation | Deactivate simulation | – |
| | Measured variable status | | |
| | Quality | | |
| | Quality substatus | | |
| | Status signal [from the factory] ¹⁾ | | |
| | Diagnostic behavior | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|-----------------------|-------------------------------|
| No. | Short text | | | |
| 491 | Current output 1 to n simulation | | Deactivate simulation | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|-------------------------------|
| No. | Short text | | | |
| 492 | Simulation frequency output 1 to n | | Deactivate simulation frequency output | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|------------------------------------|-------------------------------|
| No. | Short text | | | |
| 493 | Simulation pulse output 1 to n | | Deactivate simulation pulse output | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|-------------------------------------|-------------------------------|
| No. | Short text | | | |
| 494 | Switch output simulation 1 to n | | Deactivate simulation switch output | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|-----------------------|-------------------------------|
| No. | Short text | | | |
| 495 | Diagnostic event simulation | | Deactivate simulation | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|------------------------------------|-------------------------------|
| No. | Short text | | | |
| 496 | Status input simulation | | Deactivate simulation status input | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|-----------------------|-------------------------------|
| No. | Short text | | | |
| 497 | Simulation block output | | Deactivate simulation | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|---|-------------------------------|
| No. | Short text | | | |
| 520 | I/O 1 to n hardware configuration invalid | | 1. Check I/O hardware configuration 2. Replace wrong I/O module 3. Plug the module of double pulse output on correct slot | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|-------------------------------|
| No. | Short text | | | |
| 537 | Configuration | | 1. Check IP addresses in network 2. Change IP address | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|-------------------------------------|-------------------------------|
| No. | Short text | | | |
| 594 | Relay output simulation | | Deactivate simulation switch output | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | C | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

12.7.4 Diagnostic of process

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|---|-------------------------------|
| No. | Short text | | | |
| 803 | Current loop 1 to n | | 1. Check wiring 2. Change I/O module | – |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|--|---|
| No. | Short text | | | |
| 830 | Sensor temperature too high | | Reduce ambient temp. around the sensor housing | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|--|---|
| No. | Short text | | | |
| 831 | Sensor temperature too low | | Increase ambient temp. around the sensor housing | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|----------------------------|---|
| No. | Short text | | | |
| 832 | Electronic temperature too high | | Reduce ambient temperature | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|------------------------------|---|
| No. | Short text | | | |
| 833 | Electronic temperature too low | | Increase ambient temperature | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|----------------------------|---|
| No. | Short text | | | |
| 834 | Process temperature too high | | Reduce process temperature | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|------------------------------|---|
| No. | Short text | | | |
| 835 | Process temperature too low | | Increase process temperature | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|---|---|
| No. | Short text | | | |
| 842 | Process limit | | Low flow cut off active! 1. Check low flow cut off configuration | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | S | | |
| | Diagnostic behavior | Warning | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--------------------------|---|
| No. | Short text | | | |
| 843 | Process limit | | Check process conditions | <div><div>▪ Empty pipe detection option</div><div>▪ Low flow cut off option</div><div>▪ Switch output status option</div><div>▪ Pressure option</div></div> |
| | Measured variable status | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | S | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|---|-------------------------------|
| No. | Short text | | | |
| 862 | Partly filled pipe | | 1. Check for gas in process 2. Adjust detection limits | – |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|-------------------------------|
| No. | Short text | | | |
| 882 | Input signal | | 1. Check input configuration 2. Check external device or process conditions | – |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|--|--------------|--|---|
| No. | Short text | | | |
| 910 | Tubes not oscillating | | 1. Check electronic 2. Inspect sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status | | | |
| | Quality | Bad | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ¹⁾ | F | | |
| | Diagnostic behavior | Alarm | | |

1) Status signal can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|--|---|--------------|---|---|
| No. | Short text | | | |
| 912 | Medium inhomogeneous | | 1. Check process cond. 2. Increase system pressure | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| Diagnostic behavior [from the factory] ³⁾ | Warning | | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|--|---|--------------|--|---|
| No. | Short text | | | |
| 913 | Medium unsuitable | | 1. Check process conditions 2. Check electronic modules or sensor | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| Diagnostic behavior [from the factory] ³⁾ | Warning | | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|---|---|
| No. | Short text | | | |
| 944 | Monitoring failed | | Check process conditions for Heartbeat Monitoring | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

| Diagnostic information | | | Remedy instructions | Influenced measured variables |
|------------------------|---|--------------|--------------------------|---|
| No. | Short text | | | |
| 948 | Oscillation damping too high | | Check process conditions | <ul style="list-style-type: none">▪ Empty pipe detection option▪ Low flow cut off option▪ Switch output status option▪ Pressure option |
| | Measured variable status [from the factory] ¹⁾ | | | |
| | Quality | Good | | |
| | Quality substatus | Non specific | | |
| | | | | |
| | Status signal [from the factory] ²⁾ | S | | |
| | Diagnostic behavior [from the factory] ³⁾ | Warning | | |


1) Quality can be changed. This causes the overall status of the measured variable to change.





2) Status signal can be changed.



3) Diagnostic behavior can be changed.

12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.




 Accessing the remedial action for a diagnostic event:

- Via local display →  165
- Via web browser →  167
- Via "FieldCare" operating tool →  168
- Via "DeviceCare" operating tool →  168

 Other pending diagnostic events can be displayed in the **Diagnostic list** submenu →  196.


Navigation

"Diagnostics" menu

| | |
|--|---|
|  Diagnostics | |
| Actual diagnostics | →  196 |
| Previous diagnostics | →  196 |

| | |
|-----------------------------|-------|
| Operating time from restart | → 196 |
| Operating time | → 196 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|-----------------------------|--|--|--|
| Actual diagnostics | A diagnostic event has occurred. | Shows the current occurred diagnostic event along with its diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Previous diagnostics | Two diagnostic events have already occurred. | Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Operating time from restart | – | Shows the time the device has been in operation since the last device restart. | Days (d), hours (h), minutes (m) and seconds (s) |
| Operating time | – | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) |

12.9 Diagnostic messages in the DIAGNOSTIC Transducer Block


- The **Actual diagnostics** parameter (**actual diagnostics**) displays the message with the highest priority.
- A list of the active alarms can be viewed via the **Diagnostics 1** parameter (**diagnostics_1**) to Diagnostics 5 (**diagnostics 5**). If more than 5 messages are pending, the messages with the highest priority are shown on the display.
- You can view the last alarm that is no longer active via the **Previous diagnostics** parameter (**previous_diagnostics**).

12.10 Diagnostic list

Up to 5 currently pending diagnostic events are displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list



A0014006-EN

42 Using the example of the local display

i Accessing the remedial action for a diagnostic event:

- Via local display → 165
- Via web browser → 167
- Via "FieldCare" operating tool → 168
- Via "DeviceCare" operating tool → 168


12.11 Event logbook

12.11.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Event logbook** submenu.

Navigation path

Diagnostics menu → **Event logbook** submenu → Event logbook



A0014008-EN

43 Using the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event logbook can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events → 174
- Information events → 198

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostic event
 - ☹: Occurrence of the event
 - ☺: End of the event
- Information event
 - ☹: Occurrence of the event

i Accessing the remedial action for a diagnostic event:

- Via local display → 165
- Via web browser → 167
- Via "FieldCare" operating tool → 168
- Via "DeviceCare" operating tool → 168

i Filtering the displayed event messages → 198

12.11.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

| Info number | Info name |
|-------------|--|
| I1000 | ----- (Device ok) |
| I1079 | Sensor changed |
| I1089 | Power on |
| I1090 | Configuration reset |
| I1091 | Configuration changed |
| I1092 | Embedded HistoROM deleted |
| I1111 | Density adjust failure |
| I1137 | Electronic changed |
| I1151 | History reset |
| I1155 | Reset electronic temperature |
| I1156 | Memory error trend |
| I1157 | Memory error event list |
| I1184 | Display connected |
| I1209 | Density adjustment ok |
| I1221 | Zero point adjust failure |
| I1222 | Zero point adjustment ok |
| I1256 | Display: access status changed |
| I1278 | I/O module reset detected |
| I1335 | Firmware changed |
| I1361 | Web server login failed |
| I1397 | Fieldbus: access status changed |
| I1398 | CDI: access status changed |
| I1444 | Device verification passed |
| I1445 | Device verification failed |
| I1447 | Record application reference data |
| I1448 | Application reference data recorded |
| I1449 | Recording application ref. data failed |
| I1450 | Monitoring off |

| Info number | Info name |
|-------------|--|
| I1451 | Monitoring on |
| I1457 | Measured error verification failed |
| I1459 | I/O module verification failed |
| I1460 | HBSI verification failed |
| I1461 | Sensor verification failed |
| I1462 | Sensor electronic module verific. failed |
| I1512 | Download started |
| I1513 | Download finished |
| I1514 | Upload started |
| I1515 | Upload finished |
| I1618 | I/O module replaced |
| I1619 | I/O module replaced |
| I1621 | I/O module replaced |
| I1622 | Calibration changed |
| I1624 | Reset all totalizers |
| I1625 | Write protection activated |
| I1626 | Write protection deactivated |
| I1627 | Web server login successful |
| I1628 | Display login successful |
| I1629 | CDI login successful |
| I1631 | Web server access changed |
| I1632 | Display login failed |
| I1633 | CDI login failed |
| I1634 | Parameter factory reset |
| I1635 | Parameter delivery reset |
| I1637 | FOUNDATION Fieldbus specific reset done |
| I1639 | Max. switch cycles number reached |
| I1649 | Hardware write protection activated |
| I1650 | Hardware write protection deactivated |
| I1712 | New flash file received |
| I1725 | Sensor electronic module (ISEM) changed |
| I1726 | Configuration backup failed |

12.12 Device reset

The entire device configuration or some of the configuration can be reset to a defined state with the **Restart** parameter.

12.12.1 Function scope of "Restart" parameter

| Options | Description |
|---------------|--|
| Uninitialized | The selection has no effect on the device. |
| Run | The selection has no effect on the device. |
| Resource | The selection has no effect on the device. |

| Options | Description |
|----------------------|---|
| Defaults | All FOUNDATION Fieldbus blocks are reset to their factory settings. Example: Analog Input Channel to the Uninitialized option. |
| Processor | The device is restarted. |
| To delivery settings | Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information) and device parameters for which a customer-specific default setting was ordered are reset to this customer-specific value. |

12.12.2 Function scope of "Service reset" parameter

| Options | Description |
|----------------------------|---|
| Uninitialized | The selection has no effect on the device. |
| To delivery settings + MIB | Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information, device tag and device address) and the device parameters for which a customer-specific default setting was ordered, are reset to this customer-specific value. |
| ENP restart | The parameters of the electronic name plate are reset. The device is restarted. |

12.13 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu → Device information

► Device information

Device tag

Serial number

Device name

Firmware version

Order code

Extended order code 1

Extended order code 2

ENP version

→ ⓘ 201

→ ⓘ 201

→ ⓘ 201

→ ⓘ 201





→ ⓘ 201

→ ⓘ 201

→ ⓘ 201

→ ⓘ 201

Parameter overview with brief description

| Parameter | Description | User entry / User interface | Factory setting |
|-----------------------|--|---|-----------------|
| Device tag | Enter the name for the measuring point. | Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /) | – |
| Serial number | Displays the serial number of the measuring device. | Max. 11-digit character string comprising letters and numbers. | – |
| Device name | Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter. | Promass 300/500 | – |
| Firmware version | Shows the device firmware version installed. | Character string with the following format: xx.yy.zz | – |
| Order code | Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field. | Character string composed of letters, numbers and certain punctuation marks | – |
| Extended order code 1 | Shows the 1st part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| Extended order code 2 | Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| ENP version | Shows the version of the electronic nameplate (ENP). | Character string in the format xx.yy.zz | – |

12.14 Firmware history

| Release date | Firmware version | Order code for "Firmware version" | Firmware Changes | Documentation type | Documentation |
|--------------|------------------|-----------------------------------|-------------------|------------------------|----------------------|
| 02.2017 | 01.00.zz | Option 74 | Original firmware | Operating instructions | BA01561D/06/EN/01.16 |



It is possible to flash the firmware to the current version or an existing previous version via the service interface.



For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

- In the Download Area of the Endress+Hauser Web site: www.endress.com → Downloads
- Specify the following details:
 - Product root: e.g. 8E5B
The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance work

No special maintenance work is required.

13.1.1 Cleaning

Cleaning of surfaces not in contact with the medium

1. Recommendation: Use a lint-free cloth that is either dry or slightly dampened using water.
2. Do not use sharp objects or aggressive cleaning agents that could damage surfaces (e.g. displays, housing) and seals.
3. Do not use high-pressure steam.
4. Ensure compliance with the protection class of the device.

NOTICE

Cleaning agents can damage the surfaces!

Incorrect cleaning agents can damage the surfaces!

- Do not use cleaning agents containing concentrated mineral acids, alkalis or organic solvents e.g. benzyl alcohol, methylene chloride, xylene, concentrated glycerol cleaners or acetone.

Cleaning of surfaces in contact with the medium

Note the following for cleaning and sterilization in place (CIP/SIP):


- Use only cleaning agents to which the materials in contact with the medium are sufficiently resistant.
- Observe the permitted maximum medium temperature.

13.2 Measuring and test equipment

Endress+Hauser offers a variety of measuring and testing equipment, such as Netilion or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: →  208

13.3 Maintenance services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and conversion of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ▶ Carry out the repair according to the Installation Instructions.
- ▶ Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document all repairs and conversions and enter the details in Netilion Analytics.

14.2 Spare parts

Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu.

14.3 Repair services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the web page for information: <https://www.endress.com>
2. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging provides the best protection.

14.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring instrument

1. Switch off the device.

WARNING

Danger to persons from process conditions!

- ▶ Beware of hazardous process conditions such as pressure in the measuring instrument, high temperatures or aggressive media.

2. Carry out the installation and connection steps from the "Installing the device" and "Connecting the device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring instrument

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:













- ▶ Observe valid federal/national regulations.
- ▶ Ensure proper separation and reuse of the device components.





15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



15.1 Device-specific accessories

15.1.1 For the transmitter



| Accessory | Description |
|--|---|
| Transmitter <ul style="list-style-type: none"> ■ Proline 500 – digital ■ Proline 500 | Transmitter for replacement or storage. Use the order code to define the following specifications: <ul style="list-style-type: none"> ■ Approvals ■ Output ■ Input ■ Display/operation ■ Housing ■ Software <div>  <ul style="list-style-type: none"> ■ Proline 500 – digital transmitter: Order number: 8X5BXX-*****A ■ Proline 500 transmitter: Order number: 8X5BXX-*****B </div> <div>  Proline 500 transmitter for replacement: It is essential to specify the serial number of the current transmitter when ordering. On the basis of the serial number, the device-specific data (e.g. calibration factors) of the replaced device can be used for the new transmitter. </div> <div>  <ul style="list-style-type: none"> ■ Proline 500 – digital transmitter: Installation Instructions EA01151D ■ Proline 500 transmitter: Installation Instructions EA01152D </div> |
| External WLAN antenna | External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area". <div>  <ul style="list-style-type: none"> ■ The external WLAN antenna is not suitable for use in hygienic applications. ■ Further information on the WLAN interface →  82. </div> <div>  Order number: 71351317 </div> <div>  Installation Instructions EA01238D </div> |
| Pipe mounting set | Pipe mounting set for transmitter. <div>  Proline 500 – digital transmitter Order number: 71346427 </div> <div>  Installation Instructions EA01195D </div> <div>  Proline 500 transmitter Order number: 71346428 </div> |
| Protective cover Transmitter <ul style="list-style-type: none"> ■ Proline 500 – digital ■ Proline 500 | Is used to protect the measuring instrument from the effects of the weather: e.g. rainwater, excess heating from direct sunlight. <div>  <ul style="list-style-type: none"> ■ Proline 500 – digital transmitter Order number: 71343504 ■ Proline 500 transmitter Order number: 71343505 </div> <div>  Installation Instructions EA01191D </div> |



| | |
|--|--|
| Display guard Proline 500 – digital | <p>Is used to protect the display against impact or scoring, for example from sand in desert areas.</p> <p> Order number: 71228792</p> <p> Installation Instructions EA01093D</p> |
| Connecting cable Proline 500 – digital Sensor – Transmitter | <p>The connecting cable can be ordered directly with the measuring instrument (order code for "Cable, sensor connection") or as an accessory (order number DK8012).</p> <p>The following cable lengths are available: order code for "Cable, sensor connection"</p> <ul style="list-style-type: none"> ■ Option B: 20 m (65 ft) ■ Option E: User-configurable up to max. 50 m ■ Option F: User-configurable up to max. 165 ft <p> Maximum possible cable length for a Proline 500 – digital connecting cable: 300 m (1 000 ft)</p> |
| Connecting cable Proline 500 Sensor – Transmitter | <p>The connecting cable can be ordered directly with the measuring instrument (order code for "Cable, sensor connection") or as an accessory (order number DK8012).</p> <p>The following cable lengths are available: order code for "Cable, sensor connection"</p> <ul style="list-style-type: none"> ■ Option 1: 5 m (16 ft) ■ Option 2: 10 m (32 ft) ■ Option 3: 20 m (65 ft) <p> Possible cable length for a Proline 500 connecting cable: max. 20 m (65 ft)</p> |

15.1.2 For the sensor



| Accessories | Description |
|----------------|---|
| Heating jacket | <p>Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids.</p> <p> If using oil as a heating medium, please consult with Endress+Hauser.</p> <p>Heating jackets cannot be used with sensors fitted with a rupture disk. Use the order code with the product root DK8003.</p> <p> Special Documentation SD02151D</p> |

15.2 Communication-specific accessories





| Accessories | Description |
|-------------------|--|
| Fieldgate FXA42 | <p>Transmission of the measured values of connected 4 to 20 mA analog measuring instruments, as well as digital measuring instruments</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI01297S ■ Operating Instructions BA01778S ■ Product page: www.endress.com/fxa42 </p> |
| Field Xpert SMT50 | <p>The Field Xpert SMT50 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.</p> <p>This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI01555S ■ Operating Instructions BA02053S ■ Product page: www.endress.com/smt50 </p> |

| | |
|-------------------|--|
| Field Xpert SMT70 | <p>The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.</p> <p>This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI01342S ■ Operating Instructions BA01709S ■ Product page: www.endress.com/smt70 </p> |
| Field Xpert SMT77 | <p>The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI01418S ■ Operating Instructions BA01923S ■ Product page: www.endress.com/smt77 </p> |

15.3 Service-specific accessories

| Accessory | Description |
|------------|--|
| Applicator | <p>Software for selecting and sizing Endress+Hauser measuring instruments:</p> <ul style="list-style-type: none"> ■ Choice of measuring instruments for industrial requirements ■ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and measurement accuracy. ■ Graphic display of the calculation results ■ Determining the partial order code. Administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. <p>Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator</p> |
| Netilion | <p>IIoT ecosystem: Unlock knowledge</p> <p>With the Netilion IIoT ecosystem, Endress+Hauser allows you to optimize your plant performance, digitize workflows, share knowledge, and enhance collaboration.</p> <p>Based on decades of experience in process automation, Endress+Hauser offers the process industry an IIoT ecosystem that enables you to gain useful insights from data. These insights can be used to optimize processes, leading to increased plant availability, efficiency, and reliability - ultimately resulting in a more profitable plant.</p> <p>www.netilion.endress.com</p> |
| FieldCare | <p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> Operating Instructions BA00027S and BA00059S</p> |
| DeviceCare | <p>Tool to connect and configure Endress+Hauser field devices.</p> <p> <ul style="list-style-type: none"> ■ Technical Information: TI01134S ■ Innovation brochure: IN01047S </p> |

15.4 System components


| Accessories | Description |
|----------------------------------|--|
| Memograph M graphic data manager | <p>The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI00133R ■ Operating Instructions BA00247R </p> |
| Cerabar M | <p>The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI00426P and TI00436P ■ Operating Instructions BA00200P and BA00382P </p> |
| Cerabar S | <p>The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.</p> <p> <ul style="list-style-type: none"> ■ Technical Information TI00383P ■ Operating Instructions BA00271P </p> |
| iTEMP | <p>The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.</p> <p> "Fields of Activity" document FA00006T</p> |

16 Technical data

16.1 Application

The measuring device is intended only for the flow measurement of liquids and gases.
Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.
To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

| | |
|---------------------|---|
| Measuring principle | Mass flow measurement based on the Coriolis measuring principle |
| Measuring system | <p>The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.</p> <p>For information on the structure of the measuring instrument →  14</p> |

16.3 Input

Measured variable

Direct measured variables

- Mass flow
- Density
- Temperature

Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

Measuring range

Measuring range for liquids

| DN | | Measuring range full scale values $\dot{m}_{\min(F)}$ to $\dot{m}_{\max(F)}$ | |
|------|----------------|--|------------|
| [mm] | [in] | [kg/h] | [lb/min] |
| 8 | $\frac{3}{8}$ | 0 to 2 000 | 0 to 73.50 |
| 15 | $\frac{1}{2}$ | 0 to 6 500 | 0 to 238.9 |
| 25 | 1 | 0 to 18 000 | 0 to 661.5 |
| 40 | $1\frac{1}{2}$ | 0 to 45 000 | 0 to 1 654 |
| 50 | 2 | 0 to 70 000 | 0 to 2 573 |
| 80 | 3 | 0 to 180 000 | 0 to 6 615 |

Measuring range for gases

The full scale value depends on the density and the speed of sound of the gas used. The full scale value can be calculated with the following formulas:

$$\dot{m}_{\max(G)} = \text{minimum of } (\dot{m}_{\max(F)} \cdot \rho_G : x) \text{ and } (\rho_G \cdot (c_G/2) \cdot d_i^2 \cdot (\pi/4) \cdot 3600 \cdot n)$$

| | |
|---|---|
| $\dot{m}_{\max(G)}$ | Maximum full scale value for gas [kg/h] |
| $\dot{m}_{\max(F)}$ | Maximum full scale value for liquid [kg/h] |
| $\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$ | $\dot{m}_{\max(G)}$ can never be greater than $\dot{m}_{\max(F)}$ |
| ρ_G | Gas density in [kg/m ³] at operating conditions |
| x | Limitation constant for max. gas flow [kg/m ³] |
| c_G | Speed of sound (gas) [m/s] |
| d_i | Measuring tube internal diameter [m] |
| π | Pi |
| $n = 2$ | Number of measuring tubes |



| DN | | x |
|------|---------------|----------------------|
| [mm] | [in] | [kg/m ³] |
| 8 | $\frac{3}{8}$ | 85 |
| 15 | $\frac{1}{2}$ | 110 |
| 25 | 1 | 125 |

| DN | | x |
|------|------|---------|
| [mm] | [in] | [kg/m³] |
| 40 | 1½ | 125 |
| 50 | 2 | 125 |
| 80 | 3 | 155 |

If calculating the full scale value using the two formulas:

1. Calculate the full scale value with both formulas.
2. The smaller value is the value that must be used.

Recommended measuring range

 Flow limit →  228

Operable flow range

Over 1000 : 1.



Flow rates above the preset full scale value do not override the electronics unit, with the result that the totalizer values are registered correctly.

Input signal

External measured values


To increase the measurement accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write different measured values to the measuring instrument:

- Operating pressure to increase measurement accuracy (Endress+Hauser recommends the use of a pressure measuring instrument for absolute pressure, e.g. Cerabar M or Cerabar S)
- Medium temperature to increase measurement accuracy (e.g. iTEMP)
- Reference density for calculating the corrected volume flow for gases

 Various pressure and temperature measuring devices can be ordered from Endress +Hauser: see "Accessories" section →  209

It is recommended to read in external measured values to calculate the corrected volume flow.

Current input

The measured values are written from the automation system to the measuring device via the current input →  212.

Digital communication

The measured values are written by the automation system via FOUNDATION fieldbus.

Current input 0/4 to 20 mA

| | |
|-----------------------|---|
| Current input | 0/4 to 20 mA (active/passive) |
| Current span | <ul style="list-style-type: none"> ■ 4 to 20 mA (active) ■ 0/4 to 20 mA (passive) |
| Resolution | 1 µA |
| Voltage drop | Typically: 0.6 to 2 V for 3.6 to 22 mA (passive) |
| Maximum input voltage | ≤ 30 V (passive) |

| | |
|---------------------------------|--|
| Open-circuit voltage | ≤ 28.8 V (active) |
| Possible input variables | <ul style="list-style-type: none"> ■ Pressure ■ Temperature ■ Density |

Status input

| | |
|-----------------------------|--|
| Maximum input values | <ul style="list-style-type: none"> ■ DC -3 to 30 V ■ If status input is active (ON): $R_i > 3 \text{ k}\Omega$ |
| Response time | Configurable: 5 to 200 ms |
| Input signal level | <ul style="list-style-type: none"> ■ Low signal: DC -3 to +5 V ■ High signal: DC 12 to 30 V |
| Assignable functions | <ul style="list-style-type: none"> ■ Off ■ Reset the individual totalizers separately ■ Reset all totalizers ■ Flow override |


16.4 Output

Output signal

FOUNDATION Fieldbus


| | |
|--------------------------|---|
| FOUNDATION Fieldbus | H1, IEC 61158-2, galvanically isolated |
| Data transfer | 31.25 kbit/s |
| Current consumption | 10 mA |
| Permitted supply voltage | 9 to 32 V |
| Bus connection | With integrated reverse polarity protection |

Current output 4 to 20 mA



| | |
|-------------------------------|--|
| Signal mode | Can be set to: <ul style="list-style-type: none"> ■ Active ■ Passive |
| Current range | Can be set to: <ul style="list-style-type: none"> ■ 4 to 20 mA NAMUR ■ 4 to 20 mA US ■ 4 to 20 mA ■ 0 to 20 mA (only if the signal mode is active) ■ Fixed current |
| Maximum output values | 22.5 mA |
| Open-circuit voltage | DC 28.8 V (active) |
| Maximum input voltage | DC 30 V (passive) |
| Load | 0 to 700 Ω |
| Resolution | 0.38 µA |
| Damping | Configurable: 0 to 999.9 s |
| Assignable measured variables | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Electronics temperature ■ Oscillation frequency 0 ■ Oscillation damping 0 ■ Signal asymmetry ■ Exciter current 0 <p> The range of options increases if the measuring device has one or more application packages.</p> |



Current output 4 to 20 mA Ex i passive

| | |
|-----------------------|---|
| Order code | "Output; input 2" (21), "Output; input 3" (022): Option C: current output 4 to 20 mA Ex i passive |
| Signal mode | Passive |
| Current range | Can be set to: <ul style="list-style-type: none"> ■ 4 to 20 mA NAMUR ■ 4 to 20 mA US ■ 4 to 20 mA ■ Fixed current |
| Maximum output values | 22.5 mA |
| Maximum input voltage | DC 30 V |

| | |
|--------------------------------------|--|
| Load | 0 to 700 Ω |
| Resolution | 0.38 μ A |
| Damping | Configurable: 0 to 999 s |
| Assignable measured variables | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Electronics temperature ■ Oscillation frequency 0 ■ Oscillation damping 0 ■ Signal asymmetry ■ Exciter current 0 <p> The range of options increases if the measuring device has one or more application packages.</p> |


Pulse/frequency/switch output

| | |
|--------------------------------------|---|
| Function | Can be configured as pulse, frequency or switch output |
| Version | Open collector Can be set to: <ul style="list-style-type: none"> ■ Active ■ Passive ■ Passive NAMUR <p> Ex-i, passive</p> |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Open-circuit voltage | DC 28.8 V (active) |
| Voltage drop | For 22.5 mA: \leq DC 2 V |
| Pulse output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Maximum output current | 22.5 mA (active) |
| Open-circuit voltage | DC 28.8 V (active) |
| Pulse width | Configurable: 0.05 to 2 000 ms |
| Maximum pulse rate | 10 000 Impulse/s |
| Pulse value | Configurable |
| Assignable measured variables | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow <p> The range of options increases if the measuring device has one or more application packages.</p> |
| Frequency output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Maximum output current | 22.5 mA (active) |
| Open-circuit voltage | DC 28.8 V (active) |
| Output frequency | Configurable: end value frequency 2 to 10 000 Hz ($f_{\max} = 12\,500$ Hz) |
| Damping | Configurable: 0 to 999.9 s |
| Pulse/pause ratio | 1:1 |

| | |
|--------------------------------------|--|
| Assignable measured variables | <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Electronics temperature ■ Oscillation frequency 0 ■ Oscillation damping 0 ■ Signal asymmetry ■ Exciter current 0 <p> The range of options increases if the measuring device has one or more application packages.</p> |
| Switch output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Open-circuit voltage | DC 28.8 V (active) |
| Switching behavior | Binary, conductive or non-conductive |
| Switching delay | Configurable: 0 to 100 s |
| Number of switching cycles | Unlimited |
| Assignable functions | <ul style="list-style-type: none"> ■ Disable ■ On ■ Diagnostic behavior ■ Limit <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Totalizer 1-3 ■ Flow direction monitoring ■ Status <ul style="list-style-type: none"> ■ Partially filled pipe detection ■ Low flow cut off <p> The range of options increases if the measuring device has one or more application packages.</p> |

Relay output

| | |
|---------------------------|--|
| Function | Switch output |
| Version | Relay output, galvanically isolated |
| Switching behavior | Can be set to: <ul style="list-style-type: none"> ■ NO (normally open), factory setting ■ NC (normally closed) |

| | |
|---|--|
| Maximum switching capacity (passive) | <ul style="list-style-type: none"> ■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A |
| Assignable functions | <ul style="list-style-type: none"> ■ Disable ■ On ■ Diagnostic behavior ■ Limit <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Totalizer 1-3 ■ Flow direction monitoring ■ Status <ul style="list-style-type: none"> ■ Partially filled pipe detection ■ Low flow cut off <p> The range of options increases if the measuring device has one or more application packages.</p> |

User-configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm

Depending on the interface, failure information is displayed as follows:

FOUNDATION Fieldbus

| | |
|---|---------------------------------------|
| Status and alarm messages | Diagnostics in accordance with FF-891 |
| Failure current FDE (Fault Disconnection Electronic) | 0 mA |

Current output

| Current output 4-20 mA | |
|------------------------|--|
| Failure mode | Configurable: <ul style="list-style-type: none"> ■ 4 to 20 mA in accordance with NAMUR recommendation NE 43 ■ 4 to 20 mA in accordance with US ■ Min. value: 3.59 mA ■ Max. value: 22.5 mA ■ Definable value between: 3.59 to 22.5 mA ■ Actual value ■ Last valid value |
| Current output 4-20 mA | |
| Failure mode | Configurable: <ul style="list-style-type: none"> ■ Maximum alarm: 22 mA ■ Definable value between: 0 to 20.5 mA |

Pulse/frequency/switch output

| Pulse output | |
|------------------|---|
| Failure mode | Configurable: <ul style="list-style-type: none"> Actual value No pulses |
| Frequency output | |
| Failure mode | Configurable: <ul style="list-style-type: none"> Actual value 0 Hz Definable value between: 2 to 12 500 Hz |
| Switch output | |
| Failure mode | Configurable: <ul style="list-style-type: none"> Current status Open Closed |

Relay output

| | |
|--------------|---|
| Failure mode | Choose from: <ul style="list-style-type: none"> Current status Open Closed |
|--------------|---|

Local display

| | |
|--------------------|---|
| Plain text display | With information on cause and remedial measures |
| Backlight | Red lighting indicates a device error. |



Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication:
 - FOUNDATION Fieldbus
- Via service interface
 - Service interface CDI-RJ45
 - WLAN interface
- Plain text display
 - With information on cause and remedial actions

Web browser

| | |
|--------------------|---|
| Plain text display | With information on cause and remedial measures |
|--------------------|---|

LEDs


| | |
|--------------------|---|
| Status information | Status indicated by various LEDs The following information is displayed depending on the device version: <ul style="list-style-type: none"> Supply voltage active Data transmission active Device alarm/error has occurred Diagnostic information via LEDs → 162 |
|--------------------|---|

Low flow cut off The switch points for low flow cut off are user-selectable.

Galvanic isolation The outputs are galvanically isolated:


- from the power supply
- from one another
- from the protective ground connection (PE)


protocol-specific data

| | |
|---|---|
| Manufacturer ID | 0x452B48 (hex) |
| Ident number | 0x103B (hex) |
| Device revision | 1 |
| DD revision | Information and files under: <ul style="list-style-type: none"> ■ www.endress.com ■ www.fieldcommgroup.org |
| CFF revision | |
| Interoperability Test Kit (ITK) | Version 6.2.0 |
| ITK Test Campaign Number | Information: <ul style="list-style-type: none"> ■ www.endress.com ■ www.fieldcommgroup.org |
| Link Master capability (LAS) | Yes |
| Choice of "Link Master" and "Basic Device" | Yes Factory setting: Basic Device |
| Node address | Factory setting: 247 (0xF7) |
| Supported functions | The following methods are supported: <ul style="list-style-type: none"> ■ Restart ■ ENP Restart ■ Diagnostic ■ Set to OOS ■ Set to AUTO ■ Read trend data ■ Read event logbook |
| Virtual Communication Relationships (VCRs) | |
| Number of VCRs | 44 |
| Number of link objects in VFD | 50 |
| Permanent entries | 1 |
| Client VCRs | 0 |
| Server VCRs | 10 |
| Source VCRs | 43 |
| Sink VCRs | 0 |
| Subscriber VCRs | 43 |
| Publisher VCRs | 43 |
| Device Link Capabilities | |
| Slot time | 4 |
| Min. delay between PDU | 8 |
| Max. response delay | 16 |
| System integration | Information regarding system integration →  86. <ul style="list-style-type: none"> ■ Cyclic data transmission ■ Description of the modules ■ Execution times ■ Methods |

16.5 Power supply

Terminal assignment →  39

Available device plugs →  39

Available device plugs →  40

Supply voltage

| Order code for "Power supply" | Terminal voltage | | Frequency range |
|-------------------------------|------------------|------------|-----------------|
| Option D | DC 24 V | ±20% | – |
| Option E | AC 100 to 240 V | –15 to 10% | 50/60 Hz |
| Option I | DC 24 V | ±20% | – |
| | AC 100 to 240 V | –15 to 10% | 50/60 Hz |

Power consumption

Transmitter

Max. 10 W (active power)

| | |
|-------------------|---|
| switch-on current | Max. 36 A (<5 ms) as per NAMUR Recommendation NE 21 |
|-------------------|---|

Current consumption

Transmitter

- Max. 400 mA (24 V)
- Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)

Power supply failure



- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Overcurrent protection element

The device must be operated with a dedicated circuit breaker, as it does not have an ON/OFF switch of its own.

- The circuit breaker must be easy to reach and labeled accordingly.
- Permitted nominal current of the circuit breaker: 2 A up to maximum 10 A.

Electrical connection

- →  42
- →  49

Potential equalization


→  55

Terminals



Spring-loaded terminals: Suitable for strands and strands with ferrules.
Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

| | |
|---------------|---|
| Cable entries | <ul style="list-style-type: none"> ■ Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) ■ Thread for cable entry: <ul style="list-style-type: none"> ■ NPT ½" ■ G ½" ■ M20 ■ Device plug for digital communication: M12 ■ Device plug for connecting cable: M12 <p>A device plug is always used for the device version with the order code for "Sensor connection housing", option C "Ultra-compact, hygienic, stainless".</p> |
|---------------|---|

Cable specification →  35

| | | |
|------------------------|-----------------------------------|---|
| Overvoltage protection | Mains voltage fluctuations | →  220 |
| | Overvoltage category | Overvoltage category II |
| | Short-term, temporary overvoltage | Between cable and ground up to 1200 V, for max. 5 s |
| | Long-term, temporary overvoltage | Between cable and ground up to 500 V |

16.6 Performance characteristics

| | |
|--------------------------------|--|
| Reference operating conditions | <ul style="list-style-type: none"> ■ Error limits based on ISO 11631 ■ Water <ul style="list-style-type: none"> ■ +15 to +45 °C (+59 to +113 °F) ■ 2 to 6 bar (29 to 87 psi) ■ Data as indicated in the calibration protocol ■ Accuracy based on accredited calibration rigs according to ISO 17025 <p> To obtain measured errors, use the <i>Applicator</i> sizing tool →  208</p> |
|--------------------------------|--|

Maximum measurement error o.r. = of reading; 1 g/cm³ = 1 kg/l; T = medium temperature

Base accuracy

 Design fundamentals →  224

Mass flow and volume flow (liquids)

±0.15 % o.r.

±0.10 % o.r. (order code for "Calibration flow", option A, B, C, for mass flow)

Mass flow (gases)

±0.50 % o.r.

Density (liquids)

| Under reference conditions [g/cm ³] | Standard density calibration [g/cm ³] |
|--|--|
| ±0.0005 | ±0.002 |

Temperature

±0.5 °C ± 0.005 · T °C (±0.9 °F ± 0.003 · (T – 32) °F)

Zero point stability

| DN | | Zero point stability | |
|------|---------------|----------------------|----------|
| [mm] | [in] | [kg/h] | [lb/min] |
| 8 | $\frac{3}{8}$ | 0.20 | 0.007 |
| 15 | $\frac{1}{2}$ | 0.65 | 0.024 |
| 25 | 1 | 1.80 | 0.066 |
| 40 | 1½ | 4.50 | 0.165 |
| 50 | 2 | 7.0 | 0.257 |
| 80 | 3 | 18.0 | 0.6615 |

Flow values

Flow values as turndown parameters depending on nominal diameter.

SI units

| DN | 1:1 | 1:10 | 1:20 | 1:50 | 1:100 | 1:500 |
|------|---------|--------|--------|--------|--------|--------|
| [mm] | [kg/h] | [kg/h] | [kg/h] | [kg/h] | [kg/h] | [kg/h] |
| 8 | 2 000 | 200 | 100 | 40 | 20 | 4 |
| 15 | 6 500 | 650 | 325 | 130 | 65 | 13 |
| 25 | 18 000 | 1 800 | 900 | 360 | 180 | 36 |
| 40 | 45 000 | 4 500 | 2 250 | 900 | 450 | 90 |
| 50 | 70 000 | 7 000 | 3 500 | 1 400 | 700 | 140 |
| 80 | 180 000 | 18 000 | 9 000 | 3 600 | 1 800 | 360 |

US units

| DN | 1:1 | 1:10 | 1:20 | 1:50 | 1:100 | 1:500 |
|---------------|----------|----------|----------|----------|----------|----------|
| [inch] | [lb/min] | [lb/min] | [lb/min] | [lb/min] | [lb/min] | [lb/min] |
| $\frac{3}{8}$ | 73.50 | 7.350 | 3.675 | 1.470 | 0.735 | 0.147 |
| $\frac{1}{2}$ | 238.9 | 23.89 | 11.95 | 4.778 | 2.389 | 0.478 |
| 1 | 661.5 | 66.15 | 33.08 | 13.23 | 6.615 | 1.323 |
| 1½ | 1 654 | 165.4 | 82.70 | 33.08 | 16.54 | 3.308 |
| 2 | 2 573 | 257.3 | 128.7 | 51.46 | 25.73 | 5.146 |
| 3 | 6 615 | 661.5 | 330.8 | 132.3 | 66.15 | 13.23 |

Accuracy of outputs

The outputs have the following base accuracy specifications:

Current output

| | |
|----------|-------|
| Accuracy | ±5 µA |
|----------|-------|


Pulse/frequency output

o.r. = of reading

| | |
|----------|---|
| Accuracy | Max. ±50 ppm o.r. (over the entire ambient temperature range) |
|----------|---|

Repeatability o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability

 Design fundamentals →  224

Mass flow and volume flow (liquids)

$\pm 0.075 \%$ o.r.

$\pm 0.05 \%$ o.r. (calibration option, for mass flow)

Mass flow (gases)

$\pm 0.25 \%$ o.r. (up to a Mach number of 0.2)

Density (liquids)

$\pm 0.00025 \text{ g/cm}^3$

Temperature

$\pm 0.25 \text{ }^\circ\text{C} \pm 0.0025 \cdot T \text{ }^\circ\text{C}$ ($\pm 0.45 \text{ }^\circ\text{F} \pm 0.0015 \cdot (T-32) \text{ }^\circ\text{F}$)

Response time The response time depends on the configuration (damping).

Influence of ambient temperature

Current output

| | |
|-------------------------|--|
| Temperature coefficient | Max. $1 \text{ } \mu\text{A}/^\circ\text{C}$ |
|-------------------------|--|

Pulse/frequency output

| | |
|-------------------------|---|
| Temperature coefficient | No additional effect. Included in accuracy. |
|-------------------------|---|

Influence of medium temperature

Mass flow


o.f.s. = of full scale value

If there is a difference between the temperature during zero adjustment and the process temperature, the additional measurement error of the sensors is typically $\pm 0.0002 \%$ o.f.s./ $^\circ\text{C}$ ($\pm 0.0001 \%$ o. f.s./ $^\circ\text{F}$).

The influence is reduced when the zero adjustment is performed at process temperature.

Density

If there is a difference between the density calibration temperature and the process temperature, the measurement error of the sensors is typically $\pm 0.0001 \text{ g/cm}^3/^\circ\text{C}$ ($\pm 0.00005 \text{ g/cm}^3/^\circ\text{F}$). Field density adjustment is possible.



44 Field density adjustment, for example at +20 °C (+68 °F)

Temperature
 $\pm 0.005 \cdot T \text{ }^{\circ}\text{C}$ ($\pm 0.005 \cdot (T - 32) \text{ }^{\circ}\text{F}$)

Influence of medium pressure

The following shows how the process pressure (gauge pressure) affects the accuracy of the mass flow.

o.r. = of reading

- It is possible to compensate for the effect by:
- Reading in the current pressure measured value via the current input or a digital input.
 - Specifying a fixed value for the pressure in the device parameters.

Operating Instructions .

| DN | | [% o.r./bar] | [% o.r./psi] |
|------|------|--------------|--------------|
| [mm] | [in] | | |
| 8 | ⅜ | no effect | |
| 15 | ½ | no effect | |
| 25 | 1 | no effect | |
| 40 | 1½ | no effect | |
| 50 | 2 | -0.009 | -0.0006 |
| 80 | 3 | -0.020 | -0.0014 |

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

| Flow rate | Maximum measured error in % o.r. |
|--|--|
| $\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$ <small>A0021332</small> | $\pm \text{BaseAccu}$ <small>A0021339</small> |
| $< \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$ <small>A0021333</small> | $\pm \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$ <small>A0021334</small> |

Calculation of the maximum repeatability as a function of the flow rate

| Flow rate | Maximum repeatability in % o.r. |
|--|--|
| $\geq \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$ <small>A0021335</small> | $\pm \text{BaseRepeat}$ <small>A0021340</small> |
| $< \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$ <small>A0021336</small> | $\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$ <small>A0021337</small> |

Example of maximum measurement error



E Maximum measurement error in % o.r. (example)
Q Flow rate in % of maximum full scale value



16.7 Installation

Installation requirements → 22

16.8 Environment

Ambient temperature range → 25

Temperature tables

-  Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.
-  For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature -50 to +80 °C (-58 to +176 °F)

Climate class DIN EN 60068-2-38 (test Z/AD)

Relative humidity The device is suitable for use in outdoor and indoor areas with a relative humidity of 4 to 95%.

Operating height According to EN 61010-1
≤ 2 000 m (6 562 ft)

Degree of protection

Transmitter

- IP66/67, Type 4X enclosure, suitable for pollution degree 4
- When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2
- Display module: IP20, Type 1 enclosure, suitable for pollution degree 2

Sensor

- IP66/67, Type 4X enclosure, suitable for pollution degree 4
- When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2

Optional

Order code for "Sensor options", option CM "IP69"

External WLAN antenna

IP66/67, type 4X enclosure

Vibration resistance and shock resistance

Sinusoidal vibration similar to IEC 60068-2-6

Sensor

- 2 to 8.4 Hz, 3.5 mm peak
- 8.4 to 2 000 Hz, 1 g peak

Transmitter

- 2 to 8.4 Hz, 7.5 mm peak
- 8.4 to 2 000 Hz, 2 g peak

Broadband random vibration similar to IEC 60068-2-64

Sensor

- 10 to 200 Hz, 0.003 g²/Hz
- 200 to 2 000 Hz, 0.001 g²/Hz
- Total: 1.54 g rms

Transmitter

- 10 to 200 Hz, 0.01 g²/Hz
- 200 to 2 000 Hz, 0.003 g²/Hz
- Total: 2.70 g rms

Half-sine shocks similar to IEC 60068-2-27

- Sensor
6 ms 30 g
- Transmitter
6 ms 50 g

Rough handling shocks similar to IEC 60068-2-31

Mechanical load

Transmitter housing and sensor connection housing:

- Protect against mechanical effects, such as shock or impact
- Do not use as a ladder or climbing aid

Electromagnetic compatibility (EMC)



Details are provided in the Declaration of Conformity.




This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.

16.9 Process

Medium temperature range -40 to $+150\text{ }^{\circ}\text{C}$ (-40 to $+302\text{ }^{\circ}\text{F}$)

Dependency of ambient temperature on medium temperature





45 Exemplary representation, values in the table below.

T_a Ambient temperature
 T_m Medium temperature

A Maximum permitted medium temperature T_m at $T_{a\text{ max}} = 60\text{ }^{\circ}\text{C}$ ($140\text{ }^{\circ}\text{F}$); higher medium temperatures T_m require a reduction in the ambient temperature T_a

B Maximum permitted ambient temperature T_a for the maximum specified medium temperature T_m of the sensor

 Values for devices that are used in the hazardous area:
Separate Ex documentation (XA) for the device →  241.


| Version | Not insulated | | | | Insulated | | | |
|-------------------------|--|---|-------|-------|--|---|-------|-------|
| | A | B | | | A | B | | |
| | T_a | T_m | T_a | T_m | T_a | T_m | T_a | T_m |
| Promass E 500 – digital | $60\text{ }^{\circ}\text{C}$ ($140\text{ }^{\circ}\text{F}$) | $150\text{ }^{\circ}\text{C}$ ($302\text{ }^{\circ}\text{F}$) | – | – | $60\text{ }^{\circ}\text{C}$ ($140\text{ }^{\circ}\text{F}$) | $150\text{ }^{\circ}\text{C}$ ($302\text{ }^{\circ}\text{F}$) | – | – |
| Promass E 500 | | | | | | | | |

Medium density 0 to $5\,000\text{ kg/m}^3$ (0 to 312 lb/cf)

Pressure/temperature ratings  For an overview of the pressure/temperature ratings for the process connections, see the Technical Information

Sensor housing

The sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.

 If a measuring tube fails (e.g. due to process characteristics like corrosive or abrasive fluids), the fluid will initially be contained by the sensor housing.

In the event of a tube failure, the pressure level inside the sensor housing will rise according to the operating process pressure. If the user judges that the sensor housing burst pressure does not provide an adequate safety margin, the device can be fitted with a rupture disk. This prevents excessively high pressure from forming inside the sensor


housing. Therefore, the use of a rupture disk is strongly recommended in applications involving high gas pressures, and particularly in applications in which the process pressure is greater than 2/3 of the sensor housing burst pressure.

Burst pressure of the sensor housing

If the device is fitted with a rupture disk (order code for "Sensor option", option CA "Rupture disk"), the rupture disk trigger pressure is decisive .

The sensor housing burst pressure refers to a typical internal pressure which is reached prior to mechanical failure of the sensor housing and which was determined during type testing. The corresponding type test declaration can be ordered with the device (order code for "Additional approval", option LN "Sensor housing burst pressure, type test").

| DN | | Sensor housing burst pressure | |
|------|------|-------------------------------|-------|
| [mm] | [in] | [bar] | [psi] |
| 8 | 3⁄8 | 250 | 3 620 |
| 15 | 1⁄2 | 250 | 3 620 |
| 25 | 1 | 250 | 3 620 |
| 40 | 1½ | 200 | 2 900 |
| 50 | 2 | 180 | 2 610 |
| 80 | 3 | 120 | 1 740 |

 For information on the dimensions: see the "Mechanical construction" section of the "Technical Information" document

Rupture disk

To increase the level of safety, a device version with a rupture disk with a trigger pressure of 10 to 15 bar (145 to 217.5 psi) can be used (order code for "Sensor option", option CA "rupture disk").

The use of rupture disks cannot be combined with the separately available heating jacket.



Internal cleaning

- CIP cleaning
- SIP cleaning

Options
Oil- and grease-free version for wetted parts, without declaration
Order code for "Service", option HA ²⁾

Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.

 For an overview of the full scale values for the measuring range, see the "Measuring range" section →  211

2) Cleaning only refers to the measuring instrument. Any accessories that have been supplied are not cleaned.

- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- For the most common applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
 - The flow velocity in the measuring tubes should not exceed half the speed of sound (0.5 Mach)
 - The maximum mass flow depends on the density of the gas: formula



To calculate the flow limit, use the *Applicator* sizing tool → 208

Pressure loss



To calculate the pressure loss, use the *Applicator* sizing tool → 208

System pressure

→ 25

16.10 Mechanical construction

Design, dimensions



For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

All values (weight exclusive of packaging material) refer to devices with EN/DIN PN 40 flanges.

Transmitter

- Proline 500 – digital polycarbonate: 1.4 kg (3.1 lbs)
- Proline 500 – digital aluminum: 2.4 kg (5.3 lbs)
- Proline 500 aluminum: 6.5 kg (14.3 lbs)

Sensor

Sensor with aluminum connection housing version:

Weight in SI units

| DN [mm] | Weight [kg] |
|------------|-------------|
| 8 | 4 |
| 15 | 4 |
| 25 | 6 |
| 40 | 10 |
| 50 | 15 |
| 80 | 29 |

Weight in US units

| DN [in] | Weight [lbs] |
|------------|--------------|
| 3/8 | 9 |
| 1/2 | 9 |
| 1 | 13 |

| DN [in] | Weight [lbs] |
|------------|--------------|
| 1½ | 22 |
| 2 | 33 |
| 3 | 64 |

Materials

Transmitter housing

Housing of Proline 500 – digital transmitter

Order code for "Transmitter housing":

- Option **A** "Aluminum coated": aluminum, AlSi10Mg, coated
- Option **D** "Polycarbonate": polycarbonate

Housing of Proline 500 transmitter

Order code for "Transmitter housing":

Option **A** "Aluminum coated": aluminum, AlSi10Mg, coated

Window material

Order code for "Transmitter housing":

- Option **A** "Aluminum, coated": glass
- Option **D** "Polycarbonate": plastic

Fixing components for pipe mounting



- Screws, threaded bolts, washers, nuts: stainless A2 (chrome-nickel steel)
- Metal plates: stainless steel, 1.4301 (304)

Sensor connection housing

Order code for "Sensor connection housing":

- Option **A** "Aluminum coated": aluminum, AlSi10Mg, coated
- Option **B** "Stainless":
 - Stainless steel 1.4301 (304)
 - Optional: Order code for "Sensor feature", option **CC** "Hygienic version, for maximum corrosion resistance": stainless steel, 1.4404 (316L)
- Option **C** "Ultra-compact, stainless":
 - Stainless steel 1.4301 (304)
 - Optional: Order code for "Sensor feature", option **CC** "Hygienic version, for maximum corrosion resistance": stainless steel, 1.4404 (316L)


Cable entries/cable glands

| Cable entries and adapters | Material |
|---|--------------------------------|
| Cable gland M20 × 1.5 | Plastic |
| <ul style="list-style-type: none"> Adapter for cable entry with female thread G ½" Adapter for cable entry with female thread NPT ½" <p> Only available for certain device versions:</p> <ul style="list-style-type: none"> Order code for "Transmitter housing": <ul style="list-style-type: none"> Option A "Aluminum, coated" Option D "Polycarbonate" Order code for "Sensor connection housing": <ul style="list-style-type: none"> Proline 500 – digital: <ul style="list-style-type: none"> Option A "Aluminum coated" Option B "Stainless" Proline 500: <ul style="list-style-type: none"> Option B "Stainless" | Nickel-plated brass |
| <p>Adapter for device plug</p> <p> Device plug for digital communication: Only available for certain device versions .</p> <ul style="list-style-type: none"> Device plug for connecting cable: A device plug is always used for the device version, order code for "Sensor connection housing", option C (ultra-compact, hygienic, stainless). | Stainless steel, 1.4404 (316L) |

Device plug

| Electrical connection | Material |
|-----------------------|---|
| Plug M12x1 | <ul style="list-style-type: none"> Socket: Stainless steel, 1.4404 (316L) Contact housing: Polyamide Contacts: Gold-plated brass |

Connecting cable

 UV radiation can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Connecting cable for sensor - Proline 500 – digital transmitter

PVC cable with copper shield

Connecting cable for sensor - Proline 500 transmitter

PVC cable with copper shield

Sensor housing



- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tubes

Stainless steel, 1.4539 (904L); manifold: stainless steel, 1.4404 (316L)

Process connections

- Flanges similar to EN 1092-1 (DIN2501) / similar to ASME B 16.5 / as per JIS B2220: Stainless steel, 1.4404 (F316/F316L)
- All other process connections: Stainless steel, 1.4404 (316/316L)

 Available process connections →  232

Seals

Welded process connections without internal seals

Accessories*Protective cover*

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Process connections

- Fixed flange connections:
 - EN 1092-1 (DIN 2501) flange
 - EN 1092-1 (DIN 2512N) flange
 - NAMUR lengths in accordance with NE 132
 - ASME B16.5 flange
 - JIS B2220 flange
 - DIN 11864-2 Form A flange, DIN 11866 series A, flange with notch
- Clamp connections:
 - Tri-Clamp (OD tubes), DIN 11866 series C
- Thread:
 - DIN 11851 thread, DIN 11866 series A
 - SMS 1145 thread
 - ISO 2853 thread, ISO 2037
 - DIN 11864-1 Form A thread, DIN 11866 series A
- VCO connections:
 - 8-VCO-4
 - 12-VCO-4



Process connection materials → 231

Surface roughness

All data relate to parts in contact with medium.

The following surface roughness categories can be ordered:

| Category | Method | Option(s)/Order code "Measuring tube mat., wetted surface" |
|---|--|---|
| Not polished | – | SA |
| $Ra \leq 0.76 \mu m$ (30 μin) ¹⁾ | Mechanically polished ²⁾ | SB |
| $Ra \leq 0.76 \mu m$ (30 μin) ¹⁾ | Mechanically polished ²⁾ , welds in as-welded condition | SJ |
| $Ra \leq 0.38 \mu m$ (15 μin) ¹⁾ | Mechanically polished ²⁾ | SC |
| $Ra \leq 0.38 \mu m$ (15 μin) ¹⁾ | Mechanically polished ²⁾ , welds in as-welded condition | SK |

1) Ra according to ISO 21920

2) Inaccessible weld seams between pipe and manifold are excluded

16.11 User interface

Languages

Can be operated in the following languages:

- Via local operation
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Vietnamese, Czech, Swedish
- Via web browser
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese


Onsite operation


Via display module

Equipment level:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"

 Information about WLAN interface →  82






 46 Operation with touch control

- 1 Proline 500 – digital
- 2 Proline 500


Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured


Operating elements

- External operation via touch control (3 optical keys) without opening the housing: , , 
- Operating elements also accessible in the various zones of the hazardous area

Remote operation




→  80

Service interface

→  81

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

| Supported operating tools | Operating unit | Interface | Additional information |
|---------------------------|--|---|--|
| Web browser | Notebook, PC or tablet with web browser | <ul style="list-style-type: none"> Service interface CDI-RJ45 WLAN interface | Special Documentation for device →  242 |
| DeviceCare SFE100 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> Service interface CDI-RJ45 WLAN interface Fieldbus protocol | →  208 |
| FieldCare SFE500 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> Service interface CDI-RJ45 WLAN interface Fieldbus protocol | →  208 |
| Field Xpert | SMT70/77/50 | <ul style="list-style-type: none"> All fieldbus protocols WLAN interface Bluetooth Service interface CDI-RJ45 | Operating Instructions BA01202S Device description files: Use update function of handheld terminal |



Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
- Asset Management Solutions (AMS) from Emerson → www.emersonprocess.com
- FieldCommunicator 375/475 from Emerson → www.emersonprocess.com
- Emersons TREX → www.emerson.com
- Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The related device description files are available: www.endress.com → Download Area

Web server



The integrated web server can be used to operate and configure the device via a web browser service interface (CDI-RJ45) or via WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; Operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook, for example,) and measuring instrument:

- Upload the configuration from the measuring instrument (XML format, configuration backup)
- Save the configuration to the measuring instrument (XML format, restore configuration)
- Export event list (.csv file)

- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat Technology verification report (PDF file, only available with the **Heartbeat Verification** →  239 application package)
- Flash firmware version for device firmware upgrade, for example
- Download driver for system integration
- Visualize up to 1000 saved measured values (only available with the **Extended HistoROM** application package →  239)

HistoROM data management

The measuring instrument features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

| | HistoROM backup | T-DAT | S-DAT |
|-------------------------|--|--|---|
| Available data | <ul style="list-style-type: none"> ■ Event logbook, e.g. diagnostic events ■ Parameter data record backup ■ Device firmware package ■ Driver for system integration for exporting via web server, e.g.: DD for FOUNDATION Fieldbus | <ul style="list-style-type: none"> ■ Measured value logging ("Extended HistoROM" order option) ■ Current parameter data record (used by firmware at run time) ■ Indicator (minimum/maximum values) ■ Totalizer value | <ul style="list-style-type: none"> ■ Sensor data: e.g. nominal diameter ■ Serial number ■ Calibration data ■ Device configuration (e.g. SW options, fixed I/O or multi I/O) |
| Storage location | Fixed on the user interface PC board in the connection compartment | Can be plugged into the user interface PC board in the connection compartment | In the sensor plug in the transmitter neck part |

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
Backup and subsequent restoration of a device configuration in the device memory HistoROM backup
- Data comparison function
Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transmission

Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via web server, e.g.: DD for FOUNDATION fieldbus

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:


- Recording of 1 to 4 channels of up to 1 000 measured values (up to 250 measured values per channel)
- User configurable recording interval
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server



16.12 Certificates and approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

1. Select the product using the filters and search field.
2. Open the product page.
3. Select **Downloads**.

| | |
|--------------|--|
| CE mark | <p>The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p> |
| UKCA marking | <p>The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.</p> <p>Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com</p> |
| RCM marking | <p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p> |

| | |
|-----------------------------------|--|
| Hygienic compatibility | <ul style="list-style-type: none"> ■ 3-A approval <ul style="list-style-type: none"> ■ Only measuring instruments with the order code for "Additional approval", option LP "3A" have 3-A approval. ■ The 3-A approval refers to the measuring instrument. ■ When installing the measuring instrument, ensure that no liquid can accumulate on the outside of the measuring instrument. A remote display module must be installed in accordance with the 3-A Standard. ■ Accessories (e.g. heating jacket, weather protection cover, wall holder unit) must be installed in accordance with the 3-A Standard. Each accessory can be cleaned. Disassembly may be necessary under certain circumstances. ■ EHEDG-tested (Type EL Class I) <ul style="list-style-type: none"> Only devices with the order code for "Additional approval", option LT "EHEDG" have been tested and meet the requirements of the EHEDG. To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy cleanable Pipe couplings and Process connections" (www.ehedg.org). To meet the requirements for EHEDG certification, the orientation of the device must ensure drainability. Test criteria for cleanability according to EHEDG is a flow velocity of 1.5 m/s in the process line. This speed must be ensured for EHEDG-compliant cleaning. ■ FDA CFR 21 ■ Food Contact Materials Regulation (EC) 1935/2004 ■ Food Contact Materials Regulation GB 4806 ■ The requirements of the Food Contact Material regulations must be observed when selecting the material versions. <p> Observe special installation instructions</p> |
| Pharmaceutical compatibility | <ul style="list-style-type: none"> ■ FDA 21 CFR 177 ■ USP <87> ■ USP <88> Class VI 121 °C ■ TSE/BSE Certificate of Suitability ■ cGMP <p>Devices with the order code for "Test, certificate", option JG "Conformity with cGMP-derived requirements, declaration" comply with the requirements of cGMP with regard to the surfaces of parts in contact with the medium, design, FDA 21 CFR material conformity, USP Class VI tests and TSE/BSE conformity.</p> <p>A serial number-specific declaration is generated.</p> |
| FOUNDATION Fieldbus certification | <p>FOUNDATION Fieldbus interface</p> <p>The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:</p> <ul style="list-style-type: none"> ■ Certified in accordance with FOUNDATION Fieldbus H1 ■ Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request) ■ Physical Layer Conformance Test ■ The device can also be operated with certified devices of other manufacturers (interoperability) |

| | |
|-----------------------------------|--|
| Pressure Equipment Directive | <ul style="list-style-type: none"> ■ With the marking <ul style="list-style-type: none"> a) PED/G1/x (x = category) or b) PESR/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" <ul style="list-style-type: none"> a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or b) Schedule 2 of Statutory Instruments 2016 No. 1105. ■ Devices not bearing this marking (without PED or PESR) are designed and manufactured according to sound engineering practice. They meet the requirements of <ul style="list-style-type: none"> a) Art. 4, Section 3 of the Pressure Equipment Directive 2014/68/EU or b) Part 1, Section 8 of Statutory Instruments 2016 No. 1105. The scope of application is indicated <ul style="list-style-type: none"> a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or b) in Schedule 3, Section 2 of Statutory Instruments 2016 No. 1105. |
| Radio approval | <p>The measuring instrument has radio approval.</p> <p> For detailed information on the radio approval, see the Special Documentation →  242</p> |
| Additional certification | <p>Marine approval</p> <p>Currently valid certificates are available:</p> <ul style="list-style-type: none"> ■ In the Downloads area of the Endress+Hauser website: www.endress.com → Downloads ■ Specify the following details: <ul style="list-style-type: none"> ■ Product root, e.g. 8E5B ■ Search: Approval & Certificates → Marine <p>CRN approval</p> <p>Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.</p> <p>Tests and certificates</p> <ul style="list-style-type: none"> ■ EN10204-3.1 material certificate, wetted parts and sensor housing (order code for "Test, certificate", option JA) ■ Pressure test, internal process, test report (order code for "Test, certificate", option JB) ■ Surface roughness test ISO4287/Ra, (wetted parts), test report (option JE) ■ Compliance with requirements derived from cGMP, Declaration (option JG) |
| External standards and guidelines | <ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosure (IP code) ■ IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal). ■ IEC/EN 60068-2-31 Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices. ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements ■ GB 30439.5 Safety requirements for industrial automation products - Part 5: Flowmeter safety requirements ■ EN 61326-1/-2-3 EMC requirements for electrical equipment for measurement, control and laboratory use |


- NAMUR NE 21
Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment
- NAMUR NE 32
Data retention in the event of a power failure in field and control instruments with microprocessors
- NAMUR NE 43
Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.
- NAMUR NE 53
Software of field devices and signal-processing devices with digital electronics
- NAMUR NE 80
The application of the pressure equipment directive to process control devices
- NAMUR NE 105
Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107
Self-monitoring and diagnostics of field devices
- NAMUR NE 131
Requirements for field devices for standard applications
- NAMUR NE 132
Coriolis mass meter
- ETSI EN 300 328
Guidelines for 2.4 GHz radio components.
- EN 301489
Electromagnetic compatibility and radio spectrum matters (ERM).

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



Detailed information on the application packages:
Special Documentation →  241

Diagnostic functionality

Order code for "Application package", option EA "Extended HistoROM"

Comprises extended functions concerning the event log and the activation of the measured value memory.

Event log:

Memory volume is extended from 20 message entries (standard version) to up to 100 entries.

Data logging (line recorder):

- Memory capacity for up to 1000 measured values is activated.
- 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.
- Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.



For detailed information, see the Operating Instructions for the device.

Heartbeat Technology

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

Heartbeat Verification



Meets the requirement for traceable verification in accordance with DIN ISO 9001:2015 Clause 7.6 a) "Control of monitoring and measuring equipment".

- Functional testing in the installed state without interrupting the process.
- Traceable verification results on request, including a report.
- Simple testing process via local operation or other operating interfaces.
- Clear measuring point assessment (pass/fail) with high total test coverage within the framework of manufacturer specifications.
- Extension of calibration intervals according to operator's risk evaluation.

Heartbeat Monitoring

Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:

- Draw conclusions - using these data and other information - about the impact the process influences (e.g. corrosion, abrasion, deposit buildup etc.) have on measuring performance over time.
- Schedule servicing in time.
- Monitor the process or product quality, e.g. gas pockets.

 Detailed information on Heartbeat Technology:
Special Documentation →  241

Concentration measurement

Order code for "Application package", option ED "Concentration"

Calculation and outputting of fluid concentrations.

The measured density is converted to the concentration of a substance of a binary mixture using the "Concentration" application package:

- Choice of predefined fluids (e.g. various sugar solutions, acids, alkalis, salts, ethanol etc.).
- Common or user-defined units (°Brix, °Plato, % mass, % volume, mol/l etc.) for standard applications.
- Concentration calculation from user-defined tables.

 For detailed information, see the Special Documentation for the device.

Petroleum

Order code for "Application package", option EJ "Petroleum"

The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package.

- Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1"
- Water content, based on density measurement
- Weighted mean of the density and temperature

 For detailed information, see the Special Documentation for the device.

Petroleum & locking function

Order code for "Application package", option EM "Petroleum & locking function"

The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package. It is also possible to lock the settings.

- Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1"
- Water content, based on density measurement
- Weighted mean of the density and temperature

 For detailed information, see the Special Documentation for the device.

16.14 Accessories



Overview of accessories available to order → 206

16.15 Documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation **Brief Operating Instructions**

Brief Operating Instructions for the sensor

| Measuring instrument | Documentation code |
|----------------------|--------------------|
| Proline Promass E | KA01260D |

Brief operating instructions for transmitter

| Measuring instrument | Documentation code |
|-----------------------|--------------------|
| Proline 500 – digital | KA01233D |
| Proline 500 | KA01291D |

Technical information

| Measuring instrument | Documentation code |
|----------------------|--------------------|
| Promass E 500 | TI01282D |

Description of Device Parameters

| Measuring instrument | Documentation code |
|----------------------|--------------------|
| Promass 500 | GP01096D |

Device-dependent
additional documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.



| Contents | Documentation code Measuring instrument |
|------------------|--|
| ATEX/IECEX Ex ia | XA01473D |
| ATEX/IECEX Ex ec | XA01474D |
| cCSAus IS | XA01475D |
| cCSAus Ex ia | XA01509D |
| cCSAus Ex ec | XA01510D |
| EAC Ex ia | XA01658D |
| EAC Ex ec | XA01659D |
| JPN Ex ia | XA01780D |

| Contents | Documentation code Measuring instrument |
|---------------|--|
| KCs Ex ia | XA03287D |
| INMETRO Ex ia | XA01476D |
| INMETRO Ex ec | XA01477D |
| NEPSI Ex ia | XA01478D |
| NEPSI Ex nA | XA01479D |
| UKEX Ex ia | XA02570D |
| UKEX Ex ec | XA02572D |

Special Documentation

| Contents | Documentation code |
|---|--------------------|
| Information on the Pressure Equipment Directive | SD01614D |
| Radio approvals for WLAN interface for A309/A310 display module | SD01793D |
| Web server | SD01669D |
| Heartbeat Technology | SD01703D |
| Concentration measurement | SD01709D |
| Petroleum | – |

Installation Instructions

| Contents | Note |
|---|---|
| Installation instructions for spare part sets and accessories | <ul style="list-style-type: none"> ■ Access the overview of all the available spare part sets via <i>Device Viewer</i> →  204 ■ Accessories available for order with Installation Instructions →  206 |

Index

0 ... 9

3-A approval 237

A

Access authorization to parameters

Read access 74

Write access 74

Access code 74

Incorrect input 74

Adapting the diagnostic behavior 170

Adapting the status signal 170

Additional certification 238

Ambient conditions

Mechanical load 226

Operating height 225

Relative humidity 225

Storage temperature 225

Vibration resistance and shock resistance 226

Ambient temperature

Influence 223

Ambient temperature range 225

AMS Device Manager 85

Function 85

Application 210

Application packages 239

Applicator 211

Approvals 236

Attaching the connecting cable

Proline 500 transmitter 52

C

Cable entries

Technical data 221

Cable entry

Degree of protection 58

CE mark 10, 236

Certificates 236

cGMP 237

Check

Connection 59

Received goods 16

Checklist

Post-connection check 59

Post-installation check 34

CIP cleaning 228

Climate class 225

Commissioning 92

Advanced settings 118

Configuring the device 93

Connecting the connecting cable

Proline 500 – digital transmitter 46

Proline 500 terminal assignment 49

Sensor connection housing, Proline 500 49

Sensor connection housing, Proline 500 – digital .. 42

Terminal assignment of Proline 500 – digital 42

Connecting the device

Proline 500 49

Proline 500 – digital 42

Connecting the signal cable/supply voltage cable

Proline 500 – digital transmitter 47

Proline 500 transmitter 53

Connection

see Electrical connection

Connection cable 35

Connection preparations 41

Connection tool 35

Context menu

Calling up 70

Closing 70

Explanation 70

Current consumption 220

Cyclic data transmission 86

D

Declaration of Conformity 10

Defining the access code 136, 137

Degree of protection 58, 226

Design

Measuring device 14

Design fundamentals

Measurement error 224

Repeatability 224

Device

Configuring 93

Preparing for electrical connection 41

Device components 14

Device description files 86

Device locking, status 141

Device name

Sensor 19

Transmitter 17

Device repair 204

Device revision 86

Device type code 86

Device Viewer 204

DeviceCare 85

Device description file 86

Diagnostic behavior

Explanation 166

Symbols 166

Diagnostic information

Design, description 166, 169

DeviceCare 168

FieldCare 168

LED 162

Local display 165

Overview 174

Remedial measures 174

Web browser 167

Diagnostic list 196

Diagnostic message 165

| | |
|---|-----|
| DIAGNOSTIC Transducer Block | 196 |
| Diagnostics | |
| Symbols | 165 |
| DIP switch | |
| see Write protection switch | |
| Direct access | 72 |
| Disabling write protection | 136 |
| Display | |
| see Local display | |
| Display area | |
| For operational display | 64 |
| In the navigation view | 66 |
| Display values | |
| For locking status | 141 |
| Displaying the measured value history | 157 |
| Disposal | 205 |
| Document | |
| Function | 6 |
| Symbols | 6 |
| Document function | 6 |
| Documentation | 241 |
| Down pipe | 23 |

E

| | |
|--|--------|
| Editing view | 68 |
| Input screen | 69 |
| Using operating elements | 68, 69 |
| EHEDG-tested | 237 |
| Electrical connection | |
| Degree of protection | 58 |
| Measuring instrument | 35 |
| Operating tools | |
| Via FOUNDATION Fieldbus network | 80 |
| Via service interface (CDI-RJ45) | 81 |
| Via WLAN interface | 82 |
| Web server | 81 |
| WLAN interface | 82 |
| Electromagnetic compatibility | 226 |
| Electronics module | 14 |
| Enabling write protection | 136 |
| Enabling/disabling the keypad lock | 75 |
| Error messages | |
| see Diagnostic messages | |
| Event logbook | 197 |
| Extended order code | |
| Sensor | 19 |
| Transmitter | 17 |

F

| | |
|------------------------------|-----|
| FDA | 237 |
| Field Communicator | |
| Function | 85 |
| Field Communicator 475 | 85 |
| Field of application | |
| Residual risks | 10 |
| Field Xpert | |
| Function | 84 |
| Field Xpert SFX350 | 84 |

| | |
|---|--------|
| FieldCare | 84 |
| Device description file | 86 |
| Function | 84 |
| Filtering the event logbook | 198 |
| Firmware | |
| Release date | 86 |
| Version | 86 |
| Firmware history | 202 |
| Flow direction | 23, 29 |
| Flow limit | 228 |
| Food Contact Materials Regulation | 237 |
| FOUNDATION Fieldbus certification | 237 |
| Function range | |
| AMS Device Manager | 85 |
| Function scope | |
| Field Communicator | 85 |
| Field Communicator 475 | 85 |
| Field Xpert | 84 |
| Functions | |
| see Parameter | |

G

| | |
|--------------------------|-----|
| Galvanic isolation | 219 |
|--------------------------|-----|

H

| | |
|---------------------------------|-----|
| Hardware write protection | 138 |
| Help text | |
| Calling up | 73 |
| Closing | 73 |
| Explanation | 73 |
| HistoROM | 130 |
| Hygienic compatibility | 237 |

I

| | |
|--|-----|
| Identifying the measuring instrument | 16 |
| Incoming acceptance | 16 |
| Indication | |
| Current diagnostic event | 195 |
| Previous diagnostic event | 195 |
| Influence | |
| Ambient temperature | 223 |
| Medium pressure | 224 |
| Medium temperature | 223 |
| Information about this document | 6 |
| Inlet runs | 24 |
| Input variables | 211 |
| Inspection | |
| Installation | 34 |
| Installation | 22 |
| Installation dimensions | 24 |
| Installation requirements | |
| Down pipe | 23 |
| Inlet and outlet runs | 24 |
| Installation dimensions | 24 |
| Mounting location | 22 |
| Orientation | 23 |
| Rupture disk | 27 |
| Sensor heating | 26 |
| Thermal insulation | 25 |

| | |
|-------------------------|-----|
| Vibrations | 26 |
| Intended use | 9 |
| Internal cleaning | 228 |

L

| | |
|------------------------------------|-----|
| Languages, operation options | 233 |
| Line recorder | 157 |
| Local display | 233 |
| Navigation view | 66 |
| see Diagnostic message | |
| see In alarm condition | |
| see Operational display | |
| Text editor | 68 |
| Low flow cut off | 219 |

M

| | |
|---|--------|
| Main electronics module | 14 |
| Maintenance work | 203 |
| Managing the device configuration | 130 |
| Manufacturer ID | 86 |
| Manufacturing date | 17, 19 |
| Materials | 230 |
| Maximum measurement error | 221 |
| Measured variables | |
| see Process variables | |
| Measurement accuracy | 221 |
| Measuring and test equipment | 203 |
| Measuring device | |
| Conversion | 204 |
| Design | 14 |
| Repairs | 204 |
| Measuring instrument | |
| Disposal | 205 |
| Installing the sensor | 29 |
| Preparing for mounting | 29 |
| Removing | 205 |
| Switch on | 92 |
| Measuring principle | 210 |
| Measuring range | |
| For gases | 211 |
| For liquids | 211 |
| Measuring range, recommended | 228 |
| Measuring system | 210 |
| Mechanical load | 226 |
| Medium density | 227 |
| Medium pressure | |
| Influence | 224 |
| Medium temperature | |
| Influence | 223 |
| Menu | |
| Diagnostics | 195 |
| Setup | 94 |
| Menus | |
| For device configuration | 93 |
| For specific settings | 118 |
| Mounting dimensions | |
| see Installation dimensions | |
| Mounting location | 22 |
| Mounting preparations | 29 |

| | |
|-----------------------|----|
| Mounting requirements | |
| Static pressure | 25 |
| Mounting tool | 29 |

N

| | |
|---|-----|
| Nameplate | |
| Sensor | 19 |
| Transmitter | 17 |
| Navigation path (navigation view) | 66 |
| Navigation view | |
| In the submenu | 66 |
| In the wizard | 66 |
| Netilion | 203 |
| Numeric editor | 68 |

O

| | |
|--|---------|
| Onsite display | |
| Numeric editor | 68 |
| Operable flow range | 212 |
| Operating elements | 70, 166 |
| Operating height | 225 |
| Operating keys | |
| see Operating elements | |
| Operating menu | |
| Menus, submenus | 61 |
| Structure | 61 |
| Submenus and user roles | 62 |
| Operating philosophy | 62 |
| Operation | 141 |
| Operation options | 60 |
| Operational display | 63 |
| Operational safety | 10 |
| Order code | 17, 19 |
| Orientation (vertical, horizontal) | 23 |
| Outlet runs | 24 |
| Output signal | 214 |
| Output variables | 214 |

P

| | |
|--|-----|
| Packaging disposal | 22 |
| Parameter | |
| Changing | 73 |
| Entering values or text | 73 |
| Parameter settings | |
| Administration (Submenu) | 132 |
| Advanced setup (Submenu) | 119 |
| Analog inputs (Submenu) | 99 |
| Configuration backup (Submenu) | 130 |
| Corrected volume flow calculation (Submenu) .. | 119 |
| Current input | 100 |
| Current input (Wizard) | 100 |
| Current input 1 to n (Submenu) | 153 |
| Current output | 102 |
| Current output (Wizard) | 102 |
| Data logging (Submenu) | 157 |
| Define access code (Wizard) | 132 |
| Device information (Submenu) | 200 |
| Diagnostics (Menu) | 195 |
| Display (Submenu) | 126 |

| | |
|--|---------------|
| Display (Wizard) | 113 |
| I/O configuration | 99 |
| I/O configuration (Submenu) | 99 |
| Low flow cut off (Wizard) | 116 |
| Measured variables (Submenu) | 142 |
| Medium selection (Wizard) | 97 |
| Partially filled pipe detection (Wizard) | 117 |
| Pulse/frequency/switch output | 105 |
| Pulse/frequency/switch output (Wizard) | 105, 106, 109 |
| Pulse/frequency/switch output 1 to n (Submenu) | 154 |
| Relay output | 111 |
| Relay output 1 to n (Submenu) | 155 |
| Relay output 1 to n (Wizard) | 111 |
| Reset access code (Submenu) | 132 |
| Sensor adjustment (Submenu) | 120 |
| Setup (Menu) | 94 |
| Simulation (Submenu) | 133 |
| Status input | 101 |
| Status input 1 to n (Submenu) | 153 |
| Status input 1 to n (Wizard) | 101 |
| System units (Submenu) | 94 |
| Totalizer (Submenu) | 152 |
| Totalizer 1 to n (Submenu) | 124 |
| Totalizer handling (Submenu) | 156 |
| Value current output 1 to n (Submenu) | 154 |
| Web server (Submenu) | 78 |
| WLAN settings (Wizard) | 129 |
| Zero adjustment (Wizard) | 123 |
| Zero verification (Wizard) | 121 |
| Performance characteristics | 221 |
| Pharmaceutical compatibility | 237 |
| Post-connection check | 92 |
| Post-connection check (checklist) | 59 |
| Post-installation check | 92 |
| Post-installation check (checklist) | 34 |
| Potential equalization | 55 |
| Power consumption | 220 |
| Power supply failure | 220 |
| Pressure Equipment Directive | 238 |
| Pressure loss | 229 |
| Pressure/temperature ratings | 227 |
| Process connections | 232 |
| Process variables | |
| Calculated | 211 |
| Measured | 211 |
| Product safety | 10 |
| Proline 500 – digital transmitter | |
| Connecting the signal cable/supply voltage cable | 47 |
| Proline 500 connecting cable terminal assignment | |
| Sensor connection housing | 49 |
| Proline 500 transmitter | |
| Connecting the signal cable/supply voltage cable | 53 |
| Protecting parameter settings | 136 |
| R | |
| Radio approval | 238 |
| RCM marking | 236 |
| Read access | 74 |

| | |
|--|----------|
| Reading off measured values | 141 |
| Recalibration | 203 |
| Reference operating conditions | 221 |
| Registered trademarks | 8 |
| Remedial actions | |
| Calling up | 167 |
| Closing | 167 |
| Remote operation | 233 |
| Repair | 204 |
| Notes | 204 |
| Repair of a device | 204 |
| Repeatability | 223 |
| Replacement | |
| Device components | 204 |
| Requirements for personnel | 9 |
| Response time | 223 |
| Return | 204 |
| Rupture disk | |
| Safety instructions | 27 |
| Triggering pressure | 228 |
| S | |
| Safety | 9 |
| Sensor | |
| Installing | 29 |
| Sensor heating | 26 |
| Sensor housing | 227 |
| Serial number | 17, 19 |
| Services | |
| Maintenance | 203 |
| Repair | 204 |
| Setting the operating language | 92 |
| Settings | |
| Adapting the measuring device to the process | |
| conditions | 156 |
| Administration | 131 |
| Advanced display configurations | 126 |
| Analog input | 99 |
| Current input | 100 |
| Current output | 102 |
| Device reset | 199 |
| Device tag | 94 |
| I/O configuration | 99 |
| Local display | 113 |
| Low flow cut off | 116 |
| Managing the device configuration | 130 |
| Medium | 97 |
| Operating language | 92 |
| Partially filled pipe detection | 117 |
| Pulse output | 105 |
| Pulse/frequency/switch output | 105, 106 |
| Relay output | 111 |
| Resetting the totalizer | 156 |
| Restarting the device | 199 |
| Sensor adjustment | 120 |
| Simulation | 133 |
| Status input | 101 |
| Switch output | 109 |
| System units | 94 |

- Totalizer 124
- Totalizer reset 156
- WLAN 129
- Signal on alarm 217
- SIP cleaning 228
- Software release 86
- Spare part 204
- Spare parts 204
- Special connection instructions 55
- Special mounting instructions
 - Hygienic compatibility 27
- Standards and guidelines 238
- Static pressure 25
- Status area
 - For operational display 64
 - In the navigation view 66
- Status signals 165, 168
- Storage concept 235
- Storage conditions 21
- Storage temperature 21
- Storage temperature range 225
- Structure
 - Operating menu 61
- Submenu
 - Administration 131, 132
 - Advanced setup 118, 119
 - Analog inputs 99
 - Calculated values 119
 - Configuration backup 130
 - Corrected volume flow calculation 119
 - Current input 1 to n 153
 - Data logging 157
 - Device information 200
 - Display 126
 - Event logbook 197
 - I/O configuration 99
 - Input values 152
 - Measured values 141
 - Measured variables 142
 - Output values 154
 - Overview 62
 - Process variables 119
 - Pulse/frequency/switch output 1 to n 154
 - Relay output 1 to n 155
 - Reset access code 132
 - Sensor adjustment 120
 - Simulation 133
 - Status input 1 to n 153
 - System units 94
 - Totalizer 152
 - Totalizer 1 to n 124
 - Totalizer handling 156
 - Value current output 1 to n 154
 - Web server 78
- Supply voltage 220
- Surface roughness 232
- Switch output 216
- Symbols
 - Controlling data entries 69
 - For communication 64
 - For diagnostic behavior 64
 - For locking 64
 - For measured variable 64
 - For measurement channel number 64
 - For menus 66
 - For parameters 66
 - For status signal 64
 - For submenu 66
 - For wizards 66
 - In the status area of the local display 64
 - Input screen 69
 - Operating elements 68
- System design
 - Measuring system 210
 - see Measuring device design
- System integration 86
- T**
- Technical data, overview 210
- Temperature range
 - Ambient temperature for display 233
 - Medium temperature 227
 - Storage temperature 21
- Terminal assignment 39
- Terminal assignment of connecting cable for Proline
 - 500- digital
 - Sensor connection housing 42
- Terminals 220
- Tests and certificates 238
- Text editor 68
- Thermal insulation 25
- Tool
 - For electrical connection 35
 - For mounting 29
 - Transportation 21
- Tool tip
 - see Help text
- Totalizer
 - Configuring 124
- Transmitter
 - Turning the display module 33
 - Turning the housing 33
- Transporting the measuring instrument 21
- Troubleshooting
 - General 160
- TSE/BSE Certificate of Suitability 237
- Turning the display module 33
- Turning the electronics housing
 - see Turning the transmitter housing
- Turning the transmitter housing 33
- U**
- UKCA marking 236
- Use of measuring instrument
 - Borderline cases 9
 - Incorrect use 9
 - see Intended use
- User roles 62

USP Class VI 237

V

Version data for the device 86

Vibration resistance and shock resistance 226

Vibrations 26

W

W@M Device Viewer 16

Weight

SI units 229

Transport (notes) 21

US units 229

Wizard

Current input 100

Current output 102

Define access code 132

Display 113

Low flow cut off 116

Medium selection 97

Partially filled pipe detection 117

Pulse/frequency/switch output 105, 106, 109

Relay output 1 to n 111

Status input 1 to n 101

WLAN settings 129

Zero adjustment 123

Zero verification 121

WLAN settings 129

Workplace safety 10

Write access 74

Write protection

Via access code 136

Via block operation 140

Via write protection switch 138

Write protection switch 138



www.addresses.endress.com
