Safety Instructions **Proline Prowirl 200**

EAC: Zone 2 Ex ec and Ex ic version







Proline Prowirl 200

Table of contents

About this document	4
Associated documentation	4
Certificates and declarations	4
Manufacturer address	5
Extended order code	5
Safety instructions: General	8
Safety instructions: Installation	9
Safety instructions: Zone 0 1	.1
Гетрегаture tables 1	.1
Connection values: Signal circuits 2	0

About this document



The document number of these Safety Instructions (XA) must match the information on the nameplate.

Associated documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter serial number from nameplate.
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

To commission the device, please observe the Operating Instructions pertaining to the device:

Measuring	Documentation code				
instrument	HART	FOUNDATION Fieldbus	PROFIBUS PA	PROFINET over Ethernet-APL	Modbus TCP over Ethernet-APL
Prowirl D 200	BA01685D	BA01693D	BA01689D	BA02133D	BA02397D
Prowirl F 200	BA01686D	BA01694D	BA01690D	BA02132D	BA02398D
Prowirl O 200	BA01687D	BA01695D	BA01691D	BA02134D	BA02399D
Prowirl R 200	BA01688D	BA01696D	BA01692D	BA02135D	BA02400D

Additional documentation

Contents	Document type	Documentation code
Remote display FHX50	Special documentation	SD01007F
	Safety Instructions	XA01601F
	 OEx ia IIC T6 Ga X Ex ia IIIC T100° C Db Ex ia IIIC T105° C Db 	
Overvoltage Protection (OVP)	Special documentation	SD01090F
Explosion Protection	Brochure	CP00021Z/11

Certificates and declarations

Measuring instruments meet the fundamental health and safety requirements for the design and construction of devices and protective systems intended for use in potentially explosive atmospheres in accordance with TR CU 012/2011.

Certification body

LLP "T-Standard"

Certificate number

EA 3 KZ 7500525.01.01.01269

Affixing the certificate number certifies conformity with the standards under (depending on the device version).

- ΓΟCT 31610.0-2019 (IEC 60079-0:2017)
- ΓΟCT 31610.7-2017 (IEC 60079-7:2015)
- ΓΟCT 31610.11-2014 (IEC 60079-11:2011)
- ΓΟCT 31610.26-2016 (IEC 60079-26:2014)

Manufacturer	Endress+Hauser Flow France S.A.S.U.
address	35, rue de l'Europe
	68700 Cernay France

ExtendedThe extended order code is indicated on the nameplate, which is affixedorder codeto the device in such a way that it is clearly visible. Additional
information about the nameplate is provided in the associated
Operating Instructions.

Structure of the extended order code

* * * * * *	**********	+	A*B*C*D*E*F*G*
(Device type)	(Basic specifications)		(Optional specifications)
* =	Placeholder At this position, an option (number o specification is displayed instead of t		1

Device type

The device and the device design is defined in the "Device type" section (Product root).

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Position	Order code for	Selected option	Description
1	Instrument family	7	Vortex flowmeter
2	Sensor	D, F, O, R	Sensor type
3	Transmitter	2	Transmitter type: 2-wire, compact version Remote version
4	Generation index	B ¹⁾ , C	Platform generation
5, 6	Nominal diameter	D: DN 15150 F: DN 15300 O: DN 15300	Nominal diameter of sensor
		R: • Reducer DN 25200 • Super reducer DN 40250	

Device type

1) For information on Prowirl 7*2B**-... , see version 01.05.2024 and older.

Basic specifications

Position	Order code for	Selected option	Type of protection
1, 2 Approval		GD, ID	Ga/Gc Ex ic [ia] IIC T6T1 or 2Ex ic IIC T6T1 Gc or 2Ex ic [ia Ga] IIC T6T1 Gc
		GG, IG	2Ex ec IIC T6T1 Gc ¹⁾
		GH, IH	2Ex ic IIC T6T1 Gc ²⁾

1) The labeling changes according to whether "Display; operation" = "L" or "M": 2Ex ec [ia Ga] IIC T6...T1 Gc.

2) The labeling changes according to whether "Display; operation" = "L" or "M": 2Ex ic [ia Ga] IIC T6...T1 Gc.

Position	Order code for	Selected option	Description
3	Output; Input	A	4-20mA HART
		В	4-20mA HART, Pulse/frequency/ switch output
		С	4-20mA HART + 4-20mA analog
		D	4-20mA HART, pulse/frequency/ switch output; 4-20mA input
		E	FOUNDATION Fieldbus, Pulse/ frequency/switch output
		G	PROFIBUS PA, Pulse/frequency/switch output
		S	PROFINET over Ethernet-APL/SPE, 10Mbit/s
		Т	Modbus TCP over Ethernet-APL/SPE, 10Mbit/s
4	Display; Operation	А	W/o; via communication
		С	SD02 4-line; push buttons + data backup function
		E	SD03 4-line, illum.; touch control + data backup function
		L	Prepared for display FHX50 + M12 connection ¹⁾
		М	Prepared for display FHX50 + custom connection ¹⁾
8, 9	Sensor version; DSC sensor; measuring tube Only available for sensors F, O, R, with Generation index C with the HART communication protocol.	DA	Mass steam; 316L; 316L (integrated pressure/temperature measurement), -200 to +400 °C (-328 to +750 °F)
		DB	Mass gas/liquid; 316L; 316L (integrated pressure/temperature measurement), -40 to +260 °C (-40 to +500 °F)
		DC	Mass steam; Alloy 718; 316L (integrated pressure/temperature measurement), -200 to +400 °C (-328 to +750 °F)
		DD	Mass gas/liquid; Alloy 718; 316L (integrated pressure/temperature measurement), -40 to +100 °C (-40 to +212 °F)
11	Pressure component	А	Not used
	Only available for sensors F, O, R, with Generation index C with the HART communication protocol.	В	Pressure measuring cell 2bar/29psi abs

Position	Order code for	Selected option	Description
		С	Pressure measuring cell 4bar/58psi abs
		D	Pressure measuring cell 10bar/145psi abs
		Е	Pressure measuring cell 40bar/580psi abs
		F	Pressure measuring cell 100bar/1450psi abs
		G	Pressure measuring cell 160bar/2320psi abs
16, 17 ²⁾	Device Model	A1	1

1) FHX50 is separately approved.

2) Only for devices with order code for "Generation index" , option C

Optional specifications

ID	Order code for	Selected option	Description
Jx	Test, certificate	JN	Ambient temperature transmitter –50 °C
Nx	Accessory mounted	NA	Overvoltage Protection (OVP)

Safety instructions: General

- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations or guidelines (e.g. FOCT IEC 60079-14-2013)
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.
- Only use the device in media to which the wetted materials have sufficient durability.
- Refer to the temperature tables for the relationship between the permitted ambient temperature for the sensor and/or transmitter, depending on the range of application, and the temperature classes.

- Alterations to the device can affect the explosion protection and must be carried out by staff authorized to perform such work by Endress+Hauser.
- Observe all the technical data of the device (see nameplate).
- Avoid electrostatic charge (e.g. caused by friction, cleaning, maintenance, strong currents in the medium):
 On the attached stainless steel nameplate and on painted metallic housings that are not integrated into the local potential equalization system.

Safety instructions: Installation

- Continuous service temperature of the connecting cable: -40 to +80 °C (-50 to +80 °C for optional specifications, ID Jx (Test, Certificate) = JN); in accordance with the range of service temperature taking into account additional influences of the process conditions ($T_{a,min}$ and $T_{a,max}$ + 20 K).
- Only use certified cable glands suitable for the application. Observe selection criteria as per FOCT IEC 60079-14-2013.
- When the measuring device is connected, attention must be paid to the type of protection at the transmitter.
- In potentially explosive atmospheres:
 - Do not disconnect the electrical connection of the power supply circuit when energized.
 - Do not open the connection compartment cover when the device is energized.

Ex ec type of protection

- In potentially explosive atmospheres: Do not disconnect the electrical connection of the power supply circuit when energized.
- Seal unused entries with approved blanking elements that correspond to the type of protection. The plastic transport sealing plug does not meet this requirement and must therefore be replaced during installation.
- Only use certified cable entries and blanking elements. The metal cable entries, extensions and sealing plugs supplied meet this requirement.

Basic specification, position 3 (Output; Input) = S, T

- Only install in systems that are limited to safe extra-low voltage such as SELV, PELV, ES1 or Class 2.
- Only one conductor per terminal is allowed.

Basic specification, position 8, 9 (sensor version; DSC sensor; measuring tube) = DA, DB, DC, DD and position 11 (pressure component) = B, C, D, E, F, G

- The maximum medium temperature is limited for device versions with a pressure component that is installed directly on the sensor F, O, R:
 - To 40 °C for T6 and T5
 - To 90 °C for T4 and T1
- In the case of T4 ... T1 and medium temperatures > 90 °C the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R.
 - The spacer tube must have a minimum length of 50 cm (19.7 in).
 - The spacer tube supplied meets this requirement.

Intrinsic safety

- Observe the guidelines for interconnecting intrinsically safe circuits (e.g. FOCT IEC 60079-14-2013, proof of intrinsic safety).
- The intrinsically safe input power circuit of the device is isolated from ground. If the device is only equipped with one input, the dielectric strength of the input is at least 500 V_{rms} . If the device is equipped with more than one input, the dielectric strength of each individual input to ground is at least 500 V_{rms} , and the dielectric strength of the inputs vis-à-vis one another is also at least 500 V_{rms} .
- The device can be connected to the Endress+Hauser FXA291 service tool: refer to the Operating Instructions.
- The device can be connected to the remote display FHX50 with explosion protection; refer to the Special Documentation and Ex documentation.

Basic specification, position 3 (Output; input) = A, B, C, D, E, G, S, T:

When the intrinsically safe Ex ic circuits of the device are connected to certified intrinsically safe circuits of Category Ex ic for Equipment Groups IIB, the type of protection changes from Ex ic IIC to Ex ic IIB.

Potential equalization

- Integrate the device into the potential equalization .
- If the ground connection has been established via the pipe as specified, it is also possible to integrate the sensor into the potential equalization system via the pipe.

Overvoltage protection

Optional specification, ID Nx (Accessory Mounted) = NA

		ure when using Overvoltage Protection		
	(OVP): −40 °C • When using the internal over	rvoltage protection: Reduce the		
	admissible ambient tempera	ture at the housing by 2 K.		
	· · · · · · · · · · · · · · · · · · ·	re overvoltage protection to comply with		
		lards, install the device using overvoltage m Endress+Hauser)		
	protection (e.g. HAW56x fromObserve the safety instruction	m Endress+Hauser). ns of the overvoltage protection.		
		according to FOCT IEC 60079-14-2013		
	against atmospheric over vol	tages is required: no other circuits may		
	5 5	mal operation without additional		
	measures.The intrinsically safe input p	ower circuit of the device is isolated from		
	ground. If the device is only	equipped with one input, the dielectric		
		ast 290 $V_{\rm rms}$. If the device is equipped		
		e dielectric strength of each individual 10 V _{rms} , and the dielectric strength of the		
	inputs vis-à-vis one another			
	-			
Safety	Basic specification, position 1, 2	2 (Approval) = GD, ID		
instructions: Zone 0	Install the transmitter electron with Ga/Gc the zone 0 is permi	ics in Zone 2. For measuring instruments tted in the measuring tube.		
Temperature	Minimum amhient temnerati	190		
tables	Minimum ambient temperature Basic specification, position 3 (Output; input) = A, B, C, D, E, G , S, T:			
	$T_{a, \min} = -40 \text{°C}$			
		Ω_{ii}		
	Basic specification, position 3 (Output; Input) = A, B, D in conjunction with optional specification, ID Jx (Test, Certificate) = JN:			
	$T_{a, \min} = -50 \text{ °C}$			
	(Not permitted in conjunction with <i>optional specification, ID Nx</i> (Accessory Mounted) = $NA \Rightarrow \bigoplus 10$)			
	(Accessory Mounted) = $NA \rightarrow \triangleq 10$)			
	Maximum ambient temperature			
	$\rm T_{a,max}$ depending on temperature class, maximum medium temperature and device-specific features. See the corresponding temperature tables.			
	Compact version			
	T _{a, max}	+70 °C		
	Sensor remote version			
	T _{a, max}	+85 ℃		

Basic specification,	Basic specification,	T _{a, max} [°C]			
position 3 Output; Input ¹⁾	position 1, 2 Approval	T6 [85 °C]	T5 [100 °C]	T4 [135 ℃]	
A	all	40	60	75	
в	GD, ID, GH, IH	35 ²⁾	50 ³⁾	70 ⁴⁾	
D	GG, IG	40	55	70 ⁴⁾	
С	all	40	55	70 ⁵⁾	
D	all	35	50	65	
E G	all	40	55	70 ⁵⁾	
S T	all	40	55	65	

- 1) The following applies for installations with overvoltage protection in conjunction with basic specification, position 1, 2 (approval) = GD, ID, GH, IH: $T_{a, max} = T_{a, max} 2$ K
- 2) $T_{a, max} = 40$ °C for pulse/frequency/switch output $P_i = 0.85$ W
- 3) $T_{a, max} = 60 \degree C$ for pulse/frequency/switch output $P_i = 0.85 \text{ W}$
- 4) $T_{a, max} = 75 \text{ °C for pulse/frequency/switch output } P_i = 0.85 \text{ W}$
- 5) $T_{a, max} = 75 \text{ °C for pulse/frequency/switch output } P_i = 0 \text{ W}$

Minimum medium temperature

The following relationship of ambient temperature to minimum medium temperature applies when $T_{m,\,min}$ < –50 $^{\circ}\text{C}$

T _{m, min} [°C]	-50	-100	-150	-200
T _{a, min} [°C]	-50	-47	-44	-39

Maximum medium temperature compact version

 $T_{m, max}$ See the corresponding temperature tables.

Basic specification, position 3 (output; input) = A

Version with max. $T_{m, max range} = 280 \degree C$										
T _{a, max}		T _{m, max}								
[°C]	T6 [85 °C]									
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
60 ¹⁾	-	95 ^{3) 2)}	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
65	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
70	-	-	130 ²⁾	130 ²⁾	130 ²⁾	130 ²⁾				

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

³⁾ $T_{a, max} = 55 \text{ °C}$ for device versions with pressure component option DA, DB, DC, DD.

Version with max. $I_{m, max range} = 440$ C										
T _{a, max}	T _{m, max}									
[°C]	T6 [85 °C]	T5 [100 °C]	T4 [135 ℃]	T3 [200 °C]	T2 [300 °C]	T1 [450 °C]				
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾				
60 ¹⁾	-	95 ^{3) 2)}	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾				
70	-	-	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾				

Version with max. T _{m. max range} = 440 °C
--

- 1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.
- 2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 55 \degree C$ for device versions with pressure component option DA, DB, DC, DD.

Version with max. T _{m, max range} = 280 °C										
T _{a, max}			Tn	ı, max						
[°C]	C] T6 T5 T4 T3 T2 [85 °C] [100 °C] [135 °C] [200 °C] [300 °C] [4									
35 ¹⁾²⁾	80 ³⁾	95 ³⁾	130 ³⁾	195 ³⁾	280 ³⁾	280 ³⁾				
50 ¹⁾⁴⁾	-	95 ³⁾	130 ³⁾	195 ³⁾	280 ³⁾	280 ³⁾				
60	-	-	130 ³⁾	195 ³⁾	280 ³⁾	280 ³⁾				
65	-	-	130 ³⁾	195 ³⁾	280 ^{3) 5)}	280 ³⁾⁵⁾				
70	-	-	130 ³⁾	195 ^{3) 6)}	280 ⁶⁾	280 ⁶⁾				

Basic specification, position 3 (output; input) = B

1) The ambient temperature changes for installations with overvoltage protection in conjunction with temperature classes T5 and T6: $T_{a, max} = T_{a, max} - 2 K$

- 2) $T_{a, max} = 40 \text{ °C}$ for pulse/frequency/switch output $P_i = 0.85 \text{ W}$
- 3) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).
- 4) $T_{a,max} = 55 \text{ °C for pulse/frequency/switch output } P_i = 0.85 \text{ W}$
- 5) $T_{a,max} = 65 \text{ °C for pulse/frequency/switch output } P_i = 0.7 \text{ W}$
- 6) $T_{a, max} = 70 \text{ °C for pulse/frequency/switch output } P_i = 0.7 \text{ W}$

Basic spe	Basic specification, position 1, 2 (Approval) = GD, ID, GH, IH										
Version w	Version with max. T _{m, max range} = 440 °C										
T _{a, max}	T _{a, max} T _{m, max}										
[°C]	T6 [85 ℃]										
35 ^{1) 2)}	80 ³⁾	95 ³⁾	130 ³⁾	195 ³⁾	290 ³⁾	440 ³⁾					
50 ¹⁾⁴⁾	-	95 ³⁾	130 ³⁾	195 ³⁾	290 ³⁾	440 ³⁾					
65	-	-	130 ³⁾	195 ³⁾	290 ³⁾	440 ³⁾					
70	-	_	130 ³⁾	195 ^{5) 3)}	290 ^{3) 5)}	440 ^{3) 5)}					

1) The ambient temperature changes for installations with overvoltage protection in conjunction with temperature classes T5 and T6: $T_{a, max} = T_{a, max} - 2$ K

2) $T_{a. max} = 40 \degree C$ for pulse/frequency/switch output $P_i = 0.85 \text{ W}$

3) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

- 4) $T_{a,max} = 55 \text{ °C for pulse/frequency/switch output } P_i = 0.85 \text{ W}$
- 5) $T_{a,max} = 70 \text{ °C}$ for pulse/frequency/switch output $P_i = 0.85 \text{ W}$

Basic spe	Basic specification, position 1, 2 (Approval) = GG, IG										
Version w	Version with max. T _{m, max range} = 280 °C										
T _{a, max}											
[°C]	T6 [85 ℃]										
40	80 ¹⁾	95 ¹⁾	130 ¹⁾	195 ¹⁾	280 ¹⁾	280 ¹⁾					
55	-	95 ¹⁾	130 ¹⁾	195 ¹⁾	280 ¹⁾	280 ¹⁾					
65	-	-	130 ¹⁾	195 ¹⁾	280 1) 2)	280 1) 2)					
70	-	-	130 ¹⁾	195 ^{1) 3)}	280 ^{3) 1)}	280 ³⁾¹⁾					

- 1) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).
- 2) $T_{a,max} = 65 \text{ °C for pulse/frequency/switch output } P_i = 0.7 \text{ W}$
- 3) $T_{a, max} = 70 \degree C$ for pulse/frequency/switch output $P_i = 0.7 \text{ W}$

Basic spe	Basic specification, position 1, 2 (Approval) = GG, IG										
Version with max. $T_{m, max range} = 440 \ ^{\circ}C$											
T _{a, max}											
[°C]	T6 [85 ℃]										
40	80 ¹⁾	95 ¹⁾	130 ¹⁾	195 ¹⁾	290 ¹⁾	440 ¹⁾					
55	-	95 ¹⁾	130 ¹⁾	195 ¹⁾	290 ¹⁾	440 ¹⁾					
65	130 ¹⁾ 195 ¹⁾ 290 ¹⁾ 440 ¹⁾										
70	-	-	130 ¹⁾	195 ^{1) 2)}	290 ^{1) 2)}	440 ¹⁾²⁾					

 For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

2) $T_{a,max} = 70$ °C for pulse/frequency/switch output $P_i = 0.85$ W

Version with max. $T_{m, max range} = 280 \ ^{\circ}C$									
T _{a, max}	$ \begin{array}{c c} \Gamma_{a,max} & & & T_{m,max} \\ \hline \ \ \ \ \ \ \ \ \ \ \ \ \$								
[°C]									
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
55 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
60	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
65	-	-	130 ²⁾	195 ²⁾	280 ²⁾³⁾	280 ²⁾³⁾			
70	-	-	130 ²⁾	130 ²⁾	130 ²⁾	130 ²⁾			

Basic specification, position 3 (output; input) = C

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 65 \degree C$ for pulse/frequency/switch output $P_i = 0 W$

Version w	Version with max. $T_{m, max range} = 440 \ ^{\circ}C$										
T _{a, max}		T _{m, max} T6 T5 T4 T3 T2 T1 [85 °C] [100 °C] [135 °C] [200 °C] [300 °C] [450 °C]									
[°C]											
40 1)	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾					
55 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾					
65	-	_	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾					
70	-	_	130 ²⁾	195 ^{2) 3)}	290 ^{3) 2)}	440 ³⁾²⁾					

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 70 \degree C$ for pulse/frequency/switch output $P_i = 0 W$

Version with max. $T_{m, max range}$ = 280 °C										
T _{a, max}		T _{m, max}								
[°C]	T6 [85 °C]									
35 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
50 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
55	-	-	-	195 ²⁾	280 ²⁾	280 ²⁾				
60	-	-	-	195 ²⁾	195 ²⁾	195 ²⁾				

Basic specification, position 3 (output; input) = D

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

Version with max. $T_{m, max range} = 440 \degree C$									
T _{a, max}									
[°C]	T6 [85 ℃]	T5 [100 °C]	T4 [135 ℃]	T3 [200 °C]	T2 [300 °C]	T1 [450 ℃]			
35 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
50 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
55	-	-	-	195 ²⁾	290 ²⁾	440 ²⁾			
60	-	-	-	195 ²⁾	290 ²⁾	440 ²⁾			
65	-	-	-	-	290 ²⁾	290 ²⁾			

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

Version w	Version with max. $T_{m, max range}$ = 280 °C									
T _{a, max}	T _{m, max}									
[°C]	T6 [85 °C]	T5 [100 °C]	T4 [135 ℃]	T3 [200 °C]	T2 [300 °C]	T1 [450 °C]				
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
50 ¹⁾	-	95 ²⁾	130 ²⁾³⁾	195 ^{2) 3)}	280 ²⁾³⁾	280 ²⁾³⁾				
60	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾				
65	-	-	130 ²⁾	195 ²⁾	280 ²⁾⁴⁾	280 ²⁾⁴⁾				
70	-	-	130 ²⁾	195 ^{2) 5)}	280 ²⁾⁵⁾	280 ^{2) 5)}				

Basic specification, position 3 (output; input) = E, G

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 60 \degree C$ for pulse/frequency/switch output $P_i = 0 W$

4) $T_{a, max} = 65 \text{ °C for pulse/frequency/switch output } P_i = 0 \text{ W}$

5) $T_{a, max} = 70 \text{ °C for pulse/frequency/switch output } P_i = 0 \text{ W}$

Version w	Version with max. $T_{m, max range}$ = 440 °C									
T _{a, max}		T _{m, max}								
[°C]	T6 [85 °C]	T5 T4 T3 T2 T1								
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾				
50 ¹⁾	-	95 ²⁾	130 ²⁾³⁾	195 ^{2) 3)}	290 ²⁾³⁾	440 ²⁾³⁾				
65	-	-	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾				
70	-	-	130 ²⁾	195 ^{2) 4)}	290 4) 2)	440 ⁴⁾²⁾				

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 60 \degree C$ for pulse/frequency/switch output $P_i = 0 W$

4) $T_{a, max} = 70 \text{ °C for pulse/frequency/switch output } P_i = 0 \text{ W}$

Version with max. T _{m, max range} = 280 °C									
T _{a, max}		T _{m, max}							
[°C]	T6 [85 °C]	T5 [100 °C]	T4 T3 T2 T1 [135 °C] [200 °C] [300 °C] [450 °C]						
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
50 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
55	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
60	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			

Basic specification, position 3 (output; input) = S, T

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

Version w	Version with max. $T_{m, max range} = 440 \ ^{\circ}C$								
T _{a, max}		T _{m, max}							
[°C]	T6 [85 ℃]								
40 ¹⁾	80 ²⁾	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
50 ¹⁾	-	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
60	-	-	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			

1) The following applies for basic specification, position 1, 2 (Approval) = GD, ID, GH, IH: The ambient temperature changes to $T_{a, max} = T_{a, max} - 2$ K for installations with overvoltage protection in conjunction with temperature classes T5 and T6.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

Maximum medium temperature remote version - sensor

 $T_{m, max}$ See the corresponding temperature tables.

Version v	Version with max. $T_{m, max range}$ = 280 °C								
T _{a, max}		T _{m, max}							
[°C]	T6 [85 °C]								
55	80 1) 2)	95 ²⁾	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
70	-	95 ^{2) 3)}	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			
85	-	-	130 ²⁾	195 ²⁾	280 ²⁾	280 ²⁾			

1) $T_{a max} = 40$ °C for device versions with pressure component option DA, DB, DC, DD.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ... T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

³⁾ $T_{a, max} = 55$ °C for device versions with pressure component option DA, DB, DC, DD.

Version with max. $T_{m, max range} = 440 \ ^{\circ}C$									
T _{a, max}	T _{m, max}								
[°C]	T6 [85 °C]								
55	80 1) 2)	95 ²⁾	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
70	-	95 ^{2) 3)}	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			
85	-	-	130 ²⁾	195 ²⁾	290 ²⁾	440 ²⁾			

1) $T_{a, max} = 40$ °C for device versions with pressure component option DA, DB, DC, DD.

2) For device versions with a pressure component that is installed directly on the sensor F, O, R, the maximum medium temperature is limited to 40 °C for T6 ...T5 and to 90 °C for T4 ... T1. In the case of T4 ... T1 and medium temperatures > 90 °C, the pressure component DPC21 must be installed using a spacer tube between the pressure component and the sensor F, O, R. The length of the spacer tube must be at least 50 cm (19.7 in).

3) $T_{a, max} = 55 \degree C$ for device versions with pressure component option DA, DB, DC, DD.

Connection values: Signal circuits The following tables contain specifications which are dependent on the transmitter type and its input and output assignment. Compare the following specifications with those on the nameplate of the transmitter.

Cable specification: Connecting cable for remote version

Basic specification (approval) 1,2 = *GD*, *GH*

The sensor cable connection between the sensor and the transmitter has type of protection Ex ic.

Cable parameter: $L/R \le 38.2 \ \mu H/\Omega$

The cable supplied by Endress+Hauser complies with the specifications.

Cable specification for pressure measuring cell connecting cable


Basic specification (approval) 1,2 = GD, ID, GH, IH

The cable connection between the transmitter and pressure component or between the sensor and pressure component has type of protection Ex ic.

Cable parameter: L/R \leq 38.2 μ H/ Ω

The cable supplied by Endress+Hauser complies with the specifications.

Connecting the transmitter



Position		Basic specification, position 1, 2: Approval	Type of protection used for cable entry	Description
1	Cable entry for output 1	GG, IG GD, ID, GH, IH	Ex ec Ex ic	The following applies for devices with basic specification, position 1, 2 (Approval) = GG, IG: In the case of device versions with a plastic transport sealing plug, this plug does not meet the explosion protection requirements and must be replaced during installation by a suitable entry that meets the approval specifications. In the case of device versions with a cable entry, this entry has a separate component approval and meets the requirements of the explosion protection indicated on the nameplate.
2	Cable entry for output 2	GG, IG GD, ID, GH, IH	Ex ec Ex ic	The following applies for devices with basic specification, position 1, 2 (Approval) = GG, IG: In the case of device versions with a metal sealing plug, this plug is part of the device approval and meets the requirements of the explosion protection indicated on the nameplate. In the case of device versions with a cable entry, this entry has a separate component approval and meets the requirements of the explosion protection indicated on the nameplate.
3	Optional order code ¹⁾ : Cable entry of the remote display and operating module FHX50	GG, IG GD, ID, GH, IH	Ex ec ²⁾ Ex ic ³⁾	The following applies for devices with basic specification, position 1, 2 (Approval) = GG, IG: In the case of device versions with a metal sealing plug, this plug is part of the device approval and meets the requirements of the explosion protection indicated on the nameplate. In the case of device versions with a cable entry, this entry has a separate component approval and meets the requirements of the explosion protection indicated on the nameplate.

Position		Basic specification, position 1, 2: Approval	Type of protection used for cable entry	Description	
4 (Only for devices with generation index C)	Optional order code ⁴): Cable entry of pressure measuring cell	GG, IG GD, ID, GH, IH	Ex ec Ex ic	The following applies for devices with basic specification, position 1, 2 (approval) = GG, IG: In the case of device versions with metal extensions and sealing plugs, the latter are part of the device approval and meet the requirements of the explosion protection indicated on the nameplate. In the case of device versions with a cable entry, this entry has a separate component approval and meets the requirements of the explosion protection indicated on the nameplate.	
Position			Description		
5	5		NOTICE Housing degree of protection voided due to insufficient sealing of the housing.		
0	Potential equal	ization	NOTICE Terminal for connection to potential equalization. > Pay attention to the grounding concept of the facility.		

1)

Basic specification, position 4 (display; operation) = L, M The labeling changes according to whether "Display; Operation" = "L" or "M": 2Ex ec [ia Ga] IIC T6...T1 Gc. 2)

3) For GH, IH: The labeling changes according to whether "Display; Operation" = "L" or "M":

2Ex ic [ia Ga] IIC T6...T1 Gc.

4) Basic specification, position 8, 9 (sensor version; DSC sensor; measuring tube) = DA, DA, DC, DD and position 11 (pressure component) = B, C, D, E, F, G

Terminal assignment

Transmitter

The order code is part of the extended order code. Detailed information on the features of the device and on the structure of the extended order code $\rightarrow \triangleq 5$.

Connection versions

Order code for		Terminal numbers						
"Output"	Output 1		Outp	out 2	Input			
	1 (+)	2 (-)	3 (+)	4 (-)	5 (+)	6 (-)		
Option A	4-20m/ (pas		-	-	-	-		
Option B $^{1)}$	4-20m/ (pas		Pulse/frequency/ switch output (passive)			-		
Option $C^{1)}$	4-20m/ (pas		4-20mA analog (passive)		-			
Option D ^{1) 2)}	4-20mA HART (passive)		Pulse/frequency/ switch output (passive)		4-20mA current input (passive)			
Option E ^{1) 3)}	FOUNE Field	ATION lbus	Pulse/frequency/ switch output (passive)			-		
Option $\mathbf{G}^{(1)(4)}$	PROFIBUS PA		Pulse/frequency/ PROFIBUS PA switch output (passive)			-		
Option S	Ethernet-	NET over t-APL/SPE, - Mbit/s						
Option T	Ethernet-	TCP over APL/SPE, bit/s	-					

1) Output 1 must always be used; output 2 is optional.

2) The integrated overvoltage protection is not used with option D: Terminals 5 and 6 (current input) are not protected against overvoltage.

3) FOUNDATION Fieldbus with integrated reverse polarity protection.

4) PROFIBUS PA with integrated reverse polarity protection.

Intrinsically safe values



The order code is part of the extended order code. Detailed information on the features of the device and on the structure of the extended order code $\rightarrow \cong 5$.

Type of protection Ex ic

Order code for "Output"	Output type	Intrinsically safe values
Option A	4-20mA HART	$\begin{array}{l} U_i = DC \; 35 \; V \\ I_i = n.a. \\ P_i = 1 \; W \\ L_i = 0 \; \mu H \\ C_i = 5 \; nF \end{array}$
Option B	4-20mA HART	$\begin{array}{l} U_{i} = DC \ 35 \ V \\ I_{i} = n.a. \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 5 \ nF \end{array}$
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = DC \; 35 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 6 \; nF \end{array}$
Option C	4-20mA HART	U _i = DC 30 V
	4-20mA analog	
Option D	4-20mA HART	$\begin{array}{l} U_{i} = DC \ 35 \ V \\ I_{i} = n.a. \\ P_{i} = 1 \ W \\ L_{i} = 0 \ \mu H \\ C_{i} = 5 \ nF \end{array}$
	Pulse/frequency/switch output	$\begin{array}{l} U_{i} = DC \; 35 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 6 \; nF \end{array}$
	4 to 20 mA current input	$\begin{array}{l} U_{i} = DC \; 35 \; V \\ I_{i} = n.a. \\ P_{i} = 1 \; W \\ L_{i} = 0 \; \mu H \\ C_{i} = 5 \; nF \end{array}$
Option E	FOUNDATION Fieldbus	$ \begin{array}{ll} \mbox{STANDARD} & \mbox{FISCO} \\ U_i = 32 \ V & U_i = 17.5 \ V \\ l_i = 300 \ mA & l_i = n.a. \\ P_i = n.a. & P_i = n.a. \\ L_i = 10 \ \mu H & L_i = 10 \ \mu H \\ C_i = 5 \ nF & C_i = 5 \ nF \end{array} $
	Pulse/frequency/switch output	$\begin{array}{l} U_i = 35 \ V \\ l_i = 300 \ mA \\ P_i = 1 \ W \\ L_i = 0 \ \mu H \\ C_i = 6 \ nF \end{array}$

Order code for "Output"	Output type	Intrinsically s	afe values	
Option G	PROFIBUS PA	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$		
	Pulse/frequency/switch output	$U_i = 35 V$ $I_i = 300 mA$ $P_i = 1 W$ $L_i = 0 \mu H$ $C_i = 6 nF$		
Option S	PROFINET over Ethernet- APL/SPE, 10Mbit/s	2-WISE powe port profile S		
Option T	Modbus TCP over Ethernet- APL/SPE, 10Mbit/s	Ex ic $U_i = 17.5 V$ $I_i = 380 mA$ $P_i = 5.32 W$ $L_i = negligible$ $C_i = 1 nF$ Cable specific according to 1 $R_c = 15 to 150$ $L_c = 0.4 to 1 m$ $C_c = 45 to 200$ $C_c = C_c line/lin screen, if the sconnected to a Length of cablincluding cablic sconnected to a Length of cabli$	cations 2-WISE:) $Ω/km$ aH/km b) nF/km at + 0,5 C _c both lines are both lines are are + C _c line/ screen is one line le (not e stubs): 2)	

¹⁾ For further options see Ethernet-APL Installation Drawing HE_01622.

Safety-related values

The order code is part of the extended order code. Detailed information on the features of the device and on the structure of the extended order code $\rightarrow \cong 5$.

Type of protection Ex ec

Order code for "Output"	Output type	Safety-related values	
Option A	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$	
Option B	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$	
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$	
Option C	4-20mA HART	U _{nom} = DC 30 V U _{max} = 250 V	
	4-20mA analog		
Option D	4-20mA HART	$U_{nom} = DC 35 V$ $U_{max} = 250 V$	
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$	
	4 to 20 mA current input	$U_{nom} = DC 35 V$ $U_{max} = 250 V$	
Option E	FOUNDATION Fieldbus	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$	
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$	
Option G	PROFIBUS PA	$U_{nom} = DC 32 V$ $U_{max} = 250 V$ $P_{max} = 0.88 W$	
	Pulse/frequency/switch output	$U_{nom} = DC 35 V$ $U_{max} = 250 V$ $P_{max} = 1 W^{1}$	
Option S ²⁾	PROFINET over Ethernet- APL/SPE, 10Mbit/s	$\begin{array}{l} \textbf{2-WISE power load, APL port profile SLAX}\\ U_{nom} = DC \ 17.5 \ V\\ U_{max} = 250 \ V\\ P_{nom} = 0.9 \ W \end{array}$	
Option T ²⁾	Modbus TCP over Ethernet-APL/SPE, 10Mbit/s		

1)

Internal circuit limited by $R_{i}=760.5\ \Omega$ To be installed in systems that are limited to safe extra-low voltage such as SELV, PELV or ES1. Only one conductor per terminal is allowed. 2)

Remote display FHX50

Basic specification, position 1, 2 Approval	Cable specification	Basic specification, position 4 Display, Operation Option L, M
	Max. cable length: 60 m (196.85 ft)	U _o = 7,3 V
		I _o = 327 mA
		$P_0 = 362 \text{ mW}$
Option GD, ID, GG, IG, GH, IH		L _o = 149 μH
		C _o = 388 nF
		C _c ≤ 125 nF
		$L_c \le 149 \ \mu H$



www.addresses.endress.com

