
Description of Device Parameters **Cerabar PMC71B**

Process pressure measurement PROFIBUS PA







1 About this document

1.1 **Document function**

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 **Document structure**

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.

The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating** tool.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** $(\rightarrow \cong 58)$ they are logged in with. This document lists the submenus and their parameters that are available to the User role Maintenance.


The operating menu is dynamic and adapts the choice of parameters to the selected options.




For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:

Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols

▲ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of information


- 1 Indicates additional information
- Reference to documentation
- Operation via local display
- Operation via operating tool
- Write-protected parameter

1.6 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu



	Counter underruns of user limit Tmin	→ 🖺 21
	Minimum terminal voltage	→ 🖺 21
	Minimum electronics temperature	→ 🖺 22
	Reset user defined counters P and T	→ 🖺 22
	Pressure max	→ 🖺 19
	Counter limit overruns sensor Pmax	→ 🖺 19
	Counter overruns of user limit Pmax	→ 🖺 20
	Maximum sensor temperature	→ 🖺 20
	Counter limit overruns sensor Tmax	→ 🖺 21
	Counter overruns of user limit Tmax	→ 🖺 21
	Maximum terminal voltage	→ 🖺 22
	Maximum electronics temperature	→ 🖺 22
► Simulation		→ 🖺 23
	Simulation	→ 🖺 23
	Diagnostic event simulation	→ 🖺 23
	Value pressure simulation	→ 🖺 23
► Heartbeat Tec	chnology	→ 🖺 24
	► Heartbeat Verification	→ 🖺 24
	Date/time Heartbeat Verification	→ 🖺 24
	Operating time (Verification)	→ 🖺 24
	Verification result	→ 🖺 24
	Status	→ 🖺 25
	► Statistical Sensor Diagnostics	→ 🖺 25
	SSD: Statistical Sensor Diagnostics	→ 🖺 25
	System status	→ 🖺 25
	System status	, 🗀)

		Signal status		→ 🖺 26
		Signal noise status		→ 🖺 26
► Diagnostic settin	ıgs			→ 🖺 27
	► Properties			→ 🖺 27
		SSD Out of range de	elay time	→ 🖺 27
		SSD Monitoring del	lay time	→ 🖺 27
		500 Process alert p	ressure	→ 🖺 27
		Low alert value		→ 🖺 28
		High alert value		→ 🖺 28
		501 Process alert so	caled variable	→ 🖺 28
		Low alert value		→ 🖺 28
		High alert value		→ 🖺 29
		User temperature p	process alert	→ 🖺 29
		Low alert value		→ 🖺 29
		High alert value		→ 🖺 30
	▶ Configuration			→ 🖺 30
		► Configuration		→ 🖺 30
			500 Diagnostic behavior	→ 🖺 30
			500 Event category	→ 🖺 31
			501 Diagnostic behavior	→ 🖺 31
			501 Event category	→ 🖺 31
			502 Diagnostic behavior	→ 🖺 32
			502 Event category	→ 🖺 32
				\ E\ 22
		► Process		→ 🖺 32

		822 Event category	→ 🖺 33
		900 Diagnostic behavior	→ 🖺 33
		900 Event category	→ 🖺 33
		906 Diagnostic behavior	→ 🖺 34
		906 Event category	→ 🖺 34
Application			→ 🖺 35
► Measuring uni	ts		→ 🖺 35
	Pressure unit		→ 🖺 35
	Decimal places pressure		→ 🖺 35
	Temperature unit		→ 🖺 36
	Scaled variable unit		→ 🖺 36
	Free text		→ 🖺 37
	Decimal places scaled variable		→ 🖺 38
► Measured valu	es		→ 🖺 38
	Pressure		→ 🖺 38
	Scaled variable		→ 🖺 38
	Sensor temperature		→ 🖺 39
	Terminal voltage 1		→ 🖺 39
	Electronics temperature		→ 🖺 39
► Sensor			→ 🖺 40
	▶ Basic settings		→ 🖺 40
	Damping		→ 🖺 40
	► Sensor calibration		→ 🖺 40
	Zero adjustment		→ 🖺 40
	Calibration offset		→ 🖺 41

	Zero adjustment offset	→ 🖺 41
	Sensor Trim Reset	→ 🖺 41
	Lower sensor trim measured valu	e → 🖺 41
	Lower sensor trim	→ 🖺 42
	Upper sensor trim measured valu	e → 🖺 42
	Upper sensor trim	→ 🖺 42
•	Sensor limits	→ 🖺 43
	Lower Range Limit	→ 🖺 43
	Upper Range Limit	→ 🖺 43
	Minimum span	→ 🖺 44
	Sensor temperature lower range	limit → 🖺 44
	Sensor temperature upper range	limit → 🖺 44
•	Scaled variable	→ 🖺 44
	Scaled variable unit	→ 🖺 44
	Free text	→ 🖺 45
	Pressure	→ 🖺 46
	Scaled variable transfer function	→ 🖺 46
	Pressure value 1	→ 🖺 46
	Scaled variable value 1	→ 🖺 46
	Pressure value 2	→ 🖺 47
	Scaled variable value 2	→ 🖺 47
▶ Profibus		→ 🖺 47
•	Configuration	→ 🖺 47
	Device tag	→ 🖺 47
	Ident number selector	→ 🖺 48

	PROFIBUS ident nur	mber	→ 🖺 48
	Address mode		→ 🖺 48
	Device address		→ 🖺 49
► Analog input			→ 🖺 49
	► Analog input 1 t	o 6	→ 🖺 49
		Out value	→ 🖺 49
		Out status	→ 🖺 49
		Out unit text	→ 🖺 50
		Channel	→ 🖺 50
		PV filter time	→ 🖺 50
		Simulate enabled	→ 🖺 51
		Simulate value	→ 🖺 51
		Simulate status	→ 🖺 51
► Digital input			→ 🖺 52
	▶ Digital input 1 to	o 2	→ 🖺 52
		Out value	→ 🖺 52
		Out status	→ 🖺 52
		Channel	→ 🖺 52
		Simulate enabled	→ 🖺 53
		Simulate value	→ 🖺 53
		Simulate status	→ 🖺 53
► Analog outpu	ıt]	→ 🖺 54
	► Analog output		→ 🖺 54
		Out value	→ 🖺 54
		Out status	→ 🖺 54

		Out unit	→ 🖺 54
		Fail-safe type	→ 🖺 55
		Fail-safe time	→ 🖺 55
		Fail-safe value	→ 🖺 55
	► Information		→ 🖺 55
	Device ID		→ 🖺 55
	Profile version	1	→ 🖺 56
	► Statistics		→ 🖺 56
	CRC Count OK		→ 🖺 56
	CRC Count Fail	led	→ 🖺 56
System]		→ 🖺 57
▶ Device manager	ment		→ 🖺 57
			_
	Device tag		→ 🖺 57
	Locking status		→ 🖺 57
	Static revision		→ 🖺 57
	Reset device		→ 🖺 58
► Bluetooth confi	guration		→ 🖺 63
	Bluetooth activation		→ 🖺 63
▶ Display			→ 🖺 63
	Language		→ 🖺 63
	Format display		→ 🖺 64
	Value 1 display		→ 🖺 64
	Value 2 4 display		→ 🖺 64
	Contrast display		→ 🖺 65
	rJ		

► Information		=	→ 🖺 65
	Device name	=	→ 🖺 65
	Manufacturer	-	→ 🖺 65
	Serial number	=	→ 🖺 66
	Order code	-	→ 🖺 66
	Firmware version	-	→ 🗎 66
	Hardware version	-	→ 🖺 66
	Extended order code 1 3	=	→ 🖺 67
	Checksum	=	→ 🖺 67
► Software con:	figuration	=	→ 🖺 72
	CRC device configuration	=	→ 🖺 72
	Activate SW option	-	→ 🖺 72
	Software option overview	-	→ 🖺 72

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of quided wizards and cross-thematic special functions.

Navigation 📵 🗐 Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - SSD: Statistical Sensor Diagnostics
 - Process window
- Import/Export
- Compare

Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

A WARNING

If the wizard is aborted before all the necessary parameters have been configured, any settings already set are saved.

The device may be in an undefined state!

► Reset the device to factory settings.

Parameters for the "Commissioning" wizard

The following parameters are configured or displayed in this wizard:

- Device identification
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - Device ID
 - Device address

Measurement adjustments

- Damping
- Assign scaled variable?
- Pressure unit
- Temperature unit
- Scaled variable unit
- Zero adjustment
- Pressure

Output settings

- Scaled variable transfer function
- Lower Range Limit
- Upper Range Limit
- Minimum span
- Linearization
- Pressure value 1/2
- Scaled variable value 1/2
- Channel

Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application

Special Documentation on Heartbeat Technology is available via the Internet: www.endress.com → Download

Navigation \Box Guidance \rightarrow Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation \square Guidance \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

SSD: Statistical Sensor Diagnostics

Using statistical analysis of the pressure signal, process anomalies such as plugged impulse lines can be detected. This wizard supports the settings and thresholds that should lead to a diagnostic message.

Navigation \square Guidance \rightarrow Heartbeat Techn. \rightarrow Stat. Sens. Diag

Process window

This wizard uses user-defined limits for pressure and temperature to detect unwanted installation or application anomalies.

Applications:

- Defective heat tracer or insulation
- Frozen process connections
- Dynamic pressure peaks etc.

Navigation \square Guidance \rightarrow Heartbeat Techn. \rightarrow Process window

Import/Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create configuration report

Under Create configuration report, device documentation can be saved in PDF format. This device documentation contains the following general device information:

- Information on device parameters
- Event list
- Diagnostic list

Navigation \Box Guidance \rightarrow Import/Export

Compare

Compare datasets

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import/Export
- Datasets with the configuration currently in the device

Navigation Guidance → Compare 3.2 **Diagnostics** Navigation ■ □ Diagnostics 3.2.1 **Active diagnostics** \blacksquare Diagnostics \rightarrow Active diagnos. Navigation Active diagnostics Navigation Diagnostics \rightarrow Active diagnos. \rightarrow Active diagnos. Description Displays the currently active diagnostic message. If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed. User interface • Operating time of the device until the event occurs Symbol for diagnostic behavior Code for diagnostic behavior Event text ■ Corrective measure **Timestamp** Navigation Diagnostics → Active diagnos. → Timestamp Description Displays the timestamp for the currently active diagnostic message. User interface Days (d), hours (h), minutes (m), seconds (s) **Previous diagnostics**

16 Endress+Hauser

Diagnostics \rightarrow Active diagnos. \rightarrow Prev.diagnostics

Displays the diagnostic message for the last diagnostic event that has ended.

Navigation

Description

User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure

Timestamp	Tim	esta	ımp
-----------	-----	------	-----

Navigation □ Diagnostics → Active diagnos. → Timestamp

Description Displays the timestamp of the diagnostic message generated for the last diagnostic event

that has ended.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time from restart

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Time fr. restart

Description Indicates how long the device has been in operation since the last time the device was

restarted.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Operating time

Description Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

3.2.2 Diagnostic list

Navigation \Box Diagnostics \rightarrow Diagnostic list

3.2.3 Event logbook

Navigation \Box Diagnostics \rightarrow Event logbook

Clear event list

Navigation \square Diagnostics \rightarrow Event logbook \rightarrow Clear event list

Description Delete all entries of the event list.

Selection • Cancel

Clear data

Factory setting Cancel

Additional information Access:

Read access: ExpertWrite access: Expert

3.2.4 Minimum/maximum values

Navigation $\blacksquare \square$ Diagnostics \rightarrow Min/max val.

Pressure min

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Pressure min

Description Minimum value measured by the device

User interface Signed floating-point number

Factory setting Positive floating-point number

Pressure max

Navigation □ Diagnostics → Min/max val. → Pressure max

Description Maximum value measured by the device

User interface Signed floating-point number

Factory setting Negative floating-point number

Counter limit underruns sensor Pmin

Navigation Diagnostics \rightarrow Min/max val. \rightarrow Counter P < Pmin

Description Counts how many times the value underruns the sensor specific minimum values.

Sensor specific minimum values are shown in Application/Sensor menu.

User interface 0 to 65 535

Factory setting 0

Counter limit overruns sensor Pmax

Navigation Diagnostics \rightarrow Min/max val. \rightarrow Counter P > Pmax

Description Counts how many times the value overruns the sensor specific maximum values.

Sensor specific maximum values are shown in Application/Sensor menu.

User interface 0 to 65 535

Factory setting 0

Counter underruns of user limit Pmin

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter < P user

Description Counts how many times the value underruns the minimum values defined by the user.

User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties

menu.

User interface 0 to 65 535

Factory setting 0

Additional information Only visible if Process window in Heartbeat Monitoring is activated.

Counter overruns of user limit Pmax

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter > P user

Description Counts how many times the value overruns the maximum values defined by the user.

User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties

menu.

User interface 0 to 65 535

Factory setting 0

Additional information Only visible if Process window in Heartbeat Monitoring is activated.

Minimum sensor temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Min. sensor temp

Description Minimum value measured by the device

Users cannot reset this value.

Maximum sensor temperature

Navigation Diagnostics \rightarrow Min/max val. \rightarrow Max. sensor temp

Description Maximum value measured by the device

Users cannot reset this value.

Counter limit underruns sensor Tmin

Navigation Diagnostics \rightarrow Min/max val. \rightarrow Counter T < Tmin

Description Counts how often the value falls below the sensor-specific minimum values. The sensor-

specific minimum values are displayed in the Application ($\rightarrow \equiv 35$)/Sensor ($\rightarrow \equiv 40$)

menu.

User interface 0 to 65 535

Factory setting 0

Counter limit overruns sensor Tmax

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter T > Tmax

Description Counts how often the value exceeds the sensor-specific maximum values. The sensor-

specific maximum values are displayed in the Application ($\rightarrow \equiv 35$)/Sensor ($\rightarrow \equiv 40$)

menu.

User interface 0 to 65 535

Factory setting 0

Counter underruns of user limit Tmin

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter < T user

User interface 0 to 65 535

Factory setting 0

Additional information Only visible if Process window in Heartbeat Monitoring is activated.

Counter overruns of user limit Tmax

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter > T user

User interface 0 to 65 535

Factory setting 0

Additional information Only visible if Process window in Heartbeat Monitoring is activated.

Minimum terminal voltage

Description Minimum terminal voltage measured (supply).

User interface 0.0 to 50.0 V

Maximum terminal voltage Navigation Diagnostics \rightarrow Min/max val. \rightarrow Max.term.voltage Description Maximum terminal voltage measured (supply). User interface 0.0 to 50.0 V Minimum electronics temperature Navigation Diagnostics \rightarrow Min/max val. \rightarrow Min.electr.temp. Description Minimum measured temperature of the main electronics. User interface Signed floating-point number Maximum electronics temperature Navigation Diagnostics \rightarrow Min/max val. \rightarrow Max.electr.temp. Description Maximum measured temperature of the main electronics. User interface Signed floating-point number Reset user defined counters P and T Navigation Diagnostics \rightarrow Min/max val. \rightarrow Reset count. P T ■ Cancel Selection

Only visible if Process window in Heartbeat Monitoring is activated.

Confirm

Cancel

Factory setting

Additional information

3.2.5 Simulation

Navigation \Box Diagnostics \rightarrow Simulation

Simulation

Navigation \square Diagnostics \rightarrow Simulation

Description Simulates one or more process variables and/or events.

Warning:

Output will reflect the simulated value or event.

Selection ■ Off

Diagnostic event simulation

■ Pressure

Factory setting Off

Diagnostic event simulation

Navigation $riangleq ext{Diagnostics} o ext{Simulation} o ext{Diagnostic event}$

Description Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select "Off".

Selection ■ Off

■ Drop-down list of diagnostic events

Factory setting Off

Value pressure simulation

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Pressure

User entry Signed floating-point number

Factory setting 0 mbar

3.2.6 Heartbeat Technology

Heartbeat Verification

Navigation \bigcirc □ Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

Date/time Heartbeat Verification

Navigation □ Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat

Verification

Description Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.q. Heartbeat verification is started from display,

"----" is shown.

User interface Character string comprising numbers, letters and special characters

Factory setting 01.01.1970 00:00:00

Operating time (Verification)

Navigation Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif. \rightarrow Operating time

Description Value of the operating hours counter at the time of verification.

User interface Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif. \rightarrow Verific. result

Description Result of Heartbeat Verification.

User interface ■ Not done

PassedNot doneFailed

Factory setting Not done

Status

Navigation □ Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status

Description Shows the actual status.

User interface • Done

BusyFailedNot done

Factory setting Not done

Statistical Sensor Diagnostics

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow SSD

SSD: Statistical Sensor Diagnostics

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow SSD \rightarrow Stat. Sens. Diag

Description Enable or disable SSD.

After selecting "Disable", no statistical sensor diagnosis takes place. No diagnostic messages

are output.

Selection • Disable

■ Enable

Factory setting Disable

System status

Factory setting

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow SSD \rightarrow System status

User interface ■ Idle

No sufficient signal noise

StableNot stable

Idle

Verify System DynamicsProcess dynamic too high

Signal status

Navigation

User interface

- Idle
- Building BaselineVerifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Factory setting

Idle

Signal noise status

Navigation

□ Diagnostics \rightarrow Heartbeat Techn. \rightarrow SSD \rightarrow Noise status

User interface

- Idle
- Building Baseline
- Verifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Factory setting

Idle

Counter Baseline creation SSD

Navigation

Description

Specifies how often the baseline has been rebuilt.

User interface

Positive integer

Factory setting

0

Additional information

Access:

Read access: ExpertWrite access: -

3.2.7 Diagnostic settings

Navigation \Box Diagnostics \Rightarrow Diag. settings

Properties

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties

SSD Out of range delay time

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow SSD Delay time

User entry 0 to 604 800 s

Factory setting 600 s

SSD Monitoring delay time

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow SSD Verz. Zeit

User entry 0 to 86 400 s

Factory setting 60 s

500 Process alert pressure

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 500 Pressure

Description Define whether user-defined pressure limits should be set.

If "Off" is selected, no analysis will take place and no event message will be generated.

Selection ■ Off

■ On

Factory setting Off

Low alert value **Navigation** Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow Low alert value Description Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis. **User entry** Signed floating-point number 0 mbar **Factory setting** High alert value Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow High alert value Navigation Description Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis. **User entry** Signed floating-point number 500 mbar **Factory setting** 501 Process alert scaled variable **Navigation** Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 501 Scaled var. Description Define whether user-defined limits should be set. If "Off" is selected, no analysis will take place and no event message will be generated. Selection Off On **Factory setting** Off Low alert value Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow Low alert value Description Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis. **User entry** Signed floating-point number

28

Factory setting

0 %

High alert value

Navigation

Navigation

Description

If this limit value is exceeded or undercut, a diagnostic event is generated. There is no

hysteresis.

Set range.

User entry Signed floating-point number

Factory setting 100 %

User temperature process alert

 $riangleq ext{Diagnostics} o ext{Diag. settings} o ext{Properties} o ext{UserTemp alert}$

Description Define whether the user-defined sensor temperature limits should be set. If "Off" no

analysis and therefore no event message will take place.

Selection ■ Off

On

Factory setting Off

Low alert value

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow Low alert value

Description Set range.

If this limit value is exceeded or undercut, a diagnostic event is generated. There is no

hysteresis.

User entry $-50 \text{ to } 150 \,^{\circ}\text{C}$

Factory setting $-35 \,^{\circ}\text{C}$

High alert value **Navigation** Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow High alert value Description Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis. -50 to 150 ℃ **User entry Factory setting** 85°C Configuration Navigation Configuration Navigation 500 Diagnostic behavior Navigation Description Select event behavior. "Logbook entry only": No digital or analog transmission of the message. "Warning": Current output unchanged. Message is output digitally (default). "Alarm": Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. Selection Off ■ Alarm Warning ■ Logbook entry only

Factory setting

Off

500 Event category		
Navigation		g.
Selection	 Failure (F) Function check (C) Out of specification (S) Maintenance required (M) Not categorized 	
Factory setting	Out of specification (S)	

501 Diagnostic behavior		1
Navigation		
Description	Select event behavior.	
	"Logbook entry only": No digital or analog transmission of the message.	
	"Warning": Current output unchanged. Message is output digitally (default).	
	"Alarm": Current output assumes the set alarm current.	
	Regardless of the setting, the message appears on the display. If the permissible condition are reached again, the warning is no longer available in the instrument.	ns
Selection	 Off Alarm Warning Logbook entry only 	

501 Event category	
Navigation	$\mbox{Diagnostics} \rightarrow \mbox{Diag. settings} \rightarrow \mbox{Configuration} \rightarrow \mbox{Configuration} \rightarrow 501 \mbox{Event categ}.$

Failure (F)
Function check (C)
Out of specification (S)
Maintenance required (M)
Not categorized

Off

Factory setting Out of specification (S)

Factory setting

Selection

User interface

AlarmWarning

Logbook entry only

502 Diagnostic behavior Navigation Description Select event behavior. "Logbook entry only": No digital or analog transmission of the message. "Warning": Current output unchanged. Message is output digitally (default). "Alarm": Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. Selection ■ Off ■ Alarm Warning Logbook entry only **Factory setting** Off

502 Event category	
Navigation	$ □ $ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Configuration \rightarrow 502Event categ.
Selection	 Failure (F) Function check (C) Out of specification (S) Maintenance required (M) Not categorized
Factory setting	Out of specification (S)
	Process Navigation
822 Diagnostic behavior	
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 822Diag. behav.

Factory setting

Factory setting	Warning

822 Event category		
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 822Event categ.	
Selection	Failure (F)Function check (C)	

Out of specification (S)
Maintenance required (M)
Not categorized

Out of specification (S)

900 Event category

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 900Event categ.

Description Select category for diagnostic message.

Selection ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

Not categorized

Factory setting Maintenance required (M)

900 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 900Diag. behav.

Description Select event behavior "Logbook entry only":

No forwarding of the message via the fieldbus.

"Warning":

Warning message is transmitted via the fieldbus (default setting).

Regardless of the setting, the message appears on the display. If the permissible conditions

are reached again, the warning is no longer available in the instrument.

Selection • Warning

Logbook entry only

Factory setting Warning

906 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 906Diag. behav.

Description Select event behavior

"Logbook entry only":

No forwarding of the message via the fieldbus.

"Warning":

Warning message is transmitted via the fieldbus (default setting).

Regardless of the setting, the message appears on the display. If the permissible conditions

are reached again, the warning is no longer available in the instrument.

Selection ■ Off

Warning

Logbook entry only

Factory setting Off

906 Event category

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 906Event categ.

Description Select category for diagnostic message.

Selection ■ Failure (F)

Function check (C)Out of specification (S)

Maintenance required (M)

Not categorized

Factory setting Not categorized

3.3 Application

3.3.1 Measuring units

Navigation $\blacksquare \square$ Application \rightarrow Measuring units

Pressure unit Navigation Application \rightarrow Measuring units \rightarrow Pressure unit Selection ■ MPa ■ kPa ■ Pa ■ bar ■ mbar torr ■ atm ■ psi ■ kgf/cm² ■ gf/cm² ■ inH20 ■ inH2O (4°C) ■ mmH2O ■ mmH2O (4°C) mH2O ■ mH2O (4°C) • ftH2O ■ inHg mmHg **Factory setting** Depends on the order option

Decimal places pressure

Navigation riangleq Application riangleq Measuring units riangleq Decimal pressure

Description This selection does not affect the measurement and calculation accuracy of the device.

Selection • Automatic

■ X

X.XX.XX

x.xxx

X.XXXX

Factory setting Automatic

Temperature unit Navigation Application → Measuring units → Temperature unit Description Select the temperature unit. Selection SI units US units ■ °C **■** K **Factory setting** °C Scaled variable unit Navigation Application → Measuring units → Scaled Unit Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection

SI units

- **•** %
- mm
- cm
- m
- **■**]
- hl
- m³
- **■** q
- kg
- t
- q/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- \blacksquare m³/s
- m³/min
- m³/h
- \blacksquare m³/d
- 1/s
- l/min
- l/h
- Nm³/h
- Nl/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

Custom-specific units

Free text

Factory setting

%

US units

- ft
- in
- ft³
- qal (us)
- bbl (us;oil)
- OZ
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft^3/s
- ft³/min
- ft³/h
- ft^3/d
- qal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)bbl/d (us;oil)
- Sft³/min
- Sft³/h
- \blacksquare Sft³/d

- Imperial units
- gal (imp)
- gal/s (imp)
- gal/min (imp)
- qal/h (imp)

Free text

Navigation

User entry

Character string comprising numbers, letters and special characters (32)

Factory setting

Free text

Endress+Hauser

37

Decimal places scaled variable **Navigation** Application \rightarrow Measuring units \rightarrow Decimal scaled Description This selection does not affect the measurement and calculation accuracy of the device. Selection ■ X ■ X.X X.XX X.XXX X.XXXX **Factory setting** X.XX 3.3.2 Measured values \square Application \rightarrow Measured values Navigation Sensor pressure Navigation Application \rightarrow Measured values \rightarrow Sensor pressure User interface Signed floating-point number **Factory setting** 0 mbar Additional information Access: Read access: Expert ■ Write access: -**Pressure** Navigation Application \rightarrow Measured values \rightarrow Pressure **Factory setting** 0 mbar Scaled variable Navigation Application \rightarrow Measured values \rightarrow Scaled variable User interface Signed floating-point number

Factory setting 0 %

Sensor temperature

Navigation \square Application \rightarrow Measured values \rightarrow Sensor temp.

Description Displays the current temperature of the sensor.

User interface Floating point number with sign

Terminal voltage 1

Navigation riangleq Application riangleq Measured values riangleq Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V

Electronics temperature

Navigation \Box Application \rightarrow Measured values \rightarrow Electronics temp

Description Displays the current temperature of the main electronics.

User interface Signed floating-point number

3.3.3 Sensor

Navigation $\blacksquare \square$ Application \rightarrow Sensor

Basic settings

Navigation \square Application \rightarrow Sensor \rightarrow Basic settings

Damping

Navigation \square Application \rightarrow Sensor \rightarrow Basic settings \rightarrow Damping

Description The damping is effective before the measured value is further processed, i.e., before the

following processes:

- Scaling

Limit value monitoringForwarding to display

- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own "Damping" parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0.

Otherwise, the signal will be attenuated several times.

User entry 0 to 999.0 s

Factory setting 1 s

Sensor calibration

Navigation $\blacksquare \square$ Application \rightarrow Sensor \rightarrow Sensor cal.

Zero adjustment

Navigation \square Application \rightarrow Sensor cal. \rightarrow Zero adjustment

Description Due to the mounting position of the measuring instrument, a pressure shift may occur.

The pressure shift can be corrected with the zero adjustment.

Selection ■ No

Confirm

Factory setting No

Calibration offset

Navigation riangleq Application riangleq Sensor cal. riangleq Calibr offset

Description Enter the value by which the measured value should be corrected, e.g., a position

adjustment for absolute pressure sensors.

User entry Signed floating-point number

Factory setting 0 mbar

Additional information Parameters only available for absolute pressure sensors.

Zero adjustment offset

Navigation \square Application \rightarrow Sensor \rightarrow Sensor cal. \rightarrow Zero offset

User entry Signed floating-point number

Factory setting 0 mbar

Sensor Trim Reset

Navigation riangleq Application riangleq Sensor cal. riangleq Sen. Trim Reset

Selection ■ No

Confirm

Factory setting No

Lower sensor trim measured value

Navigation \square Application \rightarrow Sensor cal. \rightarrow LowerTrimMeasVal

User interface Signed floating-point number

Factory setting 0 mbar

Lower sensor trim

Navigation

Description

Using the Lower sensor trim and Upper sensor trim parameters, a sensor can be recalibrated, e.g. if the sensor is to be precisely calibrated to the measuring range. Maximum measurement accuracy of the sensor is achieved when the value for the Lower sensor trim parameter is as close as possible to the lower measuring range, and the value for the Upper sensor trim parameter is as close as possible to the upper measuring range.

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value.

The more accurate the reference device used for sensor calibration, the higher the measurement accuracy of the pressure transmitter will be later.

Using the Lower sensor trim and Upper sensor trim parameters, a new value is then assigned to the applied pressure.

The entered value must not exceed **Sensor pressure** +/- 10 % of the permissible maximum pressure (URL).

Input as follows:

- Apply reference pressure for the lower measuring range.
- Enter and confirm the reference pressure in the Lower sensor trim field.
- Apply reference pressure for the upper measuring range.
- Enter and confirm the reference pressure in the Upper sensor trim field.
- The sensor calibration is now complete.

User entry Signed floating-point number

Factory setting 0 mbar

Upper sensor trim measured value

Navigation Application \rightarrow Sensor \rightarrow Sensor cal. \rightarrow UpperTrimMeasVal

User interface Signed floating-point number

Factory setting 500 mbar

Upper sensor trim

Navigation

Description

Using the Lower sensor trim and Upper sensor trim parameters, a sensor can be recalibrated, e.g. if the sensor is to be precisely calibrated to the measuring range. Maximum measurement accuracy of the sensor is achieved when the value for the Lower sensor trim parameter is as close as possible to the lower measuring range, and the value for the Upper sensor trim parameter is as close as possible to the upper measuring range.

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value.

The more accurate the reference device used for sensor calibration, the higher the measurement accuracy of the pressure transmitter will be later.

Using the Lower sensor trim and Upper sensor trim parameters, a new value is then assigned to the applied pressure.

The entered value must not exceed **Sensor pressure** +/- 10 % of the permissible maximum pressure (URL).

Input as follows:

- Apply reference pressure for the lower measuring range.
- Enter and confirm the reference pressure in the Lower sensor trim field.
- Apply reference pressure for the upper measuring range.
- Enter and confirm the reference pressure in the Upper sensor trim field.
- The sensor calibration is now complete.

User entry Signed floating-point number

Factory setting 500 mbar

Sensor limits

Navigation \square Application \rightarrow Sensor \rightarrow Sensor limits

Lower Range Limit

Navigation \square Application \rightarrow Sensor \rightarrow Sensor limits \rightarrow LRL

Description Indicates the lower measuring limit of the sensor.

User interface Signed floating-point number

Factory setting Depends on the order option

Upper Range Limit

Navigation \square Application \rightarrow Sensor \rightarrow Sensor limits \rightarrow URL

Description Indicates the upper measuring limit of the sensor.

User interface Signed floating-point number

Factory setting Depends on the order option

Minimum span

Navigation riangleq Application riangleq Sensor riangleq Sensor limits riangleq Minimum span

Description Specifies the smallest possible measuring span of the sensor.

User interface Signed floating-point number

Factory setting 0.498504 mbar

Sensor temperature lower range limit

Navigation Application \rightarrow Sensor \rightarrow Sensor limits \rightarrow Sens.temp.lo.lim

Factory setting $-35 \,^{\circ}\text{C}$

Sensor temperature upper range limit

Navigation riangleq Application riangleq Sensor riangleq Sensor limits riangleq Sens.temp.up.lim

Factory setting 85 °C

Scaled variable

Scaled variable unit

Navigation riangleq Application riangleq Scaled Variable riangleq Scaled Unit

Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is

possible to define a customer specific unit with another parameter.

Selection

SI units

- **•** %
- mm
- cm • m
- **-** 1
- hl
- m³
- **■** g
- kg
- t
- q/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- \bullet m³/s
- m³/min
- m^3/h
- m³/d
- 1/s
- l/min ■ 1/h
- Nm³/h
- Nl/h
- Sm^3/s ■ Sm³/min
- Sm^3/h
- Sm³/d
- Nm³/s
- q/cm³
- kg/m³
- Nm³/min
- Nm³/d

Custom-specific units

Free text

Factory setting % US units

- ft
- in
- ft³
- qal (us)
- bbl (us;oil)
- OZ
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft^3/s
- ft³/min
- ft³/h
- ft³/d
- qal/s (us)
- qal/min (us)
- qal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- qal/h (imp)

Free text

Navigation

Application \rightarrow Sensor \rightarrow Scaled variable \rightarrow Free text

User entry

Character string comprising numbers, letters and special characters (32)

Factory setting

Free text

Endress+Hauser

45

Pressure **Navigation** Application \rightarrow Sensor \rightarrow Scaled variable \rightarrow Pressure **Factory setting** 0 mbar Scaled variable transfer function **Navigation** Application \rightarrow Sensor \rightarrow Scaled variable \rightarrow Scaled function Description "Linear": The linear pressure signal is used for the output. The flow must be calculated in the evaluation unit. "Table": The output is defined by the entered table, scaled variable/pressure. Selection Linear ■ Table **Factory setting** Linear Pressure value 1 **Navigation** Application \rightarrow Sensor \rightarrow Scaled variable \rightarrow Pressure 1 Description Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure. Signed floating-point number **User entry Factory setting** 0 mbar Scaled variable value 1 Navigation Application \rightarrow Sensor \rightarrow Scaled variable \rightarrow Scaled 1 Description Enter value for the first scaling point. This value is allocated to "Pressure value 1". **User entry** Signed floating-point number

Factory setting

0 %

Pressure value 2

Navigation riangleq Application riangleq Sensor riangleq Scaled variable riangleq Pressure 2

Description Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to

this pressure.

User entry Signed floating-point number

Factory setting 500 mbar

Scaled variable value 2

Navigation riangle Application riangle Scaled variable riangle Scaled 2

Description Enter value for the second scaling point. This value is allocated to "Pressure value 2".

User entry Signed floating-point number

Factory setting 100 %

3.3.4 Profibus

Navigation $\blacksquare \square$ Application \rightarrow Profibus

Configuration

Navigation В Application → Profibus → Configuration

Device tag

Navigation riangleq Application riangleq Profibus riangleq Configuration riangleq Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the

plant.

User entry Character string comprising numbers, letters and special characters (32)

Factory setting Deltabar

Factory setting

Software

Ident number selector		
Navigation		
Description	In order to integrate the field devices into the bus system, the PROFIBUS system needs description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the general station description (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.	a n
Selection	 0x9700 (1AI) Cerabar 0x1573 Automatic mode 	
Factory setting	Automatic mode	
PROFIBUS ident number		<u> </u>
Navigation		
Description	Shows the Profibus Ident number of the device. Which Ident number is used can be defined in the parameter Ident number selector.	
User interface	0 to 65 535	
Factory setting	1574	
Address mode		
Navigation		
Description	Shows the address mode that applies to the device address, e.g. 'Hardware' if set via DI switch	P
User interface	■ Hardware ■ Software	

Device address Navigation Application \rightarrow Profibus \rightarrow Configuration \rightarrow Device address Description The device address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered ex works with device address 126 and software addressing. The address can only be written here if it has not already been set via the DIP switches. User entry 0 to 126 **Factory setting** 126 Analog input Navigation Analog input 1 to 6 Navigation Out value Navigation Application \rightarrow Profibus \rightarrow Analog input \rightarrow Analog input 1 to 6 \rightarrow Out value Description Shows the process value reported to the controller for further processing User entry Signed floating-point number **Factory setting** 0 Out status **Navigation** Application \rightarrow Profibus \rightarrow Analog input \rightarrow Analog input 1 to 6 \rightarrow Out status Description Shows the status of the measured value reported to the controller for further processing

Endress+Hauser 49

(Hex). Writeable in Manual mode.

0 to 255

User entry

Factory setting	128
-----------------	-----

Out unit text		
Navigation		
Description	If a specific unit of OUT parameter is not in the code list the user has the possibility to write the specific text into this parameter. The unit code is then equal to "textual unit definition".	
User entry	Character string comprising numbers, letters and special characters (16)	
Factory setting	mbar	
Channel		
Navigation		
Description	Assigns a measured variable to the AI block.	
Selection	 None Pressure Scaled variable Sensor temperature Sensor pressure Electronics temperature Median of pressure signal * Noise of pressure signal * 	
Factory setting	Pressure	
PV filter time		<u> </u>
Navigation		
Description	Enter time constant for input damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.	
User entry	Positive floating-point number	

0

Factory setting

^{*} Visibility depends on order options or device settings

Factory setting

0

Simulate enabled	
Navigation	
Description	The simulation is used to bypass the physical I/O channel. In this way the block remains in the normal mode and using the simulated discrete I/O channel during operation.
Selection	DisableEnable
Factory setting	Disable
Simulate value	<u>@</u>
Navigation	
Description	The simulation value is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and using the simulated value during operation.
User entry	Signed floating-point number
Factory setting	0
Simulate status	
Navigation	
Description	To simulate a process status for this block. Possible input values can be taken from the PA profile used, see there under the chapter "Process variable status and diagnosis".
	Examples for status values are:
	0x80 (decimal 128) for status "GOOD" 0x24 (decimal 36) for status "BAD
User entry	0 to 255

	Digital inputNavigation $\ \ \ \ $ Application \rightarrow Profibus \rightarrow Digital input
	Digital input 1 to 2 Navigation
Out value	
Navigation	
Description	Shows the state of the device function, which is transmitted to the controller for further processing.
User entry	0 to 255
Factory setting	0
Out status	
Navigation	
Description	Shows the status of the device function state reported to the controller (Hex). Writeable in Manual mode.
User entry	0 to 255
Factory setting	128
Channel	
Navigation	
Description	Select the device function
Selection	 None Process alert pressure Process alert scaled variable Process alert temperature Low signal noise detected *

^{*} Visibility depends on order options or device settings

52

High signal noise detected*
Min signal noise detected*
Out of range signal detected*

Factory setting

None

Simulate enabled

Navigation \square Application \rightarrow Profibus \rightarrow Digital input 1 to 2 \rightarrow Simulate enabled

Selection ■ Disable ■ Enable

Factory setting Disable

Simulate value

Navigation Application \rightarrow Profibus \rightarrow Digital input 1 to 2 \rightarrow Simulate value

Description The simulation value is used to bypass the physical I/O channel. In this way, the block

remains in

the normal mode and using the simulated value during operation.

User entry 0 to 255

Factory setting 0

Simulate status

Navigation Application \rightarrow Profibus \rightarrow Digital input 1 to 2 \rightarrow Simulate status

Description To simulate a process status for this block. Possible input values can be taken from the PA

profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD" 0x24 (decimal 36) for status "BAD

User entry 0 to 255

Factory setting 0

^{*} Visibility depends on order options or device settings

	Analog output
	Navigation \blacksquare Application \rightarrow Profibus \rightarrow Analog output
	Analog and the different forms of the second
	Analog output 1
	Navigation $\ \ \ \ \ \ \ \ \ \ $
Out value	
Navigation	
Description	Shows an analog output value (AO) that is output from the controller to the device and can be shown on the local display. To show the AO on the local display, it must be assigned to a display output parameter as a value. This assignment is made in the menu under "System-Display".
User entry	Signed floating-point number
Factory setting	0
Out status	
Navigation	
Description	Shows the status of the external compensation value reported to the measuring device for further processing (Hex). Writeable in Manual mode.
User entry	0 to 255
Factory setting	128
Out unit	
Navigation	
User entry	0 to 65 535
Factory setting	1997

Fail-safe type	
Navigation	
Description	Select fail-safe behavior in the event of a failure (value with status 'Bad')
Selection	Fixed valueLast valid valueOff
Factory setting	Last valid value
Fail-safe time	
Navigation	
Description	Enter a delay until in the event of a failure (value with status 'Bad') the fail-safe behavior specified applies
User entry	0 to 999.0
Factory setting	0
Fail-safe value	6
Navigation	☐ Application \rightarrow Profibus \rightarrow Analog output \rightarrow Analog output \rightarrow Fail-safe value
Description	Enter value to report in the event of a failure (value with status 'Bad')
User entry	Signed floating-point number
Factory setting	0
	Information
	Navigation $\ \ $
Device ID	
Navigation	
Description	Shows the device ID used by the manufacturer to identify the measuring device type

User interface Character string comprising numbers, letters and special characters

Factory setting Deltabar

Profile version

Navigation riangleq Application riangleq Profibus riangleq Information riangleq Profile version

Description Shows the profile version

User interface Character string comprising numbers, letters and special characters

Factory setting 3.02

Statistics

Navigation $\blacksquare \square$ Application \rightarrow Profibus \rightarrow Statistics

CRC Count OK

Navigation \square Application \rightarrow Profibus \rightarrow Statistics \rightarrow CRC Count OK

Description Indicates how often the checksum test of the cyclic data telegram was successful.

User interface Positive integer

Factory setting 0

CRC Count Failed

Navigation \square Application \rightarrow Profibus \rightarrow Statistics \rightarrow CRC Count Failed

Description Indicates how often the checksum test of the cyclic data telegram detected an error.

User interface Positive integer

Factory setting 0

3.4 System

Navigation 🗐 🗎 System

3.4.1 Device management

Navigation $\blacksquare \square$ System \rightarrow Device manag.

Device tag **Navigation** System \rightarrow Device manag. \rightarrow Device tag Description Enter a unique name for the measuring point to identify the device quickly within the plant. User entry Character string comprising numbers, letters and special characters (32) Deltabar **Factory setting** Locking status **Navigation** System \rightarrow Device manag. \rightarrow Locking status Description Indicates the type of locking. "Hardware locked" (HW) The device is locked by the "WP" switch on the main electronics module. To unlock, set the switch into the OFF position. "WHG locked" (SW) Unlock the device by entering the appropriate access code in "Enter safety unlocking code". "Temporarily locked" (SW) The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes. User interface ■ Hardware locked WHG locked Temporarily locked Static revision

User interface 0 to 65 535

System \rightarrow Device manag. \rightarrow Static revision

Navigation

Description

Endress+Hauser 57

Shows the number of changes made to static parameters (e.g. configuration parameters)

Factory setting

0

Reset device	
--------------	--

Navigation System \rightarrow Device manag. \rightarrow Reset device

Description Reset the device configuration - either entirely or in part - to a defined state

Selection • Cancel

To factory defaults *
To delivery settings *
Restart device

Factory setting

Cancel

3.4.2 User management

Navigation System \rightarrow User manag.

Navigation \square System \rightarrow User manag. \rightarrow User manag.

User role

Navigation \square System \rightarrow User manag. \rightarrow User manag. \rightarrow User role

Description Shows the access authorization to the parameters via the operating tool

User interface ■ Operator

Maintenance

■ Expert

Factory setting Maintenance

Delete password

Navigation \square System \rightarrow User manag. \rightarrow Delete password

Description Deletes the 'Maintenance' password.

After deleting, the 'Operator' role will be no more available.

All users have read/write access rights.

58

^{*} Visibility depends on order options or device settings

User entry	Character string comprising numbers, letters and special characters (1)
Forgot password?	
Navigation	System → User manag. → Forgot password?
5	System \rightarrow User manag. \rightarrow Forgot password?
User entry	Character string comprising numbers, letters and special characters (1)
	Enter password
	Navigation \square System \rightarrow User manag. \rightarrow Enter password
Password	
Navigation	
Description	Enter the password for the "Maintenance" user role to get access to the functionality of this role.
User entry	Character string comprising numbers, letters and special characters (16)
Enter access code	<u>&</u>
Navigation	
Description	For authorized service personnel only.
User entry	0 to 9999
Factory setting	0
Status password entry	
Navigation	
Description	Use this function to display the status of the password verification.

Description

User interface Wrong password ■ Password rule violated Password accepted Permission denied Confirm PW mismatch Reset password accepted ■ Invalid user role Wrong sequence of entry **Factory setting** _____ Define password Navigation System → User manag. → Define password New password **Navigation** System \rightarrow User manag. \rightarrow Define password \rightarrow New password Description Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" Any valid password consists of 4 to 16 characters and can contain letters and numbers. **User entry** Character string comprising numbers, letters and special characters (16) Confirm new password **Navigation** System \rightarrow User manag. \rightarrow Define password \rightarrow Confirm password Description Enter the new password again to confirm. User entry Character string comprising numbers, letters and special characters (16) Status password entry Navigation System \rightarrow User manag. \rightarrow Define password \rightarrow Status pw entry

Endress+Hauser

Use this function to display the status of the password verification.

User interface ------

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- \blacksquare Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting

Confirm new password

Change password

Navigation \square System \rightarrow User manag. \rightarrow Change password

Old password		
Navigation	System → User manag. → Change password → Old password	
Description	Enter the current password, to subsequently change the existing password.	
User entry	Character string comprising numbers, letters and special characters (16)	
New password		
Navigation		
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers	
User entry	Character string comprising numbers, letters and special characters (16)	

Status password entry **Navigation** System \rightarrow User manag. \rightarrow Change password \rightarrow Status pw entry Description Use this function to display the status of the password verification. User interface Wrong password ■ Password rule violated Password accepted Permission denied Confirm PW mismatch Reset password accepted ■ Invalid user role Wrong sequence of entry **Factory setting** Recover password Navigation System \rightarrow User manag. \rightarrow Recover password Reset password Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Reset password Description Enter a code to reset the current "Maintenance" password. The code is delivered by your local support. **User entry** Character string comprising numbers, letters and special characters (16) Status password entry Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Status pw entry Description Use this function to display the status of the password verification. User interface Wrong password ■ Password rule violated Password accepted Permission denied Confirm PW mismatch

Reset password accepted

Wrong sequence of entry

■ Invalid user role

Factory setting

3.4.3 Bluetooth configuration

Navigation $\blacksquare \square$ System \rightarrow Bluetooth conf.

Bluetooth activation

Navigation System \rightarrow Bluetooth conf. \rightarrow Bluetooth active

Description If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool.

Reactivating via the SmartBlue app is not possible.

Selection • Disable

■ Enable

Factory setting Depends on the order option

3.4.4 Display

Language

Navigation System \rightarrow Display \rightarrow Language

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection • English

- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)

- 한국어 (Korean) ■ Bahasa Indonesia ■ tiếng Việt (Vietnamese)
- tieng việt (vietna)čeština (Czech)

Factory setting

English (alternatively, the ordered language is preset in the device)

Format display

Navigation \square System \rightarrow Display \rightarrow Format display

Description Select how measured values are shown on the display

Selection • 1 value, max. size

2 values

Factory setting 1 value, max. size

Value 1 display

Navigation \square System \rightarrow Display \rightarrow Value 1 display

Description Select the measured value that is shown on the local display

Selection • Pressure

Scaled variableSensor temperatureAnalog output 1

Factory setting Pressure

Value 2 ... 4 display

Navigation System \rightarrow Display \rightarrow Value 2 ... 4 display

Description Select the measured value that is shown on the local display

Selection • None

■ Pressure

Scaled variable

Sensor temperature

■ Analog output 1

Factory setting

None

Contrast display

Navigation System \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)

User entry 20 to 80 %

Factory setting 30 %

3.4.5 Information

Navigation \square System \rightarrow Information

Device name

Navigation System \rightarrow Information \rightarrow Device name

Description Use this function to display the device name. It can also be found on the nameplate.

User interface Character string comprising numbers, letters and special characters

Factory setting Deltabar

Manufacturer

Navigation System \rightarrow Information \rightarrow Manufacturer

Description Displays the manufacturer.

User interface Character string comprising numbers, letters and special characters

Factory setting Endress+Hauser

Serial number		
Navigation	System → Information → Serial number	
Description	The serial number is a unique alphanumerical code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.	
User interface	Character string comprising numbers, letters and special characters	
Order code		
Navigation		
Description	Shows the device order code.	
User interface	Character string comprising numbers, letters and special characters	
Factory setting	- none -	
Additional information	Access: ■ Read access: Operator ■ Write access: Expert	
Firmware version		
Navigation		
Description	Displays the device firmware version installed.	
User interface	Character string comprising numbers, letters and special characters	
Hardware version		
Navigation		
User interface	Character string comprising numbers, letters and special characters	

Extended order code 1 ... 3

Navigation System \rightarrow Information \rightarrow Ext. order cd. 1

Description The extended order code is an alphanumeric code containing all information to identify

the device and its options.

User interface Character string comprising numbers, letters and special characters

Read access: OperatorWrite access: Expert

XML build number

Navigation System \rightarrow Information \rightarrow XML build no.

User interface Positive integer

Additional information Access:

Read access: ExpertWrite access: -

Checksum

Navigation \square System \rightarrow Information \rightarrow Checksum

Description Checksum for Firmware version.

User interface Positive integer

3.4.6 Additional information

Navigation \blacksquare System \rightarrow Additional info

Sensor

Navigation $\blacksquare \square$ System \rightarrow Additional info \rightarrow Sensor

Serial number

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Additional information Access:

Read access: ExpertWrite access: -

Hardware version

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Additional information Access:

Read access: ExpertWrite access: -

Checksum

Navigation \square System \rightarrow Additional info \rightarrow Sensor \rightarrow Checksum

Description Checksum for Firmware version.

User interface Positive integer

Factory setting 0

Read access: ExpertWrite access: -

Electronics

Navigation System \rightarrow Additional info \rightarrow Electronics

Serial number

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Read access: ExpertWrite access: -

Build no. software **Navigation** System \rightarrow Additional info \rightarrow Electronics \rightarrow Build no. softw. Description Shows the build number of the module firmware User interface 0 to 65 535 Additional information Access: ■ Read access: Expert ■ Write access: -Hardware version **Navigation** System \rightarrow Additional info \rightarrow Electronics \rightarrow Hardware version Description Displays the hardware version of the module. User interface Character string comprising numbers, letters and special characters Additional information Access: ■ Read access: Expert ■ Write access: -Display/Bluetooth **Navigation** \square System \rightarrow Additional info \rightarrow Displ./Bluetooth Serial number **Navigation** System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Serial number Description Shows the serial number of the module User interface Character string comprising numbers, letters and special characters

70

Additional information

Access:

Read access: ExpertWrite access: -

Firmware version

Navigation \square System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Read access: ExpertWrite access: -

Build no. software

Navigation \square System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Build no. softw.

Description Shows the build number of the module firmware

User interface 0 to 65 535

Read access: ExpertWrite access: -

Hardware version

Navigation \square System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

User interface

3.4.7 Software configuration

Navigation \blacksquare System \rightarrow Softw. config.

CRC device configuration	
Navigation	
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535
Activate SW option	
Navigation	
Description	Enter the application package code or code of another re-ordered functionality to enable it
User entry	Positive integer
Software option overview	
Navigation	
Description	Shows all enabled software options

■ Heartbeat Verification

■ Heartbeat Monitoring



www.addresses.endress.com