
01.00.zz (Device firmware)

Products Solutions Services

Description of Device Parameters **Liquiphant FTL63**

Vibronic PROFINET over Ethernet-APL







1 About this document

1.1 **Document function**

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 **Document structure**

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.

The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating** tool.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** $(\rightarrow \triangleq 50)$ they are logged in with. This document lists the submenus and their parameters that are available to the User role Maintenance.


The operating menu is dynamic and adapts the choice of parameters to the selected options.




For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:

Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols

▲ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of information


- 1 Indicates additional information
- Reference to documentation
- Operation via local display
- Operation via operating tool
- Write-protected parameter

1.6 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu



	Minimum electronics	temperature	→ 🖺 21
	Maximum electronics	temperature	→ 🖺 21
► Simulati	on		→ 🖺 21
	Simulation		→ 🖺 21
	Frequency simulation	value	→ 🖺 22
	Fork state simulation	value	→ 🖺 22
	Diagnostic event simu	lation	→ 🖺 22
► Heartbe	at Technology		→ 🖺 23
	► Heartbeat Verifica	tion	→ 🖺 23
		Date/time Heartbeat Verification	→ 🖺 23
	C	Operating time (Verification)	→ 🖺 23
	V	Verification result	→ 🖺 23
	S	itatus	→ 🖺 24
	► Frequency history		→ 🖺 24
	Σ	Date 1 16	→ 🖺 24
	S	ensor frequency 1 16	→ 🖺 24
	▶ Process window		→ 🖺 25
	F	requency of vibrating fork	→ 🖺 25
	9	001 Process alert frequency too high	→ 🖺 25
	F	ligh alert value	→ 🖺 25
	9	001 Alarm delay	→ 🖺 25
	9	000 Process alert frequency too low	→ 🖺 26

		Low alert value		→ 🖺 26
		900 Alarm delay		→ 🖺 26
► Diagnostic settir	ngs			→ 🖺 27
	► Properties			→ 🖺 27
		49 Corrosion warni	na	→ 🖺 27
		Upper warning free		→ 🖺 27
		825 Electronics ten	nperature	→ 🖺 28
		826 Temperature o	of sensor electronics	→ 🖺 28
	▶ Configuration			→ 🖺 28
		► Sensor		→ 🖺 28
			49 Diagnostic behavior	→ 🖺 28
			49 Event category	→ 🖺 29
		► Configuration		→ 🖺 29
			436 Diagnostic behavior	→ 🖺 29
			436 Event category	→ 🖺 30
		▶ Process		→ 🖺 30
		P 110Cess		/ 🔲 🕽 0
			825 Diagnostic behavior	→ 🖺 30
			825 Event category	→ 🖺 30
			826 Diagnostic behavior	→ 🖺 31
			826 Event category	→ 🗎 31
			900 Diagnostic behavior	→ 🖺 31
			900 Event category	→ 🖺 32
			901 Diagnostic behavior	→ 🗎 32
	1		901 Event category	→ 🖺 32
				→ 🖺 33

	► Measuring units		→ 🖺 33
	Temperature unit		→ 🖺 33
	► Measured values		→ 🖺 33
	Frequency of vibra	ting fork	→ 🖺 33
	State of vibrating for	ork	→ 🖺 33
	Temperature of ser	nsor electronics	→ 🖺 34
	Electronics temper	ature	→ 🖺 34
	► Sensor		→ 🖺 34
	▶ Basic settings		→ 🖺 34
		Density setting	→ 🖺 34
		Switching delay uncovered to covered	→ 🖺 35
		Customer delay to covered	→ 🖺 35
		Switching delay covered to uncovered	→ 🖺 35
		Customer delay to uncovered	→ 🖺 36
	► Sensor calibrati	ion	→ 🖺 36
		Lower switching point at density	→ 🖺 36
		Upper switching point at density	→ 🖺 36
		Frequency at delivery status	→ 🖺 37
		Upper warning frequency	→ 🖺 37
		Upper alarm frequency	→ 🖺 37
	► Stored frequence	cy	→ 🖺 38
l		State of vibrating fork	→ 🖺 38

		Stored uncovered fr	requency	→ 🖺 38
		Stored covered freq	uency	→ 🖺 38
► PROFINET				→ 🖺 39
> (Configuration			→ 🖺 39
		PROFINET device na	ame	→ 🖺 39
		Parameter change a	acknowledge mode	→ 🖺 39
		Acknowledge paran	neter change	→ 🖺 39
		Descriptor		→ 🖺 40
▶ 1	Discrete input]	→ 🖺 40
		► Discrete input		→ 🖺 40
			Process value	→ 🖺 40
> .	Analog input]	→ 🖺 41
		► Analog input 1 t	to 3	→ 🖺 41
			Process value	→ 🖺 41
			Assign process variable	→ 🖺 42
			Damping	→ 🖺 42
▶ 1	Binary input			→ 🖺 44
		▶ Binary input 1 to	o 2	→ 🖺 44
			Controller input value	→ 🖺 44
•	Binary output]	→ 🖺 45
		Set point value		→ 🖺 45
		BO block output val	lle	→ 🖺 45
		Failure behavior		→ \(\begin{align*}
			lov	
		Failure behavior de	ıay	→ 🖺 46
		Fixed value		→ 🖺 46

		► Information		→ 🖺 46
			Device ID	→ 🖺 46
			PA profile version	→ 🖺 47
		► Application rela		→ 🖺 47
		, FF		
			AR state	→ 🖺 47
			MAC address IO controller	→ 🖺 47
			MAC address backup IO controller	→ 🖺 47
			IP address IO controller	→ 🖺 48
			IP address backup IO controller	→ 🖺 48
System				→ 🖺 49
	► Device manage	ment		→ 🖺 49
		Device tag		→ 🖺 49
		Locking status		→ 🖺 49
		Configuration cour	nter	→ 🖺 49
		Reset device		→ 🖺 50
	▶ User managem	ent		→ 🖺 50
		▶ User managem	ent	→ 🖺 50
			User role	→ 🖺 50
			Delete password	→ 🖺 50
			Forgot password?	→ 🖺 51
		► Enter password	i	→ 🖺 51
			Password	→ 🖺 51
			Enter access code	→ 🖺 51
			Status password entry	→ 🖺 51
		► Define passwor	rd	→ 🖺 52

10

		New password		→ 🖺 52
		Confirm new passw	ord	→ 🖺 52
		Status password en	try	→ 🖺 52
	► Change passwor	rd		→ 🖺 53
		Old password		→ 🖺 53
		New password		→ 🖺 53
		Confirm new passw	ord	→ 🖺 53
		Status password en	try	→ 🖺 54
	► Recover passwo	rd		→ 🖺 54
		Reset password		→ 🖺 54
		Status password en	try	→ 🖺 54
► Connectivity				→ 🖺 55
	► Interfaces			→ 🖺 55
		Display operation		→ 🖺 55
		Web server function	nality	→ 🖺 55
		Bluetooth activation	n	→ 🖺 55
		Service (UART-CDI)		→ 🖺 56
	► Ethernet			→ 🖺 56
		► Properties		→ 🖺 56
			MAC address	→ 🖺 56
			IP address	→ 🖺 56
			Subnet mask	→ 🖺 56
			Default gateway	→ 🖺 57
			Service IP active	→ 🖺 57
				<u></u>

▶ Port information	→ 🖺 57
Interface connection status	→ 🖺 57
Interface speed	→ 🖺 58
Duplex status	→ 🖺 58
Auto negotiation status	→ 🖺 58
Number of received packets	→ 🖺 58
Number of sent packets	→ 🖺 59
Number of failed received packets	→ 🖺 59
Number of failed sent packets	→ 🖺 59
Reset Ethernet diagnostics	→ 🖺 59
► APL information	→ 🖺 60
Signal to noise ratio	→ 🖺 60
Number of failed received packets	→ 🖺 60
Reset Ethernet diagnostics	→ 🖺 60
► TCP information	→ 🖺 61
Active TCP connections	→ 🖺 61
Supported TCP connections	→ 🖺 61
TCP connection requests	→ 🖺 61
TCP connection timeouts	→ 🖺 61
Number of TCP connections closed	→ 🖺 62
Number of received TCP packets	→ 🖺 62
Number of sent TCP packets	→ 🖺 62
	Interface connection status Interface speed Duplex status Auto negotiation status Number of received packets Number of sent packets Number of failed received packets Number of failed sent packets Reset Ethernet diagnostics ▶ APL information Signal to noise ratio Number of failed received packets Reset Ethernet diagnostics ▶ TCP information Active TCP connections Supported TCP connections TCP connection requests TCP connection timeouts Number of TCP connections closed Number of received TCP packets

			Number of TCP failed received packets	→ 🖺 62
			Reset Ethernet diagnostics	→ 🖺 62
	ı	➤ UDP information	ı	→ 🖺 63
			Available UDP ports	→ 🖺 63
			Number of received UDP packets	→ 🖺 63
			Number of sent UDP packets	→ 🖺 63
			Number of UDP failed received packets	→ 🖺 63
			Reset Ethernet diagnostics	→ 🖺 64
▶ Display				→ 🖺 64
	Language			→ 🖺 64
	Format display			→ 🖺 64
	Value 1 display			→ 🖺 65
	Value 2 display			→ 🖺 65
	Value 3 display			→ 🖺 65
	Value 4 display			→ 🖺 66
	Decimal places 1 4			→ 🖺 66
	Contrast display			→ 🖺 66
▶ Date/time				→ 🖺 67
	Date/time			→ 🗎 67
	Time zone			→ 🖺 67
	Enable NTP			→ 🖺 68
	NTP server address			→ 🖺 69
	Clock synchronized			→ 🖺 69
▶ Geolocation			ı	→ 🖺 69
	Location description			→ 🖺 69
			<u> </u>	

	Longitude		→ 🖺 69
	Latitude		→ 🖺 70
	Altitude		→ 🖺 70
► Information			→ 🖺 70
	Device name		→ 🖺 70
	Manufacturer		→ 🖺 71
	Serial number		→ 🖺 71
	Order code		→ 🖺 71
	Firmware version		→ 🖺 71
	Hardware version		→ 🖺 72
	Extended order code 1 3		→ 🖺 72
	Checksum		→ 🖺 72
► Software config	uration		→ 🖺 77
	CRC device configuration		→ 🖺 77
	Activate SW option]	→ 🖺 77
]	→ 1 77
	Software option overview		7 目 / /

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. This menu primarily consists of guided wizards and special functions covering multiple areas.

Navigation 🗐 🗎 Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - Process window
- WHG mode
- Import / Export
- Compare

3.1.2 "Commissioning" wizard

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

A WARNING

If the wizard is aborted before all the necessary parameters have been configured, any settings already set are saved.

The device may be in an undefined state!

► Reset the device to factory settings.

Navigation \square Guidance \rightarrow Commissioning

Parameters for the "Commissioning" wizard

The following parameters are configured in this wizard:

- Device identification
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - Time zone
 - Date/time
 - PROFINET device name
 - IP address
 - Descriptor
 - MAC address
 - Device ID
 - Manufacturer ID

Measurement adjustments

- Temperature unit
- Density setting
- Switching delay covered to uncovered
- Customer delay to uncovered
- Switching delay uncovered to covered
- Customer delay to covered
- 49 Corrosion warning
- State of vibrating fork
- Frequency of vibrating fork
- Stored covered frequency
- Frequency at delivery status
- Stored uncovered frequency

Output settings

Assign process variable

3.1.3 Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application

Special Documentation on Heartbeat Technology is available via the Internet: www.endress.com → Download

Navigation \Box Guidance \rightarrow Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation \square Guidance \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

Process window

This wizard can be used to monitor the sensor frequency for frequencies that are too low or too high. This can be used for early detection of buildup or corrosion.

Navigation \Box Guidance \rightarrow Heartbeat Techn. \rightarrow Process window

3.1.4 WHG mode

For WHG applications, the device can be protected against manipulation using the WHG wizard. After using this confirmation, the device is marked as WHG locked to indicate the device mode.

To unlock the WHG locking the sequence needs to be restarted. After entering the safety unlocking code (= Safety locking code) the device is unlocked.

Navigation \square Guidance \rightarrow WHG mode

3.1.5 Import / Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create documentation

Device documentation can be saved in PDF format under Create documentation. This device documentation contains the following general device information:

- Information on device parameters
- Diagnostic list

Navigation \Box Guidance \rightarrow Import / Export

3.1.6 Compare

Compare datasets

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import / Export
- Datasets with the configuration currently in the device

Navigation \square Guidance \rightarrow Compare

3.2 Diagnostics

3.2.1 Active diagnostics

Navigation $\blacksquare \square$ Diagnostics \rightarrow Active diagnos.

Active diagnostics

Navigation \blacksquare Diagnostics \rightarrow Active diagnos. \rightarrow Active diagnos.

Description Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event

with the highest priority is displayed.

User interface • Operating time of the device until the event occurs

Symbol for diagnostic behavior

■ Code for diagnostic behavior

■ Event text

Corrective measure

Timestamp

Navigation $\blacksquare \square$ Diagnostics \rightarrow Active diagnos. \rightarrow Timestamp

Description Displays the timestamp for the currently active diagnostic message.

User interface Date, time

Previous diagnostics

Navigation \Box Diagnostics \rightarrow Active diagnos. \rightarrow Prev.diagnostics

Description Displays the diagnostic message for the last diagnostic event that has ended.

User interface ■ Operating time of the device until the event occurs

Symbol for diagnostic behavior

• Code for diagnostic behavior

■ Event text

Corrective measure

Timestamp

Navigation \blacksquare Diagnostics \rightarrow Active diagnos. \rightarrow Timestamp

Description Displays the timestamp of the diagnostic message generated for the last diagnostic event

that has ended.

User interface Date, time

Operating time from restart

Navigation \Box Diagnostics \rightarrow Active diagnos. \rightarrow Time fr. restart

Description Indicates how long the device has been in operation since the last time the device was

restarted.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time

Clear event list

Navigation

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Operating time

Description Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

3.2.2 Diagnostic list

3.2.3 Event logbook

Navigation $\blacksquare \square$ Diagnostics \rightarrow Event logbook

Description Delete all entries of the event list.

Endress+Hauser 19

 $Diagnostics \rightarrow Event logbook \rightarrow Clear event list$

Selection • Cancel

■ Clear data

Factory setting Cancel

Additional information Access:

Read access: ExpertWrite access: Expert

3.2.4 Minimum/maximum values

Navigation $\blacksquare \square$ Diagnostics \rightarrow Min/max val.

Minimum fork frequency

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Min. frequency

Description Minimum measured frequency of the vibrating fork.

User interface Signed floating-point number

Maximum fork frequency

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Max. frequency

Description Maximum measured frequency of the vibrating fork.

User interface Signed floating-point number

Minimum temp. of sensor electronics

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Min.TSensElectr.

Description Minimum measured temperature of the sensor electronics.

User interface Signed floating-point number

Maximum temp. of sensor electronics

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Max.TSensElectr.

Description Maximum measured temperature of the sensor electronics.

User interface Signed floating-point number

Minimum electronics temperature

Navigation \Box Diagnostics \rightarrow Min/max val. \rightarrow Min.electr.temp.

Description Minimum measured temperature of the main electronics.

User interface Signed floating-point number

Maximum electronics temperature

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Max.electr.temp.

Description Maximum measured temperature of the main electronics.

User interface Signed floating-point number

3.2.5 Simulation

Description Simulates one or more process variables and/or events.

Warning:

Output will reflect the simulated value or event.

Selection ■ Off

Simulation

Navigation

State of vibrating forkSensor frequency

■ Diagnostic event simulation

Factory setting

Off

Frequency simulation value

Navigation $\blacksquare \square$ Diagnostics \rightarrow Simulation \rightarrow Freq. simulation

Description Enter the frequency value to be simulated.

Note:

Prerequisite for the simulation to have an effect on the output:

Select "Sensor frequency" in the "Mode of operation" parameter in the Application > Sensor

> Basic settings menu.

The simulated frequency value has no affect on the displayed state of the vibrating fork

("Fork uncovered", "Fork covered").

User entry 0 to 10 000 Hz

Factory setting 0 Hz

Fork state simulation value

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Simulation \rightarrow Fork. simul.val.

Description Select the state of the vibrating fork to be simulated.

Note:

Prerequisite for the simulation to have an effect on the output:

Select "Level limit detection" in the "Mode of operation" parameter in the Application >

Sensor > Basic settings menu.

The simulated state of the vibrating fork has no affect on the displayed sensor frequency.

Selection • Fork covered

■ Fork uncovered

Factory setting Fork uncovered

Diagnostic event simulation

Navigation \blacksquare Diagnostics \rightarrow Simulation \rightarrow Diagnostic event

Description Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select "Off".

Selection ■ Off

■ Drop-down list of diagnostic events

Factory setting Off

3.2.6 Heartbeat Technology

Navigation \Box Diagnostics \rightarrow Heartbeat Techn.

Heartbeat Verification

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif.

Date/time Heartbeat Verification

Navigation □ □ Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat

Verification

Description Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display,

"----" is shown.

User interface Character string comprising numbers, letters and special characters

Factory setting 01.01.1970 00:00:00

Operating time (Verification)

Navigation Diagnostics \rightarrow Heartbeat Techn. \rightarrow Heartbeat Verif. \rightarrow Operating time

Description Value of the operating hours counter at the time of verification.

User interface Days (d), hours (h), minutes (m), seconds (s)

Verification result

Description Result of Heartbeat Verification.

User interface ■ Not done

PassedNot done

■ Failed

Factory setting Not done

Status

Navigation □□ Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status

Description Shows the actual status.

User interface ■ Done

BusyFailed

Not done

Factory setting Not done

Frequency history

List of the last 16 sensor frequencies saved in the previous Heartbeat Verification.

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow Freq. history

Date 1 ... 16

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Heartbeat Techn. \rightarrow Freq. history \rightarrow Date 1 ... 16

User interface Character string comprising numbers, letters and special characters

Factory setting 1970-01-01 00:00:00

Sensor frequency 1 ... 16

Navigation \blacksquare Diagnostics \rightarrow Heartbeat Techn. \rightarrow Freq. history \rightarrow Frequency 1 ... 16

User interface Floating-point number

Factory setting 0 Hz

Process window

Navigation \square Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window

Frequency of vibrating fork

Navigation \blacksquare Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow Fork frequency

Description Displays the actual frequency of the vibrating fork.

User interface 0 to 10 000 Hz

901 Process alert frequency too high

Navigation Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow 901Freq. high

Description Note:

If the device is used for minimum detection no event for "901 Process alert frequency too

high" is triggered if the fork is not covered.

Selection • Disable

■ Enable

Factory setting Disable

High alert value

Navigation \blacksquare Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow High alert value

Prerequisite Only visible if 901 Process alert frequency too high is enabled.

Description Enter the upper limit value.

If this limit value is exceeded, an event is generated. There is no hysteresis.

User entry 0 to 2 000 Hz

Factory setting 2 000 Hz

901 Alarm delay

Navigation □ Diagnostics → Heartbeat Techn. → Process window → 901Alarm delay

Prerequisite Only visible if 901 Process alert frequency too high is enabled.

Description Enter the duration (integer) that the triggering status must be active before the alarm is

generated.

A warning is generated.

User entry 0 to 300 s

Factory setting 60 s

$900\ Process$ alert frequency too low

Navigation Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow 900Freq. too low

Description Note:

If the device is used for maximum detection no event for "900 Process alert frequency too

low" is triggered if the fork is covered.

Selection • Disable

■ Enable

Factory setting Disable

Low alert value

Navigation \blacksquare Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow Low alert value

Prerequisite Only visible if 900 Process alert frequency too low is enabled.

Description Enter the lower limit value.

If this limit value is undercut, an event is generated. There is no hysteresis.

User entry 0 to 2 000 Hz

Factory setting 0 Hz

900 Alarm delay

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Heartbeat Techn. \rightarrow Process window \rightarrow 900Alarm delay

Prerequisite Only visible if 900 Process alert frequency too low is enabled.

Description Enter the duration (integer) that the triggering status must be active before the alarm is

generated.

A warning is generated.

User entry 0 to 300 s

Factory setting 60 s

3.2.7 Diagnostic settings

Navigation \square Diagnostics \rightarrow Diag. settings

Properties

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Properties

49 Corrosion warning

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 49Corr. warning

Description Enable or disable the corrosion warning.

The corrosion warning is set if the sensor frequency exceeds frequency at delivery status

by 5 %.

If turned on, the event category can be set in menu -> Diagnostics -> Diagnostic settings ->

Configuration

The diagnostic behaviour can be changed to "Logbook entry only" in the same menu.

Selection ■ Off

On

Factory setting On

Upper warning frequency

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow U. warning freq.

Description If the actual sensor frequency is higher than the upper warning frequency, then a warning

is generated.

The process value for the actual status of the vibrating fork remains unchanged.

--> Remove the sensor and check it for corrosion.

User interface 0 to 10 000 Hz

Factory setting 0 Hz

825 Electronics temperature

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 825Electr. temp

Description Activates the monitoring of the temperature of the main electronics.

The limit values are fixed.

Selection ■ Off

■ On

Factory setting On

826 Temperature of sensor electronics

Navigation Diagnostics \rightarrow Diag. settings \rightarrow Properties \rightarrow 826TSensElectr.

Description Activates the monitoring of the temperature of the sensor electronics.

The limit values are fixed.

Selection ■ Off

On

Factory setting On

Configuration

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Diag. settings \rightarrow Configuration

Sensor

Navigation $\blacksquare \square$ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Sensor

49 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Sensor \rightarrow 49Diag. behav.

Description Select diagnostic behavior.

Logbook entry only: Message not communicated via the fieldbus.

Warning: Warning message is output via the fieldbus (factory setting).

The warning is no longer available in the device once the permissible conditions are met

again.

Selection • Warning

Logbook entry only

Factory setting Warning

49 Event category

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Sensor \rightarrow 49Event categ.

User interface ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

■ Not categorized

Factory setting Maintenance required (M)

Configuration

Navigation \square Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Configuration

436 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Configuration \rightarrow 436Diag. behav.

Description Select diagnostic behavior.

Logbook entry only: Message not communicated via the fieldbus.

Warning: Warning message is output via the fieldbus (factory setting).

The warning is no longer available in the device once the permissible conditions are met

again.

Selection • Warning

Logbook entry only

Factory setting Warning

436 Event category						
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Configuration \rightarrow 436 Event categories.					
User interface	 Failure (F) Function check (C) Out of specification (S) Maintenance required (M) Not categorized 					
Factory setting	Maintenance required (M)					
	Process					
	Navigation $\blacksquare \Box$ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process					
825 Diagnostic behavior						
Navigation						
Description	Select diagnostic behavior.					
	Logbook entry only: Message not communicated via the fieldbus.					
	Warning: Warning message is output via the fieldbus (factory setting).					
	The warning is no longer available in the device once the permissible conditions are met again.					
Selection	WarningLogbook entry only					
Factory setting	Warning					
825 Event category						
Navigation	□ Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 825Event categ.					
User interface	 Failure (F) Function check (C) Out of specification (S) Maintenance required (M) Not categorized 					

Out of specification (S)

Factory setting

826 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 826Diag. behav.

Description Select diagnostic behavior.

Logbook entry only: Message not communicated via the fieldbus.

Warning: Warning message is output via the fieldbus (factory setting).

The warning is no longer available in the device once the permissible conditions are met

again.

Selection • Warning

Logbook entry only

Factory setting Warning

826 Event category

Navigation Diagnostics \rightarrow Diagnostics \rightarrow Configuration \rightarrow Process \rightarrow 826Event categ.

User interface ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

Not categorized

Factory setting Out of specification (S)

900 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 900Diag. behav.

Description Select diagnostic behavior.

Logbook entry only: Message not communicated via the fieldbus.

Warning: Warning message is output via the fieldbus (factory setting).

The warning is no longer available in the device once the permissible conditions are met

again.

Selection • Warning

Logbook entry only

Factory setting Warning

900 Event category

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 900Event categ.

User interface ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

Not categorized

Factory setting Out of specification (S)

901 Diagnostic behavior

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 901Diag. behav.

Description Select diagnostic behavior.

Logbook entry only: Message not communicated via the fieldbus.

Warning: Warning message is output via the fieldbus (factory setting).

The warning is no longer available in the device once the permissible conditions are met

again.

Selection • Warning

■ Logbook entry only

Factory setting Warning

901 Event category

Navigation \blacksquare Diagnostics \rightarrow Diag. settings \rightarrow Configuration \rightarrow Process \rightarrow 901Event categ.

User interface ■ Failure (F)

Function check (C)Out of specification (S)Maintenance required (M)

Not categorized

Factory setting Out of specification (S)

3.3 Application

3.3.1 Measuring units

Navigation $\blacksquare \square$ Application \rightarrow Measuring units

Temperature unit

Navigation \blacksquare Application \rightarrow Measuring units \rightarrow Temperature unit

Description Select the temperature unit.

■ K

Factory setting °C

3.3.2 Measured values

Navigation $\blacksquare \square$ Application \rightarrow Measured values

Frequency of vibrating fork

Navigation $\blacksquare \Box$ Application \rightarrow Measured values \rightarrow Fork frequency

Description Displays the actual frequency of the vibrating fork.

User interface 0 to 10 000 Hz

State of vibrating fork

Navigation Application \rightarrow Measured values \rightarrow Fork state

Description Displays the actual status of the vibrating fork.

User interface ■ Fork covered

■ Fork uncovered

Temperature of sensor electronics

Navigation $\blacksquare \Box$ Application \rightarrow Measured values \rightarrow T sens.electr.

Description Displays the actual temperature of the sensor electronics.

User interface Signed floating-point number

Factory setting 0 °C

Electronics temperature

Navigation \blacksquare Application \rightarrow Measured values \rightarrow Electronics temp

Description Displays the current temperature of the main electronics.

User interface Signed floating-point number

Factory setting 0 °C

3.3.3 Sensor

Basic settings

Navigation $\blacksquare \square$ Application \rightarrow Sensor \rightarrow Basic settings

Density setting

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Basic settings \rightarrow Density setting

Description Select the density of the medium.

Selection • $> 0.4 \text{ g/cm}^3 (> 25.0 \text{ lb/ft}^3)^*$

 $- > 0.4 \text{ g/cm}^3 (> 25.0 \text{ lb/ft}^3)^*$

 $- > 0.5 \text{ g/cm}^3 (> 31.2 \text{ lb/ft}^3)$

 $-> 0.7 \text{ g/cm}^3 (> 43.7 \text{ lb/ft}^3)$

Factory setting $> 0.7 \text{ g/cm}^3 (> 43.7 \text{ lb/ft}^3)$

^{*} Visibility depends on order options or device settings

Switching delay uncovered to covered

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Basic settings \rightarrow Delay to covered

Description Select the delay time for switching from "Fork uncovered" to "Fork covered".

The value determines the delay time until the switching output switches after a change of

state is detected.

Choose between predefined values or select "Customer specific" to enter an integer

between 1 s and 60 s.

Selection ■ 0.25 s

0.50 s1.00 s1.50 s5.00 s

Customer specific

Factory setting 0.50 s

Customer delay to covered

Navigation $\blacksquare \Box$ Application \rightarrow Sensor \rightarrow Basic settings \rightarrow Cust. delay cov.

Description Enter the delay time for switching from "Fork uncovered" to "Fork covered".

The value determines the delay time until the switching output switches after a change of

state is detected.

Enter an integer between 1 s and 60 s.

User entry 1 to 60 s

Factory setting 1 s

Switching delay covered to uncovered

Navigation Sensor \rightarrow Basic settings \rightarrow Delay to uncov.

Description Select the delay time for switching from "Fork covered" to "Fork uncovered".

The value determines the delay time until the switching output switches after a change of

state is detected.

Choose between predefined values or select "Customer specific" to enter an integer

between 1 s and 60 s.

Selection ■ 0.25 s

■ 0.50 s ■ 1.00 s

■ 1.50 s ■ 5.00 s

Customer specific

Endress+Hauser

35

Factory setting

1.00 s

Customer delay to uncovered

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Basic settings \rightarrow Cust. delay unc.

Description Enter the delay time for switching from "Fork covered" to "Fork uncovered".

The value determines the delay time until the switching output switches after a change of

state is detected.

Enter an integer between 1 s and 60 s.

User entry 1 to 60 s

Factory setting 1 s

Sensor calibration

Navigation $\blacksquare \square$ Application \rightarrow Sensor \rightarrow Sensor cal.

Lower switching point at density

Navigation \blacksquare Application \rightarrow Sensor cal. \rightarrow Lower sw. point

Description Displays the sensor frequency at which the status of the vibrating fork changes to "Fork

covered" (depending on the density selected).

User interface 0 to 2 000 Hz

Factory setting Depends on density setting

Upper switching point at density

Navigation \blacksquare Application \rightarrow Sensor cal. \rightarrow Upper sw. point

Description Displays the sensor frequency at which the status of the vibrating fork changes to "Fork

uncovered" (depending on the density selected).

User interface 0 to 2 000 Hz

Factory setting Depends on density setting

Frequency at delivery status

Navigation \blacksquare Application \rightarrow Sensor cal. \rightarrow Freq. delivery

Description Sensor frequency at delivery status. The individually determined oscillation frequency in

air is in the range of 900 to 1200 Hz.

User interface 0 to 10 000 Hz

Factory setting Device-specific

Upper warning frequency

Description If the actual sensor frequency is higher than the upper warning frequency, then a warning

is generated.

The process value for the actual status of the vibrating fork remains unchanged.

--> Remove the sensor and check it for corrosion.

User interface 0 to 10 000 Hz

Factory setting 0 Hz

Upper alarm frequency

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Sensor cal. \rightarrow Upper alarm f.

Description If the actual sensor frequency is higher than the upper alarm frequency, the process value

status switches to "bad".

The process value status displays "good" as long as the fork oscillates freely.

User interface 0 to 10 000 Hz

Factory setting Device-specific

Stored frequency

Navigation $\blacksquare \Box$ Application \rightarrow Sensor \rightarrow Stored frequency

State of vibrating fork

Description Displays the actual status of the vibrating fork.

User interface ■ Fork covered

■ Fork uncovered

Stored uncovered frequency

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Stored frequency \rightarrow Stored uncov. f.

Description The actual sensor frequency can be saved in this parameter.

This is only possible when the fork is uncovered.

The value is displayed in the Heartbeat Technology verification report.

Note:

Save the frequency in a reproducible state in order to use it as a reference for further/

future analyses.

User interface 0 to 10 000 Hz

Stored covered frequency

Navigation \blacksquare Application \rightarrow Sensor \rightarrow Stored frequency \rightarrow Stored cov. f.

Description The actual sensor frequency can be saved in this parameter.

This is only possible when the fork is covered.

The value is displayed in the Heartbeat Technology verification report.

Note:

Save the frequency in a reproducible state in order to use it as a reference for further/

future analyses.

User interface 0 to 10 000 Hz

3.3.4 PROFINET

Navigation $\blacksquare \blacksquare$ Application \rightarrow PROFINET

Configuration

Navigation \square Application \rightarrow PROFINET \rightarrow Configuration

PROFINET device name

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Configuration \rightarrow PROFINET DevName

Description Up to 240 characters are allowed.

The following syntax must be used:
- 1 or more identifiers, separated with [.]
- Identifier length is 1 to 63 characters

- Identifier consists of [a-z 0-9] only lowercase letters and numbers allowed.

Parameter change acknowledge mode

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Configuration \rightarrow ParaChngAcknMode

Description Select how to acknowledge the displayed flag when changing the device configuration:

- "Acknowledge automatically": the flag disappears automatically after 20 seconds.

- "Acknowledge manually": the flag must be acknowledged manually.

Selection • Acknowledge automatically

Acknowledge manually

Factory setting Acknowledge automatically

Acknowledge parameter change

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Configuration \rightarrow AcknParaChange

Description If the Option "Manual acknowledge" is selected as the acknowledgement type, then a

parameter change must be acknowledged with the "Reset update event flag" option.

Selection ■ No acknowledge

Reset update event flag

Factory setting No acknowledge

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Configuration \rightarrow Descriptor

Description Enter a description for the measuring point

User entry Character string comprising numbers, letters and special characters (54)

Discrete input

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Discrete inp. \rightarrow Discrete inp.

Process value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Discrete inp. \rightarrow Discrete inp. \rightarrow Process value

Description Shows the process value reported to the controller for further processing

User interface 0 to 255

Factory setting 0

Additional information Vibrating fork state:

0: Vibrating fork not covered1: Vibrating fork covered

Simulation value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Discrete inp. \rightarrow Simulation value

Description Use this function to enter a simulation value of the process variable.

User entry 0 to 255

Factory setting 0

■ Read access: Expert

■ Write access: Maintenance

Simulated status

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Discrete inp. \rightarrow Simulated status

Description Specify the status of the simulated process value (Hex)

User entry 0 to 255

Factory setting 60

■ Read access: Expert

• Write access: Maintenance

Simulation

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Discrete inp. \rightarrow Discrete inp. \rightarrow Simulation

Description Switch discrete input simulation on or off (Off = 0, On <> 0).

User entry 0 to 255

Factory setting 0

■ Read access: Expert

■ Write access: Maintenance

Analog input

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input

Analog input 1 to 3

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to 3

Process value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to 3 \rightarrow Process value

Description Shows the process value reported to the controller for further processing

User interface Signed floating-point number

Factory setting

0 Hertz

Assign process variable

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to $3 \rightarrow$ Assign variable

Description

User interface ■ Fork frequency

Sensor temperatureElectronics temperature

Factory setting Fork frequency

Damping

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to 3 \rightarrow Damping

Description Enter time constant for input damping (PT1 element). Damping reduces the effect of

fluctuations in the measured value on the output signal.

User entry 0 to 999 s

Factory setting 1.0 s

Simulation value

Navigation Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to 3 \rightarrow Simulation value

Description Enter the simulation value for the selected process variable. Processing of measured values

downstream as well as the signal ouput follow this value. In this way, it is possibe to verify

whether the measuring device has been configured correctly.

Additional information:

The applicable unit of measure is specified in the "System units" submenu.

User entry Signed floating-point number

Factory setting 0 Hertz

■ Read access: Expert

Write access: Maintenance

Simulated status

Navigation Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to \rightarrow Simulated status

Description To simulate a process status for this block. Possible input values can be taken from the PA

profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD" 0x24 (decimal 36) for status "BAD

User entry 0 to 255

Factory setting 60

■ Read access: Expert

■ Write access: Maintenance

Simulation

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to \rightarrow Simulation

Description Switch simulation of the analog input on or off (Off = 0, On <> 0)

User entry 0 to 255

Factory setting 0

■ Read access: Expert

■ Write access: Maintenance

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary input

Binary input 1 to 2

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary input \rightarrow Binary input 1 to 2

Controller input value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary input 1 to $2 \rightarrow$ ControllInputVal

Description Shows for each device function the state reported to the controller for further processing

User interface 0 to 255

Factory setting 0

Simulation value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary input 1 to $2 \rightarrow$ Simulation value

Description Enter the simulated state for each device function

User entry 0 to 255

Factory setting 0

Additional information Access:

■ Read access: Expert

• Write access: Maintenance

Simulated status

Description Specify the status of the simulated state for each device function (Hex)

User entry 0 to 255

Factory setting 60

■ Read access: Expert

■ Write access: Maintenance

Simulation

Navigation Application \rightarrow PROFINET \rightarrow Binary input \rightarrow Binary input 1 to 2 \rightarrow Simulation

Description Switch simulation of the binary input on or off (Off = 0; On <> 0)

User entry 0 to 255

Factory setting 0

Read access: Expert

• Write access: Maintenance

Binary output

Navigation $\blacksquare \Box$ Application \rightarrow PROFINET \rightarrow Binary output

User entry 0 to 255

Factory setting 0

BO block output value

Set point value

Navigation

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary output \rightarrow BOBlockOutValue

Description Shows for each device function the state reported to the measuring device for further

processing

User entry 0 to 255

Factory setting 0

Failure behavior

Navigation Application \rightarrow PROFINET \rightarrow Binary output \rightarrow Failure behavior

Description Select failure behavior in the event of a failure (value with status 'Bad')

Selection • Fixed value

Last valid valueActual value

Factory setting Fixed value

Failure behavior delay

Navigation $\blacksquare \Box$ Application \rightarrow PROFINET \rightarrow Binary output \rightarrow FailBehavDelay

Description Enter a delay until in the event of a failure (value with status 'Bad') the failure behavior

specified applies

User entry Positive floating-point number

Factory setting 0 s

Fixed value

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Binary output \rightarrow Fixed value

Description Enter value to report in the event of a failure (value with status 'Bad')

User entry 0 to 255

Factory setting 0

Information

Navigation $\blacksquare \Box$ Application \rightarrow PROFINET \rightarrow Information

Device ID

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Information \rightarrow Device ID

User interface 0 to 65 535

Factory setting 41412

PA profile version

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Information \rightarrow PA profile vers.

User interface 0 to 65 535

Factory setting 0x402

Application relation

Navigation $\blacksquare \blacksquare$ Application \rightarrow PROFINET \rightarrow Applicat. relat.

AR state

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Applicat. relat. \rightarrow AR state

Description Shows whether an AR connection and a system redundancy have been established

User interface ■ Active

Not active

Redundancy 1AR activeRedundancy 2AR active

Factory setting Not active

MAC address IO controller

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Applicat. relat. \rightarrow MAC IO contr.

Description Shows the MAC address of the only or of the primary IO controller

User interface Character string comprising numbers, letters and special characters

Factory setting 0x00

MAC address backup IO controller

Navigation Application \rightarrow PROFINET \rightarrow Applicat. relat. \rightarrow MAC backup IO c.

Description Shows the MAC adress of the backup IO controller

User interface Character string comprising numbers, letters and special characters

Factory setting

0x00

IP address IO controller

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Applicat. relat. \rightarrow IP IO controller

Description Shows the IP address of the only or of the primary IO controller

User interface Character string comprising numbers, letters and special characters

Factory setting 0x00

IP address backup IO controller

Navigation \blacksquare Application \rightarrow PROFINET \rightarrow Applicat. relat. \rightarrow IP backup IO c.

Description Shows the IP adress of the backup IO controller

User interface Character string comprising numbers, letters and special characters

Factory setting 0x00

3.4 System

Navigation 🗐 🗎 System

3.4.1 Device management

Navigation $\blacksquare \square$ System \rightarrow Device manag.

 Device tag

 Navigation
 System → Device manag. → Device tag

 Description
 Enter a name for the measuring point to identify the measuring device in the plant

 User entry
 Character string comprising numbers, letters and special characters (32)

 Locking status

 Navigation
 System → Device manag. → Locking status

Description Indicates the type of locking.

"Hardware locked" (HW)

The device is locked by the "WP" switch on the main electronics module. To unlock, set the switch into the OFF position.

"WHG locked" (SW)

Unlock the device by entering the appropriate access code in "Enter safety unlocking code".

"Temporarily locked" (SW)

The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.

User interface ■ Hardware locked

WHG locked

Temporarily locked

Configuration counter

Navigation System \rightarrow Device manag. \rightarrow Config. counter

Description Shows the number of changes made to static parameters (e.g. configuration parameters)

User interface 0 to 65 535

Factory setting 0

Reset device		
Navigation	System → Device manag. → Reset device	
Description	Reset the device configuration - either entirely or in part - to a defined state	
Selection	 Cancel To factory defaults * To delivery settings * Restart device 	
Factory setting	Cancel	
	2 / 2 Hear management	
	3.4.2 User management	
	Navigation $\ \ $	
	User management	
	Navigation \square System \rightarrow User manag. \rightarrow User manag.	
User role		
Navigation		
Description	Shows the access authorization to the parameters via the operating tool	
User interface	OperatorMaintenanceExpert	
Factory setting	Maintenance	
Delete password		î
Navigation		
Description	Deletes the 'Maintenance' password.	
	After deleting, the 'Operator' role will be no more available.	
	All users have read/write access rights.	

^{*} Visibility depends on order options or device settings

User entry

Character string comprising numbers, letters and special characters (1)

Forgot password?

Navigation System \rightarrow User manag. \rightarrow Forgot password?

User entry Character string comprising numbers, letters and special characters (1)

Enter password

Navigation \square System \rightarrow User manag. \rightarrow Enter password

Password

Navigation System \rightarrow User manag. \rightarrow Enter password \rightarrow Password

Description Enter the password for the "Maintenance" user role to get access to the functionality of this

role.

User entry Character string comprising numbers, letters and special characters (16)

Enter access code

Navigation

System \rightarrow User manag. \rightarrow Enter password \rightarrow Ent. access code

Description For authorized service personnel only.

User entry 0 to 9 999

Factory setting 0

Status password entry

Navigation \square System \rightarrow User manag. \rightarrow Enter password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface • ------

Wrong passwordPassword rule violated

- 1 abbword rule violates

- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Define password

Navigation \square System \rightarrow User manag. \rightarrow Define password

New password		
Navigation		
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new passwor parameter. Any valid password consists of 4 to 16 characters and can contain letters and number	
User entry	Character string comprising numbers, letters and special characters (16)	
Confirm new password		a
Navigation		
Description	Enter the new password again to confirm.	
User entry	Character string comprising numbers, letters and special characters (16)	
Status password entry		
Navigation		
Description	Use this function to display the status of the password verification.	
User interface	 Wrong password Password rule violated Password accepted Permission denied 	

- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting

Confirm new password

Change password

Navigation \square System \rightarrow User manag. \rightarrow Change password

Old password		
Navigation		
Description	Enter the current password, to subsequently change the existing password.	
User entry	Character string comprising numbers, letters and special characters (16)	
New password		
Navigation		
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password parameter. Any valid password consists of 4 to 16 characters and can contain letters and number	
User entry	Character string comprising numbers, letters and special characters (16)	

Status password entry **Navigation** System \rightarrow User manag. \rightarrow Change password \rightarrow Status pw entry Description Use this function to display the status of the password verification. User interface Wrong password Password rule violated Password accepted Permission denied Confirm PW mismatch Reset password accepted ■ Invalid user role Wrong sequence of entry **Factory setting** Recover password Navigation System \rightarrow User manag. \rightarrow Recover password Reset password Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Reset password Description Enter a code to reset the current "Maintenance" password. The code is delivered by your local support. **User entry** Character string comprising numbers, letters and special characters (16) Status password entry Navigation System \rightarrow User manag. \rightarrow Recover password \rightarrow Status pw entry Description Use this function to display the status of the password verification. User interface Wrong password ■ Password rule violated Password accepted ■ Permission denied Confirm PW mismatch Reset password accepted ■ Invalid user role

Wrong sequence of entry

Factory setting ------

3.4.3 Connectivity

Interfaces

Navigation System \rightarrow Connectivity \rightarrow Interfaces

Display operation

Navigation System \rightarrow Connectivity \rightarrow Interfaces \rightarrow DisplayOperation

Selection ■ Disable

■ Enable

Factory setting Enable

Web server functionality

Navigation \blacksquare System \rightarrow Connectivity \rightarrow Interfaces \rightarrow Webserver funct.

Description Switch the Web server on and off.

Selection • Disable

■ Enable

Factory setting Enable

Bluetooth activation

Navigation System \rightarrow Connectivity \rightarrow Interfaces \rightarrow Bluetooth active

Description If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool.

Reactivating via the SmartBlue app is not possible.

Selection • Disable

■ Enable

Factory setting Enable

Service (UART-CDI)		
Navigation		
Selection	DisableEnable	
Factory setting	Enable	
	Ethernet	
	Navigation System \rightarrow Connectivity \rightarrow Ethernet	
	Properties	
	Navigation \square System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Properties	
MAC address		
Navigation		
Description	Shows the MAC address of the measuring device	
User interface	Character string comprising numbers, letters and special characters	
IP address		
Navigation		
Description	Enter the IP address of the device. Then accept the change with "Apply ".	
User entry	Character string comprising numbers, letters and special characters (15)	
Factory setting	192.168.1.212	
Subnet mask		
Navigation		
Description	Enter subnet mask of the device. Then accept the change with "Apply ".	

User entry Character string comprising numbers, letters and special characters (15)

Factory setting 255.255.255.0

Default gateway

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Properties \rightarrow Default gateway

Description Enter IP address for the default gateway of the device.. Then accept the change with "Apply

".

User entry Character string comprising numbers, letters and special characters (15)

Factory setting 0.0.0.0

Service IP active

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Properties \rightarrow Service IP act.

User interface ■ No

■ Yes

Factory setting No

Port information

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info

Interface connection status

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow Interface status

User interface ■ Connected

■ Not connected

Factory setting Not connected

Interface speed

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow Interface speed

User interface Positive integer

Factory setting 0 MBit/s

Duplex status

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow Duplex status

User interface ■ Full duplex

Half duplexUnknown

Factory setting Unknown

Auto negotiation status

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow Auto negot.stat.

User interface ■ Idle

In progressCompletedFailed

Speed detection failed

Factory setting Idle

Number of received packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow RX packet no.

User interface Positive integer

Factory setting 0

Number of sent packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow TX packet number

User interface Positive integer

Factory setting 0

Number of failed received packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow FailRcvdPackets

User interface Positive integer

Factory setting 0

Number of failed sent packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow No.FailTXPackets

User interface Positive integer

Factory setting 0

Reset Ethernet diagnostics

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow Port info \rightarrow ResetEthernDiag.

Selection • Cancel

■ Reset

Factory setting Cancel

APL information

Navigation $\blacksquare \Box$ System \rightarrow Connectivity \rightarrow Ethernet \rightarrow APL information

Signal to noise ratio

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow APL information \rightarrow SNR

Description Shows the signal to noise ratio of the Ethernet-APL connection. A value >21dB is good

and >23dB is excellent.

User interface Signed floating-point number

Factory setting 0 dB

Number of failed received packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow APL information \rightarrow FailRXPacketsNo.

Description Shows the number of failed received packets (PHY).

User interface 0 to 65 535

Factory setting 0

Reset Ethernet diagnostics

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow APL information \rightarrow ResetEthernDiag.

Selection • Cancel

Reset

Factory setting Cancel

TCP information

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information

Active TCP connections

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow Act. TCP connec.

User interface 0 to 65 535

Factory setting 0

Supported TCP connections

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow Supported TCP

User interface 0 to 65 535

Factory setting 0

TCP connection requests

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow TCPConnecRequest

User interface 0 to 65 535

Factory setting 0

TCP connection timeouts

Navigation \blacksquare System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow TCPConnecTimeout

User interface 0 to 255

Factory setting 0

Number of TCP connections closed

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow TCPConnect.close

User interface 0 to 255

Factory setting 0

Number of received TCP packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow No.RX TCP Packet

User interface Positive integer

Factory setting 0

Number of sent TCP packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow No.TX TCP packet

User interface Positive integer

Factory setting 0

Number of TCP failed received packets

User interface Positive integer

Factory setting 0

Reset Ethernet diagnostics

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow TCP information \rightarrow ResetEthernDiag.

Selection • Cancel

Reset

Factory setting Cancel

UDP information

Navigation $\blacksquare \Box$ System \rightarrow Connectivity \rightarrow Ethernet \rightarrow UDP information

Available UDP ports

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow UDP information \rightarrow Avail. UDP ports

User interface Positive integer

Factory setting 0

Number of received UDP packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow UDP information \rightarrow No.RX UDP Packet

User interface Positive integer

Factory setting 0

Number of sent UDP packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow UDP information \rightarrow No.TX UDP packet

User interface Positive integer

Factory setting 0

Number of UDP failed received packets

Navigation System \rightarrow Connectivity \rightarrow Ethernet \rightarrow UDP information \rightarrow UDPFailRXPackets

User interface Positive integer

Factory setting 0

Reset Ethernet diagnostics Navigation Selection Cancel Reset **Factory setting** Cancel 3.4.4 **Display** Navigation Language Navigation Description Set display language

Selection	English
	Deutsch

- Français *
- Español *Italiano *
- Nederlands *
- Portuguesa *Polski *
- FUISKI
- русский язык (Russian) *
- Svenska ⁷
- Türkçe
- ■中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean)
- čeština (Czech)

Factory setting English

Format display

Description Select how measured values are shown on the display

^{*} Visibility depends on order options or device settings

Selection ■ 1 value, max. size

■ 2 values

Factory setting 1 value, max. size

Value 1 display

Description Select the measured value that is shown on the local display

Selection • Sensor frequency

State of vibrating forkSensor temperature

Factory setting State of vibrating fork

Value 2 display

Navigation System \rightarrow Display \rightarrow Value 2 display

Description Select the measured value that is shown on the local display

Selection • None

Sensor frequencyState of vibrating forkSensor temperature

Factory setting None

Value 3 display

Navigation System \rightarrow Display \rightarrow Value 3 display

Description Select the measured value that is shown on the local display

Selection • None

Sensor frequencyState of vibrating forkSensor temperature

Factory setting None

Value 4 display

Description Select the measured value that is shown on the local display

Selection • None

Sensor frequencyState of vibrating forkSensor temperature

Factory setting None

Decimal places 1 ... 4

Description This selection does not affect the measurement and calculation accuracy of the device.

X.XX.XXX.XXX

X.XXXX

Factory setting x.x

Contrast display

Navigation System \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)

User entry 20 to 80 %

Factory setting 30 %

3.4.5 Date/time

Navigation \Box System \rightarrow Date/time

Date/time

Description Displays the date and time entered.

User interface Character string comprising numbers, letters and special characters

Factory setting 2025-01-01 00:00:00

Time zone

Description Select the time zone. Every time the time zone is changed, a logbook entry is created.

Selection

Other units

- UTC-12:00
- UTC-11:00
- UTC-10:00
- UTC-09:30
- UTC-09:00
- UTC-08:00
- UTC-07:00
- UTC-06:00
- UTC-05:00
- UTC-04:00
- UTC-03:30
- UTC-03:00
- UTC-02:30
- UTC-02:00
- UTC-01:00
- UTC 00:00
- UTC+01:00
- UTC+02:00
- UTC+03:00
- UTC+03:30
- UTC+04:00
- UTC+04:30
- UTC+05:00
- UTC+05:30
- UTC+05:45
- U1C UJ.4J
- UTC+06:00
- UTC+06:30
- UTC+07:00
- UTC+08:00UTC+08:45
- UTC+09:00
- UTC+09:30
- UTC+10:00
- UTC+10:30
- UTC+11:00
- UTC+12:00
- UTC+12:45
- UTC+13:00UTC+13:45
- UTC+14:00

System \rightarrow Date/time \rightarrow Enable NTP

Factory setting

UTC 00:00

Enable NTP

Navigation

Selection

■ No ■ Yes

Factory setting

No

NTP server address

Navigation System \rightarrow Date/time \rightarrow NTP server add.

Description IP address of the NTP server.

User entry Character string comprising numbers, letters and special characters (64)

Factory setting 192.168.1.1

Clock synchronized

Navigation System \rightarrow Date/time \rightarrow Clock synch.

Description Timestamp of last synchronization with an NTP server.

User interface Character string comprising numbers, letters and special characters

Factory setting ------

3.4.6 Geolocation

Navigation \square System \rightarrow Geolocation

Location description

Navigation System \rightarrow Geolocation \rightarrow Location descr.

Description Enter a description for the location

User entry Character string comprising numbers, letters and special characters (32)

Factory setting somewhere

Longitude

Description Enter the longitude.

User entry −180 to 180 °

Factory setting

0°

Latitude

Description Enter latitude

User entry −90 to 90 °

Factory setting 0°

Altitude

Navigation System \rightarrow Geolocation \rightarrow Altitude

Description Enter altitude

User entry Signed floating-point number

Factory setting 0 m

3.4.7 Information

Navigation $\blacksquare \square$ System \rightarrow Information

Device name

Navigation System \rightarrow Information \rightarrow Device name

Description Use this function to display the device name. It can also be found on the nameplate.

User interface Character string comprising numbers, letters and special characters

Factory setting Liquiphant

Manufacturer

Navigation $\blacksquare \square$ System \rightarrow Information \rightarrow Manufacturer

Description Displays the manufacturer.

User interface Character string comprising numbers, letters and special characters

Factory setting Endress+Hauser

Serial number

Order code

Navigation System \rightarrow Information \rightarrow Serial number

Description The serial number is a unique alphanumerical code identifying the device.

It is printed on the nameplate.

In combination with the Operations app it allows to access all device related

documentation.

User interface Character string comprising numbers, letters and special characters

Description Shows the device order code.

User interface Character string comprising numbers, letters and special characters

Factory setting - none -

Additional information Access:

■ Read access: Operator

■ Write access: Expert

Firmware version

Navigation System \rightarrow Information \rightarrow Firmware version

Description Displays the device firmware version installed.

User interface Character string comprising numbers, letters and special characters

Hardware version		
Navigation		
User interface	Character string comprising numbers, letters and special characters	
Extended order code 1 3		
Navigation	System \rightarrow Information \rightarrow Ext. order cd. 1	
Description	The extended order code is an alphanumeric code containing all information to identifulth the device and its options.	fy
User interface	Character string comprising numbers, letters and special characters	
Additional information	Access: ■ Read access: Operator ■ Write access: Expert	
XML build number		
Navigation		
User interface	Positive integer	
Additional information	Access: Read access: Expert Write access: -	
Checksum		
Navigation	System → Information → Checksum	

Checksum for Firmware version.

Positive integer

Description

User interface

3.4.8 Additional information

Navigation \square System \rightarrow Additional info

Sensor

Navigation \square System \rightarrow Additional info \rightarrow Sensor

Serial number

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

Firmware version

Navigation \blacksquare System \rightarrow Additional info \rightarrow Sensor \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Additional information Access:

Read access: ExpertWrite access: -

Build no. software

Endress+Hauser

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Build no. softw.

Description Shows the build number of the module firmware

User interface 0 to 65 535

Read access: ExpertWrite access: -

	•			
Ha	rdv	zare	version	

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

Checksum

Navigation System \rightarrow Additional info \rightarrow Sensor \rightarrow Checksum

Description Checksum for Firmware version.

User interface Positive integer

Factory setting 0

Additional information Access:

Read access: ExpertWrite access: -

Electronics

Navigation \square System \rightarrow Additional info \rightarrow Electronics

Serial number

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Additional information Access:

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Read access: ExpertWrite access: -

Build no. software

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Build no. softw.

Description Shows the build number of the module firmware

User interface 0 to 65 535

Read access: ExpertWrite access: -

Hardware version

Navigation System \rightarrow Additional info \rightarrow Electronics \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Additional information Access:

Read access: ExpertWrite access: -

Display/Bluetooth

Navigation \square System \rightarrow Additional info \rightarrow Displ./Bluetooth

Serial number

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

Firmware version

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Read access: ExpertWrite access: -

Build no. software

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Build no. softw.

Description Shows the build number of the module firmware

User interface 0 to 65 535

Read access: ExpertWrite access: -

Hardware version

Navigation System \rightarrow Additional info \rightarrow Displ./Bluetooth \rightarrow Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Read access: ExpertWrite access: -

3.4.9 Software configuration

Navigation $\blacksquare \blacksquare$ System \rightarrow Softw. config.

CRC device configuration

Navigation System \rightarrow Softw. config. \rightarrow CRC device conf.

Description CRC device configuration based on current settings of safety relevant parameters.

The CRC device configuration is unique and can be used to detect changes in safety

relevant parameter settings.

User interface 0 to 65 535

Factory setting 65 535

Activate SW option

Navigation System \rightarrow Softw. config. \rightarrow Activate SW opt.

Description Enter the application package code or code of another re-ordered functionality to enable it

User entry Positive integer

Software option overview

Navigation System \rightarrow Softw. config. \rightarrow SW option overv.

Description Shows all enabled software options

User interface

- WHG
- Heartbeat Verification
- Heartbeat Monitoring



www.addresses.endress.com