

Operating Instructions

iTEMP TMT31

Temperature transmitter



Table of contents

1	About this document	4	9	Diagnostics and troubleshooting	29
1.1	Document function	4	9.1	General troubleshooting	29
1.2	Safety instructions (XA)	4	9.2	Diagnostic information via communication interface	30
1.3	Symbols	4	9.3	Overview of diagnostic events	31
1.4	Tool symbols	5			
1.5	Documentation	6	10	Maintenance and cleaning	32
1.6	Change history	6	10.1	Maintenance work	32
2	Basic safety instructions	8	10.2	Cleaning of surfaces not in contact with the medium	32
2.1	Requirements for the personnel	8	11	Repair	32
2.2	Intended use	8	11.1	General notes	32
2.3	Workplace safety	8	11.2	Spare parts	32
2.4	Operational safety	8	11.3	Return	32
2.5	Product safety	9	11.4	Disposal	33
2.6	IT security	9	12	Accessories	33
3	Incoming acceptance and product identification	10	12.1	Device-specific accessories	33
3.1	Incoming acceptance	10	12.2	Communication-specific accessories	33
3.2	Product identification	10	12.3	Service-specific accessories	33
3.3	Storage and transport	11	12.4	Online tools	33
4	Installation	12	12.5	System components	34
4.1	Installation requirements	12	13	Technical data	35
4.2	Installing the measuring instrument	12	13.1	Input	35
4.3	Post-installation check	16	13.2	Output	35
5	Electrical connection	17	13.3	Electrical connection	36
5.1	Connecting requirements	17	13.4	Performance characteristics	36
5.2	Quick wiring guide	17	13.5	Environment	40
5.3	Connecting the sensor input	19	13.6	Mechanical construction	41
5.4	Connecting the transmitter	20	13.7	Certificates and approvals	42
5.5	Post-connection check	21	13.8	Documentation	42
6	Operation options	22			
6.1	Overview of operation options	22			
6.2	Structure and function of the operating menu	22			
6.3	Access to the operating menu via the operating tool	23			
7	System integration	26			
7.1	Overview of device description files	26			
8	Commissioning	27			
8.1	Post-installation check	27			
8.2	Switching on the device	27			
8.3	Configuring the device	27			
8.4	Protecting settings from unauthorized access	28			

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Safety instructions (XA)

When used in hazardous areas, compliance with national regulations is mandatory. Separate Ex-specific documentation is provided for measuring systems that are used in hazardous areas. This documentation is an integral part of these Operating Instructions. The installation specifications, connection data and safety instructions contained therein must be strictly observed. Make sure that you use the right Ex-specific documentation for the right device with approval for use in hazardous areas! The number of the specific Ex documentation (XA...) is provided on the nameplate. If the two numbers (on the Ex documentation and the nameplate) are identical, then you may use this Ex-specific documentation.

1.3 Symbols

1.3.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.3.2 Symbols for certain types of information


Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation

Symbol	Meaning
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
	Series of steps
	Result of a step
	Help in the event of a problem
	Visual inspection

1.3.3 Electrical symbols

Symbol	Meaning
	Direct current
	Alternating current
	Direct current and alternating current
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Potential equalization connection (PE: Protective earth) Ground terminals that must be connected to ground prior to establishing any other connections. The ground terminals are located on the interior and exterior of the device: - Interior ground terminal: potential equalization connection is connected to the supply network. - Exterior ground terminal: device is connected to the plant grounding system.

1.3.4 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
	Item numbers		Series of steps
	Views		Sections
	Hazardous area		Safe area (non-hazardous area)

1.4 Tool symbols

Symbol	Meaning
 A0011220	Flat-blade screwdriver
 A0011219	Phillips screwdriver
 A0011221	Allen key

Symbol	Meaning
 A0011222	Open-end wrench
 A0013442	Torx screwdriver

1.5 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the product configuration:

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid This document contains all the technical data on the product and provides an overview of everything that can be ordered with the product.
Brief Operating Instructions (KA)	Quick guide to obtaining the first measured value The Operating Instructions contain all the essential information about the product from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Reference The Operating Instructions contain the information that is required in the various phases of the life cycle of the product: From product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	Reference for parameters The document contains detailed explanations of readable or configurable parameters in the product. The description is aimed at those who work with the product over its entire life cycle and perform specific configurations.
Safety Instructions (XA)	Safety Instructions for electrical equipment in hazardous areas are supplied with the product depending on the approval. These are an integral part of the Operating Instructions.  The nameplate indicates the Safety Instructions (XA) that are relevant to the product.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the product documentation.

1.6 Change history

Revision history

The firmware version (FW) on the nameplate and in the Operating Instructions indicates the device release: XX.YY.ZZ (example 01.02.01).

XX Change to main version. No longer compatible. The device and Operating Instructions change.

Revision history

- YY Change to functions and operation. Compatible. The Operating Instructions change.
- ZZ Bug fixes and internal changes. No changes to the Operating Instructions.

Date	Version	Firmware version	Changes	Documentation
12/2021	RTD	01.01.zz	Original firmware	BA02157T/01.21
03/2025	RTD TC	01.01.zz	DIN rail transmitter functions added	BA02157T/02.24
06/2026	RTD TC	01.01.zz	Formal changes to the document	BA02157T/03.26

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

The device is a configurable temperature transmitter with a sensor input for resistance thermometers (RTD) or thermocouples (TC). The head transmitter version of the device is intended for mounting in a terminal head (flat face) as per DIN EN 50446. It is also possible to mount the device on a DIN rail using the optional DIN rail clip. The device is also optionally available in a version suitable for DIN rail mounting as per IEC 60715 (TH35).

If the device is used in a manner not specified by the manufacturer, the protection provided by the device may be impaired.

The manufacturer is not liable for harm caused by improper or unintended use.



The head transmitter must not be operated as a DIN rail substitute in a cabinet by using the DIN rail clip with remote sensors.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Risk of injury!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ▶ The operator is responsible for interference-free operation of the device.

Hazardous area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection or safety instrumented system):

- ▶ Based on the technical data on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area. The nameplate can be found on the side of the transmitter housing.
- ▶ Comply with the instructions in the separate supplementary documentation, which is an integral part of this manual.

Electromagnetic compatibility

The measuring system complies with the general safety requirements as per EN 61010-1, the EMC requirements as per the IEC/EN 61326 series and the NAMUR recommendations NE 21.

NOTICE

- Only power the device using a power unit that operates using an energy-limited electric circuit according to UL/EN/IEC 61010-1, Section 9.4 and the requirements in Table 18.

2.5 Product safety

This state-of-the-art device is designed and tested in accordance with good engineering practice to meet operational safety standards. It left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU declaration of conformity. The manufacturer confirms this by affixing the CE mark.

2.6 IT security

The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

3 Incoming acceptance and product identification

3.1 Incoming acceptance

On receipt of the delivery:

1. Check the packaging for damage.
 - ↳ Report all damage immediately to the manufacturer.
Do not install damaged components.
2. Check the scope of delivery using the delivery note.
3. Compare the data on the nameplate with the order specifications on the delivery note.
4. Check the technical documentation and all other necessary documents, e.g. certificates, to ensure they are complete.

 If one of the conditions is not satisfied, contact the manufacturer.

3.2 Product identification

The following options are available for identification of the device:

- Nameplate specifications
- Enter the serial number from the nameplate into *Device Viewer* (www.endress.com/deviceviewer): all the information about the device and an overview of the technical documentation supplied with the device are displayed.
- Enter the serial number from the nameplate into the *Endress+Hauser Operations app* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations app*: all the information about the device and the technical documentation pertaining to the device is displayed.

3.2.1 Nameplate

Do you have the correct device?

The nameplate provides you with the following information on the device:

- Manufacturer identification, device designation
- Order code
- Extended order code
- Serial number
- Tag name (TAG) (optional)
- Technical values such as supply voltage, current consumption, ambient temperature, communication-specific data (optional)
- Degree of protection
- Approvals with symbols
- Reference to Safety Instructions (XA) (optional)

► Compare the information on the nameplate with the order.

3.2.2 Name and address of manufacturer

Name of manufacturer:	Endress+Hauser Wetzler GmbH + Co. KG
Address of manufacturer:	Obere Wank 1, D-87484 Nesselwang or www.endress.com

3.3 Storage and transport

Carefully remove each package and protection relative to the transportation packaging.



Pack the device for storage and transportation in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.

Avoid the following environmental influences during storage:

- Direct sunlight
- Proximity to hot objects
- Mechanical vibration
- Aggressive media

Storage temperature

- Head transmitter: -50 to 100 °C (-58 to 212 °F)
- DIN rail transmitter: -50 to 100 °C (-58 to 212 °F)

4 Installation

4.1 Installation requirements

4.1.1 Dimensions

The device dimensions can be found in the "Technical data" section of the Operating Instructions.

4.1.2 Installation location

- Head transmitter:
In terminal head form B in accordance with DIN EN 50446, direct installation onto insert with cable entry (middle hole 7 mm (0.28 in))
- DIN rail transmitter:
Designed for installation on DIN rail (TH35) in accordance with IEC 60715 TH35.

 Make sure there is enough space in the terminal head.

 It is also possible to mount the head transmitter on a DIN rail as per IEC 60715 using the DIN rail clip accessory.

Information about the conditions (such as the ambient temperature, degree of protection, climate class, etc.) that must be present at the installation location so that the device can be installed correctly is provided in the "Technical data" section.

For use in hazardous areas, the limit values specified on the certificates and approvals must be observed (see Ex Safety Instructions).

NOTICE

When a DIN rail-mounted transmitter using thermocouple measurement is installed, increased measurement errors or deviations may occur, depending on the installation conditions and ambient conditions.


- If the DIN rail transmitter is mounted on the DIN rail without any adjacent devices, this may result in deviations of up to ± 1.3 °C. Greater deviations may occur if the DIN rail-mounted device is mounted in series between other DIN rail-mounted devices.

4.2 Installing the measuring instrument

4.2.1 Installing the head transmitter

Required tools: Phillips screwdriver:

- Maximum torque for securing screws = 1 Nm ($\frac{3}{4}$ foot-pound), screwdriver: Pozidriv Z2
- Maximum torque for screw terminals = 0.35 Nm ($\frac{1}{4}$ foot-pound), screwdriver: Pozidriv Z1



1 Head transmitter mounting

A Terminal head, flat face, as per DIN EN 50446, direct installation on insert with cable entry (center hole 7 mm (0.28 in))

B With DIN rail clip on DIN rail as per IEC 60715 (TH35)

A	Installation in a terminal head (flat face as per DIN 43729)
1	Terminal head
2	Retaining rings
3	Insert
4	Connection wires
5	Head transmitter
6	Mounting springs
7	Mounting screws
8	Terminal head cover
9	Cable entry

Procedure for installation in a terminal head, pos. A:


1. Open the terminal head cover (8) on the terminal head.
2. Guide the connection wires (4) of the insert (3) through the center hole in the head transmitter (5).
3. Fit the mounting springs (6) on the mounting screws (7).
4. Guide the mounting screws (7) through the side boreholes of the head transmitter and the insert (3). Then fix both mounting screws with the snap rings (2).
5. Then tighten the head transmitter (5) along with the insert (3) in the terminal head.
6. After wiring, close the terminal head cover (8) tightly again.

B	Installation on DIN rail (as per IEC 60715)
1	Mounting screws
2	Head transmitter
3	Retaining rings
4	DIN rail clip
5	DIN rail

Procedure for installation on a DIN rail, position B:

1. Press the DIN rail clip (4) onto the DIN rail (5) until it engages with a click.
2. Guide the mounting screws (1) through the lateral bores in the head transmitter (2). Then fix both mounting screws with the snap rings (3).
3. Screw the head transmitter (2) onto the DIN rail clip (4).

Installation with central spring-loaded insert



A0008520

 2 Head transmitter mounting

- 1 Thermowell
- 2 Insert
- 3 Adapter, coupling
- 4 Terminal head
- 5 Head transmitter
- 6 Mounting screws

Thermometer design with thermocouples or RTD sensors and head transmitter:

1. Fit the thermowell (1) on the process pipe or the container wall. Secure the thermowell according to the instructions before the process pressure is applied.
2. Fit the necessary neck tube nipples and adapter (3) on the thermowell.
3. Make sure sealing rings are installed if such rings are needed for harsh environmental conditions or special regulations.
4. Guide the mounting screws (6) through the lateral bores of the head transmitter (5).
5. Position the head transmitter (5) in the terminal head (4) in such a way that the bus cable (terminals 1 and 2) point to the cable entry.
6. Using a screwdriver, screw down the head transmitter (5) in the terminal head (4).
7. Guide the connection wires of the insert (3) through the lower cable entry of the terminal head (4) and through the middle hole in the head transmitter (5). Wire the connection wires up to the transmitter.
8. Screw the terminal head (4), with the integrated and wired head transmitter, onto the ready-mounted nipple and adapter (3).

NOTICE

The terminal head cover must be secured properly to meet the requirements for explosion protection.

- After wiring, securely screw the terminal head cover back on.


4.2.2 Installing the DIN rail transmitter

NOTICE

Incorrect orientation

Measurement deviates from the maximum measurement accuracy when a thermocouple is connected and the internal cold junction is used.

- Mount the device vertically and ensure it is correctly oriented.




A0039678

3 Installing the DIN rail transmitter

1. Position the top DIN rail groove at the top end of the DIN rail.
2. Slide the bottom of the device over the bottom end of the DIN rail until you can hear the lower DIN rail clip click into place on the DIN rail.
3. Pull gently on the device to check if it is correctly mounted on the DIN rail.

If it doesn't move, the DIN rail transmitter is correctly mounted.



A0039696

4 Dismantling the DIN rail transmitter

Dismantling the DIN rail transmitter:

1. Insert a screwdriver into the tab of the DIN rail clip.
2. Use the screwdriver to pull down on the DIN rail clip as shown in the diagram.
3. Hold down the screwdriver to remove the device from the DIN rail.

4.3 Post-installation check

After installing the device, always perform the following checks:

Device condition and specifications	Notes
Are the device, the connections and connecting cables free of damage (visual inspection)?	-
Do the ambient conditions match the device specification (e.g. ambient temperature, measuring range, etc.)?	See the 'Technical data' section
Have connections been established correctly and with the specified torque?	-

5 Electrical connection

5.1 Connecting requirements

CAUTION

Destruction of parts of the electronics

- ▶ Do not install or wire the device when it is connected to the operating voltage.
- ▶ Do not occupy the CDI connection.

i For information on the connection data, see the "Technical data" section.


A Phillips head screwdriver is required to wire the head transmitter with screw terminals. Use a flat blade screwdriver for the DIN rail housing version with screw terminals. The version with push-in terminals can be wired without any tools.

Proceed as follows to wire a mounted head transmitter:

1. Open the cable gland and the housing cover on the terminal head or the field housing.
2. Feed the cables through the opening in the cable gland.
3. Connect the cables as shown in →  17. If the head transmitter is fitted with push-in terminals, pay particular attention to the information in the "Connecting to push-in terminals" section.
4. Tighten the cable gland again and close the housing cover.


In order to avoid connection errors, always follow the instructions in the post-connection check section before commissioning.

5.2 Quick wiring guide



5 Terminal assignment for head transmitter

- A TC sensor input, external cold junction (CJ) Pt1000
- B TC sensor input, internal cold junction (CJ)
- C RTD sensor input: 4-, 3- and 2-wire
- D CDI interface
- E Power supply



A0056110

6 Terminal assignment for DIN rail transmitter

- A TC sensor input, external cold junction (CJ) Pt1000
- B TC sensor input, internal cold junction (CJ)
- C RTD sensor input: 4-, 3- and 2-wire
- D CDI interface
- E Power supply

In the case of a thermocouple (TC) measurement, a 2-wire RTD can be connected to measure the cold junction temperature. This is connected to terminals 3 and 4.


NOTICE

- ▶  ESD – Electrostatic discharge. Protect the terminals from electrostatic discharge. Failure to observe this may result in the destruction or malfunction of parts of the electronics.

Maximum torque for screw terminals = 0.35 Nm ($\frac{1}{4}$ lbf ft), screwdriver: Pozidriv Z1

5.3 Connecting the sensor input

5.3.1 Connecting the sensor to push-in terminals



A0062163

 7 Push-in terminal connection, using the example of a head transmitter

Fig. A, solid wire, fine-strand wire with ferrule:

1. Strip wire end to length of at least 10 mm (0.39 in).
2. Insert the wire end into the terminal.
3. Pull the wire gently to ensure it is connected correctly. If the wire is not secure, repeat from step 1.

Fig. B, fine-strand wire without ferrule:

1. Strip wire end to length of at least 10 mm (0.39 in).
2. Press down on the lever opener.
3. Insert the wire end into the terminal.
4. Release lever opener.
5. Pull the wire gently to ensure it is connected correctly. If the wire is not secure, repeat from step 1.

Fig. C, releasing the connection:

1. Press down on the lever opener.
2. Remove the wire from the terminal.
3. Release lever opener.


5.4 Connecting the transmitter

Cable specifications

No special requirements, such as shielding, apply to the instrument cable. The exception is the DIN rail version with RTD input, for which shielded cables must be used.

Also follow the general procedure described in →  17.


-  The terminals for the power supply (1+ and 2-) are protected against reverse polarity.
- Cable cross-section; see the "Technical data", →  36



A0047087

-  8 Fitting the CDI connector of the configuration kit for configuration, visualization and maintenance of the head transmitter via PC and configuration software

- 1 Configuration kit with USB port
- 2 CDI connector
- 3 Installed head transmitter with CDI interface



A0057147

-  9 Connecting the CDI connector of the configuration kit for configuration, visualization and maintenance of the DIN rail transmitter via PC and configuration software
- 1 DIN rail transmitter
2 CDI connector
3 Configuration kit with USB port


 For parameter configuration, the power supplied via the communication kit (CDI) is sufficient. No additional power supply is required.

5.5 Post-connection check

Device condition and specifications	Notes
Are the device and cables free from damage (visual check)?	--
Do the ambient conditions match the device specification (e.g. ambient temperature, measuring range, etc.)?	See "Technical data".
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	U = e.g. 10 to 36 V _{DC}
Are the mounted cables strain-relieved?	--
Are the power supply and signal cables connected correctly?	→  17
Are all the screw terminals firmly tightened and have the push-in terminal connections been checked?	--
Are all the cable entries installed, tightened and leak-tight?	--

6 Operation options

6.1 Overview of operation options




10 Operation options for the transmitter via the CDI interface

CDI (Common Data Interface) is a service and communication interface. It enables parameter configuration, diagnostics and data transfer between the device and a configuration tool such as DeviceCare or FieldCare via a serial UART connection.

6.2 Structure and function of the operating menu

6.2.1 Structure of the operating menu



User roles

Navigation System → User management

The role-based access concept consists of two hierarchical levels for the user and presents the various user roles with defined read/write authorizations derived from the NAMUR shell model.

■ Operator

The plant operator can only change settings that do not affect the application - and particularly the measuring path - and simple, application-specific functions that are used during operation. The operator is able to read all the parameters, however.

■ Maintenance

The **Maintenance** user role refers to configuration situations: commissioning and process adaptations as well as troubleshooting. It allows the user to configure and modify all available parameters. In contrast to the **Operator** user role, in the **Maintenance** role the user has read and write access to all the parameters.

■ Changing the user role

A user role - and therefore existing read and write authorization - is changed by selecting the desired user role (already pre-selected depending on the operating tool) and entering the correct password when subsequently prompted. When a user logs out, system access always returns to the lowest level in the hierarchy. A user logs out by actively selecting the logout function when operating the device.

■ As-delivered state

The **Operator** user role is not enabled when the device is delivered from the factory, i.e. the **Maintenance** role is the lowest level in the hierarchy ex-works. This state makes it possible to commission the device and make other process adaptations without having to enter a password. Afterwards, a password can be assigned for the **Maintenance** user role to protect this configuration. If the option *Configuration locked when delivered* was selected during device configuration, the device is set to the **Operator** user role when delivered. It is therefore not possible to change the configuration. The delivery password stored can be reset and reassigned.

■ Password

The **Maintenance** user role can assign a password in order to restrict access to device functions. This activates the **Operator** user role, which is now the lowest hierarchy level where the user is not asked to enter a password. The password can only be changed or disabled in the **Maintenance** user role.

Submenus

Menu	Typical tasks	Content/meaning
"Diagnostics"	Troubleshooting: ■ Diagnosing and eliminating process errors. ■ Error diagnostics in difficult cases. ■ Interpretation of device error messages and correcting associated errors.	Contains all parameters for detecting and analyzing errors: ■ Active diagnostics Displays the error message that is currently active ■ "Current output simulation" submenu Used to simulate output values.
"Application"	Commissioning: ■ Configuration of the measurement. ■ Configuration of data processing (scaling, linearization, etc.). ■ Configuration of the analog measured value output. Tasks during operation: Reading measured values.	Contains all the parameters for commissioning: ■ "Measured values" submenu Contains all the current measured values ■ "Sensor" submenu Contains all the parameters for configuring the measurement ■ "Output" submenu Contains all the parameters for configuring the analog current output
"System"	Tasks that require detailed knowledge of the system administration of the device: ■ Optimum adaptation of the measurement for system integration. ■ User and access administration, password control ■ Information for device identification	Contains all higher-level device parameters that are assigned to system, device and user management. ■ "Device management" submenu Contains parameters for general device management ■ "User management" submenu Parameters for access authorization, password assignment, etc. ■ "Information" submenu Contains all the parameters for the unique identification of the device

6.3 Access to the operating menu via the operating tool

The Endress+Hauser FieldCare and DeviceCare operating tools are available to download (<https://www.software-products.endress.com>) or can be found on the data storage medium, which you can obtain from your local Endress+Hauser Sales Center.

6.3.1 DeviceCare

Scope of functions

DeviceCare is a free configuration tool for Endress+Hauser devices. It supports devices with the following protocols, provided a suitable device driver (DTM) is installed: HART, PROFIBUS, FOUNDATION Fieldbus, EtherNet/IP, Modbus, CDI, ISS, IPC and PCP. The target group comprises customers without a digital network in plants and workshops as well as Endress+Hauser service technicians. The devices can be connected directly via a modem (point-to-point) or a bus system. DeviceCare is fast, easy and intuitive to use. It can run on a PC, laptop or tablet with a Windows operating system.

Source for device description files

See information in the "System integration" section →  26

Establishing the connection

Example: CDI communication kit TXU10 and FXA291 (USB)

1. Make sure that the DTM library is updated for all the connected devices (e.g. FXA29x, TMTxy).
2. Start DeviceCare and connect the device via the **Automatic** button.
↳ The device is detected automatically.

 When transmitting the device parameters following offline parameter configuration, the password for **Maintenance** must first be entered in the **System -> User administration** menu, if specified.

6.3.2 FieldCare

Scope of functions

FDT/DTM-based plant asset management tool from Endress+Hauser. It can be used to configure all intelligent field units in a plant and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Access is via the HART® protocol, CDI (= Endress+Hauser Common Data Interface). It also supports devices with the following protocols, provided a suitable device driver (DTM) is installed: PROFIBUS, FOUNDATION Fieldbus.

Typical functions:

- Parameter configuration of transmitters
- Loading and saving of instrument data (upload/download)
- Documentation of the measuring point
- Visualizing the measured value memory and event logbook

 For details, see the relevant Operating Instructions.

Source for device description files

For details, see →  26

Establishing the connection

Example: CDI communication kit TXU10 or FXA291 (USB)

1. Make sure that the DTM library is updated for all the connected devices (e.g. FXA29x, TMTxy).
2. Start FieldCare and create a project.

3. Right-click **Host PC** Add device...
 - ↳ The **Add new device** window opens.
 4. Select the **CDI Communication FXA291** option from the list and press **OK** to confirm.
 5. Double-click **CDI Communication FXA291** DTM.
 - ↳ Check whether the correct modem is connected to the serial interface connection.
 6. Right-click **CDI Communication FXA291** and in the context menu select the **Create network** option.
 - ↳ The connection to the device is established.
-  When transmitting the device parameters following offline parameter configuration, the password for **Maintenance** must first be entered in the **System -> User administration** menu, if specified.

7 System integration

7.1 Overview of device description files

Version data for the device

Firmware version	01.01.zz	■ On the title page of the manual ■ On the nameplate ■ Firmware version parameter System → Information → Device
------------------	----------	--

The suitable device driver software (DD/DTM) for the individual operating tools can be obtained from different sources:

- www.endress.com → Downloads → Search field: Device driver and firmware → Select type and product root
- www.endress.com → Products: individual product page, e.g. TMTxy → Downloads → Device driver and firmware

The Endress+Hauser FieldCare and DeviceCare operating tools are available for download (<https://www.software-products.endress.com>).

8 Commissioning

8.1 Post-installation check

Before commissioning the measuring point, ensure that all final checks have been completed:

- "Post-installation check" checklist →  12
- "Post-connection check" checklist →  17

8.2 Switching on the device

Once you have completed the post-connection checks, switch on the supply voltage. The device performs a number of internal test functions after it is powered up.

The device works after approx. 5 seconds. Normal measuring mode commences as soon as the switch-on procedure is completed.

8.3 Configuring the device

 For offline configuration outside normal measuring operation, the power supplied by the communication kit (CDI) is sufficient. No additional power supply is required.

The starting point is in the **Guidance** menu. Parameter settings that require specific access permissions may be disabled (lock symbol). Commissioning is the first step required in order to use a device for a specific application.

Navigation  **Guidance → Commissioning**

The following parameters can be configured:

RTD version:

Unit
Sensor type
Connection type
2-wire compensation
Lower range value output
Upper range value output
Failure mode

TC version:

Unit
Sensor type
Cold junction
Lower range value output
Upper range value output
Failure mode

In the final section, a password can be defined for the "Maintenance" user role. This is strongly recommended to protect the device against unauthorized access. The following steps describe how to configure a password for the "Maintenance" role for the first time.

Navigation  **System → User management**

Access status
Logout
Delete password

1. In the "Access status" field, the **Maintenance** role appears with the two entry fields **Logout** and **Delete password**.
2. **Logout** function:
Enable the **Logout** entry field.
 - ↳ The **Operator** role appears in the "Access status" field. The **Enter access code** entry field is displayed.
3. To return to the **Maintenance** role, enter a four-digit access code, which you have already defined, in this entry field.
 - ↳ The **Maintenance** role appears in the "Access status" field.
4. **Delete password** function:
Enable the **Delete password** entry field.
5. In the **Define software write protection code** entry field, enter a user-defined password that meets the specifications in the online help.
 - ↳ The startup screen as described in Step 1 appears.

Once the password has been entered successfully, parameter changes, particularly those that are needed for commissioning, process adaptation/optimization and troubleshooting, can only be implemented in the **Maintenance** user role and if the password is entered successfully.

8.4 Protecting settings from unauthorized access

8.4.1 Software locking

By assigning a password for the **Maintenance** user role, it is possible to restrict access authorization and protect the device against unauthorized access.

The parameters are also protected against modification by logging out of the **Maintenance** user role and switching to the **Operator** role. A lock symbol appears.

To disable the write protection, the user must log on with the **Maintenance** user role via the relevant operating tool.



User role concept →  22

9 Diagnostics and troubleshooting

9.1 General troubleshooting

Always start troubleshooting with the checklists below if faults occur after startup or during operation. The checklists take you directly (via various queries) to the cause of the problem and the appropriate remedial actions.

 Due to its design, the device cannot be repaired. However, it can be returned for inspection. See the information in the "Return" section.

General faults

Fault	Possible cause	Remedial action
Device is not responding.	Supply voltage does not match the voltage specified on the nameplate.	Check the voltage at the transmitter directly using a voltmeter and correct.
	Connecting cables are not making contact with the terminals.	Check the electrical contact between the cable and terminals and correct if necessary.
	Electronics module is defective.	Replace the device.
Output current <3.6 mA	Signal cable is not wired correctly.	Check wiring.
	Electronics module is defective.	Replace the device.
	'Low Alarm' failure current is set	Set the failure current to 'High Alarm'.

Error messages in the configuration software

→  30

Application errors without diagnostic messages for RTD sensor connection

Fault	Possible cause	Remedial action
Measured value is incorrect/inaccurate	Incorrect sensor orientation.	Install the sensor correctly.
	Heat conducted by sensor.	Observe the installed length of the sensor.
	Device programming is incorrect (number of wires).	Change the Connection type device function.
	Device programming is incorrect (scaling).	Change scaling.
	Incorrect RTD configured.	Change the Sensor type device function.
	Sensor connection.	Check that the sensor is connected correctly.
	The cable resistance of the sensor (2-wire) was not compensated.	Compensate the cable resistance.
	Offset incorrectly set.	Check offset.
Failure current (≤ 3.6 mA or ≥ 21 mA)	Sensor defective.	Check the sensor.
	RTD connected incorrectly.	Install the connecting cables correctly (terminal diagram).
	Device programming is incorrect (e.g. number of wires).	Change the Connection type device function.
	Incorrect programming.	Incorrect sensor type set in the Sensor type device function. Set the correct sensor type.

Application errors without diagnostic messages for TC sensor connection

Fault	Possible cause	Remedial action
Measured value is incorrect/ inaccurate	Incorrect sensor orientation.	Install the sensor correctly.
	Heat conducted by sensor.	Observe the installed length of the sensor.
	Device programming is incorrect (scaling).	Change scaling.
	Incorrect thermocouple type (TC) configured.	Change the Sensor type device function.
	Incorrect cold junction set.	Set the correct cold junction .
	Interference via the thermocouple wire welded in the thermowell (interference voltage coupling).	Use a sensor where the thermocouple wire is not welded.
	Offset incorrectly set.	Check offset.
Failure current (≤ 3.6 mA or ≥ 21 mA)	Sensor defective.	Check the sensor.
	Sensor is connected incorrectly.	Install the connecting cables correctly (terminal diagram).
	Incorrect programming.	Incorrect sensor type set in the Sensor type device function. Set the correct sensor type.

9.2 Diagnostic information via communication interface

Status signals

Letter/ symbol ¹⁾	Event category	Meaning
F 	Operating error	An operating error has occurred.
C 	Service mode	The device is in the service mode (e.g., during a simulation).
S 	Out of specification	The device is being operated outside its technical specifications (e.g. during startup or cleaning processes).
M 	Maintenance required	Maintenance is required.
N -	No effect	

1) As per NAMUR NE 107

Diagnostic behavior

Alarm	Measurement is interrupted. The signal outputs adopt the defined alarm status. A diagnostic message is generated.
Warning	The device continues to measure. A diagnostic message is generated.
Disabled	The diagnostic behavior is completely disabled even if the device is not recording a measured value.

If several diagnostic events are pending at the same time, only the current diagnostic message is displayed. The status signal dictates the priority in which the diagnostic messages are displayed. The following order of priority applies: F, C, S, M.

9.3 Overview of diagnostic events

Each diagnostic event is assigned a specific diagnostic behavior ex works.

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of sensor				
041	Sensor breakage detected	1. Check electrical connection 2. Replace sensor 3. Check configuration of connection type	F	Alarm
043	Short circuit	1. Check electrical connection 2. Check sensor 3. Replace sensor or cable	F	Alarm
047	Sensor limit reached	1. Check sensor 2. Check process conditions	S	Warning
145	Compensation reference point	1. Check terminal temperature 2. Check external reference point	F	Alarm
Diagnostic of electronic				
201	Electronics faulty	1. Restart device 2. Replace electronics	F	Alarm
Diagnostic of configuration				
402	Initialization active	Initialization in progress, please wait	C	Warning
410	Data transfer failed	1. Check connection 2. Repeat data transfer	F	Alarm
411	Up-/download active	Up-/download in progress, please wait	C	Warning
435	Linearization faulty	Check linearization	F	Alarm
485	Process variable simulation active	Deactivate simulation	C	Warning
491	Output simulation	Deactivate simulation	C	Warning
531	Factory adjustment missing	1. Contact service organization 2. Replace device	F	Alarm
537	Configuration	1. Check device configuration 2. Up- and download new configuration	F	Alarm
537	Configuration	Check current output configuration	F	Alarm
Diagnostic of process				
801	Supply voltage too low	Increase supply voltage	S	Alarm
825	Operating temperature	1. Check ambient temperature 2. Check process temperature	S	Warning
844	Process value out of specification	1. Check process value 2. Check application 3. Check sensor	S	Warning



The device always outputs the Low alarm state (output current < 3.6 mA) when diagnostic event 801 occurs.

10 Maintenance and cleaning

10.1 Maintenance work

The device does not require specific maintenance work.

10.2 Cleaning of surfaces not in contact with the medium

- Recommendation: Use a lint-free cloth that is either dry or slightly dampened using water.
- Do not use any sharp objects or aggressive cleaning agents that corrode the surfaces (e.g. displays, housing) and seals.
- Do not use high-pressure steam.
- Observe the degree of protection of the device.

 The cleaning agent used must be compatible with the materials of the device configuration. Do not use cleaning agents with concentrated mineral acids, bases or organic solvents.

11 Repair

11.1 General notes

Due to its design, the device cannot be repaired.

11.2 Spare parts

Product spare parts that are currently available can be found online at:
www.endress.com/onlinetools

Type
DIN mounting set (2 screws and springs, 4 lock washers, 1 CDI connector cover)
US mounting set (2 M4 screws and 1 CDI connector cover)

11.3 Return

The requirements for safe device return in the event of service or disposal vary depending on the type of device and national legislation.

1. Refer to the web page for information: <https://www.endress.com>
2. Log in to the “My Endress+Hauser” customer portal, or register if you don’t have an account yet.
3. Enter the return request directly in the portal and submit all required information and documents.
4. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.
 - ↳ Track the order's processing status online.

11.4 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

12 Accessories

The accessories currently available for the product can be selected at www.endress.com:

1. Select the product using the filters and search field.
2. Open the product page.
3. Select **Spare parts & Accessories**.

12.1 Device-specific accessories

Adapter for DIN rail mounting, DIN rail clip as per IEC 60715 (TH35) without securing screws
DIN mounting set (2 screws + springs, 4 lock washers and 1 CDI connector cover)
US mounting set (2 M4 screws and 1 CDI connector cover)

12.2 Communication-specific accessories

Configuration kit TXU10

Configuration kit for PC-programmable transmitter - FDT/DTM-based plant asset management tool, FieldCare/DeviceCare, and interface cable (4-pin connector) for PC with USB port.

For more information, please refer to: www.endress.com

12.3 Service-specific accessories

DeviceCare SFE100

DeviceCare is an Endress+Hauser configuration tool for field devices using the following communication protocols: HART, PROFIBUS DP/PA, FOUNDATION Fieldbus, IO/Link, Modbus, CDI and Endress+Hauser Common Data Interfaces.



www.endress.com/sfe100

FieldCare SFE500

FieldCare is a configuration tool for Endress+Hauser and third-party field devices based on DTM technology.

The following communication protocols are supported: HART, WirelessHART, PROFIBUS, FOUNDATION Fieldbus, Modbus, IO-Link, EtherNet/IP, PROFINET and PROFINET APL.



www.endress.com/sfe500

12.4 Online tools

Product information about the entire life cycle of the device is available at: www.endress.com/onlinetools

12.5 System components

RN series active barrier

Single- or two-channel active barrier for safe separation of 0/4 to -20 mA standard signal circuits with bidirectional HART transmission. In the signal duplicator option, the input signal is transmitted to two galvanically isolated outputs. The device has one active and one passive current input; the outputs can be operated actively or passively.

For more information, please refer to: www.endress.com

Process indicators from the RIA product family

Easily readable process indicators with various functions: loop-powered indicators for displaying 4-20 mA values, display of up to four HART variables, process indicators with control units, limit value monitoring, sensor power supply, and galvanic isolation.

Universal application thanks to international hazardous area approvals, suitable for panel mounting or field installation..

For more information, please refer to: www.endress.com

13 Technical data

13.1 Input

Measured variable Temperature (temperature-linear transmission behavior)

Resistance thermometer (RTD) as per standard	Description	α	Measuring range limits	Min. measuring span
IEC 60751:2008	Pt100 (1) Pt1000 (4)	0.003851	-200 to 850 °C (-328 to 1562 °F) -200 to 500 °C (-328 to 932 °F)	10 K (18 °F)
JIS C1604:1984	Pt100 (5)	0.003916	-200 to 510 °C (-328 to 950 °F)	10 K (18 °F)
GOST 6651-94	Pt100 (9)	0.003910	-200 to 850 °C (-328 to 1562 °F)	10 K (18 °F)
-	Pt100 (Callendar Van Dusen)	-	The measuring range limits are specified by entering the limit values that depend on the coefficients A to C and R0.	10 K (18 °F)
■ Type of connection: 2-wire, 3-wire or 4-wire connection, sensor current: ≤ 0.3 mA ■ With 2-wire circuit, compensation of the wire resistance possible (0 to 30 Ω) ■ With 3-wire and 4-wire connection, sensor wire resistance up to max. 50 Ω per wire				

Thermocouples as per standard	Description	Measuring range limits		Min. measuring span
IEC 60584, Part 1	Type A (W5Re-W20Re) (30) Type B (PtRh30-PtRh6) (31) Type E (NiCr-CuNi) (34) Type J (Fe-CuNi) (35) Type K (NiCr-Ni) (36) Type N (NiCrSi-NiSi) (37) Type R (PtRh13-Pt) (38) Type S (PtRh10-Pt) (39) Type T (Cu-CuNi) (40)	0 to 2500 °C (32 to 4532 °F) 40 to 1820 °C (104 to 3308 °F) -250 to 1000 °C (-418 to 1832 °F) -210 to 1200 °C (-346 to 2192 °F) -270 to 1372 °C (-454 to 2502 °F) -270 to 1300 °C (-454 to 2372 °F) -50 to 1768 °C (-58 to 3214 °F) -50 to 1768 °C (-58 to 3214 °F) -200 to 400 °C (-328 to 752 °F)	Recommended temperature range: 0 to 2500 °C (32 to 4532 °F) 500 to 1820 °C (932 to 3308 °F) -150 to 1000 °C (-238 to 1832 °F) -150 to 1200 °C (-238 to 2192 °F) -150 to 1200 °C (-238 to 2192 °F) -150 to 1300 °C (-238 to 2372 °F) 200 to 1768 °C (392 to 3214 °F) 200 to 1768 °C (392 to 3214 °F) -150 to 400 °C (-238 to 752 °F)	50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F)
IEC 60584, Part 1 ASTM E230-3 ASTM 988-96	Type C (W5Re-W26Re) (32)	0 to 2315 °C (32 to 4199 °F)	0 to 2000 °C (32 to 3632 °F)	50 K (90 °F)
ASTM 988-96	Type D (W3Re-W25Re) (33)	0 to 2315 °C (32 to 4199 °F)	0 to 2000 °C (32 to 3632 °F)	50 K (90 °F)
DIN 43710	Type L (Fe-CuNi) (41)	-200 to 900 °C (-328 to 1652 °F)	-150 to 900 °C (-238 to 1652 °F)	50 K (90 °F)
■ Internal cold junction (Pt1000) ■ External preset value: Configurable value -40 to 85 °C (-40 to 185 °F) ■ Maximum sensor wire resistance 10 kΩ (If the sensor wire resistance is greater than 10 kΩ, an error message is output in accordance with NAMUR NE89.)				

13.2 Output

Output signal	Analog output	4 to 20 mA, 20 to 4 mA (can be inverted)
	Galvanic isolation (TC)	U = 1.5 kV AC for 1 minute (input/output)

Failure signal Failure information as per NAMUR NE43:

Failure information is created if the measuring information is missing or not valid. The error with the highest priority is displayed.

Underranging	Linear decrease from 4.0 to 3.8 mA
Overranging	Linear increase from 20.0 to 20.5 mA
Failure e.g. sensor failure; sensor short-circuit	≤ 3.6 mA ("low") or ≥ 21 mA ("high"), can be selected

Linearization/transmission behavior Temperature linear

Filter 1st order digital filter: 0 to 120 s
Network frequency filter: 50/60 Hz (cannot be adjusted)

Protocol-specific data	DTM device description files	Information and files available at: www.endress.com
------------------------	------------------------------	---

Switch-on delay ≤ 5 s, until the first valid measured value signal is present at the current output. While switch-on delay = $I_a \leq 3.8$ mA

13.3 Electrical connection

Supply voltage Values for non-hazardous areas, protected against polarity reversal:
 $10 \text{ V} \leq V_{cc} \leq 36 \text{ V}$ (standard)
Values for hazardous area, see Ex documentation.

Current consumption 3.5 to 22.5 mA

Terminals Choice of screw terminals or push-in terminals for sensor and power supply cables:

Terminal design	Cable design	Cable cross-section
Screw terminals	Rigid or flexible	$\leq 1.5 \text{ mm}^2$ (16 AWG)
Push-in terminals ¹⁾ (Cable design, stripping length = min. 10 mm (0.39 in))	Rigid or flexible	0.2 to 1.5 mm ² (24 to 16 AWG)
	Flexible with wire end ferrules with/without plastic ferrule	0.25 to 1.5 mm ² (24 to 16 AWG)

1) For push-in terminals, flexible conductors with a conductor cross-section $\leq 0.3 \text{ mm}^2$ must be fitted with ferrules.

13.4 Performance characteristics

Response time	Resistance thermometers (RTD)	0.5 s
	Thermocouples (TC)	0.5 s
	Cold junction (CJ)	2.0 s

Update time Approx. 500 ms

Reference operating conditions	■ Calibration temperature: 25 °C ±3 K (77 °F ±5.4 °F) ■ Supply voltage: 24 V DC ■ 4-wire circuit for resistance adjustment
--------------------------------	--

Maximum measurement error	In accordance with EN IEC 62828 and the reference operating conditions specified above. The measurement error data corresponds to $\pm 2 \sigma$ (Gaussian distribution). The data includes non-linearities and repeatability.
---------------------------	--

MV = Measured value

LRL = Lower range limit of relevant sensor

Measurement error for resistance thermometers (RTD)

	Measurement error ($\pm$)	
	Increased accuracy in limited measuring range, -50 to 250 °C (-58 to 482 °F)	in the entire measuring range
RTD	0.1 °C (0.18 °F) or 0.07 % of measuring span ¹⁾	0.15 °C (0.27 °F) or 0.07 % of measuring span ¹⁾

1) Whichever is greater

The measurement error data corresponds to $\pm 2 \sigma$ (Gaussian distribution).

Measurement error for thermocouples (TC)

Standard	Description	Measuring range	Measurement error ($\pm$)	Measurement error ($\pm$)
			Measuring span $\leq$ 500 K	Measuring span $>$ 500 K
IEC 60584-1 ASTM E230-3	Type A (30)	0 to 2 500 °C (32 to 4 532 °F)	1.63 °C (2.93 °F)	1.75 °C (3.15 °F) or 0.08% of the measuring span ¹⁾
	Type B (31)	500 to 1 820 °C (932 to 3 308 °F)	1.55 °C (2.79 °F)	1.58 °C (2.84 °F) or 0.15 % of measuring span ¹⁾
IEC 60584-1 ASTM E230-3 ASTM E988-96	Type C (32)	0 to 2 000 °C (32 to 3 632 °F)	0.88 °C (1.58 °F)	1.00 °C (1.80 °F) or 0.06 % of measuring span ¹⁾
ASTM E988-96	Type D (33)		0.81 °C (1.46 °F)	0.92 °C (1.34 °F) or 0.06 % of measuring span ¹⁾
IEC 60584-1 ASTM E230-3	Type E (34)	-150 to 1 000 °C (-238 to 1 832 °F)	0.30 °C (0.54 °F)	0.33 °C (0.59 °F) or 0.05 % of measuring span ¹⁾
	Type J (35)	-150 to 1 200 °C (-238 to 2 192 °F)	0.33 °C (0.59 °F)	0.44 °C (0.79 °F) or 0.04 % of measuring span ¹⁾
	Type K (36)		0.41 °C (0.74 °F)	0.50 °C (0.90 °F) or 0.05 % of measuring span ¹⁾
	Type N (37)	-150 to 1 300 °C (-238 to 2 372 °F)	0.54 °C (0.97 °F)	0.60 °C (1.08 °F) or 0.06 % of measuring span ¹⁾
	Type R (38)	200 to 1 768 °C (-392 to 3 214 °F)	0.91 °C (1.64 °F)	0.99 °C (1.78 °F) or 0.07 % of measuring span ¹⁾
	Type S (39)	200 to 1 768 °C (392 to 3 214 °F)	0.97 °C (1.75 °F)	1.06 °C (1.91 °F) or 0.07 % of measuring span ¹⁾
	Type T (40)	-150 to 400 °C (-238 to 752 °F)	0.42 °C (0.76 °F)	0.43 °C (0.77 °F)
DIN 43710	Type L (41)	-150 to 900 °C (-238 to 1 652 °F)	0.36 °C (0.65 °F)	0.41 °C (0.74 °F) or 0.05 % of measuring span ¹⁾

1) Whichever is greater

Operating influences The measurement error data corresponds to $\pm 2 \sigma$ (Gaussian distribution).

Operating influences of ambient temperature and supply voltage on resistance thermometers (RTD)

Description	Standard	Ambient temperature: Influence ($\pm$) per 1 °C (1.8 °F) change		Supply voltage: Influence ($\pm$) per V change	
		0 to 200 °C (32 to 392 °F)	Entire measuring range	0 to 200 °C (32 to 392 °F)	Entire measuring range
Pt100 (1)	IEC 60751:2008	0.02 °C (0.04 °F)	0.04 °C (0.07 °F)	0.01 °C (0.014 °F)	0.02 °C (0.04 °F)
Pt1000 (4)		0.01 °C (0.02 °F)	0.02 °C (0.03 °F)	0.01 °C (0.009 °F)	0.01 °C (0.02 °F)
Pt100 (5)	JIS C1604:1984	0.01 °C (0.03 °F)	0.03 °C (0.05 °F)	0.01 °C (0.011 °F)	0.02 °C (0.03 °F)
Pt100 (9)	GOST 6651-94	0.02 °C (0.04 °F)	0.04 °C (0.07 °F)	0.01 °C (0.014 °F)	0.02 °C (0.04 °F)

Operating influences of ambient temperature and supply voltage on thermocouples (TC)

Description	Standard	Ambient temperature: Influence ($\pm$) per 1 °C (1.8 °F) change		Supply voltage: Influence ($\pm$) per V change	
		Measuring span $\leq$ 500 K	Measuring span $>$ 500 K	Measuring span $\leq$ 500 K	Measuring span $>$ 500 K
Type A (30)	IEC 60584-1 ASTM E230-3	0.07 °C (0.126 °F)	0.1 °C (0.18 °F)	0.04 °C (0.07 °F)	0.07 °C (0.13 °F)
Type B (31)		0.04 °C (0.072 °F)	0.07 °C (0.126 °F)	0.03 °C (0.05 °F)	0.05 °C (0.09 °F)
Type C (32)	IEC 60584-1 ASTM E230-3 ASTM E988-96				
Type D (33)	ASTM E988-96				
Type E (34)	IEC 60584-1 ASTM E230-3	0.02 °C (0.036 °F)	0.04 °C (0.072 °F)	0.02 °C (0.04 °F)	0.03 °C (0.05 °F)
Type J (35)					
Type K (36)		0.03 °C (0.05 °F)	0.05 °C (0.09 °F)	0.02 °C (0.04 °F)	0.04 °C (0.07 °F)
Type N (37)					
Type R (38)					
Type S (39)					
Type T (40)		0.02 °C (0.04 °F)	0.03 °C (0.05 °F)	0.01 °C (0.02 °F)	0.02 °C (0.04 °F)
Type L (41)	DIN 43710				

Long-term drift, resistance thermometers (RTD)

Long-term drift ($\pm$) ¹⁾		
after 1 year	after 3 years	after 5 years
Based on measured value		
0.05 °C (0.09 °F) or 0.03 % of the measuring span	0.06 °C (0.11 °F) or 0.04 % of the measuring span	0.07 °C (0.13 °F) or 0.05 % of the measuring span

1) Whichever is greater

Long-term drift, thermocouples (TC)

Long-term drift ($\pm$) ¹⁾			
	after 1 year	after 3 years	after 5 years
Type A	1.25 °C (2.25 °F) or 0.065 % of the measuring span	1.60 °C (2.88 °F) or 0.085 % of the measuring span	1.75 °C (3.15 °F) or 0.100 % of the measuring span
Type B	1.71 °C (3.078 °F)	2.24 °C (4.032 °F)	2.44 °C (4.392 °F)

Long-term drift (±) ¹⁾			
Type C	0.85 °C (1.53 °F) or 0.055 % of the measuring span	1.08 °C (1.944 °F) or 0.070 % of the measuring span	1.20 °C (2.16 °F) or 0.070 % of the measuring span
Type D	0.97 °C (1.746 °F) or 0.070 % of the measuring span	1.27 °C (2.286 °F) or 0.085 % of the measuring span	1.38 °C (2.484 °F) or 0.100 % of the measuring span
Type E	0.35 °C (0.63 °F) or 0.050 % of the measuring span	0.45 °C (0.81 °F) or 0.055 % of the measuring span	0.50 °C (0.9 °F) or 0.060 % of the measuring span
Type J	0.4 °C (0.72 °F) or 0.050 % of the measuring span	0.53 °C (0.954 °F) or 0.055 % of the measuring span	0.57 °C (1.026 °F) or 0.065 % of the measuring span
Type K	0.48 °C (0.864 °F) or 0.045 % of the measuring span	0.55 °C (0.99 °F) or 0.070 % of the measuring span	0.61 °C (1.098 °F) or 0.070 % of the measuring span
Type N	0.62 °C (1.116 °F) or 0.055 % of the measuring span	0.80 °C (1.44 °F) or 0.070 % of the measuring span	0.86 °C (1.548 °F) or 0.080 % of the measuring span
Type R	1.02 °C (1.836 °F) or 0.080 % of the measuring span	1.31 °C (2.358 °F) or 0.115 % of the measuring span	1.48 °C (2.664 °F)
Type S	1.10 °C (1.98 °F)	1.42 °C (2.556 °F)	1.54 °C (2.772 °F)
Type T	0.41 °C (0.738 °F)	0.53 °C (0.954 °F)	0.58 °C (1.044 °F)
Type L	0.34 °C (0.612 °F) or 0.045 % of the measuring span	0.4 °C (0.72 °F) or 0.065 % of the measuring span	0.47 °C (0.846 °F) or 0.060 % of the measuring span

1) Whichever is greater

Calculation of the maximum measurement error for analog value (current output):
 $\sqrt{(\text{Measurement error}^2 + \text{Influence of ambient temperature}^2 + \text{Influence of supply voltage}^2)}$

Influence of the cold junction

Pt1000 DIN IEC 60751 Cl. B (internal cold junction with thermocouples TC)



A 2-wire Pt1000 resistor must be used for external cold junction measurement. The Pt1000 must be positioned directly at the sensor terminals of the device, as the temperature difference between the Pt1000 and the terminal must be added to the measurement error of the sensor element and sensor input Pt1000.

Sensor adjustment

Sensor-Transmitter-Matching

The device enables the following method to improve the temperature measurement accuracy of RTD sensors significantly:

Callendar Van Dusen coefficient (Pt100 resistance thermometer)

The Callendar Van Dusen equation is described as:

$$R_T = R_0 [1 + AT + BT^2 + C(T - 100)T^3]$$

The coefficients A, B and C are used to match the sensor (platinum) and transmitter in order to improve the accuracy of the measuring system. The coefficients for a standard sensor are specified in IEC 60751. If no standard sensor is available or if greater accuracy is required, the coefficients for each sensor can be determined specifically with the aid of sensor calibration.

Sensor-transmitter matching using the method mentioned above significantly improves the temperature measurement accuracy of the entire system. This is because the transmitter uses the specific data pertaining to the connected sensor to calculate the measured temperature, instead of using the standardized sensor curve data.

1-point adjustment (offset)

Offset adjustment of the sensor value

Current output adjustment	Correction of the 4 and/or 20 mA current output value
---------------------------	---


13.5 Environment

Ambient temperature range	−40 to 85 °C (−40 to 185 °F)
Storage temperature	−50 to 100 °C (−58 to 212 °F)
Operating height	Up to 4 000 m (13 123 ft) above sea level.
Relative humidity	Condensation: ■ Permitted for head transmitters (95% r.h. according to IEC 60068-2-30) ■ Not permitted for DIN rail transmitters (95% r.h. IEC 60068-2-78)
Climate class	■ Head transmitter climate class: C1 (−5 to 45 °C, 5 to 95r.h.) according to IEC 60654-1 ■ DIN rail transmitter climate class: B2 (−5 to 45 °C, 5 to 95r.h.) according to IEC 60654-1
Degree of protection	■ Head transmitter with screw terminals: IP 20, head transmitter with push-in terminals: IP 30. When the device is installed, the degree of protection depends on the terminal head or housing used for field mounting. ■ DIN rail transmitter: IP 20
Vibration and shock resistance	Vibration resistance according to IEC 60068-2-6 (DNV): ■ Head transmitter: ■ 2 to 10 Hz, 10 mm ■ 10 to 150 Hz at 4 g ■ DIN rail transmitter: ■ 2 to 13.2 Hz, 1 mm ■ 13.2 to 100 Hz at 0.7 g Vibration resistance according to IEC 60068-2-27: ■ 30g, 18 ms ■ 30g, 11 ms (KTA 3505)
Electromagnetic compatibility (EMC)	CE conformity Electromagnetic compatibility in accordance with all the relevant requirements of the IEC/EN 61326 series and NAMUR Recommendation EMC (NE 21). For details, refer to the Declaration of Conformity. Maximum measurement error <1% of measuring range. Interference immunity as per IEC/EN 61326 series, industrial requirements Interference emission as per IEC/EN 61326 series (CISPR 11), Class B equipment, Group 1
Overvoltage category	Overvoltage category II
Pollution level	Pollution degree 2 as per IEC 61010-1

13.6 Mechanical construction


Design and dimensions

Dimensions in mm (in)




11 Version with screw terminals

- A Spring travel $L \geq 5\text{ mm}$ (not for US - M4 securing screws)
- B CDI interface for connecting a configuration tool



12 Version with push-in terminals. Dimensions are identical to the version with screw terminals, apart from housing height.

DIN rail transmitter



Weight

Head transmitter:

40 to 50 g (1.4 to 1.8 oz)

DIN rail transmitter:

Approx. 100 g (3.53 oz)

Materials

All the materials used are RoHS-compliant.

- Housing: polycarbonate (PC)
- Terminals:
 - Screw terminals: nickel-plated brass
 - Push-in terminals: tin-plated brass, contact springs 1.4310, 301 (AISI)
- Potting compound: SIL gel

13.7 Certificates and approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

1. Select the product using the filters and search field.
2. Open the product page.
3. Select **Downloads**.

MTTF

- **RTD input:**
418 years
- **TC input:**
350 years

The mean time to failure (MTTF) denotes the theoretically expected time until the device fails during normal operation. The term MTTF is used for systems that cannot be repaired, e.g. temperature transmitters.

13.8 Documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the product configuration:

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid This document contains all the technical data on the product and provides an overview of everything that can be ordered with the product.
Brief Operating Instructions (KA)	Quick guide to obtaining the first measured value The Operating Instructions contain all the essential information about the product from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Reference The Operating Instructions contain the information that is required in the various phases of the life cycle of the product: From product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

Document type	Purpose and content of the document
Description of Device Parameters (GP)	Reference for parameters The document contains detailed explanations of readable or configurable parameters in the product. The description is aimed at those who work with the product over its entire life cycle and perform specific configurations.
Safety Instructions (XA)	Safety Instructions for electrical equipment in hazardous areas are supplied with the product depending on the approval. These are an integral part of the Operating Instructions.  The nameplate indicates the Safety Instructions (XA) that are relevant to the product.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the product documentation.



www.addresses.endress.com
