# Safety Instructions iTEMP TMT82

Ex ia IIC T6...T4 Ga Ex ib [ia Ga] IIC T6...T4 Gb







XA03642T iTEMP TMT82

### **iTEMP TMT82**

### Table of contents

About this document
Associated documentation
Supplementary documentation
Certificates and declarations
Manufacturer address
Safety instructions:
Safety instructions: Installation
Safety instructions: Head transmitter $\ldots$ 6
Safety instructions: DIN rail transmitter
Safety instructions: Zone 1 and Zone 2
Safety instructions: Zone 0 (only for head transmitters) $\epsilon$
Temperature tables
Electrical connection data

iTEMP TMT82 XA03642T

### About this document



The document number of these Safety Instructions (XA) must match the information on the nameplate.

### Associated documentation

All documentation is available on the Internet:

www.endress.com/Deviceviewer

(enter the serial number from the nameplate).

To commission the device, please observe the Operating Instructions

pertaining to the device:

www.endress.com/product code>, e.g. iTEMP TMT82

### Supplementary documentation

Explosion protection brochure: CP00021Z

The explosion protection brochure is available on the Internet:

www.endress.com/Downloads

### Certificates and declarations

#### Korean certificate

Certificate number:

25-KA4BO-0582X

25-KA4BO-0583X

25-KA4BO-0584X

Affixing the certificate number certifies conformity with the following

standards (depending on the device version)

Protect Device Safety Certification Notice No. 2021-22



Please refer to Korean certificates for conditions of safe use.

### Manufacturer address


Endress+Hauser Wetzer GmbH + Co. KG

Obere Wank 1

87484 Nesselwang, Germany


XA03642T iTEMP TMT82

### Safety instructions:



■ 1 Installation of the head transmitter

iTEMP TMT82 XA03642T



A0050503

#### Installation of the DIN rail transmitter

#### Safety instructions: Installation

- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations (e.g. EN/IEC 60079-14).
- When installing the unit note that the housing ingress protection classification IP20 according to EN/IEC 60529 is upheld.
- When connecting the measurement unit with a certified circuit of category "ib" into an IIC or IIB hazardous area the ignition class changes to: Ex ib IIC or Ex ib IIB.
- In hazardous areas it is not permitted to use the CDI interface for configuration.

XA03642T iTEMP TMT82

#### Safety instructions: Head transmitter

• The device (connection head) must be connected to the potential compensation cable.

- The certified TID10 display may only be installed in zone 1/EPL Gb or zone 2/EPL Gc.
- The permissible ambient temperatures for the display, type TID10, are to be observed.

#### Safety instructions: DIN rail transmitter

On installation please make sure that the spacing between the intrinsically safe and non intrinsically safe circuits is at least 50 mm.

#### Safety instructions: Zone 1 and Zone 2

- According to the specifications of the manufacturer, this apparatus can be operated in zone 1 (category 2)/EPL Gb or zone 2 (category 3) /EPL Gc.
- The sensor current circuit may be introduced into zone 0 (category 1)/EPL Ga.

#### Safety instructions: Zone 0 (only for head transmitters)

(These instructions are only valid if the unit is to be installed directly in the zone 0 (category 1)/EPL Ga.)

- Explosive moisture/air mixtures are only allowed to occur under atmospheric conditions.
  - $-52^{\circ}\text{C} \leq \text{Ta} \leq +60^{\circ}\text{C}$
  - $0.8 \text{ bar} \le p \le 1.1 \text{ bar}$

If there is no explosive mixture present or the additional measures according to EN 1127-1 are upheld the unit can also be operated outside the atmospheric conditions according to the manufacturers specification.

- The restricted ambient temperatures as per EN 1127-1 6.4.2 must be observed (see table).
- The power circuit to be supplied must meet the specifications for explosion protection Ex ia IIC (EN/IEC 60079-14 12.3).
- The devices can only be used in fluids if the process-wetted materials are sufficiently resistant to such fluids.
- If the entire device is operated in Zone O/EPL Ga, the compatibility of the device materials with the fluids has to be ensured. (Housing: polycarbonate (PC), potting: silicone).
- It is not permitted to mount the TID10 display in zone O/EPL Ga.
- The temperature transmitter must be installed in such a way that electrostatic charge cannot occur, e.g. installation in grounded metallic head or grounded housing.

iTEMP TMT82 XA03642T

## Temperature tables

Type (order option)	Temperature class	Ambient temperature zone 1	Ambient temperature zone 0
TMT82-xxA1xxxxxxxx TMT82-xxA2xxxxxxx without display	Т6	-52 °C = Ta = +58 °C	-52 °C = Ta = +46 °C
	T5	-52 °C = Ta = +75 °C	-52 °C = Ta = +60 °C
	T4	-52 °C = Ta = +85 °C	-52 °C = Ta = +60 °C
TMT82-xxA1xxxxxxxxx	Т6	-40 °C = Ta = +55 °C	
TMT82-xxA2xxxxxxxxx with display (TID)	T5	-40 °C = Ta = +70 °C	
	T4	-40 °C = Ta = +85 °C	
TMT82-xxA3xxxxxxxx	Т6	-40 °C = Ta = +46 °C	
(DIN rail transmitter)	T5	-40 °C = Ta = +61 °C	
	T4	-40 °C = Ta = +85 °C	

### Electrical connection data

Туре	Electrical data		
TMT82 HART® Order option: TMT82-xxA1xxxxxxxx TMT82-xxA2xxxxxxx (head transmitter)	Power supply (terminals + and -)	$\label{eq:continuous} \begin{split} &Ui \leq 30 \; V_{DC} \\ &Ii \leq 130 \; mA \\ Π = 800 \; mW \\ &Ci = negligibly \; small \\ &Li = negligibly \; small \end{split}$	
	Sensor circuit (terminals 3 to 7)	$\label{eq:Uo} \begin{split} &Uo \leq 7.6 \ V_{DC} \\ &Io \leq 13 \ mA \\ &Po \leq 24.7 \ mW \end{split}$	
	Max. connection values Ex ia IIC Ex ia IIB Ex ia IIA	Lo = 10 mH Lo = 50 mH Lo = 50 mH	$Co = 1 \mu F$ $Co = 4.5 \mu F$ $Co = 6.7 \mu F$
	Display connection (optional)	$Uo \le 7.6 V_{DC}$ $Ii \le 130 \text{ mA}$ Ci = negligibly small Li = negligibly small	
	Max. connection values Ex ia IIC Ex ia IIB Ex ia IIA	Lo = 3.1 mH Lo = 16 mH Lo = 27 mH	Co = 0.64 μF Co = 3.8 μF Co = 12 μF

XAO3642T iTEMP TMT82

Туре	Electrical data		
TMT82 HART® Order option: TMT82-xxA3xxxxxxxx (DIN rail transmitter)	Power supply (terminals + and -)	$ \begin{aligned} &\text{Ui} = 30 \text{ V}_{\text{DC}} \\ &\text{Ii} = 130 \text{ mA} \\ &\text{Pi} = 770 \text{ mW} \\ &\text{Ci} = \text{negligibly small} \\ &\text{Li} = \text{negligibly small} \end{aligned} $	
	Sensor circuit (terminals 3 to 8)	Uo = 9 V <sub>DC</sub> Io = 13 mA Po = 29.3 mW	
	Max. connection values Ex ia IIC Ex ia IIB Ex ia IIA	Lo = 5 mH Lo = 20 mH Lo = 50 mH	$Co = 0.93 \ \mu F$ $Co = 3.8 \ \mu F$ $Co = 4.8 \ \mu F$







www.addresses.endress.com