



Füllstand



Druck



Durchfluss



Temperatur



Flüssigkeits-
analyse



Registrierung



Systeme
Komponenten



Services



Solutions

Description of Device Functions

Proline Promass 84 MODBUS RS485

Coriolis Mass Flow Measuring System




Table of contents

1	Using this manual	5
1.1	Finding a function description	5
1.1.1	Using the table of contents	5
1.1.2	Using the graphic of the function matrix	5
1.1.3	Using the index of the function matrix	5
2	Function matrix	6
2.1	General layout of the function matrix	6
2.1.1	Blocks (A, B, C, etc.)	6
2.1.2	Groups (AAA, AEA, CAA, etc.)	6
2.1.3	Function groups (000, 020, 060, etc.)	6
2.1.4	Functions (0000, 0001, 0002, etc.)	6
2.1.5	Codes identifying cells	6
2.2	Illustration of the function descriptions	8
2.3	Display lines on the local display	8
2.4	Function matrix Proline Promass 84	9
3	Block CUSTODY TRANSFER	10
4	Block MEASURED VARIABLES	12
4.1	Group MEASURING VALUES	13
4.1.1	Function group MAIN VALUES	13
4.2	Group SYSTEM UNITS	14
4.2.1	Function group CONFIGURATION	14
4.2.2	Function group ADDITIONAL CONFIGURATION	17
5	Block QUICK SETUP	19
5.1	Quick Setup	21
5.1.1	Quick Setup Commissioning	21
5.1.2	Quick Setup Pulsating Flow	23
5.1.3	Quick Setup Gas Measurement	25
5.1.4	Quick Setup Communication	26
5.2	Data back-up/transfer	27
6	Block USER INTERFACE	28
6.1	Group CONTROL	29
6.1.1	Function group BASIC CONFIGURATION	29
6.1.2	Function group UNLOCKING/LOCKING	31
6.1.3	Function group OPERATION	32
6.2	Group MAIN LINE	33
6.2.1	Function group CONFIGURATION	33
6.2.2	Function group MULTIPLEX	35
6.3	Group ADDITIONAL LINE	37
6.3.1	Function group CONFIGURATION	37
6.3.2	Function group MULTIPLEX	39
6.4	Group INFORMATION LINE	41
6.4.1	Function group CONFIGURATION	41
6.4.2	Function group MULTIPLEX	43
7	Block TOTALIZER	45
7.1	Group TOTALIZER (1 to 3)	46
7.1.1	Function group CONFIGURATION	46
7.1.2	Function group OPERATION	48
7.2	Group HANDLING TOTALIZER	49
8	Block OUTPUTS	50
8.1	Group CURRENT OUTPUT	51
8.1.1	Function group CONFIGURATION	51
8.1.2	Function group OPERATION	60
8.1.3	Function group INFORMATION	61

8.2	Group PULSE/FREQUENCY OUTPUT 1	62
8.2.1	Function group CONFIGURATION	62
8.2.2	Function group OPERATION	83
8.2.3	Function group INFORMATION	88
8.3	Group RELAY OUTPUT (1 to 2)	89
8.3.1	Function group CONFIGURATION	89
8.3.2	Function group OPERATION	93
8.3.3	Function group INFORMATION	94
8.3.4	Information on the response of the relay output	95
	Switching behavior of the relay output	96
9	Block INPUTS	98
9.1	Group STATUS INPUT	99
9.1.1	Function group CONFIGURATION	99
9.1.2	Function group OPERATION	100
9.1.3	Function group INFORMATION	101
10	Block BASIC FUNCTION	102
10.1	Group MODBUS RS485	103
10.1.1	Function group CONFIGURATION	103
10.2	Group PROCESS PARAMETER	106
10.2.1	Function group CONFIGURATION	106
10.2.2	Function group EPD PARAMETER	108
10.2.3	Function group REFERENCE PARAMETER	110
10.2.4	Function group ADJUSTMENT	112
10.2.5	Function group PRESSURE CORRECTION	114
10.3	Group SYSTEM PARAMETER	115
10.3.1	Function group CONFIGURATION	115
10.4	Group SENSOR DATA	116
10.4.1	Function group CONFIGURATION	116
10.4.2	Function group FLOW COEFFICIENT	117
10.4.3	Function group DENSITY COEFFICIENT	118
10.4.4	Function group ADDITIONAL COEFFICIENT	119
11	Block SUPERVISION	120
11.1	Group SYSTEM	121
11.1.1	Function group CONFIGURATION	121
11.1.2	Function group OPERATION	122
11.2	Group VERSION-INFO	124
11.2.1	Function group DEVICE	124
11.2.2	Function group SENSOR	125
11.2.3	Function group AMPLIFIER	126
11.2.4	Function group F-CHIP	127
11.2.5	Function group I/O MODULE	127
11.2.6	Function groups I/O SUBMODULE 2 to 4	128
12	Factory settings	129
12.1	SI units (not for USA and Canada)	129
12.1.1	Low flow cut off, full scale value, pulse value	129
12.1.2	Language	129
12.1.3	Density, length, temperature	129
12.2	US units (only for USA and Canada)	130
12.2.1	Low flow cut off, full scale value, pulse value	130
12.2.2	Language, density, length, temperature	130
	Index of function matrix	131
	Index	135

1 Using this manual

This manual must be used in conjunction with the Operating Instructions of the measuring device. A description of all the functions of the measuring device is provided here.

1.1 Finding a function description

There are various ways of locating the description of a function of your choice in the manual:

1.1.1 Using the table of contents

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as USER INTERFACE, INPUTS, OUTPUTS, etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents is on page 3.

1.1.2 Using the graphic of the function matrix

This step-by-step, top-down approach starts with the blocks, the highest level, and factory down through the matrix to the description of the function you need:

1. All blocks available, and their related groups, are illustrated on Page 9. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.1.3 Using the index of the function matrix

Each "cell" in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number.

The code identifying a selected "cell" appears at the top right on the local display.

The function matrix index lists the codes for all the available "cells" in alphabetic and consecutive order, complete with the page references for the corresponding functions.




Fig. 1: Local display

- 1 Name of the function, e.g. mass flow, user interface
- 2 Function code, e.g. 0000, CAA

The index for the function matrix is on Page 131.


A0004821

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks -> Groups -> Function groups -> Functions



A0000961

Fig. 2: Layout of the function matrix

2.1.1 Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the device. The blocks include, for example: MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZER, etc.

2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the "USER INTERFACE" block, for example, include: CONTROL, MAIN LINE, ADDITION LINE, etc.

2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the "CONTROL" group, for example, include: BASIC CONFIG., UNLOCKING/LOCKING, CONTROL, etc.

2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the measuring instrument. Numerical values can be entered or parameters selected and saved.

The functions in the "BASIC CONFIGURATION" function group include LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc. The procedure for changing the language of the user interface, for example, is as follows:

1. Select the block "USER INTERFACE".
2. Select the group "CONTROL".
3. Select the function group "BASIC CONFIG.".
4. Select the function "LANGUAGE" (here you can set the language required).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A _ _; the codes of the groups in block B start with a B _ _ etc.). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.).

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).


The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).



A0001251

2.2 Illustration of the function descriptions



A0004827-EN

Fig. 3: Example for the description of a function

- 1 Name of the function
- 2 Number of the function (appears on the local display; is **not** identical to the MODBUS RS485 register address)
- 3 Description of the function
- 4 Selection or entry options or display
- 5 Factory setting (the measuring device is delivered with this setting/selected option)
- 6 Information on communication via MODBUS RS485
 - MODBUS RS485 register (information in decimal numerical format)
 - Data type: float (length = 4 bytes), integer (length = 2 bytes), string (length = depends on function)
 - Possible ways of accessing the function:
 - read = read access via function code 03, 04 or 23
 - write = write access via function code 06, 16 or 23




Note!

If a nonvolatile device parameter is modified via the MODBUS RS485 function codes 06, 16 or 23, this change is saved in the EEPROM of the measuring device. The number of writes to the EEPROM is technically restricted to a maximum of 1 million. Attention must be paid to this limit since, if exceeded, it results in data loss and measuring device failure. For this reason, avoid constantly writing nonvolatile device parameters via the MODBUS RS485!

2.3 Display lines on the local display

The local display is split into various display lines.



A0001253

Fig. 4: Local display

- 1 Main line
- 2 Additional line
- 3 Information line

The values are assigned to the individual lines in the USER INTERFACE block, see Page 29.

2.4 Function matrix Proline Promass 84

Blocks	Groups	Function groups
CUSTODY TRANSFER Z (see P. 10)	→	→ see Page 10
↓↑		
MEASURED VARIABLES A (see P. 12)	→	→ see Page 13
	→	→ see Page 14
↓↑		
QUICK SETUP B (see P. 19)	→	→ see Page 19
↓↑		
USER INTERFACE C (see P. 28)	→	→ see Page 29
	→	→ see Page 33
	→	→ see Page 37
	→	→ see Page 41
↓↑		
TOTALIZER D (see P. 45)	→	→ see Page 46
	→	→ see Page 46
	→	→ see Page 46
	→	→ see Page 49
↓↑		
OUTPUTS E (see P. 50)	→	→ see Page 51
	→	→ see Page 62
	→	→ see Page 89
	→	→ see Page 89
↓↑		
INPUTS F (see P. 98)	→	→ see Page 99
↓↑		
BASIC FUNCTION G (see P. 102)	→	→ see Page 103
	→	→ see Page 106
	→	→ see Page 115
	→	→ see Page 116
↓↑		
SUPERVISION J (see P. 120)	→	→ see Page 121
	→	→ see Page 124

3 Block CUSTODY TRANSFER

Block	Group	Function groups	Functions			
CUSTODY TRANSFER (Z)	⇒	⇒	CUSTODY TRANSFER Z000 P. 10	PULSE OUT.1 C.T. Z001 P. 10	CURR. OUT. 1 C.T. Z003 P. 10	TOTALIZER 1 C.T. Z006 P. 11
			TOTALIZER 2 C.T. Z007 P. 11	TOTALIZER 3 C.T. Z008 P. 11	MODBUS CFG C.T. Z009 P. 11	

Function description CUSTODY TRANSFER

Note!

- If the measuring device is configured in accordance with the NTEP or MC approvals, this block (CUSTODY TRANSFER) is not available.
- If the measuring system is set to custody transfer and the hardware is sealed, then all the measuring instrument functions marked with a lock symbol are protected against access. For additional information on this topic, refer to the Operating Instructions for Proline Promass 84 MODBUS RS485 (BA129D) in Chapter 7.3.1, "Setting up custody transfer measurement".
- These functions are not available to be used again until you disable custody transfer mode of the measuring system. For additional information on this topic, refer to the Operating Instructions for Proline Promass 84 MODBUS RS485 (BA129D) in Chapter 7.3.2, "Disabling custody transfer measurement".

CUSTODY TRANSFER	Z000	Use this function to check whether the measuring point is set to custody transfer.
MODBUS register:	7550	
Data type:	Integer	
Access:	read	
		Display: 0 = C.T. NO 1 = C.T. YES
		Factory setting: C.T. NO

PULSE OUTPUT 1 CUSTODY TRANSFER	Z001	Note! This function is available only if the measuring instrument has a pulse output 1.
		Selection of the pulse output 1 for transferring the calibrated signal.
MODBUS register:	7551	
Data type:	Integer	
Access:	read/write	
		Options: 0 = NO 1 = YES
		Factory setting: NO

CURRENT OUTPUT 1 CUSTODY TRANSFER	Z003	Note! This function is available only if the measuring instrument has a current output 1.
		Selection of the current output 1 for transferring the calibrated signal.
MODBUS register:	7553	
Data type:	Integer	
Access:	read/write	
		Options: 0 = NO 1 = YES
		Factory setting: NO


Function description CUSTODY TRANSFER		
<p>TOTALIZER 1 CUSTODY TRANSFER</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>Z006</p> <p>7556</p> <p>Integer read/write</p>	<p>Selection of the totalizer 1 for transferring the calibrated signal.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p>
<p>TOTALIZER 2 CUSTODY TRANSFER</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>Z007</p> <p>7557</p> <p>Integer read/write</p>	<p>Selection of the totalizer 2 for transferring the calibrated signal.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p>
<p>TOTALIZER 3 CUSTODY TRANSFER</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>Z008</p> <p>7558</p> <p>Integer read/write</p>	<p>Selection of the totalizer 3 for transferring the calibrated signal.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p>
<p>MODBUS CONFIGURATION CUSTODY TRANSFER</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>Z009</p> <p>7559</p> <p>Integer read/write</p>	<p>Selection of the MODBUS communication for transferring the calibrated signal.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p>

4 Block MEASURED VARIABLES

Block	Groups	Function groups	Functions
MEASURED VARIABLES (A)	MEASURING VALUES (AAA) P. 13 ↓ ↑ SYSTEM UNITS (ACA) P. 14	MAIN VALUES (000) P. 13 ⇒ CONFIGURATION (040) P. 14 ↓ ↑ ADDITIONAL CONFIGURATION (042) P. 17	MASS FLOW (0000) P. 13 ⇒ UNIT MASS FLOW (0400) P. 14 ⇒ UNIT DENSITY (0420) P. 17
			VOLUME FLOW (0001) P. 13 ⇒ UNIT MASS (0401) P. 14 ⇒ UNIT REF. DENSITY (0421) P. 17
			CORRECTED VOLUME FLOW (0004) P. 13 ⇒ UNIT VOL. FLOW (0402) P. 15 ⇒ UNIT TEMPERATURE (0422) P. 18
			DENSITY (0005) P. 13 ⇒ UNIT VOLUME (0403) P. 15 ⇒ UNIT LENGTH (0424) P. 18
			REFERENCE DENSITY (0006) P. 13 ⇒ UNIT CORR. FLOW (0404) P. 16 ⇒ UNIT PRESSURE (0426) P. 18
			TEMPERATURE (0008) P. 13 ⇒ UNIT CORR. VOLUME (0405) P. 16

4.1 Group MEASURING VALUES


4.1.1 Function group MAIN VALUES






Function description		
MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES		
<p> Note!</p> <ul style="list-style-type: none"> The units of all the measured variables shown here can be set in the SYSTEM UNITS group. If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. 		
<p>MASS FLOW 0000</p> <p>MODBUS register: 2007 247</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The currently measured mass flow appears on the display.</p> <p>Display: 5-digit floating-point number, including unit and sign (e.g. 462.87 kg/h; -731.63 lb/min; etc.)</p>	
<p>VOLUME FLOW 0001</p> <p>MODBUS register: 2009 253</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The calculated volume flow appears on the display. The volume flow is derived from the measured mass flow and the measured density of the fluid.</p> <p>Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)</p>	
<p>CORRECTED VOLUME FLOW 0004</p> <p>MODBUS register: 2011</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The calculated corrected volume flow appears on the display. The calculated corrected volume flow is derived from the measured mass flow and the reference density of the fluid (density at reference temperature, measured or fixed entry).</p> <p>Display: 5-digit floating-point number, including unit and sign (e.g. 1.3549 Nm³/h; 7.9846 scm/day; etc.)</p>	
<p>DENSITY 0005</p> <p>MODBUS register: 2013 249</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The currently measured density or its specific gravity appears on the display.</p> <p>Display: 5-digit floating point number, incl. unit (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C; etc.)</p>	
<p>REFERENCE DENSITY 0006</p> <p>MODBUS register: 2015</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The density of the fluid, at reference temperature, appears on the display. The reference density can be measured or also specified via the function FIXED REFERENCE DENSITY (6461), (see Page 110).</p> <p>Display: 5-digit floating point number, incl. unit (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C; etc.)</p>	
<p>TEMPERATURE 0008</p> <p>MODBUS register: 2017 251</p> <p>Data type: Float</p> <p>Access: read</p>	<p>The currently measured temperature appears on the display.</p> <p>Display: Max. 4-digit fixed-point number, including unit and sign (e.g. -23.4 °C; 160.0 °F; 295.4 K; etc.)</p>	

4.2 Group SYSTEM UNITS

4.2.1 Function group CONFIGURATION




Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
You can select the units for measured variables in this function group.		
<p>UNIT MASS FLOW 0400</p> <p>①</p> <p>MODBUS register: 2101 Data type: Integer Access: read/write</p>	<p>For selecting the unit for displaying the mass flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for mass flow, flow direction) ■ Low flow cut off <p>Options: Metric: 0 to 3 = gram → g/s; g/min; g/h; g/day 4 to 7 = kilogram → kg/s; kg/min; kg/h; kg/day 8 to 11 = ton → t/s; t/min; t/h; t/day</p> <p>US: 12 to 15 = ounce → oz/s; oz/min; oz/h; oz/day 16 to 19 = pound → lb/s; lb/min; lb/h; lb/day 20 to 23 = ton → ton/s; ton/min; ton/h; ton/day</p> <p>Factory setting: Country-dependent (kg/h or US-lb/min)</p>	
<p>UNIT MASS 0401</p> <p>①</p> <p>MODBUS register: 2102 Data type: Integer Access: read/write</p>	<p>For selecting the unit for displaying the mass.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Pulse value (e.g. kg/p) <p>Options: Metric: 0 = g 1 = kg 2 = t</p> <p>US: 3 = oz 4 = lb 5 = ton</p> <p>Factory setting: Country-dependent (kg or US-lb)</p> <p> Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>	

Function description		
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
<p>UNIT VOLUME FLOW</p> <p></p> <p>MODBUS register: 2103 Data type: Integer Access: read/write</p>	<p>0402</p>	<p>For selecting the unit for displaying the volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for volume flow, flow direction) ■ Low flow cut off <p>Options:</p> <p>Metric:</p> <p>0 to 3 = cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day 4 to 7 = cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day 8 to 11 = cubic meter → m³/s; m³/min; m³/h; m³/day 12 to 15 = milliliter → ml/s; ml/min; ml/h; ml/day 16 to 19 = liter → l/s; l/min; l/h; l/day 20 to 23 = hectoliter → hl/s; hl/min; hl/h; hl/day 24 to 27 = megaliter → Ml/s; Ml/min; Ml/h; Ml/day</p> <p>US:</p> <p>28 to 31 = cubic centimeter → cc/s; cc/min; cc/h; cc/day 32 to 35 = acre foot → af/s; af/min; af/h; af/day 36 to 39 = cubic foot → ft³/s; ft³/min; ft³/h; ft³/day 40 to 43 = fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day 44 to 47 = gallon → gal/s; gal/min; gal/h; gal/day 88 to 92 = kilo gallon → Kgal/s; Kgal/min; Kgal/h; Kgal/day 48 to 51 = million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day 52 to 55 = barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 56 to 59 = barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 60 to 63 = barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 64 to 67 = barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Imperial:</p> <p>68 to 71 = gallon → gal/s; gal/min; gal/h; gal/day 72 to 75 = mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day 76 to 79 = barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 80 to 83 = barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Factory setting: Country-dependent (m³/h or US-Mgal/day)</p>
<p>UNIT VOLUME</p> <p></p> <p>MODBUS register: 2104 Data type: Integer Access: read/write</p>	<p>0403</p>	<p>For selecting the unit for displaying the volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Pulse value (e.g. m³/p) <p>Options:</p> <p>0 to 6 = metric → cm³; dm³; m³; ml; l; hl; Ml Mega</p> <p>7 to 16 = US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks); 22 = Kgal</p> <p>17 to 20 = Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p>Factory setting: m³</p> <p> Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>

Function description		
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
<p>UNIT CORRECTED VOLUME FLOW</p> <p>①</p> <p>MODBUS register: 2105 Data type: Integer Access: read/write</p>	<p>0404</p>	<p>For selecting the unit for displaying the corrected volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for corrected volume flow, flow direction) ■ Low flow cut off <p>Options: Metric: 0 = Nl/s 1 = Nl/min 2 = Nl/h 3 = Nl/day 4 = Nm³/s 5 = Nm³/min 6 = Nm³/h 7 = Nm³/day</p> <p>US: 8 = Sm³/s 9 = Sm³/min 10 = Sm³/h 11 = Sm³/day 12 = Scf/s 13 = Scf/min 14 = Scf/h 15 = Scf/day</p> <p>Factory setting: Nm³/h</p>
<p>UNIT CORRECTED VOLUME</p> <p>①</p> <p>MODBUS register: 2106 Data type: Integer Access: read/write</p>	<p>0405</p>	<p>For selecting the unit for displaying the corrected volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Pulse value (e.g. Nm³/p) <p>Options: Metric: 0 = Nm³ 1 = Nl</p> <p>US: 2 = Sm³ 3 = Scf</p> <p>Factory setting: Nm³</p> <p>📌 Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>

4.2.2 Function group ADDITIONAL CONFIGURATION










Function description		
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION		
<p>UNIT DENSITY 0420</p> <p>①</p> <p>MODBUS register: 2107 Data type: Integer Access: read/write</p>	<p>For selecting the unit for displaying the density.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for density) ■ Density response value for EPD ■ Density adjustment value <p>Options: 0 to 10 = metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C</p> <p>11 to 16 = US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks)</p> <p>17 to 19 = Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals)</p> <p>Factory setting: kg/l</p> <p>SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C).</p>	
<p>UNIT REFERENCE DENSITY 0421</p> <p>①</p> <p>MODBUS register: 2108 Data type: Integer Access: read/write</p>	<p>For selecting the unit for displaying the reference density.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for density) ■ Fixed reference density (for calculation of corrected volume flow) <p>Options: Metric: 1 = kg/Nl 2 = kg/Nm³</p> <p>US: 0 = g/Sccl 3 = kg/Sm³ 4 = lb/Scf</p> <p>Factory setting: kg/Nl</p>	

Function description		
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION		
UNIT TEMPERATURE ⓘ MODBUS register: Data type: Access:	0422 2109 Integer read/write	For selecting the unit for displaying the temperature. The unit you select here is also valid for: <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for temperature) ■ Reference temperature (for corrected vol. measurement with measured reference density) Options: 0 = °C (Celsius) 1 = K (Kelvin) 2 = °F (Fahrenheit) 3 = °R (Rankine) Factory setting: °C
UNIT LENGTH ⓘ MODBUS register: Data type: Access:	0424 2125 Integer read/write	For selecting the unit for displaying the length of the nominal diameter. The unit you select here is valid for: <ul style="list-style-type: none"> ■ Nominal diameter of sensor (function NOMINAL DIAMETER (6804) on Page 116) Options: 0 = MILLIMETER 1 = INCH Factory setting: MILLIMETER
UNIT PRESSURE ⓘ MODBUS register: Data type: Access:	0426 2130 Integer read/write	For selecting the unit for displaying the pressure. The unit you select here is valid for: <ul style="list-style-type: none"> ■ Specified pressure (function PRESSURE (6501) on Page 114) Options: 0 = bara 1 = barg 2 = psia 3 = psig Factory setting: bar g

5 Block QUICK SETUP

Block	Group / Function groups	Functions					
QUICK SETUP (B)	⇒	QS COMMISSION (1002) P. 19	⇒	QS - PULS. FLOW (1003) P. 19	QS - GAS MEASUREMENT (1004) P. 19	QS - COM-MUNICATION (1006) P. 19	T-DAT SAVE/LOAD (1009) P. 20

Function description QUICK SETUP		
<p> Note!</p> <ul style="list-style-type: none"> ■ The Quick Setups are only available by means of the local display. ■ The flowcharts of the various Quick Setups are provided on the pages to follow. ■ For additional information on the Setups, refer to the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D. 		
<p>QUICK SETUP COMMISSIONING</p> <p>1002</p> <p></p>	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>	
<p>QUICK SETUP PULSATING FLOW</p> <p>1003</p> <p></p>	<p> Note!</p> <p>Function only available for measuring devices with a current or frequency output.</p> <p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>	
<p>QUICK SETUP GAS MEASUREMENT</p> <p>1004</p> <p></p>	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>	
<p>QUICK SETUP COMMUNICATION</p> <p>1006</p> <p></p>	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>	

Function description QUICK SETUP		
<p>T-DAT SAVE/LOAD</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>1009</p> <p>2401 Integer read/write</p>	<p>Use this function to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual backup function).</p> <p>Application examples:</p> <ul style="list-style-type: none"> ■ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. ■ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). <p>Options: 0 = CANCEL 1 = SAVE (from EEPROM to T-DAT) 2 = LOAD (from the T-DAT into EEPROM)</p> <p>Factory setting: CANCEL</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If the target device has an older software version, the message "TRANSM. SW-DAT" is displayed during startup. Then only the SAVE function is available. ■ LOAD This function is only possible if the target device has the same software version as, or a more recent software version than, the source device. ■ SAVE This function is always available.

5.1 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the configuration program, e.g. ToF Tool - Fieldtool Package.

If the measuring device is equipped with a local display, all the important device parameters for standard operation can be configured quickly and easily by means of the "Commissioning" Quick Setup menu.

- Quick Setup Commissioning, see below
- Quick Setup Pulsating Flow → Page 23
- Quick Setup Gas Measurement → Page 25
- Quick Setup Communication → Page 26

5.1.1 Quick Setup Commissioning




Note!

- The display returns to the function SETUP COMMISSIONING (1002) if you press the \square key combination during parameter interrogation. The stored parameters remain valid.
- The "COMMISSIONING" Quick Setup must be carried out before another Quick Setup is run.

- ① The "DELIVERY SETTINGS" option sets every selected unit to the factory setting. The "ACTUAL SETTING" option accepts the units you previously configured.
- ② Only units not yet configured in the current Setup are offered for selection in each cycle. The unit for mass, volume and corrected volume is derived from the corresponding flow unit.
- ③ The "YES" option remains visible until all the units have been configured. "NO" is the only option displayed when no further units are available.
- ④ The prompt only appears if a current output and/or pulse/frequency output is available. Only the outputs not yet configured in the current Setup are offered for selection in each cycle.
- ⑤ The "YES" option remains visible until all the outputs have been configured. "NO" is the only option displayed when no further outputs are available.
- ⑥ The "automatic parameterization of the display" option contains the following basic settings/factory settings:


YES	Main line = mass flow Additional line = totalizer 1 Information line = operating/system condition
NO	The existing (selected) settings remain.
- ⑦ The execution of other Quick Setups are described in the following chapters.



a0003255-en

Fig. 5: "QUICK SETUP COMMISSIONING"- menu for straightforward configuration of the major device functions

5.1.2 Quick Setup Pulsating Flow



a0004431-en

Fig. 6: "QUICK SETUP PULSATING FLOW" menu for operation with severely pulsating flow. Recommended settings are found on the following page.

- ① Only totalizers not yet configured in the current Setup are offered for selection in each cycle.
- ② The "YES" option remains visible until all the totalizers have been configured. "NO" is the only option displayed when no further totalizers are available.
- ③ Only the output not yet configured in the current Setup is offered for selection in the second cycle.
- ④ The "YES" option remains visible until both outputs have been parameterized. "NO" is the only option displayed when no further outputs are available.



Note!

- The display returns to the cell QUICK SETUP PULSATING FLOW (1003) if you press the Q key combination during parameter interrogation.
- You can call up the Setup menu either directly from the "COMMISSIONING" Quick Setup menu or manually by means of the function QUICK SETUP PULSATING FLOW (1003).

Quick Setup "Pulsating Flow"		
HOME position → → MEASURAND → → QUICK SETUP → → QS PULSATING FLOW (1003)		
Function No.	Function name	Selection with To next function with
1003	QS PULS. FLOW	YES After is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.



Basic configuration		
2002	DISPLAY DAMPING	1 s
3002	TOTALIZER MODE (DAA)	BALANCE (Totalizer 1)
3002	TOTALIZER MODE (DAB)	BALANCE (Totalizer 2)
3002	TOTALIZER MODE (DAC)	BALANCE (Totalizer 3)
Signal type for "CURRENT OUTPUT 1"		
4004	MEASURING MODE	PULS. FLOW
4005	TIME CONSTANT	1 s
Signal type for "FREQ./PULSE OUTPUT 1" (for FREQUENCY operating mode)		
4206	MEASURING MODE	PULS. FLOW
4208	TIME CONSTANT	0 s
Signal type for "FREQ./PULSE OUTPUT 1" (for PULSE operating mode)		
4225	MEASURING MODE	PULS. FLOW
Other settings		
8005	ALARM DELAY	0 s
6400	ASSIGN LOW FLOW CUTOFF	MASS FLOW
6402	ON-VALUE LOW FLOW CUT OFF	Setting depends on diameter: DN 2 = 0.10 [kg/h] or [l/h] DN 4 = 0.45 [kg/h] or [l/h] DN 8 = 2.0 [kg/h] or [l/h] DN 15 = 6.5 [kg/h] or [l/h] DN 25 = 18 [kg/h] or [l/h] DN 40 = 45 [kg/h] or [l/h] DN 50 = 70 [kg/h] or [l/h] DN 80 = 180 [kg/h] or [l/h] DN 100 = 350 [kg/h] or [l/h] DN 150 = 650 [kg/h] or [l/h] DN 250 = 1800 [kg/h] or [l/h]
6403	OFF-VALUE LOW FLOW CUTOFF	50%
6404	PRESSURE SHOCK SUPPRESSION	0 s



Back to the HOME position:

→ Press and hold down Esc key for longer than three seconds or

→ Repeatedly press and release Esc key → Exit the function matrix step by step

5.1.3 Quick Setup Gas Measurement




Fig. 7: QUICK SETUP GAS MEASUREMENT menu

A0002502-EN

Quick Setup "Gas measurement"		
HOME position → E → MEASURED VARIABLE (A) MEASURED VARIABLE → + → QUICK SETUP (B) QUICK SETUP → E → QS-GAS MEASUREMENT (1004)		
Function No.	Function name	Setting to be selected (E) (to next function with E)
1004	QS GAS MEASUREMENT	YES After E is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.
▼		
6400	ASSIGN LOW FLOW CUTOFF	On account of the low mass flow involved when gas flows are measured, it is advisable not use a low flow cutoff. Setting: OFF
6402	ON-VALUE LOW FLOW CUT OFF	If the ASSIGNMENT LOW FLOW CUTOFF function was not set to "OFF", the following applies: Setting: 0.0000 [unit] User input: Flow rates for gas measurements are low, so the value for the switch-on point (= low flow cutoff) must be correspondingly low.
6403	OFF-VALUE LOW FLOW CUTOFF	If the ASSIGNMENT LOW FLOW CUTOFF function was not set to "OFF", the following applies: Setting: 50% User input: Enter the switch-off point as a positive hysteresis in %, referenced to the switch-on point.
▼		
Back to the HOME position: → Press and hold down Esc key E for longer than three seconds or → Repeatedly press and release Esc key E → Exit the function matrix step by step		




Note!

Quick Setup automatically deactivates the function EMPTY PIPE DETECTION (6420) so that the instrument can measure flow at low gas pressures.

5.1.4 Quick Setup Communication

To establish serial data transfer, various arrangements between the MODBUS master and MODBUS slave are required which have to be taken into consideration when configuring various functions.

These functions can be configured quickly and easily by means of the "Communication" Quick Setup. The following table explains the parameter configuration options in more detail.



A0004430-en

Settings for the Communication Setup menu:			
Fct. code	Function name	Suggested settings	Description
Call up through the function matrix:			
B	QUICK SETUP	QUICK SETUP COMMUNICATION	see P. 19
1006	QUICK SETUP COMMUNICATION	YES	see P. 19
Basic configuration:		Factory setting:	
6301	FIELD BUS ADDRESS	247	see P. 103
6302	BAUDRATE	19200 BAUD	see P. 103
6303	TRANSMISSION MODE	RTU	see P. 104
6304	PARITY	EVEN	see P. 104
6305	BYTE ORDER	1 - 0 - 3- 2	see P. 104
6306	DELAY TELE. REPLY	10 ms	see P. 105

5.2 Data back-up/transfer

You can use the T-DAT SAVE/LOAD function to transfer data (device parameters and settings) between the T-DAT (removable memory) and the EEPROM (device memory).


This is required for the following applications:

- Creating a backup: current data are transmitted from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

Installing and removing the T-DAT → Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D



a0001221-en

Data storage/transmission with T-DAT SAVE/LOAD

Information on the LOAD and SAVE options available:

LOAD:

Data are transferred from the T-DAT to the EEPROM.



Note!

- Any settings already saved on the EEPROM are deleted.
- This option is only available if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same as, or more recent than, that of the EEPROM. If this is not the case, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE:






Data are transferred from the EEPROM to the T-DAT.



6 Block USER INTERFACE

Block	Groups	Function groups	Functions	
USER INTERFACE (C)	CONTROL (CAA) P. 29 ⇕ ⇕	BASIC CONFIG. (200) P. 29 ⇕ ⇕	LANGUAGE (2000) P. 29 ⇒ CONTRAST LCD (2003) P. 30 ⇒ DISPLAY DAMPING (2002) P. 30 ⇒ BACKLIGHT (2004) P. 30	
		UNLOCKING/LOCKING (202) P. 31 ⇕ ⇕	ACCESS CODE (2020) P. 31 ⇒ DEFINE PRIVATE CODE (2021) P. 31 ⇒ STATUS ACCESS (2022) P. 31 ⇒ ACCESS CODE COUNTER (2023) P. 31	
		OPERATION (204) P. 32 ⇕ ⇕	TEST DISPLAY (2040) P. 32	
		MAIN LINE (CCA) P. 33 ⇕ ⇕	CONFIGURATION (220) P. 33 ⇕ ⇕	ASSIGN (2200) P. 33 ⇒ 100% VALUE (2201) P. 33 ⇒ FORMAT (2202) P. 34
			MULTIPLEX (222) P. 35 ⇕ ⇕	ASSIGN (2220) P. 35 ⇒ 100% VALUE (2221) P. 35 ⇒ FORMAT (2222) P. 36
		ADDITIONAL LINE (CEA) P. 37 ⇕ ⇕	CONFIGURATION (240) P. 37 ⇕ ⇕	ASSIGN (2400) P. 37 ⇒ 100% VALUE (2401) P. 37 ⇒ FORMAT (2402) P. 38 ⇒ DISPLAY MODE (2403) P. 38
			MULTIPLEX (242) P. 39 ⇕ ⇕	ASSIGN (2420) P. 39 ⇒ 100% VALUE (2421) P. 39 ⇒ FORMAT (2422) P. 40 ⇒ DISPLAY MODE (2423) P. 40
		INFORMATION LINE (CGA) P. 41 ⇕ ⇕	CONFIGURATION (260) P. 41 ⇕ ⇕	ASSIGN (2600) P. 41 ⇒ 100% VALUE (2601) P. 41 ⇒ FORMAT (2602) P. 42 ⇒ DISPLAY MODE (2603) P. 42
			MULTIPLEX (262) P. 43 ⇕ ⇕	ASSIGN (2620) P. 43 ⇒ 100% VALUE (2621) P. 43 ⇒ FORMAT (2622) P. 44 ⇒ DISPLAY MODE (2623) P. 44


6.1 Group CONTROL

6.1.1 Function group BASIC CONFIGURATION

USER INTERFACE	C	→	CONTROL	CAA	→	BASIC CONFIGURATION	200
Function description							
USER INTERFACE → CONTROL → BASIC CONFIGURATION							
<p>LANGUAGE 2000</p> <p> (only for NTEP, MC)</p> <p>MODBUS register: 2502</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the language for all texts, parameters and messages shown on the local display.</p> <p> Note! The displayed options depend on the language group available. The language group that is supplied with the measuring device is displayed in the LANGUAGE GROUP (8226) function (see Page 126).</p> <p>Options: (for language group WEST EU / USA)</p> <p>0 = ENGLISH 1 = DEUTSCH 2 = FRANCAIS 3 = ESPANOL 4 = ITALIANO 5 = NEDERLANDS 12 = PORTUGUESE</p> <p>Options: (for language group EAST EU / SCAND)</p> <p>0 = ENGLISH 7 = NORSK 8 = SVENSKA 9 = SUOMI 13 = POLISH 14 = RUSSIAN 15 = CZECH</p> <p>Options: (for language group ASIA)</p> <p>0 = ENGLISH 10 = BAHASA INDONESIA 11 = JAPANESE (syllabary)</p> <p>Options: (for language group CHINA)</p> <p>0 = ENGLISH 16 = CHINESE</p> <p>Factory setting: Depends on country, see Page 129</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If you press the / keys simultaneously at startup, the language defaults to "ENGLISH". ■ You can change the language group via the configuration software ToF Tool - Fieldtool Package. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions. 						


Function description		
USER INTERFACE → CONTROL → BASIC CONFIGURATION		
<p>DISPLAY DAMPING</p> <p>① (only for NTEP, MC)</p> <p>MODBUS register: 2503 Data type: Float Access: read/write</p>	<p>2002</p>	<p>For entering a time constant which defines how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>Input: 0 to 100 seconds</p> <p>Factory setting: 1 s</p> <p> Note! Entering the value "0" (seconds) means that the damping is switched off.</p>
<p>CONTRAST LCD</p> <p>① (only for NTEP, MC)</p> <p>MODBUS register: 2505 Data type: Float Access: read/write</p>	<p>2003</p>	<p>For adjusting the display contrast to suit local operating conditions.</p> <p>Input: 10 to 100%</p> <p>Factory setting: 50%</p>
<p>BACKLIGHT</p> <p>① (only for NTEP, MC)</p> <p>MODBUS register: 2566 Data type: Float Access: read/write</p>	<p>2004</p>	<p>For adjusting the backlight to suit local operating conditions.</p> <p>Input: 0 to 100%</p> <p> Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.</p> <p>Factory setting: 50%</p>

6.1.2 Function group UNLOCKING/LOCKING



		Function description
		USER INTERFACE → CONTROL → UNLOCKING/LOCKING
ACCESS CODE 2020 MODBUS register: 2508 Data type: Float Access: read/write		<p> Note! This function is only relevant for local operation and has no effect on access via MODBUS RS485 communication.</p> <p>All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the or keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).</p> <p>You can enable programming by entering your personal code (factory setting = 84, see function DEFINE PRIVATE CODE (2021)).</p> <p>To set the measuring instrument to access-protection mode, enter the custody code 8400 here. This locks all the functions that are marked with a keyhole symbol ().</p> <p>Input: Max. 4-digit number: 0 to 9999</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Programming is disabled if you do not press a key within 60 seconds following automatic return to the HOME position. ■ You can also disable programming in this function by entering any number (other than the defined private code). ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.
DEFINE PRIVATE CODE 2021 (only for NTEP, MC) MODBUS register: 2510 Data type: Float Access: read/write		<p> Note! This function is only relevant for local operation and has no effect on access via MODBUS RS485 communication.</p> <p>For specifying a personal code for enabling programming in the function ACCESS CODE.</p> <p>Input: 0 to 9999 (max. 4-digit number)</p> <p>Factory setting: 84</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Programming is always enabled with the code "0". ■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS 2022 MODBUS register: 2512 Data type: Integer Access: read		<p>Indicates whether access to the function matrix is currently possible (ACCESS CUSTOMER) or whether configuration is locked (LOCKED).</p> <p>Display: 0 = LOCKED (parameterization disabled) 1 = ACCESS CUSTOMER (parameterization possible)</p>
ACCESS CODE COUNTER 2023 MODBUS register: 2568 Data type: Integer Access: read		<p>Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix.</p> <p>Display: Max. 7-digit number: 0 to 9999999</p> <p>Factory setting: 0</p>


6.1.3 Function group OPERATION







Function description		
USER INTERFACE → CONTROL → OPERATION		
TEST DISPLAY 2040 MODBUS register: 2513 Data type: Integer Access: read/write		For testing the operability of the local display and its pixels. Options: 0 = OFF 1 = ON Factory setting: OFF Test sequence: 1. Start the test by selecting "ON". 2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds. 3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds. 4. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds. 5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 second. When the test is completed, the local display returns to its initial state and the setting changes to "OFF".

6.2 Group MAIN LINE


6.2.1 Function group CONFIGURATION




Function description		
USER INTERFACE → CONTROL → CONFIGURATION		
<p>ASSIGN 2200</p> <p></p> <p>MODBUS register: 2514 Data type: Integer Access: read/write</p>		<p>For assigning a value to be displayed to the main line (top line in the local display). This value is displayed during normal operation.</p> <p>Options: (standard) 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 98 = CUSTODY TRANSFER</p> <p>Factory setting: MASS FLOW</p>
<p>100% VALUE 2201</p> <p></p> <p>MODBUS register: 2519 Data type: Float Access: read/write</p>		<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2200):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → Page 129 ff.</p>

Function description		
USER INTERFACE → CONTROL → CONFIGURATION		
<p>FORMAT</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>2202</p> <p>2516 Integer read/write</p>	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

6.2.2 Function group MULTIPLEX







Function description		
USER INTERFACE → CONTROL → CONFIGURATION		
<p>ASSIGN 2220</p> <p> MODBUS register: 2522 Data type: Integer Access: read/write</p>		<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2200).</p> <p>Options: (standard) 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 98 = CUSTODY TRANSFER</p> <p>Factory setting: OFF</p>
<p>100% VALUE 2221</p> <p> MODBUS register: 2524 Data type: Float Access: read/write</p>		<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2220):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → Page 129 ff.</p>





Function description		
USER INTERFACE → CONTROL → CONFIGURATION		
<p>FORMAT</p> <p>①</p> <p>MODBUS register: Data type: Access:</p>	<p>2222</p> <p>2523 Integer read/write</p>	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

6.3 Group ADDITIONAL LINE


6.3.1 Function group CONFIGURATION







Function description		
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION		
ASSIGN 2400  MODBUS register: 2527 Data type: Integer Access: read/write		For assigning a value to be displayed to the additional line (middle line in the local display). This value is displayed during normal operation. Options: 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 20 = TOTALIZER 2 22 = TOTALIZER 3 98 = CUSTODY TRANSFER 23 = TAG NAME Factory setting: TOTALIZER 1
100% VALUE 2401  MODBUS register: 2529 Data type: Float Access: read/write		 Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % For specifying the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: depends on nominal diameter and country → Page 129 ff.

Function description		
USER INTERFACE → ADDITIONAL LINE → CONFIGURATION		
<p>FORMAT 2402</p> <p>①</p> <p>MODBUS register: 2528 Data type: Integer Access: read/write</p>		<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
<p>DISPLAY MODE 2403</p> <p>①</p> <p>MODBUS register: 2531 Data type: Integer Access: read/write</p>		<p> Note!</p> <p>This function is not available unless one of the following was selected in the ASSIGN function (2400):</p> <ul style="list-style-type: none"> ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY</p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p><i>Fig. 8: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><i>Fig. 9: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

6.3.2 Function group MULTIPLEX







Function description		
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX		
<p>ASSIGN 2420</p> <p> ⓘ</p> <p>MODBUS register: 2532 Data type: Integer Access: read/write</p>	<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2400).</p> <p>Options: 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 98 = CUSTODY TRANSFER 23 = TAG NAME</p> <p>Factory setting: OFF</p>	
<p>100% VALUE 2421</p> <p> ⓘ</p> <p>MODBUS register: 2534 Data type: Float Access: read/write</p>	<p> ⓘ Note! This function is not available unless one of the following was selected in the ASSIGN function (2420):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → Page 129 ff.</p>	





Function description		
USER INTERFACE → ADDITIONAL LINE → MULTIPLEX		
<p>FORMAT 2422</p> <p>①</p> <p>MODBUS register: 2533 Data type: Integer Access: read/write</p>		<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
<p>DISPLAY MODE 2423</p> <p>①</p> <p>MODBUS register: 2536 Data type: Integer Access: read/write</p>		<p> Note!</p> <p>This function is not available unless one of the following was selected in the ASSIGN function (2420):</p> <ul style="list-style-type: none"> ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY</p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p><i>Fig. 10: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><i>Fig. 11: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

6.4 Group INFORMATION LINE


6.4.1 Function group CONFIGURATION







Function description		
USER INTERFACE → INFORMATION LINE → CONFIGURATION		
<p>ASSIGN 2600</p> <p></p> <p>MODBUS register: 2537 Data type: Integer Access: read/write</p>	<p>For assigning a value to be displayed to the information line (bottom line in the local display). This value is displayed during normal operation.</p> <p>Options: 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 22 = TOTALIZER 3 98 = CUSTODY TRANSFER 23 = TAG NAME 24 = OPERATING/SYSTEM CONDITIONS 26 = DISPLAY FLOW DIRECTION</p> <p>Factory setting: OPERATING/SYSTEM CONDITIONS</p>	
<p>100% VALUE 2601</p> <p></p> <p>MODBUS register: 2539 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2600):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → Page 129 ff.</p>	

Function description		
USER INTERFACE → INFORMATION LINE → CONFIGURATION		
<p>FORMAT 2602</p> <p>①</p> <p>MODBUS register: 2538 Data type: Integer Access: read/write</p>		<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
<p>DISPLAY MODE 2603</p> <p>①</p> <p>MODBUS register: 2541 Data type: Integer Access: read/write</p>		<p> Note!</p> <p>This function is not available unless one of the following was selected in the ASSIGN function (2600):</p> <ul style="list-style-type: none"> ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY</p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p><i>Fig. 12: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><i>Fig. 13: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

6.4.2 Function group MULTIPLEX



Function description		
USER INTERFACE → INFORMATION LINE → MULTIPLEX		
<p> Note! If you select the BATCHING OPERATING KEYS in the function ASSIGN (2600), the multiplex display functionality is not available in the information line.</p>		
<p>ASSIGN 2620</p> <p></p> <p>MODBUS register: 2542 Data type: Integer Access: read/write</p>	<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2600).</p> <p>Options: 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 98 = CUSTODY TRANSFER 23 = TAG NAME 24 = OPERATING/SYSTEM CONDITIONS 26 = DISPLAY FLOW DIRECTION</p> <p>Factory setting: OFF</p>	
<p>100% VALUE 2621</p> <p></p> <p>MODBUS register: 2544 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2620):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → Page 129 ff.</p>	


Function description		
USER INTERFACE → INFORMATION LINE → MULTIPLEX		
<p>FORMAT 2622</p> <p>①</p> <p>MODBUS register: 2543 Data type: Integer Access: read/write</p>		<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX</p> <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.
<p>DISPLAY MODE 2623</p> <p>①</p> <p>MODBUS register: 2546 Data type: Integer Access: read/write</p>		<p> Note!</p> <p>This function is not available unless one of the following was selected in the ASSIGN function (2620):</p> <ul style="list-style-type: none"> ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY</p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p><i>Fig. 14: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><i>Fig. 15: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

7 Block TOTALIZER






Block	Groups	Function groups	Functions	
TOTALIZER (D)	TOTALIZER 1 (DAA) P. 46	CONFIGURATION (300) P. 46	UNIT TOTALIZER (3001) P. 46	
		OPERATION (304) P. 48	OVERFLOW (3041) P. 48	
	TOTALIZER 2 (DAB) P. 46	CONFIGURATION (300) P. 46	UNIT TOTALIZER (3001) P. 46	
		OPERATION (304) P. 48	OVERFLOW (3041) P. 48	
	TOTALIZER 3 (DAC) P. 46	CONFIGURATION (300) P. 46	UNIT TOTALIZER (3001) P. 46	
		OPERATION (304) P. 48	OVERFLOW (3041) P. 48	
	HANDLING TOTALIZER (DJA) P. 49	RESET ALL TOTALIZERS (3800) P. 49	FAILSAFE MODE (3801) P. 49	
				RESET TOTALIZER (3003) P. 47
				TOTALIZER MODE (3002) P. 47
				ASSIGN (3000) P. 46
				SUM (3040) P. 48
			OVERFLOW (3041) P. 48	
			UNIT TOTALIZER (3001) P. 46	
			TOTALIZER MODE (3002) P. 47	
			RESET TOTALIZER (3003) P. 47	

7.1 Group TOTALIZER (1 to 3)


7.1.1 Function group CONFIGURATION



Function description		
TOTALIZER → TOTALIZER (1 to 3) → CONFIGURATION		
<p> Note! The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.</p>		
<p>ASSIGN 3000</p> <p></p> <p>MODBUS register:</p> <p>Totalizer 1 2601</p> <p>Totalizer 2 2801</p> <p>Totalizer 3 3001</p> <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For assigning a measured variable to the totalizer in question.</p> <p>Options:</p> <p>0 = OFF</p> <p>1 = MASS FLOW</p> <p>2 = VOLUME FLOW</p> <p>3 = CORRECTED VOLUME FLOW</p> <p>Factory setting:</p> <p>MASS FLOW</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block. ■ The totalizer is reset to "0" as soon as the selection is changed. ■ If you select OFF in the function group CONFIGURATION of the totalizer in question, only the ASSIGN (3000) function remains visible. 	
<p>UNIT TOTALIZER 3001</p> <p></p> <p>MODBUS register:</p> <ul style="list-style-type: none"> ■ Totalizer 1 <ul style="list-style-type: none"> – Mass flow 2602 – Volume flow 2603 – Corr. vol. flow 2604 ■ Totalizer 2 <ul style="list-style-type: none"> – Mass flow 2802 – Volume flow 2803 – Corr. vol. flow 2804 ■ Totalizer 3 <ul style="list-style-type: none"> – Mass flow 3002 – Volume flow 3003 – Corr. vol. flow 3004 <p>Data type: Integer</p> <p>Access: read/write</p>	<p>For selecting the unit for the measured variable assigned in the function ASSIGN (3000).</p> <p>Options: for the MASS FLOW assignment</p> <p>0 to 2 = metric → g; kg; t</p> <p>3 to 4 = US → oz; lb; ton</p> <p>Factory setting: kg</p> <p>Options: for the VOLUME FLOW assignment</p> <p>0 to 6 = metric → cm³; dm³; m³; ml; l; hl; Ml Mega</p> <p>7 to 16 = US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks)</p> <p>22 = Kgal</p> <p>17 to 20 = Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p>Factory setting: m³</p>	
(continued on next page)		


Function description											
TOTALIZER → TOTALIZER (1 to 3) → CONFIGURATION											
<p>UNIT TOTALIZER 3001 (continued)</p>	<p>Options: for the CORRECTED VOLUME FLOW assignment 0 to 1 = metric → Nm³ 2 to 3 = US → Sm³; Scf</p> <p>Factory setting: Nm³</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block. 										
<p>TOTALIZER MODE 3002</p> <p></p> <p>MODBUS register:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Totalizer 1</td> <td style="text-align: right;">2605</td> </tr> <tr> <td>Totalizer 2</td> <td style="text-align: right;">2805</td> </tr> <tr> <td>Totalizer 3</td> <td style="text-align: right;">3005</td> </tr> <tr> <td>Data type:</td> <td style="text-align: right;">Integer</td> </tr> <tr> <td>Access:</td> <td style="text-align: right;">read/write</td> </tr> </table>	Totalizer 1	2605	Totalizer 2	2805	Totalizer 3	3005	Data type:	Integer	Access:	read/write	<p>For selecting how the totalizer should operate.</p> <p>Options: 0 = BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>1 = FORWARD Only positive flow components</p> <p>2 = REVERSE Only negative flow components</p> <p>Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block.
Totalizer 1	2605										
Totalizer 2	2805										
Totalizer 3	3005										
Data type:	Integer										
Access:	read/write										
<p>RESET TOTALIZER 3003</p> <p></p> <p>MODBUS register:</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 30%;">Totalizer 1</td> <td style="text-align: right;">2608</td> </tr> <tr> <td>Totalizer 2</td> <td style="text-align: right;">2808</td> </tr> <tr> <td>Totalizer 3</td> <td style="text-align: right;">3008</td> </tr> <tr> <td>Data type:</td> <td style="text-align: right;">Integer</td> </tr> <tr> <td>Access:</td> <td style="text-align: right;">read/write</td> </tr> </table>	Totalizer 1	2608	Totalizer 2	2808	Totalizer 3	3008	Data type:	Integer	Access:	read/write	<p>Resets the total and the overflow of the totalizer to zero.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block. ■ If the device is equipped with a status input, with the appropriate configuration a reset for each individual totalizer can also be triggered by a pulse (see the function ASSIGN STATUS INPUT (5000) on Page 99).
Totalizer 1	2608										
Totalizer 2	2808										
Totalizer 3	3008										
Data type:	Integer										
Access:	read/write										





7.1.2 Function group OPERATION



Function description		
TOTALIZER → TOTALIZER (1 to 3) → OPERATION		
<p> Note! The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.</p>		
<p>SUM 3040</p> <p>MODBUS register:</p> <p>Totalizer 1 2610</p> <p>Totalizer 2 2810</p> <p>Totalizer 3 3010</p> <p>Data type: Float</p> <p>Access: read</p>	<p>Displays the total for the totalizer's measured variable aggregated since measuring began. The value can be positive or negative, depending on the setting selected in the function "TOTALIZER MODE" (3002), and the direction of flow.</p> <p>Display: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The effect of the setting in the "TOTALIZER MODE" function (see Page 47) is as follows: <ul style="list-style-type: none"> - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. ■ The totalizer's response to faults is defined in the "FAILSAFE MODE" function (3801), (see Page 49). 	
<p>OVERFLOW 3041</p> <p>MODBUS register:</p> <p>Totalizer 1 2612</p> <p>Totalizer 2 2812</p> <p>Totalizer 3 3012</p> <p>Data type: Float</p> <p>Access: read</p>	<p>Displays the total for the totalizer's overflow aggregated since measuring began.</p> <p>Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9,999,999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.</p> <p>Example: Reading for 2 overflows: 2 E7 kg (= 20,000,000 kg). The value displayed in the function SUM = 196,845.7 kg Effective total quantity = 20,196,845.7 kg</p> <p>Display: integer with exponent, including sign and unit, e.g. 2E7 kg</p>	

7.2 Group HANDLING TOTALIZER



Function description		
TOTALIZER → HANDLING TOTALIZER → Handling totalizer functions		
<p>RESET ALL TOTALIZERS</p> <p> MODBUS register: 2609 Data type: Integer Access: read/write</p>	<p>3800</p>	<p>Resets the totals and the overflows of all totalizers to zero.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block. ■ If the device has a status input and if it is appropriately configured, a reset for the totalizer (1 to 3) can also be triggered by a pulse (see the ASSIGN STATUS INPUT function (5000) on Page 99).
<p>FAILSAFE MODE</p> <p> MODBUS register: 2607 Data type: Integer Access: read/write</p>	<p>3801</p>	<p>Use this function to define the common response of all totalizers (1 to 3) to error.</p> <p>Options: 0 = STOP The totalizers are paused until the fault is rectified.</p> <p>1 = ACTUAL VALUE The totalizer continues to count based on the current flow measuring value. The fault is ignored.</p> <p>2 = HOLD VALUE The totalizers continue to count the flow based on the last valid flow value (before the error occurred).</p> <p>Factory setting: STOP</p> <p> Note!</p> <p>This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z006 to Z008 in the CUSTODY TRANSFER block.



8 Block OUTPUTS



Block	Groups	Function groups	Functions																
OUTPUTS (E)	CURRENT OUTPUT (EAA) P. 51	CONFIGURATION (400) P. 51	CURRENT SPAN (4001) P. 52	VALUE 0_4 mA (4002) P. 53	VALUE 20 mA (4003) P. 55	MEASURING MODE (4004) P. 55	TIME CONSTANT (4005) P. 58	FAILSAFE MODE (4006) P. 59											
			OPERATION (404) P. 60	ACTUAL CURRENT (4040) P. 60	SIMULATION CURRENT (4041) P. 60	VALUE SIM. CURRENT (4042) P. 60	END VALUE FREQUENCY (4203) P. 64	START VALUE FREQUENCY (4202) P. 63	ASSIGN FREQUENCY (4201) P. 63	VALUE FLOW (4204) P. 64	VALUE-F-HIGH (4205) P. 65	MEASURING MODE (4206) P. 67	OUTPUT SIGNAL (4207) P. 68	TIME CONSTANT (4208) P. 70	FAILSAFE MODE (4209) P. 71				
	PULSE/FREQ. OUTPUT (ECA) P. 62	CONFIGURATION (420) P. 62	OPERATION (430) P. 83	TERMINAL NUMBER (4080) P. 61	OPERATION MODE (4200) P. 62	FAILSAFE VALUE (4211) P. 71	ASSIGN PULSE (4221) P. 72	PULSE VALUE (4222) P. 72	PULSE WIDTH (4223) P. 73	MEASURING MODE (4225) P. 74	OUTPUT SIGNAL (4226) P. 75	FAILSAFE MODE (4227) P. 77	ASSIGN STATUS (4241) P. 78	ON-VALUE (4242) P. 79	SWITCH-ON DELAY (4243) P. 79	OFF-VALUE (4244) P. 80	SWITCH-OFF DELAY (4245) P. 80	MEASURING MODE (4246) P. 81	TIME CONSTANT (4247) P. 82
				ACTUAL STATUS (4341) P. 87	SIMULATION SWITCH PNT. (4342) P. 87	VALUE SIM. SWITCH PNT. (4343) P. 87	ACTUAL FREQUENCY (4301) P. 83	SIMULATION FREQUENCY (4302) P. 83	VALUE SIM. FREQ. (4303) P. 84	SIMULATION PULSE IMPULS (4322) P. 85	VALUE SIM. IMPULS (4323) P. 86	ACTUAL STATUS (4341) P. 87	VALUE SIM. SWITCH PNT. (4342) P. 87	VALUE SIM. SWITCH PNT. (4343) P. 87	ON-VALUE (4701) P. 90	SWITCH-ON DELAY (4702) P. 90	OFF-VALUE (4703) P. 90	SWITCH-OFF DELAY (4704) P. 91	MEASURING MODE (4705) P. 91
	RELAY 1 to 2 (EGA, EGB) P. 89	CONFIGURATION (470) P. 89	OPERATION (474) P. 93	TERMINAL NUMBER (4380) P. 88	ASSIGN RELAY (4700) P. 89	ACTUAL STATUS RELAY (4741) P. 93	TERMINAL NUMBER (4780) P. 94	OPERATION (478) P. 94	ACTUAL STATUS RELAY (4741) P. 93	TERMINAL NUMBER (4780) P. 94									
				ACTUAL STATUS RELAY (4741) P. 93	TERMINAL NUMBER (4780) P. 94														





8.1 Group CURRENT OUTPUT

8.1.1 Function group CONFIGURATION







OUTPUTS	E	→	CURRENT OUTPUT	EAA	→	CONFIGURATION	400
---------	---	---	----------------	-----	---	---------------	-----

Function description	
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION	
<p>ASSIGN CURRENT OUTPUT 4000</p> <p> MODBUS register: 5801 Data type: Integer Access: read/write</p>	<p>For assigning a measured variable to the current output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE</p> <p>Factory setting: MASS FLOW</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN CURRENT OUTPUT (4000).

Function description																													
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION																													
<p>CURRENT SPAN 4001</p> <p>①</p> <p>MODBUS register: 5802 Data type: Integer Access: read/write</p>	<p>For selecting the current span. The selection specifies the operational range and the lower and upper signal on alarm.</p> <p>Options: 0 = 0–20 mA (25 mA) 1 = 4–20 mA (25 mA) 3 = 0–20 mA 4 = 4–20 mA 6 = 4–20 mA NAMUR 8 = 4–20 mA US</p> <p>Factory setting: 4–20 mA NAMUR or 4–20 mA US</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ When switching the hardware from an active (factory setting) to a passive output signal, select a current span of 4–20 mA (please refer to the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D). <div style="text-align: center;"> </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="text-align: center;">a</th> <th style="text-align: center;">1</th> <th style="text-align: center;">2</th> <th style="text-align: center;">3</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">0-20 mA (25 mA)</td> <td style="text-align: center;">0 - 24 mA</td> <td style="text-align: center;">0</td> <td style="text-align: center;">25</td> </tr> <tr> <td style="text-align: center;">4-20 mA (25 mA)</td> <td style="text-align: center;">4 - 24 mA</td> <td style="text-align: center;">2</td> <td style="text-align: center;">25</td> </tr> <tr> <td style="text-align: center;">0-20 mA</td> <td style="text-align: center;">0 - 20.5 mA</td> <td style="text-align: center;">0</td> <td style="text-align: center;">22</td> </tr> <tr> <td style="text-align: center;">4-20 mA</td> <td style="text-align: center;">4 - 20.5 mA</td> <td style="text-align: center;">2</td> <td style="text-align: center;">22</td> </tr> <tr> <td style="text-align: center;">4-20 mA NAMUR</td> <td style="text-align: center;">3.8 - 20.5 mA</td> <td style="text-align: center;">3.5</td> <td style="text-align: center;">22.6</td> </tr> <tr> <td style="text-align: center;">4-20 mA US</td> <td style="text-align: center;">3.9 - 20.8 mA</td> <td style="text-align: center;">3.75</td> <td style="text-align: center;">22.6</td> </tr> </tbody> </table> <p style="text-align: right; font-size: small;">A0002959</p> <p><i>Fig. 16: Overview of current span, operational range and signal on alarm level</i></p> <p>a Current span 1 Operational range (measuring information) 2 Lower signal on alarm level 3 Upper signal on alarm level</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If the measured value exceeds the measuring range (as defined in the functions VALUE 0_4 mA (4002) and VALUE 20 mA (4003)) a notice message is generated (#351 to 354, current span). ■ In case of a fault the behavior of the current output is according to the selected option in the function FAILSAFE MODE (4006). 	a	1	2	3	0-20 mA (25 mA)	0 - 24 mA	0	25	4-20 mA (25 mA)	4 - 24 mA	2	25	0-20 mA	0 - 20.5 mA	0	22	4-20 mA	4 - 20.5 mA	2	22	4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA US	3.9 - 20.8 mA	3.75	22.6
a	1	2	3																										
0-20 mA (25 mA)	0 - 24 mA	0	25																										
4-20 mA (25 mA)	4 - 24 mA	2	25																										
0-20 mA	0 - 20.5 mA	0	22																										
4-20 mA	4 - 20.5 mA	2	22																										
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6																										
4-20 mA US	3.9 - 20.8 mA	3.75	22.6																										

Function description		
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION		
<p>VALUE 0_4 mA 4002</p> <p>①</p> <p>MODBUS register: 5803 Data type: Float Access: read/write</p>	<p>Use this function to assign the 0/4 mA current a value. The value can be higher or lower than the value assigned to 20 (function VALUE 20 mA (4003), see Page 55). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow).</p> <p>Example: 4 mA assigned value = - 250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ Note that values with different signs cannot be entered for 0/4 mA and 20 mA if SYMMETRY is the setting selected for the MEASURING MODE function (4004). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. <p>Example for STANDARD measuring mode:</p>	 <p style="text-align: right; font-size: small;">A0001223</p> <p>① = Lower range-value (0 to 20 mA) ② = Lower signal on alarm level: depends on the setting in the function CURRENT SPAN ③ = Lower range-value (4 to 20 mA): depends on the setting in the function CURRENT SPAN ④ = Full scale value (0/4 to 20 mA): depends on the setting in the function CURRENT SPAN ⑤ = Maximum current value: depends on the setting in the function CURRENT SPAN ⑥ = Failsafe mode (upper signal on alarm level): depends on the setting in the functions CURRENT SPAN (see Page 52) and FAILSAFE MODE (see Page 59) A = Measuring range</p> <p>User input: 5-digit floating-point number, with sign</p> <p>Factory setting: 0 [kg/h] or 0.5 [kg/l] or -50 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the following functions: <ul style="list-style-type: none"> – UNIT MASS FLOW (0400) – UNIT VOLUME FLOW (0402) – UNIT CORRECTED VOLUME FLOW (0404) – UNIT DENSITY (0420) – UNIT REFERENCE DENSITY (0421) – UNIT TEMPERATURE (0422) (see Page 14 to Page 18). <p> Caution! The current output responds differently, depending on the parameters set in the various functions. Some examples of parameter settings and their effect on the current output are given in the following section.</p> <p>(continued on next page)</p>




Function description	
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION	
<p>VALUE 0_4 mA 4002 (continued)</p>	<p>Parameter setting example A:</p> <ol style="list-style-type: none"> VALUE 0_4 mA (4002) = not equal to zero flow (e.g. -5 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4002) = not equal to zero flow (e.g. -40 kg/h) <p>and MEASURING MODE (4004) = STANDARD</p> <p>When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (see Fig. ①), a fault/notice message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006).</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1)</p> </div> <div style="text-align: center;"> <p>2)</p> </div> </div> <p style="text-align: right; font-size: small;">A0001262</p> <p>Parameter setting example B:</p> <ol style="list-style-type: none"> VALUE 0_4 mA (4002) = equal to zero flow (e.g. 0 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4003) = equal to zero flow (e.g. 0 kg/h) <p>and MEASURING MODE (4004) = STANDARD</p> <p>When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. In doing so, one of the two values is parameterized as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value parameterized as the zero flow, no fault/notice message is generated and the current output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006).</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1)</p> </div> <div style="text-align: center;"> <p>2)</p> </div> </div> <p style="text-align: right; font-size: small;">A0001264</p> <p>Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed.</p> <p>Parameter setting example C: MEASURING MODE (4004) = SYMMETRY</p> <p>The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA value ① and the 20 mA value ② must have the same sign (+ or -). The 20 mA VALUE ③ (e.g. backflow) corresponds to the mirrored 20 mA VALUE ② (e.g. flow).</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001249</p> <p>ASSIGN STATUS (4241) = FLOW DIRECTION</p> <p>With this setting e.g. the flow direction output via a switching contact can be made.</p> <p>Parameter setting example D: MEASURING MODE (4004) = PULSATING FLOW → Page 55 ff.</p>



Function description		
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION		
<p>VALUE 20 mA 4003</p> <p> MODBUS register: 5805 Data type: Float Access: read/write</p>		<p>Use this function to assign the 20 mA current a value. The value can be higher or lower than the value assigned to 0/4 (function VALUE 0_4 mA (4002), see Page 53). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow).</p> <p>Example: 4 mA assigned value = -250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)</p> <p>Note that values with different signs cannot be entered for 0/4 mA and 20 mA if SYMMETRY is the setting selected for the MEASURING MODE function (4004). In this case, the message "INPUT RANGE EXCEEDED" appears on the display.</p> <p>User input: 5-digit floating-point number, with sign</p> <p>Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> - The measuring device has been configured in accordance with NTEP or MC approval. - The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ The appropriate unit is taken from the following functions: <ul style="list-style-type: none"> - UNIT MASS FLOW(0400) - UNIT VOLUME FLOW(0402) - UNIT CORRECTED VOLUME FLOW(0404) - UNIT DENSITY(0420) - UNIT REFERENCE DENSITY(0421) - UNIT TEMPERATURE(0422) (see Page 14 to Page 18). ■ The appropriate unit is taken from the function UNIT MASS FLOW (0400), (see Page 14). ■ An example for selecting the STANDARD option in the function MEASURING MODE (4004) can be found on Page 56. <p> Caution! It is very important to read and comply with the information in the function VALUE 0_4 mA (under  "Caution", examples of parameter settings) on Page 53.</p>
<p>MEASURING MODE 4004</p> <p> MODBUS register: 5807 Data type: Integer Access: read/write</p>		<p>For selecting the measuring mode for the current output.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY 2 = PULSATING FLOW</p> <p>Factory setting: STANDARD</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. <p>(continued on next page)</p>

Function description	
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION	
<p>MEASURING MODE (continued)</p>	<p>4004</p> <p>Description of the individual options: STANDARD</p> <p>The current output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the 0_4 mA VALUE ① and the 20 mA VALUE ②) are taken into account as follows for signal output.</p> <ul style="list-style-type: none"> ■ If one of the values is defined as equal to the zero flow (e.g. VALUE 0_4 mA = 0 m³/h), no message is given if this value is exceeded or not achieved and the current output retains its value (in example 4 mA). If the other value is exceeded or not achieved, the message "CURRENT OUTPUT AT FULL SCALE VALUE" appears and the current output responds in accordance with the parameter setting in the function FAILSAFE MODE (4006). ■ If both values defined are not equal to the zero flow (for example VALUE 0_4 mA = -5 m³/h, VALUE 20 mA = 10m³/h), the message "CURRENT OUTPUT AT FULL SCALE VALUE" appears if the measuring range is exceeded or not achieved and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001248</p> <p><i>Fig. 17: Example for STANDARD measuring mode</i></p> <p>SYMMETRY</p> <p>The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA value ① and the 20 mA value ② must have the same sign (+ or -). The "20 mA value" ③ (e.g. backflow) corresponds to the mirrored 20 mA value ② (e.g. flow).</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001249</p> <p><i>Fig. 18: Example for SYMMETRY measuring mode</i></p> <p> Note!</p> <ul style="list-style-type: none"> ■ The direction of flow can be output via the configurable relay or status outputs. ■ SYMMETRY cannot be selected unless the values in the VALUE 0_4 mA (4002) and VALUE 20 mA (4003) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed. <p>PULSATING FLOW</p> <p>If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears. Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the current output.</p>


Function description	
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION	
Detailed explanations and information	<p>How the current output responds under the following postulated conditions:</p> <p>1. Defined measuring range (①–②): ① and ② have the same sign</p> <div style="text-align: center;"> </div> <p>and the following flow behavior:</p> <div style="text-align: center;"> </div> <p>■ STANDARD The current output signal is proportional to the measured variable. The flow components outside the scaled measuring range are not taken into account for signal output.</p> <div style="text-align: center;"> </div> <p>■ SYMMETRY The current output signal is independent of the direction of flow.</p> <div style="text-align: center;"> </div> <p>■ PULSATING FLOW Flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds.</p> <div style="text-align: center;"> </div> <p>2. Defined measuring range (①–②): ① and ② do not have the same sign.</p> <div style="text-align: center;"> </div> <p>Flow a (—) outside, b (---) within the measuring range.</p> <div style="text-align: center;"> </div>
	A0001248
	A0001265
	A0001267
	A0001268
	A0001269
	A0001272
	A0001273







(continued on next page)

Function description	
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION	
<p>Detailed explanations and information (continued)</p>	<ul style="list-style-type: none"> <p>■ STANDARD</p> <p>a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output. A fault message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006).</p> <p>b (- -): The current output signal is proportional to the measured variable assigned.</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001274</p> <p>■ SYMMETRY</p> <p>This option is not available under these circumstances because the 0_4 mA value and the 20 mA value have different signs.</p> <p>■ PULSATING FLOW</p> <p>Flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds.</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001275</p>
<p>TIME CONSTANT 4005</p> <p>①</p> <p>MODBUS register: 5808 Data type: Float Access: read/write</p>	<p>Entering a time constant defines how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: fixed-point number 0.01 to 100.00 s</p> <p>Factory setting: 1.00 s</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block.


Function description		
OUTPUTS → CURRENT OUTPUT 1 → CONFIGURATION		
<p>FAILSAFE MODE 4006</p> <p> MODBUS register: 5810 Data type: Integer Access: read/write</p>		<p>For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options: 0 = MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN (4001), see Page 52).</p> <p>1 = MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN (4001), see Page 52).</p> <p>2 = HOLD VALUE (not recommended) Measured value output is based on the last measured value saved before the error occurred.</p> <p>3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>Factory setting: MIN. CURRENT</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMi, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block.

8.1.2 Function group OPERATION



Function description	
OUTPUTS → CURRENT OUTPUT → OPERATION	
<p>ACTUAL CURRENT 4040</p> <p>MODBUS register: 5811 Data type: Float Access: read</p>	<p>Use this function to view the computed actual value of the output current.</p> <p>Display: 0.00 to 25.00 mA</p>
<p>SIMULATION CURRENT 4041</p> <p> MODBUS register: 5813 Data type: Integer Access: read/write</p>	<p>Activates simulation of the current output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ If simulation is active, the "SIMULATION CURRENT OUTPUT" message is displayed. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. <p> Caution! The setting is not saved in the event of a power failure.</p>
<p>VALUE SIMULATION CURRENT 4042</p> <p> MODBUS register: 5814 Data type: Float Access: read/write</p>	<p>Use this function to define a freely selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself.</p> <p>User input: 0.00 to 25.00 mA</p> <p>Factory setting: 0.00 mA</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z003 in the CUSTODY TRANSFER block. ■ This function is displayed only if the function SIMULATION CURR. (4041) is active (= ON). <p> Caution! The setting is not saved in the event of a power failure.</p>


8.1.3 Function group INFORMATION





Function description		
OUTPUTS → CURRENT OUTPUT → INFORMATION		
TERMINAL NUMBER MODBUS register: Data type: Access:	4080 5816 Integer read	Displays the: <ul style="list-style-type: none"> ■ Numbers of the terminals used by the current output (in the connection compartment) ■ Polarity Display: 3 = 20 (+) / 21 (-)



8.2 Group PULSE/FREQUENCY OUTPUT 1

8.2.1 Function group CONFIGURATION







Function description	
OUTPUTS→PULSE/FREQUENCY OUTPUT 1→CONFIGURATION	
<p>OPERATION MODE 4200</p> <p>①</p> <p>MODBUS register: 3201 Data type: Integer Access: read/write</p>	<p>Configuration of the output as a pulse, frequency or status output.</p> <p>The functions available in this function group vary, depending on which option you select here.</p> <p>Options: 0 = PULSE 1 = FREQUENCY 2 = STATUS</p> <p>Factory setting: PULSE</p>




Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)		
<p>ASSIGN FREQUENCY</p> <p>①</p> <p>MODBUS register: 3202 Data type: Integer Access: read/write</p>	<p>4201</p>	<p>For assigning a measured variable to the frequency output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE</p> <p>Factory setting: MASS FLOW</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ If you select OFF, the only function shown in the CONFIGURATION function group is ASSIGN FREQUENCY (4201).
<p>START VALUE FREQUENCY</p> <p>①</p> <p>MODBUS register: 3203 Data type: Float Access: read/write</p>	<p>4202</p>	<p>For defining an initial frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE f LOW (4204).</p> <p>User input: 5-digit fixed-point number: 0 to 10000 Hz</p> <p>Factory setting: 0 Hz</p> <p>Example:</p> <ul style="list-style-type: none"> ■ VALUE f LOW = 0 kg/h, start value frequency = 0 Hz This means that at a flow rate of 0 kg/h, a frequency of 0 Hz is output. ■ VALUE f LOW = 1 kg/h, start value frequency = 10 Hz This means that at a flow rate of 1 kg/h, a frequency of 10 Hz is output. <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).





Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)		
<p>END VALUE FREQUENCY 4203</p> <p>①</p> <p>MODBUS register: 3205 Data type: Float Access: read/write</p>	<p>For defining a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH (4205).</p> <p>User input: 5-digit fixed-point number: 2 to 10000 Hz</p> <p>Factory setting: 10000 Hz</p> <p>Example:</p> <ul style="list-style-type: none"> ■ VALUE f HIGH = 10000 kg/h, full scale value = 10000 Hz This means that at a flow rate of 10000 kg/h, a frequency of 10000 Hz is output. ■ VALUE f HIGH = 3600 kg/h, full scale value = 10000 Hz This means that at a flow rate of 3600 kg/h, a frequency of 10000 Hz is output. <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical. 	
<p>VALUE f LOW 4204</p> <p>①</p> <p>MODBUS register: 3207 Data type: Float Access: read/write</p>	<p>Use this function to assign a variable to the START VALUE FREQUENCY(4202). The value can be higher or lower than the value assigned to the VALUE f HIGH. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE f LOW and VALUE f HIGH values.</p> <p>Input: 5-digit floating-point number</p> <p>Factory setting: 0 [kg/h] or 0 [kg/l] or –50 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ For a graphic illustration of the VALUE F LOW, see the VALUE-f HIGH (4205) function. ■ Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. ■ The appropriate unit is taken from the following functions: <ul style="list-style-type: none"> – UNIT MASS FLOW(0400) – UNIT VOLUME FLOW(0402) – UNIT CORRECTED VOLUME FLOW(0404) – UNIT DENSITY(0420) – UNIT REFERENCE DENSITY(0421) – UNIT TEMPERATURE(0422) (see Page 14 to Page 18). 	





Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>VALUE-f HIGH 4205</p> <p>①</p> <p>MODBUS register: 3209 Data type: Float Access: read/write</p>	<p>Use this function to assign a variable to the END VALUE FREQUENCY (4203). The value can be higher or lower than the value assigned to the VALUE F LOW. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE f LOW and VALUE f HIGH values.</p> <p>Input: 5-digit floating-point number</p> <p>Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. <div style="text-align: center;"> </div> <p style="text-align: right;">A0001279</p> <p>① = Value f low ② = Value f high</p> <p>Parameter setting example 1:</p> <ol style="list-style-type: none"> 1. VALUE f LOW (4204) = not equal to zero flow (e.g. -5 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE f LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. -40 kg/h) <p>and MEASURING MODE (4206) = STANDARD</p> <p>When you enter the values for VALUE f LOW and VALUE f HIGH the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (see Fig. ①), a fault/notice message is generated (#355 to 358, frequency range) and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209).</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1)</p> </div> <div style="text-align: center;"> <p>2)</p> </div> </div> <p style="text-align: right;">A0001262</p> <p>(continued on next page)</p>






Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>VALUE-f HIGH 4205 (continued)</p>	<p>Parameter setting example 2:</p> <ol style="list-style-type: none"> VALUE f LOW (4204) = not equal to zero flow (e.g. 0 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or VALUE f LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 0 kg/h) <p>and MEASURING MODE (4206) = STANDARD</p> <p>When you enter the values for VALUE f LOW and VALUE f HIGH the working range of the measuring device is defined. In doing so, one of the two values is parameterized as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value parameterized as the zero flow, no fault/notice message is generated and the frequency output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#355 to 358, frequency range) and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209).</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1)</p> </div> <div style="text-align: center;"> <p>2)</p> </div> </div> <p style="text-align: right; font-size: small;">A0001264</p> <p>Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed.</p> <p>Parameter setting example 3: MEASURING MODE (4206) = SYMMETRY</p> <p>The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE f LOW ① and VALUE f HIGH ② must have the same sign (+ or -). The VALUE f HIGH ③ (e.g. backflow) corresponds to the mirrored VALUE f HIGH ② (e.g. flow).</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001249</p> <p>ASSIGN STATUS (4241) = FLOW DIRECTION</p> <p>With this setting e.g. the flow direction output via a switching contact can be made.</p> <p>Parameter setting example 4: MEASURING MODE (4206) = PULSATING FLOW → Page 67 ff.</p>



Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>MEASURING MODE 4206</p> <p>ⓘ</p> <p>MODBUS register: 3211 Data type: Integer Access: read/write</p>	<p> Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).</p> <p>Use this function to define the measuring mode for the frequency output.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY 2 = PULSATING FLOW</p> <p>Factory setting: STANDARD</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for the available functions Z001 in the CUSTODY TRANSFER block. <p>Description of the individual options:</p> <p>STANDARD The frequency output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the VALUE f LOW ① and the VALUE f HIGH ②) are not taken into account for signal output.</p> <ul style="list-style-type: none"> ■ If one of the values is defined as equal to the zero flow (e.g. VALUE f LOW = 0 m³/h), no message is given if this value is exceeded or not achieved and the frequency output retains its value (0 Hz in the example). If the other value is exceeded or not achieved, the message "FREQUENCY OUTPUT AT FULL SCALE VALUE" appears and the frequency output responds in accordance with the parameter setting in the function FAILSAFE MODE (4209). ■ If both values defined are not equal to the zero flow (for example VALUE f LOW = -5 m³/h; VALUE F HIGH = 10m³/h), the message "FREQUENCY OUTPUT AT FULL SCALE VALUE" appears if the measuring range is exceeded or not achieved and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209). <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001279</p> <p><i>Fig. 19: STANDARD measuring mode</i></p> <p>SYMMETRY The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE f LOW ① and VALUE f HIGH ② must have the same sign (+ or -). The VALUE F HIGH ③ (e.g. backflow) corresponds to the mirrored VALUE F HIGH ② (e.g. flow).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001280</p> <p><i>Fig. 20: SYMMETRY measuring mode</i></p> <p>(continued on next page)</p>





Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>MEASURING MODE 4206 (continued)</p>	<p> Note!</p> <ul style="list-style-type: none"> ■ The direction of flow can be output via the configurable relay or status outputs. ■ SYMMETRY cannot be selected unless the values in the VALUE f LOW (4204) and VALUE-f HIGH (4205) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed. <p>PULSATING FLOW</p> <ul style="list-style-type: none"> ■ If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears. ■ Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the frequency output.
<p>OUTPUT SIGNAL 4207  MODBUS register: 3212 Data type: Integer Access: read/write</p>	<p>For selecting the output configuration of the frequency output.</p> <p>Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE (this selection is not supported) 3 = ACTIVE - NEGATIVE (this selection is not supported)</p> <p>Factory setting: PASSIVE - POSITIVE</p> <p>Explanation PASSIVE = power is supplied to the frequency output by means of an external power supply.</p> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the frequency output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> ■ If POSITIVE is selected, the internal transistor is activated with a positive signal level. ■ If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (see examples). <p>(continued on next page)</p>



Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>OUTPUT SIGNAL 4207 (continued)</p>	<p>Example for passive output circuit (PASSIVE) If PASSIVE is selected, the frequency output is configured as an open collector.</p>  <p>① = Open collector ② = External power supply ③ = Line monitoring off ④ = Line monitoring on (default)</p> <p>Note! For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).</p> <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p>  <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level</p>  <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p>  <p>① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>(continued on next page)</p>


Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)	
<p>OUTPUT SIGNAL 4207 (continued)</p>	<p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p style="text-align: right;">A0001981</p> <p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p>  <p style="text-align: right;">a0004690</p> <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in <i>NEGATIVE</i> quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p style="text-align: right;">A0001981</p>
<p>TIME CONSTANT 4208</p> <p>①</p> <p>MODBUS register: 3213 Data type: Float Access: read/write</p>	<p>Entering a time constant defines how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: fixed-point number 0.00 to 100.00 s</p> <p>Factory setting: 0.00 s</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMi, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (FREQUENCY)		
<p>FAILSAFE MODE 4209</p> <p> MODBUS register: 3215 Data type: Integer Access: read/write</p>		<p>For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options: 0 = FALLBACK VALUE Output is 0 Hz.</p> <p>1 = FAILSAFE LEVEL Output is the frequency specified in the FAILSAFE LEVEL function (4211).</p> <p>2 = HOLD VALUE Measured value output is based on the last measured value saved before the error occurred.</p> <p>3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>Factory setting: FALLBACK VALUE</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).
<p>FAILSAFE LEVEL 4211</p> <p> MODBUS register: 3216 Data type: Float Access: read/write</p>		<p> Note!</p> <p>This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and FAILSAFE LEVEL was selected in the FAILSAFE MODE function (4209).</p> <p>For specifying the frequency that the measuring device outputs in the event of an error.</p> <p>User input: max. 5-digit number: 0 to 12500 Hz</p> <p>Factory setting: 12500 Hz</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and FAILSAFE LEVEL was selected in the FAILSAFE MODE function (4209).

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)		
<p>ASSIGN PULSE 4221</p> <p>①</p> <p>MODBUS register: 3223 Data type: Integer Access: read/write</p>	<p>Use this function to assign a measured variable to the pulse output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW</p> <p>Factory setting: MASS FLOW</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ■ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN PULSE (4221). 	
<p>PULSE VALUE 4222</p> <p>①</p> <p>MODBUS register: 3224 Data type: Float Access: read/write</p>	<p>Use this function to define the flow at which a pulse is triggered. These pulses can be totaled by an external totalizer, and the total flow quantity since measuring started can be registered in this way.</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: Depends on nominal diameter</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ■ The appropriate unit is taken from the UNIT MASS FLOW (0400), UNIT VOLUME FLOW (0402) or UNIT CORRECTED VOLUME FLOW (0404) function (see Page 14 to Page 18). 	


Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)	
<p>PULSE WIDTH 4223</p> <p>MODBUS register: 3226 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).</p> <p>Use this function to enter the pulse width of the output pulse.</p> <p>User input: 0.05 to 2000 ms</p> <p>Factory setting: 100 ms</p> <p>Pulse output is always with the pulse width (B) entered in this function. The pauses (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width (B = P).</p>  <p style="text-align: right; font-size: small;">A0001233</p> <p><i>Fig. 21: Pulse width</i> B = Pulse width entered (the illustration applies to positive pulses) P = Pauses between the individual pulses</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ■ When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC, etc.). <p> Caution! If the pulse number or frequency resulting from the pulse value entered (see function PULSE VALUE (4222) on Page 72) and from the current flow is too large to maintain the pulse width selected (the time interval is smaller than the pulse width B entered), a system error message is generated (#359 to 362, pulse buffer) after approx. 5 seconds buffer/balance time.</p>





Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)		
<p>MEASURING MODE</p> <p>①</p> <p>MODBUS register: 3228 Data type: Integer Access: read/write</p>	<p>4225</p>	<p>Use this function to define the measuring mode for the pulse output.</p> <p>Options: 0 = STANDARD Only positive flow components are totaled. Negative components are not taken into account.</p> <p>1 = SYMMETRY Positive and negative flow components are taken into account.</p> <p> Note! The direction of flow can be output via the relay output.</p> <p>2 = PULSATING FLOW If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, the positive and negative flow components are totaled, with the signs taken into account (e.g. -10 l and +25 l = 15 l).</p> <p>Flow components outside the maximum pulse number per second (value/width) are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears.</p> <p>Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the pulse output.</p> <p>3 = STANDARD REVERSE Only negative flow components are totaled. Positive components are not taken into account.</p> <p>Factory setting: STANDARD</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).





Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)	
<p>OUTPUT SIGNAL 4226</p> <p>①</p> <p>MODBUS register: 3229 Data type: Integer Access: read/write</p>	<p>For selecting the output configuration of the pulse output.</p> <p>Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE (this selection is not supported) 3 = ACTIVE - NEGATIVE (this selection is not supported)</p> <p>Factory setting: PASSIVE - POSITIVE</p> <p>Explanation PASSIVE = power is supplied to the pulse output by means of an external power supply.</p> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the pulse output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> ■ If POSITIVE is selected, the internal transistor is activated with a positive signal level. ■ If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). <p>✎ Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ■ With the passive output configuration, the output signal levels of the pulse output depend on the external circuit (see examples). <p>Example for passive output circuit (PASSIVE) If PASSIVE is selected, the pulse output is configured as an open collector.</p>  <p style="text-align: right;">A0002147</p> <p>① = Open collector ② = External power supply ③ = Line monitoring off ④ = Line monitoring on (default)</p> <p>✎ Note! For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).</p> <p>(continued on next page)</p>

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)	
<p>OUTPUT SIGNAL 4226 (continued)</p>	<p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V. $+ U_{max} = 30 \text{ V DC}$</p> <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.</p> <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance. $+ U_{max} = 30 \text{ V DC}$</p> <p>① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <p>(continued on next page)</p>

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (PULSE)	
<p>OUTPUT SIGNAL 4226 (continued)</p>	<p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">a0004690</p> <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in <i>NEGATIVE</i> quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001981</p>
<p>FAILSAFE MODE 4227</p> <p>ⓘ</p> <p>MODBUS register: 3230 Data type: Integer Access: read/write</p>	<p>For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options: 0 = FALLBACK VALUE Output is 0 pulse.</p> <p>3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>4 = MAX. PULSE RATE Outputs the maximum pulse rate $f = 1/(2 \times T)$</p> <p>Factory setting: FALLBACK VALUE</p> <p>✎ Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMi, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).


Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (STATUS)		
<p>ASSIGN STATUS 4241</p> <p>①</p> <p>MODBUS register: 3236 Data type: Integer Access: read/write</p>	<p>Use this function to assign a switching function to the status output.</p> <p>Options:</p> <p>0 = OFF 1 = ON (operation) 2 = FAULT MESSAGE 3 = NOTICE MESSAGE 4 = FAULT MESSAGE or NOTICE MESSAGE 5 = EMPTY PIPE DETECTION (only with active function) 6 = FLOW DIRECTION 7 = MASS FLOW LIMIT VALUE 8 = VOLUME FLOW LIMIT VALUE 14 = CORRECTED VOLUME FLOW LIMIT VALUE 15 = DENSITY LIMIT VALUE 16 = REFERENCE DENSITY LIMIT VALUE 17 = TEMPERATURE LIMIT VALUE 19 = TOTALIZER 1 LIMIT VALUE 20 = TOTALIZER 2 LIMIT VALUE 21 = TOTALIZER 3 LIMIT VALUE</p> <p>Factory setting: FAULT MESSAGE</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is available only if the STATUS setting was selected in the OPERATION MODE (4200) function. ■ The behavior of the status output is a normally closed behavior, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress. <ul style="list-style-type: none"> – "Normal, error-free" operation: Flow direction = forwards; limit values = not exceeded; no fault or notice message present. – Switching response like relay output, see Page 96 ■ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN STATUS (4241). ■ Switching response like relay output, see Page 96. 	

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (STATUS)		
<p>ON-VALUE 4242</p> <p> MODBUS register: 3237 Data type: Float Access: read/write</p>		<p>Use this function to assign a value to the switch-on point (activation of the status output). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241). ■ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears. ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.
<p>SWITCH-ON DELAY 4243</p> <p> MODBUS register: 3239 Data type: Float Access: read/write</p>		<p>Use this function to define a delay (0 to 100 seconds) for the switch-on (i.e. signal changes from "not conductive" to "conductive") of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch on condition has been valid over the delay time.</p> <p>User input: fixed-point number: 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241).


		Function description
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (STATUS)		
OFF-VALUE 4244  MODBUS register: 3241 Data type: Float Access: read/write		<p>Use this function to assign a value to the switch-off point (deactivation of the status output). The value can be higher or lower than the switch-on point. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE was selected in the ASSIGN STATUS function (4241). ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.
SWITCH-OFF DELAY 4245  MODBUS register: 3243 Data type: Float Access: read/write		<p>Use this function to define a delay (0 to 100 seconds) for the switch-off (i.e. signal changes from "conductive" to "not conductive") of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch off condition has been valid over the delay time.</p> <p>User input: fixed-point number: 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200).





Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (STATUS)		
<p>MEASURING MODE</p> <p>ⓘ</p> <p>MODBUS register: 3245 Data type: Integer Access: read/write</p>	<p>4246</p>	<p>Use this function to define the measuring mode for the status output.</p> <p>Options: 0 = STANDARD The status output signal switches at the defined switch points.</p> <p>1 = SYMMETRY The status output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (see illustration).</p> <p>Factory setting: STANDARD</p> <div style="text-align: center;"> </div> <p><i>Fig. 22: Example for the SYMMETRY measuring mode</i> Switch-on point $Q = 4$ Switch-off point $Q = 10$ ① = Status output switched on (conductive) ② = Status output switched off (nonconductive)</p> <p>Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and the status output was assigned a limit value. ■ SYMMETRY cannot be selected unless the values in the ON-VALUE (4242) and OFF-VALUE (4244) functions have the same sign or one of the values is zero. ■ If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed.



A0001247







Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → CONFIGURATION (STATUS)	
<p>TIME CONSTANT 4247</p> <p>①</p> <p>MODBUS register: 3246 Data type: Float Access: read/write</p>	<p>Entering a time constant defines how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow.</p> <p>User input: fixed-point number 0.00 to 100.00 s</p> <p>Factory setting: 0.00 s</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200).








8.2.2 Function group OPERATION




Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → OPERATION (FREQUENCY)		
<p>ACTUAL FREQUENCY 4301</p> <p>MODBUS register: 3218 Data type: Float Access: read</p>	<p>Use this function to view the computed actual value of the output frequency.</p> <p>Display: 0 to 12500 Hz</p> <p> Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).</p>	
<p>SIMULATION FREQUENCY 4302</p> <p></p> <p>MODBUS register: 3220 Data type: Integer Access: read/write</p>	<p>Activates simulation of the frequency output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ■ The "SIMULATION FREQUENCY OUTPUT" message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. <p> Caution! The setting is not saved in the event of a power failure.</p>	

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → OPERATION (FREQUENCY)		
<p>VALUE 4303</p> <p>SIMULATION</p> <p>FREQUENCY</p> <p>①</p> <p>MODBUS register: 3221</p> <p>Data type: Float</p> <p>Access: read/write</p>		<p>Define a selectable frequency value (e.g. 500 Hz) which should be output at the frequency output (with maximum pulse frequency or shortened minimum pulse width). This value is used to test downstream devices and the measuring device itself.</p> <p>User input: 0 to 12500 Hz</p> <p>Factory setting: 0 Hz</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and the SIMULATION FREQUENCY function (4302) is active (= ON). <p> Caution! The setting is not saved in the event of a power failure.</p>

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → OPERATION (PULSE)		
<p>SIMULATION PULSE</p> <p> MODBUS register: 3233 Data type: Integer Access: read/write</p>	<p>4322</p>	<p>Activates simulation of the pulse output.</p> <p>Options: 0 = OFF</p> <p>1 = COUNTDOWN The pulses specified in the VALUE SIMULATION PULSE function are output.</p> <p>2 = CONTINUOUSLY Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the  key.</p> <p> Note! Simulation is started by confirming the CONTINUOUSLY option with the  key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p>Factory setting: OFF</p> <p> Note!</p> <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is available only if the PULSE setting was selected in the OPERATION MODE (4200) function. ■ The notice message #631 "SIM. PULSE" indicates that simulation is active. ■ The on/off ratio is 1:1 for both types of simulation. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. <p> Caution! The setting is not saved in the event of a power failure.</p>

Function description		
OUTPUTS → PULSE/FREQUENCY OUTPUT 1 → OPERATION (STATUS)		
<p>ACTUAL STATUS 4341</p> <p>MODBUS register: 3248 Data type: Integer Access: read</p>		<p>Use this function to check the current status of the status output.</p> <p>Display: 0 = NOT CONDUCTIVE 1 = CONDUCTIVE</p> <p> Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200).</p>
<p>SIMULATION SWITCH POINT 4342</p> <p></p> <p>MODBUS register: 3249 Data type: Integer Access: read/write</p>		<p>Use this function to activate simulation of the status output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note! <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is available only if the STATUS setting was selected in the OPERATION MODE (4200) function. ■ The "SIMULATION STATUS OUTPUT" message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. </p> <p> Caution! The setting is not saved in the event of a power failure.</p>
<p>VALUE SIMULATION SWITCH POINT 4343</p> <p></p> <p>MODBUS register: 3250 Data type: Integer Access: read/write</p>		<p>Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself.</p> <p>Options: 0 = NOT CONDUCTIVE 1 = CONDUCTIVE</p> <p>Factory setting: NOT CONDUCTIVE</p> <p> Note! <ul style="list-style-type: none"> ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z001 in the CUSTODY TRANSFER block. ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and the SIMULATION SWITCH POINT function (4342) is active (= ON). </p> <p> Caution! The setting is not saved in the event of a power failure.</p>


8.2.3 Function group INFORMATION










Function description		
OUTPUTS→PULSE/FREQUENCY OUTPUT 1→INFORMATION		
TERMINAL NUMBER	4380	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the pulse/frequency output. Display: 2 = 22 (+) / 23 (-)
MODBUS register:	3251	
Data type:	Integer	
Access:	read	


8.3 Group RELAY OUTPUT (1 to 2)

8.3.1 Function group CONFIGURATION




Function description		
OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION		
<p>ASSIGN RELAY 4700</p> <p> MODBUS register: Relay output 1 3801 Relay output 2 4001 Data type: Integer Access: read/write</p>	<p>Use this function to assign a switching function to the relay output.</p> <p>Options: (standard) 0 = OFF 1 = ON (operation) 2 = FAULT MESSAGE 3 = NOTICE MESSAGE 4 = FAULT MESSAGE or NOTICE MESSAGE 5 = EPD (empty pipe detection, only if active) 6 = FLOW DIRECTION 7 = MASS FLOW LIMIT VALUE 8 = VOLUME FLOW LIMIT VALUE 14 = CORRECTED VOLUME FLOW LIMIT VALUE 15 = DENSITY LIMIT VALUE 16 = REFERENCE DENSITY LIMIT VALUE 17 = TEMPERATURE LIMIT VALUE 19 = TOTALIZER 1 LIMIT VALUE 20 = TOTALIZER 2 LIMIT VALUE 21 = TOTALIZER 3 LIMIT VALUE</p> <p>Factory setting: FAULT MESSAGE</p> <p> Note!</p> <ul style="list-style-type: none"> ■ It is very important to read and comply with the information on the switching characteristics of the relay output, (see Page 96). ■ It is advisable to configure at least one relay output as a fault output and define the outputs' failsafe mode. ■ The relay output is configured as a normally open (NO or make) contact by default. It can be reconfigured as a normally closed (NC or break) contact by means of a jumper on the relay module (see Operating Instructions BA107D). ■ If you select OFF or ON, the only function shown in the CONFIGURATION function group is the function ASSIGN RELAY (4700). 	







Function description	
OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION	
<p>ON-VALUE 4701</p> <p>①</p> <p>MODBUS register: Relay output 1 3802 Relay output 2 4002 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to assign a value to the switch-on point (relay output pulls up). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.
<p>SWITCH-ON DELAY 4702</p> <p>①</p> <p>MODBUS register: Relay output 1 3804 Relay output 2 4004 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define a delay (0 to 100 seconds) for pull-up (i.e. signal changes from 0 to 1) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch on condition has been valid over the delay time.</p> <p>User input: fixed-point number 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p>
<p>OFF-VALUE 4703</p> <p>①</p> <p>MODBUS register: Relay output 1 3806 Relay output 2 4006 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to assign a value to the switch-off point (relay drops out). The value can be higher or lower than the switch-on point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4705) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.

Function description		
OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION		
<p>SWITCH-OFF DELAY 4704</p> <p>🕒</p> <p>MODBUS register: Relay output 1 3808 Relay output 2 4008 Data type: Float Access: read/write</p>	<p>📎 Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define a delay (0 to 100 seconds) for dropout (i.e. signal changes from 1 to 0) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch off condition has been valid over the delay time.</p> <p>User input: fixed-point number 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p>	
<p>MEASURING MODE 4705</p> <p>🕒</p> <p>MODBUS register: Relay output 1 3810 Relay output 2 4010 Data type: Integer Access: read/write</p>	<p>📎 Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define the measuring mode for the relay output.</p> <p>Options: 0 = STANDARD The relay output signal switches at the defined switch points.</p> <p>1 = SYMMETRY The relay output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the relay output switches as soon as the value is reached in the negative direction (negative sign), (see illustration).</p> <p>Factory setting: STANDARD</p>	 <p style="text-align: right; font-size: small;">A0001247</p>
		<p><i>Fig. 23: Example for the SYMMETRY measuring mode</i> Switch-on point $Q = 4$ Switch-off point $Q = 10$ ① = Relay energized ② = Relay de-energized</p> <p>📎 Note!</p> <ul style="list-style-type: none"> ■ SYMMETRY cannot be selected unless the values in the ON-VALUE (4701) and OFF-VALUE (4703) functions have the same sign or one of the values is zero. ■ If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed.


Function description		
OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION		
<p>TIME CONSTANT 4706</p> <p>①</p> <p>MODBUS register: Relay output 1 3811 Relay output 2 4011 Data type: Float Access: read/write</p>		<p>Entering a time constant defines how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the relay output changing state continuously in response to fluctuations in flow.</p> <p>User input: fixed-point number: 0.00 to 100.00 s</p> <p>Factory setting: 0.00 s</p>

8.3.2 Function group OPERATION



Function description	
OUTPUTS → RELAY OUTPUT (1 to 2) → OPERATION	
<p>ACTUAL STATUS RELAY 4740</p> <p>MODBUS register: Relay output 1 3813 Relay output 2 4013 Data type: Integer Access: read</p>	<p>Use this function to check the current status of the relay output.</p> <p>A jumper on the contact side defines the relay output as a normally open (NO or maker) or normally closed (NC or breaker) contact (see Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D).</p> <p>Display: 0 = BREAK CONTACT OPEN 1 = BREAK CONTACT CLOSED 2 = MAKE CONTACT OPEN 3 = MAKE CONTACT CLOSED</p>
<p>SIMULATION SWITCH POINT 4741</p> <p> MODBUS register: Relay output 1 3814 Relay output 2 4014 Data type: Integer Access: read/write</p>	<p>Use this function to activate simulation of the relay output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note! ■ The "SIMULATION RELAY" message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.</p> <p> Caution! The setting is not saved in the event of a power failure.</p>
<p>VALUE SIMULATION SWITCH POINT 4742</p> <p> MODBUS register: Relay output 1 3815 Relay output 2 4015 Data type: Integer Access: read/write</p>	<p> Note! The function is not visible unless the function SIMULATION SWITCH POINT (4741) is active.</p> <p>Use this function to define the status of the relay output during the simulation. This value is used to test downstream devices and the measuring device itself. Depending on the relay configuration (as make or break contact) the following selections are available.</p> <p>Options: Relay output configured as NC (breaker) contact 0 = BREAK CONTACT OPEN 1 = BREAK CONTACT CLOSED</p> <p>Options: Relay output configured as NO (maker) contact 2 = MAKE CONTACT OPEN 3 = MAKE CONTACT CLOSED</p> <p> Caution! The setting is not saved in the event of a power failure.</p>

8.3.3 Function group INFORMATION



Function description		
OUTPUTS → RELAY OUTPUT (1 to 2) → INFORMATION		
TERMINAL NUMBER	4780	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the relay output. Display: 2 = 22 (+) / 23 (-) → RELAY OUTPUT 1 3 = 20 (+) / 21 (-) → RELAY OUTPUT 2
MODBUS register:		
Relay output 1	3816	
Relay output 2	4016	
Data type:	Integer	
Access:	read	

8.3.4 Information on the response of the relay output

General

If you have configured the relay output for "LIMIT VALUE" or "FLOW DIRECTION", you can define the requisite switch points in the ON-VALUE and OFF-VALUE functions. When the measured variable in question reaches one of these predefined values, the relay output switches as shown in the illustrations below.

Relay output configured for "flow direction"

The value you entered in the function ON-VALUE defines the switch point for the positive and negative directions of flow.

If, for example, the switch point you define is $1 \text{ m}^3/\text{h}$, the relay drops out at $-1 \text{ m}^3/\text{h}$ and pulls up at $+1 \text{ m}^3/\text{h}$. Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value higher than or equal to the low flow cut off rate.




Fig. 24: Relay output configured for "flow direction"

- a Relay energized
- b Relay de-energized

A0001236

Relay output configured for "limit value"

The relay output signal switches as soon as the measured variable undershoots or overshoots a defined switch point.

Application: Monitoring flow or process-related boundary conditions.

Measured variable




Fig. 25: Relay output configured for "limit value"

- ① = Switch-off point, ② = Switch-on point, ③ = Relay de-energized































A = Maximum safety (SWITCH-OFF POINT > SWITCH-ON POINT)

B = Minimum safety (SWITCH-OFF POINT < SWITCH-ON POINT)

C = Minimum safety (SWITCH-OFF POINT = SWITCH-ON POINT, this configuration is to be avoided)


A0001235

8.3.5 Switching behavior of the relay output

Function	State	Relay coil	Contact*	
			NC	NO
ON (operation)	System in measuring mode 	energized		
	System not in measuring mode (power supply failed) 	de-energized		
Fault message	System OK 	energized		
	(System or process error) Fault → Failsafe mode, outputs/inputs and totalizers 	de-energized		
Notice message	System OK 	energized		
	(System or process error) Fault → Continuation of measuring 	de-energized		
Fault message or Notice message	System OK 	energized		
	(System or process error) Fault → Response to error or Note → Continuation of measuring 	de-energized		
Empty pipe detection (EPD)	Measuring tube full 	energized		
	Measuring tube partially filled /empty measuring tube 	de-energized		

Function	State	Relay coil	Contact*	
			NC	NO
Flow direction	Forward	energized		
	Reverse			
Limit value – Mass flow – Volume flow – Corrected volume flow – Density – Reference density – Temperature – Totalizer	Limit value not overshoot or undershot	energized		
	Limit value overshoot or undershot	de-energized		
<p>* Terminal numbers in accordance with the TERMINAL NUMBER function (4780) on Page 94.</p> <p> Note! If the measuring device has two relays, the factory setting is: <ul style="list-style-type: none"> ■ Relay 1 → normally open contact (NO) ■ Relay 2 → normally closed contact (NC) </p> <p> Caution! When using the optional software package BATCHING, it is advisable for the contacts (either normally open or normally closed contacts) to have the same switching response for all relay outputs used.</p>				


9 Block INPUTS




9.1 Group STATUS INPUT

9.1.1 Function group CONFIGURATION

INPUTS	F	→	STATUS INPUT	FAA	→	CONFIGURATION	500
--------	---	---	--------------	-----	---	---------------	-----


Function description		
INPUTS → STATUS INPUT → CONFIGURATION		
<p>ASSIGN STATUS INPUT 5000</p> <p>①</p> <p>MODBUS register: 4301 Data type: Integer Access: read/write</p>	<p>Use this function to assign a switching function to the status input.</p> <p>Options: 0 = OFF 1 = RESET TOTALIZER 1 2 = RESET TOTALIZER 2 3 = RESET TOTALIZER 3 4 = RESET ALL TOTALIZERS 5 = POSITIVE ZERO RETURN 8 = ZEROPOINT ADJUST</p> <p>Factory setting: OFF</p> <p> Caution! POSITIVE ZERO RETURN is active as long as the level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.</p>	
<p>ACTIVE LEVEL 5001</p> <p>①</p> <p>MODBUS register: 4302 Data type: Integer Access: read/write</p>	<p>Use this function to define whether the assigned function (see function ASSIGN STATUS INPUT(5000)) is released when the signal level is present (HIGH) or not present (LOW).</p> <p>Options: 1 = HIGH 0 = LOW</p> <p>Factory setting: HIGH</p>	
<p>MINIMUM PULSE WIDTH 5002</p> <p>①</p> <p>MODBUS register: 4303 Data type: Float Access: read/write</p>	<p>Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function, (see function ASSIGN STATUS INPUT (5000)).</p> <p>User input: 20 to 100 ms</p> <p>Factory setting: 50 ms</p>	

9.1.2 Function group OPERATION



Function description		
INPUTS → STATUS INPUT → OPERATION		
ACTUAL STATUS INPUT MODBUS register: Data type: Access:	5040 4305 Integer read	Use this function to view the current level of the status input. Display: 0 = LOW 1 = HIGH
SIMULATION STATUS INPUT MODBUS register: Data type: Access:	5041 4306 Integer read/write	Use this function to simulate the status input, in other words to trigger the function assigned to the status input (see the function ASSIGN STATUS INPUT (5000) on Page 99). Display: 0 = OFF 1 = ON Factory setting: OFF Note! <ul style="list-style-type: none"> ■ The "SIMULATION STATUS INPUT" notice message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. Caution! The setting is not saved in the event of a power failure.
VALUE SIMULATION STATUS INPUT MODBUS register: Data type: Access:	5042 4307 Integer read/write	Note! The function is not visible unless the function SIMULATION STATUS INPUT (5041) is active. Use this function to define the level to be assumed at the status output during the simulation. This value is used to test downstream devices and the measuring device itself. Options: 0 = LOW 1 = HIGH Factory setting: LOW Caution! The setting is not saved in the event of a power failure.

9.1.3 Function group INFORMATION



Function description		
INPUTS → STATUS INPUT → INFORMATION		
TERMINAL NUMBER MODBUS register: Data type: Access	5080 4308 Integer read	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the status input. Display: 1 = 24 (+) / 25 (-)







10 Block BASIC FUNCTION




Block	Groups	Function groups	Functions								
BASIC FUNCTION (G)	MODBUS RS485 (GDA) P. 103	CONFIGURATION (630) P. 103	TAG NAME (6300) P. 103	FIELDBUS ADDRESS (6301) P. 103	BAUDRATE (6302) P. 103	TRANSMISSION MODE (6303) P. 104	PARITY (6304) P. 104	BYTE ORDER (6305) P. 104	DELAY TELE. REPLY (6306) P. 105	WRITE PROTECTION (6307) P. 105	SCAN LIST REGISTER 1 to 16 (6308) P. 105
		PROCESS PARAMETER (GJA) P. 106	ASSIGN LF CUT OFF (6400) P. 106	ON-VALUE LF CUT OFF (6402) P. 106	OFF-VALUE LF CUT OFF (6403) P. 106	PRESS. SHOCK SUPP. (6404) P. 107					
	PROCESS PARAMETER (GJA) P. 106	EPD PARAMETER (642) P. 108	EPD (6420) P. 108	EPD VALUE LOW (6423) P. 108	EPD VALUE HIGH (6424) P. 108	EPD RESPONSE TIME (6425) P. 108	EPD EXC. CURR. (6426) P. 109				
		REFERENCE PARAMETER (646) P. 110	COR. VOL. CALC. (6460) P. 110	FIXED REFERENCE DENSITY (6462) P. 110	EXPANSION COEFF. (6462) P. 110	EXPANSION COEFF. SOR. (6463) P. 110	REFERENCE TEMPERATURE (6464) P. 111				
	SYSTEM PARAMETER (GLA) P. 115	ADJUSTMENT (648) P. 112	ZERO POINT ADJUSTMENT (6480) P. 112	DENSITY ADJUST MODE (6482) P. 112	DENSITY SET VALUE 1 (6483) P. 112	MEASURE FLUID 1 (6484) P. 112	DENSITY SET VALUE 2 (6485) P. 113	MEASURE FLUID 2 (6486) P. 113	DENSITY ADJUSTMENT (6487) P. 113	RESTORE ORIGINAL (6488) P. 113	
		PRESSURE CORRECTION (650) P. 114	PRESSURE MODE (6500) P. 114	PRESSURE (6501) P. 114							
	SYSTEM PARAMETER (GLA) P. 115	CONFIGURATION (660) P. 115	INST. DIR. SENSOR (6600) P. 115	DENSITY DAMPING (6602) P. 115	FLOW DAMPING (6603) P. 115	POSITIVE ZERO RETURN (6605) P. 115					
		SENSOR DATA (GNA) P. 116	CONFIGURATION (680) P. 116	K-FACTOR (6800) P. 116	ZERO POINT (6803) P. 116	NOMINAL DIAMETER (6804) P. 116					
	SENSOR DATA (GNA) P. 116	FLOW COEFF. (684) P. 117	COEFF. KM (6840) P. 117	COEFF. KM 2 (6841) P. 117	COEFF. KT (6842) P. 117	COEFF. KD1 (6843) P. 117	COEFF. KD2 (6844) P. 117				
		DENSITY COEFFICIENT (685) P. 118	COEFF. C 0 (6850) P. 118	COEFF. C 1 (6851) P. 118	COEFF. C 2 (6852) P. 118	COEFF. C 3 (6853) P. 118	COEFF. C 4 (6854) P. 118	COEFF. C 5 (6855) P. 118			
	SENSOR DATA (GNA) P. 116	ADDITIONAL COEFFICIENT (686) P. 119	MIN. TEMP. MEAS. (6860) P. 119	MAX. TEMP. MEAS. (6861) P. 119	MIN. TEMP. CARRIER (6862) P. 119	MAX. TEMP. CARRIER (6863) P. 119					






10.1 Group MODBUS RS485

10.1.1 Function group CONFIGURATION

BASIC FUNCTION	G	→	MODBUS RS485	GDA	→	CONFIGURATION	630
----------------	---	---	--------------	-----	---	---------------	-----


Function description		
BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
<p>TAG NAME 6300</p> <p></p> <p>MODBUS register: 4901 Data type: String (16) Access: read/write</p>		<p>For entering a tag name for the measuring device. You can edit and read this tag name via the local display or the MODBUS RS485 protocol.</p> <p>User input: max. 16-character text, permissible: A-Z, 0-9, +, -, punctuation marks</p> <p>Factory setting: "-----" (No text)</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.
<p>FIELD BUS ADDRESS</p> <p></p> <p>MODBUS register: 4910 Data type: Integer Access: read/write</p>		<p>For entering the device address.</p> <p>User input: 1 to 247</p> <p>Factory setting: 247</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.
<p>BAUDRATE 6302</p> <p></p> <p>MODBUS register: 4912 Data type: Integer Access: read/write</p>		<p>For selecting the baudrate.</p> <p>Options: 0 = 1200 BAUD 1 = 2400 BAUD 2 = 4800 BAUD 3 = 9600 BAUD 4 = 19200 BAUD 5 = 38400 BAUD 6 = 57600 BAUD 7 = 115200 BAUD</p> <p>Factory setting: 19200 BAUD</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.


Function description		
BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
<p>TRANSMISSION MODE</p> <p>①</p> <p>MODBUS register: 4913 Data type: Integer Access: read/write</p>	<p>6303</p>	<p>For selecting the data transfer mode.</p> <p>Options: 0 = RTU 1 = ASCII</p> <p>Factory setting: RTU</p> <p> Note!</p> <ul style="list-style-type: none"> ■ RTU = transmission of data in binary form. Error protection via CRC16. ■ RTU = transmission of data in the form of readable ASCII characters. Error protection via LRC. ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.
<p>PARITY</p> <p>①</p> <p>MODBUS register: 4914 Data type: Integer Access: read/write</p>	<p>6304</p>	<p>For selecting whether no parity bit or an even or uneven parity bit should be transmitted. The options available depend on the TRANSMISSION MODE function:</p> <p>Options: (for TRANSMISSION MODE = RTU) 0 = EVEN 1 = UNEVEN 2 = NONE</p> <p>Options: (for TRANSMISSION MODE = ASCII) 0 = EVEN 1 = UNEVEN</p> <p>Factory setting: EVEN</p> <p> Note!</p> <p>This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.
<p>BYTE ORDER</p> <p>①</p> <p>MODBUS register: 4915 Data type: Integer Access: read/write</p>	<p>6305</p>	<p>For selecting the byte transmission sequence for the Integer, Float and String data types.</p> <p>Options: 0 = 0-1-2-3 1 = 3-2-1-0 2 = 2-3-0-1 3 = 1-0-3-2</p> <p>Factory setting: 1-0-3-2</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The transmission sequence must suit the MODBUS master. ■ For additional information, refer to the "Byte transmission order" section in the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D. ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.

Function description		
BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
<p>DELAY TELE. REPLY</p> <p></p> <p>MODBUS register: 4916 Data type: Float Access: read/write</p>	<p>6306</p>	<p>For entering a delay time after which the measuring device replies to the request telegram of the MODBUS master. This allows communication to be adapted to slow MODBUS RS485 masters.</p> <p>User input: 0 to 100 ms</p> <p>Factory setting: 10 ms</p> <p> Note! This function cannot be changed if:</p> <ul style="list-style-type: none"> ■ The measuring device has been configured in accordance with NTEP or MC approval. ■ The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.
<p>WRITE PROTECTION</p> <p>MODBUS register: 4918 Data type: Integer Access: read</p>	<p>6307</p>	<p>Indicates whether write access to the measuring device is possible via local operation or MODBUS RS485.</p> <p>Display: 0 = OFF (write access via MODBUS possible) 1 = ON (write access via MODBUS blocked)</p> <p>Factory setting: OFF</p> <p> Note! Hardware write protection is activated and deactivated by means of a jumper on the I/O board (see Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D).</p>
<p>SCAN LIST REGISTER 1 to 16</p> <p></p> <p>MODBUS register: SCAN LIST REG. 1 5001 SCAN LIST REG. 2 5002 SCAN LIST REG. 3 5003 SCAN LIST REG. 4 5004 SCAN LIST REG. 5 5005 SCAN LIST REG. 6 5006 SCAN LIST REG. 7 5007 SCAN LIST REG. 8 5008 SCAN LIST REG. 9 5009 SCAN LIST REG. 10 5010 SCAN LIST REG. 11 5011 SCAN LIST REG. 12 5012 SCAN LIST REG. 13 5013 SCAN LIST REG. 14 5014 SCAN LIST REG. 15 5015 SCAN LIST REG. 16 5016 Data type: Integer Access: read/write</p>	<p>6308</p>	<p>By entering the register address, up to 16 device parameters can be grouped in the auto-scan buffer where they are assigned to the scan list registers 1 to 16. The data of the device parameters assigned here are read out via the register addresses 5051 to 5081.</p> <p>User input: 0 to 9999</p> <p>Factory setting: 0</p> <p> Note!</p> <ul style="list-style-type: none"> ■ For additional information and examples of using the auto-scan buffer, refer to the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D. ■ This function cannot be changed if: <ul style="list-style-type: none"> – The measuring device has been configured in accordance with NTEP or MC approval. – The measuring device has been configured in accordance with PTB, NMI, METAS or BEV approval and YES has been selected for function Z009 in the CUSTODY TRANSFER block.

10.2 Group PROCESS PARAMETER

10.2.1 Function group CONFIGURATION




Function description		
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION		
ASSIGN LOW FLOW CUTOFF ① MODBUS register: 5101 Data type: Integer Access: read/write	6400	Use this function to assign the switch point for low flow cut off rate suppression. Options: 0 = OFF 1 = MASS FLOW 2 = VOLUME FLOW 3 = CORRECTED VOLUME FLOW Factory setting: MASS FLOW
ON-VALUE LOW FLOW CUT OFF ① MODBUS register: 5138 Data type: Float Access: read/write	6402	Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active. User input: 5-digit floating-point number, [unit] Factory setting: Depends on nominal diameter 📎 Note! The appropriate unit is taken from the function group SYSTEM UNITS (see Page 14).
OFF-VALUE LOW FLOW CUTOFF ① MODBUS register: 5104 Data type: Float Access: read/write	6403	Enter the off-value (b) of the low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input: Integer 0 to 100% Factory setting: 50% 








A0003882



① = on-value, ② = off-value
 a Low flow cut off is switched on
 b Low flow cut off is switched off (a + a · H)
 H Hysteresis: 0 to 100%
 ■ Low flow cut off active
 Q Flow

Function description	
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION	
<p>PRESSURE SHOCK SUPPRESSION 6404</p> <p>ⓘ</p> <p>MODBUS register: 5140 Data type: Float Access: read/write</p>	<p>The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".</p> <p> Note! Note that pressure shock suppression cannot be used unless the low flow cut off is active, (see function ON-VALUE LOW FLOW CUT OFF on Page 106).</p> <p>Use this function to define the time span for active pressure shock suppression.</p> <p>Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (see point ① in graphic). While pressure shock suppression is active, the following conditions apply:</p> <ul style="list-style-type: none"> ■ Flow reading on display → 0 ■ Totalizer reading → the totalizers are pegged at the last correct value. <p>Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point ② in graphic).</p> <p> Note! The actual flow value is displayed and output, when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point ② in graphic).</p> <div style="text-align: center;"> </div> <p style="text-align: right; font-size: small;">A0001285-EN</p> <p>① = Off-value (low flow cut off), ② = On-value (low flow cut off) a Active when value falls below the on-value of the low flow cut off b Deactivated after specified time expires c Flow values are again used to calculate the pulses ■ Suppressed values Q Flow</p> <p>User input: max. 4-digit number, incl. unit: 0.00 to 100.0 s</p> <p>Factory setting: 0.00 s</p>


10.2.2 Function group EPD PARAMETER






Function description		
BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER		
EMPTY PIPE DETECTION  MODBUS register: 5106 Data type: Integer Access: read/write	6420	Use this function to activate the empty pipe detection (EPD). With empty measuring tubes the density of the fluid falls below the value specified in the function EPD VALUE LOW. Options: 0 = OFF 1 = ON Factory setting: ON  Caution! <ul style="list-style-type: none"> ■ Select a correspondingly low EPD response value in the function EPD VALUE LOW, so that the difference to the effective density of the fluid is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. ■ For gas measurement we strongly recommend to switch off empty pipe detection.
EPD VALUE LOW  MODBUS register: 5110 Data type: Float Access: read/write	6423	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set a lower threshold for the measured density value, in order to detect possible problems in the process indicated by too low density. User input: 5-digit floating-point number Factory setting: 0.2000 g/cc
EPD VALUE HIGH  MODBUS register: 5112 Data type: Float Access: read/write	6424	 Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function. Use this function to set an upper threshold for the measured density value. User input: 5-digit floating-point number Factory setting: 6.0000 g/cc
EPD RESPONSE TIME  MODBUS register: 5108 Data type: Float Access: read/write	6425	Use this function to enter the time span for which the criteria for an empty pipe have to be satisfied without interruption before a notice message or fault message is generated. User input: fixed-point number: 1.0 to 60 s Factory setting: 1.0 s

Function description		
BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER		
<p>EPD EXC.CURR. 6426</p> <p> MODBUS register: 5233 Data type: Float Access: read/write</p>		<p>Empty pipe detection (EPD) can be switched on in this function.</p> <p>In the event of inhomogeneous fluids or air bubbles, the exciting current of the measuring pipes increases. If the exciting current specified in this function is overshoot, error message #700 "EPD ACTIVE" is output similar to the EPD VALUE LOW () function.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 100 mA (deactivated)</p> <p> Note! The function is not activated until a value under 100 mA is input. Entering the value 100 mA deactivates the function.</p>


10.2.3 Function group REFERENCE PARAMETER












Function description	
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER	
<p>CORRECTED VOLUME CALCULATION 6460</p> <p>①</p> <p>MODBUS register: 5129 Data type: Integer Access: read/write</p>	<p>This function is used to set the reference density for calculating the corrected volume flow.</p> <p>Options: 0 = CALCULATED REFERENCE DENSITY 1 = FIXED REFERENCE DENSITY</p> <p>Factory setting: CALCULATED REFERENCE DENSITY</p>
<p>FIXED REFERENCE DENSITY 6461</p> <p>①</p> <p>MODBUS register: 5130 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless the FIXED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460).</p> <p>In this function, a fixed value for the reference density can be entered, with which the corrected volume flow or corrected volume is calculated.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 1 kg/Nl</p>
<p>EXPANSION COEFFICIENT 6462</p> <p>①</p> <p>MODBUS register: 5132 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460).</p> <p>For temperature-compensated calculations of the reference density an expansion coefficient specific to the fluid is required and can be entered in this function (see REFERENCE TEMPERATURE (6464) function on Page 111).</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0.5000 e-3 [1/K]</p>
<p>EXPANSION COEFFICIENT SQUARE 6463</p> <p>①</p> <p>MODBUS register: 5134 Data type: Float Access: read/write</p>	<p>Use this function to enter a square expansion coefficient, if the temperature compensation follows a nonlinear behavior (see REFERENCE TEMPERATURE (6464) function on Page 111).</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0 e-6 [1/K²]</p>

Function description		
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER		
<p>REFERENCE TEMPERATURE</p> <p>①</p> <p>MODBUS register: 5136 Data type: Float Access: read/write</p>	<p>6464</p>	<p> Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460).</p> <p>For entering the reference temperature for calculating the corrected volume flow, the corrected volume and the reference density.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 20.000 °C</p> <p>The reference density is calculated as follows: $\rho_N = \rho \cdot (1 + \alpha \Delta t + \beta \Delta t^2)$; Δ where $t = t - t_N$</p> <p>ρ_N = Reference density ρ = currently measured fluid density (measuring value Promass) t = Actual measured temperature of fluid (measuring value Promass) t_N = Reference temperature for calculating the reference density (e.g. 20 °C) α = Vol. expansion coefficient of the fluid, unit [1/K] (K = Kelvin) β = Square volumetric expansion coefficient of the fluid, unit [1/K²]</p>


10.2.4 Function group ADJUSTMENT





Function description		
BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT		
ZERO POINT ADJUSTMENT  MODBUS register: 5121 Data type: Integer Access: read/write	6480	This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the function ZERO POINT. Options: 0 = CANCEL 1 = START Factory setting: CANCEL  Caution! Before carrying this out, please refer to the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D for a detailed description of the procedure for zero point adjustment.  Note! <ul style="list-style-type: none"> ■ Programming is locked during zero point adjustment. The message "ZERO ADJUST RUNNING" appears on the display. ■ If the zero point adjustment is not possible (e.g. if $v > 0.1$ m/s) or has been canceled, the alarm message "ZERO ADJUST NOT POSSIBLE" appears on the display. ■ If the Promass 84 measuring electronics are fitted with a status input, then the zero point adjustment can also be activated by using this input.
DENSITY ADJUST MODE  MODBUS register: 5180 Data type: Integer Access: read/write	6482	Use this function to select whether a 1-point or a 2-point density adjustment should be carried out. Options: 0 = CANCEL 1 = 1-POINT 2 = 2-POINT
DENSITY SET VALUE 1  MODBUS register: 5124 Data type: Float Access: read/write	6483	Use this function to enter the density setpoint value for the first fluid for which you want to carry out field density adjustment. User input: 5-digit floating-point number, incl. unit  Note! <ul style="list-style-type: none"> ■ The preset density entered here should not vary from the actual fluid density by a more than $\pm 10\%$. ■ The appropriate unit is taken from the function group SYSTEM UNITS (see Page 14).
MEASURE FLUID 1  MODBUS register: 5126 Data type: Integer Access: read/write	6484	In this function the actual density of the first fluid is measured for density adjustment. Options: 0 = CANCEL 1 = START

Function description		
BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT		
<p>DENSITY SET VALUE 2</p> <p>MODBUS register: 5181 Data type: Float Access: read/write</p>	<p>6485</p>	<p>Use this function to enter the density setpoint value for the second fluid for which you want to carry out field density adjustment.</p> <p>User input: 5-digit floating-point number, incl. unit</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The preset density entered here should not vary from the actual fluid density by a more than ±10%. ■ The difference between the density setpoint values must be at least 0.2 kg/l. ■ The appropriate unit is taken from the function group SYSTEM UNITS (see Page 14).
<p>MEASURE FLUID 2</p> <p>MODBUS register: 5183 Data type: Integer Access: read/write</p>	<p>6486</p>	<p>In this function the current density of the second fluid is measured for density adjustment.</p> <p>Options: 0 = CANCEL 1 = START</p>
<p>DENSITY ADJUSTMENT</p> <p>MODBUS register: 5127 Data type: Integer Access: read/write</p>	<p>6487</p>	<p>With this function a density adjustment can be carried out on site. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations (e.g. volume flow) are as accurate as possible.</p> <p> Note!</p> <p>Before carrying this out, please refer to the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D for a detailed description of the procedure for density adjustment.</p> <p>Two types of adjustment are possible:</p> <p>1-point density adjustment (with one fluid) This type of density adjustment is necessary under the following conditions:</p> <ul style="list-style-type: none"> ■ The sensor does not measure exactly the density value that the user expects on the basis of laboratory analyses. ■ The fluid properties are outside the measuring points set at the factory, or the reference operating conditions used to calibrate the measuring device. ■ The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. <p>2-point density adjustment (with two fluids) This type of adjustment must always be carried out when the measuring tubes are changed mechanically, e.g. due to deposits, abrasion or corrosion: In such instances, the measuring tube resonance frequency is influenced in such a way that it is no longer compatible with the calibration data determined at the factory. The 2-point density adjustment takes these mechanically-based changes into account and calculates new, adjusted calibration data.</p> <p>Options: 0 = CANCEL 1 = MEASURE FLUID 1 2 = MEASURE FLUID 2 3 = DENSITY ADJUST</p> <p>Factory setting: CANCEL</p>
<p>RESTORE ORIGINAL</p> <p>MODBUS register: 5128 Data type: Integer Access: read/write</p>	<p>6488</p>	<p>With this function the original density coefficient determined at the factory are restored.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p>


10.2.5 Function group PRESSURE CORRECTION








Function description		
BASIC FUNCTION → PROCESS PARAMETER → PRESSURE CORRECTION		
<p>PRESSURE MODE 6500</p> <p>①</p> <p>MODBUS register: 5184 Data type: Integer Access: read/write</p>	<p>Use this function to configure an automatic pressure correction. In this way, the effect of a pressure deviation between the calibration and process pressures on the measured error for mass flow can be compensated, (see also Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D, "Performance characteristics" section).</p> <p>Options: 0 = OFF 1 = FIX (a fixed process pressure for pressure correction is specified).</p> <p>Factory setting: OFF</p>	
<p>PRESSURE 6501</p> <p>①</p> <p>MODBUS register: 5185 Data type: Float Access: read/write</p>	<p> Note! This function is not available unless the FIXED setting was selected in the PRESSURE MODE function (6500).</p> <p>Use this function to enter the value for the process pressure which should be used during pressure correction.</p> <p>User input: 7-digit floating-point number</p> <p>Factory setting: 0 bar g</p> <p> Note! The appropriate unit is taken from the function group SYSTEM UNITS (see Page 14).</p>	

10.3 Group SYSTEM PARAMETER


10.3.1 Function group CONFIGURATION








Function description	
BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION	
INSTALLATION DIRECTION SENSOR 6600  MODBUS register: 5501 Data type: Integer Access: read/write	Use this function to reverse the sign of the flow direction, if necessary.  Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate). Options: 0 = NORMAL (flow as indicated by the arrow) 1 = INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL
DENSITY DAMPING 6602  MODBUS register: 5508 Data type: Float Access: read/write	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the fluid, e.g. with inhomogeneous liquids. The damping acts on all functions and outputs of the measuring device. User input: max. 5-digit number, including unit: 0.00 to 100.00 s Factory setting: 0.00 s
FLOW DAMPING 6603  MODBUS register: 5510 Data type: Float Access: read/write	Setting the filter depth of the digital filter. The sensitivity of the flow measurement signal can be reduced with respect to interference peaks (e.g. in the event of a high solid content, gas bubbles in the fluid etc.). The reaction time of the measuring device increases with every increase in the filter setting. The damping acts on all functions and outputs of the measuring device. User input: 0 to 100 s Factory setting: 0 s
POSITIVE ZERO RETURN 6605  MODBUS register: 5503 Data type: Integer Access: read/write	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device. Options: 0 = OFF 1 = ON (signal output is set to the "ZERO FLOW" value, temperature and density are still output) Factory setting: OFF


10.4 Group SENSOR DATA

10.4.1 Function group CONFIGURATION




Function description		
BASIC FUNCTION → SENSOR DATA → CONFIGURATION		
<p>All sensor data (calibration factor, zero point and nominal diameter) are set at the factory and saved on the S-DAT sensor memory chip.</p> <p> Caution! Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code. Contact the Endress+Hauser service organization if you have any questions about these functions.</p> <p> Note! The individual values of the functions are also provided on the sensor nameplate.</p>		
<p>K-FACTOR 6800</p> <p></p> <p>MODBUS register: 7513 Data type: Float Access: read</p>		<p>This function shows the current calibration factor for the sensor.</p> <p>Factory setting: Depends on nominal diameter and calibration</p>
<p>ZERO POINT 6803</p> <p></p> <p>MODBUS register: 7527 Data type: Float Access: read/write</p>		<p>This function shows the current zero point correction value for the sensor.</p> <p>Display: max. 5-digit number: -99999 to +99999</p> <p>Factory setting: Depends on calibration</p>
<p>NOMINAL DIAMETER 6804</p> <p></p> <p>MODBUS register: 7525 mm 7526 inch 7526 Data type: Integer Access: read</p>		<p>Display: Nominal diameter of the sensor</p> <p>0 = DN 1 or 1/24" 1 = DN 2 or 1/12" 2 = DN 3 or 1/8" 3 = DN 3.5 or 9/64" 4 = DN 4 or 5/32" 5 = DN 6 or 1/4" 6 = DN 8 or 5/16" 7 = DN 10 or 3/8" 8 = DN 15 or 1/2" 10 = DN 20 or 3/4" 11 = DN 25 or 1" 13 = DN 32 or 1 1/4" 14 = DN 40 or 1 1/2" 16 = DN 50 or 2" 18 = DN 65 or 2 1/2" 19 = DN 80 or 3" 20 = DN 100 or 4" 21 = DN 125 or 5" 22 = DN 150 or 6" 23 = DN 200 or 8" 24 = DN 250 or 10"</p>













10.4.2 Function group FLOW COEFFICIENT




Function description	
BASIC FUNCTION → SENSOR DATA → FLOW COEFFICIENT	
All flow coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip. Contact the Endress+Hauser service organization if you have any questions about these functions.	
TEMPERATURE COEFFICIENT KM 6840 MODBUS register: 7519 Data type: Float Access: read	This function shows the temperature coefficient KM.
TEMPERATURE COEFFICIENT KM2 6841 MODBUS register: 7521 Data type: Float Access: read	This function shows the temperature coefficient KM2.
TEMPERATURE COEFFICIENT KT 6842 MODBUS register: 7523 Data type: Float Access: read	This function shows the temperature coefficient KT.
CALIBRATION COEFFICIENT KD 1 6843 MODBUS register: 7515 Data type: Float Access: read	This function shows the calibration coefficient KD 1.
CALIBRATION COEFFICIENT KD 2 6844 MODBUS register: 7517 Data type: Float Access: read	This function shows the calibration coefficient KD 2.


10.4.3 Function group DENSITY COEFFICIENT



Function description		
BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT		
All density coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.		
Contact the Endress+Hauser service organization if you have any questions about these functions.		
DENSITY COEFF. 6850 C0  MODBUS register: 7501 Data type: Float Access: read	This function shows the actual density coefficient C0.  Caution! A density adjustment can alter the calibration value of this coefficient.	
DENSITY COEFF. 6851 C1  MODBUS register: 7503 Data type: Float Access: read	This function shows the actual density coefficient C1.  Caution! A density adjustment can alter the calibration value of this coefficient.	
DENSITY COEFF. 6852 C2  MODBUS register: 7505 Data type: Float Access: read	This function shows the actual density coefficient C2.  Caution! A density adjustment can alter the calibration value of this coefficient.	
DENSITY COEFF. 6853 C3  MODBUS register: 7507 Data type: Float Access: read	This function shows the actual density coefficient C3.  Caution! A density adjustment can alter the calibration value of this coefficient.	
DENSITY COEFF. 6854 C4  MODBUS register: 7509 Data type: Float Access: read	This function shows the actual density coefficient C4.  Caution! A density adjustment can alter the calibration value of this coefficient.	
DENSITY COEFF. 6855 C5  MODBUS register: 7511 Data type: Float Access: read	This function shows the actual density coefficient C5.  Caution! A density adjustment can alter the calibration value of this coefficient.	

10.4.4 Function group ADDITIONAL COEFFICIENT



Function description		
BASIC FUNCTION → SENSOR DATA → ADDITIONAL COEFFICIENT		
<p>All sensor data are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.</p> <p> Caution! These functions are used for displaying device parameters only and consequently cannot be accessed.</p> <p>Contact the Endress+Hauser service organization if you have any questions about these functions.</p>		
<p>MINIMAL TEMPERATURE MEASURED</p> <p>MODBUS register: 7529 Data type: Float Access: read</p>	<p>6860</p>	<p>The lowest fluid temperature measured appears on the display.</p>
<p>MAXIMAL TEMPERATURE MEASURED</p> <p>MODBUS register: 7531 Data type: Float Access: read</p>	<p>6861</p>	<p>The highest fluid temperature measured appears on the display.</p>
<p>MINIMAL TEMPERATURE CARRIER TUBE</p> <p>MODBUS register: 7533 Data type: Float Access: read</p>	<p>6862</p>	<p>The lowest carrier tube temperature measured appears on the display.</p>
<p>MAXIMUM TEMPERATURE CARRIER TUBE</p> <p>MODBUS register: 7535 Data type: Float Access: read</p>	<p>6863</p>	<p>The highest carrier tube temperature measured appears on the display.</p>





11 Block SUPERVISION

Block	Groups	Function groups	Functions	
SUPERVISION (U)	SYSTEM (JAA) P. 121	CONFIGURATION (800) P. 121	ALARM DELAY (8005) P. 121 ⇒ STORAGE (8007) P. 121	
		OPERATION (804) P. 122	ACT. SYST. CONDITION (8040) P. 122 ⇒ PREV. SYST. CONDITION (8041) P. 122 ⇒ SIM. FAILSAFE MODE (8042) P. 122 ⇒ SIM. MEASURAND (8043) P. 123 ⇒ VAL. SIM. MEASURAND (8044) P. 123 ⇒ SYSTEM RESET (8046) P. 123 ⇒ OPERATION HOURS (8048) P. 123	
	VERSION-INFO (JCA) P. 124	DEVICE (810) P. 124	DEVICE SOFTWARE (8100) P. 124	
		SENSOR (820) P. 125	SERIAL NUMBER (8200) P. 125 ⇒ SW REV. NO. AMPLIFIER (8222) P. 126 ⇒	SENSOR TYPE (8201) P. 125 ⇒ SW REV. NO. S-DAT (8205) P. 125 ⇒ SW REV. NO. T-DAT (8225) P. 126 ⇒ LANGUAGE GROUP (8226) P. 126
	F-CHIP (824) P. 127	F-CHIP (824) P. 127	STATUS F-CHIP (8240) P. 127	
		I/O MODULE (830) P. 127	I/O MODULE TYPE (8300) P. 127	SW REV. I/O-MODULE (8303) P. 127
	I/O SUBMODULE 2 (834) P. 128	I/O SUBMODULE 2 (834) P. 128	SUB IN-/OUTPUT TYPE 2 (8340) P. 128	SW REV. SUB I/O (8343) P. 128
		I/O SUBMODULE 3 (836) P. 128	SUB IN-/OUTPUT TYPE 3 (8360) P. 128	SW REV. SUB I/O (8363) P. 128
	I/O SUBMODULE 4 (838) P. 128	I/O SUBMODULE 4 (838) P. 128	SUB IN-/OUTPUT TYPE 4 (8380) P. 128	SW REV. SUB I/O (8383) P. 128


11.1 Group SYSTEM





11.1.1 Function group CONFIGURATION









Function description		
SUPERVISION → SYSTEM → CONFIGURATION		
<p>ALARM DELAY 8005</p> <p></p> <p>MODBUS register: 6808 Data type: Float Access: read/write</p>	<p>Enter the time span for which the criteria for an error have to be satisfied without interruption before a fault or notice message is generated.</p> <p>This suppression acts on:</p> <ul style="list-style-type: none"> ■ Display ■ Current output ■ Frequency output ■ Relay output ■ MODBUS RS485 <p>Input: 0 to 100 s (in steps of one second)</p> <p>Factory setting: 0 s</p> <p> Caution! If this function is activated, fault and notice messages are delayed by the time corresponding to the setting before being transmitted to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be suppressed, a value of 0 seconds must be entered here.</p>	
<p>STORAGE 8007</p> <p></p> <p>MODBUS register: 6907 Data type: Integer Access: read</p>	<p>Displays whether the automatic, permanent storage of parameter changes in the EEPROM is switched on or off.</p> <p>Display: 0 = OFF 1 = ON</p> <p>Factory setting: ON</p> <p> Caution!</p> <ul style="list-style-type: none"> ■ The selection in the function can be changed by the Endress+Hauser service organization. ■ If you select OFF, all parameter changes are not stored permanently in the EEPROM. This means that these parameter changes are no longer available after a power failure. In this case, the measuring instrument starts up with the last parameter configurations saved in the EEPROM. 	

11.1.2 Function group OPERATION




Function description		
SUPERVISION → SYSTEM → OPERATION		
<p>ACTUAL SYSTEM CONDITION 8040</p> <p>MODBUS register: 6859 Data type: Integer Access: read</p> <p>MODBUS register: 6821 Data type: String (18) Access: read</p>	<p>Displays the present system condition.</p> <p>Display: 1 = "SYSTEM OK" or The fault / notice message with the highest priority.</p> <p> Note! For additional information, refer to the "System or process error messages" section in the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D.</p>	
<p>PREVIOUS SYSTEM CONDITIONS 8041</p> <p>MODBUS register: See Note Data type: Integer Access: read</p>	<p>Use this function to view the sixteen most recent fault and notice messages since measuring last started.</p> <p>Display: The 16 most recent fault or notice messages.</p> <p> Note to MODBUS! The various previous system conditions are available via the following MODBUS registers (data MODBUS register Integer/String):</p> <ul style="list-style-type: none"> ■ Fault/notice message 1 = MODBUS register 6860 ■ Fault/notice message 2 = MODBUS register 6861 ■ Fault/notice message 3 = MODBUS register 6862 ■ Fault/notice message 4 = MODBUS register 6863 ■ Fault/notice message 5 = MODBUS register 6864 ■ Fault/notice message 6 = MODBUS register 6865 ■ Fault/notice message 7 = MODBUS register 6866 ■ Fault/notice message 8 = MODBUS register 6867 ■ Fault/notice message 9 = MODBUS register 6868 ■ Fault/notice message 10 = MODBUS register 6869 ■ Fault/notice message 11 = MODBUS register 6870 ■ Fault/notice message 12 = MODBUS register 6871 ■ Fault/notice message 13 = MODBUS register 6872 ■ Fault/notice message 14 = MODBUS register 6873 ■ Fault/notice message 15 = MODBUS register 6874 ■ Fault/notice message 16 = MODBUS register 6875 <p> Note! For additional information, refer to the "System or process error messages" section in the Operating Instructions for Proline Promass 84 MODBUS RS485, BA129D.</p>	
<p>SIMULATION FAILSAFE MODE 8042</p> <p></p> <p>MODBUS register: 6812 Data type: Integer Access: read/write</p>	<p>Use this function to set all inputs, outputs and totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the message "SIMULATION FAILSAFE MODE" appears on the display.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p>	

Function description		
SUPERVISION → SYSTEM → OPERATION		
<p>SIMULATION MEASURAND</p> <p></p> <p>MODBUS register: 6813 Data type: Integer Access: read/write</p>	<p>8043</p>	<p>Use this function to set all inputs, outputs and totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the message "SIMULATION MEASURAND" appears on the display.</p> <p>Options: 0 = OFF 1 = MASS FLOW 2 = VOLUME FLOW 3 = CORRECTED VOLUME FLOW 4 = DENSITY 5 = REFERENCE DENSITY 6 = TEMPERATURE</p> <p>Factory setting: OFF</p> <p> Caution!</p> <ul style="list-style-type: none"> ■ The measuring device cannot be used for measuring while this simulation is in progress. ■ The setting is not saved in the event of a power failure.
<p>VALUE SIMULATION MEASURAND</p> <p></p> <p>MODBUS register: 6814 Data type: Float Access: read/write</p>	<p>8044</p>	<p> Note! The function is not visible unless the function SIMULATION MEASURAND (8043) is active.</p> <p>For entering a freely selectable value (e.g. 12 m³/s) to check the associated functions in the device itself and downstream signal loops.</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [unit]</p> <p> Caution!</p> <ul style="list-style-type: none"> ■ The setting is not saved in the event of a power failure. ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA) (see Page 14).
<p>SYSTEM RESET</p> <p></p> <p>MODBUS register: 6817 Data type: Integer Access: read/write</p>	<p>8046</p>	<p>Use this function to perform a reset of the measuring system.</p> <p>Options: 0 = NO 1 = RESTART SYSTEM (restart without interrupting power supply)</p> <p>Factory setting: NO</p>
<p>OPERATION HOURS</p> <p>MODBUS register: 6810 Data type: Float Access: read</p>	<p>8048</p>	<p>The hours of operation of the device appear on the display.</p> <p>Display: Depends on the number of hours of operation elapsed</p> <ul style="list-style-type: none"> ■ Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) ■ Hours of operation 10 to 10,000 hours → display format = 0000:00 (hr:min) ■ Hours of operation > 10,000 hours → display format = 000000 (hr)


11.2 Group VERSION-INFO

11.2.1 Function group DEVICE




Function description		
SUPERVISION → VERSION-INFO → DEVICE		
DEVICE SOFTWARE	8100	Displays the current device software version.
MODBUS register:	7277	
Data type:	String (16)	
Access:	read	

11.2.2 Function group SENSOR




Function description		
SUPERVISION → VERSION-INFO → SENSOR		
SERIAL NUMBER 8200 MODBUS register: 7003 Data type: String (16) Access: read		Use this function to view the serial number of the sensor.
SENSOR TYPE 8201 MODBUS register: 7012 Data type: String (16) Access: read		Use this function to view the sensor type (e.g. Promass F).
SW REV. NO. 8205 S-DAT MODBUS register: 7021 Data type: String (16) Access: read		Use this function to view the software revision number of the software used to create the content of the S-DAT.

11.2.3 Function group AMPLIFIER




Function description		
SUPERVISION → VERSION-INFO → AMPLIFIER		
<p>SW REV. NO. AMPLIFIER 8222</p> <p>MODBUS register: 7039 Data type: String (16) Access: read</p>		<p>Use this function to view the software revision number of the amplifier.</p>
<p>SW REV. NO. T-DAT 8225</p> <p>MODBUS register: 7048 Data type: String (16) Access: read</p>		<p>Use this function to view the software revision number of the software used to create the content of the T-DAT.</p>
<p>LANGUAGE GROUP 8226</p> <p>MODBUS register: 7262 Data type: Integer Access: read</p>		<p>Displays the installed language group.</p> <p>Display: 0 = TYPE UNKNOWN 1 = WEST EU / USA 2 = EAST EU / SCAND 3 = ASIA. 4 = CHINA</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The language options of the available language group are displayed in the LANGUAGE (2000) function. ■ You can change the language group via the configuration software ToF Tool - Fieldtool Package. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.

11.2.4 Function group F-CHIP




Function description		
SUPERVISION → VERSION-INFO → F-CHIP		
STATUS F-CHIP	8240	Use this function to check whether an F-CHIP is installed and which software options are available. Display: 0 = NO F-CHIP HW 7 = FAILURE 8 = CRITICAL FAIL. 9 = DEVICE ID
MODBUS register:	7057	
Data type:	Integer	
Access:	read	

11.2.5 Function group I/O MODULE



Function description		
SUPERVISION → VERSION-INFO → I/O MODULE		
I/O MODULE TYPE	8300	Displays the configuration of the I/O module. Display: 12 = MODBUS RS485
MODBUS register:	7086	
Data type:	Integer	
Access:	read	
SW REV. NO. I/O MODULE	8303	Use this function to view the software revision number of the I/O module.
MODBUS register:	7078	
Data type:	String (18)	
Access:	read	

11.2.6 Function groups I/O SUBMODULE 2 to 4



Function description		
SUPERVISION → VERSION-INFO → I/O SUBMODULE 2 to 4		
SUB IN-/OUTPUT TYPE 2 MODBUS register: 7106 Data type: Integer Access: read	8340	Displays the configuration of the I/O submodule. Display: 7 = STATUS INPUT
SW REV. NO. SUB IN-/OUTPUT TYPE 2 MODBUS register: 7190 Data type: String (18) Access: read	8343	Use this function to view the software revision number of the corresponding submodule.
SUB IN-/OUTPUT TYPE 3 MODBUS register: 7107 Data type: Integer Access: read	8360	Displays the configuration of the I/O submodule. Display: 0 = TYPE UNKNOWN 5 = PULS/FREQ. OUT. 6 = STATUS/REL. OUT
SW REV. NO. SUB IN-/OUTPUT TYPE 3 MODBUS register: 7199 Data type: String (18) Access: read	8363	Use this function to view the software revision number of the corresponding submodule.
SUB IN-/OUTPUT TYPE 4 MODBUS register: 7108 Data type: Integer Access: read	8380	Displays the configuration of the I/O submodule. Display: 0 = TYPE UNKNOWN 4 = CURRENT OUTPUT 6 = STATUS/REL. OUT
SW REV. NO. SUB IN-/OUTPUT TYPE 4 MODBUS register: 7199 Data type: String (18) Access: read	8383	Use this function to view the software revision number of the corresponding submodule.

12 Factory settings

12.1 SI units (not for USA and Canada)

12.1.1 Low flow cut off, full scale value, pulse value

Nominal diameter [mm]	Low flow cut off (approx. v = 0.04 m/s)		Full scale value (approx. v = 2.5 m/s)		Pulse value (approx. 2 pulse/s at 2.5 m/s)	
		kg/h		kg/h		kg/p
1	0.08	kg/h	4	kg/h	0.001	kg/p
2	0.40	kg/h	20	kg/h	0.010	kg/p
4	1.80	kg/h	90	kg/h	0.010	kg/p
8	8.00	kg/h	400	kg/h	0.100	kg/p
15	26.00	kg/h	1300	kg/h	0.100	kg/p
25	72.00	kg/h	3600	kg/h	1.000	kg/p
40	180.00	kg/h	9000	kg/h	1.000	kg/p
50	300.00	kg/h	15000	kg/h	10.000	kg/p
80	720.00	kg/h	36000	kg/h	10.000	kg/p
100	1200.00	kg/h	60000	kg/h	10.000	kg/p
150	2600.00	kg/h	130000	kg/h	100.000	kg/p
250	7200.00	kg/h	360000	kg/h	100.000	kg/p

12.1.2 Language

Country	Language	Country	Language
Australia	English	Malaysia	English
Belgium	English	Norway	Norsk
China	Chinese	Poland	Polish
Denmark	English	Portugal	Portuguese
Germany	Deutsch	Austria	Deutsch
England	English	Russia	Russian
Finland	Suomi	Sweden	Svenska
France	Francais	Switzerland	Deutsch
Netherlands	Nederlands	Singapore	English
Hong Kong	English	Spain	Espanol
India	English	South Africa	English
Indonesia	Bahasa Indonesia	Thailand	English
Instruments International	English	Czech Republic	Czech
Italy	Italiano	Hungary	English
Japan	Japanese		

12.1.3 Density, length, temperature

	Unit
Density	kg/l
Length	mm
Temperature	°C

12.2 US units (only for USA and Canada)

12.2.1 Low flow cut off, full scale value, pulse value

Nominal diameter [mm]	Low flow cut off		Full scale value		Pulse value	
	(approx. $v = 0.04$ m/s)		(approx. $v = 2.5$ m/s)		(approx. 2 pulse/s at 2.5 m/s)	
1	0.003	lb/min	0.15	lb/min	0.002	lb/p
2	0.015	lb/min	0.75	lb/min	0.020	lb/p
4	0.066	lb/min	3.30	lb/min	0.020	lb/p
8	0.300	lb/min	15.00	lb/min	0.200	lb/p
15	1.000	lb/min	50.00	lb/min	0.200	lb/p
25	2.600	lb/min	130.00	lb/min	2.000	lb/p
40	6.600	lb/min	330.00	lb/min	2.000	lb/p
50	11.000	lb/min	550.00	lb/min	20.000	lb/p
80	26.000	lb/min	1300.00	lb/min	20.000	lb/p
100	44.000	lb/min	2200.00	lb/min	20.000	lb/p
150	95.000	lb/min	4800.00	lb/min	200.000	lb/p
250	260.000	lb/min	13000.00	lb/min	200.000	lb/p

12.2.2 Language, density, length, temperature

	Unit
Language	English
Density	g/cc
Length	INCH
Temperature	°F

Index of function matrix

Blocks

A = MEASURED VARIABLES	12
B = QUICK SETUP	19
C = USER INTERFACE	28
D = TOTALIZER	45
E = OUTPUT	50
F = INPUT	98
G = BASIC FUNCTION	102
J = SUPERVISION	120
Z = CUSTODY TRANSFER	10

Groups

AAA = MEASURING VALUES	13
ACA = SYSTEM UNITS	14
CAA = CONTROL	29
CCA = MAIN LINE	33
CEA = ADDITIONAL LINE	37
CGA = INFORMATION LINE	41
DAA = TOTALIZER 1	46
DAB = TOTALIZER 2	46
DAC = TOTALIZER 3	46
DJA = HANDLING TOTALIZER	49
EAA = OUTPUTS	51
ECA = PULSE/FREQUENCY OUTPUT	62
EGA = RELAY OUTPUT 1	89
EGB = RELAY OUTPUT 2	89
FAA = STATUS INPUT	99
GDA = MODBUS RS485	103
GIA = PROCESS PARAMETER	106
GLA = SYSTEM PARAMETER	115
GNA = SENSOR DATA	116
JAA = SYSTEM	121
JCA = VERSION INFO	124

Function groups

000 = MAIN VALUES	13
040 = CONFIGURATION	14
042 = ADDITIONAL CONFIGURATION	17
200 = BASIC CONFIGURATION	29
202 = UNLOCKING/LOCKING	31
204 = OPERATION	32
220 = CONFIGURATION	33
222 = MULTIPLEX	35
240 = CONFIGURATION	37
242 = MULTIPLEX	39
260 = CONFIGURATION	41
262 = MULTIPLEX	43
300 = CONFIGURATION	46
304 = OPERATION	48
400 = CONFIGURATION	51
404 = OPERATION	60
408 = INFORMATION	61
420 = CONFIGURATION	62
430 = OPERATION	83
438 = INFORMATION	88
470 = CONFIGURATION	89

474 = OPERATION	93
478 = INFORMATION	94
500 = CONFIGURATION	99
504 = OPERATION	100
508 = INFORMATION	101
630 = CONFIGURATION	103
640 = CONFIGURATION	106
642 = EPD PARAMETER	108
646 = REFERENCE PARAMETER	110
648 = ADJUSTMENT	112
650 = PRESSURE CORRECTION	114
660 = CONFIGURATION	115
680 = CONFIGURATION	116
684 = FLOW COEFFICIENT	117
685 = DENSITY COEFFICIENT	118
686 = ADDITIONAL COEFFICIENT	119
800 = CONFIGURATION	121
804 = OPERATION	122
810 = DEVICE	124
820 = SENSOR	125
822 = AMPLIFIER	126
824 = F-CHIP	127
830 = I/O MODULE	127
832 = INPUT/OUTPUT 1	128
834 = I/O SUBMODULE 2	128
836 = I/O SUBMODULE 3	128
838 = I/O SUBMODULE 4	128

Functions Z...

Z000 = CUSTODY TRANSFER	10
Z001 = PULS. OUT. 1 C.T.	10
Z003 = CURR. OUT. 1 C.T.	10
Z006 = TOTALIZER 1 C.T.	11
Z007 = TOTALIZER 2 C.T.	11
Z008 = TOTALIZER 3 C.T.	11
Z009 = MODBUS CONF. CUSTODY TRANSFER	11

0...

0000 = MASS FLOW	13
0000 = TEMPERATURE	13
0001 = VOLUME FLOW	13
0004 = CORRECTED VOLUME FLOW	13
0005 = DENSITY	13
0006 = REFERENCE DENSITY	13
0400 = UNIT MASS FLOW	14
0401 = UNIT MASS	14
0402 = UNIT VOLUME FLOW	15
0403 = UNIT VOLUME	15
0404 = UNIT CORRECTED VOLUME FLOW	16
0405 = UNIT CORRECTED VOLUME	16
0420 = UNIT DENSITY	17
0421 = UNIT REFERENCE DENSITY	17
0422 = UNIT TEMPERATURE	18
0424 = UNIT LENGTH	18
0426 = UNIT PRESSURE	18

1...

1002 = OS COMMISSION	19
1003 = OS PULSATING FLOW	19
1009 = OS COMMUNICATION	19
1009 = T DAT SAVE/LOAD	20

2...

2000 = LANGUAGE	29
2002 = DISPLAY DAMPING	30
2003 = CONTRAST LCD	30
2004 = BACKLIGHT	30
2020 = ACCESS CODE	31
2021 = DEFINE PRIVATE CODE	31
2022 = STATUS ACCESS	31
2023 = ACCESS CODE	31
2040 = TEST DISPLAY	32
2200 = ASSIGN	33
2201 = 100% VALUE	33
2202 = FORMAT	34
2220 = ASSIGN	35
2221 = 100% VALUE	35
2222 = FORMAT	36
2400 = ASSIGN	37
2401 = 100% VALUE	37
2402 = FORMAT	38
2403 = DISPLAY MODE	38
2420 = ASSIGN	39
2421 = 100% VALUE	39
2422 = FORMAT	40
2423 = DISPLAY MODE	40
2600 = ASSIGN	41
2601 = 100% VALUE	41
2602 = FORMAT	42
2603 = DISPLAY MODE	42
2620 = ASSIGN	43
2621 = 100% VALUE	43
2622 = FORMAT	44
2623 = DISPLAY MODE	44

3...

3000 = ASSIGN	46
3001 = UNIT TOTALIZER	46
3002 = TOTALIZER MODE	47
3003 = RESET TOTALIZER	47
3040 = SUM	48
3041 = OVERFLOW	48
3800 = RESET ALL TOTALIZERS	49
3801 = FAILSAFE MODE	49

4...

4000 = ASSIGN CURRENT OUTPUT	51
4001 = CURRENT SPAN	52
4002 = VALUE 0_4 mA	53
4003 = VALUE 20 mA	55
4004 = MEASURING MODE	55
4005 = TIME CONSTANT	58
4006 = FAILSAFE MODE	59
4040 = ACTUAL CURRENT	60
4041 = SIMULATION CURRENT	60
4042 = VALUE SIMULATION CURRENT	60
4080 = TERMINAL NUMBER	61
4200 = OPERATION MODE	62
4201 = ASSIGN FREQUENCY	63
4202 = START VALUE FREQUENCY	63
4203 = END VALUE FREQUENCY	64
4204 = VALUE f LOW	64
4205 = VALUE f HIGH	65
4206 = MEASURING MODE	67
4207 = OUTPUT SIGNAL	68
4208 = TIME CONSTANT	70
4209 = FAILSAFE MODE	71
4301 = ACTUAL FREQUENCY	83
4302 = SIMULATION FREQUENCY	83
4303 = VALUE SIMULATION FREQUENCY	84
4322 = SIMULATION PULSE	85
4323 = VALUE SIMULATION PULSE	86
4341 = ACTUAL STATUS	87
4342 = SIMULATION SWITCH POINT	87
4343 = VALUE SIMULATION SWITCH POINT	87
4380 = TERMINAL NUMBER	88
4700 = ASSIGN RELAY	89
4701 = ON-VALUE	90
4702 = SWITCH-ON DELAY	90
4703 = OFF-VALUE	90
4704 = SWITCH-OFF DELAY	91
4705 = MEASURING MODE	91
4706 = TIME CONSTANT	92
4740 = ACTUAL STATUS RELAY	93
4741 = SIMULATION SWITCH POINT	93
4742 = VALUE SIMULATION SWITCH POINT	93
4780 = TERMINAL NUMBER	94

5...

5000 = ASSIGN STATUS INPUT	99
5001 = ACTIVE LEVEL	99
5002 = MINIMUM PULSE WIDTH	99
5040 = ACTUAL STATUS INPUT	100
5041 = SIMULATION STATUS INPUT	100
5042 = VALUE SIMULATION STATUS INPUT	100
5080 = TERMINAL NUMBER	101

6...

6300 = TAG NAME	103
6301 = FIELDBUS ADDRESS	103
6302 = BAUDRATE	103
6303 = TRANSMISSION MODE	104
6304 = PARITY	104
6305 = BYTE ORDER	104
6306 = DELAY TELEGRAM REPLY	105
6307 = WRITE PROTECTION	105
6308 = SCAN LIST REGISTER 1 to 16	105
6400 = ASSIGN LOW FLOW CUT OFF	106
6402 = ON-VALUE LOW FLOW CUT OFF	106
6403 = OFF-VALUE LOW FLOW CUT OFF	106
6404 = PRESSURE SHOCK SUPPRESSION	107
6420 = EMPTY PIPE DETECTION	108
6423 = EPD VALUE LOW	108
6424 = EPD VALUE HIGH	108
6425 = EPD RESPONSE TIME	108
6426 = EPD EXC.CURR.	109
6460 = CORRECTED VOLUME CALCULATION	110
6461 = FIXED REFERENCE DENSITY	110
6462 = EXPANSION COEFFICIENT	110
6463 = EXPANSION COEFFICIENT SQUARE	110
6464 = REFERENCE TEMPERATURE	111
6480 = ZEROPOINT ADJUST	112
6482 = DENSITY ADJUST MODE	112
6483 = DENSITY SETPOINT 1	112
6484 = MEASURE FLUID 1	112
6485 = DENSITY SETPOINT 2	113
6486 = MEASURE FLUID 2	113
6487 = DENSITY ADJUST	113
6488 = RESTORE ORIGINAL	113
6500 = PRESSURE MODE	114
6501 = PRESSURE	114
6600 = INSTALLATION DIRECTION SENSOR	115
6602 = DENSITY DAMPING	115
6603 = FLOW DAMPING	115
6605 = POSITIVE ZERO RETURN	115
6800 = K-FACTOR	116
6803 = ZERO POINT	116
6804 = NOMINAL DIAMETER	116
6840 = TEMPERATURE COEFFICIENT KM	117
6841 = TEMPERATURE COEFFICIENT KM2	117
6842 = TEMPERATURE COEFFICIENT KT	117
6843 = CALIBRATION COEFFICIENT KD 1	117
6844 = CALIBRATION COEFFICIENT KD 2	117
6850 = DENSITY COEFFICIENT C0	118
6851 = DENSITY COEFFICIENT C1	118
6852 = DENSITY COEFFICIENT C2	118
6853 = DENSITY COEFFICIENT C3	118
6854 = DENSITY COEFFICIENT C4	118
6855 = DENSITY COEFFICIENT C5	118
6860 = MIN. TEMPERATURE MEASURED	119
6861 = MAX. TEMPERATURE MEASURED	119
6862 = MIN. TEMPERATURE CARRIER TUBE	119
6863 = MAX. TEMPERATURE CARRIER TUBE	119

8...

8005 = ALARM DELAY	121
8007 = STORAGE	121
8040 = ACTUAL SYSTEM CONDITION	122
8041 = PREVIOUS SYSTEM CONDITION	122
8042 = SIMULATION FAILSAFE MODE	122
8043 = SIMULATION MEASURAND	123
8044 = VALUE SIMULATION MEASURAND	123
8046 = SYSTEM RESET	123
8048 = OPERATION HOURS	123
8100 = DEVICE SOFTWARE	124
8200 = SERIAL NUMBER	125
8201 = SENSOR TYPE	125
8205 = SW-REV. NUMBER S-DAT	125
8222 = SW-REV. NUMBER AMPLIFIER	126
8225 = SW-REV. NUMBER T-DAT	126
8226 = LANGUAGE GROUP	126
8240 = STATUS F-CHIP	127
8300 = I/O MODULE TYPE	127
8303 = SW-REV. NO. I/O MODULE	127
8340 = SUB I/O MODULE TYPE 2	128
8343 = SW-REV NO. SUB I/O MODULE TYPE 2	128
8360 = SUB I/O MODULE TYPE 3	128
8363 = SW-REV NO. SUB I/O MODULE TYPE 3	128
8380 = SUB I/O MODULE TYPE 4	128
8383 = SW-REV NO. SUB I/O MODULE TYPE 4	128

Index

A

Access type	8
Active level	99
Actual	
Current	60
Frequency	83
Actual status	
Relay output	93
Status	87
Status input	100
Actual system condition	122
Additional coefficient	119
Additional configuration	17
Additional line	
Assign	37
Configuration	37
Display mode	38
Format	38
Multiplex	39
Assign	39
Display mode	40
Format	40
100% Value	39
100% Value	37
Alarm delay	121
Amplifier (version info)	126
Assign	
Additional line	37
Additional line (Multiplex)	39
Frequency (pulse/freq. output)	63
Information line	41
Information line (Multiplex)	43
Low flow cut off	106
Main line	33
Main line (Multiplex)	35
Pulse (pulse/freq. output)	72
Relay output	89
Status (pulse/freq. output)	78
Status input	99
Totalizer	46
Assign current output	51

B

Basic functions	102
Baudrate	103
Block	
Basic functions	102
Custody transfer	10
Inputs	98
Measured variables	12
Outputs	50
Quick Setup	19
Supervision	120
Totalizer	45
User interface	28
Byte order	104

C

Calibration coefficient	
KD1	117
KD2	117
Code	
Access	31
Access counter	31
Configuration	
Additional line	37
Current output	51
Information line	41
Main line	33
MODBUS	
RS485	103
Process parameter	106
Pulse/frequency output	62
Relay output	89
Sensor data	116
Status input	99
System	121
System parameter	115
System units	14
Totalizer	46
Contrast LCD	30
Control	
Basic configuration	29
Operation	32
Unlocking/locking	31
Corrected Volume calculation	110
Corrected volume flow	13
Curr. out. 1 C.T.	10
Current output	
Actual current	60
Assign	51
Configuration	51
Current span	52
Failsafe mode	59
Information	61
Measuring mode	55
Operation	60
Simulation current	60
Terminal number	61
Time constant	58
Value simulation current	60
Value 0 to 4 mA	53
Value 20 mA	55
Current span	52

D

Damping	
Density	115
Display	30
Data type	8
Define private code	31
Delay resp. tele.	105
Density	13
Density adjustment	113
Density coefficient	
C0	118
C1	118
C2	118
C3	118
C4	118
C5	118
Device software	124
Display lines of local operation	8
Display mode	
Additional line	38
Additional line (Multiplex)	40
Information line	42
Information line (Multiplex)	44

E

EEPROM	8
Empty pipe detection (EPD)	108
End value frequency	64
EPD	
Empty pipe detection	108
Exciting current	109
Parameter	108
Response time	108
Value high	108
Value low	108
Expansion coefficient	110
Square (reference parameter)	110

F

Factory settings	
Full scale value	129
Low flow cut off	129
Pulse value	129
Failsafe mode	
Current span	59
Frequency (pulse/freq. output)	71
Pulse (pulse/freq. output)	77
Totalizer	49
F-CHIP (Version Info)	127
Fieldbus address	103
Fixed	
Reference density	110
Float	8
Flow damping	115

Format

Additional line	38
Additional line (Multiplex)	40
Information line	42
Information line (Multiplex)	44
Main line	34
Main line (Multiplex)	36

Function group

Additional coefficient	119
Additional configuration	17
Adjustment	112
Amplifier	126
Basic configuration (user interface)	29

Configuration

Additional line	37
Current output	51
Information line	41
Main line	33

MODBUS**RS485**

Process parameter	106
Pulse/freq. output	62
Relay output	89
Sensor data	116
Status input	99
System	121
System parameter	115
System units	14
Totalizer	46

Density coefficient	118
Device	124
EPD parameter	108
F-CHIP	127
Flow coefficient	117
I/O Module	127

Information

Current output	61
Pulse/Frequency output	88
Relay output	94
Status input	101

Input/Output**Main values****Multiplex**

Additional line	39
Information line	43
Main line	35

Operation

Current output	60
Pulse/frequency output	83
Relay output	93
Status input	100
System	122
Totalizer	48

Operation (user interface)

Pressure correction	114
Reference parameter	110
Sensor	124, 125
Unlocking/locking (display)	31

Function matrix
 Codes identifying 6
 General layout 6
 Overview 9

G

Group
 Additional line 37
 Control (user interface) 29
 Current output 51
 Handling Totalizer 49
 Information line 41
 Main line 33
 Measuring values 13
 MODBUS
 RS485 103
 Process parameter 106
 Pulse/frequency output 62
 Relay output 89
 Sensor data 116
 Status input 99
 System 121
 System parameter 115
 System units 14
 Version Info 124

H

Handling Totalizer 49

I

I/O Module 127
 I/O module type 127
 I/O submodule
 Type 2 128
 Type 3 128
 Type 4 128
 Illustration of function description 8
 Information
 Current output 61
 Pulse/frequency output 88
 Relay output 94
 Status input 101
 Information line
 Assign 41
 Configuration 41
 Display mode 42
 Format 42
 Multiplex 43
 Assign 43
 Display mode 44
 Format 44
 100% Value 43
 100% Value 41
 Input/output 2 to 4 128
 Inputs 98
 Installation direction sensor 115
 Integer 8

K

K-Factor 116

L

Language 29
 Factory setting (country) 129
 Language group 126
 Local operation (display lines) 8
 Low flow cut off
 Assign 106
 Off value 106
 On value 106

M

Main line
 Assign 33
 Configuration 33
 Format 34
 Multiplex 35
 Assign 35
 Format 36
 100% Value 35
 100% Value 33
 Main values 13
 Mapping reg. 1 to 16 105
 Mass flow 13
 Max. writes 8
 Maximum
 Medium temperature 119
 Temperature carrier tube 119
 Measure
 Fluid 1 112
 Fluid 2 113
 Measure fluid 1 112
 Measure fluid 2 113
 Measured variables 12
 Measuring mode
 Current span 55
 Frequency (pulse/freq. output) 67
 Pulse (pulse/freq. output) 74
 Relay output 91
 Status (pulse/freq. output) 81
 Measuring values 13
 Main values 13
 Minimal
 Temperature carrier tube 119
 Minimum
 Medium temperature 119
 Minimum pulse width (status input) 99
 MODBUS configuration custody transfer 11
 MODBUS register 8
 MODBUS RS485 103
 Mode
 Data transfer 104
 Density adjustment 112
 Multiplex
 Additional line 39
 Information line 43
 Main line 35

N

Nominal diameter 116

O

Off value

Low flow cut off 106

Pulse/freq. output 80

Relay output 90

On value

Low flow cut off 106

Pulse/freq. output 79

Relay output 90

Operation

Current output 60

Pulse/frequency output 83

Relay output 93

Status input 100

System 122

Totalizer 48

User interface 32

Operation hours 123

Output signal

Frequency (pulse/freq. output) 68

Pulse (pulse/freq. output) 75

Outputs 50

Overflow 48

P

Parity 104

Positive zero return 115

Pressure 114

Correction 114

Mode 114

Pressure shock suppression 107

Previous system condition 122

Process parameter

Adjustment 112

Configuration 106

EPD parameter 108

Pressure correction 114

Reference parameter 110

Pulse

Value 72

Width 73

Pulse/freq. output

Frequency

Actual 83

Assign frequency 63

End value frequency 64

Failsafe level 71

Failsafe mode 71

Measuring mode 67

Output signal 68

Simulation 83

Start value frequency 63

Time constant 70

Value F Low 64

Value simulation 84

Value-f high 65

Operation mode 62

Pulse

Assign pulse 72

Failsafe mode 77

Measuring mode 74

Output signal 75

Pulse value 72

Pulse Width 73

Simulation 85

Value simulation 86

Status

Actual 87

Assign status 78

Measuring mode 81

Off value 80

On value 79

Simulation 87

Switch-off delay 80

Switch-on delay 79

Time constant 82

Value simulation 87

Terminal number 88

Pulse/frequency output

Configuration 62

Information 88

Operation 83

Q

Quick Setup 19

Commissioning 19

Communication 19

Gas measurement 19

Pulsating flow 19

R

Read 8

Reference density 13

Fixed 110

Reference Temperature 111

Relay output

Actual status 93

Assign 89

Configuration 89

Flow direction 95

General 95

Information 94

Limit value 95

Measuring mode 91

Off value 90

On value 90

Operation 93

Simulation switch point 93

Switching behavior 96

Switch-off delay 91

Switch-on delay 90

Terminal number 94

Time constant 92

Value simulation switch point 93

Reset		Switching behavior of the relay output	96
All totalizers	49	Switch-off delay	
System	123	Pulse/freq. output	80
Totalizer	47	Relay output	91
Restore original	113	Switch-on delay	
S		Pulse/freq. output	79
Sensor (Version info)	124	Relay output	90
Sensor data		System	
Additional coefficient	119	Configuration	121
Configuration	116	Operation	122
Density coefficient	118	System condition	
Flow coefficient	117	Actual	122
Sensor type	125	Previous	122
Serial number	125	System parameter	115
Setpoint		System reset	123
Density 1	112	System units	
Density 2	113	Additional configuration	17
Simulation		Configuration	14
Current	60	T	
Failsafe mode	122	Tag Name	103
Frequency	83	T-DAT Save/Load	20
Measured variable	123	Temperature	13
Pulse	85	Temperature coefficient	
Relay output	93	KM	117
Status input	100	KM2	117
Switch point	87	KT	117
Start value frequency	63	Terminal number	
Status access	31	Current output	61
Status F-Chip	127	Pulse/freq. output	88
Status input		Relay output	94
Active level	99	Status input	101
Actual status	100	Test display	32
Assign	99	Time constant	
Configuration	99	Current span	58
Information	101	Frequency (pulse/freq. output)	70
Minimum pulse width	99	Relay output	92
Operation	100	Status (pulse/freq. output)	82
Simulation	100	Totalizer	45
Terminal number	101	Assign	46
Value simulation	100	Configuration	46
Storage	121	Failsafe mode	49
String	8	Operation	48
Sum	48	Overflow	48
Supervision	120	Reset all totalizers	49
SW revision number		Reset totalizer	47
Amplifier	126	Sum	48
I/O Module	127	Totalizer Mode	47
I/O submodule		Unit	46
Type 2	128	Totalizer Mode	47
Type 3	128	Totalizers 1 to 3, custody transfer measurement	11
Type 4	128		
S-DAT	125		
T-DAT	126		

U

Unit	
Corrected volume	16
Corrected volume flow	16
Density	17
Length	18
Mass	14
Mass flow	14
Reference density	17
Temperature	18
Totalizer	46
Volume	15
Volume flow	15
Unlocking/locking (display)	31
User interface	28

V

Value	
EPD value high	108
EPD value low	108
F low	64
Failsafe level	71
Simulation current	60
Simulation frequency	84
Simulation measurand	123
Simulation Pulse	86
Simulation relay output	93
Simulation status input	100
Simulation switch point	87
0 to 4 mA	53
20 mA	55
Value F high	65
Version Info	
Amplifier	126
F-CHIP	127
I/O Module	127
Input/output 1 to 4	128
Sensor	124
Volume flow	13

W

Write	8
Write protection	105
Writes (max.)	8

Z

Zero point	116
Zero point adjustment	112

Zahlen

100% Value	
Additional line	37
Additional line (Multiplex)	39
Information line	41
Information line (Multiplex)	43
Main line	33
Main line (Multiplex)	35

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation
