


Description of Device Parameters

Deltabar PMD63B

Differential pressure measurement
PROFINET over Ethernet-APL



1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Document structure

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.

The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating tool**.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.


The submenus visible to a user depend on the **User role** (→  61) they are logged in with. This document lists the submenus and their parameters that are available to the User role **Maintenance**.

The operating menu is dynamic and adapts the choice of parameters to the selected options.


 For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected



- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:
Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

⚠ WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

⚠ CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of information

 Indicates additional information

 Reference to documentation

 Operation via local display

 Operation via operating tool

 Write-protected parameter

1.6 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu

Navigation

Operating tool

| | |
|--|--|
| Guidance | →  16 |
| ▶ Commissioning | →  16 |
| ▶ Heartbeat Technology | →  17 |
| ▶ Heartbeat Verification | →  17 |
| ▶ SSD: Statistical Sensor Diagnostics | →  18 |
| ▶ Process window | →  18 |
| ▶ Import / Export | →  18 |
| ▶ Compare | →  18 |
| Diagnostics | →  19 |
| ▶ Active diagnostics | →  19 |
| Active diagnostics | →  19 |
| Timestamp | →  19 |
| Previous diagnostics | →  19 |
| Timestamp | →  20 |
| Operating time from restart | →  20 |
| Operating time | →  20 |
| ▶ Event logbook | →  20 |
| ▶ Minimum/maximum values | →  21 |
| Pressure min | →  21 |
| Pressure max | →  21 |
| Counter limit underruns sensor Pmin | →  21 |
| Counter limit overruns sensor Pmax | →  22 |
| Counter underruns of user limit Pmin | →  22 |

| | |
|---|-------|
| Counter overruns of user limit Pmax | → 22 |
| Minimum sensor temperature | → 23 |
| Maximum sensor temperature | → 23 |
| Counter limit underruns sensor Tmin | → 23 |
| Counter limit overruns sensor Tmax | → 23 |
| Counter underruns of user limit Tmin | → 24 |
| Counter overruns of user limit Tmax | → 24 |
| Minimum terminal voltage | → 24 |
| Maximum terminal voltage | → 24 |
| Minimum electronics temperature | → 24 |
| Maximum electronics temperature | → 25 |
| Reset user defined counters P and T | → 25 |
| ► Simulation | → 25 |
| Simulation | → 25 |
| Diagnostic event simulation | → 26 |
| Value pressure simulation | → 26 |
| ► Heartbeat Technology | → 26 |
| ► Heartbeat Verification | → 26 |
| Date/time Heartbeat Verification | → 26 |
| Operating time (Verification) | → 27 |
| Verification result | → 27 |
| Status | → 27 |
| ► Statistical Sensor Diagnostics | → 28 |
| SSD: Statistical Sensor Diagnostics | → 28 |
| System status | → 28 |

| | |
|-----------------------------------|-------|
| Signal status | → 28 |
| Signal noise status | → 29 |
| ► Diagnostic settings | → 29 |
| ► Properties | → 29 |
| SSD Out of range delay time | → 29 |
| SSD Monitoring delay time | → 30 |
| 500 Process alert pressure | → 30 |
| Low alert value | → 30 |
| High alert value | → 30 |
| 501 Process alert scaled variable | → 31 |
| Low alert value | → 31 |
| High alert value | → 31 |
| User temperature process alert | → 31 |
| Low alert value | → 32 |
| High alert value | → 32 |
| ► Configuration | → 32 |
| ► Configuration | → 32 |
| 436 Diagnostic behavior | → 32 |
| 436 Event category | → 33 |
| 500 Diagnostic behavior | → 33 |
| 500 Event category | → 33 |
| 501 Diagnostic behavior | → 34 |
| 501 Event category | → 34 |

| | |
|--------------------------------|-------|
| 502 Diagnostic behavior | → 34 |
| 502 Event category | → 35 |
| ► Process | → 35 |
| Sensor pressure range behavior | → 35 |
| Sensor pressure range behavior | → 35 |
| 841 Event category | → 36 |
| 900 Event category | → 36 |
| 900 Diagnostic behavior | → 36 |
| 906 Diagnostic behavior | → 37 |
| 906 Event category | → 37 |
| Application | → 38 |
| ► Measured values | → 41 |
| Pressure | → 41 |
| Scaled variable | → 41 |
| Sensor temperature | → 42 |
| Terminal voltage 1 | → 42 |
| Electronics temperature | → 42 |
| ► Measuring units | → 38 |
| Pressure unit | → 38 |
| Decimal places pressure | → 38 |
| Temperature unit | → 39 |
| Scaled variable unit | → 39 |
| Free text | → 40 |
| Decimal places scaled variable | → 41 |

► Sensor

→ 43

► Sensor calibration

→ 43

Zero adjustment

→ 43

Calibration offset

→ 43

Zero adjustment offset

→ 43

Sensor Trim Reset

→ 44

Lower sensor trim

→ 44

Upper sensor trim

→ 45

Lower range value

→ 45

Upper range value

→ 46

► Sensor configuration

→ 46

Damping

→ 46

HP/LP swap

→ 46

► Sensor limits

→ 47

Lower Range Limit

→ 47

Upper Range Limit

→ 47

Minimum span

→ 47

Sensor temperature lower range limit

→ 48

Sensor temperature upper range limit

→ 48

► Scaled variable

→ 48

Scaled variable unit

→ 48

Free text

→ 49

Pressure

→ 50

Scaled variable transfer function

→ 50

Pressure value 1

→ 50

| | |
|-----------------------------------|-------|
| Scaled variable value 1 | → 50 |
| Pressure value 2 | → 51 |
| Scaled variable value 2 | → 51 |
| Low flow cut off | → 51 |
| ► PROFINET | → 52 |
| ► Configuration | → 52 |
| PROFINET device name | → 52 |
| Parameter change acknowledge mode | → 52 |
| Acknowledge parameter change | → 52 |
| Descriptor | → 53 |
| ► Analog input | → 53 |
| ► Analog input 1 to 7 | → 53 |
| Process value | → 53 |
| Assign process variable | → 53 |
| Damping | → 54 |
| ► Binary input | → 55 |
| ► Binary input 1 to 2 | → 55 |
| Controller input value | → 55 |
| ► Binary output | → 56 |
| Set point value | → 56 |
| BO block output value | → 57 |
| Failure behavior | → 57 |
| Failure behavior delay | → 57 |
| Fixed value | → 57 |

| | |
|----------------------------------|------|
| ▶ Information | → 58 |
| Device ID | → 58 |
| PA profile version | → 58 |
| ▶ Application relation | → 58 |
| AR state | → 58 |
| MAC address IO controller | → 59 |
| MAC address backup IO controller | → 59 |
| IP address IO controller | → 59 |
| IP address backup IO controller | → 59 |
| System | → 60 |
| ▶ Device management | → 60 |
| Device tag | → 60 |
| Locking status | → 60 |
| Configuration counter | → 60 |
| Reset device | → 61 |
| ▶ User management | → 61 |
| ▶ User management | → 61 |
| User role | → 61 |
| Delete password | → 62 |
| Forgot password? | → 62 |
| ▶ Enter password | → 62 |
| Password | → 62 |
| Enter access code | → 62 |
| Status password entry | → 63 |
| ▶ Define password | → 63 |

| | |
|-----------------------------|--|
| New password | →  63 |
| Confirm new password | →  63 |
| Status password entry | →  64 |
| ► Change password | →  64 |
| Old password | →  64 |
| New password | →  64 |
| Confirm new password | →  65 |
| Status password entry | →  65 |
| ► Recover password | →  65 |
| Reset password | →  65 |
| Status password entry | →  66 |
| ► Connectivity | →  66 |
| ► Interfaces | →  66 |
| Display operation | →  66 |
| Web server functionality | →  66 |
| Bluetooth activation | →  67 |
| Service (UART-CDI) | →  67 |
| ► Ethernet | →  67 |
| MAC address | →  67 |
| IP address | →  67 |
| Subnet mask | →  68 |
| Default gateway | →  68 |
| Service IP active | →  68 |
| Interface connection status | →  68 |
| Interface speed | →  69 |

| | |
|---------------------------------------|--|
| Duplex status | →  69 |
| Auto negotiation status | →  69 |
| Received packet number | →  69 |
| Sent packet number | →  70 |
| Number of failed received packets | →  70 |
| Number of failed sent packets | →  70 |
| Signal to noise ratio | →  70 |
| Number of failed received packets | →  71 |
| Active TCP connections | →  71 |
| Supported TCP connections | →  71 |
| TCP connection requests | →  72 |
| TCP connection timeouts | →  72 |
| Number of TCP connections closed | →  72 |
| Number of received TCP packets | →  72 |
| TCP sent packet number | →  72 |
| Number of TCP failed received packets | →  73 |
| Available UDP ports | →  73 |
| UDP received packet number | →  73 |
| UDP sent packet number | →  73 |
| Number of UDP failed received packets | →  74 |
| ► Display | →  74 |
| Language | →  74 |
| Format display | →  75 |
| Value 1 display | →  75 |

| | |
|---------------------------------|-------|
| Value 2 ... 4 display | → 75 |
| Contrast display | → 76 |
| ► Date/time | → 76 |
| Date/time | → 76 |
| Time zone | → 76 |
| Enable NTP | → 77 |
| NTP server address | → 78 |
| Clock synchronized | → 78 |
| ► Geolocation | → 78 |
| Location description | → 78 |
| Longitude | → 78 |
| Latitude | → 79 |
| Altitude | → 79 |
| ► Information | → 79 |
| Device name | → 79 |
| Manufacturer | → 80 |
| Serial number | → 80 |
| Order code | → 80 |
| Firmware version | → 80 |
| Hardware version | → 81 |
| Extended order code 1 ... 3 | → 81 |
| Checksum | → 81 |
| ► Software configuration | → 86 |
| CRC device configuration | → 86 |

Activate SW option

→ 86

Software option overview

→ 86

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of guided wizards and cross-thematic special functions.

Navigation  Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - SSD: Statistical Sensor Diagnostics
 - Process window
- Import / Export
- Compare

Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

WARNING

If the wizard is aborted before all the necessary parameters have been configured, any settings already made are saved.

The device may be in an undefined state!

- ▶ Reset the device to factory settings.

 Navigation

Guidance → Commissioning

Parameters for the "Commissioning" wizard

The following parameters are configured or displayed in this wizard:

- **Device identification**
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - Time zone
 - Date/time
 - PROFINET device name
 - IP address
 - Descriptor
 - MAC address
 - Device ID
 - Manufacturer ID
- **Measurement adjustments**
 - Damping
 - Assign scaled variable?
 - Pressure unit
 - Temperature unit
 - Scaled variable unit
 - Zero adjustment
 - Pressure
- **Output settings**
 - Scaled variable transfer function
 - Low flow cut off
 - Lower Range Limit
 - Upper Range Limit
 - Minimum span
 - Linearization
 - Pressure value 1/2
 - Scaled variable value 1/2
 - Assign process variable

Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application



Special Documentation on Heartbeat Technology is available via the Internet:
www.endress.com → Download

 Navigation

Guidance → Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation

Guidance → Heartbeat Techn. → Heartbeat Verif.

SSD: Statistical Sensor Diagnostics

Using statistical analysis of the pressure signal, process anomalies such as plugged impulse lines can be detected. This wizard supports the settings and thresholds that should lead to a diagnostic message.

Navigation

Guidance → Heartbeat Techn. → Stat. Sens. Diag

Process window

This wizard uses user-defined limits for pressure and temperature to detect unwanted installation or application anomalies.

Applications:

- Defective heat tracer or insulation
- Frozen process connections
- Dynamic pressure peaks etc.

Navigation

Guidance → Heartbeat Techn. → Process window

Import / Export**Save / Restore**

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create configuration report

Under Create configuration report, device documentation can be saved in PDF format. This device documentation contains the following general device information:

- Information on device parameters
- Event list
- Diagnostic list

Navigation

Guidance → Import / Export

Compare**Compare datasets**

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import / Export
- Datasets with the configuration currently in the device

Navigation

Guidance → Compare

3.2 Diagnostics

Navigation

  Diagnostics

3.2.1 Active diagnostics

Navigation

  Diagnostics → Active diagnos.

Active diagnostics

Navigation

  Diagnostics → Active diagnos. → Active diagnos.

Description

Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.

User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure

Timestamp

Navigation

  Diagnostics → Active diagnos. → Timestamp

Description

Displays the timestamp for the currently active diagnostic message.

User interface

Days (d), hours (h), minutes (m), seconds (s)

Previous diagnostics

Navigation

  Diagnostics → Active diagnos. → Prev.diagnostics

Description

Displays the diagnostic message for the last diagnostic event that has ended.

User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure

Timestamp

| | |
|-----------------------|---|
| Navigation |   Diagnostics → Active diagnos. → Timestamp |
| Description | Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended. |
| User interface | Days (d), hours (h), minutes (m), seconds (s) |

Operating time from restart

| | |
|-----------------------|--|
| Navigation |   Diagnostics → Active diagnos. → Time fr. restart |
| Description | Indicates how long the device has been in operation since the last time the device was restarted. |
| User interface | Days (d), hours (h), minutes (m), seconds (s) |

Operating time

| | |
|-----------------------|--|
| Navigation |   Diagnostics → Active diagnos. → Operating time |
| Description | Indicates how long the device has been in operation. |
| User interface | Days (d), hours (h), minutes (m), seconds (s) |

3.2.2 Diagnostic list

Navigation   Diagnostics → Diagnostic list

3.2.3 Event logbook

Navigation   Diagnostics → Event logbook

Clear event list



| | |
|--------------------|--|
| Navigation |  Diagnostics → Event logbook → Clear event list |
| Description | Delete all entries of the event list. |

| | |
|-------------------------------|--|
| Selection | <ul style="list-style-type: none"> ▪ Cancel ▪ Clear data |
| Factory setting | Cancel |
| Additional information | Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert |

3.2.4 Minimum/maximum values

Navigation

 Diagnostics → Min/max val.

Pressure min

| | |
|------------------------|---|
| Navigation |  Diagnostics → Min/max val. → Pressure min |
| Description | Minimum value measured by the device |
| User interface | Signed floating-point number |
| Factory setting | Positive floating-point number |

Pressure max

| | |
|------------------------|---|
| Navigation |  Diagnostics → Min/max val. → Pressure max |
| Description | Maximum value measured by the device |
| User interface | Signed floating-point number |
| Factory setting | Negative floating-point number |

Counter limit underruns sensor Pmin

| | |
|-----------------------|--|
| Navigation |  Diagnostics → Min/max val. → Counter P < Pmin |
| Description | Counts how many times the value underruns the sensor specific minimum values. Sensor specific minimum values are shown in Application/Sensor menu. |
| User interface | 0 to 65 535 |

| | |
|------------------------|---|
| Factory setting | 0 |
|------------------------|---|

Counter limit overruns sensor Pmax

| | |
|-------------------|---|
| Navigation |  Diagnostics → Min/max val. → Counter P > Pmax |
|-------------------|---|

| | |
|--------------------|---|
| Description | Counts how many times the value overruns the sensor specific maximum values. Sensor specific maximum values are shown in Application/Sensor menu. |
|--------------------|---|

| | |
|-----------------------|-------------|
| User interface | 0 to 65 535 |
|-----------------------|-------------|

| | |
|------------------------|---|
| Factory setting | 0 |
|------------------------|---|

Counter underruns of user limit Pmin

| | |
|-------------------|---|
| Navigation |  Diagnostics → Min/max val. → Counter < P user |
|-------------------|---|

| | |
|--------------------|--|
| Description | Counts how many times the value underruns the minimum values defined by the user. User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties menu. |
|--------------------|--|

| | |
|-----------------------|-------------|
| User interface | 0 to 65 535 |
|-----------------------|-------------|

| | |
|------------------------|---|
| Factory setting | 0 |
|------------------------|---|

| | |
|-------------------------------|--|
| Additional information | Only visible if Process window in Heartbeat Monitoring is activated. |
|-------------------------------|--|

Counter overruns of user limit Pmax

| | |
|-------------------|---|
| Navigation |  Diagnostics → Min/max val. → Counter > P user |
|-------------------|---|

| | |
|--------------------|---|
| Description | Counts how many times the value overruns the maximum values defined by the user. User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties menu. |
|--------------------|---|

| | |
|-----------------------|-------------|
| User interface | 0 to 65 535 |
|-----------------------|-------------|

| | |
|------------------------|---|
| Factory setting | 0 |
|------------------------|---|

| | |
|-------------------------------|--|
| Additional information | Only visible if Process window in Heartbeat Monitoring is activated. |
|-------------------------------|--|

Minimum sensor temperature

Navigation   Diagnostics → Min/max val. → Min. sensor temp**Description** Minimum value measured by the device
Users cannot reset this value.

Maximum sensor temperature

Navigation   Diagnostics → Min/max val. → Max. sensor temp**Description** Maximum value measured by the device
Users cannot reset this value.

Counter limit underruns sensor Tmin

Navigation   Diagnostics → Min/max val. → Counter T < Tmin**Description** Counts how often the value falls below the sensor-specific minimum values. The sensor-specific minimum values are displayed in the Application (→ 38)/Sensor (→ 43) menu.**User interface** 0 to 65 535**Factory setting** 0

Counter limit overruns sensor Tmax

Navigation   Diagnostics → Min/max val. → Counter T > Tmax**Description** Counts how often the value exceeds the sensor-specific maximum values. The sensor-specific maximum values are displayed in the Application (→ 38)/Sensor (→ 43) menu.**User interface** 0 to 65 535**Factory setting** 0

Counter underruns of user limit Tmin

Navigation  Diagnostics → Min/max val. → Counter < T user**User interface** 0 to 65 535**Factory setting** 0**Additional information** Only visible if Process window in Heartbeat Monitoring is activated.

Counter overruns of user limit Tmax

Navigation  Diagnostics → Min/max val. → Counter > T user**User interface** 0 to 65 535**Factory setting** 0**Additional information** Only visible if Process window in Heartbeat Monitoring is activated.

Minimum terminal voltage

Navigation  Diagnostics → Min/max val. → Min.term.volt.**Description** Minimum terminal voltage measured (supply).**User interface** 0.0 to 50.0 V

Maximum terminal voltage

Navigation  Diagnostics → Min/max val. → Max.term.voltage**Description** Maximum terminal voltage measured (supply).**User interface** 0.0 to 50.0 V

Minimum electronics temperature

Navigation  Diagnostics → Min/max val. → Min.electr.temp.**Description** Minimum measured temperature of the main electronics.

| | |
|-----------------------|------------------------------|
| User interface | Signed floating-point number |
|-----------------------|------------------------------|

Maximum electronics temperature

| | |
|-----------------------|---|
| Navigation |   Diagnostics → Min/max val. → Max.electr.temp. |
| Description | Maximum measured temperature of the main electronics. |
| User interface | Signed floating-point number |

Reset user defined counters P and T

| | |
|-------------------------------|---|
| Navigation |   Diagnostics → Min/max val. → Reset count. P T |
| Selection | <ul style="list-style-type: none"> ▪ Cancel ▪ Confirm |
| Factory setting | Cancel |
| Additional information | Only visible if Process window in Heartbeat Monitoring is activated. |

3.2.5 Simulation

Navigation   Diagnostics → Simulation

Simulation

| | |
|------------------------|---|
| Navigation |   Diagnostics → Simulation → Simulation |
| Description | Simulates one or more process variables and/or events. Warning: Output will reflect the simulated value or event. |
| Selection | <ul style="list-style-type: none"> ▪ Off ▪ Pressure ▪ Diagnostic event simulation |
| Factory setting | Off |

Diagnostic event simulation**Navigation**

Diagnostics → Simulation → Diag. event sim.

Description

Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select "Off".

Selection

- Off
- Drop-down list of diagnostic events

Factory setting

Off

Value pressure simulation**Navigation**

Diagnostics → Simulation → Value pressure

User entry

Signed floating-point number

Factory setting

0 mbar

3.2.6 Heartbeat Technology

Navigation

Diagnostics → Heartbeat Techn.

Heartbeat Verification*Navigation*

Diagnostics → Heartbeat Techn. → Heartbeat Verif.

Date/time Heartbeat Verification**Navigation**

Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification

Description

Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.

User interface

Character string comprising numbers, letters and special characters

Factory setting 01.01.1970 00:00:00

Operating time (Verification)

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time

Description Value of the operating hours counter at the time of verification.

User interface Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Verific. result

Description Result of Heartbeat Verification.

User interface

- Not done
- Passed
- Not done
- Failed

Factory setting Not done

Status

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status

Description Shows the actual status.

User interface

- Done
- Busy
- Failed
- Not done

Factory setting Not done

Statistical Sensor Diagnostics

Navigation



Diagnostics → Heartbeat Techn. → SSD



SSD: Statistical Sensor Diagnostics

Navigation

Diagnostics → Heartbeat Techn. → SSD → Stat. Sens. Diag

Description

Enable or disable SSD.

After selecting 'Disable', no statistical sensor diagnosis takes place. No diagnostic messages are output.

Selection

- Disable
- Enable

Factory setting

Disable

System status

Navigation

Diagnostics → Heartbeat Techn. → SSD → System status

User interface

- Idle
- No sufficient signal noise
- Stable
- Not stable
- Verify System Dynamics

Factory setting

Idle

Signal status

Navigation

Diagnostics → Heartbeat Techn. → SSD → Signal status

User interface

- Idle
- Building Baseline
- Verifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Factory setting

Idle

Signal noise status

| | |
|------------------------|---|
| Navigation |   Diagnostics → Heartbeat Techn. → SSD → Noise status |
| User interface | <ul style="list-style-type: none"> ■ Idle ■ Building Baseline ■ Verifying Baseline ■ Verifying baseline failed ■ Monitoring ■ Out of range ■ Monitoring inactive |
| Factory setting | Idle |

Counter Baseline creation SSD

| | |
|-------------------------------|---|
| Navigation |   Diagnostics → Heartbeat Techn. → SSD → Counter Baseline |
| Description | Specifies how often the baseline has been rebuilt. |
| User interface | Positive integer |
| Factory setting | 0 |
| Additional information | Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: - |

3.2.7 Diagnostic settings

Navigation  Diagnostics → Diag. settings

Properties

Navigation  Diagnostics → Diag. settings → Properties

SSD Out of range delay time

| | |
|------------------------|--|
| Navigation |  Diagnostics → Diag. settings → Properties → SSD Delay time |
| User entry | 0 to 604 800 s |
| Factory setting | 600 s |

SSD Monitoring delay time

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → SSD Verz. Zeit |
| User entry | 0 to 86 400 s |
| Factory setting | 60 s |

500 Process alert pressure

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → 500 Pressure |
| Description | Define whether user-defined pressure limits should be set. If 'No' is selected, no analysis will take place and no event message will be generated. |
| Selection | <ul style="list-style-type: none">■ Off■ On |
| Factory setting | Off |

Low alert value

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → Low alert value |
| Description | Set area. If this limit value is exceeded or undercut, an event is generated. There is no hysteresis. |
| User entry | Signed floating-point number |
| Factory setting | 0 mbar |

High alert value

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → High alert value |
| Description | Set area. If this limit value is exceeded or undercut, an event is generated. There is no hysteresis. |
| User entry | Signed floating-point number |
| Factory setting | 500 mbar |

501 Process alert scaled variable

| | |
|------------------------|---|
| Navigation | Diagnostics → Diag. settings → Properties → 501 Scaled var. |
| Description | Define whether user-defined limits should be set. If 'No' is selected, no analysis will take place and no event message will be generated. |
| Selection | <ul style="list-style-type: none">■ Off■ On |
| Factory setting | Off |

Low alert value

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → Low alert value |
| Description | Set area. If this limit value is exceeded or undercut, an event is generated. There is no hysteresis. |
| User entry | Signed floating-point number |
| Factory setting | 0 % |

High alert value

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → High alert value |
| Description | Set area. If this limit value is exceeded or undercut, an event is generated. There is no hysteresis. |
| User entry | Signed floating-point number |
| Factory setting | 100 % |

User temperature process alert

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Properties → UserTemp alert |
| Description | Define whether the user-defined sensor temperature limits should be set. If 'No' no analysis and therefore no event message will take place. |
| Selection | <ul style="list-style-type: none">■ Off■ On |
| Factory setting | Off |

Low alert value

Navigation Diagnostics → Diag. settings → Properties → Low alert value

Description Set area.
If this limit value is exceeded or undercut, an event is generated. There is no hysteresis.

User entry -50 to 150 °C

Factory setting -35 °C

High alert value

Navigation Diagnostics → Diag. settings → Properties → High alert value

Description Set area.
If this limit value is exceeded or undercut, an event is generated. There is no hysteresis.

User entry -50 to 150 °C

Factory setting 85 °C

Configuration

Navigation Diagnostics → Diag. settings → Configuration

Configuration

Navigation Diagnostics → Diag. settings → Configuration → Configuration

436 Diagnostic behavior

Navigation Diagnostics → Diag. settings → Configuration → Configuration → 436 Diag. behav.

Selection

- Warning
- Logbook entry only

Factory setting Warning

436 Event category

| | |
|------------------------|--|
| Navigation |  Diagnostics → Diag. settings → Configuration → Configuration → 436 Event category |
| User interface | <ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized |
| Factory setting | Maintenance required (M) |

500 Diagnostic behavior

| | |
|------------------------|--|
| Navigation |   Diagnostics → Diag. settings → Configuration → Configuration → 500 Diag. behav. |
| Description | <p>Select event behavior</p> <p>'Logbook entry only': no digital or analog transmission of the message</p> <p>'Warning': Current output unchanged. Message is output digitally (default).</p> <p>'Alarm': Current output assumes the set alarm current.</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p> |
| Selection | <ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only |
| Factory setting | Off |

500 Event category

| | |
|------------------------|--|
| Navigation |   Diagnostics → Diag. settings → Configuration → Configuration → 500Event category |
| User interface | <ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized |
| Factory setting | Out of specification (S) |

501 Diagnostic behavior

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Configuration → Configuration → 501 Diag. behav. |
| Description | Select event behavior 'Logbook entry only': no digital or analog transmission of the message 'Warning': Current output unchanged. Message is output digitally (default). 'Alarm': Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. |
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only |
| Factory setting | Off |

501 Event category

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Configuration → Configuration → 501Event category |
| User interface | <ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ Not categorized |
| Factory setting | Out of specification (S) |

502 Diagnostic behavior

| | |
|--------------------|--|
| Navigation | Diagnostics → Diag. settings → Configuration → Configuration → 502 Diag. behav. |
| Description | Select event behavior 'Logbook entry only': no digital or analog transmission of the message 'Warning': Current output unchanged. Message is output digitally (default). 'Alarm': Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. |

| | |
|------------------|---|
| Selection | <ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only |
|------------------|---|

| | |
|------------------------|-----|
| Factory setting | Off |
|------------------------|-----|

502 Event category

| | |
|-------------------|--|
| Navigation |   Diagnostics → Diag. settings → Configuration → Configuration → 502Event category |
|-------------------|--|

| | |
|-----------------------|--|
| User interface | <ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized |
|-----------------------|--|

| | |
|------------------------|--------------------------|
| Factory setting | Out of specification (S) |
|------------------------|--------------------------|

Process

| | |
|-------------------|--|
| <i>Navigation</i> |   Diagnostics → Diag. settings → Configuration → Process |
|-------------------|--|

Sensor pressure range behavior



| | |
|-------------------|---|
| Navigation |   Diagnostics → Diag. settings → Configuration → Process → P-range behavior |
|-------------------|---|

| | |
|--------------------|--|
| Description | Alarm and warning messages appear on the display. If the permissible conditions are reached again, the warning message disappears. |
|--------------------|--|

Select event behavior:

'Alarm':

The signal outputs assume the specified alarm condition. A diagnostic message is generated.

'Warning':

The signal outputs assume the specified warning condition. A diagnostic message is generated.

'Logbook entry only':

No digital or analog forwarding of the message. A diagnostic message is written in the logbook.

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none"> ■ Alarm ■ Warning ■ Logbook entry only |
|------------------|--|

| | |
|------------------------|---------|
| Factory setting | Warning |
|------------------------|---------|

841 Event category

| | |
|------------------------|--|
| Navigation |  Diagnostics → Diag. settings → Configuration → Process → 841 Event category |
| User interface | <ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ Not categorized |
| Factory setting | Out of specification (S) |

900 Diagnostic behavior



| | |
|------------------------|--|
| Navigation |   Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav. |
| Description | Select event behavior 'Logbook entry only': No forwarding of the message via the fieldbus. 'Warning': Warning message is transmitted via the fieldbus (default setting). Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. |
| Selection | <ul style="list-style-type: none">■ Warning■ Logbook entry only |
| Factory setting | Warning |

900 Event category

| | |
|------------------------|--|
| Navigation |   Diagnostics → Diag. settings → Configuration → Process → 900Event category |
| User interface | <ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ Not categorized |
| Factory setting | Maintenance required (M) |

906 Diagnostic behavior

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav. |
| Description | Select event behavior 'Logbook entry only': No forwarding of the message via the fieldbus. 'Warning': Warning message is transmitted via the fieldbus (default setting). Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument. |
| Selection | <ul style="list-style-type: none">■ Off■ Warning■ Logbook entry only |
| Factory setting | Off |

906 Event category

| | |
|------------------------|--|
| Navigation | Diagnostics → Diag. settings → Configuration → Process → 906Event category |
| User interface | <ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ Not categorized |
| Factory setting | Out of specification (S) |

3.3 Application

Navigation

Application

3.3.1 Measuring units

Navigation

Application → Measuring units

Pressure unit



Navigation

Application → Measuring units → Pressure unit

Selection

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- psi
- kgf/cm²
- gf/cm²
- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

Factory setting

Depends on the order option

Decimal places pressure



Navigation

Application → Measuring units → Decimal pressure

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- Automatic
- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

Automatic

Temperature unit



Navigation Application → Measuring units → Temperature unit

Description Used to display the electronics temperature.

Selection

| | <i>SI units</i> | <i>US units</i> |
|---|-----------------|-----------------|
| ■ | °C | °F |
| ■ | K | |

Factory setting °C

Scaled variable unit



Navigation Application → Measuring units → SV unit

Description Use 'Free text', first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

| Selection | <i>SI units</i> | <i>US units</i> | <i>Imperial units</i> |
|-----------|------------------------|-------------------------|-----------------------|
| | ■ % | ■ ft | ■ gal (imp) |
| | ■ mm | ■ in | ■ gal/s (imp) |
| | ■ cm | ■ ft ³ | ■ gal/min (imp) |
| | ■ m | ■ gal (us) | ■ gal/h (imp) |
| | ■ l | ■ bbl (us;oil) | |
| | ■ hl | ■ oz | |
| | ■ m ³ | ■ lb | |
| | ■ g | ■ STon | |
| | ■ kg | ■ lb/s | |
| | ■ t | ■ lb/min | |
| | ■ g/s | ■ lb/h | |
| | ■ kg/s | ■ STon/min | |
| | ■ kg/min | ■ STon/h | |
| | ■ kg/h | ■ STon/d | |
| | ■ t/min | ■ ft ³ /s | |
| | ■ t/h | ■ ft ³ /min | |
| | ■ t/d | ■ ft ³ /h | |
| | ■ m ³ /s | ■ ft ³ /d | |
| | ■ m ³ /min | ■ gal/s (us) | |
| | ■ m ³ /h | ■ gal/min (us) | |
| | ■ m ³ /d | ■ gal/h (us) | |
| | ■ l/s | ■ gal/d (us) | |
| | ■ l/min | ■ bbl/s (us;oil) | |
| | ■ l/h | ■ bbl/min (us;oil) | |
| | ■ Nm ³ /h | ■ bbl/h (us;oil) | |
| | ■ NI/h | ■ bbl/d (us;oil) | |
| | ■ Sm ³ /s | ■ Sft ³ /min | |
| | ■ Sm ³ /min | ■ Sft ³ /h | |
| | ■ Sm ³ /h | ■ Sft ³ /d | |
| | ■ Sm ³ /d | | |
| | ■ Nm ³ /s | | |
| | ■ g/cm ³ | | |
| | ■ kg/m ³ | | |
| | ■ Nm ³ /min | | |
| | ■ Nm ³ /d | | |

Custom-specific units

Free text

Factory setting

%

Free text**Navigation**

Application → Measuring units → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Factory setting

Free text

Decimal places scaled variable**Navigation**

Application → Measuring units → Decimal scaled

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

3.3.2 Measured values*Navigation*

Application → Measured values

Sensor pressure**Navigation**

Application → Measured values → Sensor pressure

User interface

Signed floating-point number

Factory setting

0 mbar

Additional information**Access:**

- Read access: Expert
- Write access: -

Pressure**Navigation**

Application → Measured values → Pressure

Factory setting

0 mbar

Scaled variable**Navigation**

Application → Measured values → Scaled variable

User interface

Signed floating-point number

Factory setting 0 %

Sensor temperature

Navigation  Application → Measured values → Sensor temp.

Description Displays the current temperature of the sensor.

User interface Floating point number with sign

Terminal voltage 1

Navigation  Application → Measured values → Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V

Electronics temperature

Navigation  Application → Measured values → Electronics temp

Description Displays the current temperature of the main electronics.

User interface Signed floating-point number

3.3.3 Sensor

Navigation

  Application → Sensor

Sensor calibration

Navigation

  Application → Sensor → Sensor cal.

Zero adjustment



Navigation

  Application → Sensor → Sensor cal. → Zero adjustment

Description

Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Factory setting

No

Calibration offset



Navigation

  Application → Sensor → Sensor cal. → Calibr offset

User entry

Signed floating-point number

Factory setting

0 mbar

Additional information

Parameters only available for absolute pressure sensors.

Zero adjustment offset



Navigation

  Application → Sensor → Sensor cal. → Zero adj. offset

User entry

Signed floating-point number

Factory setting

0 mbar

Sensor Trim Reset**Navigation**

Application → Sensor → Sensor cal. → Sen. Trim Reset

Selection

- No
- Confirm

Factory setting

No

Lower sensor trim measured value**Navigation**

Application → Sensor → Sensor cal. → LowerTrimMeasVal

User interface

Signed floating-point number

Factory setting

0 mbar

Lower sensor trim**Navigation**

Application → Sensor → Sensor cal. → LowerSensor trim

Description

Using the Lower sensor trim and Upper sensor trim parameters, a sensor can be recalibrated, e.g. if the sensor is to be precisely calibrated to the measuring range. Maximum measurement accuracy of the sensor is achieved when the value for the Lower sensor trim parameter is as close as possible to the lower measuring range, and the value for the Upper sensor trim parameter is as close as possible to the upper measuring range. There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value.

The more accurate the reference device used for sensor calibration, the higher the measurement accuracy of the pressure transmitter will be later.

Using the Lower sensor trim and Upper sensor trim parameters, a new value is then assigned to the applied pressure.

The entered value must not exceed **Sensor pressure** +/- 10 % of the permissible maximum pressure (URL).

Input as follows:

- Apply reference pressure for the lower measuring range.
- Enter and confirm the reference pressure in the Lower sensor trim field.
- Apply reference pressure for the upper measuring range.
- Enter and confirm the reference pressure in the Upper sensor trim field.
- The sensor calibration is now complete.

User entry

Signed floating-point number

Factory setting

0 mbar

Upper sensor trim measured value

| | |
|------------------------|---|
| Navigation |  Application → Sensor → Sensor cal. → UpperTrimMeasVal |
| User interface | Signed floating-point number |
| Factory setting | 500 mbar |

Upper sensor trim

| | |
|------------------------|---|
| Navigation |  Application → Sensor → Sensor cal. → UpperSensor trim |
| Description | <p>Using the Lower sensor trim and Upper sensor trim parameters, a sensor can be recalibrated, e.g. if the sensor is to be precisely calibrated to the measuring range. Maximum measurement accuracy of the sensor is achieved when the value for the Lower sensor trim parameter is as close as possible to the lower measuring range, and the value for the Upper sensor trim parameter is as close as possible to the upper measuring range.</p> <p>There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value.</p> <p>The more accurate the reference device used for sensor calibration, the higher the measurement accuracy of the pressure transmitter will be later.</p> <p>Using the Lower sensor trim and Upper sensor trim parameters, a new value is then assigned to the applied pressure.</p> |
| | <p> The entered value must not exceed Sensor pressure +/- 10 % of the permissible maximum pressure (URL).</p> <p>Input as follows:</p> <ul style="list-style-type: none"> ▪ Apply reference pressure for the lower measuring range. ▪ Enter and confirm the reference pressure in the Lower sensor trim field. ▪ Apply reference pressure for the upper measuring range. ▪ Enter and confirm the reference pressure in the Upper sensor trim field. ▪ The sensor calibration is now complete. |
| User entry | Signed floating-point number |
| Factory setting | 500 mbar |

Lower range value

| | |
|------------------------|--|
| Navigation |  Application → Sensor → Sensor cal. → Lower range val. |
| Description | <p>The calibrated span corresponds to the span between the LRV and URV.</p> <p>Factory setting: 0 to URL.</p> <p>Other calibrated spans can be ordered as customized span.</p> |
| User entry | Signed floating-point number |
| Factory setting | 0 mbar |

Upper range value**Navigation**

Application → Sensor → Sensor cal. → Upper range val.

Description

The calibrated span corresponds to the span between the LRV and URV.

Factory setting: 0 to URL.

Other calibrated spans can be ordered as customized span.

User entry

Signed floating-point number

Factory setting

500 mbar

Basic settings**Navigation**

Application → Sensor → Basic settings

Damping**Navigation**

Application → Sensor → Sensor conf. → Damping

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own “Damping” parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry

0 to 999.0 s

Factory setting

0 s

HP/LP swap**Navigation**

Application → Sensor → Sensor conf. → HP/LP swap

Description

With this parameter the high and low pressure side of the differential pressure transmitter can be interchanged.

Selection

- No
- Yes

Factory setting No

Sensor limits

Navigation



Application → Sensor → Sensor limits

Lower Range Limit

Navigation

Application → Sensor → Sensor limits → LRL

Description Indicates the lower measuring limit of the sensor.

User interface Signed floating-point number

Factory setting Depends on the order option

Upper Range Limit

Navigation

Application → Sensor → Sensor limits → URL

Description Indicates the upper measuring limit of the sensor.

User interface Signed floating-point number

Factory setting Depends on the order option

Minimum span

Navigation

Application → Sensor → Sensor limits → Minimum span

Description Specifies the smallest possible measuring span of the sensor.

User interface Signed floating-point number

Factory setting 0.498504 mbar

Sensor temperature lower range limit

Navigation  Application → Sensor → Sensor limits → Sens.temp.lo.lim

Factory setting -35 °C

Sensor temperature upper range limit

Navigation  Application → Sensor → Sensor limits → Sens.temp.up.lim

Factory setting 85 °C

Scaled variable

Navigation   Application → Sensor → Scaled variable

Scaled variable unit 

Navigation   Application → Sensor → Scaled variable → SV unit

Description Use 'Free text', first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

| Selection | SI units | US units | Imperial units |
|------------------------------|-------------------------|-----------------|----------------|
| ■ % | ■ ft | ■ gal (imp) | |
| ■ mm | ■ in | ■ gal/s (imp) | |
| ■ cm | ■ ft ³ | ■ gal/min (imp) | |
| ■ m | ■ gal (us) | ■ gal/h (imp) | |
| ■ l | ■ bbl (us;oil) | | |
| ■ hl | ■ oz | | |
| ■ m ³ | ■ lb | | |
| ■ g | ■ STon | | |
| ■ kg | ■ lb/s | | |
| ■ t | ■ lb/min | | |
| ■ g/s | ■ lb/h | | |
| ■ kg/s | ■ STon/min | | |
| ■ kg/min | ■ STon/h | | |
| ■ kg/h | ■ STon/d | | |
| ■ t/min | ■ ft ³ /s | | |
| ■ t/h | ■ ft ³ /min | | |
| ■ t/d | ■ ft ³ /h | | |
| ■ m ³ /s | ■ ft ³ /d | | |
| ■ m ³ /min | ■ gal/s (us) | | |
| ■ m ³ /h | ■ gal/min (us) | | |
| ■ m ³ /d | ■ gal/h (us) | | |
| ■ l/s | ■ gal/d (us) | | |
| ■ l/min | ■ bbl/s (us;oil) | | |
| ■ l/h | ■ bbl/min (us;oil) | | |
| ■ Nm ³ /h | ■ bbl/h (us;oil) | | |
| ■ NI/h | ■ bbl/d (us;oil) | | |
| ■ Sm ³ /s | ■ Sft ³ /min | | |
| ■ Sm ³ /min | ■ Sft ³ /h | | |
| ■ Sm ³ /h | ■ Sft ³ /d | | |
| ■ Sm ³ /d | | | |
| ■ Nm ³ /s | | | |
| ■ g/cm ³ | | | |
| ■ kg/m ³ | | | |
| ■ Nm ³ /min | | | |
| ■ Nm ³ /d | | | |
| <i>Custom-specific units</i> | | | |
| Free text | | | |
| Factory setting | % | | |

Free text

Navigation Application → Sensor → Scaled variable → Free text

User entry Character string comprising numbers, letters and special characters (32)

Factory setting Free text

Pressure

Navigation  Application → Sensor → Scaled variable → Pressure

Factory setting 0 mbar

Scaled variable transfer function 

Navigation  Application → Sensor → Scaled variable → Scal. v. trans.

Description 'Linear'

The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit. Deviating from the bar graph (output signal), the digital value on the display shows continues to be the eradicated value.

'Square root'

The root flow signal is used for the output signal. The 'Flow (square root)' output signal is indicated on the on-site display with a root symbol.

'Table'

The output is defined according to the scaled variable / pressure table entered.

Selection

- Linear
- Square root *
- Table

Factory setting Linear

Pressure value 1 

Navigation  Application → Sensor → Scaled variable → P. value 1

Description Enter pressure for the first scaling point. 'Scaled variable value 1' will be allocated to this pressure.

User entry Signed floating-point number

Factory setting 0 mbar

Scaled variable value 1

Navigation  Application → Sensor → Scaled variable → Sc. var.value 1

Description Enter value for the first scaling point. This value is allocated to 'Pressure value 1'.

* Visibility depends on order options or device settings

User interface Signed floating-point number

Factory setting 0 %

Pressure value 2



Navigation Application → Sensor → Scaled variable → P. value 2

Description Enter pressure for the second scaling point. 'Scaled variable value 2' will be allocated to this pressure.

User entry Signed floating-point number

Factory setting 500 mbar

Scaled variable value 2



Navigation Application → Sensor → Scaled variable → Sc. var.value 2

Description Enter value for the second scaling point. This value is allocated to 'Pressure value 2'.

User entry Signed floating-point number

Factory setting 100 %

Low flow cut off



Navigation Application → Sensor → Scaled variable → Low flow cut off

Description When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.

User entry 0.0 to 50.0 %

Factory setting 5 %

3.3.4 PROFINET

Navigation

  Application → PROFINET

Configuration

Navigation

  Application → PROFINET → Configuration

PROFINET device name

Navigation

  Application → PROFINET → Configuration → PROFINET DevName

Description

Up to 240 characters are allowed.

The following syntax must be used:

- 1 or more identifiers, separated with [.]
- Identifier length is 1 to 63 characters
- Identifier consists of [a-z 0-9] only lowercase letters and numbers allowed.

Parameter change acknowledge mode

Navigation

  Application → PROFINET → Configuration → ParaChngAcknMode

Description

Select how to acknowledge the displayed flag when changing the device configuration:

- "Auto acknowledge": the flag disappears automatically after 20 seconds.
- "Manual acknowledge": the flag must be acknowledged manually.

Selection

- Auto acknowledge
- Manual acknowledge

Factory setting

Auto acknowledge

Acknowledge parameter change

Navigation

  Application → PROFINET → Configuration → AcknParaChange

Description

If the Option "Manual acknowledge" is selected as the acknowledgement type, then a parameter change must be acknowledged with the "Reset update event flag" option.

Selection

- No acknowledge
- Reset update event flag

Factory setting

No acknowledge

Descriptor

Navigation  Application → PROFINET → Configuration → Descriptor**Description** Enter a description for the measuring point**User entry** Character string comprising numbers, letters and special characters (54)**Analog input***Navigation*  Application → PROFINET → Analog input*Analog input 1 to 3**Navigation*  Application → PROFINET → Analog input → Analog input 1 to 3

Process value

Navigation  Application → PROFINET → Analog input → Analog input 1 to 7 → Process value**Description** Shows the process value reported to the controller for further processing**User interface** Signed floating-point number**Factory setting** 0 mbar

Assign process variable

Navigation  Application → PROFINET → Analog input → Analog input 1 to 7 → Assign variable**Description****User interface**

- Pressure ^{*}
- Scaled variable ^{*}
- Sensor temperature
- Sensor pressure ^{*}
- Electronics temperature
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}

Factory setting Pressure

* Visibility depends on order options or device settings

Damping

Navigation  Application → PROFINET → Analog input → Analog input 1 to 7 → Damping

Description Enter time constant for input damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.

User entry Positive floating-point number

Factory setting 1.0 s

Simulation value

Navigation  Application → PROFINET → Analog input → Analog input 1 to 7 → Simulation value

Description Enter the simulation value for the selected process variable

User entry Signed floating-point number

Factory setting 0 mbar

Additional information **Access:**
■ Read access: Expert
■ Write access: Maintenance

Simulated status

Navigation  Application → PROFINET → Analog input → Analog input 1 to 7 → Simulated status

Description To simulate a process status for this block. Possible input values can be taken from the PA profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD".

0x24 (decimal 36) for status "BAD"

User entry 0 to 255

Factory setting 60

Additional information **Access:**
■ Read access: Expert
■ Write access: Maintenance

Simulation

| | |
|-------------------------------|--|
| Navigation |  Application → PROFINET → Analog input → Analog input 1 to 7 → Simulation |
| Description | Switch simulation of the analog input on or off (Off = 0, On > 0) |
| User entry | 0 to 255 |
| Factory setting | 0 |
| Additional information | Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Maintenance |

Binary input

Navigation  Application → PROFINET → Binary input

Binary input 1 to 2

Navigation  Application → PROFINET → Binary input → Binary input 1 to 2

Controller input value

| | |
|------------------------|--|
| Navigation |  Application → PROFINET → Binary input → Binary input 1 to 2 → ControllInputVal |
| Description | Shows for each device function the state reported to the controller for further processing |
| User interface | 0 to 255 |
| Factory setting | 0 |

Simulation value

| | |
|------------------------|--|
| Navigation |  Application → PROFINET → Binary input → Binary input 1 to 2 → Simulation value |
| Description | Enter the simulated state for each device function |
| User entry | 0 to 255 |
| Factory setting | 0 |

Additional information**Access:**

- Read access: Expert
- Write access: Maintenance

Simulated status

Navigation Application → PROFINET → Binary input → Binary input 1 to 2 → Simulated status**Description**

Specify the status of the simulated state for each device function (Hex)

User entry

0 to 255

Factory setting

60

Additional information**Access:**

- Read access: Expert
- Write access: Maintenance

Simulation

Navigation Application → PROFINET → Binary input → Binary input 1 to 2 → Simulation**Description**

Switch simulation of the binary input on or off (Off = 0; On <> 0)

User entry

0 to 255

Factory setting

0

Additional information**Access:**

- Read access: Expert
- Write access: Maintenance

Binary output**Navigation** Application → PROFINET → Binary output

Set point value

Navigation Application → PROFINET → Binary output → Set point value**User entry**

0 to 255

Factory setting

0

BO block output value

| | |
|------------------------|--|
| Navigation |   Application → PROFINET → Binary output → BOBlockOutValue |
| Description | Shows for each device function the state reported to the measuring device for further processing |
| User entry | 0 to 255 |
| Factory setting | 0 |

Failure behavior

| | |
|------------------------|---|
| Navigation |   Application → PROFINET → Binary output → Failure behavior |
| Description | Select failure behavior in the event of a failure (value with status 'Bad') |
| Selection | <ul style="list-style-type: none"> ▪ Fixed value ▪ Last valid value ▪ Actual value |
| Factory setting | Fixed value |

Failure behavior delay

| | |
|------------------------|---|
| Navigation |   Application → PROFINET → Binary output → FailBehavDelay |
| Description | Enter a delay until in the event of a failure (value with status 'Bad') the failure behavior specified applies |
| User entry | Positive floating-point number |
| Factory setting | 0 s |

Fixed value

| | |
|------------------------|--|
| Navigation |   Application → PROFINET → Binary output → Fixed value |
| Description | Enter value to report in the event of a failure (value with status 'Bad') |
| User entry | 0 to 255 |
| Factory setting | 0 |

Information

Navigation

  Application → PROFINET → Information

Device ID

Navigation

  Application → PROFINET → Information → Device ID

User interface

0 to 65 535

Factory setting

41 514

PA profile version

Navigation

  Application → PROFINET → Information → PA profile vers.

User interface

0 to 65 535

Factory setting

0x402

Application relation

Navigation

  Application → PROFINET → Applicat. relat.

AR state

Navigation

  Application → PROFINET → Applicat. relat. → AR state

Description

Shows whether an AR connection and a system redundancy have been established

User interface

- Active
- Not active
- Redundancy 1AR active
- Redundancy 2AR active

Factory setting

Not active

MAC address IO controller

| | |
|------------------------|---|
| Navigation |   Application → PROFINET → Applicat. relat. → MAC IO contr. |
| Description | Shows the MAC address of the only or of the primary IO controller |
| User interface | Character string comprising numbers, letters and special characters |
| Factory setting | 0x00 |

MAC address backup IO controller

| | |
|------------------------|--|
| Navigation |   Application → PROFINET → Applicat. relat. → MAC backup IO c. |
| Description | Shows the MAC address of the backup IO controller |
| User interface | Character string comprising numbers, letters and special characters |
| Factory setting | 0x00 |

IP address IO controller

| | |
|------------------------|--|
| Navigation |   Application → PROFINET → Applicat. relat. → IP IO controller |
| Description | Shows the IP address of the only or of the primary IO controller |
| User interface | Character string comprising numbers, letters and special characters |
| Factory setting | 0x00 |

IP address backup IO controller

| | |
|------------------------|---|
| Navigation |   Application → PROFINET → Applicat. relat. → IP backup IO c. |
| Description | Shows the IP address of the backup IO controller |
| User interface | Character string comprising numbers, letters and special characters |
| Factory setting | 0x00 |

3.4 System

Navigation

  System

3.4.1 Device management

Navigation

  System → Device manag.

Device tag

Navigation

  System → Device manag. → Device tag

Description

Enter a name for the measuring point to identify the measuring device in the plant

User entry

Character string comprising numbers, letters and special characters (32)

Locking status

Navigation

  System → Device manag. → Locking status

Description

Indicates the type of locking.

'Hardware locked' (HW)

The device is locked by the 'WP' switch on the main electronics module. To unlock, set the switch into the OFF position.

'Temporarily locked' (SW)

The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.

User interface

- Hardware locked
- Temporarily locked

Configuration counter

Navigation

  System → Device manag. → Config. counter

Description

Shows the number of changes made to static parameters (e.g. configuration parameters)

User interface

0 to 65 535

Factory setting

0

Reset device**Navigation**

System → Device manag. → Reset device

Description

Reset the device configuration - either entirely or in part - to a defined state

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Factory setting

Cancel

3.4.2 User management

Navigation System → User manag.

User management

Navigation System → User manag. → User manag.

User role**Navigation**

System → User manag. → User manag. → User role

Description

Shows the access authorization to the parameters via the operating tool

User interface

- Operator
- Maintenance
- Expert
- Production
- Development

Factory setting

Maintenance

* Visibility depends on order options or device settings

Delete password**Navigation**

System → User manag. → User manag. → Delete password

Description

Deletes the 'Maintenance' password.

After deleting, the 'Operator' role will be no more available.

All users have read/write access rights.

User entry

Character string comprising numbers, letters and special characters (1)

Forgot password?**Navigation**

System → User manag. → User manag. → Forgot password?

User entry

Character string comprising numbers, letters and special characters (1)

Enter password*Navigation*

System → User manag. → Enter password

Password**Navigation**

System → User manag. → Enter password → Password

Description

Enter the password for the 'Maintenance' user role to get access to the functionality of this role.

User entry

Character string comprising numbers, letters and special characters (16)

Enter access code**Navigation**

System → User manag. → Enter password → Ent. access code

Description

For authorized service personnel only.

User entry

0 to 9999

Factory setting

0

Status password entry

Navigation  System → User manag. → Enter password → Status pw entry

Description Use this function to display the status of the password verification.

User interface -----

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting -----

Define password

Navigation  System → User manag. → Define password

New password



Navigation  System → User manag. → Define password → New password

Description Define the new 'Maintenance' password.
 A new password is valid after it has been confirmed within the 'Confirm new password' parameter.
 Any valid password consists of 4 to 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (16)

Confirm new password



Navigation  System → User manag. → Define password → Conf. new passw.

Description Enter the new password again to confirm.

User entry Character string comprising numbers, letters and special characters (16)

Status password entry

Navigation  System → User manag. → Define password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting

Change password

Navigation  System → User manag. → Change password

Old password



Navigation  System → User manag. → Change password → Old password

Description Enter the current password, to subsequently change the existing password.

User entry Character string comprising numbers, letters and special characters (16)

New password



Navigation  System → User manag. → Change password → New password

Description Define the new 'Maintenance' password.

A new password is valid after it has been confirmed within the 'Confirm new password' parameter.

Any valid password consists of 4 to 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (16)

Confirm new password



| | |
|--------------------|--|
| Navigation | System → User manag. → Change password → Conf. new passw. |
| Description | Enter the new password again to confirm. |
| User entry | Character string comprising numbers, letters and special characters (16) |

Status password entry

| | |
|------------------------|---|
| Navigation | System → User manag. → Change password → Status pw entry |
| Description | Use this function to display the status of the password verification. |
| User interface | <ul style="list-style-type: none">■ -----■ Wrong password■ Password rule violated■ Password accepted■ Permission denied■ Confirm PW mismatch■ Reset password accepted■ Invalid user role■ Wrong sequence of entry |
| Factory setting | ----- |

Recover password

Navigation System → User manag. → Recover password

Reset password

| | |
|--------------------|---|
| Navigation | System → User manag. → Recover password → Reset password |
| Description | Enter a code to reset the current 'Maintenance' password. The code is delivered by your local support. |
| User entry | Character string comprising numbers, letters and special characters (16) |

Status password entry

Navigation  System → User manag. → Recover password → Status pw entry

Description Use this function to display the status of the password verification.

User interface -----

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Factory setting -----

3.4.3 Connectivity

Navigation   System → Connectivity

Interfaces

Navigation   System → Connectivity → Interfaces

Display operation

Navigation   System → Connectivity → Interfaces → DisplayOperation

Selection

- Disable
- Enable

Factory setting Enable

Web server functionality

Navigation   System → Connectivity → Interfaces → Webserver funct.

Description Switch the Web server on and off.

Selection

- Disable
- Enable

| | |
|------------------------|--------|
| Factory setting | Enable |
|------------------------|--------|

Bluetooth activation

| | |
|-------------------|---|
| Navigation |   System → Connectivity → Interfaces → Bluetooth active |
|-------------------|---|

| | |
|--------------------|--|
| Description | If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool. Reactivating via the SmartBlue app is not possible. |
|--------------------|--|

| | |
|------------------|---|
| Selection | <ul style="list-style-type: none"> ▪ Disable ▪ Enable |
|------------------|---|

| | |
|------------------------|--------|
| Factory setting | Enable |
|------------------------|--------|

Service (UART-CDI)

| | |
|-------------------|--|
| Navigation |   System → Connectivity → Interfaces → Service (CDI) |
|-------------------|--|

| | |
|------------------|---|
| Selection | <ul style="list-style-type: none"> ▪ Disable ▪ Enable |
|------------------|---|

| | |
|------------------------|--------|
| Factory setting | Enable |
|------------------------|--------|

Ethernet

| | |
|-------------------|--|
| <i>Navigation</i> |   System → Connectivity → Ethernet |
|-------------------|--|

MAC address

| | |
|-------------------|--|
| Navigation |   System → Connectivity → Ethernet → MAC Address |
|-------------------|--|

| | |
|--------------------|---|
| Description | Shows the MAC address of the measuring device |
|--------------------|---|

| | |
|-----------------------|---|
| User interface | Character string comprising numbers, letters and special characters |
|-----------------------|---|

IP address

| | |
|-------------------|---|
| Navigation |   System → Connectivity → Ethernet → IP address |
|-------------------|---|

| | |
|--------------------|--|
| Description | Enter the IP address of the device. Then accept the change with "Apply". |
|--------------------|--|

User entry Character string comprising numbers, letters and special characters (15)

Factory setting 192.168.1.212

Subnet mask

Navigation System → Connectivity → Ethernet → Subnet mask

Description Enter subnet mask of the measuring device. Then accept the change with "Apply".

User entry Character string comprising numbers, letters and special characters (15)

Factory setting 255.255.255.0

Default gateway

Navigation System → Connectivity → Ethernet → Default gateway

Description Enter IP address for the default gateway of the measuring device. Then accept the change with "Apply".

User entry Character string comprising numbers, letters and special characters (15)

Factory setting 0.0.0.0

Service IP active

Navigation System → Connectivity → Ethernet → Service IP act.

User interface

- No
- Yes

Factory setting No

Interface connection status

Navigation System → Connectivity → Ethernet → Interface status

User interface

- Connected
- Not connected

Factory setting Not connected

Interface speed

| | |
|------------------------|--|
| Navigation |   System → Connectivity → Ethernet → Interface speed |
| User interface | Positive integer |
| Factory setting | 0 MBaud |

Duplex status

| | |
|------------------------|--|
| Navigation |   System → Connectivity → Ethernet → Duplex status |
| User interface | <ul style="list-style-type: none">■ Full duplex■ Half duplex■ Unknown |
| Factory setting | Unknown |

Auto negotiation status

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → Auto negot.stat. |
| User interface | <ul style="list-style-type: none">■ Idle■ In progress■ Completed■ Failed■ Speed detection failed |
| Factory setting | Idle |

Received packet number

| | |
|------------------------|--|
| Navigation |   System → Connectivity → Ethernet → RX packet no. |
| User interface | Positive integer |
| Factory setting | 0 |

Sent packet number

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TX packet number |
| User interface | Positive integer |
| Factory setting | 0 |

Number of failed received packets

| | |
|------------------------|--|
| Navigation |   System → Connectivity → Ethernet → FailRcvdPackets |
| User interface | Positive integer |
| Factory setting | 0 |

Number of failed sent packets

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → FailTXPacketsNo. |
| User interface | Positive integer |
| Factory setting | 0 |

Reset Ethernet diagnostics



| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → ResetEthernDiag. |
| Selection | <ul style="list-style-type: none">▪ Cancel▪ Reset |
| Factory setting | Cancel |

Signal to noise ratio

| | |
|-----------------------|--|
| Navigation |   System → Connectivity → Ethernet → SNR |
| Description | Shows the signal to noise ratio of the Ethernet-APL connection. A value >21dB is good and >23dB is excellent. |
| User interface | Signed floating-point number |

| | |
|------------------------|------|
| Factory setting | 0 dB |
|------------------------|------|

Number of failed received packets

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → FailRXPacketsNo. |
| Description | Shows the number of failed received packets. |
| User interface | 0 to 65 535 |
| Factory setting | 0 |

Reset Ethernet diagnostics

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → ResetEthernDiag. |
| Selection | <ul style="list-style-type: none">■ Cancel■ Reset |
| Factory setting | Cancel |

Active TCP connections

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → Act. TCP connec. |
| User interface | 0 to 65 535 |
| Factory setting | 0 |

Supported TCP connections

| | |
|------------------------|--|
| Navigation |   System → Connectivity → Ethernet → Supported TCP |
| User interface | 0 to 65 535 |
| Factory setting | 0 |

TCP connection requests

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TCPConnecRequest |
| User interface | 0 to 65 535 |
| Factory setting | 0 |

TCP connection timeouts

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TCPConnecTimeout |
| User interface | 0 to 255 |
| Factory setting | 0 |

Number of TCP connections closed

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TCPConnect.close |
| User interface | 0 to 255 |
| Factory setting | 0 |

Number of received TCP packets

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → No.RX TCP Packet |
| User interface | Positive integer |
| Factory setting | 0 |

TCP sent packet number

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TCP TX PacketNo. |
| User interface | Positive integer |
| Factory setting | 0 |

Number of TCP failed received packets

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → TCPFailRXPackets |
| User interface | Positive integer |
| Factory setting | 0 |

Reset Ethernet diagnostics

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → ResetEthernDiag. |
| Selection | <ul style="list-style-type: none">■ Cancel■ Reset |
| Factory setting | Cancel |

Available UDP ports

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → Avail. UDP ports |
| User interface | Positive integer |
| Factory setting | 0 |

UDP received packet number

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → UDP RX PacketNo. |
| User interface | Positive integer |
| Factory setting | 0 |

UDP sent packet number

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → UDP TX PacketNo. |
| User interface | Positive integer |
| Factory setting | 0 |

Number of UDP failed received packets

| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → UDPFailRXPackets |
| User interface | Positive integer |
| Factory setting | 0 |

Reset Ethernet diagnostics



| | |
|------------------------|---|
| Navigation |   System → Connectivity → Ethernet → ResetEthernDiag. |
| Selection | <ul style="list-style-type: none">▪ Cancel▪ Reset |
| Factory setting | Cancel |

3.4.4 Display

Navigation   System → Display

Language

| | |
|---------------------|---|
| Navigation |   System → Display → Language |
| Prerequisite | A local display is provided. |
| Description | Use this function to select the configured language on the local display. |
| Selection | <ul style="list-style-type: none">▪ English▪ Deutsch▪ Français▪ Español▪ Italiano▪ Nederlands▪ Portuguesa▪ Polski▪ русский язык (Russian)▪ Svenska▪ Türkçe▪ 中文 (Chinese)▪ 日本語 (Japanese)▪ 한국어 (Korean) |

- Bahasa Indonesia
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  System → Display → Format display

Description Select how measured values are shown on the display

Selection

- 1 value, max. size
- 2 values

Factory setting 1 value, max. size

Value 1 display



Navigation  System → Display → Value 1 display

Description Select the measured value that is shown on the local display

Selection

- Pressure
- Scaled variable
- Sensor temperature

Factory setting Pressure

Value 2 ... 4 display



Navigation  System → Display → Value 2 ... 4 display

Description Select the measured value that is shown on the local display

Selection

- None
- Pressure
- Scaled variable
- Sensor temperature

Factory setting None

Contrast display

| | |
|------------------------|---|
| Navigation |   System → Display → Contrast display |
| Description | Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle) |
| User entry | 20 to 80 % |
| Factory setting | 30 % |

3.4.5 Date/time

Navigation   System → Date/time

Date/time

| | |
|------------------------|--|
| Navigation |   System → Date/time → Date/time |
| Description | Displays the date and time entered. |
| User interface | Character string comprising numbers, letters and special characters |
| Factory setting | 2025-01-01 00:00:00 |

Time zone



| | |
|--------------------|--|
| Navigation |   System → Date/time → Time zone |
| Description | Select the time zone. Every time the time zone is changed, a logbook entry is created. |

Selection*Other units*

- UTC-12:00
- UTC-11:00
- UTC-10:00
- UTC-09:30
- UTC-09:00
- UTC-08:00
- UTC-07:00
- UTC-06:00
- UTC-05:00
- UTC-04:00
- UTC-03:30
- UTC-03:00
- UTC-02:30
- UTC-02:00
- UTC-01:00
- UTC 00:00
- UTC+01:00
- UTC+02:00
- UTC+03:00
- UTC+03:30
- UTC+04:00
- UTC+04:30
- UTC+05:00
- UTC+05:30
- UTC+05:45
- UTC+06:00
- UTC+06:30
- UTC+07:00
- UTC+08:00
- UTC+08:45
- UTC+09:00
- UTC+09:30
- UTC+10:00
- UTC+10:30
- UTC+11:00
- UTC+12:00
- UTC+12:45
- UTC+13:00
- UTC+13:45
- UTC+14:00

Factory setting

UTC 00:00

Enable NTP**Navigation**

System → Date/time → Enable NTP

Selection

- No
- Yes

Factory setting

No

NTP server address **Navigation**  System → Date/time → NTP server add.**Description** IP address of the NTP server.**User entry** Character string comprising numbers, letters and special characters (64)**Factory setting** 192.168.1.1

Clock synchronized**Navigation**   System → Date/time → Clock synch.**Description** Timestamp of last synchronization with an NTP server.**User interface** Character string comprising numbers, letters and special characters**Factory setting** -----

3.4.6 Geolocation

Navigation  System → Geolocation

Location description **Navigation**   System → Geolocation → Location descr.**Description** Enter a description for the location**User entry** Character string comprising numbers, letters and special characters (32)**Factory setting** somewhere

Longitude **Navigation**   System → Geolocation → Longitude**Description** Enter the longitude.**User entry** -180 to 180 °

Factory setting 0 °

Latitude

Navigation System → Geolocation → Latitude

Description Enter latitude

User entry -90 to 90 °

Factory setting 0 °

Altitude

Navigation System → Geolocation → Altitude

Description Enter altitude

User entry Signed floating-point number

Factory setting 0 m

3.4.7 Information

Navigation System → Information

Device name

Navigation System → Information → Device name

Description Use this function to display the device name. It can also be found on the nameplate.

User interface Character string comprising numbers, letters and special characters

Factory setting 5xB/7xB

Manufacturer

Navigation  System → Information → Manufacturer**User interface** Character string comprising numbers, letters and special characters**Factory setting** Endress+Hauser

Serial number

Navigation  System → Information → Serial number**Description** The serial number is a unique alphanumerical code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.**User interface** Character string comprising numbers, letters and special characters

Order code 

Navigation  System → Information → Order code**Description** Shows the device order code.**User interface** Character string comprising numbers, letters and special characters**Factory setting** - none -**Additional information** **Access:**

- Read access: Operator
- Write access: Expert

Firmware version

Navigation  System → Information → Firmware version**Description** Displays the device firmware version installed.**User interface** Character string comprising numbers, letters and special characters

Hardware version

Navigation  System → Information → Hardware version**User interface** Character string comprising numbers, letters and special characters

Extended order code 1 ... 3

**Navigation**  System → Information → Ext. order cd. 1**Description** The extended order code is an alphanumeric code containing all information to identify the device and its options.**User interface** Character string comprising numbers, letters and special characters**Additional information**
Access:

- Read access: Operator
- Write access: Expert

XML build number

Navigation  System → Information → XML build no.**User interface** Positive integer**Additional information**
Access:

- Read access: Expert
- Write access: -

Checksum

Navigation  System → Information → Checksum**Description** Checksum for Firmware version.**User interface** Positive integer

3.4.8 Additional information

Navigation

  System → Additional info

Sensor

Navigation

  System → Additional info → Sensor

Serial number

Navigation

  System → Additional info → Sensor → Serial number

Description

Shows the serial number of the module.

User interface

Character string comprising numbers, letters and special characters

Additional information

Access:

- Read access: Expert
- Write access: -

Firmware version

Navigation

  System → Additional info → Sensor → Firmware version

Description

Displays the firmware version of the module.

User interface

Positive integer

Additional information

Access:

- Read access: Expert
- Write access: -

Hardware version

Navigation

  System → Additional info → Sensor → Hardware version

Description

Displays the hardware version of the module.

User interface

Character string comprising numbers, letters and special characters

Additional information

Access:

- Read access: Expert
- Write access: -

Checksum

Navigation  System → Additional info → Sensor → Checksum

Description Checksum for Firmware version.

User interface Positive integer

Factory setting 0

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Electronics

Navigation  System → Additional info → Electronics

Serial number

Navigation  System → Additional info → Electronics → Serial number

Description Shows the serial number of the module.

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Firmware version

Navigation  System → Additional info → Electronics → Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Build no. software

Navigation  System → Additional info → Electronics → Build no. softw.

Description Shows the build number of the module firmware.

User interface 0 to 65 535

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Hardware version

Navigation  System → Additional info → Electronics → Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Display/Bluetooth

Navigation  System → Additional info → Displ./Bluetooth

Serial number

Navigation  System → Additional info → Displ./Bluetooth → Serial number

Description Shows the serial number of the module.

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**
■ Read access: Expert
■ Write access: -

Firmware version

| | |
|-------------------------------|--|
| Navigation |   System → Additional info → Displ./Bluetooth → Firmware version |
| Description | Displays the firmware version of the module. |
| User interface | Positive integer |
| Additional information | Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: - |

Build no. software

| | |
|-------------------------------|--|
| Navigation |   System → Additional info → Displ./Bluetooth → Build no. softw. |
| Description | Shows the build number of the module firmware. |
| User interface | 0 to 65 535 |
| Additional information | Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: - |

Hardware version

| | |
|-------------------------------|--|
| Navigation |   System → Additional info → Displ./Bluetooth → Hardware version |
| Description | Displays the hardware version of the module. |
| User interface | Character string comprising numbers, letters and special characters |
| Additional information | Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: - |

3.4.9 Software configuration

Navigation

  System → Softw. config.

CRC device configuration

Navigation

  System → Softw. config. → CRC device conf.

Description

CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.

User interface

0 to 65 535

Factory setting

65 535

Activate SW option



Navigation

  System → Softw. config. → Activate SW opt.

Description

Enter the application package code or code of another re-ordered functionality to enable it

User entry

Positive integer

Software option overview

Navigation

  System → Softw. config. → SW option overv.

Description

Shows all enabled software options

User interface

- Heartbeat Verification
- Heartbeat Monitoring

Factory setting

T_HeartbeatVerificationT_HeartbeatMonitoring



71728235

www.addresses.endress.com

Endress+Hauser 
People for Process Automation