


Operating Instructions

Proline Promag L 400

EtherNet/IP

Electromagnetic flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Document information	6		
1.1	Document function	6		
1.2	Symbols used	6		
1.2.1	Safety symbols	6		
1.2.2	Electrical symbols	6		
1.2.3	Tool symbols	7		
1.2.4	Symbols for certain types of information	7		
1.2.5	Symbols in graphics	7		
1.3	Documentation	8		
1.3.1	Standard documentation	8		
1.3.2	Supplementary device-dependent documentation	8		
1.4	Registered trademarks	8		
2	Basic safety instructions	9		
2.1	Requirements for the personnel	9		
2.2	Designated use	9		
2.3	Workplace safety	10		
2.4	Operational safety	10		
2.5	Product safety	10		
2.6	IT security	11		
3	Product description	12		
3.1	Product design	12		
4	Incoming acceptance and product identification	13		
4.1	Incoming acceptance	13		
4.2	Product identification	14		
4.2.1	Transmitter nameplate	14		
4.2.2	Sensor nameplate	15		
4.2.3	Symbols on measuring device	16		
5	Storage and transport	17		
5.1	Storage conditions	17		
5.2	Transporting the product	17		
5.2.1	For measuring devices ≤ DN 300 (12")	17		
5.2.2	For measuring devices ≥ DN 350 (14")	18		
5.3	Packaging disposal	18		
6	Installation	19		
6.1	Installation conditions	19		
6.1.1	Mounting position	19		
6.1.2	Requirements from environment and process	22		
6.1.3	Special mounting instructions	23		
6.2	Mounting the measuring device	24		
6.2.1	Required tools	24		
6.2.2	Preparing the measuring device	24		
6.2.3	Mounting the sensor	24		
6.2.4	Mounting the transmitter of the remote version	28		
6.2.5	Turning the transmitter housing	30		
6.2.6	Turning the display module	31		
6.3	Post-installation check	32		
7	Electrical connection	33		
7.1	Connection conditions	33		
7.1.1	Required tools	33		
7.1.2	Requirements for connecting cable	33		
7.1.3	Terminal assignment	35		
7.1.4	Pin assignment, device plug	36		
7.1.5	Preparing the measuring device	36		
7.1.6	Preparing the connecting cable for the remote version	37		
7.2	Connecting the measuring device	38		
7.2.1	Connecting the transmitter	38		
7.2.2	Connecting the remote version	39		
7.2.3	Ensuring potential equalization	41		
7.3	Special connection instructions	43		
7.3.1	Connection examples	43		
7.4	Hardware settings	44		
7.4.1	Setting the device address	44		
7.5	Ensuring the degree of protection	45		
7.5.1	Degree of protection IP66/67, Type 4X enclosure	45		
7.6	Post-connection check	45		
8	Operation options	47		
8.1	Overview of operation options	47		
8.2	Structure and function of the operating menu	48		
8.2.1	Structure of the operating menu	48		
8.2.2	Operating philosophy	49		
8.3	Access to the operating menu via the local display	50		
8.3.1	Operational display	50		
8.3.2	Navigation view	52		
8.3.3	Editing view	54		
8.3.4	Operating elements	55		
8.3.5	Opening the context menu	56		
8.3.6	Navigating and selecting from list	58		
8.3.7	Calling the parameter directly	58		
8.3.8	Calling up help text	59		
8.3.9	Changing the parameters	60		
8.3.10	User roles and related access authorization	61		
8.3.11	Disabling write protection via access code	61		
8.3.12	Enabling and disabling the keypad lock	61		

8.4	Access to the operating menu via the Web browser	62	11.6	Adapting the measuring device to the process conditions	89
8.4.1	Function range	62	11.7	Performing a totalizer reset	90
8.4.2	Prerequisites	62	11.7.1	Function scope of "Control Totalizer" parameter	90
8.4.3	Establishing a connection	63	11.7.2	Function scope of "Reset all totalizers" parameter	90
8.4.4	Logging on	63	11.8	Showing data logging	90
8.4.5	User interface	64	12	Diagnostics and troubleshooting ...	93
8.4.6	Disabling the Web server	65	12.1	General troubleshooting	93
8.4.7	Logging out	65	12.2	Diagnostic information via light emitting diodes	94
8.5	Access to the operating menu via the operating tool	65	12.2.1	Transmitter	94
8.5.1	Connecting the operating tool	66	12.3	Diagnostic information on local display	96
8.5.2	FieldCare	66	12.3.1	Diagnostic message	96
9	System integration	68	12.3.2	Calling up remedial measures	98
9.1	Overview of device description files	68	12.4	Diagnostic information in the Web browser ..	99
9.1.1	Current version data for the device ...	68	12.4.1	Diagnostic options	99
9.1.2	Operating tools	68	12.4.2	Calling up remedy information	99
9.2	Overview of system files	68	12.5	Diagnostic information in FieldCare	100
9.3	Integrating the measuring device in the system	68	12.5.1	Diagnostic options	100
10	Commissioning	70	12.5.2	Calling up remedy information	101
10.1	Function check	70	12.6	Diagnostic information in FieldCare	101
10.2	Switching on the measuring device	70	12.6.1	Diagnostic options	101
10.3	Configuring the device address via software ..	70	12.6.2	Calling up remedy information	102
10.4	Setting the operating language	70	12.7	Diagnostic information via communication interface	102
10.5	Configuring the measuring device	71	12.7.1	Reading out diagnostic information	102
10.5.1	Defining the tag name	71	12.8	Adapting the diagnostic information	103
10.5.2	Setting the system units	72	12.8.1	Adapting the diagnostic behavior ...	103
10.5.3	Configuring the local display	73	12.9	Overview of diagnostic information	104
10.5.4	Configuring the communication interface	75	12.10	Pending diagnostic events	107
10.5.5	Configuring the low flow cut off	76	12.11	Diagnostic list	108
10.5.6	Configuring empty pipe detection ...	77	12.12	Event logbook	108
10.6	Advanced settings	79	12.12.1	Event history	108
10.6.1	Carrying out a sensor adjustment	79	12.12.2	Filtering the event logbook	109
10.6.2	Configuring the totalizer	80	12.12.3	Overview of information events	109
10.6.3	Carrying out additional display configurations	81	12.13	Resetting the measuring device	110
10.6.4	Performing electrode cleaning	83	12.14	Device information	110
10.7	Simulation	84	12.15	Firmware history	111
10.8	Protecting settings from unauthorized access	85	13	Maintenance	113
10.8.1	Write protection via access code	85	13.1	Maintenance tasks	113
10.8.2	Write protection via write protection switch	86	13.1.1	Exterior cleaning	113
11	Operation	87	13.1.2	Interior cleaning	113
11.1	Read out and modify current Ethernet settings	87	13.1.3	Replacing seals	113
11.2	Reading device locking status	87	13.2	Measuring and test equipment	113
11.3	Adjusting the operating language	88	13.3	Endress+Hauser services	113
11.4	Configuring the display	88	14	Repair	114
11.5	Reading measured values	88	14.1	General notes	114
11.5.1	Process variables	88	14.2	Spare parts	114
11.5.2	Totalizer	89	14.3	Endress+Hauser services	114
			14.4	Return	114
			14.5	Disposal	114
			14.5.1	Removing the measuring device	114

14.5.2	Disposing of the measuring device . .	115
15	Accessories	116
15.1	Device-specific accessories	116
15.1.1	For the transmitter	116
15.1.2	For the sensor	116
15.2	Communication-specific accessories	116
15.3	Service-specific accessories	117
15.4	System components	117
16	Technical data	118
16.1	Application	118
16.2	Function and system design	118
16.3	Input	118
16.4	Output	121
16.5	Power supply	123
16.6	Performance characteristics	125
16.7	Installation	125
16.8	Environment	126
16.9	Process	126
16.10	Mechanical construction	127
16.11	Operability	138
16.12	Certificates and approvals	138
16.13	Application packages	139
16.14	Accessories	140
16.15	Documentation	140
17	Appendix	142
17.1	Overview of the operating menu	142
Index		156

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning
 A0011189-EN	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 A0011190-EN	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 A0011191-EN	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 A0011192-EN	NOTICE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
 A0011197	Direct current A terminal to which DC voltage is applied or through which direct current flows.
 A0011198	Alternating current A terminal to which alternating voltage is applied or through which alternating current flows.
 A0017381	Direct current and alternating current <ul style="list-style-type: none"> ▪ A terminal to which alternating voltage or DC voltage is applied. ▪ A terminal through which alternating current or direct current flows.
 A0011200	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
 A0011199	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
 A0011201	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Tool symbols

Symbol	Meaning
 A0013442	Torx screwdriver
 A0011219	Phillips head screwdriver
 A0011222	Open-ended wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning
 A0011182	Allowed Indicates procedures, processes or actions that are allowed.
 A0011183	Preferred Indicates procedures, processes or actions that are preferred.
 A0011184	Forbidden Indicates procedures, processes or actions that are forbidden.
 A0011193	Tip Indicates additional information.
 A0011194	Reference to documentation Refers to the corresponding device documentation.
 A0011195	Reference to page Refers to the corresponding page number.
 A0011196	Reference to graphic Refers to the corresponding graphic number and page number.
	Series of steps
	Result of a sequence of actions
 A0013562	Help in the event of a problem

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3,...	Item numbers
	Series of steps
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections
 A0013441	Flow direction
 A0011187	Hazardous area Indicates a hazardous area.
 A0011188	Safe area (non-hazardous area) Indicates a non-hazardous area.

1.3 Documentation

-  The following document types are available:
- On the CD-ROM supplied with the device
 - In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download
-  For a detailed list of the individual documents along with the documentation code (→  140)

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

EtherNet/IP™

Trademark of ODVA, Inc.

Microsoft®

Registered trademark of the Microsoft Corporation, Redmond, Washington, USA

Applicator®, FieldCare®, Field Xpert™, HistoROM®, Heartbeat Technology™

Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5 $\mu\text{S}/\text{cm}$.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the device documentation provided (on the CD-ROM) is absolutely essential.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the sensor due to corrosive or abrasive fluids!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

Environmental requirements

If a plastic transmitter housing is permanently exposed to certain steam and air mixtures, this can damage the housing.

- ▶ If you are unsure, please contact your Endress+Hauser Sales Center for clarification.
- ▶ If used in an approval-related area, observe the information on the nameplate.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security


We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

Endress+Hauser can be contacted to provide support in performing this task.

3 Product description

3.1 Product design




A0017218

1 Important components of the compact version

- 1 Display module
- 2 Smart sensor electronics module
- 3 HistoROM DAT (plug-in memory)
- 4 Main electronics module
- 5 Terminals (screw terminals, some available as plug-in terminals)
- 6 Transmitter housing, compact version
- 7 Cable glands
- 8 Sensor, compact version


4 Incoming acceptance and product identification

4.1 Incoming acceptance




A0013843

Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?




A0013695




A0013698

Are the goods undamaged?



A0013699

Do the nameplate data match the ordering information on the delivery note?



A0013697

Is the CD-ROM with the Technical Documentation and documents present?

 If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.

For an overview of the scope of the Technical Documentation provided, refer to the following:

- The "Additional standard documentation on the device" (→  8) and "Supplementary device-dependent documentation" (→  8) sections
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)

4.2.1 Transmitter nameplate




A0017346

 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number
- 5 Extended order code
- 6 Permitted ambient temperature range (T_a)
- 7 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 8 Degree of protection
- 9 Permitted temperature range for cable
- 10 2-D matrix code
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Electrical connection data, e.g. available inputs and outputs, supply voltage

4.2.2 Sensor nameplate



A0017186

 3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of sensor
- 7 Test pressure of the sensor
- 8 Fluid temperature range
- 9 Material of lining and electrodes
- 10 Degree of protection: e.g. IP, NEMA
- 11 Permitted ambient temperature (T_a)
- 12 2-D matrix code
- 13 CE mark, C-Tick
- 14 Flow direction
- 15 Manufacturing date: year-month

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

4.2.3 Symbols on measuring device

Symbol	Meaning
 A0011194	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 A0011194	Reference to documentation Refers to the corresponding device documentation.
 A0011199	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→ 📄 126)

5.2 Transporting the product


5.2.1 For measuring devices ≤ DN 300 (12")

⚠ WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device from rotating or slipping.
- ▶ Observe the weight specified on the packaging (stick-on label).
- ▶ Observe the transport instructions on the stick-on label on the electronics compartment cover.



A0015606


Observe the following notes during transport:

- Transport the measuring device to the measuring point in the original packaging.
- Lifting gear
 - Webbing slings: Do not use chains, as they could damage the housing.
 - For wood crates, the floor structure enables these to be loaded lengthwise or broadside using a forklift.
- Use the webbing slings to lift the measuring device at the process connections; do not lift at the transmitter housing or the connection housing of the remote version.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

5.2.2 For measuring devices \geq DN 350 (14")

Also observe the following notes during transport:

- Lift the measuring device by the flange using the metal brackets.
- If transporting by forklift, do not lift the sensor by the metal casing. This would buckle the casing and damage the internal magnetic coils.



A0016257

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
 - or
 - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation


6.1 Installation conditions

No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

6.1.1 Mounting position

Mounting location

Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow: $h \geq 2 \times DN$



A0017061


To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

Installation in down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes whose length $h \geq 5 \text{ m}$ (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime, which could cause air pockets.

 For information on the liner's resistance to partial vacuum (\rightarrow  127)



A0017064


 4 Installation in a down pipe

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe

Installation in partially filled pipes

A partially filled pipe with a gradient necessitates a drain-type configuration. The empty pipe detection (EPD) function offers additional protection by detecting empty or partially filled pipes.

- Do not install the sensor at the lowest point in the drain: risk of solids accumulating.
- It is advisable to install a cleaning valve.



A0017063

For very heavy sensors


If the nominal diameter $DN \geq 350$ (14 in), mount the sensor on a foundation of adequate load-bearing strength.

NOTICE

Very heavy!

Risk of damaging the metal casing and the internal magnetic coils.

- ▶ Do not support the weight of the sensor on the metal casing.



A0016276

Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube.

The measuring device also offers the empty pipe detection function to detect partially filled measuring pipes in the event of outgassing fluids or variable process pressures.

Vertical

This is the optimum orientation for self-emptying piping systems and for use in conjunction with empty pipe detection.




A0015591

Horizontal

The measuring electrode plane must be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.

i With horizontal orientation, empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.



A0016260

5 *Horizontal orientation*


- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

Inlet and outlet runs

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:

- Inlet run $\geq 5 \times DN$
- Outlet run $\geq 2 \times DN$



A0016275

Installation dimensions

i For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process

Ambient temperature range

Transmitter	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to +60 °C (-4 to +140 °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	<ul style="list-style-type: none"> ▪ Flange material carbon steel: -10 to +60 °C (+14 to +140 °F) ▪ Flange material stainless steel: -40 to +60 °C (-40 to +140 °F) Mount the transmitter separately from the sensor if both the ambient and fluid temperatures are high.
Liner	Do not exceed or fall below the permitted temperature range of the liner (→ 126).

If operating outdoors:


- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.
- Protect the display against impact.
- Protect the display from abrasion by sand in desert areas.

i A display protector can be ordered from Endress+Hauser: "Accessories" section (→ [116](#))

System pressure

- Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.
- Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

i ▪ For information on the liner's resistance to partial vacuum (→ [127](#))
 ▪ For information on the measuring system's resistance to vibration and shock (→ [126](#)), (→ [126](#))




A0015594

Vibrations

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

It is also advisable to mount the sensor and transmitter separately.

i For information on the permitted resistance to vibration and shock (→ [126](#)), (→ [126](#))



A0016266

6 Measures to prevent vibration of the device


$L > 10\text{ m (33 ft)}$

Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.

i The nomogram only applies to liquids with a viscosity similar to that of water.

1. Calculate the ratio of the diameters d/D .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.



A0016359

6.1.3 Special mounting instructions

Display protection

- To ensure that the optional display protection can be easily opened, maintain the following minimum head clearance: 350 mm (13.8 in)

6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

- Torque wrench
- For wall mounting:
 - Open-ended wrench for hexagonal screw max. M5
- For pipe mounting:
 - Open-ended wrench AF 8
 - Phillips head screwdriver PH 2
- For turning the transmitter housing (compact version):
 - Phillips head screwdriver PH 2
 - Torx screwdriver TX 20
 - Open-ended wrench AF 7

For sensor

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.


6.2.3 Mounting the sensor

⚠ WARNING

Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Install the gaskets correctly.

1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
3. If using ground disks, comply with the Installation Instructions provided.
4. Observe required screw tightening torques (→  25).
5. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



A0013964

Mounting the seals



An electrically conductive layer could form on the inside of the measuring tube!

Risk of measuring signal short circuit.

- ▶ Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

- Make sure that the seals do not protrude into the piping cross-section.
- For DIN flanges: only use seals according to DIN EN 1514-1.
- For "hard rubber" lining: additional seals are **always** required.
- For "polyurethane" lining: generally additional seals are **not** required.
- For "PTFE" lining: generally additional seals are **not** required.

Mounting the ground cable/ground disks

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks (→  41).

Screw tightening torques

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.

Screw tightening torques for EN 1092-1 (DIN 2501), PN 6/10/16

Nominal diameter [mm]	Pressure rating [bar]	Threaded fasteners [mm]	Max. screw tightening torque [Nm]		
			Hard rubber	Polyurethane	PTFE
50	PN 10/16	4 × M16	–	15	40
65 ¹⁾	PN 10/16	8 × M16	–	10	22
80	PN 10/16	8 × M16	–	15	30
100	PN 10/16	8 × M16	–	20	42
125	PN 10/16	8 × M16	–	30	55
150	PN 10/16	8 × M20	–	50	90
200	PN 10	8 × M20	–	65	130
250	PN 10	12 × M20	–	50	90
300	PN 10	12 × M20	–	55	100
350	PN 6	12 × M20	111	120	–
350	PN 10	16 × M20	112	118	–
350	PN 16	16 × M24	152	165	–
400	PN 6	16 × M20	90	98	–
400	PN 10	16 × M24	151	167	–
400	PN 16	16 × M27	193	215	–
450	PN 6	16 × M20	112	126	–
450	PN 10	20 × M24	153	133	–
500	PN 6	20 × M20	119	123	–
500	PN 10	20 × M24	155	171	–
500	PN 16	20 × M30	275	300	–
600	PN 6	20 × M24	139	147	–

Nominal diameter [mm]	Pressure rating [bar]	Threaded fasteners [mm]	Max. screw tightening torque [Nm]		
			Hard rubber	Polyurethane	PTFE
600	PN 10	20 × M27	206	219	–
600 ¹⁾	PN 16	20 × M33	415	443	–
700	PN 6	24 × M24	148	139	–
700	PN 10	24 × M27	246	246	–
700	PN 16	24 × M33	278	318	–
800	PN 6	24 × M27	206	182	–
800	PN 10	24 × M30	331	316	–
800	PN 16	24 × M36	369	385	–
900	PN 6	24 × M27	230	637	–
900	PN 10	28 × M30	316	307	–
900	PN 16	28 × M36	353	398	–
1000	PN 6	28 × M27	218	208	–
1000	PN 10	28 × M33	402	405	–
1000	PN 16	28 × M39	502	518	–
1200	PN 6	32 × M30	319	299	–
1200	PN 10	32 × M36	564	568	–
1200	PN 16	32 × M45	701	753	–
1400	PN 6	36 × M33	430	–	–
1400	PN 10	36 × M39	654	–	–
1400	PN 16	36 × M45	729	–	–
1600	PN 6	40 × M33	440	–	–
1600	PN 10	40 × M45	946	–	–
1600	PN 16	40 × M52	1007	–	–
1800	PN 6	44 × M36	547	–	–
1800	PN 10	44 × M45	961	–	–
1800	PN 16	44 × M52	1108	–	–
2000	PN 6	48 × M39	629	–	–
2000	PN 10	48 × M45	1047	–	–
2000	PN 16	48 × M56	1324	–	–
2200	PN 6	52 × M39	698	–	–
2200	PN 10	52 × M52	1217	–	–
2400	PN 6	56 × M39	768	–	–
2400	PN 10	56 × M52	1229	–	–

1) Designed acc. to EN 1092-1 (not to DIN 2501)

Screw tightening torques for ASME B16.5, Class 150

Nominal diameter		Threaded fasteners [in]	Max. screw tightening torque [Nm] ([lbf · ft])		
[mm]	[in]		Hard rubber	Polyurethane	PTFE
50	2	4 × 5/8	–	15 (11)	40 (29)
80	3	4 × 5/8	–	25 (18)	65 (48)

Nominal diameter		Threaded fasteners [in]	Max. screw tightening torque [Nm] ([lbf · ft])		
[mm]	[in]		Hard rubber	Polyurethane	PTFE
100	4	8 × 5/8	–	20 (15)	44 (32)
150	6	8 × 3/4	–	45 (33)	90 (66)
200	8	8 × 3/4	–	65 (48)	125 (92)
250	10	12 × 7/8	–	55 (41)	100 (74)
300	12	12 × 7/8	–	68 (56)	115 (85)
350	14	12 × 1	135 (100)	158 (117)	–
400	16	16 × 1	128 (94)	150 (111)	–
450	18	16 × 1 1/8	204 (150)	234 (173)	–
500	20	20 × 1 1/8	183 (135)	217 (160)	–
600	24	20 × 1 1/4	268 (198)	307 (226)	–

Screw tightening torques for AWWA C207, Class D

Nominal diameter		Threaded fasteners [in]	Max. screw tightening torque [Nm] ([lbf · ft])		
[mm]	[in]		Hard rubber	Polyurethane	PTFE
700	28	28 × 1 1/4	247 (182)	292 (215)	–
750	30	28 × 1 1/4	287 (212)	302 (223)	–
800	32	28 × 1 1/2	394 (291)	422 (311)	–
900	36	32 × 1 1/2	419 (309)	430 (317)	–
1000	40	36 × 1 1/2	420 (310)	477 (352)	–
1050	42	36 × 1 1/2	528 (389)	518 (382)	–
1200	48	44 × 1 1/2	552 (407)	531 (392)	–
1350	54	44 × 1 3/4	730 (538)	–	–
1500	60	52 × 1 3/4	758 (559)	–	–
1650	66	52 × 1 3/4	946 (698)	–	–
1800	72	60 × 1 3/4	975 (719)	–	–
2000	78	64 × 2	853 (629)	–	–
2150	84	64 × 2	931 (687)	–	–
2300	90	68 × 2 1/4	1048 (773)	–	–

Screw tightening torques for AS 2129, Table E

Nominal diameter [mm]	Threaded fasteners [mm]	Max. screw tightening torque [Nm]		
		Hard rubber	Polyurethane	PTFE
350	12 × M24	203	–	–
400	12 × M24	226	–	–
450	16 × M24	226	–	–
500	16 × M24	271	–	–
600	16 × M30	439	–	–
700	20 × M30	355	–	–
750	20 × M30	559	–	–
800	20 × M30	631	–	–
900	24 × M30	627	–	–

Nominal diameter [mm]	Threaded fasteners [mm]	Max. screw tightening torque [Nm]		
		Hard rubber	Polyurethane	PTFE
1 000	24 × M30	634	–	–
1 200	32 × M30	727	–	–

Screw tightening torques for AS 4087, PN 16

Nominal diameter [mm]	Threaded fasteners [mm]	Max. screw tightening torque [Nm]		
		Hard rubber	Polyurethane	PTFE
350	12 × M24	203	–	–
375	12 × M24	137	–	–
400	12 × M24	226	–	–
450	12 × M24	301	–	–
500	16 × M24	271	–	–
600	16 × M27	393	–	–
700	20 × M27	330	–	–
750	20 × M30	529	–	–
800	20 × M33	631	–	–
900	24 × M33	627	–	–
1 000	24 × M33	595	–	–
1 200	32 × M33	703	–	–

6.2.4 Mounting the transmitter of the remote version

⚠ CAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature (→ 22).
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

⚠ CAUTION


Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

Wall mounting




A0020523

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw in the securing screws slightly at first.
4. Fit the transmitter housing over the securing screws and mount in place.
5. Tighten the securing screws.

Pipe mounting

For plastic housing

Max. tightening torque	2 Nm
-------------------------------	------



A0020705


i A separate mounting kit can be ordered from Endress+Hauser for pipe mounting (\rightarrow 116).

6.2.5 Turning the transmitter housing


To provide easier access to the display module in the compact device version, the transmitter housing can be turned:

Tightening torques for plastic housing


Housing cover fixing screw	Max.1.3 Nm
Main electronics module fixing screw	Max.1.5 Nm




A0021602



A0021603



A0021604



A0021605


1. Loosen the fixing screws of the housing cover.
2. Open the housing cover.
3. Unlock the display module.
4. Remove the display module.
5. Loosen the fixing screws of the smart sensor electronics module.
6. Remove the smart sensor electronics module.
7. Loosen the fixing screws of the main electronics module.
8. Remove the main electronics module.
9. Loosen the fixing screws of the transmitter housing.
10. Lift the transmitter housing.
11. Turn the housing to the desired position in increments of 90°.
12. **WARNING!** Excessive tightening torque applied to the fixing screws! Risk of damaging the plastic transmitter. Tighten the fixing screws as per the tightening torque (→ 30).
NOTICE! Plug of the smart sensor electronics module connected incorrectly! No measuring signal is output. Plug in the plug of the smart sensor electronics module as per the coding.
 Reverse the procedure to reassemble the measuring device.

6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.

Tightening torques for plastic housing

Housing cover fixing screw	Max.1.3 Nm
----------------------------	------------



A0021617

1. Loosen the fixing screws of the housing cover.
2. Open the housing cover.
3. Unlock the display module.
4. Pull out the display module and turn it to the desired position in increments of 90°.
5. **WARNING!** Excessive tightening torque applied to the fixing screws! Risk of damaging the plastic transmitter. Tighten the fixing screws as per the tightening torque (→ 30).
Reverse the procedure to reassemble the measuring device.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ▪ Process temperature ▪ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) ▪ Ambient temperature ▪ Measuring range 	<input type="checkbox"/>
Has the correct orientation for the sensor been selected (→ 20)? <ul style="list-style-type: none"> ▪ According to sensor type ▪ According to medium temperature ▪ According to medium properties (outgassing, with entrained solids) 	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping (→ 20)?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Have the fixing screws been tightened with the correct tightening torque?	<input type="checkbox"/>

7 Electrical connection

 The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- Torque wrench
- For cable entries: Use corresponding tools
- For housing cover: Torx screwdriver or flat-blade screwdriver
- Wire stripper
- When using stranded cables: crimping tool for ferrule

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40 °C (-40 °F) to $+80\text{ °C}$ ($+176\text{ °F}$)
- Minimum requirement: cable temperature range \geq ambient temperature $+20\text{ K}$

Power supply cable

Standard installation cable is sufficient.

Signal cable

EtherNet/IP

The standard ANSI/TIA/EIA-568-B.2 Annex specifies CAT 5 as the minimum category for a cable used for EtherNet/IP. CAT 5e and CAT 6 are recommended.

 For more information on planning and installing EtherNet/IP networks, please refer to the "Media Planning and Installation Manual. EtherNet/IP" of the ODVA Organization.


Connecting cable for remote version

Electrode cable

Standard cable	3 × 0.38 mm ² (20 AWG) with common, braided copper shield ($\phi \sim 7\text{ mm}$ (0.28")) and individually shielded cores
Cable for empty pipe detection (EPD)	4 × 0.38 mm ² (20 AWG) with common, braided copper shield ($\phi \sim 7\text{ mm}$ (0.28")) and individually shielded cores
Conductor resistance	$\leq 50\ \Omega/\text{km}$ (0.015 Ω/ft)
Capacitance: core/shield	$\leq 420\ \text{pF}/\text{m}$ (128 pF/ft)
Operating temperature	-20 to $+80\text{ °C}$ (-68 to $+176\text{ °F}$)

Coil current cable

Standard cable	2 × 0.75 mm ² (18 AWG) with common, braided copper shield (ϕ ~ 7 mm (0.28")) and individually shielded cores
Conductor resistance	≤ 37 Ω/km (0.011 Ω/ft)
Capacitance: core/core, shield grounded	≤ 120 pF/m (37 pF/ft)
Operating temperature	-20 to +80 °C (-68 to +176 °F)
Test voltage for cable insulation	≤ AC 1433 V r.m.s. 50/60 Hz or ≥ DC 2026 V



A0003194

 7 *Cable cross-section*

- a* Electrode cable
- b* Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Reinforced connecting cable

Use in the following situations:

- When laying the cable directly in the ground
- Where there is a risk of damage from rodents

Operation in zones of severe electrical interference

The measuring system meets the general safety requirements (→  139) and EMC specifications (→  126).

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.

Cable diameter

- Cable glands supplied:
 - For standard cable: M20 × 1.5 with cable ϕ6 to 12 mm (0.24 to 0.47 in)
 - For reinforced cable: M20 × 1.5 with cable ϕ9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)


7.1.3 Terminal assignment

Transmitter

EtherNet/IP connection version

The sensor can be ordered with terminals or a device plug.

Connection methods available		Possible options for order code "Electrical connection"
Outputs	Power supply	
Terminals	Terminals	<ul style="list-style-type: none"> ▪ Option A: coupling M20x1 ▪ Option B: thread M20x1 ▪ Option C: thread G ½" ▪ Option D: thread NPT ½"
Device plug (→ 36)	Terminals	<ul style="list-style-type: none"> ▪ Option L: plug M12x1 + thread NPT ½" ▪ Option N: plug M12x1 + coupling M20 ▪ Option P: plug M12x1 + thread G ½" ▪ Option U: plug M12x1 + thread M20



A0020428

- 1 Supply voltage (wide range power unit)
- 2 EtherNet/IP


Supply voltage

Order code for "Power supply"	Terminal numbers	
	1 (L+/L)	2 (L-/N)
Option L (wide range power unit)		AC100 to 240 V
		AC/DC24 V

EtherNet/IP signal transmission

Order code for "Output"	Connection via
Option N	EtherNet/IP connector

Remote version



A0020534

8 Remote version terminal assignment

- A Transmitter wall-mount housing
- B Sensor connection housing
- 1 Electrode cable
- 2 Coil current cable
- n.c. Not connected, insulated cable shields

Terminal No. and cable colors: 6/5 = brown; 7/8 = white; 4 = green; 36/37 = yellow

7.1.4 Pin assignment, device plug

EtherNet/IP

Supply voltage for EtherNet/IP (on the device side)

<p>A0016809</p>	Pin	Assignment	Coding	Plug/socket	
	1	L+	DC24 V	A	Plug
	2				
	3				
	4	L-	DC24 V		
5		Grounding/shielding			

EtherNet/IP (on the device side)

<p>A0016812</p>	Pin	Assignment	Coding	Plug/socket	
	1	+	Tx	D	Socket
	2	+	Rx		
	3	-	Tx		
	4	-	Rx		

7.1.5 Preparing the measuring device

1. Remove dummy plug if present.
2. If measuring device is delivered with cable glands:



Observe cable specification (→ 33).

7.1.6 Preparing the connecting cable for the remote version


When terminating the connecting cable, pay attention to the following points:

- In the case of electrode cables, make sure that the ferrules do not touch the core shields on the sensor side. Minimum distance = 1 mm (exception: green “GND” cable)
- In the case of coil current cables, insulate one core of the three-core wire at the level of the core reinforcement. You only require two cores for the connection.
- Fit the fine-wire cores with ferrules.

Transmitter

Electrode cable	Coil current cable
 <p>Engineering unit mm (in)</p> <p>9</p> <p>A0021324</p>	 <p>Engineering unit mm (in)</p> <p>10</p> <p>A0021325</p>
<p>A = Termination of the cables B = Termination of the fine-wire cores with ferrules 1 = Red ferrules, $\phi 1.0$ mm (0.04 in) 2 = White ferrules, $\phi 0.5$ mm (0.02 in) * = Stripping only for reinforced cables</p>	

Sensor



7.2 Connecting the measuring device

⚠ WARNING

Risk of electric shock! Components carry dangerous voltages!


- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Observe grounding concept of the plant.
- ▶ Never mount or wire the measuring device while it is connected to the supply voltage.
- ▶ Before the supply voltage is applied, connect the protective ground to the measuring device.

Tightening torques for plastic housing

Housing cover fixing screw	Max. 1.3 Nm
Cable entry	Max. 4.5 to 5 Nm
Ground terminal	Max. 2.5 Nm

7.2.1 Connecting the transmitter

Connection via terminals



11 Connecting the supply voltage and EtherNet/IP

A0021356

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cable in accordance with the terminal assignment . For supply voltage: open the shock protection cover. For HART communication: When connecting the cable shielding to the ground terminal, observe the grounding concept of the facility.
6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. Reverse the removal procedure to reassemble the transmitter.

7.2.2 Connecting the remote version


WARNING

Risk of damaging the electronic components!

- ▶ Ground the remote version and in doing so connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.
- ▶ Ground the connection housing of the sensor via the external screw terminal.

The following procedure (in the action sequence given) is recommended for the remote version:


1. Mount the transmitter and sensor.
2. Connect the connecting cable.
3. Connect the transmitter.



A0017445

12 Transmitter: main electronics module with terminals

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 37).
5. Connect the cable in accordance with the terminal assignment (→ 36).
6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. Reverse the removal procedure to reassemble the transmitter.



A0021527

13 Sensor: connection module

1. Loosen the securing clamp of the housing cover.
2. Unscrew and lift off the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 37).
5. Connect the cable in accordance with the terminal assignment (→ 36).

6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.
Reverse the procedure to reassemble the sensor.

7.2.3 Ensuring potential equalization


⚠ CAUTION

Electrode damage can result in the complete failure of the device!

- ▶ Make sure that the fluid and sensor have the same electrical potential.
- ▶ Pay attention to internal grounding concepts in the company.
- ▶ Pay attention to the pipe material or grounding.

Connection examples for standard situations

Metal, grounded pipe




14 Potential equalization via measuring tube

Connection example in special situations

Unlined and ungrounded metal pipe

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present



15 Potential equalization via ground terminal and pipe flanges

Ground cable	Copper wire, at least 6 mm ² (0.0093 in ²)
--------------	---


1. Connect both sensor flanges to the pipe flange via a ground cable and ground them.
2. If $DN \leq 300$ (12"): Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws. If $DN \geq 350$ (14"): Mount the ground cable directly on the metal transport bracket. Observe torques (\rightarrow  25).
3. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose.

 For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

Plastic pipe or pipe with insulating liner

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present



A0016318

 16 Potential equalization via ground terminal and ground disks

1. Connect the ground disks to the ground terminal via the ground cable.
2. Connect the ground disks to ground potential.


Ground cable	Copper wire, at least 6 mm ² (0.0093 in ²)
--------------	---

 For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

Pipe with a cathodic protection unit

This connection method is only used if the following two conditions are met:

- Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment



A0016319

17 Potential equalization and cathodic protection

- 1 Isolation transformer power supply
- 2 Electrically isolated from the pipe
- 3 Capacitor

Ground cable	Copper wire, at least 6 mm ² (0.0093 in ²)
---------------------	---


1. Connect the measuring device to the power supply such that it is floating in relation to the protective ground.
2. Install the sensor in the pipe in a way that provides electrical insulation.
3. Connect the two flanges of the pipe to one another via a ground cable.
4. Guide the shield of the signal lines through a capacitor.

i For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

7.3 Special connection instructions

7.3.1 Connection examples

EtherNet/IP




A0016805

18 Connection example for EtherNet/IP

- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications (→ 33)
- 4 Device plug
- 5 Transmitter

Status input



A0017163

19 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values

7.4 Hardware settings

7.4.1 Setting the device address

EtherNet/IP

The IP address of the measuring device can be configured for the network via DIP switches.


Addressing data

IP address and configuration options			
1st octet	2nd octet	3rd octet	4th octet
192.	168.	1.	XXX
	↓		↓
	Can only be configured via software addressing		Can be configured via software addressing and hardware addressing

IP address range	1 to 254 (4th octet)
IP address broadcast	255
Addressing mode ex works	Software addressing; all DIP switches for hardware addressing are set to OFF.
IP address ex works	DHCP server active

 For device addressing via software (→  70)

Setting the address



A0021322

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Set the desired IP address using the corresponding DIP switches on the I/O electronics module.
 - ↳ Hardware addressing with the configured IP address is enabled after 10 s.
4. Reverse the removal procedure to reassemble the transmitter.


7.5 Ensuring the degree of protection

7.5.1 Degree of protection IP66/67, Type 4X enclosure

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0013960

5. Insert dummy plugs into unused cable entries.


7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Do the cables comply with the requirements (→ 33)?	<input type="checkbox"/>
Do the cables have adequate strain relief?	<input type="checkbox"/>

Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→ 45) ?	<input type="checkbox"/>
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate (→ 124)?	<input type="checkbox"/>
Is the terminal assignment correct (→ 35)?	<input type="checkbox"/>
If supply voltage is present, do values appear on the display module?	<input type="checkbox"/>
Is the potential equalization established correctly (→ 41)?	<input type="checkbox"/>
Are all housing covers installed and the screws tightened with the correct tightening torque?	<input type="checkbox"/>

8 Operation options

8.1 Overview of operation options




A0017760

- 1 Computer with Web browser (e.g. Internet Explorer) or with "FieldCare" operating tool
- 2 Automation system, e.g. "RSLogix" (Rockwell Automation) and work station for measuring device operation with Add-on Profile Level 3 for "RSLogix 5000" software (Rockwell Automation)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters (→  142)



A0018237-EN

 20 Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles. Each user role corresponds to typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Operation	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Reading measured values	<ul style="list-style-type: none"> Defining the Web server operating language Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: <ul style="list-style-type: none"> Configuration of the measurement Configuration of the communication interface 	Submenus for fast commissioning: <ul style="list-style-type: none"> Setting the individual system units Defining the medium Configuration of the digital communication interface Configuring the low flow cut off "Advanced setup" submenu: <ul style="list-style-type: none"> For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers "Device reset" submenu Resets the device configuration to certain settings
Diagnostics		"Maintenance" role Fault elimination: <ul style="list-style-type: none"> Diagnostics and elimination of process and device errors Measured value simulation 	Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> "Diagnostic list" submenu Contains up to 5 currently pending diagnostic messages. "Event logbook" submenu Contains 20 event messages that have occurred. "Device information" submenu Contains information for identifying the device. "Measured values" submenu Contains all current measured values. "Simulation" submenu Is used to simulate measured values or output values.
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases 	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> "System" submenu Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. "Sensor" submenu Configuration of the measurement. "Communication" submenu Configuration of the digital communication interface and the Web server. "Application" submenu Configuration of the functions that go beyond the actual measurement (e.g. totalizer). "Diagnostics" submenu Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals(→ 96)
- Diagnostic behavior(→ 97)
- Locking
- Communication

Locking


Symbol	Meaning
 <small>A0013963</small>	Device locked The measuring device is hardware locked (→ 86).

Communication

Symbol	Meaning
 <small>A0013965</small>	Communication via remote operation is active.

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Measured variables

Symbol	Meaning
 <small>A0013711</small>	Volume flow
 <small>A0017269</small>	Conductivity
 <small>A0013710</small>	Mass flow
 <small>A0013943</small>	Totalizer  The measurement channel number indicates which of the three totalizers is displayed.
 <small>A0013945</small>	Output  The measurement channel number indicates which of the outputs is displayed.
 <small>A0017270</small>	Status input

Measurement channel numbers


Symbol	Meaning
 <small>A0016325</small>	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols (→  97)


 The number and display format of the measured values can be configured via the **"Format display" parameter**(→  73). "Operation" menu → Display → Format display

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



i For more information about the menu icons, refer to the "Display area" section (→ 53)

Status area

The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
 - If a diagnostic event is present, the diagnostic behavior and status signal

- i** For information on the diagnostic behavior and status signal (→ 96)
- For information on the function and entry of the direct access code (→ 58)

Display area

Menus

Symbol	Meaning
 A0013973	Operation Appears: <ul style="list-style-type: none"> In the menu next to the "Operation" selection At the left in the navigation path in the "Operation" menu
 A0013974	Setup Appears: <ul style="list-style-type: none"> In the menu next to the "Setup" selection At the left in the navigation path in the "Setup" menu
 A0013975	Diagnostics Appears: <ul style="list-style-type: none"> In the menu next to the "Diagnostics" selection At the left in the navigation path in the "Diagnostics" menu
 A0013966	Expert Appears: <ul style="list-style-type: none"> In the menu next to the "Expert" selection At the left in the navigation path in the "Expert" menu

Submenus, wizards, parameters

Symbol	Meaning
 A0013967	Submenu
 A0013968	Wizard
 A0013972	Parameters within a wizard  No display symbol exists for parameters in submenus.


Locking

Symbol	Meaning
 A0013963	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> By a user-specific access code (→ ⓘ 85) By the hardware write protection switch (→ ⓘ 86)

Wizard operation

Symbol	Meaning
 A0013978	Switches to the previous parameter.
 A0013976	Confirms the parameter value and switches to the next parameter.
 A0013977	Opens the editing view of the parameter.

8.3.3 Editing view



Input mask


The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
	Selection of numbers from 0 to 9.
	Inserts decimal separator at the input position.
	Inserts minus sign at the input position.
	Confirms selection.
	Moves the input position one position to the left.
	Exits the input without applying the changes.
	Clears all entered characters.

Text editor

Symbol	Meaning
	Toggle <ul style="list-style-type: none"> Between upper-case and lower-case letters For entering numbers For entering special characters
	Selection of letters from A to Z.


 <p>A0019094</p>	Selection of letters from a to z.
 <p>A0019095</p>	Selection of special characters.
 <p>A0013985</p>	Confirms selection.
 <p>A0013987</p>	Switches to the selection of the correction tools.
 <p>A0013986</p>	Exits the input without applying the changes.
 <p>A0014040</p>	Clears all entered characters.

Correction symbols under 

Symbol	Meaning
 <p>A0013989</p>	Clears all entered characters.
 <p>A0013991</p>	Moves the input position one position to the right.
 <p>A0013990</p>	Moves the input position one position to the left.
 <p>A0013988</p>	Deletes one character immediately to the left of the input position.

8.3.4 Operating elements

Key	Meaning
 <p>A0013969</p>	<p>Minus key</p> <p><i>In a menu, submenu</i> Moves the selection bar upwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the previous parameter.</p> <p><i>With a text and numeric editor</i> In the input mask, moves the selection bar to the left (backwards).</p>
 <p>A0013970</p>	<p>Plus key</p> <p><i>In a menu, submenu</i> Moves the selection bar downwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the next parameter.</p> <p><i>With a text and numeric editor</i> Moves the selection bar to the right (forwards) in an input screen.</p>

Key	Meaning
 <small>A0013952</small>	<p>Enter key</p> <p><i>For operational display</i></p> <ul style="list-style-type: none"> Pressing the key briefly opens the operating menu. Pressing the key for 2 s opens the context menu. <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: <ul style="list-style-type: none"> If present, opens the help text for the function of the parameter. <p><i>With a Wizard</i></p> <p>Opens the editing view of the parameter.</p> <p><i>With a text and numeric editor</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
 <small>A0013971</small>	<p>Escape key combination (press keys simultaneously)</p> <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). <p><i>With a Wizard</i></p> <p>Exits the wizard and takes you to the next higher level.</p> <p><i>With a text and numeric editor</i></p> <p>Closes the text or numeric editor without applying changes.</p>
 <small>A0013953</small>	<p>Minus/Enter key combination (press the keys simultaneously)</p> <p>Reduces the contrast (brighter setting).</p>
 <small>A0013954</small>	<p>Plus/Enter key combination (press and hold down the keys simultaneously)</p> <p>Increases the contrast (darker setting).</p>
 <small>A0013955</small>	<p>Minus/Plus/Enter key combination (press the keys simultaneously)</p> <p><i>For operational display</i></p> <p>Enables or disables the keypad lock.</p>

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

1. Press  for 2 s.
 ↳ The context menu opens.



2. Press  +  simultaneously.

↳ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


1. Open the context menu.
2. Press  to navigate to the desired menu.
3. Press  to confirm the selection.
 - ↳ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

i For an explanation of the navigation view with symbols and operating elements (→ 52)

Example: Setting the number of displayed measured values to "2 values"



A0017448-EN


8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

"Expert" menu → Direct access

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



A0017223

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Input of "0914" → Parameter **Totalizer 1**
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Input of "0914-2" → Parameter **Totalizer 2**



For the direct access codes of the individual parameters


8.3.8 Calling up help text

For some parameters, help texts exist, which the user can call up from the navigation view. These briefly describe the function of the parameter and thus support fast and reliable commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press  for 2 s.
 - ↳ The help text for the selected parameter opens.



A0014002-EN


 21 Example: Help text for parameter "Enter access code"

2. Press  +  simultaneously.
 - ↳ The help text is closed.

8.3.9 Changing the parameters

i For a description of the editing display - consisting of text editor and numeric editor - with symbols (→ 54), for a description of the operating elements (→ 55)

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0014020-EN

A message is displayed if the value entered is outside the permitted value range.

Ent. access code Invalid or out of range input value Min:0 Max:9999

A0014049-EN

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access (→  85).

Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	✓	✓	✓	-- 1)
Maintenance	✓	✓	✓	✓

- 1) Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

 The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display

8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display (→  85).

The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

1. After you press , the input prompt for the access code appears.
2. Enter the access code.
 - ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.


8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is enabled and disabled in the same way:


The user is in the operational display.

- ▶ By simultaneously pressing the  +  +  keys.
 - ↳ After enabling the keypad lock:



A0016216-EN

After disabling the keypad lock:



A0016216-EN

i If the user attempts to access the operating menu while the keylock is enabled, the message **Keylock on** also appears.

8.4 Access to the operating menu via the Web browser

8.4.1 Function range

Thanks to the integrated Web server the device can be operated and configured via a Web browser. The operating menu structure is the same as in the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

8.4.2 Prerequisites

Hardware

Connecting cable	Standard Ethernet cable with RJ45 connector
Computer	RJ45 interface
Measuring device	Web server must be enabled; factory setting: ON i For information on enabling the Web server (→ 65)

Software of the computer

Web browsers supported	<ul style="list-style-type: none"> ▪ Microsoft Internet Explorer 7.x, 8.x, 9.x ▪ Mozilla Firefox 4.x, 5.x, 8.x ▪ Google chrome 15.x
Recommended operating systems	<ul style="list-style-type: none"> ▪ Windows XP ▪ Windows 7
User rights for TCP/IP settings	Admin rights required (e.g. for changing the IP address, subnet mask)
Computer configuration	<ul style="list-style-type: none"> ▪ JavaScript is enabled ▪ If JavaScript cannot be enabled, enter http://192.168.1.212/basic.html in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.

-  When installing a new firmware version:
To enable correct data display, clear the temporary memory (cache) of the Web browser under **Internet options**.

8.4.3 Establishing a connection

Configuring the Internet protocol of the computer


IP address	192.168.1.XXX; for XXX all numerical values except: 0, 212 and 255 → e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or 0.0.0.0

1. Switch on the measuring device and connect to the computer via the cable (→  66).
2. Configure the properties of the Internet protocol (TCP/IP) as defined in the table above.

Starting the Web browser

1. Start the Web browser on the computer.
2. If the IP address of the measuring device is known, enter the defined device address in the address line of the Web browser. If it is unknown (→  87).

The login page appears.



A0017362

- 1 Device tag (→  71)
- 2 Picture of device

-  If a login page does not appear, or if the page is incomplete
-  The IP address of the Web server (factory setting) is also indicated on the connection nameplate.


8.4.4 Logging on

1. Select the preferred operating language for the Web browser.
2. Enter the access code.
3. Press **OK** to confirm your entry.

Access code	0000 (factory setting); can be changed by customer (→  85)
--------------------	---

 If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



The screenshot shows a web interface for the Proline Promag L 400. At the top, there is a header area (4) containing a device tag (3) with 'Actual diagnos. Device OK' and a green checkmark, and flow data: 'Volume flow 0.0000 l/h' and 'Mass flow 0.0000 kg/h'. Below the header is a navigation bar (2) with tabs: 'Measured values', 'Menu', 'Health status', 'Data management', 'Network', and 'Logout'. The 'Health status' tab is active, showing a 'Health status' section (6) with a red warning icon and a 'Working area' (5) displaying five diagnostic messages, all marked 'OK' with green checkmarks. A small 'Endress+Hauser' logo is in the top right. A reference code 'A0017757-EN' is in the bottom right of the screenshot area.

- 1 Picture of device
- 2 Function row with 6 functions
- 3 Device tag
- 4 Header
- 5 Working area
- 6 Navigation area

Header

The following information appears in the header:

- Device tag (→  71)
- Device status with status signal (→  99)
- Current measured values (→  88)

Function row

Functions	Meaning
Measured values	The measured values of the device are displayed
Menu	Access to the operating menu structure of the device, same as for the local display and operating tool
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	Data exchange between PC and measuring device: <ul style="list-style-type: none"> - Upload the configuration from the device (XML format, create configuration backup) - Save the configuration to the device (XML format) - Export the event list (.csv file) - Export parameter settings (.csv file, create documentation of the measuring point) - Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the device: <ul style="list-style-type: none"> ▪ Network settings (e.g. IP address, MAC address) ▪ Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server for the measuring device can be enabled and disabled as required via the **Web server functionality** parameter.

Navigation

"Expert" menu → Communication → Web server

Parameter overview with brief description

Parameters	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	<ul style="list-style-type: none"> ▪ Off ▪ On 	On

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via "FieldCare" operating tool

8.4.7 Logging out

 Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.


1. Click on **Logout**.
↳ The home page with the Login box appears.
2. Close the Web browser.
3. Reset the modified properties of the Internet protocol (TCP/IP) if they are no longer needed (→  63).

8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool

Via service interface (CDI-RJ45)



- 1 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server

8.5.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

Service interface CDI-RJ45 (→ 66)

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For details, see Operating Instructions BA00027S and BA00059S

Source for device description files

See data (→ 68)

Establishing a connection


Via service interface (CDI-RJ45)

1. Start FieldCare and launch the project.
2. In the network: Add a device.
 - ↳ The **Add device** window opens.
3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.

4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
↳ The **CDI Communication TCP/IP (Configuration)** window opens.
6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
7. Establish the online connection to the device.

 For details, see Operating Instructions BA00027S and BA00059S

User interface



A0021053-EN

- 1 Header
- 2 Picture of device
- 3 Device tag (→  71)
- 4 Status area with status signal (→  99)
- 5 Display area for current measured values (→  88)
- 6 Event list with additional functions such as save/load, events list and document creation
- 7 Navigation area with operating menu structure
- 8 Working area

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.00.00	<ul style="list-style-type: none"> On the title page of the Operating instructions On transmitter nameplate(→  14) Parameter firmware version Diagnostics → Device info → Firmware version
Release date of firmware version	10.2013	---
Manufacturer ID	0x49E	Manufacturer ID parameter Diagnostics → Device info → Manufacturer ID
Device type ID	0x103A	Device type parameter Diagnostics → Device info → Device type
Device revision	<ul style="list-style-type: none"> Major revision 1 Minor revision 1 	<ul style="list-style-type: none"> On transmitter nameplate(→  14) Device revision parameter Diagnostics → Device info → Device revision
Device profile	Generic device (product type: 0x2B)	

9.1.2 Operating tools

The suitable device description file for the operating tool is listed in the table below, along with information on where the file can be acquired.

Operating tool via service interface (CDI)	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)

9.2 Overview of system files

System files	Version	Description	How to acquire
Electronic Data Sheet (EDS system file)	1.00	Certified in accordance with the following ODVA guidelines: <ul style="list-style-type: none"> Conformance test Performance test PlugFest Embedded EDS Support (File Object 0x37)	<ul style="list-style-type: none"> www.endress.com → Download Area EDS system file integrated in the device: can be downloaded via the Web browser (→  64)
Add-on Profile Level 3	<ul style="list-style-type: none"> Major revision 1 Minor revision 1 	System file for "RSLogix 5000" software (Rockwell Automation)	www.endress.com → Download Area

9.3 Integrating the measuring device in the system

 A detailed description of how to integrate the device into an automation system (e.g. from Rockwell Automation) is available as a separate document: www.endress.com → Select country → Automation → Digital Communication → Fieldbus device integration → EtherNet/IP

 For information on the protocol-specific data of EtherNet/IP (→  121)

10 Commissioning

10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-installation check" checklist (→  32)
- "Post-connection check" checklist (→  45)

10.2 Switching on the measuring device

After a successful function check, switch on the measuring device.

After a successful startup, the local display switches automatically from the startup display to the operational display.

 If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" (→  93).

10.3 Configuring the device address via software

Software addressing is carried out in the **Communication** submenu.

Navigation path

"Setup" menu → Communication

When delivered, the measuring device has the following factory settings:


Ethernet network and Web server

IP address	192.168.1.212
Subnet mask	255.255.255.0
Default gateway	192.168.1.212

-  ▪ If hardware addressing is active, software addressing is disabled.
- If a switch is changed to the "ON" position, then the first three octets of the software address are retained.
- If the IP address of the device is not known, the device address currently configured can be read out (→  87).

10.4 Setting the operating language

Factory setting: English or ordered local language




22 Taking the example of the local display

10.5 Configuring the measuring device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.

Navigation to the **Setup** menu

Structure of the "Setup" menu




10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **"Device tag" parameter** and thus change the factory setting.

i The number of characters displayed depends on the characters used.

i For information on the tag name in the "FieldCare" operating tool (→ 67)



A0013375

23 Header of the operational display with tag name

1 Device tag

Navigation

"Setup" menu → Device tag

Parameter overview with brief description


Parameters	Description	User entry	Factory setting
Device tag	Enter tag for measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag 400

10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation

"Setup" menu → System units



Parameter overview with brief description

Parameters	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Output ▪ Low flow cut off ▪ Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ l/h ▪ gal/min (us)
Volume unit	Select volume unit. Result The selected unit is taken from: Volume flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ l ▪ gal (us)

Parameters	Description	Selection	Factory setting
Conductivity unit	Select conductivity unit. <i>Result</i> The selected unit applies for: Simulation process variable	Unit choose list	µS/cm
Temperature unit	Select temperature unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Output ▪ Reference temperature ▪ Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ °C (Celsius) ▪ °F (Fahrenheit)
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Output ▪ Low flow cut off ▪ Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ kg/h ▪ lb/min
Mass unit	Select mass unit. <i>Result</i> The selected unit is taken from: Mass flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ kg ▪ lb
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Output ▪ Simulation process variable ▪ Density adjustment (in Expert menu) 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ kg/l ▪ lb/ft³
Corrected volume flow unit	Select corrected volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ▪ Output ▪ Low flow cut off ▪ Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ NI/h ▪ Sft³/h
Corrected volume unit	Select corrected volume unit. Result The selected unit is taken from: Corrected volume flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> ▪ NI ▪ Sft³


10.5.3 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

Navigation

"Setup" menu → Display

Structure of the wizard



A0013797-EN

24 "Display" wizard in the "Setup" menu

Parameter overview with brief description

Parameters	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Conductivity ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	1 l/h
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None

Parameters	Description	Selection / User entry	Factory setting
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None


10.5.4 Configuring the communication interface

The "**Communication**" submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication

Structure of the submenu



Parameter overview with brief description

Parameters	Description	User interface / Selection / User entry	Factory setting
MAC address	Displays the MAC address of the measuring device.  MAC = Media Access Control	Unique 12-digit character string comprising letters and numbers, e.g.: 00:07:05:10:01:5F	Each measuring device is given an individual address.
Default network settings	Select whether to restore network settings.	<ul style="list-style-type: none"> ▪ Off ▪ On 	Off
DHCP client	Select to activate/deactivate DHCP client functionality. Result If the web server's DHCP client functionality is activated, the IP address, subnet mask and default gateway are automatically set.  Identification is via the MAC address of the measuring device.	<ul style="list-style-type: none"> ▪ Off ▪ On 	On
IP address	Displays the IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212


10.5.5 Configuring the low flow cut off

The **Low flow cut off** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

Navigation

"Setup" menu → Low flow cut off

Structure of the wizard



A0020524-EN

Fig. 25 "Low flow cut off" wizard in the "Setup" menu

Parameter overview with brief description

Parameters	Description	Selection / User entry	Factory setting
Assign process variable	Select process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow 	Volume flow
On value low flow cutoff	Enter on value for low flow cut off.	Signed floating-point number	0 l/h
Off value low flow cutoff	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s


10.5.6 Configuring empty pipe detection

The **Empty pipe detection** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

Navigation

"Setup" menu → Empty pipe detection

Structure of the wizard




26 "Empty pipe detection" wizard in the "Setup" menu

Parameter overview with brief description

Parameters	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	Switch empty pipe detection on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
New adjustment	Select type of adjustment.	<ul style="list-style-type: none"> ■ Cancel ■ Empty pipe adjust ■ Full pipe adjust 	Cancel
Progress		<ul style="list-style-type: none"> ■ Ok ■ Busy ■ Not ok 	
Switch point empty pipe detection	Enter hysteresis in %, below this value the measuring tube will detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	Enter the time before diagnostic message S862 'Pipe empty' is displayed for empty pipe detection.	0 to 100 s	1 s

Structure of the wizard



A0017210-EN


27 "Empty pipe detection" wizard in the "Setup" menu

10.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

"Setup" menu → Advanced setup

Navigation to the "Advanced setup" submenu



28 Illustrated using the example of the local display

Overview of the parameters and submenus in the "Advanced setup" menu

Advanced setup	→	Enter access code	(→ 61)
		Sensor adjustment	(→ 79)
		Totalizer 1 to 3	(→ 80)
		Display	(→ 81)
		Electrode cleaning circuit	(→ 83)
		Administration	(→ 85)

10.6.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment

Structure of the submenu**Parameter overview with brief description**

Parameters	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<ul style="list-style-type: none"> ▪ Flow in arrow direction ▪ Flow against arrow direction 	Flow in arrow direction

10.6.2 Configuring the totalizer

In the "Totalizer 1 to 3" submenu the individual totalizers can be configured.

Navigation

"Setup" menu → Advanced setup → Totalizer 1 to 3

Parameter overview with brief description

Parameters	Description	Selection	Factory setting
Totalizer operation mode	Select totalizer calculation mode.	<ul style="list-style-type: none"> ▪ Net flow total ▪ Forward flow total ▪ Reverse flow total 	Net flow total

10.6.3 Carrying out additional display configurations

In the **"Display"** submenu you can set all the parameters involved in the configuration of the local display.

Navigation

"Setup" menu → Advanced setup → Display

Structure of the submenu

Display	→	Format display
		Value 1 display
		0% bargraph value 1
		100% bargraph value 1
		Decimal places 1
		Value 2 display
		Decimal places 2
		Value 3 display
		0% bargraph value 3
		100% bargraph value 3
		Decimal places 3
		Value 4 display
		Decimal places 4
		Language
		Display interval
		Display damping
		Header
		Header text
		Separator
		Backlight

Parameter overview with brief description

Parameters	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ▪ 1 value, max. size ▪ 1 bargraph + 1 value ▪ 2 values ▪ 1 value large + 2 values ▪ 4 values 	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Conductivity ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3 	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	1 l/h
Decimal places 1	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx 	x.xx
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 2	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx 	x.xx
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx 	x.xx
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 4	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx 	x.xx

Parameters	Description	Selection / User entry	Factory setting
Display language	Set display language.	<ul style="list-style-type: none"> ▪ English ▪ Deutsch ▪ Français ▪ Español ▪ Italiano ▪ Nederlands ▪ Portuguesa ▪ Polski ▪ русский язык (Russian) ▪ Svenska ▪ Türkçe ▪ 中文 (Chinese) ▪ 日本語 (Japanese) ▪ 한국어 (Korean) ▪ العربية (Arabic) ▪ Bahasa Indonesia ▪ ภาษาไทย (Thai) ▪ tiếng Việt (Vietnamese) ▪ čeština (Czech) 	English
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	Select header contents on local display.	Enter display header text.	Device tag
Header text	Enter display header text.		-----
Separator	Select decimal separator for displaying numerical values.	<ul style="list-style-type: none"> ▪ . ▪ , 	.
Backlight	Switch the local display backlight on and off.	<ul style="list-style-type: none"> ▪ Disable ▪ Enable 	Disable

10.6.4 Performing electrode cleaning


The **Electrode cleaning circuit** wizard guides you systematically through all the parameters that have to be set for configuring electrode cleaning.

 The wizard only appears if the device was ordered with an electrode cleaning circuit.

Navigation

"Setup" menu → Advanced setup → Electrode cleaning circuit

Structure of the submenu



Parameter overview with brief description

Parameters	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning circuit	Enable the cyclic electrode cleaning circuit.	<ul style="list-style-type: none"> ▪ Off ▪ On 	Off
ECC duration	Enter the duration of electrode cleaning in seconds.	0.01 to 30 s	2 s
ECC recovery time	Define recovery time after electrode cleaning. During this time the current output values will be held at last valid value.	1 to 3.0 ⁺³⁸ s	5 s
ECC cleaning cycle	Enter the pause duration between electrode cleaning cycles.	0.5 to 168 h	40 min
ECC Polarity	Select the polarity of the electrode cleaning circuit.	<ul style="list-style-type: none"> ▪ Positive ▪ Negative 	Depends on the electrode material

10.7 Simulation

The "**Simulation**" submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).



The parameters displayed depend on:

- The selected device order
- The set operating mode of the pulse/frequency/switch outputs

Navigation

"Diagnostics" menu → Simulation

Simulation	→	Assign simulation process variable
		Value process variable
		Simulation device alarm
		Simulation diagnostic event

Parameter overview with brief description

Parameters	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Conductivity 	Off
Value process variable	A process variable is selected in the Assign simulation process variable parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0
Simulation device alarm	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> ▪ Off ▪ On 	Off
Simulation diagnostic event	–	Enter the diagnostic number for the diagnostic event.	Positive integer	65 533

10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code for the local display and Web browser (→  85)
- Write protection via write protection switch (→  86)
- Write protection via keypad lock (→  61)

10.8.1 Write protection via access code


The effects of the customer-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access via the Web browser is protected, as are the parameters for the measuring device configuration.

Navigation

"Setup" menu → Advanced setup → Administration → Define access code

Structure of the submenu



Defining the access code via local display

1. Navigate to the **"Enter access code" parameter**.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
 - ↳ The -symbol appears in front of all write-protected parameters.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

-  If write access is activated via access code, it can be also be deactivated only via the access code (→  61).
- The user role with which the user is currently logged on via the local display (→  61) is indicated by the **"Access status display" parameter**. Navigation path: Operation → Access status display

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from write protection via the local display. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

Defining the access code via the Web browser

1. Navigate to the **"Enter access code" parameter**.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
 - ↳ The Web browser switches to the login page.

-  If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


- i** The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling

10.8.2 Write protection via write protection switch

Unlike write protection via user-specific access code, this allows write access to the entire operating menu - other than the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

Via local display



A0017260

1. Loosen the 4 fixing screws on the housing cover and open the housing cover.
2. Setting the write protection switch (WP) on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch (WP) on the main electronics module to the OFF position (factory setting) disables the hardware write protection.
 - ↳ If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter (→ 87). In addition, on the local display the -symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0015870


If hardware write protection is disabled, no option is displayed in the **Locking status** parameter (→ 87). On the local display, the -symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

3. **WARNING!** Excessive tightening torque applied to the fixing screws! Risk of damaging the plastic transmitter. Tighten the fixing screws as per the tightening torque (→ 30). Reverse the removal procedure to reassemble the transmitter.

11 Operation

11.1 Read out and modify current Ethernet settings

If the Ethernet settings such as the IP address of the measuring device are unknown, they can be read out and modified as explained in the following example for an IP address.



Prerequisite

- Software addressing is enabled: All the DIP switches for hardware addressing are set to OFF. (→ 44)
- Measuring device is switched on.

1. Change DIP switch No. 10 from OFF → ON.
2. Restart the device.
 - ↳ The device's Ethernet settings are reset to their factory settings:
IP address: 192.168.1.212; Subnet mask: 255.255.255.0; Default gateway: 192.168.1.212
3. Enter the default setting for the IP address in the address line of the Web browser.
4. In the operating menu navigate to the **IP address** parameter: "Setup" menu → Communication → IP address
 - ↳ The parameter displays the configured IP address.
5. Change the IP address of the device if necessary.
6. Change DIP switch No. 10 from ON → OFF.
7. Restart the device.
 - ↳ The modified IP address of the device is now enabled.

11.2 Reading device locking status

The write protection types that are currently active can be determined using the "**Locking status**" parameter.

"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
None	The access status displayed in " Access status display " parameter applies (→ 61). Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (→ 86).
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc). Once the internal processing has been completed, the parameters can be changed once again.

11.3 Adjusting the operating language

Information (→ 70)

 For information on the operating languages supported by the measuring device (→ 138)

11.4 Configuring the display

- Basic settings for local display (→ 73)
- Advanced settings for local display (→ 81)

11.5 Reading measured values

Using the **Measured values** submenu, it is possible to read all the measured values.

"Diagnostics" menu → Measured values


11.5.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables

Structure of the submenu



Structure of the submenu

Parameter overview with brief description

Parameters	Description	User interface
Volume flow	Displays the volume flow currently measured.	Signed floating-point number
Mass flow	Displays the mass flow currently calculated.	Signed floating-point number
Conductivity	Displays the corrected volume flow currently calculated.	Positive floating-point number
Steam quality	Displays the steam quality currently calculated.	Signed floating-point number


11.5.2 Totalizer

The **"Totalizer"** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer

Structure of the submenu



Parameter overview with brief description

Parameters	Prerequisite	Description	User interface	Factory setting
Totalizer value	In the Assign process variable parameter of the Totalizer 1 to 3 submenu one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow ▪ Condensate mass flow ▪ Energy flow ▪ Heat flow difference 	Displays the current totalizer counter value.	Signed floating-point number	01
Totalizer overflow	In the Assign process variable parameter of the Totalizer 1 to 3 submenu one of the following options is selected: <ul style="list-style-type: none"> ▪ Volume flow ▪ Corrected volume flow ▪ Mass flow ▪ Total mass flow ▪ Condensate mass flow ▪ Energy flow ▪ Heat flow difference 	Displays the current totalizer overflow.	-32.000.0 to 32.000.0	0

11.6 Adapting the measuring device to the process conditions

The following are available for this purpose:


- Basic settings using the **Setup** menu(→ 📖 71)
- Advanced settings using the **Advanced setup** submenu(→ 📖 79)

11.7 Performing a totalizer reset

Navigation

"Operation" menu → Operation

Structure of the submenu



Parameter overview with brief description

Parameters	Description	Selection / User entry	Factory setting
Control Totalizer	Control totalizer value.	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize 	Totalize
Preset value	Specify start value for totalizer.	Signed floating-point number	0 1
Reset all totalizers	Reset all totalizers to 0 and start.	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize 	Cancel

11.7.1 Function scope of "Control Totalizer " parameter

Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in Preset value parameter and the totaling process is restarted.

11.7.2 Function scope of "Reset all totalizers" parameter


Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

11.8 Showing data logging

In the device, the extended function of the HistoROM must be enabled (order option) so that the "**Data logging**" submenu appears. This contains all the parameters for the measured value history.

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



29 Chart of a measured value trend

A0016222

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

i If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

"Data logging" submenu

Data logging

→

Assign channel 1

Assign channel 2

Assign channel 3

Assign channel 4

Logging interval

Clear logging data

Parameter overview with brief description

Parameters	Description	Selection / User entry	Factory setting
Assign channel 1	Assign process variable to logging channel.	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Conductivity ▪ Electronic temperature 	Off
Assign channel 2	Assign process variable to logging channel.	Picklist (see Assign chan. 1 parameter)	Off
Assign channel 3	Assign process variable to logging channel.	Picklist (see Assign chan. 1 parameter)	Off
Assign channel 4	Assign process variable to logging channel.	Picklist (see Assign chan. 1 parameter)	Off

Parameters	Description	Selection / User entry	Factory setting
Logging interval	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	10.0 s
Clear logging data	Clear the entire logging data.	<ul style="list-style-type: none">■ Cancel■ Clear data	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Problem	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage (→ 38).
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	Main electronics module is defective.	Order spare part (→ 114).
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	1. Check the connection of the electrode cable and correct if necessary. 2. Check the connection of the coil current cable and correct if necessary.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul style="list-style-type: none"> ▪ Set the display brighter by simultaneously pressing \oplus + \boxplus. ▪ Set the display darker by simultaneously pressing \ominus + \boxplus.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part (→ 114).
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures (→ 104)
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	<ol style="list-style-type: none"> 1. Press \ominus + \oplus for 2 s ("home position"). 2. Press \boxplus. 3. Set the desired language in the Language parameter.

For output signals

Problem	Possible causes	Remedy
Signal output outside the valid range	Main electronics module is defective.	Order spare part (→ 114).
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol style="list-style-type: none"> 1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data".

For access

Problem	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position (→ 86).
No write access to parameters	Current user role has limited access authorization	1. Check user role (→ 61). 2. Enter correct customer-specific access code (→ 61).
No connection via EtherNet/IP	Device plug connected incorrectly	Check the pin assignment of the device plug (→ 36).
Not connecting to Web server	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) (→ 63). 2. Check the network settings with the IT manager.
Not connecting to Web server	Web server disabled	Via the "FieldCare" operating tool check whether the Web server of the measuring device is enabled and enable it if necessary (→ 65).
No or incomplete display of contents in the Web browser	<ul style="list-style-type: none"> ▪ JavaScript not enabled ▪ JavaScript cannot be enabled 	1. Enable JavaScript. 2. Enter http://192.168.1.212/basic.html as the IP address.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
Web browser frozen and operation no longer possible	Connection lost	1. Check cable connection and power supply. 2. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	1. Use the correct Web browser version (→ 62). 2. Clear the Web browser cache and restart the Web browser.
Content of Web browser incomplete or difficult to read	Unsuitable view settings.	Change the font size/display ratio of the Web browser.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter

Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.


LED	Color	Meaning
Power	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Device status	Green	Device status is ok
	Flashing red	A device error of diagnostic behavior "Warning" has occurred
	Red	A device error of diagnostic behavior "Alarm" has occurred
	Alternately flashing red/green	Boot loader is active
Network status	Off	Device has no EtherNet/IP address
	Green	Device's EtherNet/IP connection is active
	Flashing green	Device has EtherNet/IP address but no EtherNet/IP connection

LED	Color	Meaning
	Red	EtherNet/IP address of the device has been assigned twice
	Flashing red	Device's EtherNet/IP connection is in timeout mode
Link/Activity	Orange	Link available but no activity
	Flashing orange	Activity present
Communication	Flashing white	
Alarm	Green	Measuring device is ok
	Flashing green	Measuring device not configured
	Off	Firmware error
	Red	Main error
	Flashing red	Error
	Flashing red/green	Start measuring device

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- i** Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
 - Via parameters
 - Via submenus (→ 108)

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
F <small>A0013956</small>	Failure A device error has occurred. The measured value is no longer valid.
C <small>A0013959</small>	Function check The device is in service mode (e.g. during a simulation).
S <small>A0013958</small>	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
M <small>A0013957</small>	Maintenance required Maintenance is required. The measured value is still valid.


- i** The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required

Diagnostic behavior

Symbol	Meaning
 <small>A0013961</small>	Alarm <ul style="list-style-type: none"> ▪ Measurement is interrupted. ▪ Signal outputs and totalizers assume the defined alarm condition. ▪ A diagnostic message is generated. ▪ The background lighting changes to red.
 <small>A0013962</small>	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Key	Meaning
 <small>A0013970</small>	Plus key <i>In a menu, submenu</i> Opens the message about the remedial measures.
 <small>A0013952</small>	Enter key <i>In a menu, submenu</i> Opens the operating menu.

12.3.2 Calling up remedial measures



30 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

1. Press \oplus (ⓘ symbol).
 - ↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with \oplus or \ominus and press ⓔ .
 - ↳ The message for the remedial measures for the selected diagnostic event opens.
3. Press \ominus + \oplus simultaneously.
 - ↳ The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

1. Press ⓔ .
 - ↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press \ominus + \oplus simultaneously.
 - ↳ The message for the remedial measures closes.

12.4 Diagnostic information in the Web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.

1 Status area with status signal
 2 Diagnostic information (→ 97)
 3 Remedial measures with Service ID

- i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
- Via parameters
 - Via submenus (→ 108)

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
 A0017271	Failure A device error has occurred. The measured value is no longer valid.
 A0017278	Function check The device is in service mode (e.g. during a simulation).
 A0017277	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
 A0017276	Maintenance required Maintenance is required. The measured value is still valid.

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare

12.5.1 Diagnostic options


Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

1 Status area with status signal (→ 96)(→ 99)
 2 Diagnostic information (→ 97)(→ 97)
 3 Remedial measures with Service ID

- i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
 - Via parameters
 - Via submenu (→ 108)

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
 - ↳ A tool tip with remedy information for the diagnostic event appears.

12.6 Diagnostic information in FieldCare

12.6.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

The screenshot displays the FieldCare interface. At the top, there are several status indicators: 'Device name: xxxxxxxx', 'Device tag: xxxxxxxx', 'Status signal: Function check (C)', 'Output current 1: 4.00 mA', 'Output current 2: 4.00 mA', 'Mass flow: 0.0000 kg/s', 'Corrected volume flow: -0.0224 Nl/s', and 'Volume flow: -0.0224 l/s'. Below this is a table with columns for 'Menu / Variable', 'Value', and 'Unit'. The table lists several diagnostic categories like 'Diagnostics 1', 'Remedy information', 'Access status tooling', 'Display/operation', 'Setup', 'Diagnostics', and 'Expert'. To the right, there is a section titled 'Instrument health status' with icons for 'Failure (F)', 'Function check (C)', 'Out of specification (S)', and 'Maintenance required (M)'. A tooltip is shown over the 'Function check (C)' icon, displaying 'C485 Simulation measured variable' and 'Deactivate simulation (Service ID:147)'. A legend at the bottom of the screenshot explains the numbered callouts: 1 points to the status area, 2 points to the diagnostic information, and 3 points to the remedial measures.


1 Status area with status signal (→ 96)(→ 99)
 2 Diagnostic information (→ 97)(→ 97)
 3 Remedial measures with Service ID

i Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameters
- Via submenu (→ 108)

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.6.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.


The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
↳ A tool tip with remedy information for the diagnostic event appears.

12.7 Diagnostic information via communication interface

12.7.1 Reading out diagnostic information

The current diagnostic event and associated diagnostic information can be read out via the input assembly (fix assembly):



 For content of bytes 8 to 16 (→  121)

12.8 Adapting the diagnostic information

12.8.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostics information in the **Diagnostic behavior** submenu.

"Expert" menu → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. The totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	Measurement is resumed. The totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.9 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

Diagnostic number	Short text	Repairing action	Status signal from the factory	Diagnostic behaviour from the factory
Diagnostic of sensor				
004	Sensor defective	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	F	Alarm
022	Temperature sensor defective	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	F	Alarm
046	Sensor limit exceeded	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	S	Warning
062	Sensor connection defective	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	F	Alarm
082	Data storage	1. Change main electronic module 2. Change sensor	F	Alarm
083	Memory content	1. Restart device 2. Restore S-Dat data 3. Change sensor	F	Alarm
114	Sensor leaky	Change DSC sensor	F	Alarm
122	Temperature sensor defective	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	M	Warning
Diagnostic of electronic				
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm
252	Modules incompatible	1. Check electronic modules 2. Change I/O or main electronic module	F	Alarm
261	Electronic modules	1. Restart device 2. Check electronic modules 3. Change I/O Modul or main electronics	F	Alarm
262	Module connection	1. Check module connections 2. Change electronic modules	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	1. Emergency operation via display 2. Change main electronics	F	Alarm
275	I/O module failure	Change I/O module	F	Alarm
276	I/O module failure	1. Restart device 2. Change I/O module	F	Alarm
277	Electronics defective	1. Change pre-amplifier 2. Change main electronic module	F	Alarm

Diagnostic number	Short text	Repairing action	Status signal from the factory	Diagnostic behaviour from the factory
282	Data storage	1. Restart device 2. Contact service	F	Alarm
283	Memory content	1. Transfer data or reset device 2. Contact service	F	Alarm
302	Device verification active	Device verification active, please wait.	C	Warning
311	Electronic failure	1. Transfer data or reset device 2. Contact service	F	Alarm
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	M	Warning
350	Pre-amplifier defective	Change pre-amplifier	F	Alarm
351	Pre-amplifier defective	Change pre-amplifier	F	Alarm
370	Pre-amplifier defective	1. Check plug connections 2. Check cabel connection of remote version 3. Change pre-amplifier or main electronic module	F	Alarm
371	Temperature sensor defective	1. Check plug connections 2. Change pre-amplifier 3. Change DSC sensor	M	Warning
Diagnostic of configuration				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning
431	Trim	Carry out trim	C	Warning
437	Configuration incompatible	1. Restart device 2. Contact service	F	Alarm
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
441	Current output 1 to 2	1. Check process 2. Check current output settings	S	Warning
442	Frequency output	1. Check process 2. Check frequency output settings	S	Warning
443	Pulse output	1. Check process 2. Check pulse output settings	S	Warning
444	Current input 1	1. Check process 2. Check current input settings	S	Warning
453	Flow override	Deactivate flow override	C	Warning
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
486	Simulation current input 1	Deactivate simulation	C	Warning
491	Simulation current output 1 to 2	Deactivate simulation	C	Warning
492	Simulation frequency output	Deactivate simulation frequency output	C	Warning

Diagnostic number	Short text	Repairing action	Status signal from the factory	Diagnostic behaviour from the factory
493	Simulation pulse output	Deactivate simulation pulse output	C	Warning
494	Switch output simulation	Deactivate simulation switch output	C	Warning
495	Simulation diagnostic event	Deactivate simulation	C	Warning
538	Flow computer configuration incorrect	Check input value (pressure, temperature)	S	Warning
538	Flow computer configuration incorrect	Check entered reference value using the document Operating Instructions	S	Warning
539	Flow computer configuration incorrect	1. Check input value (pressure, temperature) 2. Check allowed values of the medium properties	S	Alarm
539	Flow computer configuration incorrect	Contact service	S	Alarm
570	Inverted delta heat	Check configuration of mounting location (parameter Installation direction)	F	Alarm
Diagnostic of process				
801	Supply voltage too low	Increase supply voltage	S	Warning
803	Current loop	1. Check wiring 2. Change I/O module	F	Alarm
825	Operating temperature	1. Check ambient temperature 2. Check process temperature	F	Alarm
828	Ambient temperature too low	Increase ambient temperature of pre-amplifier	S	Warning
829	Ambient temperature too high	Reduce ambient temperature of pre-amplifier	S	Warning
832	Ambient temperature too high	Reduce ambient temperature	S	Warning
833	Ambient temperature too low	Increase ambient temperature	S	Warning
834	Process temperature too high	Reduce process temperature	S	Warning
835	Process temperature too low	Increase process temperature	S	Warning
841	Flow velocity too high	Reduce flow velocity	S	Warning
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
844	Sensor range exceeded	Reduce flow velocity	S	Warning
862	Partly filled pipe	1. Check for gas in process 2. Adjust detection limits	S	Warning
870	Measuring inaccuracy increased	1. Check process 2. Increase flow volume	S	Warning
871	Near steam saturation limit	Check process conditions	S	Warning
872	Wet steam detected	1. Check process 2. Check plant	S	Warning
873	No steam detected	Check process (water in piping)	S	Warning

Diagnostic number	Short text	Repairing action	Status signal from the factory	Diagnostic behaviour from the factory
874	Wet steam detection uncertain	1. Check pressure, temperature 2. Check flow velocity 3. Check for flow fluctuation	S	Warning
882	Input signal	1. Check input configuration 2. Check pressure sensor or process conditions	F	Alarm
945	Sensor range exceeded	Check immediately process conditions (pressure-temperature rating)	S	Warning
946	Vibration detected	Check installation	S	Warning
947	Vibration exceeded	Check installation	S	Alarm

12.10 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

-  To call up the measures to rectify a diagnostic event:
 - Via local display (→  98)
 - Via Web browser (→  99)
 - Via "FieldCare" operating tool (→  101)

-  Other pending diagnostic events can be displayed in the **Diagnostic list** submenu(→  108)

Navigation
"Diagnostics" menu

Structure of the submenu



Parameter overview with brief description


Parameters	Prerequisite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	–
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	–

12.11 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → **Diagnostic list** submenu



A0014006-EN

31 Illustrated using the example of the local display

i To call up the measures to rectify a diagnostic event:

- Via local display (→ 98)
- Via Web browser (→ 99)
- Via "FieldCare" operating tool (→ 101)


12.12 Event logbook

12.12.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Events list



A0014006-EN

32 Illustrated using the example of the local display

The event history includes entries for:

- Diagnostic events (→ 104)
- Information events (→ 109)

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ⌚: Event has occurred
 - ⌚: Event has ended
- Information event
 - ⌚: Event has occurred

i To call up the measures to rectify a diagnostic event:

- Via local display (→ 98)
- Via Web browser (→ 99)
- Via "FieldCare" operating tool (→ 101)

 For filtering the displayed event messages (→  109)

12.12.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.12.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1361	Wrong web server login
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed

Info number	Info name
I1446	Device verification active
I1447	Record application reference data
I1448	Application reference data recorded
I1449	Recording application ref. data failed
I1450	Monitoring off
I1451	Monitoring on
I1457	Failed:Measured error verification
I1459	Failed: I/O module verification
I1460	Failed: Sensor integrity verification
I1461	Failed: Sensor verification
I1462	Failed:Sensor electronic module verific.

12.13 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

"Setup" menu → Advanced setup → Administration

Function scope of "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

12.14 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

Navigation

"Diagnostics" menu → Device information

Device information	→	Device tag
		Serial number
		Firmware version
		Device name
		Order code
		Extended order code 1

Extended order code 2
Extended order code 3
ENP version
IP address
Subnet mask
Default gateway

Parameter overview with brief description

Parameters	Description	User interface / User entry	Factory setting
Device tag	Enter tag for measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)	Promag 400
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	79AFF16000
Firmware version	Displays the device firmware version installed.	Character string with the following format: xx.yy.zz	01.00
Device name	Displays the name of the transmitter.	Character string composed of letters, numbers and certain punctuation marks.	Promag 400
Order code	Displays the device order code.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Displays the 1st part of the extended order code.	Character string	-
Extended order code 2	Displays the 2nd part of the extended order code.	Character string	-
Extended order code 3	Displays the 3rd part of the extended order code.	Character string	-
ENP version	Displays the version of the electronic nameplate.	Character string in the format xx.yy.zz	2.02.00
IP address	Displays the IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212

12.15 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
10.2013	01.00.00	Option 77	Original firmware	Operating Instructions	BA01213D/06/EN/01.13

-  Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) (→  138).
-  For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
-  The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download
 - Specify the following details:
 - Text search: Manufacturer's information
 - Search range: documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

WARNING

Cleaning agents can damage the plastic transmitter housing!

- ▶ Do not use high-pressure steam.
- ▶ Only use the permitted cleaning agents specified.

Permitted cleaning agents for the plastic transmitter housing

- Commercially available household cleaners
- Methyl alcohol or isopropyl alcohol
- Mild soap solutions

13.1.2 Interior cleaning

No interior cleaning is planned for the device.

13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.

The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory) (→  140)

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

-  Measuring device serial number:
 - Is located on the nameplate of the device.
 - Can be read out via the **Serial number** parameter in the **Device information** submenu (→  110).

14.3 Endress+Hauser services

-  Contact your Endress+Hauser Sales Center for information on services and spare parts.

14.4 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at www.services.endress.com/return-material

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.

2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Display protection	Is used to protect the display against impact or scoring from sand in desert areas.  For details, see Special Documentation SD00333F
Connecting cable for remote version	Coil current and electrode cables, various lengths, reinforced cables available on request.
Ground cable	Set, consisting of two ground cables for potential equalization.
Pipe mounting set	Pipe mounting set for transmitter.
Compact → remote conversion kit	For converting a compact device version to a remote device version.
Promag 50/53 → Promag 400 conversion kit	For converting a Promag with transmitter 50/53 to a Promag 400.

15.1.2 For the sensor

Accessories	Description
Ground disks	Are used to ground the fluid in lined measuring tubes to ensure proper measurement.  For details, see Installation Instructions EA00070D

15.2 Communication-specific accessories

Accessories	Description
Fieldgate FXA320	Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser.  For details, see "Technical Information" TI00025S and Operating Instructions BA00053S

15.3 Service-specific accessories

Accessories	Description
Applicator	<p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> ▪ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. ▪ Graphic illustration of the calculation results <p>Administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</p> <p>Applicator is available:</p> <ul style="list-style-type: none"> ▪ Via the Internet: https://wapps.endress.com/applicator ▪ On CD-ROM for local PC installation.
W@M	<p>Life cycle management for your plant</p> <p>W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle.</p> <p>The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records.</p> <p>W@M is available:</p> <ul style="list-style-type: none"> ▪ Via the Internet: www.endress.com/lifecyclemanagement ▪ On CD-ROM for local PC installation.
FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> For details, see Operating Instructions BA00027S and BA00059S</p>

15.4 System components

Accessories	Description
Memograph M graphic display recorder	<p>The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <p> For details, see "Technical Information" TI00133R and Operating Instructions BA00247R</p>

16 Technical data

16.1 Application

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5 µS/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

Measuring principle Electromagnetic flow measurement on the basis of *Faraday's law of magnetic induction*.

Measuring system The device consists of a transmitter and a sensor.
 Two device versions are available:
 ■ Compact version - the transmitter and sensor form a mechanical unit.
 ■ Remote version – the transmitter and sensor are mounted separately from one another.
 For information on the structure of the device (→  12)

16.3 Input

Measured variable **Direct measured variables**
 ■ Volume flow (proportional to induced voltage)
 ■ Electrical conductivity

Calculated measured variables

Mass flow

Measuring range Typically $v = 0.01$ to 10 m/s (0.03 to 33 ft/s) with the specified accuracy
 Electrical conductivity: 5 to $10\,000$ µS/cm/cm

Flow characteristic values in SI units

Nominal diameter		Recommended flow min./max. full scale value ($v \sim 0.3/10$ m/s) [m³/h]	Factory settings		
[mm]	[in]		Full scale value current output ($v \sim 2.5$ m/s) [m³/h]	Pulse value (~ 2 pulse/s) [m³]	Low flow cut off ($v \sim 0.04$ m/s) [m³/h]
50	2	35 to 1 100 dm³/min	300 dm³/min	2.5 dm³	5 dm³/min
65	–	60 to 2 000 dm³/min	500 dm³/min	5 dm³	8 dm³/min
80	3	90 to 3 000 dm³/min	750 dm³/min	5 dm³	12 dm³/min
100	4	145 to 4 700 dm³/min	1 200 dm³/min	10 dm³	20 dm³/min
125	–	220 to 7 500 dm³/min	1 850 dm³/min	15 dm³	30 dm³/min

Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3/10 m/s)	Factory settings		
[mm]	[in]		Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
		[m ³ /h]	[m ³ /h]	[m ³]	[m ³ /h]
150	6	20 to 600	150	0.025	2.5
200	8	35 to 1100	300	0.05	5
250	10	55 to 1700	500	0.05	7.5
300	12	80 to 2400	750	0.1	10
350	14	110 to 3300	1000	0.1	15
375	15	140 to 4200	1200	0.15	20
400	16	140 to 4200	1200	0.15	20
450	18	180 to 5400	1500	0.25	25
500	20	220 to 6600	2000	0.25	30
600	24	310 to 9600	2500	0.3	40
700	28	420 to 13500	3500	0.5	50
750	30	480 to 15000	4000	0.5	60
800	32	550 to 18000	4500	0.75	75
900	36	690 to 22500	6000	0.75	100
1000	40	850 to 28000	7000	1	125
-	42	950 to 30000	8000	1	125
1200	48	1250 to 40000	10000	1.5	150
-	54	1550 to 50000	13000	1.5	200
1400	-	1700 to 55000	14000	2	225
-	60	1950 to 60000	16000	2	250
1600	-	2200 to 70000	18000	2.5	300
-	66	2500 to 80000	20500	2.5	325
1800	72	2850 to 90000	23000	3	350
-	78	3300 to 100000	28500	3.5	450
2000	-	3400 to 110000	28500	3.5	450
-	84	3700 to 125000	31000	4.5	500
2200	-	4100 to 136000	34000	4.5	540
-	90	4300 to 143000	36000	5	570
2400	-	4800 to 162000	40000	5.5	650

Flow characteristic values in US units

Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3/10 m/s)	Factory settings		
[in]	[mm]		Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
		[gal/min]	[gal/min]	[gal]	[gal/min]
1	25	2.5 to 80	18	0.2	0.25
1 ½	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25

Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3/10 m/s)	Factory settings		
			Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
-	65	16 to 500	130	1	2
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4
8	200	155 to 4850	1200	10	15
10	250	250 to 7500	1500	15	30
12	300	350 to 10600	2400	25	45
14	350	500 to 15000	3600	30	60
15	375	600 to 19000	4800	50	60
16	400	600 to 19000	4800	50	60
18	450	800 to 24000	6000	50	90
20	500	1000 to 30000	7500	75	120
24	600	1400 to 44000	10500	100	180
28	700	1900 to 60000	13500	125	210
30	750	2150 to 67000	16500	150	270
32	800	2450 to 80000	19500	200	300
36	900	3100 to 100000	24000	225	360
40	1000	3800 to 125000	30000	250	480
42	-	4200 to 135000	33000	250	600
48	1200	5500 to 175000	42000	400	600
54	-	9 to 300 MGal/d	75 MGal/d	0.0005 MGal/d	1.3 MGal/d
-	1400	10 to 340 MGal/d	85 MGal/d	0.0005 MGal/d	1.3 MGal/d
60	-	12 to 380 MGal/d	95 MGal/d	0.0005 MGal/d	1.3 MGal/d
-	1600	13 to 450 MGal/d	110 MGal/d	0.0008 MGal/d	1.7 MGal/d
66	-	14 to 500 MGal/d	120 MGal/d	0.0008 MGal/d	2.2 MGal/d
72	1800	16 to 570 MGal/d	140 MGal/d	0.0008 MGal/d	2.6 MGal/d
78	-	18 to 650 MGal/d	175 MGal/d	0.0010 MGal/d	3.0 MGal/d
-	2000	20 to 700 MGal/d	175 MGal/d	0.0010 MGal/d	2.9 MGal/d
84	-	24 to 800 MGal/d	190 MGal/d	0.0011 MGal/d	3.2 MGal/d
-	2200	26 to 870 MGal/d	210 MGal/d	0.0012 MGal/d	3.4 MGal/d
90	-	27 to 910 MGal/d	220 MGal/d	0.0013 MGal/d	3.6 MGal/d
-	2400	31 to 1030 MGal/d	245 MGal/d	0.0014 MGal/d	4.1 MGal/d

Recommended measuring range

"Flow limit" section (→  127)

Operable flow range

Over 1000 : 1

Input signal

16.4 Output

Output signal

EtherNet/IP

Standards	In accordance with IEEE 802.3
------------------	-------------------------------

Signal on alarm

Depending on the interface, failure information is displayed as follows:

EtherNet/IP

Device diagnostics	Device condition can be read out in Input Assembly
---------------------------	--

Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

 Status signal as per NAMUR recommendation NE 107

Operating tool

Plain text display	With information on cause and remedial measures
---------------------------	---

Web browser

Plain text display	With information on cause and remedial measures
---------------------------	---

Light emitting diodes (LED)

Status information	<p>Status indicated by various light emitting diodes</p> <p>The following information is displayed depending on the device version:</p> <ul style="list-style-type: none"> ▪ Supply voltage active ▪ Data transmission active ▪ Device alarm/error has occurred ▪ EtherNet/IP network available ▪ EtherNet/IP connection established
---------------------------	---

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The following connections are galvanically isolated from each other:

- Outputs
- Power supply

Protocol-specific data

EtherNet/IP

Protocol	<ul style="list-style-type: none"> ▪ The CIP Networks Library Volume 1: Common Industrial Protocol ▪ The CIP Networks Library Volume 2: EtherNet/IP Adaptation of CIP
Communication type	<ul style="list-style-type: none"> ▪ 10Base-T ▪ 100Base-TX

Device profile	Generic device (product type: 0x2B)		
Manufacturer ID	0x49E		
Device type ID	0x1067		
Baud rates	Automatic ¹⁰ / ₁₀₀ Mbit with half-duplex and full-duplex detection		
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs		
Supported CIP connections	Max. 3 connections		
Explicit connections	Max. 6 connections		
I/O connections	Max. 6 connections (scanner)		
Configuration options for measuring device	<ul style="list-style-type: none"> ▪ DIP switches on the electronics module for IP addressing ▪ Manufacturer-specific software (FieldCare) ▪ Add-on Profile Level 3 for Rockwell Automation control systems ▪ Web browser ▪ Electronic Data Sheet (EDS) integrated in the measuring device 		
Configuration of the EtherNet interface	<ul style="list-style-type: none"> ▪ Speed: 10 MBit, 100 MBit, auto (factory setting) ▪ Duplex: half-duplex, full-duplex, auto (factory setting) 		
Configuration of the device address	<ul style="list-style-type: none"> ▪ DIP switches on the electronics module for IP addressing (last octet) ▪ DHCP ▪ Manufacturer-specific software (FieldCare) ▪ Add-on Profile Level 3 for Rockwell Automation control systems ▪ Web browser ▪ EtherNet/IP tools, e.g. RSLinx (Rockwell Automation) 		
Device Level Ring (DLR)	No		
Fix Input			
RPI	5 ms to 10 s (factory setting: 20 ms)		
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	O → T configuration:	0x66	56
	T → O configuration:	0x64	32
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	O → T configuration:	0x66	56
	T → O configuration:	0x64	32
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	O → T configuration:	0xC7	-
	T → O configuration:	0x64	32
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	O → T configuration:	0xC7	-
	T → O configuration:	0x65	32
Input Assembly	<ul style="list-style-type: none"> ▪ Current device diagnostics ▪ Volume flow ▪ Mass flow ▪ Temperature ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3 		
Configurable Input			
RPI	5 ms to 10 s (factory setting: 20 ms)		
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398

	Instance configuration:	0x68	398
	O → T configuration:	0x66	56
	T → O configuration:	0x65	88
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	O → T configuration:	0x66	56
	T → O configuration:	0x64	88
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	O → T configuration:	0xC7	-
	T → O configuration:	0x64	88
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	O → T configuration:	0xC7	-
	T → O configuration:	0x65	88
Configurable Input Assembly	<ul style="list-style-type: none"> ■ Volume flow ■ Temperature ■ Mass flow ■ Totalizer 1 to 3 ■ Flow velocity ■ Volume flow unit ■ Temperature unit ■ Mass flow unit ■ Unit totalizer 1-3 ■ Flow velocity unit 		
Fix Output			
Output Assembly	<ul style="list-style-type: none"> ■ Activation of reset totalizers 1-3 ■ Activation of reference density compensation ■ Reset totalizers 1-3 ■ External density ■ Density unit ■ Temperature unit 		
Configuration			
Configuration Assembly	<p>Only the most common configurations are listed below.</p> <ul style="list-style-type: none"> ■ Software write protection ■ Mass flow unit ■ Mass unit ■ Volume flow unit ■ Volume unit ■ Density unit ■ Reference density unit ■ Temperature unit ■ Length ■ Totalizer 1-3: <ul style="list-style-type: none"> - Assignment - Unit - Operating mode - Failure mode ■ Alarm delay 		

16.5 Power supply

Supply voltage

Transmitter

Order code for "Power supply"	Terminal voltage	Frequency range
Option L	AC100 to 240 V	50/ 60 Hz, ±4 Hz
	AC/DC24 V	50/ 60 Hz, ±4 Hz

Power consumption

Order code for "Output"	Maximum Power consumption
Option N	30 VA/8 W

Current consumption

Transmitter

Order code for "Power supply"	Maximum Current consumption	Maximum switch-on current
Option L: AC 100 to 240 V	145 mA	25 A (< 5 ms)
Option L: AC/DC 24 V	350 mA	27 A (< 5 ms)

Power supply failure

- Totalizers stop at the last value measured.
- Configuration is retained in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Electrical connection

(→  38)

Potential equalization

(→  41)

Terminals

Transmitter

- Supply voltage cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Signal cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Electrode cable: spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Coil current cable: spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

Sensor connection housing

Spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

Cable entries

Cable entry thread

- M20 x 1.5
- Via adapter:
 - NPT ½"
 - G ½"

Cable gland

- For standard cable: M20 × 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- For reinforced cable: M20 × 1.5 with cable ϕ 9.5 to 16 mm (0.37 to 0.63 in)

 If metal cable entries are used, use a grounding plate.

Cable specification

(→  33)

16.6 Performance characteristics

Reference operating conditions

In accordance with DIN EN 29104

- Fluid temperature: $+28 \pm 2$ °C ($+82 \pm 4$ °F)
- Ambient temperature range: $+22 \pm 2$ °C ($+72 \pm 4$ °F)
- Warm-up period: 30 min

Installation

- Inlet run $> 10 \times DN$
- Outlet run $> 5 \times DN$
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Maximum measured error


Error limits under reference operating conditions

o.r. = of reading

Volume flow

- ± 0.5 % o.r. ± 1 mm/s (0.04 in/s)
- Optional: ± 0.2 % o.r. ± 2 mm/s (0.08 in/s)

 Fluctuations in the supply voltage do not have any effect within the specified range.



 33 Maximum measured error in % o.r.

Electrical conductivity

Max. measured error not specified.

Repeatability

o.r. = of reading

Volume flow

Max. ± 0.1 % o.r. ± 0.5 mm/s (0.02 in/s)

Electrical conductivity

Max. ± 5 % o.r.

16.7 Installation

"Mounting requirements" (\rightarrow  19)

16.8 Environment

Ambient temperature range	(→  22)
Storage temperature	<p>The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.</p> <ul style="list-style-type: none"> ▪ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures. ▪ Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner. ▪ If protection caps or protective covers are mounted these should never be removed before installing the measuring device.
Degree of protection	<p>Transmitter</p> <ul style="list-style-type: none"> ▪ As standard: IP66/67, type 4X enclosure ▪ When housing is open: IP20, type 1 enclosure <p>Sensor</p> <ul style="list-style-type: none"> ▪ As standard: IP66/67, type 4X enclosure ▪ Optionally available for remote version: IP68, type 6P enclosure (for DN ≤ 300 (12") only possible in conjunction with stainless steel flanges) <p>Not suitable for use in corrosive atmospheres/liquids or in buried applications if special precautions are not taken.</p>
Shock resistance	Acceleration up to 2 g following IEC 60068-2-6
Vibration resistance	Acceleration up to 2 g following IEC 60068-2-6
Mechanical load	<ul style="list-style-type: none"> ▪ Protect the transmitter housing against mechanical effects, such as shock or impact; the use of the remote version is sometimes preferable. ▪ Never use the transmitter housing as a ladder or climbing aid.
Electromagnetic compatibility (EMC)	<ul style="list-style-type: none"> ▪ As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) ▪ Complies with emission limits for industry as per EN 55011 (Class A) <p> Details are provided in the Declaration of Conformity.</p>

16.9 Process

Medium temperature range	<ul style="list-style-type: none"> ▪ 0 to +80 °C (+32 to +176 °F) for hard rubber, DN 350 to 2400 (14 to 90") ▪ -20 to +50 °C (-4 to +122 °F) for polyurethane, DN 50 to 1200 (2 to 48") ▪ -20 to +90 °C (-4 to +194 °F) for PTFE, DN 50 to 300 (2 to 12")
Conductivity	<p>≥ 5 µS/cm for liquids in general</p> <p> Note that in the case of the remote version, the requisite minimum conductivity also depends on the cable length .</p>

Pressure-temperature ratings



An overview of the material load diagrams (pressure/temperature curves) for the process connections is provided in the "Technical Information" document for the device on the CD-ROM provided.

Pressure tightness

Liner: hard rubber, polyurethane

Nominal diameter		Liner	Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:		
[mm]	[in]		+25 °C (+77 °F)	+50 °C (+122 °F)	+80 °C (+176 °F)
350...2400	14...90	Hard rubber	0 (0)	0 (0)	0 (0)
50...1200	2...48	Polyurethane	0 (0)	0 (0)	-

Liner: PTFE

Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:	
[mm]	[in]	+25 °C (+77 °F)	+90 °C (+194 °F)
50	2	0 (0)	0 (0)
65	2 ½	0 (0)	40 (0.58)
80	3	0 (0)	40 (0.58)
100	4	0 (0)	135 (2.0)
125	5	135 (2.0)	240 (3.5)
150	6	135 (2.0)	240 (3.5)
200	8	200 (2.9)	290 (4.2)
250	10	330 (4.8)	400 (5.8)
300	12	400 (5.8)	500 (7.3)

Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum flow velocity is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:

- $v < 2$ m/s (6.56 ft/s): for abrasive fluids (e.g. potter's clay, lime milk, ore slurry)
- $v > 2$ m/s (6.56 ft/s): for fluids producing buildup (e.g. wastewater sludges)



For an overview of the measuring range full scale values, see the "Measuring range" section (→ 118)

Pressure loss

- No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.
- Pressure losses for configurations incorporating adapters according to DIN EN 545 (→ 23)

System pressure

(→ 22)

Vibrations

(→ 22)

16.10 Mechanical construction

Design, dimensions



For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Compact version

Weight data:

- Including the transmitter
 - Polycarbonate plastic: 1.3 kg (2.9 lbs)
 - Aluminum: 2.0 kg (4.4 lbs)
- Excluding packaging material

Weight in SI units

Lap joint flange; fixed flange DN ≥ 350 (14")

Nominal diameter		EN (DIN)						ASME, AWWA		AS			
[mm]	[in]	Pressure rating	[kg] ¹⁾										
50	2	PN 6	–	PN 10	–	PN 16	9	Class 150	9	PN 16	–	Table E	–
65	2 ½	PN 6	–	PN 10	–	PN 16	10	Class 150	–	PN 16	–	Table E	–
80	3	PN 6	–	PN 10	–	PN 16	12	Class 150	12	PN 16	–	Table E	–
100	4	PN 6	–	PN 10	–	PN 16	14	Class 150	14	PN 16	–	Table E	–
125	5	PN 6	–	PN 10	–	PN 16	20	Class 150	–	PN 16	–	Table E	–
150	6	PN 6	–	PN 10	–	PN 16	24	Class 150	24	PN 16	–	Table E	–
200	8	PN 6	–	PN 10	43	PN 16	–	Class 150	43	PN 16	–	Table E	–
250	10	PN 6	–	PN 10	63	PN 16	–	Class 150	63	PN 16	–	Table E	–
300	12	PN 6	–	PN 10	68	PN 16	–	Class 150	68	PN 16	–	Table E	–
350	14	PN 6	77	PN 10	88	PN 16	103	Class 150	137	PN 16	99	Table E	99
375	15	PN 6	–	PN 10	–	PN 16	–	Class 150	–	PN 16	105	Table E	–
400	16	PN 6	89	PN 10	104	PN 16	121	Class 150	168	PN 16	120	Table E	120
450	18	PN 6	99	PN 10	112	PN 16	138	Class 150	191	PN 16	133	Table E	143
500	20	PN 6	114	PN 10	132	PN 16	178	Class 150	228	PN 16	182	Table E	182
600	24	PN 6	155	PN 10	162	PN 16	223	Class 150	302	PN 16	260	Table E	260
700	28	PN 6	190	PN 10	240	PN 16	287	Class D	266	PN 16	367	Table E	346
750	30	PN 6	–	PN 10	–	PN 16	–	Class D	318	PN 16	445	Table E	433
800	32	PN 6	240	PN 10	315	PN 16	349	Class D	383	PN 16	503	Table E	493
900	36	PN 6	308	PN 10	393	PN 16	440	Class D	470	PN 16	702	Table E	690
1000	40	PN 6	359	PN 10	468	PN 16	562	Class D	587	PN 16	759	Table E	761
1050	42	PN 6	–	PN 10	–	PN 16	–	Class D	670	PN 16	–	Table E	–
1200	48	PN 6	529	PN 10	717	PN 16	839	Class D	901	PN 16	1219	Table E	1237
–	54	PN 6	–	PN 10	–	PN 16	–	Class D	1273	PN 16	–	Table E	–
1400	–	PN 6	784	PN 10	1114	PN 16	1200	Class D	–	PN 16	–	Table E	–
–	60	PN 6	–	PN 10	–	PN 16	–	Class D	1594	PN 16	–	Table E	–
1600	–	PN 6	1058	PN 10	1624	PN 16	1840	Class D	–	PN 16	–	Table E	–
1650	66	PN 6	–	PN 10	–	PN 16	–	Class D	2131	PN 16	–	Table E	–
1800	72	PN 6	1484	PN 10	2107	PN 16	2353	Class D	2568	PN 16	–	Table E	–
2000	78	PN 6	1877	PN 10	2630	PN 16	2925	Class D	3113	PN 16	–	Table E	–
–	84	PN 6	–	PN 10	–	PN 16	–	Class D	3755	PN 16	–	Table E	–
2200	–	PN 6	2512	PN 10	3422	PN 16	–	Class D	–	PN 16	–	Table E	–

Nominal diameter		EN (DIN)						ASME, AWWA		AS			
[mm]	[in]	Pressure rating	[kg] ¹⁾										
-	90	PN 6	-	PN 10	-	PN 16	-	Class D	4797	PN 16	-	Table E	-
2 400	-	PN 6	2996	PN 10	4094	PN 16	-	Class D	-	PN 16	-	Table E	-

1) Values with polycarbonate plastic transmitter; values for aluminum transmitter: + 0.7 kg

Lap joint flange, stamped plate

Nominal diameter		EN (DIN)	
[mm]	[in]	Pressure rating	[kg] ¹⁾
50	2	PN 10	5
65	2 ½	PN 10	6
80	3	PN 10	7
100	4	PN 10	9
125	5	PN 10	13
150	6	PN 10	17
200	8	PN 10	35
250	10	PN 10	54
300	12	PN 10	55

1) Values with polycarbonate plastic transmitter; values for aluminum transmitter: + 0.7 kg

Weight in US units

Lap joint flange; fixed flange DN ≥ 350 (14")

Nominal diameter		ASME, AWWA	
[mm]	[in]	Pressure rating	[lbs] ¹⁾
50	2	Class 150	20
65	2 ½	Class 150	-
80	3	Class 150	26
100	4	Class 150	31
125	5	Class 150	-
150	6	Class 150	53
200	8	Class 150	95
250	10	Class 150	139
300	12	Class 150	150
350	14	Class 150	302
375	15	Class 150	-
400	16	Class 150	370
450	18	Class 150	421
500	20	Class 150	503
600	24	Class 150	666
700	28	Class D	586
750	30	Class D	701

Nominal diameter		ASME, AWWA	
[mm]	[in]	Pressure rating	[lbs] ¹⁾
800	32	Class D	844
900	36	Class D	1036
1000	40	Class D	1294
-	42	Class D	1477
1200	48	Class D	1987
-	54	Class D	2807
-	60	Class D	3515
1650	66	Class D	4699
1800	72	Class D	5662
2000	78	Class D	6864
-	84	Class D	8280
-	90	Class D	10577

1) Values with polycarbonate plastic transmitter; values for aluminum transmitter: + 1.45 lbs

Transmitter remote version

Wall-mount housing

Depends on the material of the wall-mount housing:

- Polycarbonate plastic: 1.3 kg (2.9 lb)
- Aluminum: 2.0 kg (4.4 lb)

Sensor remote version

Weight data:

- Including sensor connection housing
- Excluding the connecting cable
- Excluding packaging material

Weight in SI units

Lap joint flange; fixed flange DN ≥ 350 (14")

Nominal diameter		EN (DIN)				ASME, AWWA		AS					
[mm]	[in]	Pressure rating	[kg]										
50	2	PN 6	-	PN 10	-	PN 16	6	Class 150	6	PN 16	-	Table E	-
65	2 ½	PN 6	-	PN 10	-	PN 16	7	Class 150	-	PN 16	-	Table E	-
80	3	PN 6	-	PN 10	-	PN 16	9	Class 150	9	PN 16	-	Table E	-
100	4	PN 6	-	PN 10	-	PN 16	11	Class 150	11	PN 16	-	Table E	-
125	5	PN 6	-	PN 10	-	PN 16	16	Class 150	-	PN 16	-	Table E	-
150	6	PN 6	-	PN 10	-	PN 16	20	Class 150	20	PN 16	-	Table E	-
200	8	PN 6	-	PN 10	40	PN 16	-	Class 150	40	PN 16	-	Table E	-
250	10	PN 6	-	PN 10	60	PN 16	-	Class 150	60	PN 16	-	Table E	-
300	12	PN 6	-	PN 10	65	PN 16	-	Class 150	65	PN 16	-	Table E	-
350	14	PN 6	73	PN 10	84	PN 16	101	Class 150	133	PN 16	95	Table E	95
375	15	PN 6	-	PN 10	-	PN 16	-	Class 150	-	PN 16	101	Table E	-

Nominal diameter		EN (DIN)						ASME, AWWA		AS			
[mm]	[in]	Pressure rating	[kg]										
400	16	PN 6	85	PN 10	100	PN 16	119	Class 150	164	PN 16	116	Table E	116
450	18	PN 6	95	PN 10	108	PN 16	136	Class 150	187	PN 16	129	Table E	139
500	20	PN 6	110	PN 10	128	PN 16	176	Class 150	224	PN 16	178	Table E	178
600	24	PN 6	158	PN 10	158	PN 16	221	Class 150	298	PN 16	256	Table E	256
700	28	PN 6	187	PN 10	237	PN 16	285	Class D	263	PN 16	364	Table E	343
750	30	PN 6	-	PN 10	-	PN 16	-	Class D	315	PN 16	442	Table E	430
800	32	PN 6	237	PN 10	312	PN 16	347	Class D	380	PN 16	500	Table E	490
900	36	PN 6	305	PN 10	390	PN 16	438	Class D	467	PN 16	699	Table E	687
1000	40	PN 6	356	PN 10	465	PN 16	560	Class D	584	PN 16	756	Table E	758
1050	42	PN 6	-	PN 10	-	PN 16	-	Class D	667	PN 16	-	Table E	-
1200	48	PN 6	526	PN 10	714	PN 16	837	Class D	898	PN 16	1216	Table E	1234
-	54	PN 6	-	PN 10	-	PN 16	-	Class D	1270	PN 16	-	Table E	-
1400	-	PN 6	781	PN 10	1111	PN 16	1197	Class D	-	PN 16	-	Table E	-
-	60	PN 6	-	PN 10	-	PN 16	-	Class D	1591	PN 16	-	Table E	-
1600	-	PN 6	1055	PN 10	1621	PN 16	1838	Class D	-	PN 16	-	Table E	-
1650	66	PN 6	-	PN 10	-	PN 16	-	Class D	2128	PN 16	-	Table E	-
1800	72	PN 6	1415	PN 10	2104	PN 16	2350	Class D	2565	PN 16	-	Table E	-
2000	78	PN 6	1874	PN 10	2627	PN 16	2922	Class D	3110	PN 16	-	Table E	-
-	84	PN 6	-	PN 10	-	PN 16	-	Class D	3752	PN 16	-	Table E	-
2200	-	PN 6	2509	PN 10	3419	PN 16	-	Class D	-	PN 16	-	Table E	-
-	90	PN 6	-	PN 10	-	PN 16	-	Class D	4794	PN 16	-	Table E	-
2400	-	PN 6	2993	PN 10	4091	PN 16	-	Class D	-	PN 16	-	Table E	-

Lap joint flange, stamped plate

Nominal diameter		EN (DIN)	
[mm]	[in]	Pressure rating	[kg]
50	2	PN 10	3
65	2 ½	PN 10	4
80	3	PN 10	5
100	4	PN 10	7
125	5	PN 10	11
150	6	PN 10	15
200	8	PN 10	33
250	10	PN 10	52
300	12	PN 10	53

Weight in US units

Lap joint flange; fixed flange DN ≥ 350 (14")

Nominal diameter		ASME, AWWA	
[mm]	[in]	Pressure rating	[lbs]
50	2	Class 150	13
65	2 ½	Class 150	-
80	3	Class 150	20
100	4	Class 150	24
125	5	Class 150	-
150	6	Class 150	44
200	8	Class 150	88
250	10	Class 150	132
300	12	Class 150	143
350	14	Class 150	293
375	15	Class 150	-
400	16	Class 150	361
450	18	Class 150	412
500	20	Class 150	494
600	24	Class 150	657
700	28	Class D	580
750	30	Class D	695
800	32	Class D	838
900	36	Class D	1030
1000	40	Class D	1288
-	42	Class D	1471
1200	48	Class D	1980
-	54	Class D	2800
-	60	Class D	3508
1650	66	Class D	4692
1800	72	Class D	5656
2000	78	Class D	6858
-	84	Class D	8273
-	90	Class D	10571

Measuring tube specification

Nominal diameter		Pressure rating			Measuring tube internal diameter					
[mm]	[in]	EN (DIN)	ASME AWWA	AS 2129 AS 4087	Hard rubber		Polyurethane		PTFE	
					[mm]	[in]	[mm]	[in]	[mm]	[in]
50	2	PN 10/16	Class 150	-	-	-	50.3	2.0	51.7	2.0
65 ¹⁾	2 ½	PN 10/16	Class 150	-	-	-	66.1	2.6	67.7	2.7
80	3	PN 10/16	Class 150	-	-	-	78.9	3.1	79.9	3.1
100	4	PN 10/16	Class 150	-	-	-	104.3	4.1	103.8	4.1
125	5	PN 10/16	Class 150	-	-	-	129.7	5.1	129.1	5.1

Nominal diameter		Pressure rating			Measuring tube internal diameter					
		EN (DIN)	ASME AWWA	AS 2129 AS 4087	Hard rubber		Polyurethane		PTFE	
[mm]	[in]				[mm]	[in]	[mm]	[in]	[mm]	[in]
150	6	PN 10/16	Class 150	-	-	-	158.3	6.2	156.3	6.2
200	8	PN 10/16	Class 150	-	-	-	206.7	8.1	202.1	8.0
250	10	PN 10/16	Class 150	-	-	-	260.6	10.3	256.2	10.1
300	12	PN 10/16	-	-	-	-	311.5	12.3	305.5	12.0
300	12	-	Class 150	-	-	-	309.9	12.2	303.9	12.0
350	14	PN 6	-	-	341	13.4	344	13.5	-	-
350	14	PN 10	-	-	341	13.4	344	13.5	-	-
350	14	-	-	Table E, PN 16	339	13.3	342	13.4	-	-
350	14	-	Class 150	-	339	13.3	342	13.4	-	-
375	15	PN 10	-	-	391	15.4	-	-	-	-
375	15	-	-	PN 16	389	15.3	392	15.4	-	-
400	16	PN 6	-	-	391	15.4	394	13.5	-	-
400	16	PN 10	-	-	442	17.4	394	13.5	-	-
400	16	-	-	Table E, PN 16	389	15.3	392	13.4	-	-
400	16	-	Class 150	-	389	15.3	392	13.4	-	-
450	18	PN 6	-	-	442	17.4	445	17.5	-	-
450	18	PN 10	-	-	493	19.4	445	17.5	-	-
450	18	-	-	Table E, PN 16	440	17.3	443	17.4	-	-
450	18	-	Class 150	-	438	17.2	441	17.3	-	-
500	20	PN 6	-	-	493	19.4	496	19.5	-	-
500	20	PN 10	-	-	595	23.4	496	19.5	-	-
500	20	-	-	Table E, PN 16	489	19.2	492	19.3	-	-
500	20	-	Class 150	-	489	19.2	492	19.3	-	-
600	24	PN 6	-	-	595	23.4	598	23.5	-	-
600	24	PN 10	-	-	590	23.2	598	23.5	-	-
600	24	-	-	Table E, PN 16	591	23.2	594	23.4	-	-
600	24	-	Class 150	-	589	23.1	592	23.3	-	-
700	28	PN 6	-	-	696	27.4	699	27.5	-	-
700	28	PN 10	-	-	694	27.3	697	27.4	-	-
700	28	-	-	Table E, PN 16	690	27.2	693	27.3	-	-
700	28	-	Class D	-	694	27.3	697	27.4	-	-
750	30	PN 6	-	-	-	-	699	27.5	-	-
750	30	PN 10	-	-	-	-	697	27.4	-	-
750	30	-	-	Table E, PN 16	741	29.2	744	29.3	-	-
750	30	-	Class D	-	743	29.3	746	29.4	-	-
800	32	PN 6	-	-	798	31.4	801	31.5	-	-
800	32	PN 10	-	-	796	31.3	799	31.5	-	-
800	32	-	-	Table E, PN 16	792	31.2	795	31.3	-	-
800	32	-	Class D	-	794	31.3	797	31.4	-	-
900	36	PN 6	-	-	897	35.3	900	35.4	-	-

Nominal diameter		Pressure rating			Measuring tube internal diameter					
		EN (DIN)	ASME AWWA	AS 2129 AS 4087	Hard rubber		Polyurethane		PTFE	
[mm]	[in]				[mm]	[in]	[mm]	[in]	[mm]	[in]
900	36	PN 10	-	-	895	35.2	898	35.4	-	-
900	36	-	-	Table E, PN 16	889	35.0	892	35.1	-	-
900	36	-	Class D	-	895	35.2	898	35.4	-	-
1000	40	PN 6	-	-	999	39.3	1002	39.4	-	-
1000	40	PN 10	-	-	997	39.3	1000	39.4	-	-
1000	40	-	-	Table E, PN 16	991	39.0	994	39.1	-	-
1000	40	-	Class D	-	995	39.1	998	39.3	-	-
1050	42	PN 6	-	-	-	-	-	-	-	-
1050	42	PN 10	-	-	-	-	-	-	-	-
1050	42	-	-	Table E, PN 16	-	-	-	-	-	-
1050	42	-	Class D	-	1046	41.2	1049	41.3	-	-
1200	48	PN 6	-	-	1203	47.4	1206	47.5	-	-
1200	48	PN 10	-	-	1199	47.2	1202	47.3	-	-
1200	48	-	-	Table E, PN 16	1191	46.9	1194	47.0	-	-
1200	48	-	Class D	-	1195	47.0	1198	47.2	-	-
-	54	-	Class D	-	1345	53.8	-	-	-	-
1400	-	PN 6	-	-	1402	56.1	-	-	-	-
1400	-	PN 10	-	-	1394	55.78	-	-	-	-
-	60	-	Class D	-	1498	59.9	-	-	-	-
1600	-	PN 6	-	-	1600	64.0	-	-	-	-
1600	-	PN 10	-	-	1590	63.6	-	-	-	-
-	66	-	Class D	-	1646	65.8	1198	47.2	-	-
1800	72	PN 6	-	-	1800	72.0	1206	47.5	-	-
1800	72	PN 10	-	-	1790	71.6	1202	47.3	-	-
1800	72	-	Class D	-	1790	71.6	1198	47.2	-	-
2000	78	PN 6	-	-	1998	79.9	-	-	-	-
2000	78	PN 10	-	-	1990	79.6	-	-	-	-
2000	78	-	Class D	-	1986	79.4	-	-	-	-
-	84	-	Class D	-	2099	84.0	-	-	-	-
2200	-	PN 6	-	-	2194	87.8	-	-	-	-
2200	-	PN 10	-	-	2186	87.4	-	-	-	-
-	90	-	Class D	-	2246	89.8	-	-	-	-
2400	-	PN 6	-	-	2394	95.8	-	-	-	-
2400	-	PN 10	-	-	2386	95.4	-	-	-	-

1) Designed acc. to EN 1092-1 (not to DIN 2501)

Materials

Transmitter housing


Order code for "Housing"

- Compact version, standard:
 - Option **A**: coated aluminum AlSi10Mg
 - Option **M**: polycarbonate plastic
- Compact version, inclined:
 - Option **Q**: polycarbonate plastic
 - Option **R**: coated aluminum AlSi10Mg
- Remote version (wall-mount housing):
 - Option **N**: polycarbonate plastic
 - Option **P**: coated aluminum AlSi10Mg

Window material

Transmitter housing material	Window material
Polycarbonate plastic	Plastic
Aluminum AlSi10Mg	Glass

Cable entries/cable glands



34 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G 1/2" or NPT 1/2"

Compact and remote versions and sensor connection housing

Cable entry/cable gland	Material
Cable gland M20 x 1.5	Plastic
Remote version: cable gland M20 x 1.5 <ul style="list-style-type: none"> ■ Option CK "IP68, Type 6P, waterproof" ■ Option of reinforced connecting cable 	<ul style="list-style-type: none"> ■ Sensor connection housing: Nickel-plated brass ■ Transmitter wall-mount housing: Plastic
Adapter for cable entry with internal thread G 1/2" or NPT 1/2"	Nickel-plated brass

Device plug

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none"> ■ Socket: Stainless steel 1.4404 (316L) ■ Contact housing: Polyamide ■ Contacts: Gold-plated brass

Connecting cable for remote version

Electrode and coil current cable

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor housing

- DN 50 to 300 (2 to 12"): aluminum coated AlSi10Mg
- DN 350 to 2400 (14 to 90"): carbon steel with protective varnish

Sensor connection housing

Aluminum coated AlSi10Mg

Sensor cable entries

Order code for "Housing", option N "Remote, polycarbonate" or option P "Remote, coated aluminum"

The various cable entries are suitable for hazardous and non-hazardous areas.

Electrical connection	Material
Cable gland M20 × 1.5	Nickel-plated brass
Thread G ½" via adapter	Nickel-plated brass
Thread NPT ½" via adapter	Nickel-plated brass

Measuring tubes

- DN 50 to 300 (2 to 12"): stainless steel 1.4301 (304), 1.4306 (304L)
- DN 350 to 2400 (14 to 90"): stainless steel 1.4301 (304), 1.4307

Liner

- DN 50 to 300 (2 to 12"): PTFE
- DN 50 to 1200 (2 to 48"): polyurethane
- DN 350 to 2400 (14 to 90"): hard rubber

Electrodes

1.4435 (304L), Alloy C22

Process connections

EN 1092-1 (DIN 2501)

- DN ≤ 300 (12"): 1.0038 (S235JRG2), 1.4301 (304), 1.4306 (304L), 1.4307 (304L)
- DN ≥ 350 (14"): 1.0038 (S235JRG2), A105

ASME B16.5

- DN ≤ 300 (12"): A105, 316L
- DN ≥ 350 (14"): A105

AWWA C207

DN 1200 to 2200 (48 to 90"): 1.0044 (S275JR), 1.0425 (316L) (P265GH), A105, A181

AS 2129

DN 350 to 1200 (14 to 48"): 1.0038 (S235JRG2), 1.0345 (P235GH), 1.0425 (316L) (P265GH), A105, FE 410 WB

AS 4087

DN 350 to 1200 (14 to 48"): 1.0044 (S275JR), 1.0425 (316L) (P265GH), A105

Seals

In accordance with DIN EN 1514-1

Accessories*Display protection*

Stainless steel 1.4301

Ground disks

1.4435 (316L), Alloy C22

Fitted electrodes

Measurement, reference and empty pipe detection electrodes available as standard with:

- 1.4435 (304L)
- Alloy C22

Process connections

Flange connections:

- EN 1092-1 (DIN 2501)
 - DN ≤ 300 (12"): lap joint flange (PN 10/16), lap joint flange, stamped plate (PN 10) = form A
 - DN ≥ 350 (14"): fixed flange (PN 6/10) = flat face
- ASME B16.5
 - DN ≤ 300 (12"): lap joint flange (Class 150)
 - DN ≥ 350 (14"): fixed flange (Class 150)
- AWWA C207
 - DN 1200 to 2200 (48 to 90"): fixed flange (Class D)
- AS 2129
 - DN 350 to 1200 (14 to 48"): fixed flange (Table E)
- AS 4087
 - DN 350 to 1200 (14 to 48"): fixed flange (PN 16)



For information on the materials of the process connections (→ 136)

Surface roughness

Electrodes with 1.4435 (304L), Alloy C22:
 ≤ 0.3 to 0.5 μm (11.8 to 19.7 in)
 (All data relate to parts in contact with fluid)

16.11 Operability

Local operation

Display elements

- 4-line display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +50 °C (-4 to +122 °F)
The readability of the display may be impaired at temperatures outside the temperature range.

Operating elements

External operation via touch control; 3 optical keys: , , 

Additional functionality

- Data backup function
The device configuration can be saved in the display module.
- Data comparison function
The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
The transmitter configuration can be transmitted to another device using the display module.

Remote operation

Ethernet network

Operation of the measuring device with the ethernet network via:

- Web browser
- "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- Add-on Profile Level 3 for "RSLogix" automation system with "RSLogix 5000" software from Rockwell Automation

Languages

Can be operated in the following languages:

- Via local display:
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech
- Via "FieldCare" operating tool:
English, German, French, Spanish, Italian, Dutch, Chinese, Japanese
- Via Web browser
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech

16.12 Certificates and approvals

CE mark

The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Control Drawing" document. Reference is made to this document on the nameplate.
Drinking water approval	<ul style="list-style-type: none"> ■ ACS ■ KTW/W270 ■ NSF 61 ■ WRAS BS 6920
EtherNet/IP certification	<p>The measuring device is certified and registered by the ODVA (Open Device Vendor Association). The measuring system meets all the requirements of the following specifications:</p> <ul style="list-style-type: none"> ■ Certified in accordance with the ODVA Conformance Test ■ EtherNet/IP Performance Test ■ EtherNet/IP PlugFest compliance ■ The device can also be operated with certified devices of other manufacturers (interoperability)
Other standards and guidelines	<ul style="list-style-type: none"> ■ EN 60529 Degrees of protection by housing (IP code) ■ EN 61010-1 Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures. ■ IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements) ■ ANSI/ISA-61010-1 (82.02.01): 2004 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements ■ CAN/CSA-C22.2 No. 61010-1-04 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements ■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment. ■ NAMUR NE 32 Data Retention in the Event of a Power Failure in Field and Control Instruments with Microprocessors ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics ■ NAMUR NE 105 Specifications for Integrating Fieldbus Devices in Engineering Tools for Field Devices ■ NAMUR NE 107 Self-monitoring and diagnosis of field devices ■ NAMUR NE 131 Requirements for field devices for standard applications

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered from Endress+Hauser either directly with the device or subsequently. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Cleaning	Package	Description
	Electrode cleaning circuit (ECC)	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe ₃ O ₄) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The option is designed to AVOID build up of highly conductive matter and thin layers (typically magnetite).

Diagnostics functions	Package	Description
	HistoROM extended function	Comprises extended functions concerning the event log and the activation of the measured value memory. Event log: Memory volume is extended from 20 message entries (basic version) to up to 100 entries. Data logging (line recorder): <ul style="list-style-type: none"> ▪ Memory capacity for up to 1000 measured values is activated. ▪ 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. ▪ Data logging is visualized via the local display or FieldCare.

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	<p>Heartbeat Monitoring: Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to:</p> <ul style="list-style-type: none"> ▪ Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time. ▪ Schedule servicing in time. ▪ Monitor the product quality, e.g. gas pockets. <p>Heartbeat Verification: Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process.</p> <ul style="list-style-type: none"> ▪ Access via onsite operation or other interfaces (requires no on-site presence). ▪ End-to-end, traceable documentation of the verification results and verification report. ▪ Extension of calibration intervals.

16.14 Accessories

 Overview of accessories available for order (→  116)

16.15 Documentation

 The following document types are available:

- On the CD-ROM supplied with the device
- In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download

Standard documentation	Communication	Document type	Documentation code
	----	Brief Operating Instructions	KA01113D
	----	Technical Information	TI01045D

Supplementary device-dependent documentation	Document type	Approval	Documentation code
	Special Documentation	Heartbeat Technology	SD01183D
	Installation Instructions		Specified for each individual accessory (→  116)  Overview of accessories available for order (→  116)

17 Appendix

17.1 Overview of the operating menu

The following table provides an overview of the entire operating menu structure with menus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.

* = The submenu only appears if it has been additionally ordered ("Technical Information", Section "Application packages").

Display language		(→ 70)
Operation	→	(→ 73)
Display language		(→ 70)
Websserver language		(→ 62)
Access status display		(→ 61)
Access status tooling		(→ 61)
Locking status		(→ 86)
Display	→	(→ 73)
Format display		
Contrast display		
Backlight		
Display interval		
Operation	→	(→ 90)
Control totalizer 1 to 3		
Preset value 1 to 3		
Reset all totalizers		
Setup	→	(→ 71)
Device tag		(→ 71)
System units	→	(→ 72)
Volume flow unit		
Volume unit		
Conductivity unit		
Temperature unit		
Mass flow unit		
Mass unit		

Density unit		
Communication	→	(→ 75)
MAC address		
Default network settings		
DHCP client		
IP address		
Subnet mask		
Default gateway		
Display	→	(→ 73)
Format display		
Value 1 display		
0% bargraph value 1		
100% bargraph value 1		
Value 2 display		
Value 3 display		
0% bargraph value 3		
100% bargraph value 3		
Value 4 display		
Low flow cut off	→	(→ 76)
Assign process variable		
On value low flow cut off		
Off value low flow cutoff		
Pressure shock suppression		
Empty pipe detection	→	(→ 77)
Empty pipe detection		
New adjustment		
Progress		
Switch point empty pipe detection		
Response time		
Advanced setup	→	(→ 79)
Enter access code		(→ 61)

Sensor adjustment	→	(→ 79)
Installation direction		
Totalizer1 to 3	→	(→ 80)
Assign process variable		
Unit totalizer		
Totalizer operation mode		
Failure mode		
Display	→	(→ 81)
Format display		
Value 1 display		
0% bargraph value 1		
100% bargraph value 1		
Decimal places 1		
Value 2 display		
Decimal places 2		
Value 3 display		
0% bargraph value 3		
100% bargraph value 3		
Decimal places 3		
Value 4 display		
Decimal places 4		
Display language		
Display interval		
Display damping		
Header		
Header text		
Separator		
Backlight		
Electrode cleaning circuit* (not Promag D 400)	→	(→ 83)
Electrode cleaning circuit		

	ECC duration	
	ECC recovery time	
	ECC cleaning cycle	
	ECC polarity	
	Administration	→ (→ ⓘ 85)
	Define access code	
	Confirm access code	
	Device reset	
Diagnostics		→ (→ ⓘ 93)
Actual diagnostics		(→ ⓘ 108)
Previous diagnostics		(→ ⓘ 108)
Operating time from restart		-
Operating time		(→ ⓘ 108)
	Diagnostic list	→ (→ ⓘ 108)
	Diagnostics 1 to 5	
	Event logbook	→ (→ ⓘ 108)
	Filter options	(→ ⓘ 109)
	Device information	→ (→ ⓘ 110)
	Device tag	
	Serial number	
	Firmware version	
	Device name	
	Order code	
	Extended order code1 to 3	
	ENP version	
	Device revision	
	Device ID	
	Device type	
	Manufacturer ID	
	IP address	
	Subnet mask	

Default gateway		
Measured values	→	(→ 88)
	Process variables	→ (→ 88)
	Volume flow	
	Mass flow	
	Conductivity	
	Totalizer	→ (→ 89)
	Totalizer value1 to 3	
	Totalizer overflow1 to 3	
Data logging	→	(→ 90)
Assign channel 1-4		
Logging interval		
Clear logging data		
Simulation	→	(→ 84)
Assign simulation process variable		
Value process variable		
Simulation device alarm		
Heartbeat*	→	(→ SD01183D)
	Performing verification	→
	Year	
	Month	
	Day	
	Hour	
	AM/PM	
	Minute	
	Verification mode	
	Information external device	
	External reference voltage 1 to 2	
	Start verification	
	Progress	

	Status	
	Overall result	
	Verification result	→
	Date/time	
	Verification ID	
	Operating time	
	Overall result	
	Sensor	
	Sensor electronics module	
	I/O module	
	Monitoring result	→
	Noise	
	Coil current shot time	
	Reference electrode potential against PE	
Expert		→ (→ ⓘ 49)
Direct access (0106)		→ (→ ⓘ 58)
Locking status (0122)		→ (→ ⓘ 61)
Access status display (0091)		→ (→ ⓘ 61)
Access status tooling (0005)		→ (→ ⓘ 61)
Enter access code (0003)		
	System	→
	Display	→ (→ ⓘ 81)
	Display language (0104)	→ (→ ⓘ 70)
	Format display (0098)	
	Value 1 display (0107)	
	0% bargraph value 1 (0123)	
	100% bargraph value 1 (0125)	
	Decimal places 1 (0095)	
	Value 2 display (0108)	

Decimal places 2 (0117)	
Value 3 display (0110)	
0% bargraph value 3 (0124)	
100% bargraph value 3 (0126)	
Decimal places 3 (0118)	
Value 4 display (0109)	
Decimal places 4 (0119)	
Display interval (0096)	
Display damping (0094)	
Header (0097)	
Header text (0112)	
Separator (0101)	
Contrast display (0105)	(→  55)
Backlight (0111)	
Access status display (0091)	(→  61)
Diagnostic behavior →	(→  93)
Alarm delay (0651)	(→  97)
Assign behavior of diagnostic no. 252 (0661)	(→  104)
Assign behavior of diagnostic no. 531 (0741)	(→  104)
Assign behavior of diagnostic no. 832 (0681)	(→  104)
Assign behavior of diagnostic no. 833 (0682)	(→  104)
Assign behavior of diagnostic no. 834 (0700)	(→  104)
Assign behavior of diagnostic no. 835 (0702)	(→  104)
Assign behavior of diagnostic no. 862 (0745)	(→  104)

		User volume offset (0569)	
		User volume factor (0568)	
		User mass text (0560)	
		User mass offset (0562)	
		User mass factor (0561)	
	Process param. →		(→ 📖 71)
	Filter options (6710)		
	Flow damping (6661)		
	Flow override (1839)		
	Conductivity damping (1803)		
	Conductivity measurement (6514)		
		Low flow cut off →	(→ 📖 76)
		Assign process variable (1837)	
		On value low flow cutoff (1805)	
		Off value low flow cutoff (1804)	
		Pressure shock suppression (1806)	
		Empty pipe detection →	(→ 📖 77)
		Empty pipe detection (1860)	
		Switch point (6562)	
		Response time (1859)	
		Empty pipe adj. value (6527)	
		Full pipe value (6548)	
		Current measured value (6559)	
		New adjustment (6560)	
		Progress (6571)	
		Electrode cleaning circuit* →	(→ 📖 83)
		(not Promag D 400)	

	Electrode cleaning circuit (6528)	
	ECC duration (6555)	
	ECC recovery time (6556)	
	ECC cleaning cycle (6557)	
	ECC polarity (6631)	
External compensation →		
Density source (6615)		
External density (6630)		
Fixed density (6623)		
Sensor adjustment →		(→ ⓘ 79)
Installation direction (1809)		
Integration time (6533)		
Measuring period (6536)		
	Variable adjust →	(→ ⓘ 79)
	Volume flow offset (1831)	
	Volume flow factor (1832)	
	Mass flow offset (1841)	
	Mass flow factor (1846)	
	Conductivity offset (1848)	
	Conductivity factor (1849)	
Calibration →		
Nominal diameter (2807)		
Calibration factor (6522)		
Zero point (6546)		
Conductivity calibration factor (6718)		
Properties →		
Cable length (6683)		

Communication	→		
		Configuration	→ (→ 📄 75)
		Webserver language (7221)	
		MAC address (7214)	
		Default network settings (7401)	
		DHCP client (7212)	
		IP address (7209)	
		Subnet mask (7211)	
		Default gateway (7210)	
		Web server functionality (7222)	
		Input assembly	→
		Input assembly position1 to 20	
Application	→		
		Reset all totalizers (2806)	(→ 📄 90)
		Totalizer1 to 3	→ (→ 📄 80)
		Assign process variable (0914)	
		Unit (0915)	
		Totalizer operation mode (0908)	
		Control totalizer 1 (0912)	
		Preset value 1 (0913)	
		Failure mode (0901)	
Diagnostics	→		(→ 📄 93)
		Actual diagnostics (0691)	(→ 📄 108)
		Time stamp (0667)	
		Previous diagnostics (0690)	
		Time stamp (0672)	
		Operating time from restart (0653)	

Operating time (0652)		
Diagnostic list	→	
Diagnostics 1 to 5 (692 to 696)		
Event logbook	→	(→ 📄 108)
Filter options (0705)		(→ 📄 109)
Device information	→	(→ 📄 110)
Device tag (0011)		
Serial number (0009)		
Firmware version (0010)		
Device name (0013)		
Order code (0008)		
Extended order code 1 to 3 (0023, 0021, 0022)		
Configuration counter (2751)		
ENP version (0012)		
IP address (7209)		
Subnet mask (7211)		
Default gateway (7210)		
Data logging	→	(→ 📄 90)
Assign channel 1-4 (851 to 854)		
Logging interval (0856)		
Clear logging data (0855)		
Min/max values	→	
Reset min/max values (6541)		
		Main electronic temperature →
		Minimum value (6547)
		Maximum value (6545)
Heartbeat*	→	(→ SD01183D)
		Base settings →

Customer (2754)	
Location (2755)	
Performing verification	→
Year (2846)	
Month (2845)	
Day (2842)	
Hour (2843)	
AM/PM (2813)	
Minute (2844)	
Verification mode (12105)	
Information external device (12101)	
External reference voltage 1 to 2 (12106, 12107)	
Start verification (12127)	
Progress (2808)	
Status (12153)	
Overall result (12149)	
Verification result	→
Date/time (12142)	
Verification ID (12141)	
Operating time (12126)	
Overall result (12149)	
Sensor (12152)	
Sensor electronics module (12151)	
I/O module (12145)	
Monitoring result	→
Noise (12158)	
Coil current shot time (12150)	
Reference electrode potential against PE (12155)	

	Simulation →	(→ 📄 84)
	Assign simulation process variable (1810)	
	Value process variable (1811)	
	Simulation device alarm (0654)	

Index

A

Access authorization to parameters	
Read access	61
Write access	61
Access code	61
Incorrect input	61
Adapters	23
Adapting the diagnostic behavior	103
Ambient temperature range	22
Application	9, 118
Applicator	118
Approvals	138

C

C-Tick symbol	138
Cable entries	
Technical data	124
Cable entry	
Degree of protection	45
CE mark	10, 138
Certificates	138
Check	
Installation	32
Post-connection	45
Checklist	
Post-connection check	45
Post-installation check	32
Cleaning	
Exterior cleaning	113
Interior cleaning	113
Commissioning	70
Advanced settings	79
Configuring the measuring device	71
Conductivity	126
Connecting cable	33
Connecting the measuring device	38
Connection	
see Electrical connection	
Connection examples, potential equalization	41
Connection preparations	36
Connection tools	33
Context menu	
Closing	56
Explanation	56
Opening	56
Current consumption	124

D

Declaration of Conformity	10
Define access code	85, 85
Degree of protection	45, 126
Design	
Measuring device	12
Designated use	9
Device components	12
Device description files	68, 68

Device documentation	
Supplementary documentation	8
Device locking, status	87
Device name	
Sensor	15
Transmitter	14
Device repair	114
Device revision	68
Device type ID	68
Diagnostic behavior	
Explanation	97
Symbols	97
Diagnostic information	
Communication interface	102
Design, description	97, 100, 102
FieldCare	100, 101
Light emitting diodes	94
Local display	96
Overview	104
Remedial measures	104
Web browser	99
Diagnostic list	108
Diagnostic message	96
Diagnostics	
Symbols	96
DIP switch	
see Write protection switch	
Direct access	58
Direct access code	52
Disabling write protection	85
Display	
Current diagnostic event	107
Previous diagnostic event	107
see Local display	
Display area	
For operational display	51
In the navigation view	53
Display values	
For locking status	87
Disposal	114
Document	
Function	6
Symbols used	6
Document function	6
Documentation	140
Down pipe	19
Drinking water approval	139

E

ECC	83
Electrical connection	
Degree of protection	45
Measuring device	33
Operating tools	
Via service interface (CDI-RJ45)	66
Web server	66

- Electromagnetic compatibility 126
 - Enabling write protection 85
 - Endress+Hauser services
 - Maintenance 113
 - Repair 114
 - Environment
 - Ambient temperature range 22
 - Mechanical load 126
 - Shock resistance 126
 - Storage temperature 126
 - Vibration resistance 126
 - Error messages
 - see Diagnostic messages
 - Ethernet network 138
 - EtherNet/IP
 - Diagnostic information 102
 - EtherNet/IP certification 139
 - Event history 108
 - Events list 108
 - Ex approval 139
 - Extended order code
 - Sensor 15
 - Transmitter 14
 - Exterior cleaning 113
- F**
- Field of application
 - Residual risks 10
 - FieldCare 66
 - Device description file 68
 - Establishing a connection 66
 - Function 66
 - User interface 67
 - Filtering the event logbook 109
 - Firmware
 - Release date 68
 - Version 68
 - Firmware history 111
 - Fitted electrodes 137
 - Fix assembly 102
 - Flow direction 20
 - Flow limit 127
 - Function check 70
 - Functions
 - see Parameter
- G**
- Galvanic isolation 121
- H**
- Hardware write protection 86
 - HART input
 - Connection 43
 - Heavy sensors 20
 - Help text
 - Calling up 59
 - Close 59
 - Explanation 59
- I**
- I/O electronics module 12, 38
 - Identifying the measuring device 14
 - Incoming acceptance 13
 - Information on the document 6
 - Inlet runs 21
 - Input 118
 - Input mask 54
 - Inspection check
 - Received goods 13
 - Installation 19
 - Installation conditions
 - Adapters 23
 - Down pipe 19
 - Heavy sensors 20
 - Inlet and outlet runs 21
 - Mounting location 19
 - Orientation 20
 - Partially filled pipe 20
 - System pressure 22
 - Vibrations 22
 - Installation dimensions 21
 - Interior cleaning 113
- K**
- Keypad lock
 - Disabling 61
 - Enabling 61
- L**
- Languages, operation options 138
 - Line recorder 90
 - Local display 138
 - Editing view 54
 - Navigation view 52
 - see Diagnostic message
 - see In alarm condition
 - see Operational display
 - Low flow cut off 121
- M**
- Main electronics module 12
 - Maintenance tasks 113
 - Replacing seals 113
 - Manufacturer ID 68
 - Manufacturing date 14, 15
 - Materials 135
 - Maximum measured error 125
 - Measured variables
 - Calculated 118
 - Measured 118
 - see Process variables
 - Measuring and test equipment 113
 - Measuring device
 - Configuration 71
 - Conversion 114
 - Design 12
 - Disposal 115
 - Integrating via HART protocol 68

- Mounting the sensor 24
 - Mounting the ground cable/ground disks 25
 - Mounting the seals 25
 - Screw tightening torques 25
 - Preparing for electrical connection 36
 - Preparing for mounting 24
 - Removing 114
 - Repair 114
 - Switching on 70
 - Measuring principle 118
 - Measuring range 118
 - Measuring system 118
 - Measuring tube specification 132
 - Mechanical load 126
 - Media 9
 - Medium temperature range 126
 - menu
 - Diagnostics 107
 - Setup 71
 - Menus
 - For measuring device configuration 71
 - For specific settings 79
 - Mounting dimensions
 - see Installation dimensions
 - Mounting location 19
 - Mounting preparations 24
 - Mounting requirements
 - Installation dimensions 21
 - Mounting tools 24
- N**
- Nameplate
 - Sensor 15
 - Transmitter 14
 - Navigation path (navigation view) 52
 - Navigation view
 - In the submenu 52
 - In the wizard 52
 - Numeric editor 54
- O**
- Operable flow range 120
 - Operating elements 55, 97
 - Operating keys
 - see Operating elements
 - Operating menu
 - Menus, submenus 48
 - Overview of menus with parameters 142
 - Structure 48
 - Submenus and user roles 49
 - Operating philosophy 49
 - Operation 87
 - Operation options 47, 47
 - Operational display 50
 - Operational safety 10
 - Order code 14, 15
 - Orientation (vertical, horizontal) 20
 - Outlet runs 21
 - Output 121
 - Output signal 121
 - Overview
 - Operating menu 142
- P**
- Packaging disposal 18
 - Parameter
 - Changing 60
 - Enter a value 60
 - Parameter settings
 - Communication (submenu) 75
 - Data logging (submenu) 90
 - Device information (submenu) 110
 - Diagnostics (menu) 107
 - Display (submenu) 81
 - Display (wizard) 73
 - Electrode cleaning circuit (submenu) 83
 - Empty pipe detection (wizard) 77
 - Low flow cut off (wizard) 76
 - Operation (submenu) 90
 - Process variables (submenu) 88
 - Sensor adjustment (submenu) 79
 - Setup (menu) 71
 - Simulation (submenu) 84
 - System units (submenu) 72
 - Totalizer (submenu) 89
 - Totalizer 1 to 3 (submenu) 80
 - Web server (submenu) 65
 - Partially filled pipe 20
 - Performance characteristics 125
 - Post-connection check (checklist) 45
 - Post-installation check 70
 - Post-installation check (checklist) 32
 - Potential equalization 41, 124
 - Power consumption 124
 - Power supply failure 124
 - Pressure loss 127
 - Pressure tightness 127
 - Pressure-temperature ratings 127
 - Process
 - Conductivity 126
 - Flow limit 127
 - Medium temperature 126
 - Pressure loss 127
 - Pressure tightness 127
 - Process connections 137
 - Product safety 10
 - Protecting parameter settings 85
- R**
- Read access 61
 - Reading measured values 88
 - Reading out diagnostic information, EtherNet/IP 102
 - Recalibration 113
 - Reference operating conditions 125
 - Registered trademarks 8
 - Remedial measures
 - Calling up 98
 - Closing 98

- Remote operation 138
- Remote version
 - Connecting the signal cables 39
- Repair 114
 - Notes 114
- Repair of a device 114
- Repeatability 125
- Replacement
 - Device components 114
- Replacing seals 113
- Requirements for personnel 9
- Returning devices 114

- S**
- Safety 9
- Screw tightening torques 25
- Sensor
 - Mounting 24
- Serial number 14, 15
- Setting the operating language 70
- Settings
 - Adapting the measuring device to the process conditions 89
 - Advanced display configurations 81
 - Communication interface 75
 - Device reset 110
 - Device tag 71
 - Electrode cleaning circuit (ECC) 83
 - Empty pipe detection (EPD) 77
 - Local display 73
 - Low flow cut off 76
 - Operating language 70
 - Resetting the totalizer 90
 - Sensor adjustment 79
 - Simulation 84
 - System units 72
 - Totalizer 80
 - Totalizer reset 90
- Shock resistance 126
- Showing data logging 90
- Signal on alarm 121
- Software release 68
- Spare part 114
- Spare parts 114
- Standards and guidelines 139
- Status area
 - For operational display 50
 - In the navigation view 52
- Status signals 96, 99
- Storage conditions 17
- Storage temperature 17
- Storage temperature range 126
- Structure
 - Operating menu 48
- submenu
 - Communication 75
 - Data logging 90
 - Device information 110
 - Display 81
 - Electrode cleaning circuit 83
 - Operation 90
 - Process variables 88
 - Sensor adjustment 79
 - Simulation 84
 - System units 72
 - Totalizer 89
 - Totalizer 1 to 3 80
 - Web server 65
- Submenu
 - Define access code 85
 - Events list 108
 - Overview 49
 - Process variables 88
- Supply voltage 124
- Surface roughness 137
- Symbols
 - For communication 50
 - For correction 54
 - For diagnostic behavior 50
 - For locking 50
 - For measured variable 51
 - For measurement channel number 51
 - For menus 53
 - For parameters 53
 - For status signal 50
 - For submenu 53
 - For wizard 53
 - In the status area of the local display 50
 - In the text and numeric editor 54
- System design
 - Measuring system 118
 - see Measuring device design
- System file
 - Release date 68
 - Source 68
 - Version 68
- System integration 68
- System pressure 22

- T**
- Technical data, overview 118
- Temperature range
 - Ambient temperature range for display 138
 - Storage temperature 17
- Terminal assignment 35, 38, 39
- Terminals 124
- Text editor 54
- Tool tip
 - see Help text
- Tools
 - Electrical connection 33
 - For mounting 24
 - Transport 17
- Transmitter
 - Connecting the signal cables 38
 - Turning the display module 31
 - Turning the housing 30
- Transporting the measuring device 17

Troubleshooting	
General	93
Turning the display module	31
Turning the electronics housing	
see Turning the transmitter housing	
Turning the transmitter housing	30
U	
Use of the measuring device	
Borderline cases	9
Incorrect use	9
see Designated use	
User roles	49
V	
Version data for the device	68
Vibration resistance	126
Vibrations	22
W	
W@M	113, 114
W@M Device Viewer	14, 114
Weight	
Compact version	128
Sensor remote version	130
Transport (notes)	17
wizard	
Define access code	85
Display	73
Empty pipe detection	77
Low flow cut off	76
Wizard	
Empty pipe detection (EPD)	78
Workplace safety	10
Write access	61
Write protection	
Via access code	85
Via write protection switch	86
Write protection switch	86

www.addresses.endress.com
