

# Operating Instructions

## Cerabar M, Deltapilot M

Pressure / hydrostatics




Cerabar M



Deltapilot M





A0023555

- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser distributor will supply you with current information and updates to this manual.

## Table of contents

<b>1</b>	<b>About this document</b> . . . . .	<b>5</b>	6.6	Locking/unlocking operation . . . . .	41
1.1	Document function . . . . .	5	6.7	Resetting to factory settings (reset) . . . . .	42
1.2	Symbols used . . . . .	5	<b>7</b>	<b>System integration</b> . . . . .	<b>43</b>
1.3	Terms and abbreviations . . . . .	7	7.1	Process data . . . . .	43
1.4	Turn down calculation . . . . .	8	7.2	Reading out and writing device data (ISDU – Indexed Service Data Unit) . . . . .	43
1.5	Registered trademarks . . . . .	8	<b>8</b>	<b>Commissioning</b> . . . . .	<b>48</b>
<b>2</b>	<b>Basic safety instructions</b> . . . . .	<b>9</b>	8.1	Function check . . . . .	48
2.1	Requirements for personnel . . . . .	9	8.2	Unlocking/locking configuration . . . . .	48
2.2	Designated use . . . . .	9	8.3	Commissioning without an operating menu . . . . .	49
2.3	Workplace safety . . . . .	9	8.4	Commissioning with an operating menu . . . . .	51
2.4	Operational safety . . . . .	9	8.5	Configuring level measurement . . . . .	53
2.5	Product safety . . . . .	10	8.6	Configuring pressure measurement . . . . .	57
<b>3</b>	<b>Incoming acceptance and product identification</b> . . . . .	<b>11</b>	8.7	Backing up or duplicating the device data . . . . .	59
3.1	Incoming acceptance . . . . .	11	<b>9</b>	<b>Maintenance</b> . . . . .	<b>60</b>
3.2	Product identification . . . . .	11	9.1	Information on cleaning . . . . .	60
3.3	Nameplate . . . . .	12	9.2	Exterior cleaning . . . . .	60
3.4	Identifying the sensor type . . . . .	13	<b>10</b>	<b>Diagnostics and troubleshooting</b> . . . . .	<b>61</b>
3.5	Storage and transport . . . . .	13	10.1	Diagnostic events . . . . .	61
3.6	Scope of delivery . . . . .	14	10.2	Behavior of the current output in the event of an error . . . . .	64
<b>4</b>	<b>Installation</b> . . . . .	<b>15</b>	10.3	Locking/unlocking operation . . . . .	64
4.1	Installation conditions . . . . .	15	10.4	Resetting to factory settings (reset) . . . . .	65
4.2	General installation instructions . . . . .	15	10.5	Software history . . . . .	65
4.3	Mounting sensor modules with PVDF thread . . . . .	15	<b>11</b>	<b>Repair</b> . . . . .	<b>67</b>
4.4	Installing the Cerabar M . . . . .	16	11.1	General information . . . . .	67
4.5	Installing the Deltapilot M . . . . .	26	11.2	Spare parts . . . . .	67
4.6	Mounting of the profile seal for universal process mounting adapter . . . . .	29	11.3	Return . . . . .	68
4.7	Closing the housing cover . . . . .	30	11.4	Disposal . . . . .	68
4.8	Post-installation check . . . . .	30	<b>12</b>	<b>Overview of the operating menu</b> . . . . .	<b>69</b>
<b>5</b>	<b>Electrical connection</b> . . . . .	<b>31</b>	<b>13</b>	<b>Description of device parameters</b> . . . . .	<b>71</b>
5.1	Connecting the device . . . . .	31	13.1	Expert → System . . . . .	71
5.2	Connecting the measuring unit . . . . .	31	13.2	Expert → System → Instrument info . . . . .	71
5.3	Terminals . . . . .	32	13.3	Expert → System → Display . . . . .	73
5.4	Cable specification . . . . .	32	13.4	Expert → System → Management . . . . .	73
5.5	Load for current output . . . . .	32	13.5	Expert → Measurement . . . . .	74
5.6	Field Xpert SMT70, SMT77 . . . . .	32	13.6	Expert → Measurement → Basic setup . . . . .	74
5.7	FieldPort SFP20 . . . . .	33	13.7	Expert → Measurement → Pressure . . . . .	76
5.8	Post-connection check . . . . .	33	13.8	Expert → Measurement → Level . . . . .	78
<b>6</b>	<b>Operation</b> . . . . .	<b>34</b>	13.9	Expert → Measurement → Sensor limits . . . . .	80
6.1	Operation methods . . . . .	34	13.10	Expert → Measurement → Sensor trim . . . . .	80
6.2	Operation without an operating menu . . . . .	35	13.11	Expert → Output → Current output . . . . .	81
6.3	Operation with an operating menu . . . . .	36	13.12	Expert → Communication . . . . .	84
6.4	Operation with device display (optional) . . . . .	37	13.13	Expert → Diagnosis . . . . .	84
6.5	Operation using Endress+Hauser operating program . . . . .	41			

---

13.14	Expert → Diagnosis → Diagnostic list . . . . .	86
13.15	Expert → Diagnosis → Event logbook . . . . .	86
13.16	Expert → Diagnosis → Simulation . . . . .	86
13.17	Backing up or duplicating the device data . . . . .	88
<b>14</b>	<b>Technical data . . . . .</b>	<b>89</b>
14.1	Pressure specifications . . . . .	89
14.2	Additional technical data . . . . .	89
<b>Index</b>	<b>. . . . .</b>	<b>90</b>

# 1 About this document

## 1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

## 1.2 Symbols used

### 1.2.1 Safety symbols

Symbol	Meaning
	<b>DANGER!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	<b>CAUTION!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	<b>NOTICE!</b> This symbol contains information on procedures and other facts which do not result in personal injury.

### 1.2.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.		<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

### 1.2.3 Tool symbols

Symbol	Meaning
	Allen key
	Open-ended wrench

### 1.2.4 Symbols for certain types of information



Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.

Symbol	Meaning
	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
	<b>Tip</b> Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Visual inspection


### 1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
<b>1.</b> <b>2.</b> <b>3.</b> ...	Series of steps
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections

### 1.2.6 Symbols at the device

Symbol	Meaning
 A0019159	<b>Safety instructions</b> Observe the safety instructions contained in the associated Operating Instructions.
 A0029423	<b>Connecting cable immunity to temperature change</b> Indicates that the connecting cables have to withstand a temperature of 85°C at least.


### 1.3 Terms and abbreviations



A0029505

Item	Term/abbreviation	Explanation
1	OPL	OPL: The OPL (over pressure limit = sensor overload limit) for the measuring device depends on the lowest-rated element, with regard to pressure, of the selected components, i.e., the process connection has to be taken into consideration in addition to the measuring cell. Observe pressure-temperature dependency.
2	MWP	MWP: The MWP (maximum working pressure) for the sensors depends on the lowest-rated element, with regard to pressure, of the selected components, i.e., the process connection has to be taken into consideration in addition to the measuring cell. Observe pressure-temperature dependency. The MWP may be applied at the device for an unlimited period of time. The MWP can be found on the nameplate.
3	Maximum sensor measuring range	Span between LRL and URL This sensor measuring range is equivalent to the maximum calibratable/adjustable span.
4	Calibrated/adjusted span	Span between LRV and URV Factory setting: 0 to URL Other calibrated spans can be ordered as customized spans.
p	-	Pressure
-	LRL	Lower range limit
-	URL	Upper range limit
-	LRV	Lower range value
-	URV	Upper range value
-	TD (Turn down)	Turn down Example - see the following section.

## 1.4 Turn down calculation



A0029545

- 1 Calibrated/adjusted span
- 2 Zero point-based span
- 3 Upper range limit

### Example

- Sensor: 10 bar (150 psi)
- Upper range limit (URL) = 10 bar (150 psi)
- Turn down (TD):
- Calibrated/adjusted span: 0 to 5 bar (0 to 75 psi)
- Lower range value (LRV) = 0 bar (0 psi)
- Upper range value (URV) = 5 bar (75 psi)

$$TD = \frac{URL}{|URV - LRV|}$$

$$TD = \frac{10 \text{ bar (150 psi)}}{|5 \text{ bar (75 psi)} - 0 \text{ bar (0 psi)}|} = 2$$

In this example, the TD is 2:1.  
This span is based on the zero point.

## 1.5 Registered trademarks

- KALREZ®  
Registered label of E.I. Du Pont de Nemours & Co., Wilmington, USA
- TRI-CLAMP®  
Registered label of Ladish & Co., Inc., Kenosha, USA
-  IO-Link  
Registered trademark of the IO-Link Community.
- GORE-TEX® trademark of W.L. Gore & Associates, Inc., USA

## 2 Basic safety instructions

### 2.1 Requirements for personnel

The personnel for installation, commissioning, diagnostics and maintenance must meet the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application)
- ▶ Follow instructions and comply with basic conditions

The operating personnel must meet the following requirements:

- ▶ Operating personnel are instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Follow the instructions in this manual

### 2.2 Designated use

The Cerabar M is a pressure transmitter for measuring level and pressure.

The Deltapilot M is a hydrostatic pressure sensor for measuring level and pressure.

#### 2.2.1 Incorrect use

The manufacturer is not liable for damage caused by improper or non-designated use.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

### 2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.
- ▶ Switch off the supply voltage before connecting the device.

### 2.4 Operational safety

Risk of injury!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

#### Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

#### Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.

- ▶ Use original spare parts and accessories from Endress+Hauser only.

### **Hazardous area**

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area.
- ▶ Observe the specifications in the separate supplementary documentation that is an integral part of these Instructions.


## **2.5 Product safety**

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which they are safe to operate.

It fulfills general safety requirements and legal requirements. It also conforms to the EC directives listed in the device-specific EC declaration of conformity. Endress+Hauser confirms this fact by applying the CE mark.

## 3 Incoming acceptance and product identification

### 3.1 Incoming acceptance



A0016870

- Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?
- Are the goods undamaged?
- Do the data on the nameplate correspond to the order specifications and the delivery note?
- Is the documentation available?
- If required (see nameplate): Are the safety instructions (XA) present?



If one of these conditions is not fulfilled, please contact your Endress+Hauser sales office.

### 3.2 Product identification

The following options are available to identify the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial numbers from the nameplates in *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): all the information about the device is displayed.

For an overview of the technical documentation provided, enter the serial number from the nameplates in *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))


#### 3.2.1 Manufacturer address

Endress+Hauser SE+Co. KG  
 Hauptstraße 1  
 79689 Maulburg, Germany  
 Place of manufacture: See nameplate.

### 3.3 Nameplate

- The MWP (maximum working pressure) is specified on the nameplate. This value refers to a reference temperature of 20°C (68°F) or 100°F (38 °C) for ANSI flanges.
- The pressure values permitted at higher temperatures can be found in the following standards:  
 EN 1092-1: 2001 Tab. 18 (With regard to their stability-temperature property, the materials 1.4435 and 1.4404 are grouped together under 13EO in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.)  
 ASME B 16.5a – 1998 Tab. 2-2.2 F316  
 ASME B 16.5a – 1998 Tab. 2.3.8 N10276  
 JIS B 2220
- The test pressure corresponds to the over pressure limit (OPL) of the device = MWP x 1.5 (The equation does not apply for PMP51 and PMP55 with a 40 bar (600 psi) or a 100 bar (1500 psi) measuring cell).
- The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the measuring device.

#### 3.3.1 Aluminum housing



A0030017

- 1 Device name
- 2 Order code (for re-orders)
- 3 Serial number (for identification)
- 4 Extended order code (complete)
- 5 MWP (Maximum working pressure)
- 6 Electronic version (output signal)
- 7 Min./max. span
- 8 Nominal measuring range
- 9 Supply voltage
- 10 Unit of length
- 11 ID number of notified body with regard to ATEX (optional)
- 12 ID number of notified body with regard to Pressure Equipment Directive (optional)
- 13 Approvals
- 14 Software version
- 15 Device version
- 16 Degree of protection
- 17 Wetted materials
- 18 Approval-specific information


Devices suitable for oxygen applications are fitted with an additional nameplate.



A0030019

- 1 Maximum pressure for oxygen applications
- 2 Maximum temperature for oxygen applications
- 3 Layout identification of the nameplate


### 3.3.2 Stainless steel housing, hygienic



A0030021

- 1 Device name
- 2 Order code (for re-orders)
- 3 Serial number (for identification)
- 4 Extended order code (complete)
- 5 Nominal measuring range
- 6 MWP (Maximum working pressure)
- 7 Length data
- 8 Electronic version (output signal)
- 9 Supply voltage
- 10 Min./max. span
- 11 Wetted materials
- 12 Approval-specific information
- 13 ID number of notified body with regard to ATEX (optional)
- 14 ID number of notified body with regard to Pressure Equipment Directive (optional)
- 15 Approvals
- 16 Software version
- 17 Device version
- 18 Degree of protection

Devices with certificates are fitted with an additional plate.



A0030024

- 1 Approval-specific information

### 3.4 Identifying the sensor type

In the case of gauge pressure sensors, the "Pos. zero adjust" parameter appears in the operating menu ("Setup" -> "Pos. zero adjust").

In the case of absolute pressure sensors, the "Calib. offset" parameter appears in the operating menu ("Setup" -> "Calib. offset").

### 3.5 Storage and transport

#### 3.5.1 Storage conditions

Use original packaging.

Store the measuring device in clean and dry conditions and protect from damage caused by shocks (EN 837-2).

**Storage temperature range**

See the Technical Information for Cerabar M TI00436P / Deltapilot M TI00437P.

**3.5.2 Transporting the product to the measuring point****⚠ WARNING****Incorrect transport!**

Housing and membrane may become damaged, and there is a risk of injury!

- ▶ Transport the measuring device to the measuring point in its original packaging or by the process connection.
- ▶ Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs).
- ▶ Do not use capillaries as a carrying aid for the diaphragm seals.

**3.6 Scope of delivery**

The scope of delivery comprises:

- Device
- Optional accessories

Accompanying documentation:

- Operating Instructions BA02136P is available on the Internet. See: [www.de.endress.com](http://www.de.endress.com)  
→ Download
- Brief Operating Instructions: KA01522P Cerabar M / KA01523P Deltapilot M
- Final inspection report
- Additional Safety Instructions for ATEX, IECEx and NEPSI devices
- Optional: factory calibration certificate, inspection certificates

## 4 Installation

### 4.1 Installation conditions

#### 4.1.1 Dimensions

Dimensions → see the Technical Information for Cerabar M TI00436P / Deltapilot M TI00437P, "Mechanical construction" section.

### 4.2 General installation instructions

- Devices with a G 1 1/2 thread:  
When screwing the device into the tank, the flat seal has to be positioned on the sealing surface of the process connection. To avoid additional strain on the process isolating diaphragm, the thread should never be sealed with hemp or similar materials.
- Devices with NPT threads:
  - Wrap Teflon tape around the thread to seal it.
  - Tighten the device at the hexagonal bolt only. Do not turn at the housing.
  - Do not overtighten the thread when screwing. Max. torque:  
20 to 30 Nm (14.75 to 22.13 lbf ft)
- For the following process connections a tightening torque of max. 40 Nm (29.50 lbf ft) is required:
  - Thread ISO228 G1/2 (Order option "GRC" or "GRJ" or "GOJ")
  - Thread DIN13 M20 x 1.5 (Order option "G7J" or "G8J")

### 4.3 Mounting sensor modules with PVDF thread

#### **⚠ WARNING**

##### **Risk of damage to process connection!**

Risk of injury!

- ▶ Sensor modules with PVDF thread must be installed with the mounting bracket provided!

#### **⚠ WARNING**

##### **Material fatigue from pressure and temperature!**

Risk of injury if parts burst! The thread can become loose if exposed to high pressure and temperature loads.

- ▶ The integrity of the thread must be checked regularly. Also, the thread may need to be re-tightened with the maximum tightening torque of 7 Nm (5.16 lbf ft). Teflon tape is recommended for sealing the 1/2" NPT thread.

## 4.4 Installing the Cerabar M

- Due to the orientation of the Cerabar M, there may be a shift in the zero point, i.e. when the container is empty or partially full, the measured value does not display zero. You can correct this zero point shift → 36 "Funktion der Bedienelemente".
- The local display can be rotated in 90° stages.
- For PMP55, please refer to Section "Installation instructions for devices with diaphragm seals – PMP55" → 19.
- Endress+Hauser offers a mounting bracket for installing on pipes or walls. → 23, Section "Wall and pipe mounting (optional)".


### 4.4.1 Installation instructions for devices without diaphragm seals – PMP51, PMC51

#### NOTICE

##### Damage to the device!


If a heated device is cooled during a cleaning process (e.g. by cold water), a vacuum develops for a short time and, as a result, moisture can enter the sensor through the pressure compensation element (1).

- ▶ Mount the device with the pressure compensation element (1) pointing diagonally downwards or to the side as much as possible.




A0028471

- Keep the pressure compensation and GORE-TEX® filter (1) free from contamination.
- Cerabar M transmitters without diaphragm seals are mounted as per the norms for a manometer (DIN EN 837-2). We recommend the use of shutoff devices and siphons. The orientation depends on the measuring application.
- Do not clean or touch process membranes with hard or pointed objects.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



A0028472

### Pressure measurement in gases




A0028473

- 1 Cerabar M
- 2 Shutoff device

Mount the Cerabar M with the shutoff device above the tapping point so that any condensate can flow into the process.

### Pressure measurement in vapors




A0028474

- 1 Cerabar M
- 2 Shutoff device
- 3 U-shaped siphon
- 4 Circular siphon

- Mount the Cerabar M with the siphon below the tapping point.
- Fill the siphon with liquid before commissioning. The siphon reduces the temperature to almost ambient temperature.

### Pressure measurement in liquids




A002B491

- 1 Cerabar M  
2 Shutoff device

Mount the Cerabar M with the shutoff device below or at the same level as the tapping point.

### Level measurement



A002B492

- Always install the device below the lowest measuring point.
- Do not install the device at the following positions:
  - in the filling curtain
  - in the tank outlet
  - in the suction area of a pump
  - at a point in the tank which could be affected by pressure pulses from the agitator.
- The calibration and functional test can be carried out more easily if you mount the device downstream from a shutoff device.

#### 4.4.2 Installation instructions for devices with diaphragm seals – PMP55

- Cerabar M devices with diaphragm seals are screwed in, flanged or clamped, depending on the type of diaphragm seal.
- Please note that the hydrostatic pressure of the liquid columns in the capillaries can cause zero point shift. The zero point shift can be corrected.
- Do not clean or touch the process membrane of the diaphragm seal with hard or pointed objects.
- Do not remove the protection on the process membrane until just before installation.

##### NOTICE

##### Improper handling!

Damage to the device!

- ▶ A diaphragm seal and the pressure transmitter together form a closed, oil-filled calibrated system. The fill fluid hole is sealed and may not be opened.
- ▶ If a mounting bracket is used, sufficient strain relief must be ensured for the capillaries in order to prevent them from buckling (bending radius  $\geq 100$  mm (3.94 in)).
- ▶ Please observe the application limits of the diaphragm seal filling oil as detailed in the Technical Information for Cerabar M TI00436P, "Planning instructions for diaphragm seal systems" section.

##### NOTICE

**In order to obtain more precise measurement results and to avoid a defect in the device, mount the capillaries as follows:**

- ▶ Vibration-free (in order to avoid additional pressure fluctuations)
- ▶ Not in the vicinity of heating or cooling lines
- ▶ Insulate if the ambient temperature is below or above the reference temperature
- ▶ Mount with a bending radius  $\geq 100$  mm (3.94 in)!
- ▶ Do not use the capillaries as a carrying aid for the diaphragm seals!


#### Vacuum applications

##### Installation instructions

For vacuum applications, pressure transmitters with a ceramic measuring membrane (oil-free) are preferable.


For applications under vacuum, Endress+Hauser recommends mounting the pressure transmitter below the diaphragm seal. This prevents a vacuum load on the diaphragm seal caused by the presence of fill fluid in the capillary.

When the pressure transmitter is mounted above the diaphragm seal, the maximum height difference H1 in accordance with the following illustrations must not be exceeded. The following illustration shows installation above the lower diaphragm seal:



A0023994

The maximum height difference depends on the density of the fill fluid and the lowest pressure that is permitted to occur at the diaphragm seal (empty tank). See illustration below. The following diagram shows the maximum installation height above the lower diaphragm seal for vacuum applications.




A0023986-EN

- A Height difference H1
- B Pressure at diaphragm seal
- 1 Low-temperature oil
- 2 Vegetable oil
- 3 Silicone oil
- 4 High-temperature oil
- 5 Inert oil

**Mounting with temperature isolator**

Endress+Hauser recommends the use of temperature isolators in the event of constant extreme medium temperatures which cause the maximum permissible electronics temperature of +85 °C (+185 °F) to be exceeded. Depending on the fill fluid used, diaphragm seal systems with temperature isolators can be used for maximum temperatures of up to +400 °C (+752 °F), see Technical Information, section "Diaphragm seal fill fluids". To minimize the influence of rising heat, Endress+Hauser recommends the device be mounted horizontally or with the housing pointing downwards. The additional installation height also brings about a zero point shift of maximum 21 mbar (0.315 psi) due to the hydrostatic column in the temperature isolator. You can correct this zero point shift at the device.




A0039378

- A No insulation
- B Insulation 30 mm (1.18 in)
- C Maximum insulation
- 1 Transmitter
- 2 Insulation material

**Heat insulation**

The PMP55 may only be insulated up to a certain height. The maximum permitted insulation height is indicated on the devices and applies to an insulation material with a heat conductivity  $\leq 0.04 \text{ W}/(\text{m} \times \text{K})$  and to the maximum permitted ambient and process temperature. The data were determined under the most critical application "quiescent air". Maximum permitted insulation height, here indicated on a PMP55 with a flange:



- A Ambient temperature  $\leq 70\text{ }^{\circ}\text{C}$  (158 °F)
- B Process temperature
- 1 Maximum permitted insulation height
- 2 Insulation material


### 4.4.3 Seal for flange mounting

**NOTICE**

**Corrupted measurement results.**

The seal is not allowed to press against the process isolating diaphragm as this could affect the measurement result.


- Ensure that the seal is not touching the process isolating diaphragm.



- 1 Process isolating diaphragm
- 2 Seal

#### 4.4.4 Wall and pipe mounting (optional)


Endress+Hauser offers a mounting bracket for installation on pipes or walls (for pipe diameters from 1 ¼" to 2").



Please note the following when mounting:

- Devices with capillary tubes: mount capillaries with a bending radius  $\geq$  100 mm (3.94 in).
- When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft).

#### 4.4.5 Assembling and mounting the "separate housing" version



#### Assembly and mounting

1. Insert the connector (item 4) into the corresponding connection jack of the cable (item 2).
2. Plug the cable into the housing adapter (item 6).
3. Tighten the locking screw (item 5).
4. Mount the housing on a wall or pipe using the mounting bracket (item 7). When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft). Mount the cable with a bending radius ( $r$ )  $\geq$  120 mm (4.72 in).

#### Routing the cable (e.g. through a pipe)


You require the cable shortening kit.

Order number: 71125862

For details on mounting, see SD00553P/00/A6.

### 4.4.6 PMP51, version prepared for diaphragm seal mount – welding recommendation

Version XSJ: prepared for diaphragm seal mount



For the version "XSJ - Prepared for diaphragm seal mount" in feature 110 "Process connection" in the order code up to and including 40 bar (600 psi) sensors, Endress+Hauser recommends welding on the diaphragm seal as follows: the total welding depth of the fillet weld is 1 mm (0.04 in) with an outer diameter of 16 mm (0.63 in). Welding is performed according to the WIG method.

Consecutive seam no.	Sketch/welding groove shape, dimension as per DIN 8551	Base material matching	Welding method DIN EN ISO 24063	Welding position	Inert gas, additives
A1 for sensors ≤ 40 bar (600 psi)	<p>A0024811</p>	Adapter made of AISI 316L (1.4435) to be welded to diaphragm seal made of AISI 316L (1.4435 or 1.4404)	141	PB	Inert gas Ar/H 95/5 Additive: ER 316L Si (1.4430)

#### Information on filling

The diaphragm seal must be filled as soon as it has been welded on.

- After welded into the process connection, the sensor assembly must be properly filled with a filling oil and sealed gas-tight with a sealing ball and lock screw. Once the diaphragm seal has been filled, at the zero point the device display should not exceed 10% of the full scale value of the cell measuring range. The internal pressure of the diaphragm seal must be corrected accordingly.
- Adjustment / calibration:
  - The device is operational once it has been fully assembled.
  - Perform a reset. The device must then be calibrated to the process measuring range as described in the Operating Instructions.

## 4.5 Installing the Deltapilot M

- Due to the orientation of the Deltapilot M, there may be a shift in the zero point, i.e. when the container is empty or partially full, the measured value does not display zero. You can correct this zero point shift → 36 "Function of the operating elements".
- The local display can be rotated in 90° stages.
- Endress+Hauser offers a mounting bracket for installing on pipes or walls. → 23, Section "Wall and pipe mounting (optional)".


### 4.5.1 General installation instructions

#### NOTICE

#### Damage to the device!


If a heated device is cooled during a cleaning process (e.g. by cold water), a vacuum develops for a short time and, as a result, moisture can enter the sensor via the pressure compensation (1).

- ▶ In this case, mount the device so that the pressure compensation (1) point downwards.



A002B471


- Keep the pressure compensation and GORE-TEX® filter (1) free from contamination.
- Do not clean or touch process membranes with hard or pointed objects.
- The process membrane in the rod and cable version is protected against mechanical damage by a plastic cap.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



A002B472

## 4.5.2 FMB50

### Level measurement



A0028492

- Always install the device below the lowest measuring point.
- Do not install the device at the following positions:
  - in the filling curtain
  - in the tank outlet
  - in the suction area of a pump
  - at a point in the tank which could be affected by pressure pulses from the agitator.
- The calibration and functional test can be carried out more easily if you mount the device downstream from a shutoff device.
- The Deltapilot M must also be insulated in the case of media that can harden when cold.

### Pressure measurement in gases

Mount the Deltapilot M with the shutoff device above the tapping point so that any condensate can flow into the process.

### Pressure measurement in vapors

- Mount the Deltapilot M with the siphon above the tapping point.
- Fill the siphon with liquid before commissioning. The siphon reduces the temperature to almost ambient temperature.

### Pressure measurement in liquids

Mount the Deltapilot M with the shutoff device below or at the same level as the tapping point.

## 4.5.3 Supplementary installation instructions

Sealing the probe housing

- No moisture may enter the housing when installing or operating the device, or when establishing the electrical connection.
- Always firmly tighten the housing cover and the cable entries.


## 4.5.4 Seal for flange mounting

### NOTICE

#### Corrupted measurement results.

The seal is not allowed to press against the process isolating diaphragm as this could affect the measurement result.

- ▶ Ensure that the seal is not touching the process isolating diaphragm.




A0017743

- 1 Process isolating diaphragm
- 2 Seal

### 4.5.5 Wall and pipe mounting (optional)

Endress+Hauser offers a mounting bracket for installation on pipes or walls (for pipe diameters from 1 ¼" to 2").




A0024812

Engineering unit mm (in)

Please note the following when mounting:

- Devices with capillary tubes: mount capillaries with a bending radius  $\geq$  100 mm (3.94 in).
- When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft).

### 4.5.6 Assembling and mounting the "separate housing" version



#### Assembly and mounting

1. Insert the connector (item 4) into the corresponding connection jack of the cable (item 2).
2. Plug the cable into the housing adapter (item 6).
3. Tighten the locking screw (item 5).
4. Mount the housing on a wall or pipe using the mounting bracket (item 7). When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft). Mount the cable with a bending radius ( $r$ )  $\geq$  120 mm (4.72 in).

#### Routing the cable (e.g. through a pipe)

You require the cable shortening kit.

Order number: 71125862

For details on mounting, see SD00553P/00/A6.

### 4.6 Mounting of the profile seal for universal process mounting adapter

For details on mounting, see KA00096F/00/A3.

## 4.7 Closing the housing cover

### NOTICE

#### Devices with EPDM cover seal - transmitter leakiness!

Mineral-based, animal-based or vegetable-based lubricants cause the EPDM cover seal to swell and the transmitter to become leaky.

- ▶ The thread is coated at the factory and therefore does not require any lubrication.


### NOTICE

#### The housing cover can no longer be closed.

Damaged thread!

- ▶ When closing the housing cover, please ensure that the thread of the cover and housing are free from dirt, e.g. sand. If you feel any resistance when closing the cover, check the thread on both again to ensure that they are free from dirt.

### 4.7.1 Closing the cover on the stainless steel housing



A0028497

The cover for the electronics compartment is tightened by hand at the housing until the stop. The screw serves as DustEx protection (only available for devices with DustEx approval).

## 4.8 Post-installation check

<input type="checkbox"/>	Is the device undamaged (visual inspection)?
<input type="checkbox"/>	Does the device meet the measuring point specifications? For example: <ul style="list-style-type: none"> <li>▪ Process temperature</li> <li>▪ Process pressure</li> <li>▪ Ambient temperature</li> <li>▪ Measuring range</li> </ul>
<input type="checkbox"/>	Are the measuring point identification and labeling correct (visual inspection)?
<input type="checkbox"/>	Is the device adequately protected from precipitation and direct sunlight?
<input type="checkbox"/>	Are the fixing screws and securing clamp tightened securely?

## 5 Electrical connection

### 5.1 Connecting the device

#### **⚠ WARNING**


#### **Supply voltage might be connected!**

Risk of electric shock and/or explosion!

- ▶ Make sure that no uncontrolled processes are triggered on the system.
- ▶ Switch off the supply voltage before connecting the device.
- ▶ When using the measuring device in hazardous areas, ensure compliance with the corresponding national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- ▶ A suitable circuit breaker must be provided for the device in accordance with IEC/EN61010.
- ▶ Devices with integrated overvoltage protection must be grounded.
- ▶ Protective circuits against reverse polarity, HF influences and overvoltage peaks are integrated.
- ▶ The power unit must be tested to ensure it meets safety requirements (e.g., PELV, SELV, Class 2).

Connect the device in the following order:

1. Check that the supply voltage corresponds to the supply voltage indicated on the nameplate.
2. Switch off the supply voltage before connecting the device.
3. Connect the device in accordance with the following diagram.
4. Switch on the supply voltage.



A0045628

- 1 Supply voltage +
- 2 4-20 mA
- 3 Supply voltage -
- 4 C/Q (IO-Link communication)

### 5.2 Connecting the measuring unit

#### 5.2.1 Supply voltage

##### IO-Link

- 11.5 to 30 V DC if only the analog output is used
- 18 to 30 V DC if IO-Link is used

#### 5.2.2 Current consumption

IO-Link < 60 mA

## 5.3 Terminals

- Supply voltage: 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- External ground terminal: 0.5 to 4 mm<sup>2</sup> (20 to 12 AWG)


## 5.4 Cable specification

### 5.4.1 IO-Link

Endress+Hauser recommends using twisted, four-core cable.

## 5.5 Load for current output

In order to guarantee sufficient terminal voltage, a maximum load resistance  $R_L$  (including line resistance) must not be exceeded depending on the supply voltage  $U_B$  of the supply unit.



A0045615

- 1 Power supply 11.5 to 30 V<sub>DC</sub>  
 2  $R_{Lmax}$  maximum load resistance  
 $U_B$  Supply voltage

- Output of failure current and display of "M803" (Output: MIN alarm current)
- Periodic checking to establish if it is possible to quit fault state

## 5.6 Field Xpert SMT70, SMT77

The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous (Ex Zone 2) and non-hazardous areas. It is suitable for commissioning and maintenance staff. It manages Endress+Hauser and third-party field instruments with a digital communication interface and documents the progress of the work. The SMT70 is designed as a complete solution. It comes with a pre-installed driver library and is an easy-to-use, touch-enabled tool for managing field devices throughout their entire life cycle.

The Field Xpert SMT77 for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1. It is suitable for commissioning and maintenance staff for easy management of field instruments with a digital communication interface. The touch-enabled tablet PC is designed as a complete solution. It comes with comprehensive pre-installed driver libraries and offers users a modern software user interface to manage field instruments throughout the entire life cycle.

Required tool: "IO-Link IODD Interpreter DTM"

## 5.7 FieldPort SFP20

The FieldPort SFP20 is a USB interface for the configuration of Endress+Hauser IO-Link devices, and also of devices from other vendors. Combined with the IO-Link CommDTM and the IO-Link Interpreter, the FieldPort SFP20 complies with the FDT/DTM standards.


## 5.8 Post-connection check

<input type="checkbox"/>	Is the device or cable undamaged (visual inspection)?
<input type="checkbox"/>	Do the cables used comply with the requirements?
<input type="checkbox"/>	Are the mounted cables strain-relieved?
<input type="checkbox"/>	Are all cable glands installed, securely tightened and leak-tight?
<input type="checkbox"/>	Does the supply voltage match the specifications on the nameplate?
<input type="checkbox"/>	Is the terminal assignment correct?
<input type="checkbox"/>	If required: Has the protective ground connection been established?
<input type="checkbox"/>	If supply voltage is present, is the device ready for operation and do values appear on the display module?
<input type="checkbox"/>	Are all housing covers installed and securely tightened?
<input type="checkbox"/>	Is the securing clamp tightened correctly?

## 6 Operation



### 6.1 Operation methods

#### 6.1.1 Operation without an operating menu

Operation methods	Explanation	Graphic	Description
Local operation without device display	The device is operated using the operating keys on the electronic insert.		→  35

#### 6.1.2 Operation with an operating menu

Operation with an operating menu is based on an operation concept with "user roles"  
 →  36.

Operation methods	Explanation	Graphic	Description
Local operation with device display	The device is operated using the operating keys on the device display.		→  37
Remote operation via FieldCare	The device is operated using the FieldCare operating tool.		→  41

#### 6.1.3 IO-Link

##### IO-Link information

IO-Link Smart Sensor Profile 2nd Edition

Supports

- Identification
- Diagnosis
- Digital Measuring Sensor (as per SSP 4.3.3)

IO-Link is a point-to-point connection for communication between the measuring device and an IO-Link master. The measuring device features an IO-Link communication interface type 2 (pin 4) with a second IO function on pin 2. This requires an IO-Link-compatible assembly (IO-Link master) for operation. The IO-Link communication interface enables direct access to the process and diagnostic data. It also provides the option of configuring the measuring device while in operation.

Characteristics of the IO-Link interface:

- IO-Link specification: Version 1.1
- IO-Link Smart Sensor Profile 2nd Edition
- Speed: COM2; 38.4 kBaud
- Minimum cycle time: 10 ms
- Process data width: 14 Byte
- IO-Link data storage: Yes
- Block configuration: Yes
- Device operational: The measuring device is operational 5 seconds after the supply voltage is applied

### IO-Link download

<http://www.endress.com/download>

- Select "Software" as the media type
- Select "Device Driver" as the software type
  - Select IO-Link (IODD)
  - IODD for Cerabar M PMC51, PMP51, PMP55
  - IODD for Deltapilot FMB50
- In the "Text Search" field enter the device name.

<https://ioddfinder.io-link.com/>

Search by


- Manufacturer
- Article number
- Product type

## 6.2 Operation without an operating menu

### 6.2.1 Position of operating elements

The operating keys are located in the measuring device on the electronic insert.

#### IO-Link



A0045576

- 1 Operating keys for lower range value (zero) and upper range value (span)
- 2 Green LED to indicate successful operation
- 3 Slot for optional onsite display
- 4 Slot for M12 plug

### Function of the operating elements

Operating key(s)	Meaning
"Zero" pressed for at least 3 seconds	<b>Get LRV</b> <ul style="list-style-type: none"> <li>▪ <b>"Pressure" measuring mode</b> The pressure present is accepted as the lower range value (LRV).</li> <li>▪ <b>"Level" measuring mode, "In pressure" level selection, "Wet" calibration mode</b> The pressure present is assigned to the lower level value ("Empty calibration").</li> </ul>
"Span" pressed for at least 3 seconds	<b>Get URV</b> <ul style="list-style-type: none"> <li>▪ <b>"Pressure" measuring mode</b> The pressure present is accepted as the upper range value (URV).</li> <li>▪ <b>"Level" measuring mode, "In pressure" level selection, "Wet" calibration mode</b> The pressure present is assigned to the upper level value ("Full calibration").</li> </ul>
"Zero" and "Span" pressed simultaneously for at least 3 seconds	<b>Position adjustment</b> The sensor characteristic is shifted in parallel so that the pressure present becomes the zero value.
"Zero" and "Span" pressed simultaneously for at least 12 seconds	<b>Reset</b> All the parameters are reset to the order configuration.

### 6.2.2 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorized and undesired access.

## 6.3 Operation with an operating menu

### 6.3.1 Operating concept

The operation concept makes a distinction between the following user roles:

User role	Meaning
Operator	Operators are responsible for the devices during normal "operation". This is usually limited to reading process values either directly at the device or in a control room. If the work with the devices goes beyond reading out values, it concerns simple, application-specific functions that are used during operation. Should an error occur, these users simply forward the information on the errors but do not intervene themselves.
Service engineer/ technician	Service engineers usually work with the devices in the phases following device commissioning. They are primarily involved in maintenance and troubleshooting activities for which simple settings have to be made at the device. Technicians work with the devices over the entire life cycle of the product. Thus, commissioning and advanced settings and configurations are some of the tasks they have to carry out.
Expert	Experts work with the devices over the entire life cycle of the device, but in some cases place high demands on the devices. Individual parameters/functions from the overall functionality of the devices are required for this purpose time and again. In addition to technical, process-oriented tasks, experts can also perform administrative tasks (e.g. user administration). The "Expert" has access to the entire parameter set.

### 6.3.2 Structure of the operating menu


User role	Sub-menu	Meaning/use
Operator	Language	Only consists of the "Language" parameter (000) where the operating language for the device is specified. The language can always be changed even if the device is locked.
Operator	Display/operat.	Contains parameters that are needed to configure the measured value display (selecting the values displayed, display format, etc.). With this submenu, users can change the measured value display without affecting the actual measurement.
Maintenance	Setup	Contains all the parameters that are needed to commission measuring operations. This submenu has the following structure: <ul style="list-style-type: none"> <li>▪ <b>Standard setup parameters</b> A wide range of parameters, which can be used to configure a typical application, is available at the start. The measuring mode selected determines which parameters are available. After making settings for all these parameters, the measuring operation should be completely configured in the majority of cases.</li> <li>▪ <b>"Extended setup" submenu</b> The "Extended setup" submenu contains additional parameters for more accurate configuration of the measurement, for converting the measured value and for scaling the output signal. This menu is split into additional submenus depending on the measuring mode selected.</li> </ul>
Maintenance	Diagnosis	Contains all the parameters that are needed to detect and analyze operating errors. This submenu has the following structure: <ul style="list-style-type: none"> <li>▪ <b>Diagnostic list</b> Contains up to 10 currently active error messages.</li> <li>▪ <b>Event logbook</b> Contains the last 10 error messages (no longer active).</li> <li>▪ <b>Instrument info</b> Contains information for identifying the device.</li> <li>▪ <b>Measured values</b> Contains all the current measured values.</li> <li>▪ <b>Simulation</b> Is used to simulate pressure, level, current and alarm/warning.</li> <li>▪ <b>Enter reset code</b></li> </ul>
Expert	Expert	Contains all the parameters of the device (including those already in one of the other submenus). The "Expert" submenu is structured by the function blocks of the device. It thus contains the following submenus: <ul style="list-style-type: none"> <li>▪ <b>System</b> Contains all the device parameters that do not pertain either to the measurement or to integration into a control system.</li> <li>▪ <b>Measurement</b> Contains all the parameters for configuring the measurement.</li> <li>▪ <b>Output</b> Contains all the parameters for configuring the current output.</li> <li>▪ <b>Communication</b> Contains all the parameters for configuring the communication interface.</li> <li>▪ <b>Application</b> Contains all the parameters for configuring the functions that go beyond the actual measurement.</li> <li>▪ <b>Diagnosis</b> Contains all the parameters that are needed to detect and analyze operating errors.</li> </ul>

For an overview of the entire operating menu .

## 6.4 Operation with device display (optional)

A 4-line liquid crystal display (LCD) is used for display and operation. The local display shows measured values, dialog texts, fault messages and notice messages. For easy operation the display can be taken out of the housing (see figure steps 1 to 3). It is connected to the device via a 90 mm (3.54 in) long cable. The display of the device can be turned in 90°


stages (see figure steps 4 to 6). Depending on the installation position of the device, this makes it easy to operate the device and read the measured values.



A0028500

Functions:

- 8-digit measured value display incl. sign and decimal point, bar graph for 4 to 20 mA as current display.
- Three keys for operation.
- Easy and complete menu guidance by dividing the parameters into several levels and groups
- Each parameter is given a 3-digit parameter code for easy navigation.
- Comprehensive diagnostic functions (fault and warning message etc.).



A0030013

- 1 Main line
- 2 Value
- 3 Symbol
- 4 Unit
- 5 Bar graph
- 6 Information line
- 7 Operating keys

The following table illustrates the symbols that can appear on the local display. Four symbols may appear at the same time.

Symbol	Meaning
 A0018154	<b>Lock symbol</b> The operation of the device is locked. Unlock the device, →  41.
 A0018155	<b>Communication symbol</b> Data transfer via communication
 A0013958	<b>Error message "Out of specification"</b> The device is being operated outside its technical specifications (e.g. during startup or cleaning).
 A0013959	<b>Error message "Service mode"</b> The device is in the Service mode (e.g. during a simulation).
 A0013957	<b>Error message "Maintenance required"</b> Maintenance is required. The measured value remains valid.
 A0013956	<b>Error message "Failure detected"</b> An operating error has occurred. The measured value is no longer valid.

### 6.4.1 Operating keys on the display and operating module

Operating key(s)	Meaning
 A0017879	<ul style="list-style-type: none"> <li>▪ Navigate downwards in the picklist</li> <li>▪ Edit the numerical values and characters within a function</li> </ul>
 A0017880	<ul style="list-style-type: none"> <li>▪ Navigate upwards in the picklist</li> <li>▪ Edit the numerical values and characters within a function</li> </ul>
 A0017881	<ul style="list-style-type: none"> <li>▪ Confirm entry</li> <li>▪ Jump to the next item</li> <li>▪ Select a menu item and activate the edit mode</li> </ul>
 and  A0017879 and A0017881	Contrast setting of local display: darker
 and  A0017880 and A0017881	Contrast setting of local display: brighter
 and  A0017879 and A0017880	<b>ESC functions:</b> <ul style="list-style-type: none"> <li>▪ Exit edit mode for a parameter without saving the changed value</li> <li>▪ You are in a menu at a selection level. Each time you press the keys simultaneously, you go up a level in the menu.</li> </ul>

### 6.4.2 Operating example: Parameters with a picklist

Example: selecting "Deutsch" as the language of the menu.


	Language	000	Operation
1	✓ English Deutsch		"English" is set as the menu language (default value). A ✓ in front of the menu text indicates the option that is currently active.
2	Deutsch ✓ English		Select "Deutsch" with  or  .

	Language 000	Operation
3	<ul style="list-style-type: none"> <li>✓ Deutsch</li> <li>English</li> </ul>	<ul style="list-style-type: none"> <li>▪ Select  to confirm. A ✓ in front of the menu text indicates the active option ("Deutsch" is now selected as the menu language).</li> <li>▪ Use  to exit the edit mode for the parameter.</li> </ul>

### 6.4.3 Operating example: User-definable parameters

Example: Setting the "Set URV (014)" parameter from 100 mbar (1.5 psi) to 50 mbar (0.75 psi).

Menu path: Setup → Extended setup → Current output → Set URV

	Set URV 014	Operation
1	 mbar	The local display shows the parameter to be changed. The "mbar" unit is defined in another parameter and cannot be changed here.
2	 mbar	Press  or  to enter the edit mode. The first digit is highlighted in black.
3	 mbar	Use the  key to change "1" to "5". Press the  key to confirm "5". The cursor jumps to the next position (highlighted in black). Confirm "0" with  (second position).
4	 mbar	The third digit is highlighted in black and can now be edited.
5	 mbar	Use the  key to change to the "↵" symbol. Use  to save the new value and exit edit mode. See next graphic.
6	 mbar	The new value for the upper range value is 50 mbar (0.75 psi). Use  to exit the edit mode for the parameter. Use  or  to return to the edit mode.

### 6.4.4 Operating example: Accepting the pressure present

Example: Setting pos. zero adjustment.

Menu path: Main menu → Setup → Pos. zero adjust

	Pos. zero adjust 007	Operation
1	<ul style="list-style-type: none"> <li>✓ Cancel</li> <li>Confirm</li> </ul>	The pressure for pos. zero adjustment is present at the device.
2	<ul style="list-style-type: none"> <li>Cancel</li> <li>✓ Confirm</li> </ul>	Use  or  to switch to the "Confirm" option. The active option is highlighted in black.
3	Adjustment has been accepted!	Use the  key to accept the applied pressure as zero adjustment. The device confirms the adjustment and goes back to the "Pos. zero adjust" parameter.
4	<ul style="list-style-type: none"> <li>✓ Cancel</li> <li>Confirm</li> </ul>	Use  to exit the edit mode for the parameter.

## 6.5 Operation using Endress+Hauser operating program

The FieldCare operating program is an Endress+Hauser asset management tool based on FDT technology. With FieldCare, you can configure all Endress+Hauser devices as well as devices from other manufacturers that support the FDT standard.

Hardware and software requirements can be found on the Internet:

[www.de.endress.com](http://www.de.endress.com) → Search: FieldCare → FieldCare → Technical data.

### FieldCare supports the following functions:

- Configuration of transmitters in online/offline mode
- Documentation of the measuring point
- Offline parametrization of transmitters

### Connection options:

FieldPort SFP20

- i
  - The configuration data can be uploaded to the DTM with the upload function, modified in the DTM and then downloaded to the download (FDT upload/download).
  - More information about FieldCare is available on the Internet (<http://www.de.endress.com>, Download, → Search for: FieldCare).

## 6.6 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorized and undesired access.

Locked operation is indicated as follows:

- By the  symbol on the local display
- The parameters are grayed out in FieldCare and the handheld terminal, which means they cannot be edited. Information displayed in the " parameter.

Parameters which refer to how the display appears, e.g. "Language", can still be altered.

The "Operator code" parameter is used to lock and unlock the device.

---

### Operator code (021)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Use this function to enter a code to lock or unlock operation.
<b>User entry</b>	<ul style="list-style-type: none"> <li>▪ To lock: Enter a number ≠ the release code (value range: 1 to 9999).</li> <li>▪ To unlock: Enter the release code.</li> </ul>
<b>Note</b>	The release code is "0" in the order configuration. Another release code can be defined in the "Code definition" (023) parameter. If the user has forgotten the release code, the release code can be visible by entering the number "5864".
<b>Factory setting</b>	0

## 6.7 Resetting to factory settings (reset)

### Reset via the local display

By entering a certain code, you can completely, or partially, reset the entries for the parameters to the factory settings <sup>1)</sup>. Enter the code by means of the "Enter reset code" parameter (menu path: "Diagnosis" → "Reset" → "Enter reset code"). There are various reset codes for the device. The following table illustrates which parameters are reset by the particular reset codes. Operation must be unlocked to reset parameters → 41.

### Reset via IO-Link

- Reset to factory setting:  
System → Device Management → System Command → Restore Factory Setting
- Reset to factory setting as per IO-Link (switch device off and on):  
System → Device Management → System Command → Back-To-Box
- Device reset:  
System → Device Management → System Command → Device Reset

 Any customer-specific configuration carried out at the factory is not affected by a reset (customer-specific configuration remains). If you want to change the customer-specific configuration carried out at the factory, please contact Endress+Hauser Service. As no separate service level is provided, the order code and serial number may be changed without a specific unblocking code (e.g., after replacing the electronics).

Reset code <sup>1)</sup>	IO-Link command	Description and effect
62 (Device Reset)	296	<b>PowerUp reset (warm start)</b> <ul style="list-style-type: none"> <li>▪ The device is restarted</li> <li>▪ Data are read back from the EEPROM again (processor is initialized again)</li> <li>▪ Any simulation which may be running is ended</li> </ul>
7864 (Restore to Factory Settings)	297	<b>Total reset</b> <ul style="list-style-type: none"> <li>▪ This code resets all the parameters apart from: <ul style="list-style-type: none"> <li>▪ Operating hours (162)</li> <li>▪ Event logbook</li> <li>▪ Lo Trim sensor (131)</li> <li>▪ Hi Trim Sensor (132)</li> </ul> </li> <li>▪ Any simulation which may be running is ended</li> <li>▪ The device is restarted</li> </ul>
7864 (Back-To-Box)	131	<b>Total reset (IO-Link)</b> <ul style="list-style-type: none"> <li>▪ This code resets all the parameters apart from: <ul style="list-style-type: none"> <li>▪ Operating hours (162)</li> <li>▪ Event logbook</li> <li>▪ Lo Trim sensor (131)</li> <li>▪ Hi Trim Sensor (132)</li> </ul> </li> <li>▪ Any simulation which may be running is ended</li> <li>▪ Perform manual restart</li> </ul>

1) To be entered in "Diagnosis" → "Reset" → "Enter reset code" (124)

1) The factory setting for the individual parameters is specified in the parameter description .

## 7 System integration

### 7.1 Process data

The measuring device has a current output.

- In the IO-Link communication mode, pin 4 of the M12 plug is reserved exclusively for communication
- The current output at pin 2 of the M12 plug is always active and can be optionally deactivated via IO-Link
- The measuring device's process data are transmitted cyclically as per SSP 4.3.3

Sub-index	Bit-off-set	Data type	Permitted values	Name	Offset / gradient	Description
1	80	Float32	-	Pressure	mbar: 0 / 0.01 bar: 0 / 0.00001 mmH2O: 0 / 0.101973 mH2O: 0 / 0.000101973 ftH2O: 0 / 0.00033456 inH2O: 0 / 0.00401477 Pa: 0 / 1 kPa: 0 / 0.001 MPa: 0 / 0.000001 psi: 0 / 0.0001450326 mmHg: 0 / 0.0075006 inHg: 0 / 0.0002953 kgf / cm <sup>2</sup> : 0 / 0.0000101973	Current pressure
2	48	Float32	-	Level	-	Current level
3	16	Float32	-	Temperature	C: 0 / 0.01 F: +32 / 0.018 K: +273.15 / 0.01	Actual temperature
4	8	8-bit UInteger	<ul style="list-style-type: none"> <li>■ 36 = Error</li> <li>■ 60 = Function check</li> <li>■ 120 = Outside specifications</li> <li>■ 128 = Good</li> <li>■ 129 = Simulation</li> <li>■ 164 = Maintenance required</li> </ul>	Summary status	-	Summary status as per PI specification
5	6	2-bit UInteger	<ul style="list-style-type: none"> <li>■ 0 = Default setting</li> <li>■ 1 = Calibrated</li> </ul>	Level status	-	Current level status
6	0	6-bit UInteger	<ul style="list-style-type: none"> <li>■ 0 = SSCx OFF</li> <li>■ 1 = SSCx_ON</li> </ul>	Switching of the signal channel	-	Binary process data content that signals a certain status of the evaluation signal.

### 7.2 Reading out and writing device data (ISDU – Indexed Service Data Unit)

Device data are always exchanged acyclically and at the request of the IO-Link master. Using the device data, the following parameter values or device statuses can be read out:

### 7.2.1 Endress+Hauser-specific device data

ISDU (dec)	Designation	ISDU (hex)	Size (byte)	Data type	Access	Default value	Value range	Offset / gradient	Data storage	Range limits
36	Device status	0x0024	1	UInteger	r	-	0 ~ Device is OK 1 ~ Maintenance required 2 ~ Out of specification 3 ~ Functional check 4 ~ Failure	-	No	-
37	Detailed Device Status	0x0025	5 (per 1 byte)	OctetString	r	-	-	-	No	-
66	Sim. current	0x0042	4	Float32	r/w	0		-	No	3.6 - 23.0
67	Unit changeover	0x0043	1	UInteger	r/w	0 = mbar	0 ~ mbar 1 ~ bar 2 ~ mmH2O 3 ~ mH2O 4 ~ ftH2O 5 ~ inH2O 6 ~ Pa 7 ~ kPa 8 ~ MPa 9 ~ psi 10 ~ mmHg 11 ~ inHg 12 ~ kgf / cm <sup>2</sup>	-	Yes	-
68	Zero point configuration (ZRO)	0x0044	4	Float32	r/w	0	0 mbar	-	Yes	-
69	Zero point adoption (GTZ)	0x0045	1	unit	w	-	-	-	No	-
70	Damping (TAU)	0x0046	4	Float32	r/w	2 sec.	in 000.0 sec Default 2.0 sec	-	Yes	0.0 - 999.0
73	Pressure applied for 4mA (GTL)	0x0049	1	unit	w	-	-	-	No	-
74	Pressure applied for 20mA (GTU)	0x004A	1	unit	w	-	-	-	No	-
75	Alarm current (FCU)	0x004B	1	unit	r/w	MAX	0 ~ MIN 1 ~ MAX 2 ~ HOLD	-	Yes	0 - 2
76	Simulation mode	0x004C	1	UInteger	r/w	0 = OFF	0 ~ OFF 1 ~ Sim. Pressure 2 ~ Sim current 3 ~ Sim. Error no. 4 ~ Sim. Level	-	No	0 - 4
77	Measuring mode	0x004D	1	UInteger	r/w	0 = Pressure	0 ~ Pressure 1 ~ Level	-	Yes	0 - 1
78	Temp Unit changeover	0x004E	1	UInteger	r/w	0 = °C	0 ~ °C 1 ~ °F 2 ~ K	-	Yes	0 - 2

ISDU (dec)	Designation	ISDU (hex)	Size (byte)	Data type	Access	Default value	Value range	Offset / gradient	Data storage	Range limits
79	Unit before lin.	0x004F	1	UInteger	r/w	0 = %	0 ~ % 1 ~ mm 2 ~ cm 3 ~ m 4 ~ inch 5 ~ ft 6 ~ m <sup>3</sup> 7 ~ inch <sup>3</sup> 8 ~ ft <sup>3</sup> 9 ~ l 10 ~ hl 11 ~ kg 12 ~ t 13 ~ lb 14 ~ (US) gal 15 ~ (Imp) gal	-	Yes	0 - 15
80	Calibration mode	0x0050	1	UInteger	r/w	0 = Wet	0 ~ Wet 1 ~ Dry	-	No	0 - 1
81	Reset peakhold	0x0051	1	UInteger	w	-	-	-	No	-
82	Hi Max value (maximum indicator)	0x0052	4	Float32	r	-	-	-	No	-
83	Lo Min value (minimum indicator)	0x0053	4	Float32	r	-	-	-	No	-
84	Revisioncounter (RVC)	0x0054	2	UInteger16	r	-	-	-	No	-
94	Unlocking code	0x005E	2	UInteger	w	0000	-	-	Yes	-
256	Device Type	0x0100	2	UInteger16	r	Cerabar = 0x9219 Deltapilot = 0x9123	-	-	-	-
257	ENP_VERSION	0x0101	16	String	r	02.03.00	-	-	No	-
259	Extended order code	0x0103	60	String	r	-	-	-	No	-
262	Order code	0x0106	32	String	r	-	-	-	No	-
263	Electr. serial no	0x0107	16	String	r	-	-	-	No	-
264	Sensor serial no	0x0108	16	String	r	-	-	-	No	-
265	Sim. pressure	0x0109	4	Float32	r/w	0	-	-	No	-
266	Sim. level	0x010A	4	Float32	r/w	0	-	-	No	-
267	Sim. error no.	0x010B	2	UInteger	r/w	0	-	-	No	-
268	LRL sensor	0x010C	4	Float32	r	0	-	-	No	-
269	URL sensor	0x010D	4	Float32	r	0	-	-	No	-
270	Meas. Pressure	0x010E	4	Float32	r	0	-	-	No	-
271	Sensor pressure	0x010F	4	Float32	r	0	-	-	No	-
272	Corrected press.	0x0110	4	Float32	r	0	-	-	No	-
273	Pressure af.damp	0x0111	4	Float32	r	0	-	-	No	-
274	Empty calib.	0x0112	4	Float32	r/w	0	-	-	Yes	-
275	Empty pressure	0x0113	4	Float32	r/w	0	-	-	Yes	-
276	Empty pressure	0x0114	4	Float32	r	0	-	-	No	-
277	Full calib.	0x0115	4	Float32	r/w	100.0	-	-	Yes	-
278	Full pressure	0x0116	4	Float32	r/w	0	-	-	Yes	-
279	Full pressure	0x0117	4	Float32	r	0	-	-	No	-

ISDU (dec)	Designation	ISDU (hex)	Size (byte)	Data type	Access	Default value	Value range	Offset / gradient	Data storage	Range limits
280	Level before Lin	0x0118	4	Float32	r	0	-	-	No	-
283	Output current	0x011B	4	Float32	r	0	-	-	No	-
284	Sensor temperature	0x011C	4	Float32	r	0	-	-	No	-
285	Operating hours	0x011D	4	UInteger	r	0	-	-	No	-
286	Lower Trim measured value	0x011E	4	Float32	r	0	-	-	No	-
287	Upper Trim measured value	0x011F	4	Float32	r	0	-	-	No	-
288	Lower Sensor trim	0x0120	4	Float32	r/w	0	-	-	No	-
289	Upper Sensor trim	0x0121	4	Float32	r/w	0	-	-	No	-
291	Current Output	0x0123	1	UInteger	r/w	1 = ON	0 ~ OFF 1 ~ ON	-	Yes	0 - 1
292	Device search	0x0124	1	UInteger	r/w	0 = OFF	0 ~ OFF 1 ~ ON	-	No	0 - 1
293	Alarm behaviour for pressure	0x0125	1	UInteger	r/w	0 = Warning	0 ~ Warning 1 ~ Error 2 ~ NAMUR	-	No	0 - 2
16512	Pressure Descr. Lower limit	0x4080	4	Float32	r	0	-	-	No	-
16512	Pressure Descr. Upper limit	0x4080	4	Float32	r	0	-	-	No	-
16512	Pressure Descr. Unit	0x4080	2	UInteger	r	1137 (bar)	-	-	No	-
16512	Pressure Descr. Scale	0x4080	1	Integer	r	0	-	-	No	-
16513	Level Descr. Lower limit	0x4081	4	Float32	r	0	-	-	No	-
16513	Level Descr. Upper limit	0x4081	4	Float32	r	100.0	-	-	No	-
16513	Level Descr. Unit	0x4081	2	UInteger	r	1342 (%)	-	-	No	-
16513	Level Descr. Scale	0x4081	1	Integer	r	0	-	-	No	-
16514	Temperature Descr. Lower limit	0x4082	4	Float32	r	0	-	-	No	-
16514	Temperature Descr. Upper limit	0x4082	4	Float32	r	0	-	-	No	-
16514	Temperature Descr. Unit	0x4082	2	UInteger	r	1001 (°C)	-	-	No	-
16514	Temperature Descr. Scale	0x4082	1	Integer	r	0	-	-	No	-
71 294	Lower Range Value for 4 mA	0x0047 0x0126	4	Float32	r/w	0	-	-	Yes	-
71 295	Upper Range Value for 20 mA	0x0048 0x0127	4	Float32	r/w	100.0	-	-	Yes	-

## 7.2.2 IO-Link-specific device data

ISDU (dec)	Designation	ISDU (hex)	Size (byte)	Data type	Access	Default value	Data storage
7 ... 8	VendorId	0x0007 to 0x0008			r	17	No
9 to 11	DeviceID	0x0009 to 0x000B			r	Cerabar: 0x000800 Deltapilot: 0x000900	

ISDU (dec)	Designation	ISDU (hex)	Size (byte)	Data type	Access	Default value	Data storage
16	VendorName	0x0010	max. 64	String	r	Endress+Hauser	-
17	VendorText	0x0011	max. 64	String	r	People for Process Automation	-
18	ProductName	0x0012	max. 64	String	r	Cerabar Deltapilot	-
19	ProductID	0x0013	max. 64	String	r	PMx5x FMB50	-
20	ProductText	0x0014	max. 64	String	r	Absolute and gauge pressure	-
21	Serial number	0x0015	max. 16	String	r	-	-
22	Hardware revision	0x0016	max. 64	String	r	-	-
23	Firmware version	0x0017	max. 64	String	r	-	-
24	Application Specific Tag	0x0018	32	String	r/w	-	Yes
25	Function Tag	0x0019	32	String	r/w	***	-
26	Location Tag	0x001A	32	String	r/w	***	-
260	Actual Diagnostics (STA)	0x0104	4	String	r	-	No
261	Last Diagnostic (LST)	0x0105	4	String	r	-	No

### 7.2.3 System commands

ISDU (dec)	Designation	ISDU (hex)	Value range	Access
2	Reset to factory settings (RES)	0x0002	130	w
2	Device Reset	0x0002	128	w
2	Back-To-Box	0x0002	131	w

## 8 Commissioning

The device is configured for the "Pressure" measuring mode (Cerabar) or "Level" measuring mode (Deltapilot) as standard.

The measuring range and the unit in which the measured value is transmitted correspond to the data on the nameplate.

### **WARNING**

#### **The permitted process pressure is exceeded!**

Risk of injury if parts burst! Warnings are displayed if the pressure is too high.

- ▶ If a pressure smaller than the minimum permitted pressure or greater than the maximum permitted pressure is present at the device, the following messages are output in succession (depending on the setting in the "Alarm behavior" (050) parameter): "S140 Working range P" or "F140 Working range P" "S841 Sensor range" or "F841 Sensor range" "S971 Adjustment"
- ▶ Only operate the device within the sensor range limits!

### **NOTICE**

#### **The permitted process pressure is undershot!**

Messages are displayed if the pressure is too low.

- ▶ If a pressure smaller than the minimum permitted pressure or greater than the maximum permitted pressure is present at the device, the following messages are output in succession (depending on the setting in the "Alarm behavior" (050) parameter): "S140 Working range P" or "F140 Working range P" "S841 Sensor range" or "F841 Sensor range" "S971 Adjustment"
- ▶ Only operate the device within the sensor range limits!

### 8.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:

- "Post-installation check" checklist →  30
- "Post-connection check" checklist →  33

### 8.2 Unlocking/locking configuration

If the device is locked to prevent configuration, it must first be unlocked.

#### 8.2.1 Locking/unlocking software

If the device is locked via the software (device access code), the key symbol appears in the measured value display. If an attempt is made to write to a parameter, a prompt for the device access code appears. To unlock, enter the user-defined device access code.

## 8.3 Commissioning without an operating menu

### 8.3.1 Pressure measuring mode

The following functions are possible via the keys on the electronic insert:

- Position adjustment (zero point correction)
- Setting the lower range value and upper range value
- Device reset →  42
-  ▪ Operation must be unlocked →  41
- The device is configured for the "Pressure" measuring mode as standard. You can change the measuring mode via the "Measuring mode" parameter →  51.
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.

**⚠ WARNING**

**Changing the measuring mode affects the span (URV)!**

This can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified and, if necessary, reconfigured!

Perform position adjustment (see the information at the start of the "Commissioning" section)	
1	Pressure is present at the device.
2	Press the "Zero" and "Span" keys simultaneously for at least 3 s.
3	Does the LED on the electronic insert light up briefly?
4	Yes No
5	Applied pressure for position adjustment has been accepted. Applied pressure for position adjustment has not been accepted. Observe the input limits.

Setting the lower range value	
1	The desired pressure for the lower range value is present at the device.
2	Press the "Zero" key for at least 3 s.
3	Does the LED on the electronic insert light up briefly?
4	Yes No
5	Applied pressure for lower range value has been accepted. Applied pressure for lower range value has not been accepted. Observe the input limits.

Setting the upper range value	
1	The desired pressure for the upper range value is present at the device.
2	Press the "Span" key for at least 3 s.
3	Does the LED on the electronic insert light up briefly?
4	Yes No
5	Applied pressure for upper range value has been accepted. Applied pressure for upper range value has not been accepted. Observe the input limits.

### 8.3.2 Level measuring mode

The following functions are possible via the keys on the electronic insert:

- Position adjustment (zero point correction)
- Setting the lower and upper pressure value and assigning to the lower and upper level value
- Device reset →  42



■ The "Zero" and "Span" keys only have a function with the following setting: "Level selection" = "In pressure", "Calibration mode" = "Wet"  
In other settings, the keys do not have a function.

■ The device is configured for the "Pressure" measuring mode as standard. You can change the measuring mode via the "Measuring mode" parameter →  51.

The following parameters are set to the following values at the factory:

- "Level selection" = "In pressure"
- "Calibration mode": wet
- "Unit before lin": %
- "Empty calib.": 0.0
- "Full calib.": 100.0
- "Set LRV": 0.0 (corresponds to 4 mA value)
- "Set URV": 100.0 (corresponds to 20 mA value)
- Operation must be unlocked →  41.
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.

** WARNING**

**Changing the measuring mode affects the span (URV)!**

This can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified and, if necessary, reconfigured!

Perform position adjustment (see the information at the start of the "Commissioning" section)	
1	Pressure is present at the device.
2	Press the "Zero" and "Span" keys simultaneously for at least 3 s.
3	Does the LED on the electronic insert light up briefly?
4	Yes <span style="float: right;">No</span>
5	Applied pressure for position adjustment has been accepted. <span style="float: right;">Applied pressure for position adjustment has not been accepted. Observe the input limits.</span>

Setting lower pressure value	
1	Desired pressure for lower pressure value ("empty pressure") is present at device.
2	Press the "Zero" key for at least 3 s.
3	Does the LED on the electronic insert light up briefly?
4	Yes <span style="float: right;">No</span>
5	The pressure present was saved as the lower pressure value ("empty pressure") and assigned to the lower level value ("empty calibration"). <span style="float: right;">Applied pressure was not saved as the lower pressure value. Observe the input limits.</span>

Setting upper pressure value	
1	Desired pressure for upper pressure value ("full pressure") is present at device.
2	Press the "Span" key for at least 3 s.
3	Does the LED on the electronic insert light up briefly?

Setting upper pressure value		
4	Yes	No
5	The pressure present was saved as the upper pressure value ("full pressure") and assigned to the upper level value ("full calibration").	Applied pressure was not saved as the upper pressure value. Observe the input limits.

## 8.4 Commissioning with an operating menu

Commissioning comprises the following steps:

- Function check →  48
- Selection of the language, measuring mode and pressure unit →  51
- Position adjustment/zero adjustment →  52
- Configuring measurement:
  - Pressure measurement →  57
  - Level measurement →  53

### 8.4.1 Selecting the language, measuring mode and pressure unit

---

#### Language (000)

---

<b>Navigation</b>	  Main menu → Language
<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Select the menu language for the local display.
<b>Options</b>	<ul style="list-style-type: none"> <li>▪ English</li> <li>▪ Another language (as selected when ordering the device)</li> <li>▪ Possibly a third language (language of the manufacturing plant)</li> </ul>
<b>Factory setting</b>	English

---

#### Measuring mode (005)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	<p>Select the measuring mode. The operating menu is structured differently depending on the measuring mode selected.</p> <p> <b>WARNING</b></p> <p><b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow.</p> <ul style="list-style-type: none"> <li>▶ If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.</li> </ul>
<b>Selection</b>	<ul style="list-style-type: none"> <li>▪ Pressure</li> <li>▪ Level</li> </ul>
<b>Factory setting</b>	Pressure or according to order specifications

---

**Press. eng. unit (125)**


---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ mbar, bar</li> <li>■ mmH2O, mH2O</li> <li>■ inH2O, ftH2O</li> <li>■ Pa, kPa, MPa</li> <li>■ psi</li> <li>■ mmHg, inHg</li> <li>■ kgf/cm<sup>2</sup></li> </ul>
<b>Factory setting</b>	mbar or bar depending on the nominal measuring range of the sensor, or as per order specifications.

### 8.4.2 Pos. zero adjust

---

**Corrected press. (172)**


---

<b>Navigation</b>	  Setup → Corrected press.
<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Displays the measured pressure after sensor trim and position adjustment.
<b>Note</b>	If this value is not equal to "0", it can be corrected to "0" by the position adjustment.

---

**Pos. zero adjust (007) (gauge pressure sensors)**


---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Pos. zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.
<b>Example</b>	<ul style="list-style-type: none"> <li>■ Measured value = 2.2 mbar (0.033 psi)</li> <li>■ You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present.</li> <li>■ Measured value (after pos. zero adjustment) = 0.0 mbar</li> <li>■ The current value is also corrected.</li> </ul>
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ Confirm</li> <li>■ Cancel</li> </ul>
<b>Factory setting</b>	Cancel

**Pos. zero adjust (007) (gauge pressure sensors)**

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Pos. zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.
<b>Example</b>	<ul style="list-style-type: none"> <li>■ Measured value = 2.2 mbar (0.033 psi)</li> <li>■ You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present.</li> <li>■ Measured value (after pos. zero adjustment) = 0.0 mbar</li> <li>■ The current value is also corrected.</li> </ul>
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ Confirm</li> <li>■ Cancel</li> </ul>
<b>Factory setting</b>	Cancel

## 8.5 Configuring level measurement

### 8.5.1 Information on level measurement

-  The limit values are not checked, i.e. the values entered must suit the sensor and measuring task for the device to be able to measure correctly.
  - Customer-specific units are not possible.
  - There is no unit conversion.
  - The values entered for "Empty calib./Full calib.", "Empty pressure/Full pressure" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message displayed, if the values are too close together.

### 8.5.2 Overview of level measurement

Measuring task	Level selection	Measured variable options	Description	Measured value display
Calibration is performed by entering two pressure-level value pairs.	"In pressure"	Via the "Output unit" parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> <li>■ Calibration with reference pressure (wet calibration) → 53</li> <li>■ Calibration without reference pressure (dry calibration) → 55</li> </ul>	The measured value display shows the measured value.

### 8.5.3 "In pressure" level selection: Calibration with reference pressure (wet calibration)

**Example:**

In this example, the level in a tank should be measured in "m". The maximum level is 3 m (9.8 ft).


The pressure range is derived from the level and the density of the medium. In this case, the device sets the pressure range to 0 to 300 mbar (0 to 4.5 psi).

**Prerequisite:**


- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.

**i** The values entered for "Empty calib./Full calib." and "Set LRV/Set URV" and the applied pressures must be at least 1% apart. The value will be rejected, and a message displayed, if the values are too close together. Other limit values are not checked; i.e. the values entered must be suitable for the sensor and the measuring task so that the measuring device can measure correctly.


Description	
1	Perform a "position adjustment" → 52.
2	Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode  <b>WARNING</b> <b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow. ► If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.
3	Select a pressure unit via the "Press. eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select the "In pressure" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection.
5	Select a level unit via the "Unit output" parameter, e.g. here "m" for example. Menu path: Setup → Extended setup → Level → Unit output
6	Select the "Wet" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode
7	If the calibration is performed with a medium other than the process medium, enter the density of the calibration medium in the "Adjust density" parameter. Menu path: Setup → Extended setup → Level → Adjust density
8	The pressure for the lower calibration point is present at the device, here "0 mbar" for example.  Select the "Empty calib." parameter. Menu path: Setup → Extended setup → Level → Empty calib.  Enter the level value, here 0 m for example. By confirming the value, you assign the pressure value present to the lower level value.
9	The pressure for the upper calibration point is present at the device, here 300 mbar (4.35 psi) for example.  Select the "Full calib." parameter. Menu path: Setup → Extended setup → Level → Full calib.  Enter the level value, here 3 m (9.8 ft) for example. By confirming the value, you assign the pressure value present to the upper level value.
10	Use the "Set LRV" parameter to set the level value for the lower current value (4 mA), here "0 m" for example. Menu path: Setup → Extended setup → Current output → Set LRV
11	Use the "Set URV" parameter to set the level value for the upper current value (20 mA) (3 m (9.8 ft)). Menu path: Setup → Extended setup → Current output → Set URV



A See table, step 7.  
B See table, step 8.



A0017658



A See table, step 8.  
B See table, step 9.  
C See table, step 10.  
D See table, step 11.

A0031063

Description	
12	If the process uses a different medium to the medium on which the calibration was based, the new density must be specified in the "Process density" parameter. Menu path: Setup → Extended setup → Level → Process density.
13	Result: The measuring range is configured for 0 to 3 m (0 to 9.8 ft).

**i** In this level mode, you can choose from the measured variables %, level, volume and mass, see the "Unit output" → 78.

### 8.5.4 "In pressure" level selection: calibration without reference pressure (dry calibration)


**Example:**

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 l (264 gal) corresponds to a pressure of 450 mbar (6.75 psi).  
The minimum volume of 0 liters corresponds to a pressure of 50 mbar (0.75 psi) since the device is mounted below the start of the level measuring range.

**Prerequisite:**

- The measured variable is in direct proportion to the pressure.
  - This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.
- i**
- The values entered for "Empty calib./Full calib.", "Empty pressure/Full pressure" and "Set LRV/Set URV" must be at least 1% apart. The value will be rejected, and a message displayed, if the values are too close together. Other limit values are not checked; i.e. the values entered must be suitable for the sensor and the measuring task so that the measuring device can measure correctly.
  - Due to the orientation of the device, there may be pressure shifts in the measured value, i.e. when the vessel is empty or partly filled, the measured value is not zero. For information on how to perform position adjustment, see → 52.

Description	
1	Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode  <b>⚠ WARNING</b> <b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow. ▶ If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.
2	Select the "In pressure" level mode via the "Level selection" parameter. Menu path: Setup → Extended setup → Level → Level selection.
3	Select a pressure unit via the "Press. eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
4	Select a volume unit via the "Unit output" parameter, here "l" (liters) for example. Menu path: Setup → Extended setup → Level → Unit output
5	Select the "Dry" option via the "Calibration mode" parameter. Menu path: Setup → Extended setup → Level → Calibration mode



A See table, steps 6 and 7.

B See table, steps 8 and 9.

A0030030

Description	
6	Enter the volume value for the lower calibration point via the "Empty calib." parameter, here 0 liters for example. Menu path: Setup → Extended setup → Level → Empty calib.
7	Enter the pressure value for the lower calibration point via the "Empty pressure" parameter, here "50 mbar (0.75 psi)" for example. Menu path: Setup → Extended setup → Level → Empty pressure
8	Enter the volume value for the upper calibration point via the "Full calib." parameter, here 1000 l (264 gal) for example. Menu path: Setup → Extended setup → Level → Full calib.
9	Enter the pressure value for the upper calibration point via the "Full pressure" parameter, here 450 mbar (6.75 psi) for example. Menu path: Setup → Extended setup → Level → Full pressure
10	"Adjust density" contains the factory setting 1.0, but this value can be changed if required. The value pairs subsequently entered must correspond to this density. Menu path: Setup → Extended setup → Level → Adjust density
11	Set the volume value for the lower current value (4 mA) via the "Set LRV" parameter (0 l). Menu path: Setup → Extended setup → Current output → Set LRV
12	Set the volume value for the upper current value (20 mA) via the "Set URV" parameter (1000 l (264 gal)). Menu path: Setup → Extended setup → Current output → Set URV
13	If the process uses a different medium to the medium on which the calibration was based, the new density must be specified in the "Process density" parameter. Menu path: Setup → Extended setup → Current output → Process density.
14	Result: The measuring range is configured for 0 to 1000 l (0 to 264 gal).

A0031028

A0031064

A See table, step 6.  
 B See table, step 7.  
 C See table, step 8.  
 D See table, step 9.  
 E See table, step 11  
 F See table, step 12

In this level mode, you can choose from the measured variables %, level, volume and mass, see the "Unit output" → 78.

### 8.5.5 Calibration with partially filled vessel (wet calibration)

**Example:**

This example describes a wet calibration for situations in which it is not possible to empty the vessel and then fill it to 100%.

During this wet calibration, a level of 20% is used as the calibration point for "Empty" and a level of "25%" is used as the calibration point for "Full".

The calibration is then extended to 0% to 100% and the lower range value (LRV)/upper range value (URV) are adapted accordingly.

**Prerequisite:**

- The default value in level mode for the calibration mode is "Wet".
- This value can be configured: Menu path: Setup → Extended setup → Level → Calibration mode

Description	
<p>1 Select the "Level" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode</p> <p><b>⚠ WARNING</b> <b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow. ► If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.</p>	<p>A See table, step 2 B See table, step 3</p> <p style="text-align: right; font-size: small;">A0030031</p>
<p>2 Set the value for "Empty calib." with the differential pressure for the level, e.g. 20 % Menu path: Setup → Extended setup → Level → Empty calib.</p>	
<p>3 Set the value for "Full calib." with the differential pressure for the level, e.g. 25 % Menu path: Setup → Extended setup → Level → Full calib.</p>	
<p>4 The values for the pressure when the vessel is full or empty are measured automatically during adjustment. As the transmitter automatically sets the pressure values that are best suited for an "Empty calibration" and a "Full calibration" to the minimum and maximum pressure that triggers the output current, the correct upper range value (URV) and lower range value (LRV) must be set.</p>	

## 8.6 Configuring pressure measurement

### 8.6.1 Calibration without reference pressure (dry calibration)

**Example:**


In this example, a device with a 400 mbar (6 psi) sensor is configured for the 0 to +300 mbar (0 to 4.5 psi) measuring range, i.e. the 4 mA value and 20 mA value are assigned 0 mbar and 300 mbar (4.5 psi) respectively.

**Prerequisite:**

This is a theoretical calibration, i.e. the pressure values for the lower and upper range are known.

- i** Due to the orientation of the device, there may be pressure shifts in the measured value, i.e. the measured value is not zero in an unpressurized condition. For information on how to perform position adjustment, see → 52.

Description	
1	<p>Select the "Pressure" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode</p> <p><b>⚠ WARNING</b> <b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow. ► If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.</p>
2	Select a pressure unit via the "Press. eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
3	Select the "Set LRV" parameter. Menu path: Setup → Set LRV
	Enter the value for the "Set LRV" parameter (here 0 mbar) and confirm. This pressure value is assigned to the lower current value (4 mA).
4	Select the "Set URV" parameter. Menu path: Setup → Set URV
	Enter the value for the "Set URV" parameter (here 300 mbar (4.5 psi)) and confirm. This pressure value is assigned to the upper current value (20 mA).
5	Result: The measuring range is configured for 0 to +300 mbar (0 to 4.5 psi).



A0031032

A See table, step 3.

B See table, step 4.

### 8.6.2 Calibration with reference pressure (wet calibration)

**Example:**


In this example, a device with a 400 mbar (6 psi) sensor module is configured for the 0 to +300 mbar (0 to 4.5 psi) measuring range, i.e. the 4 mA value and 20 mA value are assigned 0 mbar and 300 mbar (4.5 psi) respectively.

**Prerequisite:**

The pressure values 0 mbar and 300 mbar (4.5 psi) can be specified. For example, the device is already installed.

 For a description of the parameters mentioned, see .

Description	
1	Perform a position adjustment →  52.
2	Select the "Pressure" measuring mode via the "Measuring mode" parameter. Menu path: Setup → Measuring mode  <div style="border: 1px solid black; padding: 2px; width: fit-content;"> <b>WARNING</b> </div> <b>Changing the measuring mode affects the span (URV)</b> This situation can result in product overflow. <ul style="list-style-type: none"> <li>▶ If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.</li> </ul>
3	Select a pressure unit via the "Press. eng. unit" parameter, here "mbar" for example. Menu path: Setup → Press. eng. unit
4	The pressure for the LRV (4 mA value) is present at the device, here 0 mbar for example
	Select the "Get LRV" parameter. Menu path: Setup → Extended setup → Current output → Get LRV
	Confirm the value present at the device by selecting "Apply". The pressure value present at the device is assigned to the lower current value (4 mA).
5	The pressure for the URV (20 mA value) is present at the device, here 300 mbar (4.5 psi) for example.
	Select the "Get URV" parameter. Menu path: Setup → Extended setup → Current output → Get URV
	Confirm the value present at the device by selecting "Apply". The pressure value present at the device is assigned to the upper current value (20 mA).
6	Result: The measuring range is configured for 0 to +300 mbar (0 to 4.5 psi).



A See table, step 4.  
B See table, step 5.

A0031032

### 8.7 Backing up or duplicating the device data


The device does not have a memory module. However, with an FDT technology-based operating tool (e.g. FieldCare) you can do the following:

- Save/recover configuration data
- Duplicate device configurations
- Transfer all relevant parameters when replacing electronic inserts
- The mechanism is based on IO-Link Data Storage

For more information, read the operating manual for the FieldCare operating program.

## 9 Maintenance

, keep the pressure compensation and GORE-TEX® filter (1) free from dirt.



A0028502

### 9.1 Information on cleaning

Endress+Hauser provides flushing rings as an accessory to enable cleaning of the process membrane without removing the transmitter from the process.

For further information please contact your local Endress+Hauser Sales Center.

#### 9.1.1 Cerabar M PMP55

We recommend you perform CIP (cleaning in place (hot water)) before SIP (sterilization in place (steam)) for pipe diaphragm seals. Frequent use of SIP cleaning increases the stress and strain on the process membrane. Under unfavorable conditions, frequent changes of temperature can lead to process membrane material fatigue and potentially leaks over the long term.

### 9.2 Exterior cleaning

**Please note the following points when cleaning the device:**

- The cleaning agents used should not corrode the surface and the seals.
- Mechanical damage to the process membrane, e.g. due to sharp objects, must be avoided.
- Observe the degree of protection of the device. See the nameplate if necessary →  12.

# 10 Diagnostics and troubleshooting

## 10.1 Diagnostic events

### 10.1.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.

#### Status signals


The messages that can occur are listed in the table. The ALARM STATUS parameter shows the message with the highest priority. The device has four different status information codes according to NE107:

<b>F</b> <small>A0013956</small>	<b>"Failure"</b> A device error has occurred. The measured value is no longer valid.
<b>M</b> <small>A0013957</small>	<b>"Maintenance required"</b> Maintenance is required. The measured value remains valid.
<b>C</b> <small>A0013959</small>	<b>"Function check"</b> The device is in service mode (e.g. during a simulation).
<b>S</b> <small>A0013958</small>	<b>"Out of specification"</b> The device is being operated: <ul style="list-style-type: none"> <li>▪ Outside of its technical specifications (e.g. during startup or a cleaning)</li> <li>▪ Outside of the configuration performed by the user (e.g. level outside configured span)</li> </ul>

#### Diagnostic event and event text

The fault can be identified by means of the diagnostic event.

The event text helps you by providing information about the fault.



If two or more diagnostic events are queued simultaneously, only the diagnostic message with the highest priority is displayed.

Other diagnostic messages that are queued can be viewed in the **Diagnostic list** submenu.

Past diagnostic messages that are no longer queued are shown in the **Event logbook** submenu.

## 10.1.2 List of diagnostic events

### "C" messages

Diagnostic event		Cause	Remedial measure
Code	Description		
C482	Simul. output	Simulation of the current output is switched on, i.e. the device is not measuring at present.	End the simulation
C484	Error simul.	Fault state simulation is switched on, i.e. the device is not measuring at present.	End the simulation
C485	Measure simul.	Simulation is switched on, i.e. the device is not measuring at present.	End the simulation
C824	Process pressure	<ul style="list-style-type: none"> <li>▪ Overpressure or low pressure present.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the pressure value</li> <li>▪ Restart the device</li> <li>▪ Perform a reset</li> </ul>

### "F" messages

Diagnostic event		Cause	Remedial measure
Code	Description		
F002	Sens. unknown	Sensor does not suit the device (electronic sensor nameplate).	Contact Endress+Hauser Service
F062	Sensor conn.	<ul style="list-style-type: none"> <li>▪ Cable connection between sensor and main electronics disconnected.</li> <li>▪ Sensor defective.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the sensor cable</li> <li>▪ Replace the electronics module</li> <li>▪ Contact Endress+Hauser Service</li> <li>▪ Replace the sensor (snap-on version)</li> </ul>
F081	Initialization	<ul style="list-style-type: none"> <li>▪ Cable connection between sensor and main electronics disconnected.</li> <li>▪ Sensor defective.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Perform a reset</li> <li>▪ Check the sensor cable</li> <li>▪ Contact Endress+Hauser Service</li> </ul>
F083	Memory content	<ul style="list-style-type: none"> <li>▪ Sensor defective.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Restart the device</li> <li>▪ Contact Endress+Hauser Service</li> </ul>
F140	Working range P	<ul style="list-style-type: none"> <li>▪ Overpressure or low pressure present.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly.</li> <li>▪ Sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the process pressure</li> <li>▪ Check the sensor range</li> </ul>
F261	Electronics module	<ul style="list-style-type: none"> <li>▪ Main electronics defective.</li> <li>▪ Fault in the main electronics.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Restart the device</li> <li>▪ Replace the electronics module</li> </ul>
F282	Memory	<ul style="list-style-type: none"> <li>▪ Fault in the main electronics.</li> <li>▪ Main electronics defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Restart the device</li> <li>▪ Replace the electronics module</li> </ul>
F283	Memory content	<ul style="list-style-type: none"> <li>▪ Main electronics defective.</li> <li>▪ Electromagnetic effects are greater than the specifications in the technical data.</li> <li>▪ The supply voltage is disconnected when writing.</li> <li>▪ An error occurred when writing.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Perform a reset</li> <li>▪ Replace the electronics module</li> </ul>
F419	Current cycle	The Back-To-Box command is executed.	Restart the device
F841	Sensor range	<ul style="list-style-type: none"> <li>▪ Overpressure or low pressure present.</li> <li>▪ Sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the pressure value</li> <li>▪ Contact Endress+Hauser Service</li> </ul>

### "M" messages

Diagnostic event		Cause	Remedial measure
Code	Description		
M002	Sens. unknown	Sensor does not suit the device (electronic sensor nameplate). Device continues measuring.	Contact Endress+Hauser Service
M283	Memory content	<ul style="list-style-type: none"> <li>▪ Cause as indicated for F283.</li> <li>▪ Correct measurement can continue as long as you do not need the peakhold indicator function.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Perform a reset</li> <li>▪ Replace the electronics module</li> </ul>

Diagnostic event		Cause	Remedial measure
Code	Description		
M431	Calibration	The calibration performed would cause the nominal sensor range to be exceeded or undershot.	<ul style="list-style-type: none"> <li>▪ Check the measuring range</li> <li>▪ Check the position adjustment</li> <li>▪ Check the setting</li> </ul>
M434	Scaling	<ul style="list-style-type: none"> <li>▪ Values for calibration (e.g. lower range value and upper range value) are too close together.</li> <li>▪ Lower range value and/or upper range value exceed or fall below the sensor range limits.</li> <li>▪ The sensor was replaced and the customer-specific configuration does not suit the sensor.</li> <li>▪ Unsuitable download carried out.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the measuring range</li> <li>▪ Check the setting</li> <li>▪ Contact Endress+Hauser Service</li> </ul>
M438	Data record	<ul style="list-style-type: none"> <li>▪ The supply voltage is disconnected when writing.</li> <li>▪ An error occurred when writing.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the setting</li> <li>▪ Restart the device</li> <li>▪ Replace the electronics module</li> </ul>
M803	Current loop	Impedance of the load resistor at the analog output is too high	<ul style="list-style-type: none"> <li>▪ Check the wiring and the load at the current output</li> <li>▪ If the current output is not required, switch it off via the configuration</li> <li>▪ Connect the current output to the load</li> </ul>

*"S" messages*

Diagnostic event		Cause	Remedial measure
Code	Description		
S110	Working range T	<ul style="list-style-type: none"> <li>▪ Excess temperature or low temperature present.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data.</li> <li>▪ Sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the process temperature</li> <li>▪ Check the temperature range</li> </ul>
S140	Working range P	<ul style="list-style-type: none"> <li>▪ Overpressure or negative pressure present.</li> <li>▪ Electromagnetic effects are greater than specifications in the technical data.</li> <li>▪ Sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the process pressure</li> <li>▪ Check the sensor range</li> </ul>
S822	Process temp.	<ul style="list-style-type: none"> <li>▪ The temperature measured in the sensor is greater than the upper nominal temperature of the sensor.</li> <li>▪ The temperature measured in the sensor is lower than the lower nominal temperature of the sensor.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the temperature</li> <li>▪ Check the setting</li> </ul>
S841	Sensor range	<ul style="list-style-type: none"> <li>▪ Overpressure or low pressure present.</li> <li>▪ Sensor defective.</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the pressure value</li> <li>▪ Contact Endress+Hauser Service</li> </ul>
S971	Calibration	<ul style="list-style-type: none"> <li>▪ The current is outside the permitted range from 3.8 to 20.5 mA.</li> <li>▪ The present pressure value is outside the configured measuring range (but may be within the sensor range).</li> </ul>	<ul style="list-style-type: none"> <li>▪ Check the pressure value</li> <li>▪ Check the measuring range</li> <li>▪ Check the setting</li> </ul>

## 10.2 Behavior of the current output in the event of an error

The response of the current output to errors is defined by the following parameters:

---

### Output fail mode (051)/(190)

---

<b>Navigation</b>	 Setup → Extended setup → Current output → Output fail mode (051)/(190) Expert → Output → Current output → Output fail mode (051)/(190)
<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Select Output fail mode. In the event of an alarm, the current and the bar graph assume the current value specified with this parameter.
<b>Selection</b>	<ul style="list-style-type: none"> <li>▪ Max. alarm: can be set from 21 to 23 mA</li> <li>▪ Hold measured value: last measured value is held.</li> <li>▪ Min: 3.6 mA</li> </ul>
<b>Factory setting</b>	Max. alarm (22 mA)

## 10.3 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorized and undesired access.

Locked operation is indicated as follows:

- By the  symbol on the local display
- The parameters are grayed out in FieldCare and the handheld terminal, which means they cannot be edited. Information displayed in the " parameter.

Parameters which refer to how the display appears, e.g. "Language", can still be altered.

The "Operator code" parameter is used to lock and unlock the device.

---

### Operator code (021)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Use this function to enter a code to lock or unlock operation.
<b>User entry</b>	<ul style="list-style-type: none"> <li>▪ To lock: Enter a number ≠ the release code (value range: 1 to 9999).</li> <li>▪ To unlock: Enter the release code.</li> </ul>
<b>Note</b>	The release code is "0" in the order configuration. Another release code can be defined in the "Code definition" (023) parameter. If the user has forgotten the release code, the release code can be visible by entering the number "5864".
<b>Factory setting</b>	0

## 10.4 Resetting to factory settings (reset)

### Reset via the local display

By entering a certain code, you can completely, or partially, reset the entries for the parameters to the factory settings<sup>2)</sup>. Enter the code by means of the "Enter reset code" parameter (menu path: "Diagnosis" → "Reset" → "Enter reset code"). There are various reset codes for the device. The following table illustrates which parameters are reset by the particular reset codes. Operation must be unlocked to reset parameters → 41.

### Reset via IO-Link

- Reset to factory setting:  
System → Device Management → System Command → Restore Factory Setting
- Reset to factory setting as per IO-Link (switch device off and on):  
System → Device Management → System Command → Back-To-Box
- Device reset:  
System → Device Management → System Command → Device Reset

 Any customer-specific configuration carried out at the factory is not affected by a reset (customer-specific configuration remains). If you want to change the customer-specific configuration carried out at the factory, please contact Endress+Hauser Service. As no separate service level is provided, the order code and serial number may be changed without a specific unblocking code (e.g., after replacing the electronics).

Reset code <sup>1)</sup>	IO-Link command	Description and effect
62 (Device Reset)	296	<b>PowerUp reset (warm start)</b> <ul style="list-style-type: none"> <li>■ The device is restarted</li> <li>■ Data are read back from the EEPROM again (processor is initialized again)</li> <li>■ Any simulation which may be running is ended</li> </ul>
7864 (Restore to Factory Settings)	297	<b>Total reset</b> <ul style="list-style-type: none"> <li>■ This code resets all the parameters apart from:                             <ul style="list-style-type: none"> <li>■ Operating hours (162)</li> <li>■ Event logbook</li> <li>■ Lo Trim sensor (131)</li> <li>■ Hi Trim Sensor (132)</li> </ul> </li> <li>■ Any simulation which may be running is ended</li> <li>■ The device is restarted</li> </ul>
7864 (Back-To-Box)	131	<b>Total reset (IO-Link)</b> <ul style="list-style-type: none"> <li>■ This code resets all the parameters apart from:                             <ul style="list-style-type: none"> <li>■ Operating hours (162)</li> <li>■ Event logbook</li> <li>■ Lo Trim sensor (131)</li> <li>■ Hi Trim Sensor (132)</li> </ul> </li> <li>■ Any simulation which may be running is ended</li> <li>■ Perform manual restart</li> </ul>

1) To be entered in "Diagnosis" → "Reset" → "Enter reset code" (124)

## 10.5 Software history

Device	Date	Software version	Software modifications	Operating Instructions
Cerabar	xx.2021	01.00.zz	Original software. Compatible with: FieldCare from version xx.xx.xx and higher	BA02136P

2) The factory setting for the individual parameters is specified in the parameter description .

Device	Date	Software version	Software modifications	Operating Instructions
Deltapilot	xx.2021	01.00.zz	Original software. Compatible with: FieldCare from version xx.xx.xx and higher	BA02136P

# 11 Repair

## 11.1 General information

### 11.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs are carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

### 11.1.2 Repair of Ex-certified devices

#### **WARNING**

#### **Incorrect repairs can reduce electrical safety!**

Explosion Hazard!

- ▶ Only specialist personnel or Endress+Hauser-Service can carry out repairs to Ex certified devices.
- ▶ Relevant standards and national regulations as well as safety instructions (XA) and certificates must be observed.
- ▶ Only original Endress+Hauser spare parts may be used.
- ▶ When ordering spare parts, please check the device designation on the nameplate. Parts may only be replaced by identical parts.
- ▶ Carry out repairs according to the instructions. Following the repair, the individual testing specified for the device must be carried out.
- ▶ A certified device may be converted to another certified device version by Endress+Hauser Service only.
- ▶ All repairs and modifications must be documented.

## 11.2 Spare parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- All the spare parts available for the measuring device are listed in the *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)) along with the order code and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Located on the device and spare part nameplate.
- Can be read out via the "Serial number" parameter in the "Instrument info" submenu.

## 11.3 Return

The measuring device must be returned in the event of a factory calibration, or if the wrong device has been ordered or delivered.

As an ISO-certified company and due to legal requirements,

Endress+Hauser is required to follow certain procedures when handling returned products that have been in contact with a medium. To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at [www.services.endress.com/return-material](http://www.services.endress.com/return-material)

▶ Select country.

↳ The web site of the sales organization responsible for your area opens with all of the relevant information relating to returns.

1. If the desired country is not listed:

Click on the "Choose your location" link.

↳ An overview of Endress+Hauser sales organizations and representatives opens.

2. Contact your Endress+Hauser sales office or representative.

## 11.4 Disposal

When disposing, separate and recycle the device components based on the materials.

## 12 Overview of the operating menu

			Direct access	Description
Parameters in italics cannot be edited (read only parameters). The settings, such as the measuring mode, dry or wet calibration or hardware locking, determine whether these parameters are displayed.				
<b>Expert</b>	<b>System</b>	Operator code	021	→ ⓘ 41
		<b>Instrument info</b>		
		Device tag	022	→ ⓘ 71
		Serial number	096	→ ⓘ 71
		Firmware version	095	→ ⓘ 71
		Ext. order code	097	→ ⓘ 72
		Order code	098	→ ⓘ 72
		ENP version	099	→ ⓘ 72
		Electr. serial no.	121	→ ⓘ 72
		Sensor serial no.	122	→ ⓘ 72
		<b>Display</b>		
		Language	000	→ ⓘ 51
		Format 1st value	004	→ ⓘ 73
		<b>Management</b>		
		Enter reset code	124	→ ⓘ 73
	<b>Measurement</b>	Measuring mode	005	→ ⓘ 51
		<b>Basic setup</b>		
		Pos. zero adjust (gauge pressure sensors)	007	→ ⓘ 52
		Calib. offset (absolute pressure sensors)	008	→ ⓘ 74
		Damping value	017	→ ⓘ 75
		Press. eng. unit	125	→ ⓘ 52
		Temp. eng. unit	126	→ ⓘ 75
		Sensor temp.	110	→ ⓘ 51
		<b>Pressure</b>		
		Set LRV	013	→ ⓘ 76
		Set URV	014	→ ⓘ 76
		Meas. pressure	020	→ ⓘ 76
		Sensor pressure	109	→ ⓘ 77
		Corrected pressure	172	→ ⓘ 52
		Pressure af. damp	111	→ ⓘ 77
		<b>Level</b>		
		Unit before lin	025	→ ⓘ 78
		Calibration mode	027	→ ⓘ 78
		Empty calib.	028	→ ⓘ 78
		Empty pressure	029	→ ⓘ 79
		Empty pressure (read only)	185	
		Full calib.	031	→ ⓘ 79
		Full pressure	032	→ ⓘ 79
		Full pressure (read only)	187	
		Level before Lin.	019	→ ⓘ 80
		<b>Sensor limits</b>		
		LRL sensor	101	→ ⓘ 80
		URL sensor	102	→ ⓘ 80
		<b>Sensor trim</b>		
		Lo trim measured	129	→ ⓘ 80
		Hi trim measured	130	→ ⓘ 80
		Lo trim sensor	131	→ ⓘ 81

		Direct access	Description
		Hi trim sensor	132 → 81
<b>Output</b>	<b>Current output</b>	Output current (read only)	054 → 81
		Output fail mode	190 → 81
		Get LRV (only "Pressure")	015 → 81
		Set LRV	013 168 → 82
		Get URV (only "Pressure")	016 → 82
		Set URV	014 169 → 82
		<b>Communication</b>	Manufacturer ID
Device type code	104 → 84		
<b>Diagnosis</b>	Diagnostic code	071 → 84	
	Last diag. code	072 → 84	
	Min. meas. press.	073 → 84	
	Max. meas. press.	074 → 85	
	Reset peakhold	161 → 85	
	Operating hours	162 → 85	
	Config. counter	100 → 85	
	<b>Diagnostic list</b>	Diagnostic 1	075 → 86
		Diagnostic 2	076 → 86
		Diagnostic 3	077 → 86
		Diagnostic 4	078 → 86
		Diagnostic 5	079 → 86
		Diagnostic 6	080 → 86
		Diagnostic 7	081 → 86
		Diagnostic 8	082 → 86
		Diagnostic 9	083 → 86
		Diagnostic 10	084 → 86
	<b>Event logbook</b>	Last diag. 1	085 → 86
		Last diag. 2	086 → 86
		Last diag. 3	087 → 86
		Last diag. 4	088 → 86
Last diag. 5		089 → 86	
Last diag. 6		090 → 86	
Last diag. 7		091 → 86	
Last diag. 8		092 → 86	
Last diag. 9		093 → 86	
Last diag. 10		094 → 86	
<b>Simulation</b>	Simulation mode	112 → 86	
	Sim. pressure	113 → 87	
	Sim. level	115 → 87	
	Sim. current	117 → 87	
	Sim. error no.	118 → 87	

## 13 Description of device parameters

 This section describes the parameters in the order they are arranged in the "Expert" operating menu.

### 13.1 Expert → System

---

#### Operator code (021)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Use this function to enter a code to lock or unlock operation.
<b>User entry</b>	<ul style="list-style-type: none"> <li>■ To lock: Enter a number ≠ the release code (value range: 1 to 9999).</li> <li>■ To unlock: Enter the release code.</li> </ul>
<b>Note</b>	The release code is "0" in the order configuration. Another release code can be defined in the "Code definition" (023) parameter. If the user has forgotten the release code, the release code can be visible by entering the number "5864".
<b>Factory setting</b>	0

### 13.2 Expert → System → Instrument info

---

#### Device tag (022)

---

<b>Navigation</b>	  Setup → Extended setup → Device tag
<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Enter the device tag, e.g. TAG number (max. 32 alphanumeric characters).

---

#### Serial number (096)

---

<b>Write permission</b>	Parameter is read only. Only Endress+Hauser Service has write permission.
<b>Description</b>	Displays the serial number of the device (11 alphanumeric characters).

---

#### Firmware version (095)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
-------------------------	---

---

**Description** Displays the firmware version.

---

**Ext. order code (097)**

---

**Write permission** Parameter is read only. Only Endress+Hauser Service has write permission.

**Description** Displays extended order number.

**Factory setting** According to order specifications

---

**Order code (098)**

---

**Navigation**  Diagnosis → Instrument info → Order code

**Write access** Parameter is read only. Only Endress+Hauser Service has write permission.

**Description** Displays the order identifier.

**Factory setting** According to order specifications

---

**ENP version (099)**

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the ENP version  
(ENP = electronic nameplate)

---

**Electr.serial no (121)**

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the serial number of the main electronics (11 alphanumeric characters).

---

**Ser.no. sensor (122)**

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the serial number of the sensor (11 alphanumeric characters).

### 13.3 Expert → System → Display

---

#### Language (000)

---

<b>Navigation</b>	  Main menu → Language
<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Select the menu language for the local display.
<b>Options</b>	<ul style="list-style-type: none"> <li>▪ English</li> <li>▪ Another language (as selected when ordering the device)</li> <li>▪ Possibly a third language (language of the manufacturing plant)</li> </ul>
<b>Factory setting</b>	English

---

#### Format 1st value (004)

---

<b>Navigation</b>	  Display/operat. → Format 1st value (004)
<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Specify the number of places after the decimal point for the value displayed in the main line.
<b>Options</b>	<ul style="list-style-type: none"> <li>▪ Auto</li> <li>▪ x</li> <li>▪ x.x</li> <li>▪ x.xx</li> <li>▪ x.xxx</li> <li>▪ x.xxxx</li> <li>▪ x.xxxxx</li> </ul>
<b>Factory setting</b>	Auto

### 13.4 Expert → System → Management

---

#### Enter reset code (124)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Reset parameters completely or partially to the factory values or order configuration by entering a reset code, "Resetting to factory settings (reset)". →  42.

Factory setting: 0

## 13.5 Expert → Measurement

---

### Measuring mode (005)

---

Write permission Operator/Maintenance/Expert

Description Select the measuring mode.  
The operating menu is structured differently depending on the measuring mode selected.

**⚠ WARNING**

**Changing the measuring mode affects the span (URV)**

This situation can result in product overflow.

- ▶ If the measuring mode is changed, the setting for the span (URV) must be checked in the "Setup" operating menu and readjusted if necessary.

Selection

- Pressure
- Level

Factory setting Pressure or according to order specifications

## 13.6 Expert → Measurement → Basic setup

---

### Pos. zero adjust (007) (gauge pressure sensors)

---

Write permission Operator/Maintenance/Expert

Description Pos. zero adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.

Example

- Measured value = 2.2 mbar (0.033 psi)
- You correct the measured value via the "Pos. zero adjust" parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present.
- Measured value (after pos. zero adjustment) = 0.0 mbar
- The current value is also corrected.

Selection

- Confirm
- Cancel

Factory setting Cancel

---

### Calib. offset (008) (absolute pressure sensors)

---

<b>Write permission</b>	Maintenance/Expert
<b>Description</b>	Position adjustment – the pressure difference between the set point and the measured pressure must be known.
<b>Example</b>	<ul style="list-style-type: none"> <li>■ Measured value = 982.2 mbar (14.73 psi)</li> <li>■ You correct the measured value with the value entered, e.g. 2.2 mbar (0.033 psi) via the "Calib. offset" parameter. This means that you are assigning the value to the pressure present 980.0 mbar (14.7 psi).</li> <li>■ Measured value (after pos. zero adjustment) = 980.0 mbar (14.7 psi)</li> <li>■ The current value is also corrected.</li> </ul>
<b>Factory setting</b>	0.0

---

#### Damping value (017)

---

<b>Write permission</b>	Operators/Service engineers/Expert (if the "Damping" DIP switch is set to "on")
<b>Description</b>	Enter the damping time (time constant $\tau$ ). The damping affects the speed at which the measured value reacts to changes in pressure.
<b>Input range</b>	0,0...999,0 s
<b>Factory setting</b>	2.0 or as per order specifications

---

#### Press. eng. unit (125)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ mbar, bar</li> <li>■ mmH<sub>2</sub>O, mH<sub>2</sub>O</li> <li>■ inH<sub>2</sub>O, ftH<sub>2</sub>O</li> <li>■ Pa, kPa, MPa</li> <li>■ psi</li> <li>■ mmHg, inHg</li> <li>■ kgf/cm<sup>2</sup></li> </ul>
<b>Factory setting</b>	mbar or bar depending on the nominal measuring range of the sensor, or as per order specifications.

---

#### Temp. eng. unit (126)

---

<b>Write permission</b>	Maintenance/Expert
<b>Description</b>	Select the unit for the temperature measured values.
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ °C</li> <li>■ °F</li> <li>■ K</li> </ul>
<b>Note</b>	The setting affects the unit for the "Sensor temp." parameter.
<b>Factory setting</b>	°C

---

#### Sensor temp. (110)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the temperature currently measured in the sensor. This can deviate from the process temperature.

## 13.7 Expert → Measurement → Pressure

---

#### Set LRV (013)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Set the lower-range value – without reference pressure. Enter the pressure value for the lower current value (4 mA).
<b>Factory setting</b>	0.0 or as per order specifications

---

#### Set URV (014)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Set the upper-range value – without reference pressure. Enter the pressure value for the upper current value (20 mA).
<b>Factory setting</b>	Upper range limit or as per order specifications

---

#### Meas. pressure (020)

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the measured pressure after sensor recalibration, position adjustment and damping.

---

#### Sensor pressure (109)

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the measured pressure before the sensor trim and position adjustment.

---

#### Corrected press. (172)

---

**Navigation**   Setup → Corrected press.

**Write permission** Operators/Service engineers/Expert

**Description** Displays the measured pressure after sensor trim and position adjustment.

**Note** If this value is not equal to "0", it can be corrected to "0" by the position adjustment.

---

#### Pressure af. damp (111)

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the measured pressure after sensor trim, position adjustment and damping.

## 13.8 Expert → Measurement → Level

---

### Unit before lin. (025)

---

<b>Description</b>	Select the unit for the measured value display for the level .
<b>Note</b>	The purpose of the selected unit is to describe the measured value only, i.e., the measured value is not converted if a new output unit is selected.
<b>Example</b>	<ul style="list-style-type: none"> <li>■ Current measured value: 0.3 ft</li> <li>■ New output unit: m</li> <li>■ New measured value: 0.3 m</li> </ul>
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ %</li> <li>■ mm, cm, m</li> <li>■ ft, inch</li> <li>■ m<sup>3</sup>, in<sup>3</sup></li> <li>■ l, hl</li> <li>■ ft<sup>3</sup></li> <li>■ gal, lgal</li> <li>■ kg, t</li> <li>■ lb</li> </ul>
<b>Factory setting</b>	%

---

### Calibration mode (027)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Select the calibration mode.
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ Wet Wet calibration is performed by filling and emptying the vessel. In the event of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time ("Empty calib." and "Full calib." parameters).</li> <li>■ Dry Dry calibration is a theoretical calibration. For this calibration, you specify two pressure/level value pairs via the following parameters: "Empty calib.", "Empty pressure", "Full calib.", "Full pressure".</li> </ul>
<b>Factory setting</b>	Wet

---

### Empty calib. (028)

---

<b>Write permission</b>	Operator/Maintenance/Expert
-------------------------	-----------------------------

<b>Description</b>	Enter the output value for the lower calibration point (vessel empty). The unit defined in "Output unit" must be used.
<b>Note</b>	<ul style="list-style-type: none"> <li>■ In the case of wet calibration, the level (e.g. vessel empty or partially filled) must actually be available. The associated pressure is then automatically recorded by the device.</li> <li>■ In the case of dry calibration, the level (vessel empty) does not have to be available. For the "In pressure" level selection, the associated pressure must be entered in the "Empty pressure" parameter.</li> </ul>
<b>Factory setting</b>	0.0

---

### Empty pressure (29)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Enter the pressure value for the lower calibration point (vessel empty). See also "Empty calib.".
<b>Prerequisite</b>	<ul style="list-style-type: none"> <li>■ "Level selection" = In pressure</li> <li>■ "Calibration mode" = Dry -&gt; entry</li> <li>■ "Calibration mode" = Wet -&gt; display</li> </ul>
<b>Factory setting</b>	0.0

---

### Full calib. (031)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Enter the output value for the upper calibration point (vessel full). The unit defined in "Output unit" must be used.
<b>Note</b>	<ul style="list-style-type: none"> <li>■ In the case of wet calibration, the level (e.g. vessel full or partially filled) must actually be available. The associated pressure is then automatically recorded by the device.</li> <li>■ In the case of dry calibration, the level (vessel full) does not have to be available. For the "In pressure" level selection, the associated pressure must be entered in the "Full pressure" parameter.</li> </ul>
<b>Factory setting</b>	100.0

---

### Full pressure (032)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Enter the pressure value for the upper calibration point (vessel full). See also "Full calib.".

<b>Prerequisite</b>	<ul style="list-style-type: none"> <li>▪ "Level selection" = In pressure</li> <li>▪ "Calibration mode" = Dry -&gt; entry</li> <li>▪ "Calibration mode" = Wet -&gt; display</li> </ul>
<b>Factory setting</b>	URL of the sensor module

---

#### Level before lin. (019)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the level value prior to linearization.

### 13.9 Expert → Measurement → Sensor limits

---

#### LRL sensor (101)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the lower-range limit of the sensor

---

#### URL sensor (102)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the upper-range limit of the sensor.

### 13.10 Expert → Measurement → Sensor trim

---

#### Lo trim measured (129)

---

<b>Write permission</b>	Parameter is read only. Only Endress+Hauser Service has write permission.
<b>Description</b>	Displays the reference pressure present to be accepted for the lower calibration point.

---

#### Hi trim measured (130)

---

<b>Write permission</b>	Parameter is read only. Only Endress+Hauser Service has write permission.
<b>Description</b>	Displays the reference pressure present to be accepted for the upper calibration point.

---

#### Lo trim sensor (131)

---

<b>Description</b>	Sensor recalibration by entering a target pressure while simultaneously and automatically accepting a reference pressure present for the lower calibration point.
--------------------	---

---

#### Hi trim sensor (132)

---

<b>Description</b>	Sensor recalibration by entering a target pressure while simultaneously and automatically accepting a reference pressure present for the upper calibration point.
--------------------	---

### 13.11 Expert → Output → Current output

---

#### Output current (054)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Displays the current current value.

---

#### Output fail mode (190)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Select Output fail mode. In the event of an alarm, the current assumes the current value specified with this parameter.
<b>Options</b>	<ul style="list-style-type: none"> <li>■ Max: can be set from 21 to 23 mA, see also "High alarm curr."</li> <li>■ Hold: last measured value is held.</li> <li>■ Min: 3.6 mA</li> </ul>
<b>Factory setting</b>	Max (22 mA)

---

#### Get URV (pressure measuring mode) (015)

---

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Set the upper-range value – reference pressure is present at the device. The pressure for the upper current value (20 mA) is present at the device. Use the "Confirm" option to assign the applied pressure value to the upper current value.
<b>Prerequisite:</b>	Pressure measuring mode
<b>Options</b>	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Confirm</li> </ul>
<b>Factory setting</b>	Cancel

---

### Set LRV (013, 168)

---

<b>Write access</b>	Operator/Service engineer/Expert
<b>Description</b>	Set the pressure value, level or content for the lower current value (4 mA).
<b>Factory setting</b>	<ul style="list-style-type: none"> <li>■ 0.0 % in Level measuring mode</li> <li>■ 0.0 mbar/bar or in accordance with ordering information in Pressure measuring mode</li> <li>■ 0.0 m<sup>3</sup>/h in Flow measuring mode</li> </ul>

---

### Get URV (pressure measuring mode) (016)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Set the upper-range value – reference pressure is present at the device. The pressure for the upper current value (20 mA) is present at the device. Use the "Confirm" option to assign the applied pressure value to the upper current value.
<b>Prerequisite:</b>	Pressure measuring mode
<b>Options</b>	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Confirm</li> </ul>
<b>Factory setting</b>	Cancel

---

### Set URV (014, 169)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Set the pressure value, level or content for the upper current value (20 mA).

**Factory setting**

- 100.0 % in Level measuring mode
- URL Sensor or according to ordering information in Pressure measuring mode
- 3600 m<sup>3</sup>/h in Flow measuring mode

## 13.12 Expert → Communication

---

### Manufacturer ID (103)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the HART manufacturer ID in a decimal digit format. Here: 17 (Endress+Hauser)

---

### Device type code (104)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Cerabar M = 0x9219 Deltapilot M = 0x9123

## 13.13 Expert → Diagnosis

---

### Diagnostic code (071)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the diagnostic message with the highest priority currently present.

---

### Last diag. code (072)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
<b>Description</b>	Displays the last diagnostic message that occurred and was rectified.
<b>Note</b>	<ul style="list-style-type: none"> <li>▪ Digital communication: the last message is displayed.</li> <li>▪ Use the "Reset logbook" parameter to clear the messages listed in the parameter "Last diag. code".</li> </ul>

---

### Min. meas. press. (073)

---

<b>Write permission</b>	No write permissions. Parameter is read only.
-------------------------	---

---

**Description** Displays the lowest pressure value measured (peakhold indicator). You can reset this indicator by means of the "Reset peakhold" parameter.

---

#### Max. meas. press. (074)

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the highest pressure value measured (peakhold indicator). You can reset this indicator by means of the "Reset peakhold" parameter.

---

#### Reset peakhold (161)

---

**Write permission** Service engineers/Expert

**Description** You can reset the "Min. meas. press." and "Max. meas. press." indicators with this parameter.

**Options**

- Cancel
- Confirm

**Factory setting** Cancel

---

#### Operating hours (162)

---

**Write permission** No write permissions. Parameter is read only.

**Description** Displays the hours of operation. This parameter cannot be reset.

---

#### Config. counter (100)

---

**Write permission** Operators/Service engineers/Expert

**Description** Displays the configuration counter.  
This counter is increased by one every time a parameter or group is changed. The counter counts up to 65535 and then starts again at zero.

### 13.14 Expert → Diagnosis → Diagnostic list

---

Diagnostic 1 (075)  
 Diagnostic 2 (076)  
 Diagnostic 3 (077)  
 Diagnostic 4 (078)  
 Diagnostic 5 (079)  
 Diagnostic 6 (080)  
 Diagnostic 7 (081)  
 Diagnostic 8 (082)  
 Diagnostic 9 (083)  
 Diagnostic 10 (084)

---

#### Navigation

 Diagnostic → Diagnostic list

#### Write permission

No write permissions. Parameter is read only.

#### Description

This parameter contains up to ten diagnosis messages that are currently pending, arranged in order of priority.

### 13.15 Expert → Diagnosis → Event logbook

---

Last diag. 1 (085)  
 Last diag. 2 (086)  
 Last diag. 3 (087)  
 Last diag. 4 (088)  
 Last diag. 5 (089)  
 Last diag. 6 (090)  
 Last diag. 7 (091)  
 Last diag. 8 (092)  
 Last diag. 9 (093)  
 Last diag. 10 (094)

---

#### Navigation

 Diagnosis → Event logbook

#### Write permission

No write permissions. Parameter is read only.

#### Description

This parameter contains the last 10 diagnosis messages to occur and be rectified. They can be reset using the "Reset logbook" parameter. Errors which have occurred multiple times are displayed once only.

### 13.16 Expert → Diagnosis → Simulation

---

Simulation mode (112)

---

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Switch on simulation and select the simulation mode. When the measuring mode is changed or when the device is restarted, any simulation running is switched off.
<b>Selection</b>	<ul style="list-style-type: none"> <li>■ None</li> <li>■ Pressure → see this table, "Sim. pressure" parameter</li> <li>■ Level → see this table, "Sim. level" parameter</li> <li>■ Tank content → see this table, "Sim. tank cont." parameter</li> <li>■ Alarm/warning, → see this table, "Sim. error no." parameter</li> </ul>
<b>Factory setting</b>	None

---

### Sim. pressure (113)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Enter the simulation value. See also "Simulation mode".
<b>Prerequisite</b>	"Simulation mode" = Pressure
<b>Value at switch-on</b>	Current pressure measured value

---

### Sim. level (115)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Enter the simulation value. See also "Simulation mode".
<b>Prerequisite</b>	"Measuring mode" = Level and "Simulation mode" = Level

---

### Sim. current (117)

---

<b>Write permission</b>	Operator/Maintenance/Expert
<b>Description</b>	Enter the simulation value. See also "Simulation mode".
<b>Prerequisite</b>	"Simulation mode" = Current value
<b>Factory setting</b>	Actual current value

---

### Sim. error no. (118)

---

<b>Write permission</b>	Operators/Service engineers/Expert
<b>Description</b>	Enter the diagnostic message number. See also "Simulation mode".
<b>Prerequisite</b>	"Simulation mode"= Alarm/warning
<b>Switch on value:</b>	484 (simulation active)

### **13.17 Backing up or duplicating the device data**

The device does not have a memory module. However, with an FDT technology-based operating tool (e.g. FieldCare) you can do the following:

- Save/recover configuration data
- Duplicate device configurations
- Transfer all relevant parameters when replacing electronic inserts
- The mechanism is based on IO-Link Data Storage

For more information, read the operating manual for the FieldCare operating program.

## 14 Technical data

### 14.1 Pressure specifications

#### **⚠ WARNING**

The maximum pressure for the measuring device depends on the lowest-rated element with regard to pressure (components are: process connection, optional mounted parts or accessories).

- ▶ Only operate the measuring device within the prescribed limits of the components!
- ▶ MWP (maximum working pressure): The MWP is specified on the nameplate. This value refers to a reference temperature of +20 °C (+68 °F) and may be applied to the device for an unlimited time. Note temperature dependence of MWP. For flanges, refer to the following standards for the permitted pressure values at higher temperatures: EN 1092-1 (with regard to their stability/temperature property, the materials 1.4435 and 1.4404 are grouped together under EN 1092-1; the chemical composition of the two materials can be identical.), ASME B 16.5a, JIS B 2220 (the latest version of the standard applies in each case). MWP data that deviate from this are provided in the relevant sections of the Technical Information.
- ▶ The test pressure corresponds to the overpressure limit (OPL) of the overall system. This value refers to a reference temperature of +20 °C (+68 °F).
- ▶ The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the measuring device.
- ▶ In the case of sensor range and process connections where the over pressure limit (OPL) of the process connection is smaller than the nominal value of the sensor, the device is set at the factory, at the very maximum, to the OPL value of the process connection. If you want to use the entire sensor range, select a process connection with a higher OPL value.
- ▶ Oxygen applications: In oxygen applications, the values for  $p_{\max}$  and  $T_{\max}$  for oxygen applications may not be exceeded.
- ▶ Devices with ceramic process membrane: Avoid steam hammering! Steam hammering can cause zero point drift. Recommendation: Residue (such as condensation or drops of water) can remain at the process membrane after CIP cleaning and lead to local steam hammering if steam is introduced again immediately. In practice, drying the process membrane (e.g., by blowing off excess moisture) has proven to be a successful way of avoiding steam hammering.

#### 14.1.1 Burst pressure

Device	Measuring range	Burst pressure
PMP51 <sup>1)</sup>	400 mbar (6 psi) to 10 bar (150 psi)	100 bar (1 450 psi)
	40 bar (600 psi)	250 bar (3 625 psi)
	100 bar (1 500 psi)	1 000 bar (14 500 psi)
	400 bar (6 000 psi)	2 000 bar (29 000 psi)
	700 bar (10 500 psi)	2 800 bar (40 600 psi)

1) PMP55 with mounted diaphragm seal system, PMC51 with ceramic membrane and the universal adapter process connection are exceptions.

### 14.2 Additional technical data

For the technical data, see the Technical Information for Cerabar M TI00436P / Deltapilot M TI00437P.

# Index

## C

Calib. offset (008) (absolute pressure sensors) . . . . .	74
Calibration mode (027) . . . . .	78
CE mark (declaration of conformity) . . . . .	10
Cleaning . . . . .	60
Config. counter (100) . . . . .	85
Configuration of a level measurement . . . . .	53
Configuration of a pressure measurement . . . . .	57
Configure language . . . . .	51
Configure measuring mode . . . . .	51
Configure pressure engineering unit . . . . .	51
Configuring level measurement . . . . .	53
Configuring pressure measurement . . . . .	57
Corrected press. (172) . . . . .	52, 77

## D

Damping value (017) . . . . .	75
Declaration of conformity . . . . .	10
Designated use . . . . .	9
Device tag (022) . . . . .	71
Device type code (104) . . . . .	84
Diagnostic 1 (075) . . . . .	86
Diagnostic 2 (076) . . . . .	86
Diagnostic 3 (077) . . . . .	86
Diagnostic 4 (078) . . . . .	86
Diagnostic 5 (079) . . . . .	86
Diagnostic 6 (080) . . . . .	86
Diagnostic 7 (081) . . . . .	86
Diagnostic 8 (082) . . . . .	86
Diagnostic 9 (083) . . . . .	86
Diagnostic 10 (084) . . . . .	86
Diagnostic code (071) . . . . .	84
Diagnostic event . . . . .	61
Diagnostic events . . . . .	61
Diagnostic message . . . . .	61
Diagnostics	
Symbols . . . . .	61

## E

Electr. serial no (121) . . . . .	72
Empty calib. (028) . . . . .	78
Empty pressure (29) . . . . .	79
ENP version (099) . . . . .	72
Enter reset code (124) . . . . .	73
Event text . . . . .	61
Ext. order code (097) . . . . .	72
Exterior cleaning . . . . .	60

## F

Firmware version (095) . . . . .	71
Format 1st value (004) . . . . .	73
Full calib. (031) . . . . .	79
Full pressure (032) . . . . .	79

## G

Get URV (pressure measuring mode) (015) . . . . .	81
Get URV (pressure measuring mode) (016) . . . . .	82

## H

Hi trim measured (130) . . . . .	80
Hi trim sensor (132) . . . . .	81

## L

Last diag. 1 (085) . . . . .	86
Last diag. 2 (086) . . . . .	86
Last diag. 3 (087) . . . . .	86
Last diag. 4 (088) . . . . .	86
Last diag. 5 (089) . . . . .	86
Last diag. 6 (090) . . . . .	86
Last diag. 7 (091) . . . . .	86
Last diag. 8 (092) . . . . .	86
Last diag. 9 (093) . . . . .	86
Last diag. 10 (094) . . . . .	86
Last diag. code (072) . . . . .	84
Level before lin. (019) . . . . .	80
Lo trim measured (129) . . . . .	80
Lo trim sensor (131) . . . . .	81
Local display	
see Diagnostic message	
see In alarm condition	
LRL sensor (101) . . . . .	80

## M

Maintenance . . . . .	60
Manufacturer ID (103) . . . . .	84
Max. meas. press. (074) . . . . .	85
Meas. pressure (020) . . . . .	76
Measuring mode (005) . . . . .	51, 74
Menu	
Overview . . . . .	69
Parameter description . . . . .	71
Min. meas. press. (073) . . . . .	84

## N

Nameplate . . . . .	12
---------------------	----

## O

Operating hours (162) . . . . .	85
Operating menu	
Overview . . . . .	69
Parameter description . . . . .	71
Operational safety . . . . .	9
Operator code (021) . . . . .	41, 64, 71
Order code (098) . . . . .	72
Output current (054) . . . . .	81
Output fail mode (051)/(190) . . . . .	64
Output fail mode (190) . . . . .	81

## P

Pos. zero adjust (007) (Deltabar M and gauge pressure sensor) . . . . .	52, 74
Pos. zero adjust (007) (gauge pressure sensors) . . . . .	53
Press. eng. unit (125) . . . . .	52, 75
Pressure af. damp (111) . . . . .	77
Product safety . . . . .	10

**R**

Repair concept . . . . .	67
Requirements for personnel . . . . .	9
Reset peakhold (161) . . . . .	85

**S**

Safety instructions	
Basic . . . . .	9
Sensor pressure (109) . . . . .	77
Sensor temp. (110) . . . . .	76
Ser.no. sensor (122) . . . . .	72
Serial number (096) . . . . .	71
Set LRV (013, 168) . . . . .	82
Set LRV (013) . . . . .	76
Set URV (014, 169) . . . . .	82
Set URV (014) . . . . .	76
Sim. current (117) . . . . .	87
Sim. error no. (118) . . . . .	87
Sim. level (115) . . . . .	87
Sim. pressure (113) . . . . .	87
Simulation mode (112) . . . . .	86
Spare parts . . . . .	67
Nameplate . . . . .	67
Status signals . . . . .	61

**T**

Temp. eng. unit (126) . . . . .	75
---------------------------------	----

**U**

Unit before lin. (025) . . . . .	78
URL sensor (102) . . . . .	80
Using measuring device	
Borderline cases . . . . .	9
Incorrect use . . . . .	9
see Designated use	

**W**

W@M Device Viewer . . . . .	67
Workplace safety . . . . .	9



71536626

[www.addresses.endress.com](http://www.addresses.endress.com)

---