

Operating Instructions

Tankvision

Multi Scan NXA83B

Configuration manual





Table of Contents

1	Document information	3	7.6	Alarm Configuration	61
1.1	Target audience for this manual	3	7.7	Manual Data	71
1.2	Version history	3	7.8	W&M Calibration	74
1.3	Document function	3	7.9	Product Configuration	75
1.4	Documentation	4			
2	Basic safety instructions	5	8	Display Configuration	78
2.1	Requirements for the personnel	5	8.1	Tank Data Displays	78
2.2	IT security	5	8.2	Display Configuration	78
2.3	Designated use	5	8.3	Single Tank and Multi Tank displays	80
2.4	Workplace safety	6	8.4	Grid View and Reports	92
2.5	Operational safety	6			
2.6	Product safety	6	9	System Settings	101
3	Overview	7	9.1	System Settings	101
3.1	Tankvision Multi Scan NXA83B	7	9.2	Using System Settings	101
3.2	Configurator	7	9.3	Login Enabled	101
4	Quick Start	9	9.4	Sound Enabled	102
4.1	Configuring the NXA83B using onboard Configurator tools	9	9.5	Voice Enabled	102
5	Connecting, Network Settings, Windows XPe	10	9.6	Use Product Colors	102
5.1	Remote Control via a networked PC	10	9.7	Movement Threshold	102
5.2	Accessing the Multi Scan NXA83B operating system	12	10	Security	103
5.3	Network Settings	13	10.1	Security	103
5.4	Renaming the NXA83B network name	14	10.2	Using Security Configuration	103
5.5	Changing the Multi Scan NXA83B Network Address	15	10.3	Creating a new User Account	105
5.6	Printer Settings	16	10.4	Deleting an existing User Account	107
5.7	Connecting a modem	16	10.5	Editing an Existing User Account	108
5.8	Enhanced Write Filter (EWF)	16	10.6	Forgetting Your Password	109
5.9	Configuring the Multi Scan NXA83B database	18	11	Gauge Command Scheduler	110
5.10	Quick Start Configuring the Multi Scan NXA83B database	20	11.1	Gauge Command Scheduler	110
5.11	Data Communications Controller	20	11.2	Configuring Scheduled Commands	110
5.12	Multi Scan NXA83B Watchdog	24	12	Advanced Features	112
6	NXA83B Configuration	25	12.1	Advanced Features	112
6.1	System Configuration	25	13	Gauge Commands and Remote Configuration	113
6.2	Tankvision Multi Scan Configurator	25	13.1	Launching Gauge Commands	113
6.3	Database Transporter	30	13.2	Sending a Command	113
7	Database Configuration	33	13.3	Enraf Gauge Commands	115
7.1	Port Configuration	33	13.4	Scientific Instruments Gauge Commands	122
7.2	Configuring protocols	42	14	Technical Specification	127
7.3	Gauge Configuration	44	15	Troubleshooting	128
7.4	Tank Characteristics	49		Index	129
7.5	Tank Strapping Data Configuration	56			

1 Document information

1.1 Target audience for this manual

This manual is giving detailed information on the system capabilities and architecture. It supports project and sales engineers in designing the system architecture during acquisition and execution phase. Furthermore during operation time of the system all servicing personnel in need of detailed knowledge about the system capabilities.

1.2 Version history

Document version	Valid for SW version	Changes to the previous version
BA01291G/00/EN/01.14	3.0.10	Initial version
BA01291G/00/EN/02.15	3.0.12	Change of order code structure

1.3 Document function

1.3.1 Used symbols

Safety symbols

Symbol	Meaning
 <small>A0011189-EN</small>	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 <small>A0011190-EN</small>	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 <small>A0011191-EN</small>	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 <small>A0011192-EN</small>	NOTICE! This symbol contains information on procedures and other facts which do not result in personal injury.

Symbols for certain types of information

Symbol	Meaning
 <small>A0011193</small>	Tip Indicates additional information.
 <small>A0011195</small>	Reference to page Refers to the corresponding page number.
1. , 2. , 3. ...	Series of steps
 <small>A0018373</small>	Result of a sequence of actions

Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
1., 2., 3. ...	Series of steps
A, B, C ...	Views
	Hazardous area Indicates a hazardous area.
	Indicates a non-hazardous location Safe area (non-hazardous area)

1.4 Documentation

1.4.1 Operating instructions

Document number	Instrument	Type of Document
BA01288G/00	<ul style="list-style-type: none"> ▪ Multi Scan NXA83B 	Operation manual
BA01290G/00		Installation and Maintenance manual
BA01291G/00		Configuration manual
BA01292G/00		DCC Configuration manual
BA01289G/00		OPC Tank Data Server manual
BA01297G/00		Web Client System Operation manual
BA01287G/00		Weights and Measures Additions
BA01296G/00		Redundancy manual

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists: must have a relevant qualification for this specific function and task
- Are authorized by the plant owner/operator
- Are familiar with federal/national regulations
- Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- Being instructed and authorized according to the requirements of the task by the facility's owner operator
- Following the instructions in these Operating Instructions

2.2 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

Endress+Hauser can be contacted to provide support in performing this task.

2.3 Designated use

2.3.1 Applications

Inventory control

By using Tankvision Multi Scan to monitor the tank level and stored volume of valuable liquids remotely, owners or operators of tank farms or terminals for petroleum products and chemicals (liquids) can visualize the volume of the stored medium in real time. The data can be used to plan the inventory and distribution. The data can also be used to manage tank farm operations like pumping or transferring products. Tankvision has its unique concept using network technology. Without using proprietary software, the users can visualize and manage their valuable liquids stored in the tanks by a web browser. Tankvision Multi Scan is a flexible and cost effective solution due to its scalable architecture. The application coverage goes from small depots with only a few tanks up to refineries.

Inventory Calculations

Tankvision Multi Scan calculates based on measured variables and tank capacity tables:

- Observed/Gross volumes,
- Net volumes and
- Mass

of products like

- Hydrocarbons,
- Liquefied gases,
- Asphalt.

They are corrected according to international standards, including API/ASTM tables 5A, 5B/6, 53A, 53B/54, 23/24, LPG.

This includes temperature corrections at 15 °C, 60 °F and alternative temperatures. Additionally, available pumpable volumes and water volume are calculated.

Remote configuration of measuring equipment

Some on-site operations can be avoided using remote configuration of measuring equipment during commissioning or maintenance (the availability of this feature may depend on the system configuration).

Application areas

- Tank farms in refineries
- Ship loading terminals
- Marketing and distribution terminals
- Pipeline terminals
- Logistic terminals for tanks storing products like crude oils, refined white and black products, chemicals, LPG

2.4 Workplace safety

For work on and with the device:

- Wear the required personal protective equipment according to federal/national regulations.
- Switch off the supply voltage before connecting the device.

2.5 Operational safety

Risk of injury!

- Operate the device in proper technical condition and fail-safe condition only.
- The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers

- If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to repair of an electrical device.
- Use original spare parts and accessories from Endress+Hauser only.

2.6 Product safety

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations as listed in the EC declaration of conformity and thus complies with the statutory requirements of the EG directives. Endress+Hauser confirms the successful testing of the device by affixing to it the CE mark.

3 Overview


3.1 Tankvision Multi Scan NXA83B

The Multi Scan NXA83B is a small integrated tank gauging and tank inventory management system utilizing the latest embedded Windows technology.

In addition to being a small tank inventory management system it can also be used as a foreign device gateway to higher level DCS and site wide business information systems by providing an open interface to older legacy and proprietary protocols and interfaces.

It features:

- Windows XP Embedded operating system
- An optional full graphical LCD display with touchscreen technology
- Up to 8 communication ports configurable as host or field interfaces
- Inventory Calculations
- A wide range of communications protocols
- Fanless and diskless operation
- A maximum of 256 tanks
- OPC Data Access Server
- System health monitoring via watchdog



NXA83_Typical-Connections

- 1 SAAB TRL2
- 2 Ethernet (OPC)
- 3 ENRAF BPM
- 4 DCS (MODBUS)
- 5 MODBUS Tank Gauges
- 6 ENRAF CIU 858
- 7 WHESOE 550
- 8 VAREC MARK/SPACE

3.2 Configurator

The Multi Scan NXA83B is configured using the Tankvision Multi Scan Configurator software.

This software is pre-installed on the D drive of the NXA83B and may be accessed using remote control from a networked PC.

The database is stored in the Multi Scan NXA83B on an industrial standard flash memory card for maximum reliability. It is transferred between the Multi Scan NXA83B and the Configurator PC via an Ethernet network connection.

4 Quick Start

4.1 Configuring the NXA83B using onboard Configurator tools

This section gives a quick overview for connecting to the current version of the Multi Scan NXA83B.

To start the Tankvision Multi Scan Configurator tools:

1. Connect a cross-over network cable between the PC and the Multi Scan NXA83B.
2. Configure the network settings on the PC to use a fixed IP address of 192.168.1.252.

 In case a different IP address was assigned to the Multi Scan the IP address of the PC must be in the same range.

3. Ensure the Multi Scan NXA83B is running.
4. Start a Remote Desktop Connection on the PC and connect to the NXA83B. →  10
5. Close the NXA83B tankgauging screen, to get access to the operating system. →  12
6. Start the Tankvision Multi Scan Configurator software from the shortcut on the Windows Desktop.

To upload a database from the Multi Scan NXA83B:

1. Select the **New Project** item from the **File** menu.
2. Enter a project name, leave the other settings as "Multiscan" and "ROOT" and click **OK**. This will load a blank database.
3. Select the **Database Transporter** item from the **File** menu.
4. Click on the **Import Database** button. This will proceed to transfer the database from the Multi Scan NXA83B to the Configurator. Click **OK** when complete.
5. **Exit** the Database Transporter.
6. Select **Save Project** from the **File** menu.

The database may now be edited using the options in the Communications and Configuration menus.

To download a modified database to the Multi Scan NXA83B:

1. Ensure network connections are as previously configured.
2. Select **Save Project** from the **File** menu.
3. Select the **Database Transporter** item from the **File** menu.
4. Click on the **Export Database** button. This will proceed to transfer the database to the Multi Scan NXA83B from the Configurator.
5. Click **OK** to the message confirming the export.
6. **Exit** the Database Transporter.
7. **Exit** the Configurator software.
8. Carry out a **Commit** using the desktop shortcut, to reboot the NXA83B and save all data.

The Multi Scan NXA83B will now save the new database to the flash drive and reboot.

5 Connecting, Network Settings, Windows XPe

Multi Scan NXA83B configuration consists of the following sets of tasks:

- Configuring the operating system functions such as Networking, Printers etc.
- Configuring the database

The first set of tasks can be carried out either directly on the Multi Scan NXA83B using a keyboard/mouse or via a remote networked PC. These tasks will be described in this section. The second set of tasks (configuring the database) can only be carried out via a remote networked PC, using the Tankvision Multi Scan Configurator set of tools already loaded onto the NXA83B. This constitutes the bulk of the configuration work for the Multi Scan NXA83B and is covered in a separate Configuration manual. An introduction to the Configurator tools will be given in this section.

 The Tankvision Multi Scan Configurator tools may also be loaded onto a separate PC, which must then be connected to the NXA83B via a network connection.

Any changes made to the system will not be permanent until committed in the Enhanced Write Filter.


5.1 Remote Control via a networked PC

In many circumstances it is not feasible to connect a Keyboard and Mouse directly to the Multi Scan NXA83B, and in fact for most configuration work it is not recommended. In this case a networked PC can be used to take control of the Multi Scan NXA83B using the Windows Remote Desktop Connection.

The Multi Scan NXA83B and remote PC must be networked together, either as part of a larger network, or directly using a network cable.


To connect using a direct connection:

1. Set the networking on the remote PC to a Fixed IP address with a value similar to the Multi Scan NXA83B. For instance if the Multi Scan NXA83B address is 192.168.1.250, set the PC address to 192.168.1.251.
2. Connect a network cable between the Multi Scan NXA83B and the PC. For more details, refer to the Installation manual (BA01290G).
3. On the PC open a the Windows Remote Desktop Connection (**Windows Start** → **All Programs** → **Accessories** → **Remote Desktop Connection**) and type the network address of the Multi Scan NXA83B **192.168.1.250** into the **Computer** field.




NXA83_Remote-Desktop-Connection

4. Expand **Options**, select the **Display** tab and set the size of the remote desktop to a minimum resolution of 1024 × 768.



NXA83_Remote-Desktop-Connection_Resolution

5. Connect to the Multi Scan NXA83B by clicking the **Connect** button. If prompted, enter the account details for the Multi Scan NXA83B. By default these will be:
 - User name: Administrator
 - Password: password



NXA83_Remote-Desktop-Connection_Log-In

6. The display on the Multi Scan NXA83B will now be shown on the remote PC. For details on how to stop the operator display to gain access to the operating system → 12.

5.2 Accessing the Multi Scan NXA83B operating system


The Windows XPe operating system is normally hidden behind the main Multi Scan NXA83B operator screens, and cannot be accessed. However, in order to carry out most configuration tasks, access is required to the operating system. In this case the operator display must be stopped.

To do this first requires keyboard/mouse input, which can be carried out in one of two ways:

- Connect a PC to the Multi Scan NXA83B using the Ethernet port and take control of the Multi Scan NXA83B using the Windows Remote Desktop Connection (recommended).
- Connect a keyboard and mouse to the USB ports of Multi Scan NXA83B and use the LCD display.

For details on the latter method → 10.


To stop the operator display screens, open the right (Screens) menu, select the down arrow to show the next bank of options and click on the **Exit** option.



The login screen will be displayed.

Enter the Administrator password to continue. This will be set to "password" when the Multi Scan NXA83B is shipped, but may be changed using the Tankvision Multi Scan Configurator tools.

If a valid password is entered the operator screens will close and the Windows Desktop will be shown.



NXA83_Windows-Desktop_Low-Resolution

The Windows Taskbar is set to auto hide mode. To show the taskbar, move the mouse to the bottom of the screen.


NOTICE

Any changes of the windows settings could affect the correct operation of the Multi Scan NXA83B. Therefore:

- ▶ Take extreme care when modifying any of the windows settings.

5.2.1 Exiting from the Remote Control session

If no changes have been made to the configuration and the remote desktop session is no longer required, then the NXA83B can be returned to the standard Operator Touchscreen using the **Return To Main Screen** shortcut.



NXA83_Windows-Desktop_Return-to-Main-Screen

1 Windows Desktop shortcut icon: Return To Main Screen


This will automatically set the screen resolution to 640 × 480 and start the operator display.



If any changes have been made to the operating system settings or the database then the **Commit** shortcut should be used instead of this option.

5.3 Network Settings

The Multi Scan NXA83B has an Ethernet port, referred to in the Windows operating system as **Local Area Connection**.



For the physical locations of the network connections, refer to the Installation manual (BA01290G).

The Multi Scan NXA83B is shipped with the following default network settings:

- Computer Name: NXA83B
- Local Area Connection 3: Fixed TCP/IP Address: 192.168.1.250

For most applications these will be perfectly adequate and should be left as standard. However they may be changed at configuration time to fit in with an existing network on site.

To change the settings follow the procedure in the next section of this manual (→ 14). The TCP/IP addresses can be changed using the Local Area Connection properties in the Control Panel. This includes using DHCP to dynamically assign an address on an established network.

 Any changes will not be permanent until committed in the Enhanced Write Filter (→ 16).

5.4 Renaming the NXA83B network name

The Multi Scan NXA83B runs under the Windows XP operating system, therefore the computer name may be modified in the same way as a normal PC.

The network name of the Multi Scan NXA83B is set by default to "Multi", and in most cases it is recommended that it be left as this.

However, if the name needs to be changed then this can be performed using the following procedure:


1. Start a remote session (refer to Remote System Login section).
2. Open the **System Properties** option from the Control Panel of the remote Multi Scan NXA83B.

3. Change the Computer Name as normal. **Do NOT** reboot the Multi Scan NXA83B at this stage.
4. Select the option from the windows start menu;
Start → Programs → Tankvision Multi Scan Configurator → Rename SQL Instance
This will run a batch file that requires the old name to be entered, followed by the new name.
5. After this, double click the **Commit** shortcut to make the changes permanent.
6. Create a new project in the Tankvision Multi Scan Configurator software with the new network name.
7. Upload configuration from the Multi Scan NXA83B.

NOTICE

Modifying the NXA83B name will have repercussions in the Tankvision Multi Scan Configurator tool as it uses that name to communicate with the Multi Scan NXA83B. Therefore:

- ▶ The project settings will have to be edited as shown below.



1 Renaming the NXA83B network name

5.5 Changing the Multi Scan NXA83B Network Address

The Multi Scan NXA83B runs under the Windows XP operating system, therefore the network address and mode may be modified in the same way as any normal PC.

The network protocol is set to TCP/IP, but the address may be set as required. This includes using DHCP to dynamically assign an address on an established network.

The network settings will be set by default to: FIXED address of 192.168.1.250.

The network settings may be changed by the carrying out the following:

1. Start a remote session (refer to Remote System Login section).
2. Open the **Network Connections** option from the Control Panel of the remote Multi Scan NXA83B.
3. Modify the settings as normal.
4. After this, double click the **Commit** shortcut to make the changes permanent. The remote session will be disconnected.

5.6 Printer Settings

In order for the print features in the Multi Scan NXA83B to work, a printer needs to be configured in the Windows XPe operating system as the DEFAULT printer.

A printer can be installed after the Multi Scan NXA83B has been shipped, in the same way as installing on a normal PC running Windows XP. However, due to the restrictions on the flash disk space, it is recommended that only the basic printer driver should be loaded and not any print utilities.

For the above reason it is recommended that Endress+Hauser should be consulted on the type of printer to be attached to the Multi Scan NXA83B.

The printer should normally be connected to the Multi Scan NXA83B via one of the USB ports. However network printers can also be supported.

 Any printer setting changes will not be permanent until committed in the Enhanced Write Filter.

5.7 Connecting a modem

The communications layer of the Multi Scan NXA83B, DCC, can handle modem communications on both master and slave interfaces.

At the moment an external modem should be used, connected to one of the serial ports. However it should also be possible to connect via the USB ports.

The modem driver should be installed on the operating system as for a normal PC running Windows XP.

It is recommended that Endress+Hauser should be consulted before selecting the modem, or Endress+Hauser can supply a suitable modem.

 Any modem setting changes will not be permanent until committed in the Enhanced Write Filter.

5.8 Enhanced Write Filter (EWF)

The Multi Scan NXA83B runs under the Windows XP Embedded (XPe) operating system, which includes a component called the Enhanced Write Filter (EWF).

This prevents files from being corrupted by a sudden loss of power; therefore it is perfectly safe to switch off the Multi Scan NXA83B without shutting down the operating system.

It works by caching all disk and operating system changes. The cache is only permanently written to the flash disk when an EWF COMMIT action is called. This action saves the data to the flashdisk then reboots the Multi Scan NXA83B, thus making the modifications permanent. If the Multi Scan NXA83B is rebooted without a commit, or loses power, then all changes are lost.


To commit changes, double click on the **Commit** desktop shortcut.




NXA83_Windows-Desktop_Commit

1 Windows Desktop shortcut icon: Commit

Follow the instructions in the **Commit** window.



NXA83_Windows-Desktop_Commit_EWF-Window



NXA83_Windows-Desktop_Commit_Commit-Window

Press any key and the system will save all data permanently to the flash drive before rebooting.

The data may also be committed using the Tankvision Multi Scan Configurator tools. Refer to the online manual with that product for more details.

NOTICE

Risk of malfunction!

- ▶ Never disable the enhanced write filter!



The commit procedure may take a few minutes to complete, depending on the quantity of changes that have occurred. Never switch off the power during this period, as operating system corruption may occur.

5.9 Configuring the Multi Scan NXA83B database


The Multi Scan NXA83B is configured using the Tankvision Multi Scan Configurator software which is pre-installed on the D drive.

The Configurator software may also be installed on a separate PC if required, although it is recommended that the onboard tools are used.

To run the Configurator software on the NXA83B, a suitable PC should be connected to the Multi Scan NXA83B via a standard Ethernet network. This could be as part of a larger network or using a direct network cable between the PC and the Multi Scan NXA83B.

Before running the software, the user should log onto the NXA83B using the Windows Remote Desktop Connection and shut down the tankgauging display, so that access to the NXA83B operating system is available. Refer to previous sections of this manual for details on how to do this.

To start the Configurator tools, double click on the **Tankvision Multi Scan Configurator** icon on the NXA83B desktop.



NXA83_Windows-Desktop_Tankvision-Multi-Scan-Configurator

1 Windows Desktop shortcut icon: Tankvision Multi Scan

The Multi Scan NXA83B database may be uploaded to the Configurator software, modified, then downloaded to the Multi Scan NXA83B. Database transfer to or from the Multi Scan NXA83B is carried out by the Database Transporter sub-system.

The user can store the databases for different Multi Scan NXA83B in projects, which may be reloaded for later use. It is, however, best practice to upload the current database from the Multi Scan NXA83B before carrying out any modifications.

The configurator software allows the Multi Scan NXA83B to be configured for a wide range of functions, including:

- Host and Slave Communication ports
- Tank Inventory Data
- Programmable alarms
- Products
- Manual data
- Strapping data

The standard tank gauging displays for the Multi Scan NXA83B may also be configured to display only the data required.

For full details on how to configure the database → [33](#).

5.10 Quick Start Configuring the Multi Scan NXA83B database

This section gives a quick overview on how to connect the Multi Scan NXA83B to a Remote PC and upload a configured database.

To Upload the existing database from the Multi Scan NXA83B:

1. Connect a network cable between the PC and the left hand RJ45 network socket on the Multi Scan NXA83B.
2. Configure the network settings on the PC to use a fixed IP address of 192.168.1.251.
3. Ensure the Multi Scan NXA83B is running.
4. Start a Remote Control session from the PC and connect to the NXA83B. →  10
5. Close the NXA83B tankgauging screen, to get access to the operating system. →  12
6. Start the Tankvision Multi Scan Configurator software from the link on the Windows Desktop.
7. Select the **New Project** item from the **File** menu.
8. Enter a project name, leave the other settings as "Multiscan" and "ROOT", and click **OK**. This will load a blank database.
9. Select the **Database Transporter** item from the **File** menu.
10. Click on the **Import Database** button. This will proceed to transfer the database from the Multi Scan NXA83B to the PC. Click **OK** when complete.
11. Exit the Database Transporter
12. Select **Save Project** from the **File** menu.

The database may now be edited using the options in the Communications and Configuration menus.

Modify the display to show the data fields required, by selecting the item **Display** in the Configuration menu.

To Download a modified database to the Multi Scan NXA83B:

1. Ensure network connections are setup and working.
2. Select **Save Project** from the **File** menu.
3. Select the **Database Transporter** item from the **File** menu.
4. Click on the **Export Database** button. This will proceed to transfer the database to the Multi Scan NXA83B from the PC.
5. Click **OK** to acknowledge the message confirming the export.
6. Exit the Database Transporter.
7. Exit the Configurator software.
8. Carry out a **COMMIT** to reboot the NXA83B and save all data. →  16
The Multi Scan NXA83B will now save the new database to the flash drive and reboot.

5.11 Data Communications Controller

5.11.1 Stopping and Starting DCC

The DCC communications sub-system can be accessed.

The DCC runs as a set of services; they are automatically started when the Multi Scan NXA83B is restarted. There may, however, be times when it is necessary to stop or restart the services.

-  The Multi Scan NXA83B has a watchdog enabled by default. If the DCC Communications is stopped whilst the watchdog enabled, the Multi Scan NXA83B will be automatically re-booted after one minute. This will result in the loss of the remote session and any changes not yet saved. For details on how to disable the watchdog → 24.


To Stop the DCC services, double click the **DCCConfig** shortcut on the Windows Desktop.



1 Windows Desktop shortcut icon: DCCConfig

To stop the DCC services click on the **Stop Services** button.

See the screen below to show that DCC Host has stopped.



Data Communications Controller


- 1 Stop Services Button
- 2 Start Services Button

When all Service Details have changed to **Stopped** the button will change to **Start Services**.

To start the DCC Host again, simply click the **Start Services** button. After a few moments all installed services should change to **Running**.

5.11.2 DCC Comms Monitor


To view the DCC Host Communications Monitor, double click the **Comms Monitor** shortcut icon on the Windows Desktop:



NXA83_Windows-Desktop_Comms-Monitor

1 Windows Desktop shortcut icon: Comms Monitor

This will bring up the following screen:




NXA83_Windows-Desktop_Comms-Monitor-Window

The DCC Host module allows the user to view the data communication that occurs between the Multi Scan NXA83B and any connected devices such as tank gauges.

To view communications, select the desired Host COM port from the drop down list. e.g. Com 1. A list of gauges being polled on the selected COM port will be displayed in the box below.


One item always available in the COM Port drop down list is SIMULATOR, this is a software feature which simulates gauges within DCC Host and is treated exactly the same as a normal COM port.



NXA83_Windows-Desktop_Comms-Monitor-Window_Simulator

A blue arrow scrolls through the device list to indicate the gauge currently being polled. A red arrow will be displayed against a device being polled on fast scan.

The numbers in the list of gauges refers to the **Tank Address** of each gauge, entered in the **Gauge Configuration** screens. To display the name of the gauge in the list, hover the mouse over the Tank Address of the gauge.



NXA83_Windows-Desktop_Comms-Monitor-Window_Gauge-Name

Other sections of the Comms Monitor window are **Configuration, Statistics, Product Information, Status and Incoming Raw Data.**

Configuration shows:

- **Slave Address** – as configured in the DCC Host Comms TAB
- **Group Address** – not used on the Multi Scan NXA83B and set to 0 by default.
- **Gauge Address** – the address of the currently selected gauge. If no gauge is selected this field shows the addresses of all gauges connected to the selected COM port.

Statistics shows:


The number and validity of messages and responses since the COM port was selected.

Product Information shows:

The Level, Flow Rate and Temperature of the selected gauge. If no gauge is selected this section will not be updated and will either remain blank or display -1 to indicate no valid data.

Status shows:

The current status of the gauge being monitored by the DCC Host. If any status flags have been set, a number will appear in the corresponding box. Detailed status analysis can be obtained by clicking on **...** to expand the relevant section in a pop-up window. E.g. in the diagram below an **Alarm Status** code of **03** has been triggered. Opening the **Alarm Status** window shows this relates to a Level High-High Alarm.



NXA83_Windows-Desktop_Comms-Monitor-Window_Alarm-Status

If no gauge is selected this section will not be updated and all boxes will display **00**.

Incoming Raw Data shows:

The raw data being sent between the Multi Scan NXA83B and the attached gauge. To interpret this data will require specialized knowledge of the gauge protocol being used and is consequently only of use for maintenance and diagnostics purposes. Use of the DCC Host Comms Monitor is not recommended for general operations.

If no gauge is selected to be watched, the **Raw Data** section will display the connection status of interface, this will be one of the following:

- Disconnected
- Connecting
- Connected
- Disconnecting

If an interface is not in the **Connected** state, then no messages will be sent to any gauges on that interface.

5.12 Multi Scan NXA83B Watchdog

The Multi Scan NXA83B has a system watchdog component that monitors the health of the DCCHost communication service. If no communications occur (i.e. gauge data is not updated) for one minute, the Multi Scan NXA83B will reboot automatically.

The watchdog may be disabled by starting a remote session (refer to previous section for details) and the double clicking the **Disable Watchdog** shortcut on the Windows desktop.



1 Windows Desktop shortcut icon: Disable Watchdog

NXA83_Windows-Desktop_Disable-Watchdog-Icon

This will display a DOS window prompting for a reboot of the NXA83B. Hit any key to reboot the NXA83B with the watchdog disabled.

To re-enable the watchdog, repeat the above sequence but select the **Enable Watchdog** shortcut.

NOTICE

If the watchdog is disabled and there are problems with the processor board hardware or with any of the DCC comms services, the system will not reboot. It will just stay in faulty mode. Therefore:

- ▶ Do not leave the watchdog permanently disabled!

6 NXA83B Configuration

6.1 System Configuration

The Multi Scan NXA83B is configured using the Tankvision Multi Scan Configurator software which is installed onboard the NXA83B as standard. A PC is then required to connect to the NXA83B using Remote Desktop Connection, to run the Configurator software.

The Multi Scan NXA83B database may be uploaded to the Configurator Software, modified, and then downloaded to the Multi Scan NXA83B. Database transfer to or from the Multi Scan NXA83B is carried out by the Database Transporter sub-system.

The Configurator PC should be connected to the Multi Scan NXA83B via a standard Ethernet network. This could be as part of a larger network or using a direct cross-over network cable between the PC and the Multi Scan NXA83B.

The user can store the database for different Multi Scan NXA83B in projects, which may be reloaded for later use. It is, however, best practice to upload the current database from the Multi Scan NXA83B before making any modifications.

The Configurator software allows the Multi Scan NXA83B to be configured for a wide range of functions, including:

- Host and Slave Communication ports
- Tank Inventory Data
- Programmable alarms
- Products
- Manual data
- Strapping data


The standard tank gauging display for the Multi Scan NXA83B may also be configured to display only the data required.

6.2 Tankvision Multi Scan Configurator

6.2.1 Tankvision Multi Scan Configurator

The Multi Scan NXA83B is configured using the Tankvision Multi Scan Configurator software. This is started by double clicking on the **Tankvision Multi Scan Configurator** icon.

It is recommended that the Configurator software is run from the Multi Scan NXA83B. In this case, connect to the Multi Scan NXA83B via a Remote Desktop Connection from a networked PC and shut down the tankgauging display. The **Tankvision Multi Scan Configurator** icon can then be found on the Windows desktop. For more details →  10.




All configuration actions are accessed from this software.

6.2.2 Projects

The Configurator may be used to configure many Multi Scan NXA83B devices, by saving each NXA83B to a new project within the configurator.

Only one project may be opened at a time, and each project has the database for one Multi Scan NXA83B.

The current open project is shown in the top right of the Configurator screen.



1 Configurator Screen: Current open project


When started, the Configurator will open the last previously opened project. All actions carried out in the Configurator will be saved in the current project database unless the **Save As** option is selected in the **File** menu.

Each project must contain the following configuration data:

- **Device Network Name:** This is the network name of the Multi Scan NXA83B and is required for all transfer of data to/from the device. This will default to "Multiscan", but the Multi Scan NXA83B may be configured differently. If the Network Name is not set the same as the Multi Scan NXA83B then all database transfers will fail.


- **Device Data Directory:** This is the share name of the data directory on the Multi Scan NXA83B. This should ALWAYS be set to "ROOT". Do not change.
- **Number of Ports:** This is the number of serial ports supported by the NXA83B. The default is 8.

To change the current project, click on the **File** menu



NXA83_Configurator_New-Project

When carrying out project actions, if the current project has been edited, a message will be displayed with a prompt to save the existing data.




NXA83_Configurator_Project_Save-Changes

Click **Yes** to save the existing project, after which the new project actions will take place.

6.2.3 New Project

To create a new blank project select **New Project** from the **File** menu:



NXA83_Configurator_Create-New-Project

Enter the new project name, and then configure the details of the remote Multi Scan NXA83B in the Project Settings.

These settings are important for establishing communications with the remote device; for a description → 26.


Click **OK** to create the new project and set it as the currently open project in the Configurator.

i Before creating a new project always save any changes to the current open project, as they will be discarded when the new project is created.

6.2.4 Open Project

To open an existing project select **Open Project** from the **File** menu.

Select from the list of projects, and then click on **OK**.




NXA83_Configurator_Open-Project

The project details and database will be loaded into the Configurator as the current open project.

i Before opening a project always save any changes to the current open project, as they will be discarded when the selected project is opened.

6.2.5 Edit Project


To edit the settings for the currently opened project select **Edit Project** from the **File** menu:



- **Device Network Name:** The name in the project settings must match that of the Multi Scan NXA83B for database transfers to work.
- **Device Data Directory:** Should ALWAYS be set to "ROOT". Do not change.
- **Number of Ports:** Select the Number of Ports supported by the Multi Scan NXA83B.

6.2.6 Saving Projects

To save the current open project, select **Save Project** from the **File** menu.
 To save the project and all its data to a new project, select **Save As** from the **File** menu:



Enter the new name for the project then click **OK**.
 The current open project will be changed to the new project.
 An existing project may be specified, in which case that project will be overwritten.
 Saved projects files will be written to a directory with the name of the project. This directory will be located at:
 D:\Program Files\tankvision Multiscan Configurator\Projects

6.2.7 Backing up and restoring projects

To make a backup of a project to a USB memory stick, carry out the following:

1. Save the project via the **Tankvision Multi Scan Configurator**.
2. Plug a memory stick into a free USB port.
3. Copy the saved directory (→ 29) to the USB memory stick.

4. Carry out a **COMMIT**.
5. Remove the USB memory stick after the reboot.


To restore a backup project or load a project from another Multi Scan NXA83B, carry out the following:

1. Plug the memory stick containing the backup project into a free USB port.
2. Copy the backup project directory from the USB memory stick to the location:
D:\Program Files\tankvision\Multiscan Configurator\Projects
3. Start the **Tankvision Multi Scan Configurator** and open the project (→ 28).
4. If the project is from another Multi Scan NXA83B then use the **Edit Project** option and check that the **Device Network Name** is changed to the current Multi Scan NXA83B name.
5. Use the **Database Transporter** to export the database, then carry out a COMMIT.

6.3 Database Transporter

6.3.1 Database Transporter

The Database Transporter is responsible for transferring the database to/from the Multi Scan NXA83B and is accessed via the **File** menu in the Configurator.:




NXA83_Configurator_Database-Transporter


The current open project is displayed in the top right of the screen. The network name for the Multi Scan NXA83B is displayed in the **Name** field. It is important that this is set to the same as the network name of the Multi Scan NXA83B, if there is a difference then no transfers will take place.

6.3.2 Exporting to the Multi Scan NXA83B

To transfer the database to the Multi Scan NXA83B, click on **Export Database**. The progress of the transfer will be displayed, see below.



At the end of the transfer a message will be displayed informing whether the database export was successful or not.




Click **OK** to close the window then **Exit** the **Database Transporter**. The database will be transferred but changes will not take effect, or become permanent until written to the Flash drive by a **re-boot** of the operating system. This means that if the device is switched off before a re-boot has taken place all changes will be lost.

6.3.3 Re-booting

If new data has been downloaded to the Multi Scan NXA83B, it will not be permanently saved to the flash drive until a re-boot of the operating system has occurred. This is normally carried out at the end of an export. However it may be carried out at any time after an export.

- If the Configurator software is running onboard the Multi Scan NXA83B, then close the **Tankvision Multi Scan Configurator** and double click on the **Commit** shortcut icon on the NXA83B Desktop. A DOS window will open. When prompted, press any key to re-boot the Multi Scan NXA83B to permanently save the changes.




1 Windows Desktop shortcut icon: Commit

The Multi Scan NXA83B has a software component installed called the Enhanced Write Filter (EWF). This prevents files from being corrupted by a sudden loss of power. Once data has been written to the Flash Drive it is perfectly safe to switch off the Multi Scan NXA83B without shutting down the operating system.

6.3.4 Importing From the Multi Scan NXA83B

To transfer the database from the Multi Scan NXA83B to the Configurator, click on **Import Database**.

The progress of the transfer will be displayed.



NXA83_Configurator_Database-Transporter_Import

At the end a message will display if the database import was successful or not.



NXA83_Configurator_Database-Transporter_Import-Successful

The database imported from the Multi Scan NXA83B will overwrite the existing database in the Configurator.

7 Database Configuration

7.1 Port Configuration

7.1.1 Port Configuration

The Multi Scan NXA83B has a component installed called the Data Communications Controller (DCC) which consists of a number of services responsible for transmitting tank data to and from the device.

The three main services are:

- **DCC Host** - responsible for retrieving data from gauges and storing it in the database
- **DCC Slave** - responsible for sending tank data to other computer systems
- **OPC Server** - responsible for providing tank data to OPC clients


The Host and Slave services control communications over a number serial ports on the Multi Scan NXA83B and these must be configured with a software protocol before they can be used.

The OPC Server service communicates via the network and requires no configuration. This section of the manual provides an overview of how to configure the NXA83B communications sub-system. For a more detailed description refer to the separate DCC Configuration manual (BA01292G).

7.1.2 Data Communications Controller


The ports used in the DCC component of the Multi Scan NXA83B are configured by selecting the **Port Configuration** option from the **Communications** menu of the Tankvision Multi Scan Configurator.

This consists of a number of tabbed pages to configure the Host and Slave ports.



NXA83_Data-Communications-Controller

The **License** tab allows the licensing details to be viewed for the current open project. These are automatically retrieved from the Multi Scan NXA83B when the database is imported.




NXA83_Data-Communications-Controller_License

7.1.3 Configuring a Host or Slave port

Host ports are responsible for collecting data from Datacons and gauges, and command requests from any PC Tankgauging clients.

Slave ports are responsible for sending data to other computer systems, such as the main Distributed Control System (DCS) for the refinery, using protocol such as Modbus.

To configure a port click on the **Host Comms** or **Slave Comms** tab in the **Data Communications Controller** tool.




NXA83_Data-Communications-Controller_Host-Comms

A list of all physical COM ports (RS232/485/422 etc.) will be displayed together with any logical Modem and Network ports configured (they will have an offset of 40 for Modems, 70 for Network and 110 for OPC connections, i.e. COM 41, 71, 111 etc.).

For Modem ports click on **Add Modem Port**, for Network ports click on **Add Network Port**, for OPC ports click on **Add OPC Port** to automatically add the port to the list. Select the COM port to configure and make sure the **In Use** box is ticked.

A warning message may be displayed if a new Host port is added by selecting the **In Use** box and the number of licensed host interfaces has been exceeded.



NXA83_Data-Communications-Controller_Host-Comms_Interfaces-exceeded

Select the **Protocol** to be used on the port, from the drop down menu..

Retries determines the number of consecutive failed polls before a communications failed alarm is generated for host ports.

The **Background Scan Period** determines the update times for certain gauge parameters, such as Density, Observed Temperature, Pressures, Vapour Temperature, Multi-Element Temperatures and Water Level. It is not used for Slave ports.

For Host ports the **Connect** section determines when to connect to the COM port or Modem and poll the gauges. This will default to **Always Poll**. The following options may be selected from the drop down.


- **Always Listen** – mode for slave interfaces
- **Always Poll** - Interface will always try to be connected and polling the gauges
- **Manual** - Interface will only connect and poll gauges if manually commanded by User
- **Scheduled by Hour** - Interface will connect on the hours selected by the user
- **Scheduled by Interval** - Interface will connect periodically

7.1.4 Configuring Scheduled Connections

Scheduled connections are normally used on Modem ports, where the host port will connect to the remote site, poll for all the data and then automatically disconnect.

For scheduled connections the times to connect must be configured by clicking on the **Configure** button next to the **Connect** field.

If the **Scheduled by Hour** option was selected then the hours on which the interface will connect may be defined in the dialog box displayed:




The **Max Connection Time** field defines the maximum time in minutes that the interface will remain connected and polling the gauges before it will disconnect. Normally the interface will disconnect automatically after it has retrieved all data from then gauges. This field should be set to longer than the time it takes to update all data. The main purpose for this field is to limit the time a modem will remain connected if problems occur polling the gauges.

The **minutes** field in the **Connect at selected Hours** section defines the minutes past the hour that the connection will take place.

If problems are experienced with scheduled connections where some data is not being retrieved, it may be that the **Max Connection Time** is too short. In this case, increase the **Max Connection Time**.

If the **Scheduled by Interval** option was selected, the interval between connections must defined in the dialog box displayed:




NXA83_DCC-Config_Host-Comms_Scheduled-Connect-Interval

The **Max Connection Time** is the same as for the hourly connection display.

7.1.5 Configuring DCC Host Options

The **Options** section allows the operation of DCC Host to be modified as required. Current options supported are shown below:



NXA83_DCC-Config_DCC-Options

- **Manual levels set Programmable Alarms** - by default a manual value will not trigger a programmable alarm, ticking this option will reverse this functionality.
- **Servo/Stow set Programmable Alarms** - by default when a gauge is moving due to a stow/unstow or servo command then programmable level alarms will be suppressed, ticking this option will reverse this functionality so that the current position of the sensing head will be used to trigger alarms.
- **Log Profiles to CSV file** - when this option is ticked, the results of profile scans (Density, Pressure, Temperature etc.) will be saved as CSV data files. The file is stored in **D:\HistoricalProfiles** using a filename of the format:
<tankname>_<Gauge Number>_<Date>_<Time>.csv
- **Display Error Messages** - This option causes a pop-up message box to be displayed with any error information if DCC Host crashes.
- **Auto control the manual mode for water level** - ticking this option will set DCC to automatically set the water field into manual mode if the value from the field is invalid.
- **Set Flow to Zero if below threshold** - by default all flow data will be saved regardless of what the value is. This may lead to a flow being displayed that is due to the "ripple" of the product. Ticking this option will set DCC to clamp all flow rates to zero if the value is below the flow rate threshold value entered in the System Settings.

- **Suppress Alarms when Displacer Above Liquid Surface** – ticking this option will set DCC to ignore any level alarms returned from the gauge, but only when the displacer is above the product surface i.e. not following level. For instance when servoing or stowing etc.
- **Suppress Alarms when Displacer Below Liquid Surface** – ticking this option will set DCC to ignore any level alarms returned from the gauge, but only when the displacer is below the product surface i.e. not following level. For instance when profiling or finding water.

There are also a number of **Data Synchronization** options which can be set when the Multi Scan NXA83B is connected to a Host Tankgauging computer.

- **Auto Sync Manual Data** – When selected, any changes made to manual data (e.g. setting fields to Manual/Auto or setting manual values) on the Host computer will also be set on the Multi Scan NXA83B.
- **Auto Sync Tank Inventory Data** - When selected, any changes made to tank inventory data (e.g. Changing Tank Capacity Tables) on the Host computer will also be set on the Multi Scan NXA83B.
- **Auto Sync Alarm Data** - When selected, any changes made to alarm data (e.g. Alarm set-points or activating/deactivating alarms) on the Host computer will also be set on the Multi Scan NXA83B.
- **Auto Sync Movement Data** - When selected, any changes made to movement data (e.g. flow rate set-point) on the Host computer will also be set on the Multi Scan NXA83B.
- **Auto Sync Gauge Configuration Data** - When selected, any changes made to gauge configuration data (e.g. tank name or product) on the Host computer will also be set on the Multi Scan NXA83B.

7.1.6 Communications Parameter Configuration

Each Host or Slave port requires the Hardware configuring for the communication parameters. These parameters differ depending on the hardware, i.e. Physical COM ports, modems or Network connections.


Click on the **Configure** button next to the **Hardware** field to configure the communication parameters for the port.

Serial ports

Serial ports require the **Baud rate**, **Parity**, **Data Bits** and **Stop Bits** configuring. **Flow Control** should always be set to **None**, except for SAAB protocol ports where it should be set to **RTS**.

If the serial communications hardware produces an echo of sent characters (i.e. some RS485 or 20 mA current loop devices) then tick the **Echo Expected** field to tell the driver to handle the echoed characters.

The **Redundancy Settings** fields are only used if Redundancy has been enabled in DCC, and has been selected as either **Switch By Interface** or **Switch By System**.




NXA83_Data-Communications-Controller_Host-Comms_COM-Port-Settings

The **Timeout Period** is used to determine if a port has failed and should trigger a switch over. Switchover occurs if there has been no valid communication packets received from gauges for at least the Timeout Period.

For the redundancy mode **Switch By System**, a port can be disabled from causing a switchover by ticking the item **Do Not Trigger Redundant Switch**.

Modem ports

Modem ports require the **Modem** and **Phone Number** to be configured.




NXA83_Data-Communications-Controller_Host-Comms_Modem-Settings

The Modem should be selected from those installed in the operating system.

Network ports

Network ports require the **Network Address**, **IP Port** and the **Delay Between Polls** to be configured.



The **Network Address** is the address of the remote computer connecting to the Multi Scan NXA83B and may be entered as a TCP/IP address or the PC name. The IP Port should be entered for the interface running on the remote system.

The **Delay Between Polls** is only required for host ports and should generally not be set below 100 ms.


For slave ports the **Timeout for inactive connections** setting is used to disconnect the remote system if no requests have occurred for that length of time. Setting this value too low could affect communications. It should normally be set to 60 seconds (60000 ms).

OPC ports

The **Protocol** type will always be set to **OPC TG**. The **Retries**, **Background Scan Period** and **Redundancy Settings** fields all function in the same way as for a normal COM port.

The **Hardware** section requires configuring with the network name or IP address of the remote network device that the OPC server is running on. It also requires the OPC server details, such as the Prog ID and CLSID.


To enter these details click on the **Configure** button to the right of the **Hardware** field.



Enter the **Network Address** of the remote network device (i.e. PC) to connect to. This may be entered as the name of the device (i.e. PC name) or as its TCP/IP address, for example 192.168.1.86.


If the name of the remote device is to be used, ensure that it is known to the system that DCC Host is running. This is usually the case if both systems use the same DNS server.

To select the OPC server details, ensure that the Network Address has been entered and then click on the **Browse ID** button.



NXAB3_DCC-Config_OPC-Settings_Select-OPC-Server

This will display a list of all OPC Data Access (DA) servers (and Alarm Event servers, although these are not supported at the moment) on the remote machine. Select the correct server then click on **OK**.



NXAB3_DCC-Config_OPC-Settings_DataServer

The OPC DA server details will be automatically saved in the **OPC settings** fields. If the OPC server system is not connected to the local system at the time of configuring the port then the **OPC Prog ID** and **OPC CLSID** fields may be either manually entered, or left blank until commissioning time. However they must be entered at some time before the system is commissioned.

7.1.7 Redundancy

The DCC Host service supports redundant communications to gauges using a pair of communication ports (Physical COM ports, modems or Network connections).

Any ports that are to be used as part of a redundant communications system should have their **Redundancy Settings** field set to one of the following:

- **Switch By Interface** – where gauges will only switch to the Backup COM port if ALL gauges have failed on that interface
- **Switch By Gauge** – where gauges will switch individually
- **Switch By System** – where two systems (i.e. NXA83B) are connected by Redundant Control Links and only one system will poll the gauges at one time

After the interfaces have been configured, gauges may be configured with redundant operation. To do this, select the gauge in the **Gauge Configuration** screen in Tankvision Multi Scan Configurator, then set the **Comm Port** fields to the desired Primary Interface Comm Port and Backup Interface Comm Port.

NXA83_Device-Configuration_Comm-Port_Primary_Backup

- 1 Primary Interface Comm Port
- 2 Backup Interface Comm Port

Switch By System Redundancy

For **Switch By System** redundancy, two extra ports are required, and **MUST** be configured as:

- 1 DCC Host port configured as a **Redundant Link Control** protocol
- 1 DCC Slave port configured as a **Redundant Link Control** protocol


When the gauges are configured, they **ALL** must have the **Backup COM** port set to be the Host Redundant Link Control port.

In operation the Host Redundant Link Control is connected to the Slave Redundant Link Control of the other system, and vice-versa.


7.2 Configuring protocols

Most of the Slave protocols (Modbus, Enraf etc.) and some Host protocols (Modbus TG) require extra configuration that is specific to the protocol.

To configure any protocol specific data, select either the **Modbus TG Configuration** or the **DCC Slave Configuration** item from the **Communications** menu



Modbus TG Configuration Screen



Refer to the separate DCC configuration manual for details on configuring the protocol data.

7.3 Gauge Configuration

The Multi Scan NXA83B must be configured for all gauges which will be used in the database.

This consists of defining data for each gauge, such as name, type, COM port etc., and is carried out using the **Gauge Configuration** tool.

7.3.1 Gauge Configuration

To launch the Gauge Configuration tool, select **Gauge Configuration** from the **Communications** menu. The Gauge Configuration will hold any gauges/field devices that are already configured, for review or editing of their settings. Alternatively, the form will be empty if no gauges/field devices have been configured yet.

Each manufacturer's gauge has different basic requirements for configuration. A knowledge of the different makes and models of gauges is useful at this stage although not essential, provided that the characteristics of the actual gauges present in the system are known. The following instructions do not provide an exhaustive guide as to the valid options and selections for each type of gauge; rather instruction is given as to the way in which the information is entered into the system. Application notes and manufacturer's literature should be consulted for further information.

i Some fields will only be displayed if certain options are selected. These include the **Gauge Duty**, **Slave Datacon/Port Address** frames which will only be displayed if their respective options are selected.

The form displays the configuration of one device (such as a gauge) at a time. The buttons on the lower left of the form navigate through the list of gauges. The < and > buttons move one gauge back or forward respectively. The |<< button moves to the first gauge and the >>| button moves to the last. The **Device Number** drop-down list provides an alternative means of navigating directly to a particular gauge. The Device Numbers are allocated automatically by the system as new gauges are added, generally in order of creation, and cannot be edited by the user.

To add a new device to the list, click on the **Add** button. A new blank entry will be displayed and the editing features will be enabled. Alternatively, a new gauge may be added to the list by copying an existing one. In this case, click on the **Copy** button and then select the gauge from which the copy should be made. This will produce a new entry and the editing features will be enabled, but the displayed settings will replicate those of the gauge from which the copy was made. The effect of adding a gauge to the configuration will usually be to add a corresponding tank to the Multi Scan NXA83B display, unless the gauge is part of a multi-gauge setup.

To delete an existing device, click on the **Delete** button. Doing so will remove the corresponding tank from the Multi Scan NXA83B display unless the device is part of a multi-gauge setup.

To edit the configuration of an existing device, navigate through the list to the desired device and then click on the **Edit** button.

The buttons at the right side of the form will be enabled (black text) or disabled (greyed out) depending upon the context of what stage in the configuration the user is at. For example, the **Save** button will be enabled whenever any setting for the currently displayed device is changed, prompting the user to apply any changes before moving on to another device. A message box will be displayed as a further reminder to apply changes.

Closing the tool by means of the **Exit** or **×** button or selecting a different device without first saving will discard any changes made. To discard any erroneous changes made whilst editing the configuration of a device, click on the **Cancel** button.

When configuring a new device, it is recommended to progress through the selections and options in column order, starting by working down the left column. Certain selections, e.g. **Device Type**, will affect the appearance and data entry requirements of other settings and options further down the column and may "clear" any current settings in preparation for the user's new entries.

The following fields are not required for the Multi Scan NXA83B: **Master Datacon Name**, **Datacon Gauge Index**, **Slave Datacon Name** and **Port Address**, and the last three fields will only be displayed if a **Master Datacon Name** is specified.

The **Device Type** drop-down list provides a selection of gauges and field devices of various models from various manufacturers. Select the one that matches or most closely resembles the actual gauge or device which will be connected. Note that the selection affects the way in which the communications of the Multi Scan NXA83B behaves.

The **Tank Id** entry links the gauge to a tank in the Multi Scan NXA83B system. Typically, each gauge will be associated with a unique tank, though in the case of multi-gauge setups there will be a number of gauges all fitted to the same tank and thus share a common Tank ID.

Comm Port is the number of the port on the Multi Scan NXA83B to which the the gauge itself is connected. There are two fields for the Comm Port. The left hand field is the main COM port used for communications, and should always have a value entered. The right hand field is only required for redundant systems, and specifies the **Backup Comm Port**.

The selections for **CIU Address** and **Gauge Address** (or their corresponding names in the case of other types of gauges/devices) will depend upon not only the **Device Type** but also the way in which the gauge is connected. Typically, the **CIU Address** is the address of the device which the system or Datacon communicates with, and the Gauge Address is the address, register or location from which the level may be read. The data format of the entries

(e.g. decimal/hexadecimal) will also be determined by the **Device Type**. The following examples should illustrate the typical scenarios:

- Enraf systems may include a CIU or may communicate directly with the gauges themselves. The level is read from the gauge using one of a number of specific requests. The **CIU Address** will be that of the actual CIU (if present) as a decimal number in the range "0" to "9", and the **Gauge Address** will be the Transmission Address of the gauge as a decimal number in the range "0" to "99".
- SAAB systems may also include an interface unit; this time called a FCU, or may communicate directly with the gauges. Here, the level is read from one of a number of different Modbus registers within the FCU (if present) or the gauge. The **FCU Address** will be the Modbus Slave Address of the FCU (where present) or the gauge (direct communications without FCU) as a hexadecimal number in the range "01" to "F7". The **Gauge Address** is the Modbus Register Address from which the level will be read as a hexadecimal number in the range "0" to "FFFF". Other types of gauge that use the Modbus protocol will also follow this same pattern.
- Whessoe systems fall into two basic types, the older of which uses a communications Outstation. The **Outstation Address** is specified as a decimal number in the range "0" to "15", and the Gauge Address specifies the outstation channel from which the level is read as a decimal number in the range "0" to "15". Later Whessoe systems do not use an outstation; communication is directly to the gauge. In this case only the **Gauge Address** is required and is specified as a decimal number in the range "0" to "31".
- Motherwell systems only use the **Gauge Address** setting, whether as an index number when requesting level from a communications rack or as a field address when communicating directly with later type gauges. The Gauge Address is a hexadecimal number in the range "0" to "FF".

Gauges of other manufacturers/types will generally fall into one of the above categories. If in doubt, consult the gauge manufacturer's literature and the Datacon configuration application notes.

In the case of systems that use the Datacon for field communications, the **Datacon Gauge Index** is the address or "position" within the internal configuration database of the Datacon where this gauge will reside. The positions are addressed from 0 to 255. Each gauge must have a unique Tank Address, which for convenience should normally be set the same as the Gauge Number. This field is not normally required for a Multi Scan NXA83B.

The **Type Of Instrument** and **Type Of Record** selections are only required for certain gauge types which offer different protocols or requests for level. For example, Enraf; where the Type Of Instrument specifies the protocol ("A" = GPP, "B" = GPU, etc.) and the Type Of Record specifies the request used to read level from the gauge (typically "B").

If the gauge is one of a number of gauges all fitted to the same tank, select **Multi-Gauges**. An additional frame will be displayed wherein the **Gauge Duty** should be selected. There should be only one Primary Gauge on each tank, the others should be Secondary Gauges or used for other specific duties as listed.

Certain gauges which are provided with multi-element averaging or multi-spot temperature measurement may allow the individual element temperatures to be read via the communications. If this feature is available and desired, select **Average Temp. Fitted**.

Certain gauges which are provided with skin temperature measurement may allow the individual temperatures to be read via the communications, up to a maximum of 250 elements. This feature is normally only available on LNG tanks and is used in combination with an auxiliary gauge. If it is available and desired, select **Skin Temp. Fitted**.

To alter the response of the level flow rate measurement by the system, and consequently the volume and mass/weight flow rates, two parameters are available for user configuration.

The **Flow Rate Damping** factor is a measure of how much of the current instantaneous flow rate reading is incorporated into the filtered value, as a percentage. Increasing the figure increases the responsiveness of the resulting flow rates but reduces the effective damping. The **Flow Rate Integration** factor is a time in seconds, up to 240 seconds maximum (four minutes), used to increase the effect of damping where the level readings/flow rate calculations are performed at shorter intervals depending upon the number of gauges present on the particular communications port.

The **Background Scan/Auxiliary** settings are used to read data parameters other than Product Level from the gauge at lesser frequency than the level. Product Level is the primary data item and is the default item polled from the gauge by the system. Polls for other items may be inserted periodically by the system dependent upon the settings of the **Background Scan/Auxiliary** items. Where used, **Auxiliary 1** is assumed to be for Product (Average) Temperature, and is typically polled at half to quarter of the rate of Product Level. The other items **Auxiliary 2** to **Auxiliary 16** are inserted into the normal polling sequence at three minute intervals. These would typically be used for live Free Water, Density, Vapour Pressure, Vapour Temperature etc. The format of the Auxiliary entry will depend upon the gauge type:

- For **Enraf gauges**, the Auxiliary entry is formed of the two digit decimal Transmission Address of the device from which the item is to be read (usually the same as the Gauge Address) in the range "00" to "99" including any leading zeros, followed by the one or two character alphanumeric code of the data item as per the Enraf GPU protocol. A single letter appended to the address will be interpreted as a Type Of Request, whereas a two character code will be interpreted as a Data Item identifier for a Z Record request. As in the example displayed above, **Auxiliary 1** is set to request a C Record (Product Temperature), **Auxiliary 2** will request Data Item YB (Free Water Level) and **Auxiliary 3** will request Data Item SC (Average Servo Density). All of these auxiliary items will be requested from address 04, that being the same as the Gauge Address.
- For **SAAB gauges**, the Auxiliary items should be set to the Modbus Register Address of the desired data value as a four digit hexadecimal number in the range "0000" to "FFFF", including any leading zeros.
- Where gauges provide Product Temperature in a combined response along with Product Level, as is the case with **Whessoe** and **Motherwell gauges** for example, there is no need to set the **Auxiliary 1** item to specifically request temperature.

The Multi Scan NXA83B will assume that any values read from the gauges/field devices are in Metric units unless the system is able to determine the measurement units of the gauge/field device automatically via the communications. If this is the case, the Change Dimensions entries should be left in their default setting of **AUTO**. With certain gauges, the system must be configured specifically to match the measurement units of the data from the gauge by selecting the appropriate units of measure from the drop-down lists.

Once all settings for the gauge have been configured, always remember to apply the settings by clicking on the **Save** button before moving to another gauge.




DO NOT USE the **Download** button as it is not operational in the Tankvision Multi Scan Configurator software. There is a separate Database Transporter program to download the database to the Multi Scan NXA83B.

Once all configuration has been completed, click on **Exit** to unload the Gauge Configuration tool.

7.3.2 Multi Gauges

Tanks may be fitted with more than one gauge, for enhanced reliability. For example most LNG tanks will typically have two level gauges, one alarm gauge and one densitometer device fitted. To configure multiple gauges for a tank, perform the following in the **Gauge Configuration** screen:

1. Enter the same **Tank Id** for each gauge.
2. Tick the **Multi Gauges** box, this will display the **Gauge Duty** panel.
3. Select the appropriate duty from the **Gauge Duty** panel.



NXA83_Device-Configuration_Multi-Gauges-Steps

- 1 Drop Down Menu: Tank ID
- 2 Tickbox: Multi Gauges
- 3 Drop Down Menu: Gauge Duty

For multi-gauge tanks most configuration data entered for the tank will be saved for all the gauges on that tank. This applies to data entered in the **Tank Characteristics** and the **Alarm Configuration** screens. Consequently, when a programmable alarm is triggered on a multi-gauge tank, an alarm event will be generated for each gauge on the tank.

Data entered in the **Manual Data** screen only applies to an individual gauge.

The **Gauge Duty** defines how the gauge will be treated in the various operator displays. Most of the default screens supplied with the NXA83B are configured to display the primary gauge data. However they may be configured to show data from any other duty.

The available gauge duties are listed below.

Primary

One gauge must be configured as the primary duty gauge. This is the normal gauge used to display tank data in the operator screens.

If a Densitometer duty gauge is also present on a tank then the Product Density and Observed Temperature will be automatically be copied from the Densitometer to the primary.

Only one Primary gauge may be configured per tank.

Secondary

If a second level gauge is required on a tank, e.g. for redundancy purposes, set the duty of this gauge to Secondary. The secondary gauge may be added to the displays as required and may be accessed via Modbus and OPC interfaces. If the Difference Alarm is enabled for a tank, it monitors the Primary and Secondary gauge levels and generates an alarm if they differ by more than the preset tolerance.

Only one Secondary gauge should be configured per tank.

Backup

Any further level gauges on a tank should be configured as Backup duty. These may be added to the displays as required and may be accessed via Modbus and OPC interfaces. The alarm gauge in an LNG tank should be configured as Backup duty.

Densitometer

This duty is only required for LNG tanks. Densitometer is used for devices such as the Scientific Instruments 6280/6290, although any gauge capable of carrying out profiles may be configured as a densitometer. The main purpose of Densitometer gauges is to carry out profiles and calculate the product density, which is then automatically transferred to the primary gauge for volume calculations.

Auxiliary

An auxiliary gauge is different from all other gauge duties. It is not treated as a separate gauge, instead it is used to retrieve background scan parameters (pressures, temperatures, water bottom etc.) from a separate device and store them in the Primary gauge.

An auxiliary gauge will not poll for level, generate alarms or be displayed in the operator screens. It is typically used on a Modbus TG interface to access parameters from devices such as pressure transducers. All data retrieved from an auxiliary gauge will be transferred to the Primary gauge and used in the volume calculations.

Parameters that may be polled on an auxiliary gauge include:

- Product Temperature
- Vapour Temperature
- Density
- All Pressures
- Multi-Element temperatures (not transferred to Primary)
- Skin Temperatures (not transferred to Primary)
- Water bottom

7.4 Tank Characteristics

Tank Characteristics enables the user to configure the tank details. The Tank Characteristics module can be loaded at any time to perform tank detail changes.

A number of the data items in the Tank Characteristics module are important to the tank inventory calculations. It is therefore essential that they are configured correctly.

The tank characteristics module is a multi-tabbed data entry form where data has been organized into logical groups.

The groups are:


- Tank Details
- Roof Details
- Shell Correction
- Miscellaneous
- Inventory Control Settings

Some values that appear within the Tank Characteristics module are dependent on other settings. Indeed some fields are not visible or enabled until they are called for by the setting of another parameter.

7.4.1 Launching Tank Characteristics

1. Select the **Tank Characteristics** option from the **Configuration** menu.

The following display is typical of what will be loaded. The Left pane will contain the list of all tanks programmed into the Multi Scan NXA83B. The configuration characteristics for each tank can be accessed by expanding the menu tree and selecting the required item.



OK, Apply, and Cancel buttons are provided.

The **Forward** and **Back**  buttons can be used to move through the history of edited pages.

7.4.2 Modifying Data Within Tank Characteristics

Select the tank to be modified from the list and expand the menu tree. Any number of tanks may be expanded at any time. Click on the data group to be modified. The current details for the tank will be displayed.

 Tank Characteristics will contain default values the first time it is loaded after installing the system. It is essential that **default values** are replaced with correct operating values.

Select the field to be edited and enter/select the new data.

Each field is validated both during data entry and just before the data is saved to the database.

You can use the **TAB** key to move to the next data entry field.

You can move freely between configuration groups to edit/review them by selecting the required group from the Left pane. This is useful for making comparisons of tank details.

Changes can be abandoned by clicking the **Cancel** key or clicking  to close the **Tank Configuration** window. A window will pop up requesting confirmation.



Click **Yes** to save any changes and exit, **No** to discard any changes and exit or **Cancel** to return to **Tank Characteristics** to review or continue configuration.


Click the **Apply** button to have the changes to the database take effect. This will leave the window open.

Clicking the **Save** button will save any changes and close the **Tank Characteristics** window.

Data Item Definitions

The following sections provide definitions for each of the data fields within each group of the **Tank Characteristics** module.

Tank Details



Tank Shape – Specifies the physical shape of the tank. Four principle tank shapes are supported:

- **VC**: Vertical Cylinder
- **VCFR**: Vertical Cylinder with Floating Roof
- **SP**: Sphere
- **HZ**: Horizontal Cylinder

There are other similar tank shapes. However, most should fall into one of the above types. Vertical Cylinders that have internal floating blankets/decks should be configured as VCFR.

It is essential that the tank shape is entered correctly as this affects the inventory calculation algorithms.

Product – Select from the list of available products in the drop down menu. Details of how to configure products can be found in the relevant section later in this manual.

API/ASTM Table – The API table is related to the product that will be stored in the tank. It defines the method and operating ranges for certain characteristics of the product. Products are broadly arranged into a number of recognized API tables.

It is essential that the API table is entered correctly as this affects the inventory calculation algorithms.

Vapour Calculation – Specifies the vapour correction calculations that will be performed as part of the inventory calculations. **None** means that no vapour correction will be performed.

Max Operating Level – This defines the maximum operating level of the tank. The accuracy of this value is important as it is used to determine the maximum operating volume and consequently the amount of Ullage Volume (Available Room) in the Tank.

Min Operating Level – This defines the minimum operating level of the tank. The accuracy of this value is important as it is used to determine the minimum operating volume and consequently the amount of Usable Volume in the Tank.


Reference Height – This is the Ullage Zero level used as an alternative to maximum operating level for product. This is used to set the maximum operating volume and consequently the amount of Ullage Volume (Available Room) in the Tank.

Min & Max Operating Volume – Are read-only fields provided for your reference.

Roof Details

The **Roof Details** section is only relevant to floating roof tanks i.e. those that have been defined with a tank shape of VCFR.

This section is disabled for all other tank shapes.



NXA83_Tank-Characteristics_Roof-Details

Leg Position

Some floating roofs have legs which may be set at two positions, thus altering the level at which the roof floats or is supported on the legs. Since the legs are usually attached to the floating roof, the **Up** position of the legs allows the roof to descend to a lower level in the tank, and is the setting used in normal operation. The **Down** position causes the roof to become supported on its legs at a higher level and is the setting used for maintenance purposes.

Where a tank has a floating roof with fixed or one - position legs, it is advisable to set the "Legs Up" and "Legs Down" levels to be the same so that the Leg Position selection becomes inconsequential.

Selection of Leg Position in the Multi Scan NXA83B has **no effect** on the actual position of the legs in the tank. The purpose of this field is to select the appropriate correction data for the leg position set within the tank.

Weight – The weight of the floating roof (including any attached legs). It is important that this figure is accurate as it will be used when calculating compensation for the displacement of the product by the weight of the roof.

Roof Floating Legs Down - The point at which the roof just ceases to be resting on its legs when the legs are in the "down" or maintenance position, such that the entire weight of the roof is being supported by its buoyancy in the product. Above this level, compensation is made for the displacement of the product by the full weight of the roof.

Roof Support Legs Down - The point at which the roof legs are supporting the full weight of the roof when the legs are in the "down" or maintenance position. Below this level, no compensation is made for product displacement caused by roof weight.


Roof Floating Legs Up - The point at which the roof just ceases to be resting on its legs when the legs are in the "up" or operational position, such that the entire weight of the roof is being supported by its buoyancy in the product. Above this level, compensation is made for the displacement of the product by the full weight of the roof.

Roof Support Legs Up - The point at which the roof legs are supporting the full weight of the roof when the legs are in the "up" or operational position. Below this level, no compensation is made for product displacement caused by roof weight.

The area between the Fully Supported and Fully Floating levels is generally referred to as the roof transition zone. Between these levels it is difficult to determine the proportion of the roof's weight which is being held by the legs and therefore difficult to calculate the displacement of product by the roof. For this reason this region of the tank is normally avoided during normal operation.

Shell Correction

These settings are only relevant if you have enabled shell correction in **Inventory Control Settings**.



NXA83_Tank-Characteristics_Shell-Correction

Shell Insulation Factor – 1 for completely insulated storage, 0 for un-insulated storage, a typical value is 0.875.


Shell Expansion Coefficient – Expansion coefficient of the material the tank is constructed from, e.g. mild steel = 0.0000112.

Shell Reference Temperature – Normally the same reference temperature used for VCF calculations (typically either 15 °C or 30 °C).

Manual Air Temperature – Tick to enter the air temperature manually, do not tick if a gauge is fitted that can provide an automatic air temperature.

Miscellaneous


This section is provided for operators to note additional information about the tank. These are housekeeping features that do not affect the behavior of the system.



NXA83_Tank-Characteristics_Miscellaneous

Inventory Settings

The settings on this page control the way the inventory calculations are performed. The default settings are modified by clicking on the arrow and selecting a new setting from list. A table of available settings is shown below.



NXA83_Tank-Characteristics_Inventory-Settings

Setting 1	Setting 2	Description
Gauge Levels are Innage	Gauge Levels are Ullage	The levels returned by the gauge are innage (referenced from the bottom) or ullage (referenced from the top)
Ullage Level zero = Max. Operating Level	Ullage Level zero = Reference Level	Zero ullage is taken as the highest safe working level or the maximum height of the tank
Gauge reads Reference Density	Gauge Reads Observed Density	Use this setting with care! When set the inventory calculator derives the reference density from the observed density information, if you enter manual densities be aware of whether you enter a reference density or an observed density.
Gauge Reads Density in Vacuum	Gauge Reads Density in Air	When set an allowance for the density of air will be made during inventory calculations.
Gauge Reads Absolute Pressure	Gauge Reads Relative Pressure	Internally pressures are stored in Bar absolute, checking this option will cause the pressure stored to be calculated from the gauged value.
Display Innage Level	Display Ullage Level	Causes levels displayed to be switched between innage and ullage.
Roof Weight Specified in Air	Roof Weight Specified in Vacuum (mass)	If you know the mass of your floating roof, set to Roof Weight Specified in vacuum.
Tonnes/hour flow rate specified in Air	Tonnes/hour flow rate specified in Vacuum	Check this if you want a mass flow rate as opposed to a weight flow rate.
Disable tank shell correction	Enable tank shell correction	Select to perform tank shell correction calculation. Enter shell correction information on the relevant tab in this module.
No hydrometer correction in Vcf	Apply hydrometer correction to VCF	Set according to whether hydrometer correction is required or not.
WCF uses Table 56 calculation	WCF uses fixed 0.0011 kg/l	Select this to use a calculated WCF, which gives better accuracy when calculating WCF.
Use IP calculation of TOV/GOV	Use API calculation of TOV/GOV	Set if you wish to use American (US) style calculations, which perform the floating roof and free water corrections at a different stage to the British calculations.
No suspended sediment and water	Include suspended sediment and water	Set if you want include sediment and water correction in your inventory calculations.
No separate sediment calculation	Separate sediment and water calculations	Set to enable separate sediment and water correction calculations.
Water density 1.000 kg/l for fresh water	Water density 1.020 kg/l for sea water	Set according to whether the water you have in your tanks is fresh or sea water.
Tank calculated as hydrocarbon storage	Tank calculated as ballast/slops storage	When set movements in and out of the tank are assumed to leave a constant oil depth and vary the amount of water in the tank.
Use vapour temperature in vapour correction	Use product temperature in vapour correction	Select temperature source for vapour correction calculations.
Average gauge temperature is product temperature	Average gauge temperature is vapour temperature	This option allows an Auxiliary Vapour temperature field to be used for a Product temperature gauge.

7.5 Tank Strapping Data Configuration

7.5.1 Tank Strapping Data Configuration Introduction

If the Multi Scan NXA83B is to be used to calculate tank inventory it will need to be configured with a strapping (Tank Capacity) table for each tank.

The Tankvision Multi Scan Configurator software comes equipped with a Strapping table module that allows the user to load, remove, edit and display tank strapping tables.

Each strapping table needs to be provided in a comma separated values (.csv) text file. The Strapping table module can extract the data from the text file and load it into the strapping table database.

i The accuracy of the volumes calculated by the Multi Scan NXA83B is only as good as the accuracy of the tank strapping points provided. It is therefore recommend that care is taken when selecting the points for entry. Where possible the original tank strap points should be entered to achieve highest accuracy. The maximum number of points that can be entered is 3000.


If the original tank strap points are not available Endress+Hauser can deduce these points from the full calibration table. This is made substantially easier if the tank calibration data is available on disk in a spreadsheet format.

7.5.2 Using the Strapping Table Utility

The strapping table utility is accessed by selecting **Configuration → Strap Tables** from the Tankvision Multi Scan Configurator window.


7.5.3 Loading the Strapping Table Module

Select **Configuration → Strap Tables** from the Tankvision Multi Scan Configurator window. The Strapping Table module, below, will be loaded.




7.5.4 Adding a New Strapping Table

Select **Table → New** from the menu bar. Enter a Tank ID and click **OK**.




NXA83_Strapping-Chart_New-Strapping-Table

A new screen will be displayed with options for creating strapping points in the new table.



NXA83_Strapping-Chart_Create-new

If a file containing the strapping table is available in comma separated values (.csv) format select **Import Strapping Table**. Browse for the file location in the next window, select the file and click **Open**.



NXA83_Strapping-Chart_Import-Strapping-Table

If no file is available select **Create new strapping table**. This will enable manual entry of strapping data in the screen editor table to the Left of the Strapping Chart. A new line is automatically added to the end of the table when the last line is populated. As values are entered into the table they are simultaneously plotted onto the Strapping Chart. This is a useful aid to spot any erroneous data. The plotted characteristic should be almost linear for Vertical Cylindrical tanks. Lines can be Added or Deleted from the table by Right Clicking on the start of the line at the point in the table where a line is to be Added/Deleted.


Strapping Data may be entered at a later date; in this case select **Leave it for now**.

When the strapping table is complete, save the changes to the database by clicking on the  button.

The Strapping Table Module can be closed by selecting **Table → Exit** or by clicking on the  button.

7.5.5 Viewing Existing Tables

1. Load the Strapping table module as described in the previous section.
2. Select the table to be viewed from the drop down **Tank Id** menu.



If the strapping table has been created, the data values are displayed as a list on the Left and plotted as a graph on the Right, as in the example above. The characteristics of the graph are useful for spotting erroneous data.


If the selected tank has no strapping table you will be prompted with the Strapping Chart dialog box as if creating a new table.

7.5.6 Editing Values in an Existing Strapping Table

1. Start the Strapping Table configuration module.
2. Select the tank for which the strapping table is to be edited. The table will be populated with the existing data.
3. Select the item to be edited.
4. Type a new value and move off the row to save the changes locally to the table.
5. To save the changes to the database press the **Save** button .
6. If the **Exit** button is used prior to pressing the **Save** button, you will be prompted to save the data.

Inserting an Extra Row

1. Select the row at which a record needs to be inserted by clicking with the left mouse button the left hand side of the row.
2. Right click and select **Insert** from the pop-up menu.
A new row will be inserted above the selected row.
3. Enter **Level** and **Volume** for the new row.



4. Repeat the above procedure if more rows are to be added. When finished click on  to save the changes to the database. The Multi Scan NXA83B will automatically arrange the rows in order of ascending **Level**.

If an invalid entry has been made in a row the following box will pop up, prompting the user to review the table.



Deleting Rows

1. Select the row which needs to be deleted by clicking with the left mouse button at the left hand side of the row.
2. Right click and select **Delete** from the pop-up menu. The row will be deleted.
3. To save the changes to the database press the  button.

7.5.7 Validity of Data

The Tankvision Multi Scan Configurator software attempts to check the validity of the data entered when the user presses the **Save** button.

For example, all data entered into the **Level** column has to be in ascending order of magnitude. Also no two rows may contain the same value for level.

7.6 Alarm Configuration

7.6.1 Alarm Configuration

An integrated part of the Tankvision Multi Scan Configurator application is the Alarm Configuration module.

This module provides the user with a multi-tabbed data entry display for the entry and configuration of programmable alarms.

A wide range of programmable alarms have been provided with the Multi Scan NXA83B to ensure that the operator/user has sufficient control over product movement.

All the alarms are organized into logical groups each being assigned a different tab within the display.


The main alarm groups are:

- Movement Alarms
- Gauge Alarms
- Programmable Level Alarms
- Programmable Temperature Alarms
- Miscellaneous Alarms

The alarm configuration module is launched by selecting the appropriate tool bar button.

7.6.2 Launching Alarm Configuration


Select the **Alarm Configuration** option from the **Configuration** menu. The following display is typical:



NXA83_Alarm-Configuration

Expand the Tank to show the different types of alarms that can be configured. Select one of the alarm groups.

Movement Alarms



NXA83_Alarm-Configuration_Use-Smoothing-for-Movement-Alarms


Use Smoothing for Movement Alarms – Tick this box to apply smoothing to the volume used to test for the Unauthorised Movement Alarm and the Theft Alarm. The smoothing uses the same parameters entered for the flow calculations, i.e. Flow Rate Damping and Flow Rate Integration. These are entered in the **Gauge Configuration** screens.

Theft Alarm

This option is currently not supported.

Unauthorised Movement Alarm

This alarm is often referred to as a Leak Alarm although it applies equally to a gain or a loss of product. The Multi Scan NXA83B refers to these as unauthorized movements.




NXA83_Alarm-Configuration_Unauthorised-Movement-Alarm

The unauthorized movement alarm is intended to protect against inadvertent movement of product in static tanks. This alarm should be enabled when the tank is to remain static. The

current GSV for the tank is stored when the alarm is enabled. If the GSV in the tank change beyond the specified threshold limit the alarm will be triggered. The alarm should be disabled when performing authorized movement of product into or out of the tank.

Threshold – The volume of product by which the GSV must vary before an Unauthorized Movement alarm will be raised.

Flow Alarms




The flow alarms are intended for use when tanks are moving. They are useful to detect that flow has exceeded a tank or pipeline design limit or that flow has reduced or stopped perhaps due to some fault.

The high flow alarm will be generated when the current calculated flow rate exceeds the **High Flow Alarm** limit and where the flow is positive (i.e. into the tank), the product level is above the **Rising Hold Off**, or where the flow is negative (i.e. out of the tank), the product level is below the **Falling Hold Off**.

- **Enabled** – Tick the box to enable the Flow Alarms.
- **High Flow Alarm** – The maximum allowable flow rate before High Flow Alarm is triggered.
- **Low Flow Alarm** - The minimum allowable flow rate before Low Flow Alarm is triggered.
- **Hysteresis** – The amount a flow rate needs to change beyond the setpoint to cancel an alarm.
- **Rising Hold Off** – The High Flow alarm will not be generated below this product level when the tank is filling.
- **Falling Hold Off** - The Low Flow alarm will not be generated above this product level when the tank is emptying.

Gauge Alarms



NXA83_Alarm-Configuration_Gauge-Alarms

Gauge alarms are generated by the gauging instrument. The alarm levels displayed on this screen are for reference purposes only.


On some modern technology gauges it is possible to read the gauge alarm settings from the gauge automatically. On older gauges where this is not possible, provision is made to enter the Gauge alarm values manually.

 Since the tankgauging software does not set the Gauge alarm levels, detection of gauge alarms is determined by the gauging instrument. The Multi Scan NXA83B reads the status of the alarm bits transmitted to it by the gauge and if necessary raises an alarm.

Gauge alarm levels are normally set by the gauge commissioning engineer.

- **Gauge Alarm High High:** The gauge high high level alarm setting
- **Gauge Alarm High:** The gauge high level alarm setting
- **Gauge Alarm Low:** The gauge low level alarm setting
- **Gauge Alarm Low Low:** The gauge low low level alarm setting

Programmable Variable Alarm



NXA83_Alarm-Configuration_Programmable-Variable-Alarm


The Programmable Variable Alarm is used to trigger an alarm when the level gets above or below a set point, dependent upon the direction of flow.

The programmable variable alarm is an additional level alarm provided for use on moving tanks, it incorporates a configurable "advanced warning" alarm to indicate that product level is nearing the alarm level set point.

The user configurable fields are:

- **Enabled** – Tick the box to enable the alarms.
- **Level** – The point at which the level alarm is triggered.
- **Hysteresis** – Amount by which Level must fall/rise (dependent upon flow direction) to cancel alarm.
- **Time To Target** – Amount of advanced warning before level alarm point will be reached. The remaining time is calculated from the flow rate and an alarm will be raised at the specified time.
- **Time To Target Hysteresis** – A hysteresis value to compensate for fluctuations in flow rate.
- **Direction** – Alarms are dependent upon flow direction. Set the arrow to indicate the direction of flow; Up for Receipts (tank filling) and Down for Loading (tank emptying). Double click on the arrow to toggle direction.
- **No Flow Volume** – An alarm is raised if the Volume flow rate falls below the value entered here.
- **No Flow Cons. Time** – The "Consideration" time for the No Flow Volume alarm. When a movement starts no alarm will be raised for the period specified to allow the flow rate to stabilize.

Programmable Level Alarms



Programmable level alarms are triggered by the level returned from the gauge. They can be used where hardware alarms are not available or used in addition to the gauge hardware alarms.

The programmable level alarms have equivalent gauge level alarms. The programmable alarms would normally be used as early warnings to the gauge alarms and would be set slightly below (high alarms) and slightly above (low alarms) their respective gauge alarm values.

The configurable fields are:

- **Enabled** – Tick the box to enable the alarms.
- **High High** – Enter a value for the High High level alarm.
- **High** - Enter a value for the High level alarm.
- **Low** - Enter a value for the Low level alarm.
- **Low Low** - Enter a value for the Low Low level alarm.
- **Hysteresis** – Enter a value to compensate for minor fluctuations in level.

The term **High High** is normally associated with the extreme upper limit to which a tank would be filled. Under normal operating conditions it would be unusual to trigger this alarm. This will raise a severity "Critical" alarm.


The term **High** is not as extreme as **High High** and is normally set a small distance below the **High High** limit. This will raise a severity "High" alarm.

The term **Low Low** is normally associated with the extreme lower limit to which a tank would be emptied. Under normal operating conditions it would be unusual to trigger this alarm. This will raise a severity "Critical" alarm.

The term **Low** is not as extreme as **Low Low** and is normally set a small distance above the **Low Low** limit. This will raise a severity "High" alarm.

The programmable level alarms can be configured to alarm for any purpose, the only stipulation is that they must be configured in level order (i.e. a Low alarm may not be set higher than a High alarm) however it is recommended that they are used within the context of the definition of the alarm to avoid confusion.

Programmable Temperature Alarms




Programmable Temperature alarms are triggered by the temperature returned from the gauge.

The configurable fields are:

- **Enabled** – Tick to enable alarm.
- **High** – Set a temperature to trigger a High temperature alarm.
- **Low** - Set a temperature to trigger a Low temperature alarm.
- **Hysteresis** - Enter a value to compensate for minor fluctuations in temperature.

Programmable Water Alarms




NXA83_Alarm-Configuration_Programmable-Water-Alarms

Water alarms are triggered when tank water levels exceed the specified limits. The water level can be returned from a Water dip using a Level gauge or from a dedicated water level gauge.

The configurable fields are:

- **Enabled** – Tick the box to enable the alarms.
- **High** - The free water level, above which the alarm will be triggered.
- **Low** - The free water level, below which the alarm will be triggered. The Low level water alarm may be disabled by configuring a negative set point.
- **Hysteresis** – Enter a value to compensate for minor fluctuations in level.

Difference Alarms



NXA83_Alarm-Configuration_Difference-Alarm


For applications where an accurate product level measurement is critical a tank may have 2 level gauges. One gauge will be nominated as Primary duty with the other as a Secondary gauge.

The Multi Scan NXA83B will monitor the level returned from both gauges and can check for a difference between the two gauge levels. If the difference exceeds the tolerance entered for this alarm a difference alarm will be generated.

The configurable fields are:

- **Enabled** – Tick to enable the alarm.
- **Allowable Tolerance** – Enter the maximum allowable difference between the 2 gauge levels.
- **Hysteresis** – Enter the value required for hysteresis.

Deviation Alarms




NXA83_Alarm-Configuration_Deviation-Alarm

The deviation alarm is used to alert operators to layering occurring within a tank. When two consecutive profile points deviate by the specified amount, in their density readings or temperature, an alarm will be generated. This alarm requires the use of gauges capable of returning density profiles.

The configurable fields are:

- **Enabled** – Tick to enable the alarm.
- **Density Profile Deviance** – Enter the maximum permissible difference between consecutive density points.
- **Temperature Profile Deviance** - Enter the maximum permissible difference between consecutive density points.

Programmable Density Alarms




NXA83_Alarm-Configuration_Programmable-Density-Alarms

These are operator programmable density alarms.

The configurable fields are:

- **Enabled** – Tick to enable the alarm.
- **High** – Enter a value for the maximum permissible observed density.
- **Low** – Enter a value for the minimum permissible observed density.
- **Hysteresis** – Enter a hysteresis value for density measurement alarms.

Floating Roof Alarm



NXA83_Alarm-Configuration_Floating-Roof-Alarm


Under normal operating conditions this is generally undesirable for a floating roof to rest upon its legs. The Floating Roof alarm provides the option of generating a warning when the product level is approaching the point where the roof starts to rest on its legs.

When enabled, the Floating Roof Alarm will be activated when the product level falls below the Roof Early Warning Level. The alarm will be cleared when the product level rises above the Roof Early Warning Level by more than the Roof Warning Hysteresis.

- **Enabled** – Tick to enable.


- **Roof Early Warning** – Enter the level where the alarm will be generated. The level would normally be programmed above the Roof Fully Floating level set in the Tank Characteristics module.
- **Roof Warning Hysteresis** – Enter the distance by which the product level must return above the Roof Early Warning Level in order to clear the Roof Early Warning Alarm.

User Defined Alarms (Programmable)



NXA83_Alarm-Configuration_User-Defined-Alarm

User Defined Alarms are a set of additional Programmable alarms. There is a choice of 24 alarm types selectable from the drop down menu. These are simplified alarms with only a setpoint and hysteresis that can be configured. The units for the entry fields are automatically set when the type of alarm is selected. There is a **Description** field to enter text which will be displayed in the Alarm Event Viewer when the alarm is triggered. There are eight User Defined Alarms available.



NXA83_Alarm-Configuration_User-Defined-Alarm_Level-High

7.6.3 Modifying Data Within Alarm Configuration

1. Open the Alarm Configuration window and select the tank from the list on the left. Select the type of alarm to be modified for this tank.
N.B. all alarms are tank specific. If the same alarms are required for more than 1 tank, they will need to be configured for each tank.
The current details for the alarm for that tank will be displayed.
The Multi Scan NXA83B comes supplied with a set of default alarm parameters pre-configured. The first time Alarm Configuration is loaded after installing the system it will display the **default values**. These default values should be replaced with the correct operating values prior to commissioning the system.
2. Select the field to be edited and enter the new data values. The **TAB** key may be used to move to the next entry field or selection can be made using the mouse.
Each field is validated both during data entry and just before the data is saved to the database.
3. Once the changes are complete and correct, they can be saved by clicking the **OK** button. This will save the changes and close the window. To save the changes and continue to edit the database click the **Apply** button. It is not necessary to save the changes to one alarm before editing another but it is best practice to do so.
4. To edit further tanks follow the same procedure.
5. When all necessary configuration has been completed, the changes can be saved and the Alarm Configuration window closed by clicking the **OK** button. The window can be closed and changes can be abandoned without saving by clicking  or the **Cancel** button, however any changes already saved will be retained.

7.6.4 Generation of Alarms

Normally in a standalone configuration the alarms are detected and generated by the Data Communications Control module. It is this module that sees the changes in gauge data first.

In a client-server system it is the same module that detects and reports the alarms although it is important to note that this module will only be running on the server.

Any client connected to the server will therefore see the same alarms.

Some events may be generated locally by each client. These are normally events in response to abnormal operating data or transient or irrecoverable data access errors.

7.6.5 Enabling and Disabling Alarms

When an alarm is **Enabled**, the variable associated with the alarm is monitored against its set limits. If the variable deviates outside of the set limits an alarm will be generated.

When an alarm is **Disabled**, no alarm processing will take place for the disabled alarm and therefore no event, audible signal or otherwise will be generated if the variable deviates outside of its set limits.

The alarm configuration display provides a check box within each tab for enabling or disabling the alarm.

7.7 Manual Data

Normally tank data is collected from the field instruments automatically.

Where primary data values are not available or no longer available due to a gauge fault, data values may be switched from automatic mode to manual mode.

When in manual mode the data values must be provided by the operator.

Data that is in manual mode is normally displayed with green text on black background to signify that it is manual data. On reports it is normally suffixed with the letter M.

Where tanks are not fitted with gauges but are still required on the system, the tank may be operated with all of its primary data values in manual mode. In this way the tank inventory is calculated from the manual data. Note that gauges that have both level and temperature in manual mode will not be polled by the communications layer.

Primary data values are those measurements made by the tank gauging instrument such as:

- Product Level
- Water Level
- Product Temperature
- Product Density
- Pressure

Traditionally, most gauges provide Product Level and Product Temperature measurement capability. It is quite common to find that the rest are entered as manual data.


More modern gauging instruments have the capability to measure water level, density and pressure automatically. In this case the values would be collected automatically.

The use of this feature can be controlled by the security system.

7.7.1 Launching the Manual Data Entry Module

In order to enter Edit mode and modify manual data values users must be logged on with the correct access rights. To access manual data configuration from the main application window menu, select **Configuration → Manual Data**.


The following display is typical of what will be loaded.



A list of all tanks will be displayed on the left, together with the manual data entry fields for the selected tank.

By default a reduced set of the most common fields will be displayed.


To view the additional fields for a tank click on the advanced button .



NXAB3_Manual-Data_Additional-Fields

By default any changes to the manual data for a tank will apply to ALL gauges on that tank.

The individual gauges assigned to a tank can be viewed and edited by clicking on the **ShowHide_gauges** button .



NXAB3_Manual-Data_Individual-Gauges

In this mode the manual data can be configured for individual gauges.

7.7.2 Entering Manual Data

Select a tank/gauge from the list and edit the required parameter.

If the field is not already in manual mode tick the **Enabled** box at the start of the line.

After all required data has been entered; Click on the **OK** button to save the changes to the database and exit the application. Click on **Apply** to save the changes and continue editing.

Click on the **Cancel** button to discard any changes and exit the application.

7.8 W&M Calibration


Weights and Measures (W&M) approved Multi Scan NXA83B are required to display the approval status of all parameters displayed on screen. Data for tanks that are not approved will be displayed with a '#' symbol.

The W&M Calibration screen allows tanks to be marked as approved and also to mark the individual parameters on those tanks.

These parameters currently include:

- Product Level
- Product Temperature
- Water Level
- Density
- Vapour Pressure
- Vapour Temperature

In order to enter Edit mode and modify W&M calibration data users must be logged on with the correct access rights for Manual data entry. To start the calibration screen, select **Configuration → W&M Calibrate**.



NXA83_W&M-Calibration

In order to adjust the calibration status of a gauge, it must first be selected. Choose the tank containing the Gauge from the list on the left of the screen. Expand the tank and choose the gauge from those available. The individual calibration status boxes will be greyed out and marked as not calibrated (unticked) until the **Tank Calibrated** field is ticked. Once the **Tank Calibrated** field is ticked, the individual parameters may be ticked to show their calibration status.

7.9 Product Configuration

When first installed the system has no product information.

This function is used to enter the names of the products stored on site.

Product Configuration can be launched at any time in order to edit existing products, delete products or to add new products.

Each product must be allocated to a product group. By default, a GENERAL product group exists. Other Groups may be created as required.

7.9.1 Product Groups

Product Groups allow the user to group together products that have similar characteristics.

For example, **Product Groups** might be configured as:

- DISTILLATES
- SPIRITS
- CRUDE
- HEAVY OILS
- FUEL OIL

The following products may for example be members of the DISTILLATES product group:

- DERV
- KERO
- GAS
- OIL
- JET A1

Similarly, the following products may be members of the SPIRITS product group:


- ULMS
- LRP
- UL 95
- UL 98

And so on.

7.9.2 Launching Product Configuration

Select the **Product Configuration** option from the **Configuration** menu.

The following display is typical:



Enter the product groups as required.

To enter a new Product Group:

1. Click the **Product Group toolbar** button .
2. Enter the name of the new product group.
3. Click the **Apply** button to save the new group to the database.

To edit an existing group:


1. Select the group to be edited.
2. Modify the Group name.
3. Click the **Apply** button to save the changes to the database.

To delete an existing group:

 You can only delete a group when it contains no products.

1. Select the group to be deleted.
2. Click the **Delete** button .
3. Click the **Apply** button to confirm delete.
4. Click the **Cancel** button to abort the delete.

To enter a new product:



NXAB3_Product-Configuration_New-Product

1. Select the Group where the New Product will be added.
2. Click the **New Product** button  on the tool bar.
3. Type the name of the new product. This field is limited to 30 characters.
4. Choose a new color.
Note that the use of color is determined by options configured in the **System Settings** module. Please refer to a description of these settings for further information.
5. Click the **Apply** button.

The new product will be allocated to the selected group. To allocate the product to a tank, refer to details in the Tank Characteristics section (→  49).

To delete an existing product:

 If the selected product is currently in use, the **Delete** command will be rejected. You must remove all use of the selected product before it can be deleted.

1. Select an existing product. The current configuration details will be displayed.
2. Press the **Delete** button  on the toolbar. The product will be removed from the database.
3. Press the **Cancel** button to discard any changes.

7.9.3 Allocating Products to Tanks

The Tank Characteristics module is used to allocate a product to a tank.

See the section detailing the Tank Characteristics module (→  49) for a full and complete description.

8 Display Configuration

8.1 Tank Data Displays

As an optional feature, the Tankvision Multi Scan NXA83B is equipped with a 7 in LCD touchscreen display which is used to view the live data from any tanks configured in the database. Navigation around the different displays is by selection of the touchscreen buttons.

The display can show data to in a number of different formats:

- **Grid View** display of multiple tanks
- **Single Tank** graphical display
- **Multi Tank** graphical display
- **Reports** of multiple tanks

A range of different displays can exist for each type, which may be selected for viewing by the operator.

These displays must be configured in the Tankvision Multi Scan Configurator software before being downloaded to the NXA83B device.

The configurator user is free to select from a range of data fields to display, such as level, temperature, density etc. Other features such as pictures, bar graphs, alarm displays, text label and selector buttons may also be displayed.

8.2 Display Configuration

The Multi Scan NXA83B has the capability to configure three categories of display:


- Single Tank Displays
- Multi Tank Displays
- GridView Displays

The first two use a SCADA editor to configure the displays. This makes them highly adaptable, enabling displays to be configured to exactly match user requirements.

GridView displays are equally configurable but use a grid layout to display data. These will be covered in a later section (→  92).


Various different displays can be configured.

To open the display editor open the **Configuration** menu and select the type of display to create or edit.



1 Three categories of display: Single Tank, Multi Tank, GridView

The display selection screen will be displayed for the type of display chosen, e.g.



This will show a list of all currently configured displays.

The text is the name that will be displayed in the menu on the Multi Scan NXA83B display screen. This can be changed when the display is edited.

The item in brackets is the actual name of the configuration file for the display, for instance (display.sto).

8.2.1 Adding a display

To add a new display:

1. Open the **Configuration** menu.
2. Pick the category of display required.
3. Click on the **Add** button. A new display editor will start.

4. Configure the display as required.
5. When complete, save the display to a new file name.

A new item will be displayed in the list of displays.

8.2.2 Deleting a display

 Once a display is deleted it cannot be restored, so be sure before deleting any display.

To delete the different types of displays:

1. Select the **Configuration** menu and pick the category of display required.
2. Select the display to be deleted and click on the **Delete** button.

8.2.3 Editing a display

To edit the different types of displays:

1. Select the **Configuration** menu.
2. Select the category of display required.
3. To edit a display select the item in the list and then click on **Edit**.

This will open the display editor for this file.

8.2.4 Setting the DEFAULT display

One display of each type will be marked with **[DEFAULT SCREEN]**. This is the display that will be initially loaded when the Multi Scan NXA83B boots up.

To change the default screen, select the new screen and click on the **Set as Default** button.

8.3 Single Tank and Multi Tank displays

The Multi Scan NXA83B single tank and multi tank displays are completely flexible for the data to be shown on the screen. They are configured using the Tankvision Multi Scan Configurator software.

A display may be configured for a range of items, including:

- **Live Data Fields** – For measured data such as Level, Temperature, Pressure, Density, Water Level etc. May also include calculated data such as Volumes, Mass etc.
- **Data Entry Fields** – For manual data, alarm setpoints etc.
- **Fixed Text Labels**
- **Bar graphs** – showing percentage level etc.
- **Pictures**
- **Alarms**
- **Graphs** – For Multi-element temperatures, profiles etc.


Each field can be customized for size, color, fonts etc.

Single Tank Displays only display data for gauges from a single tank name. The configured screen becomes a template for what to display, therefore display fields cannot be configured for a specific Tank and only the gauge duty may be specified. The tank is specified at runtime.

Multi Tank Displays are fixed displays where data from multiple tanks can be displayed on the same screen. All display fields must have the tank name and duty defined at the time of configuration.

8.3.1 Display Editor


The Single Tank/Multi Tank Display editor is started as described in previous section (Display Configuration).



The editor allows all displays items to be configured as required.

All items shown in the editor are configurable and the layout is free-form, therefore they may be placed anywhere on the screen. The following areas should however be avoided:

- **Top right hand corner:** The fixed Tanks selector button goes here in normal operation
- **Top left hand corner:** The fixed Screens selector button goes here in normal operation
- **Bottom line:** The status display field goes here



- 1 Area for fixed Screens selector button
- 2 Area for fixed Tanks selector button
- 3 Area for status display field

8.3.2 Modifying an existing item


To modify an existing item in the display, first click on the item.



The item can be moved around the screen by holding down the left mouse button and dragging it to the new location.

The item can be re-sized by dragging the edge/corner to the new size. Certain items, such as pictures, can only be resized if the Stretch flag is enabled in its configuration menu.


To edit the configuration of an item right click on it, and select the option from the pop-up menu.




The options contained within the menu will depend on the display item being edited. On individual display items → 87.

8.3.3 Adding a new item

To add a new display item, right click on a blank section of the editor and select **Add Item**. Then select an item from the list.



The new item will be added to the top left corner of the editor and can now be modified as detailed above.




8.3.4 Setting the Display Name


The display name is the text that will be displayed in the menu when selecting the display on the Multi Scan NXA83B.

To set the name, right click on the background of the display (not on any field) and select **Text** from the pop-up menu. The Display name can be entered in the text box.

8.3.5 Changing the display units

The display units for all data items may be configured by right clicking on a blank section of the editor and selecting **Units** from the drop down menu.






NXA83_Display-Editor_Change-Dimensions

The units and number of decimal places for each data type may be configured and are then used in the Multi Scan NXA83B to format all live data in the display.

8.3.6 Changing the background color

The background color for the display may be configured by right clicking on a blank section of the editor and selecting the **Back Colour** menu option.



NXA83_Display-Editor_Back-Colour

The **Select** option allows the colour to be defined, or set to **Use Default** if the normal system background is to be used.

8.3.7 Copy, Paste & Select All

To copy an item, right click on the item and select **Copy** from the pop up menu.

To paste an item that has been copied, right click on a blank section of the editor and select **Paste** from the pop up menu. The new item will be pasted into the top left corner of the editor and can now be modified as previously described.

Select All will select the entire contents of the editor. This is useful for performing global changes such as type font or item colour, or for duplicating large amounts of display data. To select all items, right click on a blank section of the editor and click **Select All** in the pop up menu.

8.3.8 Resize to fit


 This command cannot be undone so it is recommended that a copy of the file is saved first.

When creating a display screen it may be desirable to eliminate any blank space around the edges of the screen. The Multi Scan NXA83B provides a tool to do this.

To resize the screen, cropping out all blank parts of the background to fit the current screen size right click on a blank section of the editor and select **Resize to fit** from the pop up menu.

8.3.9 Saving the display


To save the display configuration, either close the Display Editor or right click on a blank section of the editor and select **Save** from the menu.



NXA83_Display-Editor_Save-before-Exit

In both cases a pop-up window will appear prompting for confirmation to save the display. Click **Yes** to save or **No** to abandon any changes and exit.


The display is saved to a file of type .sto and the file name and destination can be specified. Although the file can be saved in any location, it must however be saved in the default **Config** folder for the Multi Scan NXA83B to access and use the file.



NXA83_Display-Editor_Save-As

1 Save as Screen: New file name


If a new file name is specified in the **Save As** screen (i.e. a new file name) then a new display will be added to the list of single tank displays. The changes will not have been saved in the original file.



NXA83_Display-Editor_Single-Tank-Overview

1 Single Tank Overview: New display

To overwrite an existing file, select the file from the **Save As** screen and click **Save**. A pop up window will appear prompting for confirmation to replace the existing file. Click **Yes** to proceed.



NXA83_Display-Editor_Save-As_Replace

8.3.10 Display Items

Display Items

The display may be configured with range of different items, including:

- **Label:** A fixed text field

- **Picture:** A fixed picture displayed on the Multi Scan NXA83B screen
- **Button:** A link to run an executable program
- **Command Button:** A configurable shortcut to run a gauge command
- **Group:** A field used to group together a number of other items
- **Data → Tank:** A field used to display live data, specific to a single tank, from the Multi Scan NXA83B. It is dynamic and will be refreshed periodically.
- **Data → Product Totaliser:** A field used to display live data, specific to a single product. The total amount is calculated from all tanks containing the specified product. It is dynamic and will be refreshed periodically. This field is only applicable to Multi Tank Overview (.mvo) displays.
- **Flood:** A simple vertical bar graph. The bar graph displays product level as a percentage of tank height. It is dynamic and will be refreshed periodically.
- **Flood → Product Totaliser:** A simple vertical bar graph that displays the total amount of a single product calculated from all tanks containing the product. The bar graph displays product level as a percentage of total capacity of all tanks containing the specified product. It is dynamic and will be refreshed periodically. This field is only applicable to Multi Tank Overview (.mvo) displays.
- **Alarm:** Displays an alarm icon on the screen when any alarm is active for the tank. If no alarm is active, the icon disappears.
- **Tank Picture:** This is the same as a picture except that a separate image can be specified for each of the four tank shapes. When a tank is selected, the picture displayed will be determined by the shape of the tank configured in the database.
- **Valve:** Not supported on the Multi Scan NXA83B
- **Pump:** Not supported on the Multi Scan NXA83B
- **Data Entry:** Similar to a data field except that instead of live data, data is entered by the operator. This is useful for applications such as manual data (product level, temperature etc.) and setting alarm trigger points which cannot normally be altered whilst the Multi Scan NXA83B is live.
- **Graph:** A display item that shows live data in a graphical format. It is dynamic and will be refreshed periodically. Graphical data available is: Multi-element Temperatures, Skin Temperatures, Profile Temperatures, Profile Densities, IO Block Data

After adding a display item it must be configured for use. The attributes that can be configured depends upon the item and whether it is assigned to a Single or Multi tank display. To access the configuration attributes, right clicking the item in the display editor. Below is a list of all configurable attributes.


Display Item Attributes

- **Align:** Aligns the text or picture within the item field to one of nine positions. The text/picture can be located within the item box only.
- **Arguments:** Values to be passed to an executable program
- **Color:** Sub menu for item colour options. There are four possible options depending upon the item being configured:
 - **Transparent:** Makes the label transparent so that only the text is visible
 - **Fore Color:** Sets the text colour
 - **Back Color:** Sets the Background colour
 - **Border Color:** Sets the border colour for the display item
- **Command:** Used to specify the gauge command for command buttons
- **Data:** Used to specify the type of data, from a drop down menu, to be read into the display item. This can be live or manual depending upon the item. Data can be in 1 of 3 states **Normal**, **Manual** and **Invalid**. Each may be configured to have a different appearance for colour and alignment.
- **Decimal Places:** Specifies the number of decimal places to display
- **Display:** Sub menu used to select what characteristics are displayed within a data field. The following may be enabled:
 - **Show Operating Levels:** Tick to display the tank operating levels on flood fields

- **Data:** Tick to display the actual data value, otherwise no data will be displayed. This is normally ticked.
- **Units:** Tick to display units after the data value, otherwise no units will be displayed.
- **Gauge Commands:** Tick to show the gauge commands selector screen when the item is selected. If an item is in manual mode the manual entry screen will be displayed if this option is enabled.
- **WM Status:** Tick to display the Weights and Measures status of the data. This field is composed of a number of characters to show the current status of the data. Values include:
 - '&' - data is manually entered
 - 'S' - data is stored, i.e. level when gauge is not following level etc.
 - '#' - data is not W&M approved
- **Default Decimal Places:** Tick to format the data with the default decimal places for the units selected (to set default decimal places →  84)
- **Executable:** Select the executable program for button.
- **Font:** Used to set the font, size and style (bold, italic and underline) of the text
- **Graph:** Sub menu for the graphical display to set the following items:
 - **Show Grid:** Tick to show the gridlines on the graph, otherwise none will be shown
 - **White Background:** Tick to make the background of the graph white, otherwise it will be grey
 - **Minimum Range:** Used to set the minimum range to be displayed on the x=axis of the graph
- **Order:** Sub menu. Items can be placed on the screen such that they overlap each other. The order that the items will be displayed is determined by pushing items to the back or pulling them to the front. There are no intermediate stages; items can only be sent to the back or to the front. Multi-layer ordering can be achieved by careful selection of the order that items are moved.
 - **To Front:** Moves the selected item to the front of the group
 - **To Back:** Moves the selected item to the back of the group
- **Output Value:** Defines the value to be passed to the specified data field when a command button is activated
- **Picture:** Opens a navigation window to select a picture to display
- **Picture:** Sub menu. This option is used for selecting and configuring pictures as backgrounds for buttons and labels. The following are configurable:
 - **Show:** Tick to include a picture as a background
 - **Picture:** Opens a navigation window to select a picture to display
 - **Align:** Aligns the picture to one of nine positions within the button or label
- **Product Name:** Used to select a product from a drop down menu of configured products when setting data and flood totaliser fields
- **Pump ID:** This feature is not supported in the Multi Scan NXA83B.
- **Stretch:** Unlike all other items pictures cannot be resized by "click and drag" of the picture field. Resizing the picture field will result in a white border (the field cannot be smaller than the picture). Ticking the stretch command will cause the picture to "Stretch" to fit the size of the picture field.
- **Tank ID:** In Multi tank displays (.mto) this is used to specify which tank and gauge duty is to be applied to an item. In Single tank displays (.sto) where there can only be one tank (specified at run time) this option is only used to specify the gauge duty.
- **Text:** This option opens a window for defining the text to be entered into items.
- **Valve ID:** This feature is not supported in the Multi Scan NXA83B.
- **Visibility:** Sub menu. Items can be configured to only be visible under specific conditions. The options for configuring visibility are:
 - **Always visible:** Tick this option to override visibility conditions. This option is selected by default.
 - **Tank ID:** Select a tank and gauge duty, e.g. Tank1 primary gauge
 - **Data:** Select a data value to test against, e.g. product level
 - **Test Value:** Set the condition that needs to be met to display the item, e.g. greater than 5 000


The example above could be used to display an alarm icon if the Product Level in Tank1 exceeds 5 000 mm.

Item menus




NXA83_Display-Editor_Item-menus_Add-Item

Label




NXA83_Display-Editor_Item-menus_Label

Picture




NXA83_Display-Editor_Item-menus_Picture

Button



NXA83_Display-Editor_Item-menus_Button

Command Button




NXA83_Display-Editor_Item-menus_Command-Button

Group




NXA83_Display-Editor_Item-menus_Group

Data → Tank & Data → Product Totalizer




NXA83_Display-Editor_Item-menus_Data_Product-Totalizer

Flood → Tank & Flood → Product Totalizer




NXA83_Display-Editor_Item-menus_Flood_Product-Totalizer

Alarm




NXA83_Display-Editor_Item-menus_Alarm

Tank, Valve and Pump



NXA83_Display-Editor_Item-menus_Tank-Valve-Pump

Data Entry



NXA83_Display-Editor_Item-menus_Data-Entry

8.4 Grid View and Reports

GridViews and Reports use a grid layout to display data either on screen or on paper (in the case of reports).

A range of Grid Views and Reports may be configured using the Tankvision Multi Scan Configurator tool, using a common set of configuration screens.

Reports may also be configured to be automatically printed at scheduled times.

Grid Views and Reports are completely configurable. This makes the grids highly adaptable, enabling GridViews and Reports to be configured to exactly match user requirements. Since GridViews are configured in exactly the same way as GridView Reports without the additional features of printing and report scheduling, this manual will only deal with GridView Reports.

The grid can be customized for:

- the number of columns
- the tanks to be displayed
- column totals
- flow colours
- grid title text and font

Each column in the grid can be formatted for:

- Live Data such as Level, Temperature, Pressure, Density, Water etc.
- Width
- Font
- Header Text


A report may also be configured for print layout, including:

- Landscape/Portrait
- Margins

Various different Grid Views and Reports can be configured for a Multi Scan NXA83B.

8.4.1 GridView Report Editor


To start the Grid View Reports editor select **Configuration** → **GridView Reports** (**Configuration** → **GridView Displays** for the display editor) from the Multi Scan NXA83B configurator.



NXA83_Report-Configuration_GridView-Report-Editor

Select the report to edit or select **Add** to create a new GridView.

The report editor screen will open. The editor allows all parameters to be configured for the selected grid view report.



NXA83_Report-Configuration


Configuration is split into three sections for GridViews plus an extra two for Reports:

- **Grid:** Sets global parameters for the grid, such as Caption, Fonts colors etc.
- **Filter:** Sets the criteria for selecting the tanks to be shown in the grid
- **Report Printing:** Sets report specific layout parameters, such as Landscape and Margins (Reports only)
- **Report Scheduler:** Sets automatic print parameters (Reports only)
- **Columns:** Sets the columns to be shown in the grid

To edit a section, select the relevant heading from the list on the left of the window. The appropriate data will be displayed in the right hand panel.

8.4.2 Grid

Click on the **Grid** item to edit parameters that affect the whole of the grid.




NXA83_Report-Configuration_Grid

The following parameters may be configured:

- **Caption:** This is the title for the report, displayed at the top of the screen. It is also the name used to select a report to be printed/displayed.
- **Caption Font:** Click on the **Edit** button to select the font to use for the caption.


- **Font:** Click on the **Edit** button to select the font to be used for all data in the grid, including column header text.
- **Totalise Columns:** If ticked any volume, mass and weight column will be totalized and displayed at the bottom of the column. The text box to the right allows the row name to be entered. This defaults to "Totals" and will be displayed in any "Tank ID" column.
- **Use Color:** (Displays only)
- **Use Color to Indicate Flow Direction:** When ticked, rows in a grid will change color to indicate flow direction in moving tanks. The following colors are used: **Brown** to indicate an emptying tank and **Blue** to indicate a filling tank (Displays only).
- **Use Color For Values in Alarm:** When ticked, any values which are in a state of alarm will be shown on a **Red** background (Displays only).
- **Units:** Clicking on this item will display the units edit box. This allows the units of all data items to be set. The units only apply for this grid.



NXAB3_Report-Configuration_Grid_Dimensions

8.4.3 Filter

Click on the **Filter** item to edit parameters that determine which tanks will be displayed in the grid.



NXAB3_Report-Configuration_Filter

The following parameters may be configured:

- **Filter:** This sets the mode to determine which tanks are displayed in the grid. Currently supported filter modes are:
 - **All Gauges:** All tanks will be displayed in the grid, in the order that they appear in the database configuration.
 - **By tank ID:** Only those tanks that are in the **Devices** list will be displayed in the grid.
 - **Product:** Only those tanks that contain the product named in the **Product** field will be displayed in the grid, in the order that they appear in the database configuration.
- **Product:** If the Filter mode is **Product**, this field will be enabled to allow the product type to be entered.
- **Primary Gauge:** If ticked only Primary gauges will be included in the grid
- **Devices:** If the Filter mode is **By tank ID**, this section is enabled. A list of specific tanks can be entered for display in the grid. The order that tanks appear in this list is the order that they will be displayed in the grid.

Clicking on the **Add Gauge** button opens a window for selecting a tank to be included in the device list.



NXA83_Report-Configuration_Filter_Add-Gauge

Filtering by **Tank ID** only uses the Tank ID to determine what data to display. The Gauge Duty section is not used. If the **Primary Gauge** box is ticked only primary gauges will be displayed for the selected tanks, otherwise all gauges for these tanks will be displayed.


Click **OK** to add the tank.

Clicking on the **Delete Gauge** button will delete the currently selected device.

Clicking on the **Delete All** button will delete all of the devices.

8.4.4 Report Printing

Click on the **Report Printing** item to edit parameters that determine how a report will be displayed on the printout.




NXA83_Report-Configuration_Report-Printing

The following parameters may be configured:

- **Landscape:** If ticked the report is printed as Landscape, otherwise it will be printed as Portrait.
- **Show Grid:** If ticked the grid lines will be shown on the report.
- **Center Grid:** If this is ticked the report will be centred on the page.
- **WM Approved:** If ticked the report shows the weights and measures approval status of the Multi Scan NXA83B.
- **Margins:** This section allows the margins for the printout to be defined.

8.4.5 Report Scheduling

Click on the **Report Scheduler** item to edit parameters that determine when a report will be automatically printed.




The following parameters may be configured:

- **Mode:** This sets the mode for print scheduling of the report. Choose from:
 - **None:** The report will not be printed automatically. Manual printing is still possible
 - **Hourly Trigger:** The **Minutes** field is enabled. The report will be printed every hour, at the specified Minutes past the hour.
 - **Daily Trigger:** The **Hours** and **Minutes** fields are enabled. The report will be printed once per day, at the specified time.
 - **Weekly Trigger:** The **Day of Week**, **Hours** and **Minutes** fields are enabled. The report will be printed once per week at the specified time.
- **Day Of Week:** This is a drop down menu for selecting a weekday.
- **Hours:** This is a dropdown menu for selecting an hour. The report scheduler uses the 24 hour clock.
- **Minutes:** This is a dropdown menu for selecting minutes past the hour.

8.4.6 Columns


Click on the **Columns** item to edit parameters that determine what data columns will be displayed in the grid.



NXA83_Report-Configuration_Columns

A representation of the grid will be displayed in the lower portion of the screen. This is the actual grid layout that will be displayed on the Multi Scan NXA83B, but without the tank data rows.

To edit a column, click on that column in the grid display.



NXA83_Report-Configuration_Columns_Edit

The column in the grid display will be displayed with DN00 in red, to indicate that the column is selected. The panel above it will display the current parameters for that column.


Click on a field to edit its contents.

The following parameters may be configured for each column:

- **Column Header Text:** This is the text that will be displayed at the top of the column. Click within this field to edit the text using the keyboard.
- **Data:** This is the data field that will be displayed in the column. Click on the **Edit** button to display a pop-up window and select from the drop down menu.
- **WM Status Column:** If this box is ticked, the column will display the WM status characters for the selected data instead of the data.

- **Width:** This field sets the width in pixels for the column. Click within this field to edit the value using the keyboard. Any changes to this value will be immediately reflected in the grid. Note that the full width of the Multi Scan NXA83B display is 640 pixels.
- **Align:** This sets the alignment of the data in the column.

To insert a new column select a column in the grid next to where the new column is required and click on the **Insert** button. This will add an exact copy to the right of the selected column. The parameters may then be edited as required.



1 Report Configuration Screen: Insert a new column

Columns can be removed by selecting the column and clicking the **Delete** button.

8.4.7 Saving the configuration


To save the configuration, close the window with the  button.

A prompt will appear asking if the configuration is to be saved.



NXA83_Report-Configuration_Columns_Exit-Prompt

Click **No**, to discard any changes and exit, or **Yes** to display the **Save As** dialog.



A GridView will be saved to a file type of .gvo, whilst a report is saved to a file of type .gvr and the file name and destination can be specified.

 To function on the Multi Scan NXA83B, the file must be stored in the **Config** folder.

Click **Save** to permanently save the new configuration.

If a new file name is specified, the configuration data will be saved to the new file and a new screen will be added to the list of gridviews or reports. The original file will not be changed.

9 System Settings

9.1 System Settings


System Settings are options and settings that affect the operation of the entire Multi Scan NXA83B system. The **System Settings** screen is available under the **Admin** menu.

The options that can be configured within **System Settings** are:

- Login Enabled
- Sound Enabled
- Voice Enabled
- Use Product Colours
- Movement Threshold

9.2 Using System Settings

Select the **Admin** → **System Settings** option from the main menu bar. The **System Settings** display will be loaded.



NXA83_System-Settings

To change any system settings you must be logged on as a user with administrative privileges.

To change **System Settings**:

1. Either tick/untick a box or enter the required value into the field.
2. Click on the **OK** button to close the window and save the changes to the database or the **Cancel** button to abandon the changes and exit.

9.3 Login Enabled

Determines whether users are required to enter passwords to access and modify the system.

If this option is ticked the Multi Scan NXA83B will require users to log in to access password protected controls. If users are not logged in, or do not have sufficient access rights the following dialog will pop up.



NXA83_System-Settings_Insufficient-user-rights

If this occurs click **OK** and log in with sufficient rights to continue.

If log in is not enabled, there will be no access restrictions.

9.4 Sound Enabled

This determines whether sound is enabled. Currently only voice messages are supported by this feature. To enable this feature, tick the box.

9.5 Voice Enabled

This determines whether voice messages are enabled.

If this option is ticked the voice messages, where available, will be played for the alarms and warning that occur as part of normal tank gauging operations.

9.6 Use Product Colors

This determines the strategy for colour in the tank flood panes.

Currently the Multi Scan NXA83B does not support this feature.

When ticked the color representing the product level in the tank will be Blue.

When not ticked the colour of the product is represented by the tank status. For example, if the tank is filling, the color of the product is displayed as Blue; if the tank is emptying, the color of the product is displayed as Brown; and if the tank is static, the color is displayed as Green.

9.7 Movement Threshold

This determines the minimum flow rate level that is deemed significant enough to mark a tank as moving.

A default flow rate of 5 mm/min is considered adequate for most Multi Scan NXA83B installations; however any user defined value may be entered.

10 Security

10.1 Security

The Tankvision Multi Scan Configurator software is provided with its own security and user administration functions. It is not dependent on Windows system security for access to its features.

The security database is stored for each Multi Scan NXA83B device and loaded when a project is loaded.

The User Configuration module is present in the **Admin** menu.

The security features should be used carefully to ensure users have the correct access rights for their tasks and to prevent unauthorized access to the system.

To logon as a user select **Security → Login**.



The **Login** screen allows the **User name** and **Password** to be entered.


To log off from the current user then select **Security → Logout**.

10.2 Using Security Configuration

Log on to Tankvision Multi Scan Configurator software as an administrator.

Select the **User Configuration** option from the **Admin** menu.

The default security display will be loaded.



NXA83_User-Configuration

All the current user details will be listed in a tabular form.

After installing the software only one account will exist. This is the Administrator account and it will have a default password of "password". It is recommended that this is changed to a more secure password as soon as possible.

The table is a matrix of users against their logon rights. The columns indicate the characteristics of the users account, and the rows represent the different users. It is therefore possible to deny or grant a level of access on a per feature basis (i.e. User A may be denied access to the Tank Characteristics module, User B may be granted Read Only access, and User C may have modify privileges).

The fields are defined as follows:

- **User Name:** Text entry field for user's name. This will be displayed on the **Home Page** when the user is logged on.
- **User Initials:** Optional text entry field for an abbreviated version of the user name. This is a reference only field that is not used by the Multi Scan NXA83B.
- **User Group:** Text entry field for the group a user belongs to. This is a reference only field that is not used by the Multi Scan NXA83B.
- **Password:** Text entry field for the password of the user.
- **Login Timer Enabled:** Determines whether the user account will time out after a period of inactivity.
- **Login Timer Timeout Time:** The time of inactivity required before the user account times out and the user is logged out.

The remaining columns each reflect a feature or function within the Tankvision Multi Scan Configurator software. Each cell has a drop down menu to select the level of access a user is permitted for that feature.

The following access levels are currently available for each feature:

- No Access
- Read only


- Modify
- Create
- Delete
- Full Access

The following software buttons are provided:

Button	Function
Edit	Click to edit existing user accounts.
New	Click to create New user accounts.
Copy	Click to copy an existing user account.
Delete	Click to delete an existing user account.
Cancel	Click to abandon any changes.
OK	Click to confirm changes.
Exit	Click to close the display.

10.3 Creating a new User Account

1. Log on with sufficient access rights. Select **Admin** → **User Configuration** from the main menu bar.
2. Click the **New** button. A new row will be added to the table.
3. Use the mouse and cursor keys to configure the rights of the new user.



NXAB3_User-Configuration_Adding-New-User

The following data entry fields are mandatory:


- **User name** (maximum of 20 characters)
- **Password** (minimum of 6 characters)

All the feature access rights will default to **No Access** if nothing else is specified.

Various different users can be added to a system.

4. To specify user rights for each feature scroll to the relevant column and select from the drop down menu.

Alternatively, an existing user account can be copied to create 1 or more new accounts. Select an account by clicking the start of the row and click the **Copy** button.



NXAB3_User-Configuration_Copy


A dialogue box will open requesting the number of copies required.



NXAB3_User-Configuration_Copy_Number-of-copies

Enter the number of copies and click **OK**. These will be added to the bottom of the grid and will contain exact copies of the selected user's access rights. The first 4 fields are User specific so are left blank to be completed with unique details.

5. The **OK** button will be enabled when any changes have been made to the configuration. To save the new user account to the database, click the **OK** button. Provided all fields are supplied in the correct format, the data will be saved to the database. Any problem occurring whilst the data is being saved will be reported to the user via the display's status bar shown below.



1 User Configuration Screen: Status bar


NXA82_User-Configuration_Password-length

To cancel the changes click the **Cancel** button.

To exit the display without saving changes click the **Exit** button. This will return you to the previous display.


10.4 Deleting an existing User Account

1. Log on with sufficient access rights. Select **Admin** → **User Configuration** from the main menu bar.
2. Select the account to be deleted by clicking the start of the row. It is possible to delete multiple accounts. Select the rows to be deleted whilst holding down the **CONTROL** key. Each will be highlighted in turn.



NXA83_User-Configuration_Deleting-User

3. Click the **Delete** button, a message will be displayed indicating how many rows are to be deleted.




NXA83_User-Configuration_Confirm-Delete-Multiple

4. To confirm deletion click **Yes** otherwise click **No**.

10.5 Editing an Existing User Account

1. Select **Admin** → **User Configuration** from the main menu bar.
2. Click the **Edit** button.
3. Navigate to the row and column to be edited and modify its contents.



4. Click the **OK** button to save the changes.

10.6 Forgetting Your Password

Your system administrator or anybody having administrative privileges can reset your password if you have forgotten your details.

11 Gauge Command Scheduler

11.1 Gauge Command Scheduler

The Gauge Command Scheduler is a Windows service that can be configured to send gauge commands at a specific time of day on a recurring basis.

The Gauge Commands can be sent to a Single Tank, all Tanks, or a group of tanks generally specified by Gauge Type.


Care should be exercised when scheduling gauge commands, particularly those that affect a gauge’s primary measuring capability, as the tank may be involved in some sort of critical operation such as receiving product from a ship or similar.

The Gauge Command Scheduler can be configured via the Tankvision Multi Scan Configurator tools.

11.2 Configuring Scheduled Commands

From the main page window, select the **Tools → Command Scheduler Configuration** menu item.

This will bring up the configuration application, which you can use to create, view and edit the scheduled commands.



NXA83_Gauge-Command-Service-Config

Command Schedule entries are listed on the left of the window, selecting one of these will display the details of the entry in the controls on the right.

Entry	Details
Destination	Denotes the way the gauges can be selected for scheduled item, either by a specific Tank ID, or collectively by Product or by Gauge Type.
Gauge Duty	Where tanks are fitted with more than one gauge, this option is used to specify which gauge on the tank is to perform the command.

Entry	Details
Command	This is used to select the command to be executed by the gauge or gauges.
Custom Command	If selected in the Command field this section is enabled to allow a custom command to be configured. Note that all the commands you can execute via the Multi Scan NXA83B are available from the Command list.
Schedule	<p>A scheduled command can be configured to send a single command once a day by ticking the Specified start box and entering a time into the field below. Commands can be sent at regular intervals by ticking the Command interval box and entering the interval period in the field below.</p> <p>It is also possible to execute a command between two specified times and a specified frequency by ticking the Specified start, Specified stop time and Command interval boxes.</p> <p>For example, to send a command every hour between the hours of 01:00 and 04:00 you would set the start time as 01:00, the stop time 04:00 and the interval as 01:00.</p>

When changes have been made to the schedule's detail, click **Save** to commit the changes to the database, or **Cancel** to discard them.

To create a schedule click **New** and edit the schedule as required. When the **Save** button is clicked this will add a new entry to the list on the left.

To change a schedule, select the schedule from the list on the left and click the **Edit** button. Changes saved now will overwrite the existing schedule.

To delete a schedule, select the schedule from the list on the left and click on the **Delete** button.

The Command Scheduler may be closed without saving changes by clicking the **Exit** button.

12 Advanced Features

12.1 Advanced Features

There are a number of menu items within the Tankvision Multi Scan Configurator that allow advanced access to the Multi Scan NXA83B and its directories.

These are located in the **Admin** menu and comprise:

- System Folder
- Remote System Folder
- Remote System Login

All these features should be used with extreme care, and only by fully trained users.

For further details on advanced features →  10.

13 Gauge Commands and Remote Configuration


The Gauge Commands utility allows commands and configuration items to be sent directly to any gauges attached to the Multi Scan NXA83B. This requires a remote PC connection to the Multi Scan NXA83B and the gauges to be connected and communicating with the NXA83B.

It also requires the Multi Scan NXA83B database to have been imported from device and selected as the current open project.

13.1 Launching Gauge Commands

From the Tankvision Multi Scan Configurator window, select **Tools → Gauge Commands and remote Configuration**.

Where a tank has more than one gauge, the application will default to the primary gauge for the selected tank. Users can subsequently select an alternative gauge to operate on by clicking  next to the tank and selecting the gauge duty.




The appropriate set of options will be displayed for the gauge type.

13.2 Sending a Command

Select the tank from the list in the left hand panel. Expand the tank with the  symbol (select the gauge in a multi-gauge setup).


The commands supported by the gauge will be enabled.



Select the appropriate command from the list.

Set any required parameters and click the action button (dependent upon the command, **Execute**, **Dip** etc.).

Generally feedback and status of the command will be reported back to the user via the panel at the bottom of the window.




NXAB3_Gauge-Command_Gauge-Items_HA

13.3 Enraf Gauge Commands

Enraf gauges support the following functions:

- **Gauge Items** is a general tool allowing the user to read or write any of the gauge items and view the returned data and or responses.
- **Maintenance** allows the user to set the reference level of the gauge.
- **Dipping** provides the various interface measurement modes such as Find Product Interface, Find Water Interface, and Density Dipping features.
- **Lock Test** allows the displacer position to be locked at a defined level.
- **Verify Calibration** checks the calibration accuracy of the gauge.

13.3.1 Gauge Items



NXA83_Gauge-Command_Gauge-Items_Feedback

 This feature applies to Enraf and Motherwell gauges only.

The use of this feature requires a reasonable knowledge of gauging equipment and it is recommended that it is used by competent persons only.

This feature allows the user to read/write any of the gauge configuration items. To read an item, enter the item code and click on **Execute**, the response will be displayed at the bottom of the window. To write to an item, enter the item code, the data value to be written, and click on the **Execute** button.

Enraf Gauge Items

This feature supports the conversion units from those displayed in the Multi Scan NXA83B to units the gauge is configured to understand. In order to avoid confusion between the format used for settings made via a Portable Enraf Terminal (PET) and those of the Multi Scan NXA83B we recommend that you alter the units to match those used by the gauge.

To read a Gauge Item the **Gauge Item Data** field should be left blank. The data will be converted to the currently selected units before being displayed.

When setting Gauge Items, the user must enter the data value in the exact format which is appropriate for the selected Dimensions/Units, with +/- sign and appropriate number of digits before and after the decimal point. If unsure of the correct format, read the current value of the desired Item from the gauge first. The response from the gauge will be displayed in the format appropriate to the Dimensions/Units in use. Use the same format to set the **Gauge Item Data** to the desired new value.

The following Dimensions/Units formats are supported:

Key	Designation
±	sign: character (+/-)
N	numeric digit
.	decimal point

Level

Units	Format
mm	± N N N N N . N (default)
M	± N N N . N N N N
Ft	± N N N N . N N N
In	± N N N N N . N N
f-i-s	± N N ' N N " N N

Temperature

Units	Format
° C	± N N N . N N (default)
° F	± N N N . N N

Density

Units	Format
kg/l	± N N . N N N N N (default)
kg/m3	± N N N N N . N N
lb/ft3	± N N N . N N N N
° API	± N N N N . N N N

Pressure

Units	Format
Bar	± N N . N N N N N (default)
Pa	± N N N N N N . N
kPa	± N N N N . N N N
lb/in2	± N N N . N N N N

All other Items use fixed formats that are unaffected by the Dimensions/Units selected by the user. Consult gauge manufacturer’s documentation for details.


Motherwell Gauge Items

Motherwell gauge items do not have the same unit conversion facility applied to them. The data entered into the Gauge Item Data field is transmitted verbatim to the gauge. You should consult your Motherwell documentation to determine the precise format of the data.

With Motherwell gauges you can either specify a 2 digit hexadecimal item code, as described in the Motherwell gauge documentation or you can use a "shorthand" code for certain data items.

Shorthand Code	Description
UR	Upper Reference Level
RL	Reference Level
HH	High High Alarm Level
HA	High Alarm Level
LA	Low Alarm Level
LL	Low Low Alarm Level

13.3.2 Maintenance



NXA83_Gauge-Command_Maintenance

If a gauge level reading differs from an operator's manual dip it is normal to re-align the gauge to the operator's dip.

This item is used to reset the reference level following a level dip.

The user must provide the new level dip and the level 2 password to access the gauge.

Select the tank (and gauge duty if necessary) requiring the new level dip.

Enter the **Gauge password** and **New Gauge Dip** level.

Click on the **Dip** button.

This command uses the following sequence of **Gauge Item** instructions:


1. Enter the level 2 password using W2 gauge item.
2. Set the reference level using the RL gauge item.

3. Accept the reference level using the AR gauge item.
4. Exit and re-initialize the gauge using the EX gauge item.

The status of each item is displayed as it is processed.

When the EX command is issued the gauge will re-initialize. Gauge data may disappear for a short time during this process. After re-initialization the gauge level will read the new value.

13.3.3 Dipping



NXA63_Gauge-Command_Dipping

These generally apply to the Enraf 854 series of servo operated tank gauges.

Product Measurement Mode

This instruction sends the I1 Gauge Item and will cause the displacer to travel to the I1 interface (Product level by default).

The gauge status is displayed throughout the process.

The gauge will remain at I1 until the user commands the gauge otherwise.

Density Dip – Tank Profile

Selecting this option will perform a 10 position density scan. This will start at the product level and end at the DZ Item position (0.30M by default).

Density Dip - Interface Profile

Selecting this option will perform a 10 position density scan over a reduced range, defined by the user. This is useful for density profiles around product interfaces e.g. Water interface.


Water Measurement Mode

This instruction sends the I3 Gauge Item and will cause the displacer to travel to the I3 interface (Water level by default).

The gauge status is displayed throughout the process.

The gauge will remain at I3 until the user commands the gauge otherwise.

13.3.4 Lock Test



This command uses the MZ item to set the lock level, followed by the LT command to lock the displacer at the level specified by the user.


The user must provide the level at which the displacer will be locked and click on the **Lock** button.

If the **Auto Unlock** box is ticked the lock will release after 10 seconds and the displacer will return to product level.

If the **Auto Unlock** box not is ticked the displacer will remain in the locked position until commanded otherwise by the user.

Click on the **Unlock** button to unlock the displacer.

13.3.5 Verify Calibration



NXAB3_Gauge-Command_Verify-Calibration

This command performs a calibration test by using the CA item to move the displacer to the gauge Calibration Plate and comparing this level with the known Tank Top level. If the difference is greater than 2.5 mm, the verification fails.

The displacer will remain at the calibration plate until commanded otherwise by the operator.

The displacer start position is stored and displayed on the screen and the gauge status is reported at the bottom of the window.

To cancel calibration mode and return the displacer to Product Measurement Mode click on the **Unlock** button.

13.4 Scientific Instruments Gauge Commands

The 6290 densitometer gauge from Scientific Instruments supports a wide range of diagnostic and configuration parameters.

The parameters are grouped together into a number of pages, these being:

- System Settings
- Current Mode
- Current Status
- Current Data
- Profile Configuration
- Alarm Configuration
- Drive Configuration
- Sensor Configuration
- Sensor Calibration
- Host Configuration
- Host 1 Modbus Scaling
- Host 2 Modbus Scaling
- Diagnostics

The data displayed in a page is automatically retrieved from the gauge when it is opened. Therefore all data is considered live.

The meanings of the data parameters in the pages are not described in this document. For more information on these parameters, refer to the appropriate Scientific Instruments manual.

13.4.1 Page Selection

To display the parameters on any page, select that page from the list.


The screenshot shows the 'Gauge Commands' application window. The left sidebar contains a tree view with the following items: TK-854N, TK-990, TKMOD04, TKMOD05, TKV1-02 (expanded), System Settings, Current Mode, Current Status, Current Data, Profile Configuration, Alarm Configuration, Drive Configuration (highlighted), Sensor Configuration, Sensor Calibration, Host Configuration, Host1 Modbus Scaling, Host2 Modbus Scaling, Diagnostics, and Save To File. The main area displays the 'TKV1-02 (Densitometer) SI6290 Drive Configuration' page. It features a table with the following data:

Name	Code	Value	Notes
Level Scale	1B	??	
Slow Speed	1A	??	
Reference	1B	??	
Interlock	1C	??	
Power Up Action	1D	??	
Drive Disable	1E	??	
Reel Alarm Disable	1F	??	
Instant Bottom Stop	R8	??	

Below the table, there is a control for 'Auto Update Screen Every' set to 30 seconds, with 'Start' and 'Stop' buttons. At the bottom of the window, a status bar shows: Date/Time: 15/01/2013 10:59:12, Tank ID: TKV1-02, Gauge Duty: Densitometer, Action: Waiting for Answer.

NXA83_Gauge-Command_Drive-Configuration


The parameters will initially be displayed with a value of ?? until the data is returned from the gauge.



NXAB3_Gauge-Command_Drive-Configuration_Values

13.4.2 Editing a Parameter


To edit a parameter on a page, double click on the parameter.



NXAB3_Gauge-Command_Update-Item

Enter the new parameter in the dialog, and then click on Set.

A confirmation screen will be displayed. Click **Yes** to write the data to the gauge.



NXAB3_Gauge-Command_Confirm-Action

If the confirmation screen is not required, tick the **Do not show this page again** option. This will only last until the Gauge Commands utility is closed.

The parameter will be shown as **Waiting for Answer** until the new data has been written to the gauge and read back, after which the new value will be displayed in the page.

Many of the parameters are read-only. These have a code that starts with the character "R". Any attempt to write to one of these will result in the following message being displayed.



NXAB3_Gauge-Command_not-valid

(e.g. Instant Bottom Stop, item code R8)

13.4.3 Auto Refresh

To set a page to auto refresh the data at periodic interval, set the field **Auto Update Screen Every** to the interval period required, and then click on the **Start** button.


The data will now be refreshed at the rate specified. If the Auto Update period is set too low, the page will be continually refreshing, during which time the **Waiting for Answer** may be displayed. A refresh period of 10 seconds is the lowest value recommended, with 30 seconds as the more normal value.

13.4.4 Saving the data to file

The full set of data parameters may be updated and saved to an XML format file. This may then be printed or sent to SI for investigation if problems occur with the gauge.


The file will always be saved to the Logs sub-directory of the install directory.

To save the data, click on the page **Save To File**.




NXA83_Gauge-Command_Save-to-File

Select the **File Name** in the Logs directory, and then click on the **Execute** button. All the data for all pages will now be automatically retrieved from the gauge. This may take some time, during which a progress bar will be displayed.



NXA83_Gauge-Command_Updating-Data

When complete, click **OK**. The data saved in the file will be formatted and displayed on the screen.



NXA83_Gauge-Command_Save-to-File_Complete

Previously saved files may be viewed by selecting the **File Name** and clicking on the **View** button.

14 Technical Specification

Property	Specification
CPU	AMD Geode LX2 500 Mhz , Fanless
Memory	512 MB
Disk	2 GB Compact Flash Disk as C drive 1 GB Disk On Module as D drive
Operating System	Windows XP embedded
Display	7 in Widescreen module
Resolution	640 by 480
Keyboard Input	4-wire Touch screen connected to USB port
Standard Serial	8 COM ports
USB	4 ports, USB 2.0 Compliant 2 Internal / 2 External 1 Internal port is used for the touchscreen
Ethernet	1 port , 10/100 Mhz
Power Supply	110 to 240 V _{ac}
Power Consumption	40 W
IP Rating	IP20
Operating Temperature	0 to 40 °C (+32 to +104 °F)
Storage Temperature	0 to 85 °C (+32 to +185 °F)
External Dimensions	Wall Mount: 323 mm × 300 mm × 101.5 mm (12.7 in × 11.8 in × 4 in) Rack Mount: 482.6 mm × 117 mm × 255 mm (19 in × 4.61 in × 10 in)
Mounting	To suit M6 bolts, four positions
Weight	2 kg (4.41 lbs)
Approvals	CE

15 Troubleshooting

The following are some fail modes that may occur during commissioning:

Gauge(s) are displayed with all data DN00 and the "No reply from gauge" alarm is set.

- Check that the data loop is connected to the correct port on the Multi Scan NXA83B and that the wiring is correct.
- Check that the COM port has been configured with the correct protocol and communication parameters (baud rate, parity etc.).
- Check the gauge configuration for the correct gauge addresses and other gauge specific communication parameters.

Index

A

Accessing the Multi Scan NXA83B operating system..	12
Advanced Features	112
Alarm Configuration	61
Enabling and Disabling Alarms	71
Generation of Alarms	71
Launching Alarm Configuration	61
Modifying Data Within Alarm Configuration	71

C

Changing the Multi Scan NXA83B Network Address..	15
Communications Parameter Configuration	38
Configurator	7
Configuring a Host or Slave port	34
Configuring DCC Host Options	37
Configuring protocols	42
Configuring Scheduled Commands	110
Configuring Scheduled Connections	36
Configuring the Multi Scan NXA83B database	18
Configuring the NXA83B using onboard Configurator tools	9
Connecting a modem	16
Connecting to the Multi Scan NXA83B	10

D

Data Communications Controller	20
Database Configuration	33
Database Transporter	30
Designated use	5
Dimensions	127
Display Configuration	78
Adding a display	79
Deleting a display	80
Editing a display	80
Grid View and Reports	92
Columns	97
Filter	95
Grid	94
GridView Report Editor	93
Report Printing	96
Report Scheduling	97
Saving the configuration	99
Setting the DEFAULT display	80
Single Tank and Multi Tank displays	80
Adding a new item	83
Changing the background color	85
Changing the display units	84
Copy, Paste & Select All	85
Display Editor	81
Display Items	87
Modifying an existing item	82
Resize to fit	86
Saving the display	86
Setting the Display Name	84
Tank Data Displays	78
Download Database to the Multi Scan NXA83B	9

E

Enhanced Write Filter (EWF)	16
Enraf Gauge Commands	115
Dipping	119
Gauge Items	116
Lock Test	120
Maintenance	118
Verify Calibration	121
Exiting from the Remote Control session	13
Exporting to the Multi Scan NXA83B	30

G

Gauge Command Scheduler	110
Configuring Scheduled Commands	110
Gauge Commands	113
Enraf Gauge Commands	115
Launching Gauge Commands	113
Scientific Instruments Gauge Commands	122
Sending a Command	113
Gauge Configuration	44
Multi Gauges	47

I

Icons	3
Importing From the Multi Scan NXA83B	32

L

Launching Tank Characteristics	50
--------------------------------------	----

M

Manual Data	71
Entering Manual Data	74
Launching the Manual Data Entry Module	72
Modifying Data Within Tank Characteristics	50
Multi Gauges	47

N

Network Settings	13
NXA83B Configuration	25

O

Overview	7
----------------	---

P

Port Configuration	33
Communications Parameter Configuration	38
Configuring a Host or Slave port	34
Configuring DCC Host Options	37
Configuring Scheduled Connections	36
Data Communications Controller	33
Redundancy	41
Printer Settings	16
Product Configuration	75
Allocating Products to Tanks	77
Launching Product Configuration	75
Product Groups	75

Projects 26
 Backing up projects 29
 Edit Project 29
 New Project 28
 Open Project 28
 Restoring projects 29
 Saving Projects 29

Q
 Quick Start 9
 Configuring the Multi Scan NXA83B database 20

R
 Re-booting 31
 Redundancy 41
 Remote Configuration 113
 Remote Control via a networked PC 10
 Renaming the NXA83B network name 14
 Resolution 127

S
 Safety icons 3
 Scientific Instruments Gauge Commands 122
 Auto Refresh 124
 Editing a Parameter 123
 Page Selection 122
 Saving the data to file 124
 Security 103
 Creating a new User Account 105
 Deleting an existing User Account 107
 Editing an Existing User Account 108
 Forgetting Your Password 109
 Using Security Configuration 103
 Start Tankvision Multi Scan Configurator tools 9
 Symbols 3
 System Configuration 25
 System Settings 101
 Login Enabled 101
 Movement Threshold 102
 Sound Enabled 102
 Use Product Colors 102
 Using System Settings 101
 Voice Enabled 102

T
 Tank Characteristics 49
 Launching Tank Characteristics 50
 Modifying Data Within Tank Characteristics 50
 Tank Strapping Data Configuration 56
 Adding a New Strapping Table 57
 Editing Values in an Existing Strapping Table 59
 Introduction 56
 Loading the Strapping Table Module 57
 Using the Strapping Table Utility 57
 Validity of Data 61
 Viewing Existing Tables 59
 Tankvision Multi Scan Configurator 25
 Technical Specification 127
 Troubleshooting 128

U
 Upload Database from the Multi Scan NXA83B 9

W
 W&M Calibration 74
 Watchdog 24
 Weight 127



71303673

www.addresses.endress.com
