71701641 2025-05-06 Valid as of version 01.00.zz (Device firmware)

BA02135D/06/EN/02.25-00

Operating Instructions **Proline Prowirl R 200**

Vortex flowmeter PROFINET over Ethernet-APL







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser sales organization will supply you with current information and updates to this manual.

Table of contents

1	About this document		
1.1 1.2 1.3	Document functionSymbols1.2.1Safety symbols1.2.2Electrical symbols1.2.3Communication-specific symbols1.2.4Tool symbols1.2.5Symbols for certain types of information1.2.6Symbols in graphicsDocumentation	6 6 6 7 7 8	
1.4	Registered trademarks	8	
2	Safety instructions		
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Operational safety1Product safety1IT security1Device-specific IT security12.7.1Protecting access via hardware write protection2.7.2Protecting access via a password	9 9 10 10 10 10 11	
3	Product description 1	2	
3.1	Product design 1	2	
4	Incoming acceptance and product		
	identification 1	3	
4.1 4.2	Product identification	L3 L3 L4 L6	
5	Storage and transport 1	7	
5.1 5.2	Transporting the product	L7 L7 L7	
5.3	5.2.2 Measuring devices with lifting lugs 15.2.3 Transporting with a fork lift 1	L8 L8 L8	
6	Installation 1	9	
6.1	6.1.1 Installation position	19 19 22	

6.2	Installing the device266.2.1Required tools266.2.2Preparing the measuring device266.2.3Installing the sensor266.2.4Installing the transmitter of the remote version266.2.5Turning the transmitter housing276.2.6Turning the display module28Post-mounting check28
7	Electrical connection
7.1 7.2 7.3	Electrical safety30Connecting requirements307.2.1Required tools307.2.2Requirements for connection cable307.2.3Connecting cable for remote version307.2.4Terminal assignment317.2.5Pin assignment of device plug327.2.6Shielding and grounding327.2.7Requirements for the supply unit337.2.8Preparing the measuring instrument33Connecting the device34
7.4	7.3.1Connecting the compact version 347.3.2Connecting the remote version 35Potential equalization 40
7.1	7.4.1 Requirements
7.5	Ensuring the degree of protection
7.6	Post-connection check
7.6	Post-connection check41 Operation options 42Overview of operation options42Structure and function of the operating42
7.6 8 8.1 8.2	Post-connection check41 Operation options 42Overview of operation options42Structure and function of the operating menu438.2.1Structure of the operating menu438.2.2Operating philosophy44
7.6 8 8.1	Post-connection check41 Operation options 42Overview of operation options42Structure and function of the operating menu438.2.1Structure of the operating menu43

	8.4.2 FieldCare 58 8.4.3 DeviceCare 59
	8.4.4 SIMATIC PDM
9	System integration 61
9.1	Overview of device description files 61
	9.1.1 Current version data for the device 61
	9.1.2 Operating tools 61
9.2	Device master file (GSD) 61
	9.2.1 File name of the manufacturer-
	specific device master file (GSD) 62
	9.2.2 File name of the PA Profile device
0.2	master file (GSD)
9.3	Cyclic data transmission
	9.3.2Description of the modules639.3.3Status coding70
	9.3.4 Factory setting
9.4	System redundancy S2
5.1	
10	Commissioning 72
10.1	Post-mounting and post-connection check 72
10.2	Switching on the measuring device
10.3	Setting the operating language
10.4	Configuring the device
	10.4.1 Displaying the communication
	interface
	10.4.2 Setting the system units 75
	10.4.3 Selecting and setting the medium 79
	10.4.4 Configuration of the Analog Inputs 82
	10.4.5 Configuring the low flow cut off 83
10.5	10.4.6 Advanced settings
10.5	Simulation 108 Protecting settings from unauthorized access 109
10.0	10.6.1 Write protection via access code 109
	10.6.2 Write protection via write protection
	switch 110
10.7	Application-specific commissioning 111
	10.7.1 Steam application 111
	10.7.2 Liquid application 112
	10.7.3 Gas applications 112
	10.7.4 Calculation of the measured
	variables
11	Operation 120
	1
11.1	Reading off the device locking status 120
11.2	Adjusting the operating language 120
11.3 11.4	Configuring the display120Reading off measured values120
11.4	Reading off measured values12011.4.1Process variables120
	11.4.1 Process variables
11.5	Adapting the measuring device to the process
<i>></i>	conditions 124
11.6	Displaying the measured value history 124

12	Diagnostics and troubleshooting	128
12.1	General troubleshooting	128
12.2	Diagnostic information via light emitting	
	diodes	129
	12.2.1 Transmitter	
12.3	Diagnostic information on local display	
	12.3.1 Diagnostic message	131
	12.3.2 Calling up remedial measures	133
12.4	Diagnostic information in the web browser	133
	12.4.1 Diagnostic options	133
10 F	12.4.2 Calling up remedy information	134
12.5	Diagnostic information in FieldCare or	174
	DeviceCare	134 134
	12.5.1 Diagnostic options12.5.2 Calling up remedy information	134 135
12.6	12.5.2 Calling up remedy information Adapting the diagnostic behavior	135
12.0	12.6.1 Available diagnostic behaviors	136
	12.6.2 Displaying the measured value	10
	status	136
12.7	Overview of diagnostic information	137
1017	12.7.1 Diagnostic of sensor	137
	12.7.2 Diagnostic of electronic	144
	12.7.3 Diagnostic of configuration	153
	12.7.4 Diagnostic of process	159
	12.7.5 Operating conditions for displaying	
	the following diagnostics	
	information	169
	12.7.6 Emergency mode in event of	
	temperature compensation	169
12.8	Pending diagnostic events	169
12.9	Diagnostics list	170
12.10	Event logbook	171
	12.10.1 Reading out the event logbook	171
	12.10.2 Filtering the event logbook	171
10 11	12.10.3 Overview of information events	172
12.11	Resetting the device	173
	12.11.1 Function scope of the "Device reset" parameter	173
17 17	Device information	173
	Firmware history	175
12.17		175
13	Maintenance	176
13.1	Maintenance tasks13.1.1Exterior cleaning	176 176
	13.1.1Exterior cleaning13.1.2Interior cleaning	176
	13.1.3 Replacing seals	176
13.2	Measuring and test equipment	176
13.3	Endress+Hauser services	176
19.9		170
14	Repair	177
14.1	General notes	177
	14.1.1 Repair and conversion concept	177
	14.1.2 Notes for repair and conversion	177
14.2	Spare parts	177
14.3	Endress+Hauser services	178
14.4	Return	178

14.5	Disposal17814.5.1Removing the measuring device17814.5.2Disposing of the measuring device179
15	Accessories 180
15.1	Device-specific accessories 180 15.1.1 For the transmitter 180 15.1.2 For the sensor 181
15.2 15.3	Service-specific accessories181System components181
16	Technical data 182
16.1	Application 182
16.2	Function and system design 182
16.3	Input 182
16.4	Output 189
16.5	Power supply 191
16.6	Performance characteristics 193
16.7	Installation 196
16.8	Environment 196
16.9	Process 198
16.10	Mechanical construction
16.11	Operability
	Certificates and approvals 209
	Application packages 211
16.14	Accessories 211
16.15	Documentation 211
Index	c 213

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.2.2 Electrical symbols

Symbol	Meaning	
	Direct current	
\sim	Alternating current	
\sim	Direct current and alternating current	
<u>+</u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.	
Potential equalization connection (PE: Protective earth) Ground terminals that must be connected to ground prior to establishing any oth connections.		
	The ground terminals are located on the interior and exterior of the device:Interior ground terminal: potential equalization connection is connected to the supply network.Exterior ground terminal: device is connected to the plant grounding system.	

1.2.3 Communication-specific symbols

Symbol	Meaning	
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.	
8	Bluetooth Wireless data transmission between devices over a short distance via radio technology.	

1.2.4 Tool symbols

Symbol	Meaning
0 /	Flat-blade screwdriver
$\bigcirc \not \Subset$	Allen key
Ŕ	Open-end wrench

1.2.5 Symbols for certain types of information

Symbol	Meaning
\checkmark	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
1., 2., 3	Series of steps
۲.	Result of a step
?	Help in the event of a problem
	Visual inspection

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
X	Safe area (non-hazardous area)
≈➡	Flow direction

1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the device version:

Document type	Purpose and content of the document	
Technical Information (TI)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.	
Brief Operating Instructions (KA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.	
Operating Instructions (BA)	Your reference document The Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.	
Description of Device Parameters (GP)	Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.	
Safety instructions (XA)	Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. These are an integral part of the Operating Instructions. The nameplate indicates which Safety Instructions (XA) apply to the device.	
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is a constituent part of the device documentation.	

1.4 Registered trademarks

Ethernet-APL™

Registered trademark of the PROFIBUS Nutzerorganisation e.V. (PROFIBUS User Organization), Karlsruhe, Germany

KALREZ[®], VITON[®]

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

GYLON®

Registered trademark of Garlock Sealing Technologies, Palmyar, NY, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ► Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring instrument described in this manual is intended only for the flow measurement of liquids, gases and vapors.

Depending on the version ordered, the measuring instrument can also be used to measure potentially explosive ¹⁾, flammable, toxid and oxidizing media.

Measuring instruments for use in hazardous areas, in hygienic applications, or where there is an increased risk due to pressure, are specially labeled on the nameplate.

To ensure that the measuring instrument is in perfect condition during operation:

- Only use the measuring instrument in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Using the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring instrument only for media to which the process-wetted materials are sufficiently resistant.
- Keep within the specified pressure and temperature range.
- Keep within the specified ambient temperature range.
- Protect the measuring instrument permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- Verify the compatibility of the process fluid with the sensor material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

¹⁾ Not applicable for IO-Link measuring instruments

NOTICE

Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

ACAUTION

Risk of hot or cold burns! The use of media and electronics with high or low temperatures can produce hot or cold surfaces on the device.

• Mount suitable touch protection.

2.3 Workplace safety

When working on and with the device:

• Wear the required personal protective equipment as per national regulations.

2.4 Operational safety

Damage to the device!

- Operate the device in proper technical condition and fail-safe condition only.
- The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to the repair of an electrical device.
- ► Use only original spare parts and accessories.

2.5 Product safety

This state-of-the-art device is designed and tested in accordance with good engineering practice to meet operational safety standards. It left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU declaration of conformity. The manufacturer confirms this by affixing the CE mark.

2.6 IT security

The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater inoperation safety if used correctly. The following list provides an overview of the most important functions:

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

2.7.2 Protecting access via a password

A password can be used to protect against write access to the device parameters.

This controls write access to the device parameters via the local display or other operating tools (e.g. FieldCare, DeviceCare) and, in terms of functionality, corresponds to hardware write protection. If the CDI service interface is used, read access is only possible by first entering the password.

User-specific access code

Write access to the device parameters via the local display or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ($\rightarrow \cong 109$).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning for safety reasons.
- Follow the general rules for generating a secure password when defining and managing the access code and network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see "Write protection via access code" →
 ⁽¹⁾
 ⁽²⁾
 ⁽²

2.7.3 Access via fieldbus

When communicating via fieldbus, access to the device parameters can be restricted to *"Read only"* access. The option can be changed in the **Fieldbus writing access** parameter.

This does not affect cyclic measured value transmission to the higher-order system, which is always guaranteed.

For


For detailed information on device parameters, see: "Description of Device Parameters" document $\rightarrow \cong 212$.

3 Product description

The device consists of a transmitter and a sensor.

- Two device versions are available:
- Compact version transmitter and sensor form a mechanical unit.
- Remote version transmitter and sensor are mounted in separate locations.

3.1 Product design



- 1 Electronics compartment cover
- 2 Display module
- 3 Main electronics module
- 4 Cable glands
- 5 Transmitter housing (incl. HistoROM)
- 6 I/O electronics module
- 7 Terminals (plug-in spring terminals)
- 8 Connection compartment cover9 Sensor

Endress+Hauser

4 Incoming acceptance and product identification

4.1 Incoming acceptance

On receipt of the delivery:

- 1. Check the packaging for damage.
 - → Report all damage immediately to the manufacturer. Do not install damaged components.
- 2. Check the scope of delivery using the delivery note.
- 3. Compare the data on the nameplate with the order specifications on the delivery note.

4. Check the technical documentation and all other necessary documents, e.g. certificates, to ensure they are complete.

If one of the conditions is not satisfied, contact the manufacturer.

4.2 Product identification

The device can be identified in the following ways:


- Nameplate
- Order code with details of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations app* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations app*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard device documentation" and "Supplementary device-dependent documentation" sections
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations app*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Sensor nameplate


Order code for "Housing" option B "GT18 dual compartment, 316L, compact" and option K "GT18 dual compartment, 316L, remote"



Example of a sensor nameplate

- 1 Name of sensor
- 2 Nominal diameter of sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Serial number (Ser. no.)
- 5 Measuring tube material
- 6 Measuring tube material
- 7 Maximum permitted volume flow (gas/steam): $Q_{max} \rightarrow \square 183$
- 8 Test pressure of the sensor: $OPL \rightarrow \square 199$
- 9 Seal material
- 10 Document number of safety-related supplementary documentation \rightarrow \cong 212
- 11 Ambient temperature range
- 12 CE mark
- 13 Medium temperature range
- 14 Degree of protection


Order code for "Housing" option C "GT20 dual compartment, aluminum, coated, compact"



E 2 Example of a sensor nameplate

1 Nominal diameter of sensor

- 2 Flange nominal diameter/nominal pressure
- 3 Measuring tube material
- 4 Measuring tube material
- 5 Serial number (Ser. no.)
- 6 Maximal permitted volume flow (gas/steam)
- 7 Test pressure of the sensor
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive $\rightarrow \square 212$
- 10 CE mark
- 11 Seal material
- 12 Medium temperature range
- 13 Ambient temperature range



Order code for "Housing" option J "GT20 dual compartment, aluminum, coated, remote"

■ 3 Example of a sensor nameplate

- 1 Name of sensor
- 2 Nominal diameter of sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Order code
- 5 Serial number (Ser. no.)
- 6 Extended order code (ext. ord. cd.)
- 7 Maximal permitted volume flow (gas/steam)
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive
- 10 Ambient temperature range
- 11 Document number of safety-related supplementary documentation \rightarrow \cong 212
- 12 Test pressure of the sensor
- 13 Measuring tube material
- 14 Measuring tube material
- 15 Seal material
- 16 Medium temperature range

🛐 Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.2 Symbols on the device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. Please consult the documentation for the measuring instrument to discover the type of potential danger and measures to avoid it.
	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal that must be connected to the ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight. Avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ► Do not store outdoors.

Storage temperature: -50 to +80 °C (-58 to +176 °F)

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- Observe the weight specified on the packaging (stick-on label).



Endress+Hauser

5.2.2 Measuring devices with lifting lugs

Special transportation instructions for devices with lifting lugs

- Only use the lifting lugs fitted on the device or flanges to transport the device.
- The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Outer packaging of device
- Stretch wrap made of polymer in accordance with EU Directive 2002/95/EC (RoHS) Packaging
 - Wood crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62/EC, recyclability confirmed by Resy symbol
- Transport material and fastening fixtures
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material Paper pads

6 Installation

6.1 Installation requirements

6.1.1 Installation position

Mounting location



1 Installation suitable for gases and steam

2 Installation not suitable for liquids

Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Vortex meters require a fully developed flow profile as a prerequisite for correct volume flow measurement. Therefore, please note the following:

	Orientation		Recomme	endation
			Compact version	Remote version
A	Vertical orientation (liquids)	A0015591	V V ¹⁾	
A	Vertical orientation (dry gases)			
		A0041785		
В	Horizontal orientation, transmitter head up		√ √ ²⁾	


	Orientation		Recommendation	
			Compact version	Remote version
C	Horizontal orientation, transmitter head down	A0015590	X X ³⁾	
D	Horizontal orientation, transmitter head at side	A0015592		

1) In the case of liquids, there should be upward flow in vertical pipes to avoid partial pipe filling (Fig. A). Disruption in flow measurement!

2) In the case of hot media (e.g. steam or medium temperature (TM) ≥ 200 °C (392 °F): orientation C or D

3) In the case of very cold media (e.g. liquid nitrogen): orientation B or D


Pressure measuring cell



1) Note max. permitted ambient temperature of transmitter $\rightarrow \square$ 22.

Inlet and outlet runs

To attain the specified level of accuracy of the measuring instrument, the inlet and outlet runs mentioned below must be maintained at the very minimum.



Minimum inlet and outlet runs with various flow obstructions


- *h* Difference in expansion
- 1 Reduction by one nominal diameter size
- *2* Single elbow (90° elbow)
- 3 Double elbow $(2 \times 90^{\circ} \text{ elbows, opposite})$
- 4 Double elbow 3D ($2 \times 90^{\circ}$ elbows, opposite, not on one plane)
- 5 T-piece
- 6 Extension
- 7 Control valve
- 8 Two measuring instruments in a row where $DN \le 25$ (1"): directly flange on flange
- 9 Two measuring instruments in a row where $DN \ge 40 (1\frac{1}{2})$: for spacing, see graphic

• If there are several flow disturbances present, the longest specified inlet run must be maintained.

Flow conditioner

If the inlet runs cannot be observed, the use of a flow conditioner is recommended.

The flow conditioner is fitted between two pipe flanges and centered by the mounting bolts. Generally this reduces the inlet run needed to $10 \times DN$ with full measurement accuracy.



1 Flow conditioner

The pressure loss for flow conditioners is calculated as follows:

 $\Delta p \text{ [mbar]} = 0.0085 \cdot \rho \text{ [kg/m³]} \cdot v^2 \text{ [m/s]}$

Example for steam	
p = 10 bar abs.	
t = 240 °C \rightarrow ρ = 4.39 kg/m ³	
v = 40 m/s	
$\Delta p = 0.0085 \cdot 4.39 \cdot 40^2 = 59.7 \text{ mbar}$	


Example for H ₂ O condensate (80 °C)	
$\rho = 965 \text{ kg/m}^3$	
v = 2.5 m/s	
$\Delta p = 0.0085 \cdot 965 \cdot 2.5^2 = 51.3 \text{ mbar}$	

 $\label{eq:relation} \begin{array}{l} \rho : density \ of \ the \ process \ medium \\ v: \ average \ flow \ velocity \\ abs. = \ absolute \end{array}$

For the dimensions of the flow conditioner, see the "Technical Information" document, "Mechanical construction" section

Outlet runs when installing external devices

If installing an external device, observe the specified distance.



PT Pressure

TT Temperature device

Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Environmental and process requirements

Ambient temperature range

Compact version

Measuring instrument	Non-hazardous area:	-40 to +80 °C (-40 to +176 °F)
	Ex i, Ex nA, Ex ec:	-40 to +70 °C (-40 to +158 °F)

	Ex d, XP:	-40 to +60 °C (-40 to +140 °F)
	Ex d, Ex ia:	-40 to +60 °C (-40 to +140 °F)
Local display	L.	-40 to +70 °C (-40 to +158 °F) ¹⁾

1) At temperatures below -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

Remote version

Transmitter	Non-hazardous area:	−40 to +80 °C (−40 to +176 °F)
	Ex i, Ex nA, Ex ec:	-40 to +80 °C (-40 to +176 °F)
	Ex d:	-40 to +60 °C (-40 to +140 °F)
	Ex d, Ex ia:	-40 to +60 °C (-40 to +140 °F)
Sensor	Non-hazardous area:	-40 to +85 °C (-40 to +185 °F)
	Ex i, Ex nA, Ex ec:	-40 to +85 °C (-40 to +185 °F)
	Ex d:	-40 to +85 °C (-40 to +185 °F)
	Ex d, Ex ia:	-40 to +85 °C (-40 to +185 °F)
Local display		-40 to +70 °C (-40 to +158 °F) ¹⁾

1) At temperatures < -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

► If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.

You can order a weather protection cover from Endress+Hauser. $\rightarrow \cong 180$.


Thermal insulation

For optimum temperature measurement and mass calculation, heat transfer at the sensor must be avoided for some fluids. This can be ensured by installing thermal insulation. A wide range of materials can be used for the required insulation.

This applies for:

- Compact version
- Remote sensor version


The maximum insulation height permitted is illustrated in the diagram:



- 1 Maximum insulation height
- When insulating, ensure that a sufficiently large area of the housing support remains exposed.

The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

The function of the siphon is to protect the measuring cell from excessively high steam process temperatures through the formation of condensate in the U-tube/ circular pipe. To ensure the steam condenses, the siphon may only be insulated as far as the connection flange on the measuring tube side.



🖻 5 Siphon

NOTICE

Electronics overheating on account of thermal insulation!


- Observe the maximum permitted insulation height of the transmitter neck so that the transmitter head and/or the connection housing of the remote version is completely free.
- Observe information on the permissible temperature ranges .
- ▶ Note that a certain orientation might be required, depending on the fluid temperature .

Installation for delta heat measurements

- Order code for "Sensor version", option CA "Mass; 316L; 316L (integrated temperature measurement), -200 to +400 °C (-328 to +750 °F)"
- Order code for "Sensor version", option CB "Mass; Alloy C22; 316L (integrated temperature measurement), -200 to +400 °C (-328 to +750 °F)"
- Order code for "Sensor version", option DA "Mass steam; 316L; 316L (integrated pressure/temperature measurement), -200 to +400 °C (-328 to +750 °F)"
- Order code for "Sensor version", option DB "Mass gas/liquid; 316L; 316L (integrated pressure/temperature measurement), -40 to +100 °C (-40 to +212 °F)"

The second temperature measurement is taken using a separate temperature sensor. The measuring instrument reads in this value via a communication interface.

- In the case of saturated steam delta heat measurements, the measuring instrument must be installed on the steam side.
- In the case of water delta heat measurements, the device can be installed on the cold or warm side.



6 Layout for delta heat measurement of saturated steam and water

- 1 Measuring instrument
- 2 Temperature sensor
- 3 Heat exchanger
- Q Heat flow

Installation in steam systems

The device has been tested for dynamic pressure surges of up to 300 bar (4350 psi) by condensation-induced water hammer (CIWH). Despite the robust and reinforced design, the following best practice recommendations for steam applications apply to prevent damage from condensation-induced water hammer.

- 1. Ensure sufficient and constant condensate drainage from the pipes by using correctly dimensioned and well-maintained steam traps. These are generally installed every 30 to 50 m (100 to 165 in) in horizontal pipes or at ground points.
- 2. The steam lines must have an adequate gradient of at least 1% in the direction of the steam flow to ensure that the condensate is directed to the steam traps at the drain points
- 3. If the system is shut down, they must be drained completely.
- 4. Avoid pipe configurations that cause accumulations of standing water.
- 5. Slowly increase the static pressure and steam flow rate when starting up the system.
- 6. Make sure steam does not come into contact with significantly cooler condensate.

Protective cover

A protective cover is available as an accessory for the device. It is used to protect against direct sunlight, precipitation and ice.

When installing the protective cover, a minimum upward clearance must be maintained: 222 mm (8.74 in)

The protective cover can be ordered via the product structure together with the device: Order code for "Accessories enclosed" option PB "Protective cover"



Ordered separately as an accessory \rightarrow $\implies 180$

6.2 Installing the device

6.2.1 Required tools

For transmitter

- For turning the transmitter housing: Open-ended wrench8 mm
- For opening the securing clamps: Allen key3 mm

For sensor

For flanges and other process connections: Use a suitable mounting tool.

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.

2. Remove any protective covers or protective caps present from the sensor.


3. Remove stick-on label on the electronics compartment cover.

6.2.3 Installing the sensor

WARNING

Danger due to improper process sealing!

- Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- Ensure that the seals are clean and undamaged.
- Secure the seals correctly.
- **1.** Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
- 2. To ensure compliance with device specifications, install the measuring instrument between the pipe flanges in a way that it is centered in the measurement section.
- 3. Install the measuring instrument or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Installing the transmitter of the remote version

ACAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

ACAUTION


Excessive force can damage the housing!

Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:


- Wall mounting
- Pipe mounting

Wall mounting



🖻 7 mm (in)


Pipe mounting



🖻 8 mm (in)

6.2.5 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- 1. Loosen the securing screw.
- 2. Turn the housing to the desired position.
- 3. Firmly tighten the securing screw.

6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.



- 1. Loosen the securing clamp of the electronics compartment cover using an Allen key.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Optional: pull out the display module with a gentle rotational movement.
- 4. Turn the display module to the desired position: Max. $8 \times 45^{\circ}$ in each direction.
- Without display module pulled out: Allow display module to engage at desired position.
- 6. With display module pulled out:Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.
- 7. Reassemble the transmitter in the reverse order.

6.3 Post-mounting check

Is the device undamaged (visual inspection)?	
 Does the measuring instrument correspond to the measuring point specifications? For example: Process temperature → ■ 198 Process pressure (refer to the section on "Pressure/temperature ratings" in the "Technical Information" document) Ambient temperature Measuring range → ■ 183 	
 Has the correct orientation been selected for the sensor → According to sensor type As per medium temperature As per medium properties (outgassing, with entrained solids) 	
Does the arrow on the sensor match the direction of flow of the medium $\rightarrow \implies 19?$	

Is the tag name and labeling correct (visual inspection)?	
Is the device sufficiently protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	
Has the maximum permitted insulation height been observed?	

7 Electrical connection

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver \leq 3 mm (0.12 in)

7.2.2 Requirements for connection cable

The connecting cables provided by the customer must fulfill the following requirements.

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Signal cable

Pulse/frequency/switch output

Standard installation cable is sufficient.

Ethernet-APL

Shielded twisted-pair cable. Cable type A is recommended.

See https://www.profibus.com Ethernet-APL White Paper "

Cable diameter

• Cable glands supplied:

M20 \times 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)

 Plug-in spring terminals for device version without integrated overvoltage protection: wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

7.2.3 Connecting cable for remote version

Connecting cable (standard)

Standard cable	$2\times2\times0.5~mm^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) $^{1)}$
Flame resistance	According to DIN EN 60332-1-2
Oil resistance	According to DIN EN 60811-2-1
Shielding	Galvanized copper-braid, opt. density approx. 85 %

Cable length	5 m (15 ft), 10 m (30 ft), 20 m (60 ft), 30 m (90 ft)
1 1 5	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)

 UV radiation may cause damage to the outer jacket of the cable. Protect the cable from exposure to sun as much as possible.


Connecting cable (armored)

Cable, armored	$2\times2\times0.34~mm^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) and additional steel-wire braided sheath $^{1)}$	
Flame resistance	According to DIN EN 60332-1-2	
Oil resistance	According to DIN EN 60811-2-1	
Shielding	Galvanized copper-braid, opt. density approx. 85%	
Strain relief and reinforcement	Steel-wire braid, galvanized	
Cable length	10 m (30 ft), 20 m (60 ft), 30 m (90 ft)	
Continuous operating temperature	When mounted in a fixed position: -50 to +105 °C (-58 to +221 °F); when cable can move freely: -25 to +105 °C (-13 to +221 °F)	

 UV radiation may cause damage to the outer jacket of the cable. Protect the cable from exposure to sun as much as possible.

7.2.4 Terminal assignment

Transmitter



Order code for "Output"	Terminal numbers	
	Output 1	
	1 (+)	2 (-)
Option S ¹⁾	PROFINET over Ethernet-APL	

1) PROFINET over Ethernet-APL with integrated reverse polarity protection.

	Pin	Assignment	Coding	Plug/socket
3 4	1	APL signal -	А	Socket
	2	APL signal +		
	3	Cable shield ¹		
	4	Not used		
	Metal plug housing	Cable shield		
	¹ If a cable shield is used			

7.2.5 Pin assignment of device plug

7.2.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible.

- **1.** To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.

- **1.** Observe national installation requirements and guidelines during installation.
- 2. Where there are large differences in potential between the individual grounding points,

connect only one point of the shielding directly to the reference ground.


3. In systems without potential equalization, the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- Insulate the shield that is not connected.



Connection example for PROFINET over Ethernet-APL

- 1 Cable shield
- 2 Measuring instrument
- 3 Local grounding
- 4 Potential equalization
- 5 Trunk or TCP
- 6 Field switch

7.2.7 Requirements for the supply unit

Supply voltage

Transmitter

The following supply voltage values apply for the outputs available:

Supply voltage for a compact version

Order code for "Output; input"	Minimum Terminal voltage	Maximum Terminal voltage	
Option S : PROFINET over Ethernet-APL	≥ DC 9 V	 Non-Ex: DC 30 V Ex: DC max. 15 V 	

Transient overvoltage: Up to overvoltage category I

7.2.8 Preparing the measuring instrument

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Sensor connection housing: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.
- 4. Transmitter: Connect cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.

- If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- If the measuring device is supplied with cable glands:
 Observe requirements for connecting cables →
 ⁽¹⁾ 30.

7.3 Connecting the device

NOTICE

An incorrect connection compromises electrical safety!

- Only properly trained specialist staff may perform electrical connection work.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.
- The power unit must be safety-approved (e.g. SELV/PELV protection class II limited power).


7.3.1 Connecting the compact version

Connecting the transmitter

The connection of the transmitter depends on the following order code: "Electrical connection":

- Option A, B, C, D: terminals
- Option I: device plug

Connection via terminals



- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect cable in accordance with terminal assignment .

6. **WARNING**


Housing degree of protection may be voided due to insufficient sealing of the housing.

 Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Firmly tighten the cable glands.


7. Reassemble the transmitter in the reverse order.

Connection via device plug



• Plug in the device plug and tighten firmly.

Removing a cable



 To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes while simultaneously pulling the cable end out of the terminal.

7.3.2 Connecting the remote version

WARNING

Risk of damaging electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.

The following sequence of steps is recommended :

1. Mount the sensor and transmitter.

2. Connect the .

3. Connect the transmitter.

How the connecting cable is connected in the transmitter housing depends on the measuring instrument approval and the version of the connecting cable used.

In the following versions, only terminals can be used for connection in the transmitter housing:


- Order code for "Electrical connection", option B, C, D, 6
- Certain approvals: Ex nA, Ex ec, Ex tb and Division 1
- Use of reinforced connecting cable

In the following versions, an M12 device connector is used for connection in the transmitter housing:

- All other approvals
- Use of connecting cable (standard)


Terminals are always used to connect the connecting cable in the sensor connection housing (tightening torques for screws for cable strain relief: 1.2 to 1.7 Nm).

Connecting the sensor connection housing



1. Loosen the securing clamp.

2. Unscrew the housing cover.



■ 10 Sample graphic

Connecting cable (standard, reinforced)

3. Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).


- 4. Wire the connecting cable:
 - └ Terminal 1 = brown cable
 - Terminal 2 = white cable Terminal 3 = yellow cable
 - Terminal 4 = green cable
- 5. Connect the cable shield via the cable strain relief.
- 6. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 7. Reverse the removal procedure to reassemble the connection housing.

Connecting cable (option "mass pressure-/temperature-compensated")

- **3.** Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
- 4. Wire the connecting cable:
 - ➡ Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = green cable Terminal 4 = red cable Terminal 5 = black cable Terminal 6 = yellow cable Terminal 7 = blue cable
- 5. Connect the cable shield via the cable strain relief.
- 6. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 7. Reverse the removal procedure to reassemble the connection housing.


Connecting the transmitter

Connecting transmitter via plug




Connect the plug.


Connecting transmitter via terminals



- 1. Loosen the securing clamp of the electronics compartment cover.
- 2. Unscrew the electronics compartment cover.
- **3.** Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.



- 4. Loosen the locking screw of the transmitter housing.
- 5. Loosen the securing clamp of the transmitter housing.




- 🖻 11 Sample graphic
- 6. Turn the transmitter housing to the right until it reaches the marking.

7. NOTICE


The connection board of the wall housing is connected to the electronics board of the transmitter via a signal cable!

▶ Pay attention to the signal cable when lifting the transmitter housing!

Lift the transmitter housing.



🖻 12 Sample graphic



🖻 13 Sample graphic

Connecting cable (standard, reinforced)

- 8. Disconnect the signal cable from the connection board of the wall housing . by pressing in the locking clip on the connector. Remove the transmitter housing.
- **9.** Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
- **10**. Wire the connecting cable:
 - → Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = yellow cable Terminal 4 = green cable
- **11.** Connect the cable shield via the cable strain relief.
- 12. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 13. Reverse the removal procedure to reassemble the transmitter housing.

Connecting cable (option "mass pressure-/temperature-compensated")

- 8. Disconnect both signal cables from the connection board of the wall housing. by pressing in the locking clip on the connector. Remove the transmitter housing.
- 9. Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
- **10.** Wire the connecting cable:
 - Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = green cable Terminal 4 = red cable Terminal 5 = black cable Terminal 6 = yellow cable
 - Terminal 7 = blue cable
- **11.** Connect the cable shield via the cable strain relief.
- 12. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 13. Reverse the removal procedure to reassemble the transmitter housing.

7.4 Potential equalization

7.4.1 Requirements

For potential equalization:


- Pay attention to in-house grounding concepts
- Take account of operating conditions, such as the pipe material and grounding
- Connect the medium, sensor and transmitter to the same electric potential
- Use a ground cable with a minimum cross-section of 6 mm² (10 AWG) and a cable lug for potential equalization connections

7.5 Ensuring the degree of protection

The measuring instrument fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To guarantee the degree of protection IP66/67, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.
- To ensure that moisture does not enter the cable entry: Route the cable so that it loops down before the cable entry ("water trap").




6. The cable glands supplied do not ensure housing protection when not in use. They must therefore be replaced by dummy plugs corresponding to the housing protection.

7.6 Post-connection check

Are the device and cable undamaged (visual inspection)? Do the cables used comply with the requirements → 🖹 30? Are the mounted cables strain relieved?	
Are the mounted cables strain relieved?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" $\rightarrow \cong 40$?	
Depending on the device version: are all the device plugs firmly tightened $\rightarrow \square 34$?	
Only for remote version: Is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	
Does the supply voltage match the specifications on the transmitter nameplate ?	
Is the terminal assignment correct ?	
If supply voltage is present, do values appear on the display module?	
Are all housing covers installed and firmly tightened?	
Is the securing clamp securely tightened?	
Have the screws for the cable strain relief been tightened using the correct tightening torque $\rightarrow \cong 35$?	

8 Operation options

8.1 Overview of operation options




- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Standard Ethernet switch, e.g. Scalance X204 (Siemens)
- Computer with Web browser for accessing the integrated Web server or computer with operating tool (e.g. FieldCare, DeviceCare, SIMATIC PDM) with PROFINET COM DTM "CDI Communication TCP/IP"
- 4 APL power switch (optional)
- 5 APL field switch
- 6 Measuring instrument

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device



I4 Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (e.g. operator, maintenance etc.). Each user role contains typical tasks within the device life cycle.

Menu/parameter		User role and tasks	Content/meaning
Language	Task- oriented	Role "Operator", "Maintenance" Tasks during operation:	Defining the operating languageResetting and controlling totalizers
Operation		Configuration of the operational displayReading measured values	 Configuration of the operational display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup	-	 "Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs 	 Wizards for fast commissioning: Configuring the system units Definition of the medium Configuration of the current input Configuring the outputs Configuration of the operational display Definition of output conditioning Configuring the low flow cut off
			 Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers Administration (define access code, reset measuring device)
Diagnostics		 "Maintenance" role Troubleshooting: Diagnostics and elimination of process and device errors Measured value simulation 	 Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device Measured values Contains all current measured values. Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values Heartbeat Technology Verification of device functionality on request and documentation of verification results Simulation Used to simulate measured values or output values.
Expert	Function- oriented	 Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases 	 Contains all of the device parameters and allows direct access to these by means of an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-level device parameters that do not affect measurement or measured value communication Sensor Configuration of the measurement. Communication Configuration of the digital communication interface Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer) Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to operating menu via local display

8.3.1 Operational display



- 1 Operational display
- 2 Tag name
- 3 Status area
- 4 Display area for measured values (up to 4 lines)
- 5 Operating elements $\rightarrow \square 50$

Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals $\rightarrow \square 131$
 - F: Failure
 - **C**: Function check
 - S: Out of specification
 - M: Maintenance required
- Diagnostic behavior $\rightarrow \cong 132$
 - 🛛 🐼: Alarm
 - <u>M</u>: Warning
- 🟦: Locking (the device is locked via the hardware)
- •: Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured variables

Symbol	Meaning
Ú	Volume flow

The number and display format of the measured variables can be configured via the Format display parameter ($\rightarrow \cong 105$).

Totalizer

Symbol	Meaning
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.

Measurement channel numbers


Symbol	Meaning	
14	Measurement channel 1 to 4 The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

Diagnostic behavior

Symbol	Meaning	
8	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red. 	
Δ	 Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated. 	

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.

8.3.2 Navigation view



Navigation path

The navigation path to the current position is displayed at the top left in the navigation view and consists of the following elements:

- The display symbol for the menu/submenu (►) or the wizard (►).
- An omission symbol (/ ../) for operating menu levels in between.
- Name of the current submenu, wizard or parameter


	Display symbol	Omission symbol	Parameter
	\downarrow	\checkmark	\checkmark
Example	►	//	Indication

For more information about the icons in the menu, refer to the "Display area" section $\rightarrow \cong 47$

Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
 - The direct access code to the parameter (e.g., 0022-1)
- If a diagnostic event is present, the diagnostic behavior and status signal In the wizard
- If a diagnostic event is present, the diagnostic behavior and status signal



Display area

Menus

Symbol	Meaning
Ŵ	Operation Is displayed: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu

ىر	 Setup Is displayed: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
પ	 Diagnosis Is displayed: In the menu next to the "Diagnostics" selection At the left in the navigation path in the Diagnostics menu
÷ *	Expert Is displayed: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
₩.	Wizards
Ø	Parameters within a wizard Image: No display symbol exists for parameters in submenus.


Locking procedure

Symbol	Meaning
Ô	Parameter lockedWhen displayed in front of a parameter name, indicates that the parameter is locked.By a user-specific access codeBy the hardware write protection switch

Wizards

Symbol	Meaning
	Switches to the previous parameter.
\checkmark	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 Editing view



Input screen

The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol Meaning	
0 9	Selection of numbers from 0 to 9
·	Inserts a decimal separator at the cursor position.
_	Inserts a minus sign at the cursor position.
\checkmark	Confirms the selection.
+	Moves the input position one position to the left.
	Exits the input without applying the changes.
C	Clears all entered characters.

Text editor

Symbol Meaning		
Aa1@	Toggle • Between upper-case and lower-case letters • For entering numbers • For entering special characters	
ABC_ XYZ	Selection of letters from A to Z.	
abcxyz	Selection of letters from a to z.	
···· ··· ···	Selection of special characters.	
	Confirms the selection.	
+×C+→	Switches to the selection of the correction tools.	
X	Exits the input without applying the changes.	
C	Clears all entered characters.	

Text correction under $\Join c \leftrightarrow$

Sym	nbol	Meaning
	C	Clears all entered characters.

\rightarrow	Moves the input position one position to the right.	
Ð	Moves the input position one position to the left.	
×,	Deletes one character immediately to the left of the input position.	

8.3.4 Operating elements

Operating key Meaning		
	Minus key	
	<i>In menu, submenu</i> Moves the selection bar upwards in a picklist	
	In wizards Goes to previous parameter	
	In the text and numeric editor In the input screen, moves the selection bar to the left (backwards)	
	Plus key	
	<i>In menu, submenu</i> Moves the selection bar downwards in a picklist	
	In wizards Goes to the next parameter	
	In the text and numeric editor In the input screen, moves the selection bar to the right (forwards)	
	Enter key	
	<i>In the operational display</i> Pressing the key for 2 s opens the context menu.	
	In menu, submenu Pressing the key briefly:	
	 Opens the selected menu, submenu or parameter. Starts the wizard.	
E	 If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter:	
	If present, opens the help text for the function of the parameter.	
	<i>In wizards</i> Opens the editing view of the parameter and confirms the parameter value	
	In the text and numeric editor Pressing the key briefly: 	
	 Opens the selected group. 	
	Carries out the selected action.Pressing the key for 2 s confirms the edited parameter value.	
	Escape key combination (press keys simultaneously)	
	In menu, submenu	
	Pressing the key briefly:Exits the current menu level and takes you to the next higher level.	
-++	 If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position").	
	<i>In wizards</i> Exits the wizard and takes you to the next higher level	
	<i>In the text and numeric editor</i> Closes the text or numeric editor without applying changes.	
++E	Plus/Enter key combination (press and hold down the keys simultaneously)	
	Increases the contrast (darker setting).	
	Minus/Plus/Enter key combination (press the keys simultaneously)	
	<i>In the operational display</i> Enables or disables the keypad lock (only SD02 display module).	

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Configuration backup display
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the \Box and \blacksquare keys for longer than 3 seconds.
 - └ The context menu opens.



- 2. Press + + simultaneously.
 - └ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press \pm to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - └ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\rightarrow \cong 47$

Example: Setting the number of displayed measured values to "2 values"




8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

Expert \rightarrow Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter **"914"** instead of **"00914"**
- If no channel number is entered, channel 1 is opened automatically.
- Example: Enter $00914 \rightarrow Assign \ process \ variable$ parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter 00914-2 \rightarrow Assign process variable parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

8.3.8 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

└ The help text for the selected parameter opens.




- ☑ 15 Example: Help text for parameter "Enter access code"
- 2. Press + + simultaneously.
 - └ The help text is closed.

8.3.9 Changing the parameters

For a description of the editing view - consisting of the text editor and numeric editor - with symbols $\rightarrow \cong 48$, for a description of the operating elements $\rightarrow \cong 50$

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A message is displayed if the value entered is outside the permitted value range.

Er	nt. access code
In	valid or out of range input
va	lue
Mi	in:0
Ma	ax:9999

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ► Define the access code.
 - └ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ ¹⁾

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	_ 1)

1) Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection as they do not affect the measurement: write protection via access code

The user role with which the user is currently logged on is indicated by the **Access** status display parameter. Navigation path: Operation \rightarrow Access status display

8.3.11 Disabling write protection via access code

If the @-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\rightarrow @$ 109.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ($\rightarrow \boxtimes 85$) via the respective access option.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

➡ The B -symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

🛐 For the SD03 display only

- The keypad lock is switched on automatically:
- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press the \boxdot and \boxtimes keys for 3 seconds.

- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

► The keypad lock is switched on.

Press the \boxdot and \blacksquare keys for 3 seconds.


└ The keypad lock is switched off.

8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.4.1 Connecting the operating tool


Via APL network



16 Options for remote operation via APL network

- 1 Automation system, e.g. Simatic S7 (Siemens)
- 2 Ethernet switch, e.g. Scalance X204 (Siemens)
- Computer with Web browser (e.g. Internet Explorer) for access to integrated Web server or computer with an 3 operating tool (e.g. FieldCare, DeviceCare with PROFINET COM DTM or SIMATIC PDM with FDI Package)
- APL power switch (optional) APL field switch 4
- 5
- 6 Measuring instrument

Via service interface (CDI)



1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring instrument

- 2 Commubox FXA291
- 3 Computer with operating tool (e.g. FieldCare or DeviceCare) and (CDI) DeviceDTM

8.4.2 FieldCare

Function range

FDT-based (Field Device Technology) plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

CDI service interface \rightarrow 🗎 58

Typical functions:

- Transmitter parameter configuration
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

Operating Instructions BA00027S

Operating Instructions BA00059S

```
Source for device description files \rightarrow \cong 61
```


Establishing a connection

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
 - └ The **Add device** window opens.
- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.

5. Select the desired device from the list and press **OK** to confirm.

- ← The **CDI Communication TCP/IP (Configuration)** window opens.
- 6. Enter the device address in the IP address field: 192.168.1.212 and press Enter to confirm.
- 7. Establish the online connection to the device.
- Operating Instructions BA00027S
 - Operating Instructions BA00059S

User interface



- 1 Header
- Picture of device 2
- 3 Device name
- 4 Tag name
- 5 Status area with status signal $\rightarrow \square 134$
- 6 Display area for current measured values
- 7 Editing toolbar with additional functions such as save/load, event list and create documentation 8
 - Navigation area with operating menu structure
- 9 Work area
- 10 Action area
- 11 Status area

8.4.3 **DeviceCare**

Function range

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.

Innovation brochure IN01047S



Source for device description files $\rightarrow \cong 61$

8.4.4 SIMATIC PDM

Function range

Standardized, vendor-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via the PROFINET protocol.



Source for device description files $\rightarrow \cong 61$

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.00.zz	 On the title page of the manual On the transmitter nameplate Firmware version parameter Diagnostics → Device information → Firmware version
Manufacturer	17	Manufacturer Expert → Communication → Physical block → Manufacturer
Device ID	0xA438	-
Device type ID	Prowirl 200	Device type Expert \rightarrow Communication \rightarrow Physical block \rightarrow Device type
Device revision	1	-
PROFINET over Ethernet-APL version	2.43	Version of the PROFINET specification

fera For an overview of the various firmware versions for the device ightarrow 🖺 175

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via APL port	Sources for obtaining device descriptions
FieldCare	 www.endress.com → Downloads area USB stick (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	 www.endress.com → Downloads area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
SIMATIC PDM (Siemens)	www.endress.com \rightarrow Downloads area

9.2 Device master file (GSD)

In order to integrate field devices into a bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format and data volume.

These data are available in the device master file (GSD) which is provided to the automation system when the communication system is commissioned. In addition device bit maps, which appear as icons in the network structure, can also be integrated.

The device master file (GSD) is in XML format, and the file is created in the GSDML description markup language.

With the PA Profile 4.02 device master file (GSD) it is possible to exchange field devices made by different manufacturers without having to reconfigure.

Two different device master files (GSD) can be used: Manufacturer-specific GSD and PA Profile GSD.

9.2.1 File name of the manufacturer-specific device master file (GSD)

Example of the name of a device master file:

GSDML-V2.43-EH-PROWIRL_200_APL_yyyymmdd.xml

GSDML	Description language	
V2.43	Version of the PROFINET specification	
EH	Indress+Hauser	
200_APL	Transmitter	
yyyymmdd	Date of issue (yyyy: year, mm: month, dd: day)	
.xml	File name extension (XML file)	

9.2.2 File name of the PA Profile device master file (GSD)

Example of the name of a PA Profile device master file:

GSDML-V2.43-PA_Profile_V4.02-B330-FLOW_VORTEX-yyyymmdd.xml

GSDML	Description language	
V2.43	Version of the PROFINET specification	
PA_Profile_V4.02	Version of the PA Profile specification	
B330	PA Profile device identification	
FLOW	Product line	
VORTEX	Flow measuring principle	
yyyymmdd	Date of issue (yyyy: year, mm: month, dd: day)	
.xml	File name extension (XML file)	

API	Supported modules	Slot	Input and output variables
	Analog input	1	Volume flow
0x9700	Analog input	2	Vortex frequency
	Totalizer	3	Totalizer value: volume/volume Totalizer Control

Where to acquire the manufacturer-specific GSD:

Manufacturer-specific GSD:	www.endress.com \rightarrow Downloads section
	https://www.profibus.com/products/gsd-files/gsd-library-profile-for-process-control-devices-version-40 \rightarrow Downloads section

9.3 Cyclic data transmission

9.3.1 Overview of the modules

The following graphic shows which modules are available to the device for cyclic data transfer. Cyclic data transfer is performed with an automation system.

	Measuring device		Sub-slot	Direction	Control
API	Modules Slot		500-5100	Data flow	system
	Analog Input 1 (Volume flow)	1	1	÷	
	Analog Input 2 (Vortex frequency)	2	1	÷	
	Analog Input 3	20	1	÷	
	Analog Input 4	21	1	÷	
	Totalizer 1 (Volume)	3	1	→ ←	
	Totalizer 2	70	1	→ ←	
0x9700	Totalizer 3	71	1	→ ←	PROFINET
	Binary Input 1 (Heartbeat)	80	1	÷	
	Binary Input 2	81	1	÷	
	Analog Output 1 (Pressure)	160	1	÷	
	Analog Output 2 (Density)	161	1	÷	
	Analog Output 3 (Temperature)	162	1	÷	
	Binary Output 1 (Heartbeat)	210	1	÷	
	Binary Output 2	211	1	÷	

Manufacturer-specific GSD:

9.3.2 Description of the modules

The data structure is described from the perspective of the automation system:

- Input data: Are sent from the measuring device to the automation system.
- Output data: Are sent from the automation system to the measuring device.

Analog Input module

Transmit input variables from the measuring device to the automation system.

Analog Input modules cyclically transmit the selected input variables, including the status, from the measuring device to the automation system. The input variable is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Slot	Sub-slot	Input variables
1	1	Volume flow
2	1	Vortex frequency
2021	1	 Mass flow Volume flow Density Temperature Pressure Specific volume Degree of overheating Electronics temperature Vortex frequency Vortex bow Vortex amplitude Calculated saturated steam pressure Steam quality Total mass flow Condensate mass flow Energy flow Heat flow difference Reynolds number Flow velocity Corrected volume flow

Selection: input variable

Data structure

Output data of Analog Output

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	Measured value: floating point numb			Status 1)

1) Status coding $\rightarrow \square 70$

Binary input module

Transmit binary input variables from the measuring device to the automation system.

Binary input variables are used by the measuring device to transmit the state of device functions to the automation system.

Binary Input modules cyclically transmit discrete input variables, including the status, from the measuring device to the automation system. The discrete input variable is depicted in the first byte. The second byte contains standardized status information pertaining to the input variable.

Selection: device function, binary input, slot 80

Slot	Sub-slot	Bit	Device function	Status (meaning)
		0	Verification was not performed.	 0 (device function not active)
		1	The device has failed the verification.	 1 (device function active)
		2	Currently performing verification.	
80	1	3	Verification ended.	
		4	The device has failed the verification.	
		5	Verification carried out successfully.	

Slot	Sub-slot	Bit	Device function	Status (meaning)
		6	Verification was not performed.	
		7	Reserved	

Selection: device function, binary input, slot 81

Slot	Sub-slot	Bit	Device function	Status (meaning)
		0	Reserved	 0 (device function not active)
		1	Low flow cut off	 1 (device function active)
		2	Reserved	
81	1	3	Reserved	
01	T	4	Reserved	
		5	Reserved	
		6	Reserved	
		7	Reserved	

Data structure

Input data of Binary Input

Byte 1	Byte 2
Binary Input	Status 1)

1) Status coding $\rightarrow \square 70$

Volume module

Transmit the volume counter value from the measuring device to the automation system.

The Volume module cyclically transmits the volume, including the status, from the measuring device to the automation system. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Selection: input variable

Slot	Sub-slot	Input variables
3	1	Volume

Data structure

Volume input data

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measured value: floating		point number (IE	EEE 754)	Status 1)

1) Status coding \rightarrow \square 70

Volume Totalizer Control module

Transmit the volume counter value from the measuring device to the automation system.

The Volume Totalizer Control module cyclically transmits the volume, including the status, from the measuring device to the automation system. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Selection: input variable

Slot	Sub-slot	Input variables
3	1	Volume

Data structure

Volume Totalizer Control input data

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measured value: floating point number (IEEE 754)				Status 1)

1) Status coding $\rightarrow \square 70$

Selection: output variable

Transmit the control value from the automation system to the measuring device.

Slot	Sub-slot	Value	Input variable
	3 1	1	Reset to "0"
2		2	Preset value
		3	Stop
		4	Totalize

Data structure

Volume Totalizer Control output data

Byte 1	
Control variable	

Totalizer module

Transmit totalizer value from the measuring device to the automation system.

The Totalizer module cyclically transmits a selected totalizer value, including the status, from the measuring device to the automation system. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Selection: input variable

Slot	Sub-slot	Input variable
70 to 71	1	 Mass flow Volume flow Corrected volume flow Total mass flow ¹⁾ Condensate mass flow ¹⁾ Energy flow ¹⁾ Heat flow difference ¹⁾

1) Only available with application package

Data structure

Totalizer input data

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status ¹⁾

1) Status coding $\rightarrow \square 70$

Totalizer Control module

Transmit totalizer value from the measuring device to the automation system.

The Totalizer Control module cyclically transmits a selected totalizer value, including the status, from the measuring device to the automation system. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Selection: input variable

Slot	Sub-slot	Input variable
70 to 71	1	 Mass flow Volume flow Corrected volume flow Total mass flow ¹⁾ Condensate mass flow ¹⁾ Energy flow ¹⁾ Heat flow difference ¹⁾

1) Only available with application package

Data structure

Totalizer Control input data

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	Measured value: floating point number (IEEE 754)		EEE 754)	Status 1)

1) Status coding $\rightarrow \square 70$

Selection: output variable

Transmit the control value from the automation system to the measuring device.

Slot	Sub-slot	Value	Input variable
70 +- 71 1	1	Reset to "0"	
	2	Preset value	
/010/1	70 to 71 1	3	Stop
		4	Totalize

Data structure

Totalizer Control output data

Byte 1	
Control variable	

Analog Output module

Transmit a compensation value from the automation system to the measuring device.

Analog Output modules cyclically transmit compensation values, including the status and associated unit, from the automation system to the measuring device. The compensation value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the compensation value.

Assigned compensation values

The selection is made via: Expert \rightarrow Sensor \rightarrow External compensation

Slot	Sub-slot	Compensation value
160		Pressure
161	1	Density
162		Temperature

Data structure

Output data of Analog Output

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status ¹⁾

1) Status coding $\rightarrow \square 70$

Failsafe mode

A failsafe mode can be defined for using the compensation values.

If the status is GOOD or UNCERTAIN, the compensation values transmitted by the automation system are used. If the status is BAD, the failsafe mode is activated for the use of the compensation values.

Parameters are available per compensation value to define the fails afe mode: Expert \rightarrow Sensor \rightarrow External compensation

Fail safe type parameter

- Fail safe value option: The value defined in the Fail safe value parameter is used.
- Fallback value option: The last valid value is used.
- Off option: The failsafe mode is disabled.

Fail safe value parameter

Use this parameter to enter the compensation value which is used if the Fail safe value option is selected in the Fail safe type parameter.

Binary output module

Transmit binary output values from the automation system to the measuring device.

Binary output values are used by the automation system to enable and disable device functions.

Binary output values cyclically transmit discrete output values, including the status, from the automation system to the measuring device. The discrete output values are transmitted in the first byte. The second byte contains standardised status information pertaining to the output value.

Slot	Sub-slot	Bit	Device function	Status (meaning)		
		0	Start the verification.	A change of status from 0 to 1		
		1	Reserved	starts the Heartbeat Verification ¹⁾		
		2	Reserved			
210	10 1	1	1	3	Reserved	
210		4	Reserved			
		5	Reserved			
		6	Reserved			
		7	Reserved			

Selection: device function, binary output, slot 210

1) Only available with the Heartbeat application package

Selection: device function, binary output, slot 211

Slot	Sub-slot	Bit	Device function	Status (meaning)
211	1	0	Flow override	 0 (disable device function) 1 (enable device function)
		1	Reserved	
		2	Reserved	
		3	Reserved	
		4	Reserved	
		5	Reserved	
		6	Reserved	
		7	Reserved	

Data structure

Binary Output input data

Byte 1	Byte 2
Binary Output	Status ^{1) 2)}

1) Status coding $\rightarrow \square 70$

2) If the status is BAD, the control variable is not adopted.

Status	Coding (hex)	Meaning
BAD - Maintenance alarm	0x24 to 0x27	A measured value is not available because a device error has occurred.
BAD - Process related	0x28 to 0x2B	A measured value is not available because the process conditions are not within the device's technical specification limits.
BAD - Function check	0x3C to 0x03F	A function check is active (e.g. cleaning or calibration)
UNCERTAIN - Initial value	0x4F to 0x4F	A predefined value is output until a correct measured value is available again or corrective measures have been performed that change this status.
UNCERTAIN - Maintenance demanded	0x68 to 0x6B	Signs of wear and tear have been detected on the measuring instrument. Short-term maintenance is needed to ensure that the measuring instrument remains operational. The measured value might be invalid. The use of the measured value depends on the application.
UNCERTAIN - Process related	0x78 to 0x7B	The process conditions are not within the device's technical specification limits. This could have a negative impact on the quality and accuracy of the measured value. The use of the measured value depends on the application.
GOOD - OK	0x80 to 0x83	No error has been diagnosed.
GOOD - Maintenance required	0xA4 to 0xA7	The measured value is valid. Maintenance of the device due in the near future.
GOOD - Maintenance demanded	0xA8 to 0xAB	The measured value is valid. It is highly advisable to service the device in the near future.
GOOD - Function check	0xBC to 0XBF	The measured value is valid. The measuring instrument is performing an internal function check. The function check does not have any noticeable effect on the process.

9.3.3 Status coding

9.3.4 Factory setting


The slots are already assigned in the automation system for initial commissioning.

Assigned slots

Slot	Factory setting	
1	Volume flow	
2	Vortex frequency	
3	Volume	
20 to 21	-	
70 to 71	-	
80 to 81	-	
160 to 162	-	
210 to 211	-	

9.4 System redundancy S2

A redundant layout with two automation systems is necessary for processes that are in continuous operation. If one system fails the second system guarantees continued, uninterrupted operation. The measuring device supports S2 system redundancy and can communicate with both automation systems simultaneously.



■ 17 Example of the layout of a redundant system (S2): star topology

- 1 Automation system 1
- 2 Synchronization of automation systems
- 3 Automation system 2
- 4 Industrial Ethernet Managed Switch
- 5 APL field switch
- 6 Measuring device

All the devices in the network must support S2 system redundancy.

10 Commissioning

10.1 Post-mounting and post-connection check

Before commissioning the device:

- Make sure that the post-installation and post-connection checks have been performed successfully.
- Checklist for "Post-installation" check \rightarrow 🗎 28
- Checklist for "Post-connection" check \rightarrow \cong 41


10.2 Switching on the measuring device

- Switch on the device upon successful completion of the post-mounting and postconnection check.
 - ← After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or if a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" $\rightarrow \square$ 128.

10.3 Setting the operating language


Factory setting: English or ordered local language



I8 Taking the example of the local display

10.4 Configuring the device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.



☑ 19 Navigation to the "Setup" menulusing the example of the local display

Navigation

"Setup" menu

🗲 Setup	
PROFINET device name	→ 🗎 73
► Communication	→ 🗎 73
► System units	→ 🗎 75
► Medium selection	→ 🗎 79
► Analog inputs	→ 🗎 82
► Low flow cut off	→ 🖺 83
► Advanced setup	→ 🗎 84

Parameter overview with brief description


Parameter	Description	User interface	Factory setting
PROFINET device name	Name of the measuring point.	Max. 32 characters such as letters and numbers.	

10.4.1 Displaying the communication interface

The **Communication** submenu shows all the current parameter settings for selecting and configuring the communication interface.

Navigation

"Setup" menu \rightarrow Communication



"APL port" submenu

Navigation

"Setup" menu \rightarrow Communication \rightarrow APL port

► APL port		
	IP address	→ 🗎 74
	Subnet mask	→ 🗎 74
	Default gateway	→ 🖺 74
	MAC address	→ 🖹 74

Parameter	Parameter Description User entry / User interface		Factory setting	
IP address	Enter the IP address of the measuring device.	4 octet: 0 to 255 (in the particular octet)	0.0.0.0	
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0	
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	0.0.0.0	
MAC address	Displays the MAC address of the measuring device. MAC = Media Access Control	Unique 12-digit character string comprising letters and numbers, e.g.: 00:07:05:10:01:5F	Each measuring device is given an individual address.	

"Network diagnostics" submenu

Navigation

"Setup" menu \rightarrow Communication \rightarrow Network diagnostics

► Network diagnostics	
Mean squared error) → 🗎 75
Number of failed received packets) → 🗎 75

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Mean squared error	Provides an indication of the link signal quality.	Signed floating-point number	0 dB
Number of failed received packets	Shows the number of failed received packets.	0 to 65 535	0

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

Navigation

"Setup" menu \rightarrow System units

► System units			
Volume flo	w unit]	→ 🗎 76
Volume un	it]	→ 🗎 76
Mass flow	ınit]	→ 🗎 76
Mass unit]	→ 🗎 76
Corrected v	olume flow unit]	→ 🖺 76
Corrected v	olume unit]	→ 🗎 76
Pressure ur	nit]	→ 🗎 77
Temperatu	re unit]	→ 🗎 77
Energy flov	<i>v</i> unit]	→ 🗎 77

Energy unit	→ 🗎 77	
Calorific value unit	→ 🗎 77	
Calorific value unit	→ 🗎 77	
Velocity unit	→ 🗎 78	
Density unit	→ 🗎 78	
Specific volume unit	→ 🗎 78	
Dynamic viscosity unit	 → ≌ 78	
Length unit	→ 🗎 78	

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	-	Select volume flow unit. <i>Effect</i> The selected unit applies to: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • m ³ /h • ft ³ /min
Volume unit	-	Select volume unit.	Unit choose list	Country-specific: • m ³ • ft ³
Mass flow unit	-	Select mass flow unit. <i>Effect</i> The selected unit applies to: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: kg/h lb/min
Mass unit	-	Select mass unit.	Unit choose list	Country-specific: • kg • lb
Corrected volume flow unit	-	Select corrected volume flow unit. <i>Effect</i> The selected unit applies to: Corrected volume flow parameter	Unit choose list	Country-specific: • Nm³/h • Sft³/h
Corrected volume unit	-	Select corrected volume unit.	Unit choose list	Country-specific: • Nm ³ • Sft ³

Parameter	Prerequisite	Description	Selection	Factory setting
Pressure unit	With order code for "Sensor version": "Mass (integrated temperature measurement)" option	Select process pressure unit. <i>Effect</i> The unit is taken from: • Calculated saturated steam pressure • Atmospheric pressure • Maximum value • Fixed process pressure • Pressure • Reference pressure	Unit choose list	Country-specific: • bar • psi
Temperature unit	-	Select temperature unit. <i>Effect</i> The selected unit applies to: • Temperature • Maximum value • Minimum value • Average value • Maximum value • Minimum value • Minimum value • Minimum value • Saturation temperature • Saturation temperature	Unit choose list	Country-specific: • °C • °F
Energy flow unit	With order code for "Sensor version": "Mass (integrated temperature measurement)" option	Select energy flow unit. <i>Result</i> The selected unit applies to: • Heat flow difference parameter • Energy flow parameter	Unit choose list	Depends on country: • kW • Btu/h
Energy unit	With order code for "Sensor version": "Mass (integrated temperature measurement)" option	Select energy unit.	Unit choose list	Depends on country: • kWh • Btu
Calorific value unit	 The following conditions are met: Order code for "Sensor version", "Mass (integrated temperature measurement)" option The Gross calorific value volume option or Net calorific value volume option is selected in the Calorific value type parameter. 	Select calorific value unit. <i>Result</i> The selected unit applies to: Reference gross calorific value	Unit choose list	Depends on country: • kJ/Nm ³ • Btu/Sft ³
Calorific value unit (Mass)	 The following conditions are met: Order code for "Sensor version", "Mass (integrated temperature measurement)" option The Gross calorific value mass option or Net calorific value mass option is selected in the Calorific value type parameter. 	Select calorific value unit.	Unit choose list	Depends on country: • kJ/kg • Btu/lb

Parameter	Prerequisite	Description	Selection	Factory setting
Velocity unit	-	Select velocity unit. <i>Result</i> The selected unit applies to: • Flow velocity • Maximum value	Unit choose list	Depends on country: • m/s • ft/s
Density unit	-	Select density unit. <i>Effect</i> The selected unit applies to: • Output • Simulation process variable	Unit choose list	Country-specific: • kg/m ³ • lb/ft ³
Specific volume unit	With order code for "Sensor version": "Mass (integrated temperature measurement)" option	Select the unit for the specific volume. <i>Result</i> The selected unit applies to: Specific volume	Unit choose list	Depends on country: • m ³ /kg • ft ³ /lb
Dynamic viscosity unit	-	Select dynamic viscosity unit. Result The selected unit applies to: • Dynamic viscosity parameter (gases) • Dynamic viscosity parameter (liquids)	Unit choose list	Pa s
Length unit	-	Select length unit for nominal diameter.	• m • mm • ft • in	mm

10.4.3 Selecting and setting the medium

The **Medium selection** wizard systematically guides the user through all the parameters that must be configured in order to select and set the medium.

Navigation

 $"Setup" menu \rightarrow Medium \ selection$

► Medium selection	
Select medium	→ 🗎 79
Select gas type) → 🗎 79
Gas type	→ 🗎 80
Relative humidity) → 🗎 80
Liquid type) → 🗎 80
Steam calculation mode) → 🗎 80
Steam quality) → 🗎 81
Steam quality value) → 🗎 81
Enthalpy calculation	→ 🗎 81
Density calculation	→ 🗎 81
Enthalpy type) → 🗎 81

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Select medium	-	Select medium type.	Steam	Steam
Select gas type	 The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" The Gas option is selected in the Select medium parameter parameter. 	Select measured gas type.	 Single gas[*] Gas mixture[*] Air[*] Natural gas[*] User-specific gas 	User-specific gas

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Gas type	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Single gas option is selected. 	Select measured gas type.	 Hydrogen H2 Helium He Neon Ne Argon Ar Krypton Kr Xenon Xe Nitrogen N2 Oxygen O2 Chlorine Cl2 Ammonia NH3 Carbon monoxide CO Carbon dioxide CO2 Sulfur dioxide SO2 Hydrogen sulfide H2S Hydrogen chloride HCl Methane CH4 Ethane C2H6 Propane C3H8 Butane C4H10 Ethylene C2H4 Vinyl chloride C2H3Cl 	Methane CH4
Relative humidity	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Air option is selected. 	Enter humidity content of air in %.	0 to 100 %	0 %
Liquid type	The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" The Liquid option is selected in the Select medium parameter parameter.	Select measured liquid type.	 Water LPG (Liquefied Petroleum Gas) User-specific liquid 	Water
Steam calculation mode	The Steam option is selected in the Select medium parameter parameter.	Select calculation mode of steam: based on saturated steam (T-compensated) or automatic detection (p-/T- compensated).	 Saturated steam (T-compensated) Automatic (p-/T- compensated) 	Saturated steam (T- compensated)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Steam quality	 The following conditions are met: Order code for "Application package": Option ES "Wet steam detection" Option EU "Wet steam measurement" The Steam option is selected in the Select medium parameter parameter. The software options currently enabled are displayed in the Software option overview parameter. 	 Select compensation mode for steam quality. For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement application package → ≅ 212 	 Fixed value Calculated value 	Fixed value
Steam quality value	 The following conditions are met: The Steam option is selected in the Select medium parameter parameter. The Fixed value option is selected in the Steam quality parameter parameter. 	Enter fixed value for steam quality. For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection and Wet Steam Measurement application package → □ 212	0 to 100 %	100 %
Enthalpy calculation	The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" In the Select medium parameter, the Gas option is selected and in the Select gas type parameter, the Natural gas option is selected.	Select the norm the enthalpy calculation is based on.	AGA5ISO 6976	AGA5
Density calculation	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. 	Select the norm the density calculation is based on.	 AGA Nx19 ISO 12213-2 ISO 12213-3 	AGA Nx19
Enthalpy type	The following conditions are met: In the Select gas type parameter, the User- specific gas option is selected. Or In the Liquid type parameter, the User- specific liquid option is selected.	Define which kind of enthalpy is used.	HeatCalorific value	Heat

* Visibility depends on order options or device settings

10.4.4 Configuration of the Analog Inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

Navigation

"Setup" menu → Analog inputs

► Analog inputs	
► Analog input 1 to n	→ 🗎 82

"Analog inputs" submenu

Navigation

"Setup" menu \rightarrow Analog inputs \rightarrow Volume flow

► Analog input 1 t	o n	
	Assign process variable	→ 🗎 82
	Damping	→ 🗎 82

Parameter	Description	User interface / User entry	Factory setting
Parent class		0 to 255	60
Assign process variable	Select a process variable.	 Mass flow Volume flow Density Temperature Pressure Specific volume Degrees of superheat Electronics temperature Vortex frequency Vortex kurtosis Vortex amplitude Calculated saturated steam pressure Steam quality Total mass flow Condensate mass flow Energy flow Heat flow difference Reynolds number Flow velocity Corrected volume flow 	Volume flow
Damping	Enter time constant for input damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.	Positive floating-point number	1.0 s

10.4.5 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

The measuring signal must have a certain minimum signal amplitude so that the signals can be evaluated without any errors. Using the nominal diameter, the corresponding flow can also be derived from this amplitude.

The minimum signal amplitude depends on the setting for the sensitivity of the DSC sensor, the steam quality \mathbf{x} and the force of the vibrations present \mathbf{a} .

The value \mathbf{mf} corresponds to the lowest measurable flow velocity without vibration (no wet steam) for a density of 1 kg/m³ (0.0624 lbm/ft^3).

The value **mf** can be set in the range of 20 to 6 m/s (6 to 1.8 ft/s) (factory setting 12 m/s (3.7 ft/s)) with the **Sensitivity** parameter (value range 1 to 9, factory setting 5).

The lowest flow velocity that can be measured on account of the signal amplitude v_{AmpMin} is derived from the **Sensitivity** parameter and steam quality x or from the force of vibrations present a.

Navigation

"Setup" menu \rightarrow Low flow cut off


► Low flow cut off		
Sensitivity	→ 🗎 83	
Turn down	→ 🗎 83	

Parameter	Description	User entry	Factory setting
Sensitivity	Adjust sensitivity of the device in the lower flow range. Lower sensitivity leads to more robustness against external interference.	1 to 9	5
	The parameter determines the level of sensitivity at the lower end of the measuring range (start of measuring range). Low values can improve the robustness of the device with regard to external influences. The start of measuring range is then set to a higher value. The smallest specified measuring range is when sensitivity is at a maximum.		
Turn down	Adjust the turn down. Lower turn down increases the minimum measureable flow frequency.	50 to 100 %	100 %
	The measuring range can be limited with this parameter, if necessary. The upper end of the measuring range is not affected. The start of the low end of the measuring range can be changed to a higher flow value, making it possible to cut off low flows, for example.		

10.4.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

Navigation

"Setup" menu → Advanced setup

► Advanced setup	
Enter access code	→ 🗎 85
► Medium properties	→ 🗎 85
► External compensation	→ 🗎 99
► Sensor adjustment	→ 🗎 100



Parameter	Description	User entry
Enter access code	1 1	Max. 16-digit character string comprising numbers, letters and special characters

Setting the medium properties

In the **Medium properties** submenu the reference values for the measuring application can be set.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Medium properties

► Medium propert	ies	
	Enthalpy type	→ 🖺 86
	Calorific value type	→ 🖺 86
	Reference combustion temperature	→ 🖺 86
	Reference density	→ 🖺 86
	Reference gross calorific value	→ 🗎 86
	Reference pressure	→ 🖺 87
	Reference temperature	→ 🗎 87
	Reference Z-factor	→ 🗎 87
	Linear expansion coefficient	→ 🗎 87
	Relative density	→ 🖺 87
	Specific heat capacity	→ 🗎 87
	Calorific value	→ 🗎 88
	Z-factor	→ 🖺 88

Dynamic viscosity	→ 🗎 88
Dynamic viscosity	→ 🖹 88
► Gas composition	→ 🗎 88

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Enthalpy type	The following conditions are met: In the Select gas type parameter, the User- specific gas option is selected. Or In the Liquid type parameter, the User- specific liquid option is selected.	Define which kind of enthalpy is used.	 Heat Calorific value 	Heat
Calorific value type	The Calorific value type parameter is visible.	Select calculation based on gross calorific value or net calorific value.	 Gross calorific value volume Net calorific value volume Gross calorific value mass Net calorific value mass 	Gross calorific value mass
Reference combustion temperature	The Reference combustion temperature parameter is visible.	Enter reference combustion temperature to calculate the natural gas energy value. <i>Dependency</i> The unit is taken from the Temperature unit parameter	−200 to 450 °C	20 °C
Reference density	The following conditions are met: In the Select gas type parameter, the User- specific gas option is selected. Or In the Liquid type parameter, the Water option or User-specific liquid option is selected.	Enter fixed value for reference density. <i>Dependency</i> The unit is taken from the Density unit parameter	0.01 to 15 000 kg/m ³	1000 kg/m ³
Reference gross calorific value	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. 	Enter reference gross calorific value of the natural gas. <i>Dependency</i> The unit is taken from the Calorific value unit parameter	Positive floating- point number	50 000 kJ/Nm³

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Reference pressure	The following conditions are met: • Order code for "Sensor version", Option "Mass (integrated temperature measurement)" • The Gas option is selected in the Select medium parameter parameter.	Enter reference pressure for the calulation of the reference density. <i>Dependency</i> The unit is taken from the Pressure unit parameter.	0 to 250 bar	1.01325 bar
Reference temperature	 The following conditions are met: In the Select medium parameter, the Gas option is selected. Or In the Select medium parameter, the Liquid option is selected. 	Enter reference temperature for calculating the reference density. <i>Dependency</i> The unit is taken from: Temperature unit parameter	−200 to 450 °C	0 °C
Reference Z-factor	In the Select gas type parameter, the User-specific gas option is selected.	Enter real gas constant Z for gas under reference conditions.	0.1 to 2	1
Linear expansion coefficient	 The following conditions are met: The Liquid option is selected in the Select medium parameter. The User-specific liquid option is selected in the Liquid type parameter. 	Enter linear, medium-specific expansion coefficient for calculating the reference density.	1.0 · 10 ⁻⁶ to 2.0 · 10 ⁻³	2.06 · 10 ⁻⁴
Relative density	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. 	Enter a relative density of the natural gas.	0.55 to 0.9	0.664
Specific heat capacity	 The following conditions are met: Selected medium: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Heat option is selected. 	Enter the specific heat capacity of the medium. <i>Dependency</i> The unit is taken from the Specific heat capacity unit parameter	0 to 50 kJ/(kgK)	4.187 kJ/(kgK)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Calorific value	 The following conditions are met: Selected medium: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Calorific value option is selected. In the Calorific value type parameter, the Gross calorific value volume option or Gross calorific value mass option is selected. 	Enter gross calorific value to calculate the energy flow.	Positive floating- point number	50 000 kJ/kg
Z-factor	In the Select gas type parameter, the User-specific gas option is selected.	Enter real gas constant Z for gas under operation conditions.	0.1 to 2.0	1
Dynamic viscosity (Gases)	 The following conditions are met: Order code for "Sensor version", Option "Volume" or Option "Volume high temperature" The Gas option or the Steam option is selected in the Select medium parameter. or The User-specific gas option is selected in the Select gas type parameter. 	Enter fixed value for dynamic viscosity for a gas/steam. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter.	Positive floating- point number	0.015 cP
Dynamic viscosity (Liquids)	 The following conditions are met: Order code for "Sensor version", Option "Volume" or Option "Volume high temperature" The Liquid option is selected in the Select medium parameter parameter. or The User-specific liquid option is selected in the Liquid type parameter. 	Enter fixed value for dynamic viscosity for a liquid. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter.	Positive floating- point number	1 cP

Configuring the gas composition

In the **Gas composition** submenu the gas composition for the measuring application can be set.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Medium properties \rightarrow Gas composition

► Gas composition	
Gas mixture) → 🗎 91
Mol% Ar) → 🗎 92
Mol% C2H3Cl) → 🗎 92
Mol% C2H4) → 🗎 92
Mol% C2H6) → 🗎 92
Mol% C3H8) → 🗎 93
Mol% CH4) → 🗎 93
Mol% Cl2) → 🗎 93
Mol% CO) → 🗎 93
Mol% CO2) → 🗎 94
Mol% H2] → 🗎 94
Mol% H2O) → 🗎 94
Mol% H2S) → 🗎 94
Mol% HCl) → 🗎 95
Mol% He) → 🗎 95
Mol% i-C4H10) → 🗎 95
Mol% i-C5H12) → 🗎 95
Mol% Kr) → 🗎 95
Mol% N2) → 🗎 96
Mol% n-C10H22) → 🗎 96
Mol% n-C4H10) → 🗎 96
Mol% n-C5H12] → 🗎 96

Mol% n-C6H14	→ 🖺 97
Mol% n-C7H16	→ 🗎 97
Mol% n-C8H18	→ 🗎 97
Mol% n-C9H20	→ 🗎 97
Mol% Ne	→ 🗎 97
Mol% NH3	→ 🗎 98
Mol% O2	→ 🗎 98
Mol% SO2	→ 🗎 98
Mol% Xe	→ 🗎 98
Mol% other gas	→ 🖺 99

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Gas type	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Single gas option is selected.	Select measured gas type.	 Hydrogen H2 Helium He Neon Ne Argon Ar Krypton Kr Xenon Xe Nitrogen N2 Oxygen O2 Chlorine Cl2 Ammonia NH3 Carbon monoxide CO Carbon dioxide CO2 Sulfur dioxide SO2 Hydrogen sulfide H2S Hydrogen chloride HCI Methane CH4 Ethane C2H6 Propane C3H8 Butane C4H10 Ethylene C2H4 Vinyl chloride C2H3Cl 	Methane CH4
Gas mixture	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. 	Select measured gas mixture.	 Air Hydrogen H2 Helium He Neon Ne Argon Ar Krypton Kr Xenon Xe Nitrogen N2 Oxygen O2 Chlorine Cl2 Ammonia NH3 Carbon monoxide CO Carbon dioxide CO2 Sulfur dioxide SO2 Hydrogen sulfide H2S Hydrogen chloride HCI Methane CH4 Propane C3H8 Ethane C2H6 Butane C4H10 Ethylene C2H4 Vinyl chloride C2H3CI Water Other 	Methane CH4

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% Ar	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Argon Ar option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C2H3Cl	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Vinyl chloride C2H3Cl option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C2H4	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Ethylene C2H4 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C2H6	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Ethane C2H6 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% C3H8	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Propane C3H8 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% CH4	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Methane CH4 option is selected. Or In the Select gas type parameter, the Natural gas option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	100 %
Mol% Cl2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Chlorine Cl2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% CO	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon monoxide CO option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% CO2	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon dioxide CO2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% H2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen H2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option is not selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% H2O	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% H2S	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen sulfide H2S option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% HCl	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Hydrogen chloride HCl option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% He	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Helium He option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% i-C4H10	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% i-C5H12	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Kr	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Krypton Kr option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% N2	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Nitrogen N2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option or the ISO 12213- 2 option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C10H22	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C4H10	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Butane C4H10 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected. Or In the Select medium parameter, the Liguid option is selected and in the Density calculation parameter, the Liguid option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C5H12	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% n-C6H14	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C7H16	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C8H18	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C9H2O	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Ne	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Neon Ne option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% NH3	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Ammonia NH3 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% O2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Oxygen O2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% SO2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Sulfur dioxide SO2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Xe	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Xenon Xe option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% other gas	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Other option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Relative humidity	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Air option is selected. 	Enter humidity content of air in %.	0 to 100 %	0 %

Performing external compensation

The **External compensation** submenu contains parameters which can be used to enter external or fixed values. These values are used for internal calculations.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow External compensation

► External compensation			
External value	→ 🗎 100		
Atmospheric pressure	→ 🗎 100		
Delta heat calculation) → 🗎 100		
Fixed density) → 🗎 100		
Fixed density	→ 🗎 100		
Fixed temperature	→ 🗎 100		
2nd temperature delta heat	→ 🗎 100		
Fixed process pressure	→ 🗎 100		

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
External value	With order code for "Sensor version": "Mass (integrated temperature measurement)" option	Assign variable from external device to process variable. For detailed information on the calculation of the measured variables with steam:	 Off Pressure Gauge pressure Density 2nd temperature delta heat 	Off
Atmospheric pressure	In the External value parameter, the Gauge pressure option is selected.	Enter atmospheric pressure value to be used for pressure correction. <i>Dependency</i> The unit is taken from the Pressure unit parameter	0 to 250 bar	1.01325 bar
Delta heat calculation	The Delta heat calculation parameter is visible.	Calculates the transferred heat of a heat exchanger (= delta heat).	 Off Device on cold side Device on warm side 	Device on warm side
Fixed density	With order code for "Sensor version": • Option "Volume" or • Option "Volume high temperature"	Enter fixed value for medium density. <i>Dependency</i> The unit is taken from the Density unit parameter.	0.01 to 15 000 kg/m ³	1 000 kg/m ³
Fixed density	 With order code for "Sensor version": Option "Volume" or Option "Volume high temperature" 	Enter fixed value for medium density. <i>Dependency</i> The unit is taken from the Density unit parameter.	0.01 to 15 000 kg/m ³	5 kg/m ³
Fixed temperature	-	Enter a fixed value for process temperature. <i>Dependency</i> The unit is taken from the Temperature unit parameter	−200 to 450 °C	20 °C
2nd temperature delta heat	The 2nd temperature delta heat parameter is visible.	Enter 2nd temperature value to calculate the delta heat. <i>Dependency</i> The unit is taken from the Temperature unit parameter	−200 to 450 °C	20 °C
Fixed process pressure	 The following conditions are met: Order code for "Sensor version", Option "Mass flow (integrated temperature measurement)" In the External value parameter (→ 100) the Pressure option is not selected. 	Enter fixed value for process pressure. Dependency The unit is taken from the Pressure unit parameter. For detailed information on the calculation of the measured variables with steam:	0 to 250 bar abs.	0 bar abs.

Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment

► Sensor adjustment				
Inlet configuration	→ 🗎 101			
Inlet run) → 🗎 101			
Mating pipe diameter	→ 🗎 101			
Installation factor	→ 🗎 101			

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Inlet configuration	The inlet run correction feature: Is a standard feature and can only be used in the Prowirl F 200. Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (NPS 1 to 6) EN (DIN) ASME B16.5, Sch. 40/80 JIS B2220	Select inlet configuration.	 Off Single elbow Double elbow Double elbow 3D Reduction 	Off
Inlet run	 The inlet run correction feature: Is a standard feature and can only be used in the Prowirl F 200. Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (NPS 1 to 6) EN (DIN) ASME B16.5, Sch. 40/80 JIS B2220 	Enter length of the available straight inlet run. <i>Dependency</i> The unit is taken from: Length unit parameter	0 to 20 m	0 m
Mating pipe diameter	-	Enter diameter of mating pipe to enable diameter mismatch correction. Detailed information on diameter mismatch correction: $\rightarrow \cong 102$ <i>Dependency</i> The unit is taken from the Length unit parameter.	0 to 1 m (0 to 3 ft) Input value = 0: Diameter mismatch correction is disabled.	Country-specific: • 0 m • 0 ft
Installation factor	-	Enter factor to compensate the mounting-related measurement error.	Positive floating- point number	1.0

Diameter mismatch correction

The measuring device is calibrated according to the ordered process connection. This calibration takes account of the edge at the transition from the mating pipe to the process connection. If the mating pipe used deviates from the ordered process connection, a diameter mismatch correction can compensate for the effects. The difference between the internal diameter of the ordered process connection and the internal diameter of the mating pipe used must be taken into consideration.

The measuring device can correct shifts in the calibration factor which are caused, for example, by a diameter mismatch between the device flange (e.g. ASME B16.5/Sch. 80, DN 50 (2")) and the mating pipe (e.g. ASME B16.5/Sch. 40, DN 50 (2")). Only apply diameter mismatch correction within the following limit values (listed below) for which test measurements have also been performed.

Flange connection:

- DN 15 ($\frac{1}{2}$): ±20 % of the internal diameter
- DN 25 (1"): ±15 % of the internal diameter
- DN 40 (1½"): ±12 % of the internal diameter
- $DN \ge 50$ (2"): ±10 % of the internal diameter

If the standard internal diameter of the ordered process connection differs from the internal diameter of the mating pipe, an additional measuring uncertainty of approx. 2 % o.r. must be expected.

Example

Influence of the diameter mismatch without using the correction function:


- Mating pipe DN 100 (4"), Schedule 80
- Device flange DN 100 (4"), Schedule 40
- This installation position results in a diameter mismatch of 5 mm (0.2 in). If the correction function is not used, an additional measuring uncertainty of approx. 2 % o.r. must be expected.
- If the basic conditions are met and the feature is enabled, the additional measuring uncertainty is 1 % o.r.

Configuring the totalizer

In the "Totalizer 1 to n" submenu, you can configure the specific totalizer.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n



Parameter	Description	Selection	Factory setting
Assign process variable 1 to n	Select process variable for totalizer.	 Mass flow Volume flow Corrected volume flow Total mass flow * Condensate mass flow * Energy flow * Heat flow difference * 	Volume flow
Process variable unit 1 to n	Select the unit for the process variable of the totalizer.	Unit choose list	m ³
Totalizer 1 to n operation mode	Select totalizer operation mode, e.g. only totalize forward flow or only totalize reverse flow.	NetForwardReverse	Forward
Totalizer 1 to n control	Operate the totalizer.	 Reset + hold Preset + hold Hold Totalize 	Totalize
Totalizer 1 to n failure behavior	Select totalizer behavior in the event of a device alarm.	 Hold Continue Last valid value + continue 	Continue

* Visibility depends on order options or device settings

Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display	
Format display	→ 🗎 105
Value 1 display	→ 🗎 105
0% bargraph value 1	→ 🗎 105
100% bargraph value 1	→ 🗎 105
Decimal places 1	→ 🗎 105
Value 2 display	→ 🗎 105
Decimal places 2	→ 🗎 105
Value 3 display) → 🗎 105
0% bargraph value 3) → 🖺 106
100% bargraph value 3) → 🖺 106
Decimal places 3	→ 🖺 106
Value 4 display	→ 🖺 106
Decimal places 4	→ 🗎 106
Display language	→ 🗎 106
Display interval	→ 🗎 106
Display damping	→ 🖺 106
Header) → 🗎 106
Header text	→ 🗎 106
Separator	→ 🗎 106
Backlight	→ 🖺 106


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Corrected volume flow Mass flow Flow velocity Temperature Vortex frequency Vortex kurtosis Vortex amplitude Calculated saturated steam pressure* Total mass flow* Condensate mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Density* Pressure* Specific volume* Degrees of superheat* Totalizer 1 Totalizer 2 Totalizer 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter $(\rightarrow \cong 105)$	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXX X.XXXX 	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter $(\rightarrow \cong 105)$	None

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter $(\rightarrow \cong 105)$	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	X.XX
Display language	A local display is provided.	Set display language.	 English Deutsch Français Español Italiano Nederlands* Portuguesa Polski pycский язык (Russian) Svenska* Türkçe 中文 (Chinese) 日本語 (Japanese)* 한국어 (Korean)* tiếng Việt (Vietnamese)* čeština (Czech)* 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	5.0 s
Header	A local display is provided.	Select header contents on local display.	Device tagFree text	Device tag
Header text	The Free text option is selected in the Header parameter.	Enter display header text.	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	 . (point) , (comma) 	. (point)
Backlight	Order code for "Display; operation", option E "SD03 4- line, illum.; touch control + data backup function"	Switch the local display backlight on and off.	DisableEnable	Disable

* Visibility depends on order options or device settings

Performing Heartbeat basic setup

Heartbeat setup submenu guides the user systematically through all the parameters that can be used for the Heartbeat basic setup.



Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Heartbeat setup

► Heartbeat setup		
► Heartbeat base s	ettings	→ 🗎 107

"Heartbeat base settings" submenu

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Heartbeat setup \rightarrow Heartbeat base settings

► Heartbeat base settings	
Plant operator	→ 🗎 107
Location	→ 🗎 107

Parameter overview with brief description

Parameter	Description	User entry
Plant operator		Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)
Location	Enter the location.	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

► Administration		
	► Define access code	→ 🗎 108
	Device reset	→ 🗎 108

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	CancelTo delivery settingsRestart device	Cancel

"Define access code" wizard

Complete this wizard to specify an access code for the Maintenance role.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code \rightarrow Define access code



Parameter overview with brief description

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code		Max. 16-digit character string comprising numbers, letters and special characters

10.5 Simulation

Via the **Simulation** submenu, it is possible to simulate various process variables in the process and the device alarm mode and verify downstream signal chains (switching valves or closed-control loops). The simulation can be performed without a real measurement (no flow of medium through the device).

Navigation

"Diagnostics" menu \rightarrow Simulation

► Simulation		
	Assign simulation process variable	→ 🗎 109
	Process variable value	→ 🗎 109
	Device alarm simulation	→ 🗎 109
	Diagnostic event category	→ 🗎 109
	Diagnostic event simulation	→ 🗎 109

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated steam pressure* Total mass flow* Condensate mass flow* Energy flow Heat flow to the fl	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter $(\rightarrow \cong 109).$	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Device alarm simulation	-	Switch the device alarm on and off.	OffOn	Off
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off

Parameter overview with brief description

* Visibility depends on order options or device settings

10.6 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code
- Write protection via write protection switch
- Write protection via keypad lock

10.6.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.

Defining the access code via the local display

1. Navigate to the **Enter access code** parameter.

2. Maximum of 16-digit character string comprising numbers, letters and special characters as the access code.

- 3. Enter the access code again in the to confirm.
 - ← The 🖻 symbol appears in front of all write-protected parameters.
- Disabling parameter write protection via access code $\rightarrow \cong$ 55.
 - If the access code is lost: Resetting the access code .
 - The user role with which the user is currently logged in is displayed in **Access status display** parameter.
 - Navigation path: Operation → Access status display
 - User roles and their access rights $\rightarrow \cong 55$
- The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view.
- The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.

Parameters for configuring the language	Parameters for configuring the local display	Parameters for configuring the totalizer
\downarrow	\downarrow	\downarrow
Display language	Format display	Control Totalizer
	Contrast display	Preset value
	Display interval	Reset all totalizers

10.6.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via PROFINET protocol


1. Loosen the securing clamp.

2. Unscrew the electronics compartment cover.

- **3.** Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.
 - └ Display module is attached to the edge of the electronics compartment.



- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - └ If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter . In addition to this, the symbol appears in the header of the measured value display and in the navigation view in front of the parameters.



If hardware write protection is disabled: No option is displayed in the **Locking status** parameter . On the local display, the 🖻 symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reassemble the transmitter in the reverse order.

10.7 Application-specific commissioning

10.7.1 Steam application

Select medium

Navigation:

Setup \rightarrow Medium selection

1. Open the **Medium selection** wizard.

- 2. In the **Select medium** parameter, select the **Steam** option.
- When pressure measured value is read in ²): In the Steam calculation mode parameter, select the Automatic (p-/T-compensated) option.
- If pressure measured value is not read in: In the Steam calculation mode parameter, select the Saturated steam (T-compensated) option.
- 5. In the **Steam quality value** parameter, enter the steam quality present in the pipe.
 - └ ► Measuring instrument uses this value to calculate the mass flow of the steam.

10.7.2 Liquid application

User-specific liquid, e.g. heat carrier oil

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Liquid** option.
- 3. In the **Liquid type** parameter, select the **User-specific liquid** option.
- 4. In the **Enthalpy type** parameter, select the **Heat** option.
 - Heat option: Non-flammable liquid that serves as a heat carrier.
 Calorific value option: Flammable liquid whose combustion energy is calculated.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 5. Call up the **Medium properties** submenu.
- 6. In the **Reference density** parameter, enter the reference density of the fluid.
- 7. In the **Reference temperature** parameter, enter the fluid temperature associated with the reference density.
- 8. In the **Linear expansion coefficient** parameter, enter the expansion coefficient of the fluid.
- 9. In the **Specific heat capacity** parameter, enter the heat capacity of the fluid.
- **10.** In the **Dynamic viscosity** parameter, enter the viscosity of the fluid.

10.7.3 Gas applications

- For accurate mass or corrected volume measurement, it is recommended to use the pressure-/temperature-compensated sensor version. If this sensor version is not available, read in the pressure via the . If neither of these two options is possible, the pressure can also be entered as a fixed value in the **Fixed process pressure** parameter.
- Flow computer available only with the order code for "Sensor version", option "mass" (integrated temperature measurement)" or option "mass (integrated pressure/ temperature measurement)".

²⁾ Sensor version option "Mass (integrated pressure and temperature measurement)", Pressure read in via PROFINET over Ethernet-APL

Single gas

Combustion gas, e.g. methane CH₄

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.
- 3. In the **Select gas type** parameter, select the **Single gas** option.
- 4. In the **Gas type** parameter, select the **Methane CH4** option.

Configuring medium properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

5. Open the **Medium properties** submenu.

6. In the **Reference combustion temperature** parameter, enter the reference combustion temperature of the medium.

Configuring medium properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 7. Open the **Medium properties** submenu.
- 8. In the **Reference combustion temperature** parameter, enter the reference combustion temperature of the medium.

Gas mixture

Forming gas for steel mills and rolling mills, e. g. N_2/H_2

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.

3. In the **Select gas type** parameter, select the **Gas mixture** option.

Configuring gas composition

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties \rightarrow Gas composition

4. Call up the **Gas composition** submenu.

- 5. In the **Gas mixture** parameter, select the **Hydrogen H2** option and the **Nitrogen N2** option.
- 6. In the **Mol% H2** parameter, enter the quantity of hydrogen.
- 7. In the **Mol% N2** parameter, enter the quantity of nitrogen.
 - All quantities must add up to 100 %.
 The density is determined according to NEL 40.

Configuring optional fluid properties for output of corrected volume flow

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 8. Call up the **Medium properties** submenu.
- 9. In the **Reference pressure** parameter, enter the reference pressure of the fluid.
- **10.** In the **Reference temperature** parameter, enter the reference temperature of the fluid.

Air

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter ($\rightarrow \square$ 79), select the **Gas** option.

- 4. Enter the value in the **Relative humidity** parameter ($\rightarrow \cong 80$).
 - └ The relative humidity is entered as a %. The relative humidity is converted internally to absolute humidity and is then factored into the density calculation according to NEL 40.
- 5. In the **Fixed process pressure** parameter ($\rightarrow \triangleq 100$), enter the value of the process pressure present.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 6. Call up the **Medium properties** submenu.
- 7. In the **Reference pressure** parameter ($\Rightarrow \triangleq 87$) enter the reference pressure for calculating the reference density.
 - Pressure that is used as a static reference for combustion. This makes it possible to compare combustion processes at different pressures.
- 8. In the **Reference temperature** parameter ($\Rightarrow \square 87$) enter the temperate for calculating the reference density.

Endress+Hauser recommends the use of active pressure compensation. This fully rules out the risk of measured errors due to pressure variations and incorrect entries .

Natural gas

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter ($\rightarrow \triangleq 79$), select the **Gas** option.
- 3. In the **Select gas type** parameter ($\rightarrow \square 79$), select the **Natural gas** option.
- 4. In the **Fixed process pressure** parameter ($\rightarrow \triangleq 100$), enter the value of the process pressure present.

- 5. In the **Enthalpy calculation** parameter (→ 🖺 81), select one of the following options:
 - ↦ AGA5
 - **ISO 6976** option (contains GPA 2172)
- - **ISO 12213- 2** option (contains AGA8-DC92)
 - ISO 12213-3 option (contains SGERG-88, AGA8 Gross Method 1)

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 7. Call up the **Medium properties** submenu.
- 8. In the **Calorific value type** parameter, select one of the options.
- 9. n the **Reference gross calorific value** parameter, enter the reference gross calorific value of the natural gas.
- 10. In the **Reference pressure** parameter ($\Rightarrow \cong 87$) enter the reference pressure for calculating the reference density.
- **11.** In the **Reference temperature** parameter ($\Rightarrow \square 87$) enter the temperate for calculating the reference density.

12. In the **Relative density** parameter, enter the relative density of the natural gas.

Endress+Hauser recommends the use of active pressure compensation. This fully rules out the risk of measured errors due to pressure variations and incorrect entries .

Ideal gas

The unit "corrected volume flow" is often used to measure industrial gas mixtures, in particular natural gas. To do so, the calculated mass flow is divided by a reference density. To calculate the mass flow, knowledge of the exact composition of the gas is essential. In practice, however, this information is often not available (e. g. as it varies over time). In this case, it can be useful to regard the gas as an ideal gas. This means that only the operating temperature and operating pressure variables as well as the reference temperature and reference pressure variables are needed to calculate the corrected volume flow. The error resulting from this assumption (typically 1 to 5 %) is often considerably smaller than the error caused by inaccurate composition data. This method should not be used for condensing gases (e. g. saturated steam).

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.
- 3. In the **Select gas type** parameter, select the **User-specific gas** option.
- 4. For non-flammable gas:

In the **Enthalpy type** parameter, select the **Heat** option.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 5. Call up the **Medium properties** submenu.
- 6. In the **Reference density** parameter, enter the reference density of the fluid.
- 7. In the **Reference pressure** parameter, enter the reference pressure of the fluid.
- 8. In the **Reference temperature** parameter, enter the fluid temperature associated with the reference density.
- 9. In the **Reference Z-factor** parameter, enter the value **1**.
- 10. If specific heat capacity is to be measured:In the Specific heat capacity parameter, enter the heat capacity of the fluid.
- **11.** In the **Z-factor** parameter, enter the value **1**.
- **12.** In the **Dynamic viscosity** parameter, enter the viscosity of the fluid under operating conditions.

10.7.4 Calculation of the measured variables

A flow computer can be found in the electronics of the measuring device with order code for "Sensor version", option "mass (integrated temperature measurement)" and option "mass (integrated pressure/temperature measurement)". This computer can calculate the following secondary measured variables directly from the primary measured variables recorded using the pressure value (entered or external) and/or temperature value (measured or entered).

Medium	Fluid	Standards	Explanation	
Steam ¹⁾	Water vapor	IAPWS-IF97/ ASME	 For integrated temperature measurement For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via 	
	Single gas	NEL40	For fixed process pressure, pressure measured directly at the meter	
	Gas mixture	NEL40	body or if the pressure is read in via	
	Air	NEL40		
	Natural gas	ISO 12213-2	 Contains AGA8-DC92 For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via 	
Gas		AGA NX-19	For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via	
		ISO 12213-3	 Contains SGERG-88, AGA8 Gross Method 1 For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via 	
	Other gases	Linear equation	 Ideal gases For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via 	
	Water	IAPWS-IF97/ ASME	/ –	
Liquids	Liquefied gas	Tables	Propane and butane mixture	
	Other liquid	Linear equation	tion Ideal liquids	

Mass flow and corrected volume flow

Mass flow calculation

Volume flow × operating density

- Operating density for saturated steam, water and other liquids: depends on the temperature
- Operating density for superheated steam and all other gases: depends on the temperature and process pressure

Corrected volume flow calculation

(Volume flow × operating density)/reference density

- Operating density for water and other liquids: depends on the temperature
 - Operating density for all other gases: depends on the temperature and process pressure

Energy flow

Medium	Fluid	Standards	Explanation	Heat/energy option
Steam 1)	-	IAPWS- IF97/ASME	For fixed process pressure or if the pressure is read in via	
	Single gas	ISO 6976	 Contains GPA 2172 For fixed process pressure or if the pressure is read in via 	
Gas	Gas mixture	ISO 6976	 Contains GPA 2172 For fixed process pressure or if the pressure is read in via 	Heat Gross calorific value ²⁾ in relation to mass
	Air	NEL40	For fixed process pressure or if the pressure is read in via	Net calorific value ³⁾ in relation to mass Gross calorific value ²⁾ in relation to corrected volume Net calorific value ³⁾ in relation to corrected
	Natural gas	ISO 6976	 Contains GPA 2172 For fixed process pressure or if the pressure is read in via 	volume
		AGA 5	-	-
	WaterIAPWS- IF97/ASME-quidsLiquefied gasISO 6976Contains GPA 2172		-	
Liquids			Contains GPA 2172	
	Other liquid	Linear equation	-	

2) Gross calorific value: combustion energy + condensation energy of the flue gas (gross calorific value > net calorific value)

3) Net calorific value: only combustion energy

Mass flow and energy flow calculation

Steam is calculated based on the following factors:

- Fully compensated calculation of density using the "pressure" and "temperature" measured variables

Optional configuration of diagnostic behavior to the **Alarm** option or **Warning** option option.

At 2 K above saturation, activation of the ${\rm \ensuremath{\Delta}S871}$ Near steam saturation limit diagnostic message.

- The smaller of the following two pressure values is always used to calculate the density:
 Pressure measured directly at meter body or pressure read in via
 - Saturated steam pressure, which is derived from the saturated steam line (IAPWS-IF97/ASME)

For detailed information on how to perform external compensation, see $\rightarrow \square$ 99.

Calculated value

The unit calculates the mass flow, heat flow, energy flow, density and specific enthalpy from the measured volume flow and the measured temperature and/or the pressure based on international standard IAPWS-IF97/ASME.

Formulae for calculation:

- Mass flow: $\dot{m} = \dot{v} \cdot \rho$ (T, p)
- Heat flow: $\dot{Q} = \dot{v} \cdot \rho (T, p) \cdot h_D (T, p)$
- \dot{m} = Mass flow
- Q = Heat flow
- $\dot{v} = Volume flow (measured)$
- h_D = Specific enthalpy
- T = Process temperature (measured)
- p = Process pressure
- $\rho = \text{Density}^{3}$

Pre-programmed gases

The following gases are pre-programmed in the flow computer:

Hydrogen ¹⁾	Helium 4	Neon	Argon
Krypton	Xenon	Nitrogen	Oxygen
Chlorine	Ammonia	Carbon monoxide ¹⁾	Carbon dioxide
Sulfur dioxide	Hydrogen sulfide ¹⁾	Hydrogen chloride	Methane ¹⁾
Ethane ¹⁾	Propane ¹⁾	Butane ¹⁾	Ethylene (ethene) ¹⁾
Vinyl chloride	Mixtures of up to 8 components of these gases ¹⁾		

¹⁾ The energy flow is calculated as per ISO 6976 (contains GPA 2172) or AGA5 - in relation to the net calorific value or gross calorific value .

³⁾ From steam data as per IAPWS-IF97 (ASME), for the measured temperature and the specified pressure

Energy flow calculation

Volume flow × operating density × specific enthalpy

- Operating density for saturated steam and water: depends on the temperature
- Operating density for superheated steam, natural gas ISO 6976 (contains GPA 2172), natural gasAGA5: depends on the temperature and pressure

Heat flow difference

- Between saturated steam upstream from a heat exchanger and condensate downstream from the heat exchanger (second temperature read in via) in accordance with IAPWS-IF97/ASME
- Between warm and cold water (second temperature read in via) in accordance with IAPWS-IF97/ASME

Vapor pressure and steam temperature

The measuring device can perform the following in saturated steam measurements between the feed line and return line of any heating liquid (second temperature read in via and Cp value entered:

- Calculation of saturation pressure of steam from the measured temperature and output in accordance with IAPWS-IF97/ASME
- Calculation of saturation temperature of steam from the preset pressure and output in accordance with IAPWS-IF97/ASME

11 Operation

11.1 Reading off the device locking status

Device active write protection: Locking status parameter

Operation \rightarrow Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access authorization displayed in the Access status display parameter applies $\rightarrow \textcircled{B}$ 55. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow {}$ 110.
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Petailed information:

- To configure the operating language \rightarrow B 72
- For information on the operating languages supported by the measuring device $\rightarrow~\textcircled{}$ 207

11.3 Configuring the display

Detailed information:

- On the basic settings for the local display
- On the advanced settings for the local display \rightarrow 🗎 104

11.4 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Measured values	
► Process variables) → 🗎 120
► Totalizer) → 🗎 123

11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation "Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Process variables	
Volume flow	→ 🗎 122
Corrected volume flow	→ 🗎 122
Mass flow	→ 🗎 122
Flow velocity	→ 🗎 122
Temperature	→ 🗎 122
Vortex frequency	→ 🗎 122
Vortex kurtosis	→ 🗎 122
Vortex amplitude	→ 🗎 122
Calculated saturated steam pressur	e → 🗎 122
Steam quality	→ 🗎 122
Total mass flow	→ 🗎 122
Condensate mass flow	→ 🗎 122
Energy flow	→ 🗎 122
Heat flow difference	→ 🗎 122
Reynolds number	→ 🗎 122
Density	→ 🗎 122
Specific volume	→ 🗎 123
Pressure	→ 🗎 123
Compressibility factor	→ 🗎 123
Degrees of superheat	→ 🗎 123

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface	Factory setting
Volume flow	-	Displays the volume flow currently measured. <i>Dependency</i> The unit is taken from the Volume flow unit parameter	Signed floating-point number	-
Corrected volume flow	-	Displays the corrected volume flow currently calculated. <i>Dependency</i> The unit is taken from the Corrected volume flow unit parameter	Signed floating-point number	-
Mass flow	-	Displays the mass flow currently measured. Dependency The unit is taken from the Mass flow unit parameter	Signed floating-point number	-
Flow velocity	-	Shows the flow velocity currently calculated.	Signed floating-point number	1 m/s
Temperature	-	Displays the temperature currently measured. Dependency The unit is taken from the Temperature unit parameter	Signed floating-point number	-
Vortex frequency	-	Shows the vortex frequency registered by the DSC sensor in the measuring tube.	Measuring range depending on the nominal diameter: 0.1 to 3 100 Hz	-
Vortex kurtosis	-	Shows the statistical variable kurtosis, which serves to assess the signal quality (no unit).	0 to 10	-
Vortex amplitude	-	Shows the average vortex amplitude (no unit).	0 to 1	-
Calculated saturated steam pressure	-	Shows the saturated steam pressure currently calculated.	Signed floating-point number	1E-05 bar
Steam quality	-	Shows the current steam quality.	Signed floating-point number	1 %
Total mass flow	-	Shows the total mass flow (steam and condensate) currently calculated.	Signed floating-point number	3 599.999999999971 kg,
Condensate mass flow	-	Shows the condensate mass flow currently calculated.	Signed floating-point number	3 599.999999999971 kg
Energy flow	-	Shows the energy flow currently calculated.	Signed floating-point number	0.001 kW
Heat flow difference	-	Shows the heat flow difference currently calculated.	Signed floating-point number	0.001 kW
Reynolds number	-	Shows the Reynolds number currently calculated.	Signed floating-point number	1
Density	With order code for "Sensor version": Option "Mass (integrated temperature measurement)"	Displays the density currently measured. <i>Dependency</i> The unit is taken from the Density unit parameter.	Positive floating- point number	-

Parameter	Prerequisite	Description	User interface	Factory setting
Specific volume	With order code for "Sensor version": Option "Mass (integrated temperature measurement)"	Displays the current value for the specific volume. <i>Dependency</i> The unit is taken from the Specific volume unit parameter.	Positive floating- point number	-
Pressure	One of the following conditions is met: • Order code for "Sensor version", • Option "Mass (integrated temperature measurement)" • or • The Pressure option is selected in the External value parameter parameter.	Displays the current process pressure. <i>Dependency</i> The unit is taken from the Pressure unit parameter.	0 to 250 bar	-
Compressibility factor	The following conditions are met: Order code for "Sensor version" Option "Mass (integrated temperature measurement)" The Gas option or the Steam option is selected in the Select medium parameter.	Displays the compressibility factor currently calculated.	0 to 2	-
Degrees of superheat	In the Select medium parameter, the Steam option is selected.	Displays the degree of superheating currently calculated.	0 to 500 K	-

11.4.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer

► Totalizer	
Assign process variable 1 to n] → 🗎 124
Totalizer 1 to n value] → 🗎 124
Totalizer 1 to n status] → 🗎 124
Totalizer 1 to n status (Hex)] → 🗎 124

Parameter	Description	Selection / User interface	Factory setting
Assign process variable 1 to n	Select process variable for totalizer.	 Mass flow Volume flow Corrected volume flow Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* 	Volume flow
Totalizer 1 to n value	Shows the totalizer value reported to the controller for further processing.	Signed floating-point number	0 m ³
Totalizer 1 to n status	Shows the status of the totalizer value reported to the controller for further processing ('Good', 'Uncertain', 'Bad').	GoodUncertainBad	Good
Totalizer 1 to n status (Hex)	Shows the status of the totalizer value reported to the controller for further processing (Hex).	0 to 255	128

Parameter overview with brief description

Visibility depends on order options or device settings

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the Setup menu ($\rightarrow \square 72$)
- Advanced settings using the **Advanced setup** submenu ($\rightarrow \square 84$)

11.6 Displaying the measured value history


The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

P Data logging is also available via:

```
Plant Asset Management Tool FieldCare \rightarrow \square 58.
```

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Displays the measured value trend for each logging channel in the form of a chart



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation "Diagnostics" menu \rightarrow Data logging

► Data logging	
Assign channel 1) → 🗎 126
Assign channel 2) → 🗎 126
Assign channel 3) → 🗎 126
Assign channel 4) → 🗎 126
Logging interval] → 🗎 126
Clear logging data] → 🗎 126
Data logging] → 🗎 127
Logging delay	→ 🗎 127
Data logging control] → 🗎 127
Data logging status] → 🗎 127
Entire logging duration	→ 🗎 127

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Temperature Vortex frequency Calculated steam pressure* Steam quality* Total mass flow* Condensate mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Density* Pressure* Specific volume* Degrees of superheat* Electronics temperature 	Off
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter $(\rightarrow \square 126)$	Off
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter (→ 🗎 126)	Off
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter (→ 🗎 126)	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	1.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data	Cancel

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Data logging	-	Select the type of data logging.	 Overwriting Not overwriting	Overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	NoneDelete + startStop	None
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	DoneDelay activeActiveStopped	Done
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating- point number	0 s

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Remedial action
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display dark and no output signals	Supply voltage does not match the voltage specified on the nameplate.	Apply the correct supply voltage $\rightarrow \square 34$.
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Ensure electrical contact between the cable and the terminal.
Local display dark and no output signals	 Terminals are not plugged into the I/O electronics module correctly. 	Check terminals.
Local display dark and no output signals	 I/O electronics module is defective. 	Order spare part $\rightarrow \square$ 177.
Local display dark and output signals in failure current	Sensor short-circuit, electronics module short- circuit	1. Contact service organization.
Local display cannot be read, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part $\rightarrow \square$ 177.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 137$
Text on local display appears in a language that cannot be understood.	The selected operating language cannot be understood.	 Press □ +
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part → [□] 177.

For output signals

Error	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part $\rightarrow \square$ 177.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parameter configuration error	Check and adjust parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	 Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access

Fault	Possible causes	Remedial action
Write access to parameters is not possible.	Hardware write protection is enabled.	Set the write protection switch on the main electronics module to the OFF position $\rightarrow \cong 110$.
Write access to parameters is not possible.	Current user role has limited access authorization.	1. Check user role $\rightarrow \textcircled{1}$ 55. 2. Enter correct customer-specific access code $\rightarrow \textcircled{1}$ 55.
Connection via service interface is not possible.	 The USB port on the PC is incorrectly configured. The driver is not installed correctly.	Refer to the documentation on Commubox FXA291: Technical Information TI00405C
Web browser frozen and operation no longer possible	Data transfer is active.	Wait until data transfer or current action is finished.
	Connection lost	 Check cable connection and power supply. Refresh the web browser and restart if necessary.
Display of web browser content is difficult to read or incomplete.	Web browser version used is not optimal.	 Use correct web browser version . Empty the web browser cache. Restart the web browser.
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
Incomplete or no display of content in the web browser	JavaScript is not enabled.JavaScript cannot be enabled.	Enable JavaScript.


For system integration

Error	Possible causes	Remedy
displayed correctly and contains	A device name containing one or more underscores has been specified via the automation system.	Specify a correct device name (without underscores) via the automation system.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter

Different LEDs in the transmitter provide information on the device status.




LED		Color	Meaning
1	Device status/module	Off	Firmware error/no supply voltage
	status (normal operation)	Green	Device status is ok.

LED		Color	Meaning
		Flashing green	Device is not configured.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red/green	The device restarts/self-test.
2	Flashing/network status	Green	Cyclic data exchange is active.
		Flashing green	Following request from automation system: Flash frequency: 1 Hz (flash functionality: 500 ms on, 500 ms off)
			If no "Name of Station" is defined, the LED flashes at 4 Hz. Display: no "Name of Station" available.
		Red	IP address is available but there is no connection to the automation system
		Flashing red	Cyclic data exchange was active but the connection was disconnected: Flash frequency: 3 Hz

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring instrument are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 169$
- Via submenus → 🗎 170

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in the service mode (e.g. during a simulation).
S	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range)
М	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior


Symbol	Meaning
Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.	
	 Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.

Operating elements

Operating key	Meaning
+	Plus key In menu, submenu Opens the message about the remedial measures.
E	Enter key In menu, submenu Opens the operating menu.




12.3.2 Calling up remedial measures

12.4 Diagnostic information in the web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 169$
- Via submenu →
 [™]
 [™]
 170

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
\otimes	Failure A device error has occurred. The measured value is no longer valid.
	Function check The device is in service mode (e.g. during a simulation).
<u>^</u>	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range)
\bigcirc	Maintenance required Maintenance is required. The measured value remains valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

D 📽 🖬 🍜 🕋 🖾 🗅 📖 🏻 🗽	: 💽 (1 < 1) (1	š \$ F • i d d d d d
Device name: XXXXXXX Device tag: XXXXXXX Status signal:	Function check	Mass flow: ₽ 12.34 kg/h Volume flow: ₽ 12.34 m³/h (C)
 Xxxxxx Xxxxxxx Xxxxxx Xxxx	C485 Simu Deactivate Mainenance	Instrument health status Image: Second status <

- 1 Status area with status signal $\rightarrow \square 131$
- 2 Diagnostic information $\rightarrow \square 132$
- 3 Remedial actions with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 169$
- Via submenu → 🗎 170

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.

12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
- Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ← A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior


12.6.1 Available diagnostic behaviors

The following diagnostic behaviors can be assigned:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Warning	The device continues to measure. Measured value output via PROFINET and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (Event list submenu) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.6.2 Displaying the measured value status

If modules with input data (e.g. Analog Input module, Discrete Input module, Totalizer module, Heartbeat module) are configured for cyclic data transmission, the measured value status is coded as per PROFINET PA Profile 4 Specification and transmitted along with the measured value to the PROFINET Controller via the status byte. The status byte is split into three segments: Quality, Quality Substatus and Limits.



■ 21 Structure of the status byte

The contents of the status byte depends on the configured failure mode in the individual function block. Depending on which failure mode has been configured, status information in accordance with PROFINET PA Profile Specification 4 is transmitted to the the PROFINET over Ethernet-APL controller via the status byte status information. The two bits for the limits always have the value 0.

Supported	status	information
000000000000000000000000000000000000000	0000000	

Status	Coding (hex)
BAD - Maintenance alarm	0x24 to 0x27
BAD - Process related	0x28 to 0x2B
BAD - Function check	0x3C to 0x3F
UNCERTAIN - Initial value	0x4C to 0x4F
UNCERTAIN - Maintenance demanded	0x68 to 0x6B
UNCERTAIN - Process related	0x78 to 0x7B
GOOD - OK	0x80 to 0x83
GOOD - Maintenance required	0xA4 to 0xA7

Status	Coding (hex)
GOOD - Maintenance demanded	0xA8 to 0xAB
GOOD - Function check	0xBC to 0xBF

12.7 Overview of diagnostic information

The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

In the case of some items of diagnostic information, the diagnostic behavior can be changed. Adapting the diagnostic information

12.7.1 Diagnostic of sensor

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
004	Sensor defective		1. Check plug connections	 Vortex amplitude
	Measured variable status		 Replace pre-amplifier Replace DSC sensor 	 Calculated saturated steam pressure
	Quality	Good		 Density Electronics temperature option Energy flow Flow velocity Heat flow difference
	Quality substatus	Ok		
	Coding (hex)	0x80 to 0x83		
	Status signal	F		
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.		Short text		variables
022	Management are with the status (for set the factors) 1)		 Check plug connections Replace pre-amplifier Replace DSC sensor 	 Vortex amplitude Calculated saturated steam pressure
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Good Ok Ox80 to 0x83 F Alarm	S. Replace DSC Sensor	 Density Electronics temperature option Energy flow Flow velocity Heat flow difference Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume
				 Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
046	Management reprint to a status		1. Check plug connections	Vortex amplitude
			 Replace pre-amplifier Replace DSC sensor 	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
062	Management versible status		1. Check plug connections	 Vortex amplitude
			 Replace pre-amplifier Replace DSC sensor 	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	. Short text			variables
082	Data storage inconsistent		Check module connections	 Vortex amplitude Calculated saturated steam pressure
	Measured variable status			
	Quality	Good	-	DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	. Short text			variables
083	· · · · · · · · · · · · · · · · · · ·		1. Restart device	 Vortex amplitude
	Managered wariable status		 Restore S-DAT data Replace sensor 	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	lo. Short text			variables
114	Sensor leaky		Change DSC sensor	Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	5. Short text			variables
122			1. Check plug connections	Vortex amplitude
			 Replace pre-amplifier Replace DSC sensor 	 Calculated saturated steam pressure
	Quality	Good	-	 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		 Energy flow
	Status signal	M		Flow velocityHeat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	S	hort text		
170	Pressure cell connection defect	tive	1. Check plug connections	 Vortex amplitude
	Measured variable status		2. Replace pressure cell	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		Vortex kurtosisMass flow
				Total mass flowPressure
				PressureReynolds number
				 Specific volume
				 Corrected volume flow
				 Steam quality Degrade of superbast
				Degrees of superheatVolume flow
				Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	5. Short text			variables
171	Ambient temperature too low		Increase ambient temperature	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option • Energy flow • Flow velocity • Heat flow difference
	Coding (hex)	0x80 to 0x83		
	Status signal	S		
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
172	Ambient temperature too high		Reduce ambient temperature	Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
173	Pressure cell range exceeded		1. Check process conditions	Vortex amplitude
	Measured variable status		2. Adapt process pressure	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
174	Pressure cell electronics defect	ive	Replace pressure cell	 Vortex amplitude Calculated saturated
	Measured variable status Quality Good			steam pressure • Density
	Quality substatus	Ok		 Electronics temperature option Energy flow Flow velocity Heat flow difference
	Coding (hex) Status signal	0x80 to 0x83 F		
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic	information	Remedy instructions	Influenced measured
No.	b. Short text			variables
175	Pressure cell deactivated		Enable pressure cell	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	М		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

12.7.2 Diagnostic of electronic

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
201	201 Electronics faulty		1. Restart device	Vortex amplitude
	Measured variable status		2. Replace electronics	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
242	242 Firmware incompatible		1. Check firmware version	 Vortex amplitude
	Measured variable status		2. Flash or replace main electronic module	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
262	Module connection interrupted Measured variable status		1. Check or replace connection cable between sensor electronic module (ISEM) and main electronics	 Vortex amplitude Calculated saturated steam pressure
	QualityGoodQuality substatusOkCoding (hex)0x80 to 0x83Status signalFDiagnostic behaviorAlarm	2. Check or replace ISEM or main electronics	 Density Electronics temperature option Energy flow Flow velocity Heat flow difference Vortex kurtosis Mass flow Total mass flow Pressure 	
				 Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	. Short text			variables
270	Main electronics defective		1. Restart device	 Vortex amplitude
	Measured variable status		2. Replace main electronic module	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
271	Main electronics faulty		1. Restart device	Vortex amplitude
	Measured variable status		2. Replace main electronic module	 Calculated saturated steam pressure
	Quality	Good		Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
272	Main electronics faulty		Restart device	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		Density
	Quality substatus	ality substatus Ok	-	 Electronics temperature option
	Coding (hex)	0x80 to 0x83		 Energy flow Elementation
	Status signal	F		 Flow velocity Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	b. Short text			variables
273	Main electronics defective		1. Pay attention to display emergency	 Vortex amplitude
	Measured variable status		operation 2. Replace main electronics	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	ostatus Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
275	I/O module defective		Change I/O module	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
276	I/O module faulty		1. Restart device	Vortex amplitude
	Measured variable status		2. Change I/O module	 Calculated saturated steam pressure
	Quality	Good		 Density Electronics tomporature
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
277	Electronics defective		1. Replace pre-amplifier	 Vortex amplitude
	Measured variable status		2. Replace main electronic module	 Calculated saturated steam pressure
Quality Good	Good		 Density 	
	Quality substatus Ok		 Electronics temperature option 	
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	lo. Short text			variables
282	Data storage inconsistent		Restart device	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option • Energy flow • Flow velocity • Heat flow difference
	Coding (hex)	0x80 to 0x83		
	Status signal	F		
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
283	Memory content inconsistent		Restart device	 Vortex amplitude
Measured varia	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		 Density Electronics tomporature
	Quality substatus	Quality substatus Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 View Interference Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
302	Device verification active		Device verification active, please wait.	 Vortex amplitude
	Measured variable status Quality Good			 Calculated saturated steam pressure
			DensityElectronics temperature	
	Quality substatus	Function check	-	option
	Coding (hex)	0xBC to 0xBF		Energy flowFlow velocity
	Status signal	С		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
311	Electronics failure		Maintenance required!	 Vortex amplitude
	Measured variable status		Do not reset device	 Calculated saturated steam pressure
	Quality Good	 Density Electronics tomporature 		
	Quality substatus	Quality substatus Ok		 Electronics temperature option
	Coding (hex) 0x80 to 0x83		Energy flowFlow velocity	
Status signal M	M	-	 Heat flow difference 	
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
350	Pre-amplifier defective		Replace pre-amplifier	 Vortex amplitude Calculated saturated
	Measured variable status [fr	om the factory] ¹⁾		steam pressure
	Quality	ality Good	 Density 	
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
351	Pre-amplifier defective		Replace pre-amplifier	Vortex amplitudeCalculated saturated
	Measured variable status Quality Good		steam pressure	
		Good		 Density Electronics to monotonic
	Quality substatus	ality substatus Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
370	Pre-amplifier defective		1. Check plug connections	Vortex amplitude
	Measured variable status		 Check cabel connection of remote version 	 Calculated saturated steam pressure
	Quality	Good	3. Replace pre-amplifier or main electronic module	 Density Electronics temperature
	Quality substatus	Ok	inodule	option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
371	Temperature sensor defective		1. Check plug connections	 Vortex amplitude
		 Replace pre-amplifier Replace DSC sensor 	 Calculated saturated steam pressure 	
	Quality	Good	-	Density
	Quality substatus	Ok	-	 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	М		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
410	Data transfer failed		1. Retry data transfer	 Vortex amplitude
	Measured variable status		2. Check connection	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow
				Steam qualityDegrees of superheatVolume flowVortex frequency

12.7.3 Diagnostic of configuration

	Diagnostic information		Remedy instructions	Influenced measured	
No.	Short text			variables	
412	Processing download		Download active, please wait	 Vortex amplitude Calculated saturated 	
	Measured variable status			steam pressure	
	Quality	Good		 Density Electronics tomporature 	
	Quality substatus	Ok	-	 Electronics temperature option Energy flow Flow velocity Heat flow difference 	
	Coding (hex)	0x80 to 0x83			
	Status signal	С			
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency 	

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
437	Configuration incompatible		1. Update firmware	Vortex amplitude
	Measured variable status		2. Execute factory reset	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
438	Dataset different		1. Check dataset file	 Vortex amplitude
	Measured variable status	-	 Check device parameterization Download new device parameterization 	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		 Energy flow Elevenuels situ
	Status signal	M		 Flow velocity Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
453	Flow override active		Deactivate flow override	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	QualityGoodQuality substatusOk		DensityElectronics temperature	
		Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocityHeat flow difference
	Status signal	С		
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
482	Block in OOS		Set Block in AUTO mode	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	F		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
484	Failure mode simulation active	2	Deactivate simulation	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		 Density Electronics temperature
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	С		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	b. Short text			variables
485	Process variable simulation a	tive	Deactivate simulation	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
-	Status signal	С		Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
495	Diagnostic event simulation ac	tive	Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Ok		
	Coding (hex)	0x80 to 0x83		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
497	Block output simulation active		Deactivate simulation	 Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	С		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
538	Flow computer configuration is	ncorrect	Check input value (pressure, temperature)	Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
539	Measured writely status		- · ·	Vortex amplitude
			2. Check allowed values of the medium	 Calculated saturated steam pressure
Quality	Quality	Good	properties	DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
540	Flow computer configuration i	ncorrect	Check entered reference value using the	 Vortex amplitude
	Measured variable status		document Operating Instructions	 Calculated saturated steam pressure
	Quality	Good		 Density Electronics tomporature
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
570	Inverted delta heat		Check configuration of mounting location	 Vortex amplitude
	Measured variable status		(parameter Installation direction)	 Calculated saturated steam pressure
	Quality	Bad		 Density Electronics temperature option Energy flow Flow velocity Heat flow difference
	Quality substatus	Function check		
	Coding (hex)	0x3C to 0x3F		
	Status signal	F		
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

12.7.4 Diagnostic of process

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
828	1		Increase ambient temperature of pre-	 Vortex amplitude
	Measured variable status [from the factory] 1)		amplifier	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
829	Ambient temperature too high	1	Reduce ambient temperature of pre-	Vortex amplitude
	Measured variable status [from the factory] ¹⁾		amplifier	 Calculated saturated steam pressure
	Quality	Good		 Density Electronics tomporature
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
832	Electronics temperature too hi	gh	Reduce ambient temperature	Vortex amplitudeCalculated saturated
	Measured variable status [fro	om the factory] ¹⁾		 calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
833	Electronics temperature too	low	Increase ambient temperature	 Vortex amplitude Calculated saturated
	Measured variable status [from the factory] ¹⁾		steam pressure
	Quality	Good		 Density Electronics to react the second second
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
834	Process temperature too high		Reduce process temperature	Vortex amplitude
	Measured variable status [from the factory] 1)			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
835	Process temperature too low		Increase process temperature	Vortex amplitude
	Measured variable status [fr	om the factory] ¹⁾		 Calculated saturated steam pressure
	Quality	Good		 Density Electronics tomporature
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
841	Operating range		Reduce flow velocity	 Vortex amplitude
	Measured variable status [fr	om the factory] ¹⁾		 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	5. Short text			variables
842	Process value below limit		1. Decrease process value	 Vortex amplitude
	Measured variable status		 Check application Check sensor 	 Calculated saturated steam pressure
	Quality	Good		 Density Electronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
844	4 Process value out of specification		Reduce flow velocity	Vortex amplitudeCalculated saturated
	Measured variable status [from the factory] 1) Quality Good		steam pressureDensity	
	Quality substatus	Ok	-	• Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		Heat flow differenceVortex kurtosis
	Diagnostic behavior	Warning		 Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
870	Measuring inaccuracy increase	d	1. Check process	Vortex amplitude
	Measured variable status [fr	om the factory] ¹⁾	2. Increase flow volume	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
871	Near steam saturation limit		Check process conditions	 Vortex amplitude
	Measured variable status [fro	om the factory] ¹⁾		 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
872	Wet steam detected		1. Check process	 Vortex amplitude
	Measured variable status [fr	om the factory] ¹⁾	2. Check plant	 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
873	Water detected		Check process (water in piping)	 Vortex amplitude Calculated saturated
	Measured variable status [from the factory] ¹⁾			steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
874	Management warriable status		1. Check pressure, temperature	Vortex amplitude
			 Check flow velocity Check for flow fluctuation 	 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured	
No.	s	bort text		variables	
882	1 5 5		1. Check input signal parameterization	Vortex amplitude	
	Measured variable status		 Check external device Check process conditions 	Calculated saturated steam pressureDensity	
	Quality	Bad		5	
	Quality substatus	Maintenance alarm		 Electronics temperature option 	
	Coding (hex)	0x24 to 0x27		 Energy flow Element of the second secon	
	Status signal	F		Flow velocityHeat flow difference	
	Diagnostic behavior	Alarm		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency 	

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
945	5		Check immediately process conditions (pressure-temperature rating)	 Vortex amplitude Calculated saturated steam pressure
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Good Ok 0x80 to 0x83 S Warning		 Density Electronics temperature option Energy flow Flow velocity Heat flow difference Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
946	Vibration detected		Check installation	Vortex amplitude
	Measured variable status			 Calculated saturated steam pressure
	Quality	Good		DensityElectronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	:	Short text		variables
947	Vibration exceeded		Check installation	Vortex amplitude
	Measured variable status [f	rom the factory] ¹⁾		 Calculated saturated steam pressure
	Quality	Good		 Density
	Quality substatus	Ok		 Electronics temperature option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference
	Diagnostic behavior	Warning		 Vortex kurtosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
948	Monoured variable status		1. Check process conditions: wet gas,	 Vortex amplitude Calculated saturated steam pressure
			pulsation 2. Check installation: vibration	
	Quality	Good	- I I I I I I I I I I I I I I I I I I I	 Density Electronics temperature
	Quality substatus	Ok		option
	Coding (hex)	0x80 to 0x83		Energy flowFlow velocity
	Status signal	S		 Heat flow difference Vortex kurtosis
	Diagnostic behavior	Warning		 Vortex kirrosis Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
972	5 1		 Controll process conditions Install pressure transmitter or enter correct fixed pressure value 	 Vortex amplitude Calculated saturated steam pressure
	Quality Quality substatus	Good Ok		 Density Electronics temperature option Energy flow
	Coding (hex) Status signal	0x80 to 0x83 S		 Energy now Flow velocity Heat flow difference Vortex kurtosis
	Diagnostic behavior	Warning		 Mass flow Total mass flow Pressure Reynolds number Specific volume Corrected volume flow Steam quality Degrees of superheat Volume flow Vortex frequency

12.7.5 Operating conditions for displaying the following diagnostics information

P Operating conditions for displaying the following diagnostics information:

- 871 Near steam saturation limit diagnostic message: The process temperature is less than 2K from the saturated steam line.
- Diagnostics information 872: The measured steam quality has dropped below the configured limit value for the steam quality (limit value: Expert → System → Diagnostic handling → Diagnostic limits → Steam quality limit).
- Diagnostics information 873: The process temperature is ≤ 0 °C.
- Diagnostics information 972: The degree of superheat has exceeded the configured limit value (limit value: Expert → System → Diagnostic handling → Diagnostic limits → Degrees of superheat limit).

12.7.6 Emergency mode in event of temperature compensation

- Change temperature measurement: PT1+PT2 to the PT1 option, PT2 option or the Off option.

12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.


To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \square 133$
- Via "FieldCare" operating tool $\rightarrow \triangleq 135$

Other pending diagnostic events can be displayed in the **Diagnostic list** submenu $\rightarrow \cong 170$.

Navigation

"Diagnostics" menu



Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.9 Diagnostics list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

 $\text{Diagnostics} \rightarrow \text{Diagnostic list}$

오 //Diagnose list]
Diagnostics	
SF273 Main electronic	
Diagnostics 2	•
Diagnostics 3	

22 Using the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display →
 133
- Via "FieldCare" operating tool $\rightarrow \implies 135$


12.10 Event logbook

12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu \rightarrow **Event logbook** submenu \rightarrow Events list



23 Using the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the Extended HistoROM application package (order option) is enabled in the device, the event list can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events $\rightarrow \square 137$
- Information events $\rightarrow \triangleq 172$

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostics event
 - \odot : Occurrence of the event
 - 🕒 : End of the event
- Information event
- \odot : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \implies 133$
- Via "FieldCare" operating tool →
 [™]
 [™]
 135
- Via "DeviceCare" operating tool $\rightarrow \square$ 135

For filtering the displayed event messages $\rightarrow \square 171$

12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
11090	Configuration reset
I1091	Configuration changed
I1092	HistoROM backup deleted
I1110	Write protection switch changed
I1137	Electronics changed
I1151	History reset
I1155	Reset electronics temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1227	Sensor emergency mode activated
I1228	Sensor emergency mode failed
I1256	Display: access status changed
I1335	Firmware changed
I1361	Web server: login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1459	I/O module verification failed
I1461	Sensor verification failed
I1512	Download started
I1513	Download finished
I1514	Upload started

Info number	Info name
I1515	Upload finished
I1552	Failed: Main electronic verification
I1553	Failed: Pre-amplifier verification
I1622	Calibration changed
I1624	All totalizers reset
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server: login successful
I1629	CDI: login successful
I1631	Web server access changed
I1634	Reset to factory settings
I1635	Reset to delivery settings
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated

12.11 Resetting the device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter ($\Rightarrow \triangleq 108$).

12.11.1 Function scope of the "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to the factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting. This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.


12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information

► Device information	
Device tag	→ 🗎 174
Serial number	→ 🗎 174



Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Character string comprising numbers, letters and special characters	- none -
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Character string comprising numbers, letters and special characters	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Character string comprising numbers, letters and special characters	Prowirl200APL
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	_

Parameter	Description	User interface	Factory setting
Extended order code 3	Shows the 3rd part of the extended order code. The extended order code can also be found on the nameplate of the sensor	Character string	-
	and transmitter in the "Ext. ord. cd." field.		
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00

12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
04.2025	01.00.zz	Option 70-	No change in firmware	Operating Instructions	BA02135D/06/EN/02.25
2023	01.00.zz	Option 70-	Original firmware	Operating Instructions	BA02135D/06/EN/01.21

It is possible to flash the firmware to the current version or an existing previous version via the service interface.

For the compatibility of the firmware version with the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

• In the Download Area of the Endress+Hauser Web site: www.endress.com \rightarrow Downloads

- Specify the following details:
 - Product root: e.g. 7F2C The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

NOTICE

The use of unsuitable equipment or cleaning liquids can damage the transducer.

Do not use pigs to clean the pipe.

13.1.3 Replacing seals

Replacing sensor seals

NOTICE

Seals in contact with fluid must always be replaced!

• Only Endress+Hauser sensor seals may be used: replacement seals

Replacing housing seals

NOTICE

•

When using the device in a dusty atmosphere:

- only use the associated Endress+Hauser housing seals.
- 1. Replace defect seals only with original seals from Endress+Hauser.
- 2. The housing seals must be clean and undamaged when inserted into their grooves.
- 3. Dry, clean or replace the seals if necessary.

13.2 Measuring and test equipment

Endress+Hauser offers a variety of measuring and testing equipment, such as Netilion or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \square$ 181

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and conversion of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document all repairs and conversions and enter the details in Netilion Analytics.


14.2 Spare parts

Some interchangeable measuring device components are listed on an overview sign in the connection compartment cover.

The spare part overview sign contains the following information:

- A list of the most important spare parts for the measuring device, including their ordering information.
- The URL to the *Device Viewer* (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



24 Example for "Spare part overview sign" in connection compartment cover

1 Measuring device name

2 Measuring device serial number

A Measuring device serial number:

- Is located on the device nameplate and the spare part overview sign.
- Can be read out via the Serial number parameter (→
 ¹ 174) in the Device information submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the web page for information: https://www.endress.com/support/return-material
 - → Select the region.
- 2. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.

14.5 Disposal

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to persons from process conditions!

- Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

• Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Prowirl 200 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: • Approvals • Output, input • Display/operation • Housing • Software Installation Instructions EA01056D (Order number: 7X2CXX)
Remote display FHX50	 FHX50 housing for accommodating a display module . FHX50 housing suitable for: SD02 display module (push buttons) SD03 display module (touch control) Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft))
	 The measuring instrument can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes: Order code for measuring instrument, feature 030: Option L or M "Prepared for FHX50 display" Order code for FHX50 housing, feature 050 (device version): Option A "Prepared for FHX50 display" Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation): Option C: for an SD02 display module (push buttons) Option E: for an SD03 display module (touch control)
	 The FHX50 housing can also be ordered as a retrofit kit. The measuring instrument display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing: Feature 050 (measuring instrument version): option B "Not prepared for FHX50 display" Feature 020 (display, operation): option A "None, existing displayed used" Special Documentation SD01007F (Order number: FHX50)
Overvoltage protection for 2-wire devices	The use of an external overvoltage protection, e.g. HAW 569, is recommended.
Protective cover	The protective cover is used to protect against direct sunlight, precipitation and ice. It can be ordered together with the device via the product structure: Order code for "Accessories enclosed" option PB "Protective cover" Special Documentation SD00333F
	(Order number: 71162242)
Transmitter holder (pipe mounting)	To secure the remote version to the pipe DN 20 to 80 (3/4 to 3") Order code for "Accessory enclosed", option PM

15.1.2 For the sensor

Accessories	Description	
Flow conditioner	Is used to shorten the necessary inlet run. (Order number: DK7ST) Dimensions of flow conditioner	

15.2 Service-specific accessories

Accessories	Description
Applicator	 Software for selecting and sizing Endress+Hauser measuring instruments: Choice of measuring instruments for industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic display of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator
Netilion	lloT ecosystem: Unlock knowledge With the Netilion IIoT ecosystem,Endress+Hauser allows you to optimize your plant performance, digitize workflows, share knowledge, and enhance collaboration. Drawing upon decades of experience in process automation, Endress+Hauser offers the process industry an IIoT ecosystem designed to effortlessly extract insights from data. These insights allow process optimization, leading to increased plant availability, efficiency, and reliability - ultimately resulting in a more profitable plant. www.netilion.endress.com
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. (I) Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices.

15.3 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick. The memory and also on a SD card or

16 Technical data

16.1 Application

The measuring device is intended for the flow measurement of liquids, gas and steam.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Vortex meters work on the principle of the Karman vortex street.	
Measuring system	The device consists of a transmitter and a sensor.	
	Two device versions are available: Compact version - transmitter and sensor form a mechanical unit. Remote version - transmitter and sensor are mounted in separate locations.	
	For information on the structure of the measuring instrument $ ightarrow$ 🗎 12	

16.3 Input

Measured variable

Direct measured variables

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
AA	Volume; 316L; 316L	Volume flow
AB	Volume; Alloy C22; 316L	
BA	Volume high-temperature; 316L; 316L	
BB	Volume high-temperature; Alloy C22; 316L	

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Option Description Measured variable	
CA	Mass; 316L; 316L (integrated temperature measurement)	 Volume flow
СВ	Mass; Alloy C22; 316L (integrated temperature measurement)	 Temperature

Calculated measured variables

Order co	Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable	
AA	Volume; 316L; 316L	Under constant process conditions:	
AB	Volume; Alloy C22; 316L	 Mass flow ¹⁾ Corrected volume flow 	
AC	Volume; Alloy C22; Alloy C22	The totalized values for: • Volume flow • Mass flow • Corrected volume flow	

Order cod	Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable	
BA	Volume high-temperature; 316L; 316L		
BB	Volume high-temperature; Alloy C22; 316L		

1) A fixed density must be entered for calculating the mass flow (Setup menu \rightarrow Advanced setup submenu \rightarrow External compensation submenu \rightarrow Fixed density parameter).

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
CA	Mass; 316L; 316L (integrated temperature measurement)	Corrected volume flow
СВ	Mass; Alloy C22; 316L (integrated temperature measurement)	 Mass flow Calculated saturated steam pressure Energy flow
СС	Mass; Alloy C22; Alloy C22 (integrated temperature measurement)	 Heat flow difference Specific volume Degrees of superheat
DA	Mass steam; 316L; 316L (integrated pressure/temperature measurement)	- Degrees of superneat
DB	Mass gas/liquid; 316L; 316L (integrated pressure/ temperature measurement)	

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
AA	Volume; 316L; 316L	Under constant process conditions:
AB	Volume; Alloy C22; 316L	 Mass flow ¹⁾ Corrected volume flow
BA	Volume high-temperature; 316L; 316L	The totalized values for:
BB	Volume high-temperature; Alloy C22; 316L	Volume flowMass flowCorrected volume flow

A fixed density must be entered for calculating the mass flow (Setup menu → Advanced setup submenu → External compensation submenu → Fixed density parameter).

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description	Measured variable
CA	Mass; 316L; 316L (integrated temperature measurement)	Corrected volume flow
СВ	Mass; Alloy C22; 316L (integrated temperature measurement)	 Mass flow Calculated saturated steam pressure Energy flow
DA	Mass steam; 316L; 316L (integrated pressure/temperature measurement)	 Heat flow difference Specific volume Degrees of superheat
DB	Mass gas/liquid; 316L; 316L (integrated pressure/ temperature measurement)	- Degrees of superneat

Measuring range

-

The measuring range is dependent on the nominal diameter, the fluid and environmental influences.

The following specified values are the largest possible flow measuring ranges (Q_{min} to Q_{max}) for each nominal diameter. Depending on the fluid properties and environmental influences, the measuring range may be subject to additional restrictions. Additional restrictions apply to both the lower range value and the upper range value.


Flow measuring ranges in SI units

DN [mm]	Liquids [m ³ /h]	Gas/steam [m ³ /h]
25R, 40S	0.1 to 4.9	0.52 to 25
40R, 50S	0.32 to 15	1.6 to 130
50R, 80S	0.78 to 37	3.9 to 310
80R, 100S	1.3 to 62	6.5 to 820
100R, 150S	2.9 to 140	15 to 1800
150R, 200S	5.1 to 240	25 to 3 200
200R, 250 S	11 to 540	57 to 7 300

Flow measuring ranges in US units

DN	Liquids	Gas/steam
[in]	[ft³/min]	[ft³/min]
1R, 1½S	0.061 to 2.9	0.31 to 15
1½R, 2S	0.19 to 8.8	0.93 to 74
2R, 3S	0.46 to 22	2.3 to 180
3R, 4S	0.77 to 36	3.8 to 480
4R, 6S	1.7 to 81	8.6 to 1100
6R, 8S	3 to 140	15 to 1900
8R, 10S	6.8 to 320	34 to 4300

Flow velocity



D_i Measuring tube internal diameter (corresponds to dimension K)

v Velocity in measuring tube

Q Flow

 \fbox The internal diameter of measuring tube $D_{\rm i}$ is denoted in the dimensions as dimension K.

For detailed information, see the Technical Information $\rightarrow \cong 212$ Calculation of flow velocity:

$$v [m/s] = \frac{4 \cdot Q [m^3/h]}{\pi \cdot D_i [m]^2} \cdot \frac{1}{3600 [s/h]}$$
$$v [ft/s] = \frac{4 \cdot Q [ft^3/min]}{\pi \cdot D_i [ft]^2} \cdot \frac{1}{60 [s/min]}$$

A003430

Lower range value

Reynolds number

A restriction applies to the lower range value due to the turbulent flow profile, which only occurs with Reynolds numbers greater than 5 000. The Reynolds number is dimensionless and indicates the ratio of the inertia force of a fluid to its viscous force when flowing and is used as a characteristic variable for pipe flows. In the case of pipe flows with Reynolds numbers less than 5 000, periodic vortices are no longer generated and flow rate measurement is no longer possible.

The Reynolds number is calculated as follows:

$$Re = \frac{4 \cdot Q \ [m^{3}/s] \cdot \rho \ [kg/m^{3}]}{\pi \cdot D_{i} \ [m] \cdot \mu \ [Pa \cdot s]}$$
$$Re = \frac{4 \cdot Q \ [ft^{3}/s] \cdot \rho \ [lbm/ft^{3}]}{\pi \cdot D_{i} \ [ft] \cdot \mu \ [lbf \cdot s/ft^{2}]}$$

- Re Reynolds number
- Q Flow
- *D_i* Internal diameter of measuring tube (corresponds to dimension K)
- μ Dynamic viscosity
- ρ Density

The Reynolds number 5000, together with the density and viscosity of the fluid and the nominal diameter, is used to calculate the corresponding flow rate.

$$\begin{aligned} Q_{\text{Re}=5000} \left[m^{3}/h \right] &= \frac{5000 \cdot \pi \cdot D_{i} \left[m \right] \cdot \mu \left[\text{Pa} \cdot s \right]}{4 \cdot \rho \left[\text{kg/m}^{3} \right]} \cdot 3600 \left[\text{s/h} \right] \\ Q_{\text{Re}=5000} \left[\text{ft}^{3}/h \right] &= \frac{5000 \cdot \pi \cdot D_{i} \left[\text{ft} \right] \cdot \mu \left[\text{lbf} \cdot \text{s/ft}^{2} \right]}{4 \cdot \rho \left[\text{lbm/ft}^{3} \right]} \cdot 60 \left[\text{s/min} \right] \end{aligned}$$

 $Q_{Re=5000}$ Flow rate is dependent on the Reynolds number

D_i Internal diameter of measuring tube (corresponds to dimension K)

- μ Dynamic viscosity
- ρ Density

Minimum measurable flow velocity based on signal amplitude

The measuring signal must have a certain minimum signal amplitude so that the signals can be evaluated without any errors. Using the nominal diameter, the corresponding flow can also be derived from this amplitude.


The minimum signal amplitude depends on the setting for the sensitivity of the DSC sensor, the steam quality \mathbf{x} and the force of the vibrations present \mathbf{a} .

The value **mf** corresponds to the lowest measurable flow velocity without vibration (no wet steam) for a density of 1 kg/m^3 (0.0624 lbm/ft^3).

The value **mf** can be set in the range of 20 to 6 m/s (6 to 1.8 ft/s) (factory setting 12 m/s (3.7 ft/s)) with the **Sensitivity** parameter (value range 1 to 9, factory setting 5).

A003430

The lowest flow velocity that can be measured on account of the signal amplitude v_{AmpMin} is derived from the **Sensitivity** parameter and steam quality x or from the force of vibrations present a.



v_{AmpMin}	Minimum measurable flow velocity based on signal amplitude
mf	Sensitivity
x	Steam quality
ρ	Density

Minimum measurable flow rate based on signal amplitude

$$Q_{AmpMin} [m^{3}/h] = \frac{v_{AmpMin} [m/s] \cdot \pi \cdot (D_{i} [m])^{2}}{4} \cdot 3600 [s/h]$$
$$Q_{AmpMin} [ft^{3}/min] = \frac{v_{AmpMin} [ft/s] \cdot \pi \cdot (D_{i} [ft])^{2}}{4} \cdot 60 [s/min]$$

 Q_{AmpMin} Minimum measurable flow rate based on signal amplitude

 v_{AmpMin} Minimum measurable flow velocity based on signal amplitude

D_i Internal diameter of measuring tube (corresponds to dimension K)

ρ Density

Effective lower range value

The effective lower range value Q_{Low} is determined using the largest of the three values $Q_{min},\,Q_{Re\,=\,5000}$ and $Q_{AmpMin}.$

A0034304

$Q_{Low} [m^3/h] = max \begin{cases} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ $	$ \begin{bmatrix} Q_{min} [m^{3}/h] \\ Q_{Re=5000} [m^{3}/h] \\ Q_{AmpMin} [m^{3}/h] \end{bmatrix} $
$Q_{Low} [ft^3/min] = max \begin{cases} \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ $	$ \begin{bmatrix} Q_{min} [ft^3/min] \\ Q_{Re=5000} [ft^3/min] \\ Q_{AmpMin} [ft^3/min] \end{bmatrix} $

Q_{Low}	Effective lower range value
Q _{min}	Minimum measurable flow rate
Q _{Re = 5000}	Flow rate is dependent on the Reynolds number
<i>Q_{AmpMin}</i>	Minimum measurable flow rate based on signal amplitude

The Applicator is available for calculation purposes.

Upper range value

Maximum measurable flow rate based on signal amplitude

The measuring signal amplitude must be below a certain limit value to ensure that the signals can be evaluated without error. This results in a maximum permitted flow rate Q_{AmpMax} .

Nominal diameter specifications refer to the sensor with the narrowest cross-section.

$$Q_{AmpMax} [m^{3}/h] = \frac{URV [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4 \cdot \sqrt{\frac{\rho [kg/m^{3}]}{1 [kg/m^{3}]}}} \cdot 3600 [s/h]$$
$$Q_{AmpMax} [ft^{3}/min] = \frac{URV [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4 \cdot \sqrt{\frac{\rho [lbm/ft^{3}]}{0.0624 [lbm/ft^{3}]}}} \cdot 60 [s/min]$$

*Q*_{AmpMax} Maximum measurable flow rate based on signal amplitude

```
D<sub>i</sub> Internal diameter of measuring tube (corresponds to dimension K)
```

```
Density
```

ρ

URV Limit value for determining the maximum flow rate:

- DN 15 to 40: URV = 350
- DN 50 to 300: URV = 600
- NPS ½ to 1½: URV = 1148
- NPS 2 to 12: URV = 1969

Restricted upper range value is dependent on Mach number

For gas applications, an additional restriction applies to the upper range value with regard to the Mach number in the measuring instrument, which must be less than 0.3. The Mach number Ma describes the ratio of the flow velocity v to the sound velocity c in the fluid.

A0034321

$$Ma = \frac{v [m/s]}{c [m/s]}$$
$$Ma = \frac{v [ft/s]}{c [ft/s]}$$

Ma Mach number

v Flow velocity

c Speed of sound

The corresponding flow rate can be derived using the nominal diameter.

$$Q_{Ma=0.3} [m^{3}/h] = \frac{0.3 \cdot c [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4} \cdot 3600 [s/h]$$

$$Q_{Ma=0.3} [ft^{3}/min] = \frac{0.3 \cdot c [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4} \cdot 60 [s/min]$$

$$A0034337$$

 $Q_{Ma=0.3}$ Restricted upper range value is dependent on Mach number

С	Speed of sound
D_i	Internal diameter of measuring tube (corresponds to dimension K)
ρ	Density

Effective upper range value

The effective upper range value Q_{High} is determined using the smallest of the three values $Q_{max},\,Q_{AmpMax}$ and $Q_{Ma=0.3}.$

$Q_{High} [m^{3}/h] = min \begin{cases} Q_{max} [m^{3}/h] \\ Q_{AmpMax} [m^{3}/h] \\ Q_{Ma=0.3} [m^{3}/h] \end{cases}$	
$Q_{High} [ft^3/min] = min \begin{cases} Q_{max} [ft^3/min] \\ Q_{AmpMax} [ft^3/min] \\ Q_{Ma=0.3} [ft^3/min] \end{cases}$	
	A0034338

Q_{High}	Effective upper range value
Q _{max}	Maximum measurable flow rate
<i>Q_{AmpMax}</i>	Maximum measurable flow rate based on signal amplitude
Q _{Ma = 0.3}	Restricted upper range value is dependent on Mach number

For liquids, the occurrence of cavitation may also restrict the upper range value.

The Applicator is available for calculation purposes.

Operable flow range	The value, which is typically up to 49: 1, may vary depending on the operating conditions (ratio between upper range value and lower range value)
Input signal	External measured values
	 To increase the measurement accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring instrument: Operating pressure to increase measurement accuracy (Endress+Hauser recommends the use of a pressure measuring instrument for absolute pressure, e.g. Cerabar M or Cerabar S) Medium temperature to increase measurement accuracy (e.g. iTEMP) Reference density for calculating the corrected volume flow
	 Various pressure measuring devices can be ordered as accessories from Endress+Hauser. If using pressure measuring devices, pay attention to outlet runs when installing external devices →
	If the measuring instrument does not have pressure or temperature compensation ⁴⁾ , it is recommended that external pressure measured values be read in so that the following measured variables can be calculated: • Energy flow • Mass flow • Corrected volume flow
	Digital communication
	The measured values are written from the automation system to the measuring instrument via PROFINET.

16.4 Output

Output signal

PROFINET over Ethernet-APL

Device use	 Device connection to an APL field switch The device may only be operated according to the following APL port classifications: If used in hazardous areas: SLAA or SLAC¹⁾ If used in non-hazardous areas: SLAX Connection values of APL field switch (corresponds to APL port classification SPCC or SPAA):
	 Maximum input voltage: 15 V_{DC} Minimum output values: 0.54 W
	Device connection to an SPE switch If used in non-hazardous areas: suitable SPE switch
	 SPE switch prerequisite: Support of 10BASE-T1L standard Support of PoDL power class 10, 11 or 12 Detection of SPE field devices without integrated PoDL module
	Connection values of SPE switch: • Maximum input voltage: 30 V _{DC} • Minimum output values: 1.85 W
PROFINET	According to IEC 61158 and IEC 61784
Ethernet-APL	According to IEEE 802.3cg, APL port profile specification v1.0, galvanically isolated

⁴⁾ Order code for "Sensor version", DSC sensor; measuring tube" option DA, DB

Data transfer	10 Mbit/s Full-duplex
Current consumption	Transmitter
	Max. 55.56 mA
Permitted supply voltage	 Ex: 9 to 15 V Non-Ex: 9 to 30 V
Network connection	With integrated reverse polarity protection

1) For more information on using the device in the hazardous area, see the Ex-specific Safety Instructions

Signal on alarm

Depending on the interface, failure information is displayed as follows:

PROFINET over Ethernet-APL

Device diagnostics	Diagnostics according to PROFINET PA Profile 4.02
--------------------	---

Local display

Plain text display	With information on cause and remedial measures
Backlight	Additionally for device version with SD03 local display: red lighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication: PROFINET over Ethernet-APL
- Via service interface Endress+Hauser Common Data Interface (CDI)

Plain text display	With information on cause and remedial measures
Plain text display	With information on cause and remedial measures

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	 The following information is displayed depending on the device version: Supply voltage active Data transmission active Network available Connection established PROFINET blinking feature
	Diagnostic information via light emitting diodes $\rightarrow \square$ 129

Low flow cut off The switch points for low flow cut off are preset and can be configured.

Galvanic isolation

All inputs and outputs are galvanically isolated from one another.

Protocol	Application layer protocol for decentral device periphery and distributed automation, Version 2.43		
Communication type	Ethernet Advanced Physical Layer 10BASE-T1L		
Conformance Class	Conformance Class B (PA)		
Netload Class	PROFINET Netload Robustness Class 2 10 Mbit/s		
Data transfer	10 Mbit/s Full-duplex		
Cycle times	64 ms		
Polarity	Automatic correction of crossed "APL signal +" and "APL signal -" signal lines		
Media Redundancy Protocol (MRP)	Not possible (point-to-point connection to APL field switch)		
System redundancy support	System redundancy S2 (2 AR with 1 NAP)		
Device profile	PROFINET PA profile 4.02 (Application interface identifier API: 0x9700)		
Manufacturer ID	17		
Device type ID	0xA438		
Device description files (GSD, DTM, FDI)	Information and files available at: • www.endress.com → Downloads area • www.profibus.com		
Supported connections	 2x AR (IO Controller AR) 2x AR (IO Supervisor Device AR connection allowed) 		
Configuration options for measuring instrument	 Asset management software (FieldCare, DeviceCare, Field Xpert) Integrated Web server via Web browser and IP address Device master file (GSD), can be read out via the integrated Web server of the measuring instrument. Onsite operation 		
Configuration of the device name	 DCP protocol Asset management software (FieldCare, DeviceCare, Field Xpert) Integrated web server 		
Supported functions	 Identification & Maintenance, simple device identifier via: Control system Nameplate Measured value status The process variables are communicated with a measured value status Blinking feature via the local display for simple device identification and assignment Device operation via asset management software (e.g. FieldCare, DeviceCare, SIMATIC PDM with FDI package) 		
System integration	Information regarding system integration . Cyclic data transmission Verview and description of the modules Status coding Factory setting		

Protocol-specific data

16.5 Power supply

 Terminal assignment
 → 🗎 31

 Available device plugs
 → 🖺 32

 Supply voltage
 Transmitter The following supply voltage values apply for the outputs available:

 Supply voltage for a compact version

Order code for "Output; input"	Minimum Terminal voltage	Maximum Terminal voltage
Option S : PROFINET over Ethernet-APL	≥ DC 9 V	 Non-Ex: DC 30 V Ex: DC max. 15 V

Transient overvoltage: Up to overvoltage category I

Power consumption	Transmitter	
	Order code for "Output; input"	Maximum power consumption
	Option S: PROFINET over Ethernet-APL/ SPE, 10 Mbit/s	Operation with output 1: Ex: 833 mW Non-Ex: 1.5 W
Current consumption	20 to 55.56 mA	
Power supply failure	 Totalizers stop at the last value m Depending on the device version, in the pluggable data memory (H Error messages (incl. total operation) 	the configuration is retained in the device memory or istoROM DAT).
Electrical connection	→ 🗎 34	
Potential equalization	→ 🖺 40	
Terminals	For device version without integrat wire cross-sections 0.5 to 2.5 mm ²	ed overvoltage protection: plug-in spring terminals for (20 to 14 AWG)
Cable entries	1 The type of cable entry availab	le depends on the specific device version.
	Cable gland (not for Ex d) M20 × 1.5	
	Thread for cable entry • NPT ¹ / ₂ " • G ¹ / ₂ " • M20 × 1.5	
Cable specification	→ 🗎 30	
Overvoltage protection	The use of an external overvoltage	protection, e.g. HAW 569, is recommended.

Reference operating conditions	 Error limits following ISO/DIN 11631 +20 to +30 °C (+68 to +86 °F) 2 to 4 bar (29 to 58 psi) Calibration system traceable to national standards Calibration with the process connection corresponding to the particular standard
	To obtain measured errors, use the Applicator sizing tool $\rightarrow \square$ 181
Maximum measurement error	Base accuracy o.r. = of reading A2 A1 A1 Re_{min} Re_{max} Re_{max} Re_{max} Re_{max} Re_{max} Re_{max} Re_{max}
	$-A1$ $-A2$ $-Re_{1}$ Re_{2} Re_{max}

٨	00	2	٨.	ň	
A	υu	13	4	υ	

Reynold	ls number	
Re ₁	5000	
Re ₂	10000	
Re _{min}	 Reynolds number for minimum permitted volume flow in measuring tube Standard Option N "0.65% volume PremiumCal 5-point 	
	$Q_{AmpMin} [m^{3}/h] = \frac{v_{AmpMin} [m/s] \cdot \pi \cdot (D_{i} [m])^{2}}{4} \cdot 3600 [s/h]$	
	$Q_{AmpMin} [ft^3/min] = \frac{v_{AmpMin} [ft/s] \cdot \pi \cdot (D_i [ft])^2}{4} \cdot 60 [s/min]$	40034304
Re _{max}	Defined by internal diameter of measuring tube, Mach number and maximum permitted velocity measuring tube	7 in
	$Re_{max} = \frac{\rho \cdot 4 \cdot Q_{Heigh}}{\mu \cdot \cdot K}$	A0034339
	Further information on effective upper range value $Q_{High} \rightarrow \square 187$	

Performance characteristics 16.6

Volume flow

Medium type		Incompressible		Compressible	
Reynolds number Range	Measurement error	PremiumCal ¹⁾	Standard	PremiumCal ¹⁾	Standard
Re ₂ to Re _{max}	A1	< 0.65 %	< 0.75 %	< 0.9 %	< 1.0 %
Re ₁ to Re ₂	A2	< 2.5 %	< 5.0 %	< 2.5 %	< 5.0 %

1) Order code for "Calibration flow", option N "0.65% volume PremiumCal 5-point"

Temperature

- Saturated steam and liquids at room temperature, if T > 100 °C (212 °F): < 1 °C (1.8 °F)
- Gas: < 1 % o.r. [K]
- Rise time 50 % (stirred under water, following IEC 60751): 8 s

Mass flow saturated steam

Sensor version			Mass (integrated temperature measurement) ¹⁾		Mass (integrated pressure/ temperature measurement) ¹⁾		
Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number Range	Measurement error	PremiumCal ²⁾	Standard	PremiumCal ²⁾	Standard
> 4.76	20 to 50 (66 to 164)	Re ₂ to Re _{max}	A1	< 1.6 %	< 1.7 %	< 1.4 %	< 1.5 %
> 3.62	10 to 70 (33 to 230)	Re_2 to Re_{max}	A1	< 1.9 %	< 2.0 %	< 1.7 %	< 1.8 %
In all cases no	ot specified here, the	following applies	: < 5.7 %			1	1

1) Detailed calculation with Applicator

2) Order code for "Calibration flow", option N "0.65% volume PremiumCal 5-point"

Mass flow of superheated steam/gases ^{5) 6)}

Sensor version			Mass (integrated pressure/ temperature measurement) ¹⁾		Mass (integrated temperature measurement) + external pressure compensation ²⁾		
Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number Range	Measurement error	PremiumCal ³⁾	Standard	PremiumCal ³⁾	Standard
< 40	All velocities	Re ₂ to Re _{max}	A1	< 1.4 %	< 1.5 %	< 1.6 %	< 1.7 %
< 120	1	Re ₂ to Re _{max}	A1	< 2.3 %	< 2.4 %	< 2.5 %	< 2.6 %
In all cases not	specified here, t	he following app	lies: < 6.6 %			·	•

1) Detailed calculation with Applicator

2) The use of a Cerabar S is required for the measurement errors listed in the following section. The measurement error used to calculate the error in the measured pressure is 0.15 %.

3) Order code for "Calibration flow", option N "0.65% volume PremiumCal 5-point"

⁵⁾ Single gas, gas mixture, air: NEL40; natural gas: ISO 12213-2 contains AGA8-DC92, AGA NX-19, ISO 12213-3 contains SGERG-88 and AGA8 Gross Method 1

⁶⁾ The measuring instrument is calibrated with water and has been verified under pressure on gas calibration rigs.

Water mass flow

Sensor version		Mass (integrated temperature measurement)			
Process pressure [bar abs.]Flow velocity [m/s (ft/s)]Reynolds number rangeMeasured value deviation			PremiumCal ¹⁾	Standard	
All pressures	All velocities	Re ₂ to Re _{max}	A1	< 0.75 %	< 0.85 %
		Re ₁ to Re ₂	A2	< 2.6 %	< 2.7 %

1) Order code for "Calibration flow", option N "0.65% volume PremiumCal 5-point"

Mass flow (user-specific liquids)

To specify the system accuracy, Endress+Hauser requires information about the type of liquid and its operating temperature or information in table form about the dependency between the liquid density and the temperature.

Example

- Acetone is to be measured at fluid temperatures from +70 to +90 °C (+158 to +194 °F).
- For this purpose, the **Reference temperature** parameter (7703) (here 80 °C (176 °F)), **Reference density** parameter (7700) (here 720.00 kg/m³) and **Linear expansion coefficient** parameter (7621) (here 18.0298 × 10⁻⁴ 1/°C) must be entered in the transmitter.
- The overall system uncertainty, which is less than 0.9 % for the example above, is comprised of the following measurement uncertainties: uncertainty of volume flow measurement, uncertainty of temperature measurement, uncertainty of the density-temperature correlation used (including the resulting uncertainty of density).

Mass flow (other media)

Depends on the selected fluid and the pressure value, which is specified in the parameters. Individual error analysis must be performed.

Accuracy of outputs

The outputs have the following base accuracy specifications.

Pulse/frequency output


o.r. = of reading

Accuracy Max. ±100 ppm o.r.

Repeatability

o.r. = of reading

$$r = \left\{\frac{100 \cdot D_i^3}{V}\right\}^{\frac{1}{2}} \% \text{ o.r.}$$



■ 25 Repeatability = 0.1 % o.r. with a measured volume $[m^3]$ of V = 10000 · D_i^3

The repeatability can be improved if the measured volume is increased. Repeatability is not a device characteristic but a statistical variable that is dependent on the boundary conditions indicated.

If all the configurable functions for filter times (flow damping, display damping, current output time constant, frequency output time constant, status output time constant) are set to 0, in the event of vortex frequencies of 10 Hz and higher a response time of $max(T_v, 100 \text{ ms})$ can be expected.		
In the event of measuring frequencies < 10 Hz, the response time is > 100 ms and can be up to 10 s. T_v is the average vortex period duration of the flowing fluid.		
The device is suitable for use in outdoor and indoor areas with a relative humidity of 5 to 95%.		
 According to EN 61010-1 ≤ 2 000 m (6562 ft) > 2 000 m (6562 ft) with additional overvoltage protection (e.g. Endress+Hauser HAW Series) 		
Pulse/frequency output o.r. = of reading		
Temperature coefficient Max. ±100 ppm o.r.		
-		

Installation requirements $\rightarrow \square 19$

16.8 Environment

Ambient temperature	$\rightarrow \textcircled{22}$
range	

	 Temperature tables Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
Storage temperature	All components apart from the display modules: -50 to $+80$ °C (-58 to $+176$ °F)
	Display modules
	-40 to +80 °C (-40 to +176 °F)
	Remote display FHX50: -40 to +80 °C (-40 to +176 °F)
Relative humidity	The device is suitable for use in outdoor and indoor areas with a relative humidity of 5 to 95%.
Climate class	DIN EN 60068-2-38 (test Z/AD)
Degree of protection	 Transmitter Standard: IP66/67, Type 4X enclosure, suitable for pollution degree 4 When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2 Display module: IP20, Type 1 enclosure, suitable for pollution degree 2 Sensor IP66/67, Type 4X enclosure, suitable for pollution degree 4
Vibration-resistance and	Vibration sinusoidal, in accordance with IEC 60068-2-6
shock resistance	Order code for "Housing", option B "GT18 dual compartment, 316L, compact" and order code for "Sensor version; DSC sensor; Meas. tube", option DA "Mass steam; 316L; 316L (integrated pressure/temperature measurement)" or option DB "Mass gas/liquid; 316L; 316L (integrated pressure/temp. measurement)" • 2 to 8.4 Hz, 3.5 mm peak • 8.4 to 500 Hz, 1 g peak
	Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote" • 2 to 8.4 Hz, 7.5 mm peak • 8.4 to 500 Hz, 2 g peak
	Vibration broad-band random, according to IEC 60068-2-64
	Order code for "Housing", option B "GT18 dual compartment, 316L, compact" and order code for "Sensor version; DSC sensor; Meas. tube", option DA "Mass steam; 316L; 316L (integrated pressure/temperature measurement)" or option DB "Mass gas/liquid; 316L; 316L (integrated pressure/temp. measurement)" • 10 to 200 Hz, 0.003 g ² /Hz • 200 to 500 Hz, 0.001 g ² /Hz • Total: 0.93 g rms

Electromagnetic

compatibility (EMC)

Medium temperature range

Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote")

- 10 to 200 Hz, 0.01 g²/Hz
- 200 to 500 Hz, 0.003 q²/Hz
- Total: 1.67 g rms

Half-sine shocks according to IEC 60068-2-27

- Order code for "Housing", option B "GT18 dual compartment, 316L, compact" and order code for "Sensor version; DSC sensor; Meas. tube", option DA "Mass steam; 316L; 316L (integrated pressure/temperature measurement)" or option DB "Mass gas/liquid; 316L; 316L (integrated pressure/temp. measurement)" 6 ms 30 g
- Order code for "Housing", option C "GT20 dual compartment, alu, coated, compact" or option J "GT20 dual compartment, alu, coated, remote" or option K "GT18 dual compartment, 316L, remote") 6 ms 50 g

Rough handling shocks according to IEC 60068-2-31

Details are provided in the Declaration of Conformity. **I**

This unit is not intended for use in residential environments and cannot guarantee п adequate protection of the radio reception in such environments.

16.9 **Process**

DSC sensor 1)

Order co	Order code for "Sensor version; DSC sensor; measuring tube"			
Option	Option Description Medium temperature range			
AA	Volume; 316L; 316L	-40 to +260 °C (-40 to +500 °F), stainless steel		
AB	Volume; Alloy C22; 316L			
BA	Volume high-temperature; 316L; 316L	-200 to +400 ℃ (-328 to +752 °F), stainless stee		
BB	Volume high-temperature; Alloy C22; 316L	_		
CA	Mass; 316L; 316L	-200 to +400 °C (-328 to +752 °F), stainless steel		
СВ	Mass; Alloy C22; 316L			

Capacitance sensor 1)

Seals

Order code for "DSC sensor seal"			
Option	on Description Medium temperature range		
A	Graphite	-200 to +400 °C (-328 to +752 °F)	
В	Viton	-15 to +175 °C (+5 to +347 °F)	
С	Gylon	-200 to +260 °C (-328 to +500 °F)	
D	Kalrez	-20 to +275 °C (-4 to +527 °F)	

Pressure-temperature ratings



For an overview of the pressure-temperature ratings for the process connections, see the Technical Information

Nominal pressure of sensor The following overpressure resistance values apply to the sensor shaft in the event of a membrane rupture:

Sensor version; DSC sensor; measuring tube	Overpressure, sensor shaft in [bar a]
Volume	200
Volume high-temperature	200
Mass (integrated temperature measurement)	200
Mass steam (integrated pressure/temperature measurement) Mass gas/liquid (integrated pressure/temperature measurement)	200

Pressure specifications

Order code for "Sensor version; DSC sensor; measuring tube", option DA "Mass steam" and DB "Mass gas/liquid" is available for nominal diameters from DN 25/1. Oil-free or grease-free cleaning is not possible.

The OPL (over pressure limit = sensor overload limit) for the measuring instrument depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the appropriate standards and further information . The OPL may only be applied for a limited period of time.

The MWP (maximum working pressure) for the sensors depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the appropriate standards and further information . The MWP may be applied at the device for an unlimited period. The MWP can also be found on the nameplate.

WARNING

The maximum pressure for the measuring instrument depends on the lowest-rated element with regard to pressure.

- Note specifications regarding pressure range .
- ► The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP of the device.
- MWP: The MWP is indicated on the nameplate. This value refers to a reference temperature of +20 °C (+68°F) and may be applied to the device for an unlimited time. Note temperature dependence of MWP.
- OPL: The test pressure corresponds to the over pressure limit of the sensor and may be applied only temporarily to ensure that the measurement is within the specifications and no permanent damage occurs. In the case of sensor range and process connection combinations where the OPL of the process connection is less than the nominal value of the sensor, the device is set at the factory, at the very maximum, to the OPL value of the process connection. If using the entire sensor range, select a process connection with a higher OPL value.

Sensor	Maximum sensor measuring range		MWP	OPL
	Lower (LRL)	Upper (URL)		
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]
2 bar (30 psi)	0 (0)	+2 (+30)	6.7 (100.5)	10 (150)
4 bar (60 psi)	0 (0)	+4 (+60)	10.7 (160.5)	16 (240)
10 bar (150 psi)	0 (0)	+10 (+150)	25 (375)	40 (600)
40 bar (600 psi)	0 (0)	+40 (+600)	100 (1500)	160 (2 400)

Vibrations

Weight

16.10 Mechanical construction

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Compact version

Single inner diameter line size reduction

Weight data:

- Including the transmitter:
 - Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact" 1.8 kg (4.0 lb):
 - Order code for "Housing", option B "GT18 two-chamber, 316L, compact"4.5 kg (9.9 lb):
- Excluding packaging material

Weight in SI units

All values (weight) refer to devices with EN (DIN), PN 40 flanges. Weight information in [kg].

DN	Internal diameter Weight [kg]		
[mm]	[mm]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" ¹⁾	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" ¹⁾
25R	15	6.1	8.8
40R	25	10.1	12.8
50R	40	12.1	14.8
80R	50	16.1	18.8
100R	80	23.1	25.8
150R	100	42.1	44.8
200R	150	63.1	65.8

1) For high-temperature/low-temperature version: values + 0.2 kg

Weight in US units

All values (weight) refer to devices with ASME B16.5, Class 300/Sch. 40 flanges. Weight information in [lbs].

DN	Internal diameter	Weight [lbs]		
[in]	[in]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" ¹⁾	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" ¹⁾	
1R	1⁄2	18.0	23.9	
1½R	1	22.4	28.3	
2R	1½	26.8	32.7	
3R	2	48.8	54.8	
4R	3	68.7	74.6	

DN	Internal diameter	Weight [lbs]	
[in]	[in]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact" ¹⁾	Order code for "Housing", option B "GT18 two-chamber, 316L, compact" ¹⁾
6R	4	121.6	127.5
8R	6	165.7	171.6

1) For high-temperature/low-temperature version: values + 0.4 lbs

Transmitter remote version

Wall-mount housing

Dependent on the material of wall-mount housing:

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"2.4 kg (5.2 lb):
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote"6.0 kg (13.2 lb):

Sensor remote version

Single inner diameter line size reduction

Weight data:

- Including sensor connection housing:
 - Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"0.8 kg (1.8 lb):
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote"2.0 kg (4.4 lb):
- Excluding the connecting cable
- Excluding packaging material

Weight in SI units

All values (weight) refer to devices with EN (DIN), PN 40 flanges. Weight information in [kg].

DN	Internal diameter	Weigh	t [kg]
[mm]	[mm]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote" ¹⁾	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote" ¹⁾
25R	15	5.1	6.3
40R	25	9.1	10.3
50R	40	11.1	12.3
80R	50	15.1	16.3
100R	80	22.1	23.3
150R	100	41.1	42.3
200R	150	62.1	63.3

1) For high-temperature/low-temperature version: values + 0.2 kg

Weight in US units

All values (weight) refer to devices with ASME B16.5, Class 300/Sch. 40 flanges. Weight information in [lbs].

DN	Internal diameter	Weight	[lbs]
[in]	[in]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote" ¹⁾	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote" ¹⁾
1R	1⁄2	15.6	18.3
1½R	1	20.0	22.7
2R	1½	24.4	27.2
3R	2	46.4	49.2
4R	3	66.3	69.0
6R	4	119.2	122.0
8R	6	163.3	166.0

1) For high-temperature/low-temperature version: values + 0.4 lbs

Accessories

Flow conditioner

Weight in SI units

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
15	PN 10 to 40	0.04
25	PN 10 to 40	0.1
40	PN 10 to 40	0.3
50	PN 10 to 40	0.5
80	PN 10 to 40	1.4
100	PN10 to 40	2.4
150	PN 10/16 PN 25/40	6.3 7.8
200	PN 10 PN 16/25 PN 40	11.5 12.3 15.9
250	PN 10 to 25 PN 40	25.7 27.5

1) EN (DIN)

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
15	Class 150 Class 300	0.03 0.04
25	Class 150 Class 300	0.1
40	Class 150 Class 300	0.3
50	Class 150 Class 300	0.5
80	Class 150 Class 300	1.2 1.4
100	Class 150 Class 300	2.7

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
150	Class 150 Class 300	6.3 7.8
200	Class 150 Class 300	12.3 15.8
250	Class 150 Class 300	25.7 27.5

1) ASME

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
15	20К	0.06
25	20K	0.1
40	20К	0.3
50	10K 20K	0.5
80	10K 20K	1.1
100	10K 20K	1.80
150	10K 20K	4.5 5.5
200	10K 20K	9.2
250	10K 20K	15.8 19.1

1) JIS

Weight in US units

DN ¹⁾ [in]	Pressure rating	Weight [lbs]
1/2	Class 150 Class 300	0.07 0.09
1	Class 150 Class 300	0.3
1½	Class 150 Class 300	0.7
2	Class 150 Class 300	1.1
3	Class 150 Class 300	2.6 3.1
4	Class 150 Class 300	6.0
6	Class 150 Class 300	14.0 16.0

DN ¹⁾ [in]	Pressure rating	Weight [lbs]
8	Class 150 Class 300	27.0 35.0
10	Class 150 Class 300	57.0 61.0

1) ASME

Materials Transmitter housing


Compact version

- Order code for "Housing", option B "GT18 two-chamber, 316L, compact": Stainless steel, CF3M
- Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact": Aluminum, AlSi10Mg, coated
- Window material: glass

Remote version

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": For maximum corrosion resistance: Stainless steel, CF3M
- Window material: glass

Cable entries/cable glands



■ 26 Possible cable entries/cable glands

- 1 Internal thread M20 × 1.5
- 2 Cable gland M20 × 1.5
- 3 Adapter for cable entry with internal thread G $\frac{1}{2}$ or NPT $\frac{1}{2}$
- 4 Device plug

Order code for "Housing", option B "GT18 dual compartment, 316L, compact" option K "GT18 dual compartment, 316L, remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	 Non-hazardous area Ex ia Ex ic Ex nA, Ex ec Ex tb 	Stainless steel ,1.4404
Adapter for cable entry with internal thread G ½"	Non-hazardous area and hazardous area (except for XP)	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread NPT ½"	Non-hazardous area and hazardous area	

Order code for "Housing": option C "GT20 dual compartment, aluminum, coated, compact", option J "GT20 dual compartment, aluminum, coated remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	Non-hazardous areaEx iaEx ic	Plastic
	Adapter for cable entry with internal thread G ½"	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	Non-hazardous area and hazardous area (except for XP)	Nickel-plated brass
Thread NPT ½" via adapter	Non-hazardous area and hazardous area	

Connecting cable for remote version

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor connection housing

The material of the sensor connection housing is dependent on the material selected for the transmitter housing.

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Coated aluminum AlSi10Mg
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": Stainless cast steel, 1.4408 (CF3M) Compliant with:
 - NACE MR0175
 - NACE MR0103

Measuring tubes

DN 25R to 200R (1R to 8R")/DN 40S to 250S ($1\frac{1}{2}$ S to 10S"), pressure ratingsPN 10/16/25/40, Class 150/300 , and JIS 10K/20K

- Stainless cast steel, CF3M/1.4408
- Complies with:
 - NACE MR0175-2003
 - NACE MR0103-2003
- DN15 to 150 (½ to 6"): AD2000, permitted temperature range -10 to +400 °C (+14 to +752 °F) restricted

DSC sensor

Order code for "Sensor version; DSC sensor; measuring tube", option AA, BA, CA

Pressure ratings PN 10/16/25/40, Class 150/300, as well as JIS 10K/20K:

Parts in contact with medium (marked as "wet" on the DSC sensor flange): • Stainless steel 1.4404 and 316 and 316L

- Compliant with:
 - NACE MR0175/ISO 15156-2015
 - NACE MR0103/ISO 17945-2015

Parts not in contact with medium: Stainless steel 1.4301 (304)

Order code for "Sensor version; DSC sensor; measuring tube", option AB, BB, CB

Pressure ratings PN 10/16/25/40, Class 150/300, as well as JIS 10K/20K:

Parts in contact with medium (marked as "wet" on the DSC sensor flange):

- Alloy C22, UNS N06022 similar to Alloy C22/2.4602
- Compliant with:
 - NACE MR0175/ISO 15156-2015
 - NACE MR0103/ISO 17945-2015

Parts not in contact with medium: Alloy C22, UNS N06022 similar to Alloy C22/2.4602

Process connections

DN 25R to 200R (1R to 8R")/DN 40S to 250S (1½S to 10S"), pressure ratings PN 10/16/25/40, Class 150/300, as well as JIS 10K/20K:

- "R-type" with single inner diameter line size reduction: 25R to 200R (1R to 8R") Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003
- "S-type" with double inner diameter line size reduction: DN 40S to 250S (1½S to 10S") Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003

The following materials are available depending on the pressure rating: Stainless steel, multiple certifications, 1.4404/F316/F316L)

Available process connections

Seals

- Graphite
 - Sigraflex foil ZTM (BAM-certified for oxygen applications)
- FPM (VitonTM)
- Kalrez 6375TM
- Gylon 3504TM (BAM-certified for oxygen applications)

The technical tightness of tightness class L0.01 according to the TA-Luft regulation (Technical Instructions on Air Quality Control of December 1, 2021; Section 5.2.6.3 Flange connections), with a corresponding specific leakage rate of less than 0.01 mg/(s-m) was verified by means of type-based component tests at a test pressure of 40 bar_a.

Housing support

Stainless steel, 1.4408 (CF3M)

Screws for DSC sensor

- Order code for "Sensor version", option AA "Stainless steel, A4-80 according to ISO 3506-1 (316)"
- Order code for "Sensor version", option BA, CA, DA, DB Stainless steel, A2 as per ISO 3506-1 (304)
- Order code for "Additional approval", option LL "AD 2000 (including option JA+JB+JK) > DN25 including option LK"
 - Stainless steel, A4 as per ISO 3506-1 (316)
- Order code for "Sensor version", option AB, AC, BB, CB, CC Stainless steel, 1.4980 according to EN 10269 (Gr. 660 B)

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

Flow conditioner

- Stainless steel, multiple certifications, 1.4404 (316, 316L)
- Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003

Process connections DN 25R to 200R (1R to 8R")/DN 40S to 250S (1½S to 10S"), pressure ratings PN 10/16/25/40, Class 150/300, as well as JIS 10K/20K:

- "R-type" with single inner diameter line size reduction: 25R to 200R (1R to 8R") Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003
- "S-type" with double inner diameter line size reduction: DN 40S to 250S (1½S to 10S") Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003

The following materials are available depending on the pressure rating: Stainless steel, multiple certifications, 1.4404/F316/F316L)

Available process connections

16.11 Operability

Languages

Can be operated in the following languages:


 Via local display: English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Swedish, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech

 Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

Onsite operation

Via display module

Two display modules are available:



Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured

Operating elements


- External operation via touch control (3 optical keys) without opening the housing: $\boxdot, ~\boxdot, ~\boxdot$
- Operating elements also accessible in the various zones of the hazardous area

Additional functionality

- Data backup function
 - The device configuration can be saved in the display module.
- Data comparison function The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function The transmitter configuration can be transmitted to another device using the display module.

Via remote display FHX50

The remote display FHX50 can be ordered as an optional extra $\rightarrow \cong$ 180.



☑ 27 FHX50 operating options

1 SD02 display and operating module, push buttons: cover must be opened for operation

2 SD03 display and operating module, optical buttons: operation possible through cover glass

Display and operating elements

The display and operating elements correspond to those of the display module .

Remote operation	→	
Service interface	→ 🗎 58	
	16.12 Certificates and approvals	
	Current certificates and approvals for the product are available at <u>www.endress.com</u> on the relevant product page:	
	1. Select the product using the filters and search field.	
	2. Open the product page.	
	3. Select Downloads .	
CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.	
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.	
UKCA marking	The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.	
	Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com	
RCM marking	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".	

Ex-approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.
PROFINET over Ethernet-	PROFINET interface
APL certification	 The measuring instrument is certified and registered by the PROFIBUS Nutzerorganisation e.V. (PNO). The measuring system meets all the requirements of the following specifications: Certified according to: Test specification for PROFINET devices PROFINET PA Profile 4.02 PROFINET Netload Robustness Class 2 10 Mbit/s APL conformance test The device can also be operated with certified devices of other manufacturers (interoperability) The device supports PROFINET S2 system redundancy.
Pressure Equipment Directive	 With the marking a) PED/G1/x (x = category) or b) PESR/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or b) Schedule 2 of Statutory Instruments 2016 No. 1105. Devices not bearing this marking (without PED or PESR) are designed and manufactured according to sound engineering practice. They meet the requirements of a) Art. 4 Para. 3 of the Pressure Equipment Directive 2014/68/EU or b) Part 1, Para. 8 of Statutory Instruments 2016 No. 1105. The scope of application is indicated a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or b) Schedule 3, Para. 2 of Statutory Instruments 2016 No. 1105.
Experience	The Prowirl 200 measuring system is the successor model of the Prowirl 72 and Prowirl 73.
External standards and guidelines	 EN 60529 Degrees of protection provided by enclosure (IP code) DIN ISO 13359 Measurement of conductive liquid flow in closed conduits - Flanged-type electromagnetic flowmeters - Overall length ISO 12764:2017 Measurement of fluid flow in closed conduits – Flow rate measurement by means of vortex shedding flowmeters inserted in circular cross-section conduits running full EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements EN 61326-1/-2-3 EMC requirements for electrical equipment for measurement, control and laboratory use NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors

NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

- NAMUR NE 53
- Software of field devices and signal-processing devices with digital electronics NAMUR NE 105
- Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107 Self-monitoring and diagnosis of field devices
- NAMUR NE 131 Requirements for field devices for standard applications
- ETSI EN 300 328
- Guidelines for 2.4 GHz radio components.
- EN 301489 Electromagnetic compatibility and radio spectrum matters (ERM).

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Detailed information on the application packages: Special Documentation $\rightarrow \cong 212$

16.14 Accessories

Overview of accessories available to order \rightarrow \cong 180

16.15 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- Endress+Hauser Operations app: Enter serial number from nameplate or scan matrix code on nameplate.

Standard Documentation **Brief Operating Instructions**

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Prowirl R 200	KA01325D

Brief Operating Instructions for the transmitter

Measuring instrument	Documentation code
Prowirl 200	KA01545D

Technical Information

Measuring device	Documentation code
Prowirl R 200	TI01335D

Description of Device Parameters

Measuring instrument	Documentation code
Prowirl 200	GP01170D

Supplementary devicedependent documentation

Safety instructions	

Contents	Documentation code
ATEX/IECEx Ex d	XA01635D
ATEX/IECEx Ex ia	XA01636D
ATEX/IECEx Ex ec, Ex ic	XA01637D
_C CSA _{US} XP	XA01638D
_C CSA _{US} IS	XA01639D
EAC Ex d	XA01684D
EAC Ex ia	XA01782D
EAC Ex ec, Ex ic	XA01685D
INMETRO Ex d	XA01642D
INMETRO Ex ia	XA01640D
INMETRO Ex ec, Ex ic	XA01641D
JPN Ex d	XA01766D
NEPSI Ex d	XA01643D
NEPSI Ex ia	XA01644D
NEPSI Ex ec, Ex ic	XA01645D
UKEX Ex d	XA02630D
UKEX Ex ia	XA02631D
UKEX Ex ec, Ex ic	XA02632D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Heartbeat Technology	SD02759D
Web server	SD02834D
Protective cover	SD00333F

Installation Instructions

Contents	Note
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via <i>Device Viewer</i> → ¹ 177 Accessories available for order with Installation Instructions → ¹ 180

Index

A
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Adapting the diagnostic behavior
Ambient conditions
Ambient temperature
Operating height
Storage temperature
Vibration resistance and shock resistance 197
Ambient temperature
Influence
Ambient temperature range 22
Analog Output module
Application
Applicator
Approvals
D
B
Binary input module
Binary output module
С
-
Cable entries
Technical data
Cable entry
Degree of protection
CE mark
Certificates
Checklist
Post-connection check
Post-mounting check
Cleaning
Exterior cleaning
Interior cleaning
Replacing housing seals
Replacing seals 176 Replacing sensor seals 176
1 5
Climate class
Advanced settings
Configuring the device
Connection
see Electrical connection
Connection cable
Connection preparations
Connection tools
Context menu
Calling up
Closing
Explanation
Current consumption
Cyclic data transmission
Gyene auta transmission

D

Date of manufacture 14 Declaration of Conformity 10 Defining the access code 109
Degree of protection
Measuring device
Configuring
Device components
Device description files
Device locking, status
Device master file
GSD
Device name
Sensor
Device repair
Device revision
Device type ID
Device Viewer
DeviceCare
Device description file
Diagnostic behavior
Explanation
Symbols
Diagnostic information
Design, description
FieldCare
Light emitting diodes
Local display
Overview
Remedial measures
Web browser
Diagnostic message
Diagnostics
Symbols
Diagnostics list
DIP switch
see Write protection switch
Direct access
Disabling write protection
Display
Current diagnostic event
Previous diagnostic event
see Local display
Display area
For operational display
In the navigation view
For locking status
Displaying the measured value history
Disposal
Disposal
Function
Symbols
<u>,</u>

Document function	•	•	 •	•	•	•	•	•	•	•	•	•	•			 				 		6	5
Documentation														•			•	•	•	•	2	11	L

Ε

Electrical connection
Commubox FXA291
Degree of protection
Measuring instrument 30
Operating tools
Via APL network
Via service interface (CDI) 58
RSLogix 5000
Electromagnetic compatibility
Enabling write protection
Enabling/disabling the keypad lock
Endress+Hauser services
Maintenance
Repair
Error messages
see Diagnostic messages
Event logbook
Events list
Ex-approval 210
Experience
Extended order code
Sensor
Exterior cleaning

F

Field of application
Residual risks
FieldCare
Device description file
Establishing a connection
Function
User interface
Filtering the event logbook
Firmware
Release date
Version
Firmware history
Flow direction
Function range
SIMATIC PDM
Functions
see Parameters

G

Galvanic isolation	190
Н	
I I and the second test and the second sec	110

Hardware write protection
Help text
Calling up
Closing
Explanation
I
I/O electronics module
Identifying the measuring instrument

Incoming acceptance	13
Ambient temperature	196
Information about this document	
Inlet runs	
Input screen	
Inspection	17
Connection	41
Installation	
Received goods	
Installation	
Installation dimensions	
Installation requirements	
Inlet and outlet runs	2.0
Orientation	
Thermal insulation	
Intended use	
Interior cleaning	
	170
L	
Languages, operation options	207
Line recorder	
Local display	
Editing view	48
Navigation view	
see Diagnostic message	
see In alarm condition	

Low flow cut off	• • • • • • • • • • • • • • • • • • • •	190
Μ		

see Operational display

Main destruction and della 10
Main electronics module
Maintenance tasks
Manufacturer ID
Materials
Maximum measurement error
Measured variables
Calculated
Measured
see Process variables
Measuring and test equipment
Measuring device
Conversion
Design
Disposal
Preparing for mounting 26
Removing
Repairs
Switching on
Measuring instrument
Installing the sensor
Preparing for electrical connection
Measuring principle
Measuring range
Measuring system
Medium temperature range
Menu
Diagnostics

Setup	72
For device configuration	72
-	
For specific settings	04
	<u> </u>
Analog output	
Binary input	64
Binary output	68
Totalizer	
Totalizer	66
Totalizer Control	
Volume	
Volume Totalizer Control	
Mounting dimensions	
see Installation dimensions	
Mounting location	19
Mounting preparations	
Mounting requirements	
Installation dimensions	22
Mounting location	
	26
	20

Ν

Nameplate
Sensor
Navigation path (navigation view) 47
Navigation view
In the submenu
In the wizard
Netilion
Nominal pressure
Sensor
Numeric editor

0

0
Onsite display
Operable flow range
Operating elements
Operating height
Operating keys
see Operating elements
Operating menu
Menus, submenus
Structure
Submenus and user roles
Operating philosophy
Operation
Operation options
Operational display
Operational safety
Order code
Orientation (vertical, horizontal) 19
Outlet runs
Output signal
Output variables

Ρ

Packaging disposal												18	5
551													

Parameter settings	
Administration (Submenu)	107
Advanced setup (Submenu)	84
APL port (Submenu)	. 74
Data logging (Submenu)	124
	169
Display (Submenu)	104
External compensation (Submenu)	
Gas composition (Submenu)	
Heartbeat base settings (Submenu)	
Low flow cut off (Wizard)	
Medium properties (Submenu)	. 85
Medium selection (Wizard)	79
Network diagnostics (Submenu)	
Process variables (Submenu)	120
	100
Setup (Menu)	. 72
Simulation (Submenu)	
System units (Submenu)	
Totalizer (Submenu)	
Totalizer 1 to n (Submenu)	
Volume flow (Submenu)	
Parameters	
Changing	. 54
Entering a value	
Performance characteristics	
Post-connection check	. 72
Post-connection check (checklist)	41
Post-installation check	72
Post-mounting check (checklist)	28
Potential equalization	40
Power consumption	192
Power supply failure	192
Pressure Equipment Directive	210
Pressure loss	199
Pressure-temperature ratings	198
Process conditions	
Medium temperature	198
Pressure loss	199
Product safety	. 10
PROFINET over Ethernet-APL certification	
Protecting parameter settings	109
R	

Index

Repair
Repair of a device 177
Repeatability 195
Replacement
Device components
Replacing seals
Requirements for personnel
Response time
Return
S
-
Safety
Sensor
Installing
Serial number
Setting the operating language
Settings
Adapting the measuring device to the process
conditions
Administration
Advanced display configurations
Analog Input
Communication interface
External compensation
Gas composition
Low flow cut off
Medium
Medium properties
Operating language
Resetting the device
Sensor adjustment
Simulation
System units
Totalizer 102 Simular alarma 100
Signal on alarm
SIMATIC PDM
Function
Software release
Spare part
Spare parts
Status area
For operational display
In the navigation view
Status signals
Storage conditions
Storage temperature
Storage temperature range
Structure
Operating menu
Submenu
Administration
Advanced setup
Analog inputs
APL port
Communication
Data logging
Device information

Display 104 Events list 171 External compensation 99 Gas composition 88 Heartbeat base settings 107 Heartbeat setup 107 Medium properties 85 Network diagnostics 75 Overview 44 Process variables 120 Sensor adjustment 100 Simulation 108 System units 75 Totalizer 123 Totalizer 1 to n 102 Volume flow 82 Supply unit 82
Requirements
For communication45For correction49For diagnostic behavior45For locking45For neasured variable45For measurement channel number45For menus47For status signal47For status signal47For wizards47In the status area of the local display45In the text and numeric editor49System design182Measuring system182see Measuring device design
System integration
TTechnical data, overviewTemperature rangeStorage temperature17Terminal assignment34Terminals192Text editor48Thermal insulation23
Tool Transporting
Tools 30 Electrical connection 30 Installation 26 Totalizer 4 Assign process variable 123 Configuration 123
Configuring102Totalizer Control module67Totalizer module66

Transmitter
Connecting the signal cables
Turning the display module 28
Turning the housing
Transporting the measuring instrument
Troubleshooting
General
Turning the display module
Turning the electronics housing
see Turning the transmitter housing
Turning the transmitter housing
U
UKCA marking
Use of measuring device
Borderline cases
Incorrect use
Use of measuring instrument
see Intended use
User roles
030110103
V
Version data for the device
Vibration resistance and shock resistance
Volume module
Volume Totalizer Control module
W
W@M Device Viewer 13
Weight
Compact version
SI units
US units
Flow conditioner
Sensor remote version
SI units
SI units 201 US units 201
SI units 201 US units 201 Transport (notes) 17
SI units
SI units
SI units201US units201Transport (notes)17WizardDefine access code108Low flow cut off83
SI units201US units201Transport (notes)17WizardDefine access code108Low flow cut off83Medium selection79
SI units201US units201Transport (notes)17Wizard108Low flow cut off83Medium selection79Workplace safety10
SI units 201 US units 201 Transport (notes) 17 Wizard 108 Low flow cut off 83 Medium selection 79 Workplace safety 10 Write access 55
SI units201US units201Transport (notes)17Wizard108Low flow cut off83Medium selection79Workplace safety10Write access55Write protection
SI units 201 US units 201 Transport (notes) 17 Wizard 108 Low flow cut off 83 Medium selection 79 Workplace safety 10 Write access 55 Write protection 109
SI units201US units201Transport (notes)17Wizard108Low flow cut off83Medium selection79Workplace safety10Write access55Write protection



www.addresses.endress.com

