


# Operating Instructions

## Proline Promag P 100

### Modbus RS485

Electromagnetic flow measuring system



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

## Table of contents

|          |   |           |           |  |           |
|----------|---|-----------|-----------|--|-----------|
| <b>1</b> | <b>Document information</b> . . . . .                               | <b>5</b>  | <b>7</b>  | <b>Electrical connection</b> . . . . .                           | <b>27</b> |
| 1.1      | Document function . . . . .   | 5         | 7.1       | Connection conditions . . . . .                                  | 27        |
| 1.2      | Symbols used . . . . .  | 5         | 7.1.1     | Required tools . . . . .   | 27        |
| 1.2.1    | Safety symbols . . . . .  | 5         | 7.1.2     | Requirements for connecting cable . . .                          | 27        |
| 1.2.2    | Electrical symbols . . . . .  | 5         | 7.1.3     | Terminal assignment . . . . .                                    | 28        |
| 1.2.3    | Tool symbols . . . . .  | 6         | 7.1.4     | Pin assignment, device plug . . . . .                            | 28        |
| 1.2.4    | Symbols for certain types of<br>information . . . . .               | 6         | 7.1.5     | Shielding and grounding . . . . .                                | 29        |
| 1.2.5    | Symbols in graphics . . . . .                                       | 6         | 7.1.6     | Preparing the measuring device . . . . .                         | 29        |
| 1.3      | Documentation . . . . .   | 7         | 7.2       | Connecting the measuring device . . . . .                        | 30        |
| 1.3.1    | Standard documentation . . . . .                                    | 7         | 7.2.1     | Connecting the transmitter . . . . .                             | 30        |
| 1.3.2    | Supplementary device-dependent<br>documentation . . . . .           | 7         | 7.2.2     | Ensuring potential equalization . . . . .                        | 32        |
| 1.4      | Registered trademarks . . . . .                                     | 7         | 7.3       | Hardware settings . . . . .                                      | 34        |
|          |   |           | 7.3.1     | Enabling the terminating resistor . . . .                        | 34        |
| <b>2</b> | <b>Basic safety instructions</b> . . . . .                          | <b>8</b>  | 7.4       | Ensuring the degree of protection . . . . .                      | 34        |
| 2.1      | Requirements for the personnel . . . . .                            | 8         | 7.5       | Post-connection check . . . . .                                  | 35        |
| 2.2      | Designated use . . . . .  | 8         | <b>8</b>  | <b>Operation options</b> . . . . .                               | <b>36</b> |
| 2.3      | Workplace safety . . . . .  | 9         | 8.1       | Overview of operation options . . . . .                          | 36        |
| 2.4      | Operational safety . . . . .  | 9         | 8.2       | Structure and function of the operating<br>menu . . . . .        | 37        |
| 2.5      | Product safety . . . . .  | 9         | 8.2.1     | Structure of the operating menu . . . . .                        | 37        |
|          |   |           | 8.2.2     | Operating philosophy . . . . .                                   | 38        |
| <b>3</b> | <b>Product description</b> . . . . .                                | <b>10</b> | 8.3       | Access to the operating menu via the<br>operating tool . . . . . | 39        |
| 3.1      | Product design . . . . .  | 10        | 8.3.1     | Connecting the operating tool . . . . .                          | 39        |
| 3.1.1    | Device version with Modbus RS485<br>communication type . . . . .    | 10        | 8.3.2     | FieldCare . . . . .  | 39        |
| <b>4</b> | <b>Incoming acceptance and product<br/>identification</b> . . . . . | <b>11</b> | <b>9</b>  | <b>System integration</b> . . . . .                              | <b>41</b> |
| 4.1      | Incoming acceptance . . . . .                                       | 11        | 9.1       | Overview of device description files . . . . .                   | 41        |
| 4.2      | Product identification . . . . .                                    | 12        | 9.1.1     | Current version data for the device . . .                        | 41        |
| 4.2.1    | Transmitter nameplate . . . . .                                     | 12        | 9.1.2     | Operating tools . . . . .  | 41        |
| 4.2.2    | Sensor nameplate . . . . .  | 13        | 9.2       | Modbus RS485 information . . . . .                               | 41        |
| 4.2.3    | Symbols on measuring device . . . . .                               | 14        | 9.2.1     | Function codes . . . . .   | 41        |
| <b>5</b> | <b>Storage and transport</b> . . . . .                              | <b>15</b> | 9.2.2     | Register information . . . . .                                   | 42        |
| 5.1      | Storage conditions . . . . .  | 15        | 9.2.3     | Response time . . . . .  | 42        |
| 5.2      | Transporting the product . . . . .                                  | 15        | 9.2.4     | Modbus data map . . . . .  | 42        |
| 5.3      | Packaging disposal . . . . .  | 16        | <b>10</b> | <b>Commissioning</b> . . . . .                                   | <b>45</b> |
| <b>6</b> | <b>Installation</b> . . . . .                                       | <b>17</b> | 10.1      | Function check . . . . .   | 45        |
| 6.1      | Installation conditions . . . . .                                   | 17        | 10.2      | Establishing a connection via FieldCare . . . . .                | 45        |
| 6.1.1    | Mounting position . . . . .   | 17        | 10.3      | Configuring the measuring device . . . . .                       | 45        |
| 6.1.2    | Requirements from environment and<br>process . . . . .              | 19        | 10.3.1    | Setting the system units . . . . .                               | 45        |
| 6.1.3    | Special mounting instructions . . . . .                             | 21        | 10.3.2    | Configuring communication<br>interface . . . . .                 | 46        |
| 6.2      | Mounting the measuring device . . . . .                             | 21        | 10.3.3    | Configuring the low flow cut off . . . . .                       | 48        |
| 6.2.1    | Required tools . . . . .  | 21        | 10.3.4    | Configuring empty pipe detection . . . .                         | 49        |
| 6.2.2    | Preparing the measuring device . . . . .                            | 21        | 10.4      | Advanced settings . . . . .                                      | 50        |
| 6.2.3    | Mounting the sensor . . . . .                                       | 22        | 10.4.1    | Carrying out a sensor adjustment . . . .                         | 50        |
| 6.3      | Post-installation check . . . . .                                   | 25        | 10.4.2    | Configuring the totalizer . . . . .                              | 50        |
|          |   |           | 10.4.3    | Performing electrode cleaning . . . . .                          | 51        |
|          |   |           | 10.5      | Simulation . . . . .   | 52        |
|          |   |           | 10.5.1    | Parameter overview with brief<br>description . . . . .           | 53        |

|           |   |           |                    |  |           |
|-----------|---|-----------|--------------------|--|-----------|
| 10.6      | Protecting settings from unauthorized access .....            | 53        | <b>15</b>          | <b>Accessories .....</b>                 | <b>72</b> |
| 10.6.1    | Write protection via write protection switch .....            | 53        | 15.1               | Device-specific accessories .....        | 72        |
| <b>11</b> | <b>Operation .....</b>  | <b>55</b> | 15.1.1             | For the transmitter .....                | 72        |
| 11.1      | Read device locking status .....                              | 55        | 15.1.2             | For the sensor .....                     | 72        |
| 11.2      | Reading measured values .....                                 | 55        | 15.2               | Communication-specific accessories ..... | 72        |
| 11.2.1    | Process variables .....                                       | 55        | 15.3               | Service-specific accessories .....       | 73        |
| 11.2.2    | Totalizer .....   | 56        | 15.4               | System components .....                  | 73        |
| 11.3      | Adapting the measuring device to the process conditions ..... | 56        | <b>16</b>          | <b>Technical data .....</b>              | <b>74</b> |
| 11.4      | Performing a totalizer reset .....                            | 57        | 16.1               | Application .....                        | 74        |
| <b>12</b> | <b>Diagnostics and troubleshooting ...</b>                    | <b>59</b> | 16.2               | Function and system design .....         | 74        |
| 12.1      | General troubleshooting .....                                 | 59        | 16.3               | Input .....                              | 74        |
| 12.2      | Diagnostic information via light emitting diodes .....        | 59        | 16.4               | Output .....                             | 76        |
| 12.2.1    | Transmitter .....   | 59        | 16.5               | Power supply .....                       | 77        |
| 12.3      | Diagnostic information in FieldCare .....                     | 60        | 16.6               | Performance characteristics .....        | 78        |
| 12.3.1    | Diagnostic options .....                                      | 60        | 16.7               | Installation .....                       | 79        |
| 12.3.2    | Calling up remedy information .....                           | 61        | 16.8               | Environment .....                        | 79        |
| 12.4      | Diagnostic information via communication interface .....      | 61        | 16.9               | Process .....                            | 80        |
| 12.4.1    | Reading out diagnostic information ..                         | 61        | 16.10              | Mechanical construction .....            | 82        |
| 12.4.2    | Configuring error response mode ....                          | 61        | 16.11              | Operability .....                        | 85        |
| 12.5      | Adapting the diagnostic information .....                     | 62        | 16.12              | Certificates and approvals .....         | 85        |
| 12.5.1    | Adapting the diagnostic behavior ....                         | 62        | 16.13              | Application packages .....               | 86        |
| 12.6      | Overview of diagnostic information .....                      | 63        | 16.14              | Accessories .....                        | 87        |
| 12.7      | Pending diagnostic events .....                               | 64        | 16.15              | Documentation .....                      | 87        |
| 12.8      | Diagnostic list .....   | 64        | <b>17</b>          | <b>Appendix .....</b>                    | <b>88</b> |
| 12.9      | Event logbook .....   | 65        | 17.1               | Overview of the operating menu .....     | 88        |
| 12.9.1    | Event history .....   | 65        | <b>Index .....</b> | <b>99</b>                                |           |
| 12.9.2    | Filtering the event logbook .....                             | 65        |                    |  |           |
| 12.9.3    | Overview of information events .....                          | 66        |                    |  |           |
| 12.10     | Resetting the measuring device .....                          | 66        |                    |  |           |
| 12.11     | Device information .....                                      | 66        |                    |  |           |
| 12.12     | Firmware history .....  | 67        |                    |  |           |
| <b>13</b> | <b>Maintenance .....</b>                                      | <b>69</b> |                    |  |           |
| 13.1      | Maintenance tasks .....                                       | 69        |                    |  |           |
| 13.1.1    | Exterior cleaning .....                                       | 69        |                    |  |           |
| 13.1.2    | Interior cleaning .....                                       | 69        |                    |  |           |
| 13.1.3    | Replacing seals .....   | 69        |                    |  |           |
| 13.2      | Measuring and test equipment .....                            | 69        |                    |  |           |
| 13.3      | Endress+Hauser services .....                                 | 69        |                    |  |           |
| <b>14</b> | <b>Repair .....</b>   | <b>70</b> |                    |  |           |
| 14.1      | General notes .....   | 70        |                    |  |           |
| 14.2      | Spare parts .....   | 70        |                    |  |           |
| 14.3      | Endress+Hauser services .....                                 | 70        |                    |  |           |
| 14.4      | Return .....  | 70        |                    |  |           |
| 14.5      | Disposal .....  | 70        |                    |  |           |
| 14.5.1    | Removing the measuring device .....                           | 70        |                    |  |           |
| 14.5.2    | Disposing of the measuring device ...                         | 71        |                    |  |           |

# 1 Document information

## 1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

## 1.2 Symbols used

### 1.2.1 Safety symbols

| Symbol   | Meaning  |
|--|--|
| <br>A0011189-EN   | <b>DANGER!</b><br>This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury. |
| <br>A0011190-EN   | <b>WARNING!</b><br>This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. |
| <br>A0011191-EN  | <b>CAUTION!</b><br>This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.  |
| <br>A0011192-EN | <b>NOTICE!</b><br>This symbol contains information on procedures and other facts which do not result in personal injury.                   |

### 1.2.2 Electrical symbols

| Symbol  | Meaning  |
|---|--|
| <br>A0011197 | <b>Direct current</b><br>A terminal to which DC voltage is applied or through which direct current flows.  |
| <br>A0011198 | <b>Alternating current</b><br>A terminal to which alternating voltage is applied or through which alternating current flows.   |
| <br>A0017381 | <b>Direct current and alternating current</b> <ul style="list-style-type: none"> <li>▪ A terminal to which alternating voltage or DC voltage is applied.</li> <li>▪ A terminal through which alternating current or direct current flows.</li> </ul> |
| <br>A0011200 | <b>Ground connection</b><br>A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.  |
| <br>A0011199 | <b>Protective ground connection</b><br>A terminal which must be connected to ground prior to establishing any other connections.   |
| <br>A0011201 | <b>Equipotential connection</b><br>A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.                     |

### 1.2.3 Tool symbols

| Symbol  | Meaning           |
|---|-------------------|
| <br>A0011221 | Allen key         |
| <br>A0011222 | Open-ended wrench |

### 1.2.4 Symbols for certain types of information

| Symbol  | Meaning  |
|---|--|
| <br>A0011182   | <b>Allowed</b><br>Indicates procedures, processes or actions that are allowed.             |
| <br>A0011183   | <b>Preferred</b><br>Indicates procedures, processes or actions that are preferred.         |
| <br>A0011184   | <b>Forbidden</b><br>Indicates procedures, processes or actions that are forbidden.         |
| <br>A0011193   | <b>Tip</b><br>Indicates additional information.  |
| <br>A0011194  | <b>Reference to documentation</b><br>Refers to the corresponding device documentation.     |
| <br>A0011195 | <b>Reference to page</b><br>Refers to the corresponding page number.                       |
| <br>A0011196 | <b>Reference to graphic</b><br>Refers to the corresponding graphic number and page number. |
| 1., 2., 3., ...   | <b>Series of steps</b>   |
| ✓   | <b>Result of a sequence of actions</b>   |
| <br>A0013562 | <b>Help in the event of a problem</b>  |

### 1.2.5 Symbols in graphics

| Symbol  | Meaning  |
|---|--|
| 1, 2, 3, ...  | Item numbers   |
| 1., 2., 3., ...   | Series of steps  |
| A, B, C, ...  | Views  |
| A-A, B-B, C-C, ...  | Sections   |
| <br>A0013441 | Flow direction   |
| <br>A0011187 | <b>Hazardous area</b><br>Indicates a hazardous area.                     |
| <br>A0011188 | <b>Safe area (non-hazardous area)</b><br>Indicates a non-hazardous area. |

## 1.3 Documentation

-  The following document types are available:
  - On the CD-ROM supplied with the device
  - In the Download Area of the Endress+Hauser Internet site: [www.endress.com](http://www.endress.com) → Download
-  For a detailed list of the individual documents along with the documentation code (→  87)

### 1.3.1 Standard documentation

| Document type                     | Purpose and content of the document  |
|-----------------------------------|--|
| Technical Information             | <b>Planning aid for your device</b><br>The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device. |
| Brief Operating Instructions      | <b>Guide that takes you quickly to the 1st measured value</b><br>The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.           |
| Modbus RS485 register information | <b>Reference for Modbus RS485 register information</b><br>The document provides Modbus-specific information for each individual parameter in the operating menu.                                     |

### 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

## 1.4 Registered trademarks

### Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

### Applicator®, FieldCare®, Field Xpert™, HistoROM®, Heartbeat Technology™

Registered or registration-pending trademarks of the Endress+Hauser Group

## 2 Basic safety instructions

### 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

### 2.2 Designated use

#### Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5  $\mu\text{S}/\text{cm}$ .

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the device documentation provided (on the CD-ROM) is absolutely essential.

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### WARNING

##### **Danger of breakage of the sensor due to corrosive or abrasive fluids!**

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified maximum process pressure.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### **Residual risks**

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

## **2.3 Workplace safety**

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

## **2.4 Operational safety**

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

#### **Conversions to the device**

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

#### **Repair**

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

## **2.5 Product safety**


This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which they are safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

## 3 Product description

### 3.1 Product design

#### 3.1.1 Device version with Modbus RS485 communication type




A0017609

#### 1 Important components of a measuring device

- 1 Transmitter housing cover
- 2 Main electronics module for Modbus RS485
- 3 Transmitter housing
- 4 Sensor


# 4 Incoming acceptance and product identification

## 4.1 Incoming acceptance




A0013843

Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?




A0013695




A0013698

Are the goods undamaged?



A0013699

Do the nameplate data match the ordering information on the delivery note?



A0013697

Is the CD-ROM with the Technical Documentation and documents present?

 If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.

## 4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): All information about the measuring device is displayed.

For an overview of the scope of the Technical Documentation provided, refer to the following:

- The "Additional standard documentation on the device" (→  7) and "Supplementary device-dependent documentation" (→  7) sections
- The *W@M Device Viewer*: Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))

### 4.2.1 Transmitter nameplate




A0017520

 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number
- 5 Extended order code
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Permitted ambient temperature range ( $T_a$ )
- 8 Degree of protection
- 9 2-D matrix code
- 10 Document number of safety-related supplementary documentation
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Firmware version (FW)

## 4.2.2 Sensor nameplate



A0017186

 3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of the sensor
- 7 Test pressure of the sensor
- 8 Medium temperature range
- 9 Material of lining and electrodes
- 10 Degree of protection: e.g. IP, NEMA
- 11 Permitted ambient temperature ( $T_a$ )
- 12 2-D matrix code
- 13 CE mark, C-Tick
- 14 Flow direction
- 15 Manufacturing date: year-month

### Order code

The measuring device is reordered using the order code.

#### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

### 4.2.3 Symbols on measuring device

| Symbol  | Meaning  |
|---|--|
| <br>A0011194 | <b>WARNING!</b><br>This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. |
| <br>A0011194 | <b>Reference to documentation</b><br>Refers to the corresponding device documentation.   |
| <br>A0011199 | <b>Protective ground connection</b><br>A terminal which must be connected to ground prior to establishing any other connections.           |

## 5 Storage and transport

### 5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→ 📄 79)


### 5.2 Transporting the product

#### **⚠ WARNING**

**Center of gravity of the measuring device is higher than the suspension points of the webbing slings.**

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device from rotating or slipping.
- ▶ Observe the weight specified on the packaging (stick-on label).
- ▶ Observe the transport instructions on the stick-on label on the electronics compartment cover.



A0015606

Observe the following notes during transport:

- Transport the measuring device to the measuring point in the original packaging.
- Lifting gear
  - Webbing slings: Do not use chains, as they could damage the housing.
  - For wood crates, the floor structure enables these to be loaded lengthwise or broadside using a forklift.
- Use the webbing slings to lift the measuring device at the process connections; do not lift at the transmitter housing.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

### 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
  - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
  - or
  - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Dunnage: Paper cushion

## 6 Installation


### 6.1 Installation conditions

No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

#### 6.1.1 Mounting position

##### Mounting location

Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow:  $h \geq 2 \times DN$



A0017061


To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

##### Installation in down pipes

Install a siphon or a vent valve downstream of the sensor in down pipes whose length  $h \geq 5 \text{ m}$  (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime, which could cause air pockets.

 For information on the liner's resistance to partial vacuum ( $\rightarrow$   81)



A0017064


 4 Installation in a down pipe

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe

*Installation in partially filled pipes*

A partially filled pipe with a gradient necessitates a drain-type configuration. The empty pipe detection (EPD) function offers additional protection by detecting empty or partially filled pipes.

- Do not install the sensor at the lowest point in the drain: risk of solids accumulating.
- It is advisable to install a cleaning valve.



A0017063


**Orientation**

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping). An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube.

The measuring device also offers the empty pipe detection function to detect partially filled measuring pipes in the event of outgassing fluids or variable process pressures.

*Vertical*

This is the optimum orientation for self-emptying piping systems and for use in conjunction with empty pipe detection.




A0015591

*Horizontal*

The measuring electrode plane must be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.

- i** With horizontal orientation, empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.



A0016260

5 Horizontal orientation


- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

**Inlet and outlet runs**

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:

- Inlet run  $\geq 5 \times \text{DN}$
- Outlet run  $\geq 2 \times \text{DN}$



A0016275

*Installation dimensions*

 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

**6.1.2 Requirements from environment and process**

**Ambient temperature range**

|             |   |
|-------------|---|
| Transmitter | -40 to +60 °C (-40 to +140 °F)  |
| Sensor      | <ul style="list-style-type: none"> <li>■ Flange material carbon steel: -10 to +60 °C (+14 to +140 °F)</li> <li>■ Flange material stainless steel: -40 to +60 °C (-40 to +140 °F)</li> </ul> |
| Liner       | Do not exceed or fall below the permitted temperature range of the liner ( $\rightarrow$ 80).   |

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

Temperature tables

SI units


| T <sub>a</sub><br>[°C] | T6<br>[85 °C] | T5<br>[100 °C] | T4<br>[135 °C] | T3<br>[200 °C] | T2<br>[300 °C] | T1<br>[450 °C] |
|------------------------|---------------|----------------|----------------|----------------|----------------|----------------|
| 30                     | 50            | 95             | 130            | 150            | 150            | 150            |
| 50                     | -             | 95             | 130            | 150            | 150            | 150            |
| 60                     | -             | 95             | 110            | 110            | 110            | 110            |

US units

| T <sub>a</sub><br>[°F] | T6<br>[185 °F] | T5<br>[212 °F] | T4<br>[275 °F] | T3<br>[392 °F] | T2<br>[572 °F] | T1<br>[842 °F] |
|------------------------|----------------|----------------|----------------|----------------|----------------|----------------|
| 86                     | 122            | 203            | 266            | 302            | 302            | 302            |
| 122                    | -              | 203            | 266            | 302            | 302            | 302            |
| 140                    | -              | 203            | 230            | 230            | 230            | 230            |

System pressure

- Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.
- Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.
- 
  - For information on the liner's resistance to partial vacuum (→  81)
  - For information on the measuring system's resistance to vibration and shock (→  80), (→  80)




A0015594

Vibrations

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

- 
  - For information on the permitted resistance to vibration and shock (→  80), (→  80)



A0016266

 6 Measures to prevent vibration of the device


L > 10 m (33 ft)

## Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.

 The nomogram only applies to liquids with a viscosity similar to that of water.

1. Calculate the ratio of the diameters  $d/D$ .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the  $d/D$  ratio.



A0016359

### 6.1.3 Special mounting instructions

## 6.2 Mounting the measuring device

### 6.2.1 Required tools

#### For sensor

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools

### 6.2.2 Preparing the measuring device


1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.

### 6.2.3 Mounting the sensor

#### **⚠ WARNING**

#### **Danger due to improper process sealing!**

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
  - ▶ Ensure that the gaskets are clean and undamaged.
  - ▶ Install the gaskets correctly.
1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
  2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
  3. If using ground disks, comply with the Installation Instructions provided.
  4. Observe required screw tightening torques (→  23).
  5. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



#### **Mounting the seals**

#### **⚠ CAUTION**

#### **An electrically conductive layer could form on the inside of the measuring tube!**

Risk of measuring signal short circuit.

- ▶ Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

- When mounting the process connections, make sure that the seals concerned are clean and centered correctly.
- For DIN flanges: only use seals according to DIN EN 1514-1.
- For "PFA" lining: additional seals are **always** required.
- For "PTFE" lining: generally additional seals are **not** required.

#### **Mounting the ground cable/ground disks**

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks (→  32).

### Screw tightening torques

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.

*Screw tightening torques for EN 1092-1 (DIN 2501), PN 40/25*

| Nominal diameter<br>[mm] | Pressure rating<br>[bar] | Threaded fasteners<br>[mm] | Max. screw tightening torque [Nm] |     |
|--------------------------|--------------------------|----------------------------|-----------------------------------|-----|
|                          |                          |                            | PTFE                              | PFA |
| 15                       | PN 40                    | 4 × M12                    | 11                                | -   |
| 25                       | PN 40                    | 4 × M12                    | 26                                | 20  |
| 32                       | PN 40                    | 4 × M16                    | 41                                | 35  |
| 40                       | PN 40                    | 4 × M16                    | 52                                | 47  |
| 50                       | PN 40                    | 4 × M16                    | 65                                | 59  |
| 65 <sup>1)</sup>         | PN 16                    | 8 × M16                    | 43                                | 40  |
| 65                       | PN 40                    | 8 × M16                    | 43                                | 40  |
| 80                       | PN 16                    | 8 × M16                    | 53                                | 48  |
| 80                       | PN 40                    | 8 × M16                    | 53                                | 48  |
| 100                      | PN 16                    | 8 × M16                    | 57                                | 51  |
| 100                      | PN 40                    | 8 × M20                    | 78                                | 70  |
| 125                      | PN 16                    | 8 × M16                    | 75                                | 67  |
| 125                      | PN 40                    | 8 × M24                    | 111                               | 99  |
| 150                      | PN 16                    | 8 × M20                    | 99                                | 85  |
| 150                      | PN 40                    | 8 × M24                    | 136                               | 120 |
| 200                      | PN 10                    | 8 × M20                    | 141                               | 101 |
| 200                      | PN 16                    | 12 × M20                   | 94                                | 67  |
| 200                      | PN 25                    | 12 × M24                   | 138                               | 105 |
| 250                      | PN 10                    | 12 × M20                   | 110                               | -   |
| 250                      | PN 16                    | 12 × M24                   | 131                               | -   |
| 250                      | PN 25                    | 12 × M27                   | 200                               | -   |
| 300                      | PN 10                    | 12 × M20                   | 125                               | -   |
| 300                      | PN 16                    | 12 × M24                   | 179                               | -   |
| 300                      | PN 25                    | 16 × M27                   | 204                               | -   |
| 350                      | PN 10                    | 16 × M20                   | 188                               | -   |
| 350                      | PN 16                    | 16 × M24                   | 254                               | -   |
| 350                      | PN 25                    | 16 × M30                   | 380                               | -   |
| 400                      | PN 10                    | 16 × M24                   | 260                               | -   |
| 400                      | PN 16                    | 16 × M27                   | 330                               | -   |
| 400                      | PN 25                    | 16 × M33                   | 488                               | -   |
| 450                      | PN 10                    | 20 × M24                   | 235                               | -   |
| 450                      | PN 16                    | 20 × M27                   | 300                               | -   |
| 450                      | PN 25                    | 20 × M33                   | 385                               | -   |
| 500                      | PN 10                    | 20 × M24                   | 265                               | -   |
| 500                      | PN 16                    | 20 × M30                   | 448                               | -   |

| Nominal diameter<br>[mm] | Pressure rating<br>[bar] | Threaded fasteners<br>[mm] | Max. screw tightening torque [Nm] |     |
|--------------------------|--------------------------|----------------------------|-----------------------------------|-----|
|                          |                          |                            | PTFE                              | PFA |
| 500                      | PN 25                    | 20 × M33                   | 533                               | –   |
| 600                      | PN 10                    | 20 × M27                   | 345                               | –   |
| 600 <sup>1)</sup>        | PN 16                    | 20 × M33                   | 658                               | –   |
| 600                      | PN 25                    | 20 × M36                   | 731                               | –   |

1) Designed acc. to EN 1092-1 (not to DIN 2501)

*Screw tightening torques for ASME B16.5, Class 150/300*

| Nominal diameter |      | Pressure rating<br>[psi] | Threaded fasteners<br>[in] | Max. screw tightening torque [Nm]<br>([lbf · ft]) |          |
|------------------|------|--------------------------|----------------------------|---|----------|
| [mm]             | [in] |                          |                            | PTFE  | PFA      |
| 15               | ½    | Class 150                | 4 × ½                      | 6 (4)   | – (-)    |
| 15               | ½    | Class 300                | 4 × ½                      | 6 (4)   | – (-)    |
| 25               | 1    | Class 150                | 4 × ½                      | 11 (8)  | 10 (7)   |
| 25               | 1    | Class 300                | 4 × 5/8                    | 14 (10)   | 12 (9)   |
| 40               | 1 ½  | Class 150                | 4 × ½                      | 24 (18)   | 21 (15)  |
| 40               | 1 ½  | Class 300                | 4 × ¾                      | 34 (25)   | 31 (23)  |
| 50               | 2    | Class 150                | 4 × 5/8                    | 47 (35)   | 44 (32)  |
| 50               | 2    | Class 300                | 8 × 5/8                    | 23 (17)   | 22 (16)  |
| 80               | 3    | Class 150                | 4 × 5/8                    | 79 (58)   | 67 (49)  |
| 80               | 3    | Class 300                | 8 × ¾                      | 47 (35)   | 42 (31)  |
| 100              | 4    | Class 150                | 8 × 5/8                    | 56 (41)   | 50 (37)  |
| 100              | 4    | Class 300                | 8 × ¾                      | 67 (49)   | 59 (44)  |
| 150              | 6    | Class 150                | 8 × ¾                      | 106 (78)  | 86 (63)  |
| 150              | 6    | Class 300                | 12 × ¾                     | 73 (54)   | 67 (49)  |
| 200              | 8    | Class 150                | 8 × ¾                      | 143 (105)   | 109 (80) |
| 250              | 10   | Class 150                | 12 × 7/8                   | 135 (100)   | – (-)    |
| 300              | 12   | Class 150                | 12 × 7/8                   | 178 (131)   | – (-)    |
| 350              | 14   | Class 150                | 12 × 1                     | 260 (192)   | – (-)    |
| 400              | 16   | Class 150                | 16 × 1                     | 246 (181)   | – (-)    |
| 450              | 18   | Class 150                | 16 × 1 1/8                 | 371 (274)   | – (-)    |
| 500              | 20   | Class 150                | 20 × 1 1/8                 | 341 (252)   | – (-)    |
| 600              | 24   | Class 150                | 20 × 1 ¼                   | 477 (352)   | – (-)    |

*Screw tightening torques for JIS B2220, 10/20K*

| Nominal diameter<br>[mm] | Pressure rating<br>[bar] | Threaded fasteners<br>[mm] | Max. screw tightening torque [Nm] |     |
|--------------------------|--------------------------|----------------------------|-----------------------------------|-----|
|                          |                          |                            | PTFE                              | PFA |
| 25                       | 10K                      | 4 × M16                    | 32                                | 27  |
| 25                       | 20K                      | 4 × M16                    | 32                                | 27  |
| 32                       | 10K                      | 4 × M16                    | 38                                | –   |
| 32                       | 20K                      | 4 × M16                    | 38                                | –   |
| 40                       | 10K                      | 4 × M16                    | 41                                | 37  |

| Nominal diameter<br>[mm] | Pressure rating<br>[bar] | Threaded fasteners<br>[mm] | Max. screw tightening torque [Nm] |     |
|--------------------------|--------------------------|----------------------------|-----------------------------------|-----|
|                          |                          |                            | PTFE                              | PFA |
| 40                       | 20K                      | 4 × M16                    | 41                                | 37  |
| 50                       | 10K                      | 4 × M16                    | 54                                | 46  |
| 50                       | 20K                      | 8 × M16                    | 27                                | 23  |
| 65                       | 10K                      | 4 × M16                    | 74                                | 63  |
| 65                       | 20K                      | 8 × M16                    | 37                                | 31  |
| 80                       | 10K                      | 8 × M16                    | 38                                | 32  |
| 80                       | 20K                      | 8 × M20                    | 57                                | 46  |
| 100                      | 10K                      | 8 × M16                    | 47                                | 38  |
| 100                      | 20K                      | 8 × M20                    | 75                                | 58  |
| 125                      | 10K                      | 8 × M20                    | 80                                | 66  |
| 125                      | 20K                      | 8 × M22                    | 121                               | 103 |
| 150                      | 10K                      | 8 × M20                    | 99                                | 81  |
| 150                      | 20K                      | 12 × M22                   | 108                               | 72  |
| 200                      | 10K                      | 12 × M20                   | 82                                | 54  |
| 200                      | 20K                      | 12 × M22                   | 121                               | 88  |
| 250                      | 10K                      | 12 × M22                   | 133                               | -   |
| 250                      | 20K                      | 12 × M24                   | 212                               | -   |
| 300                      | 10K                      | 16 × M22                   | 99                                | -   |
| 300                      | 20K                      | 16 × M24                   | 183                               | -   |

Screw tightening torques for AS 2129, Table E

| Nominal diameter<br>[mm] | Threaded fasteners<br>[mm] | Max. screw tightening torque<br>[Nm] |
|--------------------------|----------------------------|--------------------------------------|
|                          |                            | PTFE                                 |
| 25                       | 4 × M12                    | 21                                   |
| 50                       | 4 × M16                    | 42                                   |

Screw tightening torques for AS 4087, PN 16

| Nominal diameter<br>[mm] | Threaded fasteners<br>[mm] | Max. screw tightening torque<br>[Nm] |
|--------------------------|----------------------------|--------------------------------------|
|                          |                            | PTFE                                 |
| 50                       | 4 × M16                    | 42                                   |

### 6.3 Post-installation check

|   |                          |
|---|--------------------------|
| Is the device undamaged (visual inspection)?  | <input type="checkbox"/> |
| Does the measuring device conform to the measuring point specifications?<br>For example: <ul style="list-style-type: none"> <li>▪ Process temperature</li> <li>▪ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)</li> <li>▪ Ambient temperature</li> <li>▪ Measuring range</li> </ul> | <input type="checkbox"/> |

|  |                          |
|--|--------------------------|
| Has the correct orientation for the sensor been selected (→  18)? <ul style="list-style-type: none"><li>▪ According to sensor type</li><li>▪ According to medium temperature</li><li>▪ According to medium properties (outgassing, with entrained solids)</li></ul> | <input type="checkbox"/> |
| Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping (→  18)?   | <input type="checkbox"/> |
| Are the measuring point identification and labeling correct (visual inspection)?   | <input type="checkbox"/> |
| Is the device adequately protected from precipitation and direct sunlight?   | <input type="checkbox"/> |
| Have the fixing screws been tightened with the correct tightening torque?  | <input type="checkbox"/> |

## 7 Electrical connection

### 7.1 Connection conditions

#### 7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp (on aluminum housing): Allen screw 3 mm
- For securing screw (for stainless steel housing): open-ended wrench 8 mm
- Wire stripper
- When using stranded cables: Crimping tool for wire end ferrule

#### 7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

##### Electrical safety

In accordance with applicable federal/national regulations.

##### Permitted temperature range

- $-40\text{ °C}$  ( $-40\text{ °F}$ )... $\geq 80\text{ °C}$  ( $176\text{ °F}$ )
- Minimum requirement: cable temperature range  $\geq$  ambient temperature + 20 K

##### Power supply cable

Standard installation cable is sufficient.

##### Signal cable

###### *Modbus RS485*

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

|                                 |  |
|---------------------------------|--|
| <b>Cable type</b>               | A  |
| <b>Characteristic impedance</b> | 135 to 165 $\Omega$ at a measuring frequency of 3 to 20 MHz  |
| <b>Cable capacitance</b>        | <30 pF/m   |
| <b>Wire cross-section</b>       | >0.34 mm <sup>2</sup> (22 AWG)   |
| <b>Cable type</b>               | Twisted pairs  |
| <b>Loop resistance</b>          | $\leq 110\ \Omega/\text{km}$   |
| <b>Signal damping</b>           | Max. 9 dB over the entire length of the cable cross-section  |
| <b>Shielding</b>                | Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant. |

##### Cable diameter

- Cable glands supplied:  
M20  $\times$  1.5 with cable  $\phi 6$  to 12 mm (0.24 to 0.47 in)
- Spring terminals:  
wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

### 7.1.3 Terminal assignment


#### Transmitter

Connection version Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2

Order code for "Output", option **M**

Depending on the housing version, the transmitters can be ordered with terminals or device plugs.

| Order code for "Housing"   | Connection methods available |                       | Possible options for order code "Electrical connection"  |
|--|------------------------------|-----------------------|--|
|  | Output                       | Power supply          |  |
| Option <b>A</b>  | Terminals                    | Terminals             | <ul style="list-style-type: none"> <li>▪ Option <b>A</b>: coupling M20x1</li> <li>▪ Option <b>B</b>: thread M20x1</li> <li>▪ Option <b>C</b>: thread G ½"</li> <li>▪ Option <b>D</b>: thread NPT ½"</li> </ul>   |
| Option <b>A</b>  | Device plug<br>(→ 28)        | Terminals             | <ul style="list-style-type: none"> <li>▪ Option <b>L</b>: plug M12x1 + thread NPT ½"</li> <li>▪ Option <b>N</b>: plug M12x1 + coupling M20</li> <li>▪ Option <b>P</b>: plug M12x1 + thread G ½"</li> <li>▪ Option <b>U</b>: plug M12x1 + thread M20</li> </ul> |
| Option <b>A</b>  | Device plug<br>(→ 28)        | Device plug<br>(→ 28) | Option <b>Q</b> : 2 x plug M12x1   |
| Order code for "Housing":<br>Option <b>A</b> : compact, coated alu |                              |                       |  |



A0019528

7 Modbus RS485 terminal assignment


- 1 Power supply: DC 24 V
- 2 Output: Modbus RS485

| Order code for "Output"  | Terminal number |        |              |        |
|--|-----------------|--------|--------------|--------|
|  | Power supply    |        | Output       |        |
|  | 2 (L-)          | 1 (L+) | 27 (B)       | 26 (A) |
| Option <b>M</b>  | 24 DC V         |        | Modbus RS485 |        |
| Order code for "Output":<br>Option <b>M</b> : Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2 |                 |        |              |        |


### 7.1.4 Pin assignment, device plug

#### Modbus RS485

Supply voltage for Modbus RS485, non-hazardous area and Zone 2/Div. 2 (on the device side)

|  | Pin | Assignment          | Coding | Plug/socket |
|---|-----|---------------------|--------|-------------|
|   | 1   | L+                  | DC24 V | A           |
| 2   |     |                     |        |             |
| 3   |     |                     |        |             |
| 4   | L-  | DC24 V              |        |             |
| 5   |     | Grounding/shielding |        |             |

Modbus RS485, non-hazardous areas and zone 2/Div. 2 (on the device side)

|  | Pin | Assignment          | Coding | Plug/socket |
|---|-----|---------------------|--------|-------------|
|   | 1   |                     |        | B           |
| 2   | A   | Modbus RS485        |        |             |
| 3   |     |                     |        |             |
| 4   | B   | Modbus RS485        |        |             |
| 5   |     | Grounding/shielding |        |             |

### 7.1.5 Shielding and grounding

The shielding and grounding concept requires compliance with the following:

- Electromagnetic compatibility (EMC)
- Explosion protection
- Personal protection equipment
- National installation regulations and guidelines
- Observe cable specification (→ ☰ 27).
- Keep the stripped and twisted lengths of cable shield to the ground terminal as short as possible.
- Seamless cable shielding.

#### Grounding of the cable shield

To comply with EMC requirements:

- Ensure the cable shield is grounded to the potential matching line at multiple points.
- Connect every local ground terminal to the potential matching line.

#### NOTICE

**In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!**

Damage to the bus cable shield.

- ▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.

### 7.1.6 Preparing the measuring device

1. Remove dummy plug if present.
2. **NOTICE!** Insufficient sealing of the housing! Operational reliability of the measuring device could be compromised. Use suitable cable glands corresponding to the degree of protection.  
If measuring device is delivered without cable glands:  
Provide suitable cable gland for corresponding connecting cable (→ ☰ 27).
3. If measuring device is delivered with cable glands:  
Observe cable specification (→ ☰ 27).

## 7.2 Connecting the measuring device

### NOTICE


#### Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

### 7.2.1 Connecting the transmitter

The connection of the transmitter depends on the following order codes:


- Housing version: compact or ultracompact
- Connection version: device plug or terminals



A0019824

8 Device versions and connection versions

- A Housing version: compact, aluminum coated
- 1 Cable entry or device plug for signal transmission
- 2 Cable entry or device plug for supply voltage



A0019823

#### 9 Device versions with connection examples

- 1 Cable
- 2 Device plug for signal transmission
- 3 Device plug for supply voltage

For device version with device plug: only pay attention to Step 6.

1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
2. Depending on the housing version, unscrew or open the housing cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cable in accordance with the terminal assignment or the device plug pin assignment (→ 28).
6. Depending on the device version: tighten the cable glands or plug in the device plug and tighten (→ 28).
7. Enable the terminating resistor if applicable (→ 34).
8. **NOTICE!** Housing degree of protection voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.  
Reverse the removal procedure to reassemble the transmitter.

## 7.2.2 Ensuring potential equalization


### ⚠ CAUTION

**Electrode damage can result in the complete failure of the device!**

- ▶ Make sure that the fluid and sensor have the same electrical potential.
- ▶ Pay attention to internal grounding concepts in the company.
- ▶ Pay attention to the pipe material or grounding.

### Connection examples for standard situations

*Metal, grounded pipe*




10 Potential equalization via measuring tube

### Connection example in special situations

*Unlined and ungrounded metal pipe*

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present



11 Potential equalization via ground terminal and pipe flanges


|                     |   |
|---------------------|---|
| <b>Ground cable</b> | Copper wire, at least 6 mm <sup>2</sup> (0.0093 in <sup>2</sup> ) |
|---------------------|---|

1. Connect both sensor flanges to the pipe flange via a ground cable and ground them.
2. If DN ≤ 300 (12"): Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws. If DN ≥ 350 (14"): Mount the ground cable directly on the metal transport bracket. Observe torques (→ 23).
3. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose.

*Plastic pipe or pipe with insulating liner*

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present



A0016318

12 Potential equalization via ground terminal and ground disks


1. Connect the ground disks to the ground terminal via the ground cable.
2. Connect the ground disks to ground potential.

|                     |   |
|---------------------|---|
| <b>Ground cable</b> | Copper wire, at least 6 mm <sup>2</sup> (0.0093 in <sup>2</sup> ) |
|---------------------|---|

*Pipe with a cathodic protection unit*

This connection method is only used if the following two conditions are met:

- Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment



A0016319

13 Potential equalization and cathodic protection

- 1 Isolation transformer power supply
- 2 Electrically isolated from the pipe
- 3 Capacitor

|                     |   |
|---------------------|---|
| <b>Ground cable</b> | Copper wire, at least 6 mm <sup>2</sup> (0.0093 in <sup>2</sup> ) |
|---------------------|---|


1. Connect the measuring device to the power supply such that it is floating in relation to the protective ground.
2. Install the sensor in the pipe in a way that provides electrical insulation.
3. Connect the two flanges of the pipe to one another via a ground cable.
4. Guide the shield of the signal lines through a capacitor.

## 7.3 Hardware settings

### 7.3.1 Enabling the terminating resistor

To avoid incorrect communication transmission caused by impedance mismatch, connect the Modbus RS485 cable correctly to the start and end of the bus segment.

If the transmitter is used in the non-hazardous area or Zone 2/Div. 2




14 Terminating resistor can be enabled via DIP switch on the main electronics module

## 7.4 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").




5. Insert dummy plugs into unused cable entries.

## 7.5 Post-connection check

|  |                          |
|--|--------------------------|
| Are cables or the device undamaged (visual inspection)?  | <input type="checkbox"/> |
| Do the cables comply with the requirements (→ 27)?   | <input type="checkbox"/> |
| Do the cables have adequate strain relief?   | <input type="checkbox"/> |
| Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→ 34)?   | <input type="checkbox"/> |
| Depending on the device version: are all the device plugs firmly tightened (→ 30)?   | <input type="checkbox"/> |
| <ul style="list-style-type: none"> <li>▪ Does the supply voltage match the specifications on the transmitter nameplate (→ 77)?</li> <li>▪ For device version with Modbus RS485 intrinsically safe: does the supply voltage match the specifications on the nameplate of the Safety Barrier Promass 100 (→ 77)?</li> </ul>          | <input type="checkbox"/> |
| Is the terminal assignment or the pin assignment of the device plug (→ 28) correct?  | <input type="checkbox"/> |
| <ul style="list-style-type: none"> <li>▪ If supply voltage is present, is the power LED on the electronics module of the transmitter lit green (→ 10)?</li> <li>▪ For device version with Modbus RS485 intrinsically safe, if supply voltage is present, is the power LED on the Safety Barrier Promass 100 lit (→ 10)?</li> </ul> | <input type="checkbox"/> |
| Is the potential equalization established correctly (→ 32)?  | <input type="checkbox"/> |
| Depending on the device version, is the securing clamp or fixing screw firmly tightened?   | <input type="checkbox"/> |

## 8 Operation options

### 8.1 Overview of operation options




- 1 Computer with "FieldCare" operating tool via Commubox FXA291 and service interface (CDI)
- 2 Control system (e.g. PLC)

## 8.2 Structure and function of the operating menu

### 8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters



 15 Taking the example of the "FieldCare" operating tool

A0016726-EN

### 8.2.2 Operating philosophy


The individual parts of the operating menu are assigned to certain user roles. Each user role corresponds to typical tasks within the device lifecycle.

| Menu            |                   | User role and tasks   | Content/meaning   |
|-----------------|-------------------|---|---|
| Display/operat. | task-oriented     | <b>Role "Operator", "Maintenance"</b><br>Tasks during operation:<br>Reading measured values   | Resetting and controlling totalizers  |
| Setup           |                   | <b>"Maintenance" role</b><br>Commissioning:<br><ul style="list-style-type: none"> <li>■ Configuration of the measurement</li> <li>■ Configuration of the communication interface</li> </ul>   | Submenus for fast commissioning:<br><ul style="list-style-type: none"> <li>■ Setting the individual system units</li> <li>■ Defining the medium</li> <li>■ Configuration of the digital communication interface</li> <li>■ Configuring the low flow cut off</li> </ul> "Advanced setup" submenu:<br><ul style="list-style-type: none"> <li>■ For more customized configuration of the measurement (adaptation to special measuring conditions)</li> <li>■ Configuration of totalizers</li> </ul>  |
| Diagnostics     |                   | <b>"Maintenance" role</b><br>Fault elimination:<br><ul style="list-style-type: none"> <li>■ Diagnostics and elimination of process and device errors</li> <li>■ Measured value simulation</li> </ul>  | Contains all parameters for error detection and analyzing process and device errors:<br><ul style="list-style-type: none"> <li>■ <b>"Diagnostic list" submenu</b><br/>Contains up to 5 currently pending diagnostic messages.</li> <li>■ <b>"Event logbook" submenu</b><br/>Contains 20 event messages that have occurred.</li> <li>■ <b>"Device information" submenu</b><br/>Contains information for identifying the device.</li> <li>■ <b>"Measured values" submenu</b><br/>Contains all current measured values.</li> <li>■ <b>"Simulation" submenu</b><br/>Is used to simulate measured values or output values.</li> <li>■ <b>"Device reset" submenu</b><br/>Resets the device configuration to certain settings</li> </ul>   |
| Expert          | function-oriented | Tasks that require detailed knowledge of the function of the device:<br><ul style="list-style-type: none"> <li>■ Commissioning measurements under difficult conditions</li> <li>■ Optimal adaptation of the measurement to difficult conditions</li> <li>■ Detailed configuration of the communication interface</li> <li>■ Error diagnostics in difficult cases</li> </ul> | Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:<br><ul style="list-style-type: none"> <li>■ <b>"System" submenu</b><br/>Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication.</li> <li>■ <b>"Sensor" submenu</b><br/>Contains all parameters for configuring the measurement.</li> <li>■ <b>"Communication" submenu</b><br/>Contains all parameters for configuring the digital communication interface.</li> <li>■ <b>"Application" submenu</b><br/>Contains all parameters for configuring the functions that go beyond the actual measurement (e.g. totalizer).</li> <li>■ <b>"Diagnostics" submenu</b><br/>Contains all parameters for error detection and analyzing process and device errors and for device simulation.</li> </ul> |

## 8.3 Access to the operating menu via the operating tool

### 8.3.1 Connecting the operating tool

#### Via service interface (CDI)



- 1 Service interface (CDI) of the measuring device  
 2 Commubox FXA291  
 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

### 8.3.2 FieldCare

#### Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

Service interface CDI (→ 39)

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For details, see Operating Instructions BA00027S and BA00059S

#### Source for device description files

See data (→ 41)

#### Establishing a connection


Via service interface (CDI)

1. Start FieldCare and launch the project.
2. In the network: Add a device.
  - ↳ The **Add device** window opens.
3. Select the **CDI Communication FXA291** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication FXA291** and select the **Add device** option in the context menu that opens.

5. Select the desired device from the list and press **OK** to confirm.
6. Establish the online connection to the device.

 For details, see Operating Instructions BA00027S and BA00059S

**User interface**



- 1 Header
- 2 Picture of device
- 3 Device tag
- 4 Status area with status signal (→ 60)
- 5 Display area for current measured values
- 6 Event list with additional functions such as save/load, events list and document creation
- 7 Navigation area with operating menu structure
- 8 Working area

## 9 System integration

### 9.1 Overview of device description files

#### 9.1.1 Current version data for the device

|                                  |          |   |
|----------------------------------|----------|---|
| Firmware version                 | 01.02.00 | <ul style="list-style-type: none"> <li>▪ On the title page of the Operating instructions</li> <li>▪ On transmitter nameplate(→  12)</li> <li>▪ Parameter <b>firmware version</b><br/>Diagnostics → Device info → Firmware version</li> </ul> |
| Release date of firmware version | 04.2013  | ---   |

#### 9.1.2 Operating tools

The suitable device description file for the operating tool is listed in the table below, along with information on where the file can be acquired.

| Operating tool via service interface (CDI) | Sources for obtaining device descriptions   |
|--|---|
| FieldCare                                  | <ul style="list-style-type: none"> <li>▪ <a href="http://www.endress.com">www.endress.com</a> → Download Area</li> <li>▪ CD-ROM (contact Endress+Hauser)</li> <li>▪ DVD (contact Endress+Hauser)</li> </ul> |

## 9.2 Modbus RS485 information

### 9.2.1 Function codes

Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:

| Code | Name                  | Description   | Application   |
|------|-----------------------|---|---|
| 03   | Read holding register | Master reads one or more Modbus registers from the device.<br>A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes<br> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result. | Read device parameters with read and write access<br><br>Example:<br>Read volume flow |
| 04   | Read input register   | Master reads one or more Modbus registers from the device.<br>A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes<br> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result. | Read device parameters with read access<br><br>Example:<br>Read totalizer value       |

| Code | Name                          | Description  | Application  |
|------|-------------------------------|--|--|
| 06   | Write single registers        | Master writes a new value to <b>one</b> Modbus register of the measuring device.<br> Use function code 16 to write multiple registers with just 1 telegram.   | Write only 1 device parameter<br>Example: reset totalizer  |
| 08   | Diagnostics                   | Master checks the communication connection to the measuring device.<br>The following "Diagnostics codes" are supported:<br><ul style="list-style-type: none"> <li>▪ Sub-function 00 = Return query data (loopback test)</li> <li>▪ Sub-function 02 = Return diagnostics register</li> </ul>  |  |
| 16   | Write multiple registers      | Master writes a new value to multiple Modbus registers of the device.<br>A maximum of 120 consecutive registers can be written with 1 telegram.<br> If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map (→  42) | Write multiple device parameters   |
| 23   | Read/Write multiple registers | Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram.<br>Write access is executed <b>before</b> read access.   | Write and read multiple device parameters<br>Example:<br><ul style="list-style-type: none"> <li>▪ Read mass flow</li> <li>▪ Reset totalizer</li> </ul> |

 Broadcast messages are only allowed with function codes 06, 16 and 23.

### 9.2.2 Register information

 For an overview on Modbus-specific information of the individual device parameters, please refer to the additional document on Modbus RS485 register information (→  87)

### 9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to 5 ms

### 9.2.4 Modbus data map

#### Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.

### Structure of the Modbus data map

The Modbus data map consists of two data sets:

- Scan list: Configuration area  
The device parameters to be grouped are defined in a list in that their Modbus RS485 register addresses are entered in the list.
- Data area  
The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.

 For an overview of device parameters with their individual Modbus register address, please refer to the additional document on Modbus RS485 register information

### Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

|                                    |  |
|------------------------------------|--|
| <b>Max. entries</b>                | 16 device parameters   |
| <b>Supported device parameters</b> | Only parameters with the following characteristics are supported: <ul style="list-style-type: none"> <li>■ Access type: read or write access</li> <li>■ Data type: float or integer</li> </ul> |

#### Configuring the scan list via FieldCare

Carried out using the operating menu of the measuring device:  
Expert → Communication → Modbus data map → Scan list register 0 -15

| Scan list |                        |
|-----------|------------------------|
| No.       | Configuration register |
| 0         | Scan list register 0   |
| ...       | ...                    |
| 15        | Scan list register 15  |

#### Configuring the scan list via Modbus RS485

Carried out using register addresses 5001 - 5016

| Scan list |                       |           |                        |
|-----------|-----------------------|-----------|------------------------|
| No.       | Modbus RS485 register | Data type | Configuration register |
| 0         | 5001                  | Integer   | Scan list register 0   |
| ...       | ...                   | Integer   | ...                    |
| 15        | 5016                  | Integer   | Scan list register 15  |

### Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.

|                                   |                                  |
|-----------------------------------|----------------------------------|
| <b>Master access to data area</b> | Via register addresses 5051-5081 |
|-----------------------------------|----------------------------------|

| <b>Data area</b>  |                              |                   |                 |
|---|------------------------------|-------------------|-----------------|
| <b>Device parameter value</b>   | <b>Modbus RS485 register</b> | <b>Data type*</b> | <b>Access**</b> |
| Value of scan list register 0   | 5051                         | Integer/float     | Read/write      |
| Value of scan list register 1   | 5053                         | Integer/float     | Read/write      |
| Value of scan list register ...   | ...                          | ...               | ...             |
| Value of scan list register 15  | 5081                         | Integer/float     | Read/write      |
| * Data type depends on the device parameters entered in the scan list.<br>** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area. |                              |                   |                 |

## 10 Commissioning

### 10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-mounting check" checklist (→ 📄 25)
- "Post-connection check" checklist (→ 📄 35)


### 10.2 Establishing a connection via FieldCare

- For FieldCare connection (→ 📄 39)
- For establishing a connection via FieldCare (→ 📄 39)
- For FieldCare user interface (→ 📄 40)

### 10.3 Configuring the measuring device

The **Setup** menu with its submenus contains all parameters needed for standard operation.

*Structure of the "Setup" menu*




#### 10.3.1 Setting the system units

In the **System units** submenu, you can configure the units of all measured values.

##### Navigation path

"Setup" menu → Advanced setup → System units

##### Structure of the submenu



|  |                       |
|--|-----------------------|
|  | Corrected volume unit |
|--|-----------------------|

### Parameter overview with brief description

| Parameter                  | Description  | Options          | Factory setting   |
|----------------------------|--|------------------|---|
| Volume flow unit           | Select the unit for volume flow.<br><i>Result</i><br>The selected unit applies for:<br>- Low flow cut off<br>- Simulation process variable           | Unit choose list | Country-dependent:<br>▪ l/h<br>▪ gal/min                  |
| Volume unit                | Select the unit for volume.<br><i>Result</i><br>The selected unit applies for:<br>Value per pulse  | Unit choose list | Country-dependent:<br>▪ m <sup>3</sup><br>▪ gal           |
| Conductivity unit          | Select the unit for conductivity.<br><i>Result</i><br>The selected unit applies for:<br>Simulation process variable                                  | Unit choose list | µS/cm   |
| Mass flow unit             | Select the unit for mass flow.<br><i>Result</i><br>The selected unit applies for:<br>- Low flow cut off<br>- Simulation process variable             | Unit choose list | Country-dependent:<br>▪ kg/h<br>▪ lbs/min                 |
| Mass unit                  | Select the unit for mass.<br><i>Result</i><br>The selected unit applies for:<br>Value per pulse  | Unit choose list | Country-dependent:<br>▪ kg<br>▪ lbs                       |
| Density unit               | Select the unit for density.<br><i>Result</i><br>The selected unit applies for:<br>Fixed density   | Unit choose list | Country-dependent<br>▪ kg/l<br>▪ g/cc                     |
| Temperature unit           | Select the unit for temperature.<br><i>Result</i><br>The selected unit applies for:<br>Diagnostics: Min/max values                                   | Unit choose list | Country-dependent:<br>▪ °C (Celsius)<br>▪ °F (Fahrenheit) |
| Corrected volume flow unit | Select the unit for corrected volume flow.<br><i>Result</i><br>The selected unit applies for:<br>- Low flow cut off<br>- Simulation process variable | Unit choose list | Country-dependent:<br>▪ NI/h<br>▪ Sgal/min                |
| Corrected volume unit      | Select the unit for standard volume.<br><i>Result</i><br>The selected unit applies for:<br>- Low flow cut off<br>- Simulation process variable       | Unit choose list | Country-dependent:<br>▪ Nm <sup>3</sup><br>▪ Sgal         |


### 10.3.2 Configuring communication interface

The **Communication** submenu guides you systematically through all parameters that must be configured for selecting and setting the communication interface.

#### Navigation path

"Setup" menu → Communication

**Structure of the submenu**



**Parameter overview with brief description**

| Parameter          | Description                        | Selection/<br>User entry   | Factory setting |
|--------------------|------------------------------------|--|-----------------|
| Bus address        | Enter device address.              | 1 to 247   | 247             |
| Baud rate          | Define data transfer speed.        | Baud rate list<br>box(→ 76)  | 19 200 BAUD     |
| Data transfer mode | Select data transfer mode.         | <ul style="list-style-type: none"> <li>▪ ASCII<br/>Transmission of data in the form of readable ASCII characters. Error protection via LRC.</li> <li>▪ RTU<br/>Transmission of data in binary form. Error protection via CRC16.</li> </ul>   | RTU             |
| Parity             | Select parity bits.                | <p><b>ASCII picklist</b></p> <ul style="list-style-type: none"> <li>▪ 0 = even</li> <li>▪ 1 = odd</li> </ul> <p><b>RTU picklist</b></p> <ul style="list-style-type: none"> <li>▪ 0 = even</li> <li>▪ 1 = odd</li> <li>▪ 2 = no parity bit/1 stop bit</li> <li>▪ 3 = no parity bit/2 stop bits</li> </ul> | Even            |
| Byte order         | Select byte transmission sequence. | <ul style="list-style-type: none"> <li>▪ 0-1-2-3</li> <li>▪ 3-2-1-0</li> <li>▪ 1-0-3-2</li> <li>▪ 2-3-0-1</li> </ul>   | 1-0-3-2         |

| Parameter                  | Description  | Selection/<br>User entry   | Factory setting |
|----------------------------|--|--|-----------------|
| Assign diagnostic behavior | Select diagnostic behavior for MODBUS communication.   | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Alarm or warning</li> <li>▪ Warning</li> <li>▪ Alarm</li> </ul>  | Alarm           |
| Failure mode               | Select measured value output behavior when a diagnostic message occurs via Modbus communication.<br><br> This parameter operates in accordance with the option selected in the <b>Assign diagnostic behavior</b> parameter. | <ul style="list-style-type: none"> <li>▪ NaN value</li> <li>▪ Last valid value</li> </ul>  NaN = not a number | NaN value       |


### 10.3.3 Configuring the low flow cut off

The **Low flow cut off** submenu contains parameters that have to be set for configuring the low flow cut off.

#### Navigation path

"Setup" menu → Low flow cut off

#### Structure of the submenu




#### Parameter overview with brief description

| Parameter                  | Description   | Selection/input  | Factory setting |
|----------------------------|---|--|-----------------|
| Assign process variable    | Select process variable for low flow cut off.                                 | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Corrected volume flow</li> </ul> | Volume flow     |
| On value                   | Enter the on value for low flow cut off.                                      | Positive floating-point number   | 0               |
| Off value                  | Enter the off value for low flow cut off.                                     | 0 to 100 %   | 50 %            |
| Pressure shock suppression | Enter time frame for signal suppression (= active pressure shock suppression) | 0 to 100 s   | 0 s             |

### 10.3.4 Configuring empty pipe detection

The **Empty pipe detection (EPD)** submenu contains parameters that have to be set for configuring empty pipe detection.

#### Structure of the submenu



#### Parameter overview with brief description

| Parameter                          | Description                                      | Selection/input   | Factory setting |
|------------------------------------|--|---|-----------------|
| Empty pipe detection               | Switch empty pipe detection on and off.          | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>   | Off             |
| New adjustment                     | Select the type of adjustment.                   | <ul style="list-style-type: none"> <li>▪ Cancel</li> <li>▪ Empty pipe adjustment</li> <li>▪ Full pipe adjustment</li> </ul> | Cancel          |
| Progress                           | The progress is displayed                        | –   | –               |
| Switch point empty pipe detection  | Enter the switch point for empty pipe detection. | 1 to 99 %   | 10 %            |
| Response time empty pipe detection | Enter the time interval                          | 0 to 100 s  | 1 s             |


## 10.4 Advanced settings

The **Advanced setup** menu with its submenus contains all parameters needed for specific settings.

### Navigation path

"Setup" menu → Advanced setup

Overview of the parameters and submenus in the "Advanced setup" menu



### 10.4.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

### Navigation path

"Setup" menu → Advanced setup → Sensor adjustment

### Structure of the submenu



### Parameter overview with brief description

| Parameter              | Description  | Options   | Factory setting         |
|------------------------|--|---|-------------------------|
| Installation direction | Change the sign of the direction of flow of the fluid. | <ul style="list-style-type: none"> <li>▪ Flow in arrow direction</li> <li>▪ Flow against arrow direction</li> </ul> | Flow in arrow direction |


### 10.4.2 Configuring the totalizer

You can configure each totalizer in the three submenus **Totalizer 1-3**.

### Navigation path

"Setup" menu → Advanced setup → Totalizer 1-3

### Structure of the submenu



|  |              |
|--|--------------|
|  | Failure mode |
|--|--------------|

**Parameter overview with brief description**

| Parameter                | Prerequisite   | Description   | Selection/<br>User entry   | Factory setting  |
|--------------------------|--|---|--|--|
| Assign process variable  | -  | Select process variable for totalizer.<br><i>Result</i><br>The selection determines the choose list of the <b>Unit</b> parameter. | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Corrected volume flow</li> </ul> | Volume flow  |
| Mass unit                |  | Select the unit for mass.<br><i>Result</i><br>The selected unit is taken from:<br>Mass flow unit                                  | Unit choose list   |  |
| Volume unit              |  | Select the unit for volume.<br><i>Result</i><br>The selected unit is taken from:<br>Volume flow unit                              | Unit choose list   |  |
| Corrected volume unit    |  | Select the unit for standard volume.<br><i>Result</i><br>The selected unit is taken from:<br>Corrected volume flow unit           | Unit choose list   | Country-dependent: <ul style="list-style-type: none"> <li>▪ NI</li> <li>▪ Scf</li> </ul> |
| Totalizer operation mode | One of the following options is selected in the <b>Assign process variable</b> parameter: <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul> | Select totalizer calculation mode.  | <ul style="list-style-type: none"> <li>▪ Net flow total</li> <li>▪ Forward flow total</li> <li>▪ Reverse flow total</li> </ul>       | Net flow total   |
| Failure mode             | One of the following options is selected in the <b>Assign process variable</b> parameter: <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul> | Specify the behavior of the totalizer in the event of a device alarm.   | <ul style="list-style-type: none"> <li>▪ Stop</li> <li>▪ Actual value</li> <li>▪ Last valid value</li> </ul>                         | Stop   |

**10.4.3 Performing electrode cleaning**


The parameters of the electrode cleaning circuit can be configured in the **Electrode cleaning circuit (ECC)** submenu.

**Navigation path**

"Setup" menu → Advanced setup → Electrode cleaning circuit

 The submenu is only available if the device was ordered with electrode cleaning.

**Structure of the submenu**



|  |                    |
|--|--------------------|
|  | ECC duration       |
|  | ECC recovery time  |
|  | ECC cleaning cycle |
|  | ECC polarity       |

### Parameter overview with brief description

| Parameter                  | Prerequisite   | Description  | Selection/<br>input  | Factory<br>setting |
|----------------------------|--|--|--|--------------------|
| Electrode cleaning circuit |  | Enable the cyclic electrode cleaning circuit.  | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>            | Off                |
| ECC duration               | The following option is selected in the <b>Electrode cleaning circuit</b> parameter:<br>On | Specify the cleaning duration of the electrode cleaning circuit.   | 1 to 30 s  | 2 s                |
| ECC recovery time          | The following option is selected in the <b>Electrode cleaning circuit</b> parameter:<br>On | Specify the recovery time after electrode cleaning to prevent fluctuations in the signal outputs.<br> The last flow value measured before the cleaning is retained. | 1 to 600 s   | 60 s               |
| ECC cleaning cycle         | The following option is selected in the <b>Electrode cleaning circuit</b> parameter:<br>On | Specify the cleaning cycle of the electrode cleaning circuit.  | 30 to 10 080 min   | 30 min             |
| ECC polarity               | The following option is selected in the <b>Electrode cleaning circuit</b> parameter:<br>On | Select the polarity of the electrode cleaning circuit.   | <ul style="list-style-type: none"> <li>▪ Negative</li> <li>▪ Positive</li> </ul> | Positive           |

## 10.5 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

### Navigation path

"Diagnostics" menu → Simulation

|                   |   |                                    |
|-------------------|---|------------------------------------|
| <b>Simulation</b> | → | Assign simulation process variable |
|                   |   | Value process variable             |
|                   |   | Simulation device alarm            |

### 10.5.1 Parameter overview with brief description

| Parameter                          | Prerequisite   | Description   | Selection/<br>User entry  | Factory setting |
|------------------------------------|--|---|---|-----------------|
| Assign simulation process variable | -  | Select a process variable for the simulation process that is activated. | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Corrected volume flow</li> <li>▪ Conductivity</li> <li>▪ Corrected conductivity</li> <li>▪ Temperature</li> </ul> | Off             |
| Value process variable             | A process variable is selected in the <b>Assign simulation process variable</b> parameter. | Enter the simulation value for the selected process variable.           | Depends on the process variable selected  | -               |
| Simulation device alarm            | -  | Switch the device alarm on and off.                                     | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>   | Off             |

## 10.6 Protecting settings from unauthorized access

The following option exists for protecting the configuration of the measuring device from unintentional modification after commissioning: Write protection via write protection switch


### 10.6.1 Write protection via write protection switch

The write protection switch makes it possible to block write access to the entire operating menu with the exception of the following parameters:

- External pressure
- External temperature
- Reference density
- All parameters for configuring the totalizer

The parameter values are now read only and cannot be edited any more:

- Via service interface (CDI)
- Via Modbus RS485



A0017954

1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
2. Depending on the housing version, unscrew or open the housing cover.
3. Setting the write protection switch on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch on the main electronics module to the OFF position (factory setting) disables the hardware write protection.

- ↳ If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter (→  55); if disabled, no option is displayed in the **Locking status** parameter (→  55)
4. Reverse the removal procedure to reassemble the transmitter.

# 11 Operation

## 11.1 Read device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

### Navigation path

"Display/operation" menu → Locking status

*Function scope of "Locking status" parameter*

| Options            | Description  |
|--------------------|--|
| Hardware locked    | The write protection switch (DIP switch) for hardware locking is activated on the main electronics module. This prevents write access to the parameters (→ 53).  |
| Temporarily locked | Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc). Once the internal processing has been completed, the parameters can be changed once again. |

## 11.2 Reading measured values

You can read all measured values using the **Measured values** menu.

### Navigation path

Diagnostics → Measured values


### 11.2.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

### Navigation path

"Diagnostics" menu → Measured values → Process variables

### Structure of the submenu



### Parameter overview with brief description

| Parameter    | Description                                  | Display                         |
|--------------|--|---------------------------------|
| Volume flow  | Displays the current volume flow             | Floating-point number with sign |
| Mass flow    | Displays the mass flow currently calculated  | Floating-point number with sign |
| Conductivity | Displays the current electrical conductivity | Floating-point number           |

| Parameter              | Description   | Display                         |
|------------------------|---|---------------------------------|
| Corrected volume flow  | Displays the calculated corrected volume flow             | Floating-point number with sign |
| Corrected conductivity | Displays the electrical conductivity currently calculated | Floating-point number           |


### 11.2.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

#### Navigation path

"Diagnostics" menu → Measured values → Totalizer

#### Structure of the submenu



#### Parameter overview with brief description

| Parameter              | Prerequisite   | Description                                   | Display                         |
|------------------------|--|---|---------------------------------|
| Totalizer value 1-3    | One of the following options is selected in the <b>Assign process variable</b> parameter of the <b>Totalizer 1-3</b> submenu: <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul> | Displays the current totalizer counter value. | Floating point number with sign |
| Totalizer overflow 1-3 | One of the following options is selected in the <b>Assign process variable</b> parameter of the <b>Totalizer 1-3</b> submenu: <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul> | Displays the current totalizer overflow.      | Integer                         |

## 11.3 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (→ 45)
- Advanced settings using the **Advanced setup** menu (→ 50)

## 11.4 Performing a totalizer reset

In the **Operation** submenu, 2 parameters with various options for resetting the three totalizers are available:

- Control totalizer 1-3
- Reset all totalizers

### Navigation path

"Display/operat." menu → Operation


#### Function scope of the "Control totalizer" parameter

| Options           | Description   |
|-------------------|---|
| Totalize          | The totalizer is started.   |
| Reset + hold      | The totaling process is stopped and the totalizer is reset to 0.  |
| Preset + hold     | The totaling process is stopped and the totalizer is set to the defined start value in the <b>Preset</b> parameter.   |
| Reset + totalize  | The totalizer is reset to 0 and the totaling process is restarted.  |
| Preset + totalize | The totalizer is set to the defined start value in the <b>Preset</b> parameter and the totaling process is restarted. |

#### Function scope of the "Reset all totalizers" parameter

| Options          | Description  |
|------------------|--|
| Reset + totalize | Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized. |

#### "Operation" submenu



*Parameter overview with brief description*

| Parameter             | Prerequisite  | Description                          | Selection/<br>User entry   | Factory setting |
|-----------------------|---|--------------------------------------|--|-----------------|
| Control totalizer 1-3 | A process variable is selected in the <b>Assign process variable</b> parameter of the <b>Totalizer 1-3</b> submenu. | Control totalizer value.             | <ul style="list-style-type: none"> <li>▪ Totalize</li> <li>▪ Reset + hold</li> <li>▪ Preset + hold</li> <li>▪ Reset + totalize</li> <li>▪ Preset + totalize</li> </ul> | Totalize        |
| Preset value 1-3      | A process variable is selected in the <b>Assign process variable</b> parameter of the <b>Totalizer 1-3</b> submenu. | Specify start value for totalizer.   | Floating-point number with sign  |                 |
| Reset all totalizers  | -   | Reset all totalizers to 0 and start. | <ul style="list-style-type: none"> <li>▪ Cancel</li> <li>▪ Reset + totalize</li> </ul>   | Cancel          |

## 12 Diagnostics and troubleshooting

### 12.1 General troubleshooting

*For output signals*

| Problem   | Possible causes  | Remedy   |
|---|--|--|
| Green power LED on the main electronics module of the transmitter is dark | Supply voltage does not match that specified on the nameplate.     | Apply the correct supply voltage (→  30). |
| Green power LED on the main electronics module of the transmitter is dark | Power supply cable connected incorrectly                           | Check the terminal assignment .  |
| Green power LED on Safety Barrier Promass 100 is dark                     | Supply voltage does not match that specified on the nameplate.     | Apply the correct supply voltage (→  30). |
| Green power LED on Safety Barrier Promass 100 is dark                     | Power supply cable connected incorrectly                           | Check the terminal assignment .  |
| Device measures incorrectly.  | Configuration error or device is operated outside the application. | 1. Check and correct parameter configuration.<br>2. Observe limit values specified in the "Technical Data".                |

*For access*

| Problem                             | Possible causes   | Remedy   |
|-------------------------------------|---|--|
| No write access to parameters       | Hardware write protection enabled   | Set the write protection switch on the main electronics module to the OFF position (→  53).       |
| No connection via Modbus RS485      | Modbus RS485 bus cable connected incorrectly                                      | Check the terminal assignment .  |
| No connection via Modbus RS485      | Device plug connected incorrectly   | Check the pin assignment of the device plug (→  28).  |
| No connection via Modbus RS485      | Modbus RS485 cable incorrectly terminated   | Check terminating resistor (→  34).   |
| No connection via Modbus RS485      | Incorrect settings for the communication interface                                | Check the Modbus RS485 configuration (→  46).   |
| No connection via service interface | Incorrect configuration of USB interface on PC or driver not installed correctly. | Observe the documentation for the Commubox.<br> FXA291: Document "Technical Information" TI00405C |

### 12.2 Diagnostic information via light emitting diodes

#### 12.2.1 Transmitter

Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.

| LED   | Color | Meaning                           |
|-------|-------|-----------------------------------|
| Power | Off   | Supply voltage is off or too low. |
|       | Green | Supply voltage is ok.             |

|               |                |   |
|---------------|----------------|---|
| Alarm         | Off            | Device status is ok.  |
|               | Flashing red   | A device error of diagnostic behavior "Warning" has occurred.   |
|               | Red            | <ul style="list-style-type: none"> <li>■ A device error of diagnostic behavior "Alarm" has occurred.</li> <li>■ Boot loader is active.</li> </ul> |
| Communication | Flashing white | Modbus RS485 communication is active.   |

## 12.3 Diagnostic information in FieldCare

### 12.3.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

1 Status area with status signal (→ 60)

2 Diagnostic information (→ 61)

3 Remedy information with Service ID

- i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
- Via parameters
  - Via submenu (→ 64)

### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).


| Symbol                      | Meaning   |
|-----------------------------|---|
| <br><small>A0017271</small> | <b>Failure</b><br>A device error has occurred. The measured value is no longer valid. |
| <br><small>A0017278</small> | <b>Function check</b><br>The device is in service mode (e.g. during a simulation).    |

| Symbol  | Meaning   |
|---|---|
| <br>A0017277 | <b>Out of specification</b><br>The device is operated:<br>Outside its technical specification limits (e.g. outside the process temperature range) |
| <br>A0017276 | <b>Maintenance required</b><br>Maintenance is required. The measured value is still valid.  |

 The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



### 12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page  
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu  
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
  - ↳ A tool tip with remedy information for the diagnostic event appears.

## 12.4 Diagnostic information via communication interface

### 12.4.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270

 For an overview of diagnostic events with diagnosis number and diagnosis code (→  63)

### 12.4.2 Configuring error response mode

Error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

**Navigation path**

"Setup" menu → Communication

*Parameter overview with brief description*

| Parameter                  | Description  | Options  | Factory setting |
|----------------------------|--|--|-----------------|
| Assign diagnostic behavior | Select diagnostic behavior for MODBUS communication.   | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ Alarm or warning</li> <li>▪ Warning</li> <li>▪ Alarm</li> </ul>  | Alarm           |
| Failure mode               | Select measured value output behavior when a diagnostic message occurs via Modbus communication.<br><br> This parameter operates in accordance with the option selected in the <b>Assign diagnostic behavior</b> parameter. | <ul style="list-style-type: none"> <li>▪ NaN value</li> <li>▪ Last valid value</li> </ul>  NaN ≙ not a number | NaN value       |

## 12.5 Adapting the diagnostic information

### 12.5.1 Adapting the diagnostic behavior

Each diagnostic number is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostic numbers via the **Diagnostic no. xxx** parameter.

**Navigation path**

"Expert" menu → System → Diagnostic handling → Diagnostic behavior → Assign behavior of diagnostic no. xxx

You can assign the following options to the diagnostic number as the diagnostic behavior:

| Options            | Description   |
|--------------------|---|
| Alarm              | Measurement is interrupted. Measured value output via Modbus RS485 and totalizers assume the defined alarm condition. A diagnostic message is generated.                                |
| Warning            | Measurement is resumed. Measured value output via Modbus RS485 and totalizers are not affected. A diagnostic message is generated.  |
| Logbook entry only | The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display. |
| Off                | The diagnostic event is ignored, and no diagnostic message is generated or entered.   |

## 12.6 Overview of diagnostic information

 The amount of diagnostic information increases if the measuring device has one or more application packages.

### *Diagnostics for the sensor*

| Diagnostic number | Short text        | Remedial measures   | Status signal from the factory | Diagnostic behavior from the factory |
|-------------------|-------------------|---|--------------------------------|--------------------------------------|
| 062               | Sensor connection | 1. Check the sensor connections.<br>2. Contact service.           | F                              | Alarm                                |
| 082               | Data storage      | 1. Change main electronic module.<br>2. Change sensor.            | F                              | Alarm                                |
| 083               | Memory content    | 1. Restart device.<br>2. Restore S-DAT data.<br>3. Change sensor. | F                              | Alarm                                |

\* Diagnostic behavior can be changed: "Adapting the diagnostic behavior" section (→  62)

### *Diagnostics for the electronics*

| Diagnostic number | Short text              | Remedial measures   | Status signal from the factory | Diagnostic behavior from the factory |
|-------------------|-------------------------|---|--------------------------------|--------------------------------------|
| 242               | Software incompatible   | 1. Check software.<br>2. Flash or change main electronic module.                                | F                              | Alarm                                |
| 261               | Electronic modules      | 1. Restart device.<br>2. Check electronic modules.<br>3. Change I/O module or main electronics. | F                              | Alarm                                |
| 270               | Main electronic failure | Change main electronic module.  | F                              | Alarm                                |
| 271               | Main electronic failure | 1. Restart device.<br>2. Change main electronic module.   | F                              | Alarm                                |
| 272               | Main electronic failure | 1. Restart device.<br>2. Contact service.   | F                              | Alarm                                |
| 273               | Main electronic failure | Replace electronics.  | F                              | Alarm                                |
| 311               | Electronic failure      | 1. Transfer data or reset device.<br>2. Contact service.  | F                              | Alarm                                |

\* Diagnostic behavior can be changed: "Adapting the diagnostic behavior" section (→  62)

### *Diagnostics for the configuration*

| Diagnostic number | Short text               | Remedial measures   | Status signal from the factory | Diagnostic behavior from the factory |
|-------------------|--------------------------|---|--------------------------------|--------------------------------------|
| 410               | Data transfer            | 1. Check connection.<br>2. Retry data transfer.   | F                              | Alarm                                |
| 411               | Up-/download active      | Up-/download active, please wait  | C                              | Warning                              |
| 438               | Dataset                  | 1. Check data set file.<br>2. Check device configuration.<br>3. Up- and download new configuration. | M                              | Warning                              |
| 453               | Flow override            | Deactivate flow override.   | C                              | Warning                              |
| 484               | Simulation failsafe mode | Deactivate simulation.  | C                              | Alarm                                |

| Diagnostic number | Short text                  | Remedial measures                        | Status signal from the factory | Diagnostic behavior from the factory |
|-------------------|-----------------------------|--|--------------------------------|--------------------------------------|
| 485               | Simulation process variable | Deactivate simulation.                   | C                              | Warning                              |
| 531               | Empty pipe detection        | Perform empty pipe detection adjustment. | S                              | Warning*                             |

\* Diagnostic behavior can be changed: "Adapting the diagnostic behavior" section (→  62)

### Diagnostics for the process

| Diagnostic number | Short text          | Remedial measures  | Status signal from the factory | Diagnostic behavior from the factory |
|-------------------|---------------------|--|--------------------------------|--------------------------------------|
| 832               | Ambient temperature | Reduce ambient temperature.                                | S                              | Warning*                             |
| 833               | Ambient temperature | Increase ambient temperature.                              | S                              | Warning*                             |
| 843               | Process limit       | Check process conditions.                                  | S                              | Warning                              |
| 861               | Process fluid       | Check process conditions.                                  | F                              | Alarm*                               |
| 862               | Empty pipe          | 1. Check for gas in process.<br>2. Check detection limits. | S                              | Warning                              |

\* Diagnostic behavior can be changed: "Adapting the diagnostic behavior" section (→  62)

## 12.7 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

### Navigation path

- "Diagnostics" menu → Actual diagnostics
- "Diagnostics" menu → Previous diagnostics

### Parameter overview with brief description

| Parameter            | Prerequisite                              | Description  | Display                        |
|----------------------|---|--|--------------------------------|
| Actual diagnostics   | 1 diagnostic event has occurred           | Displays the current diagnostic event along with the diagnostic information.<br> If two or more messages occur simultaneously, the message with the highest priority is shown on the display. | Diagnostic code, short message |
| Previous diagnostics | 2 diagnostic events have already occurred | Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.   | Diagnostic code, short message |

 To call up the measures to rectify a diagnostic event:  
Via "FieldCare" operating tool (→  61)

 Other diagnostic events that are pending can be viewed in the **Diagnostic list** submenu (→  64)

## 12.8 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

**Navigation path**

"Diagnostics" menu → Diagnostic list



To call up the measures to rectify a diagnostic event:  
Via "FieldCare" operating tool (→ 61)

## 12.9 Event logbook

### 12.9.1 Event history

A chronological overview of the event messages that have occurred is provided in the events list which contains a maximum of 20 message entries. This list can be displayed via FieldCare if necessary.

**Navigation path**

Event list: **F** → Tool box → Additional functions



For information on the event list, see the FieldCare user interface (→ 40)

This event history includes entries for:

- Diagnostic events (→ 63)
- Information events (→ 66)

In addition to the operation time of its occurrence and possible troubleshooting measures, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostics event
  - : Event has occurred
  - : Event has ended
- Information event
  - : Event has occurred



To call up the measures to rectify a diagnostic event:  
Via "FieldCare" operating tool (→ 61)



For filtering the displayed event messages (→ 65)

### 12.9.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

**Navigation path**

"Diagnostics" menu → Event logbook → Filter options

**Filter categories**

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

### 12.9.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

| Information event | Event text                              |
|-------------------|---|
| I1000             | ----- (device ok)                       |
| I1089             | Power on                                |
| I1090             | Configuration reset                     |
| I1091             | Configuration changed                   |
| I1110             | Write protection switch changed         |
| I1151             | History reset                           |
| I1351             | Empty pipe detection adjustment failure |
| I1353             | Empty pipe detection adjustment Ok      |

## 12.10 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

### Navigation path

"Diagnostics" menu → Device reset → Device reset

*Function scope of the "Device reset" parameter*

| Options              | Description  |
|----------------------|--|
| Cancel               | The user exists the parameter and no action is performed.  |
| To factory defaults  | Every parameter is reset to its factory setting.   |
| To delivery settings | Every parameter for which a customized default setting was ordered is reset to that customized value; all other parameters are reset to their factory setting.<br> This option is not visible if no customized settings were ordered. |
| Restart device       | Restarting the device resets every parameter whose data are saved in the volatile memory (RAM) to the parameter's factory setting (e.g. measured value data). The device configuration remains unchanged.  |


## 12.11 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

### Navigation path

"Diagnostics" menu → Device information

*Structure of the submenu*



|  |                       |
|--|-----------------------|
|  | Extended order code 1 |
|  | Extended order code 2 |
|  | Extended order code 3 |
|  | ENP version           |

*Parameter overview with brief description*

| Parameter               | Prerequisite  | Description   | Display   |
|-------------------------|---|---|---|
| Serial number           | -   | Displays the serial number of the measuring device.<br> The number can be found on the nameplate of the sensor and transmitter.  | Max. 11-digit character string comprising letters and numbers               |
| Firmware version        | -   | Displays the device firmware version installed.   | Character string in the format xx.yy.zz                                     |
| Device name             | -   | Displays the name of the transmitter.<br> The name can be found on the nameplate of the transmitter.   |   |
| Order code              | -   | Displays the device order code.<br> The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.  | Character string composed of letters, numbers and certain punctuation marks |
| Extended order code 1-3 | Depending on the length of the extended order code, the code is divided into a maximum of 3 parameters. | Displays the 1st, 2nd or 3rd part of the extended order code.<br> The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string  |
| ENP version             | -   | Displays the version of the electronic nameplate.   | Character string in the format xx.yy.zz                                     |

## 12.12 Firmware history

| Release date | Firmware version | Order code for "Firmware version" | Firmware changes  | Documentation type     | Documentation                                |
|--------------|------------------|-----------------------------------|-------------------|------------------------|--|
| 04.2013      | 01.02.00         | Option 74                         | Update            | Operating Instructions | BA01176D/06/DE/01.13<br>BA01176D/06/EN/01.13 |
| 06.2012      | 01.01.00         | -                                 | Original firmware | -                      | -  |

 Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) .

 For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

-  The manufacturer's information is available:
- In the Download Area of the Endress+Hauser Internet site: [www.endress.com](http://www.endress.com) → Download
  - Specify the following details:
    - Product root: e.g. 5H1B
    - Text search: Manufacturer's information
    - Search range: documentation

## 13 Maintenance

### 13.1 Maintenance tasks

No special maintenance work is required.

#### 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

#### 13.1.2 Interior cleaning

No interior cleaning is planned for the device.

#### 13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.

The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory) (→  87)

### 13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

### 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

## 14 Repair

### 14.1 General notes

#### Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

#### Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

### 14.2 Spare parts

*W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

-  Measuring device serial number:
  - Is located on the nameplate of the device.
  - Can be read out via the **Serial number** parameter in the **Device information** submenu (→  66).

### 14.3 Endress+Hauser services

-  Contact your Endress+Hauser Sales Center for information on services and spare parts.

### 14.4 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at [www.services.endress.com/return-material](http://www.services.endress.com/return-material)

### 14.5 Disposal

#### 14.5.1 Removing the measuring device

1. Switch off the device.

2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

### 14.5.2 Disposing of the measuring device

#### **WARNING**

**Danger to personnel and environment from fluids that are hazardous to health.**

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

## 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).

### 15.1 Device-specific accessories

#### 15.1.1 For the transmitter

| Accessories  | Description  |
|--------------|--|
| Ground cable | Set, consisting of two ground cables for potential equalization. |

#### 15.1.2 For the sensor

| Accessories  | Description  |
|--------------|--|
| Ground disks | Are used to ground the fluid in lined measuring tubes to ensure proper measurement.<br> For details, see Installation Instructions EA00070D |

### 15.2 Communication-specific accessories

| Accessories                 | Description   |
|-----------------------------|---|
| Commubox FXA195 HART        | For intrinsically safe HART communication with FieldCare via the USB interface.<br> For details, see "Technical Information" TI00404F  |
| Commubox FXA291             | Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.<br> For details, see "Technical Information" TI00405C  |
| HART Loop Converter HMX50   | Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.<br> For details, see "Technical Information" TI00429F and Operating Instructions BA00371F  |
| Wireless HART adapter SWA70 | Is used for the wireless connection of field devices. The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity.<br> For details, see Operating Instructions BA00061S |
| Fieldgate FXA320            | Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser.<br> For details, see "Technical Information" TI00025S and Operating Instructions BA00053S  |

|                    |  |
|--------------------|--|
| Fieldgate FXA520   | <p>Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.</p> <p> For details, see "Technical Information" TI00025S and Operating Instructions BA00051S</p>   |
| Field Xpert SFX100 | <p>Compact, flexible and robust industry handheld terminal for remote configuration and for obtaining measured values via the HART current output (4-20 mA).</p> <p> For details, see Operating Instructions BA00060S</p> |

### 15.3 Service-specific accessories

| Accessories | Description   |
|-------------|---|
| Applicator  | <p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> <li>▪ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections.</li> <li>▪ Graphic illustration of the calculation results</li> </ul> <p>Administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</p> <p>Applicator is available:</p> <ul style="list-style-type: none"> <li>▪ Via the Internet: <a href="https://wapps.endress.com/applicator">https://wapps.endress.com/applicator</a></li> <li>▪ On CD-ROM for local PC installation.</li> </ul>   |
| W@M         | <p>Life cycle management for your plant</p> <p>W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle.</p> <p>The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records.</p> <p>W@M is available:</p> <ul style="list-style-type: none"> <li>▪ Via the Internet: <a href="http://www.endress.com/lifecyclemanagement">www.endress.com/lifecyclemanagement</a></li> <li>▪ On CD-ROM for local PC installation.</li> </ul> |
| FieldCare   | <p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> For details, see Operating Instructions BA00027S and BA00059S</p>   |

### 15.4 System components

| Accessories                          | Description   |
|--------------------------------------|---|
| Memograph M graphic display recorder | <p>The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <p> For details, see "Technical Information" TI00133R and Operating Instructions BA00247R</p> |

## 16 Technical data

### 16.1 Application

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

### 16.2 Function and system design

|                     |   |
|---------------------|---|
| Measuring principle | Electromagnetic flow measurement on the basis of <i>Faraday's law of magnetic induction</i> .   |
| Measuring system    | One device version is available: compact version, transmitter and sensor form a mechanical unit.<br>For information on the structure of the device (->  10) |

### 16.3 Input

|                   |  |
|-------------------|--|
| Measured variable | <p><b>Direct measured variables</b></p> <ul style="list-style-type: none"> <li>▪ Volume flow (proportional to induced voltage)</li> <li>▪ Electrical conductivity</li> </ul> <p><b>Calculated measured variables</b></p> <ul style="list-style-type: none"> <li>▪ Mass flow</li> <li>▪ Corrected volume flow</li> <li>▪ Corrected electrical conductivity</li> </ul> |
| Measuring range   | Typically $v = 0.01$ to $10$ m/s ( $0.03$ to $33$ ft/s) with the specified accuracy  |

*Flow characteristic values in SI units*

| Nominal diameter |      | Recommended flow<br>min./max. full scale value<br>( $v \sim 0.3/10$ m/s)<br>[dm <sup>3</sup> /min] | Factory settings<br>Low flow cut off<br>( $v \sim 0.04$ m/s)<br>[dm <sup>3</sup> /min] |
|------------------|------|--|--|
| [mm]             | [in] |  |  |
| 15               | ½    | 4 to 100   | 0,5  |
| 25               | 1    | 9 to 300   | 1  |
| 32               | –    | 15 to 500  | 2  |
| 40               | 1 ½  | 25 to 700  | 3  |
| 50               | 2    | 35 to 1 100  | 5  |
| 65               | –    | 60 to 2 000  | 8  |
| 80               | 3    | 90 to 3 000  | 12   |
| 100              | 4    | 145 to 4 700   | 20   |
| 125              | –    | 220 to 7 500   | 30   |

| Nominal diameter |      | Recommended flow<br>min./max. full scale value<br>(v ~ 0.3/10 m/s)<br>[dm <sup>3</sup> /min] | Factory settings<br>Low flow cut off<br>(v ~ 0.04 m/s)<br>[dm <sup>3</sup> /min] |
|------------------|------|--|--|
| [mm]             | [in] |  |  |
| 150              | 6    | 20 to 600 m <sup>3</sup> /h  | 2.5 m <sup>3</sup> /h  |
| 200              | 8    | 35 to 1 100 m <sup>3</sup> /h  | 5 m <sup>3</sup> /h  |
| 250              | 10   | 55 to 1 700 m <sup>3</sup> /h  | 7.5 m <sup>3</sup> /h  |
| 300              | 12   | 80 to 2 400 m <sup>3</sup> /h  | 10 m <sup>3</sup> /h   |
| 350              | 14   | 110 to 3 300 m <sup>3</sup> /h   | 15 m <sup>3</sup> /h   |
| 400              | 16   | 140 to 4 200 m <sup>3</sup> /h   | 20 m <sup>3</sup> /h   |
| 450              | 18   | 180 to 5 400 m <sup>3</sup> /h   | 25 m <sup>3</sup> /h   |
| 500              | 20   | 220 to 6 600 m <sup>3</sup> /h   | 30 m <sup>3</sup> /h   |
| 600              | 24   | 310 to 9 600 m <sup>3</sup> /h   | 40 m <sup>3</sup> /h   |

*Flow characteristic values in US units*

| Nominal diameter |      | Recommended flow<br>min./max. full scale value<br>(v ~ 0.3/10 m/s)<br>[gal/min] | Factory settings<br>Low flow cut off<br>(v ~ 0.04 m/s)<br>[gal/min] |
|------------------|------|---|---|
| [in]             | [mm] |   |   |
| ½                | 15   | 1.0 to 27   | 0,15  |
| 1                | 25   | 2.5 to 80   | 0,25  |
| 1 ½              | 40   | 7 to 190  | 0,75  |
| 2                | 50   | 10 to 300   | 1,25  |
| 3                | 80   | 24 to 800   | 2,5   |
| 4                | 100  | 40 to 1 250   | 4   |
| 6                | 150  | 90 to 2 650   | 12  |
| 8                | 200  | 155 to 4 850  | 15  |
| 10               | 250  | 250 to 7 500  | 30  |
| 12               | 300  | 350 to 10 600   | 45  |
| 14               | 350  | 500 to 15 000   | 60  |
| 16               | 400  | 600 to 19 000   | 60  |
| 18               | 450  | 800 to 24 000   | 90  |
| 20               | 500  | 1 000 to 30 000   | 120   |
| 24               | 600  | 1 400 to 44 000   | 180   |

**Recommended measuring range**

"Flow limit" section (→  81)

Operable flow range

Over 1000 : 1

Input signal

**Fieldbuses**

To increase the accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring device via Modbus RS485, EtherNet/IP or HART input:

- Process pressure or medium temperature to increase accuracy (e.g. external values from Cerabar M, Cerabar S or iTEMP)
- Reference density for calculating the corrected volume flow

## 16.4 Output

Output signal

**Modbus RS485**

|                      |   |
|----------------------|---|
| Physical interface   | In accordance with EIA/TIA-485-A standard   |
| Terminating resistor | Integrated, can be activated via DIP switch on the transmitter electronics module |

Signal on alarm

Depending on the interface, failure information is displayed as follows:

**Modbus RS485**

|              |   |
|--------------|---|
| Failure mode | Choose from: <ul style="list-style-type: none"> <li>▪ NaN value instead of current value</li> <li>▪ Last valid value</li> </ul> |
|--------------|---|

**Operating tool**

|                    |   |
|--------------------|---|
| Plain text display | With information on cause and remedial measures |
|--------------------|---|

**Light emitting diodes (LED)**

|                    |   |
|--------------------|---|
| Status information | Status indicated by various light emitting diodes<br>The following information is displayed depending on the device version: <ul style="list-style-type: none"> <li>▪ Supply voltage active</li> <li>▪ Data transmission active</li> <li>▪ Device alarm/error has occurred</li> </ul> |
|--------------------|---|

Ex connection data

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The following connections are galvanically isolated from each other:

- Outputs
- Power supply

Protocol-specific data

**Modbus RS485**

|                     |   |
|---------------------|---|
| Protocol            | Modbus Applications Protocol Specification V1.1 |
| Device type         | Slave   |
| Slave address range | 1 to 247  |

|                         |  |
|-------------------------|--|
| Broadcast address range | 0  |
| Function codes          | <ul style="list-style-type: none"> <li>▪ 03: Read holding register</li> <li>▪ 04: Read input register</li> <li>▪ 06: Write single registers</li> <li>▪ 08: Diagnostics</li> <li>▪ 16: Write multiple registers</li> <li>▪ 23: Read/write multiple registers</li> </ul> |
| Broadcast messages      | Supported by the following function codes: <ul style="list-style-type: none"> <li>▪ 06: Write single registers</li> <li>▪ 16: Write multiple registers</li> <li>▪ 23: Read/write multiple registers</li> </ul>   |
| Supported baud rate     | <ul style="list-style-type: none"> <li>▪ 1 200 BAUD</li> <li>▪ 2 400 BAUD</li> <li>▪ 4 800 BAUD</li> <li>▪ 9 600 BAUD</li> <li>▪ 19 200 BAUD</li> <li>▪ 38 400 BAUD</li> <li>▪ 57 600 BAUD</li> <li>▪ 115 200 BAUD</li> </ul>  |
| Data transfer mode      | <ul style="list-style-type: none"> <li>▪ ASCII</li> <li>▪ RTU</li> </ul>   |
| Data access             | Each device parameter can be accessed via Modbus RS485.<br> For Modbus register information   |

## 16.5 Power supply

Terminal assignment (→  28)

Pin assignment, device plug (→  28)

**Supply voltage** **Transmitter**  
 For device version with all communication types: DC 20 to 30 V  
 The power unit must be tested to ensure it meets safety requirements (e.g. PELV, SELV).

**Power consumption** *Transmitter*

| Order code for "Output"        | Maximum Power consumption |
|--------------------------------|---------------------------|
| Option <b>M</b> : Modbus RS485 | 3.5 W                     |

**Current consumption** *Transmitter*

| Order code for "Output"        | Maximum Current consumption | Maximum switch-on current |
|--------------------------------|-----------------------------|---------------------------|
| Option <b>M</b> : Modbus RS485 | 90 mA                       | 10 A (<0.8 ms)            |

**Power supply failure**

- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Electrical connection (→  30)

Potential equalization (→  32)

Terminals **Transmitter**  
Spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

Cable entries **Transmitter**

- Cable gland: M20 × 1.5 with cable  $\phi$ 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
  - NPT 1/2"
  - G 1/2"
  - M20

Cable specification (→  27)

## 16.6 Performance characteristics

Reference operating conditions **To DIN EN 29104**

- Fluid temperature:  $+28 \pm 2$  °C ( $+82 \pm 4$  °F)
- Ambient temperature range:  $+22 \pm 2$  °C ( $+72 \pm 4$  °F)
- Warm-up period: 30 min

**Installation**

- Inlet run > 10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.


Maximum measured error **Error limits under reference operating conditions**

o.r. = of reading

**Pulse output**

- $\pm 0.5$  % o.r.  $\pm 1$  mm/s (0.04 in/s)
- Optional:  $\pm 0.2$  % o.r.  $\pm 2$  mm/s (0.08 in/s)

 Fluctuations in the supply voltage do not have any effect within the specified range.



 16 Maximum measured error in % o.r.

A0005531

**Electrical conductivity**

Max. measured error not specified.

**Accuracy of outputs**

o.r. = of reading; o.f.s. = of full scale value

 The output accuracy must be factored into the measured error if analog outputs are used, but can be ignored for fieldbus outputs (e.g. Modbus RS485, EtherNet/IP).

*Current output*

|                 |   |
|-----------------|---|
| <b>Accuracy</b> | Max. $\pm 0.05$ % o.f.s. or $\pm 5$ $\mu$ A |
|-----------------|---|

*Pulse/frequency output*

|                 |                        |
|-----------------|------------------------|
| <b>Accuracy</b> | Max. $\pm 50$ ppm o.r. |
|-----------------|------------------------|

Repeatability

o.r. = of reading

**Volume flow**

Max.  $\pm 0.1$  % o.r.  $\pm 0.5$  mm/s (0.02 in/s)

**Electrical conductivity**

Max.  $\pm 5$  % o.r.

Temperature measurement  
response time

$T_{90} < 15$  s

## 16.7 Installation

"Mounting requirements" ( $\rightarrow$   17)

## 16.8 Environment

Ambient temperature  
range

( $\rightarrow$   19)

Storage temperature

The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.

- Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.
- If protection caps or protective covers are mounted these should never be removed before installing the measuring device.

Degree of protection


**Transmitter and sensor**

- As standard: IP66/67, type 4X enclosure
- With the order code for "Sensor options", option **CM**: IP69K can also be ordered
- When housing is open: IP20, type 1 enclosure

|                                     |   |
|-------------------------------------|---|
| Shock resistance                    | As per IEC/EN 60068-2-31  |
| Vibration resistance                | Acceleration up to 2 g following IEC 60068-2-6  |
| Mechanical load                     | <ul style="list-style-type: none"> <li>■ Protect the transmitter housing against mechanical effects, such as shock or impact.</li> <li>■ Never use the transmitter housing as a ladder or climbing aid.</li> </ul>  |
| Electromagnetic compatibility (EMC) | <ul style="list-style-type: none"> <li>■ As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)</li> <li>■ Complies with emission limits for industry as per EN 55011 (Class A)</li> </ul> <p> Details are provided in the Declaration of Conformity.</p> |

## 16.9 Process

|                          |  |
|--------------------------|--|
| Medium temperature range | <ul style="list-style-type: none"> <li>■ -20 to +150 °C (-4 to +302 °F) for PFA, DN 25 to 200 (1 to 8")</li> <li>■ -20 to +180 °C (-4 to +356 °F) for PFA high-temperature, DN 25 to 200 (1 to 8")</li> <li>■ -40 to +130 °C (-40 to +266 °F) for PTFE, DN 15 to 600 (½ to 24")</li> </ul> |
|--------------------------|--|



A0019742

- $T_A$  Ambient temperature  
 $T_F$  Medium temperature
- 1 Gray area: the ambient temperature range of -10 to -40 °C (-14 to -40 °F) applies to stainless flanges only
  - 2 Hatched area: harsh environment and IP68 only up to +130 °C (+266 °F)
  - 3 Dark-gray area: high-temperature version with insulation

|              |  |
|--------------|--|
| Conductivity | $\geq 5 \mu\text{S/cm}$ for liquids in general |
|--------------|--|

|                              |  |
|------------------------------|--|
| Pressure-temperature ratings |  An overview of the material load diagrams (pressure/temperature diagrams) for the process connections is provided in the "Technical Information" document. |
|------------------------------|--|

## Pressure tightness

*Liner: PFA*

| Nominal diameter |      | Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures: |                  |                                      |
|------------------|------|--|------------------|--------------------------------------|
| [mm]             | [in] | +25 °C (+77 °F)  | +80 °C (+176 °F) | +100 to +180 °C<br>(+212 to +356 °F) |
| 25               | 1    | 0 (0)  | 0 (0)            | 0 (0)                                |
| 32               | -    | 0 (0)  | 0 (0)            | 0 (0)                                |
| 40               | 1 ½  | 0 (0)  | 0 (0)            | 0 (0)                                |
| 50               | 2    | 0 (0)  | 0 (0)            | 0 (0)                                |
| 65               | -    | 0 (0)  | - (-)            | 0 (0)                                |
| 80               | 3    | 0 (0)  | - (-)            | 0 (0)                                |
| 100              | 4    | 0 (0)  | - (-)            | 0 (0)                                |
| 125              | -    | 0 (0)  | - (-)            | 0 (0)                                |
| 150              | 6    | 0 (0)  | - (-)            | 0 (0)                                |
| 200              | 8    | 0 (0)  | - (-)            | 0 (0)                                |

*Liner: PTFE*

| Nominal diameter |      | Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures: |                  |                   |                   |
|------------------|------|--|------------------|-------------------|-------------------|
| [mm]             | [in] | +25 °C (+77 °F)  | +80 °C (+176 °F) | +100 °C (+212 °F) | +130 °C (+266 °F) |
| 15               | ½    | 0 (0)  | 0 (0)            | 0 (0)             | 100 (1.45)        |
| 25               | 1    | 0 (0)  | 0 (0)            | 0 (0)             | 100 (1.45)        |
| 32               | -    | 0 (0)  | 0 (0)            | 0 (0)             | 100 (1.45)        |
| 40               | 1 ½  | 0 (0)  | 0 (0)            | 0 (0)             | 100 (1.45)        |
| 50               | 2    | 0 (0)  | 0 (0)            | 0 (0)             | 100 (1.45)        |
| 65               | -    | 0 (0)  | - (-)            | 40 (0.58)         | 130 (1.89)        |
| 80               | 3    | 0 (0)  | - (-)            | 40 (0.58)         | 130 (1.89)        |
| 100              | 4    | 0 (0)  | - (-)            | 135 (1.96)        | 170 (2.47)        |
| 125              | -    | 135 (1.96)   | - (-)            | 240 (3.48)        | 385 (5.58)        |
| 150              | 6    | 135 (1.96)   | - (-)            | 240 (3.48)        | 385 (5.58)        |
| 200              | 8    | 200 (2.90)   | - (-)            | 290 (4.21)        | 410 (5.95)        |
| 250              | 10   | 330 (4.79)   | - (-)            | 400 (5.80)        | 530 (7.69)        |
| 300              | 12   | 400 (5.80)   | - (-)            | 500 (7.25)        | 630 (9.14)        |
| 350              | 14   | 470 (6.82)   | - (-)            | 600 (8.70)        | 730 (10.6)        |
| 400              | 16   | 540 (7.83)   | - (-)            | 670 (9.72)        | 800 (11.6)        |
| 450              | 18   | No negative pressure permitted!  |                  |                   |                   |
| 500              | 20   |  |                  |                   |                   |
| 600              | 24   |  |                  |                   |                   |

## Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:

- $v < 2$  m/s (6.56 ft/s): for abrasive fluids (e.g. potter's clay, lime milk, ore slurry)
- $v > 2$  m/s (6.56 ft/s): for fluids producing buildup (e.g. wastewater sludges)



For an overview of the measuring range full scale values, see the "Measuring range" section (→ 74)

Pressure loss

- No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.
- Pressure losses for configurations incorporating adapters according to DIN EN 545 (→  21)

System pressure (→  20)

Vibrations (→  20)

## 16.10 Mechanical construction

Design, dimensions  For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

**Compact version**

- Including the transmitter
- High-temperature version + 1.5 kg (3.31 lbs)
- Weight specifications apply to standard pressure ratings and without packaging material.

*Weight in SI units*

| Nominal diameter |      | EN (DIN), AS <sup>1)</sup> |      | ASME            |      | JIS             |      |
|------------------|------|----------------------------|------|-----------------|------|-----------------|------|
| [mm]             | [in] | Pressure rating            | [kg] | Pressure rating | [kg] | Pressure rating | [kg] |
| 15               | ½    | PN 40                      | 4.5  | Class 150       | 4.5  | 10K             | 4.5  |
| 25               | 1    | PN 40                      | 5.3  | Class 150       | 5.3  | 10K             | 5.3  |
| 32               | –    | PN 40                      | 6    | Class 150       | –    | 10K             | 5.3  |
| 40               | 1 ½  | PN 40                      | 7.4  | Class 150       | 7.4  | 10K             | 6.3  |
| 50               | 2    | PN 40                      | 8.6  | Class 150       | 8.6  | 10K             | 7.3  |
| 65               | –    | PN 16                      | 10   | Class 150       | –    | 10K             | 9.1  |
| 80               | 3    | PN 16                      | 12   | Class 150       | 12   | 10K             | 10.5 |
| 100              | 4    | PN 16                      | 14   | Class 150       | 14   | 10K             | 12.7 |
| 125              | –    | PN 16                      | 19.5 | Class 150       | –    | 10K             | 19   |
| 150              | 6    | PN 16                      | 23.5 | Class 150       | 23.5 | 10K             | 22.5 |
| 200              | 8    | PN 10                      | 43   | Class 150       | 43   | 10K             | 39.9 |
| 250              | 10   | PN 10                      | 63   | Class 150       | 73   | 10K             | 67.4 |
| 300              | 12   | PN 10                      | 68   | Class 150       | 108  | 10K             | 70.3 |
| 350              | 14   | PN 10                      | 103  | Class 150       | 173  |                 |      |
| 400              | 16   | PN 10                      | 118  | Class 150       | 203  |                 |      |
| 450              | 18   | PN 10                      | 159  | Class 150       | 253  |                 |      |
| 500              | 20   | PN 10                      | 154  | Class 150       | 283  |                 |      |
| 600              | 24   | PN 10                      | 206  | Class 150       | 403  |                 |      |

1) For flanges to AS, only DN 25 and 50 are available.

*Weight in US units*

| Nominal diameter |      | ASME            |       |
|------------------|------|-----------------|-------|
| [mm]             | [in] | Pressure rating | [lbs] |
| 15               | ½    | Class 150       | 9.92  |
| 25               | 1    | Class 150       | 11.7  |
| 40               | 1 ½  | Class 150       | 16.3  |
| 50               | 2    | Class 150       | 19.0  |
| 80               | 3    | Class 150       | 26.5  |
| 100              | 4    | Class 150       | 30.9  |
| 150              | 6    | Class 150       | 51.8  |
| 200              | 8    | Class 150       | 94.8  |
| 250              | 10   | Class 150       | 161.0 |
| 300              | 12   | Class 150       | 238.1 |
| 350              | 14   | Class 150       | 381.5 |
| 400              | 16   | Class 150       | 447.6 |
| 450              | 18   | Class 150       | 557.9 |
| 500              | 20   | Class 150       | 624.0 |
| 600              | 24   | Class 150       | 888.6 |

## Measuring tube specification

| Nominal diameter |      | Pressure rating |           |         |         |       | Process connection internal diameter |      |      |      |
|------------------|------|-----------------|-----------|---------|---------|-------|--------------------------------------|------|------|------|
|                  |      | EN (DIN)        | ASME      | AS 2129 | AS 4087 | JIS   | PFA                                  |      | PTFE |      |
| [mm]             | [in] | [bar]           | [psi]     | [bar]   | [bar]   | [bar] | [mm]                                 | [in] | [mm] | [in] |
| 15               | ½    | PN 40           | Class 150 | -       | -       | 20K   | -                                    | -    | 15   | 0.59 |
| 25               | 1    | PN 40           | Class 150 | Table E | -       | 20K   | 23                                   | 0.91 | 26   | 1.02 |
| 32               | -    | PN 40           | -         | -       | -       | 20K   | 32                                   | 1.26 | 35   | 1.38 |
| 40               | 1 ½  | PN 40           | Class 150 | -       | -       | 20K   | 36                                   | 1.42 | 41   | 1.61 |
| 50               | 2    | PN 40           | Class 150 | Table E | PN 16   | 10K   | 48                                   | 1.89 | 52   | 2.05 |
| 65               | -    | PN 16           | -         | -       | -       | 10K   | 63                                   | 2.48 | 67   | 2.64 |
| 80               | 3    | PN 16           | Class 150 | -       | -       | 10K   | 75                                   | 2.95 | 80   | 3.15 |
| 100              | 4    | PN 16           | Class 150 | -       | -       | 10K   | 101                                  | 3.98 | 104  | 4.09 |
| 125              | -    | PN 16           | -         | -       | -       | 10K   | 126                                  | 4.96 | 129  | 5.08 |
| 150              | 6    | PN 16           | Class 150 | -       | -       | 10K   | 154                                  | 6.06 | 156  | 6.14 |
| 200              | 8    | PN 10           | Class 150 | -       | -       | 10K   | 201                                  | 7.91 | 202  | 7.95 |
| 250              | 10   | PN 10           | Class 150 | -       | -       | 10K   | -                                    | -    | 256  | 10.1 |
| 300              | 12   | PN 10           | Class 150 | -       | -       | 10K   | -                                    | -    | 306  | 12.0 |
| 350              | 14   | PN 10           | Class 150 | -       | -       | -     | -                                    | -    | 337  | 13.3 |
| 400              | 16   | PN 10           | Class 150 | -       | -       | -     | -                                    | -    | 387  | 15.2 |
| 450              | 18   | PN 10           | Class 150 | -       | -       | -     | -                                    | -    | 432  | 17.0 |
| 500              | 20   | PN 10           | Class 150 | -       | -       | -     | -                                    | -    | 487  | 19.2 |
| 600              | 24   | PN 10           | Class 150 | -       | -       | -     | -                                    | 23   | 593  | 23.3 |

Materials

**Transmitter housing**

Order code for "Housing", option **A** "Compact, coated alu":  
Coated aluminum AlSi10Mg

**Cable entries**

Order code for "Housing", option **A** "Compact, coated alu"

The various cable entries are suitable for hazardous and non-hazardous areas.

| Electrical connection      | Material            |
|----------------------------|---------------------|
| Cable gland M20 × 1.5      | Nickel-plated brass |
| Thread G ½", via adapter   |                     |
| Thread NPT ½", via adapter |                     |

**Device plug**

| Electrical connection | Material   |
|-----------------------|--|
| Plug M12x1            | <ul style="list-style-type: none"> <li>■ Socket: Stainless steel 1.4404 (316L)</li> <li>■ Contact housing: Polyamide</li> <li>■ Contacts: Gold-plated brass</li> </ul> |

**Sensor housing**

- DN 15 to 300 (½ to 12"): coated aluminum AlSi10Mg
- DN 350 to 600 (14 to 24"): carbon steel with protective varnish

**Measuring tubes**

Stainless steel 1.4301 (304) or 1.4306 (304L); for flanges made of carbon with Al/Zn protective coating (DN 15 to 300 (½ to 12")) or protective varnish (DN 350 to 600 (14 to 24"))

*Liner*

- PFA
- PTFE

**Process connections**

EN 1092-1 (DIN 2501)  
1.4571 (316L), C22, FE 410W B <sup>1)</sup>, S235JRG2

ASME B16.5  
A105, F316L <sup>1)</sup>

JIS B2220  
1.0425 (316L) <sup>1)</sup>, HII, S235JRG2

AS 2129 Table E  

- DN 25 (1"): A105 or S235JRG2
- DN 40 (1 ½"): A105 or S275JR

AS 4087 PN 16  
A105 or S275JR

 List of all available process connections (→  85)

1) DN 15 to 300 (½ to 12") with Al/Zn protective coating; DN 350 to 600 (14 to 24") with protective varnish

**Electrodes**

1.4435 (316L), Alloy C22, platinum, tantalum, titanium

**Seals**

In accordance with DIN EN 1514-1

**Accessories***Ground disks*

1.4435 (316L), Alloy C22, tantalum, titanium

|                     |  |
|---------------------|--|
| Fitted electrodes   | <p>Measuring electrodes, reference electrodes and electrodes for empty pipe detection:</p> <ul style="list-style-type: none"> <li>■ Standard: 1.4435 (316L), Alloy C22, platinum, tantalum</li> <li>■ Optional: only measuring electrodes made from platinum or tantalum</li> </ul>  |
| Process connections | <ul style="list-style-type: none"> <li>■ EN 1092-1 (DIN 2501), DN ≤ 300 (12") form A, DN ≥ 350 (14") flat face; dimensions as per DIN 2501, DN 65 PN 16 and DN 600 (24") PN 16 only as per EN 1092-1</li> <li>■ ASME B16.5</li> <li>■ JIS B2220</li> <li>■ AS 2129 Table E</li> <li>■ AS 4087 PN 16</li> </ul> <p> For information on the materials of the process connections (→  84)</p> |
| Surface roughness   | <p>Electrodes with 1.4435 (304L), Alloy C22, platinum, tantalum:<br/>         ≤ 0.3 to 0.5 μm (11.8 to 19.7 in)<br/>         (All data relate to parts in contact with fluid)</p> <p>Liner with PFA:<br/>         ≤ 0.4 μm (15.7 μin)<br/>         (All data relate to parts in contact with fluid)</p>  |

## 16.11 Operability

|                  |  |
|------------------|--|
| Remote operation | <p><b>Service interface (CDI)</b></p> <p>Operation of the measuring device with the service interface (CDI) via:<br/>         "FieldCare" operating tool with COM DTM "CDI Communication FXA291" via Commubox FXA291</p> |
| Languages        | <p>Can be operated in the following languages:<br/>         Via "FieldCare" operating tool:<br/>         English, German, French, Spanish, Italian, Chinese, Japanese</p>  |

## 16.12 Certificates and approvals

|         |   |
|---------|---|
| CE mark | <p>The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p> |
|---------|---|

|                                |  |
|--------------------------------|--|
| C-Tick symbol                  | The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".   |
| Ex approval                    | The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.   |
| Modbus RS485 certification     | The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out and is certified by the "MODBUS/TCP Conformance Test Laboratory" of the University of Michigan.  |
| Pressure Equipment Directive   | <ul style="list-style-type: none"> <li>■ With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC.</li> <li>■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.</li> </ul>   |
| Other standards and guidelines | <ul style="list-style-type: none"> <li>■ EN 60529<br/>Degrees of protection provided by enclosures (IP code)</li> <li>■ EN 61010-1<br/>Safety requirements for electrical equipment for measurement, control and laboratory use</li> <li>■ IEC/EN 61326<br/>Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements)</li> <li>■ NAMUR NE 21<br/>Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment</li> <li>■ NAMUR NE 32<br/>Data retention in the event of a power failure in field and control instruments with microprocessors</li> <li>■ NAMUR NE 43<br/>Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.</li> <li>■ NAMUR NE 53<br/>Software of field devices and signal-processing devices with digital electronics</li> <li>■ NAMUR NE 105<br/>Specifications for integrating fieldbus devices in engineering tools for field devices</li> <li>■ NAMUR NE 107<br/>Self-monitoring and diagnosis of field devices</li> <li>■ NAMUR NE 131<br/>Requirements for field devices for standard applications</li> </ul> |

## 16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered from Endress+Hauser either directly with the device or subsequently. Detailed information on the order code in question is available

from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).

### 16.14 Accessories

 Overview of accessories available for order (→  72)

### 16.15 Documentation

-  The following document types are available:
- On the CD-ROM supplied with the device
  - In the Download Area of the Endress+Hauser Internet site: [www.endress.com](http://www.endress.com) → Download

Standard documentation

| Communication | Document type                | Documentation code |
|---------------|------------------------------|--------------------|
| ----          | Brief Operating Instructions | KA01143D           |
| ----          | Technical Information        | TI01102D           |

Supplementary device-dependent documentation

| Document type             | Approval  | Documentation code   |
|---------------------------|---|--|
| Safety Instructions       | ATEX/IECEX Ex nA                                | XA01090D   |
| Special documentation     | Information on the Pressure Equipment Directive | SD01056D   |
| Special documentation     | Modbus RS485 Register Information               | SD01148D   |
| Special documentation     | Heartbeat Technology                            | SD01149D   |
| Installation Instructions |   | Specified for each individual accessory (→  72)<br> Overview of accessories available for order (→  72) |

## 17 Appendix

### 17.1 Overview of the operating menu

The following table provides an overview of the entire operating menu structure with menus and parameters. The page reference indicates where a description of the parameter can be found in the manual.


\* = The submenu only appears if it has been additionally ordered ("Technical Information", Section "Application packages").

|                             |                          |        |
|-----------------------------|--------------------------|--------|
| <b>Device information</b> → |                          | (→ 66) |
| Device name                 |                          |        |
| Device tag                  |                          |        |
| Status signal               |                          |        |
| Volume flow                 |                          |        |
| Conductivity                |                          |        |
| Temperature                 |                          |        |
| Mass flow                   |                          |        |
| Corrected volume flow       |                          |        |
| <b>Display/operat.</b> →    |                          | (→ 55) |
| Access status tooling       |                          |        |
| Locking status              |                          | (→ 53) |
|                             | <b>Operation</b> →       | (→ 57) |
|                             | Control totalizer 1 to 3 |        |
|                             | Preset value 1 to 3      |        |
|                             | Reset all totalizers     |        |
| <b>Setup</b> →              |                          | (→ 45) |
|                             | <b>System units</b> →    | (→ 45) |
|                             | Volume flow unit         |        |
|                             | Volume unit              |        |
|                             | Conductivity unit        |        |
|                             | Temperature unit         |        |
|                             | Mass flow unit           |        |
|                             | Mass unit                |        |
|                             | Density unit             |        |



|                             |                                    |            |
|-----------------------------|------------------------------------|------------|
|                             | Mass unit                          |            |
|                             | Corrected volume unit              |            |
|                             | Totalizer operation mode           |            |
|                             | Failure mode                       |            |
|                             | <b>Electrode cleaning circuit*</b> | → (→ ⓘ 51) |
|                             | Electrode cleaning circuit*        |            |
|                             | ECC duration*                      |            |
|                             | ECC recovery time*                 |            |
|                             | ECC cleaning cycle*                |            |
|                             | ECC polarity*                      |            |
| <b>Diagnostics</b>          |                                    | → (→ ⓘ 59) |
| Actual diagnostics          |                                    | → (→ ⓘ 64) |
| Timestamp                   |                                    |            |
| Previous diagnostics        |                                    | → (→ ⓘ 64) |
| Timestamp                   |                                    |            |
| Operating time from restart |                                    | → (→ ⓘ 64) |
| Operating time              |                                    |            |
| <b>Diagnostic list</b>      |                                    | → (→ ⓘ 64) |
| Diagnostics 1 to 5          |                                    |            |
| Timestamp                   |                                    |            |
| <b>Event logbook</b>        |                                    | → (→ ⓘ 65) |
| Filter options              |                                    |            |
| <b>Device information</b>   |                                    | → (→ ⓘ 66) |
| Device tag                  |                                    |            |
| Serial number               |                                    |            |
| Firmware version            |                                    |            |
| Device name                 |                                    |            |
| Order code                  |                                    |            |
| Extended order code 1 to 3  |                                    |            |
| ENP version                 |                                    |            |

|                          |                                    |                                  |
|--------------------------|------------------------------------|----------------------------------|
| <b>Measured values</b> → |                                    | (→ 55)                           |
|                          | <b>Process variables</b> →         | (→ 55)                           |
|                          | Volume flow                        |                                  |
|                          | Mass flow                          |                                  |
|                          | Conductivity                       |                                  |
|                          | Corrected volume flow              |                                  |
|                          | Temperature                        |                                  |
|                          | Corrected conductivity             |                                  |
|                          | <b>Totalizer</b> →                 | (→ 56)                           |
|                          | Totalizer value1 to 3              |                                  |
|                          | Totalizer overflow1 to 3           |                                  |
|                          | <b>Simulation</b> →                | (→ 52)                           |
|                          | Assign simulation process variable |                                  |
|                          | Value process variable             |                                  |
|                          | Simulation device alarm            |                                  |
|                          | <b>Heartbeat</b> →                 | (→ 87)                           |
|                          |                                    | <b>Performing verification</b> → |
|                          |                                    | Year                             |
|                          |                                    | Month                            |
|                          |                                    | Day                              |
|                          |                                    | Hour                             |
|                          |                                    | AM/PM                            |
|                          |                                    | Minute                           |
|                          |                                    | Start verification               |
|                          |                                    | Progress                         |
|                          |                                    | Status                           |
|                          |                                    | <b>Verification results</b> →    |
|                          |                                    | Date/time                        |
|                          |                                    | Verification ID                  |
|                          |                                    | Operating time                   |
|                          |                                    | Result                           |




|                 |                              |          |
|-----------------|------------------------------|----------|
|                 | <b>Management</b> →          | (→ 📖 59) |
|                 | Device reset                 | (→ 📖 66) |
|                 | Activate SW option           |          |
|                 | Software option overview     |          |
|                 | Permanent storage            |          |
|                 | Device tag                   |          |
| <b>Sensor</b> → |                              |          |
|                 | <b>Measured values</b> →     | (→ 📖 55) |
|                 | <b>Process variables</b> →   | (→ 📖 55) |
|                 | Volume flow                  |          |
|                 | Mass flow                    |          |
|                 | Conductivity                 |          |
|                 | Corrected volume flow        |          |
|                 | Temperature                  |          |
|                 | Corrected conductivity       |          |
|                 | <b>Totalizer</b> →           | (→ 📖 56) |
|                 | Totalizer value1 to 3        |          |
|                 | Totalizer overflow1 to 3     |          |
|                 | <b>System units</b> →        | (→ 📖 45) |
|                 | Volume flow unit             |          |
|                 | Volume unit                  |          |
|                 | Conductivity unit            |          |
|                 | Temperature unit             |          |
|                 | Mass flow unit               |          |
|                 | Mass unit                    |          |
|                 | Density unit                 |          |
|                 | Corrected volume flow unit   |          |
|                 | Corrected volume unit        |          |
|                 | Date/time format             |          |
|                 | <b>User-specific units</b> → |          |
|                 | User volume text             |          |

|                          |                                      |          |
|--------------------------|--------------------------------------|----------|
|                          | User volume factor                   |          |
|                          | User mass text                       |          |
|                          | User mass factor                     |          |
|                          | User corrected volume text           |          |
|                          | User corrected volume factor         |          |
| <b>Process param.</b> →  |                                      | (→ ⓘ 45) |
| Filter options           |                                      |          |
| Flow damping             |                                      |          |
| Flow override            |                                      |          |
| Conductivity damping     |                                      |          |
| Temperature damping      |                                      |          |
| Conductivity measurement |                                      |          |
|                          | <b>Low flow cut off</b> →            | (→ ⓘ 48) |
|                          | Assign process variable              |          |
|                          | On value low flow cut off            |          |
|                          | Off value low flow cutoff            |          |
|                          | Pressure shock suppression           |          |
|                          | <b>Empty pipe detection</b> →        | (→ ⓘ 49) |
|                          | Empty pipe detection                 |          |
|                          | Switch point empty pipe detection    |          |
|                          | Response time empty pipe detection   |          |
|                          | New adjustment                       |          |
|                          | Progress                             |          |
|                          | Empty pipe adjust value              |          |
|                          | Full pipe adjust value               |          |
|                          | Measured value EPD                   |          |
|                          | <b>Electrode cleaning circuit*</b> → | (→ ⓘ 51) |
|                          | Electrode cleaning circuit*          |          |

|  |                                |                              |          |
|--|--------------------------------|------------------------------|----------|
|  |                                | ECC duration*                |          |
|  |                                | ECC recovery time*           |          |
|  |                                | ECC cleaning cycle*          |          |
|  |                                | ECC polarity*                |          |
|  | <b>External compensation</b> → |                              |          |
|  | Temperature source             |                              |          |
|  | External temperature           |                              |          |
|  | Density source                 |                              |          |
|  | External value                 |                              |          |
|  | Fixed density                  |                              |          |
|  | Reference density              |                              |          |
|  | <b>Sensor adjustment</b> →     |                              | (→ ⓘ 50) |
|  | Installation direction         |                              |          |
|  | Integration time               |                              |          |
|  | Measuring period               |                              |          |
|  |                                | <b>Variable adjust</b> →     | (→ ⓘ 50) |
|  |                                | Volume flow factor           |          |
|  |                                | Volume flow offset           |          |
|  |                                | Mass flow factor             |          |
|  |                                | Mass flow offset             |          |
|  |                                | Conductivity factor          |          |
|  |                                | Conductivity offset          |          |
|  |                                | Corrected volume flow factor |          |
|  |                                | Corrected volume flow offset |          |
|  |                                | Temperature factor           |          |
|  |                                | Temperature offset           |          |
|  | <b>Calibration</b> →           |                              |          |
|  | Nominal diameter               |                              |          |
|  | Calibration factor             |                              |          |
|  | Zero point                     |                              |          |
|  | <b>Communication</b> →         |                              |          |

|  |                               |        |
|--|-------------------------------|--------|
|  | <b>Modbus configuration</b> → | (→ 46) |
|  | Bus address                   |        |
|  | Baud rate                     |        |
|  | Data transfer mode            |        |
|  | Parity                        |        |
|  | Byte order                    |        |
|  | Telegram delay                |        |
|  | Assign diagnostic behavior    |        |
|  | Failure mode                  |        |
|  | Interpreter mode              |        |
|  | <b>Modbus data map</b> →      | (→ 42) |
|  | Scan list register0 to 15     |        |
|  | <b>Application</b> →          |        |
|  | Reset all totalizers          | (→ 57) |
|  | <b>Totalizer 1 to 3</b> →     | (→ 50) |
|  | Assign process variable       |        |
|  | Mass unit                     |        |
|  | Volume unit                   |        |
|  | Corrected volume unit         |        |
|  | Totalizer operation mode      |        |
|  | Control totalizer 1           |        |
|  | Preset value 1                |        |
|  | Failure mode                  |        |
|  | <b>Diagnostics</b> →          | (→ 59) |
|  | Actual diagnostics            | (→ 64) |
|  | Timestamp                     |        |
|  | Previous diagnostics          | (→ 64) |
|  | Timestamp                     |        |
|  | Operating time from restart   |        |
|  | Operating time                |        |
|  | <b>Diagnostic list</b> →      | (→ 64) |





# Index

## A

- Adapters . . . . . 21
- Adapting the diagnostic behavior . . . . . 62
- Ambient temperature range . . . . . 19
- Application . . . . . 8, 74
- Applicator . . . . . 74
- Approvals . . . . . 85
- Auto scan buffer
  - see Modbus RS485 Modbus data map

## C

- C-Tick symbol . . . . . 86
- Cable entries
  - Technical data . . . . . 78
- Cable entry
  - Degree of protection . . . . . 34
- CE mark . . . . . 9, 85
- Certificates . . . . . 85
- Check
  - Installation . . . . . 25
  - Post-connection . . . . . 35
- Checklist
  - Post-connection check . . . . . 35
  - Post-installation check . . . . . 25
- Cleaning
  - Exterior cleaning . . . . . 69
  - Interior cleaning . . . . . 69
- Commissioning . . . . . 45
  - Advanced settings . . . . . 50
  - Configuring the measuring device . . . . . 45
- Conductivity . . . . . 80
- Configuring error response mode, Modbus RS485 . . . . . 61
- Connecting cable . . . . . 27
- Connecting the measuring device . . . . . 30
- Connection
  - see Electrical connection
- Connection examples, potential equalization . . . . . 32
- Connection preparations . . . . . 29
- Connection tools . . . . . 27
- Current consumption . . . . . 77

## D

- Declaration of Conformity . . . . . 9
- Degree of protection . . . . . 34, 79
- Design
  - Measuring device . . . . . 10
- Designated use . . . . . 8
- Device components . . . . . 10
- Device description files . . . . . 41, 41
- Device documentation
  - Supplementary documentation . . . . . 7
- Device locking, status . . . . . 55
- Device name
  - Sensor . . . . . 13
  - Transmitter . . . . . 12
- Device repair . . . . . 70

- Device revision . . . . . 41
- Device type ID . . . . . 41
- Diagnostic information
  - Communication interface . . . . . 61
  - Design, description . . . . . 61
  - FieldCare . . . . . 60
  - Light emitting diodes . . . . . 59
  - Overview . . . . . 63
  - Remedial measures . . . . . 63
- Diagnostic list . . . . . 64
- DIP switch
  - see Write protection switch
- Disabling write protection . . . . . 53
- Display
  - Current diagnostic event . . . . . 64
  - Previous diagnostic event . . . . . 64
- Display values
  - For device info . . . . . 67
  - For locking status . . . . . 55
  - For process variables . . . . . 55
  - For the totalizer . . . . . 56
- Disposal . . . . . 70
- Document
  - Function . . . . . 5
  - Symbols used . . . . . 5
- Document function . . . . . 5
- Documentation . . . . . 87
- Down pipe . . . . . 17

## E

- Electrical connection
  - Commbobox FXA291 . . . . . 39
  - Degree of protection . . . . . 34
  - Measuring device . . . . . 27
  - Operating tools
    - Via service interface (CDI) . . . . . 39
- Electromagnetic compatibility . . . . . 80
- Enabling write protection . . . . . 53
- Endress+Hauser services
  - Maintenance . . . . . 69
  - Repair . . . . . 70
- Environment
  - Ambient temperature . . . . . 19
  - Mechanical load . . . . . 80
  - Shock resistance . . . . . 80
  - Storage temperature . . . . . 79
  - Vibration resistance . . . . . 80
- Error messages
  - see Diagnostic messages
- Event history . . . . . 65
- Events list . . . . . 65
- Ex approval . . . . . 86
- Ex connection data . . . . . 76
- Extended order code
  - Sensor . . . . . 13
  - Transmitter . . . . . 12

- Exterior cleaning . . . . . 69
- F**
- Field of application
- Residual risks . . . . . 9
- FieldCare . . . . . 39
- Device description file . . . . . 41
  - Establishing a connection . . . . . 39
  - Function . . . . . 39
  - User interface . . . . . 40
- Filtering the event logbook . . . . . 65
- Firmware
- Release date . . . . . 41
  - Version . . . . . 41
- Firmware history . . . . . 67
- Fitted electrodes . . . . . 85
- Flow direction . . . . . 18
- Flow limit . . . . . 81
- Function check . . . . . 45
- Function codes . . . . . 41
- Functions
- see Parameter
- G**
- Galvanic isolation . . . . . 76
- H**
- Hardware write protection . . . . . 53
- I**
- I/O electronics module . . . . . 10, 30
- Identifying the measuring device . . . . . 12
- Incoming acceptance . . . . . 11
- Information on the document . . . . . 5
- Inlet runs . . . . . 19
- Input . . . . . 74
- Inspection check
- Received goods . . . . . 11
- Installation . . . . . 17
- Installation conditions
- Adapters . . . . . 21
  - Down pipe . . . . . 17
  - Inlet and outlet runs . . . . . 19
  - Mounting location . . . . . 17
  - Orientation . . . . . 18
  - Partially filled pipe . . . . . 18
  - System pressure . . . . . 20
  - Vibrations . . . . . 20
- Installation dimensions . . . . . 19
- Interior cleaning . . . . . 69
- L**
- Languages, operation options . . . . . 85
- Low flow cut off . . . . . 76
- M**
- Main electronics module . . . . . 10
- Maintenance tasks . . . . . 69
- Replacing seals . . . . . 69
- Manufacturer ID . . . . . 41
- Manufacturing date . . . . . 12, 13
- Materials . . . . . 84
- Maximum measured error . . . . . 78
- Measured variables
- Calculated . . . . . 74
  - Measured . . . . . 74
  - see Process variables
- Measuring and test equipment . . . . . 69
- Measuring device
- Configuration . . . . . 45
  - Conversion . . . . . 70
  - Design . . . . . 10
  - Disposal . . . . . 71
  - Integrating via HART protocol . . . . . 41
  - Mounting the sensor . . . . . 22
    - Mounting the ground cable/ground disks . . . . . 22
    - Mounting the seals . . . . . 22
    - Screw tightening torques . . . . . 23
  - Preparing for electrical connection . . . . . 29
  - Preparing for mounting . . . . . 21
  - Removing . . . . . 70
  - Repair . . . . . 70
- Measuring principle . . . . . 74
- Measuring range . . . . . 74
- Measuring system . . . . . 74
- Measuring tube specification . . . . . 83
- Mechanical load . . . . . 80
- Media . . . . . 8
- Medium temperature range . . . . . 80
- Menus
- For measuring device configuration . . . . . 45
  - For specific settings . . . . . 50
- Modbus RS485
- Configuring error response mode . . . . . 61
  - Diagnostic information . . . . . 61
  - Function codes . . . . . 41
  - Modbus data map . . . . . 42
  - Read access . . . . . 41
  - Reading out data . . . . . 43
  - Register addresses . . . . . 42
  - Register information . . . . . 42
  - Response time . . . . . 42
  - Scan list . . . . . 43
  - Write access . . . . . 41
- Modbus RS485 certification . . . . . 86
- Mounting dimensions
- see Installation dimensions
- Mounting location . . . . . 17
- Mounting preparations . . . . . 21
- Mounting requirements
- Installation dimensions . . . . . 19
- Mounting tools . . . . . 21
- N**
- Nameplate
- Sensor . . . . . 13
  - Transmitter . . . . . 12

- O**
- Operable flow range . . . . . 75
  - Operating menu
    - Menus, submenus . . . . . 37
    - Overview of menus with parameters . . . . . 88
    - Structure . . . . . 37
    - Submenus and user roles . . . . . 38
  - Operating philosophy . . . . . 38
  - Operation . . . . . 55
  - Operation options . . . . . 36, 36
  - Operational safety . . . . . 9
  - Order code . . . . . 12, 13
  - Orientation (vertical, horizontal) . . . . . 18
  - Outlet runs . . . . . 19
  - Output . . . . . 76
  - Output signal . . . . . 76
  - Overview
    - Operating menu . . . . . 88
- P**
- Packaging disposal . . . . . 16
  - Parameter settings
    - Empty pipe detection (EPD) . . . . . 49
    - For communication interface . . . . . 47
    - For electrode cleaning circuit (ECC) . . . . . 52
    - For low flow cut off . . . . . 48
    - For sensor adjustment . . . . . 50
    - For system units . . . . . 46
    - For the operation . . . . . 58
    - For the totalizer . . . . . 51
  - Partially filled pipe . . . . . 18
  - Performance characteristics . . . . . 78
  - Post-connection check (checklist) . . . . . 35
  - Post-installation check . . . . . 45
  - Post-installation check (checklist) . . . . . 25
  - Potential equalization . . . . . 32, 78
  - Power consumption . . . . . 77
  - Power supply failure . . . . . 77
  - Pressure Equipment Directive . . . . . 86
  - Pressure loss . . . . . 82
  - Pressure tightness . . . . . 81
  - Pressure-temperature ratings . . . . . 80
  - Process
    - Conductivity . . . . . 80
    - Flow limit . . . . . 81
    - Medium temperature . . . . . 80
    - Pressure loss . . . . . 82
    - Pressure tightness . . . . . 81
  - Process connections . . . . . 85
  - Product safety . . . . . 9
  - Protecting parameter settings . . . . . 53
- R**
- Reading measured values . . . . . 55
  - Reading out diagnostic information, Modbus RS485 . . . . . 61
  - Recalibration . . . . . 69
  - Reference operating conditions . . . . . 78
  - Registered trademarks . . . . . 7
  - Remote operation . . . . . 85
  - Repair . . . . . 70
    - Notes . . . . . 70
  - Repair of a device . . . . . 70
  - Repeatability . . . . . 79
  - Replacement
    - Device components . . . . . 70
  - Replacing seals . . . . . 69
  - Requirements for personnel . . . . . 8
  - Returning devices . . . . . 70
- S**
- Safety . . . . . 8
  - Screw tightening torques . . . . . 23
  - Sensor
    - Mounting . . . . . 22
  - Serial number . . . . . 12, 13
  - Service interface (CDI) . . . . . 85
  - Settings
    - Adapting the measuring device to the process conditions . . . . . 56
    - Communication interface . . . . . 46
    - Device reset . . . . . 66
    - Electrode cleaning circuit . . . . . 51
    - Empty pipe detection (EPD) . . . . . 49
    - Low flow cut off . . . . . 48
    - Resetting the totalizer . . . . . 57
    - Sensor adjustment . . . . . 50
    - Simulation . . . . . 52
    - System units . . . . . 45
    - Totalizer . . . . . 50
    - Totalizer reset . . . . . 57
  - Shock resistance . . . . . 80
  - Signal on alarm . . . . . 76
  - Software release . . . . . 41
  - Spare part . . . . . 70
  - Spare parts . . . . . 70
  - Standards and guidelines . . . . . 86
  - Status signals . . . . . 60
  - Storage conditions . . . . . 15
  - Storage temperature . . . . . 15
  - Storage temperature range . . . . . 79
  - Structure
    - Operating menu . . . . . 37
  - Submenu
    - Communication . . . . . 47
    - Device information . . . . . 66
    - Electrode cleaning circuit (ECC) . . . . . 51
    - Empty pipe detection (EPD) . . . . . 49
    - Events list . . . . . 65
    - Low flow cut off . . . . . 48
    - Operation . . . . . 57
    - Overview . . . . . 38
    - Process variables . . . . . 55, 55
    - Sensor adjustment . . . . . 50
    - System units . . . . . 45
    - Totalizer . . . . . 50, 56
  - Supply voltage . . . . . 77
  - Surface roughness . . . . . 85
  - System design

|   |        |
|---|--------|
| Measuring system . . . . .                      | 74     |
| see Measuring device design                     |        |
| System integration . . . . .                    | 41     |
| System pressure . . . . .                       | 20     |
| <b>T</b>  |        |
| Technical data, overview . . . . .              | 74     |
| Temperature measurement response time . . . . . | 79     |
| Temperature range                               |        |
| Storage temperature . . . . .                   | 15     |
| Terminal assignment . . . . .                   | 28, 30 |
| Terminals . . . . .                             | 78     |
| Tools   |        |
| Electrical connection . . . . .                 | 27     |
| For mounting . . . . .                          | 21     |
| Transport . . . . .                             | 15     |
| Transmitter                                     |        |
| Connecting the signal cables . . . . .          | 30     |
| Transporting the measuring device . . . . .     | 15     |
| Troubleshooting                                 |        |
| General . . . . .                               | 59     |
| <b>U</b>  |        |
| Use of the measuring device                     |        |
| Borderline cases . . . . .                      | 8      |
| Incorrect use . . . . .                         | 8      |
| see Designated use                              |        |
| User roles . . . . .                            | 38     |
| <b>V</b>  |        |
| Version data for the device . . . . .           | 41     |
| Vibration resistance . . . . .                  | 80     |
| Vibrations . . . . .                            | 20     |
| <b>W</b>  |        |
| W@M . . . . .                                   | 69, 70 |
| W@M Device Viewer . . . . .                     | 12, 70 |
| Weight  |        |
| Compact version . . . . .                       | 82     |
| Transport (notes) . . . . .                     | 15     |
| Workplace safety . . . . .                      | 9      |
| Write protection                                |        |
| Via write protection switch . . . . .           | 53     |
| Write protection switch . . . . .               | 53     |

## Declaration of Hazardous Material and De-Contamination *Erklärung zur Kontamination und Reinigung*

**RA No.**

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.  
*Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.*

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

*Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.*

**Type of instrument / sensor**

Geräte-/Sensortyp \_\_\_\_\_

**Serial number**

Seriennummer \_\_\_\_\_

**Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzeinrichtungen**

**Process data / Prozessdaten**

Temperature / Temperatur \_\_\_\_\_ [°F] \_\_\_\_\_ [°C]

Pressure / Druck \_\_\_\_\_ [psi] \_\_\_\_\_ [ Pa ]

Conductivity / Leitfähigkeit \_\_\_\_\_ [µS/cm]

Viscosity / Viskosität \_\_\_\_\_ [cp] \_\_\_\_\_ [mm<sup>2</sup>/s]

**Medium and warnings**

Warnhinweise zum Medium



|   | Medium / concentration<br><i>Medium / Konzentration</i> | Identification<br>CAS No. | flammable<br><i>entzündlich</i> | toxic<br><i>giftig</i> | corrosive<br><i>ätzend</i> | harmful/<br>irritant<br><i>gesundheitsschädlich/<br/>reizend</i> | other *<br><i>sonstiges*</i> | harmless<br><i>unbedenklich</i> |
|---|---|---------------------------|---------------------------------|------------------------|----------------------------|--|------------------------------|---------------------------------|
| Process medium<br><i>Medium im Prozess</i>                        |   |                           |                                 |                        |                            |  |                              |                                 |
| Medium for process cleaning<br><i>Medium zur Prozessreinigung</i> |   |                           |                                 |                        |                            |  |                              |                                 |
| Returned part cleaned with<br><i>Medium zur Endreinigung</i>      |   |                           |                                 |                        |                            |  |                              |                                 |

\* explosive; oxidizing; dangerous for the environment; biological risk; radioaktiv

\* *explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv*

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

*Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.*

**Description of failure / Fehlerbeschreibung** \_\_\_\_\_

**Company data / Angaben zum Absender**

|   |   |
|---|---|
| Company / Firma _____                   | Phone number of contact person / Telefon-Nr. Ansprechpartner: _____ |
| Address / Adresse _____                 | Fax / E-Mail _____  |
| Your order No. / Ihre Auftragsnr. _____ |   |

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

*"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefahrbringender Menge sind."*

\_\_\_\_\_  
(place, date / Ort, Datum)

\_\_\_\_\_  
Name, dept./Abt. (please print / bitte Druckschrift)

\_\_\_\_\_  
Signature / Unterschrift

[www.addresses.endress.com](http://www.addresses.endress.com)

---