



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services




Solutions

Operating Instructions

Proline t-mass B 150

HART

Thermal Mass Flow Measuring System



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress +Hauser distributor will supply you with current information and updates to these Instructions.

Table of contents

1	Document information	5	7	Electrical connection	23
1.1	Document function	5	7.1	Connection conditions	23
1.2	Document conventions	5	7.1.1	Required tools	23
1.2.1	Safety symbols	5	7.1.2	Requirements for connecting cable	23
1.2.2	Electrical symbols	5	7.1.3	Requirements for the supply unit	23
1.2.3	Tool symbols	5	7.1.4	Terminal assignment	23
1.2.4	Symbols for certain types of information	6	7.1.5	Preparing the measuring device	24
1.2.5	Symbols in graphics	6	7.2	Connecting the measuring device	24
1.3	Documentation	7	7.2.1	Connecting the cables	25
1.3.1	Standard documentation	7	7.3	Ensuring the degree of protection	25
1.3.2	Supplementary device-dependent documentation	7	7.4	Post-connection check	26
2	Basic safety instructions	8	8	Operation options	27
2.1	Requirements for the personnel	8	8.1	Overview of operation options	27
2.2	Designated use	8	8.2	Structure and function of the operating menu	27
2.3	Workplace safety	9	8.2.1	Structure of the operating menu	27
2.4	Operational safety	9	8.2.2	Operating philosophy	29
2.5	Product safety	9	8.3	Access to the operating menu via the local display	30
3	Product description	10	8.3.1	Operational display	30
3.1	Product design	10	8.3.2	Navigation view	32
3.2	Registered trademarks	10	8.3.3	Editing view	34
4	Incoming acceptance and product identification	11	8.3.4	Operating elements	35
4.1	Incoming acceptance	11	8.3.5	Opening the context menu	36
4.2	Product identification	12	8.3.6	Navigating and selecting from list	38
4.2.1	Transmitter nameplate	12	8.3.7	Calling up help text	38
4.2.2	Sensor nameplate	13	8.3.8	Changing the parameters	40
5	Storage and transport	14	8.3.9	User roles and related access authorization	41
5.1	Storage conditions	14	8.3.10	Disabling write protection via access code	41
5.2	Transporting the product	14	8.3.11	Enabling and disabling the keypad lock	41
5.3	Packaging disposal	14	8.4	Access to the operating menu via the operating tool	43
6	Installation	15	8.4.1	Field Xpert SFX100	43
6.1	Installation conditions	15	8.4.2	FieldCare	43
6.1.1	Mounting position	15	8.4.3	AMS Device Manager	43
6.1.2	Requirements from environment and process	19	8.4.4	SIMATIC PDM	44
6.2	Mounting the measuring device	20	8.4.5	Field Communicator 375, 475	44
6.2.1	Required tools	20	8.4.6	Connecting operating tools	44
6.2.2	Preparing the measuring device	20	9	System integration	46
6.2.3	Mounting the measuring device	20	9.1	Overview of device description files	46
6.2.4	Turning the transmitter housing	20	9.1.1	Current version data for the device	46
6.2.5	Turning the display module	21	9.1.2	Operating tools	46
6.3	Post-mounting check	21	9.2	Measured variables via HART protocol	46
			9.3	Other settings	47
			10	Commissioning	48
			10.1	Function check	48
			10.2	Switching on the measuring device	48
			10.3	Setting the operating language	48

10.4	Configuring the measuring device	49	13	Repair	92
10.4.1	Selecting the gas type	49	13.1	General notes	92
10.4.2	Specifying the process pressure	50	13.2	Spare parts	92
10.4.3	Configuring the sensor data	51	13.3	Endress+Hauser services	92
10.4.4	Determining the installation factor	51	14	Maintenance	93
10.4.5	Configuring the current output	53	14.1	Maintenance tasks	93
10.4.6	Configuring the pulse/frequency/switch output	53	14.1.1	Exterior cleaning	93
10.5	Advanced settings	55	14.1.2	Interior cleaning	93
10.5.1	Defining the tag name	56	14.2	Measuring and test equipment	93
10.5.2	Configuring applications	56	14.3	Endress+Hauser services	93
10.5.3	Setting the system units	57	15	Return	94
10.5.4	Configuring the current output	60	16	Disposal	95
10.5.5	Configuring the PFS output	62	16.1	Removing the measuring device	95
10.5.6	Configuring the output conditioning	67	16.2	Disposing of the measuring device	95
10.5.7	Configuring the low flow cut off	68	17	Technical data	96
10.5.8	Configuring the totalizer	69	17.1	Application	96
10.5.9	Configuring the local display	69	17.2	Function and system design	96
10.6	Configuration management	71	17.3	Characteristic values	96
10.7	Simulation	72	17.4	Output	98
10.8	Protecting settings from unauthorized access	73	17.5	Power supply	101
10.8.1	Write protection via access code	73	17.6	Performance characteristics	103
10.8.2	Write protection via lock switch	74	17.7	Installation	104
11	Operation	76	17.8	Environment	104
11.1	Adjusting the operating language	76	17.9	Process	105
11.2	Configuring the display	76	17.10	Mechanical construction	106
11.2.1	Navigation path	76	17.11	Operability	110
11.2.2	Parameter overview with brief description	76	17.12	Certificates and approvals	112
11.3	Reading off measured values	76	17.13	Application packages	113
11.3.1	Process variables	76	17.14	Accessories	113
11.3.2	Totalizer	77	18	Appendix	114
11.3.3	Output values	78	18.1	Overview of the Operator/Maintenance operating menu	114
11.4	Adapting the measuring device to the process conditions	78	Index	132	
11.5	Performing a totalizer reset	79			
11.6	Showing data logging	80			
12	Diagnostics and troubleshooting	81			
12.1	General troubleshooting	81			
12.2	Diagnostic information on local display	83			
12.2.1	Diagnostic message	83			
12.2.2	Calling up remedial measures	84			
12.3	Diagnostic information in the operating tool	85			
12.4	Adapting the diagnostic information	85			
12.4.1	Adapting the diagnostic behavior	85			
12.5	Overview of diagnostic information	86			
12.6	Resetting the measuring device	88			
12.7	Diagnostics list	88			
12.8	Event logbook	89			
12.8.1	Event history	89			
12.8.2	Filtering the event logbook	90			
12.8.3	Overview of information events	90			

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Document conventions

1.2.1 Safety symbols

Symbol	Meaning
 A0011189-EN	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 A0011190-EN	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 A0011191-EN	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 A0011192-EN	NOTICE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
 A0011197	Direct current A terminal to which DC voltage is applied or through which direct current flows.
 A0011198	Alternating current A terminal to which alternating voltage (sine-wave) is applied or through which alternating current flows.
 A0011200	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
 A0011199	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
 A0011201	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Tool symbols

Symbol	Meaning
 A0013442	Torx screwdriver
 A0011220	Flat blade screwdriver
 A0011219	Phillips head screwdriver

Symbol	Meaning
 A0011221	Allen key
 A0011222	Hexagon wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning
 A0011182	Allowed Indicates procedures, processes or actions that are allowed.
 A0011183	Preferred Indicates procedures, processes or actions that are preferred.
 A0011184	Forbidden Indicates procedures, processes or actions that are forbidden.
 A0011193	Tip Indicates additional information.
 A0011194	Reference to documentation Refers to the corresponding device documentation.
 A0011195	Reference to page Refers to the corresponding page number.
 A0011196	Reference to graphic Refers to the corresponding graphic number and page number.
	Series of steps
	Result of a sequence of actions
 A0013562	Help in the event of a problem

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3,...	Item numbers
	Series of steps
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections
 A0013441	Flow direction
 A0011187	Hazardous area Indicates a hazardous area.
 A0011188	Safe area (non-hazardous area) Indicates a non-hazardous location.

1.3 Documentation

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.



The document types listed are available:

- On the CD-ROM supplied with the device
- In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download

1.3.2 Supplementary device-dependent documentation

If the device is being used in a hazardous location: Instructions in the relevant supplementary documentation must be consistently observed. The supplementary documentation is an integral part of the device documentation.

Document type	Device particularities and document content
Safety Instructions	Operation in hazardous areas The document contains all the necessary information for the safe operation of the device in hazardous areas, and explains how the device can be identified as an Ex system from the device nameplate.
Installation Instructions	Ordered accessory The Installation Instructions contain all the information needed to install the ordered accessory or spare part.



The document types listed are available:

- On the CD-ROM supplied with the device
- In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

The measuring device described in these Instructions is intended only for flow measurement of gases.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.

Incorrect use

The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Risk of injury if the process connection and sensor gland are opened under pressure.

- ▶ The process connection and the sensor gland should only be opened in an unpressurized state.

NOTICE

Dust and moisture can enter the transmitter when the transmitter housing is opened.

- ▶ Only open the transmitter housing briefly, ensuring that no dust or moisture enters the housing.

NOTICE

Danger of breakage of the sensor due to corrosive or abrasive fluids!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified maximum process pressure.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

The external surface temperature of the housing can increase by max. 15 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.


2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which they are safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

3 Product description

3.1 Product design



A0017196

- 1 Electronics compartment cover
- 2 Display module
- 3 Terminal block
- 4 Electronics module
- 5 Cable gland
- 6 Transmitter housing
- 7 Sensor
- 8 S-DAT

3.2 Registered trademarks

HART®


Registered trademark of the HART Communication Foundation, Austin, USA

Applicator®, FieldCare®, Field Xpert™, HistoROM®

Registered or registration-pending trademarks of the Endress+Hauser Group


4 Incoming acceptance and product identification

4.1 Incoming acceptance




A0013843

Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?




A0013695




A0013698

Are the goods undamaged?



A0013699

Do the nameplate data match the ordering information on the delivery note?



A0013697

Is the CD-ROM with the Technical Documentation and documents present?

 If one of the conditions does not comply, contact your Endress+Hauser distributor.

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.

For an overview of the scope of the Technical Documentation provided, refer to the following:

- The chapters "Additional standard documentation on the device" (→  7) and "Supplementary device-dependent documentation" (→  7)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)


4.2.1 Transmitter nameplate



 1 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Type of cable glands
- 8 Permitted ambient temperature (T_a)
- 9 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 10 CE mark, C-Tick
- 11 Additional information on version: certificates, approvals
- 12 Permitted temperature range for cable
- 13 Manufacturing date: year-month
- 14 Degree of protection
- 15 Approval information for explosion protection
- 16 Document number of safety-related supplementary documentation (→  7)
- 17 2-D matrix code

4.2.2 Sensor nameplate



A0017233

2 Example of 1st sensor nameplate

- 1 Name of the sensor
- 2 Serial number (Ser. no.)
- 3 CE mark, C-Tick
- 4 Process pressure range
- 5 Medium temperature range
- 6 Measuring tube material
- 7 Seal material
- 8 Thread data
- 9 Sensor length
- 10 Approval information for Pressure Equipment Directive
- 11 Manufacturing date: year-month

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications have also been ordered, they are indicated collectively by the placeholder symbol "#" (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove the protection cap mounted on the transducer. It prevents mechanical damage and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→  19)

5.2 Transporting the product

Observe the following notes during transport:

- Transport the measuring device to the measuring point in the original packaging.
- Do not remove the protection cap mounted on the transducer. It prevents mechanical damage and contamination.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
 - or
 - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation

6.1 Installation conditions

For mechanical reasons and to protect the pipe, support is recommended for heavy sensors (e.g. with a hot-tap retractable assembly).

6.1.1 Mounting position





Mounting location

Thermal measuring devices require a fully developed flow profile as a prerequisite for correct flow measurement. For this reason, please pay attention to the following points and document sections when installing the device:

- Avoid flow disturbances, as the thermal measuring principle reacts sensitively to them.
- Take measures to avoid condensation (e.g. condensation trap, thermal insulation etc.).
- For mechanical reasons and to protect the pipe, support is recommended for heavy sensors (e.g. when installing a retractable assembly).

Orientation

The direction of the arrow on the sensor helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Orientation	Recommendation
Vertical orientation	 A0017337	✓ ^{1) 2)}
Horizontal orientation, transmitter head up	 A0015589	✓✓
Horizontal orientation, transmitter head down	 A0015590	✓✓ ³⁾
Inclined mounting position, transmitter head down	 A0015773	✓ ⁴⁾


- 1) In the case of saturated or unclean gases, upward flow in a vertical pipe section is preferred to minimize condensation or contamination.
- 2) Not recommended in the case of extreme vibrations or unstable installations.
- 3) Suitable only for clean and dry gases. If buildup or condensate are always present: Mount the sensor in an inclined position.
- 4) Select inclined mounting position ($\alpha = \text{approx. } 135^\circ$) if the gas is very wet or saturated with water.

Requirement for pipework

The measuring device must be professionally installed, and the following points must be observed:

- Piping must be professionally welded.
- Seals must be sized correctly.
- Flanges and seals must be correctly aligned.
- The internal diameter of the pipe must be known. The maximum permitted deviation from the input value is:
 - 1 mm (0.04 in) at DN < 200 mm (8 in)
 - 3 mm (0.12 in) at DN ≥ 200 mm (8 in)
- Following installation, the pipe must be free from dirt and particles in order to avoid damage to the sensors.

Further information → ISO standard 14511




Choosing the sensor length

The minimum length of the sensor can be calculated using the Endress+Hauser calculation program Applicator (from version 10.00) or using the following calculation.

The minimum length of the sensor is determined by the required insertion depth. The required insertion depth that is calculated must be within the adjusting range of the selected insertion version.

- ▶ Determining the dimensions A, B, C1 and C2



A0015768

- A Internal pipe diameter DN (circular pipe) or internal dimension (rectangular duct)
- B Thickness of pipe wall or of duct wall
- C1 Length of mounting set
- C2 Length of sensor compression fitting

Determining C1 and C2 (Endress+Hauser original parts only)

DK6MB-BXA mounting boss G1A	C1 + C2 = 99 mm (3.90 in)
DK6MB-DXA mounting boss G3/4A	C1 + C2 = 99 mm (3.90 in)
DK6MB-AXA mounting boss 1" NPT	C1 + C2 = 107 mm (4.21 in)
DK6MB-CXA mounting boss 3/4" NPT	C1 + C2 = 102 mm (4.02 in)


Determining C1 and C2 (not limited to Endress+Hauser original parts)

C1	Length of pipe connection used
C2 (compression fitting with G1A thread)	39 mm (1.54 in)
C2 (compression fitting with G3/4A thread)	39 mm (1.54 in)
C2 (compression fitting with 1" NPT thread)	47 mm (1.85 in)
C2 (compression fitting with 3/4" NPT thread)	42 mm (1.65 in)

► Calculating insertion depth

$$(0.3 \cdot A) + B + (C1 + C2)$$

Mounting conditions for mounting boss




A0011843

$$D = 31.0 \text{ mm} \pm 0.05 \text{ mm} (1.22 \text{ in} \pm 0.02 \text{ in})$$

- When installing in rectangular ducts with thin walls:
 - ✓ Use suitable support brackets.

Align the insertion version with the direction of flow.



A0015746


Check and ensure that the sensor on the pipe/duct is aligned at a 90° angle to the direction of flow. Rotate the sensor so that the arrow marking on the sensor body corresponds to the direction of flow. The line marking on the body used to adjust the insertion depth must be aligned with the direction of flow.

Inlet and outlet runs

The thermal measuring principle is sensitive to disturbed flow conditions.

- As a general rule, the measuring device should always be installed as far away as possible from any flow disturbances. For further information, please refer to → ISO 14511.
- If possible, the sensor should be installed upstream from valves, T-pieces, elbows etc. To attain the specified level of accuracy of the measuring device, the below mentioned inlet and outlet runs must be maintained at minimum. If there are several flow disturbances present, the longest specified inlet run must be maintained.

Recommended inlet and outlet runs



A0016943


- 1 reduction
- 2 expansion
- 3 90° elbow or T-piece
- 4 2 x 90° elbow
- 5 Control valve
- 6 2 x 90° elbow (3-dimensional)

Installation dimensions

 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Outlet run for pressure or temperature transmitter

If a pressure or temperature measuring device is installed downstream of the measuring device, make sure there is sufficient distance between the two devices.



A0015003

PT Pressure measuring device
 TT Temperature measuring device

6.1.2 Requirements from environment and process

Ambient temperature range

Measuring device	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to +60 °C (-4 to +140 °F), the readability of the display may be impaired at temperatures outside the temperature range.

- ▶ If operating outdoors:
 Avoid direct sunlight, particularly in warm climatic regions.

System pressure

Sensor

Depending on the version, please note the details on the name plate .
 Max. 20 bar g (290 psi g)


Thermal insulation

If the gas is very humid or saturated with water, the pipe and the sensor housing should be insulated to prevent water droplets condensing on the transducer.

NOTICE

Electronics overheating on account of thermal insulation!

- ▶ Observe maximum permitted insulation height of the transmitter neck so that the transmitter head is completely free.



A0015763

6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

For turning the transmitter housing (in increments of 90°): Allen screw 4 mm (0.15 in)

For sensor

For the sensor gland: Corresponding mounting tools

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove the protective cap from the sensor.
3. Remove stick-on label on the electronics compartment cover.


6.2.3 Mounting the measuring device

⚠ WARNING

Danger due to improper process sealing!


- ▶ Ensure that the gaskets are clean and undamaged (G 1 A, G ¾ A).
- ▶ Ensure that the correct sealing material has been used (e.g. Teflon tape for NPT 1", NPT ¾").
- ▶ Install the gaskets correctly.

1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.




Ensure the insertion depth and alignment are correct. Thread adapter nut: when mounting for the first time, tighten it fingertight + 1 ½ turns. For all other mounting routines, tighten it fingertight and 1 additional turn

3. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned clockwise or counterclockwise to 4 indexed positions by a maximum of 2 x 90°:



A0017227

1. Unscrew the securing screw using an Allen key.
2. Rotate the housing in the desired direction.
3. Firmly tighten the securing screw.

6.2.5 Turning the display module



A0017228

1. Remove the cover of the electronics compartment.
2. Pull out the display module with a gentle rotational movement.
3. Turn the display module to the desired position: Max. $4 \times 90^\circ$ in each direction.
4. Feed the ribbon cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment and turn it until it engages.
5. Screw the cover of the electronics compartment back on.

6.3 Post-mounting check

Is the device damaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ■ Process temperature (→ 105) ■ Process pressure (refer to the chapter on "Material load curves" of the "Technical Information" document) ■ Ambient temperature range (→ 19) ■ Measuring range (→ 96) 	<input type="checkbox"/>

Has the correct orientation for the sensor been selected (→ 15)? <ul style="list-style-type: none"> ■ According to sensor type ■ According to medium properties ■ According to medium temperature ■ According to process pressure 	<input type="checkbox"/>
Does the arrow on the sensor match the direction of flow of the medium through the piping (→ 15)?	<input type="checkbox"/>
Have sufficient inlet and outlet runs been provided upstream and downstream of the measuring point?	<input type="checkbox"/>
Correctly aligned in the direction of flow?	<input type="checkbox"/>
Correct sensor immersion depth?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Is the device protected against overheating?	<input type="checkbox"/>
Is the device protected against excessive vibrations?	<input type="checkbox"/>
Check gas property (e.g. purity, dryness, cleanness).	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>

7 Electrical connection

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- Wire stripper
- When using stranded cables: Crimping tool for wire end ferrule
- Flat blade screwdriver ≤ 3 mm (0.12 in)

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Cable specification

Permitted temperature range:

- -40 °C (-40 °F)...≥ 80 °C (176 °F)
- Minimum requirement for cable temperature range: ambient temperature +20 K

Current output

For 4-20 mA HART: Shielded cable recommended. Observe grounding concept of the plant.

Pulse/frequency/switching output

Standard installation cable is sufficient

Cable diameter

- Included cable glands: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Core cross-sectional area 0.5 to 1.5 mm² (21 to 16 AWG)

7.1.3 Requirements for the supply unit

Device supply voltage

DC 24 V (18 to 30 V)

The power supply circuit must comply with ELV (BS 7671) requirements.

Pulse/frequency/status supply voltage

An external power supply is required for each output.


Order characteristic for "Output"	Maximum terminal voltage
Option B, K	DC 30 V

Load

0 to 750 Ω, depending on the external supply voltage of the power supply unit

7.1.4 Terminal assignment

The terminal assignment for the electrical connection can be found on the nameplate of the electronics module.



A0017222

7.1.5 Preparing the measuring device

1. Remove dummy plug if present.
2. **NOTICE!** Insufficient sealing of the housing. Operational reliability of the measuring device could be defeated. Use suitable cable glands corresponding to the degree of protection.
If measuring device is delivered without cable glands:
Provide suitable cable gland for corresponding connecting cable. (→ 23)
3. If measuring device is delivered with cable glands:
Observe cable specification (→ 23).


7.2 Connecting the measuring device

NOTICE

Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ SELV/PELV-compliant 24 V DC (18 to 30 V) power supply.
- ▶ 4 to 20 mA HART active
- ▶ Maximum output values: DC 24V, 22 mA, load 0 to 750 Ω

7.2.1 Connecting the cables



1. Unscrew the connection compartment cover.
2. Remove the display module.
3. Push the supply cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit wire end ferrules.
5. Connect the cable in accordance with the terminal assignment (→ 101). For HART communication: When connecting the cable shielding to the ground terminal, observe the grounding concept of the facility.
6. Firmly tighten the screws in the terminal block.
7. Perform the same steps for the signal cable as for the power supply cable.
8. Insert the terminal block into the electronics module.
9. Firmly tighten the cable glands.
10. **NOTICE!** Housing degree of protection voided due to insufficient sealing of the housing. Screw in the thread without using any lubricant. The threads on the cover are coated with a dry lubricant.
Reverse the removal procedure to reassemble the transmitter.


7.3 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66 and IP67 (Type 4X enclosure) degree of protection.

To guarantee IP 66 and IP 67 degree of protection (Type 4X enclosure), carry out the following steps after the electrical connection:

1. Check whether the housing seals of the connection and electronics compartment are clean and inserted correctly. Dry, clean or replace the seals if necessary.

2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0013960


5. Insert dummy plugs into unused cable entries.

7.4 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Are the power supply and signal cables correctly connected?	<input type="checkbox"/>
Does the supply voltage correspond to the specifications in the connection diagram?	<input type="checkbox"/>
Do the cables comply with the requirements (→ 23)?	<input type="checkbox"/>
Do the cables have adequate strain relief? Are they routed securely?	<input type="checkbox"/>
Is the cable route completely isolated? Without loops and cross-overs?	<input type="checkbox"/>
Are all the screw terminals firmly tightened?	<input type="checkbox"/>
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→ 23) ?	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate (→ 23)?	<input type="checkbox"/>
Is the terminal assignment correct (→ 23)?	<input type="checkbox"/>
If supply voltage is present, is the device ready for operation and do values appear on the display module?	<input type="checkbox"/>
Are all housing covers installed and firmly tightened?	<input type="checkbox"/>

8 Operation options

8.1 Overview of operation options



A0015607


- 1 Local operation via display module
- 2 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX100
- 4 Field Communicator 375, 475
- 5 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters (→  114)

 For an overview of the operating menu for experts: "Description of Device Parameters" document supplied with the device



A0013431-EN


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles. Each user role contains typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation:	Defining the operating language
Display/operat.		<ul style="list-style-type: none"> ■ Configuring the measured value display ■ Reading measured values 	Configuration of the measured value display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning:	<ul style="list-style-type: none"> ■ Configuration of the measurement ■ Configuration of the outputs
Diagnostics		"Maintenance" role Fault elimination:	Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ■ "Diagnostics list" submenu Contains up to 5 currently pending diagnostic messages. ■ "Event logbook" submenu Contains up to 20 or 100 (order option) event messages that have occurred. ■ "Device info" submenu Contains information for identifying the device. ■ "Measured values" submenu Contains all current measured values. ■ "Data logging" submenu (order option) Storage and visualization of up to 1000 measured values ■ "Simulation" submenu Is used to simulate measured values or output values. ■ "Device reset" submenu Resets the device configuration to certain settings
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> ■ Commissioning measurements under difficult conditions ■ Optimal adaptation of the measurement to difficult conditions ■ Detailed configuration of the communication interface ■ Error diagnostics in difficult cases 	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> ■ "System" submenu Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. ■ "Sensor" submenu Contains all parameters for configuring the measurement. ■ "Output" submenu Contains all parameters for configuring the analog current outputs. ■ "Communication" submenu Contains all parameters for configuring the digital communication interface. ■ "Application" submenu Contains all parameters for configuring the functions that go beyond the actual measurement (e.g. totalizer). ■ "Diagnostics" submenu Contains all parameters for error detection and analyzing process and device errors and for device simulation.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



Status area

The following symbols appear in the status area of the operational display at the top right:

Status signals

Symbol	Meaning
F <small>A0013956</small>	Failure A device error has occurred. The measured value is no longer valid.
C <small>A0013959</small>	Function check The device is in service mode (e.g. during a simulation).
S <small>A0013958</small>	Out of specification The device is operated: <ul style="list-style-type: none"> Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
M <small>A0013957</small>	Maintenance required Maintenance is required. The measured value is still valid.

Diagnostic behavior

Symbol	Meaning
 <small>A0013961</small>	Alarm Measurement is interrupted. The signal outputs and totalizers assume the defined alarm condition. A diagnostics message is generated (→ 83).
 <small>A0013962</small>	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostics message is generated (→ 83).

Locking

Symbol	Meaning
 <small>A0013963</small>	Device locked The measuring device is hardware locked (→ 73).

Communication

Symbol	Meaning
 A0013965	Communication via remote operation is active.

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

	Measured variable	Measurement channel number	Diagnostic behavior
	↓	↓	↓
Example	 A0013945	 A0013948	 A0013962
			Appears only if a diagnostics event is present for this measured variable.

Measured variables

Symbol	Meaning
 A0013711	Corrected volume flow, FAD
 A0013710	Mass flow
 A0013947	Temperature
 A0013943	Totalizer
 A0013945	Current output

Measurement channel numbers

Symbol	Meaning
 A0016325	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type.	

Diagnostic behavior


The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For more information about the symbols, refer to the "Status area" section (→ 32).

 The number and display of the measured values can be configured via the parameter **Format display**.

Navigation path


"Display/operat." menu → Display → Format display

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



 For more information about the menu icons, refer to the "Display area" section (→ 33)

Status area

The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
 - If a diagnostic event is present, the diagnostic behavior and status signal

 For information on the diagnostic behavior and status signal (→ 32)

 About the function and input of the direct access code refer to the document "Description of Device Parameters"

Display area

Menus

Symbol	Meaning
 A0013973	Display/operat. Appears: <ul style="list-style-type: none"> In the menu next to the "Display/operat." selection At the left in the navigation path in the "Display/operat." menu
 A0013974	Setup Appears: <ul style="list-style-type: none"> In the menu next to the "Setup" selection At the left in the navigation path in the "Setup" menu
 A0013975	Diagnostics Appears: <ul style="list-style-type: none"> In the menu next to the "Diagnostics" selection At the left in the navigation path in the "Diagnostics" menu
 A0013966	Expert Appears: <ul style="list-style-type: none"> In the menu next to the "Expert" selection At the left in the navigation path in the "Expert" menu

Submenus, wizards, parameters

Symbol	Meaning
 A0013967	Submenu
 A0013968	Wizard
 A0013972	Parameters within a wizard  No display symbol exists for parameters in submenus.


Locking

Symbol	Meaning
 A0013963	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> By a user-specific access code (→  73) By the hardware lock switch (→  73)

Wizard operation

Symbol	Meaning
 A0013978	Switches to the previous parameter.
 A0013976	Confirms the parameter value and switches to the next parameter.
 A0013977	Opens the editing view of the parameter.

8.3.3 Editing view



Input mask

The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
	Selection of numbers from 0 to 9.
	Inserts decimal separator at the input position.
	Inserts minus sign at the input position.
	Confirms selection.
	Moves the input position one position to the left.
	Exits the input without applying the changes.
	Clears all entered characters.

Text editor

Symbol	Meaning
	Selection of letters from A to Z
	Toggle <ul style="list-style-type: none"> Between upper-case and lower-case letters For entering numbers For entering special characters




 <small>A0013985</small>	Confirms selection.
 <small>A0013987</small>	Switches to the selection of the correction tools.
 <small>A0013986</small>	Exits the input without applying the changes.
 <small>A0014040</small>	Clears all entered characters.

Correction symbols under 

Symbol	Meaning
 <small>A0013989</small>	Clears all entered characters.
 <small>A0013991</small>	Moves the input position one position to the right.
 <small>A0013990</small>	Moves the input position one position to the left.
 <small>A0013988</small>	Deletes one character immediately to the left of the input position.

8.3.4 Operating elements

Key	Meaning
 <small>A0013969</small>	<p>Minus key</p> <p><i>In a menu, submenu</i> Moves the selection bar upwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the previous parameter.</p> <p><i>With a text and numeric editor</i> In the input mask, moves the selection bar to the left (backwards).</p>
 <small>A0013970</small>	<p>Plus key</p> <p><i>In a menu, submenu</i> Moves the selection bar downwards in a choose list.</p> <p><i>With a Wizard</i> Confirms the parameter value and goes to the next parameter.</p> <p><i>With a text and numeric editor</i> Moves the selection bar to the right (forwards) in an input screen.</p>

Key	Meaning
 <small>A0013952</small>	<p>Enter key</p> <p><i>For operational display</i></p> <ul style="list-style-type: none"> Pressing the key briefly opens the operating menu. Pressing the key for 2 s opens the context menu. <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: <ul style="list-style-type: none"> If present, opens the help text for the function of the parameter. <p><i>With a Wizard</i></p> <p>Opens the editing view of the parameter.</p> <p><i>With a text and numeric editor</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
 <small>A0013971</small>	<p>Escape key combination (press keys simultaneously)</p> <p><i>In a menu, submenu</i></p> <ul style="list-style-type: none"> Pressing the key briefly: <ul style="list-style-type: none"> Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). <p><i>With a Wizard</i></p> <p>Exits the wizard and takes you to the next higher level.</p> <p><i>With a text and numeric editor</i></p> <p>Closes the text or numeric editor without applying changes.</p>
 <small>A0013953</small>	<p>Minus/Enter key combination (press the keys simultaneously)</p> <p>Reduces the contrast (brighter setting).</p>
 <small>A0013954</small>	<p>Plus/Enter key combination (press and hold down the keys simultaneously)</p> <p>Increases the contrast (darker setting).</p>
 <small>A0013955</small>	<p>Minus/Plus/Enter key combination (press the keys simultaneously)</p> <p><i>For operational display</i></p> <p>Enables or disables the keypad lock.</p>

8.3.5 Opening the context menu


Using the context menu, the user can call up the following three menus quickly and directly from the measured value display:

- Setup
- Conf. backup disp.
- Simulation

Calling up and closing the context menu

The user is in the measured value display.

- 2 s Press  for
 - ✓ The context menu opens.



A0014003-EN

2. Press \square + \square simultaneously.
 - ✓ The context menu is closed and the measured value display appears.

Calling up the menu via the context menu


1. Open the context menu.
2. Press \square to navigate to the desired menu.
3. Press \square to confirm the selection.
 - ✓ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

i For an explanation of the navigation view with symbols and operating elements (→ 32)

Example: Setting the number of displayed measured values to "2 values"



A0014010-EN

8.3.7 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. 2 s Press  for

- ✓ The help text for the selected parameter opens.



A0014002-EN

 3 *Example: Help text for parameter "Enter access code"*


2. Press  +  simultaneously.

- ✓ The help text is closed.

8.3.8 Changing the parameters


i For a description of the editing display - consisting of text editor and numeric editor - with symbols (→ 34), for a description of the operating elements (→ 30)

Example: Changing the parameter "20 mA value" to 20 kg/s



A0014020-EN

A message is displayed if the value entered is outside the permitted value range.



A0014049-EN

8.3.9 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access (→ 73).

Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	✓	✓	✓	– 1)
Maintenance	✓	✓	✓	✓

1) Despite the defined access code, certain parameters can always be modified and thus are exempted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Display/operation → Access status display

8.3.10 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display(→ 73).

The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

1. After you press , the input prompt for the access code appears.
2. Enter the access code.
 - ✓ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.


8.3.11 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is enabled and disabled in the same way:


The user is in the operational display.

- ▶ By simultaneously pressing the + + keys.
 - ✓ After enabling the keypad lock:



A0014000-EN

After disabling the keypad lock:



A0014001-EN

-  If the user attempts to access the operating menu while the keylock is enabled, the message "Keylock on" also appears.

8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.4.1 Field Xpert SFX100

Function scope

Compact, flexible and robust industrial handheld terminal for remote configuration and measured value display via HART protocol.

 For details, see Operating Instructions BA00060S

Source for device description files

See data (→  46)

8.4.2 FieldCare

Function scope

Field Device Table (FDT) based plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

- HART protocol
- Service interface

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

 For details, see Operating Instructions BA00027S and BA00059S

Source for device description files

See data (→  43)

User interface

8.4.3 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

Source for device description files

See data (→  43)

8.4.4 SIMATIC PDM

Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

Source for device description files

See data (→ 43)

8.4.5 Field Communicator 375, 475

Function scope


Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See data (→ 43)


8.4.6 Connecting operating tools

Via HART protocol



A0017373

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX100
- 6 VIATOR Bluetooth modem with connecting cable
- 7 Transmitter

Via service interface (CDI)

A0017253

- 1 Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)
- 2 Commubox FXA291
- 3 Computer with "FieldCare" operating tool

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.00.zz	<ul style="list-style-type: none"> ■ On the title page of the Operating instructions ■ On transmitter nameplate(→ 12) ■ Parameter firmware version Diagnostics → Device info→ Firmware version
Release date of firmware version	04.2012	—
Manufacturer ID	0x11	Manufacturer ID parameter Diagnostics → Device info→ Manufacturer ID
Device type ID	0x66	Device type parameter Diagnostics → Device info → Device type
HART protocol revision	6.0	—
Device revision	1	<ul style="list-style-type: none"> ■ On transmitter nameplate(→ 12) ■ Device revision parameter Diagnostics → Device info → Device revision

9.1.2 Operating tools

The following is a list of the suitable device description file for each individual operating tool with source.

Operating tool via HART protocol	Sources for obtaining device descriptions
Field Xpert SFX100	Use update function of handheld terminal
FieldCare	<ul style="list-style-type: none"> ■ www.endress.com → Download Area ■ CD-ROM (contact Endress+Hauser) ■ DVD (contact Endress+Hauser)
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area
SIMATIC PDM (Siemens)	www.endress.com → Download Area
Field Communicator 375, 475 (Emerson Process Management)	Use update function of handheld terminal

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Mass flow
Secondary dynamic variable (SV)	Totalizer
Tertiary dynamic variable (TV)	None
Quaternary dynamic variable (QV)	None

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert → Communication → HART output → Output → Assign PV
- Expert → Communication → HART output → Output → Assign SV
- Expert → Communication → HART output → Output → Assign TV
- Expert → Communication → HART output → Output → Assign QV

The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- None
- Volume flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer

9.3 Other settings

In the **Configuration** submenu, you can configure other settings for the HART protocol (e.g. Burst mode)

Navigation path

"Expert" menu → Communication → HART output → Configuration

10 Commissioning

10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-mounting check" checklist (→ [81](#))
- "Post-connection check" checklist (→ [81](#))

10.2 Switching on the measuring device


After a successful function check, switch on the measuring device.

After a successful startup, the local display switches automatically from the startup display to the measured value display.

i If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" (→ [81](#)).

10.3 Setting the operating language

Factory setting: English or ordered local language




A0013996

10.4 Configuring the measuring device


The **Setup** menu with its guided wizards contains all parameters needed for standard operation.

Navigation to the "Setup" menu



A0017371-EN

Overview of the "Setup" menu



10.4.1 Selecting the gas type

Navigation path

"Setup" menu → Select gas type

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Select gas type	Select the gas type for the measurement application.	Gas type choose list <ul style="list-style-type: none"> ■ Air ■ Argon Ar ■ Carbon dioxide CO2 ■ Nitrogen N2 	Air

10.4.2 Specifying the process pressure**Navigation path**

"Setup" menu → Process pressure

Parameter overview with brief description

Parameter/	Description	Prerequisite	Selection/ User entry	Factory setting
Process pressure	Process pressure value for calculating pressure-dependent gas properties	The in situ calibration must not be enabled.	0.5 to 21.0 bar a (7.3 to 303 psi a)	Country-dependent: 1.0130 bar a (14.692 psi a)

10.4.3 Configuring the sensor data

Configuring the pipe shape

Navigation path

"Setup" menu → Pipe shape

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Pipe shape	Select the shape of the pipe	Circular Rectangular	Circular

Configuring the pipe inner diameter

Navigation path

"Setup" menu → Pipe inner diameter

Parameter overview with brief description

Parameter	Description	Prerequisite	Selection/ User entry	Factory setting
Pipe inner diameter	(Enter the inner diameter of the pipe)	Only if the CIRCULAR pipe shape has been selected	80 to 1 500 mm	80 mm

Configuring the duct dimensions

Navigation path

"Setup" menu → Duct internal height

"Setup" menu → Duct internal width

Parameter overview with brief description

Parameter	Description	Prerequisite	Selection/ User entry	Factory setting
Duct internal height	Enter the height of a rectangular duct	Only if the RECTANGULAR pipe shape has been selected	50 to 3000 mm	80 mm (3 in)
Duct internal width	Enter the width of a rectangular duct	Only if the RECTANGULAR pipe shape has been selected	50 to 3000 mm	80 mm (3 in)

10.4.4 Determining the installation factor

Navigation path

"Setup" menu → Installation factor

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Installation factor	The factor is multiplied by the mass flow to correct sub-optimum installations	0 to 9	1

10.4.5 Configuring the current output

Navigation path

"Setup" menu → Assign current output

"Setup" menu → 4mA value

"Setup" menu → 20mA value

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Assign current output	Use this function to assign a measured variable or process variable to the current output.	Mass flow Corrected volume flow FAD volume flow Temperature	Mass flow
4mA value	Enter the value for the 4 mA current. The value can be larger than or smaller than the 20 mA value assigned. Positive and negative values are permitted depending on the measured variable (e.g. mass flow) assigned.	Number with up to 3 decimal places from - to +. The unit depends on the measured variable assigned.	0
20mA value	Enter the value for the 20 mA current. The value can be larger than or smaller than the 4 mA value assigned. Positive and negative values are permitted depending on the measured variable (e.g. mass flow) assigned.	Number with up to 3 decimal places from - to +. The unit depends on the measured variable assigned.	Maximum calibrated full scale value

10.4.6 Configuring the pulse/frequency/switch output

Navigation path

- "Setup" menu → Operating mode
- "Setup" menu → Assign frequency output
- "Setup" menu → Switch output function
- "Setup" menu → Assign pulse output

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Operating mode	Specify the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch 	Pulse
Assign frequency output	Select the process variable for the frequency output.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature 	Off
Measuring value at minimum frequency	Enter the measured value at the minimum frequency.	Depends on the process variable selected	-
Measuring value at maximum frequency	Specify the measured value at maximum frequency.	Depends on the process variable selected	-

Assign switch output	Select the function for the switch output.	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit value ■ Status 	Off
Assign limit	Select the process variable for the limit function.	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Totalizer 	Mass flow
Switch-on value	Enter the measured value for the switch-on value.	Depends on the process variable selected	-
Switch-off value	Enter the measured value for the switch-off value.	Depends on the process variable selected	-
Assign diagnostic behavior	Select the diagnostic behavior for the switch output.	<ul style="list-style-type: none"> ■ Alarm ■ Alarm or warning ■ Warning 	Alarm
Assign status	Select the device status for the switch output.	Low flow cut off	Low flow cut off
Assign pulse output	Select the process variable for the pulse output.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Off
Pulse value	Enter the measured value for the pulse output.	Depends on the process variable selected	-


10.5 Advanced settings

The **Advanced setup** menu with its submenus contains all parameters needed for specific settings.

Navigation path


"Setup" menu → Advanced setup


Navigation to the "Advanced setup" menu




A0017372-EN

Overview of the parameters and submenus in the "Advanced setup" menu





10.5.1 Defining the tag name



A0013375

1 Device tag


i The number of characters displayed depends on the characters used.

10.5.2 Configuring applications

Navigation path

"Setup" menu → "Advanced setup" → Applications

Parameter overview with brief description



Parameter	Description	Selection/ User entry	Factory setting
Select gas type	Select the gas type for the measurement application.	Gas type choose list <ul style="list-style-type: none"> ■ Air ■ Argon Ar ■ Carbon dioxide CO2 ■ Nitrogen N2 	Air
Process pressure	Process pressure value for calculating pressure-dependent gas properties	0.5 to 21.0 bar a (7.3 to 303 psi a)	Country-dependent: <ul style="list-style-type: none"> ■ 1013.25 mbar a ■ 14.696 psi a
Temperature	Use this function to view the process temperature currently measured.	None	-
Reference operating conditions	Select reference operating conditions for calculating the reference density	1013.25 mbar a, 0°C 1013.25 mbar a, 15°C 1013.25 mbar a, 20°C 1013.25 mbar a, 25°C 14.696 Psi a, 59°F 1000 mbar a, 0°C 1000 mbar a, 15°C 1000 mbar a, 20°C 1000 mbar a, 25°C 14.696 Psi a, 60°F 14.730 Psi a, 60°F User-defined	Country-dependent: <ul style="list-style-type: none"> ■ 1013.25 mbar a, 0 °C ■ 14.696 psi a, 59 °F
Reference pressure	Enter the reference pressure for calculating the reference density	0.1 to 99 bar a (1.5 to 1436 psi a)	Country-dependent: 1.0130 bar a (14.692 psi a)
Reference temperature	Enter the reference temperature for calculating the reference density	-50 to 150 °C (-58 to 423 °F°)	Country-dependent: <ul style="list-style-type: none"> ■ 0.0 °C ■ 32 °F
FAD conditions	Select reference operating conditions for calculating the FAD density (FAD = free air delivery)	1 000 mbar a, 20 °C 14.504 psi a, 68 °F User-defined	Country-dependent: <ul style="list-style-type: none"> ■ 1 000 mbar a, 20 °C ■ 14.504 psi a, 68 °F
FAD pressure	Enter the reference pressure for calculating the FAD density	0.1 to 99 bar a (1.5 to 1436 psi a)	Country-dependent: <ul style="list-style-type: none"> ■ 1 000 mbar a ■ 14.504 psi a
FAD temperature	Enter the reference temperature for calculating the FAD density	-50 to 150 °C (-58 to 423 °F°)	Country-dependent: <ul style="list-style-type: none"> ■ 20 °C ■ 68 °F


10.5.3 Setting the system units

In the **System units** submenu, you can configure the units of all measured values.

Navigation path

"Setup" menu → Advanced setup → System units

Structure of the submenu



Mass unit
Corrected volume flow unit
Corrected volume unit
FAD volume flow unit
FAD volume unit
Density unit
Pressure unit
Temperature unit
Length unit

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Mass flow unit	Select the unit for mass flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	Metric: Gram: g/s; g/min; g/h; g/day Kilogram: kg/s; kg/min; kg/h; kg/day Metric ton: t/s; t/min; t/h; t/day US: Ounce: oz/s; oz/min; oz/h; oz/day Pound: lb/s; lb/min; lb/h; lb/day Ton: ton/s; ton/min; ton/h; ton/day Arbitrary unit (see Text mass unit function): ___/s; ___/min; ___/h; ___/day	Country-dependent: ■ kg/h ■ lb/h
Mass unit	Select the unit for mass.	g kg t oz lb STon LTon User-defined	Country-dependent: ■ kg ■ lb

Parameter	Description	Selection/ User entry	Factory setting
Corrected volume flow unit	Select the unit for corrected volume flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	NI/s NI/min NI/h NI/d Nm ³ /s Nm ³ /min Nm ³ /h Nm ³ /d Sl/s Sl/min Sl/h Sl/d Sm ³ /s Sm ³ /min Sm ³ /h Sm ³ /d Scf/s Scf/min Scf/h Scf/d	Country-dependent: ■ Nm ³ /h ■ Scf/min
Corrected volume unit	Select the unit for volume.	NI Nm ³ Sl Sm ³ Scf	Country-dependent ■ Nm ³ ■ Scf
FAD volume flow unit	Select the unit for the FAD volume flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	NI Nm ³ Sl Sm ³ Scf l FAD/s l FAD/min l FAD/h l FAD/d m ³ FAD/s m ³ FAD/min m ³ FAD/h m ³ FAD/d cf FAD/s cf FAD/min cf FAD/h cf FAD/d	Country-dependent ■ m ³ FAD/h ■ cf FAD/min
FAD volume unit	Select the unit for standard volume.	l FAD m ³ FAD cf FAD	Country-dependent: ■ m ³ FAD ■ scf FAD
Density unit	Select the unit for density. <i>Result</i> The selected unit applies for: – Current outputs – Simulation process variable	g/cm ³ kg/dm ³ kg/l kg/m ³ lb/cf	Country-dependent ■ kg/m ³ ■ lb/cf
Pressure unit	Select the unit for pipe pressure.	kPa a MPa a bar a psi a mbar	Country-dependent: ■ bar a ■ psi a

Parameter	Description	Selection/ User entry	Factory setting
Temperature unit	Select the unit for temperature. <i>Result</i> The selected unit applies for: – Current outputs – Reference temperature – Simulation process variable	°C °F K °R	Country-dependent: ■ °C (Celsius) ■ °F (Fahrenheit)
Length unit	Select the unit of length for the nominal diameter.	mm m in ft	Country-dependent: ■ mm ■ in


10.5.4 Configuring the current output

In the **Current output** submenu, you can configure the values for the current output.

Navigation path

"Setup" menu → Advanced setup → Current output

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Assign current output	Use this function to assign a measured variable or process variable to the current output	Mass flow Corrected volume flow FAD volume flow Temperature	Mass flow
Mass flow unit	Select the unit for mass.	Metric: Gram: g/s; g/min; g/h; g/day Kilogram: kg/s; kg/min; kg/h; kg/day Metric ton: t/s; t/min; t/h; t/day US: Ounce: oz/s; oz/min; oz/h; oz/day Pound: lb/s; lb/min; lb/h; lb/day Ton: ton/s; ton/min; ton/h; ton/day Arbitrary unit (see TEXT mass unit function): ____/s; ____/min; ____/h; ____/day	Country-dependent: ■ kg/h ■ lb/h
Corrected volume flow unit	Select the unit for corrected volume flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	Unit choose list Nl/s Nl/min Nl/h Nl/d Nm ³ /s Nm ³ /min Nm ³ /h Nm ³ /d Sl/s Sl/min Sl/h Sl/d Sm ³ /s Sm ³ /min Sm ³ /h Sm ³ /d Scf/s Scf/min Scf/h Scf/d	Country-dependent: ■ Nm ³ /h ■ Scf/min
FAD volume flow unit	Select the unit for the FAD volume flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	Unit choose list 1 FAD/s 1 FAD/min 1 FAD/h 1 FAD/d m ³ FAD/s m ³ FAD/min m ³ FAD/h m ³ FAD/d cf FAD/s cf FAD/min cf FAD/h cf FAD/d	Country-dependent: ■ m ³ FAD/h ■ cf FAD/min

Parameter	Description	Selection/ User entry	Factory setting
Temperature unit	Select the unit for temperature. <i>Result</i> The selected unit applies for: – Current outputs – Reference temperature – Simulation process variable	°C °F K °R	Country-dependent: ■ °C (Celsius) ■ °F (Fahrenheit)
Current span	Select the current range for the process value output and for the upper/lower level for signal on alarm	Options 4 to 20mA HART NAMUR 4 to 20mA HART US 4 to 20mA FIXED CURRENT	4 to 20mA HART NAMUR
4mA value	Enter the value for the 4 mA current. The value can be larger than or smaller than the 20 mA value assigned. Positive and negative values are permitted depending on the measured variable (e.g. mass flow) assigned.	Number with up to 3 decimal places from - to +. The unit depends on the measured variable assigned.	0
20mA value	Enter the value for the 20 mA current. The value can be larger than or smaller than the 4 mA value assigned. Positive and negative values are permitted depending on the measured variable (e.g. mass flow) assigned.	Number with up to 3 decimal places from - to +. The unit depends on the measured variable assigned.	0
Failure mode	Select the value the current output adopts in an alarm condition. Prerequisite: The "FIXED CURRENT" option must not be selected in the CURRENT SPAN function (xxxx).	<ul style="list-style-type: none"> ■ Min. current ■ Max. current ■ Last valid value ■ Actual value ■ Defined value 	Max. current
Failure current	Select the current value the current output adopts in an alarm condition.	Floating point number with 2 decimal places in the range 3.59 to 22.5 mA	22.5 mA


10.5.5 Configuring the PFS output

In the **PFS output** submenu, you can configure the values for the current output.

Navigation path

"Setup" menu → Advanced setup → PFS output

Structure of the submenu



	Pulse width
	Failure mode
	Pulse output
	Invert output signal
Assign frequency	
	Unit
	Minimum frequency value
	Maximum frequency value
	Value at minimum frequency
	Value at maximum frequency
	Response time
	Damping
	Failure mode
	Failure frequency
	Invert output signal
Switch output function	(On/Off)
(Diagnostic behavior)	Assign diagnostic behavior
(Limit value)	Assign limit
	Switch-on value
	Switch-off value
(Status)	Assign status
	Switch-on delay
	Switch-off delay
	Failure mode
	Switch status
	Invert output signal

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Operating mode	Specify the output as a pulse, frequency or switch output.	<ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch 	Pulse
Assign pulse output	Select the process variable for the pulse output.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Off
Assign frequency output	Select the process variable for the frequency output.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature 	Off
Assign switch output	Select the function for the switch output.	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit value ■ Status 	Off
Assign diagnostic behavior	Select the diagnostic behavior for the switch output.	<ul style="list-style-type: none"> ■ Alarm ■ Alarm or warning ■ Warning 	Alarm
Assign limit	Select the process variable for the limit function.	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Totalizer 	Mass flow
Assign status	Select the device status for the switch output.	Low flow cut off	Low flow cut off
Mass flow unit	Select the unit for mass flow. <i>Result</i> The selected unit applies for: – Current outputs – Frequency outputs – Relay switch points (limit value for mass flow, flow direction) – Low flow cut off	Metric: Gram: g/s; g/min; g/h; g/day Kilogram: kg/s; kg/min; kg/h; kg/day Metric ton: t/s; t/min; t/h; t/day US: Ounce: oz/s; oz/min; oz/h; oz/day Pound: lb/s; lb/min; lb/h; lb/day Ton: ton/s; ton/min; ton/h; ton/day Arbitrary unit (see Text mass unit function): ____/s; ____/min; ____/h; ____/day	Country-dependent: ■ kg/h ■ lb/h
Mass unit	Select the unit for mass. <i>Result</i> The selected unit is taken from: Mass flow unit	g kg t oz lb STon LTon User-defined	Country-dependent: ■ kg ■ lb

Parameter	Description	Selection/ User entry	Factory setting
FAD volume flow unit	Use this function to select the preferred unit that is to be displayed for the FAD volume flow. The following time units can be selected: s = second, m = minute, h = hour, d = day Select the unit for the FAD volume flow. <i>Result</i> The selected unit applies for: – Current output – Frequency output – Relay switch points (limit value for corrected volume flow) – Low flow cut off	NI Nm ³ Sl Sm ³ Scf l FAD/s l FAD/min l FAD/h l FAD/d m ³ FAD/s m ³ FAD/min m ³ FAD/h m ³ FAD/d cf FAD/s cf FAD/min cf FAD/h cf FAD/d	Country-dependent: ■ m ³ FAD/h ■ cf FAD/min
FAD volume unit	Select the unit for the FAD volume unit.	l FAD m ³ FAD cf FAD	Country-dependent: ■ m ³ FAD ■ cf FAD
Corrected volume flow unit	Select the unit for corrected volume flow. <i>Result</i> The selected unit applies for: – Current outputs – Low flow cut off – Simulation process variable	NI/s NI/min NI/h NI/d Nm ³ /s Nm ³ /min Nm ³ /h Nm ³ /d Sl/s Sl/min Sl/h Sl/d Sm ³ /s Sm ³ /min Sm ³ /h Sm ³ /d Scf/s Scf/min Scf/h Scf/d	Country-dependent: ■ Nm ³ /h ■ scf/min (us)
Corrected volume unit	Select the unit for standard volume. The unit you select here is also valid for: ■ Current outputs ■ Frequency outputs ■ Relay switch points (limit value for corrected volume flow, flow direction) ■ Low flow cut off	NI Nm ³ Sl Sm ³ Scf	Country-dependent: ■ Nm ³ ■ Scf
Temperature unit	Select the unit for temperature. <i>Result</i> The selected unit applies for: – Current outputs – Reference temperature – Simulation process variable	°C °F K °R	Country-dependent: ■ °C (Celsius) ■ °F (Fahrenheit)
Pulse value	Enter the measured value for the pulse output.	Depends on the process variable selected	-
Pulse width	Specify the duration of the output pulse.	0.5 to 2000 msec	100 msec

Parameter	Description	Selection/ User entry	Factory setting
Failure mode	Select the value the current output adopts in an alarm condition. Prerequisite: The "FIXED CURRENT" option was not selected in the CURRENT SPAN function (xxxx).	<ul style="list-style-type: none"> ■ Min. current ■ Max. current ■ Last valid value ■ Actual value ■ Defined value 	Max. current
Minimum frequency value	Enter the minimum frequency value.	0 to 1 000 Hertz	0 Hertz
Maximum frequency value	Enter the maximum frequency value.	0 to 1 000 Hertz	1 000 Hertz
Measuring value at minimum frequency	Enter the measured value at the minimum frequency.	Depends on the process variable selected	-
Measuring value at maximum frequency	Specify the measured value at maximum frequency.	Depends on the process variable selected	-
Failure mode	Specify the output behavior in the event of a device alarm	<ul style="list-style-type: none"> ■ 0 Hertz ■ Actual value ■ Defined value 	0 Hertz
Failure frequency	Enter the value for the frequency output in the event of a device alarm	0 to 1 250 Hertz	0 Hertz
Switch-on value	Enter the measured value for the switch-on value.	Depends on the process variable selected	-
Switch-off value	Enter the measured value for the switch-off value.	Depends on the process variable selected	-
Switch-on delay	Specify the delay time for switching on the switch output	0.0 to 100.0 sec	0 sec
Switch-off delay	Specify the delay time for switching off the switch output	0.0 to 100.0 sec	0 sec
Failure mode	Specify the output behavior in the event of a device alarm Failsafe mode, The failsafe mode defines how the pulse output responds to a status message which is supposed to act on the status output.	Current status Open Closed	Open
Invert output signal	Invert the output signal	Yes No	No


10.5.6 Configuring the output conditioning

The damping and the step response time can be configured in the **Display behavior** submenu.

Navigation path

"Setup" menu → Advanced setup → Output conditioning

Structure of the submenu



Parameter overview with brief description


Parameter	Description	Selection/ User entry	Factory setting
Display damping	Set the reaction time of the local display to fluctuations in the measured value.	0.0 to 999.9 sec	0.0
Response time	Specify the step response time	0.0 to 999.9 sec	0
Damping	Specify the damping	0.0 to 999.9 sec	1.0
Output damping	Set the reaction time of the output signal to fluctuations in the measured value.	0.0 to 999.9 sec	0.0

10.5.7 Configuring the low flow cut off

Navigation path

"Setup" menu → "Advanced setup" menu → Low flow cut off

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Assign process variable	Select the process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Mass flow
On value low flow cut off	Enter the on value for low flow cut off	Max. 15-digit, positive floating-point number	0
Off value low flow cut off	Enter the off value for low flow cut off	0 to 100 %	50 %


10.5.8 Configuring the totalizer

You can configure the totalizer in the **Totalizer** submenu.

Navigation path

"Setup" menu → Advanced setup → Totalizer

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection/ User entry	Factory setting
Assign process variable	-	Select process variable for totalizer. <i>Result</i> The selection determines the choose list of the Unit parameter.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Mass flow
Unit	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Select the unit for the process variable of the totalizer.	Unit choose list	Country-dependent: <ul style="list-style-type: none"> ■ kg ■ lb
Failure mode	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow 	Define how the totalizer behaves in an alarm condition.	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value 	Stop

10.5.9 Configuring the local display

Navigation path

"Setup" menu → "Advanced setup" menu → "Display" menu

Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size

Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature ■ Totalizer ■ Current output 	Mass flow
0% bargraph value 1	Enter the 0% value to be shown on the bargraph display for the measured value 1.	Floating-point number with sign	0
100% bar graph value 1	Enter the 100% value to be shown on the bargraph display for the measured value 1.	Floating-point number with sign	1
Decimal places 1	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> x x.x x.xx x.xxx x.xxxx 	x.xx
Value 2 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ None ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature ■ Totalizer ■ Current output 	None
Decimal places 2	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> x x.x x.xx x.xxx x.xxxx 	x.xx
Value 3 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ None ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature ■ Totalizer ■ Current output 	None
0% bargraph value 3	Enter the 0% value to be shown on the bargraph display for the measured value 3.	Floating-point number with sign	0
100% bargraph value 3	Enter the 100% value to be shown on the bargraph display for the measured value 3.	Floating-point number with sign	0
Decimal places 3	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> x x.x x.xx x.xxx x.xxxx 	x.xx
Value 4 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ None ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature ■ Totalizer ■ Current output 	None

Decimal places 4	Select the number of decimal places for the display value.	x x.x x.xx x.xxx x.xxxx	x.xx
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10	5
Display damping	Set the reaction time of the local display to fluctuations in the measured value.	0.0 to 999.9	0
Header	Select header contents on local display.	Device tag Free text	Device tag
Header text	Select text for header on local display.	Free text	Free text
Separator	Select decimal separator for displaying numerical values.	. ,	.

10.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration.


You can do so using the **Configuration management** parameter and the related options found in the **Conf. backup display** submenu.

Navigation path

"Setup" menu → Advanced setup → Conf. backup disp.

 While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Selection/Display	Factory setting
Operating time	Indicates how long the device has been in operation up to this point.	Days (d), hours (h), minutes (m), seconds (s)	-
Last backup	Indicates when the last data backup was saved to the display module	Days (d), hours (h), minutes (m), seconds (s)	-

Configuration management	Select action for managing the device data in the display module	<ul style="list-style-type: none"> ■ Cancel ■ Execute backup ■ Restore ■ Duplicate ■ Compare ■ Clear backup data 	Cancel
Comparison result	Comparison between present device data and display backup	<ul style="list-style-type: none"> ■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible 	Check not done


10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation path

"Diagnostics" menu → Simulation

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection/ User entry	Factory setting
-----------	--------------	-------------	--------------------------	-----------------

Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Energy flow ■ Temperature 	Off
Value process variable	One of the following options is selected in the Assign simulation process variable parameter: <ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Energy flow ■ Temperature 	Enter the simulation value for the selected process variable.	Depends on the process variable selected	-
Simulation current output	-	Switch simulation of the current output on and off.	<ul style="list-style-type: none"> ■ On ■ Off 	Off
Value current output	The On option is selected in the Simulation current output parameter.	Enter the current value for simulation.	3.6 to 22.5 mA	Current value currently measured
Frequency simulation	-	Switch simulation of the frequency output on and off.	<ul style="list-style-type: none"> ■ On ■ Off 	Off
Frequency value	The On option is selected in the Frequency simulation parameter.	Enter the frequency for simulation.	0.0 to 1 000 mA	Frequency currently measured
Switch output simulation	-	Switch simulation of the switch output on and off.	<ul style="list-style-type: none"> ■ On ■ Off 	Off
Pulse value	The On option is selected in the Switch output simulation parameter.	Enter the current value for simulation.	Open Closed	Open
Simulation device alarm	-	Switch the device alarm on and off.	<ul style="list-style-type: none"> ■ On ■ Off 	Off

10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code (→  73)
- Write protection via lock switch (→  73)
- Write protection via keypad lock (→  30)

10.8.1 Write protection via access code

Using the customer-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.


Define access code

1. Navigating to the "Define access code" parameter: Setup → Advanced setup → Def. access code
2. Define a max. 4-digit numeric code as an access code.

- ✓ The -symbol appears in front of all write-protected parameters.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, they can always be modified even if the other parameters are locked.




The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the measured value display mode from the navigation and editing view.

-  If write access is activated via access code, it can be also deactivated only via the access code (→  41).
- In the "Description of Device Parameters" documents, each write-protected parameter is identified with the .

10.8.2 Write protection via lock switch

Unlike write protection via user-specific access code, this allows write access to the entire operating menu - other than the **Contrast display** parameter - to be locked.


The values of the parameters are still visible, but can no longer be changed (except for **Contrast display**), either via the local display, the service interface (CDI) or HART protocol.



1. Unscrew the electronics compartment cover.
2. Pull out the display module with a gentle rotational movement.

A0017255


3.



A0017375

To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.

4. Setting the lock switch (WP) on the main electronics module to the ON position enables the hardware write protection. Setting the lock switch (WP) on the main electronics module to the OFF position (factory setting) disables the hardware write protection.
- ✓ If the hardware write protection is enabled, the  symbol appears before the parameters in the header of the measured value display and in the navigation view.



A0015870

If the hardware write protection is disabled, the  symbol does not appear before the parameters in the header of the measured value display and in the navigation view.

5. Feed the ribbon cable into the gap between the housing and electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
6. Screw down the electronics compartment cover

11 Operation

11.1 Adjusting the operating language

See the "Commissioning" section for information on how to set the operating language (→ 48).


11.2 Configuring the display

- Basic settings for local display
- Advanced settings for local display (→ 55)

11.2.1 Navigation path

"Display/operat." menu

"Display" submenu



11.2.2 Parameter overview with brief description

Parameter	Description	Selection/ User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Contrast display	Adjust the contrast of the local display to ambient conditions (reading angle).	20 to 50 %	30 %
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10	5

11.3 Reading off measured values

You can read all measured values using the **Measured values** menu.

Navigation path

Diagnostics → Measured values

11.3.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.


Navigation path

"Diagnostics" menu → Measured values → Process variables

Temperature display navigation path

The temperature display can also be viewed directly in the Setup menu:
 "Setup" menu → Temperature

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Display
Mass flow	Displays the mass flow currently calculated	Floating-point number with sign
Corrected volume flow	Displays the calculated volume flow	Floating-point number with sign
FAD volume flow	Displays the FAD volume flow currently calculated	Floating-point number with sign
Temperature	Displays the current process temperature	Floating-point number with sign


11.3.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation path

"Diagnostics" menu → Measured values → Totalizer

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Display
Totalizer value	One of the following options is selected in the Assign process variable parameter of the Totalizer submenu: <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature 	Displays the current totalizer counter value.	Floating-point number with sign

Totalizer overflow	One of the following options is selected in the Assign process variable parameter of the Totalizer submenu: <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Energy flow ■ Temperature 	Displays the number of totalizer overflows. Value range: 0 to 32 000	Integer
--------------------	--	---	---------


11.3.3 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation path

"Diagnostics" menu → Measured values → Output values

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Display
Output current	-	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Pulse output	-	Displays the value currently measured for the pulse output.	Positive floating-point number
Output frequency	-	Displays the value currently measured for the frequency output.	0.0 to 1 000 Hz (Up to 1 250 Hz under failure mode)
Switch status	-	Displays the current switch output status.	<ul style="list-style-type: none"> ■ Open ■ Closed

11.4 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** (→ 49) menu
- Advanced settings using the **Advanced setup** (→ 55) menu

11.5 Performing a totalizer reset

In the **Operation** submenu, 2 parameters with various options for resetting the totalizers are available:

- Control totalizer
- Preset value
- Resetting the totalizer

Navigation path

"Display/operat." menu → Operation


Function scope of the "Control totalizer" parameter

Options	Description
Totalize	
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to the defined start value in the Preset parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in the Preset parameter and the totaling process is restarted.

Function scope of the "Reset totalizer" parameter

Options	Description
Cancel	Reset the totalizer to 0 and start.
Reset + totalize	Resets the totalizer to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

"Operation" submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection/ User entry	Factory setting
Control totalizer		Control totalizer value.	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize 	Totalize
Preset value		Specify start value for totalizer.	Floating-point number with sign	0
Reset all totalizers	-	Reset the totalizer to 0 and start.	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize 	Cancel


11.6 Showing data logging

In the device, the extended function of the HistoROM must be enabled (order option) so that the **Data logging** submenu appears. This contains all the parameters for the measured value history.

Navigation path


Diagnostics → Data logging

"Data logging" submenu



Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



4 Chart of a measured value trend

A0013859

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

i If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

12 Diagnostics and troubleshooting

12.1 General troubleshooting


Problem	Possible cause	Remedy
Local display dark and no signal output at current output (0 mA)	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage (→ 23).
Local display dark and no signal output at current output (0 mA)	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no signal output at current output (0 mA)	No contact between connecting cables and terminals.	Check the contacting of the cables and correct if necessary.
Local display dark and no signal output at current output (0 mA)	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no signal output at current output (0 mA)	I/O electronics module is defective.	Order spare part (→ 92).
Local display is dark, but signal output is within the valid current range (3.6 to 22 mA)	Display is set too bright or too dark.	<ul style="list-style-type: none"> ■ Set the display brighter by simultaneously pressing \square + \square. ■ Set the display darker by simultaneously pressing \square + \square.
Local display is dark, but signal output is within the valid current range (3.6 to 22 mA)	Ribbon cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid current range (3.6 to 22 mA)	Display module is defective.	Order spare part (→ 92).
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	Main electronics module is defective.	Order spare part (→ 92).
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	I/O electronics module is defective.	Order spare part (→ 92).
Device shows correct value on local display, but signal output is incorrect, though in the valid current range.	Configuration error	Check and correct parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol style="list-style-type: none"> 1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data".
Text on measured value display and in navigation view appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	<ol style="list-style-type: none"> 1. Press \square + \square for 2 s ("home position"). 2. Press \square. 3. Set the desired language in the Language parameter.
No connection via HART protocol	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly. Observe the maximum load (→ 23).

No connection via HART protocol	Commubox <ul style="list-style-type: none"> ■ Connected incorrectly ■ Configured incorrectly ■ Drivers not installed correctly ■ USB or COM interface on computer configured incorrectly 	Observe the documentation for the Commubox.  <ul style="list-style-type: none"> ■ FXA 191 HART: Document "Technical Information" TI00237F ■ FXA 195 HART: Document "Technical Information" TI00404F
No connection via service interface (CDI)	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox.  FXA 291 HART: Document "Technical Information" TI00405C

12.2 Diagnostic information on local display

12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message alternating with the operational display.



Status signals

Symbol	Meaning
F <small>A0013956</small>	Failure A device error has occurred. The measured value is no longer valid.
C <small>A0013959</small>	Function check The device is in service mode (e.g. during a simulation).
S <small>A0013958</small>	Out of specification The device is operated: <ul style="list-style-type: none"> ■ Outside its technical specification limits (e.g. outside the process temperature range) ■ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
M <small>A0013957</small>	Maintenance required Maintenance is required. The measured value is still valid.


The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required

Diagnostic behavior

Symbol	Meaning
 <small>A0013961</small>	Alarm Measurement is interrupted. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
 <small>A0013962</small>	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information.




If two or more diagnostic events are pending simultaneously, only the message with the highest priority is shown. Other diagnostic messages that are pending can be viewed in the **Diagnostic list** submenu (→ 81).

Past diagnostic messages that are no longer pending are shown in the **Event logbook** submenu (→ 81).

Operating elements

Key	Meaning
 <small>A0013970</small>	Plus key <i>In a menu, submenu</i> Opens the message about the remedial measures.
 <small>A0013952</small>	Enter key <i>In a menu, submenu</i> Opens the operating menu.

12.2.2 Calling up remedial measures



5 Message for remedial measures

- 1 Short text
- 2 Diagnostic behavior with diagnostic code
- 3 Service ID
- 4 Operation time of occurrence
- 5 Remedial measures


The user is in the diagnostic message.

1. Press **+** (**i** symbol).
 - ✓ The message for the remedial measures for the diagnostic event opens.
2. Press **-** + **+** simultaneously.
 - ✓ The message about the remedial measures closes.

12.3 Diagnostic information in the operating tool

If diagnostic information is present in the operating tool, the status signal appears in the top left status area along with the corresponding symbol in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)



A0016518-EN

Calling up remedial measures

1. Navigate to the "Diagnostics" menu.
 - ✓ In the "Actual diagnostics" parameter, the diagnostic code is shown with a short text.
2. On the right in the display range, hover the cursor over the "Actual diagnostics" parameter.
 - ✓ A tool tip with remedial measures for the diagnostic number appears.


12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior

Each diagnostic number is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostic numbers via the **Diagnostics No. xxx** parameter.

Navigation path

"Expert" menu → System → Diagnostic handling → Diagnostic behavior → Assign behavior of diagnostic no. xxx



A0014048-EN

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. The signal outputs assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.5 Overview of diagnostic information

Diagnostic number	Short text	Remedial measures	Status signal from the factory	Diagnostic behavior from the factory
Diagnostics for the sensor				
004	Sensor	Change sensor	F	Alarm*
082	Data storage	1. Change main electronic module. 2. Change sensor.	F	Alarm*
083	Memory content	1. Restart device. 2. Restore S-Dat data. 3. Change sensor.	F	Alarm*

Diagnostic number	Short text	Remedial measures	Status signal from the factory	Diagnostic behavior from the factory
Diagnostics for the electronics				
270	Main electronic failure	Change main electronic module.	F	Alarm
271	Main electronic failure	1. Restart device. 2. Change main electronic module.	F	Alarm
272	Main electronic failure	1. Restart device. 2. Contact service.	F	Alarm*
273	Main electronic failure	1. Emergency operation via display. 2. Change main electronics.	F	Alarm*
282	Data storage	1. Restart device. 2. Contact service.	F	Alarm

283	Memory content	1. Transfer data or reset device. 2. Contact service.	F	Alarm*
311	Electronic failure	1. Transfer data or reset device. 2. Contact service.	F	Alarm*
311	Electronic failure	Maintenance required! 1. Do not perform reset. 2. Contact service.	M	Warning

* Diagnostic behavior can be changed: Section 12.4 "Adapting the diagnostic behavior"

Diagnostic number	Short text	Remedial measures	Status signal from the factory	Diagnostic behavior from the factory
Diagnostics for the configuration				
410	Data transfer	1. Check connection. 2. Retry data transfer.	F	Alarm*
411	Upload/download	1. Check connection. 2. Retry data transfer.	F	Alarm*
411	Up-/download active	Up-/download active, please wait	C	Warning*
431	Trim	Carry out trim.	C	Warning*
437	Incompatible configuration	1. Restart device. 2. Contact service.	F	Alarm*
437	Incompatible configuration	1. Transfer data or reset device. 2. Contact service.	C	Alarm
438	Dataset	1. Check data set file. 2. Check device configuration. 3. Up- and download new configuration.	M	Warning*
441	Current output	1. Check process. 2. Check current output settings.	S	Warning*
442	Frequency output	1. Check process. 2. Check frequency output setting.	S	Warning*
443	Pulse output	1. Check process. 2. Check pulse output setting.	S	Warning*
453	Flow override	Deactivate flow override.	C	Warning*
484	Simulation failsafe mode	Deactivate simulation.	C	Alarm
485	Simulation process variable	Deactivate simulation.	C	Warning*
491	Simulation current output	Deactivate simulation.	C	Warning*
492	Frequency simulation	Deactivate simulation.	C	Warning*
493	Simulation pulse output	Deactivate simulation.	C	Warning
494	Switch output simulation	Deactivate simulation.	C	Warning

* Diagnostic behavior can be changed: Section 12.4 "Adapting the diagnostic behavior"

Diagnostic number	Short text	Remedial measures	Status signal from the factory	Diagnostic behavior from the factory
Diagnostics for the process				
803	Current loop	1. Check wiring. 2. Change electronics module.	M F	Alarm
832	Ambient temperature	Reduce ambient temperature.	S	Warning*
833	Ambient temperature	Increase ambient temperature.	S	Warning*
834	Process temperature	Reduce process temperature.	S	Warning*
835	Process temperature	Increase process temperature.	S	Warning*
841	Flow velocity	1. Check process conditions. 2. Increase system pressure	S	Alarm
842	Process limit	Low flow cut off active! Check low flow cut off configuration.	S	Logbook entry only
861	Temperature differential	1. Check process conditions. 2. Check signal path.	S	Alarm
862	Partly filled pipe	1. Check for gas in process. 2. Adjust detection limits.	S	Warning*

* Diagnostic behavior can be changed: Section 12.4 "Adapting the diagnostic behavior"

12.6 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

Navigation path

"Diagnostics" menu → Device reset → Device reset

Function scope of the "Device reset" parameter


Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to the factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

12.7 Diagnostics list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

"Diagnostics" menu → Diagnostic list



A0014006-EN

Calling up and closing remedial measures

1. Press **E**.
 - ✓ The message for the remedial measures for the selected diagnostic number opens.
2. Press **□** + **+** simultaneously.
 - ✓ The message about the remedial measures closes.

 For the structure of the remedial measure message (→  83)


12.8 Event logbook

12.8.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Events list



A0014008-EN

A maximum of 20 event messages can be displayed in chronological order. If the advanced HistoROM function is enabled in the device (order option), up to 1000 entries can be displayed.

The event history includes entries for:

- Diagnostic events (→  81)
- Information events (→  81)

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostics event
 - : Occurrence of the event
 - : End of the event
- Information event
 - : Occurrence of the event

Calling up and closing remedial measures

1. Press **E**.
 - ✓ The message for the remedial measures for the selected diagnostic number opens.
2. Press **□** + **+** simultaneously.
 - ✓ The message about the remedial measures closes.

-  For the structure of the remedial measure message (→  83)
- For filtering the displayed event messages (→  89)

12.8.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Information event	Event text
I1000	—— (device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Trend data deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1209	Density adjustment OK
I1221	Error during zero point adjustment
I1222	Zero point adjustment OK

11227	Sensor emergency mode activated
11228	Sensor emergency mode failed
1264	Safety sequence aborted
1327	Zero point adjust failed signal path
1335	Firmware changed

13 Repair

13.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices only by Endress+Hauser Service or at the factory.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

13.2 Spare parts

- Some interchangeable measuring device components are identified by an overview sign. This contains information about the spare part.
- The spare part overview sign is located in the connection compartment cover of the device and contains the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL for the *W@M Device Viewer* (www.endress.com/deviceviewer):
All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Is located on the device nameplate and the spare part overview sign.
- Can be read out via the "Serial number" parameter in the "Device information" submenu.

13.3 Endress+Hauser services



For information about service and spare parts, contact your Endress+Hauser distributor.

14 Maintenance

14.1 Maintenance tasks

No special maintenance work is required.

14.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

14.1.2 Interior cleaning

Cleaning the transducer

In applications with dirty gases, it is advisable to inspect and clean the device regularly to minimize measured errors caused by fouling or buildup.

The inspection and cleaning intervals depend on experience and the field of application.

NOTICE

The use of unsuitable equipment or cleaning liquids can damage the transducer.

- ▶ Do not use pigs to clean the pipe.
- ▶ Use an oil-free cleaning agent that does not form a film to clean the sensor. Gently clean the surface using a soft brush.
- ▶ When cleaning make sure that the transducers are not damaged.
- ▶ Never use cleaning agents that can corrode the material and the seal.

Sensor-specific information:

- Follow the safety instructions when removing the sensor (→  8).
- Follow the instructions in the "Installation" section when removing the sensor (→  20).

14.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser representative can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

14.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser representative can provide detailed information on the services.

15 Return

Observe the following points for returning the device:

- Contact your Endress+Hauser Sales Center to obtain information about the procedure and basic conditions.
- Enclose the completed "Decontamination declaration" form with the device.



The form is available:

As a photocopy master at the end of this manual

16 Disposal

16.1 Removing the measuring device

1. Switch off the device.
2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids. Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

16.2 Disposing of the measuring device

⚠ WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid local site rules and federal/national regulations.
- Ensure proper separation and reuse of the device components.

17 Technical data

17.1 Application

The measuring device is suitable for flow measurement of gases only.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

17.2 Function and system design

Measuring principle	Mass flow measurement based on thermal measuring principle
Measuring system	The device consists of a transmitter and a sensor. One device version is available: compact version - transmitter and sensor form a mechanical unit. For information on the structure of the device (→  10)

17.3 Characteristic values

Measured variable	<p>Direct measured variables</p> <ul style="list-style-type: none"> ■ Mass flow ■ Gas temperature <p>Calculated measured variables</p> <ul style="list-style-type: none"> ■ Corrected volume flow ■ FAD (free air delivery) volume flow
-------------------	---

Measuring range The available measuring range depends on the choice of gas and the size of the pipe. The measuring device is calibrated individually with air (under ambient conditions) and the value is converted in order to adapt it to the customer's gas if necessary.

 To obtain information on other gases and process conditions, please contact your Endress +Hauser sales office.

The following tables list the ranges available for air.

Measuring range "Calibration flow", option G and H (→  103)

SI units for insertion version

DN [mm]	[kg/h]		[Nm ³ /h] at 0 °C (1.013 bar a)		[Nm ³ /h at 15 °C (1.013 bar a)	
	min.	Max.	min.	Max.	min.	Max.
80	20	2030	16	1 570	17	1 660
100	38	3 750	29	2 900	31	3 070
150	75	7 500	58	5 800	61	6 130
200	125	12 500	97	9 700	102	10 200
250	200	20 000	155	15 500	164	16 400
300	280	28 000	217	21 700	229	22 900
400	500	50 000	387	38 700	409	40 900

DN	[kg/h]		[Nm ³ /h] at 0 °C (1.013 bar a)		[Nm ³ /h] at 15 °C (1.013 bar a)	
	[mm]	min.	Max.	min.	Max.	min.
500	800	80 000	620	62 000	655	65 500
600	1 150	115 000	890	89 000	941	94 100
700	1 590	159 000	1 230	123 000	1 300	130 000
1 000	3 200	320 000	2 480	248 000	2 620	262 000
1 500	7 200	720 000	5 568	556 800	5 886	588 600

US units for insertion version

DN	[lb/h]		[Scf/min] at 32 °F (14.7 psi a)		[Scf/min] at 59 °F (14.7 psi a)	
	[in]	min.	Max.	min.	Max.	min.
3	45	4 476	9	924	10	977
4	83	8 269	17	1 710	18	1 810
6	165	16 540	34	3 420	36	3 610
8	276	27 560	57	5 680	60	6 000
10	441	44 100	91	9 130	97	9 650
12	617	61 740	128	12 800	135	13 500
16	1 103	110 300	228	22 800	241	24 100
20	1 764	176 400	365	36 500	386	38 600
24	2 536	253 600	524	52 400	554	55 400
28	3 506	350 600	724	72 400	765	76 500
40	7 056	705 600	1 460	146 000	1 542	154 200
60	15 876	1 587 600	3 280	328 000	3 465	346 500

Measuring range "Calibration flow" option K with extended flow (→ 103)*SI units for insertion version*

DN	[kg/h]		[Nm ³ /h] at 0 °C (1.013 bar a)		[Nm ³ /h] at 15 °C (1.013 bar a)	
	[mm]	min.	Max.	min.	Max.	min.
80	20	3 045	16	2 355	17	2 490
100	38	5 625	29	4 350	31	4 605
150	75	11 250	58	8 700	61	9 195
200	125	18 750	97	14 550	102	15 300
250	200	30 000	155	23 250	164	24 600
300	280	42 000	217	32 550	229	34 350
400	500	75 000	387	58 050	409	61 350
500	800	120 000	620	93 000	655	98 250
600	1 150	172 500	890	133 500	941	141 150
700	1 590	238 500	1 230	184 500	1 300	195 000
1 000	3 200	480 000	2 480	372 000	2 620	393 000
1 500	7 200	1 080 000	5 568	835 200	5 886	882 900

US units for insertion version

DN	[lb/h]		[Scf/min] at 32 °F (14.7 psi a)		[Scf/min] at 59 °F (14.7 psi a)	
	[in]	min.	Max.	min.	Max.	min.
3	45	6714	9	1386	10	1466
4	83	12403.5	17	2565	18	2715
6	165	24807	34	5130	36	5415
8	276	41344.5	57	8520	60	9000
10	441	66150	91	13695	97	14475
12	617	92610	128	19200	135	20250
16	1103	165375	228	34200	241	36150
20	1764	264600	365	54750	386	57900
24	2536	380362.5	524	78600	554	81300
28	3506	525892.5	724	108600	765	114750
40	7056	1058400	1460	219000	1542	231300
60	15876	2381400	3280	492000	3465	519750

Operable flow range

Over 100 : 1 as standard (measuring range of "Calibration flow", option K: over 150 : 1 in the extended range).

The flow is measured and output even in the extended measuring range (above the calibration full scale value). The extended range is not subject to the specified uncertainty of measurement, however.

17.4 Output

Output signal

Current output

Current output	4-20 mA HART, active
Maximum output values	<ul style="list-style-type: none"> ■ DC 24 V (no flow) ■ 22 mA  If the option Defined value is selected in the Failure mode parameter : 22.5 mA
Load	0 to 750 Ω
Resolution	16 Bit or 0.38 µA
Damping	Adjustable: 0 to 999 s
Assignable measured variables	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature

Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switching output
Version	Passive, open collector
Maximum input values	<ul style="list-style-type: none"> ■ DC 30 V ■ 25 mA
Voltage drop	For 25 mA: ≤ DC 2 V
Pulse output	

Pulse width	Adjustable: 0.5 to 2000 ms → pulse rate: 0 to 1000 Pulse/s
Pulse value	Adjustable
Assignable measured variables	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow
Frequency output	
Maximum frequency	Adjustable: 0 to 1000 Hz
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature
Switching output	
Switching behavior	Binary, conductive or non-conductive
Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit value ■ Status

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Current output

Failure mode	Can be selected (as per NAMUR recommendation NE 43)
Minimum alarm	3.6 mA
Maximum alarm	22 mA
Adjustable value	3.59 to 22.5 mA

Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from: <ul style="list-style-type: none"> ■ Actual value ■ No pulses
Frequency output	
Failure mode	Choose from: <ul style="list-style-type: none"> ■ Actual value ■ Defined value: 0 to 1250 Hz ■ 0 Hz
Switching output	
Failure mode	Choose from: <ul style="list-style-type: none"> ■ Current status ■ Open ■ Closed

Local display

Plain text display	With information on cause and corrective action
---------------------------	---

 Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication: HART protocol
- Via service interface

Plain text display	With information on cause and corrective action
---------------------------	---

Low flow cut off The switch point for low flow cut off is programmable.

Galvanic isolation The following connections are galvanically isolated from each other:

- Outputs
- Voltage supply

Protocol-specific data

HART


Manufacturer ID	0x11
Device type ID	0x66
HART protocol revision	6.0
Device description files (DTM, DD)	Information and files under: www.endress.com
HART load	Min. 250 Ω
Dynamic variables	<p>The measured variables can be freely assigned to the dynamic variables.</p> <p>Measured variables for PV (primary dynamic variable)</p> <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature <p>Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)</p> <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature ■ Totalizer

17.5 Power supply

Terminal assignment

Transmitter

Connection version 4-20 mA HART, pulse/frequency/switching output



A0017178

- 1 Supply voltage
- 2 Signal transmission: Pulse/frequency/switching output
- 3 Signal transmission: 4-20 mA HART
- 4 Ground terminal for cable shield

Supply voltage

Order characteristic for "Power supply"	Terminal numbers	
	1 (L+)	2 (L-)
Option D	DC 24 V (18 to 30 V)	

Signal transmission

Order characteristic for "Output"	Terminal numbers			
	Output 1		Output 2	
	26 (+)	27 (-)	24 (+)	25 (-)
Option A	4-20 mA HART active		-	
Option B	4-20 mA HART active		Pulse/frequency/switch output	
Option K	-		Pulse/frequency/switch output	

Supply voltage

DC 24 V (18 to 30 V)

The power supply circuit must comply with SELV/PELV requirements.


Power consumption

Order characteristic for "Output"	Maximum power consumption
<ul style="list-style-type: none"> ■ Option A: 4-20mA HART ■ Option B: 4-20mA HART, pulse/frequency/switching output ■ Option K: Pulse/frequency/switching output 	3.1 W

Current consumption	Order characteristic for "Output"	Maximum current consumption	Maximum switch-on current
	<ul style="list-style-type: none"> ■ Option A: 4-20mA HART ■ Option B: 4-20mA HART, pulse/frequency/switching output ■ Option K: Pulse/frequency/switching output 	185 mA	< 2.5 A

Power supply failure	<ul style="list-style-type: none"> ■ Totalizers stop at the last value measured. ■ Configuration is retained in the device memory. ■ Error messages (incl. total operated hours) are stored.
----------------------	---

Electrical connection **Connecting the transmitter**



1 Cable entry for supply voltage
2 Cable entry for signal transmission

A0017179

Connection examples

Potential equalization	No special measures for potential equalization are required.
------------------------	--

Terminals	Plug-in screw terminals for specified wire cross-sections
-----------	---

Cable entries	<ul style="list-style-type: none"> ■ Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) ■ Thread for cable entry: <ul style="list-style-type: none"> – NPT ½" – G ½"
---------------	---

Cable specification	Wire cross-sectional area
	0.5 to 1.5 mm ² (21 to 16 AWG)
	Permitted temperature range
	<ul style="list-style-type: none"> ■ –40 °C (–40 °F)...≥ 80 °C (176 °F) ■ Minimum requirement: cable temperature range ≥ ambient temperature + 20 K
	Signal cable
	<i>Current output</i>
	For 4-20 mA HART: Shielded cable recommended. Observe grounding concept of the plant.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Supply voltage cable


Standard installation cable is sufficient.

17.6 Performance characteristics

Reference operating conditions

- Calibration systems traceable to national standards
- Accredited in accordance with ISO/IEC 17025
- Air controlled to 24 °C ± 0.5 °C (75.2 °F ± 0.9 °F) at atmospheric pressure
- Humidity controlled < 40 % RH

Maximum measured error



6 Maximum measured error (% mass flow) as % of measured value/full scale value. G, H, K: Order code options for "Calibration flow", see the following table

Order code option for "Calibration flow"	Accuracy	Description
K	<ul style="list-style-type: none"> ■ Q = 100 to 150 %: from ±3 % to ±6.5 % of the current measured value increasing linearly as expressed in the following equation: $\pm 3 \pm (X_n - 100) \times 0.07$ [% o.r.] ■ Q = 15 to 100 %: ±3 % of current measured value ■ Q = 1 to 15 % ±0.45 % of full scale value (all data under reference conditions)	The measuring device is calibrated and adjusted on an accredited, traceable calibration system. A calibration protocol certifies measurement accuracy.
H	<ul style="list-style-type: none"> ■ Q = 20 to 100 % ±4 % of current measured value ■ Q = 1 to 20 % ±0.8 % of full scale value (all data under reference conditions)	The quality of the device from a measurement technology point of view is tested. A proof report confirms that the measuring device is measuring within the specified tolerance. Extended range not specified
G	Q = 1 to 100 % ±5 % of full scale value of measuring range. (under reference conditions)	In this version, no calibration or accuracy testing is carried out on the measuring device.

- The full scale value depends on the pipe/duct nominal diameter of the measuring device.
- Full scale values of the calibrated measuring range (→ 96)
- (100 % < X_n ≤ 150 %); X_n = current flow as a % of the full scale value

Accuracy of outputs

o.r. = of reading; o.f.s. = of full scale value

Current output

Accuracy	Max. ±0.05 % o.f.s. or ±10 µA
-----------------	-------------------------------

Repeatability ±0.5 % of value for velocities > 1.0 m/s (3.3 ft/s)

Response time Typically < 3 s for 63 % of a given step change (in both directions)

Influence of medium pressure Air: 0.35 % of value per bar (0.02 % per psi) of process pressure change

17.7 Installation

"Mounting requirements" (→  15)

17.8 Environment

Ambient temperature range	Measuring device	-40 to +60 °C (-40 to +140 °F)
	Local display	-20 to +60 °C (-4 to +140 °F), the readability of the display may be impaired at temperatures outside the temperature range.

- ▶ If operating outdoors:
Avoid direct sunlight, particularly in warm climatic regions.

Storage temperature -40 to +80 °C (-40 to +176 °F), preferably at +20 °C (+68 °F)

Degree of protection **Transmitter**

- As standard: IP66/67, type 4X enclosure
- When housing is open: IP20, type 1 enclosure
- Display module: IP20, type 1 enclosure

Sensor
IP66/67, type 4X enclosure


Shock resistance As per IEC/EN 60068-2-31

Vibration resistance Acceleration up to 2 g, 10 to 150 Hz, as per IEC/EN 60068-2-6

Electromagnetic compatibility (EMC) As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21).
 Details are provided in the Declaration of Conformity.

17.9 Process

Medium temperature range	<p>Sensor -40 to +100 °C (-40 to +212 °F)</p> <p>Seals (G thread only)</p> <ul style="list-style-type: none"> ■ HNBR: -40 to +100 °C (-40 to +212 °F) ■ EPDM: -35 to +100 °C (-31 to +212 °F) <p>Clamping ring PEEK: -40 to +100 °C (-40 to +212 °F)</p>
Flow limit	<p>See "Measuring range" (→ 96) section</p> <p>The velocity in the measuring tube should not exceed 70 m/s (230 ft/s).</p>
Pressure loss	<p>Negligible.</p> <p>For a precise calculation, use the Applicator.</p>
System pressure	<p>Sensor Depending on the version, please note the details on the name plate . Max. 20 bar g (290 psi g)</p>
Thermal insulation	<p>If the gas is very humid or saturated with water, the pipe and the sensor housing should be insulated to prevent water droplets condensing on the transducer.</p> <p>NOTICE</p> <p>Electronics overheating on account of thermal insulation!</p> <ul style="list-style-type: none"> ▶ Observe maximum permitted insulation height of the transmitter neck so that the transmitter head is completely free.




A0015763

17.10 Mechanical construction

Design, dimensions

Compact version



A0015743

Dimensions in SI units

L [mm]	A ¹⁾ [mm]	B [mm]	C [mm]	D [mm]
235	146	133	129	407
335	146	133	129	507
435	146	133	129	597.4
608	146	133	129	770.4

1) For version without local display values - 7 mm


Dimensions in US units

L [in]	A ¹⁾ [in]	B [in]	C [in]	D [in]
9	5.75	5.24	5.08	16.02
13	5.75	5.24	5.08	19.96
17	5.75	5.24	5.08	23.52
24	5.75	5.24	5.08	30.33

1) For version without local display values - 0.28 in

Hot tap

Low pressure version (up to 4.5 bar g (65 psi g))




A0014289

- 1 Sensor connection with safety chain
- 2 Ball valve
- 3 Retrofit adapter
- 4 Process connection mounting boss
- 5 Flange adapter
- 6 Process connection flange
- V1 Version with retrofit adapter
- V2 Version with mounting boss
- V3 Version with flange

	A	B	C	D	E	F	G	L	N	O	P	Q	R
mm	42.4	96	620	71	165	88	209	~249.5	33.4	33.4	123.9	105.5	61
inch	1.67	3.78	24.4	2.80	3.78	2.80	6.50	~3.46	1.31	1.31	4.88	4.15	2.40

Medium pressure version (up to 16 bar g (230 psi g))



A0014310

- 1 Sensor connection
- 2 Ball valve
- 3 Retrofit adapter
- 4 Process connection mounting boss
- 5 Flange adapter
- 6 Process connection flange
- 7 Extractor assembly
- V1 Version with retrofit adapter
- V2 Version with mounting boss
- V3 Version with flange

	A	B	D	E	F	G	L1	L2	L3	N	O	P	Q	R	U	V	W	x
mm	42.4	96	71	165	88	209	~249.5	133	148	33.4	33.4	123.9	105.5	61	150	165	215	129
inch	1.67	3.78	2.80	3.78	2.80	6.50	~9.82	5.24	5.83	1.31	1.31	4.88	4.15	2.40	5.91	6.50	8.46	5.08

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Weight in SI units

Compact version

Sensor length [mm]	235	335	435	608
Weight [kg] ¹⁾	2.2	2.3	2.4	2.5

1) Weight of entire measuring device

Hot tap

Hot tap versions	[kg]
with retrofit adapter (version V1)	1.8
with mounting boss (version V2)	2.2
with flange (version V3)	4.3
Extractor assembly	7.8

Weight in US units*Compact version*

Sensor length [in]	9	13	17	24
Weight [lbs]	4.8	5.7	5.3	5.5

Hot tap

Hot tap versions	[lbs]
with retrofit adapter (version V1)	4.0
with mounting boss (version V2)	4.9
with flange (version V3)	9.5
Extractor assembly	17.5

Materials**Transmitter housing**

- Order characteristic for "Housing", option **A**: aluminum coating AlSi10Mg
- Window material: glass

Sensor*Compression fitting:*

- Thread: G 3/4 A, G 1 A, 3/4" NPT, 1" NPT
- Stainless steel 1.4404/1.4571 and 316L/316TI
- Clamping ring: PEEK 450G
- Sealing ring: EPDM/HNBR, 316/316L (outer ring)

Transducer

- Stainless steel 1.4404/1.4435 as per EN 10216-5/ EN 10272-5/ EN 10028-7/ EN 10088-2
- Stainless steel 316L as per ASTM A269/ A479/ A240/ A666

Cable entries

Order characteristic for "Housing", option A: compact, aluminum coating

Electrical connection	Type of protection	Material
Cable gland M20 × 1.5	For non-hazardous areas	Plastic
Thread G 1/2" via adapter	For non-Ex and Ex	Nickel-plated brass
Thread NPT 1/2" via adapter		

Accessories

Mounting boss

1.4404 as per EN 10272 and 316/316L as per ASTM A479

Hot tap

- Process connection:
 - Mounting boss:
 - 1.4404 as per EN 10272 and 316/316L as per ASTM A479
 - Flange socket:
 - 1.4404 as per EN 1092-1, 316L as per JIS B 2220, ASME B16.5
- Sensor connection:
 - 1.4404 as per EN 10216-5 and 316/316L as per ASTM A312
- Ball valve:
 - CF3M and CF8M
 - Seal:
 - PTFE

17.11 Operability

Operating concept

Operator-oriented menu structure for user-specific tasks

- Commissioning
- Operation
- Diagnostics
- Expert level

Quick and safe commissioning

Menu guidance with brief explanations of the individual parameter functions

Reliable operation

- Operation in different languages: (→  112)
 - Via local display
 - Via operating tools
- Uniform operating philosophy applied to device and operating tools

Efficient diagnostics increase measurement reliability

- Remedial information is integrated in plain text
- Diverse simulation options and optional line recorder functions

Local operation

"Display; Operation" Order code option C

Display elements

- 4-line display
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F)
 - The readability of the display may be impaired at temperatures outside the temperature range.

Operating elements

Local operation with 3 push buttons (, , )

Additional functionality


- Data backup function
The device configuration can be saved in the display module.
- Data comparison function
The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
The transmitter configuration can be transmitted to another device using the display module.

Remote operation

Via HART protocol

This communication interface is present in the following device version:

- Order characteristic for "Outlet", option **A**: 4-20 mA HART
- Order characteristic for "Outlet", option **B**: 4-20 mA HART, pulse/frequency/switching output




A0017373

☐ 7 Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX100
- 6 VIATOR Bluetooth modem with connecting cable
- 7 Transmitter

Via service interface (CDI)



A0017253

- 1 Service interface (CDI) of the measuring device
- 2 Commubox FXA291
- 3 Computer with "FieldCare" operating tool

Languages

Can be operated in the following languages:

- Via local display:
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Japanese, Chinese, Korean, Bahasa (Indonesian), Vietnamese, Czech
- Via operating tools:
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Japanese, Chinese, Korean, Bahasa (Indonesian), Vietnamese, Czech

17.12 Certificates and approvals

CE mark

The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

cCSA_{US}

The following hazardous area versions currently available:

NI

Class 1, Division 2, Groups A, B, C and D T4 or Class I, Zone 2 IIC T4

-
- Other standards and guidelines
- EN 60529
Degrees of protection provided by enclosures (IP code)
 - EN 61010-1
Protection Measures for Electrical Equipment for Measurement, Control, Regulation and Laboratory Procedures.
 - IEC/EN 61326
Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements)
 - NAMUR NE 21
Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment.
 - NAMUR NE 32
Data retention in the event of a power failure in field and control instruments with microprocessors
 - NAMUR NE 43
Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.
 - NAMUR NE 53
Software of field devices and signal-processing devices with digital electronics
 - NAMUR NE 105
Specifications for integrating fieldbus devices in engineering tools for field devices
 - NAMUR NE 107
Status classification as per NE107

17.13 Application packages

 For an overview of the application packages that can be ordered, see the "Technical Information" document

17.14 Accessories

 For an overview of the accessories that can be ordered, see the "Technical Information" document

18 Appendix

18.1 Overview of the Operator/Maintenance operating menu

The following table provides an overview of the operating menu structure with the specific parameters for operators, maintenance staff and experts. The page reference indicates where a description of the parameter can be found in the manual.

Language (0104)		(→ 48)
Display/operat.	→	(→ 27)
Display	→	(→ 76)
Format display (0098)		(→ 76)
Contrast display (0105)		(→ 76)
Display interval (0096)		(→ 76)
Operation	→	(→ 79)
Control totalizer (0912)		(→ 76)
Preset value (0913)		(→ 76)
Reset all totalizers (2806)		(→ 76)
Setup	→	(→ 49)
Select gas type (3381)		(→ 49)
Process pressure (3376)		(→ 50)
Temperature (1853)		(→ 77)
Pipe shape (3441)		(→ 51)
Pipe inner diameter (3476)		(→ 51)
Duct internal height (3405)		(→ 51)
Duct internal width (3411)		(→ 51)
Installation factor (3470)		(→ 51)
Assign current output (0359)		(→ 53)
4 mA value (0367)		(→ 53)
20 mA value (0372)		(→ 53)
Operating mode (0469)		(→ 53)
Assign frequency output (0478)		(→ 53)

Measuring value at minimum frequency (0476)		(→ 53)
Measuring value at maximum frequency (0475)		(→ 53)
Switch output function (0481)		(→ 54)
Assign limit (0483)		(→ 54)
Switch-off value (0464)		(→ 54)
Switch-on value (0466)		(→ 54)
Assign pulse output (0460)		(→ 54)
Value per pulse (0455)		(→ 54)
Advanced setup	→	(→ 55)
Enter access code (0092)		(→ 73)
Define access code (0093)		(→ 73)
Device tag (0215)		(→ 56)
Applications	→	(→ 56)
Select gas type (3381)		(→ 57)
Process pressure (3376)		(→ 57)
Temperature (1853)		(→ 57)
Reference conditions (3439)		(→ 57)
Reference pressure (3378)		(→ 57)
Reference temperature (3379)		(→ 57)
FAD conditions	→	(→ 56)
FAD conditions (3438)		(→ 57)
FAD pressure (3373)		(→ 57)
FAD temperature (3374)		(→ 57)
System units	→	(→ 57)
Mass flow unit (0554)		(→ 58)
Mass unit (0574)		(→ 58)
Corrected volume flow unit (0558)		(→ 58)
Corrected volume unit (0575)		(→ 58)

FAD volume flow unit (0601)		(→  58)
FAD volume unit (0591)		(→  58)
Density unit (0555)		(→  58)
Pressure unit (0564)		(→  58)
Temperature unit (0557)		(→  58)
Length unit (0551)		(→  58)
Current output	→	(→  60)
Assign current output (0359)		(→  61)
Mass flow unit (0554)		(→  61)
Corrected volume flow unit (0558)		(→  61)
FAD volume flow unit (0601)		(→  61)
Temperature unit (0557)		(→  61)
PFS output	→	(→  62)
Operating mode (0469)		(→  64)
Assign pulse (0460)		(→  64)
Assign frequency (0478)		(→  64)
Switch output function (0481)		(→  64)
Assign diagnostic behavior (0482)		(→  64)
Assign limit (0483)		(→  64)
Assign status (0485)		(→  64)
Mass flow unit (0554)		(→  64)
Mass unit (0574)		(→  64)
FAD volume flow unit (0601)		(→  64)
FAD volume unit (0591)		(→  64)
Corrected volume flow unit (0558)		(→  64)
Corrected volume unit (0575)		(→  64)
Unit (0915)		(→  64)

Temperature unit (0557)		(→  64)
Value per pulse (0455)		(→  64)
Pulse width (0452)		(→  64)
Failure mode (0480)		(→  64)
Minimum frequency value (0453)		(→  64)
Maximum frequency value (0454)		(→  64)
Maximum frequency value (0454)		(→  64)
Minimum frequency value (0453)		(→  64)
Measuring value at minimum frequency (0476)		(→  64)
Measuring value at maximum frequency (0475)		(→  64)
Measuring value at maximum frequency (0475)		(→  64)
Measuring value at minimum frequency (0476)		(→  64)
Failure mode (0451)		(→  64)
Failure frequency (0474)		(→  64)
Switch-on value (0466)		(→  64)
Switch-off value (0464)		(→  64)
Switch-off value (0464)		(→  64)
Switch-on value (0466)		(→  64)
Switch-on delay (0467)		(→  64)
Switch-off delay (0465)		(→  64)
Failure mode (0486)		(→  64)
Invert output signal (0470)		(→  64)
Output conditioning	→	(→  67)
Display damping (0094)		(→  67)
		Current output → (→  67)
		Response time (0378) (→  67)
		Damping output (0363) (→  67)

	PFS output	→	(→ 67)
	Response time (0491)		(→ 67)
	Damping output (0477)		(→ 67)
	Low flow cut off	→	(→ 68)
	Assign process variable (1837)		(→ 68)
	On value low flow cutoff (1805)		(→ 68)
	Off value low flow cutoff (1804)		(→ 68)
	Totalizer	→	(→ 69)
	Assign process variable (0914)		(→ 69)
	Unit (0915)		(→ 69)
	Failure mode (901)		(→ 69)
	Display	→	(→ 69)
	Format display (0098)		(→ 69)
	Value 1 display (0107)		(→ 70)
	0% bargraph value 1 (0123)		(→ 70)
	100% bargraph value 1 (0125)		(→ 70)
	Decimal places 1 (0095)		(→ 70)
	Value 2 display (0108)		(→ 70)
	Decimal places 2 (0117)		(→ 70)
	Value 3 display (0110)		(→ 70)
	0% bargraph value 3 (0124)		(→ 70)
	100% bargraph value 3 (0126)		(→ 70)
	Decimal places 3 (0118)		(→ 70)
	Value 4 display (0109)		(→ 70)
	Decimal places 4 (0119)		(→ 71)
	Display interval (0096)		(→ 71)
	Display damping (0094)		(→ 71)
	Header (0097)		(→ 71)
	Header text (0112)		(→ 71)

	Separator (0101)	(→ 71)
	Conf. backup disp. →	(→ 71)
	Operating time (0652)	(→ 71)
	Last backup (0102)	(→ 71)
	Configuration management (0100)	(→ 72)
	Comparison result (0103)	(→ 72)
Diagnostics →		(→ 81)
Actual diagnostics (0691)		(→ 81)
Previous diagnostics (0690)		(→ 81)
Operating time from restart (0653)		-
Operating time (0652)		(→ 71)
	Diagnostics list →	(→ 88)
	Diagnostics 1 to 5(0696)	(→ 88)
	Event logbook →	(→ 81)
	Filter options (0705)	(→ 89)
	Events list →	(→ 81)
	Device info →	(→ 46)
	Device tag (0011)	(→ 92)
	Serial number (0009)	(→ 92)
	Firmware version (0010)	(→ 46)
	Device name (0013)	(→ 46)
	Order code (0008)	(→ 46)
	Extended order code 1 (0023)	(→ 46)
	Extended order code 2 (0021)	(→ 46)
	Extended order code 3 (0022)	(→ 46)
	ENP version (0012)	(→ 46)
	Device revision (0204)	(→ 46)
	Device ID (0221)	(→ 46)
	Device type (0222)	(→ 46)

Manufacturer ID (0223)		(→ 46)
Measured values	→	(→ 76)
	Process variables →	(→ 76)
	Mass flow (1838)	(→ 76)
	Corrected volume flow (1847)	(→ 76)
	FAD volume flow (1851)	(→ 76)
	Temperature (1853)	(→ 76)
	Totalizer →	(→ 76)
	Totalizer value (0911)	(→ 76)
	Totalizer overflow (0910)	(→ 76)
	Output values →	(→ 76)
	Output current (0361)	(→ 78)
	Pulse output (0456)	(→ 78)
	Output frequency (0471)	(→ 78)
	Switch status (0461)	(→ 78)
	Data logging →	(→ 76)
	Assign channel 1 (0851)	(→ 76)
	Assign channel 2 (0852)	(→ 76)
	Assign channel 3 (0853)	(→ 76)
	Assign channel 4 (0854)	(→ 76)
	Logging interval (0856)	(→ 76)
	Clear logging data (0855)	(→ 76)
	Display channel 1 →	(→ 76)
	Display channel 2 →	(→ 76)
	Display channel 3 →	(→ 76)
	Display channel 4 →	(→ 76)
	Simulation →	(→ 48)
	Assign simulation process variable (1810)	(→ 48)
	Value process variable (1811)	(→ 48)

	Simulation current output 1 (0354)		(→ 48)
	Value current output 1 (0355)		(→ 48)
	Frequency simulation (0472)		(→ 48)
	Frequency value (0473)		(→ 48)
	Pulse simulation (0458)		(→ 48)
	Pulse value (0459)		(→ 48)
	Switch output simulation (0462)		(→ 48)
	Switch status (0463)		(→ 48)
	Simulation device alarm (0654)		(→ 48)
	Device reset →		(→ 81)
	Device reset		(→ 81)
	Expert →		
	Direct access (0106)		(→ 32)
	Locking status (0122)		(→ 30)
	Access stat.display (0091)		
	System →		
	Enter access code (0003)		(→ 73)
	Define access code (0093)		(→ 73)
	Display →		(→ 76)
	Language (0104)		(→ 48)
	Format display (0098)		(→ 69)
	Value 1 display (0107)		(→ 70)
	0% bargraph value 1 (0123)		(→ 70)
	100% bargraph value 1 (0125)		(→ 70)
	Decimal places 1 (0095)		(→ 70)
	Value 2 display (0108)		(→ 70)
	Decimal places 2 (0117)		(→ 70)
	Value 3 display (0110)		(→ 70)
	0% bargraph value 3 (0124)		(→ 70)

	100% bargraph value 3 (0126)		(→ 70)
	Decimal places 3 (0118)		(→ 70)
	Value 4 display (0109)		(→ 70)
	Decimal places 4 (0119)		(→ 71)
	Display interval (0096)		(→ 71)
	Display damping (0094)		(→ 71)
	Header (0097)		(→ 71)
	Header text (0112)		(→ 71)
	Separator (0101)		(→ 71)
	Contrast display (0105)		(→ 76)
	Access status display (0091)		(→ 41)
	Conf. backup disp. →		(→ 71)
	Operating time		(→ 71)
	Last backup		(→ 71)
	Configuration management		(→ 72)
	Comparison result		(→ 72)
	Diagnostic behavior →		
	Alarm delay →		
		Diagnostic behavior →	
	Management →		
	Device reset (0000)		(→ 88)
	Activate SW option (0029)		
	Reset write protection (0000)		
Sensor →			
	Measured values →		(→ 76)
		Process variables →	(→ 77)
		Mass flow (1838)	(→ 77)
		Corrected volume flow (1847)	(→ 77)
		FAD volume flow (1851)	(→ 77)
		Temperature (1853)	(→ 77)

	Totalizer	→	(→ 77)
	Totalizer value (0911)		(→ 77)
	Totalizer overflow (0910)		(→ 78)
	Output values	→	(→ 78)
	Output current (0361)		(→ 78)
	Pulse output 1 to 2 (0456)		(→ 78)
	Output frequency 1 to 2 (0471)		(→ 78)
	Switch status 1 to 2 (0461)		(→ 78)
	System units	→	(→ 57)
	Mass flow unit (0554)		(→ 58)
	Mass unit (0574)		(→ 58)
	Corrected volume flow unit (0558)		(→ 58)
	Corrected volume unit (0575)		(→ 58)
	FAD volume flow unit (0601)		(→ 58)
	FAD volume unit (0591)		(→ 58)
	Density unit (0555)		(→ 58)
	Pressure unit (0564)		(→ 58)
	Temperature unit (0557)		(→ 58)
	Length unit (0551)		(→ 58)
	Date/time format (2812)		
	User spec. units	→	
	User mass text (560)		
	User mass offset (562)		
	User mass factor (561)		
	Process param.	→	
	Flow override (1839)		
	Flow damping (1802)		
	Low flow cut off	→	(→ 68)
	Assign process variable (1837)		(→ 68)

	On value low flow cutoff (1805)	(→ 68)
	Off value low flow cutoff (1804)	(→ 68)
Calculated value →	Reference values →	
	Reference conditions (3439)	(→ 57)
	Reference pressure (3378)	(→ 57)
	Reference temperature (3379)	(→ 57)
	Reference density (3377)	
	FAD conditions (3438)	(→ 57)
	FAD pressure (3473)	(→ 57)
	FAD temperature (3474)	(→ 57)
	FAD density (3372)	
	Fluid properties →	
	Density (3462)	
	Reference density (3377)	
	FAD density (3372)	
Sensor adjustment →	Installation settings →	
	Installation factor (3470)	(→ 51)
	Pipe shape (3441)	(→ 51)
	Pipe inner diameter (3476)	(→ 51)
	Duct internal height (3405)	(→ 51)
	Duct internal width (3411)	(→ 51)
	Orientation (3437)	
	Pipe wall thickness (3409)	
	Mounting set height (3435)	
	Insertion depth (3406)	
	In-situ adjustment →	
	Operating mode (3400)	
	Values in use →	

Flow reference in use
(3440)

Flow reference value 1
(3401)

Power coefficient 1 (3425)

Flow reference value 2
(3418)

Power coefficient 2 (3426)

Flow reference value 3
(3419)

Power coefficient 3 (3427)

Flow reference value 4
(3420)

Power coefficient 4 (3428)

Flow reference value 5
(3421)

Power coefficient 5 (3429)

Flow reference value 6
(3422)

Power coefficient 6 (3430)

Flow reference value 7
(3423)

Power coefficient 7 (3431)

Flow reference value 8
(3424)

Power coefficient 8 (3432)

Flow reference value 9
(3474)

Power coefficient 9 (3475)

New adjustment →

Select flow reference
(3382)


Perform adjustment →

Clear values (3529)

Flow reference value 1
(3384)

Power coefficient 1 (3392)

Flow reference value 2
(3385)



Failure mode (364)	
Output current (361)	(→ 78)
Start-up mode (368)	
PFS output 1	→
Operating mode (469)	(→ 53)
Assign pulse (460)	(→ 54)
Value per pulse (455)	(→ 54)
Pulse width (452)	(→ 64)
Failure mode (480)	(→ 64)
Pulse output (456)	(→ 78)
Assign frequency (478)	(→ 53)
Minimum frequency value (453)	(→ 64)
Maximum frequency value (454)	(→ 64)
Measuring value at minimum frequency (476)	(→ 64)
Measuring value at maximum frequency (475)	(→ 64)
Damping output (477)	(→ 67)
Response time (491)	(→ 67)
Failure mode (451)	(→ 64)
Output frequency (471)	(→ 78)
Switch output function (481)	(→ 54)
Assign diagnostic behavior (482)	(→ 64)
Assign limit (483)	(→ 64)
Switch-on value (466)	(→ 54)
Switch-off value (464)	(→ 54)
Assign status (485)	(→ 54)
Switch-on delay (467)	(→ 64)
Switch-off delay (465)	(→ 64)
Failure mode (486)	(→ 64)
Switch status (461)	(→ 78)

	Invert output signal (470)	(→ 64)
Communication →		
	HART output →	
	Configuration →	
	Burst mode (208)	
	Burst command (207)	
	HART address (219)	
	No. of preambles (217)	
	HART short tag (220)	
	Information	
	Device revision (204)	(→ 46)
	Device ID (221)	(→ 46)
	Device type (222)	(→ 46)
	Manufacturer ID (223)	(→ 46)
	HART revision (205)	
	HART descriptor (212)	
	HART message (216)	
	HART date code (202)	
	Hardware revision (206)	
	Software revision (224)	
	Output	(→ 46)
	Assign PV (234)	(→ 46)
	Primary variable (PV) (201)	(→ 46)
	Assign SV (235)	(→ 46)
	Secondary variable (SV) (226)	(→ 46)
	Assign TV (236)	(→ 46)
	Tertiary variable (TV) (228)	(→ 46)
	Assign QV (237)	(→ 46)
	Quaternary variable (QV) (203)	(→ 46)
Application →		
	Reset all totalizers (2806)	(→ 79)

	Totalizer →	
	Assign process variable (914)	(→ 69)
	Unit (915)	(→ 69)
	Control totalizer (912)	(→ 79)
	Preset value (913)	(→ 79)
	Failure mode (901)	(→ 69)
	Diagnostics →	
	Actual diagnostics (691)	(→ 81)
	Previous diagnostics (690)	(→ 81)
	Operating time from restart (653)	-
	Operating time (652)	(→ 71)
	Diagnostics list →	(→ 88)
	Diagnostics 1 (692)	(→ 88)
	Diagnostics 2 (693)	(→ 88)
	Diagnostics 3 (694)	(→ 88)
	Diagnostics 4 (695)	(→ 88)
	Diagnostics 5 (696)	(→ 88)
	Event logbook →	(→ 89)
	Filter options (705)	(→ 90)
	Device info →	(→ 46)
	Device tag (11)	(→ 92)
	Serial number (9)	(→ 92)
	Firmware version (10)	(→ 46)
	Device name (13)	(→ 46)
	Order code (8)	(→ 46)
	Extended order code 1 (23)	(→ 46)
	Extended order code 2 (21)	(→ 46)
	Extended order code 3 (22)	(→ 46)
	ENP version (12)	(→ 46)
	Configuration counter (233)	

Data logging	→	(→ 80)
Assign channel 1 (851)		(→ 80)
Assign channel 2 (852)		(→ 80)
Assign channel 3 (853)		(→ 80)
Assign channel 4 (854)		(→ 80)
Logging interval (856)		(→ 80)
Clear logging data (855)		(→ 80)
Display channel 1	→	(→ 80)
Display channel 2	→	(→ 80)
Display channel 3	→	(→ 80)
Display channel 4	→	(→ 80)
Data logging	→	
Electronics temperature	→	
Minimum value (3445)		
Maximum value (3444)		
Process temperature	→	
Minimum value (3447)		
Maximum value (3446)		
Simulation	→	(→ 72)
Assign process variable (1810)		(→ 73)
Value process variable (1811)		(→ 73)
Simulation current output 1 (354)		(→ 73)
Value current output 1 (355)		(→ 73)
Frequency simulation (472)		(→ 73)
Frequency value (473)		(→ 73)
Pulse simulation (458)		(→ 73)
Pulse value (459)		(→ 73)
Switch output simulation (462)		(→ 73)
Pulse value (463)		(→ 73)

	Simulation device alarm (654)	(→ 73)
--	----------------------------------	--------

Index

A

Access authorization to parameters	
Read access	41
Write access	41
Access code	41
Incorrect input	41
Adapting the diagnostic behavior	85
Ambient temperature range	19, 104
AMS Device Manager	43
Function	43
Application	8, 96
Application packages	113
Applicator	96, 97
Approvals	112

C

Cable entries	
Technical data	102
Cable entry	
Degree of protection	25
Cable specification	23, 102
CE mark	112
CE mark (declaration of conformity)	9
Certificates	112
Check	
Installation	21
Post-connection	26
Received goods	11
Checklist	
Post-connection check	26
Post-mounting check	21
Cleaning	
Cleaning the transducer	93
Exterior cleaning	93
Interior cleaning	93
Commissioning	48
Advanced settings	55
Configuring the measuring device	49
Communication-specific data	46
Connecting cable	
Requirements	23
Connecting the measuring device	24
Connection preparations	24
Connection tools	23
Context menu	
Calling up	36
Close	36
Explanation	36
C-Tick symbol	112
Current consumption	102

D

Declaration of Conformity	9
Declaration of Contamination	94
Define access code	73
Degree of protection	25, 104

Design

Measuring device	10
Designated use	8
Device components	10
Device description files	46
Device documentation	
Supplementary documentation	7
Device name	
Sensor	13
Transmitter	12
Device repair	92
Device revision	46
Device type ID	46
Diagnostic behavior	
Explanation	83
Symbols	83
Diagnostic information	84
In the operating tool	85
Local display	83
Overview	86
Remedial measures	86
Diagnostic message	83
Diagnostics	
Symbols	83
Diagnostics list	88
DIP switch	
see Lock switch	
Direct access code	32
Disabling write protection	73
Display	
see Local display	
Display area	
For operational display	31
In the navigation view	33
Display values	
For output values	78
For process variables	77
For the totalizer	77
Disposal	95
Document	
Function	5
Symbols used	5
Document function	5

E

Electrical connection	
Commubox FXA191, 195	44
Commubox FXA195	111
Commubox FXA291	45, 112
Degree of protection	25
Field Communicator	44, 111
Handheld terminals	44, 111
Measuring device	23
Operating tools	44, 111
Via HART protocol	44, 111
Via service interface (CDI)	45, 112

- Electromagnetic compatibility 104
 - Electronic modules 25
 - Electronics board
 - I/O electronics modules 25
 - Electronics housing
 - Turning
 - see Turning the transmitter housing
 - Electronics module 10
 - Enabling write protection 73
 - Endress+Hauser services
 - About maintenance 93
 - About repair 92
 - Error messages
 - see Diagnostic messages
 - Event history 89
 - Events list 89
 - Ex approval 112
 - Extended order code
 - Sensor 13
 - Transmitter 12
 - Exterior cleaning 93
- F**
- FieldCare 43
 - Function 43
 - User interface 43
 - Field Communicator
 - Function 44
 - Field Communicator 375
 - Function 44
 - Field of application
 - Residual risks 8
 - Field Xpert 43
 - Function 43
 - Filtering the event logbook 90
 - Firmware
 - Release date 46
 - Version 46
 - Flow direction 15, 20
 - Flow limit 105
 - Function check 48
 - Functions
 - see Parameter
 - Function scope
 - AMS Device Manager 43
 - FieldCare 43
 - Field Communicator 44
 - Field Communicator 475 44
 - Field Xpert 43
 - SIMATIC PDM 44
- G**
- Galvanic isolation 100
- H**
- HART protocol
 - Device variables 46
 - Measured variables 46
 - Revision 46
- I**
- Help text
 - Calling up 38
 - Close 38
 - Explanation 38
 - HistoROM (description) 71
- I**
- Identifying the measuring device 12
 - Incoming acceptance 11
 - Influence
 - Medium pressure 104
 - Information on the document 5
 - Inlet runs 18
 - Input 96
 - Input mask 34
 - Installation 15
 - Installation conditions
 - Inlet and outlet runs 18
 - Installation dimensions 18
 - Mounting location 15
 - Orientation 15
 - System pressure 19, 105
 - Thermal insulation 19, 105
 - Installation dimensions 18
 - Interior cleaning 93
- K**
- Keypad lock
 - Disabling 41
 - Enabling 41
- L**
- Languages, local operation 112
 - Line recorder 80
 - Load 23
 - Local display
 - see In alarm condition
 - see Diagnostic message
 - see Operational display
 - Editing view 34
 - Navigation view 32
 - Local operation
 - Languages 112
 - Lock switch 74
 - Low flow cut off 100
- M**
- Main electronics module 10
 - Maintenance 93
 - Maintenance tasks 93
 - Managing the device configuration 71
 - Manufacturer ID 46
 - Manufacturing date 12, 13
 - Materials 109
 - Maximum measured error 103
 - Measured variables
 - see Process variables
 - Calculated 96
 - Direct 96
 - Measuring and test equipment 93

- Measuring device
 - Configuration 49
 - Conversion 92
 - Design 10
 - Disposal 95
 - Enabling 48
 - Integrating via HART protocol 46
 - Mounting the sensor 20
 - Preparing for electrical connection 24
 - Preparing for mounting 20
 - Removing 95
 - Repair 92
 - Return 94
 - Measuring principle 96
 - Measuring range 96
 - Calibrated 96
 - Extended 97
 - Measuring range, recommended 105
 - Measuring system 96
 - Media 8
 - Medium pressure
 - Influence 104
 - Menus
 - For measuring device configuration 49
 - For specific settings 55
 - Mounting dimensions
 - see Installation dimensions
 - Mounting location 15
 - Mounting preparations 20
 - Mounting tools 20
- N**
- Nameplate
 - Sensor 13
 - Transmitter 12
 - Navigation path (navigation view) 32
 - Navigation view
 - In the wizard 32
 - Of the submenu 32
 - Numeric editor 34
- O**
- Operable flow range 98
 - Operating elements 35, 84
 - Operating keys
 - see Operating elements
 - Operating menu
 - Design 27
 - Menus, submenus 27
 - Submenus and user roles 29
 - Wizards 27
 - Operating menu overview
 - Operators and maintenance 114
 - Operating philosophy 29
 - Operating tools
 - Connection overview 44
 - Operation 76
 - Operational display 30
 - Operational safety 9
- Operation options 27
 - Control system 27
 - Local operation 27
 - Operating tool 27
 - Overview 27
 - Order code 12, 13
 - Orientation (vertical, horizontal) 15
 - Outlet run
 - Pressure measuring device 19
 - Outlet runs 18
 - Output 98
 - Output signal 98
- P**
- Packaging disposal 14
 - Parameter
 - Changing 40
 - Enter a value 40
 - Parameter settings
 - Assign current output 53
 - Duct internal height, duct internal width 51
 - For applications 56
 - For conf. backup disp. 71
 - For local display 69, 76
 - For low flow cut off 68
 - For medium selection and setting 50
 - For pulse/frequency/switch output 53
 - For simulation 72
 - For system units 58, 61, 64
 - For the installation factor setting 52
 - For the operation 79
 - For the process pressure setting 50
 - For the totalizer 67, 69
 - Pipe inner diameter 51
 - Pipe shape 51
 - Performance characteristics 103
 - Post-connection
 - see Electrical connection
 - Post-connection check (checklist) 26
 - Post-installation check 48
 - Post-mounting check (checklist) 21
 - Potential equalization 102
 - Power supply failure 102
 - Pressure loss 105
 - Product safety 9
 - Protecting parameter settings 73
- R**
- Read access 41
 - Reading off measured values 76
 - Recalibration 93
 - Reference operating conditions 103
 - Registered trademarks 10
 - Remedial measures
 - Calling up 84
 - Close 84
 - Remote operation 111
 - Repair 92
 - Concept 92

- Notes 92
- Repair of a device 92
- Repeatability 104
- Replacement
 - Device components 92
- Requirements for personnel 8
- Response time 104
- Returning the measuring device 94
- S**
- Safety
 - Safety instructions 8
- Seals
 - Medium temperature range 105
- Sensor
 - Medium temperature range 105
 - Mounting 20
 - System pressure 19, 105
- Serial number 12, 13
- Settings
 - Adapting the measuring device to the process conditions
 - 78
 - Applications 56
 - Current output 60, 62
 - Device reset 88
 - Device tag 56
 - Installation factor 51
 - Local display 69
 - Low flow cut off 68
 - Managing the device configuration 71
 - Medium 49, 50
 - Operating language 48
 - Pipe shape 51, 53
 - Pulse/frequency/switch output 53
 - Resetting the totalizer 79
 - Sensor data 51
 - Simulation 72
 - System units 57
 - Totalizer 67, 69
 - Totalizer reset 79
- Setting the operating language 48
- Shock resistance 104
- Showing data logging 80
- Signal on alarm 99
- SIMATIC PDM 44
 - Function 44
- Software release 46
- Spare part 92
- Spare parts 92
 - Concept 92
 - Nameplate 92
- Standards and guidelines 113
- Status area
 - For operational display 30
 - In the navigation view 32
- Status signals 83
- Storage conditions 14
- Storage temperature 14
- Structure of the operating menu 27
- Submenu
 - Conf. backup disp. 71
 - Current output 60
 - Data logging 80
 - Events list 89
 - Local display 68
 - Operation 76, 79
 - Output values 78
 - PFS output 62
 - Process variables 76
 - Simulation 72
 - System units 57
 - Totalizer 67, 69, 77
- Submenus 29
- Supply unit
 - Requirements 23
- Supply voltage 23, 101
- Symbols
 - For communication 30
 - For correction 34
 - For diagnostic behavior 30
 - For locking 30
 - For measured variable 31
 - For measurement channel number 31
 - For menus 33
 - For parameters 33
 - For status signal 30
 - For submenu 33
 - For wizard 33
 - In the status area of the local display 30
 - In the text and numeric editor 34
- System design
 - see Measuring device design
 - Measuring system 96
- System integration 46
- System pressure 19, 105
- T**
- Technical data, overview 96
- Temperature range
 - Ambient temperature 19, 104
 - Ambient temperature range for display 110
 - Medium temperature 105
 - Storage temperature 14
- Terminal assignment 25, 101
- Terminals 102
- Terminal voltage 23
- Text editor 34
- Thermal insulation 19, 105
- Tools
 - For electrical connection 23
 - For mounting 20
 - Transport 14
- Tool tip
 - see Help text
- Transmitter
 - Connecting the signal cables 25
 - Turning the display module 21
 - Turning the housing 20

Transmitter housing	
Turning	20
Transporting the measuring device	14
Troubleshooting	
General	81
Turning the display module	21
U	
Use of the measuring device	
see Designated use	
Use of the measuring devices	
Borderline cases	8
Incorrect use	8
User interface	
FieldCare	43
User roles	29
V	
Version data for the device	46
Vibration resistance	104
W	
W@M	92, 93
W@M Device Viewer	12, 92
Weight	
SI units	108
Transport (notes)	14
US units	109
Workplace safety	9
Write access	41
Write protection	
Via access code	73
Via lock switch	74

Declaration of Hazardous Material and De-Contamination *Erklärung zur Kontamination und Reinigung*

RA No.

Please reference the Return Authorization Number (RA#), obtained from Endress+Hauser, on all paperwork and mark the RA# clearly on the outside of the box. If this procedure is not followed, it may result in the refusal of the package at our facility.
Bitte geben Sie die von E+H mitgeteilte Rücklieferungsnummer (RA#) auf allen Lieferpapieren an und vermerken Sie diese auch außen auf der Verpackung. Nichtbeachtung dieser Anweisung führt zur Ablehnung ihrer Lieferung.

Because of legal regulations and for the safety of our employees and operating equipment, we need the "Declaration of Hazardous Material and De-Contamination", with your signature, before your order can be handled. Please make absolutely sure to attach it to the outside of the packaging.

Aufgrund der gesetzlichen Vorschriften und zum Schutz unserer Mitarbeiter und Betriebseinrichtungen, benötigen wir die unterschriebene "Erklärung zur Kontamination und Reinigung", bevor Ihr Auftrag bearbeitet werden kann. Bringen Sie diese unbedingt außen an der Verpackung an.

Type of instrument / sensor

Geräte-/Sensortyp _____

Serial number

Seriennummer _____

Used as SIL device in a Safety Instrumented System / Einsatz als SIL Gerät in Schutzeinrichtungen

Process data / Prozessdaten

Temperature / Temperatur _____ [°F] _____ [°C]

Pressure / Druck _____ [psi] _____ [Pa]

Conductivity / Leitfähigkeit _____ [µS/cm]

Viscosity / Viskosität _____ [cp] _____ [mm²/s]

Medium and warnings

Warnhinweise zum Medium



	Medium / concentration <i>Medium / Konzentration</i>	Identification CAS No.	flammable <i>entzündlich</i>	toxic <i>giftig</i>	corrosive <i>ätzend</i>	harmful/ irritant <i>gesundheitsschädlich/ reizend</i>	other * <i>sonstiges*</i>	harmless <i>unbedenklich</i>
Process medium <i>Medium im Prozess</i>								
Medium for process cleaning <i>Medium zur Prozessreinigung</i>								
Returned part cleaned with <i>Medium zur Endreinigung</i>								

* explosive; oxidizing; dangerous for the environment; biological risk; radioaktiv

* *explosiv; brandfördernd; umweltgefährlich; biogefährlich; radioaktiv*

Please tick should one of the above be applicable, include safety data sheet and, if necessary, special handling instructions.

Zutreffendes ankreuzen; trifft einer der Warnhinweise zu, Sicherheitsdatenblatt und ggf. spezielle Handhabungsvorschriften beilegen.

Description of failure / Fehlerbeschreibung _____

Company data / Angaben zum Absender

Company / Firma _____	Phone number of contact person / Telefon-Nr. Ansprechpartner: _____
Address / Adresse _____	Fax / E-Mail _____
Your order No. / Ihre Auftragsnr. _____	

"We hereby certify that this declaration is filled out truthfully and completely to the best of our knowledge. We further certify that the returned parts have been carefully cleaned. To the best of our knowledge they are free of any residues in dangerous quantities."

"Wir bestätigen, die vorliegende Erklärung nach unserem besten Wissen wahrheitsgetreu und vollständig ausgefüllt zu haben. Wir bestätigen weiter, dass die zurückgesandten Teile sorgfältig gereinigt wurden und nach unserem besten Wissen frei von Rückständen in gefahrbringender Menge sind."

(place, date / Ort, Datum)

Name, dept./Abt. (please print / bitte Druckschrift)

Signature / Unterschrift

www.endress.com/worldwide

Endress+Hauser 

People for Process Automation
