



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Operating Instructions

Appendix to the operating instructions

Energy Manager RMx621 with ModBus Interface V3.03.00

Connecting the Energy Manager to ModBus-IDA-systems




Table of contents

1 General	3
1.1 Transport damage	3
1.2 Scope of delivery	3
1.3 Basics	3
2 Installation.....	4
2.1 Prerequisites	4
2.2 Connections and terminal diagram	4
3 Commissioning.....	5
3.1 Configuring the ModBus interface on the Energy Manager RMx621	5
4 Data transmission	6
4.1 ModBus telegram.....	6
4.2 Measured value status.....	6
4.3 Request procedure	7
4.3.1 From master to RMx621	7
4.3.2 Response from RMx621 in event of successful request	7
4.3.3 Response from RMx621 in event of unsuccessful request	7
4.3.4 Error code.....	8
5 Troubleshooting.....	8
5.1 No communication with RMx621	8

1 General

1.1 Transport damage

Please inform both your supplier and transport company.

1.2 Scope of delivery

- This Operating Manual
- Energy Manager RMx621 with ModBus option (order code: RMC621-xxxXXXXxx**A**x or RMC621-xxxXXXXxx**B**x RMS621-xxXXXXxx**A**x or RMS621-xxXXXXxx**B**x)
- Operating Manual for the RMx621

If anything is missing, please ask your supplier!

Please note the following pictograms:



Note: Information about commissioning and operation



Caution: Failure to observe instructions can cause damage to the device or lead to malfunction!

1.3 Basics

- RMx621 uses ModBus RTU (Remote Terminal Unit) in accordance with ModBus-IDA Protocol Specification V 1.1a (June 2004)
- ModBus can be set for all RS232/RS485 interfaces available to the RMx621
- Configuration of the ModBus at the RMx621 via Setup – Communication – RS485 / MODBUS(1) or RS232/485 / MODBUS(2)

2 Installation


Refer to the installation instructions provided for the Energy Computer RMx621 in the associated operating manual.

2.1 Prerequisites

The ModBus option is available for the Energy Manager RMx621 with firmware version V3.03.00 or later.

2.2 Connections and terminal diagram

Connecting the Energy Manager RMx621 to a ModBus system.





3 Commissioning

3.1 Configuring the ModBus interface on the Energy Manager RMx621

All of the parameters relevant for the ModBus interface can be found in the following menu:

- "Setup/Communication/RS485/MODBUS (1)" or
- "Setup/Communication/RS232/RS485/MODBUS (2)".



If you are commissioning the device for the first time, please set the "Use" parameter to 'MODBUS'. This makes the following parameters visible:

- Use
- Unit address
- Baud rate
- Parity
- Register

Function (menu item)	Parameter setting	Description
Use	<ul style="list-style-type: none"> • RS485 • RS232/RS485 • ModBus 	Defines the operating mode of the optional interface
Unit address	000	Input 1 to 247 The RMx621 always responds to the address 0.
Baud rate	9600 19200 38400 57600	Setting for the transmission rate on the ModBus
Parity	Even Odd None	
Register	Reg 000 to 002 Reg 003 to 005	Allocation of the values in the Energy Manager to the ModBus

4 Data transmission

4.1 ModBus telegram

RMx621 supports the function 03: Read Holding Register.

This allows for up to 36 current measured values with status to be transmitted.

Each measured value occupies 3 registers (6 bytes). The measured values are assigned to the registers in the ModBus settings in the RMx621.

Register 000	:	Status of the first measured value (16-bit integer, high byte first)
Register 001 to 002	:	First measured value (32-bit float, high byte first)
Register 003	:	Status of second measured value (16-bit integer, high byte first)
Register 004 to 005	:	Second measured value (32-bit float, high byte first)
.	.	.
Register 105	:	Status of 36th measured value (16-bit integer, high byte first)
Register 106 to 107	:	36th measured value (32-bit float, high byte first)



Note:

All values correspond to the physical base units: °C, bar, /sec, kg, kJ, dm³, kg/m³ (density), kJ/kg (enthalpy)

4.2 Measured value status

0	:	Invalid value
1	:	Measured value valid
2	:	Overflow warning
3	:	Overflow error
4	:	Underflow warning
5	:	Underflow error
6	:	Saturated steam alarm
7	:	Error in differential pressure calculation
8	:	Wrong medium for DP calculation
9	:	Wrong value range → DP calculation inaccurate
10	:	Differential pressure → General error
11	:	Range overshoot (T _{sat} > 350 etc.) on
12	:	Change in state of aggregation
26	:	Differential pressure → General error
99	:	No measured value is assigned to the register in the setup of the ModBus

When a request is made by the master, the desired start register and the number of registers that are to be read are sent to the RMx621.

4.3 Request procedure

4.3.1 From master to RMx621

ga fk r1 r0 a1 a0 c1 c2

ga	Unit address (1 to 247)
fk	Function, always 03
r1 r0	Start register (high byte first)
a1 a0	Number of registers (high byte first)
c0 c1	CRC checksum (low byte first)

4.3.2 Response from RMx621 in event of successful request

ga fk az s1 s0 w3 w2 w1 w0 s1 s0 w3 w2 w1 w0 s1 s0 w3 w2 w1 w0 c1 c0

ga	Unit address
fk	Function, always 03
az	Number of bytes of all subsequent measured values
s1 s0	Status of the first measured value (16-bit integer, high byte first)
w3 w2 w1 w0	First measured value in 32-bit float format, high byte first
s1 s0	Status of the second measured value (16-bit integer, high byte first)
w3 w2 w1 w0	Second measured value (32-bit float, high byte first)
.	
.	
s1 s0	Status of the last measured value (16-bit integer, high byte first)
w3 w2 w1 w0	Last measured value (32-bit float, high byte first)
c0 c1	Checksum CRC 16-bit (low byte first)

4.3.3 Response from RMx621 in event of unsuccessful request

ga fk fc c0 c1

ga	Unit address
fk	Requested function + 80hex
fc	Error code
c0 c1	Checksum CRC 16-bit (low byte first)

4.3.4 Error code

01 : Function not known

02 : Start register invalid

03 : Number of registers to be read invalid



Note:

If there are checksum or parity errors in the request from the master, the RMx621 does not respond.

5 Troubleshooting

5.1 No communication with RMx621

If communication with the RMx621 does not materialize via the ModBus, please check the following possibilities:

- Was setup in the RMx621 completed correctly?
- Are the RMx621 and the master using the same baud rate and parity?
- Is the wiring of the interface OK?
- Does the unit address sent by the master match the specified unit address of the RMx621?
- Do all slaves at the ModBus have different unit addresses?
- Is the RS232 jack plug unplugged? (only necessary for non-Ex devices when using the second RS485 interface for ModBus)

www.endress.com/worldwide
