

Operating Instructions

iTEMP TMT82

2-channel temperature transmitter
with HART® protocol



Table of contents

1	About this document	4	8	Commissioning	39
1.1	Document function	4	8.1	Function check	39
1.2	Symbols	4	8.2	Switching on the device	39
1.3	Tool symbols	5	8.3	Protecting settings from unauthorized access .	39
1.4	Documentation	6	9	Diagnostics and troubleshooting ...	40
1.5	Change history	6	9.1	General troubleshooting	40
1.6	Registered trademarks	7	9.2	Diagnostic information via LED	41
2	Basic safety instructions	8	9.3	Diagnostic information on local display	42
2.1	Requirements for the personnel	8	9.4	Overview of diagnostic information	42
2.2	Intended use	8	9.5	Diagnostic list	43
2.3	Workplace safety	8	10	Maintenance and cleaning	45
2.4	Operational safety	8	10.1	Maintenance work	45
2.5	Product safety	9	10.2	Cleaning of surfaces not in contact with the medium	46
2.6	IT security	9	11	Repair	46
3	Incoming acceptance and product identification	9	11.1	General information	46
3.1	Incoming acceptance	9	11.2	Spare parts	46
3.2	Product identification	10	11.3	Return	46
3.3	Storage and transport	10	11.4	Disposal	47
4	Installation	12	12	Accessories	47
4.1	Installation requirements	12	12.1	Device-specific accessories	47
4.2	Installing the transmitter	12	12.2	Communication-specific accessories	48
4.3	Post-installation check	18	12.3	Service-specific accessories	49
5	Electrical connection	19	12.4	Online tools	49
5.1	Connecting requirements	19	12.5	System components	49
5.2	Quick wiring guide	20	13	Technical data	51
5.3	Connecting the sensor	22	13.1	Input	51
5.4	Connecting the transmitter	24	13.2	Output	52
5.5	Special connection instructions	25	13.3	Electrical connection	54
5.6	Ensuring the degree of protection	25	13.4	Performance characteristics	54
5.7	Post-connection check	26	13.5	Environment	62
6	Operation options	27	13.6	Mechanical construction	63
6.1	Overview of operation options	27	13.7	Certificates and Approvals	68
6.2	Structure and function of the operating menu	28	14	Operating menu and parameter description	70
6.3	Measured value display and operating elements	30	14.1	"Setup" menu	77
6.4	Access to the operating menu via the operating tool	32	14.2	"Diagnostics" menu	97
7	System integration	36	14.3	"Expert" menu	105
7.1	HART device variables and measured values ..	36	Index	124	
7.2	Device variables and measured values	37			
7.3	Supported HART commands	37			

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
	Alternating current
	Direct current and alternating current
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Potential equalization connection (PE: Protective earth) Ground terminals that must be connected to ground prior to establishing any other connections. The ground terminals are located on the interior and exterior of the device: ■ Interior ground terminal: potential equalization connection is connected to the supply network. ■ Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Symbols for certain types of information


Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.

Symbol	Meaning
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
	Series of steps
	Result of a step
	Help in the event of a problem
	Visual inspection

1.2.4 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3,...	Item numbers		Series of steps
A, B, C, ...	Views	A-A, B-B, C-C, ...	Sections
	Hazardous area		Safe area (non-hazardous area)

1.3 Tool symbols

Symbol	Meaning
 A0011220	Flat-blade screwdriver
 A0011219	Phillips screwdriver
 A0011221	Allen key
 A0011222	Open-ended wrench
 A0013442	Torx screwdriver

1.4 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the product configuration:

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid This document contains all the technical data on the product and provides an overview of everything that can be ordered with the product.
Brief Operating Instructions (KA)	Quick guide to obtaining the first measured value The Operating Instructions contain all the essential information about the product from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Reference The Operating Instructions contain the information that is required in the various phases of the life cycle of the product: From product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	Reference for parameters The document contains detailed explanations of readable or configurable parameters in the product. The description is aimed at those who work with the product over its entire life cycle and perform specific configurations.
Safety Instructions (XA)	Safety Instructions for electrical equipment in hazardous areas are supplied with the product depending on the approval. These are an integral part of the Operating Instructions.  The nameplate indicates the Safety Instructions (XA) that are relevant to the product.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the product documentation.

1.5 Change history

Revision history

The firmware version (FW) on the nameplate and in the Operating Instructions indicates the device release: XX.YY.ZZ (example 01.02.01).

XX	Change to main version. No longer compatible. The device and Operating Instructions change.
YY	Change to functions and operation. Compatible. The Operating Instructions change.
ZZ	Bug fixes and internal changes. No changes to the Operating Instructions.

Date	Firmware version	Modifications	Documentation
01.2011	01.00.zz	Original firmware	BA01028T/13.10
10.2012	01.00.zz	No changes to functions and operation.	BA01028T/14.12
02.2014	01.01.zz	Functional safety (SIL3)	BA01028T/15.13
02.2017	01.01.zz	Change in operating parameters for Functional Safety (SIL3)	BA01028T/17.17

Date	Firmware version	Modifications	Documentation
04.2019	01.02.zz	Change in device behavior for Functional Safety (SIL3)	BA01028T/19.19
05.2024	01.02.zz	New operating parameters for sensor backup reset	BA01028T/26.24

1.6 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

The device is a universal and user-configurable temperature transmitter with either one or two sensor inputs for resistance thermometers (RTD), thermocouples (TC), resistance and voltage transmitters. The head transmitter version of the device is intended for mounting in a terminal head (flat face) as per DIN EN 50446. The device is also available as an integrated unit in a field housing. It is also possible to mount the device on a DIN rail using the optional DIN rail clip. The device is also optionally available in a version suitable for DIN rail mounting as per IEC 60715 (TH35).

If the device is used in a manner not specified by the manufacturer, the protection provided by the device may be impaired.

The manufacturer is not liable for harm caused by improper or unintended use.



In SIL mode, the head transmitter must not be operated using the DIN rail clip and remote sensors as a substitute for a DIN rail transmitter in a cabinet.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Damage to the device!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ▶ The operator is responsible for trouble-free operation of the device.

Approval-related area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g., explosion protection or safety instrumented system):

- ▶ Based on the technical data on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area. The nameplate can be found on the side of the transmitter housing.

- ▶ Comply with the instructions in the separate supplementary documentation, which is an integral part of this manual.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

- ▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

Electromagnetic compatibility

The measuring system complies with the general safety requirements as per EN 61010-1, the EMC requirements as per the IEC/EN 61326 series and the NAMUR recommendations NE 21.

NOTICE

- ▶ The device must only be powered by a power unit that operates using an energy-limited electric circuit according to UL/EN/IEC 61010-1, Section 9.4 and the requirements in Table 18.

2.5 Product safety

This product is designed in accordance with good engineering practice to meet state-of-the-art safety requirements and has been tested and left the factory in a condition in which it is safe to operate.

2.6 IT security

The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

3 Incoming acceptance and product identification

3.1 Incoming acceptance

On receipt of the delivery:

1. Check the packaging for damage.
 - ↳ Report all damage immediately to the manufacturer.
Do not install damaged components.
2. Check the scope of delivery using the delivery note.
3. Compare the data on the nameplate with the order specifications on the delivery note.

4. Check the technical documentation and all other necessary documents, e.g. certificates, to ensure they are complete.



If one of the conditions is not satisfied, contact the manufacturer.

3.2 Product identification

The following options are available for identification of the device:

- Nameplate specifications
- Enter the serial number from the nameplate into *Device Viewer* (www.endress.com/deviceviewer): all the information about the device and an overview of the technical documentation supplied with the device are displayed.
- Enter the serial number from the nameplate into the *Endress+Hauser Operations app* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations app*: all the information about the device and the technical documentation pertaining to the device is displayed.

3.2.1 Nameplate

Do you have the correct device?

The nameplate provides you with the following information on the device:

- Manufacturer identification, device designation
- Order code
- Extended order code
- Serial number
- Tag name (TAG) (optional)
- Technical values such as supply voltage, current consumption, ambient temperature, communication-specific data (optional)
- Degree of protection
- Approvals with symbols
- Reference to Safety Instructions (XA) (optional)

► Compare the information on the nameplate with the order.

3.2.2 Name and address of manufacturer

Name of manufacturer:	Endress+Hauser Wetzlar GmbH + Co. KG
Address of manufacturer:	Obere Wank 1, D-87484 Nesselwang or www.endress.com

3.3 Storage and transport

Storage temperature

Head transmitter	–50 to 100 °C (–58 to 212 °F)
Optional	–52 to 85 °C (–62 to 185 °F), Product Configurator, order code for "Test, certificate, declaration", option "JN"
Head transmitter, field mount housing with separate terminal compartment incl. display	–35 to 85 °C (–31 to 185 °F), Product Configurator, order code for "Field housing", option "R" and "S"
DIN rail transmitter	–40 to 100 °C (–40 to 212 °F)

Maximum relative humidity: < 95 % as per IEC 60068-2-30



Pack the device for storage and transportation in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.

Avoid the following environmental influences during storage:

- Direct sunlight
- Vibration
- Aggressive media

4 Installation

4.1 Installation requirements

- Head transmitter:
 - In the terminal head, flat face, as per DIN EN 50446, direct mounting on insert with cable entry (middle hole 7 mm (0.28 in))
 - In the field mount housing with separate terminal compartment, if stable sensors are used, the device can be fitted directly on the sensor, otherwise it has to be mounted separately from the process
 - In the field housing, separated from the process
- DIN rail transmitter:
On DIN rail as per IEC 60715 TH35.

 It is also possible to mount the head transmitter on a DIN rail as per IEC 60715 using the DIN rail clip accessory. →  47

 SIL mode: The head transmitter must not be operated using the DIN rail clip and remote sensors as a substitute for a DIN rail transmitter in a cabinet.

Information about the conditions (such as the ambient temperature, degree of protection, climate class etc.) that must be met at the mounting point so that the device can be mounted correctly is provided in the "Technical data" section →  51.


For use in hazardous areas, the limit values specified on the certificates and approvals must be observed (see Ex Safety Instructions).

4.2 Installing the transmitter

A Phillips head screwdriver is required to mount the head transmitter:

- Maximum torque for securing screws = 1 Nm ($\frac{3}{4}$ lbf ft), screwdriver: Pozidriv PZ2
- Maximum torque for screw terminals = 0.35 Nm ($\frac{1}{4}$ lbf ft), screwdriver: Pozidriv PZ1

4.2.1 Mounting the head transmitter



A0046718


1 Head transmitter mounting (three versions)

Item A	Mounting in a terminal head (terminal head flat face as per DIN 43729)
1	Terminal head
2	Circlips
3	Insert
4	Connection wires
5	Head transmitter
6	Mounting springs
7	Mounting screws
8	Terminal head cover
9	Cable entry

Procedure for mounting in a terminal head, Fig. A:

1. Open the terminal head cover (8) on the terminal head.
2. Guide the connection wires (4) of the insert (3) through the center hole in the head transmitter (5).
3. Fit the mounting springs (6) on the mounting screws (7).
4. Guide the mounting screws (7) through the side boreholes of the head transmitter and the insert (3). Then fix both mounting screws with the snap rings (2).
5. Then tighten the head transmitter (5) along with the insert (3) in the terminal head.
6. After wiring → 19, close the terminal head cover (8) tightly again.

Item B	Mounting in a field housing
1	Field housing cover
2	Mounting screws with springs
3	Head transmitter
4	Field housing



2 Dimensions of angle bracket for wall mount (complete wall mounting set available as accessory)

Procedure for mounting in a field housing, Fig. B:


1. Open the cover (1) of the field housing (4).
2. Guide the mounting screws (2) through the lateral bores in the head transmitter (3).
3. Screw the head transmitter to the field housing.
4. After wiring, close the field housing cover (1) again. → 19

Item C	Mounting on DIN rail (DIN rail as per IEC 60715)
1	Mounting screws with springs
2	Head transmitter
3	Circlips
4	DIN rail clip
5	DIN rail

Procedure for mounting on a DIN rail, Fig. C:

1. Press the DIN rail clip (4) onto the DIN rail (5) until it engages with a click.
2. Fit the mounting springs on the mounting screws (1) and guide the screws through the side boreholes of the head transmitter (2). Then fix both mounting screws with the snap rings (3).
3. Screw the head transmitter (2) onto the DIN rail clip (4).

Remotely mounting the field mount housing




A0027188

3 Mounting the field mount housing using special mounting bracket, see chapter 'Accessories'. Dimensions in mm (in)

1 Combined wall/pipe mounting bracket 2", L-shaped, material 304

2 Pipe mounting bracket 2", U-shaped, material 316L

Installation with a central-spring-loaded insert



A0008520

Thermometer design with thermocouples or RTD sensors and head transmitter:

1. Fit the thermowell (1) on the process pipe or the container wall. Secure the thermowell according to the instructions before the process pressure is applied.
2. Fit the necessary neck tube nipples and adapter (3) on the thermowell.


3. Make sure sealing rings are installed if such rings are needed for harsh environmental conditions or special regulations.
4. Guide the mounting screws (6) through the lateral bores of the head transmitter (5).
5. Position the head transmitter (5) in the terminal head (4) in such a way that the power supply (terminals 1 and 2) point to the cable entry.
6. Using a screwdriver, screw down the head transmitter (5) in the terminal head (4).
7. Guide the connection wires of the insert (3) through the lower cable entry of the terminal head (4) and through the middle hole in the head transmitter (5). Wire the connection wires up to the transmitter → 20.
8. Screw the terminal head (4), with the integrated and wired head transmitter, onto the ready-mounted nipple and adapter (3).

NOTICE

The terminal head cover must be secured properly to meet the requirements for explosion protection.

- After wiring, securely screw the terminal head cover back on.

Mounting the display on the head transmitter




A0009852

 4 *Mounting the display*

1. Loosen the screw on the terminal head cover. Flip back the terminal head cover.
2. Remove the cover of the display connection area.
3. Fit the display module onto the mounted and wired head transmitter. The fastening pins must click securely into place on the head transmitter. After mounting, securely tighten the terminal head cover.

 The display can be used only with the appropriate terminal heads - cover with viewing window (e.g. TA30 from Endress+Hauser). In the field mount housing with separate terminal compartment the display is already installed.

Display installation positions in the field mount housing with separate terminal compartment



5 Display installation positions, attachable in 90° stages

1 Marking foam ring

1. Remove the cover clamp.
2. Unscrew the housing cover together with the O-ring.
3. Remove the foam ring.
4. Remove the attached display from the head transmitter.
5. Unscrew the mounting screws situated in the lateral bores in the head transmitter. Do not unwire the head transmitter.
6. Fit the head transmitter in the desired position in 90° stages as shown in the drawing. For turning it to 180° use the hardware setting via DIP switch on the attached display.
7. Then fix the head transmitter with the mounting screws again.

On completion of the display position installation, follow the action steps in reverse order.

i Refit the display module onto the mounted and wired head transmitter. The fastening pins must click securely into place on the head transmitter.

Put the foam ring back into the field housing. The marking (1) must point upwards.


4.2.2 Mounting the DIN rail transmitter

NOTICE

Horizontal orientation

Measurement deviates from the maximum measurement accuracy rating when a thermocouple is connected and the internal reference junction is used.

- Mount the device vertically and ensure it is aligned correctly (sensor connection at the bottom / power supply at the top)!



A0017821

6 Mounting the DIN rail transmitter

- 1. Slide the upper DIN rail clip upwards and the lower clip downwards until they click into place.
- 2. Fit the device on the DIN rail from the front.
- 3. Slide the two DIN rail clips back together until they click into place.

4.3 Post-installation check

After installing the device, carry out the following final checks:

Device condition and specifications	Notes
Is the device undamaged (visual check)?	-
Do the ambient conditions match the device specification (e.g. ambient temperature, measuring range, etc.)?	See "Technical data" section → 51

5 Electrical connection

⚠ CAUTION

Destruction of parts of the electronics

- ▶ Do not install or wire the device when it is connected to the operating voltage.
- ▶ Do not occupy the display connection.

NOTICE

Tighten the screw terminals in accordance with the specified torque as this could damage the transmitter.

- ▶ Maximum tightening torque = 0.35 Nm ($\frac{1}{4}$ lbf ft), screwdriver: Pozidriv PZ1.

5.1 Connecting requirements


A Phillips head screwdriver is required to wire the head transmitter with screw terminals. Use a flat-blade screwdriver for the DIN rail transmitter version with screw terminals. The version with push-in terminals can be wired without any tools.

Proceed as follows to wire a head transmitter mounted in the terminal head or field housing:

1. Open the cable gland and the housing cover on the terminal head or the field housing.
2. Feed the cables through the opening in the cable gland.
3. Connect the cables as shown in →  20. If the head transmitter is fitted with push-in terminals, pay particular attention to the "Connecting to push-in terminals" section. → 
4. Tighten the cable gland again.
5. Close the housing cover.

 Before commissioning, refer to the information in the "Post-connection check" section to prevent connection errors.

Proceed as follows to wire the transmitter in a field mount housing:




A0042426

1. Remove the cover clamp.
2. Unscrew the housing cover on the terminal compartment. The terminal compartment is opposite the electronics module together with the display cover.
3. Open the cable glands of the device.

4. Route the appropriate connecting cables through the openings of the cable glands.
5. Wire the cables as described in the "Connecting the sensor" and "Connecting the transmitter" sections. →  22, →  24
6. Once wiring is complete, tighten the screw terminals.
7. Tighten the cable glands again.
8. Refer to the information provided in the "Ensuring the degree of protection" section.
9. Screw the housing cover tight and fit the cover clamp back on.

The transmitter is wired and can be put into operation. In order to avoid connection errors always follow the instructions in the post-connection check section before commissioning!


5.2 Quick wiring guide



A0046019

 7 Assignment of terminal connections for head transmitter


- A Sensor input 2, TC and mV
- B Sensor input 2, RTD and Q, 3- and 2-wire
- C Sensor input 1, TC and mV
- D Sensor input 1, RTD and Q, 4-, 3- and 2-wire
- E Display connection, service interface
- F Bus connection and power supply



A0047534

8 Terminal assignment of the field mount housing with separate terminal compartment

- 1 Sensor input 1, RTD, : 2-, 3- and 4-wire
- 2 Sensor input 2, RTD: 2-, 3-wire
- 3 Bus connection and power supply
- 4 Sensor input 1, thermocouple (TC)
- A If the sensor input thermocouple (TC) option is selected: Fixed connection of the external reference junction, terminals 4, 5 and 6 (Pt100, IEC 60751, class B, 3-wire). It is not possible to connect a second thermocouple (TC) on sensor 2.



A0047533

9 Assignment of terminal connections for DIN rail transmitter

- A 4 to 20 mA power supply
 B To check the output current, an ammeter (DC measurement) can be connected between the "Test" and "-" terminals.
 C HART connection
 D Sensor input 2, TC and mV
 E Sensor input 2, RTD and Ω , 3- and 2-wire
 F Sensor input 1, TC and mV
 G Sensor input 1, RTD and Ω , 4-, 3- and 2-wire

An unshielded installation cable is sufficient if only the analog signal is used. The use of shielded cables is recommended in the event of increased EMC interference. For a head transmitter in the field mount housing with separate terminal compartment and for the DIN rail transmitter, a shielded cable must be used for sensor cable lengths of 30 m (98.4 ft) or more.

A shielded cable is recommended for HART communication. Observe grounding concept of the plant. A minimum load of 250 Ω is required in the signal circuit in order to operate the HART transmitter via the HART protocol (terminals 1 and 2).

NOTICE

ESD - Electrostatic discharge

- Protect the terminals from electrostatic discharge. Failure to observe this may result in the destruction or malfunction of parts of the electronics.

5.3 Connecting the sensor

Terminal assignment of the sensor connections → 20.

NOTICE


Galvanic connection between the sensors (e.g., caused by sensor elements that are not isolated from the thermowell). The resulting equalizing currents distort the measurements considerably.

- ▶ When connecting 2 sensors, ensure that there is no galvanic connection between the sensors. The sensors must remain galvanically isolated from one another by connecting each sensor separately to a transmitter. The device provides sufficient galvanic isolation ($> 2 \cdot 10^3 \text{ V}_{AC}$) between the input and output.

The following connection combinations are possible when both sensor inputs are assigned:

		Sensor input 1			
Sensor input 2		RTD or resistance transmitter, 2-wire	RTD or resistance transmitter, 3-wire	RTD or resistance transmitter, 4-wire	Thermocouple (TC), voltage transmitter
	RTD or resistance transmitter, 2-wire	✓	✓	-	✓
	RTD or resistance transmitter, 3-wire	✓	✓	-	✓
	RTD or resistance transmitter, 4-wire	-	-	-	-
	Thermocouple (TC), voltage transmitter	✓	✓	✓	✓
	For field mount housing with a thermocouple on sensor input 1: It is not possible to connect a second thermocouple (TC), RTD, resistance transmitter or voltage transmitter to sensor input 2 as this input is needed for the external reference junction.				

5.3.1 Connecting the sensor to push-in terminals



10 Push-in terminal connection, using the example of a head transmitter

Fig. A, solid wire, fine-strand wire with ferrule:

1. Strip wire end to length of at least 10 mm (0.39 in).
2. Insert the wire end into the terminal.
3. Pull the wire gently to ensure it is connected correctly. If the wire is not secure, repeat from step 1.

Fig. B, fine-strand wire without ferrule:


1. Strip wire end to length of at least 10 mm (0.39 in).
2. Press down on the lever opener.
3. Insert the wire end into the terminal.
4. Release lever opener.
5. Pull the wire gently to ensure it is connected correctly. If the wire is not secure, repeat from step 1.

Fig. C, releasing the connection:

1. Press down on the lever opener.
2. Remove the wire from the terminal.
3. Release lever opener.

5.4 Connecting the transmitter

Please also observe the procedure on → 19.



A0042362

11 Connecting the signal cables and power supply

- 1 Head transmitter installed in field mount housing with separate terminal compartment
- 2 Head transmitter installed in field housing
- 3 Head transmitter installed in terminal head
- 4 DIN rail transmitter mounted on DIN rail
- 5 Terminals for HART protocol and power supply
- 6 Internal ground connection
- 7 External ground connection
- 8 Shielded signal cable (recommended for HART protocol)




- The terminals for the signal cable connection (1+ and 2-) are protected against reverse polarity.
- Conductor cross-section:
 - Max. 2.5 mm² (13 AWG) for screw terminals
 - Max. 1.5 mm² (15 AWG) for screw terminals. Stripping length of wire at least 10 mm (0.39 in).

5.5 Special connection instructions

Shielding and grounding

The specifications of the FieldComm Group must be observed when installing the HART transmitter.




12 Shielding and grounding the signal cable at one end with HART communication

- 1 Optional grounding of the field device, isolated from cable shielding
- 2 Grounding of the cable shield at one end
- 3 Supply unit
- 4 Grounding point for HART communication cable shield

5.6 Ensuring the degree of protection

The device meets the requirements for IP67 protection. Compliance with the following points is mandatory following installation in the field or servicing in order to ensure that IP67 protection is maintained:

1. The transmitter must be mounted in a terminal head with the appropriate degree of protection.
The housing seals must be clean and undamaged when inserted into the sealing groove. Dry, clean or replace the seals for this purpose if necessary.
2. The connecting cables used must have the specified external diameter (e.g., M20x1.5, cable diameter 8 to 12 mm).
Firmly tighten the cable gland. → 13, 25
3. The cables must loop down before they enter the cable glands ("water trap").
↳ This means that any moisture that may form cannot enter the gland.
4. Install the device in such a way that the cable glands are not facing upwards.
→ 13, 25
5. Replace unused cable glands with dummy plugs.
6. The grommet used must remain in the cable gland.




13 Connection tips to retain IP67 protection

5.7 Post-connection check

Device condition and specifications	Notes
Are the device and cables free from damage (visual check)?	--
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	■ Head transmitter: $U = 11$ to $42 V_{DC}$ ■ DIN rail transmitter: $U = 12$ to $42 V_{DC}$ ■ SIL mode: $U = 11$ to $32 V_{DC}$ for the head transmitter or $U = 12$ to $32 V_{DC}$ for the DIN rail transmitter ■ Other values apply in the hazardous area, see the corresponding Ex Safety Instructions.
Are the mounted cables strain-relieved?	--
Are the power supply and signal cables connected correctly?	→  20
Are all the screw terminals firmly tightened and have the push-in terminal connections been checked?	--
Are all the cable entries installed, tightened and leak-tight?	--
Are all the housing covers installed and firmly tightened?	--

6 Operation options

6.1 Overview of operation options




14 Operation options for the transmitter via HART communication

i For the head transmitter, display and operating elements are available locally only if the head transmitter was ordered with a display unit!

6.2 Structure and function of the operating menu

6.2.1 Structure of the operating menu



A0045951



The configuration in the SIL mode is different from the configuration in the standard mode. For more detailed information, please refer to the Functional Safety Manual (FY01105T).

Submenus and user roles


Certain parts of the menu are assigned to certain user roles. Each user role corresponds to typical tasks within the life cycle of the device.

User role	Typical tasks	Menu	Content/meaning
Maintenance Operator	Commissioning: ■ Configuration of the measurement. ■ Configuration of data processing (scaling, linearization, etc.). ■ Configuration of the analog measured value output. Tasks during operation: ■ Configuration of the display. ■ Reading measured values.	"Setup"	Contains all parameters for commissioning: ■ Setup parameters Once values have been set for these parameters, the measurement should usually be fully configured. ■ "Extended setup" submenu Contains additional submenus and parameters: ■ For more accurate configuration of the measurement (adaptation to special measuring conditions). ■ For converting the measured value (scaling, linearization). ■ For scaling the output signal. ■ Required in ongoing operation: configuration of the measured value display (displayed values, display format, etc.).
	Troubleshooting: ■ Diagnosing and eliminating process errors. ■ Interpretation of device error messages and correcting associated errors.	"Diagnostics"	Contains all parameters for detecting and analyzing errors: ■ Diagnostic list Contains up to 3 currently pending error messages. ■ Event logbook Contains the last 5 error messages. ■ "Device information" submenu Contains information for identifying the device. ■ "Measured values" submenu Contains all current measured values. ■ "Simulation" submenu Used to simulate measured values, output values or diagnostic messages.
Expert	Tasks that require detailed knowledge of the function of the device: ■ Commissioning measurements under difficult conditions. ■ Optimal adaptation of the measurement to difficult conditions. ■ Detailed configuration of the communication interface. ■ Error diagnostics in difficult cases.	"Expert"	Contains all the parameters of the device (including those already contained in one of the other menus). The structure of this menu is based on the function blocks of the device: ■ "System" submenu Contains all higher-level device parameters that do not affect measurement or measured value communication. ■ "Sensor" submenu Contains all parameters for configuring the measurement. ■ "Output" submenu Contains all parameters for configuring the analog current output. ■ "Communication" submenu Contains all parameters for configuring the digital communication interface. ■ "Diagnostics" submenu Contains all parameters needed to detect and analyze operational errors.

6.3 Measured value display and operating elements

6.3.1 Display elements

Head transmitter



15 Optional LC display for head transmitter

Item no.	Function	Description
1	Displays the TAG	TAG, 32 characters long.
2	"Communication" symbol	The communication symbol appears when read and write-accessing via the fieldbus protocol.
3	Unit display	Unit display for the measured value displayed.
4	Measured value display	Displays the current measured value.
5	Value/channel display S1, S2, DT, PV, I, %	e.g. S1 for a measured value from channel 1 or DT for the device temperature
6	'Configuration locked' symbol	The 'configuration locked' symbol appears when configuration is locked via the hardware.
7	Status signals	
	Symbols	Meaning
	F	Error message "Failure detected" A device fault has occurred. The measured value is no longer valid. The display alternates between the error message and "- - -" (no valid measured value present), see "Diagnostic events" section. The display alternates between the error message and "- - -" (no valid measured value present). Detailed information on the error messages can be found in the Operating Instructions.
	C	"Service mode" The device is in service mode (e.g. during a simulation).
	S	"Out of specification" The device is being operated outside its technical specifications (e.g. during warm-up or cleaning processes).
	M	"Maintenance required" Maintenance is required. The measured value remains valid. The display alternates between the measured value and the diagnostic message.

DIN rail transmitter

i The DIN rail transmitter version does not have an interface to the LC display and therefore does not have a local display either.

Two LEDs on the front indicate the device status.

Type	Function and characteristic
Status LED (red)	When the device is operating without errors, the device status is displayed. This function can no longer be guaranteed in the event of an error. ■ LED off: without diagnostic message ■ LED is lit: diagnostic display, category F ■ LED flashing: diagnostic display, categories C, S or M
Power LED (green) 'ON'	When the device is operating without errors, the operating status is displayed. This function can no longer be guaranteed in the event of an error. ■ LED off: Power failure or insufficient supply voltage ■ LED is lit: Supply voltage is OK (either via CDI or via supply voltage, terminals 1+, 2-)

6.3.2 Local operation


You can make hardware settings for the fieldbus interface using miniature switches (DIP switches) on the rear of the optional display.

 The user has the option of ordering the display with the head transmitter, or as an accessory for subsequent mounting. →  47

If the head transmitter was ordered with the field mount housing with separate terminal compartment, the display is included already.

NOTICE

- ▶  ESD – Electrostatic discharge. Protect the terminals from electrostatic discharge. Failure to observe this may result in the destruction or malfunction of parts of the electronics.

	1: Connection to head transmitter
	2: DIP switches (1 - 64, SW/HW, ADDR and SIM = simulation mode) no function for this head transmitter
	3: DIP switch (WRITE LOCK = write protection; DISPL. 180° = switch, turn the display monitor 180°)

 16 Hardware settings via DIP switches

A0014562

Procedure for setting the DIP switch:

1. Open the cover of the terminal head or field housing.
2. Remove the attached display from the head transmitter.
3. Configure the DIP switch on the rear of the display accordingly. In general: switch to ON = function is active, switch to OFF = function disabled.
4. Fit the display onto the head transmitter in the correct position. The head transmitter accepts the settings within one second.
5. Secure the cover back onto the terminal head or field housing.

Switching write protection on/off

Write protection is switched on and off via a DIP switch on the rear of the optional attachable display. When write protection is active, parameters cannot be modified. A lock symbol on the display indicates that write protection is on. Write protection prevents any write access to the parameters. Write protection remains active even when the display is

removed. To disable the write protection, the device must be restarted with the display attached and the DIP switch disabled (WRITE LOCK = OFF). Alternatively, the display can be removed and reattached during operation to disable write protection.

Turning the display

The display can be rotated 180° using the "DISPL. 180°" DIP switch. The setting is retained when the display is removed.

6.4 Access to the operating menu via the operating tool

6.4.1 FieldCare

Range of functions

FDT/DTM-based plant asset management tool from Endress+Hauser. It can configure all intelligent field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Access takes place via the HART protocol or CDI interface (= Endress+Hauser Common Data Interface).

Typical functions:

- Configuration of transmitters
- Loading and saving of instrument data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



For details, see Operating Instructions BA00065S

NOTICE


The following applies if using the device in hazardous areas: Before accessing the device with the Commubox FXA291 via the CDI (= Endress+Hauser Common Data Interface), disconnect the transmitter from the power supply, terminals (1+) and (2-).

- Failure to comply with this instruction can result in damage to parts of the electronics.

Source for device description files

For details, see →  36

User interface



A0055534

6.4.2 DeviceCare

Range of functions


The fastest way to configure Endress+Hauser field devices is to use the dedicated DeviceCare tool. DeviceCare's user-friendly design allows transparent and intuitive device connection and configuration. Intuitive menus and step-by-step instructions with status information ensure optimum transparency.

Quick and easy to install, connects devices in a single click (one-click connection). Automatic hardware identification and driver catalog update. The devices are configured using DTMs (Device Type Manager). Multilingual support is available; the tool can also be operated on a tablet and supports touch functionality. Hardware interfaces for modems : (USB/RS232), TCP/IP, USB and PCMCIA.

Source for device description files

For details, see → 36

Operator interface



A005534

6.4.3 Field Xpert

Range of functions

Field Xpert is a tablet PC with integrated touchscreen for commissioning and maintaining field devices in explosion hazardous and safe areas. It enables the efficient configuration of FOUNDATION fieldbus, HART and WirelessHART devices. Communication is wireless via Bluetooth or WiFi interfaces.

6.4.4 Source for device description files

See information → 36.

6.4.5 AMS Device Manager

Range of functions

Program from Emerson Process Management for operating and configuring measuring instruments via the HART protocol.

Source for device description files

See information → 36.

6.4.6 SIMATIC PDM

Range of functions

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnostics of intelligent field devices via HART protocol.

Source for device description files

See information →  36.

6.4.7 AMS Trex Device Communicator

Range of functions

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via the HART protocol.

Source for device description files

See information →  36.

7 System integration

Version data for the device

Firmware version	01.02.zz	- On the title page of the Operating instructions - On the nameplate Firmware version parameter Diagnosis → Instrument info → Firmware version
Manufacturer ID	0x11	Manufacturer ID parameter Diagnostics → Device information → Manufacturer ID
Device type code	0x11CC	Device type parameter Diagnostics → Device information → Device type
HART protocol revision	7	---
Device revision	3	- On the transmitter nameplate Device revision parameter Diagnostics → Device information → Device revision

The suitable device description file (DD or DTM) for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tools

Operating tool	Sources for obtaining device descriptions (DD) or device type managers (DTM)
FieldCare, DeviceCare, FieldXpert SMT70 (Endress+Hauser)	www.endress.com → Downloads → Device driver: Enter type, product root and process communication.
SIMATIC PDM (Siemens)	
Yokogawa, Plant Resource Manager	
Control Builder, Field Device Manager (Honeywell)	
Schneider Invensys, Archestra IDE	
PACTware	
AMS Trex Device Communicator (Emerson Process Management)	Use update function of handheld terminal

7.1 HART device variables and measured values

The following measured values are assigned to the device variables at the factory:

Device variables for temperature measurement

Device variable	Measured value
Primary device variable (PV)	Sensor 1
Secondary device variable (SV)	Device temperature
Tertiary device variable (TV)	Sensor 1
Quaternary device variable (QV)	Sensor 1



It is possible to change the assignment of device variables to process variables in the menu **Expert → Communication → HART output**.

7.2 Device variables and measured values

The following measured values are assigned to the individual device variables:

Device variable code	Measured value
0	Sensor 1
1	Sensor 2
2	Device temperature
3	Average of sensor 1 and sensor 2
4	Difference between sensor 1 and sensor 2
5	Sensor 1 (backup sensor 2)
6	Sensor 1 with switchover to sensor 2 if a limit value is exceeded
7	Average of sensor 1 and sensor 2 with backup

 The device variables can be queried via HART command 9 or 33 from a HART master.

7.3 Supported HART commands

 The HART protocol enables the transfer of measuring data and device data between the HART master and the field device for configuration and diagnostics purposes. HART masters such as the handheld terminal or PC-based operating programs (e.g. FieldCare) need device description files (DD, DTM) which are used to access all the information in a HART device. This information is transmitted exclusively via "commands".

There are three different types of command

- **Universal commands:**
All HART devices support and use universal commands. These are associated with the following functionalities for example:
 - Recognition of HART devices
 - Reading digital measured values
- **Common practice commands:**
Common practice commands offer functions which are supported and can be executed by many but not all field devices.
- **Device-specific commands:**
These commands allow access to device-specific functions which are not HART standard. Such commands access individual field device information, among other things.

Command No.	Designation
Universal commands	
0, Cmd0	Read unique identifier
1, Cmd001	Read primary variable
2, Cmd002	Read loop current and percent of range
3, Cmd003	Read dynamic variables and loop current
6, Cmd006	Write polling address
7, Cmd007	Read loop configuration
8, Cmd008	Read dynamic variable classifications
9, Cmd009	Read device variables with status
11, Cmd011	Read unique identifier associated with TAG
12, Cmd012	Read message

Command No.	Designation
13, Cmd013	Read TAG, descriptor, date
14, Cmd014	Read primary variable transducer information
15, Cmd015	Read device information
16, Cmd016	Read final assembly number
17, Cmd017	Write message
18, Cmd018	Write TAG, descriptor, date
19, Cmd019	Write final assembly number
20, Cmd020	Read long TAG (32-byte TAG)
21, Cmd021	Read unique identifier associated with long TAG
22, Cmd022	Write long TAG (32-byte TAG)
38, Cmd038	Reset configuration changed flag
48, Cmd048	Read additional device status
Common practice commands	
33, Cmd033	Read device variables
34, Cmd034	Write primary variable damping value
35, Cmd035	Write primary variable range values
36, Cmd036	Set primary variable upper range value
37, Cmd037	Set primary variable lower range value
40, Cmd040	Enter/Exit fixed current mode
42, Cmd042	Perform device reset
44, Cmd044	Write primary variable units
45, Cmd045	Trim loop current zero
46, Cmd046	Trim loop current gain
50, Cmd050	Read dynamic variable assignments
51, Cmd051	Write dynamic variable assignments
54, Cmd054	Read device variable information
59, Cmd059	Write number of response preambles
103, Cmd103	Write burst period
104, Cmd104	Write burst trigger
105, Cmd105	Read burst mode configuration
107, Cmd107	Write burst device variables
108, Cmd108	Write burst mode command number
109, Cmd109	Burst mode control

8 Commissioning

8.1 Function check

Before commissioning the measuring point make sure that all final checks have been carried out:

- "Post-installation check" checklist, →  18
- "Post-connection check" checklist, →  26

8.2 Switching on the device

Once you have completed the post-connection checks, switch on the supply voltage. The device performs a number of internal test functions after it is powered up. During this process, a sequence containing device information appears on the display.

Step	Display
1	Text "Display" and firmware version of the display
2	Device name with firmware and hardware versions
3	Information on the sensor configuration (sensor element and connection type)
4	Set measuring range
5a	Current measured value or
5b	Current diagnostic message  If the switch-on procedure is not successful, the relevant diagnostic event, depending on the cause, is displayed. A detailed list of diagnostic events and the corresponding troubleshooting instructions can be found in the "Diagnostics and troubleshooting" section .

The device works after approx. 30 seconds, the attachable display module after approx. 33 seconds during normal operation. Normal measuring mode commences as soon as the switch-on procedure is completed. Measured values and status values appear on the display.

8.3 Protecting settings from unauthorized access

If the device is locked and the parameter settings cannot be changed, it must first be enabled via the hardware or software lock. The device is write-protected if the lock symbol appears in the header of the measured value display.

To unlock the device

- either switch the write protection switch on the back of the display to the "OFF" position (hardware write protection), or
- deactivate the software write protection via the operating tool. See the description for the '**Define device write protection**' parameter. →  95

 When hardware write protection is active (write protection switch on the back of the display to the "ON" position), write protection cannot be disabled via the operating tool. Hardware write protection must always be disabled before software write protection can be enabled or disabled.

9 Diagnostics and troubleshooting

9.1 General troubleshooting

Always start troubleshooting with the checklists below if faults occur after commissioning or during operation. The checklists take you directly (via various queries) to the cause of error and the appropriate remedial action.

General faults

Error	Possible cause	Remedy
Device is not responding.	Supply voltage does not match the voltage specified on the nameplate.	Connect the correct voltage.
	Connecting cables are not in contact with the terminals.	Check the electrical contact between the cable and terminals and correct if necessary.
Output current < 3.6 mA	Signal cable is not wired correctly.	Check wiring.
	Electronics module is defective.	Replace the device.
HART communication is not working.	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly.
	Commubox is connected incorrectly.	Connect Commubox correctly.
	Commubox is not set to "HART".	Set Commubox selector switch to "HART".

Check display (optionally in conjunction with head transmitter)

Error	Possible cause	Remedy
Display is blank	No supply voltage	- Check the supply voltage at the head transmitter, terminals + and -. - Ensure that the display module holders are correctly seated and that the display module is properly connected to the head transmitter, . - If possible, test the display module with other suitable head transmitters, e.g. an Endress+Hauser head transmitter.
	The display module is defective.	Replace the module.
	The electronics of the head transmitter are defective.	Replace the head transmitter.

Application errors without diagnostic messages for RTD sensor connection

Error	Possible cause	Remedy
Measured value is incorrect/ inaccurate	Incorrect sensor orientation.	Install the sensor correctly.
	Heat conducted by sensor.	Observe the installation length of the sensor.
	Device programming is incorrect (number of wires).	Change the Connection type device function.
	Device programming is incorrect (scaling).	Change scaling.
	Incorrect RTD configured.	Change the Sensor type device function.
	Sensor connection.	Check that the sensor is connected correctly.

Error	Possible cause	Remedy
	The cable resistance of the sensor (2-wire) was not compensated.	Compensate the cable resistance.
	Offset incorrectly set.	Check offset.
Failure current (≤ 3.6 mA or ≥ 21 mA)	Sensor defective.	Check the sensor.
	RTD connected incorrectly.	Install the connecting cables correctly (terminal diagram).
	Device programming is incorrect (e.g., number of wires).	Change the Connection type device function.
	Incorrect programming.	Incorrect sensor type set in the Sensor type device function. Set the correct sensor type.

Application errors without diagnostic messages for TC sensor connection


Error	Possible cause	Remedy
Measured value is incorrect/inaccurate	Incorrect sensor orientation.	Install the sensor correctly.
	Heat conducted by sensor.	Observe the installation length of the sensor.
	Device programming is incorrect (scaling).	Change scaling.
	Incorrect thermocouple type (TC) configured.	Change the Sensor type device function.
	Incorrect reference junction set.	Set the correct reference junction .
	Interference via the thermocouple wire welded in the thermowell (interference voltage coupling).	Use a sensor where the thermocouple wire is not welded.
	Offset incorrectly set.	Check offset.
Failure current (≤ 3.6 mA or ≥ 21 mA)	Sensor defective.	Check the sensor.
	Sensor is connected incorrectly.	Install the connecting cables correctly (terminal diagram).
	Incorrect programming.	Incorrect sensor type set in the Sensor type device function. Set the correct sensor type.

9.2 Diagnostic information via LED

DIN rail transmitter

Error	Possible cause	Remedy
Status LED is lit or flashing red.	Diagnostic events as per NAMUR NE 107 → 42	Check diagnostic events: - LED is lit: diagnostic display, category F - LED flashing: diagnostic display, categories C, S or M
Power LED is not lit green.	Power failure or insufficient supply voltage	Check the supply voltage and check if wiring is correct.

9.3 Diagnostic information on local display



A0014837

- A Display in the event of a warning
- B Display in the event of an alarm
- 1 Status signal in the header
- 2 The display alternates between the primary measured value and the status - indicated by the appropriate letter (M, C or S) - plus the defined diagnostic number.
- 3 The display alternates between "- - -" (no valid measured value) and the status - indicated by the appropriate letter (F) - plus the defined diagnostic number.

9.4 Overview of diagnostic information

9.4.1 Displaying diagnostic events

Status signals


Symbol	Event category	Meaning
F	Operating error	An operating error has occurred. The measured value is no longer valid.
C	Service mode	The device is in the service mode (e.g., during a simulation).
S	Out of specification	The device is being operated outside its technical specifications (e.g., during startup or cleaning processes).
M	Maintenance required	Maintenance is required. The measured value remains valid.

Diagnostic behavior

Alarm	Measurement is interrupted. The signal outputs adopt the defined alarm status. A diagnostic message is generated (status signal F).
Warning	The device continues to measure. A diagnostic message is generated (status signals M, C or S).

Diagnostic event and event text

The error can be identified by means of the diagnostic event. The event text helps you by providing information about the error.



If several diagnostic events are pending at the same time, only the diagnostic message with the highest priority is displayed. Additional pending diagnostic messages are shown in the **Diagnostic list** submenu → 98.

 Past diagnostic messages that are no longer pending are shown in the **Event logbook** submenu → 99.

9.5 Diagnostic list

Each diagnostic event is assigned a certain event behavior at the factory. The user can change this assignment for certain diagnostic events.

 The relevant sensor input for these diagnostic events can be identified with the **Actual diag channel** parameter or on the optional attachable display.

Diagnostic number	Short text	Corrective measure	Status signal from the factory	Diagnostic behavior from the factory
			Can be changed to	
Diagnostics for the sensor				
001	Device malfunction	1. Restart device 2. Check electrical connection of sensor 1 3. Check/replace sensor 1 4. Replace electronics	F	Alarm
006	Redundancy active	1. Check electrical wiring. 2. Replace sensor. 3. Check connection type.	M	Warning
041	Sensor broken	1. Check electrical wiring. 2. Replace sensor. 3. Check connection type.	F	Alarm
042	Sensor corroded	1. Check electrical wiring of sensor. 2. Replace sensor.	M	Warning ¹⁾
			F	
043	Short-circuit	1. Check electronic wiring. 2. Replace sensor.	F	Alarm
044	Sensor drift	1. Check sensors. 2. Check process temperatures.	M	Warning ¹⁾
			F, S	
045	Working area	1. Check ambient temperature. 2. Check external reference measuring point.	F	Alarm

Diagnostic number	Short text	Corrective measure	Status signal from the factory	Diagnostic behavior from the factory
			Can be changed to	
062	Sensor connection	1. Check electronic wiring. 2. Replace sensor. 3. Check connection type. 4. Contact service.	F	Alarm
101	Sensor value too low	1. Check process temperatures. 2. Check sensor. 3. Check sensor type.	S	Warning
			F	
102	Sensor value too high	1. Check process temperatures. 2. Check sensor. 3. Check sensor type.	S	Warning
			F	
104	Backup active	1. Check electrical wiring of sensor 1. 2. Replace sensor 1. 3. Check connection type.	M	Warning
105	Calibration interval	1. Execute calibration and reset calibration interval. 2. Switch off calibration counter.	M	Warning ¹⁾
			F	
106	Backup not available	1. Check electrical wiring of sensor 2. 2. Replace sensor 2. 3. Check connection type.	M	Warning
Diagnostics for the electronics				
201	Device malfunction	Replace electronics.	F	Alarm
221	Reference measurement	Replace electronics.	F	Alarm
241	Software	1. Restart device. 2. Perform device reset. 3. Replace device.	F	Alarm
242	Software incompatible	Contact service.	F	Alarm
261	Electronics module	Replace electronics.	F	Alarm
262	Module connection short circuit	1. Ensure that display module is correctly seated on the head transmitter. 2. Test the display module using other suitable head transmitters. 3. Display module defective? Replace module.	M	Warning
282	Data memory	Replace device.	F	Alarm
283	Memory content	Replace electronics.	F	Alarm
301	Supply voltage ²⁾	1. Increase supply voltage. 2. Check connection wires for corrosion.	F	Alarm
Diagnostics for the configuration				
401	Factory reset	Please wait until the reset procedure is complete.	C	Warning
402	Initialization	Please wait until the start-up procedure is complete.	C	Warning
410	Data transfer	Check HART communication.	F	Alarm
411	Download active	Please wait until the up-/download is complete.	C	Warning
431	Factory calibration	Replace electronics.	F	Alarm

Diagnostic number	Short text	Corrective measure	Status signal from the factory	Diagnostic behavior from the factory
			Can be changed to	
435	Linearization	1. Check configuration of sensor parameters. 2. Check configuration of special sensor linearization. 3. Contact service. 4. Replace electronics.	F	Alarm
437	Configuration	1. Check configuration of sensor parameters. 2. Check configuration of special sensor linearization. 3. Check configuration of transmitter settings. 4. Contact service.	F	Alarm
438	Dataset	Carry out new parameter configuration.	F	Alarm
451	Data processing	Please wait until data processing is complete.	C	Warning
483	Simulation input	Deactivate simulation.	C	Warning
485	Measured value simulation			
491	Current output simulation			
501	CDI connection	Disconnect CDI plug.	C	Warning
525	HART communication	1. Check communication path. 2. Check HART master. 3. Sufficient power supply? 4. Check HART communication settings. 5. Contact service.	F	Alarm
Diagnostics for the process				
803	Loop current	1. Check wiring. 2. Replace electronics.	F	Alarm
842	Process limit value	Check scaling of analog output.	M F, S	Warning ¹⁾
925	Device temperature	Observe ambient temperature in accordance with specification.	S F	Warning

1) Diagnostic behavior can be changed in: "Alarm" or "Warning"

2) In the case of this diagnostic event, the device always outputs a "low" alarm status (output current 3.6 mA).

10 Maintenance and cleaning

10.1 Maintenance work

The device does not require specific maintenance work.

10.2 Cleaning of surfaces not in contact with the medium

- Recommendation: Use a lint-free cloth that is either dry or slightly dampened using water.
- Do not use any sharp objects or aggressive cleaning agents that corrode the surfaces (e.g. displays, housing) and seals.
- Do not use high-pressure steam.
- Observe the degree of protection of the device.

 The cleaning agent used must be compatible with the materials of the device configuration. Do not use cleaning agents with concentrated mineral acids, bases or organic solvents.

11 Repair

11.1 General information

Due to its design, the device cannot be repaired.

11.2 Spare parts

Product spare parts that are currently available can be found online at:
www.endress.com/onlinetools

Type
Standard - DIN securing set (2 screws and springs, 4 shaft lock-down rings, 1 plug for the display interface)
US - M4 securing set (2 screws and 1 plug for the display interface)
TID10 service cable; connecting cable for service interface, 40 cm
Spare parts kit for DIN rail transmitter (terminals and fixing lever housing)
Spare parts especially for field mount housing with separate terminal compartment
Display to plug on transmitter electronics
Foam insert

11.3 Return

The requirements for safe device return in the event of service or disposal vary depending on the type of device and national legislation.

1. Refer to the web page for information: <https://www.endress.com>
2. Log in to the “My Endress+Hauser” customer portal, or register if you don’t have an account yet.
3. Enter the return request directly in the portal and submit all required information and documents.
4. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.
 - ↳ Track the order's processing status online.

11.4 Disposal

 If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.


12 Accessories



The accessories currently available for the product can be selected at www.endress.com:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Spare parts & Accessories**.

12.1 Device-specific accessories

Accessories for the head transmitter
Display unit TID10 for Endress+Hauser head transmitter iTEMP TMT8x or TMT7x, attachable
Field housing TA30x for Endress+Hauser head transmitter
Adapter for DIN rail mounting, DIN rail clip as per IEC 60715 (TH35) without securing screws
Standard – DIN terminal head mounting set (2 screws + springs, 4 securing disks and 1 display connector cover)
US mounting set – M4 screws (2 M4 screws and 1 display connector cover)

Accessory mounted	
Captive screw for field housing TA30H	 A0053779

Accessory enclosed	
Wall mounting bracket, 316 L	 A0061686
Pipe mounting bracket, 316 L	 A0061687

Accessories for field mount housing with separate terminal compartment	
Cover locking	
Stainless steel wall mounting bracket Stainless steel pipe mounting bracket	
Cable glands M20x1.5 and NPT ½"	
Adapter M20x1.5 outside/M24x1.5 inside	
Dummy plugs M20x1.5 and NPT ½"	

12.2 Communication-specific accessories

Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.  For details, see the Technical Information
WirelessHART adapter SWA70	Is used for the wireless connection of field devices. The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks.  For details, see the Technical Information
Field Xpert SMT70B	Universal, high-performance tablet PC for device configuration The tablet PC enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as a comprehensive, all-in-one solution. Field Xpert also uses the most secure Bluetooth® interface available for its wireless connections. With a pre-installed driver library, it is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.  For details, see the Technical Information

12.3 Service-specific accessories

Configurator

Product Configurator - the tool for individual product configuration

- Up-to-the-minute configuration data
- Depending on the device: direct input of information specific to the measuring point, such as the measuring range or operating language
- Automatic verification of exclusion criteria
- Automatic creation of the order code and its breakdown in PDF or Excel output format
- Ability to order directly in the Endress+Hauser Online Shop

The Configurator is available at www.endress.com on the relevant product page:

1. Select the product using the filters and search field.
2. Open the product page.
3. Select **Configuration**.

DeviceCare SFE100

DeviceCare is an Endress+Hauser configuration tool for field devices using the following communication protocols: HART, PROFIBUS DP/PA, FOUNDATION Fieldbus, IO/Link, Modbus, CDI and Endress+Hauser Common Data Interfaces.

 www.endress.com/sfe100

FieldCare SFE500

FieldCare is a configuration tool for Endress+Hauser and third-party field devices based on DTM technology.

The following communication protocols are supported: HART, WirelessHART, PROFIBUS, FOUNDATION Fieldbus, Modbus, IO-Link, EtherNet/IP, PROFINET and PROFINET APL.

 www.endress.com/sfe500

Netilion

With the Netilion IIoT ecosystem, Endress+Hauser enables the optimization of plant performance, digitization of workflows, sharing of knowledge and improved collaboration. Drawing upon decades of experience in process automation, Endress+Hauser offers the process industry an IIoT ecosystem designed to effortlessly extract insights from data. These insights allow process optimization, leading to increased plant availability, efficiency, reliability and ultimately a more profitable plant.

 www.netilion.endress.com

12.4 Online tools

Product information about the entire life cycle of the device is available at: www.endress.com/onlinetools

12.5 System components

RN series active barrier

Single- or two-channel active barrier for safe separation of 0/4 to -20 mA standard signal circuits with bidirectional HART transmission. In the signal duplicator option, the input signal is transmitted to two galvanically isolated outputs. The device has one active and one passive current input; the outputs can be operated actively or passively.

For more information, please refer to: www.endress.com

Process indicators from the RIA product family

Easily readable process indicators with various functions: loop-powered indicators for displaying 4-20 mA values, display of up to four HART variables, process indicators with control units, limit value monitoring, sensor power supply, and galvanic isolation.

Universal application thanks to international hazardous area approvals, suitable for panel mounting or field installation..

For more information, please refer to: www.endress.com

Data Manager of the RSG product family

Data Managers are flexible and powerful systems to organize process values. Up to 20 universal inputs and up to 14 digital inputs for direct connection of sensors, optionally with HART, are available as an option. The measured process values are clearly presented on the display and logged safely, monitored for limit values and analyzed. The values can be forwarded via common communication protocols to higher-level systems and connected to one another via individual plant modules.

For more information, please refer to: www.endress.com

13 Technical data

13.1 Input

Measured variable	Temperature (temperature-linear transmission behavior), resistance and voltage.
Measuring range	It is possible to connect two sensors that are independent of one another ¹⁾ . The measuring inputs are not galvanically isolated from each other.

Resistance thermometer (RTD) as per standard	Description	α	Measuring range limits	Min. measuring span
IEC 60751:2008	Pt100 (1) Pt200 (2) Pt500 (3) Pt1000 (4)	0.003851	-200 to 850 °C (-328 to 1562 °F) -200 to 850 °C (-328 to 1562 °F) -200 to 500 °C (-328 to 932 °F) -200 to 250 °C (-328 to 482 °F)	10 K (18 °F)
JIS C1604:1984	Pt100 (5)	0.003916	-200 to 510 °C (-328 to 950 °F)	10 K (18 °F)
DIN 43760 IPTS-68	Ni100 (6) Ni120 (7)	0.006180	-60 to 250 °C (-76 to 482 °F) -60 to 250 °C (-76 to 482 °F)	10 K (18 °F)
GOST 6651-94	Pt50 (8) Pt100 (9)	0.003910	-185 to 1100 °C (-301 to 2012 °F) -200 to 850 °C (-328 to 1562 °F)	10 K (18 °F)
OIML R84: 2003, GOST 6651-2009	Cu50 (10) Cu100 (11)	0.004280	-180 to 200 °C (-292 to 392 °F) -180 to 200 °C (-292 to 392 °F)	10 K (18 °F)
	Ni100 (12) Ni120 (13)	0.006170	-60 to 180 °C (-76 to 356 °F) -60 to 180 °C (-76 to 356 °F)	10 K (18 °F)
OIML R84: 2003, GOST 6651-94	Cu50 (14)	0.004260	-50 to 200 °C (-58 to 392 °F)	10 K (18 °F)
-	Pt100 (Callendar van Dusen) Nickel polynomial Copper polynomial	-	The measuring range limits are specified by entering the limit values that depend on the coefficients A to C and R0.	10 K (18 °F)
	■ Connection type: 2-wire, 3-wire or 4-wire connection, sensor current: ≤ 0.3 mA ■ With 2-wire circuit, compensation of the wire resistance possible (0 to 30 Ω) ■ With 3-wire and 4-wire connection, sensor wire resistance up to max. 50 Ω per wire			
Resistance transmitter	Resistance Ω		10 to 400 Ω 10 to 2 000 Ω	10 Ω 10 Ω

1) In the case of 2-channel measurement the same measuring unit must be configured for the two channels (e.g. both °C or F or K). Independent 2-channel measurement of a resistance transmitter (Ohm) and voltage transmitter (mV) is not possible.

Thermocouples as per standard	Description	Measuring range limits		Min. measuring span
IEC 60584, Part 1 ASTM E230-3	Type A (W5Re-W20Re) (30) Type B (PtRh30-PtRh6) (31) Type E (NiCr-CuNi) (34) Type J (Fe-CuNi) (35) Type K (NiCr-Ni) (36) Type N (NiCrSi-NiSi) (37) Type R (PtRh13-Pt) (38) Type S (PtRh10-Pt) (39) Type T (Cu-CuNi) (40)	0 to 2 500 °C (32 to 4 532 °F) 40 to 1 820 °C (104 to 3 308 °F) -250 to 1 000 °C (-418 to 1 832 °F) -210 to 1 200 °C (-346 to 2 192 °F) -270 to 1 372 °C (-454 to 2 501 °F) -270 to 1 300 °C (-454 to 2 372 °F) -50 to 1 768 °C (-58 to 3 214 °F) -50 to 1 768 °C (-58 to 3 214 °F) -200 to 400 °C (-328 to 752 °F)	Recommended temperature range: 0 to 2 500 °C (32 to 4 532 °F) 500 to 1 820 °C (932 to 3 308 °F) -150 to 1 000 °C (-238 to 1 832 °F) -150 to 1 200 °C (-238 to 2 192 °F) -150 to 1 200 °C (-238 to 2 192 °F) -150 to 1 300 °C (-238 to 2 372 °F) 200 to 1 768 °C (392 to 3 214 °F) 200 to 1 768 °C (392 to 3 214 °F) -150 to 400 °C (-238 to 752 °F)	50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F) 50 K (90 °F)
IEC 60584, Part 1 ASTM E230-3 ASTM E988-96	Type C (W5Re-W26Re) (32)	0 to 2 315 °C (32 to 4 199 °F)	0 to 2 000 °C (32 to 3 632 °F)	50 K (90 °F)
ASTM E988-96	Type D (W3Re-W25Re) (33)	0 to 2 315 °C (32 to 4 199 °F)	0 to 2 000 °C (32 to 3 632 °F)	50 K (90 °F)
DIN 43710	Type L (Fe-CuNi) (41) Type U (Cu-CuNi) (42)	-200 to 900 °C (-328 to 1 652 °F) -200 to 600 °C (-328 to 1 112 °F)	-150 to 900 °C (-238 to 1 652 °F) -150 to 600 °C (-238 to 1 112 °F)	50 K (90 °F)
GOST R8.585-2001	Type L (NiCr-CuNi) (43)	-200 to 800 °C (-328 to 1 472 °F)	-200 to 800 °C (328 to 1 472 °F)	50 K (90 °F)
	- Internal reference junction (Pt100) - External reference junction: configurable value -40 to 85 °C (-40 to 185 °F) - Maximum sensor wire resistance 10 kΩ (If the sensor wire resistance is greater than 10 kΩ, an error message is output in accordance with NAMUR NE 89)			
Voltage transmitter (mV)	Millivolt transmitter (mV)	-20 to 100 mV		5 mV

Type of input

The following connection combinations are possible when both sensor inputs are assigned:

Sensor input 1					
Sensor input 2		RTD or resistance transmitter, 2-wire	RTD or resistance transmitter, 3-wire	RTD or resistance transmitter, 4-wire	Thermocouple (TC), voltage transmitter
	RTD or resistance transmitter, 2-wire	☑	☑	-	☑
	RTD or resistance transmitter, 3-wire	☑	☑	-	☑
	RTD or resistance transmitter, 4-wire	-	-	-	-
	Thermocouple (TC), voltage transmitter	☑	☑	☑	☑
	For field mount housing with a thermocouple on sensor input 1: It is not possible to connect a second thermocouple (TC), resistance thermometer, resistance transmitter or voltage transmitter on sensor input 2 as this input is needed for the external reference junction.				

13.2 Output

Output signal

Analog output	4 to 20 mA, 20 to 4 mA (can be inverted)
Signal encoding	FSK ±0.5 mA via current signal
Data transmission rate	1200 baud
Galvanic isolation	U = 2 kV AC for 1 minute (input/output)

Failure signal


Failure information as per NAMUR NE43:

The information is created if the measuring information is missing or not valid. A complete list of all the errors occurring in the measuring system is created.


Underranging	Linear decrease from 4.0 to 3.8 mA
Overranging	Linear increase from 20.0 to 20.5 mA
Failure e.g. sensor failure or sensor short-circuit	≤ 3.6 mA ("low") or ≥ 21 mA ("high"), can be selected The "high" alarm setting can be set between 21.5 mA and 23 mA, thus providing the flexibility needed to meet the requirements of various control systems.

Load

Head transmitter: $R_{b \max.} = (U_{b \max.} - 11 \text{ V}) / 0.023 \text{ A}$ (current output).



DIN rail transmitter: $R_{b \max.} = (U_{b \max.} - 12 \text{ V}) / 0.023 \text{ A}$ (current output).



Load in Ω . U_b = supply voltage in V DC

Linearization/transmission behavior

Temperature-linear, resistance-linear, voltage-linear

Mains filter

50/60 Hz

Filter

1st order digital filter: 0 to 120 s

Protocol-specific data

HART version	7
Device address in the multi-drop mode ¹⁾	Software setting addresses 0 to 63
Device description files (DD)	Information and files are available free of charge at: www.endress.com www.fieldcommgroup.org
Load (communication resistor)	Min. 250 Ω

1) Not possible in SIL mode, see Functional Safety Manual FY01105T

Write protection for device parameters

- Hardware: Write protection for head transmitter on optional display using DIP switch
- Software: Write protection using password

Switch-on delay	■ Until the start of HART communication, approx. 6 s²⁾, while switch-on delay = I_a ≤ 3.8 mA ■ Until the first valid measured value signal is present for HART communication and at the current output, approx. 15 s, while switch-on delay = I_a ≤ 3.8 mA
-----------------	---

13.3 Electrical connection

Supply voltage	Values for non-hazardous areas, protected against polarity reversal: ■ Head transmitter ■ 11 V ≤ V_{cc} ≤ 42 V (standard) ■ 11 V ≤ V_{cc} ≤ 32 V (SIL mode) ■ I: ≤ 23 mA ■ DIN rail transmitter ■ 12 V ≤ V_{cc} ≤ 42 V (standard) ■ 12 V ≤ V_{cc} ≤ 32 V (SIL mode) ■ I: ≤ 23 mA Values for hazardous area, see Ex documentation.
----------------	---

Current consumption	Current consumption ≤ 23 mA
---------------------	-----------------------------

Terminals	Choice of screw terminals or push-in terminals for sensor and power supply cables:
-----------	--

Terminal design	Cable design	Cable cross-section
Screw terminals	Rigid or flexible	≤ 2.5 mm ² (14 AWG)
		Field mount housing: 2.5 mm ² (12 AWG) plus ferrule
Push-in terminals (cable version, stripping length = min. 10 mm (0.39 in))	Rigid or flexible	0.2 to 1.5 mm ² (24 to 16 AWG)
	Flexible with ferrules (with or without plastic ferrule)	0.25 to 1.5 mm ² (24 to 16 AWG)

 Ferrules must be used with push-in terminals and when using flexible cables with a cable cross-section of ≤ 0.3 mm². Otherwise, the use of ferrules when connecting flexible cables to push-in terminals is not recommended.

13.4 Performance characteristics

Response time	The measured value update depends on the sensor type and connection type. It falls within the following ranges: <table><tr><td>Resistance thermometers (RTD)</td><td>0.9 to 1.5 s (depends on the connection type 2/3/4-wire)</td></tr><tr><td>Thermocouples (TC)</td><td>1.1 s</td></tr><tr><td>Reference junction</td><td>1.1 s</td></tr></table>	Resistance thermometers (RTD)	0.9 to 1.5 s (depends on the connection type 2/3/4-wire)	Thermocouples (TC)	1.1 s	Reference junction	1.1 s
Resistance thermometers (RTD)	0.9 to 1.5 s (depends on the connection type 2/3/4-wire)						
Thermocouples (TC)	1.1 s						
Reference junction	1.1 s						

 When recording step responses, it must be taken into account that the times for measuring the second channel and the internal reference junction may be added to the specified times.

2) Does not apply to SIL mode

Update time ≤ 100 ms

Reference conditions

- Calibration temperature: 25 °C ±3 K (77 °F ±5.4 °F)
- Supply voltage: 24 V DC
- 4-wire circuit for resistance adjustment

Maximum measurement error In accordance with EN IEC 62828 and the reference operating conditions specified above. The measurement error data correspond to $\pm 2 \sigma$ (Gaussian distribution). The data include non-linearities and repeatability.

Typically

Standard	Description	Measuring range	Typical measurement error (±)	
Resistance thermometer (RTD) as per standard			Digital value ¹⁾	Value at current output
IEC 60751:2008	Pt100 (1)	0 to 200 °C (32 to 392 °F)	0.07 °C (0.13 °F)	0.09 °C (0.16 °F)
IEC 60751:2008	Pt1000 (4)		0.05 °C (0.09 °F)	0.08 °C (0.14 °F)
GOST 6651-94	Pt100 (9)		0.06 °C (0.11 °F)	0.08 °C (0.14 °F)
Thermocouples (TC) as per standard			Digital value	Value at current output
IEC 60584, Part 1 ASTM E230-3	Type K (NiCr-Ni) (36)	0 to 800 °C (32 to 1472 °F)	0.25 °C (0.45 °F)	0.35 °C (0.63 °F)
	Type R (PtRh13-Pt) (38)		0.59 °C (1.06 °F)	0.64 °C (1.15 °F)
	Type S (PtRh10-Pt) (39)		0.67 °C (1.21 °F)	0.71 °C (1.28 °F)

1) Measured value transmitted via HART.

Measurement error for resistance thermometers (RTD) and resistance transmitters

Standard	Description	Measuring range	Measurement error ($\pm$)	
			Digital ¹⁾	D/A ²⁾
			Based on measured value ³⁾	
IEC 60751:2008	Pt100 (1)	-200 to 850 °C (-328 to 1562 °F)	ME = $\pm$ (0.05 °C (0.09 °F) + 0.0039% * (MV - LRL))	0.03 % ($\approx$ 4.8 μ A)
	Pt200 (2)		ME = $\pm$ (0.04 °C (0.07 °F) + 0.01% * (MV - LRL))	
	Pt500 (3)	-200 to 500 °C (-328 to 932 °F)	ME = $\pm$ (0.02 °C (0.04 °F) + 0.01% * (MV - LRL))	
	Pt1000 (4)	-200 to 250 °C (-328 to 482 °F)	ME = $\pm$ (0.01 °C (0.02 °F) + 0.009% * (MV - LRL))	
JIS C1604:1984	Pt100 (5)	-200 to 510 °C (-328 to 950 °F)	ME = $\pm$ (0.04 °C (0.07 °F) + 0.005% * (MV - LRL))	
GOST 6651-94	Pt50 (8)	-185 to 1100 °C (-301 to 2012 °F)	ME = $\pm$ (0.08 °C (0.14 °F) + 0.007% * (MV - LRL))	
	Pt100 (9)	-200 to 850 °C (-328 to 1562 °F)	ME = $\pm$ (0.04 °C (0.07 °F) + 0.005% * (MV - LRL))	
DIN 43760 IPTS-68	Ni100 (6)	-60 to 250 °C (-76 to 482 °F)	ME = $\pm$ (0.042 °C (0.076 °F) - 0.005% * (MV - LRL))	
	Ni120 (7)		ME = $\pm$ (0.035 °C (0.063 °F) - 0.004% * (MV - LRL))	
OIML R84: 2003 / GOST 6651-2009	Cu50 (10)	-180 to 200 °C (-292 to 392 °F)	ME = $\pm$ (0.09 °C (0.16 °F) + 0.006% * (MV - LRL))	
	Cu100 (11)	-180 to 200 °C (-292 to 392 °F)	ME = $\pm$ (0.05 °C (0.09 °F) + 0.003% * (MV - LRL))	
	Ni100 (12)	-60 to 180 °C (-76 to 356 °F)	ME = $\pm$ (0.05 °C (0.09 °F) - 0.005% * (MV - LRL))	
	Ni120 (13)		ME = $\pm$ (0.05 °C (0.09 °F) - 0.005% * (MV - LRL))	
OIML R84: 2003, GOST 6651-94	Cu50 (14)	-50 to 200 °C (-58 to 392 °F)	ME = $\pm$ (0.10 °C (0.18 °F) + 0.004% * (MV - LRL))	

Standard	Description	Measuring range	Measurement error ($\pm$)	
Resistance transmitter	Resistance Ω	10 to 400 Ω	ME = $\pm$ (16 Ω + 0.0025% * (MV - LRL))	0.03 % ($\cong$ 4.8 μ A)
		10 to 2 000 Ω	ME = $\pm$ (30 Ω + 0.007% * (MV - LRL))	

- 1) Measured value transmitted via HART.
 2) Percentages based on the configured measuring span of the analog output signal.
 3) Deviations from maximum measurement error due to rounding is possible.

Measurement error for thermocouples (TC) and voltage transmitters

Standard	Description	Measuring range	Measurement error ($\pm$)	
			Digital ¹⁾	D/A ²⁾
			Based on measured value ³⁾	
IEC 60584-1 ASTM E230-3	Type A (30)	0 to 2 500 °C (32 to 4 532 °F)	ME = $\pm$ (0.7 °C (1.26 °F) + 0.019% * (MV - LRL))	0.03 % ($\cong$ 4.8 μ A)
	Type B (31)	500 to 1 820 °C (932 to 3 308 °F)	ME = $\pm$ (1.15 °C (2.07 °F) - 0.04% * (MV - LRL))	
IEC 60584-1 ASTM E230-3 ASTM E988-96	Type C (32)	0 to 2 000 °C (32 to 3 632 °F)	ME = $\pm$ (0.4 °C (0.72 °F) + 0.0065% * (MV - LRL))	
ASTM E988-96	Type D (33)	0 to 2 000 °C (32 to 3 632 °F)	ME = $\pm$ (0.55 °C (0.99 °F) - 0.005% * (MV - LRL))	
IEC 60584-1 ASTM E230-3	Type E (34)	-150 to 1 000 °C (-238 to 1 832 °F)	ME = $\pm$ (0.16 °C (0.29 °F) - 0.001% * (MV - LRL))	
	Type J (35)	-150 to 1 200 °C (-238 to 2 192 °F)	ME = $\pm$ (0.22 °C (0.4 °F) - 0.0045% * (MV - LRL))	
	Type K (36)		ME = $\pm$ (0.28 °C (0.5 °F) - 0.003% * (MV - LRL))	
	Type N (37)	-150 to 1 300 °C (-238 to 2 372 °F)	ME = $\pm$ (0.37 °C (0.67 °F) - 0.01% * (MV - LRL))	
	Type R (38)	200 to 1 768 °C (392 to 3 214 °F)	ME = $\pm$ (0.65 °C (1.17 °F) - 0.01% * (MV - LRL))	
	Type S (39)		ME = $\pm$ (0.7 °C (1.26 °F) - 0.005% * (MV - LRL))	
	Type T (40)	-150 to 400 °C (-238 to 752 °F)	ME = $\pm$ (0.3 °C (0.54 °F) - 0.027% * (MV - LRL))	
DIN 43710	Type L (41)	-150 to 900 °C (-238 to 1 652 °F)	ME = $\pm$ (0.24 °C (0.43 °F) - 0.0055% * (MV - LRL))	
	Type U (42)	-150 to 600 °C (-238 to 1 112 °F)	ME = $\pm$ (0.33 °C (0.59 °F) - 0.028% * (MV - LRL))	
GOST R8.585-2001	Type L (43)	-200 to 800 °C (-328 to 1 472 °F)	ME = $\pm$ (2.2 °C (3.96 °F) - 0.015% * (MV - LRL))	
Voltage transmitter (mV)		-20 to 100 mV	ME = $\pm$ 10 μ V	4.8 μ A

- 1) Measured value transmitted via HART.
 2) Percentages based on the configured measuring span of the analog output signal.
 3) Deviations from maximum measurement error due to rounding is possible.

MV = measured value

LRL = lower range limit of the sensor in question

Total measurement error of transmitter at current output = $\sqrt{(\text{Measurement error digital}^2 + \text{Measurement error D/A}^2)}$

Sample calculation with Pt100, measuring range 0 to 200 °C (32 to 392 °F), ambient temperature 25 °C (77 °F), supply voltage 24 V:

Measurement error digital = 0.05 °C + 0.0039% x (200 °C - (-200 °C)):	0.07 °C (0.13 °F)
Measurement error D/A = 0.03 % x 200 °C (360 °F)	0.06 °C (0.11 °F)
Measurement error digital value (HART):	0.07 °C (0.13 °F)
Measurement error analog value (current output): $\sqrt{(\text{measurement error digital}^2 + \text{measurement error D/A}^2)}$	0.09 °C (0.16 °F)

Sample calculation with Pt100, measuring range 0 to 200 °C (32 to 392 °F), ambient temperature 35 °C (95 °F), supply voltage 30 V:

Measurement error digital = $0.05\text{ °C} + 0.0039\% \times (200\text{ °C} - (-200\text{ °C}))$:	0.07 °C (0.13 °F)
Measurement error D/A = $0.03\% \times 200\text{ °C}$ (360 °F)	0.06 °C (0.11 °F)
Influence of ambient temperature (digital) = $(35 - 25) \times (0.002\% \times 200\text{ °C} - (-200\text{ °C}))$, min. 0.005 °C	0.08 °C (0.14 °F)
Influence of ambient temperature (D/A) = $(35 - 25) \times (0.001\% \times 200\text{ °C})$	0.02 °C (0.04 °F)
Influence of supply voltage (digital) = $(30 - 24) \times (0.002\% \times 200\text{ °C} - (-200\text{ °C}))$, min. 0.005 °C	0.05 °C (0.09 °F)
Influence of supply voltage (D/A) = $(30 - 24) \times (0.001\% \times 200\text{ °C})$	0.01 °C (0.02 °F)
Measurement error digital value (HART): $\sqrt{(\text{Measurement error digital})^2 + \text{Influence of ambient temperature (digital)}^2 + \text{Influence of supply voltage (digital)}^2}$	0.12 °C (0.22 °F)
Measurement error analog value (current output): $\sqrt{(\text{Measurement error digital})^2 + \text{Measurement error D/A}^2 + \text{Influence of ambient temperature (digital)}^2 + \text{Influence of ambient temperature (D/A)}^2 + \text{Influence of supply voltage (digital)}^2 + \text{Influence of supply voltage (D/A)}^2}$	0.13 °C (0.23 °F)

The measurement error data correspond to $\pm 2\sigma$ (Gaussian distribution).

MV = measured value

LRL = lower range limit of the sensor in question

Physical input measuring range of sensors	
10 to 400 Ω	Cu50, Cu100, polynomial RTD, Pt50, Pt100, Ni100, Ni120
10 to 2 000 Ω	Pt200, Pt500, Pt1000
-20 to 100 mV	Thermocouples type: A, B, C, D, E, J, K, L, N, R, S, T, U



Other measurement errors apply in SIL mode.



For more information, please refer to Functional Safety Manual FY01105T.

Sensor adjustment

Sensor-transmitter matching

RTD sensors are one of the most linear temperature measuring elements. Nevertheless, the output must be linearized. To significantly improve temperature measurement accuracy, the device allows the use of two methods:

■ Callendar van Dusen coefficients (Pt100 resistance thermometer)

The Callendar van Dusen equation is described as:

$$R_T = R_0[1 + AT + BT^2 + C(T - 100)T^3]$$

The coefficients A, B and C are used to match the sensor (platinum) and transmitter in order to improve the accuracy of the measuring system. The coefficients for a standard sensor are specified in IEC 751. If no standard sensor is available or if greater accuracy is required, the coefficients for each sensor can be determined specifically with the aid of sensor calibration.

■ Linearization for copper/nickel resistance thermometers (RTD)

The polynomial equation for copper/nickel is as follows:

$$R_T = R_0(1 + AT + BT^2)$$

The coefficients A and B are used for the linearization of nickel or copper resistance thermometers (RTD). The exact values of the coefficients derive from the calibration data and are specific to each sensor. The sensor-specific coefficients are then sent to the transmitter.

Sensor-transmitter matching using one of the methods mentioned above significantly improves the temperature measurement accuracy of the entire system. This is because the transmitter uses the specific data pertaining to the connected sensor to calculate the measured temperature, instead of using the standardized sensor curve data.

1-point adjustment (offset)

Shifts the sensor value

2-point adjustment (sensor trimming)

Correction (slope and offset) of the measured sensor value at transmitter input

Current output adjustment	Correction of 4 or 20 mA current output value (not possible in SIL mode)
---------------------------	--

Operating influences	The measurement error data correspond to $\pm 2 \sigma$ (Gaussian distribution).
----------------------	--

Influence of ambient temperature and supply voltage on operation for resistance thermometers (RTD) and resistance transmitters

Description	Standard	Ambient temperature: Influence ($\pm$) per 1 °C (1.8 °F) change			Supply voltage: Influence ($\pm$) per V change		
		Digital ¹⁾	D/A ²⁾		Digital	D/A	
		Maximum	Based on measured value		Maximum	Based on measured value	
Pt100 (1)	IEC 60751:2008	≤ 0.02 °C (0.036 °F)	0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)	0.001 %	≤ 0.02 °C (0.036 °F)	0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)	0.001 %
Pt200 (2)		≤ 0.026 °C (0.047 °F)	-		≤ 0.026 °C (0.047 °F)	-	
Pt500 (3)		≤ 0.014 °C (0.025 °F)	0.002% * (MV - LRL), at least 0.009 °C (0.016 °F)		≤ 0.014 °C (0.025 °F)	0.002% * (MV - LRL), at least 0.009 °C (0.016 °F)	
Pt1000 (4)		≤ 0.01 °C (0.018 °F)	0.002% * (MV - LRL), at least 0.004 °C (0.007 °F)		≤ 0.01 °C (0.018 °F)	0.002% * (MV - LRL), at least 0.004 °C (0.007 °F)	
Pt100 (5)	JIS C1604:1984		0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)			0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)	
Pt50 (8)	GOST 6651-94	≤ 0.03 °C (0.054 °F)	0.002% * (MV - LRL), at least 0.01 °C (0.018 °F)		≤ 0.03 °C (0.054 °F)	0.002% * (MV - LRL), at least 0.01 °C (0.018 °F)	
Pt100 (9)		≤ 0.02 °C (0.036 °F)	0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)		≤ 0.02 °C (0.036 °F)	0.002% * (MV - LRL), at least 0.005 °C (0.009 °F)	

Description	Standard	Ambient temperature: Influence (±) per 1 °C (1.8 °F) change		Supply voltage: Influence (±) per V change	
Ni100 (6)	DIN 43760 IPITS-68	≤ 0.005 °C (0.009 °F)	-	≤ 0.005 °C (0.009 °F)	-
Ni120 (7)			-		-
Cu50 (10)	OIML R84: 2003 / GOST 6651-2009	≤ 0.008 °C (0.014 °F)	-	≤ 0.008 °C (0.014 °F)	-
Cu100 (11)			0.002% * (MV - LRL), at least 0.004 °C (0.007 °F)		0.002% * (MV - LRL), at least 0.004 °C (0.007 °F)
Ni100 (12)		≤ 0.004 °C (0.007 °F)	-	≤ 0.004 °C (0.007 °F)	-
Ni120 (13)			-		-
Cu50 (14)	OIML R84: 2003 / GOST 6651-94	≤ 0.008 °C (0.014 °F)	-	≤ 0.008 °C (0.014 °F)	-
Resistance transmitter (Ω)					
10 to 400 Ω		≤ 6 mΩ	0.0015% * (MV - LRL), at least 1.5 mΩ	≤ 6 mΩ	0.0015% * (MV - LRL), at least 1.5 mΩ
10 to 2 000 Ω		≤ 30 mΩ	0.0015% * (MV - LRL), at least 15 mΩ	≤ 30 mΩ	0.0015% * (MV - LRL), at least 15 mΩ

1) Measured value transmitted via HART.

2) Percentages based on the configured measuring span of the analog output signal

Influence of ambient temperature and supply voltage on operation for thermocouples (TC) and voltage transmitters

Description	Standard	Ambient temperature: Influence (±) per 1 °C (1.8 °F) change		Supply voltage: Influence (±) per V change	
		Digital ¹⁾	D/A ²⁾	Digital	D/A
		Maximum	Based on measured value	Maximum	Based on measured value
Type A (30)	IEC 60584-1 ASTM E230-3	≤ 0.14 °C (0.25 °F)	0.0055% * (MV - LRL), at least 0.03 °C (0.054 °F)	≤ 0.14 °C (0.25 °F)	0.0055% * (MV - LRL), at least 0.03 °C (0.054 °F)
Type B (31)		≤ 0.06 °C (0.11 °F)	-	≤ 0.06 °C (0.11 °F)	-
Type C (32)	IEC 60584-1 ASTM E230-3 ASTM E988-96	≤ 0.09 °C (0.16 °F)	0.0045% * (MV - LRL), at least 0.03 °C (0.054 °F)	≤ 0.09 °C (0.16 °F)	0.0045% * (MV - LRL), at least 0.03 °C (0.054 °F)
Type D (33)	ASTM E988-96	≤ 0.08 °C (0.14 °F)	0.004% * (MV - LRL), at least 0.035 °C (0.063 °F)	≤ 0.08 °C (0.14 °F)	0.004% * (MV - LRL), at least 0.035 °C (0.063 °F)
Type E (34)	IEC 60584-1 ASTM E230-3	≤ 0.03 °C (0.05 °F)	0.003% * (MV - LRL), at least 0.016 °C (0.029 °F)	≤ 0.03 °C (0.05 °F)	0.003% * (MV - LRL), at least 0.016 °C (0.029 °F)
Type J (35)		≤ 0.02 °C (0.04 °F)	0.0028% * (MV - LRL), at least 0.02 °C (0.036 °F)	≤ 0.02 °C (0.04 °F)	0.0028% * (MV - LRL), at least 0.02 °C (0.036 °F)
Type K (36)		≤ 0.04 °C (0.07 °F)	0.003% * (MV - LRL), at least 0.013 °C (0.023 °F)	≤ 0.04 °C (0.07 °F)	0.003% * (MV - LRL), at least 0.013 °C (0.023 °F)
Type N (37)			0.0028% * (MV - LRL), at least 0.020 °C (0.036 °F)		0.0028% * (MV - LRL), at least 0.020 °C (0.036 °F)
Type R (38)		≤ 0.06 °C (0.11 °F)	0.0035% * (MV - LRL), at least 0.047 °C (0.085 °F)	≤ 0.06 °C (0.11 °F)	0.0035% * (MV - LRL), at least 0.047 °C (0.085 °F)
Type S (39)		≤ 0.05 °C (0.09 °F)	-	≤ 0.05 °C (0.09 °F)	-
Type T (40)		≤ 0.01 °C (0.02 °F)	-	≤ 0.01 °C (0.02 °F)	-
Type L (41)	DIN 43710	≤ 0.02 °C (0.04 °F)	-	≤ 0.02 °C (0.04 °F)	-

Description	Standard	Ambient temperature: Influence (±) per 1 °C (1.8 °F) change			Supply voltage: Influence (±) per V change		
Type U (42)		≤ 0.01 °C (0.02 °F)	-		≤ 0.01 °C (0.02 °F)	-	
Type L (43)	GOST R8.585-2001	≤ 0.01 °C (0.02 °F)	-		≤ 0.01 °C (0.02 °F)	-	
Voltage transmitter (mV)				0.001 %			0.001 %
-20 to 100 mV	-	≤ 3 µV	-		≤ 3 µV	-	

- 1) Measured value transmitted via HART.
2) Percentages based on the configured measuring span of the analog output signal

MV = measured value

LRL = lower range limit of the sensor in question

Total measurement error of transmitter at current output = $\sqrt{(\text{Measurement error digital}^2 + \text{Measurement error D/A}^2)}$

Long-term drift, resistance thermometers (RTD) and resistance transmitters

Description	Standard	Long-term drift (±) ¹⁾				
		after 1 year	after 3 years	after 5 years	after 10 years	after 20 years
		Based on measured value				
Pt100 (1)	IEC 60751:2008	≤ 0.016% * (MV - LRL) or 0.04 °C (0.07 °F)	≤ 0.025% * (MV - LRL) or 0.05 °C (0.09 °F)	≤ 0.028% * (MV - LRL) or 0.06 °C (0.10 °F)	≤ 0.03% * (MV - LRL) or 0.065 °C (0.12 °F)	≤ 0.03% * (MV - LRL) or 0.07 °C (0.13 °F)
Pt200 (2)		0.25 °C (0.44 °F)	0.41 °C (0.73 °F)	0.50 °C (0.91 °F)	0.58 °C (1.04 °F)	0.58 °C (1.04 °F)
Pt500 (3)		≤ 0.018% * (MV - LRL) or 0.08 °C (0.14 °F)	≤ 0.03% * (MV - LRL) or 0.14 °C (0.25 °F)	≤ 0.036% * (MV - LRL) or 0.17 °C (0.31 °F)	≤ 0.05% * (MV - LRL) or 0.2 °C (0.36 °F)	≤ 0.05% * (MV - LRL) or 0.2 °C (0.36 °F)
Pt1000 (4)		≤ 0.0185% * (MV - LRL) or 0.04 °C (0.07 °F)	≤ 0.031% * (MV - LRL) or 0.07 °C (0.12 °F)	≤ 0.038% * (MV - LRL) or 0.08 °C (0.14 °F)	≤ 0.05% * (MV - LRL) or 0.1 °C (0.18 °F)	≤ 0.05% * (MV - LRL) or 0.1 °C (0.18 °F)
Pt100 (5)	JIS C1604:1984	≤ 0.015% * (MV - LRL) or 0.04 °C (0.07 °F)	≤ 0.024% * (MV - LRL) or 0.07 °C (0.12 °F)	≤ 0.027% * (MV - LRL) or 0.08 °C (0.14 °F)	≤ 0.027% * (MV - LRL) or 0.085 °C (0.153 °F)	≤ 0.027% * (MV - LRL) or 0.085 °C (0.153 °F)
Pt50 (8)	GOST 6651-94	≤ 0.017% * (MV - LRL) or 0.07 °C (0.13 °F)	≤ 0.027% * (MV - LRL) or 0.12 °C (0.22 °F)	≤ 0.03% * (MV - LRL) or 0.14 °C (0.25 °F)	≤ 0.03% * (MV - LRL) or 0.12 °C (0.22 °F)	≤ 0.03% * (MV - LRL) or 0.12 °C (0.22 °F)
Pt100 (9)		≤ 0.016% * (MV - LRL) or 0.04 °C (0.07 °F)	≤ 0.025% * (MV - LRL) or 0.07 °C (0.12 °F)	≤ 0.028% * (MV - LRL) or 0.07 °C (0.13 °F)	≤ 0.03% * (MV - LRL) or 0.06 °C (0.11 °F)	≤ 0.03% * (MV - LRL) or 0.06 °C (0.11 °F)
Ni100 (6)	DIN 43760 IPTS-68	0.04 °C (0.06 °F)	0.05 °C (0.10 °F)	0.061 °C (0.11 °F)	0.065 °C (0.12 °F)	0.065 °C (0.12 °F)
Ni120 (7)					0.061 °C (0.11 °F)	0.061 °C (0.11 °F)
Cu50 (10)	OIML R84: 2003 / GOST 6651-2009	0.06 °C (0.10 °F)	0.09 °C (0.16 °F)	0.11 °C (0.20 °F)	0.11 °C (0.198 °F)	0.11 °C (0.198 °F)
Cu100 (11)		≤ 0.015% * (MV - LRL) or 0.04 °C (0.06 °F)	≤ 0.024% * (MV - LRL) or 0.06 °C (0.10 °F)	≤ 0.027% * (MV - LRL) or 0.06 °C (0.11 °F)		
Ni100 (12)		0.03 °C (0.06 °F)	0.05 °C (0.09 °F)	0.06 °C (0.10 °F)	0.058 °C (0.104 °F)	0.058 °C (0.104 °F)
Ni120 (13)		0.03 °C (0.06 °F)	0.05 °C (0.09 °F)	0.06 °C (0.10 °F)		
Cu50 (14)	OIML R84: 2003 / GOST 6651-94	0.06 °C (0.10 °F)	0.09 °C (0.16 °F)	0.10 °C (0.18 °F)	0.11 °C (0.198 °F)	0.11 °C (0.198 °F)

Description	Standard	Long-term drift (±) ¹⁾				
Resistance transmitter						
10 to 400 Ω		≤ 0.0122% * (MV - LRL) or 12 mΩ	≤ 0.02% * (MV - LRL) or 20 mΩ	≤ 0.022% * (MV - LRL) or 22 mΩ	≤ 0.025% * (MV - LRL) or 30 mΩ	≤ 0.025% * (MV - LRL) or 250 mΩ
10 to 2 000 Ω		≤ 0.015% * (MV - LRL) or 144 mΩ	≤ 0.024% * (MV - LRL) or 240 mΩ	≤ 0.03% * (MV - LRL) or 295 mΩ	≤ 0.16% * (MV - LRL) or 350 mΩ	≤ 0.16% * (MV - LRL) or 1 600 mΩ

1) Whichever is greater

Long-term drift, thermocouples (TC) and voltage transmitters

Description	Standard	Long-term drift ($\pm$) ¹⁾				
		after 1 year	after 3 years	after 5 years	after 10 years	after 20 years
		Based on measured value				
Type A (30)	IEC 60584-1 ASTM E230-3	$\leq 0.048\% * (MV - LRL)$ or 0.46 °C (0.83 °F)	$\leq 0.072\% * (MV - LRL)$ or 0.69 °C (1.24 °F)	$\leq 0.1\% * (MV - LRL)$ or 0.94 °C (1.69 °F)	$\leq 0.11\% * (MV - LRL)$ or 1 °C (1.8 °F)	$\leq 0.11\% * (MV - LRL)$ or 1.1 °C (1.98 °F)
Type B (31)		1.08 °C (1.94 °F)	1.63 °C (2.93 °F)	2.23 °C (4.01 °F)	2.5 °C (4.5 °F)	2.5 °C (4.5 °F)
Type C (32)	IEC 60584-1 ASTM E230-3 ASTM E988-96	$\leq 0.038\% * (MV - LRL)$ or 0.41 °C (0.74 °F)	$\leq 0.057\% * (MV - LRL)$ or 0.62 °C (1.12 °F)	$\leq 0.078\% * (MV - LRL)$ or 0.85 °C (1.53 °F)	$\leq 0.085\% * (MV - LRL)$ or 1.0 °C (1.8 °F)	$\leq 0.085\% * (MV - LRL)$ or 1.0 °C (1.8 °F)
Type D (33)	ASTM E988-96	$\leq 0.035\% * (MV - LRL)$ or 0.57 °C (1.03 °F)	$\leq 0.052\% * (MV - LRL)$ or 0.86 °C (1.55 °F)	$\leq 0.071\% * (MV - LRL)$ or 1.17 °C (2.11 °F)	$\leq 0.08\% * (MV - LRL)$ or 1.3 °C (2.34 °F)	$\leq 0.08\% * (MV - LRL)$ or 1.3 °C (2.34 °F)
Type E (34)	IEC 60584-1 ASTM E230-3	$\leq 0.024\% * (MV - LRL)$ or 0.15 °C (0.27 °F)	$\leq 0.037\% * (MV - LRL)$ or 0.23 °C (0.41 °F)	$\leq 0.05\% * (MV - LRL)$ or 0.31 °C (0.56 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.4 °C (0.72 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.4 °C (0.72 °F)
Type J (35)		$\leq 0.025\% * (MV - LRL)$ or 0.17 °C (0.31 °F)	$\leq 0.037\% * (MV - LRL)$ or 0.25 °C (0.45 °F)	$\leq 0.051\% * (MV - LRL)$ or 0.34 °C (0.61 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.4 °C (0.72 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.4 °C (0.72 °F)
Type K (36)		$\leq 0.027\% * (MV - LRL)$ or 0.23 °C (0.41 °F)	$\leq 0.041\% * (MV - LRL)$ or 0.35 °C (0.63 °F)	$\leq 0.056\% * (MV - LRL)$ or 0.48 °C (0.86 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.55 °C (0.99 °F)	$\leq 0.06\% * (MV - LRL)$ or 0.55 °C (0.99 °F)
Type N (37)		0.36 °C (0.65 °F)	0.55 °C (0.99 °F)	0.75 °C (1.35 °F)	0.8 °C (1.44 °F)	0.8 °C (1.44 °F)
Type R (38)		0.83 °C (1.49 °F)	1.26 °C (2.27 °F)	1.72 °C (3.10 °F)	1.9 °C (3.42 °F)	1.9 °C (3.42 °F)
Type S (39)		0.84 °C (1.51 °F)	1.27 °C (2.29 °F)	1.73 °C (3.11 °F)	1.9 °C (3.42 °F)	1.9 °C (3.42 °F)
Type T (40)		0.25 °C (0.45 °F)	0.37 °C (0.67 °F)	0.51 °C (0.92 °F)	0.6 °C (1.08 °F)	0.6 °C (1.08 °F)
Type L (41)	DIN 43710	0.20 °C (0.36 °F)	0.31 °C (0.56 °F)	0.42 °C (0.76 °F)	$\leq 0.05\% * (MV - LRL)$ or 0.4 °C (0.72 °F)	$\leq 0.05\% * (MV - LRL)$ or 0.4 °C (0.72 °F)
Type U (42)		0.24 °C (0.43 °F)	0.37 °C (0.67 °F)	0.50 °C (0.90 °F)	0.6 °C (1.08 °F)	0.6 °C (1.08 °F)
Type L (43)	GOST R8.585-2001	0.22 °C (0.40 °F)	0.33 °C (0.59 °F)	0.45 °C (0.81 °F)	0.5 °C (0.9 °F)	0.5 °C (0.9 °F)
Voltage transmitter (mV)						
– 20 to 100 mV		$\leq 0.027\% * (MV - LRL)$ or 5.5 μV	$\leq 0.041\% * (MV - LRL)$ or 8.2 μV	$\leq 0.056\% * (MV - LRL)$ or 11.2 μV	$\leq 0.07\% * (MV - LRL)$ or 12 μV	$\leq 0.07\% * (MV - LRL)$ or 12 μV

1) Whichever is greater

Long-term drift analog output

Long-term drift D/A ¹⁾ (±)				
after 1 year	after 3 years	after 5 years	after 10 years	after 20 years
0.021%	0.029%	0.031%	0.031%	0.031%

1) Percentages based on the configured measuring span of the analog output signal.

Influence of the reference junction

- Pt100 DIN IEC 60751 Cl. B (internal reference junction with thermocouples TC)
- Field mount housing with separate terminal compartment: Pt100 DIN IEC 60751 Cl. B (external reference junction with thermocouples TC)

13.5 Environment

Ambient temperature range

Head transmitter/DIN rail transmitter	–40 to 85 °C (–40 to 185 °F), for hazardous areas, see Safety Instructions for explosion-proof devices
Optional	–50 to 85 °C (–58 to 185 °F), for hazardous areas, see Safety Instructions for explosion-proof devices, Product Configurator order code for "Test, certificate, declaration", option "JM" ¹⁾
Optional	–52 to 85 °C (–62 to 185 °F), for hazardous areas, see Safety Instructions for explosion-proof devices, Product Configurator order code for "Test, certificate, declaration", option "JN" ¹⁾
Head transmitter, field mount housing with separate terminal compartment incl. display	–30 to 85 °C (–22 to 185 °F). At temperatures < –20 °C (–4 °F), the display may react slowly, Product Configurator order code: "Field housing", option "R" and "S"
SIL mode	–40 to 70 °C (–40 to 158 °F)

1) If the temperature is below –40 °C (–40 °F), increased failure rates are likely.

Storage temperature

Head transmitter	–50 to 100 °C (–58 to 212 °F)
Optional	–52 to 85 °C (–62 to 185 °F) Product Configurator order code for "Test, certificate, declaration", option "JN" ¹⁾
Head transmitter, field mount housing with separate terminal compartment incl. display	–35 to 85 °C (–31 to 185 °F). At temperatures < –20 °C (–4 °F), the display may react slowly, Product Configurator order code: "Field housing", option "R" and "S"
DIN rail transmitter	–40 to 100 °C (–40 to 212 °F)

1) If the temperature is below –50 °C (–58 °F), increased failure rates are likely.

Relative humidity

- Condensation:
 - Head transmitter permitted
 - DIN rail transmitter not permitted
- Max. rel. humidity: 95% as per IEC 60068-2-30

Operating altitude

Up to 4 000 m (13 123 ft) above sea level.


Climate class

- Head transmitter: climate class C1 as per EN 60654-1
- DIN rail transmitter: climate class B2 as per IEC 60654-1
- Head transmitter, field mount housing with separate terminal compartment including display: climate Class Dx as per IEC 60654-1

Degree of protection	■ Head transmitter with screw or push-in terminals: IP 20. In the installed state, it depends on the terminal head or field housing used. ■ When installed in field mount housing with separate terminal compartment: IP 67, NEMA Type 4x ■ DIN rail transmitter: IP 20
Vibration resistance	Vibration resistance as per DNVGL-CG-0339: 2015 and DIN EN 60068-2-27 ■ Head transmitter: 2 to 100 Hz at 4g (increased vibration stress) ■ DIN rail transmitter: 2 to 100 Hz at 0.7g (general vibration stress) Shock resistance as per KTA 3505 (section 5.8.4 Shock test)
Electromagnetic compatibility (EMC)	CE conformity Electromagnetic compatibility in accordance with all the relevant requirements of the IEC/EN 61326 series and NAMUR Recommendation EMC (NE 21). For details, refer to the Declaration of Conformity. All tests were passed both with and without ongoing digital HART communication. Maximum measurement error <1% of measuring range. Interference immunity as per IEC/EN 61326 series, industrial requirements Interference emission as per IEC/EN 61326 series, Class B equipment
Overvoltage category	Overvoltage category II
Pollution degree	Pollution degree 2
Protection class	Protection class III


13.6 Mechanical construction

Design and dimensions	Dimensions in mm (in) <i>Head transmitter</i> 17 Version with screw terminals A Spring travel $L \geq 5$ mm (not for US - M4 securing screws) B Mounting elements for attachable measured value display TID10 C Service interface for connecting measured value display or configuration tool
-----------------------	--



18 Version with push-in terminals. Dimensions are identical to the version with screw terminals, apart from housing height.

DIN rail transmitter





Field housing

All field housings have an internal geometry in accordance with DIN EN 50446, Form B (flat face). Cable glands in the diagrams: M20x1.5

Maximum ambient temperatures for cable glands	
Type	Temperature range
Polyamide cable gland ½" NPT, M20x1.5 (non-Ex)	–40 to +100 °C (–40 to 212 °F)
Polyamide cable gland M20x1.5 (for dust ignition-proof area)	–20 to +95 °C (–4 to 203 °F)
Brass cable gland ½" NPT, M20x1.5 (for dust ignition-proof area)	–20 to +130 °C (–4 to +266 °F)


TA30A	Specification
A0009820	- Two cable entries - Material: aluminum, polyester powder coated - Seals: silicone - Degree of protection: - IP66/68 (NEMA Type 4x encl.) - For ATEX: IP66/67 - Cable entry glands: NPT ½" and M20x1.5 - Head color: blue, RAL 5012 - Cap color: gray, RAL 7035 - Weight: 330 g (11.64 oz)


TA30A with display window in cover	Specification
	- Two cable entries - Material: aluminum, polyester powder coated - Seals: silicone - Protection degree: - IP66/68 (NEMA Type 4x encl.) - For ATEX: IP66/67 - Cable entry glands: NPT 1/2" and M20x1.5 - Head color: blue, RAL 5012 - Cap color: gray, RAL 7035 - Weight: 420 g (14.81 oz) - Display window: single-pane safety glass according to DIN 8902 - Display window in cover for head transmitter with TID10 display


TA30H	Specification
	- Flameproof (XP) version, explosion-protected, captive screw cap, with two cable entries - Degree of protection: IP 66/68, NEMA Type 4x Encl. Ex-version: IP 66/67 - Material: - Aluminum, with polyester powder coating - Stainless steel 316L without coating - Dry lubricant Klüber Syntheso Glep 1 - Cable entry glands: NPT 1/2", M20x1.5 - Color of aluminum head: blue, RAL 5012 - Color of aluminum cap: gray, RAL 7035 - Weight: - Aluminum approx. 640 g (22.6 oz) - Stainless steel approx. 2 400 g (84.7 oz) i When the housing cover is unscrewed: Before fastening, clean the threads in the cover and on the lower part of the housing and lubricate if necessary (recommended lubricant: Klüber Syntheso Glep 1).

TA30H with display window in cover	Specification
A0009831	■ Flameproof (XP) version, explosion-protected, captive screw cap, with two cable entries ■ Degree of protection: IP 66/68, NEMA Type 4x Encl. Ex-version: IP 66/67 ■ Material: ■ Aluminum with polyester powder coating ■ Stainless steel 316L without coating ■ Dry lubricant Klüber Syntheso Glep 1 ■ Display window: single-pane safety glass according to DIN 8902 ■ Cable entry glands: NPT ½", M20x1.5 ■ Color of aluminum head: blue, RAL 5012 ■ Color of aluminum cap: gray, RAL 7035 ■ Weight: ■ Aluminum approx. 860 g (30.33 oz) ■ Stainless steel approx. 2 900 g (102.3 oz) ■ For display TID10 i When the housing cover is unscrewed: Before fastening, clean the threads in the cover and on the lower part of the housing and lubricate if necessary (recommended lubricant: Klüber Syntheso Glep 1).

TA30H with three cable entries	Specification
A0055299	■ Flameproof (XP) version, explosion-protected, captive screw cap, with three cable entries (two at the front, one at the bottom) with grounding screw ■ Protection class: NEMA Type 4x Encl. ■ Material: ■ Aluminum, with polyester powder coating ■ Dry lubricant Klüber Syntheso Glep 1 ■ Cable entry glands: ½" NPT ■ Color of head: blue, RAL 5012 ■ Color of cap: gray, RAL 7035 ■ Weight: approx. 640 g (22.6 oz) i When the housing cover is unscrewed: Before screwing it on, clean the threads in the cover and on the lower part of the housing and lubricate if necessary (recommended lubricant: Klüber Syntheso Glep 1).

TA30H with three cable entries and display window in cover	Specification
 Technical drawing of the TA30H device. The front view shows a cylindrical head with a display window and three cable entry glands. Dimensions: total height 143.2 (5.64), head height 115.2 (4.54), head diameter 125 (4.92), mounting bracket height 20.5 (0.8), mounting bracket width 28 (1.1), and base width 78 (3.07). The side view shows the device profile with a height of 28 (1.1) for the mounting bracket. A bottom view shows the circular base with three cable entry glands and a central display window. The drawing is labeled A0055300.	■ Flameproof (XP) version, explosion-protected, captive screw cap, with three cable entries (two at the front, one at the bottom), with grounding screw ■ Protection class: NEMA Type 4x Encl. ■ Material: ■ Aluminum with polyester powder coating ■ Stainless steel 316L without coating ■ Dry lubricant Klüber Syntheso Glep 1 ■ Display window: single-pane safety glass according to DIN 8902 ■ Cable entry glands: ½" NPT ■ Color of aluminum head: blue, RAL 5012 ■ Color of aluminum cap: gray, RAL 7035 ■ Weight: ■ Aluminum approx. 860 g (30.33 oz) ■ Stainless steel approx. 2 900 g (102.3 oz) ■ For display TID10 i When the housing cover is unscrewed: Before screwing it on, clean the threads in the cover and on the lower part of the housing and lubricate if necessary (recommended lubricant: Klüber Syntheso Glep 1).

TA30D	Specification
 Technical drawing of the TA30D device. The front view shows a cylindrical head with two cable entry glands. Dimensions: total height 110 (4.3), head height 107.5 (4.23), mounting bracket height 15.5 (0.6), mounting bracket width 28 (1.1), and base width 78 (3.1). The side view shows the device profile with a height of 28 (1.1) for the mounting bracket. The drawing is labeled A0009822.	■ 2 cable entries ■ Material: aluminum, polyester powder coated ■ Seals: silicone ■ Degree of protection: ■ IP66/68 (NEMA Type 4x encl.) ■ For ATEX: IP66/67 ■ Cable entry glands: NPT ½" and M20x1.5 ■ Two head transmitters can be mounted. In the standard configuration one transmitter is mounted in the terminal head cover and an additional terminal block is installed directly on the insert. ■ Head color: blue, RAL 5012 ■ Cap color: gray, RAL 7035 ■ Weight: 390 g (13.75 oz)

Field mount housing with separate terminal compartment	Specification
 A0042357	■ Separate electronics compartment and terminal compartment ■ Display rotatable in 90° increments ■ Material: Die-cast aluminum housing AlSi10Mg with powder coating on polyester base ■ Cable entry: 2x ½" NPT, 2x M20x1.5 ■ Protection class: IP67, NEMA type 4x ■ Color: blue, RAL 5012 ■ Weight: approx. 1.4 kg (3 lb)

Weight	■ Head transmitter: Approx. 40 to 50 g (1.4 to 1.8 oz) ■ Field housing: See specifications ■ DIN rail transmitter: Approx. 100 g (3.53 oz)
--------	--

Materials	All the materials used are RoHS-compliant. ■ Housing: polycarbonate (PC) ■ Terminals: ■ Screw terminals: nickel-plated brass and gold-plated or tin-plated contacts ■ Push-in terminals: tin-plated brass, contact springs 1.4310, 301 (AISI) ■ Potting compound: ■ Head transmitter: QSIL 553 ■ DIN rail housing: Silgel612EH Field housing: see specifications
-----------	--

13.7 Certificates and Approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

1.

Select the product using the filters and search field.
2.

Open the product page.
3.

Select **Downloads**.

Functional safety	SIL 2/3 (hardware/software) certified to: ■ IEC 61508-1:2010 (Management) ■ IEC 61508-2:2010 (Hardware) ■ IEC 61508-3:2010 (Software)
-------------------	---

HART certification	The temperature transmitter is registered by the FieldComm Group. The device meets the requirements of the FieldComm Group HART Specifications, Revision 7.
--------------------	---

Test certificate	Complies with: ■ WELMEC 8.8, only in SIL mode: "Guide on the General and Administrative Aspects of the Voluntary System of Modular Evaluation of Measuring Instruments". ■ OIML R117-1 Edition 2007 (E) "Dynamic measuring systems for liquids other than water". ■ EN 12405-1/A2 Edition 2010 "Gas meters – Conversion devices – Part 1: Volume conversion". ■ OIML R140-1 Edition 2007 (E) "Measuring systems for gaseous fuel"
------------------	--

14 Operating menu and parameter description

 The following tables list all the parameters in the "Setup", "Diagnostics" and "Expert" operating menus. The page number refers to where a description of the parameter can be found.

Depending on the parameter configuration, not all submenus and parameters are available in every device. Information on this can be found in the parameter description under "Prerequisite". The parameter groups for the Expert setup contain all the parameters of the "Setup" and "Diagnostics" operating menus, as well as other parameters that are solely reserved for experts.

This symbol  indicates how to navigate to the parameter using operating tools (e.g. FieldCare).

 The configuration in the SIL mode is different from the configuration in the standard mode. For more detailed information, please refer to the Functional Safety Manual (FY01105T).

Setup →	Device tag	→  77
	Unit	→  78
	Sensor type 1	→  78
	Connection type 1	→  78
	2-wire compensation 1	→  79
	Reference junction 1	→  79
	RJ preset value 1	→  80
	Sensor type 2	→  78
	Connection type 2	→  78
	2-wire compensation 2	→  79
	Reference junction 2	→  79
	RJ preset value 2	→  80
	Assign current output (PV)	→  80
	Reset sensor backup	→  80
	Lower range value	→  81
	Upper range value	→  81

Setup →	Advanced setup →	Enter access code	→  82
		Access status tooling	→  83
		Locking status	→  84
		Device temperature alarm	→  84

Setup →	Advanced setup →	Sensors →	Sensor offset 1	→  84
			Sensor offset 2	→  84
			Corrosion detection	→  84
			Drift/difference mode	→  85
			Drift/difference status signal	→  85
			Drift/difference alarm delay	→  86
			Drift/difference set point	→  86
			Sensor switch set point	→  86

Setup →	Advanced setup→	Current output →	Output current	→  87
			Measuring mode	→  87
			Out of range category	→  88
			Failure mode	→  88
			Failure current	→  88
			Current trimming 4 mA	→  89
			Current trimming 20 mA	→  89

Setup →	Advanced setup→	Display→	Display interval	→  89
			Format display	→  90
			Value 1 display	→  90
			Decimal places 1	→  91
			Value 2 display	→  91
			Decimal places 2	→  92
			Value 3 display	→  92
			Decimal places 3	→  93

Setup →	Advanced setup→	SIL →	SIL option	→  93
			Operational state	→  93
			SIL checksum	→  93
			Timestamp SIL configuration	→  93
			Force safe state	→  93

Setup →	Advanced setup→	Administration →	Device reset	→  95
			Define device write protection code	→  95

Diagnostics →	Actual diagnostics			→  97
	Previous diagnostics 1			→  97
	Reset backup			→  97
	Operating time			→  97

Diagnostics →	Diagnostic list→	Actual diagnostics count	→  98
		Actual diagnostics n ¹⁾	→  97
		Actual diag channel	→  98

1) n = number of sensor inputs (1 and 2)

Diagnostics →	Event logbook →	Previous diagnostics n ¹⁾	→  99
		Previous diag channel n	→  99

1) n = number of sensor inputs (1 and 2)

Diagnostics →	Device information →	Device tag	→  77
		Serial number	→  100
		Firmware version	→  100
		Device name	→  100
		Order code	→  100
		Configuration counter	→  101

Diagnostics →	Measured values →	Sensor 1 value	→  101
		Sensor 2 value	→  101
		Device temperature	→  101

Diagnostics →	Measured values →	Min/max values →	Sensor n ¹⁾ min value	→  102
			Sensor n max value	→  102
			Reset sensor min/max values	→  102
			Device temperature min	→  102
			Device temperature max	→  103
			Reset device temperature min/max	→  103

1) n = number of sensor inputs (1 and 2)

Diagnostics →	Simulation →	Current output simulation	→  103
		Current output value	→  104

Expert →	Enter access code	→  82
	Access status tooling	→  83
	Locking status	→  84

Expert →	System →	Unit	→  78
		Damping	→  105
		Alarm delay	→  105
		Mains filter	→  105
		Device temperature alarm	→  106

Expert →	System →	Display→	Display interval	→  89
			Format display	→  90
			Value 1 display	→  90
			Decimal places 1	→  91
			Value 2 display	→  91
			Decimal places 2	→  92
			Value 3 display	→  92
			Decimal places 3	→  93

Expert →	System →	Administration →	Device reset	→  95
			Define device write protection code	→  95

Expert →	Sensors →	Sensor n ¹⁾ →	Sensor type n	→  78
			Connection type n	→  78
			2-wire compensation n	→  79
			Reference junction n	→  79
			RJ preset value	→  80
			Sensor offset n	→  84
			Sensor n lower limit	→  106
			Sensor n upper limit	→  106
			Sensor n serial number	→  106

1) n = number of sensor inputs (1 and 2)

Expert →	Sensors →	Sensor n ¹⁾ →	Sensor trimming→	Sensor trimming	→  107
				Sensor trimming lower value	→  107
				Sensor trimming upper value	→  108
				Sensor trimming min span	→  108

1) n = number of sensor inputs (1 and 2)

Expert →	Sensors →	Sensor n ¹⁾ →	Linearization →	Sensor n lower limit	→  106
				Sensor n upper limit	→  106
				Call./v. Dusen coeff. R0, A, B, C	→  109
				Polynomial coeff. R0, A, B	→  110

1) n = number of sensor inputs (1 and 2)

Expert →	Sensors →	Diagnostic settings →	Corrosion detection	→  84
			Drift/difference mode	→  85
			Drift/difference alarm category	→  85
			Drift/difference alarm delay	→  86
			Drift/difference set point	→  86
			Sensor switch set point	→  86
			Calibration counter start	→  110
			Calibration alarm category	→  111
			Calibration counter start value	→  111
			Count value	→  111

Expert →	Output →	Output current	→  87
		Percent of range	→  112
		Measuring mode	→  112

	Lower range value	→  81
	Upper range value	→  81
	Out of range category	→  88
	Failure mode	→  88
	Failure current	→  88
	Current trimming 4 mA	→  89
	Current trimming 20 mA	→  89

Expert →	Communication →	HART configuration →	Device tag	→  112
			HART short tag	→  112
			HART address	→  113
			No. of preambles	→  113
			Configuration changed	→  113
			Reset configuration changed flag	→  113

Expert →	Communication →	HART info →	Device type	→  113
			Device revision	→  114
			Device ID	→  114
			Manufacturer ID	→  114
			HART revision	→  114
			HART descriptor	→  115
			HART message	→  115
			Hardware revision	→  122
			Software revision	→  115
			HART date code	→  115

Expert →	Communication →	HART output →	Assign current output (PV)	→  80
			PV	→  116
			Reset sensor backup	→  116
			Assign SV	→  117
			SV	→  117
			Assign TV	→  117
			TV	→  117
			Assign QV	→  117
			QV	→  118

Expert →	Communication →	Burst configuration 1-3 →	Burst mode	→  118
			Burst command	→  118
			Burst variables 0-3	→  119
			Burst trigger mode	→  120
			Burst trigger level	→  120
			Min. update period	→  120
			Max. update period	→  121

Expert →	Diagnostics →	Actual diagnostics	→ ⓘ 97
		Previous diagnostics 1	→ ⓘ 97
		Reset backup	→ ⓘ 97
		Operating time	→ ⓘ 97

Expert →	Diagnostics →	Diagnostic list →	Actual diagnostics count	→ ⓘ 98
			Actual diagnostics	→ ⓘ 97
			Actual diag channel	→ ⓘ 98

Expert →	Diagnostics →	Event logbook →	Previous diagnostics n ¹⁾	→ ⓘ 99
			Previous diag channel	→ ⓘ 99

1) n = number of sensor inputs (1 and 2)

Expert →	Diagnostics →	Device information →	Device tag	→ ⓘ 77
			Serial number	→ ⓘ 100
			Firmware version	→ ⓘ 100
			Device name	→ ⓘ 100
			Order code	→ ⓘ 100
			Extended order code	→ ⓘ 121
			Extended order code 2	→ ⓘ 121
			Extended order code 3	→ ⓘ 121
			ENP version	→ ⓘ 122
			Device revision	→ ⓘ 114
			Manufacturer ID	→ ⓘ 122
			Manufacturer	→ ⓘ 122
			Hardware revision	→ ⓘ 122
			Configuration counter	→ ⓘ 101

Expert →	Diagnostics →	Measured values →	Value sensor n ¹⁾	→ ⓘ 101
			Sensor n raw value	→ ⓘ 123
			Device temperature	→ ⓘ 101

1) n = number of sensor inputs (1 and 2)

Expert →	Diagnostics →	Measured values →	Min/max values →	Sensor n ¹⁾ min value	→ ⓘ 102
				Sensor n max value	→ ⓘ 102
				Reset sensor min/max values	→ ⓘ 102
				Device temperature min	→ ⓘ 102
				Device temperature max	→ ⓘ 103
				Reset device temperature min/max	→ ⓘ 103

1) n = number of sensor inputs (1 and 2)

Expert →	Diagnostics →	Simulation →	Current output simulation	→ 103
			Current output value	→ 104

14.1 "Setup" menu

This menu contains all the parameters that are needed to configure the basic settings of the device. The transmitter can be put into operation with this limited parameter set.

 n = Stands for the number of sensor inputs (1 and 2)

Backup function

If the **Sensor 1 (backup sensor 2)** option or **Average: 0.5 x (SV1+SV2) with backup** is selected in the **Assign current output (PV) parameter**, the corresponding backup function is active.

If **Sensor 1 (backup sensor 2)** is selected, the transmitter automatically switches to sensor 2 as the primary measured value in the event of a failure of sensor 1. The measured value of sensor 2 is used as the PV. The 4 to 20 mA signal is not interrupted. The status for the faulty sensor is output via HART. If a display is connected, a diagnostic message is displayed on it.

If **Average: 0.5 x (SV1+SV2) with backup** is selected, 3 scenarios can occur:

- If sensor 1 fails, the average value corresponds to the measured value of sensor 2, the 4 to 20 mA signal is not interrupted and a diagnosis is output via HART.
- If sensor 2 fails, the average value corresponds to the measured value of sensor 1, the 4 to 20 mA signal is not interrupted and a diagnosis is output via HART.
- If both sensors fail simultaneously, the transmitter follows the configured failure mode and a diagnosis is output via HART.

The **Reset sensor backup** parameter defines how the transmitter acts after the sensor error has been rectified.

Reset sensor backup parameter	Assign current output (PV) parameter	
	Sensor 1 (backup sensor 2) option	Average: 0.5 x (SV1+SV2) with backup option
Option: Automatic	The transmitter automatically switches back to sensor 1 after rectifying the sensor error and sensor 1 is used as the PV.	The transmitter automatically switches back to the average value after rectifying the sensor error and this value is used as the PV.
Option: Manual	After the sensor 1 error has been rectified, the transmitter only switches back to normal operation after manual confirmation via the Reset backup in the Diagnostics menu and sensor 1 is used as the PV. The return to normal operation can also take place by switching the transmitter off and on. Until confirmation, sensor 2 is used as the PV and a diagnosis is output via HART.	After the sensor error has been rectified, the transmitter only switches back to normal operation after manual confirmation via the Reset backup button in the Diagnostics menu and the average value is used as the PV. The return to normal operation can also take place by switching the transmitter off and on. Until confirmation, sensor 1 or sensor 2 is used as the PV depending on the scenario and a diagnosis is output via HART.

Device tag

Navigation

 Setup → Device tag
Diagnostics → Device information → Device tag
Expert → Diagnostics → Device information → Device tag

Description

Use this function to enter a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header of the plug-in display.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

EH_TMT82_serial number

Unit	
Navigation	 Setup → Unit Expert → System → Unit
Description	Selection of the unit for all measured values.
Options	■ °C ■ °F ■ K ■ °R ■ Ohm ■ mV
Factory setting	°C

Sensor type n	
Navigation	 Setup → Sensor type n Expert → Sensors → Sensor n → Sensor type n
Description	Use this function to select the sensor type for the sensor input in question ■ Sensor type 1: settings for sensor input 1 ■ Sensor type 2: settings for sensor input 2  Please observe the terminal assignment when connecting the individual sensors. In the case of 2-channel operation, the possible connection options must also be observed.  Note for the version field mount housing with separate terminal compartment: If a thermocouple (TC) is selected as sensor type, it is only possible to select it for sensor 1. The reference junction will be measured on the second channel (sensor 2). In this case do not change the setup of the reference junction as well as for the second channel
Options	A list of all the possible sensor types is provided in the "Technical data" section. →  51
Factory setting	Sensor type 1: Pt100 IEC751 Sensor type 2: No sensor

Connection type n	
Navigation	 Setup → Connection type n Expert → Sensors → Sensor n → Connection type n
Prerequisite	An RTD sensor must be specified as the sensor type.
Description	Use this function to select the connection type for the sensor.

Options	■ Sensor 1 (connection type 1): 2-wire, 3-wire, 4-wire ■ Sensor 2 (connection type 2): 2-wire, 3-wire
Factory setting	■ Sensor 1 (connection type 1): 4-wire ■ Sensor 2 (connection type 2): 2-wire

2-wire compensation n

Navigation	 Setup → 2-wire compensation n Expert → Sensors → Sensor n → 2-wire compensation n
Prerequisite	An RTD sensor with a 2-wire connection type must be specified as the sensor type.
Description	Use this function to specify the resistance value for two-wire compensation in RTDs.
User entry	0 to 30 Ohm
Factory setting	0

Reference junction n

Navigation	 Setup → Reference junction n Expert → Sensors → Sensor n → Reference junction n
Prerequisite	A thermocouple (TC) sensor must be selected as the sensor type.
Description	Use this function to select reference junction measurement for temperature compensation of thermocouples (TC).  ■ If Fixed Value is selected, the compensation value is specified via the RJ preset value parameter. ■ Temperature measured must be configured for channel 2 if Measured value sensor 2 is selected
Options	■ No compensation: no temperature compensation is used. ■ Internal measurement: the internal reference junction temperature is used. ■ Preset value: a fixed preset value is used. ■ Measured value sensor 2: the measured value of sensor 2 is used.  It is not possible to select the Measured value sensor 2 option for the Reference junction 2 parameter.  Note for the version field mount housing with separate terminal compartment: If a thermocouple (TC) is selected as sensor type, it is only possible to select it for sensor 1. The reference junction will be measured on the second channel (sensor 2). In this case do not change the setup of the reference junction as well as for the second channel.
Factory setting	Internal measurement

RJ preset value n

Navigation	 Setup → RJ preset value Expert → Sensors → Sensor n → RJ preset value
Prerequisite	The Preset value parameter must be set if the Reference junction n option is selected.
Description	The Fixed value parameter must be set if the Reference junction n option is selected.
User entry	–50 to +85 °C
Factory setting	0.00

Assign current output (PV)

Navigation	 Setup → Assign current output (PV) Expert → Communication → HART output → Assign current output (PV)
Description	Use this function to assign a measured variable to the primary HART value (PV).
Options	■ Sensor 1 (measured value) ■ Sensor 2 (measured value) ■ Device temperature ■ Average of the two measured values: $0.5 \times (SV1+SV2)$ ■ Difference between sensor 1 and sensor 2: $SV1-SV2$ ■ Sensor 1 (backup sensor 2): If sensor 1 fails, the value of sensor 2 automatically becomes the primary HART value (PV): sensor 1 (OR sensor 2) ■ Sensor switching: If the value exceeds the configured threshold value T for sensor 1, the measured value of sensor 2 becomes the primary HART value (PV). The system switches back to sensor 1 if the measured value of sensor 1 is at least 2 K below T: sensor 1 (sensor 2, if sensor 1 > T) ■ Average: $0.5 \times (SV1+SV2)$ with backup (measured value of sensor 1 or sensor 2 in the event of a sensor error in the other sensor)  The threshold value can be configured using the Sensor switch set point parameter. With temperature-dependent switching, it is possible to combine 2 sensors that offer advantages in different temperature ranges.
Factory setting	Sensor 1

Reset sensor backup¹⁾

1) The parameter is not visible in the SIMATIC PDM operating tool.

Navigation	 Setup → Reset sensor backup Expert → Communication → HART output → Reset sensor backup
-------------------	---

Prerequisite	In the Assign current output (PV) parameter, the option Sensor 1 (Backup sensor 2) or 0.5 x (SV1+SV2) with backup must be configured.
Description	Use this function to select the method by which the device is reset from the sensor backup function to normal measuring mode.  If Automatic is selected: The device is automatically reset to normal measuring mode after all sensor errors on sensor 1 are rectified. If Manual is selected: The device is manually reset to normal measuring mode after all sensor errors on sensor 1 are rectified. Manual acknowledgment is carried out via the Reset backup parameter in the Diagnostics menu.
Options	■ Automatic ■ Manual
Factory setting	Automatic

Lower range value

Navigation	 Setup → Lower range value Expert → Output → Lower range value
Description	Use this function to assign a measured value to the current value 4 mA.  The limit value that can be set depends on the sensor type used in the Sensor type parameter and the measured variable assigned in the Assign current output (PV) parameter.
User entry	Depends on the sensor type and the setting for "Assign current output (PV)".
Factory setting	0

Upper range value

Navigation	 Setup → Upper range value Expert → Output → Upper range value
Description	Use this function to assign a measured value to the current value 20 mA.  The limit value that can be set depends on the sensor type used in the Sensor type parameter and the measured variable assigned in the Assign current output (PV) parameter.
User entry	Depends on the sensor type and the setting for "Assign current output (PV)".
Factory setting	100

14.1.1 "Advanced setup" submenu

Corrosion monitoring


Sensor connection cable corrosion can lead to false measured value readings. Therefore the unit offers the possibility of recognizing any corrosion before a measured value is affected. Corrosion monitoring is only possible for RTDs with a 4-wire connection and thermocouples.

Drift/difference mode

If two sensors are connected and the measured values differ by a specified value, a status signal is generated as a diagnostic event. The drift/difference monitoring function can be used to verify the correctness of the measured values and for mutual monitoring of the connected sensors. Drift/difference monitoring is enabled with the **Drift/difference mode** parameter. A distinction is made between two specific modes. If the **In band** option is selected ($ISV1-SV2I < \text{drift/difference set point}$), a diagnostic message is issued if the value drops below the set point, or if the value exceeds the set point if the **Out band (drift)** option is selected ($ISV1-SV2I > \text{drift/difference set point}$).

Procedure for configuring the drift/difference mode

1. Start
↓
2. For drift/difference monitoring, select Out band for drift detection and In band for difference monitoring.
↓
3. Set the alarm category for drift/difference monitoring to Out of specification (S) , Maintenance required (M) or Failure (F) as required.
↓
4. Set the limit value for drift/difference monitoring to the desired value.
↓
5. End



19 Drift/difference mode

A Value under range
B Value over range
D Drift
L+, Upper (+) or lower (-) limit value
L-
t Time
x Diagnostic event, status signal is generated

Enter access code

Navigation

Setup → Advanced setup → Enter access code
Expert → Enter access code

Description	Use this function to enable the service parameters via the operating tool. If an incorrect access code is entered, users retain their current access authorization.  If a value is entered that is not equal to the access code, the parameter is automatically set to 0. The service parameters should only be modified by the service organization.
Additional information	Software device write protection is also switched on and off with this parameter. NOTICE The device is not in the SIL mode. - Do not enter access code 7452 under any circumstances. This code is specifically intended for SIL mode activation only. Software device write protection in conjunction with download from an operating tool with offline capabilities - Download, the device does not have a defined write protection code: The download is performed as normal. - Download, defined write protection code, device is not locked. - The Enter access code parameter (offline) contains the correct write protection code: the download is carried out, and the device is not locked following the download. The write protection code in the Enter access code parameter is set to 0. - The Enter access code parameter (offline) does not contain the correct write protection code: the download is carried out, and the device is locked following the download. The write protection code in the Enter access code parameter is reset to 0. - Download, defined write protection code, device is locked. - The Enter access code parameter (offline) contains the correct write protection code: the download is carried out, and the device is locked following the download. The write protection code in the Enter access code parameter is reset to 0. - The Enter access code parameter (offline) does not contain the correct write protection code: the download is not carried out. No values are changed in the device. The value of the Enter access code parameter (offline) also remains unchanged.
User entry	0 to 9 999
Factory setting	0

Access status tooling

Navigation	 Setup → Advanced setup → Access status tooling Expert → Access status tooling
Description	Use this function to show access authorization to the parameters.
Additional information	If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter .
Options	- Operator - Service
Factory setting	Operator

Locking status

Navigation	 Setup → Advanced setup → Locking status Expert → Locking status
Description	Use this function to view the device locking status. The DIP switch for hardware locking is fitted on the display module. When write protection is activated, write access to the parameters is disabled.

Device temperature alarm

Navigation	 Setup → Advanced setup → Device temperature alarm
Description	Use this function to select the category (status signal) as to how the device reacts when the electronics temperature of the transmitter exceeds or falls below the limit value < -40 °C (-40 °F) or > +85 °C (+185 °F).
Options	■ Off ■ Out of specification (S) ■ Failure (F)
Factory setting	Out of specification (S)

"Sensors" submenu

Sensor offset n

 n = Stands for the number of sensor inputs (1 and 2)

Navigation	 Setup → Advanced setup → Sensors → Sensor offset n Expert → Sensors → Sensor n → Sensor offset n
Description	Use this function to set the zero point correction (offset) of the sensor measured value. The value indicated is added to the measured value.
User entry	-10.0 to +10,0
Factory setting	0.0

Corrosion detection

Navigation	 Setup → Advanced setup → Sensors → Corrosion detection Expert → Sensors → Diagnostic settings → Corrosion detection
-------------------	--

Description	Use this function to select the category (status signal) which is displayed when corrosion is detected in the sensor connection cables.  Only possible for RTD sensors with 4-wire connection and thermocouples (TC).
Options	■ Maintenance required (M) ■ Failure (F)
Factory setting	Maintenance required (M)

Drift/difference mode

Navigation	 Setup → Advanced setup → Sensors → Drift/difference mode Expert → Sensors → Diagnostic settings → Drift/difference mode
Description	Use this function to choose whether the device reacts to the value exceeding or dropping below the drift/difference set point.  Can only be selected for 2-channel operation.
Additional information	■ If the Out band (drift) option is selected, a status signal is displayed if the absolute value for the differential value exceeds the drift/difference set point ■ If the In band option is selected, a status signal is displayed if the absolute value for the differential value drops below the drift/difference set point.
Options	■ Off ■ Out band (drift) ■ In band
Factory setting	Off

Drift/difference alarm category

Navigation	 Setup → Advanced setup → Sensors → Drift/difference alarm category Expert → Sensors → Diagnostic settings → Drift/difference alarm category
Prerequisite	The Drift/difference mode parameter must be enabled with the Out band (drift) or In band option.
Description	Use this function to select the alarm category (status signal) as to how the device reacts when a drift/difference is detected between sensor 1 and sensor 2.
Options	■ Out of specification (S) ■ Maintenance required (M) ■ Failure (F)
Factory setting	Maintenance required (M)

Drift/difference alarm delay

Navigation	 Setup → Advanced setup → Sensors → Drift/difference alarm delay Expert → Sensors → Diagnostic settings → Drift/difference alarm delay
Prerequisite	The Drift/difference mode parameter must be enabled with the Out band (drift) or In band option. →  85
Description	Alarm delay for drift detection monitoring.  Useful for example in the event of different thermal mass ratings for the sensors in conjunction with a high temperature gradient in the process.
User entry	0 to 255 s
Factory setting	0 s

Drift/difference set point

Navigation	 Setup → Advanced setup → Sensors → Drift/difference set point Expert → Sensors → Diagnostic settings → Drift/difference set point
Prerequisite	The Drift/difference mode parameter must be enabled with the Out band (drift) or In band option.
Description	Use this function to configure the maximum permissible measured value deviation between sensor 1 and sensor 2 which results in drift/difference detection.
Options	0.1 to 999.0 K (0.18 to 1 798.2 °F)
Factory setting	999.0

Sensor switch set point

Navigation	 Setup → Advanced setup → Sensors → Sensor switch set point Expert → Sensors → Diagnostic settings → Sensor switch set point
Description	Use this function to set the threshold value for sensor switching .
Additional information	The threshold value is relevant if the sensor switching function is assigned to a HART variable (PV, SV, TV, QV).
Options	Depends on the sensor types selected.
Factory setting	850 °C

"Current output" submenu

Adjustment of the analog output (4 and 20 mA current trimming)

Current trimming is used to compensate the analog output (D/A conversion). Here, the output current of the transmitter can be adapted so that it suits the value expected at the higher-level system.

NOTICE

Current trimming does not affect the digital HART value. This can cause the measured value shown on the plug-in display to differ from the value displayed in the higher-order system.

- The digital measured values can be adapted with the sensor trimming parameter in the menu Expert → Sensors → Sensor trimming.

Procedure

1. Start
↓
2. Install an accurate ammeter (more accurate than the transmitter) in the current loop.
↓
3. Switch on current output simulation and set the simulation value to 4 mA.
↓
4. Measure the loop current with the ammeter and make a note of the value.
↓
5. Set the simulation value to 20 mA.
↓
6. Measure the loop current with the ammeter and make a note of the value.
↓
7. Enter the current values determined as adjustment values in the Current trimming 4 mA/20 mA parameters
↓
8. End

Output current

Navigation	 Setup → Advanced setup → Current output → Output current Expert → Output → Output current
Description	Use this function to view the calculated output current in mA.

Measuring mode

Navigation	 Setup → Advanced setup → Current output → Measuring mode Expert → Output → Measuring mode
Description	Enables the inversion of the output signal.

Additional information	■ Standard The output current increases with increasing temperatures ■ inverted The output current decreases with increasing temperatures
Options	■ Standard ■ inverted
Factory setting	Standard

Out of range category

Navigation	 Setup → Advanced setup → Current output → Out of range category Expert → Output → Out of range category
Description	Use this function to select the category (status signal) as to how the device reacts when the value is outside the set measuring range.
Options	■ Out of specification (S) ■ Maintenance required (M) ■ Failure (F)
Factory setting	Maintenance required (M)

Failure mode

Navigation	 Setup → Advanced setup → Current output → Failure mode Expert → Output → Failure mode
Description	Use this function to select the signal on alarm level of the current output in the event of an error.
Additional information	If Max. is selected, the signal on alarm level is specified using the Failure current parameter.
Options	■ Min. ■ Max.
Factory setting	Max.

Failure current

Navigation	 Setup → Advanced setup → Current output → Failure current Expert → Output → Failure current
Prerequisite	The Max. option is enabled in the Failure mode parameter.

Description	Use this function to set the value the current output adopts in an alarm condition.
User entry	21.5 to 23.0 mA
Factory setting	22.5

Current trimming 4 mA

Navigation	 Setup → Advanced setup → Current output → Current trimming 4 mA Expert → Output → Current trimming 4 mA
Description	Use this function to set the correction value for the current output at the lower range limit at 4 mA .
User entry	3.85 to 4.15 mA
Factory setting	4 mA

Current trimming 20 mA

Navigation	 Setup → Advanced setup → Current output → Current trimming 20 mA Expert → Output → Current trimming 20 mA
Description	Use this function to set the correction value for the current output at the upper range limit at 20 mA .
User entry	19.850 to 20.15 mA
Factory setting	20.000 mA

"Display" submenu

The settings for displaying the measured value on the optional plug-in display (only for head transmitter) are made in the "Display" menu.



These settings do not affect the output values of the transmitter, and are only used to specify the display format on the screen.


Display interval

Navigation	 Setup → Advanced setup → Display → Display interval Expert → System → Display → Display interval
-------------------	---

Description	Use this function to set the display time of the measured values on the local display if the values are displayed in alternation. The display only alternates between values if more than one measured value is defined. i ▪ The Value 1 display - Value 3 display parameters are used to specify which measured values are shown on the display → 90. ▪ The display format of the displayed measured values is specified using the Format display parameter.
User entry	4 to 20 s
Factory setting	4 s


Format display

Navigation	Setup → Advanced setup → Display → Format display Expert → System → Display → Format display
Description	Use this function to select how the measured value is shown on the local display. The display format Measured value or Measured value with bar graph can be configured.
Options	▪ Value ▪ Value + Bargraph
Factory setting	Value
Additional information	<i>Value</i>



A0014564

Value + Bargraph



A0014563

Value 1 display

Navigation	 Setup → Advanced setup → Display → Value 1 display Expert → System → Display → Value 1 display
Description	Use this function to select one of the measured values to be shown on the local display.  The Format display parameter is used to specify how the measured values are displayed →  90.
Options	■ Process value ■ Sensor 1 ■ Sensor 2 ■ Output current ■ Percent of range ■ Device temperature
Factory setting	Process value

Decimal places 1

Navigation	 Setup → Advanced setup → Display → Decimal places 1 Expert → System → Display → Decimal places 1
Prerequisite	A measured value is specified in the Value 1 display parameter →  90.
Description	Use this function to select the number of decimal places for the display value. This setting does not affect the accuracy of the device for measuring or calculating the value.  If Automatic is selected, the maximum possible number of decimal places is always shown on the display.
Options	■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ Automatic
Factory setting	Automatic

Value 2 display

Navigation	 Setup → Advanced setup → Display → Value 2 display Expert → System → Display → Value 2 display
Description	Use this function to select one of the measured values to be shown on the local display.  The Format display parameter is used to specify how the measured values are displayed.

Options	■ Off ■ Process value ■ Sensor 1 ■ Sensor 2 ■ Output current ■ Percent of range ■ Device temperature
----------------	--

Factory setting	Off
------------------------	-----

Decimal places 2

Navigation	 Setup → Advanced setup → Display → Decimal places 2 Expert → System → Display → Decimal places 2
-------------------	---

Prerequisite	A measured value is specified in the Value 2 display parameter.
---------------------	--

Description	Use this function to select the number of decimal places for the display value. This setting does not affect the accuracy of the device for measuring or calculating the value.
--------------------	---



If **Automatic** is selected, the maximum possible number of decimal places is always shown on the display.

Options	■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ Automatic
----------------	--

Factory setting	Automatic
------------------------	-----------

Value 3 display

Navigation	 Setup → Advanced setup → Display → Value 3 display Expert → System → Display → Value 3 display
-------------------	---

Description	Use this function to select one of the measured values to be shown on the local display.
--------------------	--



The **Format display** parameter is used to specify how the measured values are displayed.

Options	■ Off ■ Process value ■ Sensor 1 ■ Sensor 2 ■ Output current ■ Percent of range ■ Device temperature
----------------	--

Factory setting	Off
------------------------	-----

Decimal places 3

Navigation	 Setup → Advanced setup → Display → Decimal places 3 Expert → System → Display → Decimal places 3
Prerequisite	A measured value is specified in the Value 3 display parameter.
Description	Use this function to select the number of decimal places for the display value. This setting does not affect the accuracy of the device for measuring or calculating the value.  If Automatic is selected, the maximum possible number of decimal places is always shown on the display.
Options	■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ Automatic
Factory setting	Automatic
	"SIL" submenu  This menu only appears if the device was ordered with the 'SIL mode' option. The SIL option parameter indicates whether the device can be operated in the SIL mode. To enable the SIL mode for the device, menu-guided operation for Enable SIL must be performed.  A detailed description is provided in the Functional Safety Manual FY01105T.

SIL option

Navigation	 Setup → Advanced setup → SIL → SIL option
Description	Use this function to display whether the device has been ordered with SIL certification. SIL certificate of the device  The SIL option is required to operate the device in the SIL mode.
Options	■ No ■ Yes
Factory setting	No

Operational state

Navigation	 Setup → Advanced setup → SIL → Operational state
-------------------	--

Description Use this function to display the device operational state in the SIL mode.

Display

- Checking SIL option
- Startup normal mode
- Self diagnostic
- Normal mode
- Download active
- SIL mode active
- Safe para start
- Safe param running
- Save parameter values
- Parameter check
- Reboot pending
- Reset checksum
- Safe state - Active
- Download verification
- Upload active
- Safe state - Passive
- Safe state - temporary

Factory setting Checking SIL option

SIL checksum

Navigation  Setup → Advanced setup → SIL → SIL checksum

Description Use this function to display the SIL checksum entered



The **SIL checksum** displayed can be used to check the device configuration. If 2 devices have identical configurations, the SIL checksum is also identical. This can make for easy device replacement because if the checksum is the same, the device configuration is guaranteed to be identical too.

Timestamp SIL configuration

Navigation  Setup → Advanced setup → SIL → Timestamp SIL configuration

Description Use this function to enter the date and time when SIL configuration has been completed and the SIL checksum has been calculated.



The date and time must be entered manually. This information is not generated automatically by the device.

User entry DD.MM.YYYY hh:mm

Factory setting 0

Force safe state

Navigation	 Setup → Advanced setup → SIL → Force safe state
Prerequisite	The Operational state parameter displays SIL mode active .
Description	This parameter is used to test error detection and the safe state of the device.
Options	■ On ■ Off
Factory setting	Off

“Administration” submenu

Device reset

Navigation	 Setup → Advanced setup → Administration → Device reset Expert → System → Device reset
Description	Use this function to reset the device configuration - either entirely or in part - to a defined state.
Options	■ Not active No action is executed and the user exits the parameter. ■ To factory defaults All the parameters are reset to the factory setting. ■ To delivery settings All the parameters are reset to the order configuration. The order configuration can differ from the factory setting if customer-specific parameter values were defined when the device was ordered. ■ Restart device The device is restarted but the device configuration remains unchanged.
Factory setting	Not active

Define device write protection code

Navigation	 Setup → Advanced setup → Administration → Define device write protection code Expert → System → Define device write protection code
Description	Use this function to set a write protection code for the device. NOTICE The device is not in the SIL mode. ▶ Do not under any circumstances use the SIL access code 7452 as the write protection code. This code is specifically intended for SIL mode activation only.  If the code is programmed into the device firmware, it is saved in the device and the operating tool displays the value 0 so that the defined write protection code is not openly displayed for viewing.

User entry 0 to 9 999

Factory setting 0



If the device is delivered with this factory setting, the device write protection is not active.

Additional information

- Activating device write protection: To do so, enter a value in the **Enter access code** parameter that does not correspond to the write protection code defined here.
- Deactivating device write protection: If device write protection is activated, enter the defined write protection code in the **Enter access code** parameter.
- Once the device has been reset to the factory setting or the order configuration, the defined write protection code is no longer valid. The code adopts the factory setting (= 0).
- Hardware write protection (DIP switches) is active:
 - Hardware write protection has priority over the software write protection described here.
 - No value can be entered in the **Enter access code** parameter. The parameter is a read only parameter.
 - Device write protection via software can only be defined and enabled if hardware write protection via the DIP switches is disabled.



If the write protection code is forgotten, it can be deleted or overwritten by the service organization.

14.2 "Diagnostics" menu

All the information that describes the device, the device status and the process conditions can be found in this group.

Actual diagnostics 1

Navigation	 Diagnostics → Actual diagnostics 1 Expert → Diagnostics → Actual diagnostics 1
Description	Use this function to display the current diagnostics message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
Display	Symbol for event behavior and diagnostic event.
Additional information	Example for display format: F261-Electronics modules

Previous diagnostics 1

Navigation	 Diagnostics → Previous diagnostics 1 Expert → Diagnostics → Previous diagnostics 1
Description	Use this function to display the last diagnostic message with the highest priority.
Display	Symbol for event behavior and diagnostic event.
Additional information	Example for display format: F261-Electronics modules

Reset backup ¹⁾

1) The 'Reset backup' button is not visible in the SIMATIC PDM operating tool.

Navigation	 Diagnostics → Reset backup Expert → Diagnostics → Reset backup
Prerequisite	Sensor 1 (backup sensor 2) or 0.5 x (SV1+SV2) with backup must be set in the Assign current output (PV) parameter. The Manual option must be set in the Reset sensor backup parameter.
Description	Click the button to reset the device manually from backup mode to the normal measuring mode.

Operating time

Navigation	 Diagnostics → Operating time Expert → Diagnostics → Operating time
Description	Use this function to display the length of time the device has been in operation up to now.
Display	Hours (h)

14.2.1 "Diagnostic list" submenu

Up to 3 diagnostic messages currently pending are displayed in this submenu. If more than 3 messages are pending, the messages with the highest priority are shown on the display. Information on diagnostics measures in the device and an overview of all the diagnostics messages →  40.

Actual diagnostics count

Navigation	 Diagnostics → Diagnostic list → Actual diagnostics count Expert → Diagnostics → Diagnostic list → Actual diagnostics count
Description	Use this function to display the number of status messages currently pending in the device.

Actual diagnostics 1-3

Navigation	 Diagnostics → Diagnostic list → Actual diagnostics 1-3 Expert → Diagnostics → Diagnostic list → Actual diagnostics 1-3
Description	Use this function to display the current diagnostic message with the highest priority to the third-highest priority.
Display	Symbol for event behavior and diagnostic event.
Additional information	Example for display format: F261-Electronics modules

Actual diagnostics 1-3 channel

Navigation	 Diagnostics → Diagnostic list → Actual diag 1-3 channel Expert → Diagnostics → Diagnostic list → Actual diagnostics 1-3 channel
Description	Use this function to display the sensor input to which the diagnostics message refers.
Display	■ - - - - - ■ Sensor 1 ■ Sensor 2

14.2.2 "Event logbook" submenu

Previous diagnostics n



n = Number of diagnostics messages (n = 1 to 5)

Navigation



Diagnostics → Diagnostic list → Previous diagnostics n
Expert → Diagnostics → Diagnostic list → Previous diagnostics n

Description

Use this function to display the diagnostic messages that occurred in the past. The last 5 messages are listed in chronological order.

Display

Symbol for event behavior and diagnostic event.

Additional information

Example for display format:
F261-Electronics modules

Previous diag n channel

Navigation



Diagnostics → Diagnostic list → Previous diag channel
Expert → Diagnostics → Diagnostic list → Previous diag channel

Description

Use this function to display the possible sensor input to which the diagnostics message refers.

Display

■ - - - - -
■ Sensor 1
■ Sensor 2

14.2.3 "Device information" submenu

Device tag

Navigation



Setup → Device tag
Diagnostics → Device information → Device tag
Expert → Diagnostics → Device information → Device tag

Description

Use this function to enter a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header of the attachable display.
→ 30

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

32 x '?'

Serial number

Navigation

Diagnostics → Device information → Serial number
Expert → Diagnostics → Device information → Serial number

Description

Use this function to display the serial number of the device. It can also be found on the nameplate.

**Uses of the serial number**

- To identify the measuring instrument quickly, e.g. when contacting Endress +Hauser.
- To obtain specific information on the measuring instrument using the Device Viewer: www.endress.com/deviceviewer

Display

Max. 11-digit character string comprising letters and numbers

Firmware version

Navigation

Diagnostics → Device information → Firmware version
Expert → Diagnostics → Device information → Firmware version

Description

Use this function to view the installed device firmware version.

Display

Max. 6-digit character string in the format xx.yy.zz

Device name

Navigation

Diagnostics → Device information → Device name
Expert → Diagnostics → Device information → Device name

Description

Use this function to display the device name. It can also be found on the nameplate.

Order code

Navigation

Diagnostics → Device information → Order code
Expert → Diagnostics → Device information → Order code

Description

Use this function to display the order code of the device. It can also be found on the nameplate. The order code is generated by a reversible transformation from the extended order code, which defines all the device features of the product structure. In contrast, the device features cannot be read directly from the order code.

**Uses of the order code**

- To order an identical replacement device.
- To identify the measuring instrument quickly and easily, e.g. when contacting the manufacturer.

Configuration counter

Navigation

Diagnostics → Device information → Configuration counter
 Expert → Diagnostics → Device information → Configuration counter

Description

Use this function to display the counter reading for changes to device parameters.



Static parameters, whose values change during optimization or configuration, cause this parameter to increase by 1. This supports parameter version management. If several parameters change, e.g. as a result of loading parameters from FieldCare etc. to the device, the counter can show a higher value. The counter cannot be reset and is also not reset to the default value when the device is reset. If the counter overflows, (16 bit), it starts again at 1.

14.2.4 "Measured values" submenu

Sensor n value



n = Stands for the number of sensor inputs (1 and 2)

Navigation

Diagnostics → Measured values → Sensor n value
 Expert → Diagnostics → Measured values → Sensor n value

Description

Use this function to display the current measured value at the sensor input.

Device temperature

Navigation

Diagnostics → Measured values → Device temperature
 Expert → Diagnostics → Measured values → Device temperature

Description

Use this function to display the current electronics temperature.

"Min/Max values" submenu**Sensor n min value**

n = Stands for the number of sensor inputs (1 and 2)

NavigationDiagnostics → Measured values → Min/max values → Sensor n min value
Expert → Diagnostics → Measured values → Min/max values → Sensor n min value**Description**

Use this function to display the minimum temperature measured in the past at sensor input 1 or 2 (peakhold indicator).

Sensor n max value

n = Stands for the number of sensor inputs (1 and 2)

NavigationDiagnostics → Measured values → Min/max values → Sensor n max value
Expert → Diagnostics → Measured values → Min/max values → Sensor n max value**Description**

Use this function to display the maximum temperature measured in the past at sensor input 1 or 2 (peakhold indicator).

Reset sensor min/max values**Navigation**Diagnostics → Measured values → Min/max values → Reset sensor min/max values
Expert → Diagnostics → Measured values → Min/max values → Reset sensor min/max values**Description**

Reset the peakhold indicators for the minimum and maximum temperatures measured at the sensor inputs.

Options

- No
- Yes

Factory setting

No

Device temperature min**Navigation**Diagnostics → Measured values → Min/max values → Device temperature min
Expert → Diagnostics → Measured values → Min./max values → Device temperature min

Description Use this function to display the minimum electronics temperature measured in the past (maximum indicator).

Device temperature max

Navigation  Diagnostics → Measured values → Min/max values → Device temperature max
Expert → Diagnostics → Measured values → Min/max values → Device temperature max

Description Use this function to display the maximum temperature measured in the past (maximum indicator).

Reset device temp. min/max values

Navigation  Diagnostics → Measured values → Min/max values → Reset device temperature min/max
Expert → Diagnostics → Measured values → Min/max values → Reset device temp. min/max values

Description Reset the peakhold indicators for the minimum and maximum electronic temperatures measured.

Options

- No
- Yes

Factory setting No

14.2.5 "Simulation" submenu

Current output simulation

Navigation  Diagnostics → Simulation → Current output simulation
Expert → Diagnostics → Simulation → Current output simulation

Description Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostics message of the "function check" category (C) while simulation is in progress.

Display Measured value display ↔ C491 (current output simulation)

Options

- Off
- On

Factory setting Off

Additional information

The simulation value is defined in the **Value current output** parameter.

Value current output

Navigation

Diagnostics → Simulation → Value current output
Expert → Diagnostics → Simulation → Value current output

Additional information

The **Current output simulation** parameter must be set to **On**.

Description

Use this function to set a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream evaluation units.

User entry

3.58 to 23.0 mA

Factory setting

3.58 mA

14.3 “Expert” menu

 The parameter groups for the Expert setup contain all the parameters of the "Setup" and "Diagnostics" operating menus, as well as other parameters that are solely reserved for experts. Descriptions of the additional parameters can be found in this section. All the fundamental parameter settings for transmitter commissioning and diagnostic evaluation are described in the "Setup menu" →  77 and "Diagnostics menu" →  97 sections.

14.3.1 “System” submenu

Damping	
Navigation	 Expert → System → Damping
Description	Use this function to set the time constant for current output damping.
User entry	0 to 120 s
Factory setting	0.00 s
Additional information	The current output responds to fluctuations in the measured value with an exponential delay. The time constant of this delay is defined by this parameter. If a low time constant is entered, the current output responds quickly to the measured value. On the other hand, if a high time constant is entered, the current output reaction is delayed.
Alarm delay	
Navigation	 Expert → System → Alarm delay
Description	Use this function to set the delay time during which a diagnostics signal is suppressed before it is output.
User entry	0 to 5 s
Factory setting	2 s
Mains filter	
Navigation	 Expert → System → Mains filter
Description	Use this function to select the mains filter for A/D conversion.
Options	■ 50 Hz ■ 60 Hz
Factory setting	50 Hz

Device temperature alarm → 84

Navigation

 Expert → System → Device temperature alarm

"Display" submenu

→ 89

"Administration" submenu

→ 95

14.3.2 "Sensors" submenu

"Sensor 1/2" submenu

 n = Stands for the number of sensor inputs (1 and 2)

Sensor n lower limit

Navigation

 Expert → Sensors → Sensor n → Sensor n lower limit

Description

Indication of the lower, physical sensor range.

Sensor n upper limit

Navigation

 Expert → Sensors → Sensor n → Sensor n upper limit

Description

Indication of the upper, physical sensor range.

Sensor serial number

Navigation

 Expert → Sensors → Sensor n → Serial no. sensor

Description

Use this function to enter the serial number of the connected sensor.

User entry

String with up to 12 characters consisting of numbers and/or text

Factory setting

" " (no text)

*"Sensor trimming" submenu***Sensor error adjustment (sensor trimming)**

Sensor trimming is used to adapt the actual sensor signal to the linearization of the selected sensor type stored in the transmitter. Compared to sensor transmitter matching, sensor trimming only takes place at the start and end value and does not achieve the same level of accuracy.



Sensor trimming does not adapt the measuring range. It is used to adapt the sensor signal to the linearization stored in the transmitter.

Procedure

1. Start
↓
2. Set the Sensor trimming parameter to the Customer-specific setting.
↓
3. Using a water/oil bath, bring the sensor connected to the transmitter to a known and stable temperature. A temperature which is close to the set lower range limit is recommended.
↓
4. Enter the reference temperature for the value at the lower range limit for the Sensor trimming lower value parameter. Based on the difference between the specified reference temperature and the temperature actually measured at the input, the transmitter internally calculates a correction factor which is now used to linearize the input signal.
↓
5. Using a water/oil bath, bring the sensor connected to the transmitter to a known and stable temperature close to the set upper range limit.
↓
6. Enter the reference temperature for the value at the upper range limit for the Sensor trimming upper value parameter.
↓
7. End

Sensor trimming**Navigation**

Expert → Sensors → Sensor n → Sensor trimming → Sensor trimming

Description

Use this function to select the linearization method to be used for the connected sensor.



The original linearization can be restored by resetting this parameter to the **Factory setting** option.

Options

- Factory setting
- Customer-specific

Factory setting

Factory setting

Sensor trimming lower value**Navigation**

Expert → Sensors → Sensor n → Sensor trimming → Sensor trimming lower value

Prerequisite	The Customer-specific option is enabled in the Sensor trimming parameter→  107.
Description	Lower point for linear characteristic calibration (this affects offset and slope).
User entry	Depends on the selected sensor type and the assignment of the current output (PV).
Factory setting	-200 °C

Sensor trimming upper value

Navigation	 Expert → Sensors → Sensor n → Sensor trimming → Sensor trimming upper value
Prerequisite	The Customer-specific option is enabled in the Sensor trimming parameter.
Description	Upper point for linear characteristic calibration (this affects offset and slope).
User entry	Depends on the selected sensor type and the assignment of the current output (PV).
Factory setting	850 °C

Sensor trimming min span

Navigation	 Expert → Sensors → Sensor n → Sensor trimming → Sensor trimming min span
Prerequisite	The Customer-specific option is enabled in the Sensor trimming parameter.
Description	Use this function to view the minimum possible span between the sensor trimming upper and lower value.

"Linearization" submenu

Procedure for configuring a linearization using Callendar/Van Dusen coefficients from a calibration certificate

1. Start
↓
2. Assign current output (PV) = set sensor 1 (measured value)
↓
3. Select unit (°C).
↓
4. Select the sensor type (linearization type) "RTD platinum (Callendar/Van Dusen)".
↓
5. Select connection type, e.g., 3-wire.
↓
6. Set the sensor lower and sensor upper limits.
↓

7. Enter the four coefficients A, B, C and R0.
↓
8. If special linearization is also used for a second sensor, repeat steps 2 to 6.
↓
9. End

Sensor n lower limit

Navigation	 Expert → Sensors → Sensor n → Linearization → Sensor n lower limit
Prerequisite	The RTD platinum, RTD poly nickel or RTD copper polynomial option is enabled in the Sensor type parameter.
Description	Use this function to set the lower calculation limit for special sensor linearization.
User entry	Depends on the sensor type selected.
Factory setting	-200 °C

Sensor n upper limit

Navigation	 Expert → Sensors → Sensor n → Linearization → Sensor n upper limit
Prerequisite	The RTD platinum, RTD poly nickel or RTD copper polynomial option is enabled in the Sensor type parameter.
Description	Use this function to set the upper calculation limit for special sensor linearization.
User entry	Depends on the sensor type selected.
Factory setting	850 °C

Call./v. Dusen coeff. R0

Navigation	 Expert → Sensors → Sensor n → Linearization → Call./v. Dusen coeff. R0
Prerequisite	The RTD platinum (Callendar/Van Dusen) option is enabled in the Sensor type parameter.
Description	Setting of the R0 value for the linearization based on the Callendar-Van Dusen method.
User entry	10 to 2 000 Ohm
Factory setting	100.000 Ohm

Call./v. Dusen coeff. A, B and C

Navigation	 Expert → Sensors → Sensor n → Linearization → Call./v. Dusen coeff. A, B, C
Prerequisite	The RTD platinum (Callendar/Van Dusen) option is enabled in the Sensor type parameter.
Description	Use this function to set the coefficients for sensor linearization based on the Callendar/Van Dusen method.
Factory setting	■ A: 3.910000e-003 ■ B: -5.780000e-007 ■ C: -4.180000e-012

Polynomial coeff. R0

Navigation	 Expert → Sensors → Sensor n → Linearization → Polynomial coeff. R0
Prerequisite	The RTD poly nickel or RTD copper polynomial option is enabled in the Sensor type parameter.
Description	Use this function to set the R0 Value only for linearization of nickel/copper sensors.
User entry	10 to 2 000 Ohm
Factory setting	100.00 Ohm

Polynomial coeff. A, B

Navigation	 Expert → Sensors → Sensor n → Linearization → Polynomial coeff. A, B
Prerequisite	The RTD poly nickel or RTD copper polynomial option is enabled in the Sensor type parameter.
Description	Use this function to set the coefficients for sensor linearization of copper/nickel resistance thermometers.
Factory setting	Polynomial coeff. A = 5.49630e-003 Polynomial coeff. B = 6.75560e-006

“Diagnostic settings” submenu

Calibration counter start

Navigation	 Expert → Sensors → Diagnostic settings → Calibration counter start
Description	Option to control the calibration counter.  ■ The countdown duration (in days) is specified with the Calibration counter start value parameter. ■ The status signal issued when the limit value is reached is defined with the Calibration alarm category parameter.
Options	■ Off: Stops the calibration counter ■ On: Starts the calibration counter ■ Reset + run: Resets to the set start value and starts the calibration counter
Factory setting	Off

Calibration alarm category

Navigation	 Expert → Sensors → Diagnostic settings → Calibration alarm category
Description	Use this function to select the category (status signal) as to how the device reacts when the set calibration countdown expires.
Options	■ Maintenance required (M) ■ Failure (F)
Factory setting	Maintenance required (M)

Calibration counter start value

Navigation	 Expert → Sensors → Diagnostic settings → Calibration counter start value
Description	Use this function to set the start value for the calibration counter.
User entry	0 to 365 d (days)
Factory setting	365

Count value

Navigation	 Expert → Sensors → Diagnostic settings → Count value
Description	Use this function to view the time remaining until the next calibration.  The calibration counter only runs if the device is active. Example: If the calibration counter is set to 365 days on January 1, 2023, and no electricity is supplied to the device for 100 days, the alarm for the calibration appears on April 10, 2024.

14.3.3 “Output” submenu

Percent of range	
Navigation	 Expert → Output → Percent of range
Description	Use this function to display the measured value in % of the measuring span.
Measuring mode	
Navigation	 Expert → Output → Measuring mode
Description	Enables the inversion of the output signal.
Additional information	▪ Standard The output current increases with increasing temperatures ▪ inverted The output current decreases with increasing temperatures
Options	▪ Standard ▪ inverted
Factory setting	Standard

14.3.4 “Communication” submenu

“HART configuration” submenu

Device tag →  99	
Navigation	 Diagnostics → Device information → Device tag Expert→ Communication → HART configuration → Device tag
HART short tag	
Navigation	 Expert→ Communication → HART configuration → HART short tag
Description	Use this function to define a short tag for the measuring point.
User entry	Up to 8 alphanumeric characters (letters, numbers and special characters)
Factory setting	SHORTTAG

HART address

Navigation	 Expert → Communication → HART configuration → HART address
Description	Use this function to define the HART address of the device.
User entry	0 to 63
Factory setting	0
Additional information	Only with address "0" a measured value transmission via the current value is possible. The current is fixed at 4.0 mA for all other addresses (Multidrop mode).

No. of preambles

Navigation	 Expert → Communication → HART configuration → No. of preambles
Description	Use this function to define the number of preambles in the HART telegram
User entry	2 to 20
Factory setting	5

Configuration changed

Navigation	 Expert → Communication → HART configuration → Configuration changed
Description	Indicates whether the configuration of the device has been changed by a master (primary or secondary).

Reset configuration changed flag

Navigation	 Expert → Communication → HART configuration → Reset configuration changed flag
Description	The Configuration changed information is reset by a master (primary or secondary).

“HART info” submenu

Device type

Navigation	 Expert → Communication → HART info → Device type
Description	Use this function to view the device type with which the device is registered with the HART FieldComm Group. The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.
Factory setting	0x11CC or TMT82 (depends on the configuration tool)

Device revision

Navigation	 Expert → Communication → HART info → Device revision
Description	Use this function to view the device revision with which the device is registered with the HART FieldComm Group. It is needed to assign the appropriate device description file (DD) to the device.
Factory setting	3

Device ID

Navigation	 Expert → Communication → HART info → Device ID
Description	A unique HART identifier is saved in the device ID and used by the control systems to identify the device. The device ID is also transmitted in command 0. The device ID is determined unambiguously from the serial number of the device.
Display	ID generated for specific serial number

Manufacturer ID

Navigation	 Expert → Communication → HART info → Manufacturer ID Expert → Diagnostics → Device information → Manufacturer ID
Description	Use this function to view the manufacturer ID under which the device is registered with the HART FieldComm Group.
Factory setting	0x11 (hexadecimal) or 17 (decimal)

HART revision

Navigation	 Expert → Communication → HART info → HART revision
-------------------	--

Description Use this function to display the HART revision of the device

HART descriptor

Navigation  Expert → Communication → HART info → HART descriptor

Description Definition of a description for the measuring point.

User entry Up to 16 alphanumeric characters (letters, numbers and special characters)

Factory setting 16 x spaces

HART message

Navigation  Expert → Communication → HART info → HART message

Description Use this function to define a HART message which is sent via the HART protocol when requested by the master.

User entry Up to 32 alphanumeric characters (letters, numbers and special characters)

Factory setting 32 x spaces

Hardware revision

Navigation  Expert → Diagnostics → Device information → Hardware revision
Expert → Communication → HART info → Hardware revision

Description Use this function to display the hardware revision for the device.

Software revision

Navigation  Expert → Communication → HART info → Software revision

Description Use this function to display the software revision of the device.

HART date code

Navigation  Expert → Communication → HART info → HART date code

Description	Use this function to define date information for individual use.
User entry	Date in year-month-day (YYYY-MM-DD) format
Factory setting	2010-01-01

“HART output” submenu

Assign current output (PV)

Navigation	 Expert → Communication → HART output → Assign current output (PV)
Description	Use this function to assign a measured variable to the primary HART value (PV)
Options	■ Sensor 1 (measured value) ■ Sensor 2 (measured value) ■ Device temperature ■ Average of the two measured values: $0.5 \times (SV1+SV2)$ ■ Difference between sensor 1 and sensor 2: $SV1-SV2$ ■ Sensor 1 (backup sensor 2): If sensor 1 fails, the value of sensor 2 automatically becomes the primary HART value (PV): sensor 1 (OR sensor 2) ■ Sensor switching: If the value exceeds the configured threshold value T for sensor 1, the measured value of sensor 2 becomes the primary HART value (PV). The system switches back to sensor 1 if the measured value of sensor 1 is at least 2 K below T: sensor 1 (sensor 2, if sensor 1 > T) ■ Average: $0.5 \times (SV1+SV2)$ with backup (measured value of sensor 1 or sensor 2 in the event of a sensor error in the other sensor)  The threshold value can be set with the Sensor switch set point parameter. With temperature-dependent switching, it is possible to combine 2 sensors that offer advantages in different temperature ranges.
Factory setting	Sensor 1

PV

Navigation	 Expert → Communication → HART output → PV
Description	Use this function to display the primary HART value

Reset sensor backup → 80

Navigation	 Setup → Reset sensor backup Expert → Communication → HART output → Reset sensor backup
-------------------	---

Assign SV

Navigation	 Expert → Communication → HART output → Assign SV
Description	Use this function to assign a measured variable to the secondary HART value (SV)
Options	See Assign current output (PV) parameter →  116
Factory setting	Device temperature

SV

Navigation	 Expert → Communication → HART output → SV
Description	Use this function to display the secondary HART value

Assign TV

Navigation	 Expert → Communication → HART output → Assign TV
Description	Use this function to assign a measured variable to the tertiary HART value (TV)
Options	See Assign current output (PV) parameter →  116
Factory setting	Sensor 1

TV

Navigation	 Expert → Communication → HART output → TV
Description	Use this function to display the tertiary HART value

Assign QV

Navigation	 Expert → Communication → HART output → Assign QV
Description	Allocation of a measuring variable to the fourth HART variable (QV)
Options	See Assign current output (PV) parameter →  116

Factory setting Sensor 1

QV

Navigation  Expert → Communication → HART output → QV

Description Use this function to display the quaternary HART value

"Burst configuration 1 to 3" submenu

 Up to 3 burst modes can be configured.

Burst mode

Navigation  Expert → Communication → Burst configuration 1 to 3 → Burst mode

Description Activation of the HART burst mode for burst message X. Message 1 has the highest priority, message 2 the second-highest priority, etc. This prioritization is only correct if the **Min. update period** is the same for all burst configurations. The prioritization of the messages depends on the **Min. update period**; the shortest time has the highest priority.

Options **■ Off**
The device only sends data to the bus at the request of a HART master
■ On
The device regularly sends data to the bus without being requested to do so.

Factory setting Off

Burst command

Navigation  Expert → Communication → Burst configuration 1 to 3 → Burst command

Description Use this function to select the command whose answer is sent to the HART master in the activated burst mode.

Options	■ Command 1 Read out the primary variable ■ Command 2 Read out the current and the main measured value as a percentage ■ Command 3 Read out the dynamic HART variables and the current ■ Command 9 Read out the dynamic HART variables including the related status ■ Command 33 Read out the dynamic HART variables including the related unit ■ Command 48 Read out the additional device status
----------------	---

Factory setting	Command 2
------------------------	-----------

Additional information	Commands 1, 2, 3, 9 and 48 are universal HART commands. Command 33 is a "Common-Practice" HART command. More details on this are provided in the HART specifications.
-------------------------------	--

Burst variable n

 n = Number of burst variables (0 to 7)

Navigation	 Expert → Communication → Burst configuration 1 to 3 → Burst variable n
-------------------	--

Prerequisite	This parameter can only be selected if the Burst mode option is enabled. The selection of burst variables depends on the burst command. If command 9 and command 33 are selected, the burst variables can be selected.
---------------------	---

Description	Use this function to assign a measured variable to slots 0 to 7.
--------------------	--

 This assignment is **only** relevant for the burst mode. The measured variables are assigned to the 4 HART variables (PV, SV, TV, QV) in the **HART output** menu →  116.

Options	■ Sensor 1 (measured value) ■ Sensor 2 (measured value) ■ Device temperature ■ Average of the two measured values: $0.5 \times (SV1 + SV2)$ ■ Difference between sensor 1 and sensor 2: $SV1 - SV2$ ■ Sensor 1 (backup sensor 2): If sensor 1 fails, the value of sensor 2 automatically becomes the primary HART value (PV): sensor 1 (OR sensor 2). ■ Sensor switching: If the value exceeds the configured threshold value T for sensor 1, the measured value of sensor 2 becomes the primary HART value (PV). The system switches back to sensor 1 if the measured value of sensor 1 is at least 2 K below T: sensor 1 (sensor 2, if sensor 1 > T)
----------------	---

 The threshold value can be set with the **Sensor switch set point** parameter. With temperature-dependent switching, it is possible to combine 2 sensors that offer advantages in different temperature ranges.

Average: $0.5 \times (SV1 + SV2)$ with backup (measured value of sensor 1 or sensor 2 in the event of a sensor error in the other sensor)

Factory setting	Burst variable 0 to 7: Not used
------------------------	---------------------------------

Burst trigger mode	
Navigation	 Expert → Communication → Burst configuration 1 to 3 → Burst trigger mode
Description	Use this function to select the event that triggers burst message X.  ■ Continuous: The message is triggered in a time-controlled manner, at least observing the time interval defined in the Min. update period parameter. ■ Range: The message is triggered if the specified measured value has changed by the value defined in the Burst trigger level X parameter. ■ Rising: The message is triggered if the specified measured value exceeds the value in the Burst trigger level X parameter. ■ Falling: The message is triggered if the specified measured value falls below the value in the Burst trigger level X parameter. ■ On change: The message is triggered if a measured value of the message changes.
Options	■ Continuous ■ Range ■ Rising ■ In band ■ Change
Factory setting	Continuous

Burst trigger level	
Navigation	 Expert → Communication → Burst configuration 1 to 3 → Burst trigger level
Prerequisite	This parameter can only be selected if the Burst mode option is enabled.
Description	Use this function to enter the value which, together with the trigger mode, determines the time of burst message 1. This value determines the time of the message.
User entry	-1.0e ⁺²⁰ to +1.0e ⁺²⁰
Factory setting	-10.000

Min. update period	
Navigation	 Expert → Communication → Burst configuration 1 to 3 → Min. update period
Prerequisite	This parameter is dependent on the selection in the Burst trigger mode .

Description	Use this function to enter the minimum time span between two burst commands of burst message X. The value is entered in the milliseconds unit.
User entry	500 to [value entered for the maximum time span in the Max. update period] parameter as integers
Factory setting	1000

Max. update period

Navigation	 Expert → Communication → Burst configuration 1 to 3 → Max. update period
Prerequisite	This parameter is dependent on the selection in the Burst trigger mode .
Description	Use this function to enter the maximum time span between two burst commands of burst message X. The value is entered in the milliseconds unit.
User entry	[Value entered for the minimum time span in the Min. update period] parameter to 3600000 as integers
Factory setting	2000

14.3.5 "Diagnostics" submenu

"Diagnostic list" submenu

For a detailed description, see →  98

"Event logbook" submenu

For a detailed description, see →  99

"Device information" submenu

Extended order code 1-3

Navigation	 Diagnostics → Device information → Extended order code 1-3 Expert → Diagnostics → Device information → Extended order code 1-3
Description	Use this function to display the first, second and/or third part of the extended order code. On account of length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model. It can also be found on the nameplate.  Uses of the extended order code ■ To order an identical replacement device. ■ To check the ordered device features using the delivery note.

ENP version

Navigation	 Diagnostics → Device information → ENP version Expert → Diagnostics → Device information → ENP version
Description	Use this function to display the version of the electronic nameplate (ENP).
Display	6-digit number in the format xx.yy.zz

Device revision

Navigation	 Diagnostics → Device information → Device revision Expert → Diagnostics → Device information → Device revision Expert → Communication → HART info → Device revision
Description	Use this function to view the device revision with which the device is registered with the HART FieldComm Group. It is needed to assign the appropriate device description file (DD) to the device.
Display	2-digit hexadecimal number

Manufacturer ID → 114

Navigation	 Diagnostics → Device information → Manufacturer ID Expert → Communication → HART info → Manufacturer ID Expert → Diagnostics → Device information → Manufacturer ID
-------------------	---

Manufacturer

Navigation	 Diagnostics → Device information → Manufacturer Expert → Diagnostics → Device information → Manufacturer
Description	Displays the manufacturer name.

Hardware revision

Navigation	 Diagnostics → Device information → Hardware revision Expert → Diagnostics → Device information → Hardware revision Expert → Communication → HART info → Hardware revision
-------------------	---

Description Use this function to display the hardware revision for the device.

“Measured values” submenu

Sensor n raw value

 n = Stands for the number of sensor inputs (1 and 2)

Navigation  Expert → Diagnostics → Measured values → Sensor n raw value

Description Displays the non-linearized mV/Ohm value at the specific sensor input.

“Min/Max values” submenu

For a detailed description, see →  102

“Simulation” submenu

For a detailed description, see →  103

Index

0 ... 9

2-wire compensation (parameter) 79

A

Access status tooling (parameter) 83

Accessories

Communication-specific 48

Device-specific 47

System components 49

Actual diagnostics 1 (parameter) 97

Actual diagnostics 1-3 98

Actual diagnostics 1-3 channel 98

Actual diagnostics count 98

Administration (submenu) 95, 106

Advanced setup (submenu) 81

Alarm delay (parameter) 105

Assign current output (PV) (parameter) 80, 116

Assign QV (parameter) 117

Assign SV (parameter) 117

Assign TV (parameter) 117

B

Burst command (parameter) 118

Burst configuration (submenu) 118

Burst mode (parameter) 118

Burst trigger level (parameter) 120

Burst trigger mode (parameter) 120

Burst variables (parameter) 119

C

Calibration alarm category (parameter) 111

Calibration counter start (parameter) 110

Calibration counter start value (parameter) 111

Call./v. Dusen coeff. A, B and C (parameter) 110

Call./v. Dusen coeff. R0 (parameter) 109

Communication (submenu) 112

Configuration changed (parameter) 113

Configuration counter 101

Connection combinations 23

Connection type (parameter) 78

Corrosion detection (parameter) 84

Count value 111

Current output (submenu) 87

Current output simulation (parameter) 103

Current trimming 4 mA (parameter) 89

Current trimming 20 mA (parameter) 89

D

Damping (parameter) 105

Decimal places 1 (parameter) 91

Decimal places 2 (parameter) 92

Decimal places 3 (parameter) 93

Define device write protection code (parameter) 95

Device ID 114

Device info (submenu) 99

Device information (submenu) 121

Device name 100

Device reset (parameter) 95

Device revision 114, 122

Device tag (parameter) 77, 99, 112

Device temperature 101

Device temperature alarm (parameter) 84, 106

Device temperature max 103

Device temperature min 102

Device type 113

Diagnostic events

Diagnostic behavior 42

Status signals 42

Diagnostic list 43

Diagnostic list (submenu) 98

Diagnostic settings (menu) 110

Diagnostics (menu) 97

Diagnostics (submenu) 121

Display (menu) 89

Display (submenu) 106

Display interval (parameter) 89

Disposal 47

Document

Function 4

Document function 4

Drift/difference alarm category (parameter) 85

Drift/difference alarm delay 86

Drift/difference mode (parameter) 85

Drift/difference set point (parameter) 86

E

ENP version 122

Enter access code (parameter) 82

Event log (submenu) 99

Expert (Menu) 105

Extended order code 121

F

Failure current (parameter) 88

Failure mode (parameter) 88

FieldCare

Operator interface 34

Range of functions 32

User interface 33

Firmware version 100

Force safe state (parameter) 94

Format display (parameter) 90

H

Hardware revision 115, 122

HART address (parameter) 113

HART configuration (submenu) 112

HART date code (parameter) 115

HART descriptor (parameter) 115

HART info (submenu) 113

HART message (parameter) 115

HART output (submenu) 116

HART protocol

Device variables 36

Operating tools	36
Version data for the device	36
HART revision	114
HART short tag (parameter)	112
I	
Intended use	8
L	
Linearization (submenu)	108
Locking status	84
Lower range value (parameter)	81
M	
Mains filter (parameter)	105
Manufacturer	122
Manufacturer ID (parameter)	114, 122
Max. update period (parameter)	121
Measured values (submenu)	101, 123
Measuring mode (parameter)	87, 112
Min. update period (parameter)	120
Min/max values (submenu)	102
N	
No. of preambles (parameter)	113
O	
Operating time	97
Operation options	
Local operation	27
Operating tool	27
Overview	27
Operational state (parameter)	93
Order code	100
Out of range category (parameter)	88
Output (submenu)	112
Output current	87
P	
Percent of range (parameter)	112
Polynomial coeff. A, B (parameter)	110
Polynomial coeff. R0 (parameter)	110
Previous diag n channel	99
Previous diagnostics	99
Previous diagnostics 1	97
Product safety	9
PV	116
Q	
QV	118
R	
Reference junction (parameter)	79
Requirements for personnel	8
Reset backup	97
Reset configuration changed flag (parameter)	113
Reset device temp. min/max values (parameter)	103
Reset sensor backup (parameter)	80, 116
Reset sensor min/max values (parameter)	102
Return	46

RJ preset value (parameter)	80
S	
Sensor 1/2 (submenu)	106
Sensor lower limit	106
Sensor lower limit (parameter)	109
Sensor max value	102
Sensor min value	102
Sensor offset (parameter)	84
Sensor raw value	123
Sensor switch set point (parameter)	86
Sensor trimming (parameter)	107
Sensor trimming (submenu)	107
Sensor trimming lower value (parameter)	107
Sensor trimming min span	108
Sensor trimming upper value (parameter)	108
Sensor type (parameter)	78
Sensor upper limit	106
Sensor upper limit (parameter)	109
Sensor value	101
Sensors (submenu)	84, 106
Serial no. sensor (parameter)	106
Serial number	100
Setup (menu)	77
SIL (submenu)	93
SIL checksum (parameter)	94
SIL option (parameter)	93
Simulation (submenu)	103
Software revision	115
Solid wire	24
Structure of the operating menu	28
SV	117
System (submenu)	105
System components	49
T	
Terminal assignment	20
Timestamp SIL configuration (parameter)	94
Troubleshooting	
Application error with RTD sensor connection	40
Application error with TC sensor connection	41
Checking the display	40
General faults	40
TV	117
U	
Unit (parameter)	78
Upper range value (parameter)	81
V	
Value 1 display (parameter)	90
Value 2 display (parameter)	91
Value 3 display (parameter)	92
Value current output (parameter)	104
W	
Wire without wire end ferrule	24
Workplace safety	8



www.addresses.endress.com
