
Valid as of version 01.01.zz (Device firmware) Products Solutions

Services

# Operating Instructions **Proline Promass E 200**

Coriolis flowmeter PROFIBUS PA







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser sales organization will supply you with current information and updates to this manual.

## Table of contents

1	About this document 6	6.2	6.1.3 Special installation instructions	
1.1 1.2	Document function	6.3	Installing the device	25 25 25 26 26
	1.2.6 Symbols in graphics 7	7	Electrical connection	28
1.3 1.4	Documentation	7.1 7.2	Electrical safety	28 28
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Requirements for the personnel 9 Intended use 9 Workplace safety 10 Operational safety 10 Product safety 10 IT security 11 Device-specific IT security 11 2.7.1 Protecting access via hardware write protection 11 2.7.2 Protecting access via a password 11 2.7.3 Access via fieldbus 12	7.3 7.4 7.5 7.6	7.2.2 Requirements for connection cable	29 29 31 31 32 33 34 34 34 34 35
3	Product description	7.7	Post-connection check	
3.1	Product design	8	Operation options	36
4	Incoming acceptance and product	8.1	Overview of operation options	36
4.1 4.2	identification14Incoming acceptance14Product identification144.2.1 Transmitter nameplate154.2.2 Sensor nameplate164.2.3 Symbols on the device17	8.2	Structure and function of the operating menu	37 37 38 39 39 41
_	S. 10		8.3.3 Editing view	42
<b>5</b> 5.1 5.2	Storage and transport18Storage conditions18Transporting the product185.2.1 Measuring devices without lifting lugs185.2.2 Measuring devices with lifting lugs195.2.3 Transporting with a fork lift19Packaging disposal10		<ul> <li>8.3.4 Operating elements</li> <li>8.3.5 Opening the context menu</li> <li>8.3.6 Navigating and selecting from list</li> <li>8.3.7 Calling the parameter directly</li> <li>8.3.8 Calling up help text</li> <li>8.3.9 Changing the parameters</li> <li>8.3.10 User roles and related access authorization</li> </ul>	
5.3	Packaging disposal		8.3.11 Disabling write protection via access code	49
6	Installation 20		8.3.12 Enabling and disabling the keypad	45
6.1	Installation requirements	8.4	lock	50 50 50 50

	8.4.3	User interface		11	Operation	. 94
	8.4.4 8.4.5	Disabling the Web server Logging out		11.1	Reading the device locking status	. 94
8.5		to the operating menu via the		11.2	Adjusting the operating language $\ldots\ldots$	
0.5		ng tool	53	11.3	Configuring the display	
	8.5.1	Connecting the operating tool	53	11.4	Reading off measured values	
	8.5.2	FieldCare	54		11.4.1 Process variables	
	8.5.3	DeviceCare	54		11.4.2 Totalizer	
	8.5.4	SIMATIC PDM	55	11.5	11.4.3 Output variables	
				11.7	conditions	
9	Syster	n integration	56	11.6	Performing a totalizer reset	
9.1	Overvie	w of device description files	56	11.7	Displaying the measured value history	
	9.1.1	Current version data for the device			1 3 3	
	9.1.2	Operating tools	56	12	Diagnostics and troubleshooting	101
9.2	Device 1	master file (GSD)	56			
	9.2.1	Manufacturer-specific GSD	57	12.1 12.2	General troubleshooting	
	9.2.2	Profile GSD	57	12.2	12.2.1 Diagnostic message	
9.3	-	ata transmission	57		12.2.2 Calling up remedial actions	105
	9.3.1	Block model	57	12.3	Diagnostic information in FieldCare or	100
	9.3.2	Description of the modules	58		DeviceCare	105
1.0	•				12.3.1 Diagnostic options	105
10	Comm	iissioning	64		12.3.2 Calling up remedy information	107
10.1	Post-in	stallation and post-connection check	64	12.4	Adapting the diagnostic information	107
10.2		ng on the measuring instrument	64		12.4.1 Adapting the diagnostic behavior	
10.3		iring the device address via software	64	12.5	Overview of diagnostic information	110
10 (		PROFIBUS network	64		12.5.1 Diagnostic of sensor	110
10.4		the operating language			12.5.2 Diagnostic of electronic	112
10.5		Profining the tag name			12.5.3 Diagnostic of configuration	116 119
		Defining the tag name Setting the system units	66	12.6	Pending diagnostic events	122
		Selecting and setting the medium	69	12.7	Diagnostic list	123
		Configuring communication			Event logbook	123
		interface	69		12.8.1 Reading out the event logbook	123
	10.5.5	Configuring the local display	70		12.8.2 Filtering the event logbook	124
		Configuring the low flow cut off	72		12.8.3 Overview of information events $\dots$	
		Partially filled pipe detection	73	12.9	Resetting the device	126
	10.5.8	Configuring the partial filled pipe			12.9.1 Function scope of the "Device reset"	106
10.6	. 1	detection	74	12.10	parameter	
10.6		ed settings	75		Device information	126 128
		Carrying out a sensor adjustment	76	12.11	Firmware history	120
	10.0.2	Configuring the pulse/frequency/switch output	77	10	N/ = interes	120
	10 6 3	Configuring the totalizer		13	Maintenance	129
		Carrying out additional display		13.1	Maintenance work	
		configurations	85	10.0	13.1.1 Cleaning	
	10.6.5	Using parameters for device		13.2	Measuring and test equipment	
		administration	87	13.3	Maintenance services	129
10.7	_	ration management	88	1,	<b>.</b>	100
	10.7.1	Function range of "Configuration		14	Repair	130
100		management" parameter		14.1	General notes	130
10.8		ion			14.1.1 Repair and conversion concept	
10.9		ing settings from unauthorized access.		a . =	14.1.2 Notes for repair and conversion	
		Write protection via access code Write protection via write protection	21	14.2	Spare parts	130
	10.7.4	switch	92	14.3	Repair services	
				14.4	Return	131

14.5	Disposal	131
	14.5.1 Removing the measuring	
	instrument	131
	14.5.2 Disposing of the measuring	
	instrument	132
15	Accessories	133
15.1	Device-specific accessories	133
	15.1.1 For the transmitter	133
	15.1.2 For the sensor	134
15.2	Communication-specific accessories	134
15.3	Service-specific accessories	135
15.4	System components	136
16	Technical data	137
16.1	Application	137
16.2	Function and system design	137
16.3	Input	138
16.4	Output	139
16.5	Power supply	142
16.6	Performance characteristics	144
16.7	Installation	148
16.8	Environment	148
16.9	Process	149
16.10	Mechanical construction	150
16.11	Operability	153
16.12	Certificates and approvals	155
16.13	Application packages	158
	Accessories	159
16.15	Documentation	159
Indox	7	161

## 1 About this document

#### 1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

## 1.2 Symbols

#### 1.2.1 Safety symbols

#### **⚠** DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

#### **WARNING**

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

#### **↑** CALITION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

#### NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

#### 1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
~	Alternating current
$\overline{\sim}$	Direct current and alternating current
=	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective earth (PE) Ground terminals that must be connected to ground prior to establishing any other connections.
	The ground terminals are located on the interior and exterior of the device:  Interior ground terminal: protective earth is connected to the mains supply.  Exterior ground terminal: device is connected to the plant grounding system.

#### 1.2.3 Communication-specific symbols

Symbol	Meaning
<b></b>	Wireless Local Area Network (WLAN) Communication via a wireless, local area network
*	Bluetooth Wireless data transmission between devices over a short distance via radio technology

Symbol	Meaning
•	LED LED is off.
<b>\\\\</b>	LED LED is on.
	LED LED flashing.

## 1.2.4 Tool symbols

Symbol	Meaning
0	Flat-blade screwdriver
06	Allen key
Ó	Open-end wrench

## 1.2.5 Symbols for certain types of information


Symbol	Meaning
<b>~</b>	Permitted Procedures, processes or actions that are permitted.
<b>V</b>	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
Ĩ	Reference to documentation
	Reference to page
	Reference to graphic
<b>&gt;</b>	Notice or individual step to be observed
1., 2., 3	Series of steps
L-	Result of a step
?	Help in the event of a problem
	Visual inspection

## 1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections

Symbol	Meaning
EX	Hazardous area
×	Safe area (non-hazardous area)
≋➡	Flow direction

#### 1.3 Documentation



- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the Downloads area of the Endress+Hauser website (www.endress.com/downloads), depending on the device version:

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions (KA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Your reference document The Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.
Safety instructions (XA)	Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. These are an integral part of the Operating Instructions.
	The nameplate indicates which Safety Instructions (XA) apply to the device.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is a constituent part of the device documentation.

## 1.4 Registered trademarks

#### **PROFIBUS®**

Registered trademark of the PROFIBUS Nutzerorganisation e.V. (PROFIBUS User Organization), Karlsruhe, Germany

#### TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

## 2 Safety instructions

## 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

#### 2.2 Intended use

#### Application and media

The measuring instrument described in this manual is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring instrument can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring instruments for use in hazardous areas, in hygienic applications, or where there is an increased risk due to pressure, are specially labeled on the nameplate.

To ensure that the measuring instrument remains in proper condition during the operating time:

- ▶ Only use the measuring instrument in full compliance with the data on the nameplate and the general conditions listed in the manual and supplementary documentation.
- ▶ Using the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring instrument only for media against which the materials in contact with the process are sufficiently resistant.
- ▶ Keep within the specified pressure and temperature range.
- ► Keep within the specified ambient temperature range.
- ► Protect the measuring instrument permanently against corrosion from environmental influences.

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### **▲** WARNING

#### Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all wetted materials during the process.
- ▶ Keep within the specified pressure and temperature range.

#### NOTICE

#### Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### Residual risks

#### **▲** WARNING

Risk of hot or cold burns! The use of media and electronics with high or low temperatures can produce hot or cold surfaces on the device.

▶ Mount suitable touch protection.

#### **A** WARNING

#### Danger of housing breaking due to measuring tube breakage!

If a measuring tube ruptures, the pressure inside the sensor housing will rise according to the operating process pressure.

▶ Use a rupture disk.

#### **A** WARNING

#### Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

▶ Take precautions to prevent injury and material damage if the rupture disk is actuated.

## 2.3 Workplace safety

For work on and with the device:

Wear the required personal protective equipment according to federal/national regulations.

## 2.4 Operational safety

Damage to the device!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for the interference-free operation of the device.

#### Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

▶ If modifications are nevertheless required, consult with the manufacturer.

#### Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

## 2.5 Product safety

This state-of-the-art device is designed and tested in accordance with good engineering practice to meet operational safety standards. It left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU declaration of conformity. The manufacturer confirms this by affixing the CE mark.

## 2.6 IT security

The manufacturer warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

## 2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater inoperation safety if used correctly. The following list provides an overview of the most important functions:

#### 2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

#### 2.7.2 Protecting access via a password

A password can be used to protect against write access to the device parameters.

This controls write access to the device parameters via the local display or other operating tools (e.g. FieldCare, DeviceCare) and, in terms of functionality, corresponds to hardware write protection. If the CDI service interface is used, read access is only possible by first entering the password.

#### User-specific access code

Local display and operating tool (e.g. FieldCare, DeviceCare)

- When delivered, the device does not have an access code; the default value is 0000 (open).

#### General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning for security reasons.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see "Write protection via access code" → \( \begin{align\*} \equiv \text{91}. \\ \equiv \text{91}. \end{align\*}

#### 2.7.3 Access via fieldbus

When communicating via fieldbus, access to the device parameters can be restricted to "Read only" access. The option can be changed in the **Fieldbus writing access** parameter.

This does not affect cyclic measured value transmission to the higher-order system, which is always quaranteed.



 $\hfill \hfill \hfill$ 


## **3** Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

## 3.1 Product design



■ 1 Important components of a measuring device

- 1 Electronics compartment cover
- 2 Display module
- 3 Main electronics module
- 4 Cable glands
- 5 Transmitter housing (incl. integrated HistoROM)
- 6 I/O electronics module
- 7 Terminals (pluggable spring terminals)
- 8 Connection compartment cover
- 9 Sensor

## 4 Incoming acceptance and product identification

## 4.1 Incoming acceptance

On receipt of the delivery:

- 1. Check the packaging for damage.
  - Report all damage immediately to the manufacturer. Do not install damaged components.
- 2. Check the scope of delivery using the delivery note.
- 3. Compare the data on the nameplate with the order specifications on the delivery note.
- 4. Check the technical documentation and all other necessary documents, e.g. certificates, to ensure they are complete.
- If one of the conditions is not satisfied, contact the manufacturer.

#### 4.2 Product identification


The device can be identified in the following ways:

- Nameplate
- Order code with details of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations app* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations app*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard device documentation" and "Supplementary device-dependent documentation" sections
- The Device Viewer: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations app*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.


#### 4.2.1 Transmitter nameplate



■ 2 Example of a transmitter nameplate


- 1 Manufacturer/certificate holder
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number
- 5 Extended order code
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Type of cable glands
- 8 Permitted ambient temperature  $(T_a)$
- 9 Firmware version (FW) from the factory
- 10 CE mark, RCM mark
- 11 Additional information on version: certificates, approvals
- 12 Permitted temperature range for cable
- 13 Date of manufacture: year-month
- 14 Degree of protection
- 15 Approval information for explosion protection
- 16 Document number of safety-related supplementary documentation → 🖺 159
- 17 2-D matrix code

#### 4.2.2 Sensor nameplate



**₽** 3 Example of a sensor nameplate, part 1

- 1 Name of sensor
- Manufacturer/certificate holder
- 3 Nominal diameter of the sensor; flange nominal diameter/nominal pressure; sensor test pressure; medium temperature range; material of measuring tube and manifold
- 4 Sensor-specific information
- CE mark, RCM symbol
- 6 Order code
- Serial number (Ser. no.)
- Extended order code (Ext. ord. cd.)



#### € 4 Example of a sensor nameplate, part 2

- Approval information for explosion protection, Pressure Equipment Directive and degree of protection 1
- Permitted ambient temperature  $(T_a)$ 2
- 3 Document number of safety-related supplementary documentation
- 4 2-D matrix code
- 5 Flow direction
- Manufacturing date: year-month

## Order code

The measuring device is reordered using the order code.

#### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

## 4.2.3 Symbols on the device

Symbol	Meaning
$\triangle$	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. Please consult the documentation for the measuring instrument to discover the type of potential danger and measures to avoid it.
(i	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal that must be connected to the ground prior to establishing any other connections.

## 5 Storage and transport

## 5.1 Storage conditions


Observe the following notes for storage:

- ► Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight. Avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ▶ Do not store outdoors.

Storage temperature  $\rightarrow \triangleq 148$ 

## 5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A002925

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


#### 5.2.1 Measuring devices without lifting lugs

#### **MARNING**

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ► Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0029214

#### 5.2.2 Measuring devices with lifting lugs

#### **A** CAUTION

#### Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.

#### 5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

## 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Outer packaging of device Stretch wrap made of polymer in accordance with EU Directive 2002/95/EC (RoHS)
- Packaging
  - Wood crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
  - Cardboard box in accordance with European packaging guideline 94/62/EC, recyclability confirmed by Resy symbol
- Transport material and fastening fixtures
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Filler material Paper pads

## 6 Installation

## 6.1 Installation requirements

#### **6.1.1** Installation position

#### Mounting location




To avoid measurement errors caused by gas bubble formation in the measuring tube, avoid the following installation locations in the pipe:

- Highest point of a pipeline
- Directly upstream of a free pipe outlet in a down pipe

#### Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A002877

- 5 Installation in a down pipe (e.g. for batching applications)
- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Filling container

20

DN/	NPS	Ø orifice plate, pipe restriction	
[mm]	[in]	[mm]	[in]
8	3/8	6	0.24
15	1/2	10	0.40
25	1	14	0.55
40	1 ½	22	0.87
50	2	28	1.10


#### Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Recommendation		
A	Vertical orientation	A0015591	<b>√ √</b> 1)
В	Horizontal orientation, transmitter at top	A0015589	✓ ✓ <sup>2)</sup> Exception:  → 🖸 6, 🖺 21
С	Horizontal orientation, transmitter at bottom	A0015590	✓ ✓ ³) Exception: → 🖸 6, 🖺 21
D	Horizontal orientation, transmitter at side	A0015592	×

- 1) This orientation is recommended to ensure self-draining.
- Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 3) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the medium properties.



■ 6 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for media with entrained solids: Risk of solids accumulating
- 2 Avoid this orientation for outgassing media: Risk of gas accumulating

#### Inlet and outlet runs

No special precautions need to be taken for fittings that create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs  $\rightarrow \triangleq 22$ .



Installation dimensions



For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section

#### 6.1.2 Environmental and process requirements

#### Ambient temperature range

Measuring instrument	-40 to +60 °C (-40 to +140 °F)
Readability of the local display	-20 to $+60$ °C ( $-4$ to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.

► If operating outdoors: Avoid direct sunlight, particularly in warm climatic regions.



You can order a weather protection cover from Endress+Hauser.  $\rightarrow \triangleq 133$ .

#### Static pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- ► Ensure the static pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)




#### Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.

#### NOTICE

#### Electronics overheating on account of thermal insulation!

- ► Recommended orientation: horizontal orientation, transmitter housing pointing downwards.
- ▶ Do not insulate the transmitter housing .
- ▶ Maximum permissible temperature at the lower end of the transmitter housing:  $80 \,^{\circ}\text{C} (176 \,^{\circ}\text{F})$
- ► Thermal insulation with exposed extension neck: We recommend that you do not insulate the extension neck in order to ensure optimum dissipation of heat.



■ 7 Thermal insulation with exposed extension neck

#### Heating

#### **NOTICE**

#### Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter.
- ▶ Depending on the medium temperature, take the device orientation requirements into account.

#### **NOTICE**

#### Danger of overheating when heating

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80  $^{\circ}$ C (176  $^{\circ}$ F).
- ► Ensure that sufficient convection takes place at the transmitter neck.
- ► Ensure that a sufficiently large area of the transmitter neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
- Consider the behavior of the process diagnostics "830 Ambient temperature too high" and "832 Electronics temperature too high" if overheating cannot be avoided by a suitable system design.

#### Heating options

If a medium requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters 1)
- Via pipes carrying hot water or steam
- Via heating jackets

#### **Vibrations**

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

<sup>1)</sup> The use of parallel electric band heaters is generally recommended (bidirectional electricity flow). Particular considerations must be made if a single-wire heating cable is to be used. Additional information is provided in the document EA01339D "Installation instructions for electrical trace heating systems".

#### 6.1.3 Special installation instructions

#### Drainability

When installed vertically, the measuring tubes can be drained completely and protected against buildup.

#### Hygienic compatibility

When installing in hygienic applications, please refer to the information in the "Certificates and approvals/hygienic compatibility" section  $\Rightarrow \triangleq 156$ 

#### Rupture disk

Process-related information:  $\rightarrow \blacksquare 150$ .


#### **WARNING**

#### Danger from medium escaping!

Medium escaping under pressure can cause injury or material damage.

- ► Take precautions to prevent danger to persons and damage if the rupture disk is actuated.
- ▶ Observe the information on the rupture disk sticker.
- Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- ▶ Do not use a heating jacket.
- ▶ Do not remove or damage the rupture disk.
- ▶ After the rupture disk is actuated, do not operate the measuring instrument any more.

The position of the rupture disk is indicated on a sticker applied over it. If the rupture disk is triggered, the sticker is destroyed. The disk can therefore be visually monitored.



A0032051

1 Rupture disk label

#### Zero point verification and zero adjustment

Experience shows that zero adjustment is advisable only in special cases:

- To achieve maximum measurement accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity media).
- For gas applications with low pressure.
- To achieve the highest possible measurement accuracy at low flow rates, the installation must protect the sensor from mechanical stress during operation.

To get a representative zero point, ensure that

- any flow in the device is prevented during the adjustment
- the process conditions (e.g. pressure, temperature) are stable and representative

Verification and adjustment cannot be performed if the following process conditions are present:

Gas pockets

Ensure that the system has been sufficiently flushed with the medium. Repeat flushing can help to eliminate gas pockets

■ Thermal circulation

In the event of temperature differences (e.g. between the measuring tube inlet and outlet section), induced flow can occur even if the valves are closed due to thermal circulation in the device

Leaks at the valves

If the valves are not leak-tight, flow is not sufficiently prevented when determining the zero point

If these conditions cannot be avoided, it is advisable to keep the factory setting for the zero point.

## 6.2 Installing the device

#### 6.2.1 Required tools

#### For transmitter

- For turning the transmitter housing: Open-ended wrench8 mm
- For opening the securing clamps: Allen key3 mm

#### For sensor

For flanges and other process connections: Use a suitable mounting tool.

#### 6.2.2 Preparing the measuring instrument

- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. If present, remove transport protection of the rupture disk.
- 4. Remove stick-on label on the electronics compartment cover.


#### 6.2.3 Installing the measuring instrument

#### **A** WARNING

## Danger due to improper process sealing!

- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the seals and sealing surfaces are clean and undamaged.
- ► Secure the seals correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the medium.


2. Install the measuring instrument or turn the transmitter housing so that the cable entries do not point upwards.



A0029263

#### 6.2.4 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




A0032242

- 1. Loosen the securing screw.
- 2. Turn the housing to the desired position.
- 3. Firmly tighten the securing screw.

#### 6.2.5 Turning the display module

The display module can be turned to optimize display readability and operability.



A0032238

- 1. Loosen the securing clamp of the electronics compartment cover using an Allen key.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Optional: pull out the display module with a gentle rotational movement.
- 4. Turn the display module to the desired position: Max.  $8 \times 45^{\circ}$  in each direction.
- 5. Without display module pulled out:
  Allow display module to engage at desired position.
- 6. With display module pulled out:

  Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.
- 7. Reassemble the transmitter in the reverse order.

26

## 6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring instrument correspond to the measuring point specifications?  For example:  Process temperature → 🖺 149  Pressure (refer to the "Pressure-temperature ratings" section of the "Technical Information" document).  Ambient temperature → 🖺 148  Measuring range	
<ul> <li>Has the correct orientation for the sensor been selected →</li></ul>	
Does the arrow on the sensor match the direction of flow of the medium? $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	
Is the tag name and labeling correct (visual inspection)?	
Is the device sufficiently protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

## 7 Electrical connection

## 7.1 Electrical safety

In accordance with applicable national regulations.

## 7.2 Connecting requirements

#### 7.2.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver ≤ 3 mm (0.12 in)

#### 7.2.2 Requirements for connection cable

The connecting cables provided by the customer must fulfill the following requirements.

#### Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.


#### Cable diameter

- Cable glands supplied: M20  $\times$  1.5 with cable  $\phi$  6 to 12 mm (0.24 to 0.47 in)
- Plug-in spring terminals for device version without integrated overvoltage protection: wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

## 7.2.3 Terminal assignment

#### **Transmitter**

Connection version for PROFIBUS PA, pulse/frequency/switch output



Order code for "Output"	Terminal numbers			
	Output 1		Output 2	
	1 (+)	2 (-)	3 (+)	4 (-)
Option G <sup>1) 2)</sup>	PROFIE	BUS PA	Pulse/frequency/switch output (passive)	

- 1) Output 1 must always be used; output 2 is optional.
- 2) PROFIBUS PA with integrated reverse polarity protection.

#### 7.2.4 Pin assignment of device plug

	Pin	Assignment		Coding	Plug/socket
2 / 3	1	+	PROFIBUS PA +	A	Plug
1 4	2		Grounding		
	3	-	PROFIBUS PA -		
	4		Not used		
	Met al plug hous ing		Cable shield		

## 7.2.5 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 % is ideal.

- 1. To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus quaranteed.


- 1. Observe national installation requirements and quidelines during installation.
- 2. Where there are large differences in potential between the individual grounding points,
  - connect only one point of the shielding directly to the reference ground.
- 3. In systems without potential equalization, the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

#### NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- ▶ Insulate the shield that is not connected.



■ 8 Connection example for PROFIBUS PA

- 1 Automation system (e.g. PLC)
- 2 PROFIBUS PA segment coupler
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring instrument
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

30

## 7.2.6 Requirements for the supply unit

#### Supply voltage

Transmitter

An external power supply is required for each output.

For installation in systems where the power unit is safety-approved (e.g. SELV/PELV Class 2 limited energy). Only one wire is permitted per terminal.

Order code for "Output"	Minimum Terminal voltage	Maximum Terminal voltage
Option G: PROFIBUS PA, pulse/frequency/switch output	≥ DC 9 V	DC 32 V


#### Load

Load for current output: 0 to  $500\,\Omega$ , depending on the external supply voltage of the power supply unit

Calculation of the maximum load

Depending on the supply voltage of the power supply unit ( $U_S$ ), the maximum load ( $R_B$ ) including line resistance must be observed to ensure adequate terminal voltage at the device. In doing so, observe the minimum terminal voltage

- For  $U_S = 17.9$  to 18.9 V:  $R_B \le (U_S 17.9$  V): 0.0036 A
- For  $U_S = 18.9$  to 24 V:  $R_B \le (U_S 13 \text{ V})$ : 0.022 A
- For  $U_S = 224 \text{ V}$ :  $R_B \le 500 \Omega$



- A Operating range for order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/ frequency/switch output" with Ex i and option C "4-20 mA HART + 4-20 mA analog"
- B Operating range for order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/ frequency/switch output" with non-Ex and Ex d

#### Sample calculation

Supply voltage of power supply unit:  $U_S = 19 \text{ V}$ Maximum load:  $R_B \le (19 \text{ V} - 13 \text{ V})$ :  $0.022 \text{ A} = 273 \Omega$ 

#### 7.2.7 Preparing the device

#### **NOTICE**

#### Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

▶ Use suitable cable glands corresponding to the degree of protection.

- 1. Remove dummy plug if present.
- 2. If the measuring instrument is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.

## 7.3 Connecting the device

#### NOTICE

#### An incorrect connection compromises electrical safety!


- ► Only properly trained specialist staff may perform electrical connection work.
- ▶ Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ⊕ before connecting additional cables.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

#### 7.3.1 Connecting the transmitter

The connection of the transmitter depends on the following order code: "Electrical connection":

- Option A, B, C, D: terminals
- Option I: device plug

#### Connection via terminals



- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit wire end ferrules.
- 5. Connect cable in accordance with terminal assignment  $\rightarrow \triangleq 29$ .

#### 6. NOTICE


#### Housing degree of protection voided due to insufficient sealing of the housing.

Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Firmly tighten the cable glands.


7. Reassemble the transmitter in the reverse order.

#### Connection via device plug



▶ Plug in the device plug and tighten firmly.

#### Removing a cable



To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes while simultaneously pulling the cable end out of the terminal.

#### 7.3.2 Potential equalization

#### Requirements


For potential equalization:

- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Connect the medium, sensor and transmitter to the same electric potential
- Use a ground cable with a minimum cross-section of 6 mm<sup>2</sup> (10 AWG) and a cable lug for potential equalization connections

## 7.4 Special connection instructions

## 7.4.1 Connection examples


#### Current output 4 to 20 mA (without HART)



■ 9 Connection example for 4 to 20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Optional additional display unit: Observe maximum load
- 4 Transmitter with current output (passive)

#### Pulse output/frequency output/switch output



■ 10 Connection example for pulse output/frequency output/switch output (passive)

- 1 Automation system with pulse input/frequency input/switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter with pulse output/frequency output/switch output (passive)

#### **PROFIBUS PA**


See https://www.profibus.com "PROFIBUS Installation Guidelines".

## 7.5 Hardware settings

#### 7.5.1 Setting the device address

#### **PROFIBUS PA**

The address must always be configured for a PROFIBUS DP/PA device. The valid address range is between 1 and 126. In a PROFIBUS DP/PA network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.



Address switch in the connection compartment; example of how to configure the device address 10.

#### Hardware addressing

- 1. Set switch 8 to the "OFF" position.
- 2. Set the address using switches 1 to 7.

The change of address takes effect after 10 seconds. The device is restarted.

#### *Software addressing* $\rightarrow$ $\stackrel{\triangle}{=}$ 64

- 1. Set switches 1 to 7 to the "OFF" position.
- 2. Set switch 8 to "ON".
  - The device restarts automatically and reports the current address (factory setting: 126).
- 3. Configure the address via the operating menu: **Setup** menu→**Communication** submenu→**Device address** parameter


## 7.6 Ensuring the degree of protection

#### 7.7 Post-connection check

Are the device and cable undamaged (visual inspection)?		
Do the cables used meet the requirements → 🖺 28?		
Are the mounted cables strain-relieved and fixed securely in place?		
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" → 🖺 35?		
Depending on the device version: Are all the device plugs firmly tightened $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $		
Does the supply voltage match the specifications on the transmitter nameplate?		
Is the terminal assignment correct ?		
Is the terminal assignment or the device plug pin assignment correct?		
If supply voltage is present: Does anything appear on the display module screen?		
Are all housing covers installed and firmly tightened?		
Is the securing clamp securely tightened?		

#### **Operation options** 8

#### Overview of operation options 8.1




- Local operation via display module Computer with operating tool (e.g. FieldCare, SIMATIC PDM)
- Automation system (e.g. PLC)

# 8.2 Structure and function of the operating menu

# 8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device



 $\blacksquare$  12 Schematic structure of the operating menu


# 8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (e.g. operator, maintenance etc.). Each user role contains typical tasks within the device life cycle.

Menu/pa	arameter	User role and tasks	Content/meaning
Language	Task-	Role "Operator", "Maintenance"	Defining the operating language
Operation	oriented	Tasks during operation:  Configuring the operational display Reading measured values	<ul> <li>Defining the operating language</li> <li>Resetting and controlling totalizers</li> <li>Configuring the operational display (e.g. display format, display contrast)</li> <li>Resetting and controlling totalizers</li> </ul>
Setup		<ul> <li>"Maintenance" role</li> <li>Commissioning:</li> <li>Configuring the measurement</li> <li>Configuring the inputs and outputs</li> </ul>	Wizard for quick commissioning:  Configuring the system units Defining the medium Configuring the outputs Configuring the operational display Defining the output conditioning Configuring the low flow cut off Configuring the detection of partially filled and empty pipes Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuring totalizers Administration (define access code, reset measuring instrument)
Diagnostics		"Maintenance" role Troubleshooting:  Diagnostics and elimination of process and device errors  Measured value simulation	Contains all parameters for error detection and analyzing process and device errors:  Diagnostic list Contains up to 5 currently pending diagnostic messages.  Event logbook Contains event messages that have occurred.  Device information Contains information for identifying the device.  Measured values Contains all current measured values.  Analog inputs Is used to display the analog input.  Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values  Heartbeat Technology The functionality of the device is checked on demand and the verification results are documented.  Simulation Used to simulate measured values or output values.  Testpoints
Expert	Function- oriented	Tasks that require detailed knowledge of the function of the device:  Commissioning measurements under difficult conditions  Optimal adaptation of the measurement to difficult conditions  Detailed configuration of the communication interface  Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:  System Contains all higher-level device parameters that do not affect measurement or measured value communication.  Sensor Configuring the measurement.  Output Configure the pulse/frequency/switch output.  Communication Configuring the digital communication interface.  Submenus for function blocks (e.g. "Analog Inputs") Configuring function blocks.  Application Configuring the functions that go beyond the actual measurement (e.g. totalizer).  Diagnostics Error detection and analysis of process and device errors and for device simulation and the Heartbeat Technology menu.

# 8.3 Access to operating menu via local display

### 8.3.1 Operational display



A002934

- 1 Operational display
- 2 Tag name
- 3 Status area
- 4 Display area for measured values (up to 4 lines)
- *5 Operating elements* → 🖺 44


### Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 103
  - **F**: Failure
  - **C**: Function check
  - **S**: Out of specification
  - M: Maintenance required
- Diagnostic behavior → 🖺 104
  - 🐼: Alarm
  - <u>M</u>: Warning
- 🖆: Locking (the device is locked via the hardware )
- ←: Communication (communication via remote operation is active)

### Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Appears only if a diagnostics event is present for this measured variable.

### Measured variables

Symbol	Meaning
ṁ	Mass flow
Ü	<ul><li>Volume flow</li><li>Corrected volume flow</li></ul>

ρ	<ul><li>Density</li><li>Reference density</li></ul>
å.	Temperature

The number and display format of the measured variables can be configured via the **Format display** parameter ( $\Rightarrow \triangleq 71$ ).

### Totalizer

Symbol	Meaning
Σ	Totalizer  The measurement channel number indicates which of the three totalizers is displayed.

### Measurement channel numbers


Symbol	Meaning
14	Measurement channel 1 to 4  The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).

### Diagnostic behavior

Symbol	Meaning	
8	Alarm  Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.	
Δ	<ul> <li>Warning</li> <li>Measurement is resumed.</li> <li>The signal outputs and totalizers are not affected.</li> <li>A diagnostic message is generated.</li> </ul>	

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.


# 8.3.2 Navigation view




### Navigation path

The navigation path to the current position is displayed at the top left in the navigation view and consists of the following elements:

- The display symbol for the menu/submenu (►) or the wizard (►).
- An omission symbol (/ ../) for operating menu levels in between.
- Name of the current submenu, wizard or parameter





### Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
  - The direct access code to the parameter (e.g., 0022-1)
  - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal



- For information on the diagnostic behavior and status signal  $\rightarrow \triangleq 103$

### Display area

#### Menus

Symbol	Meaning
P	Operation Is displayed: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu

۶	Setup Is displayed: ■ In the menu next to the "Setup" selection ■ At the left in the navigation path in the Setup menu
હ	Diagnosis Is displayed: ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the Diagnostics menu
3,€	Expert Is displayed: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

### Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
1>.	Wizards
Ø.	Parameters within a wizard  No display symbol exists for parameters in submenus.


### Locking procedure

Symbol	Meaning
û	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked.  By a user-specific access code  By the hardware write protection switch

### Wizards

Symbol	Meaning
<b>←</b>	Switches to the previous parameter.
<b>√</b>	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

#### **Editing view** 8.3.3



- Display area of the entered values
- Input mask

### Input screen

The following input symbols are available in the input mask of the numeric and text editor:

### Numeric editor

Symbol	Meaning
0	Selection of numbers from 0 to 9
9	
·	Inserts a decimal separator at the cursor position.
_	Inserts a minus sign at the cursor position.
4	Confirms the selection.
+	Moves the input position one position to the left.
X	Exits the input without applying the changes.
С	Clears all entered characters.

### Text editor

Symbol	Meaning
Aa1@	Toggle  Between upper-case and lower-case letters  For entering numbers  For entering special characters
ABC_  XYZ	Selection of letters from A to Z.
abc _  xyz	Selection of letters from a to z.
····^ ~&	Selection of special characters.
<b>√</b>	Confirms the selection.
€XC←→	Switches to the selection of the correction tools.
X	Exits the input without applying the changes.
С	Clears all entered characters.

### $Text\ correction\ under\ \checkmark c \leftrightarrow$

Symbol	Meaning
C	Clears all entered characters.

$\rightarrow$	Moves the input position one position to the right.	
€	Moves the input position one position to the left.	
<b>*</b>	Deletes one character immediately to the left of the input position.	

# 8.3.4 Operating elements

Operating key	Meaning
	Minus key
	In menu, submenu Moves the selection bar upwards in a picklist
	In wizards Goes to previous parameter
	In the text and numeric editor In the input screen, moves the selection bar to the left (backwards)
	Plus key
	In menu, submenu Moves the selection bar downwards in a picklist
(+)	In wizards Goes to the next parameter
	In the text and numeric editor In the input screen, moves the selection bar to the right (forwards)
	Enter key
	In the operational display Pressing the key for 2 s opens the context menu.
	<ul><li>In menu, submenu</li><li>Pressing the key briefly:</li><li>Opens the selected menu, submenu or parameter.</li></ul>
	<ul> <li>Starts the wizard.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul>
E	<ul><li>Pressing the key for 2 s in a parameter:</li><li>If present, opens the help text for the function of the parameter.</li></ul>
	In wizards Opens the editing view of the parameter and confirms the parameter value
	In the text and numeric editor
	<ul><li>Pressing the key briefly:</li><li>Opens the selected group.</li></ul>
	<ul> <li>Carries out the selected action.</li> <li>Pressing the key for 2 s confirms the edited parameter value.</li> </ul>
	Escape key combination (press keys simultaneously)
	In menu, submenu
	<ul><li>Pressing the key briefly:</li><li>Exits the current menu level and takes you to the next higher level.</li></ul>
-++	<ul> <li>If help text is open, closes the help text of the parameter.</li> <li>Pressing the key for 2 s returns you to the operational display ("home position").</li> </ul>
	In wizards Exits the wizard and takes you to the next higher level
	In the text and numeric editor Closes the text or numeric editor without applying changes.
+ + E	Plus/Enter key combination (press and hold down the keys simultaneously)
	Increases the contrast (darker setting).
	Minus/Plus/Enter key combination (press the keys simultaneously)
	In the operational display Enables or disables the keypad lock (only SD02 display module).

### 8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Configuration backup display
- Simulation

### Calling up and closing the context menu

The user is in the operational display.

- 1. Press the  $\Box$  and  $\Box$  keys for longer than 3 seconds.
  - ► The context menu opens.



40017/21 P

- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - The context menu is closed and the operational display appears.

### Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
  - The selected menu opens.

### 8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements  $\rightarrow \implies 41$ 

Example: Setting the number of displayed measured values to "2 values"




### 8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

### Navigation path

Expert → Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
   Example: Enter 00914 → Assign process variable parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter **00914-2** → **Assign process variable** parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


### 8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

### Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

- 1. Press E for 2 s.
  - ► The help text for the selected parameter opens.




A0014002-EN

- 13 Example: Help text for parameter "Enter access code"
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The help text is closed.

### 8.3.9 Changing the parameters

For a description of the editing view - consisting of the text editor and numeric editor - with symbols  $\rightarrow \triangleq 42$ , for a description of the operating elements  $\rightarrow \triangleq 44$ 

**Example:** Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0029563-EN

A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

A0014049-EN

### 8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access .

### Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
  - The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	<b>√</b> 1)

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	_ 1)

- Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection as they do not affect the measurement: write protection via access code
- The user role with which the user is currently logged on is indicated by the **Access** status display parameter. Navigation path: Operation  $\rightarrow$  Access status display

### 8.3.11 Disabling write protection via access code

If the  $\square$ -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation  $\rightarrow \square$  91.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter via the respective access option.

- 1. After you press 🗉, the input prompt for the access code appears.
- 2. Enter the access code.
  - ► The 🗈-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

### 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

### Switching on the keypad lock

### 🚹 For the SD03 display only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

### To activate the keylock manually:

1. The device is in the measured value display.

Press the  $\Box$  and  $\blacksquare$  keys for 3 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
  - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

### Switching off the keypad lock

- ► The keypad lock is switched on.
  - Press the  $\Box$  and  $\Box$  keys for 3 seconds.
  - ► The keypad lock is switched off.

# 8.4 Access to operating menu via web browser

### 8.4.1 Function range

For additional information on the web server, see the Special Documentation for the device.


### 8.4.2 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (factory setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

### 8.4.3 User interface



A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal  $\rightarrow \blacksquare 106$
- 6 Display area for current measured values
- 7 Editing toolbar with additional functions such as save/load, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Work area
- 10 Action area
- 11 Status area

### Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal → 🖺 106
- Current measured values

### **Function row**

Functions	Meaning	
Measured values	Displays the measured values of the measuring instrument	
Menu	<ul> <li>Access to the operating menu from the measuring instrument</li> <li>The structure of the operating menu is the same as for the local display</li> <li>Detailed information on the "Description of Device Parameters" operating menu</li> </ul>	
Device status	Displays the diagnostic messages currently pending, listed in order of priority	

Functions	Meaning	
Data management	Data exchange between computer and measuring instrument:  Device configuration:  Load settings from the device (XML format, save configuration)  Save settings to the device (XML format, restore configuration)  Documents - Export documents:  Export backup data record (.csv file, create documentation of the measuring point configuration)  Verification report (PDF file, only available with the "Heartbeat Verification" application package)  File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring instrument: PROFIBUS PA: GSD file	
Network	Configuration and checking of all the parameters required for establishing the connection to the measuring instrument:  Network settings (e.g. IP address, MAC address)  Device information (e.g. serial number, firmware version)	
Logout	End the operation and call up the login page	

### Navigation area

The menus, the associated submenus and parameters can be selected in the navigation area.

### Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

### 8.4.4 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

### **Navigation**

"Expert" menu  $\rightarrow$  Communication  $\rightarrow$  Web server

### Parameter overview with brief description

Parameter	Description	Selection
Web server functionality	Switch the Web server on and off.	• Off • On

### Function scope of the "Web server functionality" parameter

Option	Description
Off	<ul><li>The Web server is completely disabled.</li><li>Port 80 is locked.</li></ul>
On	<ul> <li>The complete Web server functionality is available.</li> <li>JavaScript is used.</li> <li>The password is transferred in an encrypted state.</li> <li>Any change to the password is also transferred in an encrypted state.</li> </ul>

### Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

# 8.4.5 Logging out

- Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.
- 1. Select the **Logout** entry in the function row.
  - ► The home page with the Login box appears.
- 2. Close the Web browser.
- 3. If no longer needed:

  Reset the modified properties of the Internet protocol (TCP/IP).


# 8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

# 8.5.1 Connecting the operating tool

#### Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.




■ 14 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring instrument

Endress+Hauser 53

A0028838

### Via service interface (CDI)



A001401

- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring instrument
- 2 Commubox FXA291
- 3 Computer with FieldCare operating tool with COM DTM CDI Communication FXA291

### 8.5.2 FieldCare

### **Function range**

FDT-based (Field Device Technology) plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

### Access is via:


- PROFIBUS PA protocol → 🖺 53
- CDI service interface → 🖺 54

### Typical functions:

- Transmitter parameter configuration
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



- Operating Instructions BA00027S
- Operating Instructions BA00059S



### 8.5.3 DeviceCare

### **Function range**

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.

Innovation brochure IN01047S

Source for device description files  $\rightarrow \triangleq 56$ 

### 8.5.4 SIMATIC PDM

### **Function** range

Standardized, vendor-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via the PROFIBUS PA protocol.

Source for device description files  $\rightarrow \triangleq 56$ 

# 9 System integration

# 9.1 Overview of device description files

### 9.1.1 Current version data for the device

Firmware version	01.01.zz	<ul> <li>On the title page of the manual</li> <li>On the transmitter nameplate → □ 15</li> <li>Parameter Firmware version parameter Diagnostics → Device information → Firmware version</li> </ul>
Release date of firmware version	06.2015	
Manufacturer ID	0x11	Parameter <b>Manufacturer ID</b> parameter Diagnostics → Device information → Manufacturer ID
Device type code	0x155F	Device type Diagnostics → Device information → Device type
Profile version	3.02	

For an overview of the various firmware versions for the device  $\rightarrow \stackrel{\triangle}{=} 128$ 

# 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via PROFIBUS protocol	Sources for obtaining device descriptions
FieldCare	<ul> <li>www.endress.com → Downloads area</li> <li>USB stick (contact Endress+Hauser)</li> <li>E-mail → Downloads area</li> </ul>
DeviceCare	<ul> <li>www.endress.com → Downloads area</li> <li>E-mail → Downloads area</li> </ul>
SIMATIC PDM (Siemens)	www.endress.com → Downloads area

# 9.2 Device master file (GSD)

In order to integrate field devices into a bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate.

These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned. In addition device bit maps, which appear as icons in the network structure, can also be integrated.

With the Profile 3.0 device master file (GSD) it is possible to exchange field devices made by different manufacturers without having to reconfigure.

Generally speaking two different GSD versions are possible with Profile 3.0 and higher.

• Before configuring, the user must decide which GSD should be used to operate the system.

• The setting can be changed via a Class 2 master.

### 9.2.1 Manufacturer-specific GSD

This GSD guarantees the unrestricted functionality of the measuring device. Device-specific process parameters and functions are therefore available.

Manufacturer-specific GSD	ID number	File name
PROFIBUS PA	0x1564	EH3x1564.gsd

The fact that the manufacturer-specific GSD should be used is specified in the **Ident number selector** parameter by selecting the **Manufacturer** option.



Where to acquire the manufacturer-specific GSD:

www.endress.com → Downloads area

### 9.2.2 Profile GSD

Differs in terms of the number of Analog Input blocks (AI) and the measured values. If a system is configured with a Profile GSD, it is possible to exchange devices made by different manufacturers. However, it is essential to ensure that the order of the cyclic process values is correct.

ID number	Supported blocks	Supported channels
0x9740	<ul><li>1 Analog Input</li><li>1 Totalizer</li></ul>	<ul><li>Channel Analog Input: volume flow</li><li>Channel totalizer: volume flow</li></ul>
0x9741	<ul><li>2 Analog Input</li><li>1 Totalizer</li></ul>	<ul> <li>Channel Analog Input 1: volume flow</li> <li>Channel Analog Input 2: mass flow</li> <li>Channel totalizer: volume flow</li> </ul>
0x9742	<ul><li>3 Analog Input</li><li>1 Totalizer</li></ul>	<ul> <li>Channel Analog Input 1: volume flow</li> <li>Channel Analog Input 2: mass flow</li> <li>Channel Analog Input 3: corrected volume flow</li> <li>Channel totalizer: volume flow</li> </ul>

The Profile GSD that is to be used is specified in the **Ident number selector** parameter by selecting the **Profile 0x9740** option, **Profile 0x9741** option or **Profile 0x9742** option.

# 9.3 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

### 9.3.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a PROFIBUS master (Class 1), e.g. a control system.

Measuring instrument					Control system
	Analog Input block 1 to 6	→ 🖺 58	Output value AI	$\rightarrow$	
			Output value TOTAL	$\rightarrow$	
Transducer	Totalizer block 1 to 3	→ 🖺 59	Controller SETTOT	<b>←</b>	
Block			Configuration MODETOT	<b>←</b>	PROFIBUS PA
	Analog Output block 1	→ 🖺 61	Input values AO	<b>←</b>	
	Discrete Input block 1 to 2	→ 🖺 61	Output values DI	<b>→</b>	

Discrete Output block 1 to 4	→ 🖺 62	Input values DO	+	

#### Defined order of modules

The measuring device works as a modular PROFIBUS slave. In contrast to a compact slave, a modular slave has a variable design and consists of several individual modules. The device master file (GSD) contains a description of the individual modules (input and output data) along with their individual properties.

The modules are permanently assigned to the slots, i.e. when configuring the modules, the order and the arrangement of the modules must be respected.

Slot	Module	Function block
16	AI	Analog Input block 1 to 4
7	TOTAL or	Totalizer block 1
8	SETTOT_TOTAL or	Totalizer block 2
9	SETOT_MODETOT_TOTAL	Totalizer block 3
10	AO	Analog Output block 1
1112	DI	Discrete Input block 1 to 2
13 16	DO	Discrete Output block 1 to 3

To optimize the data throughput rate of the PROFIBUS network, it is advisable to only configure modules that are processed in the PROFIBUS master system. If this results in gaps between the configured modules, these gaps must be assigned to the EMPTY\_MODULE.

# 9.3.2 Description of the modules

The data structure is described from the perspective of the PROFIBUS master:

- Input data: Are sent from the measuring device to the PROFIBUS master.
- Output data: Are sent from the PROFIBUS master to the measuring device.

### AI module (Analog Input)

Transmit an input variable from the measuring device to the PROFIBUS master (Class 1).

The selected input variable including its status is cyclically transmitted to the PROFIBUS master (Class 1) via the AI module. The input variable is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Four Analog Input blocks are available (slot 1 to 6).

Selection: input variable

The input variable can be determined using the **Channel** parameter.

Channel	Input variable	
32961	Mass flow	
33122	Volume flow	
33093	O93 Corrected volume flow	
32850 Density		
33092 Reference density		
33101 Temperature		

### Factory setting

Function block	Factory setting
AI 1 Volume flow	
AI 2	Mass flow
AI 3	Corrected volume flow
AI 4	Density
AI 5	Reference density
AI 6	Temperature

#### Data structure

### Input data of Analog Input

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	Measured value: floating point number (IEEE 754)		EEE 754)	Status

### TOTAL module

Transmit a totalizer value from the measuring device to the PROFIBUS master (Class 1).

A selected totalizer value, along with the status, is cyclically transmitted to a PROFIBUS Master (Class 1) via the TOTAL module. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the totalizer value.

Three Totalizer blocks are available (slot 7 to 9).

Selection: totalizer value

The totalizer value can be specified using the CHANNEL parameter.

Channel	Input variable
32961	Mass flow
33122	Volume flow
33093	Corrected volume flow

### Factory setting

Function block	Factory setting: TOTAL
Totalizer 1, 2 and 3	Volume flow

### Data structure

### Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	Measured value: floating point number (I		EEE 754)	Status

### SET\_TOT\_TOTAL module

The module combination consists of the SET\_TOT and TOTAL functions:

- SETTOT: Control the totalizers via the PROFIBUS master.
- TOTAL: Transmit totalizer value incl. status to PROFIBUS master.

Three totalizer blocks are available (slot 7 to 9).

Selection: control totalizer

Value SETTOT	Control totalizer
0	Totalize
1	Reset + hold
2	Preset + hold

### Factory setting

Function block	Factory setting: Value SETTOT (meaning)
Totalizer 1, 2 and 3	0 (totalizing)

#### Data structure

### Output data of SETTOT

Byte 1	
Control variable 1	

### Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measured value: floating point number (IEE		EEE 754)	Status	

### SETTOT\_MODETOT\_TOTAL module

The module combination consists of the SETTOT, MODETOT and TOTAL functions:

- SETTOT: Control the totalizers via the PROFIBUS master.
- MODETOT: Configure the totalizers via the PROFIBUS master.
- TOTAL: Transmit totalizer value, along with the status, to the PROFIBUS master.

Three totalizer blocks are available (slot 7 to 9).

Selection: totalizer configuration

MODETOT value	Totalizer configuration
0	Balancing
1	Balance the positive flow
2	Balance the negative flow
3	Stop totalizing

### Factory setting

Function block	Factory setting: Value MODETOT (meaning)
Totalizer 1, 2 and 3	0 (balancing)

#### Data structure

#### Output data of SETTOT and MODETOT

Byte 1	Byte 2
Control variable 1: SETTOT	Control variable 2: MODETOT

### Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status

### AO module (Analog Output)

Transmit a compensation value from the PROFIBUS master (class 1) to the measuring device.

A compensation value, including the status, is cyclically transmitted from the PROFIBUS master (class 1) to the measuring device via the AO module. The compensation value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the compensation value.

One Analog Output block is available (slot 10).

### Assigned compensation values

A compensation value is permanently assigned to the individual Analog Output blocks.

CHANNEL	Function block	Compensation value
306	AO 1	External pressure <sup>1)</sup>

- 1) The compensation values must be transmitted to the device in the SI basic unit
- The selection is made via: Expert  $\rightarrow$  Sensor  $\rightarrow$  External compensation

### Data structure

### Output data of Analog Output

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status 1)

### Status coding

### DI module (Discrete Input)

Transmit discrete input values from the measuring device to the PROFIBUS master (class 1). Discrete input values are used by the measuring device to transmit the state of device functions to the PROFIBUS master (class 1).

The DI module cyclically transmits the discrete input value, including the status, to the PROFIBUS master (class 1). The discrete input value is depicted in the first byte. The second byte contains standardized status information pertaining to the input value.

Two Discrete Input blocks are available (slot 11 to 12).

Selection: device function

The device function can be specified using the CHANNEL parameter.

CHANNEL	Device function	Factory setting: Status (meaning)
893	Status switch output	
894	Empty pipe detection	■ 0 (device function not active)
895	Low flow	■ 1 (device function active)
1430	Verification status 1)	

1) Only available with the Heartbeat Verification application package

### Factory setting

Function block	Factory setting
DI 1	Empty pipe detection
DI 2	Low flow

### Data structure

### Input data of Discrete Input

Byte 1	Byte 2
Discrete	Status

### **DO module (Discrete Output)**

Transmit discrete output values from the PROFIBUS master (class 1) to the measuring device. Discrete output values are used by the PROFIBUS master (class 1) to enable and disable device functions.

The DO module cyclically transmits the discrete output value, including the status, to the measuring device. The discrete output value is depicted in the first byte. The second byte contains standardized status information pertaining to the output value.

Four Discrete Output blocks are available (slot 13 to 16).

### *Assigned device functions*

A device function is permanently assigned to the individual Discrete Output blocks.

CHANNEL	Function block	Device function	Values: control (meaning)
891	DO 1	Flow override	
890	DO 2	Zero adjustment	■ 0 (disable device function)
253	DO 3	Pulse/freq./switch output	• 1 (enable device function)
1429	DO 4	Start verification 1)	

 $\hbox{1)} \qquad \hbox{Only available with the Heartbeat Verification application package} \\$ 

### Data structure

### Output data of Discrete Output

Byte 1	Byte 2
Discrete	Status

### EMPTY\_MODULE module

This module is used to assign empty spaces arising from modules not being used in the slots.

The measuring device works as a modular PROFIBUS slave. In contrast to a compact slave, a modular PROFIBUS slave has a variable design and consists of several individual modules. The GSD file contains a description of the individual modules along with their individual properties.

The modules are permanently assigned to the slots. When configuring the modules, it is absolutely essential to observe the sequence/arrangement of the modules. Any gaps between the configured modules must be filled with the EMPTY MODULE.

# 10 Commissioning

# 10.1 Post-installation and post-connection check

Before commissioning the device:

- ► Make sure that the post-installation and post-connection checks have been performed successfully.
- Checklist for "Post-installation" check → 🗎 27
- Checklist for "Post-connection" check → 🗎 35

# 10.2 Switching on the measuring instrument

- Switch on the device upon successful completion of the post-mounting and postconnection check.
  - After a successful startup, the local display switches automatically from the startup display to the operational display.

# 10.3 Configuring the device address via software

In the "Communication" submenu the device address can be set.

### **Navigation**

"Setup" menu → Communication → Device address

### 10.3.1 PROFIBUS network

At time of delivery, the measuring device has the following factory setting:


Device address	126



- To display the current device address: **Device address** parameter → 🖺 69
- If hardware addressing is active, software addressing is blocked

# 10.4 Setting the operating language


Factory setting: English or ordered local language




■ 15 Taking the example of the local display


#### Configuring the device 10.5

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.




Navigation to the "Setup" menu using the example of the local display





# 10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



■ 17 Header of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool

### Navigation

"Setup" menu  $\rightarrow$  Device tag

### Parameter overview with brief description

Parameter	Description	User entry
Device tag	3.1	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

### 10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

 $\begin{array}{l} \textbf{Navigation} \\ \text{"Setup" menu} \rightarrow \text{System units} \end{array}$ 

► System units			
	Mass flow unit		→ 🖺 67
		J	
	Mass unit		→ 🖺 67
	Volume flow unit		→ 🖺 67
	volume now unit		, = 0,
	Volume unit		→ 🖺 67
	volume unit		/ 🗏 0/
			) F) (0
	Corrected volume flow unit		→ 🖺 68
		1	
	Corrected volume unit		→ 🖺 68
		1	
	Density unit		→ 🖺 68
		•	
	Reference density unit		→ 🖺 68
		I	
	Temperature unit		→ 🖺 68
	Length unit		
	Pressure unit		→ 🖺 68
	11court unit		, <u> </u>

### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit.  Effect  The selected unit applies to:  Output  Low flow cut off Simulation process variable	Unit choose list	Country-specific:     kg/h     lb/min
Mass unit	Select mass unit.	Unit choose list	Country-specific:     kg     lb
Volume flow unit	Select volume flow unit.  Effect  The selected unit applies to:  Output  Low flow cut off Simulation process variable	Unit choose list	Country-specific:  l/h gal/min (us)
Volume unit	Select volume unit.	Unit choose list	Country-specific:  • 1 (DN > 150 (6"): m³ option)  • gal (us)


Parameter	Description	Selection	Factory setting
Corrected volume flow unit	Select corrected volume flow unit.  Effect  The selected unit applies to:  Corrected volume flow parameter  (→   96)	Unit choose list	Country-specific: NI/h Sft³/min
Corrected volume unit	Select corrected volume unit.	Unit choose list	Country-specific: NI Sft³
Reference density unit	Select reference density unit.	Unit choose list	Country-specific • kg/Nl • lb/Sft <sup>3</sup>
Density unit	Select density unit.  Effect  The selected unit applies to:  Output Simulation process variable Density adjustment (Expert menu)	Unit choose list	Country-specific:  • kg/l  • lb/ft <sup>3</sup>
Density 2 unit	Select second density unit.	Unit choose list	Country-specific:  • kg/l • lb/ft³
Temperature unit	Select temperature unit.  Effect  The selected unit applies to:  Minimum value  Maximum value  Maximum value  Minimum value  Average value  Minimum value  Maximum value  Maximum value  Maximum value  Reference temperature	Unit choose list	Country-specific:
Pressure unit	Select process pressure unit.  Effect  The unit is taken from:  ■ Pressure value parameter (→ 🖺 69)  ■ External pressure parameter	Unit choose list	Country-specific:  • bar a  • psi a

# 10.5.3 Selecting and setting the medium

The **Medium selection** wizard systematically guides the user through all the parameters that must be configured in order to select and set the medium.

### Navigation

"Setup" menu  $\rightarrow$  Medium selection



### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Select medium	-	Select medium type.	<ul><li>Liquid</li><li>Gas</li></ul>	-
Select gas type	In the <b>Select medium</b> parameter the <b>Gas</b> option is selected.	Select measured gas type.	Gas type choose list	-
Reference sound velocity	In the <b>Select gas type</b> parameter the <b>Others</b> option is selected.	Enter sound velocity of gas at 0 $^{\circ}$ C (32 $^{\circ}$ F).	1 to 99999.9999 m/s	-
Temperature coefficient sound velocity	In the <b>Select gas type</b> parameter the <b>Others</b> option is selected.	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	-
Pressure compensation	-	Select pressure compensation type.	<ul><li>Off</li><li>Fixed value</li><li>External value</li></ul>	-
Pressure value	In the <b>Pressure compensation</b> parameter the <b>Fixed value</b> option is selected.	Enter process pressure to be used for pressure correction.	Positive floating- point number	Country-specific:  1.01 bar a  14.7 psi a

### 10.5.4 Configuring communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

### Navigation

"Setup" menu → Communication



### Parameter overview with brief description


Parameter	Description	User entry	
Device address	Enter device address.	0 to 126	

# 10.5.5 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

### Navigation

"Setup" menu → Display



# Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> </ul>	-
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  Okg/h  Olb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see  Value 1 display  parameter (→ 🗎 71)	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see  Value 1 display  parameter (→ 🖺 71)	-
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  Okg/h Olb/min
100% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🗎 71)	-
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🗎 71)	-
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🗎 71)	-
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🗎 71)	-
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🖺 71)	-

# 10.5.6 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

### Navigation

"Setup" menu  $\rightarrow$  Low flow cut off



# Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	<ul><li> Off</li><li> Mass flow</li><li> Volume flow</li><li> Corrected volume flow</li></ul>	-
On value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \implies 72$ ).	Enter off value for low flow cut off.	0 to 100.0 %	_
Pressure shock suppression	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \implies 72$ ).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	-


72

### 10.5.7 Partially filled pipe detection

The **Partial filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

#### Navigation

"Setup" menu  $\rightarrow$  Partially filled pipe detection



### Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for partially filled pipe detection.	<ul><li>Off</li><li>Density</li><li>Reference density</li></ul>	-
Low value partial filled pipe detection	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \blacksquare 73$ ).	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Depends on country:  • 200 kg/m <sup>3</sup> • 12.5 lb/ft <sup>3</sup>
High value partial filled pipe detection	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \implies 73$ ).	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Depends on country:  • 6 000 kg/m <sup>3</sup> • 374.6 lb/ft <sup>3</sup>
Response time part. filled pipe detect.	A process variable is selected in the <b>Assign process variable</b> parameter (→ 🖺 73).	Use this function to enter the minimum time (hold time) the signal must be present before diagnostic message S962 "Pipe only partly filled" is triggered in the event of a partially filled or empty measuring pipe.	0 to 100 s	-

### 10.5.8 Configuring the partial filled pipe detection

The **Partial filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

#### Navigation

"Setup" menu  $\rightarrow$  Partially filled pipe detection



### Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry
Assign process variable	-	Select process variable for partially filled pipe detection.	<ul><li>Off</li><li>Density</li><li>Reference density</li></ul>
Low value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter:  Density Reference density	Enter lower limit value for deactivating partialy filled pipe detection.	Positive floating-point number
High value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter:  Density Reference density	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number
Response time part. filled pipe detect.	One of the following options is selected in the Assign process variable parameter:  Density Reference density	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s

74

### 10.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.


Navigation to the "Advanced setup" submenu



### Navigation

"Setup" menu  $\rightarrow$  Advanced setup

► Advanced setup	
Enter access code	
► Sensor adjustment	→ 🖺 76
► Pulse/frequency/switch output	→ 🖺 79
► Totalizer 1 to n	→ 🖺 83
► Display	→ 🖺 85




### 10.6.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

#### Navigation

"Setup" menu → Advanced setup → Sensor adjustment



#### Parameter overview with brief description

Parameter	Description	Selection
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<ul><li>Flow in arrow direction</li><li>Flow against arrow direction</li></ul>

#### Zero verification and zero adjustment

Experience shows that zero adjustment is advisable only in special cases:

- To achieve maximum measurement accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity media).
- For gas applications with low pressure.
- To achieve the highest possible measurement accuracy at low flow rates, the installation must protect the sensor from mechanical stress during operation.

To get a representative zero point, ensure that:

- any flow in the device is prevented during the adjustment
- the process conditions (e.g. pressure, temperature) are stable and representative

76


Zero verification and zero adjustment cannot be performed if the following process conditions are present:

- Gas pockets
   Ensure that the system has been sufficiently flushed with the medium. Repeat flushing can help to eliminate gas pockets
- Thermal circulation
  In the event of temperature differences (e.g. between the measuring tube inlet and outlet section), induced flow can occur even if the valves are closed due to thermal circulation in the device
- Leaks at the valves
   If the valves are not leak-tight, flow is not sufficiently prevented when determining the zero point

If these conditions cannot be avoided, it is advisable to keep the factory setting for the zero point.

#### Navigation

"Setup" menu → Advanced setup → Sensor adjustment → Zero point adjustment



#### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface
Zero point adjustment control	-	Start zero point adjustment.	<ul><li>Cancel</li><li>Busy</li><li>Zero point adjust failure</li><li>Start</li></ul>
Adjustment in progress	In the <b>Zero point adjustment control</b> parameter, the <b>Start</b> option is selected.		0 to 100 %

### 10.6.2 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

#### **Navigation**

"Setup" menu → Pulse/frequency/switch output



Parameter	Description	Selection
Operating mode	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>

### Configuring the pulse output

### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Pulse/frequency/switch output

▶ Pulse/frequency/switch output	
Operating mode	→ 🗎 78
Assign pulse output	→ 🖺 78
Value per pulse	→ 🖺 78
Pulse width	→ 🖺 78
Failure mode	→ 🖺 79
Invert output signal	→ 🖺 79

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	-
Assign pulse output	The <b>Pulse</b> option is selected in <b>Operating mode</b> parameter.	Select process variable for pulse output.	<ul><li> Off</li><li> Mass flow</li><li> Volume flow</li><li> Corrected volume flow</li></ul>	-
Value per pulse	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 78) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🖺 78).	Enter measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 78) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🖺 78).	Define time width of the output pulse.	5 to 2 000 ms	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Failure mode	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 78) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🖺 78).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>No pulses</li></ul>	-
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	_

### Configuring the frequency output

### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Pulse/frequency/switch output

► Pulse/frequency/switch output	
Operating mode	→ 🖺 80
Assign frequency output	→ 🖺 80
Minimum frequency value	→ 🖺 80
Maximum frequency value	→ 🖺 80
Measuring value at minimum frequency	→ 🖺 80
Measuring value at maximum frequency	→ 🖺 80
Failure mode	→ 🖺 80
Failure frequency	→ 🖺 81
Invert output signal	→ 🖺 81

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	-
Assign frequency output	The <b>Frequency</b> option is selected in <b>Operating mode</b> parameter (→ 🖺 78).	Select process variable for frequency output.	Off     Mass flow     Volume flow     Corrected volume flow     Density     Reference density     Temperature     Carrier pipe temperature     Electronic temperature     Oscillation frequency     Oscillation amplitude     Oscillation damping     Signal asymmetry	-
Minimum frequency value	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 78$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\rightarrow \trianglerighteq 80$ ).	Enter minimum frequency.	0 to 1000 Hz	0 Hz
Maximum frequency value	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter $( \rightarrow ) \cong 78)$ and a process variable is selected in the <b>Assign frequency output</b> parameter $( \rightarrow ) \cong 80)$ .	Enter maximum frequency.	0 to 1000 Hz	1000 Hz
Measuring value at minimum frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\Rightarrow \implies 78$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\Rightarrow \implies 80$ ).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 78$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\rightarrow \boxminus 80$ ).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 78) and a process variable is selected in the <b>Assign frequency output</b> parameter (→ 🖺 80).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>Defined value</li><li>0 Hz</li></ul>	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Failure frequency	In the <b>Operating mode</b> parameter (→ □ 78), the <b>Frequency</b> option is selected, in the <b>Assign frequency output</b> parameter (→ □ 80) a process variable is selected, and in the <b>Failure mode</b> parameter, the <b>Defined value</b> option is selected.	Enter frequency output value in alarm condition.	0.0 to 1250.0 Hz	_
Invert output signal	_	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

### Configuring the switch output

### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Pulse/frequency/switch output

► Pulse/frequency/switch output		
Operating mode		→ 🖺 82
Switch output fu	nction	→ 🖺 82
Assign diagnosti	c behavior	→ 🖺 82
Assign limit		→ 🖺 82
Assign flow dire	ction check	→ 🖺 82
Assign status		→ 🖺 82
Switch-on value		→ 🖺 82
Switch-off value		→ 🖺 82
Switch-on delay		→ 🖺 82
Switch-off delay		→ 🖺 83
Failure mode		→ 🖺 83
Invert output sig	nal	→ 🖺 83

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	-
Switch output function	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Select function for switch output.	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Status</li> </ul>	_
Assign diagnostic behavior	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Diagnostic behavior option is selected.</li> </ul>	Select diagnostic behavior for switch output.	<ul><li>Alarm</li><li>Alarm or warning</li><li>Warning</li></ul>	-
Assign limit	<ul> <li>The Switch option is selected in Operating mode parameter.</li> <li>The Limit option is selected in Switch output function parameter.</li> </ul>	Select process variable for limit function.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> </ul>	-
Assign flow direction check	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Flow direction check option is selected in the Switch output function parameter.</li> </ul>	Select process variable for flow direction monitoring.		_
Assign status	<ul> <li>The Switch option is selected in Operating mode parameter.</li> <li>The Status option is selected in Switch output function parameter.</li> </ul>	Select device status for switch output.	<ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> <li>Digital output 3</li> </ul>	-
Switch-on value	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Enter measured value for the switch-on point.	Signed floating-point number	Depends on country:  • 0 kg/h  • 0 lb/min
Switch-off value	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Enter measured value for the switch-off point.	Signed floating-point number	Depends on country:  • 0 kg/h  • 0 lb/min
Switch-on delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-on of status output.	0.0 to 100.0 s	-


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Switch-off delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-off of status output.	0.0 to 100.0 s	-
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	-
Invert output signal	-	Invert the output signal.	■ No ■ Yes	_

### 10.6.3 Configuring the totalizer

In the "Totalizer 1 to n" submenu, you can configure the specific totalizer.

### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Totalizer 1 to n



### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	<ul><li>Mass flow</li><li>Volume flow</li><li>Corrected volume flow</li></ul>	-
Unit totalizer	One of the following options is selected in the Assign process variable parameter:  Mass flow Volume flow Corrected volume flow	Select the unit for the process variable of the totalizer.	Unit choose list	Country-specific:  • kg • lb
Control Totalizer	One of the following options is selected in the Assign process variable parameter:  • Mass flow  • Volume flow  • Corrected volume flow	Control the totalizer value.	<ul><li>Totalize</li><li>Reset + hold</li><li>Preset + hold</li></ul>	-

Parameter	Prerequisite	Description	Selection	Factory setting
Totalizer operation mode	In the Assign process variable parameter, one of the following options is selected:  Mass flow  Volume flow Corrected volume flow	Select totalizer calculation mode.	<ul> <li>Net flow total</li> <li>Forward flow total</li> <li>Reverse flow total</li> <li>Last valid value</li> </ul>	_
Failure mode	In the Assign process variable parameter, one of the following options is selected:  Mass flow  Volume flow Corrected volume flow	Define the totalizer behavior in the event of a device alarm.	<ul><li>Stop</li><li>Actual value</li><li>Last valid value</li></ul>	-

### 10.6.4 Carrying out additional display configurations

In the  $\bf Display$  submenu you can set all the parameters associated with the configuration of the local display.

### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Display

Format display	→ 🖺 86
Value 1 display	→ 🖺 86
0% bargraph value 1	→ 🖺 86
100% bargraph value 1	→ 🖺 86
Decimal places 1	→ 🖺 86
Value 2 display	→ 🖺 86
Decimal places 2	→ 🖺 86
Value 3 display	→ 🖺 86
0% bargraph value 3	→ 🖺 86
100% bargraph value 3	→ 🖺 86
Decimal places 3	→ 🖺 86
Value 4 display	→ 🖺 86
Decimal places 4	→ 🖺 86
Language	→ 🖺 87
Display interval	→ 🖺 87
Display damping	→ 🖺 87
Header	→ 🖺 87
Header text	→ 🖺 87
Separator	→ 🖺 87
Backlight	→ 🖺 87
	Value 1 display  0% bargraph value 1  100% bargraph value 1  Decimal places 1  Value 2 display  Decimal places 2  Value 3 display  0% bargraph value 3  100% bargraph value 3  Decimal places 3  Value 4 display  Decimal places 4  Language  Display interval  Display damping  Header  Header text  Separator

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> </ul>	-
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  Okg/h Olb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the <b>Value 1 display</b> parameter.	Select the number of decimal places for the display value.	X     X.X     X.XX     X.XXX     X.XXXX	-
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🖺 71)	-
Decimal places 2	A measured value is specified in the <b>Value 2 display</b> parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see <b>Value 1 display</b> parameter (→ 🗎 71)	-
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  0 kg/h 0 lb/min
100% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Decimal places 3	A measured value is specified in the <b>Value 3 display</b> parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXXX	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🖺 71)	-
Decimal places 4	A measured value is specified in the <b>Value 4 display</b> parameter.	Select the number of decimal places for the display value.	• x • x.x • x.xx • x.xxx • x.xxx	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Language	A local display is provided.	Set display language.	■ English ■ Deutsch* ■ Français* ■ Español* ■ Italiano* ■ Nederlands* ■ Portuguesa* ■ Polski* ■ русский язык (Russian)* ■ Svenska* ■ Türkçe* ■ 中文 (Chinese)* ■ 日本語 (Japanese)* ■ 한국어 (Korean)* ■ tiếng Việt (Vietnamese)* ■ čeština (Czech)*	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	_
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	_
Header	A local display is provided.	Select header contents on local display.	<ul><li>Device tag</li><li>Free text</li></ul>	-
Header text	The <b>Free text</b> option is selected in the <b>Header</b> parameter.	Enter display header text.	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	-
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	<ul><li>. (point)</li><li>, (comma)</li></ul>	. (point)
Backlight	Order code for "Display; operation", option <b>E</b> "SD03 4- line, illum.; touch control + data backup function"	Switch the local display backlight on and off.	<ul><li>Disable</li><li>Enable</li></ul>	-


<sup>\*</sup> Visibility depends on order options or device settings

### 10.6.5 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

### **Navigation**

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration



#### Parameter overview with brief description

Parameter	Description	User entry / Selection
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes via the local display.	0 to 9999
Confirm access code	Confirm the entered access code.	0 to 9999
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul> <li>Cancel</li> <li>To fieldbus defaults</li> <li>To factory defaults</li> <li>To delivery settings</li> <li>Restart device</li> </ul>


Visibility depends on communication

### 10.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. The device configuration is managed via the **Configuration management** parameter.

#### **Navigation**

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Configuration backup display



Parameter	Prerequisite	Description	User interface / Selection
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Last backup	A local display is provided.	Indicates when the last data backup was saved to the display module.	Days (d), hours (h), minutes (m) and seconds (s)
Configuration management	A local display is provided.	Select action for managing the device data in the display module.	<ul> <li>Cancel</li> <li>Execute backup</li> <li>Restore</li> <li>Duplicate</li> <li>Compare</li> <li>Clear backup data</li> </ul>
Comparison result	A local display is provided.	Comparison between present device data and display backup.	<ul> <li>Settings identical</li> <li>Settings not identical</li> <li>No backup available</li> <li>Backup settings corrupt</li> <li>Check not done</li> <li>Dataset incompatible</li> </ul>

### 10.7.1 Function range of "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the display module of the device. The backup copy includes the transmitter data of the device.
Restore	The complete backup data from the original device is restored. This option may be used only with the original device and not with another device. The comparison function must be used to verify the serial numbers before the restore option can be used.
Compare	The device configuration saved in the display module is compared with the current device configuration of the HistoROM backup.
Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
Clear backup data	The backup copy of the device configuration is deleted from the display module of the device.

### HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

### 10.8 Simulation

Via the **Simulation** submenu, it is possible to simulate various process variables in the process and the device alarm mode and verify downstream signal chains (switching valves or closed-control loops). The simulation can be performed without a real measurement (no flow of medium through the device).

 $\begin{tabular}{ll} \textbf{Navigation} \\ "Diagnostics" menu $\rightarrow$ Simulation \\ \end{tabular}$ 

► Simulation		
Assign sim	ulation process variable	→ 🖺 90
Value proc	ess variable	→ 🖺 90
Frequency	simulation	→ 🖺 90
Frequency	value	→ 🖺 91
Pulse simu	lation	→ 🖺 91
Pulse value	2	→ 🖺 91
Switch out	put simulation	→ 🖺 91
Switch stat	rus	→ 🖺 91
Simulation	device alarm	→ 🖺 90
Diagnostic	event category	→ 🖺 90
Simulation	diagnostic event	→ 🖺 90

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> </ul>
Value process variable	A process variable is selected in the <b>Assign simulation process variable</b> parameter (→ 🖺 90).	Enter the simulation value for the selected process variable.	Depends on the process variable selected
Simulation device alarm	-	Switch the device alarm on and off.	Off On
Diagnostic event category	-	Select a diagnostic event category.	<ul><li>Sensor</li><li>Electronics</li><li>Configuration</li><li>Process</li></ul>
Simulation diagnostic event	-	Select a diagnostic event to simulate this event.	<ul> <li>Off</li> <li>Diagnostic event picklist (depends on the category selected)</li> </ul>
Frequency simulation	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Switch the simulation of the frequency output on and off.	• Off • On

90

Parameter	Prerequisite	Description	Selection / User entry
Frequency value	In the <b>Frequency simulation</b> parameter, the <b>On</b> option is selected.	Enter the frequency value for the simulation.	0.0 to 1250.0 Hz
Pulse simulation	In the <b>Operating mode</b> parameter, the <b>Pulse</b> option is selected.	Set and switch off the pulse output simulation.  For <b>Fixed value</b> option: <b>Pulse width</b> parameter (→ 🖺 78) defines the pulse width of the pulses output.	<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>
Pulse value	In the <b>Pulse simulation</b> parameter $(\Rightarrow \stackrel{\cong}{=} 91)$ , the <b>Down-counting value</b> option is selected.	Enter the number of pulses for simulation.	0 to 65 535
Switch output simulation	In the <b>Operating mode</b> parameter, the <b>Switch</b> option is selected.	Switch the simulation of the switch output on and off.	• Off • On
Switch status	In the Switch output simulation parameter (→ 🗎 91) Switch output simulation 1 to n parameter Switch output simulation 1 to n parameter, the On option is selected.	Select the status of the status output for the simulation.	<ul><li>Open</li><li>Closed</li></ul>

### 10.9 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code
- Write protection via write protection switch
- Write protection via keypad lock

#### 10.9.1 Write protection via access code

The effects of the user-specific access code are as follows:


- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.

#### Defining the access code via the local display

- 1. Navigate to the **Enter access code** parameter.
- 2. Maximum of 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the to confirm.
  - → The 🗈 symbol appears in front of all write-protected parameters.
- Disabling parameter write protection via access code  $\rightarrow$  🖺 49.
  - If the access code is lost: Resetting the access code .
  - The user role with which the user is currently logged in is displayed in Access status display parameter.
    - Navigation path: Operation → Access status display
    - User roles and their access rights  $\rightarrow \triangleq 49$
- The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view.
- The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.




### 10.9.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display"** parameter.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via PROFIBUS PA protocol




- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.

- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.
  - └ Display module is attached to the edge of the electronics compartment.



- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
  - └ If the hardware write protection is enabled: The **Hardware locked** option is displayed in the **Locking status** parameter . In addition to this, the  ${\color{orange} \, \boxtimes}\,$  symbol appears in the header of the measured value display and in the navigation view in front of the parameters.



If hardware write protection is disabled: No option is displayed in the **Locking status** parameter . On the local display, the 🖹 symbol disappears from in front of the parameters in the header of the operational display and in the navigation

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reassemble the transmitter in the reverse order.

### 11 Operation

### 11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation → Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access authorization displayed in the <b>Access status display</b> parameter applies $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed again.

### 11.2 Adjusting the operating language



Detailed information:

- To configure the operating language → 🖺 64
- $\bullet$  For information on the operating languages supported by the measuring device  $\rightarrow~\cong~153$

### 11.3 Configuring the display

Detailed information:

- On the basic settings for the local display  $\rightarrow$   $\stackrel{ riangle}{=}$  70
- On the advanced settings for the local display  $\rightarrow$   $\stackrel{ riangle}{=}$  85


### 11.4 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

#### **Navigation**

"Diagnostics" menu → Measured values

► Measured value	S		
	► Process variables		
	Λ	Mass flow	
	V	Jolume flow	
	C	Corrected volume flow	
	Ξ	Density	




### 11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Process variables




Parameter	Description	User interface
Mass flow	Displays the mass flow currently measured.  Dependency The unit is taken from the Mass flow unit parameter	Signed floating-point number
Volume flow	Displays the currently measured volume flow.  Dependency The unit is taken from: Volume flow unit parameter	Signed floating-point number
Corrected volume flow	Displays the corrected volume flow currently calculated.  Dependency The unit is taken from the Corrected volume flow unit parameter	Signed floating-point number
Density	Displays the density or specific density currently measured.  Dependency The unit is taken from the Density unit parameter	Positive floating-point number
Reference density	Displays the density at the reference temperature.  Dependency The unit is taken from the Reference density unit parameter	Positive floating-point number
Temperature	Displays the temperature currently measured.  Dependency The unit is taken from the <b>Temperature unit</b> parameter	Positive floating-point number

### 11.4.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Totalizer



96


Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign process variable	-	Select process variable for totalizer.	<ul><li>Mass flow</li><li>Volume flow</li><li>Corrected volume flow</li></ul>
Totalizer value 1 to n	One of the following options is selected in the Assign process variable parameter:  Volume flow  Mass flow  Corrected volume flow  Total mass flow  Condensate mass flow  Energy flow  Heat flow difference	Displays the current totalizer counter value.	Signed floating-point number
Totalizer status 1 to n	-	Displays the current totalizer status.	■ Good ■ Uncertain ■ Bad
Totalizer status (Hex) 1 to n	In <b>Target mode</b> parameter, the <b>Auto</b> option is selected.	Displays the current status value (hex) of the totalizer.	0 to 0xFF

### 11.4.3 Output variables

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

#### Navigation

"Diagnostics" menu → Measured values → Output values



### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Terminal voltage 1	-	Displays the current terminal voltage that is applied at the output.	0.0 to 50.0 V
Pulse output	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Output frequency	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Displays the value currently measured for the frequency output.	0 to 1250 Hz
Switch status	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Displays the current switch output status.	<ul><li>Open</li><li>Closed</li></ul>

# 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (→ 🖺 65)
- Advanced settings using the **Advanced setup** submenu (→ 🗎 75)

### 11.6 Performing a totalizer reset


The totalizers are reset in the **Operation** submenu: Control Totalizer

Function scope of "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value 1 to n</b> parameter.
Stop totalizing option	Totalizing is stopped.

#### Navigation

"Operation" menu → Totalizer handling



#### Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry
Control Totalizer 1 to n	One of the following options is selected in the Assign process variable parameter:  Mass flow Volume flow Corrected volume flow	Control the totalizer value.	<ul><li>Totalize</li><li>Reset + hold</li><li>Preset + hold</li></ul>
Preset value 1 to n	In the Assign process variable parameter one of the following options is selected:  Volume flow  Mass flow  Corrected volume flow  Total mass flow  Condensate mass flow  Energy flow  Heat flow difference	Specify start value for totalizer.	Signed floating-point number
Reset all totalizers	-	Reset all totalizers to 0 and start.	<ul><li>Cancel</li><li>Reset + totalize</li></ul>

### 11.7 Displaying the measured value history

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

#### **Function scope**

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Displays the measured value trend for each logging channel in the form of a chart



■ 18 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.
- If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

#### **Navigation**

"Diagnostics" menu  $\rightarrow$  Data logging

▶ Data logging	
Assign channel 1	→ 🖺 100
Assign channel 2	→ 🖺 100
Assign channel 3	→ 🖺 100
Assign channel 4	→ 🖺 100
Logging interval	→ 🗎 100
Clear logging data	→ 🖺 100

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign channel 1	The <b>Extended HistoROM</b> application package is available.	Assign process variable to logging channel.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Carrier pipe temperature</li> <li>Electronic temperature</li> <li>Oscillation frequency</li> <li>Oscillation amplitude</li> <li>Oscillation damping</li> <li>Signal asymmetry</li> </ul>
Assign channel 2	The <b>Extended HistoROM</b> application package is available.  The software options currently enabled are displayed in the <b>Software option overview</b> parameter.	Assign a process variable to logging channel.	For the picklist, see <b>Assign</b> channel 1 parameter (→ 🖺 100)
Assign channel 3	The <b>Extended HistoROM</b> application package is available.  The software options currently enabled are displayed in the <b>Software option overview</b> parameter.	Assign a process variable to logging channel.	For the picklist, see <b>Assign</b> channel 1 parameter (→ 🖺 100)
Assign channel 4	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see <b>Assign</b> channel 1 parameter (→ 🗎 100)
Logging interval	The <b>Extended HistoROM</b> application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s
Clear logging data	The <b>Extended HistoROM</b> application package is available.	Clear the entire logging data.	Cancel Clear data
Data logging	-	Select the type of data logging.	<ul><li>Overwriting</li><li>Not overwriting</li></ul>
Logging delay	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Enter the time delay for measured value logging.	0 to 999 h
Data logging control	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Start and stop measured value logging.	<ul><li>None</li><li>Delete + start</li><li>Stop</li></ul>
Data logging status	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the measured value logging status.	<ul><li>Done</li><li>Delay active</li><li>Active</li><li>Stopped</li></ul>
Entire logging duration	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the total logging duration.	Positive floating-point number

100

## 12 Diagnostics and troubleshooting

### 12.1 General troubleshooting

### For local display

Fault	Possible causes	Remedial action
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display dark and no output signals	Supply voltage does not match the voltage specified on the nameplate.	Apply the correct supply voltage $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the electrical contact between the cable and terminals and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.	Order spare part → 🖺 130.
Local display cannot be read, but signal output is within the valid range	Display is set too bright or too dark.	<ul> <li>Set the display brighter by simultaneously pressing</li></ul>
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🖺 130.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial actions $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Text on local display appears in a language that cannot be understood.	The selected operating language cannot be understood.	1. Press □ + ⊕ for 2 s ("home position"). 2. Press □. 3. Configure the required language in the Display language parameter (→ □ 87).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul> <li>Check the cable and the connector between the main electronics module and display module.</li> <li>Order spare part → ■ 130.</li> </ul>

### For output signals

Fault	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🖺 130.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parameter configuration error	Check and adjust parameter configuration.
Device is measuring incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration.     Observe limit values specified in the "Technical Data".  "Technical Data".

#### For access


Fault	Possible causes	Remedial action
Write access to parameters is not possible.	Hardware write protection is enabled.	Set the write protection switch on the main electronics module to the <b>OFF</b> position $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Write access to parameters is not possible.	Current user role has limited access authorization.	<ol> <li>Check user role → □ 49.</li> <li>Enter correct customer-specific access code → □ 49.</li> </ol>

Fault	Possible causes	Remedial action
Connection via PROFIBUS PA is not possible.	PROFIBUS PA cable is incorrectly terminated.	Check the terminating resistor .
Connection via the service interface is not possible.	<ul> <li>The USB port on the PC is incorrectly configured.</li> <li>The driver is not installed correctly.</li> </ul>	Observe the documentation for the Commubox FXA291:  Technical Information TI00405C

### 12.2 Diagnostic information on local display

### 12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring instrument are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
  - Via parameter → 🗎 122

#### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
  - F = Failure
  - C = Function Check
  - S = Out of Specification
  - M = Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in the service mode (e.g. during a simulation).
S	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range)
М	Maintenance required Maintenance is required. The measured value remains valid.

### Diagnostic behavior

Symbol	Meaning
8	Alarm  Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Δ	Warning  Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

### Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### **Operating elements**

Operating key	Meaning
<b>(+)</b>	Plus key In menu, submenu Opens the message about the remedial measures.
E	Enter key In menu, submenu Opens the operating menu.

### 12.2.2 Calling up remedial actions



A0029431-EN

- 19 Message for remedial actions
- 1 Diagnostic information
- 2 Event text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operating time of occurrence
- 6 Remedial actions
- 1. The user is in the diagnostic message.

Press ± (① symbol).

- The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with  $\pm$  or  $\Box$  and press  $\Box$ .
  - ► The message about the remedial measures opens.
- 3. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.


The user is in the **Diagnostics** menu in the **Diagnostic list** submenu. A list of active diagnostics is displayed. The user can select a diagnostic event.

- 1. Press E.
  - ightharpoonup The message for the remedial actions for the selected diagnostic event opens.
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial actions closes.

### 12.3 Diagnostic information in FieldCare or DeviceCare

#### 12.3.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



- 2 Diagnostic information  $\rightarrow \Box 104$
- 3 Remedial actions with service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
  - Via parameter  $\rightarrow$  🗎 122
  - Via submenu  $\rightarrow \implies 123$

#### Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
8	Failure A device error has occurred. The measured value is no longer valid.
<b>W</b>	Function check The device is in service mode (e.g. during a simulation).
<u>^</u> ?	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range)
<b>&amp;</b>	Maintenance required Maintenance is required. The measured value remains valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

#### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### 12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
   Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
   Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
  - ► A tool tip with remedy information for the diagnostic event appears.


### 12.4 Adapting the diagnostic information

### 12.4.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Diagnostic behavior in accordance with Specification PROFIBUS PA Profile 3.02, Condensed Status.

 $\texttt{Expert} \rightarrow \texttt{System} \rightarrow \texttt{Diagnostic handling} \rightarrow \texttt{Diagnostic behavior}$ 



A0019179-EN


#### Available diagnostic behaviors

The following diagnostic behaviors can be assigned:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Warning	The device continues to measure. Measured value output via PROFIBUS and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the <b>Event logbook</b> submenu ( <b>Event list</b> submenu) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

#### Displaying the measured value status

If the Analog Input, Digital Input and Totalizer function blocks are configured for cyclic data transmission, the device status is coded as per PROFIBUS PA Profile 3.02 Specification and transmitted along with the measured value to the PROFIBUS Master (Class 1) via the coding byte (byte 5). The coding byte is split into three segments: Quality, Quality Substatus and Limits.



20 Structure of the coding byte

The contents of the coding byte depends on the configured failure mode in the individual function block. Depending on which failure mode has been configured, status information in accordance with PROFINET PA Profile Specification 4 is transmitted to the PROFIBUS master (Class 1) via the coding byte status information.

#### Determining the measured value status and device status via the diagnostic behavior

When the diagnostic behavior is assigned, this also changes the measured value status and device status for the diagnostic information. The measured value status and device status depend on the choice of diagnostic behavior and on the group in which the diagnostic information is located.

The diagnostic information is grouped as follows:

- Diagnostic information pertaining to the sensor: diagnostic number 000 to 199
- Diagnostic information pertaining to the electronics: diagnostic number 200 to 399  $\rightarrow$  🖺 109
- Diagnostic information pertaining to the configuration: diagnostic number 400 to 599
   → 110
- Diagnostic information pertaining to the process: diagnostic number 800 to 999
   → 

  110

Depending on the group in which the diagnostic information is located, the following measured value status and device status are firmly assigned to the particular diagnostic behavior:

Diagnostic information pertaining to the sensor: diagnostic number 000 to 199

Diagnostic behavior	N	leasured value st	Device diagnosis		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Maintenance alarm	0x24 to 0x27	F (Failure)	Maintenance alarm
Warning	GOOD	Maintenance demanded	0xA8 to 0xAB	M (Maintenance)	Maintenance demanded
Logbook entry only	GOOD	ok	0x80 to 0x8E	_	_
Off	GOOD	UK	UXOU IU UXOE	_	_

Diagnostic information pertaining to the electronics: diagnostic number 200 to 399

Diagnostic number 200 to 301, 303 to 399

Diagnostic behavior	IV	leasured value sta	Davisa dia apastisa		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	Device diagnostics (fixed assignment)
Alarm	BAD	Maintenance	0x24 to 0x27	F	Maintenance
Warning	BAD	alarm	0X24 t0 0X27	(Failure)	alarm
Logbook entry only	ogbook entry only Off	ok 0x80 to 0x8E	000 +- 005		
Off			_	_	

### Diagnostic information 302

Diagnostic behavior	IV	leasured value sta	Device diagnostics		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Function check, local override	0x24 to 0x27	С	Function check
Warning	GOOD	Function check	0xBC to 0xBF	_	-

Data logging continues when Heartbeat Verification is started. The signal outputs and totalizers are not affected.

- Signal status: Function check
- Choice of diagnostic behavior: alarm or warning (factory setting)

When the Heartbeat Verification is started, data logging is interrupted, the last valid measured value is output and the totalizer counter is stopped.

5	N				
Diagnostic behavior	0 111	Quality	Coding	Category	Device diagnosis (fixed assignment)

Diagnostic information pertaining to the configuration: diagnostic number 400 to 599

Diagnostic behavior	M	leasured value st	Device diagnosis		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTA IN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition
Logbook entry only	GOOD	GOOD ok	0x80 to 0x8E	_	
Off				_	_

Diagnostic information pertaining to the process: diagnostic number 800 to 999

Diagnostic hohovion	M	leasured value st	Davisa dingnasia		
Diagnostic behavior (configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	Device diagnosis (fixed assignment)
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTA IN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition
Logbook entry only	GOOD	ok	0x80 to 0x8E	_	_
Off	GOOD	OK	UXOU IU UXOE	_	_

#### 12.5 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
  - All of the measured variables affected in the entire Promass instrument family are always listed under "Measured variables affected". The measured variables available for the device in question depend on the device version. When assigning the measured variables to the device functions, for example to the individual outputs, all of the measured variables available for the device version in question are available for selection.
- In the case of some items of diagnostic information, the diagnostic behavior can be changed. Adapting the diagnostic information  $\rightarrow \implies 107$

#### 12.5.1 Diagnostic of sensor

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
022	Sensor temperature		1. Change main electronic module	■ Density
			2. Change sensor	<ul><li>Mass flow</li><li>Reference density</li></ul>
	Status signal	F		Corrected volume flow
	Diagnostic behavior	Alarm		<ul><li>Temperature</li><li>Volume flow</li></ul>

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
046	Sensor limit exceeded  Status signal S		Inspect sensor     Check process condition	<ul><li>Density</li><li>Mass flow</li></ul>
				<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		Volume flow

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
062	Sensor connection		Change main electronic module     Change sensor	<ul><li>Mass flow</li><li>Corrected volume flow</li></ul>
	Status signal	F	_	<ul> <li>Volume flow</li> </ul>
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
082	Data storage		Change main electronic module     Change sensor	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	nort text		variables
083	083 Memory content		Restart device     Restore S-Dat data	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	3. Change sensor	option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic i	information	Remedy instructions	Influenced measured variables
No.	Short text			variables
140	Sensor signal		Check or change main electronics     Change sensor	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	S		<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		Temperature

## 12.5.2 Diagnostic of electronic

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
242	Software incompatible		Check software     Flash or change main electronics	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	module	option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
252	Modules incompatible		Check electronic modules     Change I/O or main electronic module	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	_	option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
261	Electronic modules		Restart device     Check electronic modules	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	3. Change I/O Modul or main electronics	option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
262	Module connection		Check module connections     Change electronic modules	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
270	Main electronic failure		Change main electronic module	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Low now cut on option</li> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
271	Main electronic failure		Restart device     Change main electronic module	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
272	Main electronic failure		Restart device     Contact service	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
273	Main electronic failure		Emergency operation via display     Change main electronics	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
274	Main electronic failure		Unstable measurement  1. Change main electronics	<ul><li>Mass flow</li><li>Corrected volume flow</li></ul>
	Status signal	S	_	<ul> <li>Volume flow</li> </ul>
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
275	I/O module failure		Change I/O module	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
276	I/O module failure		Restart device     Change I/O module	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
282	Data storage		Restart device     Contact service	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	an contact service	option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> </ul>
				<ul><li>Corrected volume flow</li><li>Temperature</li><li>Volume flow</li></ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
283	Memory content	Transfer data or reset device     Contact service	<ul><li>Density</li><li>Empty pipe detection</li></ul>	
	Status signal	F		option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Low now cut on option</li> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	S	hort text		variables
302	Device verification active		Device verification active, please wait.	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
311	Electronic failure	1. Transfer data or reset device 2. Contact service	<ul><li>Density</li><li>Empty pipe detection</li></ul>	
	Status signal	F		option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
311	Electronic failure	ronic failure  Maintenance required!  1. Do not perform reset	<ul><li>Density</li><li>Empty pipe detection</li></ul>	
	Status signal	M	2. Contact service	option  Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
362	Main electronic failure		Change main electronic module     Change sensor	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

# 12.5.3 Diagnostic of configuration

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
410	Data transfer		Check connection     Retry data transfer	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
412	Processing Download		Download active, please wait	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
437	Configuration incompatible		Restart device     Contact service	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F		option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
438	438 Dataset	Check data set file     Check device configuration	<ul><li>Density</li><li>Empty pipe detection</li></ul>	
	Status signal	M	3. Up- and download new configuration	option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
442	.2 Frequency output		1. Check process	-
			2. Check frequency output settings	
	Status signal	S		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
443	Pulse output		Check process     Check pulse output settings	_
	Status signal	S		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
453	Flow override	Deactivate flow override	<ul><li>Density</li><li>Empty pipe detection</li></ul>	
	Status signal	С		option  Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
482	FB not Auto/Cas		Set Block in AUTO mode	_
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
484	Simulation failure mode		Deactivate simulation	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  • Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
485	Simulation measured variable		Deactivate simulation	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
492	Simulation frequency output		Deactivate simulation frequency output  Density  Figure 6	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
493	Simulation pulse output		Deactivate simulation pulse output	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
494	Switch output simulation		Deactivate simulation switch output	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	С		option  Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
495	Simulation diagnostic event		Deactivate simulation	-
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
497	Simulation block output		Deactivate simulation	_
	Status signal	С		
	Diagnostic behavior	Warning		

## 12.5.4 Diagnostic of process

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	hort text		
801	Supply voltage too low		Increase supply voltage	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables	
830	Sensor temperature too high		Reduce ambient temp. around the sensor housing	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	S	_	<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		<ul><li>Volume flow</li></ul>

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
831	Sensor temperature too low		Increase ambient temp. around the sensor housing	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	S		<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
832	832 Electronic temperature too high	h	Reduce ambient temperature  Reduce ambient temperature  Empty pipe	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
833	Electronic temperature too low	,	Increase ambient temperature	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
834	Process temperature too high		Reduce process temperature	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	S		<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		<ul><li>Temperature</li><li>Volume flow</li></ul>

Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables	
835	Process temperature too low  Status signal  Diagnostic behavior	S Warning	Increase process temperature	<ul> <li>Density</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
842	Process limit		Low flow cut off active!  1. Check low flow cut off configuration	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	S	hort text		variables
862	Partly filled pipe		Check for gas in process     Adjust detection limits	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
882	Input signal		Check input configuration     Check external device or process	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	F	conditions	<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Alarm		Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
910	Tubes not oscillating		Check process conditions     Increase supply	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	F	3. Check main electronic or sensor	option  Low flow cut off option
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
912	Medium inhomogeneous		Check process cond.     Increase system pressure	<ul><li>Density</li><li>Empty pipe detection</li></ul>
	Status signal	S		option  • Low flow cut off option
	Diagnostic behavior	Warning		<ul> <li>Mass flow</li> <li>Switch output status option</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
913	Medium unsuitable		Check process conditions     Increase supply	<ul><li>Density</li><li>Mass flow</li></ul>
	Status signal	S	3. Check main electronic or sensor	<ul><li>Reference density</li><li>Corrected volume flow</li></ul>
	Diagnostic behavior	Warning		Volume flow


### 12.6 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- Accessing the remedial action for a diagnostic event:
  - Via local display  $\rightarrow$   $\stackrel{\blacksquare}{=}$  103
  - Via "FieldCare" operating tool → 🗎 105
  - Via "DeviceCare" operating tool → 🗎 105
- Other pending diagnostic events can be displayed in the **Diagnostic list** submenu  $\rightarrow \stackrel{\square}{=} 123$ .

### Navigation

"Diagnostics" menu



### Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

### 12.7 Diagnostic list

Up to 5 currently pending diagnostic events are displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

### Navigation path

Diagnostics → Diagnostic list



A0014006-EN

■ 21 Using the example of the local display

- Accessing the remedial action for a diagnostic event:

   Via local display → 🗎 103
  - Via "FieldCare" operating tool → 

    105
  - Via "DeviceCare" operating tool → 🖺 105


### 12.8 Event logbook

### 12.8.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Event logbook** submenu.

#### Navigation path

**Diagnostics** menu  $\rightarrow$  **Event logbook** submenu  $\rightarrow$  Event logbook



■ 22 Using the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event logbook can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events → 🖺 110
- Information events → 🗎 124

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostic event
  - 🕣: Occurrence of the event
  - 🕒: End of the event
- Information event
  - €: Occurrence of the event
- Accessing the remedial action for a diagnostic event:
  - Via local display → 

    103
  - Via "FieldCare" operating tool  $\rightarrow$  🖺 105
- $box{ }$  Filtering the displayed event messages  $ightarrow binom{1}{2}$

### 12.8.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

#### Navigation path

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Filter options

### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

### 12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed

Info number	Info name
I1092	Trend data deleted
I1110	Write protection switch changed
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1227	Sensor emergency mode activated
I1228	Sensor emergency mode failed
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1440	Main electronic module changed
I1442	I/O module changed
I1444	Device verification passed
I1445	Device verification failed
I1450	Monitoring off
I1451	Monitoring on
I1459	Failed: I/O module verification
I1461	Failed: Sensor verification
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1552	Failed: Main electronic verification
I1554	Safety sequence started
I1555	Safety sequence confirmed
I1556	Safety mode off

## 12.9 Resetting the device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter ( $\rightarrow \triangleq 88$ ).

### 12.9.1 Function scope of the "Device reset" parameter


Options	Description		
Cancel	No action is executed and the user exits the parameter.		
To fieldbus defaults	Every parameter is reset to fieldbus default values.		
To factory defaults	Every parameter is reset to the factory setting.		
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.		
	This option is not visible if no customer-specific settings have been ordered.		
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.		

### 12.10 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

### **Navigation**

"Diagnostics" menu → Device information



### Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	-
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name	Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter.	Max. 32 characters such as letters or numbers.	-
Order code	Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 3	Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	_
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	-
PROFIBUS ident number	Displays the PROFIBUS identification number.	0 to FFFF	0x155F
Status PROFIBUS Master Config	Displays the status of the PROFIBUS Master configuration.	<ul><li>Active</li><li>Not active</li></ul>	-

### 12.11 Firmware history

Release	Firmwar	Order code	Firmware changes	Documentation	Documentation
date	e	for		type	
	version	"Firmware			
		version"			

- It is possible to flash the firmware to the current version or an existing previous version via the service interface.
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
  - $\blacksquare$  In the Download Area of the Endress+Hauser Web site: www.endress.com  $\to$  Downloads
  - Specify the following details:
    - Product root: e.g. 8E2B
       The product root is the first part of the order code: see the nameplate on the device.
    - Text search: Manufacturer's information
    - Media type: Documentation Technical Documentation

### 13 Maintenance

### 13.1 Maintenance work

No special maintenance work is required.

### 13.1.1 Cleaning

### Cleaning of surfaces not in contact with the medium

- 1. Recommendation: Use a lint-free cloth that is either dry or slightly dampened using water.
- 2. Do not use sharp objects or aggressive cleaning agents that could damage surfaces (e.g. displays, housing) and seals.
- 3. Do not use high-pressure steam.
- 4. Ensure compliance with the protection class of the device.

### NOTICE

### Cleaning agents can damage the surfaces!

Incorrect cleaning agents can damage the surfaces!

▶ Do not use cleaning agents containing concentrated mineral acids, alkalis or organic solvents e.g. benzyl alcohol, methylene chloride, xylene, concentrated glycerol cleaners or acetone.

### Cleaning of surfaces in contact with the medium

Note the following for cleaning and sterilization in place (CIP/SIP):

- Use only cleaning agents to which the materials in contact with the medium are sufficiently resistant.
- Observe the permitted maximum medium temperature.

## 13.2 Measuring and test equipment

Endress+Hauser offers a variety of measuring and testing equipment, such as Netilion or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment:  $\rightarrow \implies 135$ 

### 13.3 Maintenance services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

## 14 Repair

### 14.1 General notes

### 14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

### 14.1.2 Notes for repair and conversion

For repair and conversion of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ► Carry out the repair according to the Installation Instructions.
- ▶ Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document all repairs and conversions and enter the details in Netilion Analytics.


### 14.2 Spare parts

Some interchangeable measuring device components are listed on an overview sign in the connection compartment cover.

The spare part overview sign contains the following information:

- A list of the most important spare parts for the measuring device, including their ordering information.
- The URL to the *Device Viewer* (www.endress.com/deviceviewer):
  All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

130



■ 23 Example for "Spare part overview sign" in connection compartment cover

- Measuring device name
- Measuring device serial number
- Measuring device serial number:
  - Is located on the device nameplate and the spare part overview sign.
  - Can be read out via the **Serial number** parameter ( $\rightarrow \equiv 127$ ) in the **Device** information submenu.

#### 14.3 Repair services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

#### 14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the web page for information: https://www.endress.com
- 2. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging provides the best protection.

#### 14.5 **Disposal**



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

#### 14.5.1 Removing the measuring instrument

1. Switch off the device.

### **WARNING**

### Danger to persons from process conditions!

- ▶ Beware of hazardous process conditions such as pressure in the measuring instrument, high temperatures or aggressive media.
- 2. Carry out the installation and connection steps from the "Installing the device" and "Connecting the device" sections in reverse order. Observe the safety instructions.

### 14.5.2 Disposing of the measuring instrument

### **A** WARNING

### Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ▶ Ensure proper separation and reuse of the device components.

132

### 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

### 15.1 Device-specific accessories

### 15.1.1 For the transmitter

Accessory	Description
Promass 200 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications:  Approvals Output Display/operation Housing Software Installation Instructions EA00104D  (Order number: 8X2CXX)
Remote display FHX50	FHX50 housing for accommodating a display module .  FHX50 housing suitable for: SD02 display module (push buttons) SD03 display module (touch control)  Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft))  The measuring instrument can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes: Order code for measuring instrument, feature 030: Option L or M "Prepared for FHX50 display" Order code for FHX50 housing, feature 050 (measuring instrument version): Option A "Prepared for FHX50 display" Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation): Option C: for an SD02 display module (push buttons) Option E: for an SD03 display module (touch control)  The FHX50 housing can also be ordered as a retrofit kit. The measuring instrument display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing: Feature 050 (measuring instrument version): option B "Not prepared for FHX50 display" Feature 020 (display, operation): option A "None, existing displayed used" Special Documentation SD01007F (Order number: FHX50)

Accessory	Description
Overvoltage protection for 2-wire devices	Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, feature 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting.
	<ul> <li>OVP10: For 1-channel devices (feature 020, option A):</li> <li>OVP20: For 2-channel devices (feature 020, options B, C, E or G)</li> </ul>
	Special Documentation SD01090F
	(Order number OVP10: 71128617) (Order number OVP20: 71128619)
Protective cover	The weather protection cover is used to protect against direct sunlight, precipitation and ice.  It can be ordered together with the device via the product structure:  Order code for "Accessories enclosed" option PB "Protective cover"
	Special Documentation SD00333F
	(Order number: 71162242)

### 15.1.2 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids.
	If using oil as a heating medium, please consult with Endress+Hauser.
	Heating jackets cannot be used with sensors fitted with a rupture disk.
	If ordered together with the measuring device:
	Order code for "Accessory enclosed"
	■ Option RB "Heating jacket, G 1/2" female thread"
	<ul> <li>Option RC "Heating jacket, G 3/4" female thread"</li> </ul>
	• Option RD "Heating jacket, NPT 1/2" female thread"
	Option RE "Heating jacket, NPT 3/4" female thread"  If and and only a great left.
	If ordered subsequently:    No. the and are described to a made to the property   100000000000000000000000000000000000
	Use the order code with the product root DK8003.
	Special Documentation SD02151D

# 15.2 Communication-specific accessories

Accessories	Description	
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.  Technical Information TI00405C	
Fieldgate FXA42	Transmission of the measured values of connected 4 to 20 mA analog measuring instruments, as well as digital measuring instruments  Technical Information TI01297S Operating Instructions BA01778S Product page: www.endress.com/fxa42	

Field Xpert SMT50	The Field Xpert SMT50 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.  This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
	<ul> <li>Operating Instructions BA02053S</li> <li>Product page: www.endress.com/smt50</li> </ul>
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.  This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
	<ul> <li>Technical Information TI01342S</li> <li>Operating Instructions BA01709S</li> <li>Product page: www.endress.com/smt70</li> </ul>
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.  Technical Information TI01418S Operating Instructions BA01923S Product page: www.endress.com/smt77

# 15.3 Service-specific accessories

Accessory	Description	
Applicator	<ul> <li>Software for selecting and sizing Endress+Hauser measuring instruments:</li> <li>Choice of measuring instruments for industrial requirements</li> <li>Calculation of all the necessary data for identifying the optimum flowmete e.g. nominal diameter, pressure loss, flow velocity and measurement accuracy.</li> <li>Graphic display of the calculation results</li> <li>Determining the partial order code. Administration, documentation and access to all project-related data and parameters over the entire life cycle o a project.</li> <li>Applicator is available:</li> <li>Via the Internet: https://portal.endress.com/webapp/applicator</li> </ul>	
Netilion	lloT ecosystem: Unlock knowledge With the Netilion IIoT ecosystem, Endress+Hauser allows you to optimize your plant performance, digitize workflows, share knowledge, and enhance collaboration. Based on decades of experience in process automation, Endress+Hauser offers the process industry an lloT ecosystem that enables you to gain useful insights from data. These insights can be used to optimize processes, leading to increased plant availability, efficiency, and reliability - ultimately resulting in a more profitable plant.  www.netilion.endress.com	
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all intelligent field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  Operating Instructions BA00027S and BA00059S	
DeviceCare	Tool to connect and configure Endress+Hauser field devices.  • Technical Information: TI01134S • Innovation brochure: IN01047S	

# 15.4 System components

Accessories	Description		
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relev measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.		
	<ul><li>Technical Information TI00133R</li><li>Operating Instructions BA00247R</li></ul>		
Cerabar M	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.		
	<ul> <li>Technical Information TI00426P and TI00436P</li> <li>Operating Instructions BA00200P and BA00382P</li> </ul>		
Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.		
	<ul><li>Technical Information TI00383P</li><li>Operating Instructions BA00271P</li></ul>		

### 16 Technical data

### 16.1 Application

The measuring device is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

## 16.2 Function and system design

Measuring principle	Mass flow measurement based on the Coriolis measuring principle	
	The device consists of a transmitter and a sensor.	
	The device is available as a compact version: The transmitter and sensor form a mechanical unit.	
	For information on the structure of the measuring instrument $\rightarrow                   $	

## 16.3 Input

#### Measured variable

#### Direct measured variables

- Mass flow
- Density
- Temperature

### Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

### Measuring range

### Measuring range for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
8	3/8	0 to 2 000	0 to 73.50
15	1/2	0 to 6 500	0 to 238.9
25	1	0 to 18000	0 to 661.5
40	1½	0 to 45 000	0 to 1654
50	2	0 to 70 000	0 to 2 573

### Measuring range for gases

The full scale value depends on the density and the speed of sound of the gas used. The full scale value can be calculated with the following formulas:

$$\dot{m}_{\,\,\text{max}\,(G)} = \text{minimum of} \qquad \qquad (\dot{m}_{\text{max}(F)} \cdot \rho_G : x \,) \text{ and}$$

$$(\rho_G\cdot (c_G/2)\cdot d_i^2\cdot (\pi/4)\cdot 3600\cdot n)$$

m <sub>max(G)</sub>	Maximum full scale value for gas [kg/h]
m <sub>max(F)</sub>	Maximum full scale value for liquid [kg/h]
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{ max(G)}$ can never be greater than $\dot{m}_{ max(F)}$
P <sub>G</sub>	Gas density in [kg/m³] at operating conditions
х	Limitation constant for max. gas flow [kg/m³]
$\mathbf{c}_{G}$	Speed of sound (gas) [m/s]
d <sub>i</sub>	Measuring tube internal diameter [m]
π	Pi
n = 2	Number of measuring tubes

DN		x
[mm]	[in]	[kg/m³]
8	3/8	85
15	1/2	110
25	1	125

138

DN		x
[mm]	[in]	[kg/m³]
40	1½	125
50	2	125

If calculating the full scale value using the two formulas:

- 1. Calculate the full scale value with both formulas.
- 2. The smaller value is the value that must be used.

### Recommended measuring range

i

Flow limit  $\rightarrow$   $\triangleq$  150

### Operable flow range


Over 1000:1.

Flow rates above the preset full scale value do not override the electronics unit, with the result that the totalizer values are registered correctly.

#### Input signal

#### External measured values

To increase the measurement accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write the operating pressure to the measuring instrument. Endress+Hauser recommends the use of a pressure measuring instrument for absolute pressure, e.g. Cerabar M or Cerabar S.



It is recommended to read in external measured values to calculate the following measured variables:

- Mass flow
- Corrected volume flow

Digital communication

The measured values are written by the automation system via PROFIBUS PA.

### 16.4 Output

### Output signal

### Pulse/frequency/switch output

Function	Can be configured as pulse, frequency or switch output	
Version	Passive, open collector	
Maximum input values	■ DC 35 V ■ 50 mA	
Voltage drop	■ At ≤ 2 mA: 2 V ■ At 10 mA: 8 V	
Residual current	≤ 0.05 mA	
Pulse output		
Pulse width	Configurable: 5 to 2 000 ms	
Maximum pulse rate	100 Impulse/s	
Pulse value	Configurable	

Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> </ul>
Frequency output	
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Standard density</li> <li>Temperature</li> </ul>
Switch output	
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value <ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Standard density</li> <li>Temperature</li> <li>Totalizer 1-3</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status <ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> </ul> </li> </ul>

### PROFIBUS PA

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transmission	31.25 kbit/s
<b>Current consumption</b>	16 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

Signal on alarm

Depending on the interface, failure information is displayed as follows:

### Pulse/frequency/switch output

Pulse output	
Failure mode	Configurable:  • Actual value  • No pulses
Frequency output	

140

Failure mode	Configurable:  Actual value  O Hz  Definable value between: 0 to 1250 Hz
Switch output	
Failure mode	Configurable:  Current status  Open  Closed

### **PROFIBUS PA**

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Failure current FDE (Fault Disconnection Electronic)	0 mA

### Local display

Plain text display	With information on cause and remedial measures
Backlight	Additionally for device version with SD03 local display: red lighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

### Interface/protocol

- Via digital communication: PROFIBUS PA
- Via service interface Endress+Hauser service interface CDI (Common Data Interface)
- Plain text display With information on cause and remedial actions

Low flow cut off	The switch points for low flow cut off are user-selectable.
Galvanic isolation	All outputs are galvanically isolated from one another.

### Protocol-specific data

Manufacturer ID	0x11
Ident number	0x155F
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files at:  ■ www.endress.com → Download Area  ■ https://www.profibus.com
Supported functions	Identification & Maintenance     Simple device identification via control system and nameplate     PROFIBUS upload/download     Reading and writing parameters is up to ten times faster with PROFIBUS upload/download     Condensed Status     Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur


Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Local display</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>	
System integration	For information on system integration, see → ■ 57  Cyclic data transmission Block model Description of the modules	

#### Power supply 16.5

### Terminal assignment

#### **Transmitter**

Connection version for PROFIBUS PA, pulse/frequency/switch output



- Ground terminal for cable shield

Order code for "Output"	Terminal numbers			
	Output 1		Output 2	
	1 (+)	2 (-)	3 (+)	4 (-)
Option G 1) 2)	PROFIBUS PA		Pulse/frequency/switch output (passive)	

- Output 1 must always be used; output 2 is optional. 1)
- PROFIBUS PA with integrated reverse polarity protection.

### Supply voltage

#### Transmitter

An external power supply is required for each output.

For installation in systems where the power unit is safety-approved (e.g. SELV/PELV Class 2 limited energy). Only one wire is permitted per terminal.

Order code for "Output"	Minimum Terminal voltage	Maximum Terminal voltage
Option G: PROFIBUS PA, pulse/frequency/switch output	≥ DC 9 V	DC 32 V

142

### Power consumption

#### Transmitter

Order code for "Output; input"	Maximum power consumption
Option G: PROFIBUS PA, pulse/frequency/switch output	<ul> <li>Operation with output 1: 512 mW</li> <li>Operation with output 1 and 2: 2512 mW</li> </ul>



For information on the Ex connection values

### Current consumption

### Power supply failure

- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

#### Electrical connection

### Potential equalization

→ 🖺 33

#### **Terminals**

- For device version without integrated overvoltage protection: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- For device version with integrated overvoltage protection: screw terminals for wire crosssections 0.2 to 2.5 mm<sup>2</sup> (24 to 14 AWG)

#### Cable entries



The type of cable entry available depends on the specific device version.

### Cable gland (not for Ex d)

 $M20 \times 1.5$ 

### Thread for cable entry

- NPT ½"
- G ½"
- M20 × 1.5

### Cable specification

→ 🖺 28

#### Overvoltage protection

The device can be ordered with integrated overvoltage protection: Order code for "Accessory mounted", option NA "Overvoltage protection"

Input voltage range	Values correspond to supply voltage specifications $\rightarrow$ $\  \   \   \   \          $	
Resistance per channel	2 · 0.5 Ω max.	
DC sparkover voltage	400 to 700 V	
Trip surge voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	

Nominal discharge current (8/20 μs)	10 kA
Temperature range	-40 to +85 °C (-40 to +185 °F)

1) The voltage is reduced by the amount of the internal resistance  $I_{\text{min}} \cdot R_i$ 

Depending on the temperature class, restrictions apply to the ambient temperature for device versions with overvoltage protection .

For detailed information on the temperature tables, see the "Safety Instructions" (XA) for the device.

### 16.6 Performance characteristics


# Reference operating conditions

- Error limits based on ISO 11631
- Water
  - +15 to +45 °C (+59 to +113 °F)
  - 2 to 6 bar (29 to 87 psi)
- Data as indicated in the calibration protocol
- Accuracy based on accredited calibration rigs according to ISO 17025
- To obtain measured errors, use the *Applicator* sizing tool  $\rightarrow \triangleq 135$

# Maximum measurement error

o.r. = of reading;  $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature

### Base accuracy



Mass flow and volume flow (liquids)

±0.25 % o.r.

Mass flow (gases)

±0.50 % o.r.

Density (liquids)

Under reference conditions	Standard density calibration	
[g/cm³]	[g/cm³]	
±0.0005	±0.002	

#### **Temperature**

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$ 

### Zero point stability

DN		Zero point stability	
[mm]	[in]	[kg/h]	[lb/min]
8	<sup>3</sup> / <sub>8</sub>	0.24	0.0088
15	1/2	0.78	0.0287
25	1	2.16	0.0794

DN		Zero point stability	
[mm]	[in]	[kg/h]	[lb/min]
40	1½	5.40	0.1985
50	2	8.40	0.3087

## Flow values

Flow values as turndown parameters depending on nominal diameter.

#### SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6 500	650	325	130	65	13
25	18 000	1800	900	360	180	36
40	45 000	4500	2 2 5 0	900	450	90
50	70 000	7 000	3 500	1400	700	140

#### US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3/8	73.50	7.350	3.675	1.470	0.735	0.147
1/2	238.9	23.89	11.95	4.778	2.389	0.478
1	661.5	66.15	33.08	13.23	6.615	1.323
11/2	1654	165.4	82.70	33.08	16.54	3.308
2	2 5 7 3	257.3	128.7	51.46	25.73	5.146

## Accuracy of outputs

The outputs have the following base accuracy specifications:

Pulse/frequency output

o.r. = of reading

Accuracy	Max. ±100 ppm o.r.
----------	--------------------

Repeatability

o.r. = of reading;  $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature

## Base repeatability

Pesign fundamentals → 147

Mass flow and volume flow (liquids)

±0.125 % o.r.

Mass flow (gases)

 $\pm 0.25$  % o.r. (up to a Mach number of 0.2)

Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$ 

### **Temperature**

 $\pm 0.25$  °C  $\pm 0.0025$  · T °C ( $\pm 0.45$  °F  $\pm 0.0015$  · (T-32) °F)

#### Response time

- The response time depends on the configuration (damping).
- Response time in the event of erratic changes in the measured variable: After 500 ms  $\rightarrow$  95 % of full scale value

# Influence of ambient temperature

## Pulse/frequency output

o.r. = of reading

Temperature coefficient	Max. ±100 ppm o.r.
-------------------------	--------------------

# Influence of medium temperature

#### Mass flow


o.f.s. = of full scale value

If there is a difference between the temperature during zero adjustment and the process temperature, the additional measurement error of the sensors is typically  $\pm 0.0002$  %o.f.s./°C ( $\pm 0.0001$  % o.f.s./°F).

The influence is reduced when the zero adjustment is performed at process temperature.

#### Density

If there is a difference between the density calibration temperature and the process temperature, the measurement error of the sensors is typically  $\pm 0.0001 \text{ g/cm}^3/^{\circ}\text{C}$  ( $\pm 0.00005 \text{ g/cm}^3/^{\circ}\text{F}$ ). Field density adjustment is possible.



■ 24 Field density adjustment, for example at +20  $^{\circ}$ C (+68  $^{\circ}$ F)

## Temperature

 $\pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.005 \cdot (\text{T} - 32) \,^{\circ}\text{F})$ 

Influence of medium pressure

The following shows how the process pressure (gauge pressure) affects the accuracy of the mass flow.

o.r. = of reading

- It is possible to compensate for the effect by:
- Reading in the current pressure measured value via the current input or a digital
- Specifying a fixed value for the pressure in the device parameters.

Operating Instructions .

DN		[% o.r./bar]	[% o.r./psi]
[mm]	[in]		
8	3/8	no effec	t
15	1/2	no effec	t
25	1	no effec	t
40	11/2	no effec	t
50	2	-0.009	-0.0006

## Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate		Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$		± BaseAccu
	A0021332	
$< \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$		± ZeroPoint MeasValue · 100
	A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate		Maximum repeatability in % o.r.
$\geq \frac{\frac{4}{3} \cdot \text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$		± ½ · BaseAccu
	A0021341	AUUZ1345
$< \frac{4/3 \cdot ZeroPoint}{BaseAccu} \cdot 100$		$\pm \frac{2}{3} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
	A0021342	A0021344

### Example of maximum measurement error



- Maximum measurement error in % o.r. (example: DN 25)
- Flow rate in % of maximum full scale value

## 16.7 Installation

Installation requirements

→ 🗎 20

## 16.8 Environment

# Ambient temperature range

→ \( \bigsize 22 \rightarrow \bigsize 22 \rightarrow \bigsize 22 \rightarrow \bigsize 22

### Temperature tables



Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature

 $-40 \text{ to } +80 \,^{\circ}\text{C} \, (-40 \text{ to } +176 \,^{\circ}\text{F})$ , preferably at  $+20 \,^{\circ}\text{C} \, (+68 \,^{\circ}\text{F})$ 

Climate class

DIN EN 60068-2-38 (test Z/AD)

#### Degree of protection

#### Transmitter

- Standard: IP66/67, type 4X enclosure, suitable for pollution degree 4
- When the housing is open: IP20, type 1 enclosure, suitable for pollution degree 2
- Display module: IP20, type 1 enclosure, suitable for pollution degree 2

### Sensor

IP66/67, Type 4X 2) enclosure, suitable for pollution degree 4

## Device plug

IP67, only in screwed situation

## Vibration resistance and shock resistance

#### Sinusoidal vibration similar to IEC 60068-2-6

- 2 to 8.4 Hz, 3.5 mm peak
- 8.4 to 2000 Hz, 1 g peak

#### Broadband random vibration similar to IEC 60068-2-64

- 10 to 200 Hz, 0.003 g<sup>2</sup>/Hz
- 200 to 2000 Hz, 0.001 g<sup>2</sup>/Hz
- Total: 1.54 g rms

#### Half-sine shocks similar to IEC 60068-2-27

6 ms 30 q

Rough handling shocks similar to IEC 60068-2-31

<sup>2)</sup> Type 4X is not used when a pressure measuring cell is installed.

# Electromagnetic compatibility (EMC)

- As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21), NAMUR Recommendation 21 (NE 21) is fulfilled when the device is installed in accordance with NAMUR Recommendation 98 (NE 98).
- As per IEC/EN 61000-6-2 and IEC/EN 61000-6-4
- Details are provided in the Declaration of Conformity.
- This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.

## 16.9 Process

Medium temperature range -40 to +150 °C (-40 to +302 °F)


Medium density 0 to 2 000 kg/m³ (0 to 125 lb/cf)

Pressure/temperature ratings for the process connections, see ratings

For an overview of the pressure/temperature ratings for the process connections, see the Technical Information

#### Sensor housing

The sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.



In the event of a tube failure, the pressure level inside the sensor housing will rise according to the operating process pressure. If the user judges that the sensor housing burst pressure does not provide an adequate safety margin, the device can be fitted with a rupture disk. This prevents excessively high pressure from forming inside the sensor housing. Therefore, the use of a rupture disk is strongly recommended in applications involving high gas pressures, and particularly in applications in which the process pressure is greater than 2/3 of the sensor housing burst pressure.

### Burst pressure of the sensor housing

If the device is fitted with a rupture disk (order code for "Sensor option", option CA "Rupture disk"), the rupture disk trigger pressure is decisive .

The sensor housing burst pressure refers to a typical internal pressure which is reached prior to mechanical failure of the sensor housing and which was determined during type testing. The corresponding type test declaration can be ordered with the device (order code for "Additional approval", option LN "Sensor housing burst pressure, type test").

DN		Sensor housing	burst pressure
[mm]	[in]	[bar]	[psi]
8	3/8	250	3 6 2 0
15	1/2	250	3 6 2 0
25	1	250	3 6 2 0
40	11/2	200	2 900

DN		Sensor housing burst pressure	
[mm]	[in]	[bar]	[psi]
50	2	180	2610
80	3	120	1740

For information on the dimensions: see the "Mechanical construction" section of the "Technical Information" document

### Rupture disk

To increase the level of safety, a device version with a rupture disk with a trigger pressure of 10 to 15 bar (145 to 217.5 psi) can be used (order code for "Sensor option", option CA "rupture disk").

The use of rupture disks cannot be combined with the separately available heating jacket.

#### Internal cleaning

- CIP cleaning
- SIP cleaning

#### **Options**

Oil- and grease-free version for wetted parts, without declaration Order code for "Service", option HA  $^{3)}$ 

#### Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.

- For an overview of the full scale values for the measuring range, see the "Measuring range" section  $\rightarrow \stackrel{ riangle}{=} 138$
- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- For the most common applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
  - The flow velocity in the measuring tubes should not exceed half the speed of sound (0.5 Mach)
  - The maximum mass flow depends on the density of the gas: formula
- To calculate the flow limit, use the *Applicator* sizing tool  $\rightarrow \triangleq 135$

## Pressure loss

## System pressure

→ 🖺 22

## 16.10 Mechanical construction

#### Design, dimensions

For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section

150

<sup>3)</sup> Cleaning only refers to the measuring instrument. Any accessories that have been supplied are not cleaned.

## Weight

All values (weight exclusive of packaging material) refer to devices with EN/DIN PN 40 flanges.

## Weight in SI units

DN [mm]	Weight [kg]
8	5
15	5.5
25	7
40	11
50	16

## Weight in US units


DN [in]	Weight [lbs]
3/8	11
1/2	12
1	15
1½	24
2	35

## Materials

## Transmitter housing

- Order code for "Housing", option C "Compact, aluminum coated": Aluminum, AlSi10Mq, coated
- Window material: glass

## Cable entries/cable glands



A002835

■ 25 Possible cable entries/cable glands

- 1 Internal thread  $M20 \times 1.5$
- 2 Cable gland M20 × 1.5
- 3 Adapter for cable entry with internal thread G  $\frac{1}{2}$ " or NPT  $\frac{1}{2}$ "
- 4 Device plug

Order code for "Housing", option C "GT20 dual compartment, aluminum coated"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	<ul><li>Non-hazardous area</li><li>Ex ia</li><li>Ex ic</li></ul>	Plastic
	Adapter for cable entry with female thread G ½"	Nickel-plated brass
Adapter for cable entry with female thread NPT ½"	Non-hazardous area and hazardous area (except for CSA Ex d/XP)	Nickel-plated brass
Thread NPT ½" via adapter	Non-hazardous area and hazardous area	

## Device plug

Electrical connection	Material
Plug M12x1	<ul> <li>Socket: stainless steel, 1.4401/316</li> <li>Contact housing: plastic, PUR, black</li> <li>Contacts: metal, CuZn, gold-plated</li> <li>Threaded connection seal: NBR</li> </ul>

### Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

## Measuring tubes

Stainless steel, 1.4539 (904L); manifold: stainless steel, 1.4404 (316L)

## **Process connections**

- Flanges similar to EN 1092-1 (DIN2501) / similar to ASME B 16.5 / as per JIS B2220: Stainless steel, 1.4404 (F316/F316L)
- All other process connections: Stainless steel, 1.4404 (316/316L)
- Available process connections → 🖺 153

### Seals

Welded process connections without internal seals

## Accessories

Protective cover

Stainless steel, 1.4404 (316L)

Remote display FHX50

Housing material:

- Plastic PBT
- Stainless steel CF-3M (316L, 1.4404)

### Process connections

- Fixed flange connections:
  - EN 1092-1 (DIN 2501) flange
  - EN 1092-1 (DIN 2512N) flange
  - NAMUR lengths in accordance with NE 132
  - ASME B16.5 flange
  - JIS B2220 flange
  - DIN 11864-2 Form A flange, DIN 11866 series A, flange with notch
- Clamp connections:

Tri-Clamp (OD tubes), DIN 11866 series C

- Thread:
  - DIN 11851 thread, DIN 11866 series A
  - SMS 1145 thread
  - ISO 2853 thread, ISO 2037
  - DIN 11864-1 Form A thread, DIN 11866 series A
- VCO connections:
  - 8-VCO-4
  - 12-VCO-4
- i

Process connection materials

#### Surface roughness

All data relate to parts in contact with medium.

*The following surface roughness categories can be ordered:* 

Category	Method	Option(s)/Order code "Measuring tube mat., wetted surface"
Not polished	_	SA
Ra $\leq$ 0.76 µm (30 µin) 1)	Mechanically polished <sup>2)</sup>	SB
Ra ≤ 0.76 μm (30 μin) <sup>1)</sup>	Mechanically polished <sup>2)</sup> , welds in as-welded condition	SJ
Ra $\leq$ 0.38 $\mu$ m (15 $\mu$ in) $^{1)}$	Mechanically polished <sup>2)</sup>	SC
Ra ≤ 0.38 μm (15 μin) <sup>1)</sup>	Mechanically polished <sup>2)</sup> , welds in as-welded condition	SK

- 1) Ra according to ISO 21920
- 2) Inaccessible weld seams between pipe and manifold are excluded

## 16.11 Operability

### Languages


Can be operated in the following languages:

- Via local display:
- English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Swedish, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech
- Via "FieldCare" operating tool:
   English, German, French, Spanish, Italian, Chinese, Japanese

### Onsite operation

## Via display module

Two display modules are available:



### Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured

## Operating elements


- lacktriangledown Operation with 3 push buttons with open housing: lacktriangledown, lacktriangledown
- External operation via touch control (3 optical keys) without opening the housing:  $\boxdot$ ,  $\boxdot$ ,
- Operating elements also accessible in the various zones of the hazardous area

#### Additional functionality

- Data backup function
  - The device configuration can be saved in the display module.
- Data comparison function
  - The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
  - The transmitter configuration can be transmitted to another device using the display module.

### Via remote display FHX50

The remote display FHX50 can be ordered as an optional extra $\rightarrow \triangleq 133$ .



■ 26 FHX50 operating options

- 1 SD02 display and operating module, push buttons: cover must be opened for operation
- 2 SD03 display and operating module, optical buttons: operation possible through cover glass

## Display and operating elements

The display and operating elements correspond to those of the display module.

Remote operation	→ 🖺 53		
Service interface	→ 🖺 54		

## 16.12 Certificates and approvals

Current certificates and approvals for the product are available at <a href="https://www.endress.com">www.endress.com</a> on the relevant product page:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Downloads**.

#### CE mark

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

### **UKCA** marking

The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK:

Endress+Hauser Ltd. Floats Road Manchester M23 9NF

United Kingdom www.uk.endress.com

### RCM marking

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

### Ex-approval

The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.

#### Hygienic compatibility

- 3-A approval
  - Only measuring instruments with the order code for "Additional approval", option LP "3A" have 3-A approval.
  - The 3-A approval refers to the measuring instrument.
  - When installing the measuring instrument, ensure that no liquid can accumulate on the outside of the measuring instrument.
    - A remote display module must be installed in accordance with the 3-A Standard.
  - Accessories (e.g. heating jacket, weather protection cover, wall holder unit) must be installed in accordance with the 3-A Standard.
    - Each accessory can be cleaned. Disassembly may be necessary under certain circumstances.
- EHEDG-tested (Type EL Class I)

Only devices with the order code for "Additional approval", option LT "EHEDG" have been tested and meet the requirements of the EHEDG.

To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy cleanable Pipe couplings and Process connections" (www.ehedg.org).

To meet the requirements for EHEDG certification, the orientation of the device must ensure drainability.

Test criteria for cleanability according to EHEDG is a flow velocity of 1.5~m/s in the process line. This speed must be ensured for EHEDG-compliant cleaning.

- FDA CFR 21
- Food Contact Materials Regulation (EC) 1935/2004
- Food Contact Materials Regulation GB 4806
- The requirements of the Food Contact Material regulations must be observed when selecting the material versions.



Observe special installation instructions

# Pharmaceutical compatibility

- FDA 21 CFR 177
- USP <87>
- USP <88> Class VI 121 °C
- TSE/BSE Certificate of Suitability
- cGMP

Devices with the order code for "Test, certificate", option JG "Conformity with cGMP-derived requirements, declaration" comply with the requirements of cGMP with regard to the surfaces of parts in contact with the medium, design, FDA 21 CFR material conformity, USP Class VI tests and TSE/BSE conformity.

A serial number-specific declaration is generated.

#### Certification PROFIBUS

#### **PROFIBUS** interface

The measuring device is certified and registered by the PNO (PROFIBUS Nutzerorganisation e.V./PROFIBUS User Organization). The measuring system meets all the requirements of the following specifications:

- Certified according to PA Profile 3.02
- The device can also be operated with certified devices of other manufacturers (interoperability)

## Pressure Equipment Directive

- With the marking
  - a) PED/G1/x (x = category) or
  - b) PESR/G1/x (x = category)

on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements"

- a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or
- b) Schedule 2 of Statutory Instruments 2016 No. 1105.
- Devices not bearing this marking (without PED or PESR) are designed and manufactured according to sound engineering practice. They meet the requirements of
  - a) Art. 4, Section 3 of the Pressure Equipment Directive 2014/68/EU or
  - b) Part 1, Section 8 of Statutory Instruments 2016 No. 1105.

The scope of application is indicated

- a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or
- b) in Schedule 3, Section 2 of Statutory Instruments 2016 No. 1105.

## External standards and quidelines

#### ■ EN 60529

Degrees of protection provided by enclosure (IP code)

■ IEC/EN 60068-2-6

Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal).

■ IEC/EN 60068-2-31

Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices.

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements

■ GB 30439.5

Safety requirements for industrial automation products - Part 5: Flowmeter safety requirements

■ EN 61326-1/-2-3

EMC requirements for electrical equipment for measurement, control and laboratory use

■ IEC 61508

Functional safety of electrical/electronic/programmable electronic safety-related systems

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 80

The application of the pressure equipment directive to process control devices

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

NAMUR NE 107

Self-monitoring and diagnostics of field devices

NAMUR NE 131

Requirements for field devices for standard applications

■ NAMUR NE 132

Coriolis mass meter

■ ETSI EN 300 328

Guidelines for 2.4 GHz radio components.

■ EN 301489

Electromagnetic compatibility and radio spectrum matters (ERM).

## 16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



#### Diagnostic functionality

Order code for "Application package", option EA "Extended HistoROM"

Comprises extended functions concerning the event log and the activation of the measured value memory.

#### Event log:

Memory volume is extended from 20 message entries (standard version) to up to 100 entries.

Data logging (line recorder):

- Memory capacity for up to 1000 measured values is activated.
- 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.
- Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.



For detailed information, see the Operating Instructions for the device.

## Heartbeat Technology

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

## **Heartbeat Verification**

Meets the requirement for traceable verification in accordance with DIN ISO 9001:2015 Clause 7.6 a) "Control of monitoring and measuring equipment".

- Functional testing in the installed state without interrupting the process.
- Traceable verification results on request, including a report.
- Simple testing process via local operation or other operating interfaces.
- Clear measuring point assessment (pass/fail) with high total test coverage within the framework of manufacturer specifications.
- Extension of calibration intervals according to operator's risk evaluation.



Detailed information on Heartbeat Technology:

Special Documentation  $\rightarrow \triangleq 159$ 

## Petroleum & locking function

Order code for "Application package", option EM "Petroleum & locking function"

The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package. It is also possible to lock the settings.

- Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1"
- Water content, based on density measurement
- Weighted mean of the density and temperature



For detailed information, see the Special Documentation for the device.

## 16.14 Accessories



Overview of accessories available to order  $\rightarrow \implies 133$ 

## 16.15 Documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

#### Standard documentation

### **Brief Operating instructions**

## Brief Operating Instructions for the sensor

Measuring instrument	Documentation code
Proline Promass E	KA01260D

## Brief Operating Instructions for transmitter

Measuring device	Documentation code
Proline Promass 200	KA01269D

### **Technical information**

Measuring device	Documentation code
Promass E 200	TI01300D

## Device-dependent

## Safety instructions

Contents	Documentation code
ATEX/IECEx Ex i	XA00144D
ATEX/IECEx Ex d	XA00143D
ATEX/IECEx Ex nA	XA00145D
cCSAus IS	XA00151D
cCSAus XP	XA00152D
INMETRO Ex i	XA01300D
INMETRO Ex d	XA01305D
INMETRO Ex nA	XA01306D
JPN Ex d	XA01763D
KCs Ex d	XA03546D
NEPSI Ex i	XA00156D
NEPSI Ex d	XA00155D
NEPSI Ex nA	XA00157D
NEPSI Ex i	XA1755D

Contents	Documentation code
NEPSI Ex d	XA1754D
NEPSI Ex nA	XA1756D

## Special documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Display and operating module FHX50	SD01007F
Heartbeat Technology	SD01850D

## **Installation Instructions**

Contents	Note
Installation instructions for spare part sets and accessories	<ul> <li>Access the overview of all the available spare part sets via <i>Device Viewer</i> →          □ 130</li> <li>Accessories available for order with Installation Instructions →          □ 133</li> </ul>

## Index

09	D
3-A approval	Date of manufacture
	Declaration of Conformity
A	Defining the access code
Access authorization to parameters	Degree of protection
Read access	Design fundamentals
Write access	Measurement error
Access code	Repeatability
Incorrect input	Device
Adapting the diagnostic behavior	Configuring 6
Ambient conditions	Preparing for electrical connection
Storage temperature	Device components
Vibration resistance and shock resistance 148	Device description files
Ambient temperature	Device locking, status
Influence	Device master file
Analog Input module	GSD
Analog Output module	Device name
Application	Sensor
Application packages	Transmitter
Applicator	Device repair
Approvals	Device revision
C	Device type code
C California de la contra del contra de la contra del la contra de la contra del la cont	Device Viewer
Cable entries	DeviceCare
Technical data	Device description file 50
Cable entry	Diagnostic behavior
Degree of protection	Explanation
CE mark	Symbols
Certificates	Diagnostic information
Certification PROFIBUS	Design, description
Check	DeviceCare
	FieldCare
Connection	Local display
Checklist	Overview
Post-connection check	Remedial measures
Post-installation check	Diagnostic list
CIP cleaning	Diagnostic message
Climate class	Diagnostics
Commissioning	Symbols
Advanced settings	DIP switch
Configuring the device	see Write protection switch
Compatibility with previous model	Direct access
Connecting the device	Disabling write protection
Connection	Discrete Input module 6
see Electrical connection	Discrete Output module 62
Connection cable	Display
Connection preparations	see Local display
Connection tools	Display area
Context menu	For operational display
Calling up	In the navigation view 4
Closing	Display values
Explanation	For locking status
Current consumption	Displaying the measured value history
Cyclic data transmission	Disposal
Sychic data transmission	Document
	Function
·	

Symbols         6           Document function         6           Documentation         159	Identifying the measuring instrument
Down pipe	Current diagnostic event
	Previous diagnostic event
E	Influence
EHEDG-tested	Ambient temperature
Electrical connection	Medium pressure
Commubox FXA291	Medium temperature
Degree of protection	Information about this document 6
Measuring instrument	Inlet runs
Operating tools	Input screen
Via PROFIBUS PA network	Input variables
Via service interface (CDI)	Inspection
Electromagnetic compatibility	Installation
EMPTY_MODULE module	Installation
Enabling write protection	Installation dimensions
Error messages	Installation requirements
see Diagnostic messages	Down pipe
Event logbook	Installation dimensions
Ex-approval	Mounting location
Extended order code	Orientation
Sensor	Rupture disk
Transmitter	Sensor heating
	Thermal insulation
F	Vibrations
FDA	Intended use
Field of application	Internal cleaning
Residual risks	S .
FieldCare	L
Device description file	Languages, operation options
Function	Line recorder
Filtering the event logbook	Load
Release date	Editing view 42
Version	Navigation view 41
Firmware history	see Diagnostic message
Flow direction	see In alarm condition
Flow limit	see Operational display
Food Contact Materials Regulation	Low flow cut off
SIMATIC PDM	M
Functions	Main electronics module
see Parameter	Maintenance work
see i didinetei	Managing the device configuration
G	Manufacturer ID
Galvanic isolation	Manufacturing date
	Materials
H	Maximum measurement error
Hardware write protection	Measured variables
Help text	see Process variables
Calling up	Measurement accuracy
Closing	Measuring and test equipment
Explanation	Measuring device
Historion of the Historian of the Histor	Conversion
Hygienic compatibility	Repairs
Ţ	Structure
I/O electronics module	

162

Measuring instrument	Operating menu
Disposal	Menus, submenus
Installing the sensor	Structure
Preparing for mounting	Submenus and user roles
Removing	Operating philosophy
Switch on	Operation
Measuring principle	Operation options
Measuring range	Operational display
For gases	Operational safety
For liquids	Order code
Measuring range, recommended 150	Orientation (vertical, horizontal) 21
Measuring system	Outlet runs
Medium density	Output signal
Medium pressure	Output variables
Influence	_
Medium temperature	P
Influence	Packaging disposal
Menu	Parameter settings
Diagnostics	Administration (Submenu) 87
Setup	Communication (Submenu) 69
Menus	Configuration backup display (Submenu) 88
For device configuration 65	Data logging (Submenu)
For specific settings	Device information (Submenu) 126
Module	Diagnostics (Menu)
Analog Input	Display (Submenu)
Analog output 61	Display (Wizard) 70
Discrete Input 61	Low flow cut off (Wizard)
Discrete Output 62	Medium selection (Submenu) 69
EMPTY MODULE 63	Output values (Submenu)
Totalizer	Partially filled pipe detection (Wizard) 73, 74
SET_TOT_TOTAL	Process variables (Submenu)
SETTOT_MODETOT_TOTAL 60	Pulse/frequency/switch output (Wizard)
TOTAL	
Mounting dimensions	Sensor adjustment (Submenu) 76
see Installation dimensions	Setup (Menu)
Mounting location	Simulation (Submenu)
Mounting preparations	System units (Submenu)
Mounting requirements	Totalizer (Submenu)
Static pressure	Totalizer 1 to n (Submenu) 83
Mounting tools	Totalizer handling (Submenu)
	Web server (Submenu)
N	Zero point adjustment (Submenu) 76
Nameplate	Parameters
Sensor	Changing
Transmitter	Entering a value
Navigation path (navigation view) 41	Performance characteristics
Navigation view	Pharmaceutical compatibility
In the submenu 41	Post-connection check
In the wizard	Post-connection check (checklist)
Netilion	Post-installation check
Numeric editor	Post-installation check (checklist)
0	Potential equalization
Oneita displan	Power consumption
Onsite display	Power supply failure
Operable flow range	Pressure Equipment Directive
Operating elements	Pressure loss
Operating slaments	Pressure/temperature ratings
see Operating elements	Process connections
	i

Process variables	Sensor adjustment
Calculated	Simulation
Measured	Switch output
Product safety	System units
Protecting parameter settings 91	Tag name
ח	Totalizer
R	Totalizer reset
RCM marking	SETTOT_MODETOT_TOTAL module 60
Read access	Signal on alarm
Reading off measured values	SIMATIC PDM
Recalibration	Function
Reference operating conditions	SIP cleaning
Remedial actions	Software release
Calling up	Spare part
Closing	Spare parts
Remote operation	Special connection instructions
Repair	Special mounting instructions
Notes	Hygienic compatibility
Repair of a device	Static pressure
Repeatability	Status area
Replacement	For operational display
Device components	In the navigation view
Requirements for personnel	Status signals
Response time	Storage conditions
Return	Storage temperature
Rupture disk	Storage temperature range
Safety instructions	Structure
Triggering pressure	Measuring device
	Operating menu
S	Submenu
Safety	Administration
Sensor	Advanced setup
Installing	Communication
Sensor heating	Configuration backup display 88
Sensor housing	Data logging
Serial number	Device information
Services	Display
Maintenance	Event logbook
Repair	Measured values
SET_TOT_TOTAL module	Medium selection
Setting the operating language 64 Settings	Output values
Adapting the measuring device to the process	Overview
conditions	Process variables
Administration	Sensor adjustment
Advanced display configurations	Simulation
Communication interface 69	System units
Local display	Totalizer 1 to n
Low flow cut off	Totalizer handling
Managing the device configuration 88	Web server
Medium	Zero point adjustment
Operating language	Supply unit
Partial filled pipe detection 74	Requirements
Partially filled pipe detection	Supply voltage
Pulse output	Surface roughness
Pulse/frequency/switch output 77, 79	Symbols
Resetting the device	For communication
Resetting the totalizer	For correction

For diagnostic behavior For locking For measured variable For measurement channel number For menus For parameters For status signal For submenu For wizards In the status area of the local display	39 41 . 41 . 39 41 . 39
see Measuring device design	137
System integration	56
Temperature range	137
Storage temperature	142 31 143 42 22
Transportation	18
Electrical connection	28 25 59
Assign process variable	83 98
Transmitter  Connecting the signal cables	26 26
Troubleshooting General	156
see Turning the transmitter housing Turning the transmitter housing	26
U	
UKCA marking	
Borderline cases	
User roles	38

USP Class VI
V Version data for the device
W
W@M Device Viewer
Weight
SI units
Transport (notes)
US units
Wizard
Display
Low flow cut off
Partially filled pipe detection
Pulse/frequency/switch output 77, 78, 79, 83
Workplace safety
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com