

Description of Device Parameters

Proline Promass 100

PROFIBUS DP

Coriolis flowmeter




Table of contents

| | | | |
|---|-----------|---|------------|
| 1 About this document | 4 | | |
| 1.1 Document function | 4 | 3.9.2 "Event logbook" submenu | 163 |
| 1.2 Target group | 4 | 3.9.3 "Device info" submenu | 164 |
| 1.3 Using this document | 4 | 3.9.4 "Min/max val." submenu | 168 |
| 1.3.1 Information on the document structure | 4 | 3.9.5 "Heartbeat" submenu | 177 |
| 1.3.2 Structure of a parameter description | 6 | 3.9.6 "Simulation" submenu | 177 |
| 1.4 Symbols used | 6 | | |
| 1.4.1 Symbols for certain types of information | 6 | 4 Country-specific factory settings .. | 181 |
| 1.4.2 Symbols in graphics | 7 | 4.1 SI units | 181 |
| 1.5 Documentation | 7 | 4.1.1 System units | 181 |
| 1.5.1 Standard documentation | 7 | 4.1.2 Full scale values | 181 |
| 1.5.2 Supplementary device-dependent documentation | 7 | 4.1.3 On value low flow cut off | 182 |
| 2 Overview of the Expert operating menu | 8 | 4.2 US units | 183 |
| 4.2.1 System units | 183 | 4.2.2 Full scale values | 183 |
| 4.2.3 On value low flow cut off | 183 | | |
| 3 Description of device parameters ... | 11 | | |
| 3.1 "System" submenu | 14 | 5 Explanation of abbreviated units .. | 185 |
| 3.1.1 "Display" submenu | 14 | 5.1 SI units | 185 |
| 3.1.2 "Diagn. handling" submenu | 28 | 5.2 US units | 185 |
| 3.1.3 "Administration" submenu | 36 | 5.3 Imperial units | 187 |
| 3.2 "Sensor" submenu | 41 | | |
| 3.2.1 "Measured val." submenu | 42 | Index | 188 |
| 3.2.2 "System units" submenu | 50 | | |
| 3.2.3 "Process param." submenu | 57 | | |
| 3.2.4 "Measurement mode" submenu | 66 | | |
| 3.2.5 "External comp." submenu | 68 | | |
| 3.2.6 "Calculated value" submenu | 69 | | |
| 3.2.7 "Sensor adjustm." submenu | 73 | | |
| 3.2.8 "Calibration" submenu | 79 | | |
| 3.2.9 "Supervision" submenu | 81 | | |
| 3.3 "Communication" submenu | 81 | | |
| 3.3.1 "PROFIBUS DP conf" submenu | 82 | | |
| 3.3.2 "PROFIBUS DP info" submenu | 83 | | |
| 3.3.3 "Physical block" submenu | 85 | | |
| 3.3.4 "Web server" submenu | 95 | | |
| 3.4 "Analog inputs" submenu | 98 | | |
| 3.4.1 "Analog input 1 to n" submenu | 98 | | |
| 3.5 "Discrete inputs" submenu | 112 | | |
| 3.5.1 "Discrete input 1 to n" submenu | 112 | | |
| 3.6 "Analog outputs" submenu | 119 | | |
| 3.6.1 "Analog output 1 to n" submenu | 119 | | |
| 3.7 "Discrete outputs" submenu | 131 | | |
| 3.7.1 "Discrete output 1 to n" submenu | 131 | | |
| 3.8 "Application" submenu | 141 | | |
| 3.8.1 "Totalizer 1 to n" submenu | 142 | | |
| 3.8.2 "Viscosity" submenu | 156 | | |
| 3.8.3 "Concentration" submenu | 156 | | |
| 3.9 "Diagnostics" submenu | 156 | | |
| 3.9.1 "Diagnostic list" submenu | 159 | | |

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions
- Operating concept of the operating menus: Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
Navigation path to the parameter via the operating tool
The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

| Symbol | Meaning |
|---|---|
|  | Tip Indicates additional information. |
|  | Reference to documentation |
|  | Reference to page |
|  | Reference to graphic |
|  | Operation via local display |
|  | Operation via operating tool |
|  | Write-protected parameter |

1.4.2 Symbols in graphics

| Symbol | Meaning | Symbol | Meaning |
|--------------------|--------------|--------------|---------|
| 1, 2, 3 ... | Item numbers | A, B, C, ... | Views |
| A-A, B-B, C-C, ... | Sections | | |

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

| Measuring device | Documentation code |
|----------------------------|--------------------|
| Promass A 100 | BA01246D |
| Promass E 100 (8E1B**-...) | BA01248D |
| Promass E 100 (8E1C**-...) | BA01714D |
| Promass F 100 | BA01249D |
| Promass G 100 | BA01348D |
| Promass H 100 | BA01250D |
| Promass I 100 | BA01251D |
| Promass O 100 | BA01252D |
| Promass P 100 | BA01253D |
| Promass S 100 | BA01254D |
| Promass X 100 | BA01255D |

1.5.2 Supplementary device-dependent documentation

Special Documentation


| Content | Documentation code |
|---|--------------------|
| Information on the Pressure Equipment Directive | SD01614D |
| Concentration Measurement | SD01152D |
| Heartbeat Technology | SD01153D |
| Web server | SD01821D |

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

| | |
|-------------------------|----------------------|
| Expert | |
| Direct access | → 11 |
| Locking status | → 12 |
| Access stat.disp | → 13 |
| Access stat.tool | → 13 |
| Ent. access code | → 14 |
| System | → 14 |
| ▶ Display | → 14 |
| ▶ Diagn. handling | → 28 |
| ▶ Administration | → 36 |
| Sensor | → 41 |
| ▶ Measured val. | → 42 |
| ▶ System units | → 50 |
| ▶ Process param. | → 57 |
| ▶ Measurement mode | → 66 |
| ▶ External comp. | → 68 |
| ▶ Calculated value | → 69 |
| ▶ Sensor adjustm. | → 73 |
| ▶ Calibration | → 79 |
| ▶ Supervision | → 81 |
| Communication | → 81 |
| PROFIBUS DP conf | → 82 |

| | |
|-------------------------|-------|
| ▶ PROFIBUS DP info | → 83 |
| ▶ Physical block | → 85 |
| ▶ Web server | → 95 |
| ▶ Analog inputs | → 98 |
| ▶ Analog input 1 to n | → 98 |
| ▶ Discrete inputs | → 112 |
| ▶ Discrete input 1 to n | → 112 |
| ▶ Analog outputs | → 119 |
| ▶ Analog output 1 to n | → 119 |
| ▶ Discrete outputs | → 131 |
| ▶ Discr. out. 1 to n | → 131 |
| ▶ Application | → 141 |
| ▶ Totalizer 1 to n | → 142 |
| ▶ Viscosity | → 156 |
| ▶ Concentration | → 156 |
| ▶ Diagnostics | → 156 |
| Actual diagnos. | → 157 |
| Prev.diagnostics | → 157 |
| Time fr. restart | → 158 |
| Operating time | → 158 |
| ▶ Diagnostic list | → 159 |
| ▶ Event logbook | → 163 |
| ▶ Device info | → 164 |
| ▶ Min/max val. | → 168 |



3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

| Expert | |
|--------------------|-----------------------|
| Direct access | → 11 |
| Locking status | → 12 |
| Access stat.disp | → 13 |
| Access stat.tool | → 13 |
| Ent. access code | → 14 |
| ▶ System | → 14 |
| ▶ Sensor | → 41 |
| ▶ Communication | → 81 |
| ▶ Analog inputs | → 98 |
| ▶ Discrete inputs | → 112 |
| ▶ Analog outputs | → 119 |
| ▶ Discrete outputs | → 131 |
| ▶ Application | → 141 |
| ▶ Diagnostics | → 156 |


Direct access



| | |
|---------------------|---|
| Navigation | Expert → Direct access |
| Prerequisite | There is a local display with operating elements. |
| Description | Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose. |
| User entry | 0 to 65 535 |

Additional information*User entry*

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

A0029414

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
Example: Enter 00914 → **Assign variable** parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign variable** parameter

Locking status**Navigation**

Expert → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Temp. locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Selection

| Options | Description |
|---------------------------------|---|
| Hardware locked (priority 1) | The write protection switch (DIP switch) for hardware locking is activated on the I/O electronic module. This locks write access to the parameters . |
| Temp. locked (priority 2) | Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again. |

Access stat.disp

| | |
|-------------------------------|--|
| Navigation |  Expert → Access stat.disp |
| Prerequisite | A local display is provided. |
| Description | Displays the access authorization to the parameters via the local display. |
| User interface | <ul style="list-style-type: none"> ▪ Operator ▪ Maintenance |
| Factory setting | Operator |
| Additional information | <p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Ent. access code parameter (→  14).</p> <p> For information about the Ent. access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device</p> |

Access stat.tool

| | |
|-------------------------------|---|
| Navigation |  Expert → Access stat.tool |
| Description | Displays the access authorization to the parameters via the operating tool or Web browser. |
| User interface | <ul style="list-style-type: none"> ▪ Operator ▪ Maintenance |
| Factory setting | Maintenance |
| Additional information | <p><i>Description</i></p> <p> Access authorization can be modified via the Ent. access code parameter (→  14).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device</p> |

Ent. access code**Navigation**  Expert → Ent. access code**Description**

Use this function to enter the user-specific release code to remove parameter write protection.

User entry

0 to 9 999

3.1 "System" submenu

Navigation  Expert → System

| | |
|-------------------|--|
| ▶ System | |
| ▶ Display | →  14 |
| ▶ Diagn. handling | →  28 |
| ▶ Administration | →  36 |

3.1.1 "Display" submenu

Navigation  Expert → System → Display

| | |
|------------------|--|
| ▶ Display | |
| Display language | →  15 |
| Format display | →  16 |
| Value 1 display | →  18 |
| 0% bargraph 1 | →  19 |
| 100% bargraph 1 | →  20 |
| Decimal places 1 | →  20 |
| Value 2 display | →  20 |
| Decimal places 2 | →  21 |
| Value 3 display | →  21 |

| | |
|------------------|-------|
| 0% bargraph 3 | → 22 |
| 100% bargraph 3 | → 22 |
| Decimal places 3 | → 23 |
| Value 4 display | → 23 |
| Decimal places 4 | → 24 |
| Display interval | → 24 |
| Display damping | → 25 |
| Header | → 25 |
| Header text | → 26 |
| Separator | → 26 |
| Contrast display | → 27 |
| Backlight | → 27 |
| Access stat.disp | → 27 |

Display language

Navigation

Expert → System → Display → Display language

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык(Ru) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *

* Visibility depends on order options or device settings

- 한국어 (Korean) *
- Bahasa Indonesia *
- tiếng Việt (Viet) *
- čeština (Czech) *

| | |
|-----------------|---|
| Factory setting | English (alternatively, the ordered language is preset in the device) |
|-----------------|---|

Format display

| | |
|------------|--|
| Navigation |  Expert → System → Display → Format display |
|------------|--|

| | |
|--------------|------------------------------|
| Prerequisite | A local display is provided. |
|--------------|------------------------------|

| | |
|-------------|---|
| Description | Use this function to select how the measured value is shown on the local display. |
|-------------|---|

| | |
|-----------|--|
| Selection | <ul style="list-style-type: none">■ 1 value, max.■ Bagr. + 1 value■ 2 values■ Val. large+2val.■ 4 values |
|-----------|--|

| | |
|-----------------|---------------|
| Factory setting | 1 value, max. |
|-----------------|---------------|


| | |
|------------------------|---|
| Additional information | <i>Description</i> The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation. |
|------------------------|---|

-  ■ The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 24).


* Visibility depends on order options or device settings

Possible measured values shown on the local display:


"1 value, max." option




"Bagr. + 1 value" option




"2 values" option



"Val. large+2val." option



"4 values" option



Value 1 display

| | |
|------------------------|--|
| Navigation | Expert → System → Display → Value 1 display |
| Prerequisite | A local display is provided. |
| Description | Use this function to select one of the measured values to be shown on the local display. |
| Selection | <ul style="list-style-type: none">■ Mass flow■ Volume flow■ Correct.vol.flow■ Target mass flow [*]■ Carrier mass fl. [*]■ Density■ Ref.density■ Concentration [*]■ Dynam. viscosity [*]■ Kinematic visc.■ TempCompDynVisc [*]■ TempCompKinVisc■ Temperature■ Carr. pipe temp. [*]■ Electronic temp.■ Osc. freq. 0■ Osc. freq. 1 [*]■ Freq. fluct. 0■ Freq. fluct. 1 [*]■ Osc. ampl. 0 [*]■ Osc. ampl. 1 [*]■ Freq. fluct. 0■ Osc. damping 0■ Osc. damping 1 [*]■ Damping fluct 0■ Damping fluct 1■ Signal asymmetry■ Exc. current 0■ Exc. current 1 [*]■ Sensor integrity [*]■ None■ Totalizer 1■ Totalizer 2■ Totalizer 3 |
| Factory setting | Mass flow |

* Visibility depends on order options or device settings

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

Selection

- **Oscil. frequency** option

Displays the current oscillation frequency of the measuring tubes. This frequency depends on the density of the medium.

- **Oscil. amplitude** option

Displays the relative oscillation amplitude of the measuring tubes in relation to the preset value. This value is 100 % under optimum conditions.

- **Oscil. damping** option

Displays the current oscillation damping. Oscillation damping is an indicator of the sensor's current need for excitation power.

- **Signal asymmetry** option

Displays the relative difference between the oscillation amplitude at the inlet and outlet of the sensor. The measured value is the result of production tolerances of the sensor coils and should remain constant over the life time of a sensor.

0% bargraph 1**Navigation**

Expert → System → Display → 0% bargraph 1

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

100% bargraph 1



Navigation

Expert → System → Display → 100% bargraph 1

Prerequisite

A local display is provided.

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → [181](#)

Additional information

Description

The **Format display** parameter (→ [16](#)) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ [50](#)).

Decimal places 1



Navigation

Expert → System → Display → Decimal places 1

Prerequisite

A measured value is specified in the **Value 1 display** parameter (→ [18](#)).

Description

Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information

Description

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display



Navigation

Expert → System → Display → Value 2 display

Prerequisite

A local display is provided.

| | |
|-------------------------------|---|
| Description | Use this function to select one of the measured values to be shown on the local display. |
| Selection | For the picklist, see the Value 1 display parameter (→ 18) |
| Factory setting | None |
| Additional information | <p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 50).</p> |

Decimal places 2



| | |
|-------------------------------|---|
| Navigation |  Expert → System → Display → Decimal places 2 |
| Prerequisite | A measured value is specified in the Value 2 display parameter (→ 20). |
| Description | Use this function to select the number of decimal places for measured value 2. |
| Selection | <ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX |
| Factory setting | x.xx |
| Additional information | <p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p> |

Value 3 display



| | |
|------------------------|---|
| Navigation |  Expert → System → Display → Value 3 display |
| Prerequisite | A local display is provided. |
| Description | Use this function to select one of the measured values to be shown on the local display. |
| Selection | For the picklist, see the Value 1 display parameter (→ 18) |
| Factory setting | None |

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

0% bargraph 3**Navigation**

  Expert → System → Display → 0% bargraph 3

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information*Description*

 The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

100% bargraph 3**Navigation**

  Expert → System → Display → 100% bargraph 3

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

Decimal places 3**Navigation**

Expert → System → Display → Decimal places 3

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 21).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display**Navigation**

Expert → System → Display → Value 4 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ 18)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→ 50).

Decimal places 4**Navigation**

  Expert → System → Display → Decimal places 4

Prerequisite

A measured value is specified in the **Value 4 display** parameter (→ 23).

Description

Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval**Navigation**

  Expert → System → Display → Display interval

Prerequisite

A local display is provided.

Description

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry

1 to 10 s

Factory setting

5 s

Additional information*Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Display damping**Navigation**

Expert → System → Display → Display damping

Prerequisite

A local display is provided.

Description

Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

**Header****Navigation**

Expert → System → Display → Header

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection

- Device tag
- Free text


Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.

1) proportional transmission behavior with first order delay



A0029422

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 165).
- Free text
Is defined in the **Header text** parameter (→ 26).

Header text



Navigation

Expert → System → Display → Header text

Prerequisite

In the **Header** parameter (→ 25), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.

User entry


Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information

Description

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator



Navigation

Expert → System → Display → Separator

Prerequisite

A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation  Expert → System → Display → Contrast display

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Backlight

Navigation  Expert → System → Display → Backlight

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

Access stat.disp

Navigation  Expert → System → Display → Access stat.disp

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.

User interface

- Operator
- Maintenance

Factory setting Operator

Additional information*Description*

If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.



Access authorization can be modified via the **Ent. access code** parameter (→  14).



For information about the **Ent. access code** parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device



If additional write protection is active, this restricts the current access authorization even further.


Display

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

3.1.2 "Diagn. handling" submenu

Navigation

 Expert → System → Diagn. handling



Alarm delay

*Navigation*

  Expert → System → Diagn. handling → Alarm delay

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

*Additional information**Result*

This setting affects the following diagnostic messages:

- 046 Sensor limit
- 140 Sensor sig.asym.
- 144 MeasErrorTooHigh
- 190 Special event 1
- 191 Special event 5
- 192 Special event 9

- 830 Sensor temp.
- 831 Sensor temp.
- 832 Electronic temp.
- 833 Electronic temp.
- 834 Process temp.
- 835 Process temp.
- 843 Process limit
- 862 Partly filled
- 910 Tube not oscill.
- 912 Medium inhomog.
- 913 Medium unsuitab.
- 944 MonitoringFailed
- 990 Special event 4
- 991 Special event 8
- 992 Special event 12

"Diagn. behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagn. behavior** submenu (→  29).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

| Diagnostic behavior | Description |
|---------------------|--|
| Alarm | The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. |
| Warning | The device continues to measure. The measured value output via PROFIBUS and the totalizers are not affected. A diagnostic message is generated. |
| Logbook only | The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→  163) (Event list submenu (→  163)) and not in alternation with the operational display. |
| Off | The diagnostic event is ignored, and no diagnostic message is generated or entered. |

 For a list of all the diagnostic events, see the Operating Instructions for the device

Navigation

  Expert → System → Diagn. handling → Diagn. behavior

▶ **Diagn. behavior**

| | |
|--|--|
| Diagnostic no. 140 | →  30 |
| Diagnostic no. 046 | →  30 |
| Diagnostic no. 144 | →  31 |
| Diagnostic no. 832 | →  31 |
| Diagnostic no. 833 | →  32 |

| | |
|--------------------|-------|
| Diagnostic no. 834 | → 32 |
| Diagnostic no. 835 | → 32 |
| Diagnostic no. 912 | → 33 |
| Diagnostic no. 913 | → 33 |
| Diagnostic no. 944 | → 33 |
| Diagnostic no. 948 | → 34 |
| Diagnostic no. 192 | → 34 |
| Diagnostic no. 274 | → 34 |
| Diagnostic no. 392 | → 35 |
| Diagnostic no. 592 | → 35 |
| Diagnostic no. 992 | → 35 |

Diagnostic no. 140 (Sensor sig.asym.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 140

Description

Use this function to change the diagnostic behavior of the diagnostic message **140 Sensor sig.asym..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → 29

Diagnostic no. 046 (Sensor limit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 046

Description

Option for changing the diagnostic behavior of the diagnostic message **046 Sensor limit.**

| | |
|-------------------------------|---|
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only |
| Factory setting | Warning |
| Additional information |  For a detailed description of the options available, see → 29 |

Diagnostic no. 144 (MeasErrorTooHigh)



| | |
|-------------------------------|--|
| Navigation |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 144 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 144 MeasErrorTooHigh . |
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only |
| Factory setting | Alarm |
| Additional information |  For a detailed description of the options available, see → 29 |

Diagnostic no. 832 (Electronic temp.)



| | |
|-------------------------------|--|
| Navigation |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 |
| Description | Use this function to change the diagnostic behavior of the diagnostic message 832 Electronic temp.. |
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only |
| Factory setting | Warning |
| Additional information |  For a detailed description of the options available, see → 29 |

Diagnostic no. 833 (Electronic temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833

Description

Use this function to change the diagnostic behavior of the diagnostic message **833 Electronic temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [29](#)

Diagnostic no. 834 (Process temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834

Description

Use this function to change the diagnostic behavior of the diagnostic message **834 Process temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [29](#)

Diagnostic no. 835 (Process temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835

Description

Use this function to change the diagnostic behavior of the diagnostic message **835 Process temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [29](#)

Diagnostic no. 912 (Medium inhomog.)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 912 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 912 Medium inhomog.. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 913 (Medium unsuitab.)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 913 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 913 Medium unsuitab.. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 944 (MonitoringFailed)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 944 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 944 MonitoringFailed. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 948 (Oscill. damping)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 948 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 948 Oscill. damping. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 192 (Special event 9)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 192 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 192 Special event 9. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 374 (Sensor electron.)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 274 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 374 Sensor electron.. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 392 (Special event 10)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 392 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 392 Special event 10 . |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 592 (Special event 11)

| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 592 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 592 Special event 11 . |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available, see → 29 |

Diagnostic no. 992 (Special event 12)

| | |
|------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 992 |
| Description | Option for changing the diagnostic behavior of the diagnostic message 992 Special event 12 . |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only |
| Factory setting | Warning |


Additional information

For a detailed description of the options available, see → [29](#)

3.1.3 "Administration" submenu

Navigation

Expert → System → Administration



"Def. access code" wizard




The **Def. access code** wizard (→ [36](#)) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Def. access code** parameter (→ [38](#)) can be found directly in the **Administration** submenu. There is no **Confirm code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code



Def. access code

**Navigation**

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol.

On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→  14).

 If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm code**Navigation**

 Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

0 to 9 999

Factory setting

0

"Reset access code" submenu*Navigation*

  Expert → System → Administration → Reset acc. code

| | |
|--|--|
|  Reset acc. code | |
| Operating time | →  38 |
| Reset acc. code | →  38 |

Operating time

Navigation

  Expert → Diagnostics → Operating time

  Diagnostics → Operating time

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

The maximum number of days is 9999, which is equivalent to 27 years.

Reset acc. code

Navigation

  Expert → System → Administration → Reset acc. code → Reset acc. code

Description

Use this function to enter a reset code to reset the user-specific release code to the factory setting.

User entry

Character string comprising numbers, letters and special characters

Factory setting

0x00

Additional information

Description

 For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via interface CDI RJ45)
- Fieldbus

Additional parameters in the "Administration" submenu

Def. access code

**Navigation**

 Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting 0**Additional information** *Description*

The write protection affects all parameters in the document marked with the  symbol.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→ 14).

 If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Device reset **Navigation**  Expert → System → Administration → Device reset**Description** Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.**Selection**

- Cancel
- To delivery set.
- Restart device

Factory setting Cancel**Additional information** *Selection*

| Options | Description |
|------------------|--|
| Cancel | No action is executed and the user exits the parameter. |
| To delivery set. | Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered. |
| Restart device | The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged. |

Activate SW opt. **Navigation**  Expert → System → Administration → Activate SW opt.**Description** Use this function to enter an activation code to enable an additional, ordered software option.

User entry Max. 10-digit string consisting of numbers.

Factory setting Depends on the software option ordered

Additional information

Description

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **SW option overv.** parameter (→ 40).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→ 40).

Web browser

 Once a software option has been activated, the page must be loaded again in the Web browser.

SW option overv.

Navigation  Expert → System → Administration → SW option overv.

Description Displays all the software options that are enabled in the device.

User interface

- HBT Verification
- HBT Monitoring
- Concentration
- Viscosity

Additional information*Description*

Displays all the options that are available if ordered by the customer.

"HBT Verification" option and "HBT Monitoring" option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

"Concentration" option

Order code for "Application package", option **ED** "Concentration" and option **EE** "Special density"

"Viscosity" option

 Only available for Promass I.

Order code for "Application package", option **EG** "Viscosity"

3.2 "Sensor" submenu

Navigation


  Expert → Sensor

| | |
|---------------------------|--|
| ► Sensor | |
| ► Measured val. | →  42 |
| ► System units | →  50 |
| ► Process param. | →  57 |
| ► Measurement mode | →  66 |
| ► External comp. | →  68 |
| ► Calculated value | →  69 |
| ► Sensor adjustm. | →  73 |
| ► Calibration | →  79 |
| ► Supervision | →  81 |

3.2.1 "Measured val." submenu

Navigation


Expert → Sensor → Measured val.



"Process variab." submenu

Navigation

Expert → Sensor → Measured val. → Process variab.



| | |
|------------------|--|
| Target vol. flow | →  48 |
| Carrier vol. fl. | →  48 |

Mass flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Mass flow

Description Displays the mass flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Mass flow unit** parameter (→  50)

Volume flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Volume flow

Description Displays the volume flow currently calculated.

User interface Signed floating-point number

Additional information *Description*

The volume flow is calculated from the mass flow currently measured and the density currently measured.

Dependency

 The unit is taken from the **Volume flow unit** parameter (→  51)

Correct.vol.flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow

Description Displays the corrected volume flow currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Cor.volflow unit** parameter (→  53)

Density

| | |
|-------------------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → Density |
| Description | Displays the density currently measured. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Density unit parameter (→ 54) |

Ref.density

| | |
|-------------------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → Ref.density |
| Description | Displays the reference density currently calculated. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Ref. dens. unit parameter (→ 55) |

Temperature

| | |
|-------------------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → Temperature |
| Description | Displays the medium temperature currently measured. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Temperature unit parameter (→ 55) |

Pressure value

| | |
|-----------------------|--|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → Pressure value |
| Description | Displays the fixed or external pressure value. |
| User interface | Signed floating-point number |

Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ 56)

Dynam. viscosity

Navigation

Expert → Sensor → Measured val. → Process variab. → Dynam. viscosity

Prerequisite

For the following order code:

"Application package", option **EG "Viscosity"**



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 40).

Description

Displays the dynamic viscosity currently calculated.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Dyn. visc. unit** parameter.

Kinematic visc.

Navigation

Expert → Sensor → Measured val. → Process variab. → Kinematic visc.

Prerequisite

For the following order code:

"Application package", option **EG "Viscosity"**



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 40).

Description

Displays the kinematic viscosity currently calculated.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Kin. visc. unit** parameter.

TempCompDynVisc

| | |
|-------------------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → TempCompDynVisc |
| Prerequisite | For the following order code: "Application package", option EG "Viscosity"  The software options currently enabled are displayed in the SW option overv. parameter (→  40). |
| Description | Displays the temperature compensation currently calculated for the viscosity. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i>  The unit is taken from the Dyn. visc. unit parameter. |

TempCompKinVisc

| | |
|-------------------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → TempCompKinVisc |
| Prerequisite | For the following order code: "Application package", option EG "Viscosity"  The software options currently enabled are displayed in the SW option overv. parameter (→  40). |
| Description | Displays the temperature compensation currently calculated for the kinetic viscosity. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i>  The unit is taken from the Kin. visc. unit parameter. |

Concentration

| | |
|-----------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Process variab. → Concentration |
| Prerequisite | For the following order code: "Application package", option ED "Concentration"  The software options currently enabled are displayed in the SW option overv. parameter (→  40). |
| Description | Displays the concentration currently calculated. |
| User interface | Signed floating-point number |

Additional information*Dependency*

The unit is taken from the **Concentr. unit** parameter.

Target mass flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Target mass flow

Prerequisite

With the following conditions:

- Order code for "Application package", option **ED** "Concentration"
- The **WT-%** option is selected in the **Concentr. unit** parameter parameter.



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 40).

Description

Displays the mass flow currently measured for the target medium.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Mass flow unit** parameter (→ 50)

Carrier mass fl.

Navigation

Expert → Sensor → Measured val. → Process variab. → Carrier mass fl.

Prerequisite

With the following conditions:

- Order code for "Application package", option **ED** "Concentration"
- The **WT-%** option is selected in the **Concentr. unit** parameter parameter.



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 40).

Description

Displays the mass flow currently measured for the carrier medium.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Mass flow unit** parameter (→ 50)

Targ.corr.vol.fl

Navigation

Expert → Sensor → Measured val. → Process variab. → Targ.corr.vol.fl

User interface

Signed floating-point number

Factory setting 0 NL/h

Carr.corr.vol.fl

Navigation  Expert → Sensor → Measured val. → Process variab. → Carr.corr.vol.fl

User interface Signed floating-point number

Factory setting 0 NL/h

Target vol. flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Target vol. flow

User interface Signed floating-point number

Factory setting 0 l/h

Carrier vol. fl.


Navigation  Expert → Sensor → Measured val. → Process variab. → Carrier vol. fl.

User interface Signed floating-point number

Factory setting 0 l/h

"Totalizer" submenu

Navigation  Expert → Sensor → Measured val. → Totalizer



Totalizer val. 1 to n

| | |
|-------------------------------|--|
| Navigation |   Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n |
| Prerequisite | In the Target mode parameter (→ 149), the Auto option is selected. |
| Description | Displays the current reading for totalizer 1-3. |
| User interface | Signed floating-point number |
| Additional information | <i>Description</i>  In the event of an error, the totalizer adopts the mode defined in the Failure mode parameter (→ 146). <i>User interface</i> The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the Operation mode parameter (→ 145). <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 143). |

Status (Hex) 1 to n

| | |
|-----------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Totalizer → Status (Hex) 1 to n |
| Prerequisite | In Target mode parameter (→ 149), the Auto option is selected. |
| Description | Displays the status value (hex) of the particular totalizer. |
| User interface | 0 to 0xFF |

Tot. status 1 to n

| | |
|-----------------------|--|
| Navigation |   Expert → Sensor → Measured val. → Totalizer → Tot. status 1 to n |
| Description | Displays the status of the particular totalizer. |
| User interface | <ul style="list-style-type: none">■ Good■ Uncertain■ Bad |

3.2.2 "System units" submenu

Navigation

Expert → Sensor → System units

| ► System units | |
|------------------|------|
| Mass flow unit | → 50 |
| Mass unit | → 51 |
| Volume flow unit | → 51 |
| Volume unit | → 53 |
| Cor.volflow unit | → 53 |
| Corr. vol. unit | → 54 |
| Density unit | → 54 |
| Ref. dens. unit | → 55 |
| Temperature unit | → 55 |
| Pressure unit | → 56 |
| Date/time format | → 57 |

Mass flow unit



Navigation

Expert → Sensor → System units → Mass flow unit

Description

Use this function to select the unit for the mass flow.

Selection

SI units

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

| | |
|------------------------|--|
| Factory setting | Country-specific: ■ kg/h (DN > 150 (6)": t/h) ■ lb/min |
|------------------------|--|

| | |
|-------------------------------|--|
| Additional information | <i>Result</i> The selected unit applies for: ■ Target mass flow parameter (→ 47) ■ Carrier mass fl. parameter (→ 47) ■ Mass flow parameter (→ 43) |
|-------------------------------|--|

Selection

 For an explanation of the abbreviated units: → 185

Mass unit

| | |
|-------------------|--|
| Navigation |  Expert → Sensor → System units → Mass unit |
|-------------------|--|

| | |
|--------------------|--|
| Description | Use this function to select the unit for the mass. |
|--------------------|--|

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------|-----------------|-----------------|
| ■ g | ■ oz | |
| ■ kg | ■ lb | |
| ■ t | ■ STon | |

| | |
|------------------------|--|
| Factory setting | Country-specific: ■ kg (DN > 150 (6)": t) ■ lb |
|------------------------|--|

| | |
|-------------------------------|--|
| Additional information | <i>Selection</i>  For an explanation of the abbreviated units: → 185 |
|-------------------------------|--|

Volume flow unit

| | |
|-------------------|---|
| Navigation |  Expert → Sensor → System units → Volume flow unit |
|-------------------|---|

| | |
|--------------------|---|
| Description | Use this function to select the unit for the volume flow. |
|--------------------|---|

Selection

| <i>SI units</i> | <i>US units</i> | <i>Imperial units</i> |
|------------------------|------------------------|-----------------------|
| ■ cm ³ /s | ■ af/s | ■ gal/s (imp) |
| ■ cm ³ /min | ■ af/min | ■ gal/min (imp) |
| ■ cm ³ /h | ■ af/h | ■ gal/h (imp) |
| ■ cm ³ /d | ■ af/d | ■ gal/d (imp) |
| ■ dm ³ /s | ■ ft ³ /s | ■ Mgal/s (imp) |
| ■ dm ³ /min | ■ ft ³ /min | ■ Mgal/min (imp) |
| ■ dm ³ /h | ■ ft ³ /h | ■ Mgal/h (imp) |
| ■ dm ³ /d | ■ ft ³ /d | ■ Mgal/d (imp) |
| ■ m ³ /s | ■ fl oz/s (us) | ■ bbl/s (imp;beer) |
| ■ m ³ /min | ■ fl oz/min (us) | ■ bbl/min (imp;beer) |
| ■ m ³ /h | ■ fl oz/h (us) | ■ bbl/h (imp;beer) |
| ■ m ³ /d | ■ fl oz/d (us) | ■ bbl/d (imp;beer) |
| ■ ml/s | ■ gal/s (us) | ■ bbl/s (imp;oil) |
| ■ ml/min | ■ gal/min (us) | ■ bbl/min (imp;oil) |
| ■ ml/h | ■ gal/h (us) | ■ bbl/h (imp;oil) |
| ■ ml/d | ■ gal/d (us) | ■ bbl/d (imp;oil) |
| ■ l/s | ■ kgal/s (us) | |
| ■ l/min | ■ kgal/min (us) | |
| ■ l/h | ■ kgal/h (us) | |
| ■ l/d | ■ kgal/d (us) | |
| ■ hl/s | ■ Mgal/s (us) | |
| ■ hl/min | ■ Mgal/min (us) | |
| ■ hl/h | ■ Mgal/h (us) | |
| ■ hl/d | ■ Mgal/d (us) | |
| ■ Ml/s | ■ bbl/s (us;liq.) | |
| ■ Ml/min | ■ bbl/min (us;liq.) | |
| ■ Ml/h | ■ bbl/h (us;liq.) | |
| ■ Ml/d | ■ bbl/d (us;liq.) | |
| | ■ bbl/s (us;beer) | |
| | ■ bbl/min (us;beer) | |
| | ■ bbl/h (us;beer) | |
| | ■ bbl/d (us;beer) | |
| | ■ bbl/s (us;oil) | |
| | ■ bbl/min (us;oil) | |
| | ■ bbl/h (us;oil) | |
| | ■ bbl/d (us;oil) | |
| | ■ bbl/s (us;tank) | |
| | ■ bbl/min (us;tank) | |
| | ■ bbl/h (us;tank) | |
| | ■ bbl/d (us;tank) | |

Factory setting

Country-specific:

- l/h (DN > 150 (6"): m³/h)
- gal/min (us)

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  43)*Selection*
 For an explanation of the abbreviated units: →  185

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- l (DN > 150 (6"): m³)
- gal (us)

Additional information*Selection*

For an explanation of the abbreviated units: → 185

Cor.volflow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting

Country-specific:

- NI/h (DN > 150 (6"): Nm³/h)
- Sft³/min

Additional information*Result*

The selected unit applies for:

Correct.vol.flow parameter (→ 43)*Selection*

 For an explanation of the abbreviated units: → 185

Corr. vol. unit**Navigation**
 Expert → Sensor → System units → Corr. vol. unit
Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- NI
- Nm³
- Sm³

US units

- Sft³
- Sgal (us)
- Sbbl (us;liq.)

Imperial units

Sgal (imp)

Factory setting

Country-specific:

- NI (DN > 150 (6"): Nm³)
- Sft³

Additional information*Selection*

 For an explanation of the abbreviated units: → 185

Density unit**Navigation**
 Expert → Sensor → System units → Density unit
Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/dm³
- kg/l
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

| | |
|-------------------------------|--|
| Factory setting | Country-specific: ■ kg/l ■ lb/ft ³ |
| Additional information | <p><i>Result</i></p> <p>The selected unit applies for: Density parameter (→ 44)</p> |
| | <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ SD = specific density The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F). ■ SG = specific gravity The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F). |
| |  For an explanation of the abbreviated units: → 185 |

Ref. dens. unit

| | | | | | | | | | | | |
|-------------------------------|--|-----------------|-----------------|----------------------|---------------------|---------|--|----------------------|--|----------------------|--|
| Navigation |  Expert → Sensor → System units → Ref. dens. unit | | | | | | | | | | |
| Description | Use this function to select the unit for the reference density. | | | | | | | | | | |
| Selection | <table border="0"> <tr> <td><i>SI units</i></td> <td><i>US units</i></td> </tr> <tr> <td>■ kg/Nm³</td> <td>lb/Sft³</td> </tr> <tr> <td>■ kg/Nl</td> <td></td> </tr> <tr> <td>■ g/Scm³</td> <td></td> </tr> <tr> <td>■ kg/Sm³</td> <td></td> </tr> </table> | <i>SI units</i> | <i>US units</i> | ■ kg/Nm ³ | lb/Sft ³ | ■ kg/Nl | | ■ g/Scm ³ | | ■ kg/Sm ³ | |
| <i>SI units</i> | <i>US units</i> | | | | | | | | | | |
| ■ kg/Nm ³ | lb/Sft ³ | | | | | | | | | | |
| ■ kg/Nl | | | | | | | | | | | |
| ■ g/Scm ³ | | | | | | | | | | | |
| ■ kg/Sm ³ | | | | | | | | | | | |
| Factory setting | Country-dependent ■ kg/Nl ■ lb/Sft ³ | | | | | | | | | | |
| Additional information | <p><i>Result</i></p> <p>The selected unit applies for:</p> <ul style="list-style-type: none"> ■ Ext. ref.density parameter (→ 71) ■ Fix ref.density parameter (→ 71) ■ Ref.density parameter (→ 44) <p><i>Selection</i></p> | | | | | | | | | | |
| |  For an explanation of the abbreviated units: → 185 | | | | | | | | | | |

Temperature unit

| | |
|--------------------|---|
| Navigation |  Expert → Sensor → System units → Temperature unit |
| Description | Use this function to select the unit for the temperature. |

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------------|---|--|
| | <ul style="list-style-type: none"> ■ °C ■ K | <ul style="list-style-type: none"> ■ °F ■ °R |
| Factory setting | Country-specific: | |

| | |
|------------------------|--|
| Factory setting | Country-specific: |
| | <ul style="list-style-type: none"> ■ °C ■ °F |

| | |
|-------------------------------|--|
| Additional information | <i>Result</i> |
| | The selected unit applies for: |
| | <ul style="list-style-type: none"> ■ Maximum value parameter (→ 169) ■ Minimum value parameter (→ 169) ■ Maximum value parameter (→ 170) ■ Minimum value parameter (→ 170) ■ Maximum value parameter (→ 171) ■ Minimum value parameter (→ 171) ■ Ref. temperature parameter ■ Temperature parameter (→ 44) ■ Ref. temperature parameter (→ 71) |
| | <i>Selection</i> |

 For an explanation of the abbreviated units: → [185](#)

Pressure unit



 Expert → Sensor → System units → Pressure unit

Description Use this function to select the unit for the pipe pressure.

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------------|--|--|
| | <ul style="list-style-type: none"> ■ Pa a ■ kPa a ■ MPa a ■ bar ■ Pa g ■ kPa g ■ MPa g ■ bar g | <ul style="list-style-type: none"> ■ psi a ■ psi g |
| Factory setting | Country-specific: | |

| | |
|------------------------|--|
| Factory setting | Country-specific: |
| | <ul style="list-style-type: none"> ■ bar a ■ psi a |

Additional information*Result*

The unit is taken from:

- **Pressure value** parameter (→ [69](#))
- **External press.** parameter (→ [69](#))
- **Pressure value** parameter (→ [44](#))

Selection

 For an explanation of the abbreviated units: → [185](#)

Date/time format**Navigation**

 Expert → Sensor → System units → Date/time format

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy am/pm
- mm/dd/yy hh:mm
- mm/dd/yy am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

 For an explanation of the abbreviated units: → [185](#)

3.2.3 "Process param." submenu

Navigation

 Expert → Sensor → Process param.

| ► Process param. | |
|--------------------|----------------------|
| Flow damping | → 58 |
| Density damping | → 58 |
| Temp. damping | → 59 |
| Flow override | → 59 |
| ► Low flow cut off | → 60 |
| ► Partial pipe det | → 63 |

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping

Description

Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 100.0 s

Factory setting

0 s

Additional information

Description

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if 0 is entered (factory setting).

Result

The damping affects the following variables of the device:

- Outputs
- Low flow cut off → 60
- Totalizers → 142

Density damping



Navigation

Expert → Sensor → Process param. → Density damping

Description

Use this function to enter a time constant for the damping (PT1 element) of the density measured value.

User entry

0 to 999.9 s

Factory setting

0 s

2) Proportional behavior with first-order lag

Additional information*Description*

The damping is performed by a PT1 element³⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased



Damping is switched off if **0** is entered (factory setting).

Temp. damping**Navigation**

Expert → Sensor → Process param. → Temp. damping

Description

Use this function to enter a time constant for the damping (PT1 element) of the temperature measured value.

User entry

0 to 999.9 s

Factory setting

0 s

Additional information*Description*

The damping is performed by a PT1 element⁴⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased



Damping is switched off if **0** is entered (factory setting).

Flow override**Navigation**

Expert → Sensor → Process param. → Flow override

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

3) Proportional behavior with first-order lag

4) Proportional behavior with first-order lag

Additional information*Result*

This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**


- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized



Positive zero return can also be enabled via the Status input: **Assign stat.inp.** parameter.

"Low flow cut off" submenu*Navigation*

Expert → Sensor → Process param. → Low flow cut off

**Assign variable***Navigation*

Expert → Sensor → Process param. → Low flow cut off → Assign variable

Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow

Factory setting

Mass flow

On value**Navigation**

Expert → Sensor → Process param. → Low flow cut off → On value

PrerequisiteOne of the following options is selected in the **Assign variable** parameter (→ [60](#)):

- Mass flow
- Volume flow
- Correct.vol.flow

DescriptionUse this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → [61](#).**User entry**

Positive floating-point number

Factory settingDepends on country and nominal diameter → [182](#)**Additional information***Dependency* The unit depends on the process variable selected in the **Assign variable** parameter (→ [60](#)).

Off value**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value

PrerequisiteOne of the following options is selected in the **Assign variable** parameter (→ [60](#)):


- Mass flow
- Volume flow
- Correct.vol.flow

DescriptionUse this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → [61](#).**User entry**

0 to 100.0 %

Factory setting

50 %

Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pres. shock sup.**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup.

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 60):

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry

0 to 100 s

Factory setting

0 s

Additional information*Description***Pressure shock suppression is enabled**


- Prerequisite:
 - Flow rate < on-value of low flow cut off
 - or
 - Changing the flow direction
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.



- Q** Flow
t Time
A Drip
B Pressure shock
C Pressure shock suppression active as specified by the time entered
D Pressure shock suppression inactive
1 Valve closes
2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
3 The time entered has elapsed: pressure shock suppression is deactivated
4 The actual flow value is now displayed and output
5 On value for low flow cut off
6 Off value for low flow cut off

"Partial pipe det" submenu

Navigation

Expert → Sensor → Process param. → Partial pipe det

| ► Partial pipe det | |
|---------------------------|----------------------|
| Assign variable | → 64 |
| Low value | → 64 |
| High value | → 64 |
| Response time | → 65 |
| Max. damping | → 65 |

Assign variable**Navigation**

Expert → Sensor → Process param. → Partial pipe det → Assign variable

Description

Use this function to select a process variable to detect empty or partially filled measuring tubes.

For gas measurement: Deactivate monitoring due to low gas density.

Selection

- Off
- Density
- Ref.density

Factory setting

Off

Low value**Navigation**

Expert → Sensor → Process param. → Partial pipe det → Low value

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 64):

- Density
- Ref.density

Description

Use this function to enter a lower limit value to enable detection of empty or partially filled measuring tubes. If the measured density falls below this value, monitoring is enabled.

User entry

Signed floating-point number

Factory setting

200

Additional information

User entry

The lower limit value must be less than the upper limit value defined in the **High value** parameter (→ 64).

i The unit depends on the process variable selected in the **Assign variable** parameter (→ 64).

Limit value

i If the displayed value is outside the limit value, the measuring device displays the diagnostic message **△S862 Partly filled**.

High value**Navigation**

Expert → Sensor → Process param. → Partial pipe det → High value

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 64):

- Density
- Ref.density

| | |
|-------------------------------|--|
| Description | Use this function to enter an upper limit value to enable detection of empty or partially filled measuring tubes. If the measured density exceeds this value, detection is enabled. |
| User entry | Signed floating-point number |
| Factory setting | 6 000 |
| Additional information | <p><i>User entry</i></p> <p>The upper limit value must be greater than the lower limit value defined in the Low value parameter (→ 64).</p> <p> The unit depends on the process variable selected in the Assign variable parameter (→ 64).</p> <p><i>Limit value</i></p> <p> If the displayed value is outside the limit value, the measuring device displays the diagnostic message △S862 Partly filled.</p> |

Response time

| | |
|------------------------|---|
| Navigation |   Expert → Sensor → Process param. → Partial pipe det → Response time |
| Prerequisite | One of the following options is selected in the Assign variable parameter (→ 64): ■ Density ■ Ref.density |
| Description | Use this function to enter the minimum length of time (debouncing time) the signal must be present for the diagnostic message △S862 Partly filled to be triggered if the measuring pipe is empty or partially full. |
| User entry | 0 to 100 s |
| Factory setting | 1 s |

Max. damping

| | |
|------------------------|--|
| Navigation |   Expert → Sensor → Process param. → Partial pipe det → Max. damping |
| Prerequisite | One of the following options is selected in the Assign variable parameter (→ 64): ■ Density ■ Ref.density |
| Description | Use this function to enter a damping value to enable detection of empty or partially filled measuring tubes. |
| User entry | Positive floating-point number |
| Factory setting | 0 |

Additional information**Description**

If oscillation damping exceeds the specified value, the measuring device presumes that the pipe is partially filled and the flow signal is set to **0**. The measuring device displays the diagnostic message **△S862 Partly filled**. In the case of non-homogeneous media or air pockets, the damping of the measuring tubes increases.


User entry

- Damping is disabled if **0** is entered (factory setting).
- Damping is enabled if the value entered is greater than **0**.
- The value entered depends on application-specific influence variables, such as the medium, nominal diameter, sensor etc.

Example

- If the pipe is filled normally the value of the oscillation damping is 500.
- If the pipe is partially filled the value of the oscillation damping is > 5000.
- A practical damping value would then be 2000: enter 2000 as the value.

3.2.4 "Measurement mode" submenu

Navigation Expert → Sensor → Measurement mode

Select medium

**Navigation** Expert → Sensor → Measurement mode → Select medium**Description**

Use this function to select the type of medium.

Selection

Liquid

Factory setting

Liquid

Select gas type

| | |
|-------------------------------|---|
| Navigation | Expert → Sensor → Measurement mode → Select gas type |
| Prerequisite | The Gas option is selected in the Select medium parameter (→ 66). |
| Description | Use this function to select the type of gas for the measuring application. |
| Selection | <ul style="list-style-type: none">■ Air■ Ammonia NH₃■ Argon Ar■ Sulf. hex.fl.SF₆■ Oxygen O₂■ Ozone O₃■ Nitrog. ox. NO_x■ Nitrogen N₂■ Nitrous ox. N₂O■ Methane CH₄■ Hydrogen H₂■ Helium He■ Hydrog.chlor.HCl■ Hydrog.sulf. H₂S■ Ethylene C₂H₄■ Carbon diox. CO₂■ Carbon monox. CO■ Chlorine Cl₂■ Butane C₄H₁₀■ Propane C₃H₈■ Propylene C₃H₆■ Ethane C₂H₆■ Others |
| Factory setting | Methane CH ₄ |
| Additional information | <i>Description</i> The gas type needs to be selected so that it is possible to comply with accuracy specifications in gas applications. |

Sound velocity


| | |
|------------------------|---|
| Navigation | Expert → Sensor → Measurement mode → Sound velocity |
| Prerequisite | In the Select gas type parameter (→ 67), the Others option is selected. |
| Description | Use this function to enter the sound velocity of the gas at 0 °C (+32 °F). |
| User entry | 1 to 99 999.9999 m/s |
| Factory setting | 415.0 m/s |

Temp. coeff. SV

| | |
|------------------------|---|
| Navigation | Expert → Sensor → Measurement mode → Temp. coeff. SV |
| Prerequisite | The Others option is selected in the Select gas type parameter (→ 67). |
| Description | Use this function to enter a temperature coefficient for the sound velocity of the gas. |
| User entry | Positive floating-point number |
| Factory setting | 0 (m/s)/K |

3.2.5 "External comp." submenu

Navigation Expert → Sensor → External comp.

**Pressure compen.**

| | |
|-------------------------------|--|
| Navigation | Expert → Sensor → External comp. → Pressure compen. |
| Description | Use this function to select the type of pressure compensation. |
| Selection | <ul style="list-style-type: none">■ Off■ Fixed value■ External value |
| Factory setting | Off |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none">■ Fixed value A fixed pressure value is used for compensation: Pressure value parameter (→ 69)■ External value The pressure value read in via PROFIBUS DP is used for compensation.■ Current input 1 The pressure value read in via the current input is used for compensation. |



For more information, see the "Cyclic data transmission" section of the Operating Instructions

Pressure value


| | |
|-------------------------------|---|
| Navigation | Expert → Sensor → External comp. → Pressure value |
| Prerequisite | The Fixed value option is selected in the Pressure compen. parameter (→ 68). |
| Description | Use this function to enter a value for the process pressure that is used for pressure correction. |
| User entry | Positive floating-point number |
| Factory setting | 0 bar |
| Additional information | <p><i>User entry</i></p> The unit is taken from the Pressure unit parameter (→ 56) |

External press.

| | |
|-------------------------------|---|
| Navigation | Expert → Sensor → External comp. → External press. |
| Prerequisite | The External value option is selected in the Pressure compen. parameter (→ 68). |
| Description | Use this function to enter an external pressure value. |
| User entry | Positive floating-point number |
| Factory setting | 0 bar |
| Additional information | <p><i>User entry</i></p> The unit is taken from the Pressure unit parameter (→ 56) |

3.2.6 "Calculated value" submenu*Navigation*

Expert → Sensor → Calculated value



"Corr. vol.flow." submenu**Navigation**

Expert → Sensor → Calculated value → Corr. vol.flow.

| | |
|--------------------------|-------|
| ► Corr. vol.flow. | |
| Corr. vol.flow. | → 70 |
| Ext. ref.density | → 71 |
| Fix ref.density | → 71 |
| Ref. temperature | → 71 |
| Linear exp coeff | → 72 |
| Square exp coeff | → 72 |

Corr. vol.flow.**Navigation**

Expert → Sensor → Calculated value → Corr. vol.flow. → Corr. vol.flow.

Description

Use this function to select the reference density for calculating the corrected volume flow.

Selection

- Fix ref.density
- Calc ref density
- Ref. dens API 53
- Ext. ref.density

Factory setting

Calc ref density

Additional information*Selection*

The **Ref. dens API 53** option is suitable only for applications involving LPG⁵⁾, where the flow rate is measured on the basis of the corrected volume flow.

Selecting this option means that the reference density is used, taking into account the values in table 53 E of API MPMS section 11.2. Temperature measurement (measured internally or read into the device from an external source) and density measurement take place during operation while the medium is flowing. The mass flow is divided by the reference density to give the corrected volume flow and is issued as an output signal.

5) liquefied petroleum gas

Ext. ref.density

| | |
|-------------------------------|---|
| Navigation |  Expert → Sensor → Calculated value → Corr. vol.flow. → Ext. ref.density |
| Prerequisite | In the Corr. vol.flow. parameter (→ 70), the Ext. ref.density option is selected. |
| Description | Displays the reference density which is read in externally, e.g. via the current input. |
| User interface | Floating point number with sign |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Ref. dens. unit parameter (→ 55) |

Fix ref.density

| | |
|-------------------------------|--|
| Navigation |  Expert → Sensor → Calculated value → Corr. vol.flow. → Fix ref.density |
| Prerequisite | The Fix ref.density option is selected in the Corr. vol.flow. parameter (→ 70) parameter. |
| Description | Use this function to enter a fixed value for the reference density. |
| User entry | Positive floating-point number |
| Factory setting | 1 kg/Nl |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Ref. dens. unit parameter (→ 55) |

Ref. temperature

| | |
|------------------------|---|
| Navigation |  Expert → Sensor → Calculated value → Corr. vol.flow. → Ref. temperature |
| Prerequisite | The Calc ref density option is selected in the Corr. vol.flow. parameter (→ 70). |
| Description | Use this function to enter a reference temperature for calculating the reference density. |
| User entry | -273.15 to 99 999 °C |
| Factory setting | Country-specific: ■ +20 °C ■ +68 °F |

Additional information*Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [55](#))

Reference density calculation

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_N : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

Linear exp coeff**Navigation**

 Expert → Sensor → Calculated value → Corr. vol.flow. → Linear exp coeff

Prerequisite

The **Calc ref density** option is selected in the **Corr. vol.flow.** parameter (→ [70](#)) parameter.

Description

Use this function to enter a linear, fluid-specific expansion coefficient for calculating the reference density.

User entry

Signed floating-point number

Factory setting

0.0

Square exp coeff**Navigation**

 Expert → Sensor → Calculated value → Corr. vol.flow. → Square exp coeff

Prerequisite

The **Calc ref density** option is selected in the **Corr. vol.flow.** parameter (→ [70](#)) parameter.

Description

For fluid with a non-linear expansion pattern: use this function to enter a quadratic, fluid-specific expansion coefficient for calculating the reference density.

User entry

Signed floating-point number


Factory setting

0.0

3.2.7 "Sensor adjustm." submenu

Navigation

Expert → Sensor → Sensor adjustm.



Install. direct.



Navigation

Expert → Sensor → Sensor adjustm. → Install. direct.

Description

Use this function to change the sign of the medium flow direction.

Selection

- In arrow direct.
- Against arrow

Factory setting

In arrow direct.

Additional information


Description

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

"Zero point adj." submenu



- It is generally not necessary to perform zero point adjustment.
- However, this function may be needed in some applications with low flow and strict accuracy requirements.
- A zero point adjustment cannot increase repeatability.
- The following conditions should be met to perform a zero point adjustment successfully without the adjustment finishing in an error:
 - The real flow must be **0**.
 - The pressure must be at least 15 psi g.
- The adjustment takes a maximum of 60 s. The more stable the conditions, the faster the adjustment is completed.
- This function can also be used to check the health of the measuring device. A healthy measuring device has a maximum zero point deviation of ±100 compared to the factory setting of the measuring device (calibration report).

Navigation Expert → Sensor → Sensor adjustm. → Zero point adj.

Zero point adj.

**Navigation** Expert → Sensor → Sensor adjustm. → Zero point adj. → Zero point adj.**Description**

Use this function to select the start of the zero point adjustment.



Observe conditions →  73.

Selection

- Cancel
- Busy
- Zero adjust fail
- Start

Factory setting

Cancel

Additional information*Description*

- Cancel
If zero point adjustment has failed, select this option to cancel zero point adjustment.
- Busy
Is displayed during zero point adjustment.
- Zero adjust fail
Is displayed if zero point adjustment has failed.
- Start
Select this option to start zero point adjustment.

Progress

Navigation Expert → Sensor → Sensor adjustm. → Zero point adj. → Progress**Description**

The progress of the process is indicated.

User interface

0 to 100 %

"Variable adjust" submenu*Navigation*
 Expert → Sensor → Sensor adjustm. → Variable adjust

| ► Variable adjust | |
|-------------------|--|
| Mass flow offset | →  75 |
| Mass flow factor | →  76 |
| Vol. flow offset | →  76 |
| Vol. flow factor | →  76 |
| Density offset | →  77 |
| Density factor | →  77 |
| Corr. vol offset | →  77 |
| Corr. vol factor | →  78 |
| Ref.dens. offset | →  78 |
| Ref.dens. factor | →  78 |
| Temp. offset | →  79 |
| Temp. factor | →  79 |

Mass flow offset**Navigation**
 Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset
Description

Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.

User entry

Signed floating-point number

Factory setting

0 kg/s

Additional information

Description



Corrected value = (factor × value) + offset

Mass flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor

Description

Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Vol. flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/s

Additional information*Description*

Corrected value = (factor × value) + offset

Vol. flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Density offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density offset

Description Use this function to enter the zero point shift for the density trim. The density unit on which the shift is based is kg/m³.

User entry Signed floating-point number

Factory setting 0 kg/m³

Additional information *Description*

Corrected value = (factor × value) + offset

Density factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density factor

Description Use this function to enter a quantity factor for the density. This multiplication factor is applied over the density range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

Corr. vol offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset

Description Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm³/s.

User entry Signed floating-point number

Factory setting 0 Nm³/s

Additional information *Description*

Corrected value = (factor × value) + offset

Corr. vol factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor

Description

Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Ref.dens. offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Ref.dens. offset

Description

Use this parameter to enter the zero point shift for the reference density trim. The reference density unit on which the shift is based is 1 kg/Nm³.

User entry

Signed floating-point number

Factory setting

0 kg/Nm³

Additional information*Description*

Corrected value = (factor × value) + offset

Ref.dens. factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Ref.dens. factor

Description

Use this function to enter a quantity factor (without time) for the reference density. This multiplication factor is applied over the reference density range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Temp. offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset

Description

Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is K.

User entry

Signed floating-point number

Factory setting

0 K

Additional information*Description*

Corrected value = (factor × value) + offset

Temp. factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor

Description

Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in K.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

3.2.8 "Calibration" submenu

Navigation

Expert → Sensor → Calibration

| ▶ Calibration | |
|------------------|-------|
| Cal. factor | → 80 |
| Zero point | → 80 |
| Nominal diameter | → 80 |
| C0 to 5 | → 80 |

Cal. factor

Navigation   Expert → Sensor → Calibration → Cal. factor

Description Displays the current calibration factor for the sensor.

User interface Signed floating-point number

Factory setting Depends on nominal diameter and calibration.

Zero point



Navigation   Expert → Sensor → Calibration → Zero point

Description Use this function to enter the zero point correction value for the sensor.

User entry Signed floating-point number

Factory setting Depends on nominal diameter and calibration.

Nominal diameter

Navigation   Expert → Sensor → Calibration → Nominal diameter

Description Displays the nominal diameter of the sensor.

User interface DNxx / x"

Factory setting Depends on the size of the sensor

Additional information *Description*

 The value is also specified on the sensor nameplate.

C0 to 5

Navigation   Expert → Sensor → Calibration → C0 to 5

Description Displays the current density coefficients C0 to 5 of the sensor.


User interface Signed floating-point number

Factory setting 0

3.2.9 "Supervision" submenu

Navigation

Expert → Sensor → Supervision



Limit tube damp.



Navigation

Expert → Sensor → Supervision → Limit tube damp.

Description

Use this function to enter a limit value for measuring tube damping.

User entry

Positive floating-point number

Factory setting

Positive floating-point number

Additional information


Limit value

- If the displayed value is outside the limit value, the measuring device displays the diagnostic message **△S948 Tube damp. high.**
- For detecting inhomogeneous media, for example

3.3 "Communication" submenu

Navigation


Expert → Communication



3.3.1 "PROFIBUS DP conf" submenu

Navigation

Expert → Communication → PROFIBUS DP conf



Address mode

Navigation

Expert → Communication → PROFIBUS DP conf → Address mode

Description

Displays the configured address mode.

User interface

- Hardware
- Software

Factory setting

Software

Additional information

Description

For detailed information, see the "Setting the device address" section of the Operating Instructions.

Device address



Navigation

Expert → Communication → PROFIBUS DP conf → Device address

Description

Use this function to enter the device address.

User entry

0 to 126

Factory setting

126

Additional information

Description

The address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.

Displays the configured address mode: **Address mode** parameter (→ 82)

Ident num select

Navigation Expert → Communication → PROFIBUS DP conf → Ident num select

Description Use this function to select the device master file (GSD).

- Selection**
- Automatic mode
 - Manufacturer
 - Profile
 - 1AI,1Tot(0x9740)
 - 2AI,1Tot(0x9741)

Factory setting Automatic mode

Additional information *Description*

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

3.3.2 "PROFIBUS DP info" submenu

Navigation Expert → Communication → PROFIBUS DP info

| PROFIBUS DP info | |
|------------------|-------|
| Stat Master Conf | → 83 |
| Ident number | → 84 |
| Profile version | → 84 |
| Base current | → 84 |
| Baudrate | → 84 |
| Master avail. | → 85 |

Stat Master Conf

Navigation Expert → Communication → PROFIBUS DP info → Stat Master Conf

Description For displaying the status of the PROFIBUS Master configuration.

User interface ■ Active
 ■ Not active

Factory setting Not active

Ident number

Navigation  Expert → Communication → PROFIBUS DP info → Ident number

Description For displaying the PROFIBUS identification number.

User interface 0 to FFFF

Factory setting 0x1561

Profile version

Navigation  Expert → Communication → PROFIBUS DP info → Profile version

Description Displays the profile version.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting 3.02

Base current

Navigation  Expert → Communication → PROFIBUS DP info → Base current

Description Displays the basic current: Every PA measuring device taps a constant basic current from the MBP cable. This base current must be at least 10 mA. The base current enables power to be supplied to the measuring device.

User interface 16 mA

Baudrate

Navigation  Expert → Communication → PROFIBUS DP info → Baudrate

Description Displays the transmission rate.

| | |
|------------------------|--|
| User interface | <ul style="list-style-type: none"> ■ Not available ■ 9.6 kBaud ■ 19.2 kBaud ■ 31.25 kBaud ■ 45.45 kBaud ■ 93.75 kBaud ■ 187.5 kBaud ■ 500 kBaud ■ 1.5 MBaud ■ 3 MBaud ■ 6 MBaud ■ 12 MBaud |
| Factory setting | 9.6 kBaud |

Master avail.

| | |
|------------------------|---|
| Navigation |   Expert → Communication → PROFIBUS DP info → Master avail. |
| Description | Displays whether or not a PROFIBUS master is present in the network. |
| User interface | <ul style="list-style-type: none"> ■ No ■ Yes |
| Factory setting | No |

3.3.3 "Physical block" submenu

Navigation   Expert → Communication → Physical block

| | |
|-------------------------|--|
| ► Physical block | |
| Device tag | →  86 |
| Static revision | →  87 |
| Strategy | →  87 |
| Alert key | →  87 |
| Target mode | →  87 |
| Mode block act | →  88 |
| Mode block perm | →  88 |
| Mode blk norm | →  88 |

| | |
|------------------|-------|
| Alarm summary | → 88 |
| Software rev. | → 89 |
| Hardware rev. | → 89 |
| Manufacturer ID | → 90 |
| Device ID | → 90 |
| Serial number | → 90 |
| Diagnostics | → 90 |
| Diagnostics mask | → 91 |
| Dev certificate | → 92 |
| Factory reset | → 92 |
| Descriptor | → 92 |
| Device message | → 92 |
| Device inst.date | → 93 |
| Ident num select | → 93 |
| Hardware lock | → 93 |
| Feature support | → 94 |
| Feature enabled | → 94 |
| Condensed status | → 94 |

Device tag**Navigation**

Expert → Communication → Physical block → Device tag

Description

Use this function to enter the name for the measuring point.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promass 100 DP

Static revision

| | |
|-------------------------------|---|
| Navigation |   Expert → Communication → Physical block → Static revision |
| Description | Displays the event counter: every write access to a static block parameter is counted. |
| User interface | 0 to FFFF |
| Additional information | <p><i>Description</i></p>  Static parameters are parameters that are not changed by the process. |

Strategy



| | |
|------------------------|--|
| Navigation |   Expert → Communication → Physical block → Strategy |
| Description | Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers. |
| User entry | 0 to FFFF |
| Factory setting | 0 |

Alert key



| | |
|------------------------|---|
| Navigation |   Expert → Communication → Physical block → Alert key |
| Description | Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events. |
| User entry | 0 to 0xFF |
| Factory setting | 0 |

Target mode



| | |
|-----------------------|---|
| Navigation |   Expert → Communication → Physical block → Target mode |
| Description | Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application. |
| User interface | <ul style="list-style-type: none"> ▪ Auto ▪ Out of service |

Mode block act

Navigation

 Expert → Communication → Physical block → Mode block act

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ [87](#)).

User interface

- Auto
- Out of service

Additional information

Description

 A comparison of the current mode with the target mode (**Target mode** parameter (→ [87](#))) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation

 Expert → Communication → Physical block → Mode block perm

Description

Displays the Mode block perm: This defines which modes of operation in the Target mode (→ [87](#)) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode blk norm

Navigation

 Expert → Communication → Physical block → Mode blk norm

Description

Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Out of service

Alarm summary

Navigation

 Expert → Communication → Physical block → Alarm summary

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

| | |
|-------------------------------|---|
| User interface | <ul style="list-style-type: none"> ■ Discrete alarm ■ Alm statHiHi lim ■ Alrm stat Hi lim ■ Alm statLoLo lim ■ Alrm stat Lo lim ■ Update Event |
| Additional information | <p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Physical Block function block.</p> <p><i>User interface</i></p> <ul style="list-style-type: none"> ■ Discrete alarm Alarm or warning message with a discrete value. ■ Alm statHiHi lim Upper alarm limit ■ Alrm stat Hi lim Upper warning limit ■ Alm statLoLo lim Lower alarm limit ■ Alrm stat Lo lim Lower warning limit ■ Update Event This option constitutes a special alarm that is triggered if a static parameter is changed. If such a parameter is modified, the associated bit is set in the Alarm summary parameter (→ 88), the output of the block switches to "GOOD (NC) Active Update Event" (if the current status has a lower priority than this), and the block remains in this state for a duration of 10 s. The block then reverts to the normal state (the output has the last status and the Update Event option bit in the Alarm summary parameter (→ 88) is deleted again). |

Software rev.

| | |
|-----------------------|---|
| Navigation |  Expert → Communication → Physical block → Software rev. |
| Description | Displays the firmware version of the measuring device. |
| User interface | Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /). |

Hardware rev.

| | |
|-----------------------|---|
| Navigation |  Expert → Communication → Physical block → Hardware rev. |
| Description | Displays the hardware revision of the measuring device. |
| User interface | Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /). |

Manufacturer ID

Navigation  Expert → Communication → Physical block → Manufacturer ID

Description Displays the manufacturer ID with which the measuring device has been registered with the PNO (PROFIBUS User Organization).

User interface 0 to FFFF

Factory setting 0x11

Device ID

Navigation  Expert → Communication → Physical block → Device ID

Description Displays the device ID for identifying the measuring device in a PROFIBUS network.

User interface Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Promass 100 DP

Serial number

Navigation  Expert → Communication → Physical block → Serial number

Description Displays the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Diagnostics

Navigation  Expert → Communication → Physical block → Diagnostics

Description Displays the diagnostic messages.

User interface

- HW Error
- HW Error
- Temp motor

- Electronic temp
- Checksum error
- Measuremnt error
- Not initialized
- Init. error
- Zero point error
- Power supply
- Conf invalid
- On warmstart
- On coldstart
- Maintenance req.
- Char.invalid
- Ident num Error
- More info avlble
- Mainten. alarm
- Mainten.demanded
- Fct.chk or sim.
- Inval.proc.cond.

Diagnostics mask

Navigation Expert → Communication → Physical block → Diagnostics mask**Description**

Displays the diagnostic messages supported by the measuring device.

User interface

- HW Error
- HW Error
- Temp motor
- Electronic temp
- Checksum error
- Measuremnt error
- Not initialized
- Init. error
- Zero point error
- Power supply
- Conf invalid
- On warmstart
- On coldstart
- Maintenance req.
- Char.invalid
- Ident num Error
- More info avlble
- Mainten. alarm
- Mainten.demanded
- Fct.chk or sim.
- Inval.proc.cond.

Dev certificate

Navigation   Expert → Communication → Physical block → Dev certificate

Description Displays certificates of the measuring device, e.g. Ex certificate.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory reset

Navigation   Expert → Communication → Physical block → Factory reset

Description Use this function to reset a certain set of parameters in a block.

Selection

- to defaults
- warmstart device
- reset bus addr
- Cancel

Factory setting Cancel

Descriptor

Navigation   Expert → Communication → Physical block → Descriptor

Description Use this function to enter a user-specific string to describe the device within the application.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Device message

Navigation   Expert → Communication → Physical block → Device message

Description Use this function to enter a user-definable message (a string) to describe the device within the application or in the plant.

User entry Max. 32 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Device inst.date

| | |
|--------------------|---|
| Navigation | Expert → Communication → Physical block → Device inst.date |
| Description | Use this function to enter the date of installation of the device. |
| User entry | Max. 16 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /). |

Ident num select

| | |
|-------------------------------|--|
| Navigation | Expert → Communication → Physical block → Ident num select |
| Description | Use this function to select the device master file (GSD). |
| Selection | <ul style="list-style-type: none">■ Automatic mode■ Manufacturer■ Profile■ 1AI,1Tot(0x9740)■ 2AI,1Tot(0x9741) |
| Factory setting | Automatic mode |
| Additional information | <i>Description</i> In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned. |

Hardware lock

| | |
|-----------------------|---|
| Navigation | Expert → Communication → Physical block → Hardware lock |
| Description | Displays the hardware write protection. |
| User interface | <ul style="list-style-type: none">■ Unprotected■ Protected |

Additional information*Description*

Indicates whether it is possible to write-access the measuring device via PROFIBUS (acyclic data transmission, e.g. via the "FieldCare" operating program).

 For detailed information on hardware write protection, see the "Write protection via write protection switch" section of the Operating Instructions.

User interface

- Unprotected
Write access via PROFIBUS is possible (acyclic data transmission).
- Protected
Write access via PROFIBUS is locked (acyclic data transmission).

Feature support**Navigation**

  Expert → Communication → Physical block → Feature support

Description

Displays the PROFIBUS features that are supported by the measuring device.

User interface

- Condensed status
- Classic diag
- Data ex.broad.
- MS1 app.relation
- PROFIsafe comm.

Feature enabled**Navigation**

  Expert → Communication → Physical block → Feature enabled

Description

Displays the PROFIBUS features that are enabled in the measuring device.

User interface

- Condensed status
- Classic diag
- Data ex.broad.
- MS1 app.relation
- PROFIsafe comm.

Condensed status**Navigation**

  Expert → Communication → Physical block → Condensed status

Description

Use this function to switch the condensed status diagnostic on and off.

Selection


- Off
- On

Factory setting On

3.3.4 "Web server" submenu

Navigation

Expert → Communication → Web server



Webserv.language

Navigation

Expert → Communication → Web server → Webserv.language

Description

Use this function to select the Web server language setting.

Selection

- English *
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык(Ru) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية(Ara) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Viet) *
- čeština (Czech) *

* Visibility depends on order options or device settings

Factory setting English

MAC Address

Navigation   Expert → Communication → Web server → MAC Address**Description** Displays the MAC⁶⁾ address of the measuring device.**User interface** Unique 12-digit character string comprising letters and numbers**Factory setting** Each measuring device is given an individual address.**Additional information** *Example*For the display format
00:07:05:10:01:5F

DHCP client **Navigation**   Expert → Communication → Configuration → DHCP client Setup → Communication → DHCP client**Description** Use this function to activate and deactivate the DHCP client functionality.**Selection**

- Off
- On

Factory setting Off**Additional information** *Result*If the DHCP client functionality of the Web server is activated, the IP address (→  96), Subnet mask (→  97) and Default gateway (→  97) are set automatically. Identification is via the MAC address of the measuring device.

IP address **Navigation**   Expert → Communication → Web server → IP address**Description** Displays the IP address of the device's web server.**User interface** 4 octet: 0 to 255 (in the particular octet)**Factory setting** 192.168.1.212

6) Media Access Control

Subnet mask

Navigation Expert → Communication → Web server → Subnet mask

Description Displays the subnet mask.

User interface 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

Default gateway

Navigation Expert → Communication → Web server → Default gateway

Description Displays the default gateway.

User interface 4 octet: 0 to 255 (in the particular octet)

Factory setting 0.0.0.0

Webserver funct.

Navigation Expert → Communication → Web server → Webserver funct.

Description Use this function to switch the Web server on and off.

Selection

- Off
- On

Factory setting On

Additional information *Description*



Once disabled, the Webserver funct. can only be re-enabled via the local display or the operating tool FieldCare.


Selection

| Option | Description |
|--------|--|
| Off | <ul style="list-style-type: none"> ■ The web server is completely disabled. ■ Port 80 is locked. |
| On | <ul style="list-style-type: none"> ■ The complete functionality of the web server is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state. |

3.4 "Analog inputs" submenu

Navigation


Expert → Analog inputs



3.4.1 "Analog input 1 to n" submenu

Navigation

Expert → Analog inputs → Analog input 1 to n



Channel



Navigation

Expert → Analog inputs → Analog input 1 to n → Channel

Description

For selecting the process variable.

Selection

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *
- Density
- Ref.density
- Concentration *
- Dynam. viscosity *
- Kinematic visc.
- TempCompDynVisc *
- TempCompKinVisc *

* Visibility depends on order options or device settings

- Temperature
- Carr. pipe temp. *
- Electronic temp.
- Osc. freq. 0
- Osc. freq. 1 *
- Freq. fluct. 0
- Freq. fluct. 1 *
- Osc. ampl. 0 *
- Osc. ampl. 1 *
- Freq. fluct. 0
- Osc. damping 0
- Osc. damping 1 *
- Damping fluct 0
- Damping fluct 1 *
- Signal asymmetry
- Exc. current 0
- Exc. current 1 *
- Sensor integrity

Factory setting Mass flow

Additional information Selection

 Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: Value 1 display parameter (→ 18)

PV filter time



Navigation  Expert → Analog inputs → Analog input 1 to n → PV filter time

Description Use this function to enter a time to suppress signal peaks. During the specified time the Analog input does not respond to an erratic increase in the process variable.

User entry Positive floating-point number

Factory setting 0

Fail safe type



Navigation  Expert → Analog inputs → Analog input 1 to n → Fail safe type

Description Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting Off

* Visibility depends on order options or device settings

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 100).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value**Navigation**

Expert → Analog inputs → Analog input 1 to n → Fail safe value

Prerequisite

In **Fail safe type** parameter (→ 99), the **Fail safe value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 100)) in the event of an error.

User entry

Signed floating-point number

Factory setting

0

Out value**Navigation**

Expert → Analog inputs → Analog input 1 to n → Out value

Prerequisite

In **Target mode** parameter (→ 102), the **Auto** option is selected.

Description

Displays the analog value which is calculated when the function is executed.

User interface

Signed floating-point number

Out status**Navigation**

Expert → Analog inputs → Analog input 1 to n → Out status

Description

Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Analog inputs → Analog input 1 to n → Out status

Prerequisite In **Target mode** parameter (→ 102), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Analog inputs → Analog input 1 to n → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Analog inputs → Analog input 1 to n → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Analog inputs → Analog input 1 to n → Strategy

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Alert key

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Target mode

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block act**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Mode block act

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 102).

User interface

- Auto
- Man
- Out of service

Additional information**Description**

A comparison of the current mode with the target mode (**Target mode** parameter (→ 102)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation  Expert → Analog inputs → Analog input 1 to n → Mode block perm

Description Displays the Mode block perm: This defines which modes of operation in the Target mode (→ [102](#)) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface 0 to 255

Mode blk norm

Navigation  Expert → Analog inputs → Analog input 1 to n → Mode blk norm

Description Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary

Navigation  Expert → Analog inputs → Analog input 1 to n → Alarm summary

Description Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alm statHiHi lim
- Alrm stat Hi lim
- Alm statLoLo lim
- Alrm stat Lo lim
- Update Event

Additional information *Description*

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Inputs function block.

Batch ID**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Batch ID

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Batch operation

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Batch phase

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Batch Recipe

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information *Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PVscale lo range

Navigation Expert → Analog inputs → Analog input 1 to n → PVscale lo range

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PVscale up range

Navigation Expert → Analog inputs → Analog input 1 to n → PVscale up range

Description Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 100.0

Out scale low

Navigation Expert → Analog inputs → Analog input 1 to n → Out scale low

Description Use this function to enter the lower value range for the output value in system units.

User entry Signed floating-point number

Factory setting 0

Out scale up

Navigation Expert → Analog inputs → Analog input 1 to n → Out scale up

Description Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number

Factory setting 100.0

Lin type

Navigation Expert → Analog inputs → Analog input 1 to n → Lin type

Description Use this function to switch off the linearization type for the input value.

Selection Off

Factory setting Off

Out unit

Navigation Expert → Analog inputs → Analog input 1 to n → Out unit

Description Use this function to enter a numerical code (hex) for the system unit.

User entry 0 to 65 535

Factory setting 1997

Out dec_ point

Navigation Expert → Analog inputs → Analog input 1 to n → Out dec_ point

Description Use this function to enter the maximum number of decimal places that are displayed for the output value.

User entry 0 to 7

Factory setting 0

Alarm hysteresis

Navigation Expert → Analog inputs → Analog input 1 to n → Alarm hysteresis

Description Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry Signed floating-point number

Factory setting 0

Hi Hi Lim

| | |
|-------------------------------|---|
| Navigation | Expert → Analog inputs → Analog input 1 to n → Hi Hi Lim |
| Description | Use this function to enter the value for the upper alarm limit (HiHi alarm value parameter (→ 108)). |
| User entry | Signed floating-point number |
| Factory setting | Positive floating-point number |
| Additional information | <p><i>Description</i></p> <p> If the output value Out value (→ 100) exceeds this limit value, the HiHi alarm state parameter (→ 109) is output.</p> <p><i>User entry</i></p> <p> The value is entered in the defined units (Out unit parameter (→ 106)) and must be in the range defined in the Out scale low parameter (→ 105) and Out scale up parameter (→ 105).</p> |

Hi Lim

| | |
|-------------------------------|---|
| Navigation | Expert → Analog inputs → Analog input 1 to n → Hi Lim |
| Description | Use this function to enter the value for the upper warning limit (Hi alarm value parameter (→ 109)). |
| User entry | Signed floating-point number |
| Factory setting | Positive floating-point number |
| Additional information | <p><i>Description</i></p> <p> If the output value Out value (→ 100) exceeds this limit value, the Hi alarm state parameter (→ 109) is output.</p> <p><i>User entry</i></p> <p> The value is entered in the defined units (Out unit parameter (→ 106)) and must be in the range defined in the Out scale low parameter (→ 105) and Out scale up parameter (→ 105).</p> |

Lo Lim**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Lo Lim

Description

Use this function to enter the value for the lower warning limit (**Lo alarm value** parameter (→ [109\)\).](#)

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

i If the output value Out value (→ [100](#)) exceeds this limit value, the **Lo alarm state** parameter (→ [110](#)) is output.

User entry

i The value is entered in the defined units (**Out unit** parameter (→ [106\)\) and must be in the range defined in the **Out scale low** parameter \(→ \[105\\) and **Out scale up** parameter \\(→ \\[105\\\).\\]\\(#\\)\]\(#\)](#)

Lo Lo Lim**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Lo Lo Lim

Description

Use this function to enter the value for the lower alarm limit (**LoLo alarm value** parameter (→ [110\)\).](#)

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

i If the output value Out value (→ [100\) exceeds this limit value, the **LoLo alarm state** parameter \(→ \[110\\) is output.\]\(#\)](#)

User entry

i The value is entered in the defined units (**Out unit** parameter (→ [106\)\) and must be in the range defined in the **Out scale low** parameter \(→ \[105\\) and **Out scale up** parameter \\(→ \\[105\\\).\\]\\(#\\)\]\(#\)](#)

HiHi alarm value**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → HiHi alarm value

Description

Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ [107\)\).](#)

| | |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

HiHi alarm state

| | |
|------------------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → HiHi alarm state |
| Description | Displays the status for the upper alarm limit value (Hi Hi Lim parameter (→  107)). |
| User interface | <ul style="list-style-type: none">■ No alarm■ Alm statHiHi lim |
| Additional information | <i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm. |

Hi alarm value

| | |
|----------------|--|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Hi alarm value |
| Description | Displays the alarm value for the upper warning limit value (Hi Lim parameter (→  107)). |
| User interface | Signed floating-point number |

Hi alarm state

| | |
|------------------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Hi alarm state |
| Description | Displays the status for the upper warning limit value (Hi Lim parameter (→  107)). |
| User interface | <ul style="list-style-type: none">■ No warning■ Alrm stat Hi lim |
| Additional information | <i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm. |

Lo alarm value

| | |
|-------------|--|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Lo alarm value |
| Description | Displays the alarm value for the lower warning limit value (Lo Lim parameter (→  108)). |

| | |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

Lo alarm state

| | |
|------------------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Lo alarm state |
| Description | Displays the status for the lower warning limit value (Lo Lim parameter (→  108)). |
| User interface | <ul style="list-style-type: none">■ No warning■ Alrm stat Lo lim |
| Additional information | <i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm. |

LoLo alarm value

| | |
|----------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → LoLo alarm value |
| Description | Displays the alarm value for the lower alarm limit value (Lo Lo Lim parameter (→  108)). |
| User interface | Signed floating-point number |

LoLo alarm state

| | |
|------------------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → LoLo alarm state |
| Description | Displays the status for the lower alarm limit value (Lo Lo Lim parameter (→  108)). |
| User interface | <ul style="list-style-type: none">■ No alarm■ Alm statLoLo lim |
| Additional information | <i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm. |

Simulate enabled

| | |
|-------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Simulate enabled |
| Description | Use this function to enable or disable block simulation. |

| | |
|-------------------------------|---|
| Selection | <ul style="list-style-type: none"> ■ Disable ■ Enable |
| Factory setting | Disable |
| Additional information | <p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.</p> |

Simulate value

| | |
|-------------------------------|--|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Simulate value |
| Description | Use this function to enter a simulation value for the block. |
| User entry | Signed floating-point number |
| Factory setting | 0 |
| Additional information | <p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.</p> |

Simulate status

| | |
|-------------------------------|---|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Simulate status |
| Description | Use this function to enter a simulation status for the block. |
| User entry | 0 to 255 |
| Factory setting | 0 |
| Additional information | <p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.</p> |

Out unit text

| | |
|--------------------|--|
| Navigation |  Expert → Analog inputs → Analog input 1 to n → Out unit text |
| Description | Use this function to enter the out unit text: if a specific out unit does not appear in the code list, the user can enter the specific text. The unit code is then equivalent to the definition provided here. |


User entry Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting NoUnit

3.5 "Discrete inputs" submenu

Navigation


Expert → Discrete inputs



3.5.1 "Discrete input 1 to n" submenu

Navigation

Expert → Discrete inputs → Discrete input 1 to n



Channel



Navigation

Expert → Discrete inputs → Discrete input 1 to n → Channel

Description

Use this function to assign a measured variable to the particular function block.

Selection

- Empty pipe det.
- Low flow cut off
- Verific. status *

* Visibility depends on order options or device settings

| | |
|------------------------|-----------------|
| Factory setting | Empty pipe det. |
|------------------------|-----------------|

Invert

| | |
|-------------------|---|
| Navigation | Expert → Discrete inputs → Discrete input 1 to n → Invert |
|-------------------|---|

| | |
|--------------------|---|
| Description | Use this function to invert the input signal. |
|--------------------|---|

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none">■ Off■ On |
|------------------|--|

| | |
|------------------------|-----|
| Factory setting | Off |
|------------------------|-----|

Fail safe type

| | |
|-------------------|---|
| Navigation | Expert → Discrete inputs → Discrete input 1 to n → Fail safe type |
|-------------------|---|

| | |
|--------------------|---|
| Description | Use this function to select the failure mode. |
|--------------------|---|

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none">■ Fail safe value■ Fallback value■ Off |
|------------------|--|

| | |
|------------------------|-----|
| Factory setting | Off |
|------------------------|-----|

| | |
|-------------------------------|------------------|
| Additional information | <i>Selection</i> |
|-------------------------------|------------------|

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 113).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value

| | |
|-------------------|--|
| Navigation | Expert → Discrete inputs → Discrete input 1 to n → Fail safe value |
|-------------------|--|

| | |
|---------------------|--|
| Prerequisite | In Fail safe type parameter (→ 113), the Fail safe value option is selected. |
|---------------------|--|

| | |
|--------------------|--|
| Description | Use this function to enter a failure value. The value entered is displayed as the output value (Out value parameter (→ 114)) in the event of an error. |
|--------------------|--|

| | |
|-------------------|----------|
| User entry | 0 to 255 |
|-------------------|----------|

Factory setting 0

Out value

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out value

Prerequisite In **Target mode** parameter (→ [115](#)), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface 0 to 255

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status

Prerequisite In **Target mode** parameter (→ [115](#)), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Discrete inputs → Discrete input 1 to n → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

| | |
|-------------------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Static revision |
| Description | Displays the event counter: every write access to a static block parameter is counted. |
| User interface | 0 to FFFF |
| Additional information | <p><i>Description</i></p>  Static parameters are parameters that are not changed by the process. |

Strategy



| | |
|------------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Strategy |
| Description | Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers. |
| User entry | 0 to FFFF |
| Factory setting | 0 |

Alert key



| | |
|------------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Alert key |
| Description | Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events. |
| User entry | 0 to 0xFF |
| Factory setting | 0 |

Target mode



| | |
|-----------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Target mode |
| Description | Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application. |
| User interface | <ul style="list-style-type: none"> ▪ Auto ▪ Man ▪ Out of service |

Mode block act

| | |
|-------------------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Mode block act |
| Description | Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→  115). |
| User interface | <ul style="list-style-type: none">▪ Auto▪ Man▪ Out of service |
| Additional information | Description  A comparison of the current mode with the target mode (Target mode parameter (→  115)) indicates whether it was possible to reach the target mode. |

Mode block perm

| | |
|-----------------------|---|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Mode block perm |
| Description | Displays the Mode block perm: This defines which modes of operation in the Target mode (→  115) are available for the function block. The operating modes that are supported vary depending on the type and function of the block. |
| User interface | 0 to 255 |

Mode blk norm

| | |
|-----------------------|--|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Mode blk norm |
| Description | Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block. |
| User interface | <ul style="list-style-type: none">▪ Auto▪ Man▪ Out of service |

Alarm summary

| | |
|--------------------|--|
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Alarm summary |
| Description | Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed. |

| | |
|-------------------------------|---|
| User interface | <ul style="list-style-type: none"> ■ Discrete alarm ■ Alm statHiHi lim ■ Alrm stat Hi lim ■ Alm statLoLo lim ■ Alrm stat Lo lim ■ Update Event |
| Additional information | <p>Description</p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Inputs function block.</p> |

| | |
|--------------------|---|
| Batch ID |  |
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Batch ID |
| Description | Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process. |
| User entry | Positive integer |

| | |
|------------------------|--|
| Batch operation |  |
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Batch operation |
| Description | Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation. |
| User entry | 0 to 65 535 |
| Factory setting | 0 |

| | |
|------------------------|--|
| Batch phase |  |
| Navigation |  Expert → Discrete inputs → Discrete input 1 to n → Batch phase |
| Description | Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation. |
| User entry | 0 to 65 535 |
| Factory setting | 0 |

Batch Recipe**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Batch Recipe

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information*Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Simulate enabled**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Simulate enabled

Description

Use this function to enable or disable block simulation.

Selection

- Disable
- Enable

Factory setting

Disable

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Simulate value

Description

Use this function to enter a simulation value for the block.

User entry

0 to 255

Factory setting

0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status

Navigation Expert → Discrete inputs → Discrete input 1 to n → Simulate status

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

3.6 "Analog outputs" submenu

Navigation Expert → Analog outputs

► Analog outputs

► Analog output 1 to n

→ 119

3.6.1 "Analog output 1 to n" submenu

Navigation Expert → Analog outputs → Analog output 1 to n

► Analog output 1 to n

Set point val

→ 120

Set point status

→ 120

Fail safe time

→ 120

Fail safe type

→ 121

Fail safe value

→ 121

Out value

→ 121

Out status

→ 122

Out status

→ 122

Set point val

Navigation Expert → Analog outputs → Analog output 1 to n → Set point val

Description Use this function to enter an analog set point.

User entry Signed floating-point number

Factory setting 0

Set point status

Navigation Expert → Analog outputs → Analog output 1 to n → Set point status

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Fail safe time

Navigation Expert → Analog outputs → Analog output 1 to n → Fail safe time

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry 0 to 999.0

Factory setting 0

Additional information *User entry*

NOTE!

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- ▶ Check in advance to ensure that the safety-specific requirements of the process would permit this.
- ▶ If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type

Navigation Expert → Analog outputs → Analog output 1 to n → Fail safe type

Description Use this function to select the failure mode.

- Selection**
- Fail safe value
 - Fallback value
 - Off

Factory setting Fallback value

Additional information *Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 121).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value

Navigation Expert → Analog outputs → Analog output 1 to n → Fail safe value

Prerequisite In **Fail safe type** parameter (→ 121), the **Fallback value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 121)) in the event of an error.

User entry Signed floating-point number

Factory setting 0

Out value

Navigation Expert → Analog outputs → Analog output 1 to n → Out value

Prerequisite In **Target mode** parameter (→ 123), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface Signed floating-point number

Out status

Navigation   Expert → Analog outputs → Analog output 1 to n → Out status

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation   Expert → Analog outputs → Analog output 1 to n → Out status

Prerequisite In **Target mode** parameter (→  123), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Analog outputs → Analog output 1 to n → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Analog outputs → Analog output 1 to n → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Strategy

Description

Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Alert key

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Target mode

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Mode block act**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Mode block act

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 123).

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Additional information*Description*

A comparison of the current mode with the target mode (**Target mode** parameter (→ 123)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation

Expert → Analog outputs → Analog output 1 to n → Mode block perm

Description

Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 123) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode blk norm

Navigation

Expert → Analog outputs → Analog output 1 to n → Mode blk norm

Description

Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Alarm summary

Navigation

Expert → Analog outputs → Analog output 1 to n → Alarm summary

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alm statHiHi lim
- Alrm stat Hi lim
- Alm statLoLo lim
- Alrm stat Lo lim
- Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Outputs function block.

Batch ID**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Batch ID

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Batch operation

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Batch phase

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Batch Recipe

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information *Description*

 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PVsclae lo range



Navigation  Expert → Analog outputs → Analog output 1 to n → PVscale lo range

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PVsclae up range



Navigation  Expert → Analog outputs → Analog output 1 to n → PVscale up range

Description Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 100.0

Readback value

Navigation  Expert → Analog outputs → Analog output 1 to n → Readback value

Description Displays the readback value. The readback value indicates the current position of the control element within the travel range (between the open and close position) in PV scale units.

User interface Signed floating-point number

Readback status

| | |
|-----------------------|--|
| Navigation |  Expert → Analog outputs → Analog output 1 to n → Readback status |
| Description | Displays the readback status. The readback status contains the status information of the slave. |
| User interface | 0 to 255 |

RCAS in value

| | |
|------------------------|---|
| Navigation |  Expert → Analog outputs → Analog output 1 to n → RCAS in value |
| Description | Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade RCAS in value parameter (→  127). The normal algorithm calculates the output value of the block on the basis of this set point. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

RCAS in status

| | |
|------------------------|---|
| Navigation |  Expert → Analog outputs → Analog output 1 to n → RCAS in status |
| Description | Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→  127). |
| User entry | 0 to 255 |
| Factory setting | 0 |

Input channel

| | |
|------------------------|--|
| Navigation |  Expert → Analog outputs → Analog output 1 to n → Input channel |
| Description | Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block. |
| Selection | None |
| Factory setting | None |

Output channel

| | |
|------------------------|---|
| Navigation | Expert → Analog outputs → Analog output 1 to n → Output channel |
| Description | Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block. |
| Selection | <ul style="list-style-type: none">▪ External press.▪ External temp.▪ Ext. ref.density |
| Factory setting | External press. |

RCAS out value

| | |
|-----------------------|---|
| Navigation | Expert → Analog outputs → Analog output 1 to n → RCAS out value |
| Description | Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode. |
| User interface | Signed floating-point number |

RCAS out status

| | |
|-----------------------|---|
| Navigation | Expert → Analog outputs → Analog output 1 to n → RCAS out status |
| Description | Displays the RCAS out status. Displays the status of the set point. |
| User interface | 0 to 0xFF |

Pos value

| | |
|-----------------------|--|
| Navigation | Expert → Analog outputs → Analog output 1 to n → Pos value |
| Description | Displays the current value of the positioner. |
| User interface | 0 to 255 |

Position status

Navigation  Expert → Analog outputs → Analog output 1 to n → Position status

Description Displays the current status of the positioner.

User interface 0 to 255

Setp. deviation

Navigation  Expert → Analog outputs → Analog output 1 to n → Setp. deviation

Description Displays the deviation between the set point (**Set point val** parameter (→  120)) and the actual value (**Readback value** parameter (→  126)).

User interface Signed floating-point number

Simulate enabled



Navigation  Expert → Analog outputs → Analog output 1 to n → Simulate enabled

Description Use this function to enable or disable block simulation.

Selection
■ Disable
■ Enable

Factory setting Disable

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value



Navigation  Expert → Analog outputs → Analog output 1 to n → Simulate value

Description Use this function to enter a simulation value.

User entry Signed floating-point number

Factory setting 0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Simulate status

Description

Use this function to enter a simulation status for the block.

User entry

0 to 255

Factory setting

0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Increase close**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Increase close

Description

Use this function to enter the effective direction of the positioner in automatic mode.

User entry

0 to 255

Factory setting

0

Out scale up**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Out scale up

Description

Use this function to enter the upper value range for the output value in system units.

User entry

Signed floating-point number

Factory setting

100.0

Out scale low

Navigation Expert → Analog outputs → Analog output 1 to n → Out scale low

Description Use this function to enter the lower value range for the output value in system units.

User entry Signed floating-point number

Factory setting 0

3.7 "Discrete outputs" submenu

Navigation Expert → Discrete outputs

► Discrete outputs

► Discr. out. 1 to n

→ 131

3.7.1 "Discrete output 1 to n" submenu

Navigation Expert → Discrete outputs → Discr. out. 1 to n

► Discr. out. 1 to n

Set point val

→ 132

Set point status

→ 132

Invert

→ 132

Fail safe time

→ 132

Fail safe type

→ 133

Fail safe value

→ 133

Out value

→ 134

Out status

→ 134

Out status

→ 134

Set point val

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Set point val

Description Use this function to enter an analog set point.

User entry 0 to 255

Factory setting 0

Set point status

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Set point status

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Invert

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Invert

Description Use this function to switch inversion on and off. Specifies whether the set point should be inverted before the value is set as the output value or the RCAS value (in the automatic mode).

Selection

- Off
- On

Factory setting Off

Fail safe time

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Fail safe time

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry Signed floating-point number

Factory setting 0

Additional information*User entry***NOTE!**

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- ▶ Check in advance to ensure that the safety-specific requirements of the process would permit this.
- ▶ If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type**Navigation**

Expert → Discrete outputs → Discr. out. 1 to n → Fail safe type

Description

Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting

Fallback value

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 133).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value**Navigation**

Expert → Discrete outputs → Discr. out. 1 to n → Fail safe value

Prerequisite

In **Fail safe type** parameter (→ 133), the **Fail safe value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 134)) in the event of an error.

User entry

0 to 255

Factory setting

0

Out value

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Out value

Prerequisite In **Target mode** parameter (→ 135), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface 0 to 255

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Out status

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Out status

Prerequisite In **Target mode** parameter (→ 135), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description 

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

| | |
|-------------------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Static revision |
| Description | Displays the event counter: every write access to a static block parameter is counted. |
| User interface | 0 to FFFF |
| Additional information | <i>Description</i>  Static parameters are parameters that are not changed by the process. |

Strategy

| | |
|------------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Strategy |
| Description | Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers. |
| User entry | 0 to FFFF |
| Factory setting | 0 |

Alert key

| | |
|------------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Alert key |
| Description | Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events. |
| User entry | 0 to 0xFF |
| Factory setting | 0 |

Target mode

| | |
|--------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Target mode |
| Description | Displays the Target mode: The target mode specifies which mode of operation is used for this function block. This mode is generally set by a control application. |

User interface

- Local override
- Remote Cascaded
- Man
- Out of service
- Auto

Mode block act

Navigation

 Expert → Discrete outputs → Discr. out. 1 to n → Mode block act

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→  135).

User interface

- Local override
- Remote Cascaded
- Man
- Out of service
- Auto

Additional information**Description**

 A comparison of the current mode with the target mode (**Target mode** parameter (→  135)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation

 Expert → Discrete outputs → Discr. out. 1 to n → Mode block perm

Description

Displays the Mode block perm: This defines which modes of operation in the Target mode (→  135) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode blk norm

Navigation

 Expert → Discrete outputs → Discr. out. 1 to n → Mode blk norm

Description

Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

| | |
|-----------------------|--|
| User interface | <ul style="list-style-type: none"> ■ Local override ■ Remote Cascaded ■ Man ■ Out of service ■ Auto |
|-----------------------|--|

Alarm summary

| | |
|-------------------------------|--|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Alarm summary |
| Description | Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed. |
| User interface | <ul style="list-style-type: none"> ■ Discrete alarm ■ Alm statHiHi lim ■ Alrm stat Hi lim ■ Alm statLoLo lim ■ Alrm stat Lo lim ■ Update Event |
| Additional information | <p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Outputs function block.</p> |

Batch ID

| | |
|--------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Batch ID |
| Description | Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process. |
| User entry | Positive integer |

Batch operation

| | |
|------------------------|--|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Batch operation |
| Description | Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation. |
| User entry | 0 to 65 535 |
| Factory setting | 0 |

Batch phase

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Batch phase

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Batch Recipe

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information *Description*

 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Readback value

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Readback value

Description Displays the readback value. The readback value indicates the current position of the control element and the element's sensors.

User interface 0 to 255

Readback status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Readback status

Description Displays the readback status. Displays the status of the readback value.

User interface 0 to 255

RCAS in value

Navigation Expert → Discrete outputs → Discr. out. 1 to n → RCAS in value

Description Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade **RCAS in value** parameter (→ [139](#)). The normal algorithm calculates the output value of the block on the basis of this set point.

User entry 0 to 255

Factory setting 0

RCAS in status

Navigation Expert → Discrete outputs → Discr. out. 1 to n → RCAS in status

Description Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→ [139](#)).

User entry 0 to 255

Factory setting 0

Input channel

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Input channel

Description Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.

Selection None

Factory setting None

Output channel

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Output channel

Description Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none">■ Flow override■ Zero point adj.*■ Start verificat.* |
|------------------|--|

| | |
|------------------------|---------------|
| Factory setting | Flow override |
|------------------------|---------------|

RCAS out value

| | |
|-------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → RCAS out value |
|-------------------|---|

| | |
|--------------------|---|
| Description | Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode. |
|--------------------|---|

| | |
|-----------------------|----------|
| User interface | 0 to 255 |
|-----------------------|----------|

RCAS out status

| | |
|-------------------|--|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → RCAS out status |
|-------------------|--|

| | |
|--------------------|---|
| Description | Displays the RCAS out status. Displays the status of the set point. |
|--------------------|---|

| | |
|-----------------------|----------|
| User interface | 0 to 255 |
|-----------------------|----------|

Simulate enabled



| | |
|-------------------|---|
| Navigation |  Expert → Discrete outputs → Discr. out. 1 to n → Simulate enabled |
|-------------------|---|

| | |
|--------------------|--|
| Description | Use this function to enable or disable block simulation. |
|--------------------|--|

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none">■ Disable■ Enable |
|------------------|--|

| | |
|------------------------|---------|
| Factory setting | Disable |
|------------------------|---------|

| | |
|-------------------------------|--------------------|
| Additional information | <i>Description</i> |
|-------------------------------|--------------------|

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

* Visibility depends on order options or device settings

Simulate value

| | |
|-------------------------------|--|
| Navigation | Expert → Discrete outputs → Discr. out. 1 to n → Simulate value |
| Description | Use this function to enter a simulation value. |
| User entry | 0 to 255 |
| Factory setting | 0 |
| Additional information | <p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.</p> |


Simulate status

| | |
|-------------------------------|---|
| Navigation | Expert → Discrete outputs → Discr. out. 1 to n → Simulate status |
| Description | Use this function to enter a simulation status for the block. |
| User entry | 0 to 255 |
| Factory setting | 0 |
| Additional information | <p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.</p> |

3.8 "Application" submenu

Navigation

Expert → Application



3.8.1 "Totalizer 1 to n" submenu

Navigation

Expert → Application → Totalizer 1 to n

| ► Totalizer 1 to n | |
|-----------------------|-----------------------|
| Assign variable | → 142 |
| Unit totalizer | → 143 |
| Control Tot. 1 to n | → 144 |
| Preset value 1 to n | → 145 |
| Operation mode | → 145 |
| Failure mode | → 146 |
| Totalizer val. 1 to n | → 147 |
| Tot. status 1 to n | → 147 |
| Status (Hex) 1 to n | → 147 |

Assign variable



Navigation

Expert → Application → Totalizer 1 to n → Assign variable

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *

Factory setting

Mass flow

Additional information

Description

If the option selected is changed, the device resets the totalizer to 0.

* Visibility depends on order options or device settings

Unit totalizer**Navigation**

  Expert → Application → Totalizer 1 to n → Unit totalizer

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→  142):

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow ^{*}
- Carrier mass fl. ^{*}

Description

Use this function to select the process variable of a totalizer.

 The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→  50).

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

or

SI units

- Nl
- Nm³
- Sl
- Sm³

US units

- Sft³
- Sgal (us)
- Sbbl (us;liq.)

Imperial units

- Sgal (imp)

Factory setting

Country-specific:

- kg
- lb

* Visibility depends on order options or device settings

Additional information*Selection*

The selection is independent of the process variable selected in the **Assign variable** parameter (→ [142](#)).

Dependency

The following parameters depend on the option selected:

- **Alarm hysteresis** parameter (→ [151](#))
- **Hi Hi Lim** parameter (→ [152](#))
- **Hi Lim** parameter (→ [152](#))
- **Lo Lim** parameter (→ [153](#))
- **Lo Lo Lim** parameter (→ [153](#))
- **Totalizer val.** parameter (→ [49](#))
- **Preset value** parameter (→ [145](#))

Control Tot. 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Control Tot. 1 to n

Prerequisite

In the **Assign variable** parameter (→ [142](#)), one of the following options is selected:

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold

Factory setting

Totalize

Additional information*Selection*

- Totalize
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter.

* Visibility depends on order options or device settings

Preset value 1 to n**Navigation**

  Expert → Application → Totalizer 1 to n → Preset value 1 to n

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [142](#)):

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *

Description

Use this function to enter an initial value for the specific totalizer.

User entry

Signed floating-point number

Factory setting

Country-specific:

- kg
- lb

Additional information

User entry

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [143](#)).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Operation mode**Navigation**

  Expert → Application → Totalizer 1 to n → Operation mode

Prerequisite

In the **Assign variable** parameter (→ [142](#)), one of the following options is selected:

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward total
- Reverse total
- Last valid value

Factory setting

Net flow total

* Visibility depends on order options or device settings

Additional information*Selection*

- Net flow total
Positive and negative flow values are totaled and balanced against one another. Net flow is registered in the flow direction.
- Forward total
Only the flow in the forward flow direction is totaled.
- Reverse total
Only the flow against the forward flow direction is totaled (= reverse flow total).
- Last valid value
The value is frozen. Totaling is stopped.

Failure mode**Navigation**

Expert → Application → Totalizer 1 to n → Failure mode

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 142):

- Mass flow
- Volume flow
- Correct.vol.flow
- Target mass flow *
- Carrier mass fl. *

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Actual value

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop
Totalizing is stopped when a device alarm occurs.
- Actual value
The totalizer continues to count based on the current measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

* Visibility depends on order options or device settings

Totalizer val. 1 to n

| | |
|-------------------------------|--|
| Navigation |  Expert → Application → Totalizer 1 to n → Totalizer val. 1 to n |
| Prerequisite | In the Target mode parameter (→ 149), the Auto option is selected. |
| Description | Displays the current reading for totalizer 1-3. |
| User interface | Signed floating-point number |
| Additional information | <i>Description</i>  In the event of an error, the totalizer adopts the mode defined in the Failure mode parameter (→ 146). <i>User interface</i> The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the Operation mode parameter (→ 145). <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 143). |

Tot. status 1 to n

| | |
|-----------------------|--|
| Navigation |  Expert → Application → Totalizer 1 to n → Tot. status 1 to n |
| Description | Displays the status of the particular totalizer. |
| User interface | <ul style="list-style-type: none">■ Good■ Uncertain■ Bad |

Status (Hex) 1 to n

| | |
|-----------------------|---|
| Navigation |  Expert → Application → Totalizer 1 to n → Status (Hex) 1 to n |
| Prerequisite | In Target mode parameter (→ 149), the Auto option is selected. |
| Description | Displays the status value (hex) of the particular totalizer. |
| User interface | 0 to 0xFF |

Tag description

Navigation  Expert → Application → Totalizer 1 to n → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Application → Totalizer 1 to n → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy

Navigation  Expert → Application → Totalizer 1 to n → Strategy

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation  Expert → Application → Totalizer 1 to n → Alert key

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode**Navigation**

█ Expert → Application → Totalizer 1 to n → Target mode

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block act**Navigation**

█ Expert → Application → Totalizer 1 to n → Mode block act

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 149).

User interface

- Auto
- Man
- Out of service

Additional information*Description*

A comparison of the current mode with the target mode (**Target mode** parameter (→ 149)) indicates whether it was possible to reach the target mode.

Mode block perm**Navigation**

█ Expert → Application → Totalizer 1 to n → Mode block perm

Description

Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 149) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode blk norm**Navigation**

█ Expert → Application → Totalizer 1 to n → Mode blk norm

Description

Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary

Navigation

█ Expert → Application → Totalizer 1 to n → Alarm summary

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alm statHiHi lim
- Alrm stat Hi lim
- Alm statLoLo lim
- Alrm stat Lo lim
- Update Event

Additional information**Description**

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Totalizer function block.

Batch ID

**Navigation**

█ Expert → Application → Totalizer 1 to n → Batch ID

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Factory setting

0

Batch operation

**Navigation**

█ Expert → Application → Totalizer 1 to n → Batch operation

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

Diagram: Expert → Application → Totalizer 1 to n → Batch phase

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe**Navigation**

Diagram: Expert → Application → Totalizer 1 to n → Batch Recipe

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information*Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Alarm hysteresis**Navigation**

Diagram: Expert → Application → Totalizer 1 to n → Alarm hysteresis

Description

Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry

Signed floating-point number

Factory setting

0 kg

Additional information*User entry*

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 143).

Hi Hi Lim**Navigation**

█ Expert → Application → Totalizer 1 to n → Hi Hi Lim

Description

Use this function to enter the value for the upper alarm limit of the totalizer (**HiHi alarm value** parameter (→ 154)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

i If the output value Out value (→ 100) exceeds this limit value, the **HiHi alarm state** parameter (→ 154) is output.

User entry

i The value is entered in the defined units (**Out unit** parameter (→ 106)) and must be in the range defined in the **Out scale low** parameter (→ 105) and **Out scale up** parameter (→ 105).

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 143).

Hi Lim**Navigation**

█ Expert → Application → Totalizer 1 to n → Hi Lim

Description

Use this function to enter the value for the upper warning limit of the totalizer (**Hi alarm value** parameter (→ 154)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

i If the output value Out value (→ 100) exceeds this limit value, the **Hi alarm state** parameter (→ 154) is output.

User entry

i The value is entered in the defined units (**Out unit** parameter (→ 106)) and must be in the range defined in the **Out scale low** parameter (→ 105) and **Out scale up** parameter (→ 105).

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 143).

Lo Lim**Navigation**

Expert → Application → Totalizer 1 to n → Lo Lim

Description

Use this function to enter the value for the lower warning limit of the totalizer (**Lo alarm value** parameter (→ 155)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ 100) exceeds this limit value, the **Lo alarm state** parameter (→ 155) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 106)) and must be in the range defined in the **Out scale low** parameter (→ 105) and **Out scale up** parameter (→ 105).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 143).

Lo Lo Lim**Navigation**

Expert → Application → Totalizer 1 to n → Lo Lo Lim

Description

Use this function to enter the value for the lower alarm limit of the totalizer (**LoLo alarm value** parameter (→ 155)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ 100) exceeds this limit value, the **LoLo alarm state** parameter (→ 155) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 106)) and must be in the range defined in the **Out scale low** parameter (→ 105) and **Out scale up** parameter (→ 105).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 143).

HiHi alarm value

Navigation  Expert → Application → Totalizer 1 to n → HiHi alarm value

Description Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→  152)).

User interface Signed floating-point number

HiHi alarm state

Navigation  Expert → Application → Totalizer 1 to n → HiHi alarm state

Description Displays the status for the upper alarm limit value (**Hi Hi Lim** parameter (→  152)).

User interface

- No alarm
- Alrm statHiHi lim

Additional information *User interface*

 The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation  Expert → Application → Totalizer 1 to n → Hi alarm value

Description Displays the warning value for the upper warning limit value (**Hi Lim** parameter (→  152)).

User interface Signed floating-point number

Hi alarm state

Navigation  Expert → Application → Totalizer 1 to n → Hi alarm state

Description Displays the status for the upper warning limit value (**Hi Lim** parameter (→  152)).

User interface

- No warning
- Alrm stat Hi lim

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation  Expert → Application → Totalizer 1 to n → Lo alarm value

Description Displays the warning value for the lower warning limit value (**Lo Lim** parameter (→  153)).

User interface Signed floating-point number

Lo alarm state

Navigation  Expert → Application → Totalizer 1 to n → Lo alarm state

Description Displays the status for the lower warning limit value (**Lo Lim** parameter (→  153)).

User interface

- No warning
- Alm stat Lo lim

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

LoLo alarm value

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm value

Description Displays the alarm value for the lower alarm limit value (**Lo Lo Lim** parameter (→  153)).

User interface Signed floating-point number

LoLo alarm state

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm state

Description Displays the status for the lower alarm limit value (**Lo Lo Lim** parameter (→  153)).

User interface

- No alarm
- Alm statLoLo lim

Additional information *User interface*

 The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.


3.8.2 "Viscosity" submenu

 Only available for Promass I.

 For detailed information on the parameter descriptions for the **Viscosity** application package, refer to the Special Documentation for the device

Navigation

 Expert → Application → Viscosity



3.8.3 "Concentration" submenu

 For detailed information on the parameter descriptions for the **Concentration** application package, refer to the Special Documentation for the device

Navigation


 Expert → Application → Concentration




3.9 "Diagnostics" submenu

Navigation

 Expert → Diagnostics





Actual diagnos.

Navigation Expert → Diagnostics → Actual diagnos.

Prerequisite A diagnostic event has occurred.

Description Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*

Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 159).

Example

For the display format:

F271 Main electronic

Timestamp

Navigation Expert → Diagnostics → Timestamp

Description Displays the operating time when the current diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

The diagnostic message can be viewed via the **Actual diagnos.** parameter (→ 157).

Example

For the display format:

24d12h13m00s

Prev.diagnostics

Navigation Expert → Diagnostics → Prev.diagnostics

Prerequisite Two diagnostic events have already occurred.

Description Displays the diagnostic message that occurred before the current message.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Example*

For the display format:

 F271 Main electronic

Timestamp

Navigation  Expert → Diagnostics → Timestamp

Description Displays the operating time when the last diagnostic message before the current message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

 The diagnostic message can be viewed via the **Prev.diagnostics** parameter
(→  157).

Example

For the display format:
24d12h13m00s

Time fr. restart

Navigation   Expert → Diagnostics → Time fr. restart

Description Use this function to display the time the device has been in operation since the last device restart.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation   Expert → Diagnostics → Operating time


Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.9.1 "Diagnostic list" submenu

Navigation
 Expert → Diagnostics → Diagnostic list


Diagnostics 1

Navigation
 Expert → Diagnostics → Diagnostic list → Diagnostics 1
Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic
- F276 I/O module

Timestamp

Navigation
 Expert → Diagnostics → Diagnostic list → Timestamp
Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 159).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2

Description

Displays the current diagnostics message with the second-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:
■ F271 Main electronic
■ F276 I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 160).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 3

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic
- F276 I/O module

Timestamp**Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 3** parameter (→ 160).

Example

For the display format:

24d12h13m00s

Diagnostics 4**Navigation**

Expert → Diagnostics → Diagnostic list → Diagnostics 4

Description

Displays the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic
- F276 I/O module

Timestamp**Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 161).

Example

For the display format:
24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:
■ F271 Main electronic
■ F276 I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ 162).

Example


For the display format:
24d12h13m00s

3.9.2 "Event logbook" submenu

Navigation



Expert → Diagnostics → Event logbook



Filter options



Navigation



Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information

Description



The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu



The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation



Expert → Diagnostics → Event logbook → Event list



| | | |
|--|------------|--------|
| | Event list | → 164 |
|--|------------|--------|

Event list**Navigation**

Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter.

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- : Occurrence of the event
- : End of the event

Examples

For the display format:

- I1091 Configuration modified
 24d12h13m00s
- F271 Main electronic
 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.9.3 "Device info" submenu**Navigation**

Expert → Diagnostics → Device info

| | |
|--------------------|--------|
| Device info | |
| Device tag | → 165 |
| Serial number | → 165 |
| Firmware version | → 165 |
| Device name | → 166 |

| | |
|------------------|-----------------------|
| Order code | → 166 |
| Ext. order cd. 1 | → 166 |
| Ext. order cd. 2 | → 167 |
| Ext. order cd. 3 | → 167 |
| ENP version | → 167 |

Device tag

Navigation

  Expert → Diagnostics → Device info → Device tag

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant.

User interface

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promass 100 DP

Serial number

Navigation

  Expert → Diagnostics → Device info → Serial number

Description

Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface

A maximum of 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation

  Expert → Diagnostics → Device info → Firmware version

Description

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name**Navigation**

Expert → Diagnostics → Device info → Device name

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Factory setting

Promass 100 DP

Order code**Navigation**

Expert → Diagnostics → Device info → Order code

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Ext. order cd. 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Ext. order cd. 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 166)

Ext. order cd. 3**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 3

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 166)

ENP version**Navigation**

Expert → Diagnostics → Device info → ENP version

Description

Displays the version of the electronic nameplate.

User interface

Character string

Factory setting

2.02.00










Additional information*Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.9.4 "Min/max val." submenu

Navigation

  Expert → Diagnostics → Min/max val.

| | |
|---|---|
|  Min/max val. | |
|  Reset min/max | →  168 |
|  Electronic temp. | →  169 |
|  Medium temp. | →  170 |
|  Carr. pipe temp. | →  170 |
|  Oscil. frequency | →  172 |
|  Tors.oscil.freq. | →  172 |
|  Oscil. amplitude | →  173 |
|  Tor. osc. amp. | →  174 |
|  Oscil. damping | →  175 |
|  Tors.oscil.damp. | →  175 |
|  Signal asymmetry | →  176 |

Reset min/max

Navigation

  Expert → Diagnostics → Min/max val. → Reset min/max

Description

Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection

- Cancel
- Oscil. amplitude
- Osc. ampl. 1 *
- Oscil. damping
- Tors.oscil.damp. *
- Oscil. frequency
- Tors.oscil.freq.*
- Signal asymmetry

Factory setting

Cancel


* Visibility depends on order options or device settings

Additional information*Selection*

Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: Value 1 display parameter (→ 18)

"Electronic temp." submenu**Navigation**

Expert → Diagnostics → Min/max val. → Electronic temp.

**Minimum value****Navigation**

Expert → Diagnostics → Min/max val. → Electronic temp. → Minimum value

Description

Displays the lowest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 55)

Maximum value**Navigation**

Expert → Diagnostics → Min/max val. → Electronic temp. → Maximum value

Description


Displays the highest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 55)

"Medium temp." submenu**Navigation** Expert → Diagnostics → Min/max val. → Medium temp.

Minimum value

Navigation Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value**Description**

Displays the lowest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 55)


Maximum value

Navigation Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value**Description**

Displays the highest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 55)**"Carr. pipe temp." submenu****Navigation** Expert → Diagnostics → Min/max val. → Carr. pipe temp.

Minimum value

| | |
|-------------------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Carr. pipe temp. → Minimum value |
| Prerequisite |  Only available for: <ul style="list-style-type: none"> ■ Promass A ■ Promass F ■ Promass G ■ Promass H ■ Promass I ■ Promass O ■ Promass P ■ Promass Q ■ Promass S ■ Promass X |
| | For the following order code "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the lowest previously measured temperature value of the carrier pipe. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i> |
| |  The unit is taken from the Temperature unit parameter (→  55) |

Maximum value


| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Carr. pipe temp. → Maximum value |
| Prerequisite |  Only available for: <ul style="list-style-type: none"> ■ Promass A ■ Promass F ■ Promass G ■ Promass H ■ Promass I ■ Promass O ■ Promass P ■ Promass Q ■ Promass S ■ Promass X |
| | For the following order code "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the highest previously measured temperature value of the carrier pipe. |
| User interface | Signed floating-point number |

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ [55](#))

"Oscil. frequency" submenu**Navigation**

Expert → Diagnostics → Min/max val. → Oscil. frequency



Minimum value**Navigation**

Expert → Diagnostics → Min/max val. → Oscil. frequency → Minimum value

Description

Displays the lowest previously measured oscillation frequency.

User interface

Signed floating-point number

Maximum value**Navigation**

Expert → Diagnostics → Min/max val. → Oscil. frequency → Maximum value

Description


Displays the highest previously measured oscillation frequency.

User interface

Signed floating-point number

"Tors.oscil.freq." submenu**Navigation**

Expert → Diagnostics → Min/max val. → Tors.oscil.freq.



Minimum value


| | |
|-----------------------|---|
| Navigation | Expert → Diagnostics → Min/max val. → Tors. oscil. freq. → Minimum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the lowest previously measured torsion oscillation frequency. |
| User interface | Signed floating-point number |

Maximum value

| | |
|-----------------------|---|
| Navigation | Expert → Diagnostics → Min/max val. → Tors. oscil. freq. → Maximum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the highest previously measured torsion oscillation frequency. |
| User interface | Signed floating-point number |

"Oscil. amplitude" submenu

Navigation  Expert → Diagnostics → Min/max val. → Oscil. amplitude



Minimum value


| | |
|-----------------------|--|
| Navigation | Expert → Diagnostics → Min/max val. → Oscil. amplitude → Minimum value |
| Description | Displays the lowest previously measured oscillation amplitude. |
| User interface | Signed floating-point number |

Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Oscil. amplitude → Maximum value |
| Description | Displays the highest previously measured oscillation amplitude. |
| User interface | Signed floating-point number |

"Tor. osc. amp." submenu

Navigation   Expert → Diagnostics → Min/max val. → Tor. osc. amp.



Minimum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Tor. osc. amp. → Minimum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the lowest previously measured torsion oscillation amplitude. |
| User interface | Signed floating-point number |


Maximum value

| | |
|---------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Tor. osc. amp. → Maximum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the highest previously measured torsion oscillation amplitude. |

| | |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

"Oscil. damping" submenu

Navigation Expert → Diagnostics → Min/max val. → Oscil. damping



Minimum value

Navigation Expert → Diagnostics → Min/max val. → Oscil. damping → Minimum value

Description Displays the lowest previously measured oscillation damping.

User interface Signed floating-point number

Maximum value


Navigation Expert → Diagnostics → Min/max val. → Oscil. damping → Maximum value

Description Displays the highest previously measured oscillation damping.

User interface Signed floating-point number

"Tors.oscil.damp." submenu

Navigation Expert → Diagnostics → Min/max val. → Tors.oscil.damp.



Minimum value


| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Tors.oscil.damp. → Minimum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the lowest previously measured torsion oscillation damping. |
| User interface | Signed floating-point number |

Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Tors.oscil.damp. → Maximum value |
| Prerequisite |  Only available for Promass I. For the following order code: "Application package", option EB "Heartbeat Verification + Monitoring" |
| Description | Displays the highest previously measured torsion oscillation damping. |
| User interface | Signed floating-point number |

"Signal asymmetry" submenu

Navigation   Expert → Diagnostics → Min/max val. → Signal asymmetry



Minimum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Signal asymmetry → Minimum value |
| Description | Displays the lowest previously measured signal asymmetry. |
| User interface | Signed floating-point number |


Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Signal asymmetry → Maximum value |
| Description | Displays the highest previously measured signal asymmetry. |
| User interface | Signed floating-point number |


3.9.5 "Heartbeat" submenu

 For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device

Navigation   Expert → Diagnostics → Heartbeat

**3.9.6 "Simulation" submenu**

Navigation   Expert → Diagnostics → Simulation



Assign proc.var.**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var.

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Dynam. viscosity^{*}
- Kinematic visc.
- TempCompDynVisc^{*}
- TempCompKinVisc^{*}
- Concentration^{*}
- Target mass flow^{*}
- Carrier mass fl.^{*}

Factory setting

Off

Additional information*Description*

The simulation value of the process variable selected is defined in the **Value proc. var.** parameter (→ 178).

Value proc. var.**Navigation**

Expert → Diagnostics → Simulation → Value proc. var.

Prerequisite

One of the following options is selected in the **Assign proc.var.** parameter (→ 178):

- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Dynam. viscosity^{*}
- Kinematic visc.
- TempCompDynVisc^{*}
- TempCompKinVisc^{*}
- Concentration^{*}
- Target mass flow^{*}
- Carrier mass fl.^{*}

* Visibility depends on order options or device settings

| | |
|-------------------------------|--|
| Description | Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly. |
| User entry | Depends on the process variable selected |
| Factory setting | 0 |
| Additional information | <p><i>Entry</i></p>  The unit of the displayed measured value is taken from the System units submenu (→ 50). |

Sim. alarm



| | |
|-------------------------------|---|
| Navigation |  Expert → Diagnostics → Simulation → Sim. alarm |
| Description | Use this function to switch the device alarm on and off. |
| Selection | <ul style="list-style-type: none"> ▪ Off ▪ On |
| Factory setting | Off |
| Additional information | <p><i>Description</i></p> <p>The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.</p> |

Event category

| | |
|------------------------|---|
| Navigation |  Expert → Diagnostics → Simulation → Event category |
| Description | Use this function to select the category of the diagnostic events that are displayed for the simulation in the Sim. diag. event parameter (→ 179). |
| Selection | <ul style="list-style-type: none"> ▪ Sensor ▪ Electronics ▪ Configuration ▪ Process |
| Factory setting | Process |

Sim. diag. event

| | |
|--------------------|--|
| Navigation |  Expert → Diagnostics → Simulation → Sim. diag. event |
| Description | Use this function to select a diagnostic event for the simulation process that is activated. |

| | |
|-------------------------------|---|
| Selection | <ul style="list-style-type: none">■ Off■ Diagnostic event picklist (depends on the category selected) |
| Factory setting | Off |
| Additional information | <p><i>Description</i></p> <p> For the simulation, you can choose from the diagnostic events of the category selected in the Event category parameter (→ 179).</p> |

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

| | |
|-----------------------|-------|
| Mass | kg |
| Mass flow | kg/h |
| Volume | l |
| Volume flow | l/h |
| Corrected volume | Nl |
| Corrected volume flow | Nl/h |
| Density | kg/l |
| Reference density | kg/Nl |
| Temperature | °C |
| Pressure | bar a |

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

| Nominal diameter [mm] | [kg/h] |
|--------------------------|---------|
| 1 | 4 |
| 2 | 20 |
| 4 | 90 |
| 8 | 400 |
| 15 | 1300 |
| 15 FB | 3600 |
| 25 | 3600 |
| 25 FB | 9000 |
| 40 | 9000 |
| 40 FB | 14000 |
| 50 | 14000 |
| 50 FB | 36000 |
| 80 | 36000 |
| 100 | 60000 |
| 150 | 130 t/h |
| 250 | 360 t/h |
| 350 | 650 t/h |

4.1.3 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

| Nominal diameter [mm] | On-value for liquid [kg/h] |
|--------------------------|-------------------------------|
| 1 | 0.08 |
| 2 | 0.4 |
| 4 | 1.8 |
| 8 | 8 |
| 15 | 26 |
| 15 FB | 72 |
| 25 | 72 |
| 25 FB | 180 |
| 40 | 180 |
| 40 FB | 300 |
| 50 | 300 |
| 50 FB | 720 |
| 80 | 720 |
| 100 | 1200 |
| 150 | 2.6 t/h |
| 250 | 7.2 t/h |
| 350 | 13 t/h |

| Nominal diameter [mm] | Switch-on value for gas [kg/h] |
|--------------------------|-----------------------------------|
| 1 | 0.02 |
| 2 | 0.1 |
| 4 | 0.45 |
| 8 | 2 |
| 15 | 6.5 |
| 15 FB | 18 |
| 25 | 18 |
| 25 FB | 45 |
| 40 | 45 |
| 40 FB | 75 |
| 50 | 75 |
| 50 FB | 180 |
| 80 | 180 |
| 100 | 300 |
| 150 | 650 |
| 250 | 1.8 t/h |
| 350 | 3.25 t/h |

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

| | |
|-----------------------|-----------------------|
| Mass | lb |
| Mass flow | lb/min |
| Volume | gal (us) |
| Volume flow | gal/min (us) |
| Corrected volume | Sft ³ |
| Corrected volume flow | Sft ³ /min |
| Density | lb/ft ³ |
| Reference density | lb/Sft ³ |
| Temperature | °F |
| Pressure | psi a |

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

| Nominal diameter [in] | [lb/min] |
|--------------------------|----------|
| 1/24 | 0.15 |
| 1/12 | 0.75 |
| 1/8 | 3.3 |
| 3/8 | 15 |
| 1/2 | 50 |
| 1/2 FB | 130 |
| 1 | 130 |
| 1 FB | 330 |
| 1½ | 330 |
| 1½ FB | 550 |
| 2 | 550 |
| 2 FB | 1300 |
| 3 | 1300 |
| 4 | 2200 |
| 6 | 4800 |
| 10 | 13 000 |
| 14 | 23 500 |

4.2.3 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

| Nominal diameter [in] | On-value for liquid [lb/min] |
|--------------------------|---------------------------------|
| 1/24 | 0.003 |
| 1/12 | 0.015 |
| 1/8 | 0.066 |
| 3/8 | 0.3 |
| 1/2 | 1 |
| 1/2 FB | 2.6 |
| 1 | 2.6 |
| 1 FB | 6.6 |
| 1½ | 6.6 |
| 1½ FB | 11 |
| 2 | 11 |
| 2 FB | 26 |
| 3 | 26 |
| 4 | 44 |
| 6 | 95 |
| 10 | 260 |
| 14 | 470 |

| Nominal diameter [in] | Switch-on value for gas [lb/min] |
|--------------------------|-------------------------------------|
| 1/24 | 0.001 |
| 1/12 | 0.004 |
| 1/8 | 0.016 |
| 3/8 | 0.075 |
| 1/2 | 0.25 |
| 1/2 FB | 0.65 |
| 1 | 0.65 |
| 1 FB | 1.65 |
| 1½ | 1.65 |
| 1½ FB | 2.75 |
| 2 | 2.75 |
| 2 FB | 6.5 |
| 3 | 6.5 |
| 4 | 11 |
| 6 | 23.75 |
| 10 | 65 |
| 14 | 117.5 |

5 Explanation of abbreviated units

5.1 SI units

| Process variable | Units | Explanation |
|------------------|--|---|
| Density | g/cm ³ , g/m ³ | Gram/volume unit |
| | kg/dm ³ , kg/l, kg/m ³ | Kilogram/volume unit |
| | SD4°C, SD15°C, SD20°C | Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F). |
| | SG4°C, SG15°C, SG20°C | Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F). |
| Pressure | Pa a, kPa a, MPa a | Pascal, kilopascal, megapascal (absolute) |
| | bar | Bar |
| | Pa g, kPa g, MPa g | Pascal, kilopascal, megapascal (relative/gauge) |
| | bar g | Bar (relative/gauge) |
| Mass | g, kg, t | Gram, kilogram, metric ton |
| Mass flow | g/s, g/min, g/h, g/d | Gram/time unit |
| | kg/s, kg/min, kg/h, kg/d | Kilogram/time unit |
| | t/s, t/min, t/h, t/d | Metric ton/time unit |
| Ref.density | kg/Nm ³ , kg/Nl, g/Scm ³ , kg/Sm ³ | Kilogram, gram/standard volume unit |
| Corrected volume | Nl, Nm ³ , Sm ³ | Normal liter, normal cubic meter, standard cubic meter |
| Correct.vol.flow | Nl/s, Nl/min, Nl/h, Nl/d | Normal liter/time unit |
| | Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d | Normal cubic meter/time unit |
| | Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d | Standard cubic meter/time unit |
| Temperature | °C, K | Celsius, Kelvin |
| Volume | cm ³ , dm ³ , m ³ | Cubic centimeter, cubic decimeter, cubic meter |
| | ml, l, hl, Ml Mega | Milliliter, liter, hectoliter, megaliter |
| Volume flow | cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d | Cubic centimeter/time unit |
| | dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d | Cubic decimeter/time unit |
| | m ³ /s, m ³ /min, m ³ /h, m ³ /d | Cubic meter/time unit |
| | ml/s, ml/min, ml/h, ml/d | Milliliter/time unit |
| | l/s, l/min, l/h, l/d | Liter/time unit |
| | hl/s, hl/min, hl/h, hl/d | Hectoliter/time unit |
| | Ml/s, Ml/min, Ml/h, Ml/d | Megaliter/time unit |
| Time | s, m, h, d, y | Second, minute, hour, day, year |

5.2 US units

| Process variable | Units | Explanation |
|------------------|--|--------------------------------|
| Density | lb/ft ³ , lb/gal (us) | Pound/cubic foot, pound/gallon |
| | lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank) | Pound/volume unit |

| Process variable | Units | Explanation |
|------------------|--|---|
| Pressure | psi a | Pounds per square inch (absolute) |
| | psi g | Pounds per square inch (gauge) |
| Mass | oz, lb, STon | Ounce, pound, standard ton |
| Mass flow | oz/s, oz/min, oz/h, oz/d | Ounce/time unit |
| | lb/s, lb/min, lb/h, lb/d | Pound/time unit |
| | STon/s, STon/min, STon/h, STon/d | Standard ton/time unit |
| Ref.density | lb/Sft ³ | Weight unit/standard volume unit |
| Corrected volume | Sft ³ , Sgal (us), Sbbl (us;liq.) | Standard cubic foot, standard gallon, standard barrel |
| Correct.vol.flow | Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d | Standard cubic foot/time unit |
| | Sgal/s (us), Sgal/min (us), Sgal/h (us), Sgal/d (us) | Standard gallon/time unit |
| | Sbbl/s (us;liq.), Sbbl/min (us;liq.), Sbbl/h (us;liq.), Sbbl/d (us;liq.) | Barrel/time unit (normal liquids) |
| Temperature | °F, °R | Fahrenheit, Rankine |
| Volume | af | Acre foot |
| | ft ³ | Cubic foot |
| | fl oz (us), gal (us), kgal (us), Mgal (us) | Fluid ounce, gallon, kilogallon, million gallon |
| | bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank) | Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks) |
| Volume flow | af/s, af/min, af/h, af/d | Acre foot/time unit |
| | ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d | Cubic foot/time unit |
| | fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us) | Fluid ounce/time unit |
| | gal/s (us), gal/min (us), gal/h (us), gal/d (us) | Gallon/time unit |
| | kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us) | Kilogallon/time unit |
| | Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us) | Million gallon/time unit |
| | bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.) | Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl |
| | bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer) | Barrel /time unit (beer) Beer: 31.0 gal/bbl |
| | bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil) | Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl |
| | bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank) | Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl |
| Time | s, m, h, d, y | Second, minute, hour, day, year |
| | am, pm | Ante meridiem (before midday), post meridiem (after midday) |

5.3 Imperial units

| Process variable | Units | Explanation |
|------------------|---|---|
| Density | lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil) | Pound/volume unit |
| Corrected volume | Sgal (imp) | Standard gallon |
| Correct.vol.flow | Sgal/s (imp), Sgal/min (imp), Sgal/h (imp), Sgal/d (imp) | Standard gallon/time unit |
| Volume | gal (imp), Mgal (imp) bbl (imp;beer), bbl (imp;oil) | Gallon, mega gallon Barrel (beer), barrel (petrochemicals) |
| Volume flow | gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp) Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp) bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer) | Gallon/time unit Mega gallon/time unit Barrel /time unit (beer) Beer: 36.0 gal/bbl |
| | bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil) | Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl |
| Time | s, m, h, d, y am, pm | Second, minute, hour, day, year Ante meridiem (before midday), post meridiem (after midday) |

Index

0 ... 9

- 0% bargraph value 1 (Parameter) 19
- 0% bargraph value 3 (Parameter) 22
- 100% bargraph value 1 (Parameter) 20
- 100% bargraph value 3 (Parameter) 22

A

- Access status display (Parameter) 13, 27
- Access status tooling (Parameter) 13
- Activate SW option (Parameter) 39
- Actual diagnostics (Parameter) 157
- Address mode (Parameter) 82
- Administration (Submenu) 36
- Alarm delay (Parameter) 28
- Alarm hysteresis (Parameter) 106, 151
- Alarm summary (Parameter) 88, 103, 116, 124, 137,
- Alert key (Parameter) 87, 102, 115, 123, 135, 148
- Analog input 1 to n (Submenu) 98
- Analog inputs (Submenu) 98
- Analog output 1 to n (Submenu) 119
- Analog outputs (Submenu) 119
- Application (Submenu) 141
- Assign behavior of diagnostic no. 046 (Parameter) 30
- Assign behavior of diagnostic no. 140 (Parameter) 30
- Assign behavior of diagnostic no. 144 (Parameter) 31
- Assign behavior of diagnostic no. 192 (Parameter) 34
- Assign behavior of diagnostic no. 274 (Parameter) 34
- Assign behavior of diagnostic no. 392 (Parameter) 35
- Assign behavior of diagnostic no. 592 (Parameter) 35
- Assign behavior of diagnostic no. 832 (Parameter) 31
- Assign behavior of diagnostic no. 833 (Parameter) 32
- Assign behavior of diagnostic no. 834 (Parameter) 32
- Assign behavior of diagnostic no. 835 (Parameter) 32
- Assign behavior of diagnostic no. 912 (Parameter) 33
- Assign behavior of diagnostic no. 913 (Parameter) 33
- Assign behavior of diagnostic no. 944 (Parameter) 33
- Assign behavior of diagnostic no. 948 (Parameter) 34
- Assign behavior of diagnostic no. 992 (Parameter) 35
- Assign process variable (Parameter) 60, 64, 142
- Assign simulation process variable (Parameter) 178

B

- Backlight (Parameter) 27
- Base current (Parameter) 84
- Batch ID (Parameter) 104, 117, 125, 137, 150
- Batch operation (Parameter) 104, 117, 125, 137, 150
- Batch phase (Parameter) 104, 117, 125, 138, 151
- Batch Recipe Unit Procedure (Parameter) 104, 118, 125, 138, 151
- Baudrate (Parameter) 84

C

- C0 to 5 (Parameter) 80
- Calculated values (Submenu) 69
- Calibration (Submenu) 79

- Calibration factor (Parameter) 80
- Carrier corrected volume flow (Parameter) 48
- Carrier mass flow (Parameter) 47
- Carrier pipe temperature (Submenu) 170
- Carrier volume flow (Parameter) 48
- Channel (Parameter) 98, 112
- Communication (Submenu) 81
- Concentration (Parameter) 46
- Concentration (Submenu) 156
- Condensed status diagnostic (Parameter) 94
- Confirm access code (Parameter) 37
- Contrast display (Parameter) 27
- Control Totalizer 1 to n (Parameter) 144
- Corrected volume flow (Parameter) 43
- Corrected volume flow calculation (Parameter) 70
- Corrected volume flow calculation (Submenu) 70
- Corrected volume flow factor (Parameter) 78
- Corrected volume flow offset (Parameter) 77
- Corrected volume flow unit (Parameter) 53
- Corrected volume unit (Parameter) 54

D

- Date/time format (Parameter) 57
- Decimal places 1 (Parameter) 20
- Decimal places 2 (Parameter) 21
- Decimal places 3 (Parameter) 23
- Decimal places 4 (Parameter) 24
- Default gateway (Parameter) 97
- Define access code (Parameter) 36, 38
- Define access code (Wizard) 36
- Density (Parameter) 44
- Density damping (Parameter) 58
- Density factor (Parameter) 77
- Density offset (Parameter) 77
- Density unit (Parameter) 54
- Descriptor (Parameter) 92
- Device address (Parameter) 82
- Device certification (Parameter) 92
- Device ID (Parameter) 90
- Device information (Submenu) 164
- Device install date (Parameter) 93
- Device message (Parameter) 92
- Device name (Parameter) 166
- Device reset (Parameter) 39
- Device tag (Parameter) 86, 165
- Diagnostic behavior (Submenu) 29
- Diagnostic event category (Parameter) 179
- Diagnostic handling (Submenu) 28
- Diagnostic list (Submenu) 159
- Diagnostics (Parameter) 90
- Diagnostics (Submenu) 156
- Diagnostics 1 (Parameter) 159
- Diagnostics 2 (Parameter) 160
- Diagnostics 3 (Parameter) 160
- Diagnostics 4 (Parameter) 161
- Diagnostics 5 (Parameter) 162

| | | | |
|---|--------|---|---------|
| Diagnostics mask (Parameter) | 91 | Totalizer 1 to n | 150 |
| Direct access | | Batch phase | |
| 0% bargraph value 1 | 19 | Analog input 1 to n | 104 |
| 0% bargraph value 3 | 22 | Analog output 1 to n | 125 |
| 100% bargraph value 1 | 20 | Discrete input 1 to n | 117 |
| 100% bargraph value 3 | 22 | Discrete output 1 to n | 138 |
| Access status display | 13, 27 | Totalizer 1 to n | 151 |
| Access status tooling | 13 | Batch Recipe Unit Procedure | |
| Activate SW option | 39 | Analog input 1 to n | 104 |
| Actual diagnostics | 157 | Analog output 1 to n | 125 |
| Address mode | 82 | Discrete input 1 to n | 118 |
| Alarm delay | 28 | Discrete output 1 to n | 138 |
| Alarm hysteresis | | Totalizer 1 to n | 151 |
| Analog input 1 to n | 106 | Baudrate | 84 |
| Totalizer 1 to n | 151 | C0 to 5 | 80 |
| Alarm summary | 88 | Calibration factor | 80 |
| Analog input 1 to n | 103 | Carrier corrected volume flow | 48 |
| Analog output 1 to n | 124 | Carrier mass flow | 47 |
| Discrete input 1 to n | 116 | Carrier volume flow | 48 |
| Discrete output 1 to n | 137 | Channel | |
| Totalizer 1 to n | 150 | Analog input 1 to n | 98 |
| Alert key | 87 | Discrete input 1 to n | 112 |
| Analog input 1 to n | 102 | Concentration | 46 |
| Analog output 1 to n | 123 | Condensed status diagnostic | 94 |
| Discrete input 1 to n | 115 | Contrast display | 27 |
| Discrete output 1 to n | 135 | Control Totalizer 1 to n | 144 |
| Totalizer 1 to n | 148 | Corrected volume flow | 43 |
| Assign behavior of diagnostic no. 046 | 30 | Corrected volume flow calculation | 70 |
| Assign behavior of diagnostic no. 140 | 30 | Corrected volume flow factor | 78 |
| Assign behavior of diagnostic no. 144 | 31 | Corrected volume flow offset | 77 |
| Assign behavior of diagnostic no. 192 | 34 | Corrected volume flow unit | 53 |
| Assign behavior of diagnostic no. 274 | 34 | Corrected volume unit | 54 |
| Assign behavior of diagnostic no. 392 | 35 | Date/time format | 57 |
| Assign behavior of diagnostic no. 592 | 35 | Decimal places 1 | 20 |
| Assign behavior of diagnostic no. 832 | 31 | Decimal places 2 | 21 |
| Assign behavior of diagnostic no. 833 | 32 | Decimal places 3 | 23 |
| Assign behavior of diagnostic no. 834 | 32 | Decimal places 4 | 24 |
| Assign behavior of diagnostic no. 835 | 32 | Default gateway | 97 |
| Assign behavior of diagnostic no. 912 | 33 | Define access code | 38 |
| Assign behavior of diagnostic no. 913 | 33 | Density | 44 |
| Assign behavior of diagnostic no. 944 | 33 | Density damping | 58 |
| Assign behavior of diagnostic no. 948 | 34 | Density factor | 77 |
| Assign behavior of diagnostic no. 992 | 35 | Density offset | 77 |
| Assign process variable | 60, 64 | Density unit | 54 |
| Totalizer 1 to n | 142 | Descriptor | 92 |
| Assign simulation process variable | 178 | Device address | 82 |
| Backlight | 27 | Device certification | 92 |
| Base current | 84 | Device ID | 90 |
| Batch ID | | Device install date | 93 |
| Analog input 1 to n | 104 | Device message | 92 |
| Analog output 1 to n | 125 | Device name | 166 |
| Discrete input 1 to n | 117 | Device reset | 39 |
| Discrete output 1 to n | 137 | Device tag | 86, 165 |
| Totalizer 1 to n | 150 | Diagnostic event category | 179 |
| Batch operation | | Diagnostics | 90 |
| Analog input 1 to n | 104 | Diagnostics 1 | 159 |
| Analog output 1 to n | 125 | Diagnostics 2 | 160 |
| Discrete input 1 to n | 117 | Diagnostics 3 | 160 |
| Discrete output 1 to n | 137 | Diagnostics 4 | 161 |

| | | | |
|--------------------------------------|-----|--|--------|
| Diagnostics 5 | 162 | Totalizer 1 to n | 152 |
| Diagnostics mask | 91 | High value partial filled pipe detection | 64 |
| Direct access | 11 | Ident number selector | 83, 93 |
| Display damping | 25 | Increase close | |
| Display interval | 24 | Analog output 1 to n | 130 |
| Display language | 15 | Input channel | |
| Dynamic viscosity | 45 | Analog output 1 to n | 127 |
| ENP version | 167 | Discrete output 1 to n | 139 |
| Enter access code | 14 | Installation direction | 73 |
| Extended order code 1 | 166 | Invert | |
| Extended order code 2 | 167 | Discrete input 1 to n | 113 |
| Extended order code 3 | 167 | Discrete output 1 to n | 132 |
| External pressure | 69 | IP address | 96 |
| External reference density | 71 | Kinematic viscosity | 45 |
| Factory reset | 92 | Limit value measuring tube damping | 81 |
| Fail safe time | | Lin type | |
| Analog output 1 to n | 120 | Analog input 1 to n | 106 |
| Discrete output 1 to n | 132 | Linear expansion coefficient | 72 |
| Fail safe type | | Lo alarm state | |
| Analog input 1 to n | 99 | Analog input 1 to n | 110 |
| Analog output 1 to n | 121 | Totalizer 1 to n | 155 |
| Discrete input 1 to n | 113 | Lo alarm value | |
| Discrete output 1 to n | 133 | Analog input 1 to n | 109 |
| Fail safe value | | Totalizer 1 to n | 155 |
| Analog input 1 to n | 100 | Lo Lim | |
| Analog output 1 to n | 121 | Analog input 1 to n | 108 |
| Discrete input 1 to n | 113 | Totalizer 1 to n | 153 |
| Discrete output 1 to n | 133 | Lo Lo alarm state | |
| Failure mode | | Analog input 1 to n | 110 |
| Totalizer 1 to n | 146 | Totalizer 1 to n | 155 |
| Feature enabled | 94 | Lo Lo alarm value | |
| Feature supported | 94 | Analog input 1 to n | 110 |
| Filter options | 163 | Totalizer 1 to n | 155 |
| Firmware version | 165 | Lo Lo Lim | |
| Fixed reference density | 71 | Analog input 1 to n | 108 |
| Flow damping | 58 | Totalizer 1 to n | 153 |
| Flow override | 59 | Locking status | 12 |
| Format display | 16 | Low value partial filled pipe detection | 64 |
| Hardware lock | 93 | MAC address | 96 |
| Hardware revision | 89 | Manufacturer ID | 90 |
| Header | 25 | Mass flow | 43 |
| Header text | 26 | Mass flow factor | 76 |
| Hi alarm state | | Mass flow offset | 75 |
| Analog input 1 to n | 109 | Mass flow unit | 50 |
| Totalizer 1 to n | 154 | Mass unit | 51 |
| Hi alarm value | | Master availability | 85 |
| Analog input 1 to n | 109 | Maximum damping partial filled pipe det. | 65 |
| Totalizer 1 to n | 154 | Maximum value 169, 170, 171, 172, 173, 174, | |
| Hi Hi alarm state | | 175, 176, 177 | 177 |
| Analog input 1 to n | 109 | Minimum value 169, 170, 171, 172, 173, 174, | |
| Totalizer 1 to n | 154 | 175, 176, 177 | 176 |
| Hi Hi alarm value | | Mode block actual | 88 |
| Analog input 1 to n | 108 | Analog input 1 to n | 102 |
| Totalizer 1 to n | 154 | Analog output 1 to n | 123 |
| Hi Hi Lim | | Discrete input 1 to n | 116 |
| Analog input 1 to n | 107 | Discrete output 1 to n | 136 |
| Totalizer 1 to n | 152 | Totalizer 1 to n | 149 |
| Hi Lim | | Mode block normal | 88 |
| Analog input 1 to n | 107 | Analog input 1 to n | 103 |

| | |
|--|----------|
| Analog output 1 to n | 124 |
| Discrete input 1 to n | 116 |
| Discrete output 1 to n | 136 |
| Totalizer 1 to n | 149 |
| Mode block permitted | 88 |
| Analog input 1 to n | 103 |
| Analog output 1 to n | 124 |
| Discrete input 1 to n | 116 |
| Discrete output 1 to n | 136 |
| Totalizer 1 to n | 149 |
| Nominal diameter | 80 |
| Off value low flow cutoff | 61 |
| On value low flow cutoff | 61 |
| Operating time | 158 |
| Operating time from restart | 158 |
| Order code | 166 |
| Out decimal point | |
| Analog input 1 to n | 106 |
| Out scale lower range | |
| Analog input 1 to n | 105 |
| Analog output 1 to n | 131 |
| Out scale upper range | |
| Analog input 1 to n | 105 |
| Analog output 1 to n | 130 |
| Out status | |
| Analog input 1 to n | 100, 101 |
| Analog output 1 to n | 122 |
| Discrete input 1 to n | 114 |
| Discrete output 1 to n | 134 |
| Out unit | |
| Analog input 1 to n | 106 |
| Out unit text | |
| Analog input 1 to n | 111 |
| Out value | |
| Analog input 1 to n | 100 |
| Analog output 1 to n | 121 |
| Discrete input 1 to n | 114 |
| Discrete output 1 to n | 134 |
| Output channel | |
| Analog output 1 to n | 128 |
| Discrete output 1 to n | 139 |
| Position status | |
| Analog output 1 to n | 129 |
| Position value | |
| Analog output 1 to n | 128 |
| Preset value 1 to n | 145 |
| Pressure compensation | 68 |
| Pressure shock suppression | 62 |
| Pressure unit | 56 |
| Pressure value | 44, 69 |
| Previous diagnostics | 157 |
| PROFIBUS ident number | 84 |
| Profile version | 84 |
| Progress | 74 |
| PV filter time | |
| Analog input 1 to n | 99 |
| PV scale lower range | |
| Analog input 1 to n | 105 |
| Analog output 1 to n | 126 |
| PV scale upper range | |
| Analog input 1 to n | 105 |
| Analog output 1 to n | 126 |
| RCAS in status | |
| Analog output 1 to n | 127 |
| Discrete output 1 to n | 139 |
| RCAS in value | |
| Analog output 1 to n | 127 |
| Discrete output 1 to n | 139 |
| RCAS out status | |
| Analog output 1 to n | 128 |
| Discrete output 1 to n | 140 |
| RCAS out value | |
| Analog output 1 to n | 128 |
| Discrete output 1 to n | 140 |
| Readback status | |
| Analog output 1 to n | 127 |
| Discrete output 1 to n | 138 |
| Readback value | |
| Analog output 1 to n | 126 |
| Discrete output 1 to n | 138 |
| Reference density | 44 |
| Reference density factor | 78 |
| Reference density offset | 78 |
| Reference density unit | 55 |
| Reference sound velocity | 67 |
| Reference temperature | 71 |
| Reset access code | 38 |
| Reset min/max values | 168 |
| Response time part. filled pipe detect | 65 |
| Select gas type | 67 |
| Select medium | 66 |
| Separator | 26 |
| Serial number | 90, 165 |
| Set point status | |
| Analog output 1 to n | 120 |
| Discrete output 1 to n | 132 |
| Set point value | |
| Analog output 1 to n | 120 |
| Discrete output 1 to n | 132 |
| Setpoint deviation | |
| Analog output 1 to n | 129 |
| Simulate enabled | |
| Analog input 1 to n | 110 |
| Analog output 1 to n | 129 |
| Discrete input 1 to n | 118 |
| Discrete output 1 to n | 140 |
| Simulate status | |
| Analog input 1 to n | 111 |
| Analog output 1 to n | 130 |
| Discrete input 1 to n | 119 |
| Discrete output 1 to n | 141 |
| Simulate value | |
| Analog input 1 to n | 111 |
| Analog output 1 to n | 129 |
| Discrete input 1 to n | 118 |
| Discrete output 1 to n | 141 |
| Simulation device alarm | 179 |
| Simulation diagnostic event | 179 |

| | |
|---|------------------------------|
| Software option overview | 40 |
| Software revision | 89 |
| Square expansion coefficient | 72 |
| Static revision | 87 |
| Analog input 1 to n | 101 |
| Analog output 1 to n | 122 |
| Discrete input 1 to n | 115 |
| Discrete output 1 to n | 135 |
| Totalizer 1 to n | 148 |
| Status PROFIBUS Master Config | 83 |
| Strategy | 87 |
| Analog input 1 to n | 101 |
| Analog output 1 to n | 123 |
| Discrete input 1 to n | 115 |
| Discrete output 1 to n | 135 |
| Totalizer 1 to n | 148 |
| Subnet mask | 97 |
| Tag description | |
| Analog input 1 to n | 101 |
| Analog output 1 to n | 122 |
| Discrete input 1 to n | 114 |
| Discrete output 1 to n | 134 |
| Totalizer 1 to n | 148 |
| Target corrected volume flow | 47 |
| Target mass flow | 47 |
| Target mode | 87 |
| Analog input 1 to n | 102 |
| Analog output 1 to n | 123 |
| Discrete input 1 to n | 115 |
| Discrete output 1 to n | 135 |
| Totalizer 1 to n | 149 |
| Target volume flow | 48 |
| Temp. compensated dynamic viscosity | 46 |
| Temp. compensated kinematic viscosity | 46 |
| Temperature | 44 |
| Temperature coefficient sound velocity | 68 |
| Temperature damping | 59 |
| Temperature factor | 79 |
| Temperature offset | 79 |
| Temperature unit | 55 |
| Timestamp | 157, 158, 159, 160, 161, 162 |
| Totalizer operation mode | |
| Totalizer 1 to n | 145 |
| Totalizer status (Hex) 1 to n | 49, 147 |
| Totalizer status 1 to n | 49, 147 |
| Totalizer value 1 to n | 49, 147 |
| Unit totalizer | |
| Totalizer 1 to n | 143 |
| Value 1 display | 18 |
| Value 2 display | 20 |
| Value 3 display | 21 |
| Value 4 display | 23 |
| Value process variable | 178 |
| Volume flow | 43 |
| Volume flow factor | 76 |
| Volume flow offset | 76 |
| Volume flow unit | 51 |
| Volume unit | 53 |
| Web server functionality | 97 |
| Web server language | 95 |
| Zero point | 80 |
| Zero point adjustment control | 74 |
| Direct access (Parameter) | 11 |
| Discrete input 1 to n (Submenu) | 112 |
| Discrete inputs (Submenu) | 112 |
| Discrete output 1 to n (Submenu) | 131 |
| Discrete outputs (Submenu) | 131 |
| Display (Submenu) | 14 |
| Display damping (Parameter) | 25 |
| Display interval (Parameter) | 24 |
| Display language (Parameter) | 15 |
| Document | |
| Explanation of the structure of a parameter description | 6 |
| Function | 4 |
| Structure | 4 |
| Symbols used | 6 |
| Target group | 4 |
| Using the document | 4 |
| Document function | 4 |
| Dynamic viscosity (Parameter) | 45 |
| E | |
| Electronic temperature (Submenu) | 169 |
| ENP version (Parameter) | 167 |
| Enter access code (Parameter) | 14 |
| Event list (Submenu) | 163 |
| Event logbook (Submenu) | 163 |
| Extended order code 1 (Parameter) | 166 |
| Extended order code 2 (Parameter) | 167 |
| Extended order code 3 (Parameter) | 167 |
| External compensation (Submenu) | 68 |
| External pressure (Parameter) | 69 |
| External reference density (Parameter) | 71 |
| F | |
| Factory reset (Parameter) | 92 |
| Factory settings | 181 |
| SI units | 181 |
| US units | 183 |
| Fail safe time (Parameter) | 120, 132 |
| Fail safe type (Parameter) | 99, 113, 121, 133 |
| Fail safe value (Parameter) | 100, 113, 121, 133 |
| Failure mode (Parameter) | 146 |
| Feature enabled (Parameter) | 94 |
| Feature supported (Parameter) | 94 |
| Filter options (Parameter) | 163 |
| Firmware version (Parameter) | 165 |
| Fixed reference density (Parameter) | 71 |
| Flow damping (Parameter) | 58 |
| Flow override (Parameter) | 59 |
| Format display (Parameter) | 16 |
| Function | |
| see Parameter | |
| H | |
| Hardware lock (Parameter) | 93 |
| Hardware revision (Parameter) | 89 |

| | | | |
|---|--|---|-------------------------|
| Header (Parameter) | 25 | Mode block permitted (Parameter) | 88, 103, 116, |
| Header text (Parameter) | 26 | 124, | 136, |
| Heartbeat (Submenu) | 177 | | 149 |
| Hi alarm state (Parameter) | 109, 154 | N | |
| Hi alarm value (Parameter) | 109, 154 | Nominal diameter (Parameter) | 80 |
| Hi Hi alarm state (Parameter) | 109, 154 | | |
| Hi Hi alarm value (Parameter) | 108, 154 | O | |
| Hi Hi Lim (Parameter) | 107, 152 | Off value low flow cutoff (Parameter) | 61 |
| Hi Lim (Parameter) | 107, 152 | On value low flow cutoff (Parameter) | 61 |
| High value partial filled pipe detection (Parameter) | 64 | Operating time (Parameter) | 158 |
| I | | Operating time from restart (Parameter) | 158 |
| Ident number selector (Parameter) | 83, 93 | Order code (Parameter) | 166 |
| Increase close (Parameter) | 130 | Oscillation amplitude (Submenu) | 173 |
| Input channel (Parameter) | 127, 139 | Oscillation damping (Submenu) | 175 |
| Installation direction (Parameter) | 73 | Oscillation frequency (Submenu) | 172 |
| Invert (Parameter) | 113, 132 | Out decimal point (Parameter) | 106 |
| IP address (Parameter) | 96 | Out scale lower range (Parameter) | 105, 131 |
| K | | Out scale upper range (Parameter) | 105, 130 |
| Kinematic viscosity (Parameter) | 45 | Out status (Parameter) | 100, 101, 114, 122, 134 |
| L | | Out unit (Parameter) | 106 |
| Limit value measuring tube damping (Parameter) | 81 | Out unit text (Parameter) | 111 |
| Lin type (Parameter) | 106 | Out value (Parameter) | 100, 114, 121, 134 |
| Linear expansion coefficient (Parameter) | 72 | Output channel (Parameter) | 128, 139 |
| Lo alarm state (Parameter) | 110, 155 | | |
| Lo alarm value (Parameter) | 109, 155 | P | |
| Lo Lim (Parameter) | 108, 153 | Parameter | |
| Lo Lo alarm state (Parameter) | 110, 155 | Structure of a parameter description | 6 |
| Lo Lo alarm value (Parameter) | 110, 155 | Partially filled pipe detection (Submenu) | 63 |
| Lo Lo Lim (Parameter) | 108, 153 | Physical block (Submenu) | 85 |
| Locking status (Parameter) | 12 | Position status (Parameter) | 129 |
| Low flow cut off (Submenu) | 60 | Position value (Parameter) | 128 |
| Low value partial filled pipe detection (Parameter) | 64 | Preset value 1 to n (Parameter) | 145 |
| M | | Pressure compensation (Parameter) | 68 |
| MAC address (Parameter) | 96 | Pressure shock suppression (Parameter) | 62 |
| Manufacturer ID (Parameter) | 90 | Pressure unit (Parameter) | 56 |
| Mass flow (Parameter) | 43 | Pressure value (Parameter) | 44, 69 |
| Mass flow factor (Parameter) | 76 | Previous diagnostics (Parameter) | 157 |
| Mass flow offset (Parameter) | 75 | Process parameters (Submenu) | 57 |
| Mass flow unit (Parameter) | 50 | Process variable adjustment (Submenu) | 75 |
| Mass unit (Parameter) | 51 | Process variables (Submenu) | 42 |
| Master availability (Parameter) | 85 | PROFIBUS DP configuration (Submenu) | 82 |
| Maximum damping partial filled pipe det. (Parameter) | 65 | PROFIBUS DP info (Submenu) | 83 |
| Maximum value (Parameter) | 169, 170, 171, 172, 173, 174, 175, 176, 177 | PROFIBUS ident number (Parameter) | 84 |
| Measured values (Submenu) | 42 | Profile version (Parameter) | 84 |
| Measurement mode (Submenu) | 66 | Progress (Parameter) | 74 |
| Medium temperature (Submenu) | 170 | PV filter time (Parameter) | 99 |
| Min/max values (Submenu) | 168 | PV scale lower range (Parameter) | 105, 126 |
| Minimum value (Parameter) | 169, 170, 171, 172, 173, 174, 175, 176, 176 | PV scale upper range (Parameter) | 105, 126 |
| Mode block actual (Parameter) | 88, 102, 116, 123, 136, 149 | | |
| Mode block normal (Parameter) | 88, 103, 116, 124, 136, 149 | R | |
| | | RCAS in status (Parameter) | 127, 139 |
| | | RCAS in value (Parameter) | 127, 139 |
| | | RCAS out status (Parameter) | 128, 140 |
| | | RCAS out value (Parameter) | 128, 140 |
| | | Readback status (Parameter) | 127, 138 |
| | | Readback value (Parameter) | 126, 138 |
| | | Reference density (Parameter) | 44 |
| | | Reference density factor (Parameter) | 78 |
| | | Reference density offset (Parameter) | 78 |
| | | Reference density unit (Parameter) | 55 |

| | |
|---|-----|
| Reference sound velocity (Parameter) | 67 |
| Reference temperature (Parameter) | 71 |
| Reset access code (Parameter) | 38 |
| Reset access code (Submenu) | 37 |
| Reset min/max values (Parameter) | 168 |
| Response time part. filled pipe detect. (Parameter) | 65 |

S

| | |
|---|-----------------------------|
| Select gas type (Parameter) | 67 |
| Select medium (Parameter) | 66 |
| Sensor (Submenu) | 41 |
| Sensor adjustment (Submenu) | 73 |
| Separator (Parameter) | 26 |
| Serial number (Parameter) | 90, 165 |
| Set point status (Parameter) | 120, 132 |
| Set point value (Parameter) | 120, 132 |
| Setpoint deviation (Parameter) | 129 |
| Signal asymmetry (Submenu) | 176 |
| Simulate enabled (Parameter) | 110, 118, 129, 140 |
| Simulate status (Parameter) | 111, 119, 130, 141 |
| Simulate value (Parameter) | 111, 118, 129, 141 |
| Simulation (Submenu) | 177 |
| Simulation device alarm (Parameter) | 179 |
| Simulation diagnostic event (Parameter) | 179 |
| Software option overview (Parameter) | 40 |
| Software revision (Parameter) | 89 |
| Square expansion coefficient (Parameter) | 72 |
| Static revision (Parameter) | 87, 101, 115, 122, 135, 148 |
| Status PROFIBUS Master Config (Parameter) | 83 |
| Strategy (Parameter) | 87, 101, 115, 123, 135, 148 |
| Submenu | |
| Administration | 36 |
| Analog input 1 to n | 98 |
| Analog inputs | 98 |
| Analog output 1 to n | 119 |
| Analog outputs | 119 |
| Application | 141 |
| Calculated values | 69 |
| Calibration | 79 |
| Carrier pipe temperature | 170 |
| Communication | 81 |
| Concentration | 156 |
| Corrected volume flow calculation | 70 |
| Device information | 164 |
| Diagnostic behavior | 29 |
| Diagnostic handling | 28 |
| Diagnostic list | 159 |
| Diagnostics | 156 |
| Discrete input 1 to n | 112 |
| Discrete inputs | 112 |
| Discrete output 1 to n | 131 |
| Discrete outputs | 131 |
| Display | 14 |
| Electronic temperature | 169 |
| Event list | 163 |
| Event logbook | 163 |
| External compensation | 68 |
| Heartbeat | 177 |
| Low flow cut off | 60 |

| | |
|---|-----|
| Measured values | 42 |
| Measurement mode | 66 |
| Medium temperature | 170 |
| Min/max values | 168 |
| Oscillation amplitude | 173 |
| Oscillation damping | 175 |
| Oscillation frequency | 172 |
| Partially filled pipe detection | 63 |
| Physical block | 85 |
| Process parameters | 57 |
| Process variable adjustment | 75 |
| Process variables | 42 |
| PROFIBUS DP configuration | 82 |
| PROFIBUS DP info | 83 |
| Reset access code | 37 |
| Sensor | 41 |
| Sensor adjustment | 73 |
| Signal asymmetry | 176 |
| Simulation | 177 |
| Supervision | 81 |
| System | 14 |
| System units | 50 |
| Torsion oscillation amplitude | 174 |
| Torsion oscillation damping | 175 |
| Torsion oscillation frequency | 172 |
| Totalizer | 48 |
| Totalizer 1 to n | 142 |
| Viscosity | 156 |
| Web server | 95 |
| Zero point adjustment | 73 |

| | |
|-----------------------------------|----|
| Subnet mask (Parameter) | 97 |
| Supervision (Submenu) | 81 |
| System (Submenu) | 14 |
| System units (Submenu) | 50 |

T

| | |
|--|------------------------------|
| Tag description (Parameter) | 101, 114, 122, 134, 148 |
| Target corrected volume flow (Parameter) | 47 |
| Target group | 4 |
| Target mass flow (Parameter) | 47 |
| Target mode (Parameter) | 87, 102, 115, 123, 135, 149 |
| Target volume flow (Parameter) | 48 |
| Temp. compensated dynamic viscosity (Parameter) | 46 |
| Temp. compensated kinematic viscosity (Parameter) | 46 |
| Temperature (Parameter) | 44 |
| Temperature coefficient sound velocity (Parameter) | 68 |
| Temperature damping (Parameter) | 59 |
| Temperature factor (Parameter) | 79 |
| Temperature offset (Parameter) | 79 |
| Temperature unit (Parameter) | 55 |
| Timestamp (Parameter) | 157, 158, 159, 160, 161, 162 |
| Torsion oscillation amplitude (Submenu) | 174 |
| Torsion oscillation damping (Submenu) | 175 |
| Torsion oscillation frequency (Submenu) | 172 |
| Totalizer (Submenu) | 48 |
| Totalizer 1 to n (Submenu) | 142 |
| Totalizer operation mode (Parameter) | 145 |
| Totalizer status (Hex) 1 to n (Parameter) | 49, 147 |
| Totalizer status 1 to n (Parameter) | 49, 147 |

Totalizer value 1 to n (Parameter) 49, 147

U

Unit totalizer (Parameter) 143

V

Value 1 display (Parameter) 18
Value 2 display (Parameter) 20
Value 3 display (Parameter) 21
Value 4 display (Parameter) 23
Value process variable (Parameter) 178
Viscosity (Submenu) 156
Volume flow (Parameter) 43
Volume flow factor (Parameter) 76
Volume flow offset (Parameter) 76
Volume flow unit (Parameter) 51
Volume unit (Parameter) 53

W

Web server (Submenu) 95
Web server functionality (Parameter) 97
Web server language (Parameter) 95
Wizard
 Define access code 36

Z

Zero point (Parameter) 80
Zero point adjustment (Submenu) 73
Zero point adjustment control (Parameter) 74

www.addresses.endress.com
