

Description of Device Parameters

Prosonic Flow Heat

Ultrasonic time-of-flight flowmeter




Table of contents

1 About this document	4		
1.1 Document function	4	5.2 US units	77
1.2 Target group	4	5.3 Imperial units	77
1.3 Using this document	4		
1.3.1 Information on the document structure	4	Index	78
1.3.2 Structure of a parameter description	6		
1.4 Symbols used	6		
1.4.1 Symbols for certain types of information	6		
1.4.2 Symbols in graphics	6		
1.5 Documentation	7		
1.5.1 Standard documentation	7		
1.5.2 Supplementary device-dependent documentation	7		
2 Overview of the Expert operating menu	8		
3 Description of device parameters	10		
3.1 "System" submenu	11		
3.1.1 "Diagn. handling" submenu	12		
3.1.2 "Administration" submenu	18		
3.2 "Sensor" submenu	19		
3.2.1 "Measured val." submenu	19		
3.2.2 "System units" submenu	25		
3.2.3 "Process param." submenu	31		
3.2.4 "Sensor adjustm." submenu	35		
3.2.5 "Calibration" submenu	38		
3.3 "Output" submenu	41		
3.3.1 "PFS output" submenu	41		
3.4 "Application" submenu	52		
3.4.1 "Totalizer 1 to n" submenu	53		
3.4.2 "Inventory count." submenu	57		
3.5 "Diagnostics" submenu	58		
3.5.1 "Diagnostic list" submenu	60		
3.5.2 "Event logbook" submenu	64		
3.5.3 "Device info" submenu	66		
3.5.4 "Mainboard module" submenu	69		
3.5.5 "Simulation" submenu	70		
4 Country-specific factory settings	75		
4.1 SI units	75		
4.1.1 System units	75		
4.1.2 Pulse value	75		
4.2 US units	75		
4.2.1 System units	75		
4.2.2 Pulse value	76		
5 Explanation of abbreviated units	77		
5.1 SI units	77		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions
- Operating concept of the operating menus: Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the operating tool

The names of the menus, submenus and parameters are displayed in abbreviated format.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Prosonic Flow E Heat	BA01793D

1.5.2 Supplementary device-dependent documentation

Special documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
RFID TAG	SD01565D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Locking status (0004)	→ 10
Access stat.tool (0005)	→ 11
Ent. access code (0003)	→ 11
 ▶ System	→ 11
▶ Diagn. handling	→ 12
▶ Administration	→ 18
 ▶ Sensor	→ 19
▶ Measured val.	→ 19
▶ System units	→ 25
▶ Process param.	→ 31
▶ Sensor adjustm.	→ 35
▶ Calibration	→ 38
 ▶ Output	→ 41
▶ PFS output 1	→ 41
 ▶ Application	→ 52
Reset all tot. (2806)	→ 52
▶ Totalizer 1 to n	→ 53
 ▶ Diagnostics	→ 58
Actual diagnos. (0691)	→ 58
Timestamp (0667)	→ 59
Prev.diagnostics (0690)	→ 59

Timestamp (0672)	→ 59
Time fr. restart (0653)	→ 60
Operating time (0652)	→ 60
▶ Diagnostic list	→ 60
▶ Event logbook	→ 64
▶ Device info	→ 66
▶ Mainboard module	→ 69
▶ Simulation	→ 70

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the operating tool.

Expert	
Locking status (0004)	→ 10
Access stat.tool (0005)	→ 11
Ent. access code (0003)	→ 11
System	→ 11
Sensor	→ 19
Output	→ 41
Application	→ 52
Diagnostics	→ 58

Locking status

Navigation Expert → Locking status (0004)

Description Displays the active write protection.

User interface

- CT act.-all par.
- Temp. locked

Additional information *Display*

If two or more types of write protection are active, all the active types of write protection are displayed in the operating tool.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

Selection

Options	Description
CT act.-all par.	Write access to all parameters is locked (via the operating tool).
Temp. locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access stat.tool


Navigation	Expert → Access stat.tool (0005)
Description	Displays the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Ent. access code parameter (→ 11).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7</p>

Ent. access code

Navigation	Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	0 to 9999

3.1 "System" submenu


Navigation  Expert → System



3.1.1 "Diagn. handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay



Navigation

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information

Result

This setting affects the following diagnostic messages:

- 832 Electronic temp.
- 833 Electronic temp.
- 834 Process temp.
- 835 Process temp.

"Diagn. behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagn. behavior** submenu (→ 12).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Options	Description
Logbook only	
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

 For a list of all the diagnostic events, see the Operating Instructions for the device
→  7

Navigation



Expert → System → Diagn. handling → Diagn. behavior

 Diagn. behavior	
Diagnostic no. 302 (0742)	→  13
Diagnostic no. 832 (0675)	→  14
Diagnostic no. 833 (0676)	→  14
Diagnostic no. 834 (0677)	→  14
Diagnostic no. 835 (0678)	→  15
Diagnostic no. 840 (0680)	→  15
Diagnostic no. 442 (0658)	→  16
Diagnostic no. 443 (0659)	→  16
Diagnostic no. 125 (0775)	→  16
Diagnostic no. 124 (0774)	→  17
Diagnostic no. 160 (0776)	→  17
Diagnostic no. 881 (0724)	→  17

Diagnostic no. 302 (Verific. active)



Navigation

 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0742)

Description

Option for changing the diagnostic behavior of the diagnostic message **302 Verific. active**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional informationDetailed description of the options available for selection: → [12](#)**Diagnostic no. 832 (Electronic temp.)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

DescriptionOption for changing the diagnostic behavior of the diagnostic message **832 Electronic temp..****Selection**

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information*Selection*Detailed description of the options available for selection: → [12](#)**Diagnostic no. 833 (Electronic temp.)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)

DescriptionOption for changing the diagnostic behavior of the diagnostic message **833 Electronic temp..****Selection**

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information*Selection*Detailed description of the options available for selection: → [12](#)**Diagnostic no. 834 (Process temp.)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)

DescriptionOption for changing the diagnostic behavior of the diagnostic message **834 Process temp..**

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	----------------------------------------------------------------------------------------------------------------

Factory setting	Warning
------------------------	---------

Additional information	<i>Selection</i>
-------------------------------	------------------



Detailed description of the options available for selection: → 12

Diagnostic no. 835 (Process temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)
-------------------	---------------------------------------------------------------------------------

Description	Option for changing the diagnostic behavior of the diagnostic message 835 Process temp..
--------------------	-------------------------------------------------------------------------------------------------

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	----------------------------------------------------------------------------------------------------------------

Factory setting	Warning
------------------------	---------

Additional information	<i>Selection</i>
-------------------------------	------------------



Detailed description of the options available for selection: → 12

Diagnostic no. 841 (Sensor range)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 840 (0680)
-------------------	---------------------------------------------------------------------------------

Description	Option for changing the diagnostic behavior of the diagnostic message 841 Sensor range.
--------------------	------------------------------------------------------------------------------------------------

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	----------------------------------------------------------------------------------------------------------------

Factory setting	Warning
------------------------	---------

Additional information	Detailed description of the options available for selection: → 12
-------------------------------	--------------------------------------------------------------------

Diagnostic no. 442 (Freq. output)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 442 Freq. output .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 12

Diagnostic no. 443 (Pulse output)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 12

Diagnostic no. 125 (Rel. sound vel.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 125 (0775)
Description	Option for changing the diagnostic behavior of the diagnostic message 125 Rel. sound vel. .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only

Factory setting Warning

Additional information  Detailed description of the options available for selection: → [12](#)

Diagnostic no. 124 (Rel.sig.strength)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 124 (0774)

Description Option for changing the diagnostic behavior of the diagnostic message **124 Rel.sig.strength**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting Warning

Additional information  Detailed description of the options available for selection: → [12](#)

Diagnostic no. 160 (Signal path off)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)

Description Option for changing the diagnostic behavior of the diagnostic message **160 Signal path off**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting Warning

Additional information  Detailed description of the options available for selection: → [12](#)

Diagnostic no. 881 (Sen.sig. path 1 to n)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 881 (0724)

Description Option for changing the diagnostic behavior of the diagnostic message **881 Sen.sig. path 1 to n**.

Selection


- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

 Detailed description of the options available for selection: →  12

3.1.2 "Administration" submenu*Navigation*
 Expert → System → Administration
**Device reset****Navigation**
 Expert → System → Administration → Device reset (0000)
Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery set.
- Restart device
- Rest.S-DATBackup

Factory setting

Cancel


Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery set.	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

3.2 "Sensor" submenu

Navigation


Diagram Expert → Sensor



3.2.1 "Measured val." submenu

Navigation


Diagram Expert → Sensor → Measured val.



"Process variab." submenu

Navigation

Diagram Expert → Sensor → Measured val. → Process variab.



Volume flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)
Description	Displays the volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Volume flow unit parameter (→  25)

Mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)
Description	Displays the mass flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→  27)

Sound velocity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Sound velocity (1850)
Description	Displays the sound velocity currently measured.
User interface	Signed floating-point number

Flow velocity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Flow velocity (1852)
Description	Displays the flow velocity currently measured.
User interface	Signed floating-point number

Temperature

Navigation	Expert → Sensor → Measured val. → Process variab. → Temperature (1853)
Description	Displays the medium temperature currently measured.
User interface	Signed floating-point number
Additional information	<p><i>Dependency</i></p>  The unit is taken from the Temperature unit parameter (→ 28)

"System values" submenu

Navigation  Expert → Sensor → Measured val. → System values

 **System values**

Signal strength (2914)	→  21
Asymmetry (2913)	→  22
SNR (2917)	→  22
Turbulence (2907)	→  23

Signal strength

Navigation	Expert → Sensor → Measured val. → System values → Signal strength (2914)
Description	Use this function to display the current signal strength.
User interface	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>A drop in the signal strength over time can be an indicator of deposit buildup on the converter or high ultrasonic damping in the gas. A very fast drop is an indication of a high concentration of CO₂.</p>

Acceptance rate

Navigation  Expert → Sensor → Measured val. → System values → Acceptance rate (2912)

Description Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted.
Multipath measuring devices only: Displays the minimum of all acceptance rates measured.

User interface 0 to 100 %

Asymmetry

Navigation  Expert → Sensor → Measured val. → System values → Asymmetry (2913)

Prerequisite The **Dual path sensor** option is selected in the **Path conf.** parameter parameter.

Description Use this function to display the asymmetry of the measured values between signal path 1 and signal path 2.

User interface Signed floating-point number

Factory setting 0 %

Additional information *Limit values*

If the value 0 is displayed, both measured values are the same. The higher the displayed value, the greater the difference between the two measured values of the signal paths.

SNR

Navigation  Expert → Sensor → Measured val. → System values → SNR (2917)

Description Use this function to display the current signal-to-noise ratio.

User interface Signed floating-point number

Additional information *Description*

A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality. A very fast drop is an indication of a high concentration of CO₂.

Turbulence

Navigation  Expert → Sensor → Measured val. → System values → Turbulence (2907)

Description Use this function to display the current turbulence.

User interface Signed floating-point number

Reynolds number

Navigation  Expert → Sensor → Measured val. → System values → Reynolds number (2908)

Description Displays the Reynolds number.

User interface Signed floating-point number

Profile factor

Navigation  Expert → Sensor → Measured val. → System values → Profile factor (2909)

Description Displays the profile factor.

The profile factor describes the correction factor applied based on the flow profile present.
The more the profile deviates from even distribution, the smaller the factor.

The profile factor is used to calculate the flow rate.

User interface Signed floating-point number

"Totalizer" submenu

Navigation  Expert → Sensor → Measured val. → Totalizer

 **Totalizer**

Totalizer val. 1 to n (0911-1 to n)

→  24

Tot. overflow 1 to n (0910-1 to n)

→  24

Totalizer val. 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 53) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information*Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Tot. overflow 1 to n** parameter if the display range is exceeded.

In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 56).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Operation mode** parameter (→ 55).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 54).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer val. 1** parameter: 1968457 m³
- Value in the **Tot. overflow 1** parameter: $1 \cdot 10^7$ (1 overflow) = 10 000 000 [m³]
- Current totalizer reading: 11 968 457 m³

Tot. overflow 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 53) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow.

The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer val. 1 to n** parameter.

User interface

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [54](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer val. 1** parameter: 1 968 457 m³
- Value in the **Tot. overflow 1** parameter: $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

3.2.2 "System units" submenu

Navigation



Expert → Sensor → System units

► System units	
Volume flow unit (0553)	→ 25
Volume unit (0563)	→ 27
Mass flow unit (0554)	→ 27
Mass unit (0574)	→ 28
Temperature unit (0557)	→ 28
Length unit (0551)	→ 29
Velocity unit (0566)	→ 29
Density unit (0555)	→ 30
Kin. visc. unit (0578)	→ 30
Date/time format (2812)	→ 31

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ /s	■ af/s	■ gal/s (imp)
■ cm ³ /min	■ af/min	■ gal/min (imp)
■ cm ³ /h	■ af/h	■ gal/h (imp)
■ cm ³ /d	■ af/d	■ gal/d (imp)
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)
■ m ³ /s	■ fl oz/s (us)	■ bbl/s (imp;beer)
■ m ³ /min	■ fl oz/min (us)	■ bbl/min (imp;beer)
■ m ³ /h	■ fl oz/h (us)	■ bbl/h (imp;beer)
■ m ³ /d	■ fl oz/d (us)	■ bbl/d (imp;beer)
■ ml/s	■ gal/s (us)	■ bbl/s (imp;oil)
■ ml/min	■ gal/min (us)	■ bbl/min (imp;oil)
■ ml/h	■ gal/h (us)	■ bbl/h (imp;oil)
■ ml/d	■ gal/d (us)	■ bbl/d (imp;oil)
■ l/s	■ kgal/s (us)	
■ l/min	■ kgal/min (us)	
■ l/h	■ kgal/h (us)	
■ l/d	■ kgal/d (us)	
■ hl/s	■ Mgal/s (us)	
■ hl/min	■ Mgal/min (us)	
■ hl/h	■ Mgal/h (us)	
■ hl/d	■ Mgal/d (us)	
■ Ml/s	■ bbl/s (us;liq.)	
■ Ml/min	■ bbl/min (us;liq.)	
■ Ml/h	■ bbl/h (us;liq.)	
■ Ml/d	■ bbl/d (us;liq.)	
	■ bbl/s (us;beer)	
	■ bbl/min (us;beer)	
	■ bbl/h (us;beer)	
	■ bbl/d (us;beer)	
	■ bbl/s (us;oil)	
	■ bbl/min (us;oil)	
	■ bbl/h (us;oil)	
	■ bbl/d (us;oil)	
	■ bbl/s (us;tank)	
	■ bbl/min (us;tank)	
	■ bbl/h (us;tank)	
	■ bbl/d (us;tank)	

Factory setting

Country-specific:

- m³/h
- ft³/min

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  20)*Selection*
 For an explanation of the abbreviated units: →  77

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- dm³
- ft³

Additional information*Selection*

For an explanation of the abbreviated units: → [77](#)

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- kg/s
- kg/min
- kg/h
- kg/d
- t/h
- t/d

US units

- oz/s
- oz/min
- lb/s
- lb/min
- lb/h
- lb/d
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Result*

The selected unit applies for:
Mass flow parameter

Selection

 For an explanation of the abbreviated units: → [77](#)

Mass unit**Navigation**

 Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

 For an explanation of the abbreviated units: → [77](#)

Temperature unit**Navigation**

 Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.

Selection*SI units*

- °C
- K

US units

- °F
- °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Result*

The selected unit applies for:

- Temperature (→ 21)
- Maximum value
- Minimum value
- Maximum value
- Minimum value

Selection

 For an explanation of the abbreviated units: → 77

Length unit**Navigation**

Expert → Sensor → System units → Length unit (0551)

Description

Use this function to select the unit of length for the nominal diameter.

Selection*SI units*

- m
- mm
- µm

US units

- ft
- in

Factory setting

Country-specific:

- mm
- in

Additional information*Selection*

 For an explanation of the abbreviated units: → 77

Velocity unit**Navigation**

Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection*SI units*

m/s

US units

ft/s

Factory setting

Country-specific:

- m/s
- ft/s

Additional information*Result*

The selected unit applies for:

- Flow velocity (→ 20)
- Sound velocity (→ 20)
- Maximum value
- Minimum value
- Maximum value
- Minimum value

Selection

 For an explanation of the abbreviated units: → 77

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Selection*

 For an explanation of the abbreviated units: → 77

Kin. visc. unit**Navigation**

Expert → Sensor → System units → Kin. visc. unit (0578)

Description

Use this function to select the unit for the kinematic viscosity.

Selection	<i>SI units</i>
	▪ cSt
	▪ m ² /s
	▪ St

Factory setting	Country-specific:
	▪ m ² /s
	▪ cSt

Date/time format

Navigation Expert → Sensor → System units → Date/time format (2812)

Description Use this function to select the desired time format for calibration history.

Selection	▪ dd.mm.yy hh:mm ▪ dd.mm.yy am/pm ▪ mm/dd/yy hh:mm ▪ mm/dd/yy am/pm
------------------	------------------------------------------------------------------------------

Factory setting dd.mm.yy hh:mm

Additional information *Selection*

For an explanation of the abbreviated units: → 77

3.2.3 "Process param." submenu

Navigation Expert → Sensor → Process param.

▶ Process param.	
Flow override (1839)	→ 32
Flow damping (1802)	→ 32
Temp. damping (1886)	→ 33
▶ Low flow cut off	→ 33

Flow override**Navigation**

█ Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized

Positive zero return can also be enabled via the Status input: **Assign stat.inp.** parameter.

Flow damping**Navigation**

█ Expert → Sensor → Process param. → Flow damping (1802)

Description

Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 999.9 s

Factory setting

0 s

Additional information*Description*

The damping is performed by a PT1 element¹⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased



Damping is switched off if **0** is entered (factory setting).

Result

The damping affects the following variables of the device:

- Outputs
- Low flow cut off → 33
- Totalizers → 53

Temp. damping**Navigation**

Expert → Sensor → Process param. → Temp. damping (1886)

Description

Use this function to enter the time constant for temperature damping.

User entry

0 to 999.9 s

Factory setting

10 s

"Low flow cut off" submenu*Navigation*

Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign variable (1837)	→ 34
On value (1805)	→ 34
Off value (1804)	→ 34

1) Proportional behavior with first-order lag

Assign variable


Navigation	Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description	Use this function to select the process variable for low flow cutoff detection.
Selection	<ul style="list-style-type: none">■ Off■ Volume flow■ Mass flow
Factory setting	Off

On value

Navigation	Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite	In the Assign variable parameter (→ 34), one of the following options is selected: <ul style="list-style-type: none">■ Volume flow■ Mass flow
Description	Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → 34.
User entry	Positive floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i> The unit depends on the process variable selected in the Assign variable parameter (→ 34).

Off value

Navigation	Expert → Sensor → Process param. → Low flow cut off → Off value (1804)
Prerequisite	In the Assign variable parameter (→ 34), one of the following options is selected: <ul style="list-style-type: none">■ Volume flow■ Mass flow
Description	Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 34.
User entry	0 to 100.0 %
Factory setting	50 %


Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.4 "Sensor adjustm." submenu


Navigation

Diagram → Expert → Sensor → Sensor adjustm.

**"Process variable adjustment" submenu**

Navigation

Diagram → Expert → Sensor → Sensor adjustm. → Variable adjust



Vol. flow offset

Navigation  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry Signed floating-point number

Factory setting 0 l/h

Additional information *Description*

 Corrected value = (factor × value) + offset

Vol. flow factor

Navigation  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

 Corrected value = (factor × value) + offset

Mass flow offset

Navigation  Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/h.

User entry Signed floating-point number

Factory setting 0 kg/h

Additional information *Description*

 Corrected value = (factor × value) + offset

Mass flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

S. veloc. offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. offset (1848)
Description	Use this function to enter the zero point shift for the sound velocity trim. The sound velocity unit on which the shift is based is m/s.
User entry	Signed floating-point number
Factory setting	0 m/s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

S. veloc. factor


Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. factor (1849)
Description	Use this function to enter a quantity factor (without time) for the sound velocity. This multiplication factor is applied over the sound velocity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

3.2.5 "Calibration" submenu

Navigation



Expert → Sensor → Calibration



Nominal diameter

Navigation

Expert → Sensor → Calibration → Nominal diameter (2807)

Description

Displays the nominal diameter of the sensor.

User interface

DNxx / x"

Factory setting

Depends on the size of the sensor

Additional information

Description

The value is also specified on the sensor nameplate.

Cal. factor

Navigation

Expert → Sensor → Calibration → Cal. factor (2920)

Description

Displays the current calibration factor for the sensor.

User interface

Signed floating-point number

Factory setting

1

Zero point

Navigation

Expert → Sensor → Calibration → Zero point (2921)

Description

Displays the current zero point correction value for the sensor.

User interface

Signed floating-point number

Factory setting

0

"Recalibration" submenu**Navigation**

Expert → Sensor → Calibration → Recalibration

► Recalibration	
Year (2846)	→ 39
Month (2845)	→ 39
Day (2842)	→ 40
Hour (2843)	→ 40
AM/PM (2813)	→ 40
Minute (2844)	→ 41

Year**Navigation**

Expert → Sensor → Calibration → Recalibration → Year (2846)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the year of recalibration.

User entry

9 to 99

Factory setting

10

Month**Navigation**

Expert → Sensor → Calibration → Recalibration → Month (2845)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to select the month of recalibration.

Selection

- January
- February
- March
- April
- May
- June
- July
- August
- September
- October
- November
- December

Factory setting

January

Day**Navigation**

Expert → Sensor → Calibration → Recalibration → Day (2842)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the day of the month of recalibration.

User entry

1 to 31 d

Factory setting

1 d

Hour**Navigation**

Expert → Sensor → Calibration → Recalibration → Hour (2843)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the hour of recalibration.

User entry

0 to 23 h

Factory setting

12 h

AM/PM**Navigation**

Expert → Sensor → Calibration → Recalibration → AM/PM (2813)

Prerequisite

Can be edited if Heartbeat Verification is not active.

In the **Date/time format** parameter (2812) (→ 31), the **dd.mm.yy am/pm** option or the **mm/dd/yy am/pm** option is selected.

Description	Use this function to enter the morning (AM option) or afternoon (PM option) time format for counting based on the 12-hour clock.
Selection	<ul style="list-style-type: none"> ■ AM ■ PM
Factory setting	AM


Minute



Navigation	Expert → Sensor → Calibration → Recalibration → Minute (2844)
Prerequisite	Can be edited if Heartbeat Verification is not active.
Description	Use this function to enter the minutes of recalibration.
User entry	0 to 59 min
Factory setting	0 min


3.3 "Output" submenu

Navigation Expert → Output



3.3.1 "PFS output" submenu

Navigation Expert → Output → PFS output



Measuring mode (0457-1)	→ 45
Failure mode (0480-1)	→ 46
Pulse output 1 (0456-1)	→ 46
Assign freq. (0478-1)	→ 47
Min. freq. value (0453-1)	→ 47
Max. freq. value (0454-1)	→ 48
Val. at min.freq (0476-1)	→ 48
Val. at max.freq (0475-1)	→ 49
Measuring mode (0479-1)	→ 49
Damping out. 1 (0477-1)	→ 50
Response time (0491-1)	→ 50
Failure mode (0451-1)	→ 51
Failure freq. (0474-1)	→ 52
Output freq. 1 (0471-1)	→ 52

Operating mode



Navigation

Expert → Output → PFS output 1 → Operating mode (0469-1)

Description

Use this function to select the operating mode of the output as a pulse or frequency output.

Selection

- Pulse
- Frequency

Factory setting

Pulse

Additional information


"Pulse" option

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume or mass is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1000 Impuls/s



2 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, mass flow, temperature, sound velocity, flow velocity, acceptance rate, signal asymmetry, turbulence, signal strength or signal-to-noise ratio.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz



3 Flow-proportional frequency output

Assign pulse 1**Navigation**

Expert → Output → PFS output 1 → Assign pulse 1 (0460-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 42) parameter.

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow

Factory setting


Off

Value per pulse

Navigation	Expert → Output → PFS output 1 → Value per pulse (0455-1)
Prerequisite	In the Operating mode parameter (→ 42), the Pulse option is selected, and one of the following options is selected in the Assign pulse parameter (→ 43): <ul style="list-style-type: none">▪ Volume flow▪ Mass flow
Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 75
Additional information	<i>User entry</i> Weighting of the pulse output with a quantity. The lower the pulse value, the <ul style="list-style-type: none">▪ better the resolution.▪ the higher the frequency of the pulse response.

Pulse width

Navigation	Expert → Output → PFS output 1 → Pulse width (0452-1)
Prerequisite	In the Operating mode parameter (→ 42), the Pulse option is selected, and one of the following options is selected in the Assign pulse parameter (→ 43): <ul style="list-style-type: none">▪ Volume flow▪ Mass flow
Description	Use this function to enter the duration of the output pulse.
User entry	0.05 to 2 000 ms
Factory setting	100 ms
Additional information	<i>Description</i> <ul style="list-style-type: none">▪ Define how long a pulse is (duration).▪ The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$.▪ The interval between two pulses lasts at least as long as the set pulse width.▪ The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$.▪ If the flow exceeds these limit values, the measuring device displays the diagnostic message △S443 Pulse output 1.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- f_{\max} : $1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- Q_{\max} : $5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation Expert → Output → PFS output 1 → Measuring mode (0457-1)

Prerequisite In the **Operating mode** parameter (→ 42), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 43):

- Volume flow
- Mass flow

Description Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse
- Reverse flow
- Rev. flow comp.

Factory setting Forward flow

Additional information *Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Rev. flow comp.
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.

For a detailed description of the options available, see the **Measuring mode** parameter

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter

Failure mode**Navigation**

█ Expert → Output → PFS output 1 → Failure mode (0480-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 43):

- Volume flow
- Mass flow

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

Selection

- Actual value
In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.
- No pulses
In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output 1**Navigation**

█ Expert → Output → PFS output 1 → Pulse output 1 (0456-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 42) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 44) and **Pulse width** parameter (→ 44) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert outp.sig.** parameter i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 46)) can be configured.

Assign freq.



Navigation	Expert → Output → PFS output 1 → Assign freq. (0478-1)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 42) parameter.
Description	Use this function to select the process variable for the frequency output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Temperature
Factory setting	Off

Min. freq. value



Navigation	Expert → Output → PFS output 1 → Min. freq. value (0453-1)
Prerequisite	In the Operating mode parameter (→ 42), the Frequency option is selected, and one of the following options is selected in the Assign freq. parameter (→ 47): <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Sound velocity ▪ Flow velocity ▪ Temperature
Description	Use this function to enter the start value frequency.
User entry	0.0 to 10 000.0 Hz
Factory setting	0.0 Hz

Max. freq. value**Navigation**

█ Expert → Output → PFS output 1 → Max. freq. value (0454-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature

Description

Use this function to enter the end value frequency.

User entry

0.0 to 10 000.0 Hz

Factory setting

10000.0 Hz

Val. at min.freq**Navigation**

█ Expert → Output → PFS output 1 → Val. at min.freq (0476-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature

Description

Use this function to enter the measured value for the start value frequency.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information

Dependency

The entry depends on the process variable selected in the **Assign freq.** parameter (→ 47).

Val. at max.freq**Navigation**

Expert → Output → PFS output 1 → Val. at max.freq (0475-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature

Description

Use this function to enter the measured value for the end value frequency.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

The entry depends on the process variable selected in the **Assign freq.** parameter (→ 47).

Measuring mode**Navigation**

Expert → Output → PFS output 1 → Measuring mode (0479-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse
- Rev. flow comp.

* Visibility depends on order options or device settings

Factory setting	Forward flow
------------------------	--------------

Damping out. 1

Navigation Expert → Output → PFS output 1 → Damping out. 1 (0477-1)

Prerequisite In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow

Description Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry 0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element²⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time

Navigation Expert → Output → PFS output 1 → Response time (0491-1)

Prerequisite In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity*
- Temperature*
- Acceptance rate*
- Signal strength*
- SNR*
- Turbulence*
- Signal asymmetry*

2) proportional transmission behavior with first order delay

* Visibility depends on order options or device settings

Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ▪ Damping of pulse/frequency/switch output and ▪ Depending on the measured variable assigned to the output. <ul style="list-style-type: none"> - Flow damping or - Temperature damping

Failure mode	
Navigation	 Expert → Output → PFS output 1 → Failure mode (0451-1)
Prerequisite	In the Operating mode parameter (→ 42), the Frequency option is selected, and one of the following options is selected in the Assign freq. parameter (→ 47): <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz
Factory setting	0 Hz
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Actual value <p>In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.</p> ▪ Defined value <p>In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure freq. (→ 52) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.</p> ▪ 0 Hz <p>In the event of a device alarm, the frequency output is "switched off".</p> <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Failure freq.**Navigation**

█ Expert → Output → PFS output 1 → Failure freq. (0474-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 47):

- Volume flow
- Mass flow

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 12 500.0 Hz

Factory setting

0.0 Hz

Output freq. 1**Navigation**

█ Expert → Output → PFS output 1 → Output freq. 1 (0471-1)

Prerequisite

In the **Operating mode** parameter (→ 42), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.


User interface

0.0 to 12 500.0 Hz

3.4 "Application" submenu

Navigation

█ Expert → Application

**Reset all tot.****Navigation**

█ Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.4.1 "Totalizer 1 to n" submenu

Navigation



Expert → Application → Totalizer 1 to n

► Totalizer 1 to n

Assign variable (0914-1 to n)	→ 53
Unit totalizer 1 to n (0915-1 to n)	→ 54
Operation mode (0908-1 to n)	→ 55
Control Tot. 1 to n (0912-1 to n)	→ 55
Preset value 1 to n (0913-1 to n)	→ 56
Failure mode (0901-1 to n)	→ 56

Assign variable



Navigation



Expert → Application → Totalizer 1 to n → Assign variable (0914-1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only **Assign variable** parameter (→ 53) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Unit totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 53) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ 53).

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- ft³

Additional information*Description*

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 25).

Selection

The selection is dependent on the process variable selected in the **Assign variable** parameter (→ 53).

Operation mode**Navigation**

Expert → Application → Totalizer 1 to n → Operation mode (0908-1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [53](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward total
- Reverse total

Factory setting

Net flow total

Additional information*Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward total
Only the flow in the forward flow direction is totalized.
- Reverse total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Tot. 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912-1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [53](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset+totalize
- Hold

Factory setting

Totalize

Additional information*Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.

Options	Description
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset+totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.

Preset value 1 to n

Navigation

Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 53) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to enter a start value for the Totalizer 1 to n.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³
- 0 ft³

Additional information

User entry

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 54).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode



Navigation

Expert → Application → Totalizer 1 to n → Failure mode (0901–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 53) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Stop

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

■ Stop

The totalizer is stopped in the event of a device alarm.

■ Actual value

The totalizer continues to count based on the actual measured value; the device alarm is ignored.

■ Last valid value

The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.4.2 "Inventory count." submenu*Navigation*

Expert → Application → Inventory count.

► Inventory count.

Unit (0974)

→ 57

Unit**Navigation**

Expert → Application → Inventory count. → Unit (0974)

Description

Displays the unit of the inventory counter.

User interface*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Additional information*Description*

The parameter cannot be configured or reset.

3.5 "Diagnostics" submenu

Navigation

Expert → Diagnostics

▶ Diagnostics	
Actual diagnos. (0691)	→ 58
Timestamp (0667)	→ 59
Prev.diagnostics (0690)	→ 59
Timestamp (0672)	→ 59
Time fr. restart (0653)	→ 60
Operating time (0652)	→ 60
▶ Diagnostic list	→ 60
▶ Event logbook	→ 64
▶ Device info	→ 66
▶ Mainboard module	→ 69
▶ Simulation	→ 70

Actual diagnos.

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

i Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 60).

Example

For the display format:

☒ F271 Main electronics

Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Actual diagnos. parameter (→  58).
	<i>Example</i> For the display format: 24d12h13m00s

Prev.diagnostics

Navigation	 Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Example</i> For the display format:  F271 Main electronics

Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Prev.diagnostics parameter (→  59).
	<i>Example</i> For the display format: 24d12h13m00s

Time fr. restart

Navigation  Expert → Diagnostics → Time fr. restart (0653)

Description Use this function to display the time the device has been in operation since the last device restart.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation  Expert → Diagnostics → Operating time (0652)

Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.5.1 "Diagnostic list" submenu

Navigation  Expert → Diagnostics → Diagnostic list

 Diagnostic list	
Diagnostics 1 (0692)	→  61
Timestamp (0683)	→  61
Diagnostics 2 (0693)	→  61
Timestamp (0684)	→  62
Diagnostics 3 (0694)	→  62
Timestamp (0685)	→  62
Diagnostics 4 (0695)	→  63
Timestamp (0686)	→  63

Diagnostics 5 (0696)	→ 63
Timestamp (0687)	→ 64

Diagnostics 1

Navigation	Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Displays the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: F276 I/O module

Timestamp

Navigation	Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i> The diagnostic message can be viewed via the Diagnostics 1 parameter (→ 61). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: F276 I/O module

Timestamp

Navigation

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→  61).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

█ Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:
☒ F276 I/O module

Timestamp

Navigation

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 3** parameter (→  62).

Example

For the display format:
24d12h13m00s

Diagnostics 4

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format:  F276 I/O module

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 4 parameter (→  63). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 5

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)
Description	Displays the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format:  F276 I/O module

Timestamp

Navigation

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

i The diagnostic message can be viewed via the **Diagnostics 5** parameter (→  63).

Example


For the display format:

24d12h13m00s

3.5.2 "Event logbook" submenu

Navigation

█ Expert → Diagnostics → Event logbook



Filter options

**Navigation**

█ Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information*Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu

The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

Navigation

Expert → Diagnostics → Event logbook → Event list

**Event list****Navigation**

Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter.

User interface

- For a "Category I" event message

Information event, short message, symbol for event recording and operating time when error occurred

- For a "Category F, C, S, M" event message (status signal)

Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊖: End of the event

Examples

For the display format:

I1091 Configuration modified

⊖ 24d12h13m00s

HistoROM


A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.5.3 "Device info" submenu

Navigation



Expert → Diagnostics → Device info



Device tag



Navigation



Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant.

User interface

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Prosonic Flow E Heat**Serial number****Navigation**  Expert → Diagnostics → Device info → Serial number (0009)**Description** Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.**Additional information** *Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version**Navigation**  Expert → Diagnostics → Device info → Firmware version (0010)**Description** Displays the device firmware version installed.**User interface** Character string in the format xx.yy.zz**Additional information** *Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name**Navigation**  Expert → Diagnostics → Device info → Device name (0013)**Description** Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.**User interface** Max. 32 characters such as letters or numbers.**Factory setting** Pros.Flow E Heat

Order code**Navigation**

█ Expert → Diagnostics → Device info → Order code (0008)

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

i The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

i **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Ext. order cd. 1**Navigation**

█ Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

i The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Ext. order cd. 2**Navigation**

█ Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 68)

Ext. order cd. 3

Navigation Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description Displays the third part of the extended order code.

User interface Character string

Additional information For additional information, see **Ext. order cd. 1** parameter (→ 68)

Config. counter

Navigation Expert → Diagnostics → Device info → Config. counter (0233)

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

ENP version

Navigation Expert → Diagnostics → Device info → ENP version (0012)

Description Displays the version of the electronic nameplate.

User interface Character string

Factory setting 2.02.00

Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.5.4 "Mainboard module" submenu

Navigation Expert → Diagnostics → Mainboard module

Mainboard module

Software rev.

→ 70

Build no. softw.	→ 70
Bootloader rev.	→ 70

Software rev.

Navigation  Expert → Diagnostics → Mainboard module → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. softw.

Navigation  Expert → Diagnostics → Mainboard module → Build no. softw. (0079)

Description Displays the software build number of the module.

User interface Positive integer

Bootloader rev.

Navigation  Expert → Diagnostics → Mainboard module → Bootloader rev. (0073)

Description Displays the bootloader revision of the software.

User interface Positive integer

3.5.5 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation

 Simulation	
Assign proc.var. (1810)	→ 71
Proc. var. value (1811)	→ 71
FreqOutputSim 1 (0472-1)	→ 72

Freq value 1 (0473-1)	→ 72
Puls.outp.sim. 1 (0458-1)	→ 73
Pulse value 1 (0459-1)	→ 73
Dev. alarm sim. (0654)	→ 73
Diag. event sim. (0737)	→ 74

Assign proc.var.**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated.

Selection

- Off
- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature

Factory setting

Off

Additional information*Description*

The simulation value of the process variable selected is defined in the **Proc. var. value** parameter (→ 71).

Proc. var. value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

In the **Assign proc.var.** parameter (→ 71), one of the following options is selected:

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

* Visibility depends on order options or device settings

Factory setting 0

Additional information *User entry*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 25).

FreqOutputSim 1



Navigation  Expert → Diagnostics → Simulation → FreqOutputSim 1 (0472-1)

Prerequisite In the **Operating mode** parameter (→ 42), the **Frequency** option is selected.

Description Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

 The desired simulation value is defined in the .

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Freq value 1



Navigation  Expert → Diagnostics → Simulation → Freq value 1 (0473-1)

Prerequisite In the , the **On** option is selected.

Description Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 12 500.0 Hz

Puls.outp.sim. 1

Navigation	Expert → Diagnostics → Simulation → Puls.outp.sim. 1 (0458–1)
Prerequisite	In the Operating mode parameter (→ 42), the Pulse option is selected.
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none">▪ Off▪ Fixed value▪ Down-count. val.
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the .</p> <p><i>Selection</i></p> <ul style="list-style-type: none">▪ Off Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ Fixed value Pulses are continuously output with the pulse width specified in the Pulse width parameter (→ 44).▪ Down-count. val. The pulses specified in the Pulse value parameter (→ 73) are output.

Pulse value 1

Navigation	Expert → Diagnostics → Simulation → Pulse value 1 (0459–1)
Prerequisite	In the , the Down-count. val. option is selected.
Description	Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.
User entry	0 to 65 535

Dev. alarm sim.

Navigation	Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)
Description	Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Event category

Navigation

 Expert → Diagnostics → Simulation → Event category (0738)

Description

Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diag. event sim.** parameter (→  74).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting

Sensor

Diag. event sim.



Navigation

 Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting

Off

Additional information

Description

 For the simulation, you can choose from the diagnostic events of the category selected in the **Event category** parameter (→  74).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Velocity	m/s
Temperature	°C
Length	mm

4.1.2 Pulse value

Nominal diameter [mm]	[dm ³ /pulse]
50	3
65	4
80	6
100	10
150	25

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft ³
Volume flow	ft ³ /min
Velocity	ft/s
Temperature	°F
Length	in

4.2.2 Pulse value

Nominal diameter [in]	[gal/pulse]
2	0.8
2 ½	1.1
3	1.6
4	2.6
6	6.6

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Velocity	m/s	Meter/time unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm³, dm³, m³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	dm³/s, dm³/min, dm³/h, dm³/d	Cubic decimeter/time unit
	m³/s, m³/min, m³/h, m³/d	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Velocity	ft/s	Foot/time unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	ft³	Cubic foot
Volume flow	ft³/s, ft³/min, ft³/h, ft³/d	Cubic foot/time unit
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

A

Acceptance rate (Parameter)	22
Access status tooling (Parameter)	11
Actual diagnostics (Parameter)	58
Administration (Submenu)	18
Alarm delay (Parameter)	12
AM/PM (Parameter)	40
Application (Submenu)	52
Assign behavior of diagnostic no. 124 (Parameter)	17
Assign behavior of diagnostic no. 125 (Parameter)	16
Assign behavior of diagnostic no. 160 (Parameter)	17
Assign behavior of diagnostic no. 302 (Parameter)	13
Assign behavior of diagnostic no. 442 (Parameter)	16
Assign behavior of diagnostic no. 443 (Parameter)	16
Assign behavior of diagnostic no. 832 (Parameter)	14
Assign behavior of diagnostic no. 833 (Parameter)	14
Assign behavior of diagnostic no. 834 (Parameter)	14
Assign behavior of diagnostic no. 835 (Parameter)	15
Assign behavior of diagnostic no. 840 (Parameter)	15
Assign behavior of diagnostic no. 881 (Parameter)	17
Assign frequency output (Parameter)	47
Assign process variable (Parameter)	34, 53
Assign pulse output 1 (Parameter)	43
Assign simulation process variable (Parameter)	71
Asymmetry (Parameter)	22

B

Bootloader revision (Parameter)	70
Build no. software (Parameter)	70

C

Calibration (Submenu)	38
Calibration factor (Parameter)	38
Configuration counter (Parameter)	69
Control Totalizer 1 to n (Parameter)	55

D

Damping output 1 (Parameter)	50
Date/time format (Parameter)	31
Day (Parameter)	40
Density unit (Parameter)	30
Device alarm simulation (Parameter)	73
Device information (Submenu)	66
Device name (Parameter)	67
Device reset (Parameter)	18
Device tag (Parameter)	66
Diagnostic behavior (Submenu)	12
Diagnostic event category (Parameter)	74
Diagnostic event simulation (Parameter)	74
Diagnostic handling (Submenu)	12
Diagnostic list (Submenu)	60
Diagnostics (Submenu)	58
Diagnostics 1 (Parameter)	61
Diagnostics 2 (Parameter)	61
Diagnostics 3 (Parameter)	62
Diagnostics 4 (Parameter)	63

Diagnostics 5 (Parameter)	63
Direct access	
Acceptance rate (2912)	22
Access status tooling (0005)	11
Actual diagnostics (0691)	58
Alarm delay (0651)	12
AM/PM (2813)	40
Assign behavior of diagnostic no. 124 (0774)	17
Assign behavior of diagnostic no. 125 (0775)	16
Assign behavior of diagnostic no. 160 (0776)	17
Assign behavior of diagnostic no. 302 (0742)	13
Assign behavior of diagnostic no. 442 (0658)	16
Assign behavior of diagnostic no. 443 (0659)	16
Assign behavior of diagnostic no. 832 (0675)	14
Assign behavior of diagnostic no. 833 (0676)	14
Assign behavior of diagnostic no. 834 (0677)	14
Assign behavior of diagnostic no. 835 (0678)	15
Assign behavior of diagnostic no. 840 (0680)	15
Assign behavior of diagnostic no. 881 (0724)	17
Assign frequency output	
Pulse/frequency/switch output 1 (0478-1)	47
Assign process variable	
Totalizer 1 to n (0914-1 to n)	53
Assign process variable (1837)	34
Assign pulse output 1 (0460-1)	43
Assign simulation process variable (1810)	71
Asymmetry (2913)	22
Bootloader revision (0073)	70
Build no. software (0079)	70
Calibration factor (2920)	38
Configuration counter (0233)	69
Control Totalizer 1 to n (0912-1 to n)	55
Damping output 1 (0477-1)	50
Date/time format (2812)	31
Day (2842)	40
Density unit (0555)	30
Device alarm simulation (0654)	73
Device name (0013)	67
Device reset (0000)	18
Device tag (0011)	66
Diagnostic event category (0738)	74
Diagnostic event simulation (0737)	74
Diagnostics 1 (0692)	61
Diagnostics 2 (0693)	61
Diagnostics 3 (0694)	62
Diagnostics 4 (0695)	63
Diagnostics 5 (0696)	63
ENP version (0012)	69
Enter access code (0003)	11
Extended order code 1 (0023)	68
Extended order code 2 (0021)	68
Extended order code 3 (0022)	69
Failure frequency	
Pulse/frequency/switch output 1 (0474-1)	52
Failure mode	
Pulse/frequency/switch output 1 (0451-1)	51

Pulse/frequency/switch output 1 (0480–1)	46	Sound velocity offset (1848)	37
Totalizer 1 to n (0901–1 to n)	56	Temperature (1853)	21
Filter options	64	Temperature damping (1886)	33
Firmware version (0010)	67	Temperature unit (0557)	28
Flow damping (1802)	32	Timestamp	59, 61, 62, 63, 64
Flow override (1839)	32	Totalizer operation mode	
Flow velocity (1852)	20	Totalizer 1 to n (0908–1 to n)	55
Frequency output simulation 1 (0472–1)	72	Totalizer overflow 1 to n (0910–1 to n)	24
Frequency value 1 (0473–1)	72	Totalizer value 1 to n (0911–1 to n)	24
Hour (2843)	40	Turbulence (2907)	23
Kinematic viscosity unit (0578)	30	Unit (0974)	57
Length unit (0551)	29	Unit totalizer 1 to n (0915–1 to n)	54
Locking status (0004)	10	Value per pulse	
Mass flow (1847)	20	Pulse/frequency/switch output 1 (0455–1)	44
Mass flow factor (1846)	37	Velocity unit (0566)	29
Mass flow offset (1841)	36	Volume flow (1838)	20
Mass flow unit (0554)	27	Volume flow factor (1832)	36
Mass unit (0574)	28	Volume flow offset (1831)	36
Maximum frequency value		Volume flow unit (0553)	25
Pulse/frequency/switch output 1 (0454–1)	48	Volume unit (0563)	27
Measuring mode		Year (2846)	39
Pulse/frequency/switch output 1 (0457–1)	45	Zero point (2921)	38
Pulse/frequency/switch output 1 (0479–1)	49	Document	
Measuring value at maximum frequency		Explanation of the structure of a parameter	
Pulse/frequency/switch output 1 (0475–1)	49	description	6
Measuring value at minimum frequency		Function	4
Pulse/frequency/switch output 1 (0476–1)	48	Structure	4
Minimum frequency value		Symbols used	6
Pulse/frequency/switch output 1 (0453–1)	47	Target group	4
Minute (2844)	41	Using the document	4
Month (2845)	39	Document function	4
Nominal diameter (2807)	38		
Off value low flow cutoff (1804)	34	E	
On value low flow cutoff (1805)	34	ENP version (Parameter)	69
Operating mode		Enter access code (Parameter)	11
Pulse/frequency/switch output 1 (0469–1)	42	Event list (Submenu)	65
Operating time (0652)	60	Event logbook (Submenu)	64
Operating time from restart (0653)	60	Extended order code 1 (Parameter)	68
Order code (0008)	68	Extended order code 2 (Parameter)	68
Output frequency 1 (0471–1)	52	Extended order code 3 (Parameter)	69
Preset value 1 to n (0913–1 to n)	56		
Previous diagnostics (0690)	59	F	
Process variable value (1811)	71	Factory settings	75
Profile factor (2909)	23	SI units	75
Pulse output 1 (0456–1)	46	US units	75
Pulse output simulation 1 (0458–1)	73	Failure frequency (Parameter)	52
Pulse value 1 (0459–1)	73	Failure mode (Parameter)	46, 51, 56
Pulse width		Filter options (Parameter)	64
Pulse/frequency/switch output 1 (0452–1)	44	Firmware version (Parameter)	67
Reset all totalizers (2806)	52	Flow damping (Parameter)	32
Response time		Flow override (Parameter)	32
Pulse/frequency/switch output 1 (0491–1)	50	Flow velocity (Parameter)	20
Reynolds number (2908)	23	Frequency output simulation 1 (Parameter)	72
Serial number (0009)	67	Frequency value 1 (Parameter)	72
Signal strength (2914)	21	Function	
Signal to noise ratio (2917)	22	see Parameter	
Software revision (0072)	70		
Sound velocity (1850)	20	H	
Sound velocity factor (1849)	37	Hour (Parameter)	40

I	
Inventory counter (Submenu)	57
K	
Kinematic viscosity unit (Parameter)	30
L	
Length unit (Parameter)	29
Locking status (Parameter)	10
Low flow cut off (Submenu)	33
M	
Mainboard module (Submenu)	69
Mass flow (Parameter)	20
Mass flow factor (Parameter)	37
Mass flow offset (Parameter)	36
Mass flow unit (Parameter)	27
Mass unit (Parameter)	28
Maximum frequency value (Parameter)	48
Measured values (Submenu)	19
Measuring mode (Parameter)	45, 49
Measuring value at maximum frequency (Parameter)	49
Measuring value at minimum frequency (Parameter)	48
Minimum frequency value (Parameter)	47
Minute (Parameter)	41
Month (Parameter)	39
N	
Nominal diameter (Parameter)	38
O	
Off value low flow cutoff (Parameter)	34
On value low flow cutoff (Parameter)	34
Operating mode (Parameter)	42
Operating time (Parameter)	60
Operating time from restart (Parameter)	60
Order code (Parameter)	68
Output (Submenu)	41
Output frequency 1 (Parameter)	52
P	
Parameter	
Structure of a parameter description	6
Preset value 1 to n (Parameter)	56
Previous diagnostics (Parameter)	59
Process parameters (Submenu)	31
Process variable adjustment (Submenu)	35
Process variable value (Parameter)	71
Process variables (Submenu)	19
Profile factor (Parameter)	23
Pulse output 1 (Parameter)	46
Pulse output simulation 1 (Parameter)	73
Pulse value 1 (Parameter)	73
Pulse width (Parameter)	44
Pulse/frequency/switch output (Submenu)	41
R	
Recalibration (Submenu)	39
Reset all totalizers (Parameter)	52
Response time (Parameter)	50
S	
Reynolds number (Parameter)	23
Sensor (Submenu)	19
Sensor adjustment (Submenu)	35
Serial number (Parameter)	67
Signal strength (Parameter)	21
Signal to noise ratio (Parameter)	22
Simulation (Submenu)	70
Software revision (Parameter)	70
Sound velocity (Parameter)	20
Sound velocity factor (Parameter)	37
Sound velocity offset (Parameter)	37
Submenu	
Administration	18
Application	52
Calibration	38
Device information	66
Diagnostic behavior	12
Diagnostic handling	12
Diagnostic list	60
Diagnostics	58
Event list	65
Event logbook	64
Inventory counter	57
Low flow cut off	33
Mainboard module	69
Measured values	19
Output	41
Process parameters	31
Process variable adjustment	35
Process variables	19
Pulse/frequency/switch output	41
Recalibration	39
Sensor	19
Sensor adjustment	35
Simulation	70
System	11
System units	25
System values	21
Totalizer	23
Totalizer 1 to n	53
System (Submenu)	11
System units (Submenu)	25
System values (Submenu)	21
T	
Target group	4
Temperature (Parameter)	21
Temperature damping (Parameter)	33
Temperature unit (Parameter)	28
Timestamp (Parameter)	59, 61, 62, 63, 64
Totalizer (Submenu)	23
Totalizer 1 to n (Submenu)	53
Totalizer operation mode (Parameter)	55
Totalizer overflow 1 to n (Parameter)	24
Totalizer value 1 to n (Parameter)	24
Turbulence (Parameter)	23

U

- Unit (Parameter) 57
Unit totalizer 1 to n (Parameter) 54

V

- Value per pulse (Parameter) 44
Velocity unit (Parameter) 29
Volume flow (Parameter) 20
Volume flow factor (Parameter) 36
Volume flow offset (Parameter) 36
Volume flow unit (Parameter) 25
Volume unit (Parameter) 27

Y

- Year (Parameter) 39

Z

- Zero point (Parameter) 38

www.addresses.endress.com
