

Description of Device Parameters

Proline Prosonic Flow 100

HART

Ultrasonic time-of-flight flowmeter




Table of contents

1 About this document	4	4 Country-specific factory settings ..	156
1.1 Document function	4	4.1 SI units	156
1.2 Target group	4	4.1.1 System units	156
1.3 Using this document	4	4.1.2 Full scale values	156
1.3.1 Information on the document structure	4	4.1.3 Output current span	156
1.3.2 Structure of a parameter description	6	4.1.4 Pulse value	156
1.4 Symbols used	6	4.1.5 On value low flow cut off	156
1.4.1 Symbols for certain types of information	6	4.2 US units	157
1.4.2 Symbols in graphics	7	4.2.1 System units	157
1.5 Documentation	7	4.2.2 Full scale values	157
1.5.1 Standard documentation	7	4.2.3 Output current span	157
1.5.2 Supplementary device-dependent documentation	7	4.2.4 Pulse value	157
		4.2.5 On value low flow cut off	158
2 Overview of the Expert operating menu	8	5 Explanation of abbreviated units ..	159
3 Description of device parameters ...	10	5.1 SI units	159
3.1 "System" submenu	13	5.2 US units	159
3.1.1 "Display" submenu	13	5.3 Imperial units	159
3.1.2 "Administration" submenu	26		
3.1.3 "Diagn. handling" submenu	31		
3.2 "Sensor" submenu	38		
3.2.1 "Measured val." submenu	38		
3.2.2 "System units" submenu	47		
3.2.3 "Process param." submenu	53		
3.2.4 "External comp." submenu	57		
3.2.5 "Sensor adjustm." submenu	58		
3.2.6 "Calibration" submenu	60		
3.3 "Output" submenu	64		
3.3.1 "Current output 1" submenu	64		
3.3.2 "PFS output" submenu	78		
3.4 "Communication" submenu	98		
3.4.1 "HART output" submenu	98		
3.4.2 "Web server" submenu	115		
3.4.3 "Diag. config." submenu	118		
3.5 "Application" submenu	123		
3.5.1 "Totalizer 1 to n" submenu	124		
3.5.2 "Inventory count." submenu	128		
3.6 "Diagnostics" submenu	129		
3.6.1 "Diagnostic list" submenu	132		
3.6.2 "Event logbook" submenu	135		
3.6.3 "Device info" submenu	137		
3.6.4 "Mainboard module" submenu	141		
3.6.5 "Sens. electronic" submenu	142		
3.6.6 "Display module" submenu	143		
3.6.7 "Min/max val." submenu	144		
3.6.8 "Heartbeat" submenu	148		
3.6.9 "Simulation" submenu	149		
		Index	160

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
Navigation path to the parameter via the operating tool
The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Prosonic Flow E 100	BA01769D

1.5.2 Supplementary device-dependent documentation

Special documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
RFID TAG	SD01565D

Contents	Documentation code
Heartbeat Technology	SD02079D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

» Expert	
Direct access (0106)	→ ↗ 10
Locking status (0004)	→ ↗ 11
Access status (0005)	→ ↗ 12
Ent. access code (0003)	→ ↗ 13
▶ System	→ ↗ 13
▶ Display	→ ↗ 13
▶ Diagn. handling	→ ↗ 31
▶ Administration	→ ↗ 26
▶ Sensor	→ ↗ 38
▶ Measured val.	→ ↗ 38
▶ System units	→ ↗ 47
▶ Process param.	→ ↗ 53
▶ External comp.	→ ↗ 57
▶ Sensor adjustm.	→ ↗ 58
▶ Calibration	→ ↗ 60
▶ Output	→ ↗ 64
▶ Curr.output 1	→ ↗ 64
▶ PFS output 1	→ ↗ 78
▶ Communication	→ ↗ 98
▶ HART output	→ ↗ 98

▶ Web server	→ 115
▶ Diag. config.	→ 118
▶ Application	→ 123
Reset all tot. (2806)	→ 123
▶ Totalizer 1 to n	→ 124
▶ Diagnostics	→ 129
Actual diagnos. (0691)	→ 129
Prev.diagnostics (0690)	→ 130
Time fr. restart (0653)	→ 131
Operating time (0652)	→ 131
▶ Diagnostic list	→ 132
▶ Event logbook	→ 135
▶ Device info	→ 137
▶ Mainboard module	→ 141
▶ Sens. electronic	→ 142
▶ Display module	→ 143
▶ Heartbeat	→ 148
▶ Simulation	→ 149

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
Access status (0005)	→ 12
Ent. access code (0003)	→ 13
▶ System	→ 13
▶ Sensor	→ 38
▶ Output	→ 64
▶ Communication	→ 98
▶ Application	→ 123
▶ Diagnostics	→ 129

Direct access

**Navigation**

Expert → Direct access (0106)

Prerequisite

There is a local display with operating elements.

Description

Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.


User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
Example: Enter 00914 → **Assign variable** parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign variable** parameter

Locking status

Navigation

Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- Temp. locked

Additional information

Display

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7

Selection

Options	Description
Hardware locked (priority 1)	The write protection switch (DIP switch) for locking the hardware is activated on the main electronic module. This locks write access to the parameters .
Temp. locked (priority 2)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access stat.disp

Navigation	  Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Ent. access code parameter (→  13).</p> <p> For information about the Ent. access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

Access status

Navigation	  Expert → Access status (0005)
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Ent. access code parameter (→  13).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

Ent. access code**Navigation**
  Expert → Ent. access code (0003)
Description

Use this function to enter the user-specific release code to remove parameter write protection.

User entry

0 to 9 999

3.1 "System" submenu

Navigation
  Expert → System

► System	
► Display	→  13
► Diagn. handling	→  31
► Administration	→  26

3.1.1 "Display" submenu

Navigation
  Expert → System → Display

► Display	
Display language (0104)	→  14
Format display (0098)	→  15
Value 1 display (0107)	→  17
0% bargraph 1 (0123)	→  17
100% bargraph 1 (0125)	→  18
Decimal places 1 (0095)	→  18
Value 2 display (0108)	→  19
Decimal places 2 (0117)	→  19
Value 3 display (0110)	→  20

0% bargraph 3 (0124)	→ 20
100% bargraph 3 (0126)	→ 21
Decimal places 3 (0118)	→ 21
Value 4 display (0109)	→ 21
Decimal places 4 (0119)	→ 22
Display interval (0096)	→ 22
Display damping (0094)	→ 23
Header (0097)	→ 23
Header text (0112)	→ 24
Separator (0101)	→ 25
Contrast display (0105)	→ 25
Backlight (0111)	→ 25

Display language

Navigation

Expert → System → Display → Display language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano
- Nederlands *
- Portuguesa *
- Polski *
- русский язык(Ru) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *

* Visibility depends on order options or device settings

- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Viet) *
- čeština (Czech) *

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display (0098)

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

- Selection**
- 1 value, max.
 - Bargr. + 1 value
 - 2 values
 - Val. large+2val.
 - 4 values

Factory setting 1 value, max.

Additional information *Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.

-  ■ The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 22).


* Visibility depends on order options or device settings

Possible measured values shown on the local display:


"1 value, max." option



"Bagr. + 1 value" option




"2 values" option




2

"Val. large+2val." option



"4 values" option



Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Mass flow ■ Sound velocity ■ Flow velocity * ■ Temperature * ■ Volume flow ■ Curr.output 1 ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Curr.output 1 ■ SNR * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

0% bargraph 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ 0 m ³ /h ■ 0 ft ³ /h
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

100% bargraph 1



Navigation	  Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 156
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

Decimal places 1



Navigation	  Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is specified in the Value 1 display parameter (→ 17).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 19).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 17)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 47).

0% bargraph 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none">■ 0 m³/h■ 0 ft³/h
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 47).

100% bargraph 3

Navigation	Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 47).

Decimal places 3

Navigation	Expert → System → Display → Decimal places 3 (0118)
Prerequisite	A measured value is specified in the Value 3 display parameter (→ 20).
Description	Use this function to select the number of decimal places for measured value 3.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX
Additional information	<i>Description</i> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display

Navigation	Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

Decimal places 4



Navigation Expert → System → Display → Decimal places 4 (0119)

Prerequisite A measured value is specified in the **Value 4 display** parameter (→ 21).

Description Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation Expert → System → Display → Display interval (0096)

Prerequisite A local display is provided.

Description Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ■ The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

Display damping



Navigation  Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

 Damping is switched off if 0 is entered (factory setting).

Header



Navigation  Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting Device tag

1) proportional transmission behavior with first order delay

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 138).
- Free text
Is defined in the **Header text** parameter (→ 24).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 23), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Backlight

Navigation Expert → System → Display → Backlight (0111)

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

Access stat.disp

Navigation Expert → System → Display → Access stat.disp (0091)

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.

User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Ent. access code parameter (→ 26 13).</p> <p> For information about the Ent. access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p>


Display

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

3.1.2 "Administration" submenu

Navigation

 Expert → System → Administration



"Def. access code" wizard

 The **Def. access code** wizard (→ [26](#)) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Def. access code** parameter (→ [29](#)) can be found directly in the **Administration** submenu. There is no **Confirm code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code

► Def. access code

Def. access code

→ 27

Confirm code

→ 27

Def. access code**Navigation**

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→ 13).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm code**Navigation**

Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.


User entry

0 to 9 999

Factory setting	0
-----------------	---

"Reset access code" submenu

Navigation  Expert → System → Administration → Reset acc. code



Operating time

Navigation  Expert → System → Administration → Reset acc. code → Operating time (0652)

Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*
The maximum number of days is 9999, which is equivalent to 27 years.

Reset acc. code

Navigation  Expert → System → Administration → Reset acc. code → Reset acc. code (0024)

Description Use this function to enter a reset code to reset the user-specific release code to the factory setting.

User entry Character string comprising numbers, letters and special characters

Factory setting 0x00

Additional information*Description*

For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via interface CDI RJ45)
- Fieldbus

Additional parameters in the "Administration" submenu**Def. access code****Navigation**

Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the symbol.



Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→ 13).



If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Device reset**Navigation**

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery set.
- Restart device
- Rest.S-DATBackup

Factory setting

Cancel

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery set.	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Activate SW opt.**Navigation**
  Expert → System → Administration → Activate SW opt. (0029)
Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ Once the activation code has been entered, check if the new software option is displayed in the **SW option overv.** parameter (→  31).
- ↳ The new software option is active if it is displayed.

- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

- i** The software options currently enabled are displayed in the **SW option overv.** parameter (→ 31).

Web browser

- i** Once a software option has been activated, the page must be loaded again in the Web browser.

SW option overv.

Navigation   Expert → System → Administration → SW option overv. (0015)

Description Displays all the software options that are enabled in the device.

User interface

- HBT Monitoring
- HBT Verification

Additional information *Description*
 Displays all the options that are available if ordered by the customer.

"HBT Verification" option and "HBT Monitoring" option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

3.1.3 "Diagn. handling" submenu

Navigation   Expert → System → Diagn. handling

► Diagn. handling	
→ 32	
Alarm delay (0651)	
→ 32	
► Diagn. behavior	
→ 32	

Alarm delay**Navigation**

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- 832 Electronic temp.
- 833 Electronic temp.
- 834 Process temp.
- 835 Process temp.

"Diagn. behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagn. behavior** submenu (→ [32](#)).


The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook only	The device continues to measure. The diagnostic message is entered only in the Event logbook submenu (→ 32) (Event list submenu (→ 32)) and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

For a list of all the diagnostic events, see the Operating Instructions for the device
→ [7](#) → [7](#)

Navigation

Expert → System → Diagn. handling → Diagn. behavior



Diagnostic no. 443 (0659)	→ 34
Diagnostic no. 840 (0680)	→ 34
Diagnostic no. 881 (0724)	→ 35
Diagnostic no. 835 (0678)	→ 35
Diagnostic no. 834 (0677)	→ 35
Diagnostic no. 833 (0676)	→ 36
Diagnostic no. 832 (0675)	→ 36
Diagnostic no. 302 (0742)	→ 36
Diagnostic no. 125 (0775)	→ 37
Diagnostic no. 124 (0774)	→ 37
Diagnostic no. 160 (0776)	→ 38

Diagnostic no. 441 (Curr.output 1)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)
Description	Option for changing the diagnostic behavior of the diagnostic message 441 Curr.output 1 .
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 32

Diagnostic no. 442 (Freq. output)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 442 Freq. output .

Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i>  Detailed description of the options available for selection: → 32

Diagnostic no. 443 (Pulse output)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i>  Detailed description of the options available for selection: → 32

Diagnostic no. 841 (Sensor range)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 840 (0680)
Description	Option for changing the diagnostic behavior of the diagnostic message 841 Sensor range .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 32

Diagnostic no. 881 (Sen.sig. path 1 to n)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 881 (0724)
Description	Option for changing the diagnostic behavior of the diagnostic message 881 Sen.sig. path 1 to n .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 32

Diagnostic no. 835 (Process temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)
Description	Option for changing the diagnostic behavior of the diagnostic message 835 Process temp..
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 32

Diagnostic no. 834 (Process temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)
Description	Option for changing the diagnostic behavior of the diagnostic message 834 Process temp..
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning

Additional information*Selection*

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 833 (Electronic temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)

Description

Option for changing the diagnostic behavior of the diagnostic message **833 Electronic temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information*Selection*

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 832 (Electronic temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

Description

Option for changing the diagnostic behavior of the diagnostic message **832 Electronic temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information*Selection*

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 302 (Verific. active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0742)

Description

Option for changing the diagnostic behavior of the diagnostic message **302 Verific. active.**

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	 Detailed description of the options available for selection: → 32
-------------------------------	---

Diagnostic no. 125 (Rel. sound vel.)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 125 (0775)
-------------------	---

Description	Option for changing the diagnostic behavior of the diagnostic message 125 Rel. sound vel. .
--------------------	--

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	 Detailed description of the options available for selection: → 32
-------------------------------	---

Diagnostic no. 124 (Rel.sig.strength)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 124 (0774)
-------------------	---

Description	Option for changing the diagnostic behavior of the diagnostic message 124 Rel.sig.strength .
--------------------	---

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	 Detailed description of the options available for selection: → 32
-------------------------------	---

Diagnostic no. 160 (Signal path off)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)

Description

Option for changing the diagnostic behavior of the diagnostic message **160 Signal path off**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [32](#)

3.2 "Sensor" submenu

Navigation

Expert → Sensor

▶ Sensor	
▶ Measured val.	→ 38
▶ System units	→ 47
▶ Process param.	→ 53
▶ External comp.	→ 57
▶ Sensor adjustm.	→ 58
▶ Calibration	→ 60

3.2.1 "Measured val." submenu

Navigation

Expert → Sensor → Measured val.

▶ Measured val.	
▶ Process variab.	→ 39
▶ System values	→ 40

► Output values → 43

► Totalizer → 45

"Process variab." submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

► Process variab.

Volume flow (1838) → 39

Mass flow (1847) → 39

Sound velocity (1850) → 40

Flow velocity (1852) → 40

Temperature (1853) → 40

Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description

Displays the volume flow that is currently measured.

User interface

Signed floating-point number

Additional information

Dependency

 The unit is taken from the **Volume flow unit** parameter (→ 47)

Mass flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description

Displays the mass flow currently calculated.

User interface

Signed floating-point number

Additional information

Dependency

 The unit is taken from the **Mass flow unit** parameter (→ 49)

Sound velocity

Navigation   Expert → Sensor → Measured val. → Process variab. → Sound velocity (1850)

Description Displays the sound velocity currently measured.

User interface Signed floating-point number

Flow velocity

Navigation   Expert → Sensor → Measured val. → Process variab. → Flow velocity (1852)

Description Displays the flow velocity currently measured.

User interface Signed floating-point number

Temperature

Navigation   Expert → Sensor → Measured val. → Process variab. → Temperature (1853)

Description Displays the medium temperature currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [50](#))

"System values" submenu

Navigation   Expert → Sensor → Measured val. → System values

 System values	
Signal strength (2914)	→ 41
Asymmetry (2913)	→ 41
SNR (2917)	→ 42
Turbulence (2907)	→ 42

Signal strength

Navigation	 Expert → Sensor → Measured val. → System values → Signal strength (2914)
Description	Use this function to display the current signal strength.
User interface	Signed floating-point number
Additional information	<i>Description</i> A drop in the signal strength over time can be an indicator of deposit buildup on the converter or high ultrasonic damping in the gas. A very fast drop is an indication of a high concentration of CO ₂ .

Acceptance rate

Navigation	 Expert → Sensor → Measured val. → System values → Acceptance rate (2912)
Description	Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted. Multipath measuring devices only: Displays the minimum of all acceptance rates measured.
User interface	0 to 100 %

Asymmetry

Navigation	 Expert → Sensor → Measured val. → System values → Asymmetry (2913)
Prerequisite	The Dual path sensor option is selected in the Path conf. parameter parameter.
Description	Use this function to display the asymmetry of the measured values between signal path 1 and signal path 2.
User interface	Signed floating-point number
Factory setting	0 %
Additional information	<i>Limit values</i> If the value 0 is displayed, both measured values are the same. The higher the displayed value, the greater the difference between the two measured values of the signal paths.

SNR

Navigation   Expert → Sensor → Measured val. → System values → SNR (2917)

Description Use this function to display the current signal-to-noise ratio.

User interface Signed floating-point number

Additional information *Description*

A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality. A very fast drop is an indication of a high concentration of CO₂.

Turbulence

Navigation   Expert → Sensor → Measured val. → System values → Turbulence (2907)

Description Use this function to display the current turbulence.

User interface Signed floating-point number

Reynolds number

Navigation   Expert → Sensor → Measured val. → System values → Reynolds number (2908)

Description Displays the Reynolds number.

User interface Signed floating-point number

Profile factor

Navigation   Expert → Sensor → Measured val. → System values → Profile factor (2909)

Description Displays the profile factor.

The profile factor describes the correction factor applied based on the flow profile present. The more the profile deviates from even distribution, the smaller the factor.

The profile factor is used to calculate the flow rate.

User interface Signed floating-point number

"Output values" submenu**Navigation**
 Expert → Sensor → Measured val. → Output values

► Output values	
Output curr. 1 (0361-1)	→  43
Measur. curr. 1 (0366-1)	→  43
Pulse output 1 (0456-1)	→  43
Output freq. 1 (0471-1)	→  44
Switch status 1 (0461-1)	→  44

Output curr. 1**Navigation**
 Expert → Sensor → Measured val. → Output values → Output curr. 1 (0361-1)
Description

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measur. curr. 1**Navigation**
 Expert → Sensor → Measured val. → Output values → Measur. curr. 1 (0366-1)
Description

Use this function to display the actual measured value of the output current.

User interface

0 to 30 mA

Pulse output 1**Navigation**
 Expert → Sensor → Measured val. → Output values → Pulse output 1 (0456-1)
PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→  80) parameter.**Description**


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information**Description**

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 82) and **Pulse width** parameter (→ 82) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 97) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 84)) can be configured.

Output freq. 1**Navigation**

Expert → Sensor → Measured val. → Output values → Output freq. 1 (0471-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Switch status 1**Navigation**

Expert → Sensor → Measured val. → Output values → Switch status 1 (0461-1)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 80).

Description


Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

"Totalizer" submenu*Navigation* Expert → Sensor → Measured val. → Totalizer**Totalizer val. 1 to n****Navigation** Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911-1 to n)**Prerequisite**

One of the following options is selected in the **Assign variable** parameter (→  124) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information*Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Tot. overflow 1 to n** parameter if the display range is exceeded.

i In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 127).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Operation mode** parameter (→ 125).

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 125).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer val. 1** parameter: 1968457 m³
- Value in the **Tot. overflow 1** parameter: $1 \cdot 10^7$ (1 overflow) = 10 000 000 [m³]
- Current totalizer reading: 11 968 457 m³

Tot. overflow 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 124) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer val. 1 to n** parameter.

User interface

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 125).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer val. 1** parameter: 1968457 m³
- Value in the **Tot. overflow 1** parameter: $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

3.2.2 "System units" submenu

Navigation

Expert → Sensor → System units

▶ System units	
Volume flow unit (0553)	→ 47
Volume unit (0563)	→ 49
Mass flow unit (0554)	→ 49
Mass unit (0574)	→ 50
Temperature unit (0557)	→ 50
Length unit (0551)	→ 51
Velocity unit (0566)	→ 51
Density unit (0555)	→ 52
Kin. visc. unit (0578)	→ 53
Date/time format (2812)	→ 53

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ /s	■ af/s	■ gal/s (imp)
■ cm ³ /min	■ af/min	■ gal/min (imp)
■ cm ³ /h	■ af/h	■ gal/h (imp)
■ cm ³ /d	■ af/d	■ gal/d (imp)
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)
■ m ³ /s	■ fl oz/s (us)	■ bbl/s (imp;beer)
■ m ³ /min	■ fl oz/min (us)	■ bbl/min (imp;beer)
■ m ³ /h	■ fl oz/h (us)	■ bbl/h (imp;beer)
■ m ³ /d	■ fl oz/d (us)	■ bbl/d (imp;beer)
■ ml/s	■ gal/s (us)	■ bbl/s (imp;oil)
■ ml/min	■ gal/min (us)	■ bbl/min (imp;oil)
■ ml/h	■ gal/h (us)	■ bbl/h (imp;oil)
■ ml/d	■ gal/d (us)	■ bbl/d (imp;oil)
■ l/s	■ kgal/s (us)	
■ l/min	■ kgal/min (us)	
■ l/h	■ kgal/h (us)	
■ l/d	■ kgal/d (us)	
■ hl/s	■ Mgal/s (us)	
■ hl/min	■ Mgal/min (us)	
■ hl/h	■ Mgal/h (us)	
■ hl/d	■ Mgal/d (us)	
■ Ml/s	■ bbl/s (us;liq.)	
■ Ml/min	■ bbl/min (us;liq.)	
■ Ml/h	■ bbl/h (us;liq.)	
■ Ml/d	■ bbl/d (us;liq.)	
	■ bbl/s (us;beer)	
	■ bbl/min (us;beer)	
	■ bbl/h (us;beer)	
	■ bbl/d (us;beer)	
	■ bbl/s (us;oil)	
	■ bbl/min (us;oil)	
	■ bbl/h (us;oil)	
	■ bbl/d (us;oil)	
	■ bbl/s (us;tank)	
	■ bbl/min (us;tank)	
	■ bbl/h (us;tank)	
	■ bbl/d (us;tank)	

Factory setting

Country-specific:

- m³/h
- ft³/min

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  39)*Selection*
 For an explanation of the abbreviated units: →  159
Customer-specific units
 The unit for the customer-specific volume is specified in the **Volume text** parameter.

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- dm³
- ft³

Additional information*Selection*

For an explanation of the abbreviated units: → 159

Customer-specific units

The unit for the customer-specific volume is specified in the **Volume text** parameter.

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- kg/s
- kg/min
- kg/h
- kg/d
- t/h
- t/d

US units

- oz/s
- oz/min
- lb/s
- lb/min
- lb/h
- lb/d
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Result*

The selected unit applies for:
Mass flow parameter

Selection

 For an explanation of the abbreviated units: → [159](#)

Customer-specific units

 The unit for the customer-specific mass is specified in the **Mass text** parameter.

Mass unit**Navigation**

  Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

 For an explanation of the abbreviated units: → [159](#)

Customer-specific units

 The unit for the customer-specific mass is specified in the **Mass text** parameter.

Temperature unit**Navigation**

  Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.

Selection*SI units*

- °C
- K

US units

- °F
- °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Result*

The selected unit applies for:

- Temperature (→ 40)
- Maximum value (→ 148)
- Minimum value (→ 148)
- Maximum value (→ 146)
- Minimum value (→ 146)

Selection

 For an explanation of the abbreviated units: → 159

Length unit**Navigation**

 Expert → Sensor → System units → Length unit (0551)

Description

Use this function to select the unit of length for the nominal diameter.

Selection*SI units*

- m
- mm
- µm

US units

- ft
- in

Factory setting

Country-specific:

- mm
- in

Additional information*Selection*

 For an explanation of the abbreviated units: → 159

Velocity unit**Navigation**

 Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection*SI units*

m/s

US units

ft/s

Factory setting

Country-specific:

- m/s
- ft/s

Additional information*Result*

The selected unit applies for:

- Flow velocity (→ 40)
- Sound velocity (→ 40)
- Maximum value (→ 147)
- Minimum value (→ 147)
- Maximum value (→ 145)
- Minimum value (→ 145)

Selection

 For an explanation of the abbreviated units: → 159

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Selection*

- SD = specific density

The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

- SG = specific gravity

The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

 For an explanation of the abbreviated units: → 159

Customer-specific units

 The unit for the customer-specific density is specified in the **Density text** parameter.

Kin. visc. unit**Navigation**

Expert → Sensor → System units → Kin. visc. unit (0578)

Description

Use this function to select the unit for the kinematic viscosity.

Selection

SI units

- cSt
- m²/s
- St

Factory setting

Country-specific:

- m²/s
- cSt

Date/time format**Navigation**

Expert → Sensor → System units → Date/time format (2812)

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy am/pm
- mm/dd/yy hh:mm
- mm/dd/yy am/pm

Factory setting

dd.mm.yy hh:mm

Additional information

Selection

For an explanation of the abbreviated units: → [159](#)

3.2.3 "Process param." submenu

Navigation

Expert → Sensor → Process param.

Process param.	
Flow override (1839)	→ 54
Flow damping (1802)	→ 54
Temp. damping (1886)	→ 55
Low flow cut off	→ 55

Flow override**Navigation**

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized

Positive zero return can also be enabled via the Status input: **Assign stat.inp.** parameter.

Flow damping**Navigation**

Expert → Sensor → Process param. → Flow damping (1802)

Description

Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 999.9 s

Factory setting

0 s

Additional information*Description*

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased



Damping is switched off if **0** is entered (factory setting).

Result

The damping affects the following variables of the device:

- Outputs → [64](#)
- Low flow cut off → [55](#)
- Totalizers → [124](#)

Temp. damping**Navigation**

Expert → Sensor → Process param. → Temp. damping (1886)

Description

Use this function to enter the time constant for temperature damping.

User entry

0 to 999.9 s

Factory setting

10 s

"Low flow cut off" submenu*Navigation*

Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign variable (1837)	→ 56
On value (1805)	→ 56
Off value (1804)	→ 56

2) Proportional behavior with first-order lag

Assign variable

Navigation Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

Description Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow

Factory setting

Off

On value

Navigation Expert → Sensor → Process param. → Low flow cut off → On value (1805)

Prerequisite In the **Assign variable** parameter (→ 56), one of the following options is selected:

- Volume flow
- Mass flow

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → 56.

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter → 156

Additional information

Dependency

The unit depends on the process variable selected in the **Assign variable** parameter (→ 56).

Off value

Navigation Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite In the **Assign variable** parameter (→ 56), one of the following options is selected:

- Volume flow
- Mass flow

Description


Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 56.

User entry

0 to 100.0 %

Factory setting

50 %


Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.4 "External comp." submenu

Navigation

Expert → Sensor → External comp.

**Fixed density****Navigation**

Expert → Sensor → External comp. → Fixed density (1862)

PrerequisiteThe **Mass flow** option is selected in the **Assign curr.** parameter (→ 65).**Description**

Use this function to enter a fixed value for the density. The density is used to calculate the mass flow.

User entry

Positive floating-point number

Factory setting

1 000 kg/l


Additional information*User entry*

The unit is taken from the **Density unit** parameter (→ 52).

3.2.5 "Sensor adjustm." submenu

Navigation


Expert → Sensor → Sensor adjustm.



"Process variable adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm. → Variable adjust



Vol. flow offset



Navigation

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 l/h

Additional information

Description

Corrected value = (factor × value) + offset

Vol. flow factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*



Corrected value = (factor × value) + offset

Mass flow offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/h.

User entry Signed floating-point number

Factory setting 0 kg/h

Additional information *Description*



Corrected value = (factor × value) + offset

Mass flow factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)

Description Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*



Corrected value = (factor × value) + offset

S. veloc. offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. offset (1848)

Description Use this function to enter the zero point shift for the sound velocity trim. The sound velocity unit on which the shift is based is m/s.

User entry Signed floating-point number

Factory setting 0 m/s

Additional information *Description*

Corrected value = (factor × value) + offset

S. veloc. factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. factor (1849)

Description Use this function to enter a quantity factor (without time) for the sound velocity. This multiplication factor is applied over the sound velocity range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu

Navigation

Expert → Sensor → Calibration

► Calibration

Cal. factor (2920)	→ 61
Zero point (2921)	→ 61
Nominal diameter (2807)	→ 61

Cal. factor

Navigation	 Expert → Sensor → Calibration → Cal. factor (2920)
Description	Displays the current calibration factor for the sensor.
User interface	Signed floating-point number
Factory setting	1

Zero point

Navigation	 Expert → Sensor → Calibration → Zero point (2921)
Description	Displays the current zero point correction value for the sensor.
User interface	Signed floating-point number
Factory setting	0

Nominal diameter

Navigation	 Expert → Sensor → Calibration → Nominal diameter (2807)
Description	Displays the nominal diameter of the sensor.
User interface	DNxx / x"
Factory setting	Depends on the size of the sensor
Additional information	<p><i>Description</i></p>  The value is also specified on the sensor nameplate.

"Recalibration" submenu

Navigation  Expert → Sensor → Calibration → Recalibration

 Recalibration	→  62
Year (2846)	
Month (2845)	→  62

Day (2842)	→ 63
Hour (2843)	→ 63
AM/PM (2813)	→ 63
Minute (2844)	→ 64

Year**Navigation**

Expert → Sensor → Calibration → Recalibration → Year (2846)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the year of recalibration.

User entry

9 to 99

Factory setting

10

Month**Navigation**

Expert → Sensor → Calibration → Recalibration → Month (2845)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to select the month of recalibration.

Selection

- January
- February
- March
- April
- May
- June
- July
- August
- September
- October
- November
- December

Factory setting

January

Day

Navigation Expert → Sensor → Calibration → Recalibration → Day (2842)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to enter the day of the month of recalibration.

User entry 1 to 31 d

Factory setting 1 d

Hour

Navigation Expert → Sensor → Calibration → Recalibration → Hour (2843)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to enter the hour of recalibration.

User entry 0 to 23 h

Factory setting 12 h

AM/PM

Navigation Expert → Sensor → Calibration → AM/PM (2813)

Prerequisite Can be edited if Heartbeat Verification is not active.

In the **Date/time format** parameter (2812) (→ 53), the **dd.mm.yy am/pm** option or the **mm/dd/yy am/pm** option is selected.

Description Use this function to enter the morning (**AM** option) or afternoon (**PM** option) time format for counting based on the 12-hour clock.

Selection
■ AM
■ PM

Factory setting AM

Minute**Navigation**

Expert → Sensor → Calibration → Recalibration → Minute (2844)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the minutes of recalibration.

User entry

0 to 59 min


Factory setting

0 min

3.3 "Output" submenu

Navigation


Expert → Output



3.3.1 "Current output 1" submenu

Navigation

Expert → Output → Curr.output 1



Failure current (0352-1)	→ 76
Output curr. 1 (0361-1)	→ 76
Measur. curr. 1 (0366-1)	→ 77

Assign curr. 1**Navigation**

Expert → Output → Curr.output 1 → Assign curr. 1 (0359-1)

Description

Use this function to select a process variable for the current output.

Selection

- Off
- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

Factory setting

Volume flow

Current span**Navigation**

Expert → Output → Curr.output 1 → Current span (0353-1)

Description

Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

Selection

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA
- Fixed current

Factory setting

Country-specific:
 ■ 4...20 mA NAMUR
 ■ 4...20 mA US

* Visibility depends on order options or device settings

Additional information**Description**


- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 75).
- The measuring range is specified via the **0/4 mA value** parameter (→ 67) and **20 mA value** parameter (→ 68).

"Fixed current" option

- This option is used for a HART Multidrop network.
- It can only be used for the 4...20 mA HART current output (current output 1).
- The current value is set via the **Fixed current** parameter (→ 66).

Example

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:



- 1 Current span for process value
 2 Lower level for signal on alarm
 3 Upper level for signal on alarm

Selection

Options	1	2	3
4...20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US	3.9 to 20.8 mA	< 3.6 mA	> 21.95 mA
4...20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA	0 to 20.5 mA	< 0 mA	> 21.95 mA

Fixed current**Navigation**

Expert → Output → Curr.output 1 → Fixed current (0365-1)

Prerequisite

The **Fixed current** option is selected in the **Current span** parameter (→ 65).

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

0/4 mA value**Navigation**

Expert → Output → Curr.output 1 → 0/4 mA value (0367-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 65):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a value for the 0/4 mA current.

User entry

Signed floating-point number

Factory setting

0 l/h

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign curr.** parameter (→ 65). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 68).

Dependency

The unit depends on the process variable selected in the **Assign curr.** parameter (→ 65).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 65)
- Measuring mode (→ 69)
- Failure mode (→ 75)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measuring mode with **Forward flow** option

- **0/4 mA value** parameter (→ 67) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 68) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




Q = Flow

I = Current

1 = Measuring range is exceeded or undershot

Configuration example B

Measuring mode with **Forward/Reverse** option



- I* Current
- Q* Flow
- 1 Value assigned to the 0/4 mA current
- 2 Forward flow
- 3 Reverse flow

Configuration example C

Measuring mode with **Rev. flow comp.** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → 69.

20 mA value



Navigation

Expert → Output → Curr.output 1 → 20 mA value (0372-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 65):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign curr.** parameter (→ 65). In addition, the value can be greater than or

smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→ 67).

Dependency

 The unit depends on the process variable selected in the **Assign curr.** parameter (→ 65).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse** option is selected in the **Measuring mode** parameter (→ 69), different signs cannot be entered for the values of the **0/4 mA value** parameter (→ 67) and **20 mA value** parameter (→ 68). The diagnostic message **△S441 Curr.output 1** is displayed.

Configuration examples

 Observe the configuration examples for the **0/4 mA value** parameter (→ 67).

Measuring mode



Navigation

Expert → Output → Curr.output 1 → Measuring mode (0351-1)

Prerequisite

One of the following options is selected in the **Assign curr.** parameter (→ 65):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

One of the following options is selected in the **Current span** parameter (→ 65):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse
- Rev. flow comp.

Factory setting

Forward flow

* Visibility depends on order options or device settings

Additional information**Description**

i The process variable that is assigned to the current output via the **Assign curr.** parameter (→ 65) is displayed below the parameter.


"Forward flow" option

The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Both values are defined such that they are not equal to zero flow e.g.:

- 0/4 mA current value = -5 m³/h
- 20 mA current value = 10 m³/h

"Forward/Reverse" option

A0013758

- | | |
|---|--------------------------------------|
| I | Current |
| Q | Flow |
| 1 | Value assigned to the 0/4 mA current |
| 2 | Forward flow |
| 3 | Reverse flow |

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 67) and **20 mA value** parameter (→ 68) must have the same sign.
- The value for the **20 mA value** parameter (→ 68) (e.g. reverse flow) corresponds to the mirrored value for the **0/4 mA value** parameter (→ 68) (e.g. forward flow).

"Rev. flow comp." option


The **Rev. flow comp.** option is primarily used to compensate for abrupt reverse flow which can occur in connection with positive displacement pumps as a result of wear or high viscosity. The reverse flows are recorded in a buffer and balanced against forward flow the next time flow is in the forward direction.

Flow values can aggregate in the buffer in the event of prolonged and unwanted fluid reverse flow. However, these flows are not taken into consideration by the current output configuration, i.e. the reverse flow is not compensated.

If this option is set, the measuring device does not attenuate the flow signal. The flow signal is not attenuated.


*Examples of how the current output behaves***Example 1**

Defined measuring range: lower range value and upper range value with the **same** sign

**Fig 3 Measuring range**

- I Current
- Q Flow
- 1 Lower range value (value assigned to 0/4 mA current)
- 2 Upper range value (value assigned to 20 mA current)


With the following flow response:

**Fig 4 Flow response**

- Q Flow
- t Time

With **Forward flow** option


The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output:.



- I Current
- t Time

With **Forward/Reverse** option


The current output signal is independent of the direction of flow.



- I Current
- t Time

With **Rev. flow comp.** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different signs**





Fig. 5 Measuring range
 I Current
 Q Flow
1 Lower range value (value assigned to 0/4 mA current)
2 Upper range value (value assigned to 20 mA current)


With flow a (\rightarrow) outside, b (\dashrightarrow) inside the measuring range



Q Flow
 t Time
1 Lower range value (value assigned to 0/4 mA current)
2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

- a (\rightarrow): The flow components outside the scaled measuring range cannot be taken into account for signal output.
- b (\dashrightarrow): The current output signal is proportional to the process variable assigned.



A0028100


I Current
 t Time

With Forward/Reverse option

This option is not possible in this case as the values for the **0/4 mA value** parameter (\rightarrow 67) and **20 mA value** parameter (\rightarrow 68) have different signs.

With Rev. flow comp. option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0028101

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping out. 1



Navigation

Expert \rightarrow Output \rightarrow Curr.output 1 \rightarrow Damping out. 1 (0363-1)

Prerequisite

One of the following options is selected in the **Assign curr.** parameter (\rightarrow 65):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

One of the following options is selected in the **Current span** parameter (\rightarrow 65):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

* Visibility depends on order options or device settings

Description	Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	1.0 s
Additional information	<p><i>Entry</i></p> <p>Use this function to enter a time constant (PT1 element³⁾) for current output damping:</p> <ul style="list-style-type: none"> ▪ If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables. ▪ On the other hand, the current output reacts more slowly if a high time constant is entered. <p> Damping is switched off if 0 is entered (factory setting).</p>

Response time

Navigation	  Expert → Output → Curr.output 1 → Response time (0378-1)
Prerequisite	<p>One of the following options is selected in the Assign curr. parameter (→ 65):</p> <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Sound velocity ▪ Flow velocity * ▪ Temperature * ▪ Acceptance rate * ▪ Signal strength * ▪ SNR * ▪ Turbulence * ▪ Signal asymmetry * <p>One of the following options is selected in the Current span parameter (→ 65):</p> <ul style="list-style-type: none"> ▪ 4...20 mA NAMUR ▪ 4...20 mA US ▪ 4...20 mA ▪ 0...20 mA
Description	Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ▪ Current output damping → 73 and ▪ Depending on the measured variable assigned to the output. Flow damping

³⁾ proportional transmission behavior with first order delay

* Visibility depends on order options or device settings

Failure mode**Navigation**

Expert → Output → Curr.output 1 → Failure mode (0364-1)

Prerequisite

One of the following options is selected in the **Assign curr.** parameter (→ [65](#)):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

One of the following options is selected in the **Current span** parameter (→ [65](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

Factory setting

Max.

* Visibility depends on order options or device settings

Additional information**Description**

 This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  65).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  65).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (→  76).

Failure current**Navigation**

 Expert → Output → Curr.output 1 → Failure current (0352-1)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (→  75).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output curr. 1**Navigation**

 Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)

Description

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measur. curr. 1

Navigation Expert → Output → Curr.output 1 → Measur. curr. 1 (0366-1)**Description**

Use this function to display the actual measured value of the output current.

User interface

0 to 30 mA

Trim

**Navigation** Expert → Output → Curr.output 1 → Trim (0362-1)**Description**

Use this function to select the calibration mode for process-specific recalibration.

Selection

- Off
- 4 mA
- 20 mA
- Calculate
- Reset

Factory setting

Off

Additional information*Description* For a detailed description of current output trimming, see

Trim value high

**Navigation** Expert → Output → Curr.output 1 → Trim value high (0356-1)**Prerequisite**

If the sensor output adjustment is 20 mA.

Description

Use this function to enter the upper value for the trim (approx. 20 mA).

User entry

18 to 22 mA

Factory setting

20 mA

Additional information*Description* For a detailed description of current output trimming, see

Trim value low

Navigation Expert → Output → Curr.output 1 → Trim value low (0357-1)

Prerequisite If the sensor output adjustment is 4 mA.

Description Use this function to enter the lower value for the trim (approx. 4 mA).

User entry 3 to 5 mA

Factory setting 4 mA

Additional information *Description*

For a detailed description of current output trimming, see

Status

Navigation Expert → Output → Curr.output 1 → Status (0360-1)

Description Displays the status of the last output current (OutValue).

User interface 0 to 255

Factory setting 0

Additional information *Description*

A combination of bits in one byte: **76543210**

- The first two bits **7** and **6** describe the overall status.
- The middle bits **5** to **2** describe a substatus which, in turn, depends on the overall status.
- The last two bits **1** and **0** describe whether a limit has been reached.

User interface

For detailed information on interpreting display values, see the "Status of output current" section

3.3.2 "PFS output" submenu

Navigation Expert → Output → PFS output

PFS output 1
Operating mode (0469-1) → 80
Assign pulse 1 (0460-1) → 81

Value per pulse (0455-1)	→ 82
Pulse width (0452-1)	→ 82
Measuring mode (0457-1)	→ 83
Failure mode (0480-1)	→ 84
Pulse output 1 (0456-1)	→ 84
Assign freq. (0478-1)	→ 85
Min. freq. value (0453-1)	→ 85
Max. freq. value (0454-1)	→ 86
Val. at min.freq (0476-1)	→ 86
Val. at max.freq (0475-1)	→ 87
Measuring mode (0479-1)	→ 88
Damping out. 1 (0477-1)	→ 88
Response time (0491-1)	→ 89
Failure mode (0451-1)	→ 90
Failure freq. (0474-1)	→ 90
Output freq. 1 (0471-1)	→ 91
Switch out funct (0481-1)	→ 91
Assign diag. beh (0482-1)	→ 92
Assign limit (0483-1)	→ 92
Switch-on value (0466-1)	→ 94
Switch-off value (0464-1)	→ 95
Assign dir.check (0484-1)	→ 95
Assign status (0485-1)	→ 96
Switch-on delay (0467-1)	→ 96
Switch-off delay (0465-1)	→ 96

Failure mode (0486-1)	→ 97
Switch status 1 (0461-1)	→ 97
Invert outp.sig. (0470-1)	→ 97

Operating mode**Navigation**

Expert → Output → PFS output 1 → Operating mode (0469-1)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse


Additional information*"Pulse" option*

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume or mass is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s



6 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, mass flow, temperature, sound velocity, flow velocity, acceptance rate, signal asymmetry, turbulence, signal strength or signal-to-noise ratio.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz




7 *Flow-proportional frequency output*

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example


Alarm response without alarm



8 *No alarm, high level*

Example

Alarm response in case of alarm



9 *Alarm, low level*

Assign pulse 1

**Navigation**

Expert → Output → PFS output 1 → Assign pulse 1 (0460-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 80) parameter.

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow

Factory setting	Off
------------------------	-----

Value per pulse

Navigation Expert → Output → PFS output 1 → Value per pulse (0455-1)

Prerequisite In the **Operating mode** parameter (→ 80), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 81):

- Volume flow
- Mass flow

Description Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter → 156

Additional information *User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width

Navigation Expert → Output → PFS output 1 → Pulse width (0452-1)

Prerequisite In the **Operating mode** parameter (→ 80), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 81):

- Volume flow
- Mass flow


Description Use this function to enter the duration of the output pulse.

User entry 0.05 to 2 000 ms

Factory setting 100 ms

Additional information *Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1**.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- f_{\max} : $1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- Q_{\max} : $5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation

Expert → Output → PFS output 1 → Measuring mode (0457-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 81):

- Volume flow
- Mass flow

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse
- Reverse flow
- Rev. flow comp.

Factory setting

Forward flow

Additional information

Selection

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Rev. flow comp.
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



For a detailed description of the options available, see the **Measuring mode** parameter (→ 69)

Examples



For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 69)

Failure mode**Navigation**

Expert → Output → PFS output 1 → Failure mode (0480-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 81):

- Volume flow
- Mass flow

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

Selection

- Actual value
In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.
- No pulses
In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output 1**Navigation**

Expert → Output → PFS output 1 → Pulse output 1 (0456-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 80) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 82) and **Pulse width** parameter (→ 82) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0028726

- 0 Non-conductive*
- 1 Conductive*
- NC NC contact (normally closed)*
- NO NO contact (normally open)*

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 97) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 84)) can be configured.

Assign freq.



Navigation	Expert → Output → PFS output 1 → Assign freq. (0478-1)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 80) parameter.
Description	Use this function to select the process variable for the frequency output.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Sound velocity ■ Flow velocity ■ Temperature ■ Acceptance rate ■ Signal strength ■ SNR ■ Turbulence ■ Signal asymmetry
Factory setting	Off

Min. freq. value



Navigation	Expert → Output → PFS output 1 → Min. freq. value (0453-1)
Prerequisite	<p>In the Operating mode parameter (→ 80), the Frequency option is selected, and one of the following options is selected in the Assign freq. parameter (→ 85):</p> <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Sound velocity ■ Flow velocity ■ Temperature

- Acceptance rate
- Signal strength
- SNR
- Turbulence
- Signal asymmetry

Description Use this function to enter the start value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 0.0 Hz

Max. freq. value



Navigation Expert → Output → PFS output 1 → Max. freq. value (0454-1)

Prerequisite In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature
- Acceptance rate
- Signal strength
- SNR
- Turbulence
- Signal asymmetry

Description Use this function to enter the end value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 10 000.0 Hz

Val. at min.freq



Navigation Expert → Output → PFS output 1 → Val. at min.freq (0476-1)

Prerequisite In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature
- Acceptance rate
- Signal strength
- SNR
- Turbulence
- Signal asymmetry

Description	Use this function to enter the measured value for the start value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i>
	 The entry depends on the process variable selected in the Assign freq. parameter (→ 85).

Val. at max.freq

Navigation	 Expert → Output → PFS output 1 → Val. at max.freq (0475-1)
Prerequisite	In the Operating mode parameter (→ 80), the Frequency option is selected, and one of the following options is selected in the Assign freq. parameter (→ 85): <ul style="list-style-type: none">▪ Volume flow▪ Mass flow▪ Sound velocity▪ Flow velocity▪ Temperature▪ Acceptance rate▪ Signal strength▪ SNR▪ Turbulence▪ Signal asymmetry
Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Description</i> Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency. <i>Dependency</i>  The entry depends on the process variable selected in the Assign freq. parameter (→ 85).

Measuring mode



Navigation

Expert → Output → PFS output 1 → Measuring mode (0479–1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse
- Rev. flow comp.

Factory setting

Forward flow

Additional information

Selection

For a detailed description of the options available, see the **Measuring mode** parameter (→ 69)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 69)

Damping out. 1



Navigation

Expert → Output → PFS output 1 → Damping out. 1 (0477–1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal strength *
- SNR *
- Turbulence *
- Signal asymmetry *

* Visibility depends on order options or device settings

Description	Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.
User entry	0 to 999.9 s
Factory setting	0.0 s
Additional information	<p><i>User entry</i></p> <p>Use this function to enter a time constant (PT1 element⁴⁾) for frequency output damping:</p> <ul style="list-style-type: none"> ▪ If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables. ▪ On the other hand, the current output reacts more slowly if a high time constant is entered. <p> Damping is switched off if 0 is entered (factory setting).</p> <p>The frequency output is subject to separate damping that is independent of all preceding time constants.</p>

Response time

Navigation	 Expert → Output → PFS output 1 → Response time (0491-1)
Prerequisite	In the Operating mode parameter (→ 80), the Frequency option is selected, and one of the following options is selected in the Assign freq. parameter (→ 85): <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Sound velocity ▪ Flow velocity * ▪ Temperature * ▪ Acceptance rate * ▪ Signal strength * ▪ SNR * ▪ Turbulence * ▪ Signal asymmetry *
Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ▪ Damping of pulse/frequency/switch output → 73 and ▪ Depending on the measured variable assigned to the output. <ul style="list-style-type: none"> – Flow damping or – Temperature damping

⁴⁾ proportional transmission behavior with first order delay
^{*} Visibility depends on order options or device settings

Failure mode**Navigation**

Expert → Output → PFS output 1 → Failure mode (0451-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature
- Acceptance rate
- Signal strength
- SNR
- Turbulence
- Signal asymmetry

Description

Use this function to select the failure mode of the frequency output in the event of a device alarm.

Selection

- Actual value
- Defined value
- 0 Hz

Factory setting

0 Hz

Additional information*Selection*

- Actual value

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

- Defined value

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure freq. (→ 90) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

- 0 Hz

In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Failure freq.**Navigation**

Expert → Output → PFS output 1 → Failure freq. (0474-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 85):

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity

- Temperature
- Acceptance rate
- Signal strength
- SNR
- Turbulence
- Signal asymmetry

Description	Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.
User entry	0.0 to 12 500.0 Hz
Factory setting	0.0 Hz

Output freq. 1

Navigation	 Expert → Output → PFS output 1 → Output freq. 1 (0471-1)
Prerequisite	In the Operating mode parameter (→ 80), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz

Switch out funct



Navigation	 Expert → Output → PFS output 1 → Switch out funct (0481-1)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 80).
Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diag. behavior ▪ Limit ▪ Fl. direct.check ▪ Status
Factory setting	Off

Additional information*Selection*

- Off
The switch output is permanently switched off (open, non-conductive).
- On
The switch output is permanently switched on (closed, conductive).
- Diag. behavior
Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.
- Limit
Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.
- Status
Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diag. beh**Navigation** Expert → Output → PFS output 1 → Assign diag. beh (0482-1)**Prerequisite**

- In the **Operating mode** parameter (→ 80), the **Switch** option is selected.
- In the **Switch out funct** parameter (→ 91), the **Diag. behavior** option is selected.

Description

Use this function to select the diagnostic event category that is displayed for the switch output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting

Alarm

Additional information*Description*

 If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation** Expert → Output → PFS output 1 → Assign limit (0483-1)**Prerequisite**

- The **Switch** option is selected in the **Operating mode** parameter (→ 80) parameter.
- The **Limit** option is selected in the **Switch out funct** parameter (→ 91) parameter.

Description Use this function to select a process variable for the limit function.

Selection


- Off
- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature
- Signal strength
- SNR
- Turbulence
- Signal asymmetry
- Acceptance rate
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting Volume flow

Additional information *Description*

Behavior of status output when Switch-on value > Switch-off value:


- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- | | |
|---|------------------|
| 1 | Switch-on value |
| 2 | Switch-off value |
| 3 | Conductive |
| 4 | Non-conductive |
| A | Process variable |
| B | Status output |

Behavior of status output when Switch-on value < Switch-off value:


- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive



- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output 1 → Switch-on value (0466-1)

Prerequisite

- In the **Operating mode** parameter (→ 80), the **Switch** option is selected.
- In the **Switch out funct** parameter (→ 91), the **Limit** option is selected.

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³/h
- 0 ft³/h

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 92).

Switch-off value**Navigation**

Expert → Output → PFS output 1 → Switch-off value (0464-1)

Prerequisite

- In the **Operating mode** parameter (→ 80), the **Switch** option is selected.
- In the **Switch out funct** parameter (→ 91), the **Limit** option is selected.

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³/h
- 0 ft³/h

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 92).

Assign dir.check**Navigation**

Expert → Output → PFS output 1 → Assign dir.check (0484-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 80).
- The **Fl. direct.check** option is selected in the **Switch out funct** parameter (→ 91).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity

Factory setting	Volume flow
-----------------	-------------

Assign status



Navigation   Expert → Output → PFS output 1 → Assign status (0485-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [80](#)).
- The **Status** option is selected in the **Switch out funct** parameter (→ [91](#)).

Description Use this function to select a device status for the switch output.

Selection

- Off
- Low flow cut off

Factory setting Low flow cut off

Additional information *Options*
If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay



Navigation   Expert → Output → PFS output 1 → Switch-on delay (0467-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [80](#)).
- The **Limit** option is selected in the **Switch out funct** parameter (→ [91](#)).

Description Use this function to enter a delay time for switching on the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Switch-off delay



Navigation   Expert → Output → PFS output 1 → Switch-off delay (0465-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [80](#)).
- The **Limit** option is selected in the **Switch out funct** parameter (→ [91](#)).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode**Navigation**

Expert → Output → PFS output 1 → Failure mode (0486-1)

Description

Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status 1**Navigation**

Expert → Output → PFS output 1 → Switch status 1 (0461-1)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 80).

Description

Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert outp.sig.**Navigation**

Expert → Output → PFS output 1 → Invert outp.sig. (0470-1)

Description

Use this function to select whether to invert the output signal.


Selection

- No
- Yes

Factory setting No


Additional information Selection

No option (passive - negative)



A0026693

Yes option (passive - positive)




A0026692

3.4 "Communication" submenu

Navigation


Expert → Communication



3.4.1 "HART output" submenu

Navigation

Expert → Communication → HART output



"Configuration" submenu*Navigation*

Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→ 99
Device tag (0215)	→ 99
HART address (0219)	→ 100
No. of preambles (0217)	→ 100
Fieldb.writ.acc. (0273)	→ 100

HART short tag**Navigation**

Expert → Communication → HART output → Configuration → HART short tag (0220)

Description

Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

Factory setting

PROSONIC

Device tag**Navigation**

Expert → Communication → HART output → Configuration → Device tag (0215)

Description

Use this function to enter the name for the measuring point.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Prosonic Flow E 100

HART address

Navigation	Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0
Additional information	<i>Description</i> For addressing in a HART Multidrop network, the Fixed current option must be set in the Current span parameter (→ 65) (current output 1).

No. of preambles

Navigation	Expert → Communication → HART output → Configuration → No. of preambles (0217)
Description	Use this function to enter the number of preambles in the HART protocol.
User entry	2 to 20
Factory setting	5
Additional information	<i>User entry</i> As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.

Fieldb.writ.acc.

Navigation	Expert → Communication → HART output → Configuration → Fieldb.writ.acc. (0273)
Description	Use this function to restrict access to the measuring device via fieldbus (HART interface).
Selection	<ul style="list-style-type: none">■ Read + write■ Read only
Factory setting	Read + write

Additional information*Description*

If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.

Selection

- Read + write
The parameters are readable and writable.
- Read only
The parameters are only readable.

"Burst configuration 1 to n" submenu*Navigation*

Expert → Communication → HART output → Burst config.
→ Burst config. 1 to n

► Burst config.	
► Burst config. 1 to n	
Burst mode 1 to n (2032-1 to n)	→ 102
Burst command 1 to n (2031-1 to n)	→ 102
Burst variable 0 (2033)	→ 103
Burst variable 1 (2034)	→ 104
Burst variable 2 (2035)	→ 104
Burst variable 3 (2036)	→ 104
Burst variable 4 (2037)	→ 105
Burst variable 5 (2038)	→ 105
Burst variable 6 (2039)	→ 105
Burst variable 7 (2040)	→ 105
Trigger mode (2044-1 to n)	→ 106
Trigger level (2043-1 to n)	→ 106
Min. upd. per. (2042-1 to n)	→ 107
Max. upd. per. (2041-1 to n)	→ 107

Burst mode 1 to n

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst mode 1 to n (2032–1 to n)
Description	Use this function to select whether to activate the HART burst mode for burst message X.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<i>Options</i> <ul style="list-style-type: none">▪ Off The measuring device transmits data only when requested by the HART master.▪ On The measuring device transmits data regularly without being requested.

Burst command 1 to n

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst command 1 to n (2031–1 to n)
Description	Use this function to select the HART command that is sent to the HART master.
Selection	<ul style="list-style-type: none">▪ Command 1▪ Command 2▪ Command 3▪ Command 9▪ Command 33▪ Command 48
Factory setting	Command 2
Additional information	<i>Selection</i> <ul style="list-style-type: none">▪ Command 1 Read out the primary variable.▪ Command 2 Read out the current and the main measured value as a percentage.▪ Command 3 Read out the dynamic HART variables and the current.▪ Command 9 Read out the dynamic HART variables including the related status.▪ Command 33 Read out the dynamic HART variables including the related unit.▪ Command 48 Read out the complete device diagnostics. <p><i>"Command 33" option</i> The HART device variables are defined via Command 107.</p>

The following measured variables (HART device variables) can be read out:

- Volume flow
- Mass flow
- Temperature
- Totalizer 1...3
- Sound velocity
- Flow velocity
- Signal asymmetry *
- Acceptance rate *
- Turbulence
- Signal strength *
- SNR *
- Percent of range
- Measur. curr.
- Primary var (PV)
- Second.var(SV)
- Tertiary var(TV)
- Quaterna.var(QV)

Commands

-  ■ Information about the defined details of the command: HART specifications
 ■ The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 64).

Burst variable 0



Navigation

 Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 0 (2033)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Volume flow
- Mass flow
- Flow velocity
- Temperature
- Sound velocity
- Signal asymmetry *
- Acceptance rate *
- Turbulence
- Signal strength *
- SNR *
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Percent of range
- Measur. curr.
- Primary var (PV)
- Second.var(SV)
- Tertiary var(TV)
- Quaterna.var(QV)
- Not used

* Visibility depends on order options or device settings

Factory setting Volume flow

Additional information *Selection*

The **Not used** option is set if a burst message is not configured.

Burst variable 1



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 1 (2034)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 103).

Factory setting Not used

Burst variable 2



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 2 (2035)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 103).

Factory setting Not used

Burst variable 3



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 3 (2036)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 103).

Factory setting Not used

Burst variable 4

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 4 (2037)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (→ 103).
Factory setting	Not used

Burst variable 5

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 5 (2038)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (→ 103).
Factory setting	Not used

Burst variable 6

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 6 (2039)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (→ 103).
Factory setting	Not used

Burst variable 7

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 7 (2040)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (→ 103).
Factory setting	Not used

Trigger mode

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Trigger mode (2044–1 to n)

Description Use this function to select the event that triggers burst message X.

Selection

- Continuous
- Window
- Rising
- Falling
- On change

Factory setting Continuous

Additional information *Options*

- Continuous
The message is sent continuously, at least at intervals corresponding to the time frame specified in the **Burst min per** parameter (→ 107).
- Window
The message is sent if the specified measured value has changed by the value in the **Trigger level** parameter (→ 106).
- Rising
The message is sent if the specified measured value exceeds the value in the **Trigger level** parameter (→ 106).
- Falling
The message is sent if the specified measured value drops below the value in the **Trigger level** parameter (→ 106).
- On change
The message is sent if a measured value changes in the burst message.

Trigger level

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Trigger level (2043–1 to n)

Description For entering the burst trigger value.

User entry Signed floating-point number

Additional information *Description*
Together with the option selected in the **Trigger mode** parameter (→ 106) the burst trigger value determines the time of burst message X.

Min. upd. per.

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Min. upd. per. (2042–1 to n)
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	1 000 ms

Max. upd. per.

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Max. upd. per. (2041–1 to n)
Description	Use this function to enter the maximum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	2 000 ms

"Information" submenu*Navigation*

Expert → Communication → HART output → Information

▶ Information	
Device revision (0204)	→ 108
Device ID (0221)	→ 108
Device type (0209)	→ 108
Manufacturer ID (0259)	→ 109
HART revision (0205)	→ 109
HART descriptor (0212)	→ 109
HART message (0216)	→ 109
Hardware rev. (0206)	→ 110

Software rev. (0224)	→ 110
HART date code (0202)	→ 110

Device revision

Navigation	Expert → Communication → HART output → Information → Device revision (0204)
Description	Displays the device revision with which the device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x01
Additional information	<i>Description</i> The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation	Expert → Communication → HART output → Information → Device ID (0221)
Description	Use this function to view the device ID for identifying the measuring device in a HART network.
User interface	6-digit hexadecimal number
Additional information	<i>Description</i> In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	Expert → Communication → HART output → Information → Device type (0209)
Description	Displays the device type with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x5c (for Prosonic Flow E 100)

Additional information*Description*

The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID**Navigation**

Expert → Communication → HART output → Information → Manufacturer ID (0259)

Description

Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Factory setting

0x11 (for Endress+Hauser)

HART revision**Navigation**

Expert → Communication → HART output → Information → HART revision (0205)

Description

Use this function to display the HART protocol revision of the measuring device.

User interface

5 to 7

Factory setting

7

HART descriptor**Navigation**

Expert → Communication → HART output → Information → HART descriptor (0212)

Description

Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Pros.Flow E 100

HART message**Navigation**

Expert → Communication → HART output → Information → HART message (0216)

Description

Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Pros.Flow E 100

Hardware rev.

Navigation  Expert → Communication → HART output → Information → Hardware rev. (0206)

Description Displays the hardware revision of the measuring device.

User interface 0 to 30

Factory setting 1

Software rev.

Navigation  Expert → Communication → HART output → Information → Software rev. (0224)

Description Displays the software revision of the measuring device.

User interface 0 to 255

Factory setting 1

HART date code



Navigation  Expert → Communication → HART output → Information → HART date code (0202)

Description Use this function to enter the date information for individual use.

User entry Date entry format: yyyy-mm-dd

Factory setting 2009-07-20

Additional information *Example*

Device installation date

"Output" submenu*Navigation*

Expert → Communication → HART output → Output

▶ Output	
Assign PV (0234)	→ 111
Primary var (PV) (0201)	→ 112
Assign SV (0235)	→ 112
Second.var(SV) (0226)	→ 112
Assign TV (0236)	→ 113
Tertiary var(TV) (0228)	→ 113
Assign QV (0237)	→ 114
Quaterna.var(QV) (0203)	→ 114

Assign PV**Navigation**

Expert → Communication → HART output → Output → Assign PV (0234)

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Off
- Volume flow
- Mass flow
- Sound velocity
- Flow velocity *
- Temperature *
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- SNR *

Factory setting

Volume flow

* Visibility depends on order options or device settings

Primary var (PV)

Navigation  Expert → Communication → HART output → Output → Primary var (PV) (0201)

Description Displays the current measured value of the primary dynamic variable (PV).

User interface Signed floating-point number

Additional information *User interface*

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→  111).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  47).

Assign SV



Navigation  Expert → Communication → HART output → Output → Assign SV (0235)

Description Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- SNR *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting

Totalizer 1

Second.var(SV)

Navigation  Expert → Communication → HART output → Output → Second.var(SV) (0226)

Description Displays the current measured value of the secondary dynamic variable (SV).

User interface Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (→ 112).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

Assign TV**Navigation**

Expert → Communication → HART output → Output → Assign TV (0236)

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- SNR *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting

Totalizer 2

Tertiary var(TV)**Navigation**

Expert → Communication → HART output → Output → Tertiary var(TV) (0228)

Description

Displays the current measured value of the tertiary dynamic variable (TV).

User interface

Signed floating-point number

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign TV** parameter (→ 113).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

* Visibility depends on order options or device settings

Assign QV**Navigation**

Expert → Communication → HART output → Output → Assign QV (0237)

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Acceptance rate *
- Signal asymmetry *
- Turbulence
- Signal strength *
- SNR *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting

Totalizer 3

Quaterna.var(QV)**Navigation**

Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)

Description

Displays the current measured value of the quaternary dynamic variable (QV).

User interface

Signed floating-point number

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→ 114).

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

* Visibility depends on order options or device settings

3.4.2 "Web server" submenu

Navigation

Expert → Communication → Web server

▶ Web server	
Webserv.language (7221)	→ 115
MAC Address (7214)	→ 116
DHCP client (7212)	→ 116
IP address (7209)	→ 116
Subnet mask (7211)	→ 117
Default gateway (7210)	→ 117
Webserver funct. (7222)	→ 117
Login page (7273)	→ 118

Webserv.language

Navigation

Expert → Communication → Web server → Webserv.language (7221)

Description

Use this function to select the Web server language setting.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык(Ru) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Ara) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Viet) *
- čeština (Czech) *

* Visibility depends on order options or device settings

Factory setting English

MAC Address

Navigation	  Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁵⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format 00:07:05:10:01:5F

DHCP client



Navigation	  Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<i>Result</i> If the DHCP client functionality of the Web server is activated, the IP address (→  116), Subnet mask (→  117) and Default gateway (→  117) are set automatically.  Identification is via the MAC address of the measuring device.

IP address



Navigation	  Expert → Communication → Web server → IP address (7209)
Description	Displays the IP address of the device's web server.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

5) Media Access Control

Subnet mask

Navigation Expert → Communication → Web server → Subnet mask (7211)

Description Displays the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

Default gateway

Navigation Expert → Communication → Web server → Default gateway (7210)

Description Displays the default gateway.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 0.0.0.0

Webserver funct.

Navigation Expert → Communication → Web server → Webserver funct. (7222)

Description Use this function to switch the Web server on and off.

Selection

- Off
- HTML Off
- On

Factory setting On

Additional information *Description*

Once disabled, the Webserver funct. can only be re-enabled via the local display or the operating tool FieldCare.

Options

Option	Description
Off	<ul style="list-style-type: none"> ▪ The web server is completely disabled. ▪ Port 80 is locked.
HTML Off	The HTML version of the web server is not available.
On	<ul style="list-style-type: none"> ▪ The complete functionality of the web server is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Expert → Communication → Web server → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.4.3 "Diag. config." submenu

For a list of all the diagnostic events, see the Operating Instructions for the device

Assign a category to the particular diagnostic event:

- **Failure (F)** option
A device error has occurred. The measured value is no longer valid.
- **Funct. check (C)** option
The device is in service mode (e.g. during a simulation).
- **Out of spec. (S)** option
The device is being operated:
 - Outside its technical specification limits (e.g. outside the process temperature range)
 - Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
- **Mainten. req.(M)** option
Maintenance is required. The measured value is still valid.
- **No effect (N)** option
Has no effect on the condensed status.

Navigation

Expert → Communication → Diag. config.

► Diag. config.	
Event category 124 (0270)	→ 119
Event category 125 (0271)	→ 119
Event category 160 (0272)	→ 120
Event category 441 (0210)	→ 120
Event category 442 (0230)	→ 120
Event category 443 (0231)	→ 121
Event category 832 (0218)	→ 121

Event category 833 (0225)	→ 122
Event category 834 (0227)	→ 122
Event category 835 (0229)	→ 122
Event category 840 (0267)	→ 123

Event category 124 (Rel.sig.strength)

Navigation Expert → Communication → Diag. config. → Event category 124 (0270)

Description Use this function to select a category for the diagnostic message **124 Rel.sig.strength**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information For a detailed description of the event categories available for selection:

Event category 125 (Rel. sound vel.)

Navigation Expert → Communication → Diag. config. → Event category 125 (0271)

Description Use this function to select a category for the diagnostic message **125 Rel. sound vel.**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information For a detailed description of the event categories available for selection:

Event category 160 (Signal path off)

Navigation	Expert → Communication → Diag. config. → Event category 160 (0272)
Description	Use this function to select a category for the diagnostic message 160 Signal path off .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Mainten. req.(M)
Additional information	For a detailed description of the event categories available for selection:

Event category 441 (Curr.output 1 to n)

Navigation	Expert → Communication → Diag. config. → Event category 441 (0210)
Description	Use this function to select a category for the diagnostic message 441 Curr.output 1 to n .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	<i>Selection</i> For a detailed description of the event categories available for selection:

Event category 442 (Freq. output)

Navigation	Expert → Communication → Diag. config. → Event category 442 (0230)
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select the category assigned to diagnostic message 442 Freq. output .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)

Factory setting Out of spec. (S)

Additional information *Selection*



For a detailed description of the event categories available for selection:

Event category 443 (Pulse output)



Navigation Expert → Communication → Diag. config. → Event category 443 (0231)

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select the category assigned to diagnostic message **443 Pulse output**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information *Selection*



For a detailed description of the event categories available for selection:

Event category 832 (Electronic temp.)



Navigation Expert → Communication → Diag. config. → Event category 832 (0218)

Description Use this function to select a category for the diagnostic message **832 Electronic temp..**

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information *Selection*



For a detailed description of the event categories available for selection:

Event category 833 (Electronic temp.)**Navigation**

Expert → Communication → Diag. config. → Event category 833 (0225)

Description

Use this option to select a category for the diagnostic message **833 Electronic temp..**

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information

Selection

For a detailed description of the event categories available for selection:

Event category 834 (Process temp.)**Navigation**

Expert → Communication → Diag. config. → Event category 834 (0227)

Description

Use this option to select a category for the diagnostic message **834 Process temp..**

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information

Selection

For a detailed description of the event categories available for selection:

Event category 835 (Process temp.)**Navigation**

Expert → Communication → Diag. config. → Event category 835 (0229)

Description

Use this option to select a category for the diagnostic message **835 Process temp..**

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information*Selection*

For a detailed description of the event categories available for selection:

**Event category 841 (Sensor range)****Navigation**

Expert → Communication → Diag. config. → Event category 840 (0267)

Description

Use this function to select a category for the diagnostic message **841 Sensor range**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information


For a detailed description of the event categories available for selection:



3.5 "Application" submenu

Navigation

Expert → Application

**Reset all tot.****Navigation**

Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting


Cancel

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.5.1 "Totalizer 1 to n" submenu*Navigation*

Expert → Application → Totalizer 1 to n

**Assign variable****Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (0914-1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only **Assign variable** parameter (→ 124) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Unit totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 124) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ 124).

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- ft³

Additional information*Description*

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 47).

Selection

The selection is dependent on the process variable selected in the **Assign variable** parameter (→ 124).

Operation mode**Navigation**

Expert → Application → Totalizer 1 to n → Operation mode (0908–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 124) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward total
- Reverse total

Factory setting Net flow total

Additional information *Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward total
Only the flow in the forward flow direction is totalized.
- Reverse total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Tot. 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912-1 to n)

Prerequisite One of the following options is selected in the **Assign variable** parameter (→ 124) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset+totalize
- Hold

Factory setting Totalize

Additional information *Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset+totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.

Preset value 1 to n

Navigation	  Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913-1 to n)
Prerequisite	One of the following options is selected in the Assign variable parameter (→ 124) of the Totalizer 1 to n submenu: <ul style="list-style-type: none">▪ Volume flow▪ Mass flow
Description	Use this function to enter a start value for the Totalizer 1 to n.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none">▪ 0 m³▪ 0 ft³
Additional information	<i>User entry</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 125). <i>Example</i> This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode



Navigation	  Expert → Application → Totalizer 1 to n → Failure mode (0901-1 to n)
Prerequisite	One of the following options is selected in the Assign variable parameter (→ 124) of the Totalizer 1 to n submenu: <ul style="list-style-type: none">▪ Volume flow▪ Mass flow
Description	Use this function to select how a totalizer behaves in the event of a device alarm.
Selection	<ul style="list-style-type: none">▪ Stop▪ Actual value▪ Last valid value
Factory setting	Stop

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

■ Stop

The totalizer is stopped in the event of a device alarm.

■ Actual value


The totalizer continues to count based on the actual measured value; the device alarm is ignored.

■ Last valid value

The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.5.2 "Inventory count." submenu*Navigation*

Expert → Application → Inventory count.



Unit

Navigation

Expert → Application → Inventory count. → Unit (0974)

Description

Displays the unit of the inventory counter.

User interface*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Additional information*Description*

The parameter cannot be configured or reset.

3.6 "Diagnostics" submenu

Navigation

Expert → Diagnostics

▶ Diagnostics	
Actual diagnos. (0691)	→ 129
Timestamp (0667)	→ 130
Prev.diagnostics (0690)	→ 130
Timestamp (0672)	→ 131
Time fr. restart (0653)	→ 131
Operating time (0652)	→ 131
▶ Diagnostic list	→ 132
▶ Event logbook	→ 135
▶ Device info	→ 137
▶ Mainboard module	→ 141
▶ Sens. electronic	→ 142
▶ Display module	→ 143
▶ Heartbeat	→ 148
▶ Simulation	→ 149

Actual diagnos.

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*

 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→  132).

Example

For the display format:
 F271 Main electronics

Timestamp

Navigation  Expert → Diagnostics → Timestamp

Description Displays the operating time when the current diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

 The diagnostic message can be viewed via the **Actual diagnos.** parameter (→  129).

Example

For the display format:
24d12h13m00s

Prev.diagnostics

Navigation   Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite Two diagnostic events have already occurred.

Description Displays the diagnostic message that occurred before the current message.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Example*

For the display format:
 F271 Main electronics

Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Prev.diagnostics parameter (→  130).
	<i>Example</i> For the display format: 24d12h13m00s

Time fr. restart

Navigation	  Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)


Operating time

Navigation	  Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.6.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Examples

For the display format:

- F271 Main electronics
- F276 I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

Display

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 132).

Example

For the display format:

24d12h13m00s

Diagnostics 2

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  F271 Main electronics ■  F276 I/O module

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the second-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 2 parameter (→  133). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 3

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Displays the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  F271 Main electronics ■  F276 I/O module

Timestamp**Navigation**

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 3** parameter (→ 133).

Example

For the display format:
24d12h13m00s

Diagnostics 4**Navigation**

█ █ Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)

Description

Displays the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- ⓘ F271 Main electronics
- ⓘ F276 I/O module

Timestamp**Navigation**

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 134).

Example

For the display format:
24d12h13m00s

Diagnostics 5


Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)
Description	Displays the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  F271 Main electronics ▪  F276 I/O module

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fifth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 5 parameter (→  135).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

3.6.2 "Event logbook" submenu

Navigation  Expert → Diagnostics → Event logbook



Filter options**Navigation**

Diagram: Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information**Description**

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
 - F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu


i The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation

Diagram: Expert → Diagnostics → Event logbook → Event list



Event list**Navigation**

Diagram: Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter.

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ⊗F271 Main electronics
⊖ 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.6.3 "Device info" submenu

Navigation

 Expert → Diagnostics → Device info

► Device info	
Device tag (0011)	→  138
Serial number (0009)	→  138
Firmware version (0010)	→  138
Device name (0013)	→  139
Order code (0008)	→  139
Ext. order cd. 1 (0023)	→  139
Ext. order cd. 2 (0021)	→  140
Ext. order cd. 3 (0022)	→  140
Config. counter (0233)	→  140
ENP version (0012)	→  140

Device tag

Navigation	  Expert → Diagnostics → Device info → Device tag (0011)
Description	Displays a unique name for the measuring point so it can be identified quickly within the plant.
User interface	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	Prosonic Flow E 100

Serial number

Navigation	  Expert → Diagnostics → Device info → Serial number (0009)
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>
	 Uses of the serial number <ul style="list-style-type: none">▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser.▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation	  Expert → Diagnostics → Device info → Firmware version (0010)
Description	Displays the device firmware version installed.
User interface	Character string in the format xx.yy.zz
Additional information	<i>Display</i>

-  The Firmware version is also located:
 - On the title page of the Operating instructions
 - On the transmitter nameplate

Device name

Navigation   Expert → Diagnostics → Device info → Device name (0013)

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Factory setting Pros.Flow E 100

Order code

Navigation   Expert → Diagnostics → Device info → Order code (0008)

Description Displays the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information *Description*

 The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Ext. order cd. 1

Navigation   Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface Character string

Additional information *Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Ext. order cd. 2

Navigation Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description Displays the second part of the extended order code.

User interface Character string

Additional information For additional information, see **Ext. order cd. 1** parameter (→ 139)

Ext. order cd. 3

Navigation Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description Displays the third part of the extended order code.

User interface Character string

Additional information For additional information, see **Ext. order cd. 1** parameter (→ 139)

Config. counter

Navigation Expert → Diagnostics → Device info → Config. counter (0233)

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

ENP version

Navigation Expert → Diagnostics → Device info → ENP version (0012)

Description Displays the version of the electronic nameplate.

User interface Character string

Factory setting 2.02.00


Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.6.4 "Mainboard module" submenu

Navigation

Expert → Diagnostics → Mainboard module



Software rev.

Navigation

Expert → Diagnostics → Mainboard module → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. softw.

Navigation

Expert → Diagnostics → Mainboard module → Build no. softw. (0079)

Description

Displays the software build number of the module.

User interface

Positive integer

Bootloader rev.

Navigation

Expert → Diagnostics → Mainboard module → Bootloader rev. (0073)

Description

Displays the bootloader revision of the software.


User interface

Positive integer

3.6.5 "Sens. electronic" submenu

Navigation

Expert → Diagnostics → Sens. electronic



Software rev.

Navigation

Expert → Diagnostics → Sens. electronic → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. softw.

Navigation

Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description

Displays the software build number of the module.

User interface

Positive integer

Bootloader rev.

Navigation

Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)

Description

Displays the bootloader revision of the software.


User interface

Positive integer

3.6.6 "Display module" submenu

Navigation

Expert → Diagnostics → Display module



Software rev.

Navigation

Expert → Diagnostics → Display module → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. softw.

Navigation

Expert → Diagnostics → Display module → Build no. softw. (0079)

Description

Displays the software build number of the module.

User interface

Positive integer

Bootloader rev.

Navigation

Expert → Diagnostics → Display module → Bootloader rev. (0073)

Description

Displays the bootloader revision of the software.

User interface

Positive integer

3.6.7 "Min/max val." submenu

Navigation

Expert → Diagnostics → Min/max val.

► Min/max val.

Reset min/max



Navigation

Expert → Diagnostics → Min/max val. → Reset min/max (5647)

Description

Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection

Cancel

Factory setting

Cancel

"Meas. point 1" submenu

Navigation

Expert → Diagnostics → Min/max val. → Meas. point 1

► Meas. point 1

Reset min/max (2922-1)

→ 144

Reset min/max



Navigation

Expert → Diagnostics → Min/max val. → Meas. point 1 → Reset min/max (2922-1)

Description

Use this function to select the peakhold indicators that are to be reset.

Selection


- Cancel
- Flow velocity
- Sound velocity
- Signal strength
- SNR
- Turbulence
- Acceptance rate
- Asymmetry

Factory setting

Cancel

*"Sound velocity" submenu**Navigation*

Expert → Diagnostics → Min/max val. → Meas. point 1 → Sound velocity

**Maximum value****Navigation**

Expert → Diagnostics → Min/max val. → Meas. point 1 → Sound velocity
→ Maximum value (2968)

Description

Maximum value of sound velocity since the last reset.

User interface

Signed floating-point number

Factory setting

0 m/s

Minimum value**Navigation**

Expert → Diagnostics → Min/max val. → Meas. point 1 → Sound velocity
→ Minimum value (2969)

Description

Minimum value of sound velocity since the last reset.

User interface


Signed floating-point number

Factory setting

0 m/s

*"Sensor elec.temp" submenu**Navigation*

Expert → Diagnostics → Min/max val. → Meas. point 1 → Sensor elec.temp



Maximum value


Navigation	  Expert → Diagnostics → Min/max val. → Meas. point 1 → Sensor elec.temp → Maximum value (3020)
Description	Maximum value of sensor electronic temperature since the last reset.
User interface	Signed floating-point number
Factory setting	Positive floating-point number

Minimum value

Navigation	  Expert → Diagnostics → Min/max val. → Meas. point 1 → Sensor elec.temp → Minimum value (3021)
Description	Minimum value of sensor electronic temperature since the last reset.
User interface	Signed floating-point number
Factory setting	Negative floating-point number

"Signal strength" submenu

Navigation   Expert → Diagnostics → Min/max val. → Meas. point 1 → Signal strength



Maximum value


Navigation	  Expert → Diagnostics → Min/max val. → Meas. point 1 → Signal strength → Maximum value (2972)
Description	Maximum value of signal strength since the last reset.
User interface	Signed floating-point number
Factory setting	0 dB

Minimum value

Navigation	Expert → Diagnostics → Min/max val. → Meas. point 1 → Signal strength → Minimum value (2973)
Description	Minimum value of signal strength since the last reset.
User interface	Signed floating-point number
Factory setting	0 dB

"Flow velocity" submenu

Navigation Expert → Diagnostics → Min/max val. → Meas. point 1 → Flow velocity



Maximum value

Navigation	Expert → Diagnostics → Min/max val. → Meas. point 1 → Flow velocity → Maximum value (2911)
Description	Maximum value of flow velocity since the last reset.
User interface	Signed floating-point number
Factory setting	0 m/s


Minimum value

Navigation	Expert → Diagnostics → Min/max val. → Meas. point 1 → Flow velocity → Minimum value (2918)
Description	Minimum value of flow velocity since the last reset.
User interface	Signed floating-point number

Factory setting 0 m/s

"Medium temp." submenu

Navigation  Expert → Diagnostics → Min/max val. → Meas. point 1
→ Medium temp.



Maximum value

Navigation  Expert → Diagnostics → Min/max val. → Meas. point 1 → Medium temp.
→ Maximum value (2963)

Description Maximum value of medium temperature since the last reset.

User interface Signed floating-point number

Factory setting Positive floating-point number

Minimum value

Navigation  Expert → Diagnostics → Min/max val. → Meas. point 1 → Medium temp.
→ Minimum value (2950)


Description Minimum value of medium temperature since the last reset.

User interface Signed floating-point number


Factory setting Negative floating-point number

3.6.8 "Heartbeat" submenu

 For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device

Navigation Expert → Diagnostics → Heartbeat

3.6.9 "Simulation" submenu

Navigation Expert → Diagnostics → Simulation

Assign proc.var.**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature

Factory setting

Off

Additional information*Description*

The simulation value of the process variable selected is defined in the **Proc. var. value** parameter (→ 150).

Proc. var. value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

In the **Assign proc.var.** parameter (→ 150), one of the following options is selected:

- Volume flow
- Mass flow
- Sound velocity
- Flow velocity
- Temperature *

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

* Visibility depends on order options or device settings

Curr.out. 1 sim.**Navigation**

Diagram: Expert → Diagnostics → Simulation → Curr.out. 1 sim. (0354-1)

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is specified in the **Value curr.out 1** parameter (→ [151](#)).

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value curr.out 1**Navigation**

Diagram: Expert → Diagnostics → Simulation → Value curr.out 1 (0355-1)

Prerequisite

In the **Curr.out. 1 sim.** parameter, the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

0 to 22.5 mA

FreqOutputSim 1**Navigation**

Diagram: Expert → Diagnostics → Simulation → FreqOutputSim 1 (0472-1)

Prerequisite

In the **Operating mode** parameter (→ [80](#)), the **Frequency** option is selected.

Description

Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting	Off
Additional information	<i>Description</i>
	 The desired simulation value is defined in the Freq value parameter (→ 152).

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Freq value 1



Navigation	 Expert → Diagnostics → Simulation → Freq value 1 (0473-1)
Prerequisite	In the FreqOutputSim parameter (→ 151), the On option is selected.
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.
User entry	0.0 to 12 500.0 Hz

Puls.outp.sim. 1



Navigation	 Expert → Diagnostics → Simulation → Puls.outp.sim. 1 (0458-1)
Prerequisite	In the Operating mode parameter (→ 80), the Pulse option is selected.
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none">▪ Off▪ Fixed value▪ Down-count. val.
Factory setting	Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value** parameter (→ 153).

Selection

- Off

Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Fixed value

Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 82).

- Down-count. val.

The pulses specified in the **Pulse value** parameter (→ 153) are output.

Pulse value 1**Navigation**

Expert → Diagnostics → Simulation → Pulse value 1 (0459-1)

Prerequisite

In the **Puls.outp.sim.** parameter (→ 152), the **Down-count. val.** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch sim. 1**Navigation**

Expert → Diagnostics → Simulation → Switch sim. 1 (0462-1)

Prerequisite

In the **Operating mode** parameter (→ 80), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Switch status** parameter (→ 154).

Selection

- Off

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- On

Switch simulation is active.

Switch status 1**Navigation**

Expert → Diagnostics → Simulation → Switch status 1 (0463-1)

Prerequisite

In the **Switch sim.** parameter (→ 153) **Switch sim. 1 to n** parameter **Switch sim. 1 to n** parameter, the **On** option is selected.

Description

Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information*Selection*

- Open

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Closed

Switch simulation is active.

Dev. alarm sim.**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Event category

Navigation Expert → Diagnostics → Simulation → Event category (0738)

Description Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diag. event sim.** parameter (→ 155).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting Process

Diag. event sim.

Navigation Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*



For the simulation, you can choose from the diagnostic events of the category selected in the **Event category** parameter (→ 155).

4 Country-specific factory settings

4.1 SI units

i Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Velocity	m/s
Temperature	°C
Length	mm

4.1.2 Full scale values

i The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [mm]	[dm ³ /min]
50	720
65	1 200
80	1 680
100	2 880
150	6 360

4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
------------------	------------------

4.1.4 Pulse value

Nominal diameter [mm]	[dm ³ /pulse]
50	3
65	4
80	6
100	10
150	25

4.1.5 On value low flow cut off

i The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	Switch-on point ($v \sim 0.1 \text{ m/s}$) [dm 3 /min]
50	14.4
65	24.0
80	33.6
100	57.6
150	127.2

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft 3
Volume flow	ft 3 /min
Velocity	ft/s
Temperature	°F
Length	in

4.2.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [in]	[gal/min]
2	190
2 ½	317
3	444
4	761
6	1680

4.2.3 Output current span

Current output 1	4 to 20 mA US
------------------	---------------

4.2.4 Pulse value

Nominal diameter [in]	[gal/pulse]
2	0.8
2 ½	1.1
3	1.6

Nominal diameter [in]	[gal/pulse]
4	2.6
6	6.6

4.2.5 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	Switch-on point ($v \sim 0.1 \text{ m/s}$) [dm 3 /min]
2	3.8
2 ½	6.3
3	8.9
4	15.2
6	33.6

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Velocity	m/s	Meter/time unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Temperature	°C , K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Velocity	ft/s	Foot/time unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	ft ³	Cubic foot
Volume flow	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

- 0/4 mA value (Parameter) 67
0% bargraph value 1 (Parameter) 17
0% bargraph value 3 (Parameter) 20
20 mA value (Parameter) 68
100% bargraph value 1 (Parameter) 18
100% bargraph value 3 (Parameter) 21

A

- Acceptance rate (Parameter) 41
Access status (Parameter) 12
Access status display (Parameter) 12, 25
Activate SW option (Parameter) 30
Actual diagnostics (Parameter) 129
Administration (Submenu) 26
Alarm delay (Parameter) 32
AM/PM (Parameter) 63
Application (Submenu) 123
Assign behavior of diagnostic no. 124 (Parameter) 37
Assign behavior of diagnostic no. 125 (Parameter) 37
Assign behavior of diagnostic no. 160 (Parameter) 38
Assign behavior of diagnostic no. 302 (Parameter) 36
Assign behavior of diagnostic no. 441 (Parameter) 33
Assign behavior of diagnostic no. 442 (Parameter) 33
Assign behavior of diagnostic no. 443 (Parameter) 34
Assign behavior of diagnostic no. 832 (Parameter) 36
Assign behavior of diagnostic no. 833 (Parameter) 36
Assign behavior of diagnostic no. 834 (Parameter) 35
Assign behavior of diagnostic no. 835 (Parameter) 35
Assign behavior of diagnostic no. 840 (Parameter) 34
Assign behavior of diagnostic no. 881 (Parameter) 35
Assign current output 1 (Parameter) 65
Assign diagnostic behavior (Parameter) 92
Assign flow direction check (Parameter) 95
Assign frequency output (Parameter) 85
Assign limit (Parameter) 92
Assign process variable (Parameter) 56, 124
Assign pulse output 1 (Parameter) 81
Assign PV (Parameter) 111
Assign QV (Parameter) 114
Assign simulation process variable (Parameter) 150
Assign status (Parameter) 96
Assign SV (Parameter) 112
Assign TV (Parameter) 113
Asymmetry (Parameter) 41

B

- Backlight (Parameter) 25
Bootloader revision (Parameter) 141, 142, 143
Build no. software (Parameter) 141, 142, 143
Burst command 1 to n (Parameter) 102
Burst configuration 1 to n (Submenu) 101
Burst mode 1 to n (Parameter) 102
Burst trigger level (Parameter) 106
Burst trigger mode (Parameter) 106
Burst variable 0 (Parameter) 103

- Burst variable 1 (Parameter) 104
Burst variable 2 (Parameter) 104
Burst variable 3 (Parameter) 104
Burst variable 4 (Parameter) 105
Burst variable 5 (Parameter) 105
Burst variable 6 (Parameter) 105
Burst variable 7 (Parameter) 105

C

- Calibration (Submenu) 60
Calibration factor (Parameter) 61
Communication (Submenu) 98
Configuration (Submenu) 99
Configuration counter (Parameter) 140
Confirm access code (Parameter) 27
Contrast display (Parameter) 25
Control Totalizer 1 to n (Parameter) 126
Current output 1 (Submenu) 64
Current output 1 simulation (Parameter) 151
Current span (Parameter) 65

D

- Damping output 1 (Parameter) 73, 88
Date/time format (Parameter) 53
Day (Parameter) 63
Decimal places 1 (Parameter) 18
Decimal places 2 (Parameter) 19
Decimal places 3 (Parameter) 21
Decimal places 4 (Parameter) 22
Default gateway (Parameter) 117
Define access code (Parameter) 27, 29
Define access code (Wizard) 26
Density unit (Parameter) 52
Device alarm simulation (Parameter) 154
Device ID (Parameter) 108
Device information (Submenu) 137
Device name (Parameter) 139
Device reset (Parameter) 29
Device revision (Parameter) 108
Device tag (Parameter) 99, 138
Device type (Parameter) 108
DHCP client (Parameter) 116
Diagnostic behavior (Submenu) 32
Diagnostic configuration (Submenu) 118
Diagnostic event category (Parameter) 155
Diagnostic event simulation (Parameter) 155
Diagnostic handling (Submenu) 31
Diagnostic list (Submenu) 132
Diagnostics (Submenu) 129
Diagnostics 1 (Parameter) 132
Diagnostics 2 (Parameter) 133
Diagnostics 3 (Parameter) 133
Diagnostics 4 (Parameter) 134
Diagnostics 5 (Parameter) 135

Direct access	Burst variable 0
0/4 mA value	Burst configuration 1 to n (2033)
Current output 1 (0367-1)	67
0% bargraph value 1 (0123)	17
0% bargraph value 3 (0124)	20
20 mA value	
Current output 1 (0372-1)	68
100% bargraph value 1 (0125)	18
100% bargraph value 3 (0126)	21
Acceptance rate (2912)	41
Access status (0005)	12
Access status display (0091)	12, 25
Activate SW option (0029)	30
Actual diagnostics (0691)	129
Alarm delay (0651)	32
AM/PM (2813)	63
Assign behavior of diagnostic no. 124 (0774)	37
Assign behavior of diagnostic no. 125 (0775)	37
Assign behavior of diagnostic no. 160 (0776)	38
Assign behavior of diagnostic no. 302 (0742)	36
Assign behavior of diagnostic no. 441 (0657)	33
Assign behavior of diagnostic no. 442 (0658)	33
Assign behavior of diagnostic no. 443 (0659)	34
Assign behavior of diagnostic no. 832 (0675)	36
Assign behavior of diagnostic no. 833 (0676)	36
Assign behavior of diagnostic no. 834 (0677)	35
Assign behavior of diagnostic no. 835 (0678)	35
Assign behavior of diagnostic no. 840 (0680)	34
Assign behavior of diagnostic no. 881 (0724)	35
Assign current output 1 (0359-1)	65
Assign diagnostic behavior	
Pulse/frequency/switch output 1 (0482-1) ...	92
Assign flow direction check	
Pulse/frequency/switch output 1 (0484-1) ...	95
Assign frequency output	
Pulse/frequency/switch output 1 (0478-1) ...	85
Assign limit	
Pulse/frequency/switch output 1 (0483-1) ...	92
Assign process variable	
Totalizer 1 to n (0914-1 to n)	124
Assign process variable (1837)	56
Assign pulse output 1 (0460-1)	81
Assign PV (0234)	111
Assign QV (0237)	114
Assign simulation process variable (1810)	150
Assign status	
Pulse/frequency/switch output 1 (0485-1) ...	96
Assign SV (0235)	112
Assign TV (0236)	113
Asymmetry (2913)	41
Backlight (0111)	25
Bootloader revision (0073)	141, 142, 143
Build no. software (0079)	141, 142, 143
Burst command 1 to n (2031-1 to n)	102
Burst mode 1 to n (2032-1 to n)	102
Burst trigger level	
Burst configuration 1 to n (2043-1 to n) ...	106
Burst trigger mode	
Burst configuration 1 to n (2044-1 to n) ...	106
Burst variable 1	
Burst configuration 1 to n (2034)	104
Burst variable 2	
Burst configuration 1 to n (2035)	104
Burst variable 3	
Burst configuration 1 to n (2036)	104
Burst variable 4	
Burst configuration 1 to n (2037)	105
Burst variable 5	
Burst configuration 1 to n (2038)	105
Burst variable 6	
Burst configuration 1 to n (2039)	105
Burst variable 7	
Burst configuration 1 to n (2040)	105
Calibration factor (2920)	61
Configuration counter (0233)	140
Contrast display (0105)	25
Control Totalizer 1 to n (0912-1 to n)	126
Current output 1 simulation (0354-1)	151
Current span	
Current output 1 (0353-1)	65
Damping output 1 (0363-1)	73
Damping output 1 (0477-1)	88
Date/time format (2812)	53
Day (2842)	63
Decimal places 1 (0095)	18
Decimal places 2 (0117)	19
Decimal places 3 (0118)	21
Decimal places 4 (0119)	22
Default gateway (7210)	117
Define access code	29
Density unit (0555)	52
Device alarm simulation (0654)	154
Device ID (0221)	108
Device name (0013)	139
Device reset (0000)	29
Device revision (0204)	108
Device tag (0011)	138
Device tag (0215)	99
Device type (0209)	108
DHCP client (7212)	116
Diagnostic event category (0738)	155
Diagnostic event simulation (0737)	155
Diagnostics 1 (0692)	132
Diagnostics 2 (0693)	133
Diagnostics 3 (0694)	133
Diagnostics 4 (0695)	134
Diagnostics 5 (0696)	135
Direct access (0106)	10
Display damping (0094)	23
Display interval (0096)	22
Display language (0104)	14
ENP version (0012)	140
Enter access code (0003)	13
Event category 124 (0270)	119
Event category 125 (0271)	119
Event category 160 (0272)	120

Event category 441 (0210)	120	Maximum frequency value Pulse/frequency/switch output 1 (0454-1)	86
Event category 442 (0230)	120	Maximum value (2911)	147
Event category 443 (0231)	121	Maximum value (2963)	148
Event category 832 (0218)	121	Maximum value (2968)	145
Event category 833 (0225)	122	Maximum value (2972)	146
Event category 834 (0227)	122	Maximum value (3020)	146
Event category 835 (0229)	122	Measured current 1 (0366-1)	43, 77
Event category 840 (0267)	123	Measuring mode Current output 1 (0351-1)	69
Extended order code 1 (0023)	139	Pulse/frequency/switch output 1 (0457-1)	83
Extended order code 2 (0021)	140	Pulse/frequency/switch output 1 (0479-1)	88
Extended order code 3 (0022)	140	Measuring value at maximum frequency Pulse/frequency/switch output 1 (0475-1)	87
Failure current Current output 1 (0352-1)	76	Measuring value at minimum frequency Pulse/frequency/switch output 1 (0476-1)	86
Failure frequency Pulse/frequency/switch output 1 (0474-1)	90	Min. update period Burst configuration 1 to n (2042-1 to n)	107
Failure mode Current output 1 (0364-1)	75	Minimum frequency value Pulse/frequency/switch output 1 (0453-1)	85
Pulse/frequency/switch output 1 (0451-1)	90	Minimum value (2918)	147
Pulse/frequency/switch output 1 (0480-1)	84	Minimum value (2950)	148
Pulse/frequency/switch output 1 (0486-1)	97	Minimum value (2969)	145
Totalizer 1 to n (0901-1 to n)	127	Minimum value (2973)	147
Fieldbus writing access (0273)	100	Minimum value (3021)	146
Filter options	136	Minute (2844)	64
Firmware version (0010)	138	Month (2845)	62
Fixed current Current output 1 (0365-1)	66	No. of preambles (0217)	100
Fixed density (1862)	57	Nominal diameter (2807)	61
Flow damping (1802)	54	Off value low flow cutoff (1804)	56
Flow override (1839)	54	On value low flow cutoff (1805)	56
Flow velocity (1852)	40	Operating mode Pulse/frequency/switch output 1 (0469-1)	80
Format display (0098)	15	Operating time (0652)	28, 131
Frequency output simulation 1 (0472-1)	151	Operating time from restart (0653)	131
Frequency value 1 (0473-1)	152	Order code (0008)	139
Hardware revision (0206)	110	Output current 1 (0361-1)	43, 76
HART address (0219)	100	Output frequency 1 (0471-1)	44, 91
HART date code (0202)	110	Preset value 1 to n (0913-1 to n)	127
HART descriptor (0212)	109	Previous diagnostics (0690)	130
HART message (0216)	109	Primary variable (PV) (0201)	112
HART revision (0205)	109	Process variable value (1811)	150
HART short tag (0220)	99	Profile factor (2909)	42
Header (0097)	23	Pulse output 1 (0456-1)	43, 84
Header text (0112)	24	Pulse output simulation 1 (0458-1)	152
Hour (2843)	63	Pulse value 1 (0459-1)	153
Invert output signal Pulse/frequency/switch output 1 (0470-1)	97	Pulse width Pulse/frequency/switch output 1 (0452-1)	82
IP address (7209)	116	Quaternary variable (QV) (0203)	114
Kinematic viscosity unit (0578)	53	Reset access code (0024)	28
Length unit (0551)	51	Reset all totalizers (2806)	123
Locking status (0004)	11	Reset min/max values Measuring point 1 (2922-1)	144
Login page (7273)	118	Reset min/max values (5647)	144
MAC address (7214)	116	Response time Current output 1 (0378-1)	74
Manufacturer ID (0259)	109	Pulse/frequency/switch output 1 (0491-1)	89
Mass flow (1847)	39	Reynolds number (2908)	42
Mass flow factor (1846)	59	Secondary variable (SV) (0226)	112
Mass flow offset (1841)	59		
Mass flow unit (0554)	49		
Mass unit (0574)	50		
Max. update period Burst configuration 1 to n (2041-1 to n)	107		

Separator (0101)	25	Year (2846)	62
Serial number (0009)	138	Zero point (2921)	61
Signal strength (2914)	41	Direct access (Parameter)	10
Signal to noise ratio (2917)	42	Display (Submenu)	13
Software option overview (0015)	31	Display damping (Parameter)	23
Software revision (0072)	141, 142, 143	Display interval (Parameter)	22
Software revision (0224)	110	Display language (Parameter)	14
Sound velocity (1850)	40	Display module (Submenu)	143
Sound velocity factor (1849)	60	Document	
Sound velocity offset (1848)	60	Explanation of the structure of a parameter description	6
Status		Function	4
Current output 1 (0360-1)	78	Structure	4
Subnet mask (7211)	117	Symbols used	6
Switch output function		Target group	4
Pulse/frequency/switch output 1 (0481-1)	91	Using the document	4
Switch output simulation 1 (0462-1)	153	Document function	4
Switch status 1 (0461-1)	44, 97		
Switch status 1 (0463-1)	154		
Switch-off delay		E	
Pulse/frequency/switch output 1 (0465-1)	96	ENP version (Parameter)	140
Switch-off value		Enter access code (Parameter)	13
Pulse/frequency/switch output 1 (0464-1)	95	Event category 124 (Parameter)	119
Switch-on delay		Event category 125 (Parameter)	119
Pulse/frequency/switch output 1 (0467-1)	96	Event category 160 (Parameter)	120
Switch-on value		Event category 441 (Parameter)	120
Pulse/frequency/switch output 1 (0466-1)	94	Event category 442 (Parameter)	120
Temperature (1853)	40	Event category 443 (Parameter)	121
Temperature damping (1886)	55	Event category 832 (Parameter)	121
Temperature unit (0557)	50	Event category 833 (Parameter)	122
Tertiary variable (TV) (0228)	113	Event category 834 (Parameter)	122
Timestamp	130, 131, 132, 133, 134, 135	Event category 835 (Parameter)	122
Totalizer operation mode		Event category 840 (Parameter)	123
Totalizer 1 to n (0908-1 to n)	125	Event list (Submenu)	136
Totalizer overflow 1 to n (0910-1 to n)	46	Event logbook (Submenu)	135
Totalizer value 1 to n (0911-1 to n)	45	Extended order code 1 (Parameter)	139
Trim		Extended order code 2 (Parameter)	140
Current output 1 (0362-1)	77	Extended order code 3 (Parameter)	140
Trim value high		External compensation (Submenu)	57
Current output 1 (0356-1)	77		
Trim value low		F	
Current output 1 (0357-1)	78	Factory settings	156
Turbulence (2907)	42	SI units	156
Unit (0974)	128	US units	157
Unit totalizer 1 to n (0915-1 to n)	125	Failure current (Parameter)	76
Value 1 display (0107)	17	Failure frequency (Parameter)	90
Value 2 display (0108)	19	Failure mode (Parameter)	75, 84, 90, 97, 127
Value 3 display (0110)	20	Fieldbus writing access (Parameter)	100
Value 4 display (0109)	21	Filter options (Parameter)	136
Value current output 1 (0355-1)	151	Firmware version (Parameter)	138
Value per pulse		Fixed current (Parameter)	66
Pulse/frequency/switch output 1 (0455-1)	82	Fixed density (Parameter)	57
Velocity unit (0566)	51	Flow damping (Parameter)	54
Volume flow (1838)	39	Flow override (Parameter)	54
Volume flow factor (1832)	59	Flow velocity (Parameter)	40
Volume flow offset (1831)	58	Flow velocity (Submenu)	147
Volume flow unit (0553)	47	Format display (Parameter)	15
Volume unit (0563)	49	Frequency output simulation 1 (Parameter)	151
Web server functionality (7222)	117	Frequency value 1 (Parameter)	152
Web server language (7221)	115		

Function
see Parameter

H

Hardware revision (Parameter)	110
HART address (Parameter)	100
HART date code (Parameter)	110
HART descriptor (Parameter)	109
HART message (Parameter)	109
HART output (Submenu)	98
HART revision (Parameter)	109
HART short tag (Parameter)	99
Header (Parameter)	23
Header text (Parameter)	24
Heartbeat (Submenu)	148
Hour (Parameter)	63

I

Information (Submenu)	107
Inventory counter (Submenu)	128
Invert output signal (Parameter)	97
IP address (Parameter)	116

K

Kinematic viscosity unit (Parameter)	53
--	----

L

Length unit (Parameter)	51
Locking status (Parameter)	11
Login page (Parameter)	118
Low flow cut off (Submenu)	55

M

MAC address (Parameter)	116
Mainboard module (Submenu)	141
Manufacturer ID (Parameter)	109
Mass flow (Parameter)	39
Mass flow factor (Parameter)	59
Mass flow offset (Parameter)	59
Mass flow unit (Parameter)	49
Mass unit (Parameter)	50
Max. update period (Parameter)	107
Maximum frequency value (Parameter)	86
Maximum value (Parameter)	145, 146, 147, 148
Measured current 1 (Parameter)	43, 77
Measured values (Submenu)	38
Measuring mode (Parameter)	69, 83, 88
Measuring point 1 (Submenu)	144
Measuring value at maximum frequency (Parameter)	87
Measuring value at minimum frequency (Parameter)	86
Medium temperature (Submenu)	148
Min. update period (Parameter)	107
Min/max values (Submenu)	144
Minimum frequency value (Parameter)	85
Minimum value (Parameter)	145, 146, 147, 148
Minute (Parameter)	64
Month (Parameter)	62

N

No. of preambles (Parameter)	100
--	-----

Nominal diameter (Parameter)

O

Off value low flow cutoff (Parameter)	56
On value low flow cutoff (Parameter)	56
Operating mode (Parameter)	80
Operating time (Parameter)	28, 131
Operating time from restart (Parameter)	131
Order code (Parameter)	139
Output (Submenu)	64, 111
Output current 1 (Parameter)	43, 76
Output frequency 1 (Parameter)	44, 91
Output values (Submenu)	43

P

Parameter

Structure of a parameter description	6
Preset value 1 to n (Parameter)	127
Previous diagnostics (Parameter)	130
Primary variable (PV) (Parameter)	112
Process parameters (Submenu)	53
Process variable adjustment (Submenu)	58
Process variable value (Parameter)	150
Process variables (Submenu)	39
Profile factor (Parameter)	42
Pulse output 1 (Parameter)	43, 84
Pulse output simulation 1 (Parameter)	152
Pulse value 1 (Parameter)	153
Pulse width (Parameter)	82
Pulse/frequency/switch output (Submenu)	78

Q

Quaternary variable (QV) (Parameter)	114
--	-----

R

Recalibration (Submenu)	61
Reset access code (Parameter)	28
Reset access code (Submenu)	28
Reset all totalizers (Parameter)	123
Reset min/max values (Parameter)	144
Response time (Parameter)	74, 89
Reynolds number (Parameter)	42

S

Secondary variable (SV) (Parameter)	112
Sensor (Submenu)	38
Sensor adjustment (Submenu)	58
Sensor electronic module (ISEM) (Submenu)	142
Sensor electronic temperature (ISEM) (Submenu)	145
Separator (Parameter)	25
Serial number (Parameter)	138
Signal strength (Parameter)	41
Signal strength (Submenu)	146
Signal to noise ratio (Parameter)	42
Simulation (Submenu)	149
Software option overview (Parameter)	31
Software revision (Parameter)	110, 141, 142, 143
Sound velocity (Parameter)	40
Sound velocity (Submenu)	145
Sound velocity factor (Parameter)	60

Sound velocity offset (Parameter)	60	Switch-on delay (Parameter)	96
Status (Parameter)	78	Switch-on value (Parameter)	94
Submenu		System (Submenu)	13
Administration	26	System units (Submenu)	47
Application	123	System values (Submenu)	40
Burst configuration 1 to n	101		
Calibration	60		
Communication	98		
Configuration	99		
Current output 1	64		
Device information	137		
Diagnostic behavior	32		
Diagnostic configuration	118		
Diagnostic handling	31		
Diagnostic list	132		
Diagnostics	129		
Display	13		
Display module	143		
Event list	136		
Event logbook	135		
External compensation	57		
Flow velocity	147		
HART output	98		
Heartbeat	148		
Information	107		
Inventory counter	128		
Low flow cut off	55		
Mainboard module	141		
Measured values	38		
Measuring point 1	144		
Medium temperature	148		
Min/max values	144		
Output	64, 111		
Output values	43		
Process parameters	53		
Process variable adjustment	58		
Process variables	39		
Pulse/frequency/switch output	78		
Recalibration	61		
Reset access code	28		
Sensor	38		
Sensor adjustment	58		
Sensor electronic module (ISEM)	142		
Sensor electronic temperature (ISEM)	145		
Signal strength	146		
Simulation	149		
Sound velocity	145		
System	13		
System units	47		
System values	40		
Totalizer	45		
Totalizer 1 to n	124		
Web server	115		
Subnet mask (Parameter)	117		
Switch output function (Parameter)	91		
Switch output simulation 1 (Parameter)	153		
Switch status 1 (Parameter)	44, 97, 154		
Switch-off delay (Parameter)	96		
Switch-off value (Parameter)	95		

www.addresses.endress.com
