

Description of Device Parameters

Proline Promass 200

PROFIBUS PA

Coriolis flowmeter




Table of contents

1 Document information	4		
1.1 Document function	4	3.10.2 "Event logbook" submenu	180
1.2 Target group	4	3.10.3 "Device info" submenu	182
1.3 Using this document	4	3.10.4 "I/O module" submenu	186
1.3.1 Information on the document structure	4	3.10.5 "Display module" submenu	186
1.3.2 Structure of a parameter description	6	3.10.6 "Data logging" submenu	187
1.4 Symbols used	6	3.10.7 "Min/max val." submenu	192
1.4.1 Symbols for certain types of information	6	3.10.8 "Heartbeat" submenu	201
1.4.2 Symbols in graphics	7	3.10.9 "Simulation" submenu	202
1.5 Documentation	7		
1.5.1 Standard documentation	7		
1.5.2 Supplementary device-dependent documentation	7		
2 Overview of the Expert operating menu	8		
3 Description of device parameters ...	11		
3.1 "System" submenu	14	4 Country-specific factory settings ..	208
3.1.1 "Display" submenu	15	4.1 SI units	208
3.1.2 "Conf.backup disp" submenu	28	4.1.1 System units	208
3.1.3 "Diagn. handling" submenu	32	4.1.2 Full scale values	208
3.1.4 "Administration" submenu	39	4.1.3 Pulse value	208
3.2 "Sensor" submenu	44	4.1.4 On value low flow cut off	209
3.2.1 "Measured val." submenu	45	4.2 US units	209
3.2.2 "System units" submenu	51	4.2.1 System units	209
3.2.3 "Process param." submenu	58	4.2.2 Full scale values	210
3.2.4 "Measurement mode" submenu	66	4.2.3 Pulse value	210
3.2.5 "External comp." submenu	68	4.2.4 On value low flow cut off	210
3.2.6 "Calculated value" submenu	70		
3.2.7 "Sensor adjustm." submenu	73		
3.2.8 "Calibration" submenu	79		
3.3 "Output" submenu	82		
3.3.1 "Pulse/frequency/switch output" submenu	82	5 Explanation of abbreviated units ..	212
3.4 "Communication" submenu	103	5.1 SI units	212
3.4.1 "PROFIBUS PA conf" submenu	104	5.2 US units	212
3.4.2 "PROFIBUS PA info" submenu	105	5.3 Imperial units	214
3.4.3 "Physical block" submenu	107		
3.5 "Analog inputs" submenu	116		
3.5.1 "Analog input 1 to n" submenu	116		
3.6 "Discrete inputs" submenu	129		
3.6.1 "Discrete input 1 to n" submenu	130		
3.7 "Analog outputs" submenu	137		
3.7.1 "Analog output 1 to n" submenu	137		
3.8 "Discrete outputs" submenu	149		
3.8.1 "Discrete output 1 to n" submenu	149		
3.9 "Application" submenu	159		
3.9.1 "Totalizer 1 to n" submenu	159		
3.10 "Diagnostics" submenu	172		
3.10.1 "Diagnostic list" submenu	175		

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



- Navigation path to the parameter via the local display (direct access code)
- Navigation path to the parameter via the operating tool
- The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Promass 8A2B**-...	BA01828D
Promass 8E2B**-...	BA01133D
Promass 8E2C**-...	BA01637D
Promass 8F2B**-...	BA01113D

1.5.2 Supplementary device-dependent documentation

Special Documentation


Content	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Display and operating module FHX50	SD01007F
Heartbeat Technology	SD01850D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

» Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access stat.disp (0091)	→ 13
Ent. access code (0092)	→ 14
▶ System	→ 14
▶ Display	→ 15
▶ Conf.backup disp	→ 28
▶ Diagn. handling	→ 32
▶ Administration	→ 39
▶ Sensor	→ 44
▶ Measured val.	→ 45
▶ System units	→ 51
▶ Process param.	→ 58
▶ Measurement mode	→ 66
▶ External comp.	→ 68
▶ Calculated value	→ 70
▶ Sensor adjustm.	→ 73
▶ Calibration	→ 79
▶ Output	→ 82
▶ PFS output	→ 82

▶ Communication	→ 103
▶ PROFIBUS PA conf	→ 104
▶ PROFIBUS PA info	→ 105
▶ Physical block	→ 107
▶ Analog inputs	→ 116
▶ Analog input 1 to n	→ 116
▶ Discrete inputs	→ 129
▶ Discrete input 1 to n	→ 130
▶ Analog outputs	→ 137
▶ Analog output 1	→ 137
▶ Discrete outputs	→ 149
▶ Discr. out. 1 to n	→ 149
▶ Application	→ 159
▶ Totalizer 1 to n	→ 159
▶ Diagnostics	→ 172
Actual diagnos. (0691)	→ 173
Prev.diagnostics (0690)	→ 174
Time fr. restart (0653)	→ 175
Operating time (0652)	→ 175
▶ Diagnostic list	→ 175
▶ Event logbook	→ 180
▶ Device info	→ 182
▶ Data logging	→ 187
▶ Min/max val.	→ 192



3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

 Expert	
Direct access (0106)	→  11
Locking status (0004)	→  12
Access stat.disp (0091)	→  13
Ent. access code (0092)	→  14
 System	→  14
 Sensor	→  44
 Output	→  82
 Communication	→  103
 Analog inputs	→  116
 Discrete inputs	→  129
 Analog outputs	→  137
 Discrete outputs	→  149
 Application	→  159
 Diagnostics	→  172

Direct access



Navigation

 Expert → Direct access (0106)

Description


Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.

User entry

0 to 65 535

Additional information*User entry*

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

A0029414

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
Example: Enter 00914 → **Assign variable** parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign variable** parameter

Locking status**Navigation**

Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- Temp. locked

Additional information*Display*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7

Selection

Options	Description
None	The access status displayed in the Access stat.disp parameter (→ 13) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).
Temp. locked (priority 2) (priority 2)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access stat.disp

Navigation	 Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the Ent. access code parameter (→ 14).</p> <p> For information about the Ent. access code parameter (→ 14): see the "Disabling write protection via the access code" section of the Operating Instructions for the device → 7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p>
	<p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7</p>

Access stat.tool

Navigation	 Expert → Access stat.tool (0005)
Description	Displays the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance

Additional information*Description*

 The access authorization can be modified via the **Ent. access code** parameter
(→ [14](#)).

 If additional write protection is active, this restricts the current access authorization even further.

Display

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

Ent. access code**Navigation**

 Expert → Ent. access code (0092)

Description

Use this function to enter the user-specific release code to remove parameter write protection on the local display.

User entry

0 to 9 999

Ent. access code**Navigation**

 Expert → Ent. access code (0003)

Description

Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.


User entry

0 to 9 999

3.1 "System" submenu

Navigation

  Expert → System



3.1.1 "Display" submenu

Navigation

Expert → System → Display

► Display	
Language (0104)	→ 16
Format display (0098)	→ 16
Value 1 display (0107)	→ 19
0% bargraph 1 (0123)	→ 19
100% bargraph 1 (0125)	→ 20
Decimal places 1 (0095)	→ 20
Value 2 display (0108)	→ 21
Decimal places 2 (0117)	→ 21
Value 3 display (0110)	→ 22
0% bargraph 3 (0124)	→ 22
100% bargraph 3 (0126)	→ 23
Decimal places 3 (0118)	→ 23
Value 4 display (0109)	→ 23
Decimal places 4 (0119)	→ 24
Display interval (0096)	→ 24
Display damping (0094)	→ 25
Header (0097)	→ 25
Header text (0112)	→ 26
Separator (0101)	→ 27
Contrast display (0105)	→ 27
Backlight (0111)	→ 27
Access stat.disp (0091)	→ 28

Language

Navigation  Expert → System → Display → Language (0104)

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano
- Nederlands *
- Portuguesa *
- Polski *
- русский язык(Ru) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- Bahasa Indonesia *
- tiêng Việt (Vit) *
- čeština (Czech) *

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display (0098)

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max.
- Bargr. + 1 value
- 2 values
- Val. large+2val.
- 4 values

Factory setting 1 value, max.

* Visibility depends on order options or device settings

Additional information*Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.




- The **Value 1 display** parameter (→ 19) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 24).

Possible measured values shown on the local display:


"1 value, max." option




"Bagr. + 1 value" option




"2 values" option



"Val. large+2val." option



"4 values" option



Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	<ul style="list-style-type: none">■ Mass flow■ Volume flow■ Correct.vol.flow■ Density■ Ref.density■ Temperature■ Totalizer 1■ Totalizer 2■ Totalizer 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 51).</p>

0% bargraph 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none">■ 0 kg/h■ 0 lb/min

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

100% bargraph 1**Navigation**

Expert → System → Display → 100% bargraph 1 (0125)

Prerequisite

A local display is provided.

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → 208

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Decimal places 1**Navigation**

Expert → System → Display → Decimal places 1 (0095)

Prerequisite

A measured value is specified in the **Value 1 display** parameter (→ 19).

Description

Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ [19](#))

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ [16](#)) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ [51](#)).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ [21](#)).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 19)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 51).

0% bargraph 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 22).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none">■ 0 kg/h■ 0 lb/min
Additional information	<i>Description</i> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 51).

100% bargraph 3

Navigation	Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	A selection was made in the Value 3 display parameter (→ 22).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Description</i> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 51).

Decimal places 3

Navigation	Expert → System → Display → Decimal places 3 (0118)
Prerequisite	A measured value is specified in the Value 3 display parameter (→ 22).
Description	Use this function to select the number of decimal places for measured value 3.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX
Additional information	<i>Description</i> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display

Navigation	Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection For the picklist, see the **Value 1 display** parameter (→ 19)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Decimal places 4



Navigation Expert → System → Display → Decimal places 4 (0119)

Prerequisite A measured value is specified in the **Value 4 display** parameter (→ 23).

Description Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation Expert → System → Display → Display interval (0096)

Prerequisite A local display is provided.

Description Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ■ The **Value 1 display** parameter (→ 19) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Display damping



Navigation  Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

 Damping is switched off if 0 is entered (factory setting).

Header



Navigation  Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting Device tag

1) proportional transmission behavior with first order delay

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 183).
- Free text
Is defined in the **Header text** parameter (→ 26).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 25), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Additional information Set the contrast via the push-buttons:

- Brighter: Press and hold down the **-** **=** keys simultaneously.
- Darker: Press and hold down the **+** **=** keys simultaneously.

Backlight

Navigation Expert → System → Display → Backlight (0111)

Prerequisite Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Disable

Access stat.disp

Navigation	  Expert → System → Display → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the Ent. access code parameter (→  14).</p> <p> For information about the Ent. access code parameter (→  14): see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p>
	<p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

3.1.2 "Conf.backup disp" submenu

Navigation   Expert → System → Conf.backup disp

 Conf.backup disp	
Operating time (0652)	→  29
Last backup (0102)	→  29
Config. managem. (0100)	→  29
Compar. result (0103)	→  31

Operating time

Navigation	  Expert → System → Conf.backup disp → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

Last backup

Navigation	  Expert → System → Conf.backup disp → Last backup (0102)
Prerequisite	A local display is provided.
Description	Use this function to display the time since a backup copy of the data was last saved to the display module.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Config. managem.



Navigation	  Expert → System → Conf.backup disp → Config. managem. (0100)
Prerequisite	A local display is provided.
Description	Use this function to select an action to save the data to the display module.
Selection	<ul style="list-style-type: none">■ Cancel■ Execute backup■ Restore■ Duplicate■ Compare■ Clear backup
Factory setting	Cancel

Additional information*Description*

Configuration via the local display is disabled while the action is performed.

 For information on the status message in the operating tool, see: **Backup state** parameter (→ 30)

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the display module of the device. The backup copy includes the transmitter data of the device. The following message appears on local display: Backup active, please wait!
Restore	The last backup copy of the device configuration is restored from the display module to the device's HistoROM backup. The backup copy includes the transmitter data of the device. The following message appears on local display: Restore active! Do not interrupt power supply!
Compare	The device configuration saved in the display module is compared with the current device configuration of the HistoROM backup. The following message appears on local display: Comparing files The result can be viewed in Compar. result parameter (→ 31).
Duplicate	The transmitter configuration from another device is duplicated to the device using the display module. The following message appears on local display: Copy active! Do not interrupt power supply!
Clear backup	The backup copy of the device configuration is deleted from the display module of the device. The following message appears on local display: Deleting file

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state**Navigation**

 Expert → System → Conf.backup disp → Backup state (0121)

Prerequisite

A local display is provided.

Description

Use this function to view the status of the data backup process.

User interface

- None
- Store in progr.
- Restore in progr.
- Import in progr.
- Delete in progr.
- Comp. in progr.

Factory setting

None


Compar. result

Navigation	 Expert → System → Conf.backup disp → Compar. result (0103)
Prerequisite	A local display is provided.
Description	Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.
User interface	<ul style="list-style-type: none"> ■ Set. identical ■ Set. not ident. ■ No backup ■ Backup corrupt ■ Check not done ■ Dataset incomp.
Factory setting	Check not done
Additional information	<p><i>Description</i></p> <p> The comparison is started via the Compare option in the Config. managem. parameter (→  29).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Set. identical <ul style="list-style-type: none"> – The current device configuration of the HistoROM is identical to the backup copy in the display module. – If the transmitter configuration of another device has been copied to the device via the display module and the Duplicate option in the Config. managem. parameter (→  29), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical. ■ Set. not ident. <ul style="list-style-type: none"> The current device configuration of the HistoROM is not identical to the backup copy in the display module. ■ No backup <ul style="list-style-type: none"> There is no backup copy of the device configuration of the HistoROM in the display module. ■ Backup corrupt <ul style="list-style-type: none"> The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module. ■ Check not done <ul style="list-style-type: none"> The device configuration of the HistoROM has not yet been compared to the backup copy in the display module. ■ Dataset incomp. <ul style="list-style-type: none"> The backup copy in the display module is not compatible with the device. <p><i>HistoROM</i></p> <p>A HistoROM is a "non-volatile" device memory in the form of an EEPROM.</p>

3.1.3 "Diagn. handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay



Navigation

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information

Description

This setting affects the following diagnostic messages:

- 046 Sensor limit
- 140 Sensor signal
- 830 Sensor temp.
- 831 Sensor temp.
- 832 Electronic temp.
- 833 Electronic temp.
- 834 Process temp.
- 835 Process temp.
- 912 Medium inhomog.
- 913 Medium unsuitab.

"Diagn. behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagn. behavior** submenu (→ 32).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Warning	The device continues to measure. The measured value output via PROFIBUS and the totalizers are not affected. A diagnostic message is generated.
Logbook only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 180) (Event list submenu (→ 181)) and not in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

 For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

► Diagn. behavior	
Diagnostic no. 046 (0655)	→ 34
Diagnostic no. 140 (0723)	→ 34
Diagnostic no. 274 (0725)	→ 34
Diagnostic no. 442 (0658)	→ 35
Diagnostic no. 443 (0659)	→ 35
Diagnostic no. 801 (0660)	→ 35
Diagnostic no. 830 (0715)	→ 36
Diagnostic no. 831 (0716)	→ 36
Diagnostic no. 832 (0675)	→ 37
Diagnostic no. 833 (0676)	→ 37
Diagnostic no. 834 (0677)	→ 37
Diagnostic no. 835 (0678)	→ 38
Diagnostic no. 862 (0679)	→ 38
Diagnostic no. 912 (0720)	→ 38
Diagnostic no. 913 (0717)	→ 39

Diagnostic no. 046 (Sensor limit)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 046 (0655)
Description	Option for changing the diagnostic behavior of the diagnostic message △046 Sensor limit.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 32

Diagnostic no. 140 (Sensor signal)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 140 (0723)
Description	Option for changing the diagnostic behavior of the diagnostic message 140 Sensor signal.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 32

Diagnostic no. 274 (Main electronic)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 274 (0725)
Description	Option for changing the diagnostic behavior of the diagnostic message 274 Main electronic.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 32

Diagnostic no. 442 (Freq. output)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 442 Freq. output .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 32

Diagnostic no. 443 (Pulse output)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 32

Diagnostic no. 801 (Supply voltage)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 801 (0660)
Description	Option for changing the diagnostic behavior of the diagnostic message 801 Supply voltage .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only

Factory setting Warning

Additional information Selection



Detailed description of the options available for selection: → [32](#)

Diagnostic no. 830 (Sensor temp.)



Navigation Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 830 (0715)

Prerequisite If the carrier tube temperature is available (applies only to Promass F).

Description Option for changing the diagnostic behavior of the diagnostic message **830 Sensor temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting Warning

Additional information Detailed description of the options available for selection: → [32](#)

Diagnostic no. 831 (Sensor temp.)



Navigation Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 831 (0716)

Prerequisite If the carrier tube temperature is available (applies only to Promass F).

Description Option for changing the diagnostic behavior of the diagnostic message **831 Sensor temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting Warning

Additional information Detailed description of the options available for selection: → [32](#)

Diagnostic no. 832 (Electronic temp.)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)
Description	Option for changing the diagnostic behavior of the diagnostic message 832 Electronic temp..
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 32

Diagnostic no. 833 (Electronic temp.)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
Description	Option for changing the diagnostic behavior of the diagnostic message 833 Electronic temp..
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 32

Diagnostic no. 834 (Process temp.)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)
Description	Option for changing the diagnostic behavior of the diagnostic message 834 Process temp..
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning

Additional information*Selection*

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 835 (Process temp.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)

Description

Option for changing the diagnostic behavior of the diagnostic message **835 Process temp..**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information*Selection*

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 862 (Empty pipe)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 862 (0679)

Description

Option for changing the diagnostic behavior of the diagnostic message **862 Empty pipe.**

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [32](#)

Diagnostic no. 912 (Medium inhomog.)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 912 (0720)

Description

Option for changing the diagnostic behavior of the diagnostic message **912 Medium inhomog..**

Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 32

Diagnostic no. 913 (Medium unsuitab.)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 913 (0717)
Description	Option for changing the diagnostic behavior of the diagnostic message 913 Medium unsuitab..
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 32

3.1.4 "Administration" submenu*Navigation*  Expert → System → Administration

 Administration	
 Def. access code	→ 40
Device reset (0000)	→ 42
Activate SW opt. (0029)	→ 42
SW option overv. (0015)	→ 43
Sens. emerg.mode (2566)	→ 43


"Def. access code" wizard

i The **Def. access code** wizard (→ 40) is only available when operating via the local display.

If operating via the operating tool, the **Def. access code** parameter (→ 41) can be found directly in the **Administration** submenu. There is no **Confirm code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code

**Def. access code****Navigation**

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

i Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→ 14).

i If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm code

Navigation	Expert → System → Administration → Def. access code → Confirm code
Description	Enter the defined release code a second time to confirm the release code.
User entry	0 to 9 999
Factory setting	0

Additional parameters in the "Administration" submenu

Def. access code

Navigation	Expert → System → Administration → Def. access code
Description	Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.
User entry	0 to 9 999
Factory setting	0
Additional information	<i>Description</i> The write protection affects all parameters in the document marked with the symbol. Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Ent. access code parameter (→ 14). If you lose the access code, please contact your Endress+Hauser sales organization.
	<i>User entry</i> A message is displayed if the access code is not in the input range.
	<i>Factory setting</i> If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the " Maintenance " role.

Device reset**Navigation**

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To fact.defaults
- To delivery set.
- Restart device

Factory setting

Cancel

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To bus defaults	Every parameter is reset to fieldbus default values.
To fact.defaults	Every parameter is reset to its factory setting.
To delivery set.	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting. This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Activate SW opt.**Navigation**

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information

Description

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **SW option overv.** parameter (→ 43).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→ 43).

SW option overv.

Navigation  Expert → System → Administration → SW option overv. (0015)

Description Displays all the software options that are enabled in the device.

User interface

- Extend. HistoROM
- HBT Monitoring
- HBT Verification

Additional information *Description*
Displays all the options that are available if ordered by the customer.

"Extend. HistoROM" option

Order code for "Application package", option **EA** "Extended HistoROM"

"HBT Verification" option and "HBT Monitoring" option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

Sens. emerg.mode



Navigation  Expert → System → Administration → Sens. emerg.mode (2566)

Prerequisite The device has identified an error during verification of the characteristics in the sensor data storage or electronics module. A diagnostic message of status type **XF** is output.

Description	Use this function to switch on the emergency mode of the sensor to use the backup of the sensor characteristics or main electronics characteristics stored in the HistoROM.
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Ok
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p>i This parameter becomes visible if the data in the S-DAT or on-board memory cannot be read on account of a defect or error. There is a copy of the data on the HistoROM (FT10). If the emergency mode is activated, this copy is used and the device measure correctly again at least up until the next device switch-off/switch-on. After switch-on/switch-off, the emergency mode would have to be reactivated again. This ensures that the client can operate the device until a new spare part arrives.</p> <p>The status signal of the output diagnostic message changes from F (failure) to M (maintenance required), the diagnostic behavior changes from Alarm to Warning: ΔM. The diagnostic message is output until the characteristics in the sensor data storage are again correct.</p> <p>i Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the \mathbb{E}-button.</p> <p>i Information on status signals and diagnostic behavior: Operating Instructions about the device, "Diagnostic message" chapter</p>

3.2 "Sensor" submenu

Navigation


Expert → Sensor

► Sensor	
► Measured val.	→ 45
► System units	→ 51
► Process param.	→ 58
► Measurement mode	→ 66
► External comp.	→ 68
► Calculated value	→ 70
► Sensor adjustm.	→ 73
► Calibration	→ 79

3.2.1 "Measured val." submenu

Navigation


Expert → Sensor → Measured val.



"Process variab." submenu

Navigation

Expert → Sensor → Measured val. → Process variab.



Mass flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Mass flow (1840)

Description

Use this function to view the mass flow currently calculated.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Mass flow unit** parameter (→ 51)

Volume flow

Navigation   Expert → Sensor → Measured val. → Process variab. → Volume flow (1813)

Description Use this function to view the volume flow currently measured.

User interface Signed floating-point number

Additional information *Description*

The volume flow is calculated from the measured mass flow and the measured density.

Dependency

 The unit is taken from the **Volume flow unit** parameter (→  52)

Correct.vol.flow

Navigation   Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1842)

Description Use this function to view the corrected volume flow currently calculated.

User interface Signed floating-point number

Additional information *Description*

The corrected volume flow is derived from the measured mass flow and the reference density of the fluid (density at reference temperature, measured or fixed entry).

Dependency

 The unit is taken from the **Cor.volflow unit** parameter (→  54)

Density

Navigation   Expert → Sensor → Measured val. → Process variab. → Density (1843)

Description Use this function to view the currently measured density or its specific gravity.

User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Density unit** parameter (→  55)

Ref.density

Navigation	  Expert → Sensor → Measured val. → Process variab. → Ref.density (1844)
Description	Displays the density at the reference temperature.
User interface	Positive floating-point number
Additional information	<p><i>Description</i> The reference density displayed is calculated using the measured density.</p> <p><i>Dependency</i>  The unit is taken from the Ref. dens. unit parameter (→  56)</p>

Temperature

Navigation	  Expert → Sensor → Measured val. → Process variab. → Temperature (1845)
Description	Use this function to view the temperature currently measured.
User interface	Positive floating-point number
Additional information	<p><i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  56)</p>

"Totalizer" submenu

Navigation   Expert → Sensor → Measured val. → Totalizer

 Totalizer							
<table border="0"> <tr> <td style="border: 1px solid black; padding: 5px; width: 60%;">Totalizer val. 1 to n (3827–1 to n)</td> <td style="width: 20%; text-align: right; vertical-align: bottom;">→  48</td> </tr> <tr> <td style="border: 1px solid black; padding: 5px;">Status (Hex) 1 to n (3825–1 to n)</td> <td style="text-align: right; vertical-align: bottom;">→  48</td> </tr> <tr> <td style="border: 1px solid black; padding: 5px;">Tot. status 1 to n (3826–1 to n)</td> <td style="text-align: right; vertical-align: bottom;">→  48</td> </tr> </table>		Totalizer val. 1 to n (3827–1 to n)	→  48	Status (Hex) 1 to n (3825–1 to n)	→  48	Tot. status 1 to n (3826–1 to n)	→  48
Totalizer val. 1 to n (3827–1 to n)	→  48						
Status (Hex) 1 to n (3825–1 to n)	→  48						
Tot. status 1 to n (3826–1 to n)	→  48						

Totalizer val. 1 to n

Navigation	  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (3827–1 to n)
Prerequisite	In the Target mode parameter (→ 165), the Auto option is selected.
Description	Displays the current reading for totalizer 1-3.
User interface	Signed floating-point number
Additional information	<i>Description</i>  In the event of an error, the totalizer adopts the mode defined in the Failure mode parameter (→ 163). <i>User interface</i> The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the Operation mode parameter (→ 162). <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 160).

Status (Hex) 1 to n

Navigation	  Expert → Sensor → Measured val. → Totalizer → Status (Hex) 1 to n (3825–1 to n)
Prerequisite	In Target mode parameter (→ 165), the Auto option is selected.
Description	Displays the status value (hex) of the particular totalizer.
User interface	0 to 0xFF

Tot. status 1 to n

Navigation	  Expert → Sensor → Measured val. → Totalizer → Tot. status 1 to n (3826–1 to n)
Description	Displays the status of the particular totalizer.
User interface	<ul style="list-style-type: none">■ Good■ Uncertain■ Bad

"Output values" submenu*Navigation*

Expert → Sensor → Measured val. → Output values

► Output values	
Terminal volt. 1 (0662)	→ 49
Pulse output (0456)	→ 49
Output freq. (0471)	→ 50
Switch status (0461)	→ 50

Terminal volt. 1**Navigation**

Expert → Sensor → Measured val. → Output values → Terminal volt. 1 (0662)

Description

Displays the current terminal voltage that is applied at the output.

User interface

0.0 to 50.0 V

Pulse output**Navigation**

Expert → Sensor → Measured val. → Output values → Pulse output (0456)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 84) parameter.**Description**


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 86) and **Pulse width** parameter (→ 86) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 103) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 88)) can be configured.

Output freq.

Navigation	Expert → Sensor → Measured val. → Output values → Output freq. (0471)
Prerequisite	In the Operating mode parameter (→ 84), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0 to 1 250 Hz

Switch status

Navigation	Expert → Sensor → Measured val. → Output values → Switch status (0461)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 84).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation

Expert → Sensor → System units

► System units	
Mass flow unit (0554)	→ 51
Mass unit (0574)	→ 52
Volume flow unit (0553)	→ 52
Volume unit (0563)	→ 54
Cor.volflow unit (0558)	→ 54
Corr. vol. unit (0575)	→ 55
Density unit (0555)	→ 55
Ref. dens. unit (0556)	→ 56
Temperature unit (0557)	→ 56
Length unit (0551)	→ 57
Pressure unit (0564)	→ 57
Date/time format (2812)	→ 58

Mass flow unit



Navigation

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection

SI units

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Result*

The selected unit applies for:

Mass flow parameter (→  45)*Selection* For an explanation of the abbreviated units: →  212

Mass unit**Navigation**  Expert → Sensor → System units → Mass unit (0574)**Description**

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection* For an explanation of the abbreviated units: →  212

Volume flow unit**Navigation**  Expert → Sensor → System units → Volume flow unit (0553)**Description**

Use this function to select the unit for the volume flow.

Selection*SI units*

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d

US units

- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)

Imperial units

- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)

Factory setting*Country-specific:*

- l/h
- gal/min (us)

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  46)

Selection

For an explanation of the abbreviated units: →  212

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- l (DN > 150 (6)": m³)
- gal (us)

Additional information*Selection*

For an explanation of the abbreviated units: → 212

Cor.volflow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting	Country-specific: ■ NL/h ■ Sft ³ /min
------------------------	--

Additional information	<i>Result</i> The selected unit applies for: Correct.vol.flow parameter (→ 46) <i>Selection</i>  For an explanation of the abbreviated units: → 212
-------------------------------	---

Corr. vol. unit

Navigation  Expert → Sensor → System units → Corr. vol. unit (0575)

Description Use this function to select the unit for the corrected volume.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ NL	■ Sft ³	Sgal (imp)
	■ Nm ³	■ Sgal (us)	
	■ Sm ³	■ Sbbl (us;liq.)	

Factory setting	Country-specific: ■ NL ■ Sft ³
------------------------	---

Additional information	<i>Selection</i>  For an explanation of the abbreviated units: → 212
-------------------------------	--

Density unit

Navigation  Expert → Sensor → System units → Density unit (0555)

Description Use this function to select the unit for the density.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ g/cm ³	■ lb/ft ³	■ lb/gal (imp)
	■ g/m ³	■ lb/gal (us)	■ lb/bbl (imp;beer)
	■ kg/dm ³	■ lb/bbl (us;liq.)	■ lb/bbl (imp;oil)
	■ kg/l	■ lb/bbl (us;beer)	
	■ kg/m ³	■ lb/bbl (us;oil)	
	■ SD4°C	■ lb/bbl (us;tank)	
	■ SD15°C		
	■ SD20°C		
	■ SG4°C		
	■ SG15°C		
	■ SG20°C		

Factory setting	Country-specific: ■ kg/l ■ lb/ft ³
Additional information	<p><i>Result</i></p> <p>The selected unit applies for: Density parameter (→  46)</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ SD = specific density The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F). ■ SG = specific gravity The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F). <p> For an explanation of the abbreviated units: →  212</p>

Ref. dens. unit												
Navigation	  Expert → Sensor → System units → Ref. dens. unit (0556)											
Description	Use this function to select the unit for the reference density.											
Selection	<table border="0"> <tr> <td><i>SI units</i></td> <td><i>US units</i></td> </tr> <tr> <td>■ kg/Nm³</td> <td>lb/Sft³</td> </tr> <tr> <td>■ kg/Nl</td> <td></td> </tr> <tr> <td>■ g/Scm³</td> <td></td> </tr> <tr> <td>■ kg/Sm³</td> <td></td> </tr> </table>	<i>SI units</i>	<i>US units</i>	■ kg/Nm ³	lb/Sft ³	■ kg/Nl		■ g/Scm ³		■ kg/Sm ³		
<i>SI units</i>	<i>US units</i>											
■ kg/Nm ³	lb/Sft ³											
■ kg/Nl												
■ g/Scm ³												
■ kg/Sm ³												
Factory setting	Country-dependent ■ kg/Nl ■ lb/Sft ³											
Additional information	<p><i>Result</i></p> <p>The selected unit applies for:</p> <ul style="list-style-type: none"> ■ Fix ref.density parameter (→  71) ■ Ref.density parameter (→  47) <p><i>Selection</i></p> <p> For an explanation of the abbreviated units: →  212</p>											

Temperature unit		
Navigation	  Expert → Sensor → System units → Temperature unit (0557)	
Description	Use this function to select the unit for the temperature.	

Selection	<i>SI units</i>	<i>US units</i>
	▪ °C	▪ °F
	▪ K	▪ °R

Factory setting	Country-specific: ▪ °C ▪ °F
-----------------	-----------------------------------

Additional information	<i>Result</i> The selected unit applies for: ▪ Minimum value parameter (→ 195) ▪ Maximum value parameter (→ 195) ▪ Maximum value parameter (→ 196) ▪ Minimum value parameter (→ 196) ▪ Average value parameter (→ 196) ▪ Minimum value parameter (→ 197) ▪ Maximum value parameter (→ 197) ▪ Minimum value parameter (→ 198) ▪ Maximum value parameter (→ 198) ▪ Ref. temperature parameter (→ 71)
------------------------	---

Selection

 For an explanation of the abbreviated units: → 212

Length unit

Navigation  Expert → Sensor → System units → Length unit (0551)

Description Use this function to select the unit of length for the nominal diameter.

Selection	<i>SI units</i>	<i>US units</i>
	▪ m	▪ ft
	▪ mm	▪ in
	▪ µm	

Factory setting	Country-specific: ▪ mm ▪ in
-----------------	-----------------------------------

Additional information	<i>Selection</i>
------------------------	------------------

 For an explanation of the abbreviated units: → 212

Pressure unit

Navigation  Expert → Sensor → System units → Pressure unit (0564)


Description Use this function to select the unit for the pipe pressure.

Selection	<i>SI units</i>	<i>US units</i>
	<ul style="list-style-type: none"> ■ Pa a ■ kPa a ■ MPa a ■ bar ■ Pa g ■ kPa g ■ MPa g ■ bar g 	<ul style="list-style-type: none"> ■ psi a ■ psi g
Factory setting	Country-specific:	
	<ul style="list-style-type: none"> ■ bar a ■ psi a 	
Additional information	<i>Result</i>	
	The unit is taken from:	
	<ul style="list-style-type: none"> ■ Pressure value parameter (→  69) ■ External press. parameter (→  69) 	
	<i>Selection</i>	
	 For an explanation of the abbreviated units: →  212	

Date/time format		
Navigation	  Expert → Sensor → System units → Date/time format (2812)	
Description	Use this function to select the desired time format for calibration history.	
Selection	<ul style="list-style-type: none"> ■ dd.mm.yy hh:mm ■ dd.mm.yy am/pm ■ mm/dd/yy hh:mm ■ mm/dd/yy am/pm 	
Factory setting	dd.mm.yy hh:mm	
Additional information	<i>Selection</i>	
	 For an explanation of the abbreviated units: →  212	

3.2.3 "Process param." submenu

Navigation   Expert → Sensor → Process param.



Density damping (1808)	→ 59
Flow override (1839)	→ 60
Temp. damping (1807)	→ 60
▶ Low flow cut off	→ 61
▶ Partial pipe det	→ 64

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping (1801)

Description

Use this function to enter a value for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 0 s

Additional information *User entry*

- Value = 0: no damping
- Value > 0: damping is increased

Result

The damping affects the following variables of the device:

- Outputs → [82](#)
- Low flow cut off → [61](#)
- Totalizers → [159](#)

Density damping



Navigation

Expert → Sensor → Process param. → Density damping (1808)

Description

Use this function to enter a value for density damping. Use this parameter to reduce the sensitivity of the measuring signal to fluctuations in the density of the medium. For this purpose, the depth of the density filter is adjusted. The damping is suitable for non-homogeneous liquids, for example.

User entry 0 to 999.9 s

Factory setting 0 s

Additional information*Result*

The damping has an effect on the following process variables:

- Density (→ [46](#))
- Ref.density (→ [47](#))
- Volume flow (→ [46](#))
- Correct.vol.flow (→ [46](#))

Flow override**Navigation**

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information*Result*

This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: value at zero flow
 - Temperature: continues to be output
 - Totalizers 1-3: stop being totalized



The **Flow override** option can also be activated in the **Status input** submenu: **Assign stat.inp.** parameter.

Temp. damping**Navigation**

Expert → Sensor → Process param. → Temp. damping (1807)

Description

Use this function to enter a value for temperature damping. Use this parameter to reduce the sensitivity of the temperature measuring signal to interference peaks. For this purpose, the temperature filter is adjusted.

User entry

0 to 999.9 s

Factory setting

0 s

Additional information*Result*

-  In addition to the temperature, the damping has an effect on the following temperature-dependent process variables:
- Ref.density (→ [47](#))
 - Correct.vol.flow (→ [46](#))

"Low flow cut off" submenu*Navigation*
 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign variable (1837)	→ 61
On value (1805)	→ 61
Off value (1804)	→ 62
Pres. shock sup. (1806)	→ 62

Assign variable**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow

Factory setting

Mass flow

On value**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite

A process variable is selected in the **Assign variable** parameter (→ [61](#)).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → [62](#).

User entry

Positive floating-point number

Factory setting Depends on country and nominal diameter → [209](#)

Additional information *Dependency*

 The unit depends on the process variable selected in the **Assign variable** parameter (→ [61](#)).

Off value



Navigation  Expert → Sensor → Process param. → Low flow cut off → Off value (1804)


Prerequisite A process variable is selected in the **Assign variable** parameter (→ [61](#)).

Description Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → [61](#).

User entry 0 to 100.0 %

Factory setting 50 %

Additional information *Example*



A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pres. shock sup.



Navigation  Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)

Prerequisite A process variable is selected in the **Assign variable** parameter (→ [61](#)).

Description Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry 0 to 100 s

Factory setting 0 s

Additional information*Description***Pressure shock suppression is enabled**


- Prerequisite:
 - Flow rate < on-value of low flow cut off
or
 - Changing the flow direction
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.



A0012888

<i>Q</i>	Flow
<i>t</i>	Time
<i>A</i>	Drip
<i>B</i>	Pressure shock
<i>C</i>	Pressure shock suppression active as specified by the time entered
<i>D</i>	Pressure shock suppression inactive
1	Valve closes
2	Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
3	The time entered has elapsed: pressure shock suppression is deactivated
4	The actual flow value is now displayed and output
5	On-value for low flow cut off
6	Off-value for low flow cut off

"Partial pipe det" submenu**Navigation**
 Expert → Sensor → Process param. → Partial pipe det

► Partial pipe det	
Assign variable (1833)	→  64
Low value (1834)	→  64
High value (1835)	→  65
Response time (1836)	→  65
Max. damping (2492)	→  66

Assign variable**Navigation**
 Expert → Sensor → Process param. → Partial pipe det → Assign variable (1833)
Description

Use this function to select a process variable to detect empty or partially filled measuring tubes. For gas measurement: Deactivate monitoring due to low gas density.

Selection

- Off
- Density
- Ref.density

Factory setting

Off

Low value**Navigation**
 Expert → Sensor → Process param. → Partial pipe det → Low value (1834)
Prerequisite

One of the following options is selected in the **Assign variable** parameter (→  64):

- Density
- Ref.density

Description

Use this function to enter a lower limit value to enable detection of empty or partially filled measuring tubes. If the measured density falls below this value, monitoring is enabled.

User entry

Positive floating-point number

Factory setting

200

Additional information*User entry*

The lower limit value must be less than the upper limit value that is specified in the **High value** parameter (→ 65).



The unit depends on the process variable selected in the **Assign variable** parameter (→ 64).

High value**Navigation**

Expert → Sensor → Process param. → Partial pipe det → High value (1835)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 64):

- Density
- Ref.density

Description

Use this function to enter an upper limit value to enable detection of empty or partially filled measuring tubes. If the measured density exceeds this value, detection is enabled.

User entry

Signed floating-point number

Factory setting

6 000

Additional information*User entry*

The upper limit value must be greater than the lower limit value, that is specified in the **Low value** parameter (→ 64).



The unit depends on the process variable selected in the **Assign variable** parameter (→ 64).

Response time**Navigation**

Expert → Sensor → Process param. → Partial pipe det → Response time (1836)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 64):

- Density
- Ref.density

Description

Use this parameter to enter the time period until the diagnostic message **△S862 Partly filled** appears in the case of a partially filled or empty measuring tube.

User entry

0 to 100 s

Factory setting

1 s

Max. damping

Navigation Expert → Sensor → Process param. → Partial pipe det → Max. damping (2492)

Prerequisite One of the following options is selected in the **Assign variable** parameter (→ [64](#)):

- Density
- Ref.density

Description Use this function to enter a damping value to enable detection of empty or partially filled measuring tubes.

User entry Positive floating-point number

Factory setting 0

Additional information *Description*


In the case of non-homogeneous media or air pockets, the damping of the measuring tubes increases. If the set value is exceeded, the diagnostic message **△S862 Partly filled** is displayed.

User entry

The parameter is enabled only if the input value is greater than **0**.

3.2.4 "Measurement mode" submenu

Navigation Expert → Sensor → Measurement mode

**Select medium**

Navigation Expert → Sensor → Measurement mode → Select medium (2513)

Description Use this function to select the type of medium.

Selection

- Liquid
- Gas

Factory setting Liquid

Select gas type



Navigation Expert → Sensor → Measurement mode → Select gas type (2488)

Prerequisite In the **Select medium** parameter (→ 66) the **Gas** option is selected.

Description Use this function to select the type of gas for the measuring application.

Selection

- Air
- Ammonia NH₃
- Neon Ne
- Argon Ar
- Sulf. hex.fl.SF₆
- Oxygen O₂
- Ozone O₃
- Nitrog. ox. NO_x
- Nitrogen N₂
- Nitrous ox. N₂O
- Methane CH₄
- Hydrogen H₂
- Helium He
- Hydrog.chlor.HCl
- Hydrog.sulf. H₂S
- Ethylene C₂H₄
- Carbon diox. CO₂
- Carbon monox. CO
- Chlorine Cl₂
- Butane C₄H₁₀
- Propane C₃H₈
- Propylene C₃H₆
- Ethane C₂H₆
- Others
- Krypton Kr
- Xenon Xe
- Vinyl Chloride
- Sulfur diox. SO₂

Factory setting Air

Sound velocity



Navigation Expert → Sensor → Measurement mode → Sound velocity (2489)

Prerequisite In the **Select gas type** parameter (→ 67) the **Others** option is selected.

Description Use this function to enter the sound velocity of the desired gas at 0 °C (+32 °F).

User entry 1 to 99 999.9999 m/s

Factory setting 331.5 m/s

Additional information *User entry*

For conversion: 1 m/s = 3.281 ft/s

Temp. coeff. SV



Navigation Expert → Sensor → Measurement mode → Temp. coeff. SV (2490)

Prerequisite In the **Select gas type** parameter (→ 67) the **Others** option is selected.

Description Use this function to enter the temperature coefficient of the sound velocity of the desired gas.

User entry Positive floating-point number


Factory setting 0.61 (m/s)/K

Additional information *User entry*

For conversion: $T [K] = 0.555 \times T [^{\circ}F]$

3.2.5 "External comp." submenu

Navigation Expert → Sensor → External comp.



Pressure compen.



Navigation Expert → Sensor → External comp. → Pressure compen. (2579)

Description Use this function to switch on automatic pressure correction.

Selection

- Off
- Fixed value
- External value

Factory setting	Off
Additional information	<p><i>Description</i></p> <p>With the automatic pressure correction it is possible to compensate the differential pressure effect between the calibration pressure and process pressure, which affects the measured error of the mass flow or density.</p> <p><i>"Off" option</i></p> <p>Pressure correction is switched off.</p> <p><i>"Fixed value" option</i></p> <p>The process pressure for pressure correction is fixed.</p> <p> The unit is taken from the Pressure unit parameter (→ 57)</p> <p><i>"External value" option</i></p> <p>The process pressure for pressure correction is read in.</p>

Pressure value



Navigation	 Expert → Sensor → External comp. → Pressure value (2580)
Prerequisite	In the Pressure compen. parameter (→ 68) the Fixed value option is selected.
Description	Use this function to enter a value for the process pressure to be used for pressure correction.
User entry	Positive floating-point number
Factory setting	Country-specific: ■ 1.01 bar a ■ 14.7 psi a
Additional information	<p><i>Dependency</i></p> <p> The unit is taken from the Pressure unit parameter (→ 57)</p>

External press.

Navigation	 Expert → Sensor → External comp. → External press. (2592)
Prerequisite	The following conditions are met: ■ The Gas option is selected in the Select medium parameter (→ 66). ■ The External value option is selected in the Pressure compen. parameter (→ 68).
Description	Displays the fixed value for the process pressure.
User interface	Signed floating-point number


Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ 57)

3.2.6 "Calculated value" submenu

Navigation


Expert → Sensor → Calculated value



"Corr. vol.flow." submenu

Navigation

Expert → Sensor → Calculated value → Corr. vol.flow.



Corr. vol.flow.

**Navigation**

Expert → Sensor → Calculated value → Corr. vol.flow. → Corr. vol.flow. (1812)

Description

Use this function to select the reference density for calculating the corrected volume flow.

Selection

- Fix ref.density
- Calc ref density

Factory setting

Calc ref density

Additional information*Selection*

The **Ref. dens API 53** option is suitable only for applications involving LPG²⁾, where the flow rate is measured on the basis of the corrected volume flow.

Selecting this option means that the reference density is used, taking into account the values in table 53 E of API MPMS section 11.2. Temperature measurement (measured internally or read into the device from an external source) and density measurement take place during operation while the medium is flowing. The mass flow is divided by the reference density to give the corrected volume flow and is issued as an output signal.

2) liquefied petroleum gas

"Reference values" submenu*Navigation*
 Expert → Sensor → Calculated value → Reference values

► Reference values	
Fix ref.density (1814)	→  71
Ref. temperature (1816)	→  71
Linear exp coeff (1817)	→  72
Square exp coeff (1818)	→  72

Fix ref.density**Navigation**
 Expert → Sensor → Calculated value → Reference values → Fix ref.density (1814)
Prerequisite

The **Fix ref.density** option is selected in the **Corr. vol.flow.** parameter (→  70) parameter.

Description

Use this function to enter a fixed value for the reference density.

User entry

Positive floating-point number

Factory setting

1 kg/Nl

Additional information

Dependency

 The unit is taken from the **Ref. dens. unit** parameter (→  56)

Ref. temperature**Navigation**
 Expert → Sensor → Calculated value → Reference values → Ref. temperature (1816)
Prerequisite

The **Calc ref density** option is selected in the **Corr. vol.flow.** parameter (→  70) parameter.

Description

Use this function to enter a reference temperature for calculating the reference density.

User entry

-273.15 to 99 999 °C

Factory setting

Country-specific:

■ +20 °C

■ +68 °F

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 56)

Reference density calculation

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_N : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

Linear exp coeff**Navigation**

Expert → Sensor → Calculated value → Reference values → Linear exp coeff (1817)

Prerequisite

The **Calc ref density** option is selected in the **Corr. vol.flow.** parameter (→ 70) parameter.

Description

Use this function to enter a linear, fluid-specific expansion coefficient for calculating the reference density.

User entry

Signed floating-point number

Factory setting

0.0

Square exp coeff**Navigation**

Expert → Sensor → Calculated value → Reference values → Square exp coeff (1818)

Prerequisite

The **Calc ref density** option is selected in the **Corr. vol.flow.** parameter (→ 70) parameter.

Description

For fluid with a non-linear expansion pattern: use this function to enter a quadratic, fluid-specific expansion coefficient for calculating the reference density.

User entry

Signed floating-point number


Factory setting

0.0

3.2.7 "Sensor adjustm." submenu

Navigation

Expert → Sensor → Sensor adjustm.



Install. direct.



Navigation

Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description

Use this function to change the sign of the medium flow direction.

Selection

- In arrow direct.
- Against arrow

Factory setting

In arrow direct.

Additional information

Description


Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

"Zero point adj." submenu



- It is generally not necessary to perform zero point adjustment.
- However, this function may be needed in some applications with low flow and strict accuracy requirements.
- A zero point adjustment cannot increase repeatability.
- The following conditions should be met to perform a zero point adjustment successfully without the adjustment finishing in an error:
 - The real flow must be **0**.
 - The pressure must be at least 15 psi g.
- The adjustment takes a maximum of 60 s. The more stable the conditions, the faster the adjustment is completed.
- This function can also be used to check the health of the measuring device. A healthy measuring device has a maximum zero point deviation of ±100 compared to the factory setting of the measuring device (calibration report).

Navigation Expert → Sensor → Sensor adjustm. → Zero point adj.



Zero point adj.



Navigation Expert → Sensor → Sensor adjustm. → Zero point adj. → Zero point adj. (2587)

Description Use this parameter to start automatic zero point adjustment.

Selection

- Cancel
- Busy
- Zero adjust fail
- Start

Factory setting Cancel

Additional information Description

During calibration, the **Busy** option and the **Adj. in progress** parameter (→ 74) appear beneath the parameter. If the sensor is defective or flow is present, the **Zero adjust fail** option appears on the display. At the same time, this event is entered in the event logbook (event list) → 181.

The new zero point value determined by the measuring device is displayed in the **Zero point** parameter (→ 80).

Information on the procedure for performing zero point adjustment is provided in the Operating Instructions for the device.

Description

- Cancel
If zero point adjustment has failed, select this option to cancel zero point adjustment.
- Busy
Is displayed during zero point adjustment.
- Zero adjust fail
Is displayed if zero point adjustment has failed.
- Start
Select this option to start zero point adjustment.

Adj. in progress

Navigation Expert → Sensor → Sensor adjustm. → Zero point adj. → Adj. in progress (2588)

Prerequisite The **Start** option is selected in the **Zero point adj.** parameter (→ 74).

Description Displays the current status of the zero point adjustment via a progress bar.

User interface 0 to 100 %

"Variable adjust" submenu

Navigation

Expert → Sensor → Sensor adjustm. → Variable adjust

► Variable adjust	
Mass flow offset (1820)	→ 75
Mass flow factor (1819)	→ 76
Vol. flow offset (1815)	→ 76
Vol. flow factor (1821)	→ 76
Corr. vol offset (1824)	→ 77
Corr. vol factor (1823)	→ 77
Density offset (1826)	→ 77
Density factor (1825)	→ 78
Ref.dens. offset (1828)	→ 78
Ref.dens. factor (1827)	→ 78
Temp. offset (1830)	→ 78
Temp. factor (1829)	→ 79

Mass flow offset



Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1820)

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is 1 kg/s.

User entry Signed floating-point number

Factory setting 0 kg/s

Additional information *Description* Corrected value = (factor × value) + offset**Mass flow factor** **Navigation**  Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1819)**Description** Use this function to enter a quantity factor (without time) for the mass flow. This factor refers in each case to the mass flow of 1 kg/s.**User entry** Positive floating-point number**Factory setting** 1**Vol. flow offset** **Navigation**  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1815)**Description** Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is 1 m³/s.**User entry** Signed floating-point number**Factory setting** 0 m³/s**Additional information** *Description* Corrected value = (factor × value) + offset**Vol. flow factor** **Navigation**  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1821)**Description** Use this function to enter a quantity factor (without time) for the volume flow. This factor refers in each case to the volume of 1 m³/s.**User entry** Positive floating-point number**Factory setting** 1

Corr. vol offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1824)

Description Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm³/s.

User entry Signed floating-point number

Factory setting 0 Nm³/s

Additional information *Description*



Corrected value = (factor × value) + offset

Corr. vol factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1823)

Description Use this function to enter a quantity factor (without time) for the corrected volume flow. This factor refers in each case to the standard volume of 1 Nm³/s.

User entry Positive floating-point number

Factory setting 1

Density offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density offset (1826)

Description Use this parameter to enter the zero point shift for the density trim. The density unit on which the shift is based is 1 kg/m³.

User entry Signed floating-point number

Factory setting 0 kg/m³

Additional information *Description*



Corrected value = (factor × value) + offset

Density factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density factor (1825)

Description Use this function to enter a quantity factor for the density. This factor refers in each case to the density of 1 kg/m³.

User entry Positive floating-point number

Factory setting 1

Ref.dens. offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Ref.dens. offset (1828)

Description Use this parameter to enter the zero point shift for the reference density trim. The standard density unit on which the shift is based is 1 kg/Nm³.

User entry Signed floating-point number

Factory setting 0 kg/Nm³

Additional information *Description*

Corrected value = (factor × value) + offset

Ref.dens. factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Ref.dens. factor (1827)

Description Use this function to enter a quantity factor for the reference density. This factor refers in each case to the reference density of 1 kg/Nm³.

User entry Positive floating-point number

Factory setting 1

Temp. offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1830)

Description Use this function to enter the zero point shift for the temperature trim. The temperature on which the shift is based is entered in Kelvin.

User entry Signed floating-point number

Factory setting 0 K

Additional information *Description*



Corrected value = (factor × value) + offset

Temp. factor



Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1829)

Description Use this parameter to enter a factor by which the temperature in Kelvin is multiplied.

User entry Positive floating-point number

Factory setting 1

3.2.8 "Calibration" submenu

Navigation

Expert → Sensor → Calibration

Calibration	
Cal. factor (2431)	→ 80
Zero point (2437)	→ 80
Nominal diameter (2807)	→ 80
C 0 (2469)	→ 81
C 1 (2574)	→ 81
C 2 (2575)	→ 81
C 3 (2576)	→ 81
C 4 (2577)	→ 82
C 5 (2578)	→ 82

Cal. factor

Navigation   Expert → Sensor → Calibration → Cal. factor (2431)

Description Displays the current calibration factor for the sensor.

User interface Signed floating-point number

Factory setting Depends on nominal diameter and calibration

Additional information *Description*

 The value is also specified on the sensor nameplate.

Zero point



Navigation   Expert → Sensor → Calibration → Zero point (2437)

Description Use this function to enter a zero point correction value for the sensor.

User entry Signed floating-point number

Factory setting 0

Additional information *Description*

 The value is also specified on the sensor nameplate.

Nominal diameter

Navigation   Expert → Sensor → Calibration → Nominal diameter (2807)

Description Displays the nominal diameter of the sensor.

User interface DNxx / x"

Factory setting Depends on the size of the sensor

Additional information *Description*

 The value is also specified on the sensor nameplate.

C 0

Navigation   Expert → Sensor → Calibration → C 0 (2469)

Description Displays the current density coefficient C0 of the sensor.

Additional information *Description*

 A density trim can alter the calibration value of the density coefficient.

C 1

Navigation   Expert → Sensor → Calibration → C 1 (2574)

Description Displays the current density coefficient C1 of the sensor.

Additional information *Description*

 A density trim can alter the calibration value of the density coefficient.

C 2

Navigation   Expert → Sensor → Calibration → C 2 (2575)

Description Displays the current density coefficient C2 of the sensor.

Additional information *Description*

 A density trim can alter the calibration value of the density coefficient.

C 3

Navigation   Expert → Sensor → Calibration → C 3 (2576)

Description Displays the current density coefficient C3 of the sensor.

Additional information *Description*

 A density trim can alter the calibration value of the density coefficient.

C 4

Navigation  Expert → Sensor → Calibration → C 4 (2577)**Description**

Displays the current density coefficient C4 of the sensor.

Additional information*Description*

A density trim can alter the calibration value of the density coefficient.

C 5


Navigation  Expert → Sensor → Calibration → C 5 (2578)**Description**

Displays the current density coefficient C5 of the sensor.


Additional information*Description*

A density trim can alter the calibration value of the density coefficient.

3.3 "Output" submenu

Navigation  Expert → Output

3.3.1 "Pulse/frequency/switch output" submenu

Navigation  Expert → Output → PFS output

Failure mode (0480)	→ 88
Pulse output (0456)	→ 88
Assign freq. (0478)	→ 89
Min. freq. value (0453)	→ 90
Max. freq. value (0454)	→ 90
Val. at min.freq (0476)	→ 91
Val. at max.freq (0475)	→ 91
Measuring mode (0479)	→ 91
Damping out. (0477)	→ 94
Response time (0491)	→ 94
Failure mode (0451)	→ 95
Failure freq. (0474)	→ 96
Output freq. (0471)	→ 96
Switch out funct (0481)	→ 96
Assign diag. beh (0482)	→ 97
Assign limit (0483)	→ 98
Switch-on value (0466)	→ 99
Switch-off value (0464)	→ 100
Assign dir.check (0484)	→ 100
Assign status (0485)	→ 101
Switch-on delay (0467)	→ 101
Switch-off delay (0465)	→ 101
Failure mode (0486)	→ 102
Switch status (0461)	→ 102
Invert outp.sig. (0470)	→ 103

Operating mode**Navigation**

Expert → Output → PFS output → Operating mode (0469)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse


Additional information*"Pulse" option*

Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass, volume or corrected volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s



2 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as mass flow, volume flow, corrected volume flow, density, reference density, temperature, carrier tube temperature, electronic temperature, vibration frequency, oscillation amplitude, oscillation damping or signal asymmetry.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz




3 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm



4 No alarm, high level

Example

Alarm response in case of alarm



5 Alarm, low level

Assign pulse



Navigation

Expert → Output → PFS output → Assign pulse (0460)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 84) parameter.

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow

Factory setting


Off

Value per pulse

Navigation	Expert → Output → PFS output → Value per pulse (0455)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 84) and a process variable is selected in the Assign pulse parameter (→ 85).
Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 208
Additional information	<i>User entry</i> Weighting of the pulse output with a quantity. The lower the pulse value, the <ul style="list-style-type: none">▪ better the resolution.▪ the higher the frequency of the pulse response.

Pulse width

Navigation	Expert → Output → PFS output → Pulse width (0452)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 84) and a process variable is selected in the Assign pulse parameter (→ 85).
Description	Use this function to enter the duration of the output pulse.
User entry	5 to 2 000 ms
Factory setting	100 ms
Additional information	<i>Description</i> <ul style="list-style-type: none">▪ Define how long a pulse is (duration).▪ The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$.▪ The interval between two pulses lasts at least as long as the set pulse width.▪ The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$.▪ If the flow exceeds these limit values, the measuring device displays the diagnostic message △S443 Pulse output 1.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- f_{\max} : $1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- Q_{\max} : $5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation

Expert → Output → PFS output → Measuring mode (0457)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse** parameter (→ 85):

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse
- Reverse flow
- Rev. flow comp.

Factory setting

Forward flow

Additional information

Selection

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Rev. flow comp.
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



For a detailed description of the options available, see the **Measuring mode** parameter (→ 91)

Failure mode**Navigation**

Expert → Output → PFS output → Failure mode (0480)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign pulse** parameter (→ 85).

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

Selection

- Actual value
In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.
- No pulses
In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output**Navigation**

Expert → Output → PFS output → Pulse output (0456)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 84) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 86) and **Pulse width** parameter (→ 86) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0028726

- 0 Non-conductive*
- 1 Conductive*
- NC NC contact (normally closed)*
- NO NO contact (normally open)*

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 103) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 88)) can be configured.

Assign freq.



Navigation

Expert → Output → PFS output → Assign freq. (0478)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) parameter.

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Carr. pipe temp. *
- Electronic temp.
- Oscil. frequency
- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Selection*

- Oscil. frequency
Displays the current oscillation frequency of the measuring tubes. This frequency depends on the density of the medium.
- Oscil. amplitude
Displays the relative oscillation amplitude of the measuring tubes in relation to the preset value. This value is 100 % under optimum conditions. The value can decrease in the event of low 4 to 20 mA loop currents and/or difficult media (two-phase, high viscosity or high gas velocity).
- Oscil. damping
Displays the current oscillation damping. Oscillation damping is an indicator of the sensor's current need for excitation power.
- Signal asymmetry
Displays the relative difference between the oscillation amplitude at the inlet and outlet of the sensor. The measured value is the result of production tolerances of the sensor coils and should remain constant over the life time of a sensor.

Min. freq. value**Navigation**

Expert → Output → PFS output → Min. freq. value (0453)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign freq.** parameter (→ 89).

Description

Use this function to enter the start value frequency.

User entry

0 to 1 000 Hz

Factory setting

0 Hz

Max. freq. value**Navigation**

Expert → Output → PFS output → Max. freq. value (0454)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign freq.** parameter (→ 89).

Description

Use this function to enter the end value frequency.

User entry

0 to 1 000 Hz

Factory setting

1 000 Hz

Val. at min.freq**Navigation**

Expert → Output → PFS output → Val. at min.freq (0476)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign freq.** parameter (→ 89).

Description

Use this function to enter the measured value for the start value frequency.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Dependency*

The entry depends on the process variable selected in the **Assign freq.** parameter (→ 89).

Val. at max.freq**Navigation**

Expert → Output → PFS output → Val. at max.freq (0475)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign freq.** parameter (→ 89).

Description

Use this function to enter the measured value for the end value frequency.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

The entry depends on the process variable selected in the **Assign freq.** parameter (→ 89).

Measuring mode**Navigation**

Expert → Output → PFS output → Measuring mode (0479)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 89):

- Mass flow
- Volume flow
- Correct.vol.flow
- Density

- Ref.density
- Temperature
- Carr. pipe temp. *
- Electronic temp.
- Oscil. frequency
- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

 Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: Assign freq. parameter (→ 89)

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse
- Rev. flow comp.

Factory setting

Forward flow

Additional information

"Forward flow" option

The frequency output signal is proportional to the measured variable assigned. The measuring range is defined by the values that are assigned to the Val. at min.freq (A) and the Val. at max.freq (B).

The flow components outside the scaled measuring range are taken into account for signal output as follows:

One of the values is defined as equal to zero flow e.g.:


- Val. at min.freq = 0 kg/h
- Val. at max.freq = 10kg/h
 - If the effective flow exceeds or falls below this measured value, no diagnostic message is output and the frequency output retains its value (0 Hz in the example).
 - If the effective flow exceeds or falls below the other measured value, the diagnostic message **△S442 Freq. output** is displayed and the frequency output behaves as configured in the **Failure mode** parameter (→ 95).

Both values are defined such that they are not equal to zero flow e.g.:

- Val. at min.freq = -5 kg/h
- Val. at max.freq = 10kg/h

If the effective flow exceeds or falls below this measuring range, the diagnostic message **△S442 Freq. output 1 to n** is displayed and the frequency output behaves as configured in the **Failure mode** parameter (→ 95).

* Visibility depends on order options or device settings




A0026641

- A Val. at min.freq
- B Val. at max.freq

"Forward/Reverse" option

The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The Val. at min.freq (A) and Val. at max.freq (B) must have the same sign (+ or -). The Val. at max.freq (C) (e.g. reverse flow) corresponds to the mirrored Val. at min.freq (e.g. forward flow).



A0026642

- The flow direction can be output via the configurable relay or status outputs.
- The **Forward/Reverse** option can only be selected if the values in the **Val. at min.freq** parameter (→ 91) and **Val. at max.freq** parameter (→ 91) have the same sign or one of the values is zero.
- The **Forward/Reverse** option cannot be selected if the values have different signs.

"Rev. flow comp." option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

If buffering cannot be processed within approx. 60 s, the diagnostic message **△S442 Freq. output 1 to n** is displayed.

If buffering cannot be processed within approx. 60 s, the diagnostic message **△S442 Freq. output** is displayed.

Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid reverse flow. However, this buffer is reset in all relevant programming adjustments which affect the frequency output.

Damping out.**Navigation**

Expert → Output → PFS output → Damping out. (0477)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 89):

- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Carr. pipe temp.*
- Electronic temp.
- Oscil. frequency
- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: **Assign freq.** parameter (→ 89)

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element³⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time**Navigation**

Expert → Output → PFS output → Response time (0491)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Frequency** option is selected, and one of the following options is selected in the **Assign freq.** parameter (→ 89):

- Mass flow
- Volume flow
- Correct.vol.flow

* Visibility depends on order options or device settings

3) proportional transmission behavior with first order delay

- Density
- Ref.density
- Temperature
- Carr. pipe temp. *
- Electronic temp.
- Oscil. frequency
- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

 Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: Assign freq. parameter (→ 89).

Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ■ Damping of pulse/frequency/switch output and ■ Depending on the measured variable assigned to the output. <ul style="list-style-type: none"> - Flow damping or - Density damping or - Temperature damping

Failure mode



Navigation	 Expert → Output → PFS output → Failure mode (0451)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 84) and a process variable is selected in the Assign freq. parameter (→ 89).
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Actual value ■ Defined value ■ 0 Hz
Factory setting	0 Hz

* Visibility depends on order options or device settings

Additional information**Selection****■ Actual value**

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

■ Defined value

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure freq. (→ 96) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

■ 0 Hz

In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Failure freq.**Navigation**

Expert → Output → PFS output → Failure freq. (0474)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 84) and a process variable is selected in the **Assign freq.** parameter (→ 89).

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 1250.0 Hz

Factory setting

0.0 Hz

Output freq.**Navigation**

Expert → Output → PFS output → Output freq. (0471)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0 to 1250 Hz

Switch out funct**Navigation**

Expert → Output → PFS output → Switch out funct (0481)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 84).

Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diag. behavior ▪ Limit ▪ Fl. direct.check ▪ Status
Factory setting	Off
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off The switch output is permanently switched off (open, non-conductive). ▪ On The switch output is permanently switched on (closed, conductive). ▪ Diag. behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ▪ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ▪ Fl. direct.check Indicates the flow direction (forward or reverse flow). ▪ Status Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diag. beh



Navigation	Expert → Output → PFS output → Assign diag. beh (0482)
Prerequisite	<ul style="list-style-type: none"> ▪ In the Operating mode parameter (→ 84), the Switch option is selected. ▪ In the Switch out funct parameter (→ 96), the Diag. behavior option is selected.
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning
Factory setting	Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output → Assign limit (0483)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 84) parameter.
- The **Limit** option is selected in the **Switch out funct** parameter (→ 96) parameter.

Description

Use this function to select a process variable for the limit function.

Selection

- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3


Factory setting

Mass flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive




A0026891

- | | |
|---|------------------|
| 1 | Switch-on value |
| 2 | Switch-off value |
| 3 | Conductive |
| 4 | Non-conductive |
| A | Process variable |
| B | Status output |

Behavior of status output when Switch-on value < Switch-off value:


- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive



- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output → Switch-on value (0466)

Prerequisite

- In the **Operating mode** parameter (→ 84), the **Switch** option is selected.
- In the **Switch out funct** parameter (→ 96), the **Limit** option is selected.

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

 When using a hysteresis: Switch-on value > Switch-off value.

Dependency

 The unit depends on the process variable selected in the **Assign limit** parameter (→ [98](#)).

Switch-off value**Navigation**

  Expert → Output → PFS output → Switch-off value (0464)

Prerequisite

- In the **Operating mode** parameter (→ [84](#)), the **Switch** option is selected.
- In the **Switch out funct** parameter (→ [96](#)), the **Limit** option is selected.

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

 When using a hysteresis: Switch-on value > Switch-off value.

Dependency

 The unit depends on the process variable selected in the **Assign limit** parameter (→ [98](#)).

Assign dir.check**Navigation**

  Expert → Output → PFS output → Assign dir.check (0484)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [84](#)).
- The **Fl. direct.check** option is selected in the **Switch out funct** parameter (→ [96](#)).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection	<ul style="list-style-type: none">■ Mass flow■ Volume flow■ Correct.vol.flow
------------------	--

Factory setting	Mass flow
------------------------	-----------

Assign status

Navigation	Expert → Output → PFS output → Assign status (0485)
-------------------	---

Prerequisite	<ul style="list-style-type: none">■ The Switch option is selected in the Operating mode parameter (→ 84).■ The Status option is selected in the Switch out funct parameter (→ 96).
---------------------	---

Description	Use this function to select a device status for the switch output.
--------------------	--

Selection	<ul style="list-style-type: none">■ Partial pipe det■ Low flow cut off■ Digital outp. 3
------------------	---

Factory setting	Partial pipe det
------------------------	------------------

Additional information	<i>Options</i>
-------------------------------	----------------

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay

Navigation	Expert → Output → PFS output → Switch-on delay (0467)
-------------------	---

Prerequisite	<ul style="list-style-type: none">■ The Switch option is selected in the Operating mode parameter (→ 84).■ The Limit option is selected in the Switch out funct parameter (→ 96).
---------------------	--

Description	Use this function to enter a delay time for switching on the switch output.
--------------------	---

User entry	0.0 to 100.0 s
-------------------	----------------

Factory setting	0.0 s
------------------------	-------

Switch-off delay

Navigation	Expert → Output → PFS output → Switch-off delay (0465)
-------------------	--

Prerequisite	<ul style="list-style-type: none">■ The Switch option is selected in the Operating mode parameter (→ 84).■ The Limit option is selected in the Switch out funct parameter (→ 96).
---------------------	--

Description	Use this function to enter a delay time for switching off the switch output.
--------------------	--

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode



Navigation Expert → Output → PFS output → Failure mode (0486)

Description Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting Open

Additional information *Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status

Navigation Expert → Output → PFS output → Switch status (0461)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (→ 84).

Description Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information *User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert outp.sig.**Navigation**

Expert → Output → PFS output → Invert outp.sig. (0470)

Description

Use this function to select whether to invert the output signal.

Selection

- No
- Yes


Factory setting

No

Additional information


Selection

No option (passive - negative)



A0026693

Yes option (passive - positive)




A0026692

3.4 "Communication" submenu

Navigation


Expert → Communication



3.4.1 "PROFIBUS PA conf" submenu

Navigation

Expert → Communication → PROFIBUS PA conf



Address mode

Navigation

Expert → Communication → PROFIBUS PA conf → Address mode (1468)

Description

Displays the configured address mode.

User interface

- Hardware
- Software

Factory setting

Software

Additional information

Description

For detailed information, see the "Setting the device address" section of the Operating Instructions.

Device address



Navigation

Expert → Communication → PROFIBUS PA conf → Device address (1462)

Description

Use this function to enter the device address.

User entry

0 to 126

Factory setting

126

Additional information

Description

The address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.

Displays the configured address mode: **Address mode** parameter (→ 104)

Ident num select**Navigation**

Expert → Communication → PROFIBUS PA conf → Ident num select (1461)

Description

Use this function to select the device master file (GSD).

Selection

- Automatic mode
- Promass 200
- 3AI,1Tot(0x9742)
- 2AI,1Tot(0x9741)
- 1AI,1Tot(0x9740)

Factory setting

Automatic mode

Additional information*Description*

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

3.4.2 "PROFIBUS PA info" submenu

Navigation

Expert → Communication → PROFIBUS PA info

▶ PROFIBUS PA info	
Stat Master Conf (1465)	→ 105
Ident number (1464)	→ 106
Profile version (1463)	→ 106
Base current (1466)	→ 106
Terminal volt. 1 (0662)	→ 106

Stat Master Conf

Navigation

Expert → Communication → PROFIBUS PA info → Stat Master Conf (1465)

Description

For displaying the status of the PROFIBUS Master configuration.

User interface

- Active
- Not active

Factory setting Not active

Ident number

Navigation  Expert → Communication → PROFIBUS PA info → Ident number (1464)

Description For displaying the PROFIBUS identification number.

User interface 0 to FFFF

Factory setting 0x155F

Profile version

Navigation  Expert → Communication → PROFIBUS PA info → Profile version (1463)

Description Displays the profile version.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting 3.02

Base current

Navigation  Expert → Communication → PROFIBUS PA info → Base current (1466)

Description Displays the basic current: Every PA measuring device taps a constant basic current from the MBP cable. This base current must be at least 10 mA. The base current enables power to be supplied to the measuring device.

User interface 15 mA

Terminal volt. 1

Navigation  Expert → Communication → PROFIBUS PA info → Terminal volt. 1 (0662)

Description Displays the current terminal voltage that is applied at the output.

User interface 0.0 to 50.0 V

3.4.3 "Physical block" submenu

Navigation

Expert → Communication → Physical block

► Physical block	
Device tag (1496)	→ 108
Static revision (1495)	→ 108
Strategy (1494)	→ 108
Alert key (1473)	→ 109
Target mode (1497)	→ 109
Mode block act (1472)	→ 109
Mode block perm (1493)	→ 109
Mode blk norm (1492)	→ 110
Alarm summary (1474)	→ 110
Software rev. (1478)	→ 111
Hardware rev. (1479)	→ 111
Manufacturer ID (1502)	→ 111
Device ID (1480)	→ 111
Serial number (1481)	→ 112
Diagnostics (1482)	→ 112
Diagnostics mask (1484)	→ 112
Dev certificate (1486)	→ 113
Factory reset (1488)	→ 113
Descriptor (1489)	→ 114
Device message (1490)	→ 114
Device inst.date (1491)	→ 114
Ident num select (1461)	→ 114

Hardware lock (1499)	→ 115
Feature support (1477)	→ 115
Feature enabled (1476)	→ 115
Condensed status (1500)	→ 116

Device tag

Navigation Expert → Communication → Physical block → Device tag (1496)

Description Use this function to enter the name for the measuring point.

User entry Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Promass 200

Static revision

Navigation Expert → Communication → Physical block → Static revision (1495)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

Static parameters are parameters that are not changed by the process.

Strategy

Navigation Expert → Communication → Physical block → Strategy (1494)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key**Navigation**

Expert → Communication → Physical block → Alert key (1473)

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

Expert → Communication → Physical block → Target mode (1497)

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Out of service

Mode block act**Navigation**

Expert → Communication → Physical block → Mode block act (1472)

Description

Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 109).

User interface

- Auto
- Out of service

Additional information*Description*

A comparison of the current mode with the target mode (**Target mode** parameter (→ 109)) indicates whether it was possible to reach the target mode.

Mode block perm**Navigation**

Expert → Communication → Physical block → Mode block perm (1493)

Description

Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 109) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface	0 to 255
----------------	----------

Mode blk norm

Navigation	 Expert → Communication → Physical block → Mode blk norm (1492)
Description	Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">■ Auto■ Out of service

Alarm summary

Navigation	 Expert → Communication → Physical block → Alarm summary (1474)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alm statHiHi lim■ Alrm stat Hi lim■ Alm statLoLo lim■ Alrm stat Lo lim■ Update Event
Additional information	<p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Physical Block function block.</p> <p><i>User interface</i></p> <ul style="list-style-type: none">■ Discrete alarm Alarm or warning message with a discrete value.■ Alm statHiHi lim Upper alarm limit■ Alrm stat Hi lim Upper warning limit■ Alm statLoLo lim Lower alarm limit■ Alrm stat Lo lim Lower warning limit■ Update Event This option constitutes a special alarm that is triggered if a static parameter is changed. If such a parameter is modified, the associated bit is set in the Alarm summary parameter (→  110), the output of the block switches to "GOOD (NC) Active Update Event" (if the current status has a lower priority than this), and the block remains in this state for a duration of 10 s. The block then reverts to the normal state (the output has the last status and the Update Event option bit in the Alarm summary parameter (→  110) is deleted again).

Software rev.

Navigation	 Expert → Communication → Physical block → Software rev. (1478)
Description	Displays the firmware version of the measuring device.
User interface	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Hardware rev.

Navigation	 Expert → Communication → Physical block → Hardware rev. (1479)
Description	Displays the hardware revision of the measuring device.
User interface	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Manufacturer ID

Navigation	 Expert → Communication → Physical block → Manufacturer ID (1502)
Description	Displays the manufacturer ID with which the measuring device has been registered with the PNO (PROFIBUS User Organization).
User interface	0 to FFFF
Factory setting	0x11

Device ID

Navigation	 Expert → Communication → Physical block → Device ID (1480)
Description	Displays the device ID for identifying the measuring device in a PROFIBUS network.
User interface	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	Promass 200

Serial number

Navigation	  Expert → Communication → Physical block → Serial number (1481)
Description	Displays the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number <ul style="list-style-type: none">▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser.▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Diagnostics

Navigation	  Expert → Communication → Physical block → Diagnostics (1482)
Description	Displays the diagnostic messages.
User interface	<ul style="list-style-type: none">▪ HW Error▪ HW Error▪ Temp motor▪ Electronic temp▪ Checksum error▪ Measuremnt error▪ Not initialized▪ Init. error▪ Zero point error▪ Power supply▪ Conf invalid▪ On warmstart▪ On coldstart▪ Maintenance req.▪ Char.invalid▪ Ident num Error▪ More info avlble▪ Mainten. alarm▪ Mainten.demanded▪ Fct.chk or sim.▪ Inval.proc.cond.

Diagnostics mask

Navigation	  Expert → Communication → Physical block → Diagnostics mask (1484)
Description	Displays the diagnostic messages supported by the measuring device.

User interface

- HW Error
- HW Error
- Temp motor
- Electronic temp
- Checksum error
- Measuremnt error
- Not initialized
- Init. error
- Zero point error
- Power supply
- Conf invalid
- On warmstart
- On coldstart
- Maintenance req.
- Char.invalid
- Ident num Error
- More info avlble
- Mainten. alarm
- Mainten.demanded
- Fct.chk or sim.
- Inval.proc.cond.

Dev certificate**Navigation**
 Expert → Communication → Physical block → Dev certificate (1486)
Description

Displays certificates of the measuring device, e.g. Ex certificate.

User interface

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory reset**Navigation**
 Expert → Communication → Physical block → Factory reset (1488)
Description

Use this function to reset a certain set of parameters in a block.

Selection

- to defaults
- warmstart device
- reset bus addr
- Cancel

Factory setting

Cancel

Descriptor**Navigation**

Expert → Communication → Physical block → Descriptor (1489)

Description

Use this function to enter a user-specific string to describe the device within the application.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Device message**Navigation**

Expert → Communication → Physical block → Device message (1490)

Description

Use this function to enter a user-definable message (a string) to describe the device within the application or in the plant.

User entry

Max. 32 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Device inst.date**Navigation**

Expert → Communication → Physical block → Device inst.date (1491)

Description

Use this function to enter the date of installation of the device.

User entry

Max. 16 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Ident num select**Navigation**

Expert → Communication → Physical block → Ident num select (1461)

Description

Use this function to select the device master file (GSD).

Selection

- Automatic mode
- Promass 200
- 3AI,1Tot(0x9742)
- 2AI,1Tot(0x9741)
- 1AI,1Tot(0x9740)

Factory setting

Automatic mode

Additional information**Description**

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file

(GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

Hardware lock

Navigation  Expert → Communication → Physical block → Hardware lock (1499)

Description Displays the hardware write protection.

User interface

- Unprotected
- Protected

Additional information *Description*

Indicates whether it is possible to write-access the measuring device via PROFIBUS (acyclic data transmission, e.g. via the "FieldCare" operating program).

 For detailed information on hardware write protection, see the "Write protection via write protection switch" section of the Operating Instructions.

User interface

- Unprotected
Write access via PROFIBUS is possible (acyclic data transmission).
- Protected
Write access via PROFIBUS is locked (acyclic data transmission).

Feature support

Navigation  Expert → Communication → Physical block → Feature support (1477)

Description Displays the PROFIBUS features that are supported by the measuring device.

User interface

- Condensed status
- Classic diag
- Data ex.broad.
- MS1 app.relation
- PROFIsafe comm.

Feature enabled

Navigation  Expert → Communication → Physical block → Feature enabled (1476)

Description Displays the PROFIBUS features that are enabled in the measuring device.

User interface

- Condensed status
- Classic diag
- Data ex.broad.
- MS1 app.relation
- PROFIsafe comm.

Condensed status**Navigation**

Expert → Communication → Physical block → Condensed status (1500)

Description

Use this function to switch the condensed status diagnostic on and off.

Selection

- Off
- On


Factory setting

On

3.5 "Analog inputs" submenu

Navigation


Expert → Analog inputs



3.5.1 "Analog input 1 to n" submenu

Navigation

Expert → Analog inputs → Analog input 1 to n



Channel

Navigation Expert → Analog inputs → Analog input 1 to n → Channel (1561–1 to n)

Description For selecting the process variable.

Selection

- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature

Factory setting Mass flow

PV filter time

Navigation Expert → Analog inputs → Analog input 1 to n → PV filter time (1524–1 to n)

Description Use this function to enter a time to suppress signal peaks. During the specified time the Analog input does not respond to an erratic increase in the process variable.

User entry Positive floating-point number

Factory setting 0

Fail safe type

Navigation Expert → Analog inputs → Analog input 1 to n → Fail safe type (1525–1 to n)

Description Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting Off

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 118).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value

Navigation Expert → Analog inputs → Analog input 1 to n → Fail safe value (1526–1 to n)

Prerequisite In **Fail safe type** parameter (→ 117), the **Fail safe value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 118)) in the event of an error.

User entry Signed floating-point number

Factory setting 0

Out value

Navigation Expert → Analog inputs → Analog input 1 to n → Out value (1552–1 to n)

Prerequisite In **Target mode** parameter (→ 120), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface Signed floating-point number

Out status

Navigation Expert → Analog inputs → Analog input 1 to n → Out status (1564–1 to n)

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation Expert → Analog inputs → Analog input 1 to n → Out status (1549–1 to n)

Prerequisite In **Target mode** parameter (→ 120), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description

Navigation	Expert → Analog inputs → Analog input 1 to n → Tag description (1562–1 to n)
Description	Use this function to enter a string to identify the block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	Expert → Analog inputs → Analog input 1 to n → Static revision (1560–1 to n)
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>
	Static parameters are parameters that are not changed by the process.

Strategy

Navigation	Expert → Analog inputs → Analog input 1 to n → Strategy (1559–1 to n)
Description	Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert key

Navigation	Expert → Analog inputs → Analog input 1 to n → Alert key (1522–1 to n)
Description	Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	0

Target mode



Navigation Expert → Analog inputs → Analog input 1 to n → Target mode (1563–1 to n)

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block act

Navigation Expert → Analog inputs → Analog input 1 to n → Mode block act (1521–1 to n)

Description Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 120).

User interface

- Auto
- Man
- Out of service

Additional information

Description

A comparison of the current mode with the target mode (**Target mode** parameter (→ 120)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation Expert → Analog inputs → Analog input 1 to n → Mode block perm (1553–1 to n)

Description Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 120) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode blk norm

Navigation Expert → Analog inputs → Analog input 1 to n → Mode blk norm (1546–1 to n)

Description Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface	<ul style="list-style-type: none"> ■ Auto ■ Man ■ Out of service
-----------------------	---

Alarm summary

Navigation	 Expert → Analog inputs → Analog input 1 to n → Alarm summary (1537-1 to n)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none"> ■ Discrete alarm ■ Alm statHiHi lim ■ Alrm stat Hi lim ■ Alm statLoLo lim ■ Alrm stat Lo lim ■ Update Event
Additional information	<p>Description</p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Inputs function block.</p>

Batch ID

Navigation	 Expert → Analog inputs → Analog input 1 to n → Batch ID (1533-1 to n)
Description	Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.
User entry	Positive integer

Batch operation

Navigation	 Expert → Analog inputs → Analog input 1 to n → Batch operation (1534-1 to n)
Description	Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch phase

Navigation Expert → Analog inputs → Analog input 1 to n → Batch phase (1535–1 to n)

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe

Navigation Expert → Analog inputs → Analog input 1 to n → Batch Recipe (1536–1 to n)

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information**Description**

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PVscl lo range

Navigation Expert → Analog inputs → Analog input 1 to n → PVscale lo range (1554–1 to n)

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PVscl up range

Navigation	Expert → Analog inputs → Analog input 1 to n → PVscale up range (1555–1 to n)
Description	Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.
User entry	Signed floating-point number
Factory setting	100.0

Out scale low

Navigation	Expert → Analog inputs → Analog input 1 to n → Out scale low (1548–1 to n)
Description	Use this function to enter the lower value range for the output value in system units.
User entry	Signed floating-point number
Factory setting	0

Out scale up

Navigation	Expert → Analog inputs → Analog input 1 to n → Out scale up (1551–1 to n)
Description	Use this function to enter the upper value range for the output value in system units.
User entry	Signed floating-point number
Factory setting	100.0

Lin type

Navigation	Expert → Analog inputs → Analog input 1 to n → Lin type (1523–1 to n)
Description	Use this function to switch off the linearization type for the input value.
Selection	Off
Factory setting	Off

Out unit

Navigation Expert → Analog inputs → Analog input 1 to n → Out unit (1550–1 to n)

Description Use this function to enter a numerical code (hex) for the system unit.

User entry 0 to 65 535

Factory setting 1997

Out dec_ point

Navigation Expert → Analog inputs → Analog input 1 to n → Out dec_ point (1547–1 to n)

Description Use this function to enter the maximum number of decimal places that are displayed for the output value.

User entry 0 to 7

Factory setting 0

Alarm hysteresis

Navigation Expert → Analog inputs → Analog input 1 to n → Alarm hysteresis (1527–1 to n)

Description Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry Signed floating-point number

Factory setting 0

Hi Hi Lim

Navigation Expert → Analog inputs → Analog input 1 to n → Hi Hi Lim (1528–1 to n)

Description Use this function to enter the value for the upper alarm limit (**HiHi alarm value** parameter (→ 126)).

User entry Signed floating-point number

Factory setting Positive floating-point number

Additional information*Description*

If the output value Out value (→ 118) exceeds this limit value, the **HiHi alarm state** parameter (→ 126) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

Hi Lim**Navigation**

Expert → Analog inputs → Analog input 1 to n → Hi Lim (1529–1 to n)

Description

Use this function to enter the value for the upper warning limit (**Hi alarm value** parameter (→ 127)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

If the output value Out value (→ 118) exceeds this limit value, the **Hi alarm state** parameter (→ 127) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

Lo Lim**Navigation**

Expert → Analog inputs → Analog input 1 to n → Lo Lim (1530–1 to n)

Description

Use this function to enter the value for the lower warning limit (**Lo alarm value** parameter (→ 127)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ 118) exceeds this limit value, the **Lo alarm state** parameter (→ 127) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

Lo Lo Lim

Navigation Expert → Analog inputs → Analog input 1 to n → Lo Lo Lim (1531–1 to n)

Description Use this function to enter the value for the lower alarm limit (**LoLo alarm value** parameter (→ [128\)\)\).](#)

User entry Signed floating-point number

Factory setting Negative floating-point number

Additional information *Description*

If the output value Out value (→ [118\)\) exceeds this limit value, the **LoLo alarm state** parameter \(→ \[128\\)\\) is output.\]\(#\)](#)

User entry

The value is entered in the defined units (**Out unit** parameter (→ [124\)\)\) and must be in the range defined in the **Out scale low** parameter \(→ \[123\\)\\) and **Out scale up** parameter \\(→ \\[123\\\)\\\).\\]\\(#\\)\]\(#\)](#)

HiHi alarm value

Navigation Expert → Analog inputs → Analog input 1 to n → HiHi alarm value (1541–1 to n)

Description Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ [124\)\)\).](#)

User interface Signed floating-point number

HiHi alarm state

Navigation Expert → Analog inputs → Analog input 1 to n → HiHi alarm state (1540–1 to n)

Description Displays the status for the upper alarm limit value (**Hi Hi Lim** parameter (→ [124\)\)\).](#)

User interface

- No alarm
- Alm statHiHi lim

Additional information *User interface*

The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to n → Hi alarm value (1539–1 to n)
Description	Displays the alarm value for the upper warning limit value (Hi Lim parameter (→  125)).
User interface	Signed floating-point number

Hi alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → Hi alarm state (1538–1 to n)
Description	Displays the status for the upper warning limit value (Hi Lim parameter (→  125)).
User interface	<ul style="list-style-type: none">■ No warning■ Alrm stat Hi lim
Additional information	<i>User interface</i>
	 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to n → Lo alarm value (1543–1 to n)
Description	Displays the alarm value for the lower warning limit value (Lo Lim parameter (→  125)).
User interface	Signed floating-point number

Lo alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → Lo alarm state (1542–1 to n)
Description	Displays the status for the lower warning limit value (Lo Lim parameter (→  125)).
User interface	<ul style="list-style-type: none">■ No warning■ Alrm stat Lo lim
Additional information	<i>User interface</i>
	 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

LoLo alarm value

Navigation	Expert → Analog inputs → Analog input 1 to n → LoLo alarm value (1545–1 to n)
Description	Displays the alarm value for the lower alarm limit value (Lo Lo Lim parameter (→ 126)).
User interface	Signed floating-point number

LoLo alarm state

Navigation	Expert → Analog inputs → Analog input 1 to n → LoLo alarm state (1544–1 to n)
Description	Displays the status for the lower alarm limit value (Lo Lo Lim parameter (→ 126)).
User interface	<ul style="list-style-type: none">■ No alarm■ Alm statLoLo lim
Additional information	<i>User interface</i> The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Simulate enabled



Navigation	Expert → Analog inputs → Analog input 1 to n → Simulate enabled (1556–1 to n)
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value



Navigation	Expert → Analog inputs → Analog input 1 to n → Simulate value (1558–1 to n)
Description	Use this function to enter a simulation value for the block.
User entry	Signed floating-point number

Factory setting	0
Additional information	<p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.</p>

Simulate status


Navigation	█ Expert → Analog inputs → Analog input 1 to n → Simulate status (1557–1 to n)
Description	Use this function to enter a simulation status for the block.
User entry	0 to 255
Factory setting	0
Additional information	<p><i>Description</i></p> <p>The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.</p>

Out unit text

Navigation	█ Expert → Analog inputs → Analog input 1 to n → Out unit text (1532–1 to n)
Description	Use this function to enter the out unit text: if a specific out unit does not appear in the code list, the user can enter the specific text. The unit code is then equivalent to the definition provided here.
User entry	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	NoUnit

3.6 "Discrete inputs" submenu

Navigation █ █ Expert → Discrete inputs



3.6.1 "Discrete input 1 to n" submenu

Navigation

Expert → Discrete inputs → Discrete input 1 to n

► Discrete input 1 to n	
Channel (2187-1 to n)	→ 130
Invert (2188-1 to n)	→ 130
Fail safe type (2189-1 to n)	→ 131
Fail safe value (2190-1 to n)	→ 131
Out value (2194-1 to n)	→ 131
Out status (2203-1 to n)	→ 132
Out status (2193-1 to n)	→ 132

Channel



Navigation

Expert → Discrete inputs → Discrete input 1 to n → Channel (2187-1 to n)

Description

Use this function to assign a measured variable to the particular function block.

Selection

- Empty pipe det.
- Low flow cut off
- Switch out.stat.
- Verific. status *

Factory setting

Switch out.stat.

Invert



Navigation

Expert → Discrete inputs → Discrete input 1 to n → Invert (2188-1 to n)

Description

Use this function to invert the input signal.

Selection

- Off
- On

Factory setting

Off

* Visibility depends on order options or device settings

Fail safe type

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Fail safe type (2189–1 to n)
Description	Use this function to select the failure mode.
Selection	<ul style="list-style-type: none">▪ Fail safe value▪ Fallback value▪ Off
Factory setting	Off
Additional information	<p><i>Selection</i></p> <p>If an input or simulation value has the status BAD, the function block uses this predefined failure value:</p> <ul style="list-style-type: none">▪ Fail safe value<ul style="list-style-type: none">A substitute value is used. This is specified in the Fail safe value parameter (→ 131).▪ Fallback value<ul style="list-style-type: none">If the value was good at one point, then this last valid value is used.▪ Off<ul style="list-style-type: none">The system continues to use the bad value.

Fail safe value

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Fail safe value (2190–1 to n)
Prerequisite	In Fail safe type parameter (→ 131), the Fail safe value option is selected.
Description	Use this function to enter a failure value. The value entered is displayed as the output value (Out value parameter (→ 131)) in the event of an error.
User entry	0 to 255
Factory setting	0

Out value

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Out value (2194–1 to n)
Prerequisite	In Target mode parameter (→ 133), the Auto option is selected.
Description	Displays the analog value which is calculated when the function is executed.
User interface	0 to 255

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status (2203–1 to n)

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status (2193–1 to n)

Prerequisite In **Target mode** parameter (→  133), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Discrete inputs → Discrete input 1 to n → Tag description (2201–1 to n)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Static revision (2200–1 to n)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy

Navigation Expert → Discrete inputs → Discrete input 1 to n → Strategy (2199–1 to n)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation Expert → Discrete inputs → Discrete input 1 to n → Alert key (2182–1 to n)

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Discrete inputs → Discrete input 1 to n → Target mode (2202–1 to n)

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block act

Navigation Expert → Discrete inputs → Discrete input 1 to n → Mode block act (2181–1 to n)

Description Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 133).

User interface

- Auto
- Man
- Out of service

Additional information	Description
	 A comparison of the current mode with the target mode (Target mode parameter (→ 133)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Mode block perm (2195-1 to n)
Description	Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 133) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode blk norm

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Mode blk norm (2192-1 to n)
Description	Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">▪ Auto▪ Man▪ Out of service

Alarm summary

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Alarm summary (2191-1 to n)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none">▪ Discrete alarm▪ Alm statHiHi lim▪ Alrm stat Hi lim▪ Alm statLoLo lim▪ Alrm stat Lo lim▪ Update Event
Additional information	 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Inputs function block.

Batch ID**Navigation**

☒ Expert → Discrete inputs → Discrete input 1 to n → Batch ID (2183–1 to n)

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

☒ Expert → Discrete inputs → Discrete input 1 to n → Batch operation (2184–1 to n)

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

☒ Expert → Discrete inputs → Discrete input 1 to n → Batch phase (2185–1 to n)

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe**Navigation**

☒ Expert → Discrete inputs → Discrete input 1 to n → Batch Recipe (2186–1 to n)

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information*Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Simulate enabled**Navigation**

Expert → Discrete inputs → Discrete input 1 to n → Simulate enabled (2196–1 to n)

Description

Use this function to enable or disable block simulation.

Selection

- Disable
- Enable

Factory setting

Disable

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value**Navigation**

Expert → Discrete inputs → Discrete input 1 to n → Simulate value (2198–1 to n)

Description

Use this function to enter a simulation value for the block.

User entry

0 to 255

Factory setting

0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status**Navigation**

Expert → Discrete inputs → Discrete input 1 to n → Simulate status (2197–1 to n)

Description

Use this function to enter a simulation status for the block.

User entry

0 to 255

Factory setting

0


Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

3.7 "Analog outputs" submenu

Navigation


Expert → Analog outputs



3.7.1 "Analog output 1 to n" submenu

Navigation

Expert → Analog outputs → Analog output 1 to n



Set point val
**Navigation**

Expert → Analog outputs → Analog output 1 → Set point val (1661-1)

Description

Use this function to enter an analog set point.

User entry

Signed floating-point number

Factory setting

0

Set point status

Navigation Expert → Analog outputs → Analog output 1 → Set point status (1660–1)

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Fail safe time

Navigation Expert → Analog outputs → Analog output 1 → Fail safe time (1635–1)

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry 0 to 999.0

Factory setting 0

Additional information *User entry*

NOTE!

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- ▶ Check in advance to ensure that the safety-specific requirements of the process would permit this.
- ▶ If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type

Navigation Expert → Analog outputs → Analog output 1 → Fail safe type (1636–1)

Description Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting Fallback value

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value

A substitute value is used. This is specified in the **Fail safe value** parameter (→ 139).

- Fallback value

If the value was good at one point, then this last valid value is used.

- Off

The system continues to use the bad value.

Fail safe value**Navigation**

Expert → Analog outputs → Analog output 1 → Fail safe value (1637-1)

Prerequisite

In **Fail safe type** parameter (→ 138), the **Fallback value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 139)) in the event of an error.

User entry

Signed floating-point number

Factory setting

0

Out value**Navigation**

Expert → Analog outputs → Analog output 1 → Out value (1647-1)

Prerequisite

In **Target mode** parameter (→ 141), the **Auto** option is selected.

Description

Displays the analog value which is calculated when the function is executed.

User interface

Signed floating-point number

Out status**Navigation**

Expert → Analog outputs → Analog output 1 → Out status (1669-1)

Description

Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Analog outputs → Analog output 1 → Out status (1645–1)

Prerequisite In **Target mode** parameter (→ 141), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Analog outputs → Analog output 1 → Tag description (1667–1)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Analog outputs → Analog output 1 → Static revision (1666–1)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Analog outputs → Analog output 1 → Strategy (1665–1)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation Expert → Analog outputs → Analog output 1 → Alert key (1632-1)

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Analog outputs → Analog output 1 → Target mode (1668-1)

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Mode block act

Navigation Expert → Analog outputs → Analog output 1 → Mode block act (1631-1)

Description Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 141).

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Additional information *Description*



A comparison of the current mode with the target mode (**Target mode** parameter (→ 141)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation  Expert → Analog outputs → Analog output 1 → Mode block perm (1648-1)

Description Displays the Mode block perm: This defines which modes of operation in the Target mode (→ [141](#)) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface 0 to 255

Mode blk norm

Navigation  Expert → Analog outputs → Analog output 1 → Mode blk norm (1643-1)

Description Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Alarm summary

Navigation  Expert → Analog outputs → Analog output 1 → Alarm summary (1642-1)

Description Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alm statHiHi lim
- Alrm stat Hi lim
- Alm statLoLo lim
- Alrm stat Lo lim
- Update Event

Additional information *Description*

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Outputs function block.

Batch ID

Navigation Expert → Analog outputs → Analog output 1 → Batch ID (1633-1)

Description Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry Positive integer

Batch operation

Navigation Expert → Analog outputs → Analog output 1 → Batch operation (1639-1)

Description Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch phase

Navigation Expert → Analog outputs → Analog output 1 → Batch phase (1640-1)

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe

Navigation Expert → Analog outputs → Analog output 1 → Batch Recipe (1641-1)

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information	Description
	 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PVscale lo range

Navigation  Expert → Analog outputs → Analog output 1 → PVscale lo range (1651-1)

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PVscale up range

Navigation  Expert → Analog outputs → Analog output 1 → PVscale up range (1652-1)

Description Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 100.0

Readback value

Navigation  Expert → Analog outputs → Analog output 1 → Readback value (1659-1)

Description Displays the readback value. The readback value indicates the current position of the control element within the travel range (between the open and close position) in PV scale units.

User interface Signed floating-point number

Readback status

Navigation	 Expert → Analog outputs → Analog output 1 → Readback status (1658-1)
Description	Displays the readback status. The readback status contains the status information of the slave.
User interface	0 to 255

RCAS in value

Navigation	 Expert → Analog outputs → Analog output 1 → RCAS in value (1655-1)
Description	Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade RCAS in value parameter (→  145). The normal algorithm calculates the output value of the block on the basis of this set point.
User entry	Signed floating-point number
Factory setting	0

RCAS in status

Navigation	 Expert → Analog outputs → Analog output 1 → RCAS in status (1654-1)
Description	Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→  145).
User entry	0 to 255
Factory setting	0

Input channel

Navigation	 Expert → Analog outputs → Analog output 1 → Input channel (1670-1)
Description	Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.
Selection	None
Factory setting	None

Output channel

Navigation Expert → Analog outputs → Analog output 1 → Output channel (1671-1)

Description Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.

Selection External press.

Factory setting External press.

RCAS out value

Navigation Expert → Analog outputs → Analog output 1 → RCAS out value (1657-1)

Description Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.

User interface Signed floating-point number

RCAS out status

Navigation Expert → Analog outputs → Analog output 1 → RCAS out status (1656-1)

Description Displays the RCAS out status. Displays the status of the set point.

User interface 0 to 0xFF

Pos value

Navigation Expert → Analog outputs → Analog output 1 → Pos value (1650-1)

Description Displays the current value of the positioner.

User interface 0 to 255

Position status

Navigation Expert → Analog outputs → Analog output 1 → Position status (1649-1)

Description Displays the current status of the positioner.

User interface	0 to 255
----------------	----------

Setp. deviation

Navigation	Expert → Analog outputs → Analog output 1 → Setp. deviation (1653-1)
Description	Displays the deviation between the set point (Set point val parameter (→ 137)) and the actual value (Readback value parameter (→ 144)).
User interface	Signed floating-point number

Simulate enabled

Navigation	Expert → Analog outputs → Analog output 1 → Simulate enabled (1662-1)
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value

Navigation	Expert → Analog outputs → Analog output 1 → Simulate value (1664-1)
Description	Use this function to enter a simulation value.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status

Navigation Expert → Analog outputs → Analog output 1 → Simulate status (1663-1)

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Increase close

Navigation Expert → Analog outputs → Analog output 1 → Increase close (1638-1)

Description Use this function to enter the effective direction of the positioner in automatic mode.

User entry 0 to 255

Factory setting 0

Out scale up

Navigation Expert → Analog outputs → Analog output 1 → Out scale up (1646-1)

Description Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number

Factory setting 100.0

Out scale low

Navigation Expert → Analog outputs → Analog output 1 → Out scale low (1644-1)

Description Use this function to enter the lower value range for the output value in system units.


User entry Signed floating-point number

Factory setting 0

3.8 "Discrete outputs" submenu

Navigation


Expert → Discrete outputs



3.8.1 "Discrete output 1 to n" submenu

Navigation

Expert → Discrete outputs → Discr. out. 1 to n



Set point val



Navigation

Expert → Discrete outputs → Discr. out. 1 to n → Set point val (1715-1 to n)

Description

Use this function to enter an analog set point.

User entry

0 to 255

Factory setting

0

Set point status

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Set point status (1714–1 to n)

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Invert

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Invert (1692–1 to n)

Description Use this function to switch inversion on and off. Specifies whether the set point should be inverted before the value is set as the output value or the RCAS value (in the automatic mode).

Selection

- Off
- On

Factory setting Off

Fail safe time

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Fail safe time (1697–1 to n)

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry Signed floating-point number

Factory setting 0

Additional information *User entry*

NOTE!

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- ▶ Check in advance to ensure that the safety-specific requirements of the process would permit this.
- ▶ If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Fail safe type (1696–1 to n)
Description	Use this function to select the failure mode.
Selection	<ul style="list-style-type: none">▪ Fail safe value▪ Fallback value▪ Off
Factory setting	Fallback value
Additional information	<p><i>Selection</i></p> <p>If an input or simulation value has the status BAD, the function block uses this predefined failure value:</p> <ul style="list-style-type: none">▪ Fail safe value<ul style="list-style-type: none">A substitute value is used. This is specified in the Fail safe value parameter (→ 151).▪ Fallback value<ul style="list-style-type: none">If the value was good at one point, then this last valid value is used.▪ Off<ul style="list-style-type: none">The system continues to use the bad value.

Fail safe value

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Fail safe value (1693–1 to n)
Prerequisite	In Fail safe type parameter (→ 151), the Fail safe value option is selected.
Description	Use this function to enter a failure value. The value entered is displayed as the output value (Out value parameter (→ 151)) in the event of an error.
User entry	0 to 255
Factory setting	0

Out value

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Out value (1704–1 to n)
Prerequisite	In Target mode parameter (→ 153), the Auto option is selected.
Description	Displays the analog value which is calculated when the function is executed.
User interface	0 to 255

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Out status (1723–1 to n)

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Out status (1703–1 to n)

Prerequisite In **Target mode** parameter (→  153), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Tag description (1721–1 to n)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Static revision (1720–1 to n)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Strategy (1719–1 to n)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Alert key (1694–1 to n)

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Target mode (1722–1 to n)

Description Displays the Target mode: The target mode specifies which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Local override
- Remote Cascaded
- Man
- Out of service
- Auto

Mode block act

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Mode block act (1691–1 to n)

Description Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→ 153).

User interface	<ul style="list-style-type: none">■ Local override■ Remote Cascaded■ Man■ Out of service■ Auto
Additional information	<p><i>Description</i></p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 153)) indicates whether it was possible to reach the target mode.</p>

Mode block perm

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Mode block perm (1705–1 to n)
Description	Displays the Mode block perm: This defines which modes of operation in the Target mode (→ 153) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode blk norm

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Mode blk norm (1702–1 to n)
Description	Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">■ Local override■ Remote Cascaded■ Man■ Out of service■ Auto

Alarm summary

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Alarm summary (1701–1 to n)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alm statHiHi lim■ Alrm stat Hi lim■ Alm statLoLo lim■ Alrm stat Lo lim■ Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Outputs function block.

Batch ID**Navigation**

Expert → Discrete outputs → Discr. out. 1 to n → Batch ID (1695–1 to n)

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

Expert → Discrete outputs → Discr. out. 1 to n → Batch operation (1698–1 to n)

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

Expert → Discrete outputs → Discr. out. 1 to n → Batch phase (1699–1 to n)

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Batch Recipe (1700–1 to n)

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information *Description*

 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Readback value

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Readback value (1713–1 to n)

Description Displays the readback value. The readback value indicates the current position of the control element and the element's sensors.

User interface 0 to 255

Readback status

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → Readback status (1712–1 to n)

Description Displays the readback status. Displays the status of the readback value.

User interface 0 to 255

RCAS in value

Navigation  Expert → Discrete outputs → Discr. out. 1 to n → RCAS in value (1707–1 to n)

Description Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade **RCAS in value** parameter (→  156). The normal algorithm calculates the output value of the block on the basis of this set point.

User entry 0 to 255

Factory setting 0

RCAS in status

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → RCAS in status (1706–1 to n)
Description	Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→ 156).
User entry	0 to 255
Factory setting	0

Input channel

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Input channel (1724–1 to n)
Description	Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.
Selection	None
Factory setting	None

Output channel

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Output channel (1725–1 to n)
Description	Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.
Selection	<ul style="list-style-type: none"> ▪ Flow override ▪ Zero point adj.* ▪ PFS output* ▪ Start verificat.*
Factory setting	Flow override

RCAS out value

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → RCAS out value (1711–1 to n)
Description	Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.

* Visibility depends on order options or device settings

User interface	0 to 255
----------------	----------

RCAS out status

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → RCAS out status (1708-1 to n)
------------	--

Description	Displays the RCAS out status. Displays the status of the set point.
-------------	---

User interface	0 to 255
----------------	----------

Simulate enabled



Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Simulate enabled (1716-1 to n)
------------	---

Description	Use this function to enable or disable block simulation.
-------------	--

Selection	<ul style="list-style-type: none">■ Disable■ Enable
-----------	--

Factory setting	Disable
-----------------	---------

Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.
------------------------	--

Simulate value



Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Simulate value (1718-1 to n)
------------	---

Description	Use this function to enter a simulation value.
-------------	--

User entry	0 to 255
------------	----------

Factory setting	0
-----------------	---

Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.
------------------------	---

Simulate status

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Simulate status (1717–1 to n)

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

3.9 "Application" submenu

Navigation Expert → Application

► Application

► Totalizer 1 to n

→ 159

3.9.1 "Totalizer 1 to n" submenu

Navigation Expert → Application → Totalizer 1 to n

► Totalizer 1 to n

Assign variable (3808–1 to n)

→ 160

Unit totalizer (3835–1 to n)

→ 160

Control Tot. 1 to n (3830–1 to n)

→ 161

Preset value 1 to n (3829–1 to n)

→ 162

Operation mode (3823–1 to n)

→ 162

Failure mode (3810–1 to n)

→ 163

Totalizer val. 1 to n (3827–1 to n)

→ 163

Tot. status 1 to n (3826–1 to n)

→ 164

Status (Hex) 1 to n (3825–1 to n)

→ 164

Assign variable**Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (3808–1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Mass flow
- Volume flow
- Correct.vol.flow

Factory setting

Mass flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Unit totalizer**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer (3835–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ 160):

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to select the process variable of a totalizer.

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 51).

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

SI units

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

or

	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ Nl	■ Sft ³	Sgal (imp)
	■ Nm ³	■ Sgal (us)	
	■ Sl	■ Sbbl (us;liq.)	
	■ Sm ³		
Factory setting	Country-specific:		
	■ kg		
	■ lb		
Additional information	<i>Selection</i>		
	The selection is independent of the process variable selected in the Assign variable parameter (→ 160).		
	<i>Dependency</i>		
	The following parameters depend on the option selected:		
	■ Alarm hysteresis parameter (→ 168)		
	■ Hi Hi Lim parameter (→ 168)		
	■ Hi Lim parameter (→ 169)		
	■ Lo Lim parameter (→ 169)		
	■ Lo Lo Lim parameter (→ 170)		
	■ Totalizer val. parameter (→ 48)		
	■ Preset value parameter (→ 162)		

Control Tot. 1 to n

Navigation	Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (3830-1 to n)
Prerequisite	In the Assign variable parameter (→ 160), one of the following options is selected: ■ Mass flow ■ Volume flow ■ Correct.vol.flow
Description	Use this function to select the control of totalizer value 1-3.
Selection	■ Totalize ■ Reset + hold ■ Preset + hold
Factory setting	Totalize
Additional information	<i>Selection</i> ■ Totalize The totalizer is started or continues totalizing with the current counter reading. ■ Reset + hold The totaling process is stopped and the totalizer is reset to 0. ■ Preset + hold The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.

Preset value 1 to n

Navigation

  Expert → Application → Totalizer 1 to n → Preset value 1 to n (3829–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [160](#)):

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to enter an initial value for the specific totalizer.

User entry

Signed floating-point number

Factory setting

Country-specific:

- kg
- lb

Additional information

User entry

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [160](#)).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Operation mode

**Navigation**

  Expert → Application → Totalizer 1 to n → Operation mode (3823–1 to n)

Prerequisite

In the **Assign variable** parameter (→ [160](#)), one of the following options is selected:

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward total
- Reverse total
- Last valid value

Factory setting

Net flow total

Additional information*Selection*

- Net flow total
Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward total
Only the flow in the forward flow direction is totalized.
- Reverse total
Only the flow against the forward flow direction is totalized (= reverse flow total).
- Last valid value
The value is frozen. Totaling is stopped.

Failure mode**Navigation**

Expert → Application → Totalizer 1 to n → Failure mode (3810-1 to n)

Prerequisite

In the **Assign variable** parameter (→ 160), one of the following options is selected:

- Mass flow
- Volume flow
- Correct.vol.flow

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Actual value

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop
Totalizing is stopped when a device alarm occurs.
- Actual value
The totalizer continues to count based on the current measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

Totalizer val. 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Totalizer val. 1 to n (3827-1 to n)

Prerequisite

In the **Target mode** parameter (→ 165), the **Auto** option is selected.

Description

Displays the current reading for totalizer 1-3.

User interface Signed floating-point number

Additional information *Description*

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 163).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Operation mode** parameter (→ 162).

Dependency

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

Tot. status 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Tot. status 1 to n (3826–1 to n)

Description Displays the status of the particular totalizer.

User interface

- Good
- Uncertain
- Bad

Status (Hex) 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Status (Hex) 1 to n (3825–1 to n)

Prerequisite In **Target mode** parameter (→ 165), the **Auto** option is selected.

Description Displays the status value (hex) of the particular totalizer.

User interface

0 to 0xFF

Tag description



Navigation  Expert → Application → Totalizer 1 to n → Tag description (3833–1 to n)

Description Use this function to enter a string to identify the block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Application → Totalizer 1 to n → Static revision (3832–1 to n)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*



Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Application → Totalizer 1 to n → Strategy (3831–1 to n)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key



Navigation  Expert → Application → Totalizer 1 to n → Alert key (3803–1 to n)

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode



Navigation  Expert → Application → Totalizer 1 to n → Target mode (3834–1 to n)

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block act

Navigation  Expert → Application → Totalizer 1 to n → Mode block act (3801–1 to n)

Description Displays the Mode block act: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block act shows the actual mode in which the function block is currently operating. A comparison of the Mode block act with the Target mode indicates whether it was possible to reach the Target mode (→  165).

User interface

- Auto
- Man
- Out of service

Additional information *Description*
 A comparison of the current mode with the target mode (**Target mode** parameter (→  165)) indicates whether it was possible to reach the target mode.

Mode block perm

Navigation  Expert → Application → Totalizer 1 to n → Mode block perm (3828–1 to n)

Description Displays the Mode block perm: This defines which modes of operation in the Target mode (→  165) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface 0 to 255

Mode blk norm

Navigation  Expert → Application → Totalizer 1 to n → Mode blk norm (3824–1 to n)

Description Displays the Mode blk norm: This is available to allow the operator to select the Mode blk norm from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary

Navigation  Expert → Application → Totalizer 1 to n → Alarm summary (3809–1 to n)

Description Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alm statHiHi lim■ Alrm stat Hi lim■ Alm statLoLo lim■ Alrm stat Lo lim■ Update Event
Additional information	<p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Totalizer function block.</p>

Batch ID	
Navigation	 Expert → Application → Totalizer 1 to n → Batch ID (3804-1 to n)
Description	Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.
User entry	Positive integer
Factory setting	0

Batch operation	
Navigation	 Expert → Application → Totalizer 1 to n → Batch operation (3805-1 to n)
Description	Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch phase	
Navigation	 Expert → Application → Totalizer 1 to n → Batch phase (3806-1 to n)
Description	Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch Recipe**Navigation**

█ Expert → Application → Totalizer 1 to n → Batch Recipe (3807–1 to n)

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information*Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Alarm hysteresis**Navigation**

█ Expert → Application → Totalizer 1 to n → Alarm hysteresis (3802–1 to n)

Description

Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry

Signed floating-point number

Factory setting

0 kg

Additional information*User entry*

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

Hi Hi Lim**Navigation**

█ Expert → Application → Totalizer 1 to n → Hi Hi Lim (3815–1 to n)

Description

Use this function to enter the value for the upper alarm limit of the totalizer (**HiHi alarm value** parameter (→ 170)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

 If the output value Out value (→ 118) exceeds this limit value, the **HiHi alarm state** parameter (→ 171) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

Hi Lim**Navigation**

Expert → Application → Totalizer 1 to n → Hi Lim (3816–1 to n)

Description

Use this function to enter the value for the upper warning limit of the totalizer (**Hi alarm value** parameter (→ 171)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

 If the output value Out value (→ 118) exceeds this limit value, the **Hi alarm state** parameter (→ 171) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

Lo Lim**Navigation**

Expert → Application → Totalizer 1 to n → Lo Lim (3819–1 to n)

Description

Use this function to enter the value for the lower warning limit of the totalizer (**Lo alarm value** parameter (→ 171)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

 If the output value Out value (→ 118) exceeds this limit value, the **Lo alarm state** parameter (→ 172) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

Lo Lo Lim**Navigation**

 Expert → Application → Totalizer 1 to n → Lo Lo Lim (3822–1 to n)

Description

Use this function to enter the value for the lower alarm limit of the totalizer (**LoLo alarm value** parameter (→ 172)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

 If the output value Out value (→ 118) exceeds this limit value, the **LoLo alarm state** parameter (→ 172) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 124)) and must be in the range defined in the **Out scale low** parameter (→ 123) and **Out scale up** parameter (→ 123).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 160).

HiHi alarm value**Navigation**

 Expert → Application → Totalizer 1 to n → HiHi alarm value (3814–1 to n)

Description

Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ 168)).

User interface

Signed floating-point number

HiHi alarm state

Navigation	 Expert → Application → Totalizer 1 to n → HiHi alarm state (3813-1 to n)
Description	Displays the status for the upper alarm limit value (Hi Lim parameter (→  168)).
User interface	<ul style="list-style-type: none">■ No alarm■ Alm statHiHi lim
Additional information	<i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation	 Expert → Application → Totalizer 1 to n → Hi alarm value (3812-1 to n)
Description	Displays the warning value for the upper warning limit value (Hi Lim parameter (→  169)).
User interface	Signed floating-point number

Hi alarm state

Navigation	 Expert → Application → Totalizer 1 to n → Hi alarm state (3811-1 to n)
Description	Displays the status for the upper warning limit value (Hi Lim parameter (→  169)).
User interface	<ul style="list-style-type: none">■ No warning■ Alm stat Hi lim
Additional information	<i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation	 Expert → Application → Totalizer 1 to n → Lo alarm value (3818-1 to n)
Description	Displays the warning value for the lower warning limit value (Lo Lim parameter (→  169)).
User interface	Signed floating-point number

Lo alarm state

Navigation  Expert → Application → Totalizer 1 to n → Lo alarm state (3817-1 to n)

Description Displays the status for the lower warning limit value (**Lo Lim** parameter (→  169)).

User interface

- No warning
- Alrm stat Lo lim

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

LoLo alarm value

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm value (3821-1 to n)

Description Displays the alarm value for the lower alarm limit value (**Lo Lo Lim** parameter (→  170)).

User interface Signed floating-point number

LoLo alarm state

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm state (3820-1 to n)

Description Displays the status for the lower alarm limit value (**Lo Lo Lim** parameter (→  170)).

User interface

- No alarm
- Alm statLoLo lim


Additional information *User interface*

 The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

3.10 "Diagnostics" submenu

Navigation

  Expert → Diagnostics



Prev.diagnostics (0690)	→ 174
Time fr. restart (0653)	→ 175
Operating time (0652)	→ 175
► Diagnostic list	→ 175
► Event logbook	→ 180
► Device info	→ 182
► Data logging	→ 187
► Min/max val.	→ 192
► Heartbeat	→ 201
► Simulation	→ 202

Actual diagnos.

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

- Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 175).
- Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Example

For the display format:

F271 Main electronic

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Actual diagnos.** parameter
(→  173).

Example

For the display format:
24d12h13m00s

Prev.diagnostics

Navigation

 Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite

Two diagnostic events have already occurred.

Description

Displays the diagnostic message that occurred before the current message.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:
☒F271 Main electronic

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the last diagnostic message before the current message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Prev.diagnostics** parameter
(→ [174](#)).

Example

For the display format:

24d12h13m00s

Time fr. restart

Navigation

Expert → Diagnostics → Time fr. restart (0653)

Description

Use this function to display the time the device has been in operation since the last device restart.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation

Expert → Diagnostics → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.10.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list

► Diagnostic list	
Diagnostics 1 (0692)	→ 176
Diagnostics 2 (0693)	→ 176
Diagnostics 3 (0694)	→ 177
Diagnostics 4 (0695)	→ 178
Diagnostics 5 (0696)	→ 179

Diagnostics 1

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Displays the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: <ul style="list-style-type: none">▪  S442 Freq. output▪  F276 I/O module

Timestamp

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 1 parameter (→  176).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Freq. output
- F276 I/O module

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→  176).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Freq. output
- F276 I/O module

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  177). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Examples</i> For the display format: ■ Δ S442 Freq. output ■ \otimes F276 I/O module

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 178).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Freq. output
- F276 I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ 179).

Example

For the display format:


24d12h13m00s

3.10.2 "Event logbook" submenu

Navigation



Expert → Diagnostics → Event logbook



Filter options



Navigation



Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information

Description



The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
■ F = Failure
■ C = Function Check
■ S = Out of Specification
■ M = Maintenance Required

Filter options



Navigation



Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting All

Additional information *Description*

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required


"Event list" submenu

i The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

Navigation

Expert → Diagnostics → Event logbook → Event list



Event list

Navigation Expert → Diagnostics → Event logbook → Event list

Description Displays the history of event messages of the category selected in the **Filter options** parameter (→ 180).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information *Description*

A maximum of 20 event messages are displayed in chronological order.

If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊖: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ΔS442 Freq. output
⊖ 01d04h12min30s

 Additional information, such as remedial measures, can be retrieved via the  key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **Extended HistoROM** application package, see the "Application packages" section of the "Technical Information" document

3.10.3 "Device info" submenu

Navigation

 Expert → Diagnostics → Device info

► Device info	
Device tag (0011)	→  183
Serial number (0009)	→  183
Firmware version (0010)	→  183
Device name (0013)	→  184
Order code (0008)	→  184
Ext. order cd. 1 (0023)	→  184
Ext. order cd. 2 (0021)	→  185
Ext. order cd. 3 (0022)	→  185
ENP version (0012)	→  185

Device tag

Navigation

  Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promass

Additional information

Display



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation

  Expert → Diagnostics → Device info → Serial number (0009)

Description

Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information

Description



Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation

  Expert → Diagnostics → Device info → Firmware version (0010)

Description

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name**Navigation**

Expert → Diagnostics → Device info → Device name (0013)

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Factory setting

Promass 200

Order code**Navigation**

Expert → Diagnostics → Device info → Order code (0008)

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Ext. order cd. 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Ext. order cd. 2**Navigation**

Diagram Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 184)

Ext. order cd. 3**Navigation**

Diagram Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 184)

Config. counter**Navigation**

Diagram Expert → Diagnostics → Device info → Config. counter (0233)

Description

Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface

0 to 65 535

ENP version**Navigation**

Diagram Expert → Diagnostics → Device info → ENP version (0012)

Description

Displays the version of the electronic nameplate.

User interface

Character string

Factory setting 2.02.00


Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.10.4 "I/O module" submenu

Navigation

Expert → Diagnostics → I/O module



Software rev.

Navigation

Expert → Diagnostics → I/O module → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

3.10.5 "Display module" submenu

Navigation

Expert → Diagnostics → Display module



Software rev.

Navigation

Expert → Diagnostics → Display module → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

3.10.6 "Data logging" submenu

Navigation

Expert → Diagnostics → Data logging

► Data logging	
Assign chan. 1 (0851)	→ 187
Assign chan. 2 (0852)	→ 188
Assign chan. 3 (0853)	→ 188
Assign chan. 4 (0854)	→ 189
Logging interval (0856)	→ 189
Clear logging (0855)	→ 190
► Displ.channel 1	
► Displ.channel 2	
► Displ.channel 3	
► Displ.channel 4	

Assign chan. 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

i The software options currently enabled are displayed in the **SW option overv.** parameter (→ 43).

Description

Use this function to select a process variable for the data logging channel.

Selection

- Off
- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Carr. pipe temp. *
- Electronic temp.
- Oscil. frequency

* Visibility depends on order options or device settings

- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

Factory setting Off

Additional information *Description*

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

Selection

 Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: **Assign freq.** parameter (→  89)

Assign chan. 2



Navigation	  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)
Prerequisite	The Extended HistoROM application package is available.
	 The software options currently enabled are displayed in the SW option overv. parameter (→  43).
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→  187)
Factory setting	Off

Assign chan. 3



Navigation	  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available.
	 The software options currently enabled are displayed in the SW option overv. parameter (→  43).
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→  187)

Factory setting	Off
------------------------	-----

Assign chan. 4

Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the SW option overv. parameter (→ 43).
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→ 187)
Factory setting	Off

Logging interval

Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the SW option overv. parameter (→ 43).
Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	1.0 to 3 600.0 s
Factory setting	10.0 s
Additional information	<p><i>Description</i></p> <p>This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log}:</p> <ul style="list-style-type: none"> ▪ If 1 logging channel is used: $T_{log} = 1000 \times t_{log}$ ▪ If 2 logging channels are used: $T_{log} = 500 \times t_{log}$ ▪ If 3 logging channels are used: $T_{log} = 333 \times t_{log}$ ▪ If 4 logging channels are used: $T_{log} = 250 \times t_{log}$ <p>Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{log} always remains in the memory (ring memory principle).</p> <p> The log contents are cleared if the length of the logging interval is changed.</p>

Example

If 1 logging channel is used:

- $T_{log} = 1000 \times 1 \text{ s} = 1\,000 \text{ s} \approx 15 \text{ min}$
- $T_{log} = 1000 \times 10 \text{ s} = 10\,000 \text{ s} \approx 3 \text{ h}$
- $T_{log} = 1000 \times 80 \text{ s} = 80\,000 \text{ s} \approx 1 \text{ d}$
- $T_{log} = 1000 \times 3\,600 \text{ s} = 3\,600\,000 \text{ s} \approx 41 \text{ d}$

Clear logging**Navigation**

Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **SW option overv.** parameter (→ 43).

Description

Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information*Selection*

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

"Displ.channel 1" submenu**Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

**Display channel 1****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **SW option overv.** parameter (→ 43).

One of the following options is selected in the **Assign chan. 1** parameter (→ 187):

- Mass flow
- Volume flow
- Correct.vol.flow
- Density
- Ref.density
- Temperature
- Carr. pipe temp.*

* Visibility depends on order options or device settings


- Electronic temp.
- Oscil. frequency
- Oscil. amplitude
- Oscil. damping
- Signal asymmetry

Description

Displays the measured value trend for the logging channel in the form of a chart.

Additional information*Prerequisite*

 Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: **Assign freq.** parameter (→ 89)

Description

A0016357

6 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Displ.channel 2" submenu*Navigation*

Expert → Diagnostics → Data logging → Displ.channel 2

**Display channel 2****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is defined in the **Assign chan. 2** parameter.

Description

See the **Display channel 1** parameter → 190

"Displ.channel 3" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign chan. 3** parameter.

Description

See the **Display channel 1** parameter → 190

"Displ.channel 4" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign chan. 4** parameter.

Description


See the **Display channel 1** parameter → 190

3.10.7 "Min/max val." submenu

Navigation



Expert → Diagnostics → Min/max val.



► Terminal volt.	→ 194
► Main elect.temp.	→ 195
► IO module temp.	→ 196
► Medium temp.	→ 197
► Carr. pipe temp.	→ 198
► Oscil. frequency	→ 199
► Oscil. amplitude	→ 199
► Oscil. damping	→ 200
► Signal asymmetry	→ 201

Reset min/max

Navigation

Expert → Diagnostics → Min/max val. → Reset min/max (2504)

Description

Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection

- Cancel
- Terminal volt. 1
- IO module temp.
- Oscil. amplitude
- Oscil. damping
- Oscil. frequency
- Signal asymmetry


Factory setting

Cancel

Additional information

Options

Detailed description of the options **Oscil. frequency**, **Oscil. amplitude**, **Oscil. damping** and **Signal asymmetry**: **Assign freq.** parameter (→ 89)

"Terminal volt." submenu**Navigation** Expert → Diagnostics → Min/max val. → Terminal volt.

Minimum value**Navigation** Expert → Diagnostics → Min/max val. → Terminal volt. → Minimum value (0689)**Description**

Use this function to display the smallest previously measured terminal voltage value in Volts.

User interface

0.0 to 50.0 V

Maximum value**Navigation** Expert → Diagnostics → Min/max val. → Terminal volt. → Maximum value (0663)**Description**

Use this function to view the largest previously measured terminal voltage value in Volts.

User interface


0.0 to 50.0 V

Average value**Navigation** Expert → Diagnostics → Min/max val. → Terminal volt. → Average value (0698)**Description**

Use this function to view the average of all previously measured terminal voltage values in Volts.

User interface

Signed floating-point number

"Main elect.temp." submenu**Navigation**  Expert → Diagnostics → Min/max val. → Main elect.temp.

Minimum value

Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (2457)**Description**

Displays the lowest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 56)

Maximum value

Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (2456)**Description**

Displays the highest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 56)

"IO module temperature" submenu**Navigation** Expert → Diagnostics → Min/max val. → IO module temp.

► IO module temp.	
Minimum value (0688)	→  196
Maximum value (0665)	→  196
Average value (0697)	→  196

Minimum value**Navigation** Expert → Diagnostics → Min/max val. → IO module temp. → Minimum value (0688)**Description**

Displays the lowest previously measured temperature value of the I/O electronics module.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→  56)

Maximum value**Navigation** Expert → Diagnostics → Min/max val. → IO module temp. → Maximum value (0665)**Description**

Displays the highest previously measured temperature value of the I/O electronics module.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→  56)

Average value**Navigation** Expert → Diagnostics → Min/max val. → IO module temp. → Average value (0697)**Description**

Displays the average value of all previously measured temperature values of the I/O electronics module.

User interface


-1273.15 to 726.85 °C

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ [56](#))

"Medium temp." submenu**Navigation**

Expert → Diagnostics → Min/max val. → Medium temp.



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (2502)

Description

Displays the lowest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ [56](#))

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (2501)

Description


Displays the highest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ [56](#))

"Carr. pipe temp." submenu**Navigation** Expert → Diagnostics → Min/max val. → Carr. pipe temp.

Minimum value

Navigation Expert → Diagnostics → Min/max val. → Carr. pipe temp. → Minimum value (2461)**Prerequisite**

If the carrier tube temperature is available (applies only to Promass F).

Description

Displays the lowest previously measured temperature value of the carrier pipe.

User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→  56)

Maximum value

Navigation Expert → Diagnostics → Min/max val. → Carr. pipe temp. → Maximum value (2460)**Prerequisite**

If the carrier tube temperature is available (applies only to Promass F).

Description

Displays the highest previously measured temperature value of the carrier pipe.


User interface

Signed floating-point number

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→  56)

"Oscil. frequency" submenu**Navigation**

Expert → Diagnostics → Min/max val. → Oscil. frequency



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Oscil. frequency → Minimum value (2583)

Description

Displays the lowest previously measured oscillation frequency.

User interface

Signed floating-point number

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Oscil. frequency → Maximum value (2582)

Description


Displays the highest previously measured oscillation frequency.

User interface

Signed floating-point number

"Oscil. amplitude" submenu**Navigation**

Expert → Diagnostics → Min/max val. → Oscil. amplitude



Minimum value


Navigation	  Expert → Diagnostics → Min/max val. → Oscil. amplitude → Minimum value (2472)
Description	Displays the lowest previously measured oscillation amplitude.
User interface	Signed floating-point number

Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Oscil. amplitude → Maximum value (2471)
Description	Displays the highest previously measured oscillation amplitude.
User interface	Signed floating-point number

"Oscil. damping" submenu

Navigation   Expert → Diagnostics → Min/max val. → Oscil. damping



Minimum value

Navigation	  Expert → Diagnostics → Min/max val. → Oscil. damping → Minimum value (2586)
Description	Displays the lowest previously measured oscillation damping.
User interface	Signed floating-point number


Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Oscil. damping → Maximum value (2585)
Description	Displays the highest previously measured oscillation damping.

User interface	Signed floating-point number
----------------	------------------------------

"Signal asymmetry" submenu

Navigation Expert → Diagnostics → Min/max val. → Signal asymmetry



Minimum value

Navigation Expert → Diagnostics → Min/max val. → Signal asymmetry → Minimum value (2551)

Description Displays the lowest previously measured signal asymmetry.

User interface Signed floating-point number

Maximum value

Navigation Expert → Diagnostics → Min/max val. → Signal asymmetry → Maximum value (2476)

Description Displays the highest previously measured signal asymmetry.


User interface Signed floating-point number

3.10.8 "Heartbeat" submenu

For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → [7](#)

Navigation


Expert → Diagnostics → Heartbeat



3.10.9 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation



Assign proc.var.



Navigation

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Mass flow
- Volume flow

- Correct.vol.flow
- Density
- Ref.density
- Temperature

Factory setting Off

Additional information *Description*

-  The simulation value of the process variable selected is defined in the **Value proc. var.** parameter (→ 203).

Value proc. var.



Navigation  Expert → Diagnostics → Simulation → Value proc. var. (1811)

Prerequisite A process variable is selected in the **Assign proc.var.** parameter (→ 202).

Description Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry Depends on the process variable selected

Factory setting 0

Additional information *User entry*

-  The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Frequency sim.



Navigation  Expert → Diagnostics → Simulation → Frequency sim. (0472)

Prerequisite In the **Operating mode** parameter (→ 84), the **Frequency** option is selected.

Description Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting Off

Additional information*Description*

The desired simulation value is defined in the **Freq. value** parameter (→ 204).

Selection

- Off

Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- On

Frequency simulation is active.

Freq. value**Navigation**

Expert → Diagnostics → Simulation → Freq. value (0473)

Prerequisite

In the **Frequency sim.** parameter (→ 203), the **On** option is selected.

Description

Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry

0.0 to 1250.0 Hz

Pulse sim.**Navigation**

Expert → Diagnostics → Simulation → Pulse sim. (0458)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Pulse** option is selected.

Description

Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off

- Fixed value

- Down-count. val.

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value** parameter (→ 205).

Selection

- Off

Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Fixed value

Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 86).

- Down-count. val.

The pulses specified in the **Pulse value** parameter (→ 205) are output.

Pulse value**Navigation**

Expert → Diagnostics → Simulation → Pulse value (0459)

Prerequisite

In the **Pulse sim.** parameter (→ 204), the **Down-count. val.** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch sim.**Navigation**

Expert → Diagnostics → Simulation → Switch sim. (0462)

Prerequisite

In the **Operating mode** parameter (→ 84), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information	Description
	<p> The desired simulation value is defined in the Switch status parameter (→ 206).</p>
	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ On Switch simulation is active.

Switch status

Navigation	 Expert → Diagnostics → Simulation → Switch status (0463)
Prerequisite	In the Switch sim. parameter (→ 205) Switch sim. 1 to n parameter Switch sim. 1 to n parameter, the On option is selected.
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	<ul style="list-style-type: none">▪ Open▪ Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ Closed Switch simulation is active.

Sim. alarm

Navigation	 Expert → Diagnostics → Simulation → Sim. alarm (0654)
Description	Use this function to switch the device alarm on and off.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p>The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.</p>

Event category**Navigation**

Expert → Diagnostics → Simulation → Event category (0738)

Description

Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Sim. diag. event** parameter (→ 207).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting

Process

Sim. diag. event**Navigation**

Expert → Diagnostics → Simulation → Sim. diag. event (0737)

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting

Off

Additional information*Description* For the simulation, you can choose from the diagnostic events of the category selected in the **Event category** parameter (→ 207).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	l
Volume flow	l/h
Corrected volume	Nl
Corrected volume flow	Nl/h
Density	kg/l
Reference density	kg/Nl
Temperature	°C
Length	mm
Pressure	bar a

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	[kg/h]
1	4
2	20
4	90
8	400
15	1300
25	3600
40	9000
50	14000
80	36000

4.1.3 Pulse value

Nominal diameter [mm]	(~ 2 pulses/s at 2 m/s) [kg/p]
1	0.001
2	0.01
4	0.01
8	0.1
15	0.1

Nominal diameter [mm]	(~ 2 pulses/s at 2 m/s) [kg/p]
25	1
40	1
50	10
80	10

4.1.4 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	On-value for liquid [kg/h]
1	0.08
2	0.4
4	1.8
8	8
15	26
25	72
40	180
50	300
80	720

Nominal diameter [mm]	On-value for gas [kg/h]
1	0.02
2	0.1
4	0.45
8	2
15	6.5
25	18
40	45
50	75
80	180

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	gal (us)
Volume flow	gal/min (us)

Corrected volume	Sft ³
Corrected volume flow	Sft ³ /min
Density	lb/ft ³
Reference density	lb/Sft ³
Temperature	°F
Length	in
Pressure	psi a

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	[lb/min]
1/24	0.15
1/12	0.75
1/8	3.3
3/8	15
1/2	50
1	130
1½	330
2	515
3	1320

4.2.3 Pulse value

Nominal diameter [in]	(~ 2 pulses/s at 2.0 m/s) [lb/p]
1/24	0.002
1/12	0.02
1/8	0.02
3/8	0.2
1/2	0.2
1	2
1½	2
2	20
3	20

4.2.4 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	On-value for liquid [lb/min]
1/24	0.003
1/12	0.015

Nominal diameter [in]	On-value for liquid [lb/min]
1/8	0.066
3/8	0.3
1/2	1
1	2.6
1½	6.6
2	11
3	26

Nominal diameter [in]	On-value for gas [lb/min]
1/24	0.001
1/12	0.004
1/8	0.016
3/8	0.075
1/2	0.25
1	0.65
1½	1.65
2	2.75
3	6.5

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Pressure	Pa a, kPa a, MPa a	Pascal, kilopascal, megapascal (absolute)
	bar	Bar
	Pa g, kPa g, MPa g	Pascal, kilopascal, megapascal (relative/gauge)
	bar g	Bar (relative/gauge)
Length	µm, mm, m	Micrometer, millimeter, meter
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Ref.density	kg/Nm ³ , kg/Nl, g/Scm ³ , kg/Sm ³	Kilogram, gram/standard volume unit
Corrected volume	Nl, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Correct.vol.flow	Nl/s, Nl/min, Nl/h, Nl/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Pressure	psi a	Pounds per square inch (absolute)

Process variable	Units	Explanation
	psi g	Pounds per square inch (gauge)
Length	in, ft	Inch, foot
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Ref.density	lb/Sft ³	Weight unit/standard volume unit
Corrected volume	Sft ³ , Sgal (us), Sbbl (us;liq.)	Standard cubic foot, standard gallon, standard barrel
Correct.vol.flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
	Sgal/s (us), Sgal/min (us), Sgal/h (us), Sgal/d (us)	Standard gallon/time unit
	Sbbl/s (us;liq.), Sbbl/min (us;liq.), Sbbl/h (us;liq.), Sbbl/d (us;liq.)	Barrel/time unit (normal liquids)
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Corrected volume	Sgal (imp)	Standard gallon
Correct.vol.flow	Sgal/s (imp), Sgal/min (imp), Sgal/h (imp), Sgal/d (imp)	Standard gallon/time unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0% bargraph value 1 (Parameter)	19
0% bargraph value 3 (Parameter)	22
100% bargraph value 1 (Parameter)	20
100% bargraph value 3 (Parameter)	23

A

Access status display (Parameter)	13, 28
Access status tooling (Parameter)	13
Activate sensor emergency mode (Parameter)	43
Activate SW option (Parameter)	42
Actual diagnostics (Parameter)	173
Address mode (Parameter)	104
Adjustment in progress (Parameter)	74
Administration (Submenu)	39
Alarm delay (Parameter)	32
Alarm hysteresis (Parameter)	124, 168
Alarm summary (Parameter)	110, 121, 134, 142, 154, 166
Alert key (Parameter)	109, 119, 133, 141, 153, 165
Analog input 1 to n (Submenu)	116
Analog inputs (Submenu)	116
Analog output 1 to n (Submenu)	137
Analog outputs (Submenu)	137
Application (Submenu)	159
Assign behavior of diagnostic no. 046 (Parameter)	34
Assign behavior of diagnostic no. 140 (Parameter)	34
Assign behavior of diagnostic no. 274 (Parameter)	34
Assign behavior of diagnostic no. 442 (Parameter)	35
Assign behavior of diagnostic no. 443 (Parameter)	35
Assign behavior of diagnostic no. 801 (Parameter)	35
Assign behavior of diagnostic no. 830 (Parameter)	36
Assign behavior of diagnostic no. 831 (Parameter)	36
Assign behavior of diagnostic no. 832 (Parameter)	37
Assign behavior of diagnostic no. 833 (Parameter)	37
Assign behavior of diagnostic no. 834 (Parameter)	37
Assign behavior of diagnostic no. 835 (Parameter)	38
Assign behavior of diagnostic no. 862 (Parameter)	38
Assign behavior of diagnostic no. 912 (Parameter)	38
Assign behavior of diagnostic no. 913 (Parameter)	39
Assign channel 1 (Parameter)	187
Assign channel 2 (Parameter)	188
Assign channel 3 (Parameter)	188
Assign channel 4 (Parameter)	189
Assign diagnostic behavior (Parameter)	97
Assign flow direction check (Parameter)	100
Assign frequency output (Parameter)	89
Assign limit (Parameter)	98
Assign process variable (Parameter)	61, 64, 160
Assign pulse output (Parameter)	85
Assign simulation process variable (Parameter)	202
Assign status (Parameter)	101
Average value (Parameter)	194, 196

B

Backlight (Parameter)	27
---------------------------------	----

Backup state (Parameter)	30
Base current (Parameter)	106
Batch ID (Parameter)	121, 135, 143, 155, 167
Batch operation (Parameter)	121, 135, 143, 155, 167
Batch phase (Parameter)	122, 135, 143, 155, 167
Batch Recipe Unit Procedure (Parameter)	122, 135, 143, 156, 168

C

C 0 (Parameter)	81
C 1 (Parameter)	81
C 2 (Parameter)	81
C 3 (Parameter)	81
C 4 (Parameter)	82
C 5 (Parameter)	82
Calculated values (Submenu)	70
Calibration (Submenu)	79
Calibration factor (Parameter)	80
Carrier pipe temperature (Submenu)	198
Channel (Parameter)	117, 130
Clear logging data (Parameter)	190
Communication (Submenu)	103
Comparison result (Parameter)	31
Condensed status diagnostic (Parameter)	116
Configuration backup display (Submenu)	28
Configuration counter (Parameter)	185
Configuration management (Parameter)	29
Confirm access code (Parameter)	41
Contrast display (Parameter)	27
Control Totalizer 1 to n (Parameter)	161
Corrected volume flow (Parameter)	46
Corrected volume flow calculation (Parameter)	70
Corrected volume flow calculation (Submenu)	70
Corrected volume flow factor (Parameter)	77
Corrected volume flow offset (Parameter)	77
Corrected volume flow unit (Parameter)	54
Corrected volume unit (Parameter)	55

D

Damping output (Parameter)	94
Data logging (Submenu)	187
Date/time format (Parameter)	58
Decimal places 1 (Parameter)	20
Decimal places 2 (Parameter)	21
Decimal places 3 (Parameter)	23
Decimal places 4 (Parameter)	24
Define access code (Parameter)	40, 41
Define access code (Wizard)	40
Density (Parameter)	46
Density damping (Parameter)	59
Density factor (Parameter)	78
Density offset (Parameter)	77
Density unit (Parameter)	55
Descriptor (Parameter)	114
Device address (Parameter)	104
Device certification (Parameter)	113

Device ID (Parameter)	111	Assign behavior of diagnostic no. 834 (0677)	37
Device information (Submenu)	182	Assign behavior of diagnostic no. 835 (0678)	38
Device install date (Parameter)	114	Assign behavior of diagnostic no. 862 (0679)	38
Device message (Parameter)	114	Assign behavior of diagnostic no. 912 (0720)	38
Device name (Parameter)	184	Assign behavior of diagnostic no. 913 (0717)	39
Device reset (Parameter)	42	Assign channel 1 (0851)	187
Device tag (Parameter)	108, 183	Assign channel 2 (0852)	188
Diagnostic behavior (Submenu)	32	Assign channel 3 (0853)	188
Diagnostic event category (Parameter)	207	Assign channel 4 (0854)	189
Diagnostic handling (Submenu)	32	Assign diagnostic behavior (0482)	97
Diagnostic list (Submenu)	175	Assign flow direction check (0484)	100
Diagnostics (Parameter)	112	Assign frequency output (0478)	89
Diagnostics (Submenu)	172	Assign limit (0483)	98
Diagnostics 1 (Parameter)	176	Assign process variable Totalizer 1 to n (3808-1 to n)	160
Diagnostics 2 (Parameter)	176	Assign process variable (1833)	64
Diagnostics 3 (Parameter)	177	Assign process variable (1837)	61
Diagnostics 4 (Parameter)	178	Assign pulse output (0460)	85
Diagnostics 5 (Parameter)	179	Assign simulation process variable (1810)	202
Diagnostics mask (Parameter)	112	Assign status (0485)	101
Direct access		Average value (0697)	196
0% bargraph value 1 (0123)	19	Average value (0698)	194
0% bargraph value 3 (0124)	22	Backlight (0111)	27
100% bargraph value 1 (0125)	20	Backup state (0121)	30
100% bargraph value 3 (0126)	23	Base current (1466)	106
Access status display (0091)	13, 28	Batch ID Analog input 1 to n (1533-1 to n)	121
Access status tooling (0005)	13	Analog output 1 (1633-1)	143
Activate sensor emergency mode (2566)	43	Discrete input 1 to n (2183-1 to n)	135
Activate SW option (0029)	42	Discrete output 1 to n (1695-1 to n)	155
Actual diagnostics (0691)	173	Totalizer 1 to n (3804-1 to n)	167
Address mode (1468)	104	Batch operation Analog input 1 to n (1534-1 to n)	121
Adjustment in progress (2588)	74	Analog output 1 (1639-1)	143
Alarm delay (0651)	32	Discrete input 1 to n (2184-1 to n)	135
Alarm hysteresis Analog input 1 to n (1527-1 to n)	124	Discrete output 1 to n (1698-1 to n)	155
Totalizer 1 to n (3802-1 to n)	168	Totalizer 1 to n (3805-1 to n)	167
Alarm summary Analog input 1 to n (1537-1 to n)	121	Batch phase Analog input 1 to n (1535-1 to n)	122
Analog output 1 (1642-1)	142	Analog output 1 (1640-1)	143
Discrete input 1 to n (2191-1 to n)	134	Discrete input 1 to n (2185-1 to n)	135
Discrete output 1 to n (1701-1 to n)	154	Discrete output 1 to n (1699-1 to n)	155
Totalizer 1 to n (3809-1 to n)	166	Totalizer 1 to n (3806-1 to n)	167
Alarm summary (1474)	110	Batch Recipe Unit Procedure Analog input 1 to n (1536-1 to n)	122
Alert key Analog input 1 to n (1522-1 to n)	119	Analog output 1 (1641-1)	143
Analog output 1 (1632-1)	141	Discrete input 1 to n (2186-1 to n)	135
Discrete input 1 to n (2182-1 to n)	133	Discrete output 1 to n (1700-1 to n)	156
Discrete output 1 to n (1694-1 to n)	153	Totalizer 1 to n (3807-1 to n)	168
Totalizer 1 to n (3803-1 to n)	165	C 0 (2469)	81
Alert key (1473)	109	C 1 (2574)	81
Assign behavior of diagnostic no. 046 (0655)	34	C 2 (2575)	81
Assign behavior of diagnostic no. 140 (0723)	34	C 3 (2576)	81
Assign behavior of diagnostic no. 274 (0725)	34	C 4 (2577)	82
Assign behavior of diagnostic no. 442 (0658)	35	C 5 (2578)	82
Assign behavior of diagnostic no. 443 (0659)	35	Calibration factor (2431)	80
Assign behavior of diagnostic no. 801 (0660)	35	Channel Analog input 1 to n (1561-1 to n)	117
Assign behavior of diagnostic no. 830 (0715)	36	Discrete input 1 to n (2187-1 to n)	130
Assign behavior of diagnostic no. 831 (0716)	36		
Assign behavior of diagnostic no. 832 (0675)	37		
Assign behavior of diagnostic no. 833 (0676)	37		

Clear logging data (0855)	190
Comparison result (0103)	31
Condensed status diagnostic (1500)	116
Configuration counter (0233)	185
Configuration management (0100)	29
Contrast display (0105)	27
Control Totalizer 1 to n (3830-1 to n)	161
Corrected volume flow (1842)	46
Corrected volume flow calculation (1812)	70
Corrected volume flow factor (1823)	77
Corrected volume flow offset (1824)	77
Corrected volume flow unit (0558)	54
Corrected volume unit (0575)	55
Damping output (0477)	94
Date/time format (2812)	58
Decimal places 1 (0095)	20
Decimal places 2 (0117)	21
Decimal places 3 (0118)	23
Decimal places 4 (0119)	24
Define access code	41
Density (1843)	46
Density damping (1808)	59
Density factor (1825)	78
Density offset (1826)	77
Density unit (0555)	55
Descriptor (1489)	114
Device address (1462)	104
Device certification (1486)	113
Device ID (1480)	111
Device install date (1491)	114
Device message (1490)	114
Device name (0013)	184
Device reset (0000)	42
Device tag (0011)	183
Device tag (1496)	108
Diagnostic event category (0738)	207
Diagnostics (1482)	112
Diagnostics 1 (0692)	176
Diagnostics 2 (0693)	176
Diagnostics 3 (0694)	177
Diagnostics 4 (0695)	178
Diagnostics 5 (0696)	179
Diagnostics mask (1484)	112
Direct access (0106)	11
Display damping (0094)	25
Display interval (0096)	24
ENP version (0012)	185
Enter access code (0003)	14
Enter access code (0092)	14
Extended order code 1 (0023)	184
Extended order code 2 (0021)	185
Extended order code 3 (0022)	185
External pressure (2592)	69
Factory reset (1488)	113
Fail safe time	
Analog output 1 (1635-1)	138
Discrete output 1 to n (1697-1 to n)	150
Fail safe type	
Analog input 1 to n (1525-1 to n)	117
Analog output 1 (1636-1)	138
Discrete input 1 to n (2189-1 to n)	131
Discrete output 1 to n (1696-1 to n)	151
Fail safe value	
Analog input 1 to n (1526-1 to n)	118
Analog output 1 (1637-1)	139
Discrete input 1 to n (2190-1 to n)	131
Discrete output 1 to n (1693-1 to n)	151
Failure frequency (0474)	96
Failure mode	
Totalizer 1 to n (3810-1 to n)	163
Failure mode (0451)	95
Failure mode (0480)	88
Failure mode (0486)	102
Feature enabled (1476)	115
Feature supported (1477)	115
Filter options	180
Filter options (0705)	180
Firmware version (0010)	183
Fixed reference density (1814)	71
Flow damping (1801)	59
Flow override (1839)	60
Format display (0098)	16
Frequency simulation (0472)	203
Frequency value (0473)	204
Hardware lock (1499)	115
Hardware revision (1479)	111
Header (0097)	25
Header text (0112)	26
Hi alarm state	
Analog input 1 to n (1538-1 to n)	127
Totalizer 1 to n (3811-1 to n)	171
Hi alarm value	
Analog input 1 to n (1539-1 to n)	127
Totalizer 1 to n (3812-1 to n)	171
Hi Hi alarm state	
Analog input 1 to n (1540-1 to n)	126
Totalizer 1 to n (3813-1 to n)	171
Hi Hi alarm value	
Analog input 1 to n (1541-1 to n)	126
Totalizer 1 to n (3814-1 to n)	170
Hi Hi Lim	
Analog input 1 to n (1528-1 to n)	124
Totalizer 1 to n (3815-1 to n)	168
Hi Lim	
Analog input 1 to n (1529-1 to n)	125
Totalizer 1 to n (3816-1 to n)	169
High value partial filled pipe detection (1835)	65
Ident number selector (1461)	105, 114
Increase close	
Analog output 1 (1638-1)	148
Input channel	
Analog output 1 (1670-1)	145
Discrete output 1 to n (1724-1 to n)	157
Installation direction (1809)	73
Invert	
Discrete input 1 to n (2188-1 to n)	130
Discrete output 1 to n (1692-1 to n)	150
Invert output signal (0470)	103

Language (0104)	16
Last backup (0102)	29
Length unit (0551)	57
Lin type	
Analog input 1 to n (1523-1 to n)	123
Linear expansion coefficient (1817)	72
Lo alarm state	
Analog input 1 to n (1542-1 to n)	127
Totalizer 1 to n (3817-1 to n)	172
Lo alarm value	
Analog input 1 to n (1543-1 to n)	127
Totalizer 1 to n (3818-1 to n)	171
Lo Lim	
Analog input 1 to n (1530-1 to n)	125
Totalizer 1 to n (3819-1 to n)	169
Lo Lo alarm state	
Analog input 1 to n (1544-1 to n)	128
Totalizer 1 to n (3820-1 to n)	172
Lo Lo alarm value	
Analog input 1 to n (1545-1 to n)	128
Totalizer 1 to n (3821-1 to n)	172
Lo Lo Lim	
Analog input 1 to n (1531-1 to n)	126
Totalizer 1 to n (3822-1 to n)	170
Locking status (0004)	12
Logging interval (0856)	189
Low value partial filled pipe detection (1834)	64
Manufacturer ID (1502)	111
Mass flow (1840)	45
Mass flow factor (1819)	76
Mass flow offset (1820)	75
Mass flow unit (0554)	51
Mass unit (0574)	52
Maximum damping partial filled pipe det. (2492)	66
Maximum frequency value (0454)	90
Maximum value (0663)	194
Maximum value (0665)	196
Maximum value (2456)	195
Maximum value (2460)	198
Maximum value (2471)	200
Maximum value (2476)	201
Maximum value (2501)	197
Maximum value (2582)	199
Maximum value (2585)	200
Measuring mode (0457)	87
Measuring mode (0479)	91
Measuring value at maximum frequency (0475)	91
Measuring value at minimum frequency (0476)	91
Minimum frequency value (0453)	90
Minimum value (0688)	196
Minimum value (0689)	194
Minimum value (2457)	195
Minimum value (2461)	198
Minimum value (2472)	200
Minimum value (2502)	197
Minimum value (2551)	201
Minimum value (2583)	199
Minimum value (2586)	200
Mode block actual	
Analog input 1 to n (1521-1 to n)	120
Analog output 1 (1631-1)	141
Discrete input 1 to n (2181-1 to n)	133
Discrete output 1 to n (1691-1 to n)	153
Totalizer 1 to n (3801-1 to n)	166
Mode block actual (1472)	109
Mode block normal	
Analog input 1 to n (1546-1 to n)	120
Analog output 1 (1643-1)	142
Discrete input 1 to n (2192-1 to n)	134
Discrete output 1 to n (1702-1 to n)	154
Totalizer 1 to n (3824-1 to n)	166
Mode block normal (1492)	110
Mode block permitted	
Analog input 1 to n (1553-1 to n)	120
Analog output 1 (1648-1)	142
Discrete input 1 to n (2195-1 to n)	134
Discrete output 1 to n (1705-1 to n)	154
Totalizer 1 to n (3828-1 to n)	166
Mode block permitted (1493)	109
Nominal diameter (2807)	80
Off value low flow cutoff (1804)	62
On value low flow cutoff (1805)	61
Operating mode (0469)	84
Operating time (0652)	29, 175
Operating time from restart (0653)	175
Order code (0008)	184
Out decimal point	
Analog input 1 to n (1547-1 to n)	124
Out scale lower range	
Analog input 1 to n (1548-1 to n)	123
Analog output 1 (1644-1)	148
Out scale upper range	
Analog input 1 to n (1551-1 to n)	123
Analog output 1 (1646-1)	148
Out status	
Analog input 1 to n (1549-1 to n)	118
Analog input 1 to n (1564-1 to n)	118
Analog output 1 (1645-1)	140
Analog output 1 (1669-1)	139
Discrete input 1 to n (2193-1 to n)	132
Discrete input 1 to n (2203-1 to n)	132
Discrete output 1 to n (1703-1 to n)	152
Discrete output 1 to n (1723-1 to n)	152
Out unit	
Analog input 1 to n (1550-1 to n)	124
Out unit text	
Analog input 1 to n (1532-1 to n)	129
Out value	
Analog input 1 to n (1552-1 to n)	118
Analog output 1 (1647-1)	139
Discrete input 1 to n (2194-1 to n)	131
Discrete output 1 to n (1704-1 to n)	151
Output channel	
Analog output 1 (1671-1)	146
Discrete output 1 to n (1725-1 to n)	157
Output frequency (0471)	50, 96

Position status	
Analog output 1 (1649-1)	146
Position value	
Analog output 1 (1650-1)	146
Preset value 1 to n (3829-1 to n)	162
Pressure compensation (2579)	68
Pressure shock suppression (1806)	62
Pressure unit (0564)	57
Pressure value (2580)	69
Previous diagnostics (0690)	174
PROFIBUS ident number (1464)	106
Profile version (1463)	106
Pulse output (0456)	49, 88
Pulse simulation (0458)	204
Pulse value (0459)	205
Pulse width (0452)	86
PV filter time	
Analog input 1 to n (1524-1 to n)	117
PV scale lower range	
Analog input 1 to n (1554-1 to n)	122
Analog output 1 (1651-1)	144
PV scale upper range	
Analog input 1 to n (1555-1 to n)	123
Analog output 1 (1652-1)	144
RCAS in status	
Analog output 1 (1654-1)	145
Discrete output 1 to n (1706-1 to n)	157
RCAS in value	
Analog output 1 (1655-1)	145
Discrete output 1 to n (1707-1 to n)	156
RCAS out status	
Analog output 1 (1656-1)	146
Discrete output 1 to n (1708-1 to n)	158
RCAS out value	
Analog output 1 (1657-1)	146
Discrete output 1 to n (1711-1 to n)	157
Readback status	
Analog output 1 (1658-1)	145
Discrete output 1 to n (1712-1 to n)	156
Readback value	
Analog output 1 (1659-1)	144
Discrete output 1 to n (1713-1 to n)	156
Reference density (1844)	47
Reference density factor (1827)	78
Reference density offset (1828)	78
Reference density unit (0556)	56
Reference sound velocity (2489)	67
Reference temperature (1816)	71
Reset min/max values (2504)	193
Response time (0491)	94
Response time part. filled pipe detect. (1836)	65
Select gas type (2488)	67
Select medium (2513)	66
Separator (0101)	27
Serial number (0009)	183
Serial number (1481)	112
Set point status	
Analog output 1 (1660-1)	138
Discrete output 1 to n (1714-1 to n)	150
Set point value	
Analog output 1 (1661-1)	137
Discrete output 1 to n (1715-1 to n)	149
Setpoint deviation	
Analog output 1 (1653-1)	147
Simulate enabled	
Analog input 1 to n (1556-1 to n)	128
Analog output 1 (1662-1)	147
Discrete input 1 to n (2196-1 to n)	136
Discrete output 1 to n (1716-1 to n)	158
Simulate status	
Analog input 1 to n (1557-1 to n)	129
Analog output 1 (1663-1)	148
Discrete input 1 to n (2197-1 to n)	136
Discrete output 1 to n (1717-1 to n)	159
Simulate value	
Analog input 1 to n (1558-1 to n)	128
Analog output 1 (1664-1)	147
Discrete input 1 to n (2198-1 to n)	136
Discrete output 1 to n (1718-1 to n)	158
Simulation device alarm (0654)	206
Simulation diagnostic event (0737)	207
Software option overview (0015)	43
Software revision (0072)	186
Software revision (1478)	111
Square expansion coefficient (1818)	72
Static revision	
Analog input 1 to n (1560-1 to n)	119
Analog output 1 (1666-1)	140
Discrete input 1 to n (2200-1 to n)	132
Discrete output 1 to n (1720-1 to n)	152
Totalizer 1 to n (3832-1 to n)	165
Static revision (1495)	108
Status PROFIBUS Master Config (1465)	105
Strategy	
Analog input 1 to n (1559-1 to n)	119
Analog output 1 (1665-1)	140
Discrete input 1 to n (2199-1 to n)	133
Discrete output 1 to n (1719-1 to n)	153
Totalizer 1 to n (3831-1 to n)	165
Strategy (1494)	108
Switch output function (0481)	96
Switch output simulation (0462)	205
Switch status (0461)	50, 102
Switch status (0463)	206
Switch-off delay (0465)	101
Switch-off value (0464)	100
Switch-on delay (0467)	101
Switch-on value (0466)	99
Tag description	
Analog input 1 to n (1562-1 to n)	119
Analog output 1 (1667-1)	140
Discrete input 1 to n (2201-1 to n)	132
Discrete output 1 to n (1721-1 to n)	152
Totalizer 1 to n (3833-1 to n)	164
Target mode	
Analog input 1 to n (1563-1 to n)	120
Analog output 1 (1668-1)	141
Discrete input 1 to n (2202-1 to n)	133

Discrete output 1 to n (1722-1 to n)	153
Totalizer 1 to n (3834-1 to n)	165
Target mode (1497)	109
Temperature (1845)	47
Temperature coefficient sound velocity (2490)	68
Temperature damping (1807)	60
Temperature factor (1829)	79
Temperature offset (1830)	78
Temperature unit (0557)	56
Terminal voltage 1 (0662)	49, 106
Timestamp	174, 176, 177, 178, 179
Totalizer operation mode	
Totalizer 1 to n (3823-1 to n)	162
Totalizer status (Hex) 1 to n (3825-1 to n)	48, 164
Totalizer status 1 to n (3826-1 to n)	48, 164
Totalizer value 1 to n (3827-1 to n)	48, 163
Unit totalizer	
Totalizer 1 to n (3835-1 to n)	160
Value 1 display (0107)	19
Value 2 display (0108)	21
Value 3 display (0110)	22
Value 4 display (0109)	23
Value per pulse (0455)	86
Value process variable (1811)	203
Volume flow (1813)	46
Volume flow factor (1821)	76
Volume flow offset (1815)	76
Volume flow unit (0553)	52
Volume unit (0563)	54
Zero point (2437)	80
Zero point adjustment control (2587)	74
Direct access (Parameter)	11
Discrete input 1 to n (Submenu)	130
Discrete inputs (Submenu)	129
Discrete output 1 to n (Submenu)	149
Discrete outputs (Submenu)	149
Display (Submenu)	15
Display channel 1 (Submenu)	190
Display channel 2 (Submenu)	191
Display channel 3 (Submenu)	192
Display channel 4 (Submenu)	192
Display damping (Parameter)	25
Display interval (Parameter)	24
Display module (Submenu)	186
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4
Document function	4
E	
ENP version (Parameter)	185
Enter access code (Parameter)	14
Event list (Submenu)	181
Event logbook (Submenu)	180
Extended order code 1 (Parameter)	184
Extended order code 2 (Parameter)	185
Extended order code 3 (Parameter)	185
External compensation (Submenu)	68
External pressure (Parameter)	69
F	
Factory reset (Parameter)	113
Factory settings	
SI units	208
US units	209
Fail safe time (Parameter)	138, 150
Fail safe type (Parameter)	117, 131, 138, 151
Fail safe value (Parameter)	118, 131, 139, 151
Failure frequency (Parameter)	96
Failure mode (Parameter)	88, 95, 102, 163
Feature enabled (Parameter)	115
Feature supported (Parameter)	115
Filter options (Parameter)	180
Firmware version (Parameter)	183
Fixed reference density (Parameter)	71
Flow damping (Parameter)	59
Flow override (Parameter)	60
Format display (Parameter)	16
Frequency simulation (Parameter)	203
Frequency value (Parameter)	204
Function	
see Parameter	
H	
Hardware lock (Parameter)	115
Hardware revision (Parameter)	111
Header (Parameter)	25
Header text (Parameter)	26
Heartbeat (Submenu)	201
Hi alarm state (Parameter)	127, 171
Hi alarm value (Parameter)	127, 171
Hi Hi alarm state (Parameter)	126, 171
Hi Hi alarm value (Parameter)	126, 170
Hi Hi Lim (Parameter)	124, 168
Hi Lim (Parameter)	125, 169
High value partial filled pipe detection (Parameter)	65
I	
I/O module (Submenu)	186
Ident number selector (Parameter)	105, 114
Increase close (Parameter)	148
Input channel (Parameter)	145, 157
Installation direction (Parameter)	73
Invert (Parameter)	130, 150
Invert output signal (Parameter)	103
IO module temperature (Submenu)	196
L	
Language (Parameter)	16
Last backup (Parameter)	29
Length unit (Parameter)	57
Lin type (Parameter)	123
Linear expansion coefficient (Parameter)	72
Lo alarm state (Parameter)	127, 172

Lo alarm value (Parameter)	127, 171	Out value (Parameter)	118, 131, 139, 151	
Lo Lim (Parameter)	125, 169	Output (Submenu)	82	
Lo Lo alarm state (Parameter)	128, 172	Output channel (Parameter)	146, 157	
Lo Lo alarm value (Parameter)	128, 172	Output frequency (Parameter)	50, 96	
Lo Lo Lim (Parameter)	126, 170	Output values (Submenu)	49	
Locking status (Parameter)	12			
Logging interval (Parameter)	189			
Low flow cut off (Submenu)	61			
Low value partial filled pipe detection (Parameter)	64			
M				
Main electronic temperature (Submenu)	195	Structure of a parameter description	6	
Manufacturer ID (Parameter)	111	Partially filled pipe detection (Submenu)	64	
Mass flow (Parameter)	45	Physical block (Submenu)	107	
Mass flow factor (Parameter)	76	Position status (Parameter)	146	
Mass flow offset (Parameter)	75	Position value (Parameter)	146	
Mass flow unit (Parameter)	51	Preset value 1 to n (Parameter)	162	
Mass unit (Parameter)	52	Pressure compensation (Parameter)	68	
Maximum damping partial filled pipe det. (Parameter)	66	Pressure shock suppression (Parameter)	62	
Maximum frequency value (Parameter)	90	Pressure unit (Parameter)	57	
Maximum value (Parameter)	194, 195, 196, 197, 198, 199, 200, 201	Pressure value (Parameter)	69	
Measured values (Submenu)	45	Previous diagnostics (Parameter)	174	
Measurement mode (Submenu)	66	Process parameters (Submenu)	58	
Measuring mode (Parameter)	87, 91	Process variable adjustment (Submenu)	75	
Measuring value at maximum frequency (Parameter)	91	Process variables (Submenu)	45	
Measuring value at minimum frequency (Parameter)	91	PROFIBUS ident number (Parameter)	106	
Medium temperature (Submenu)	197	PROFIBUS PA configuration (Submenu)	104	
Min/max values (Submenu)	192	PROFIBUS PA info (Submenu)	105	
Minimum frequency value (Parameter)	90	Profile version (Parameter)	106	
Minimum value (Parameter)	194, 195, 196, 197, 198, 199, 200, 201	Pulse output (Parameter)	49, 88	
Mode block actual (Parameter)	109, 120, 133, 141, 153, 166	Pulse simulation (Parameter)	204	
Mode block normal (Parameter)	110, 120, 134, 142, 154, 166	Pulse value (Parameter)	205	
Mode block permitted (Parameter)	109, 120, 134, 142, 154, 166	Pulse width (Parameter)	86	
N				
Nominal diameter (Parameter)	80	Pulse/frequency/switch output (Submenu)	82	
O				
Off value low flow cutoff (Parameter)	62	PV filter time (Parameter)	117	
On value low flow cutoff (Parameter)	61	PV scale lower range (Parameter)	122, 144	
Operating mode (Parameter)	84	PV scale upper range (Parameter)	123, 144	
Operating time (Parameter)	29, 175			
Operating time from restart (Parameter)	175			
Order code (Parameter)	184			
Oscillation amplitude (Submenu)	199			
Oscillation damping (Submenu)	200			
Oscillation frequency (Submenu)	199			
Out decimal point (Parameter)	124			
Out scale lower range (Parameter)	123, 148			
Out scale upper range (Parameter)	123, 148			
Out status (Parameter)	118, 132, 139, 140, 152			
Out unit (Parameter)	124			
Out unit text (Parameter)	129			
S				
Select gas type (Parameter)	67			
Select medium (Parameter)	66			
Sensor (Submenu)	44			
Sensor adjustment (Submenu)	73			
Separator (Parameter)	27			

Serial number (Parameter)	112, 183
Set point status (Parameter)	138, 150
Set point value (Parameter)	137, 149
Setpoint deviation (Parameter)	147
Signal asymmetry (Submenu)	201
Simulate enabled (Parameter)	128, 136, 147, 158
Simulate status (Parameter)	129, 136, 148, 159
Simulate value (Parameter)	128, 136, 147, 158
Simulation (Submenu)	202
Simulation device alarm (Parameter)	206
Simulation diagnostic event (Parameter)	207
Software option overview (Parameter)	43
Software revision (Parameter)	111, 186
Square expansion coefficient (Parameter)	72
Static revision (Parameter)	108, 119, 132, 140, 152, 165
Status PROFIBUS Master Config (Parameter)	105
Strategy (Parameter)	108, 119, 133, 140, 153, 165
Submenu	
Administration	39
Analog input 1 to n	116
Analog inputs	116
Analog output 1 to n	137
Analog outputs	137
Application	159
Calculated values	70
Calibration	79
Carrier pipe temperature	198
Communication	103
Configuration backup display	28
Corrected volume flow calculation	70
Data logging	187
Device information	182
Diagnostic behavior	32
Diagnostic handling	32
Diagnostic list	175
Diagnostics	172
Discrete input 1 to n	130
Discrete inputs	129
Discrete output 1 to n	149
Discrete outputs	149
Display	15
Display channel 1	190
Display channel 2	191
Display channel 3	192
Display channel 4	192
Display module	186
Event list	181
Event logbook	180
External compensation	68
Heartbeat	201
I/O module	186
IO module temperature	196
Low flow cut off	61
Main electronic temperature	195
Measured values	45
Measurement mode	66
Medium temperature	197
Min/max values	192

Oscillation amplitude	199
Oscillation damping	200
Oscillation frequency	199
Output	82
Output values	49
Partially filled pipe detection	64
Physical block	107
Process parameters	58
Process variable adjustment	75
Process variables	45
PROFIBUS PA configuration	104
PROFIBUS PA info	105
Pulse/frequency/switch output	82
Reference values	71
Sensor	44
Sensor adjustment	73
Signal asymmetry	201
Simulation	202
System	14
System units	51
Terminal voltage	194
Totalizer	47
Totalizer 1 to n	159
Zero point adjustment	73
Switch output function (Parameter)	96
Switch output simulation (Parameter)	205
Switch status (Parameter)	50, 102, 206
Switch-off delay (Parameter)	101
Switch-off value (Parameter)	100
Switch-on delay (Parameter)	101
Switch-on value (Parameter)	99
System (Submenu)	14
System units (Submenu)	51

T

Tag description (Parameter)	119, 132, 140, 152, 164
Target group	4
Target mode (Parameter)	109, 120, 133, 141, 153, 165
Temperature (Parameter)	47
Temperature coefficient sound velocity (Parameter)	68
Temperature damping (Parameter)	60
Temperature factor (Parameter)	79
Temperature offset (Parameter)	78
Temperature unit (Parameter)	56
Terminal voltage (Submenu)	194
Terminal voltage 1 (Parameter)	49, 106
Timestamp (Parameter)	174, 176, 177, 178, 179
Totalizer (Submenu)	47
Totalizer 1 to n (Submenu)	159
Totalizer operation mode (Parameter)	162
Totalizer status (Hex) 1 to n (Parameter)	48, 164
Totalizer status 1 to n (Parameter)	48, 164
Totalizer value 1 to n (Parameter)	48, 163

U

Unit totalizer (Parameter)	160
--------------------------------------	-----

V

Value 1 display (Parameter)	19
---------------------------------------	----

Value 2 display (Parameter)	21
Value 3 display (Parameter)	22
Value 4 display (Parameter)	23
Value per pulse (Parameter)	86
Value process variable (Parameter)	203
Volume flow (Parameter)	46
Volume flow factor (Parameter)	76
Volume flow offset (Parameter)	76
Volume flow unit (Parameter)	52
Volume unit (Parameter)	54

W

Wizard

Define access code	40
------------------------------	----

Z

Zero point (Parameter)	80
Zero point adjustment (Submenu)	73
Zero point adjustment control (Parameter)	74

www.addresses.endress.com
