


Operating Instructions

Dosimass

Modbus RS485

Coriolis flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document	5	7	Electrical connection	24
1.1	Document function	5	7.1	Connection conditions	24
1.2	Symbols used	5	7.1.1	Connecting cable requirements	24
1.2.1	Safety symbols	5	7.1.2	Terminal assignment	24
1.2.2	Electrical symbols	5	7.1.3	Pin assignment, device plug	25
1.2.3	Symbols for certain types of information	5	7.1.4	Requirements for the supply unit	27
1.2.4	Symbols in graphics	6	7.2	Connecting the measuring device	27
1.3	Documentation	6	7.2.1	Connecting the transmitter	27
1.3.1	Standard documentation	7	7.3	Ensuring the degree of protection	28
1.3.2	Supplementary device-dependent documentation	7	7.4	Post-connection check	28
1.4	Registered trademarks	7	8	Operation options	29
2	Basic safety instructions	8	8.1	Overview of operation options	29
2.1	Requirements for the personnel	8	8.2	Access to the operating menu via the operating tool	29
2.2	Designated use	8	8.2.1	Connecting the operating tool	29
2.3	Workplace safety	9	8.2.2	FieldCare	30
2.4	Operational safety	9	8.2.3	DeviceCare	31
2.5	Product safety	9	9	System integration	32
2.6	IT security	10	9.1	Overview of device description files	32
3	Product description	11	9.1.1	Current version data for the device	32
3.1	Product design	11	9.1.2	Operating tools	32
4	Incoming acceptance and product identification	12	9.2	Modbus RS485 information	32
4.1	Incoming acceptance	12	9.2.1	Function codes	32
4.2	Product identification	12	9.2.2	Register information	33
4.2.1	Sensor nameplate	13	9.2.3	Response time	33
4.2.2	Symbols on measuring device	14	9.2.4	Data types	33
5	Storage and transport	15	9.2.5	Byte transmission sequence	34
5.1	Storage conditions	15	9.2.6	Modbus data map	35
5.2	Transporting the product	15	10	Commissioning	37
5.3	Packaging disposal	15	10.1	Function check	37
6	Mounting	16	10.2	Switching on the measuring device	37
6.1	Installation conditions	16	10.3	Connecting via FieldCare	37
6.1.1	Mounting position	16	10.4	Configuring the measuring device	37
6.1.2	Environment and process requirements	19	10.4.1	Defining the tag name	38
6.1.3	Special mounting instructions	20	10.4.2	Setting the system units	38
6.2	Mounting the measuring device	22	10.4.3	Configuring the status input	39
6.2.1	Required tools	22	10.4.4	Configuring the switch output (batch)	40
6.2.2	Preparing the measuring device	22	10.4.5	Configuring the communication interface	41
6.2.3	Mounting the measuring device	23	10.4.6	Low flow cut off	42
6.3	Post-installation check	23	10.4.7	Detection of partially filled pipes	43
			10.5	Advanced settings	44
			10.5.1	Sensor adjustment	44
			10.5.2	Configuring the totalizer	45
			10.6	Simulation	46
			11	Operation	48
			11.1	Reading device locking status	48

11.2	Reading access authorization status on operating software	48	15.2	Service-specific accessories	67
11.3	Reading measured values	48	16	Technical data	69
11.3.1	Process variables	48	16.1	Application	69
11.3.2	"Totalizer" submenu	49	16.2	Function and system design	69
11.3.3	Input values	50	16.3	Input	69
11.4	Performing a totalizer reset	50	16.4	Output	70
11.4.1	Function scope of the "Control Totalizer" parameter	51	16.5	Power supply	72
11.4.2	Function scope of the "Reset all totalizers" parameter	51	16.6	Performance characteristics	73
11.5	Batching control	51	16.7	Installation	74
12	Diagnostics and troubleshooting ...	54	16.8	Environment	75
12.1	General troubleshooting	54	16.9	Process	76
12.2	Diagnostic information in FieldCare or DeviceCare	54	16.10	Mechanical construction	78
12.2.1	Diagnostic options	54	16.11	Operability	79
12.2.2	Calling up remedy information	56	16.12	Certificates and approvals	80
12.3	Diagnostic information via communication interface	56	16.13	Accessories	81
12.3.1	Reading out diagnostic information ..	56	16.14	Supplementary documentation	81
12.3.2	Configuring error response mode	56	Index	82	
12.4	Adapting the diagnostic information	57			
12.4.1	Adapting the diagnostic behavior	57			
12.5	Overview of diagnostic information	57			
12.6	Pending diagnostic events	59			
12.7	Diagnostic list	60			
12.8	Event logbook	60			
12.8.1	Event history	60			
12.8.2	Filtering the event logbook	60			
12.8.3	Overview of information events	61			
12.9	Resetting the measuring device	61			
12.9.1	Function scope of the "Device reset" parameter	61			
12.10	Device information	61			
12.11	Firmware history	63			
13	Maintenance	64			
13.1	Maintenance tasks	64			
13.1.1	Exterior cleaning	64			
13.1.2	Interior cleaning	64			
13.2	Measuring and test equipment	64			
13.3	Endress+Hauser services	64			
14	Repair	65			
14.1	General notes	65			
14.2	Spare parts	65			
14.3	Endress+Hauser services	65			
14.4	Return	65			
14.5	Disposal	65			
14.5.1	Removing the measuring device	65			
14.5.2	Disposing of the measuring device ...	66			
15	Accessories	67			
15.1	Communication-specific accessories	67			





1 About this document

1.1 Document function






These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used



1.2.1 Safety symbols











Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols








Symbol	Meaning
	Direct current
	Alternating current
	Direct current and alternating current
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections. The ground terminals are situated inside and outside the device: <ul style="list-style-type: none"> ▪ Inner ground terminal: Connects the protective earth to the mains supply. ▪ Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Symbols for certain types of information


Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.

Symbol	Meaning
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation.
	Reference to page.
	Reference to graphic.
	Notice or individual step to be observed.
	Series of steps.
	Result of a step.
	Help in the event of a problem.
	Visual inspection.

1.2.4 Symbols in graphics

Symbol	Meaning
	Item numbers
	Series of steps
	Views
	Sections
	Hazardous area
	Safe area (non-hazardous area)
	Flow direction

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

 Detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device. <ul style="list-style-type: none"> ■ Incoming acceptance and product identification ■ Storage and transport ■ Installation
Transmitter Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value). <ul style="list-style-type: none"> ■ Product description ■ Installation ■ Electrical connection ■ Operation options ■ System integration ■ Commissioning ■ Diagnostic information
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations. The document provides Modbus-specific information for each individual parameter in the Expert operating menu.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use


Application and media

The measuring device described in these Brief Operating Instructions is intended only for flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Keep within the specified pressure and temperature range.
- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation. →  6
- ▶ Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

NOTICE**Verification for borderline cases:**

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks**⚠ WARNING**

The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

- ▶ For elevated fluid temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ Due to the increased risk of electric shock, gloves must be worn.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.


3 Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design



A0026625

 1 Important components of the measuring device


1 Transmitter

2 Sensor


4 Incoming acceptance and product identification

4.1 Incoming acceptance


Are the order codes on the delivery note (1) and the product sticker (2) identical?




Are the goods undamaged?





Do the nameplate data match the ordering information on the delivery note?



Is the document folder present with accompanying documents?
Is the optional CD-ROM with the Technical Documentation present?





-  If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section →  13.

4.2 Product identification


The following options are available for identification of the device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in the *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the device is displayed.
- Enter the serial number from nameplates in the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate using the *Endress+Hauser Operations App*: All information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard documentation on the device" →  7 and "Supplementary device-dependent documentation" →  7 sections
- The *W@M Device Viewer*: enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Sensor nameplate



 2 Example of a sensor nameplate

- 1 Manufacturing location
- 2 Order code: see the specifications on the order confirmation for the meanings of the individual letters and digits
- 3 Serial number
- 4 Supply voltage and power consumption
- 5 Process connection
- 6 Wetted materials
- 7 Maximum process temperature
- 8 Permitted ambient temperature range
- 9 Space reserved for additional information on the device version (approvals, certificates, etc.)
- 10 Degree of protection
- 11 Flow direction
- 12 Cable temperature
- 13 Space reserved for additional information on the device version (approvals, certificates, etc.)




Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

4.2.2 Symbols on measuring device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature: -40 to +80 °C (-40 to +176 °F), preferably at +20 °C (+68 °F)

5.2 Transporting the product

Transport the device to the measuring point in the original packaging.

-  Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:

- Outer packaging of device
 - Polymer stretch wrap that complies with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material
 - Paper pads


6 Mounting

6.1 Installation conditions

No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

6.1.1 Mounting position

Mounting location




A0028772

To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:


- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A0028773





 3 Installation in a down pipe (e.g. for batching applications)

- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Batching tank

DN		Ø orifice plate, pipe restriction	
[mm]	[in]	[mm]	[in]
8	3⁄8	6	0.24
15	1⁄2	10	0.40
25	1	14	0.55


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orientation			Recommendation
A	Vertical orientation	 A0015591	
B	Horizontal orientation, transmitter at top	 A0015589	✓✓ ¹⁾ → 4, 17
C	Horizontal orientation, transmitter at bottom	 A0015590	✓✓ ²⁾ → 4, 17
D	Horizontal orientation, transmitter at side	 A0015592	✗

- 1) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.




4 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.
- 2 Avoid this orientation for outgassing fluids: Risk of gas accumulating.

Valves

Never install the sensor downstream from a filling valve. If the sensor is completely empty this corrupts the measured value.

i Correct measurement is only possible if the pipe is completely full. Perform sample fillings before commencing filling in production.




A0003768

- 1 Measuring device
- 2 Filling valve
- 3 Container

Filling systems

The pipe system must be completely full to ensure optimum measurement.




A0003795

5 Filling system

- 1 Measuring device
- 2 Filling valve
- 3 Container

Inlet and outlet runs

No special precautions need to be taken for fittings which create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs → 19.



A0029322

A0029323

Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.

6.1.2 Environment and process requirements**Ambient temperature range**

Measuring device	-40 to +60 °C (-40 to +140 °F) (Sensor, transmitter) Install the measuring device in a shady location. Avoid direct sunlight, particularly in warm climatic regions.
-------------------------	--

Temperature tables

Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

System pressure

It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- Ensure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:


- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)

Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.

NOTICE**Electronics overheating on account of thermal insulation!**

- Recommended orientation: horizontal orientation, pointing downwards.
- Do not insulate the .
- Maximum permissible temperature at the lower end of the : 80 °C (176 °F)
- Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.



6 Thermal insulation with extended neck free

A0034391

Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter .
- ▶ Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE

Danger of overheating when heating

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- ▶ Ensure that sufficient convection takes place at the transmitter neck.
- ▶ Ensure that a sufficiently large area of the transmitted neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

Using an electrical trace heating system

If heating is regulated via phase angle control or pulse packages, magnetic fields can affect the measured values (= for values that are greater than the values permitted by the EN standard (sine 30 A/m)).

For this reason, the sensor must be magnetically shielded: the sensor housing can be shielded with tin plates or electric sheets without a privileged direction (e.g. V330-35A).

The sheet must have the following properties:

- Relative magnetic permeability $\mu_r \geq 300$
- Plate thickness $d \geq 0.35 \text{ mm}$ ($d \geq 0.014 \text{ in}$)


Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

6.1.3 Special mounting instructions


Information for filling systems

Correct measurement is possible only if the piping is completely filled. We therefore recommend that some test batches be carried out prior to production batching.

Circular filling system

A0003761

- 1 Tank
- 2 Measuring device
- 3 Batching valve
- 4 Vessel

Linear filling system

A0003762

- 1 Tank
- 2 Measuring device
- 3 Batching valve
- 4 Vessel

Zero point adjustment

The **Sensor adjustment** submenu contains parameters required for zero point adjustment.

NOTICE

All Dosimass measuring devices are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions .

Therefore, a zero point adjustment is generally not required for the Dosimass!

- Experience shows that a zero point adjustment is advisable only in special cases.
- When maximum accuracy is required and flow rates are very low.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).




Detailed information on reference conditions → 73

Prerequisites for zero point adjustment

Note the following points before performing the adjustment:


- A zero point adjustment can be performed only with fluids that contain no gas or solid contents.
- A zero point adjustment takes place when the measuring tubes are completely filled and there is zero flow ($v = 0 \text{ m/s}$ (0 ft/s)). For this purpose, shut-off valves (for example) can be provided upstream or downstream from the sensor, or existing valves and gate valves may be used.
 - Normal operation → Valves 1 and 2 open
 - Zero point adjustment with pump pressure → Valve 1 open and valve 2 closed
 - Zero point adjustment without pump pressure → Valve 1 closed and valve 2 open



A0008558

 7

Performing the zero point adjustment

1. Let the system run until normal operating conditions are present.
2. Stop the flow ($v = 0 \text{ m/s}$ (0 ft/s)).
3. Check the shutoff valves for leaks.
4. Check the necessary process pressure.
5. Perform the adjustment using the ZERO POINT ADJUSTMENT →  44 function.

6.2 Mounting the measuring device

6.2.1 Required tools

For process connections, use the appropriate installation tool.

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.


6.2.3 Mounting the measuring device

WARNING


Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Install the gaskets correctly.
- ▶ Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ▪ Process temperature ▪ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) ▪ Ambient temperature ▪ Measuring range 	<input type="checkbox"/>
Has the correct orientation for the sensor been selected ? <ul style="list-style-type: none"> ▪ According to sensor type ▪ According to medium temperature ▪ According to medium properties (outgassing, with entrained solids) 	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping →  17?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Are the securing screw and securing clamp tightened securely?	<input type="checkbox"/>

7 Electrical connection

 The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Connecting cable requirements

The connecting cables provided by the customer must fulfill the following requirements.



Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.


Signal cable

 Cables are not included in the scope of delivery; they can be ordered as an accessory →  67.

Status input and switch output (batch)

Standard installation cable is sufficient.

Modbus RS485

-  The electrical connection of the shield to the device housing must be properly implemented (e.g. using a knurled nut).
- Please note the following with regard to cable loading:
 - Voltage drop due to the cable length and cable type.
 - Valve performance.

Total length of cable in the Modbus network ≤ 50 m

Use a shielded cable.

Example:

Terminated device connector with cable: Lumberg RKWTH 8-299/10

Total length of cable in the Modbus network > 50 m

Use shielded twisted pair cable for RS485 applications.



Example:

- Cable: Belden item no. 9842 (for 4-wire version, the same cable can be used for the power supply)
- Terminated device plug: Lumberg RKCS 8/9 (shieldable version)

7.1.2 Terminal assignment

Connection is solely by means of device plug:


There are different device versions available. Order code for "Output, input":

- Option 4: Modbus RS485, 1 status output (batch), 1 status input →  25
- Option 5: Modbus RS485, 2 status outputs (batch), 1 status input →  26

7.1.3 Pin assignment, device plug

Device version: Modbus RS485, status output and status input

Order code for "Output, input", option 4:
Modbus RS485, 1 switch output (batch), 1 status input



8 Connection to device


- A Coupling: Supply voltage, Modbus RS485
- B Connector: Supply voltage, Modbus RS485
- C Coupling: Switch output (batch), status input
- D Connector: Switch output (batch), status input
- E PELV or SELV power supply
- V1 Valve 1 (batch)
- 1 to Pin assignment
- 8

Pin assignment

Connection: Coupling (A) – Connector (B)			Connection: Coupling (C) – Connector (D)		
Pin	Assignment		Pin	Assignment	
1	L+	Supply voltage	1	+	Status input
2	+	Service interface RX	2	–	Status input
3	+	Service interface TX	3	–	Switch output (batch)
4	L-	Supply voltage	4	+	Switch output (batch)
5	Not assigned		5	Not assigned	
6	A	Modbus RS485			
7	B	Modbus RS485			
8	–	Service interface GND			

Device version: Modbus RS485 , 2 status outputs and status input

Order code for "Output, input", option 5:
Modbus RS485, 2 switch outputs (batch), 1 status input



A0032571

9 Connection to device

- A Coupling: Supply voltage, Modbus RS485
- B Connector: Supply voltage, Modbus RS485
- C Coupling: Switch outputs (batch), status input
- D Connector: Switch outputs (batch), status input
- E PELV or SELV power supply
- V1 Valve (batch), level 1
- V2 Valve (batch), level 2
- 1 to Pin assignment
- 8


Pin assignment

Connection: Coupling (A) – Connector (B)			Connection: Coupling (C) – Connector (D)		
Pin	Assignment		Pin	Assignment	
1	L+	Supply voltage	1	+	Status input
2	+	Service interface RX	2	+	Switch output (batch) 2
3	+	Service interface TX	3	–	Switch outputs, status input
4	L-	Supply voltage	4	+	Switch output (batch) 1
5	Not assigned		5	Not assigned	
6	A	Modbus RS485			
7	B	Modbus RS485			
8	–	Service interface GND			

7.1.4 Requirements for the supply unit

Supply voltage

DC 24 V (nominal voltage: DC 20 to 30 V)

-  The power unit must be tested to ensure that it meets safety requirements (e.g. PELV, SELV).
- The supply voltage must not exceed a maximum short-circuit current of 50 A.

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by appropriately trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ☹ before connecting additional cables.
- ▶ For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.
- ▶ The power unit must be tested to ensure it meets safety requirements (e.g. PELV, SELV).

7.2.1 Connecting the transmitter

Connection by means of device plug

Connection is solely by means of device plug.




A0032534

A, C Coupling
B, D Plug

Grounding

Grounding is by means of a cable socket.



A0007235


7.3 Ensuring the degree of protection

The measuring device fulfills all the requirements for IP67 degree of protection, Type 4X enclosure.

To guarantee IP67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:


- Tighten all device plugs.

7.4 Post-connection check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the supply voltage in the system match the specifications on the device's nameplate?	<input type="checkbox"/>
Do the cables used comply with the necessary specifications?	<input type="checkbox"/>
Are the maximum values for voltage and current at the pulse and status output being observed? →  70	<input type="checkbox"/>

8 Operation options

8.1 Overview of operation options



- 1 Computer with "FieldCare" or "DeviceCare" operating tool
2 Control system (e.g. PLC)


8.2 Access to the operating menu via the operating tool

8.2.1 Connecting the operating tool

Using the service adapter and Commubox FXA291

Operation and configuration can be performed using the Endress+Hauser FieldCare or DeviceCare service and configuration software.

The device is connected to the USB port of the computer via the service adapter and Commubox FXA291.



- 1 Supply voltage 24 V DC
2 Service adapter
3 Dosimag
4 Commubox FXA291
5 Computer with "FieldCare" or "DeviceCare" operating tool



The service adapter, cable and Commubox FXA291 are not included in the delivery. These components can be ordered as accessories → 67.

8.2.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

Service adapter and Commubox FXA291


Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information →  32

Establishing a connection


Service adapter, Commubox FXA291 and "FieldCare" operating tool

1. Start FieldCare and launch the project.
2. In the network: Add a device.
 - ↳ The **Add device** window opens.
3. Select the **CDI Communication FXA291** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication FXA291** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
6. Establish the online connection to the device.



For additional information, see Operating Instructions BA00027S and BA00059S

User interface



A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal → 55
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.2.3 DeviceCare

Function scope

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure IN01047S

Source for device description files

See information → 32

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	03.00.zz	<ul style="list-style-type: none"> On the title page of the Operating Instructions On the transmitter nameplate Firmware version Diagnostics menu → Device information submenu → Firmware version parameter
Release date of firmware version	05.2015	---



For an overview of the different firmware versions for the device

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.




Operating tool	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)

9.2 Modbus RS485 information

9.2.1 Function codes


Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:

Code	Name	Description	Application
03	Read holding register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	Read device parameters with read and write access Example: Read mass flow
04	Read input register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	Read device parameters with read access Example: Read totalizer value

Code	Name	Description	Application
06	Write single registers	Master writes a new value to one Modbus register of the measuring device.  Use function code 16 to write multiple registers with just 1 telegram.	Write only 1 device parameter Example: reset totalizer
08	Diagnostics	Master checks the communication connection to the measuring device. The following "Diagnostics codes" are supported: <ul style="list-style-type: none"> ▪ Sub-function 00 = Return query data (loopback test) ▪ Sub-function 02 = Return diagnostics register 	
16	Write multiple registers	Master writes a new value to multiple Modbus registers of the device. A maximum of 120 consecutive registers can be written with 1 telegram.  If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map →  35	Write multiple device parameters Example: <ul style="list-style-type: none"> ▪ Mass flow unit ▪ Mass unit
23	Read/Write multiple registers	Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram. Write access is executed before read access.	Write and read multiple device parameters Example: <ul style="list-style-type: none"> ▪ Read mass flow ▪ Reset totalizer

 Broadcast messages are only allowed with function codes 06, 16 and 23.

9.2.2 Register information

 For an overview of device parameters with their respective Modbus register information, please refer to the "Modbus RS485 register information" section in the "Description of device parameters" documentation .

9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to 5 ms

9.2.4 Data types

The measuring device supports the following data types:

FLOAT (floating point number IEEE 754) Data length = 4 bytes (2 registers)			
Byte 3	Byte 2	Byte 1	Byte 0
SEEEEEEE	EMMMMMMM	MMMMMMMM	MMMMMMMM
S = sign, E = exponent, M = mantissa			

INTEGER Data length = 2 bytes (1 register)	
Byte 1	Byte 0
Most significant byte (MSB)	Least significant byte (LSB)

STRING Data length = depends on the device parameter, e.g. presentation of a device parameter with a data length = 18 bytes (9 registers)				
Byte 17	Byte 16	...	Byte 1	Byte 0
Most significant byte (MSB)		...		Least significant byte (LSB)

9.2.5 Byte transmission sequence

Byte addressing, i.e. the transmission sequence of the bytes, is not specified in the Modbus specification. For this reason, it is important to coordinate or match the addressing method between the master and slave during commissioning. This can be configured in the measuring device using the **Byte order** parameter.

The bytes are transmitted depending on the selection in the **Byte order** parameter:

FLOAT				
	Sequence			
Options	1.	2.	3.	4.
1 - 0 - 3 - 2 *	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)
0 - 1 - 2 - 3	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)
2 - 3 - 0 - 1	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)
3 - 2 - 1 - 0	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)
* = factory setting, S = sign, E = exponent, M = mantissa				

INTEGER		
	Sequence	
Options	1.	2.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 1 (MSB)	Byte 0 (LSB)
0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 0 (LSB)	Byte 1 (MSB)
* = factory setting, MSB = most significant byte, LSB = least significant byte		

STRING Presentation taking the example of a device parameter with a data length of 18 bytes.					
	Sequence				
Options	1.	2.	...	17.	18.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 17 (MSB)	Byte 16	...	Byte 1	Byte 0 (LSB)

0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 16	Byte 17 (MSB)	...	Byte 0 (LSB)	Byte 1
* = factory setting, MSB = most significant byte, LSB = least significant byte					

9.2.6 Modbus data map

Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.

Structure of the Modbus data map

The Modbus data map consists of two data sets:

- **Scan list: Configuration area**
The device parameters to be grouped are defined in a list in that their Modbus RS485 register addresses are entered in the list.
- **Data area**
The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.



For an overview of device parameters with their respective Modbus register information, please refer to the "Modbus RS485 register information" section in the "Description of device parameters" documentation.

Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

Max. entries	16 device parameters
Supported device parameters	Only parameters with the following characteristics are supported: <ul style="list-style-type: none"> ■ Access type: read or write access ■ Data type: float or integer

Configuring the scan list via FieldCare or DeviceCare

Carried out using the operating menu of the measuring device:

Expert → Communication → Modbus data map → Scan list register 0 to 15

Scan list	
No.	Configuration register
0	Scan list register 0
...	...
15	Scan list register 15

Configuring the scan list via Modbus RS485

Carried out using register addresses 5001 - 5016

Scan list			
No.	Modbus RS485 register	Data type	Configuration register
0	5001	Integer	Scan list register 0
...	...	Integer	...
15	5016	Integer	Scan list register 15

Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.



Master access to data area	Via register addresses 5051-5081
----------------------------	----------------------------------

Data area				
Device parameter value	Modbus RS485 register		Data type*	Access**
	Start register	End register (Float only)		
Value of scan list register 0	5051	5052	Integer/float	Read/write
Value of scan list register 1	5053	5054	Integer/float	Read/write
Value of scan list register
Value of scan list register 15	5081	5082	Integer/float	Read/write
* Data type depends on the device parameters entered in the scan list. ** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area.				

10 Commissioning

10.1 Function check


Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist →  23
- "Post-connection check" checklist →  28



10.2 Switching on the measuring device

- ▶ The function check has been completed successfully.
Switch on the supply voltage.
 - ↳ The measuring device runs through internal test functions.

The device is operational and operation commences.

 If the device does not start up successfully, depending on the cause, a diagnostic message is displayed in the system asset management tool "FieldCare".







10.3 Connecting via FieldCare







- For FieldCare connection
- For connecting via FieldCare →  30
- For the FieldCare →  31 user interface

10.4 Configuring the measuring device

The **Setup** menu with its submenus contains all the parameters needed for standard operation.

Navigation
"Setup" menu

 38), 'System units' (▶  38), 'Status input' (▶  39), 'Batch output' (▶  40), 'Communication' (▶  41), and 'Low flow cut off' (▶  42)." data-bbox="313 648 960 876"/>

Setup Menu Item	Page Reference
Device tag	→  38
▶ System units	→  38
▶ Status input	→  39
▶ Batch output	→  40
▶ Communication	→  41
▶ Low flow cut off	→  42

► Partially filled pipe detection

→ 43

► Advanced setup

→ 44

10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

 Enter the tag name in the "FieldCare" operating tool → 31

Navigation
"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 16 characters, such as letters, numbers or special characters (e.g. @, %, /).	Dosimass

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation
"Setup" menu → System units

► System units

Mass flow unit

→ 39

Mass unit

→ 39

Volume flow unit

→ 39

Volume unit

→ 39

Density unit

→ 39

Temperature unit

→ 39

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Low flow cut off Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> g/s oz/s
Mass unit	Select mass unit.	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg lb Country-specific: <ul style="list-style-type: none"> g oz
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Low flow cut off Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> ml/s fl oz/s (us)
Volume unit	Select volume unit.	Unit choose list	Country-specific: <ul style="list-style-type: none"> l gal (us) Country-specific: <ul style="list-style-type: none"> ml fl oz (us)
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Simulation process variable Density adjustment (Expert menu) 	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg/l g/cm³
Temperature unit	Select temperature unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Maximum value parameter (6108) Minimum value parameter (6109) Temperature parameter 	Unit choose list	Country-specific: <ul style="list-style-type: none"> °C °F

10.4.3 Configuring the status input

Navigation

"Setup" menu → Status input

Structure of the submenu

► Status input		
Assign status input	→	📄 40
Active level	→	📄 40
Response time status input	→	📄 40

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign status input	Start condition for a batching process: <ul style="list-style-type: none"> There is no diagnostic message from the Alarm category. The batch quantity must be > 0. In the Switch output function parameter, the Batching option is selected. 	Select function for the status input.	<ul style="list-style-type: none"> Off Start batch Start & stop batch Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override 	Off
Active level	–	Define input signal level at which the assigned function is triggered.	<ul style="list-style-type: none"> High Low 	High
Response time status input	–	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	10 to 200 ms	50 ms

10.4.4 Configuring the switch output (batch)

A batch profile (1 to 6) can be assigned to the switch output (batch) in the **Batch output** submenu.

The individual batch profiles are configured in the **Settings batch profile 1 to n** submenu.

Navigation

"Setup" menu → Batch output

► Batch output

Batch profile

→ 40

► Settings batch profile 1 to n

→ 40

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Batch profile	Select suitable profile for fluid configured by customer.	<ul style="list-style-type: none"> Profile 1 Profile 2 Profile 3 Profile 4 Profile 5 Profile 6 	Profile 1

Batch profile settings

The **Settings batch profile 1 to n** submenu contains all the parameters that must be set for configuration of the batch profiles.

Navigation

"Setup" menu → Batch output → Settings batch profile 1 to n

▶ Settings batch profile 1 to n

Input selector

→ 41

Batch unit

→ 41

Batch quantity

→ 41

Drip correction mode

→ 41

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Input selector	–	Select a process variable for batch profile.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow 	Mass flow
Batch unit	One of the following options is selected in the Input selector parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow 	Select unit for process variable of the batch profile. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> ■ Batch quantity ■ Fixed compensation quantity ■ Batch unit 	Unit choose list	Depending on country: <ul style="list-style-type: none"> ■ g (Mass flow) ■ oz (Mass flow)
Batch quantity	One of the following options is selected in the Input selector parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow 	Enter a quantity of selected process variable for batch profile. <i>Dependency</i> The unit is taken from: Batch unit parameter	Positive floating-point number	Depending on country: <ul style="list-style-type: none"> ■ 0 g ■ 0 oz
Drip correction mode	One of the following options is selected in the Input selector parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow 	Select a drip correction.	<ul style="list-style-type: none"> ■ Off ■ Fixed time ■ Fixed time or low flow cut off 	Off

10.4.5 Configuring the communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication

▶ Communication

Bus address

→ 42

Baudrate	→ 42
Data transfer mode	→ 42
Parity	→ 42
Byte order	→ 42
Assign diagnostic behavior	→ 42
Failure mode	→ 42

Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Bus address	Enter device address.	1 to 247	247
Baudrate	Define data transfer speed.	<ul style="list-style-type: none">1200 BAUD2400 BAUD4800 BAUD9600 BAUD19200 BAUD38400 BAUD57600 BAUD115200 BAUD	19200 BAUD
Data transfer mode	Select data transfer mode.	<ul style="list-style-type: none">ASCIIRTU	RTU
Parity	Select parity bits.	Picklist ASCII option: <ul style="list-style-type: none">0 = Even option1 = Odd option Picklist RTU option: <ul style="list-style-type: none">0 = Even option1 = Odd option2 = None / 1 stop bit option3 = None / 2 stop bits option	Even
Byte order	Select byte transmission sequence.	<ul style="list-style-type: none">0-1-2-33-2-1-01-0-3-22-3-0-1	1-0-3-2
Assign diagnostic behavior	Select diagnostic behavior for MODBUS communication.	<ul style="list-style-type: none">OffAlarm or warningWarningAlarm	Alarm
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication. NaN ¹⁾	<ul style="list-style-type: none">NaN valueLast valid value	NaN value

1) Not a Number

10.4.6 Low flow cut off

The **Low flow cut off** submenu contains the parameters that must be set in order to configure the low flow cut off.

Navigation

"Setup" menu → Low flow cut off

► Low flow cut off		
Assign process variable	→	43
On value low flow cutoff	→	43
Off value low flow cutoff	→	43
Pressure shock suppression	→	43

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	–	Select process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow 	Mass flow
On value low flow cutoff	A process variable is selected in the Assign process variable parameter (→ 43).	Enter on value for low flow cut off.	Positive floating-point number	For liquids: depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter (→ 43).	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	A process variable is selected in the Assign process variable parameter (→ 43).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.4.7 Detection of partially filled pipes

The **Partially filled pipe detection** submenu contains parameters required for configuring partially filled pipe detection.

Navigation

"Setup" menu → Partially filled pipe detection

► Partially filled pipe detection		
Assign process variable	→	44
Low value partial filled pipe detection	→	44
High value partial filled pipe detection	→	44
Response time part. filled pipe detect.	→	44

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	–	Select process variable for partially filled pipe detection.	<div>■ Off</div> <div>■ Density</div>	Off
Low value partial filled pipe detection	A process variable is selected in the Assign process variable parameter (→ 44).	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-specific: <div>■ 200 kg/m³</div> <div>■ 12.5 lb/ft³</div>
High value partial filled pipe detection	A process variable is selected in the Assign process variable parameter (→ 44).	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-specific: <div>■ 6 000 kg/m³</div> <div>■ 374.6 lb/ft³</div>
Response time part. filled pipe detect.	A process variable is selected in the Assign process variable parameter (→ 44).	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s	1 s

10.5 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation

"Setup" menu → Advanced setup

▶ Advanced setup

Enter access code

→ 44

▶ Sensor adjustment

→ 44

▶ Totalizer 1 to n

→ 45

▶ Administration

Parameter overview with brief description

Parameter	Description	User entry
Enter access code	Enter access code to disable write protection of parameters.	Max. 16-digit character string comprising numbers, letters and special characters

10.5.1 Sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation
"Setup" menu → Advanced setup → Sensor adjustment

► Sensor adjustment

Installation direction

→ 45

► Zero point adjustment

Zero point adjustment control

→ 45

Progress

→ 45

Parameter overview with brief description

Parameter	Description	Selection / User interface	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<div>■ Flow in arrow direction</div> <div>■ Flow against arrow direction</div>	Flow in arrow direction
Zero point adjustment control	Start zero point adjustment.	<div>■ Cancel</div> <div>■ Busy</div> <div>■ Zero point adjust failure</div> <div>■ Start</div>	Cancel
Progress	Shows the progress of the process.	0 to 100 %	–

10.5.2 Configuring the totalizer

The totalizer in question can be configured in the **Totalizer 1 to n** submenu.

Navigation
"Setup" menu → Advanced setup → Totalizer 1 to n

► Totalizer 1 to n

Assign process variable

→ 46

Mass unit

→ 46

Volume unit

→ 46

Totalizer operation mode

→ 46

Failure mode

→ 46

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	–	Select process variable for totalizer.	<ul style="list-style-type: none"> Off Volume flow Mass flow 	Mass flow
Mass unit	The Mass flow option is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Select mass unit.	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg lb Country-specific: <ul style="list-style-type: none"> g oz
Volume unit	The Volume flow option is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Select volume unit.	Unit choose list	Country-specific: <ul style="list-style-type: none"> l gal (us) Country-specific: <ul style="list-style-type: none"> ml fl oz (us)
Totalizer operation mode	A process variable is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	<ul style="list-style-type: none"> Net flow total Forward flow total Reverse flow total 	Net flow total
Failure mode	A process variable is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Define totalizer behavior in alarm condition.	<ul style="list-style-type: none"> Stop Actual value Last valid value 	Stop

10.6 Simulation


The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu → Simulation

► Simulation	
Assign simulation process variable	→ 47
Value process variable	→ 47
Simulation device alarm	→ 47

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Density ■ Temperature 	Off
Value process variable	A process variable is selected in the Assign simulation process variable parameter (→  47).	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Simulation device alarm	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off

11 Operation

11.1 Reading device locking status

Device active write protection: **Locking status** parameter

Navigation

"Operation" menu → Locking status

Function scope of the "Locking status" parameter

Options	Description
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Locking status	Indicates the write protection with the highest priority that is currently active.	Temporarily locked	Temporarily locked

11.2 Reading access authorization status on operating software

Displaying active access authorization: **Access status tooling** parameter

Navigation

"Operation" menu → Access status tooling

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Access status tooling	Shows the access authorization to the parameters via the operating tool.	<ul style="list-style-type: none">■ Operator■ Maintenance	Maintenance

11.3 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

11.3.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables

► Process variables		
Mass flow		→ ⓘ 49
Volume flow		→ ⓘ 49
Density		→ ⓘ 49
Temperature		→ ⓘ 49

Parameter overview with brief description

Parameter	Description	User interface
Mass flow	Displays the mass flow currently measured. <i>Dependency</i> The unit is taken from the Mass flow unit parameter (→ ⓘ 39).	Signed floating-point number
Volume flow	Displays the volume flow currently calculated. <i>Dependency</i> The unit is taken from the Volume flow unit parameter (→ ⓘ 39).	Signed floating-point number
Density	Shows the density currently measured. <i>Dependency</i> The unit is taken from the Density unit parameter (→ ⓘ 39).	Signed floating-point number
Temperature	Shows the medium temperature currently measured. <i>Dependency</i> The unit is taken from the Temperature unit parameter (→ ⓘ 39).	Signed floating-point number

11.3.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer

► Totalizer		
Totalizer value 1 to n		→ ⓘ 50
Totalizer overflow 1 to n		→ ⓘ 50

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer value	One of the following options is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu: <ul style="list-style-type: none">■ Volume flow■ Mass flow	Displays the current totalizer counter value.	Signed floating-point number
Totalizer overflow	One of the following options is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu: <ul style="list-style-type: none">■ Volume flow■ Mass flow	Displays the current totalizer overflow.	Integer with sign

11.3.3 Input values

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu → Measured values → Input values

► Input values

Value status input → 50

Parameter overview with brief description

Parameter	Description	User interface
Value status input	Shows the current input signal level.	<ul style="list-style-type: none">■ High■ Low

11.4 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu → Totalizer handling


► Totalizer handling

Control Totalizer 1 to n → 51

Preset value 1 to n → 51

Reset all totalizers → 51

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer	A process variable is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Control totalizer value.	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold 	Totalize
Preset value	A process variable is selected in the Assign process variable parameter (→ 46) of the Totalizer 1 to n submenu.	Specify start value for totalizer. <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer depending on the selection made in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Volume flow option: Volume flow unit parameter ■ Mass flow option: Mass flow unit parameter 	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> ■ 0 kg ■ 0 lb
Reset all totalizers	–	Reset all totalizers to 0 and start.	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize 	Cancel

11.4.1 Function scope of the "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.













11.4.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.




11.5 Batching control


The **Batching** submenu contains all the parameters required for batching control.

Navigation
"Operation" submenu → Batching

► Batching		
Batch control	→	 52
Batch counter	→	 52
Last batch quantity	→	 52
Quantity last drip	→	 52
Current drip correction quantity	→	 52
Overall batching quantity	→	 53
Overflow number overall batch. quantity	→	 53
Switch output function 1	→	 53
Switch status 1	→	 53
Switch output function 2	→	 53
Switch status 2	→	 53
Reset overall batching quantity	→	 53

Parameter overview with brief description


Parameter	Description	Selection / User interface	Factory setting
Batch control	Switch the batch on and off.	<ul style="list-style-type: none">■ Start■ Stop	Stop
Batch counter	Shows number of passed batch procedures.	Positive integer	–
Last batch quantity	Shows total quantity of last batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Quantity last drip	Shows drip quantity of last batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Current drip correction quantity	Shows the drip correction quantity of current batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–

Parameter	Description	Selection / User interface	Factory setting
Overall batching quantity	Shows the total quantity of all passed batch procedures of current profile. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Overflow number overall batch. quantity	Shows how often an overflow of the overall batching quantity has occurred.	–32 000.0 to 32 000.0	–
Switch output function 1 to n	Select function for the switch output.	<ul style="list-style-type: none"> ■ Close ■ Open ■ Batching 	<ul style="list-style-type: none"> ■ Batching (Switch output function 1) ■ Open (Switch output function 2)
Switch status 1 to n	Select status of switch output.	<ul style="list-style-type: none"> ■ Closed ■ Open 	–
Reset overall batching quantity	Reset the total quantity of all passed batch procedures to 0.	<ul style="list-style-type: none"> ■ Reset ■ Cancel 	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting


For access

Error	Possible causes	Solution
No write access to parameters	Current user role has limited access authorization	Check the access authorization status .
No connection via Modbus RS485	Device plug connected incorrectly	Check the pin assignment of the connector .
No connection via Modbus RS485	Modbus RS485 cable incorrectly terminated	Check terminating resistor .
No connection via Modbus RS485	Incorrect settings for the communication interface	Check the Modbus RS485 configuration → 41.
No connection via service adapter	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox.  FXA291: Document "Technical Information" TI00405C

12.2 Diagnostic information in FieldCare or DeviceCare

12.2.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



A0021799-EN

- 1 Status area with status signal
- 2 Diagnostic information → 55
- 3 Remedy information with Service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter
- Via submenu → 60

Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
	Failure A device error has occurred. The measured value is no longer valid.
	Function check The device is in service mode (e.g. during a simulation).
	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
	Maintenance required Maintenance is required. The measured value is still valid.

i The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



12.2.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.



1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
↳ A tool tip with remedy information for the diagnostic event appears.

12.3 Diagnostic information via communication interface

12.3.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270

 For an overview of diagnostic events with diagnosis number and diagnosis code
→  57



12.3.2 Configuring error response mode

The error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

Navigation path

Setup → Communication

Parameter overview with brief description

Parameters	Description	Selection	Factory setting
Failure mode	<p>Select measured value output behavior when a diagnostic message occurs via Modbus communication.</p> <p> This effect of this parameter depends on the option selected in the Assign diagnostic behavior parameter.</p>	<ul style="list-style-type: none"> ■ NaN value ■ Last valid value <p> NaN ≡ not a number</p>	NaN value

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior



Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The measured value output via Modbus RS485 and the totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The measured value output via Modbus RS485 and the totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered only in the Event logbook submenu.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.5 Overview of diagnostic information

 In the case of some items of diagnostic information, the diagnostic behavior can be changed. Change the diagnostic information →  57

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of sensor				
022	Sensor temperature	1. Change main electronic module 2. Change sensor	F	Alarm
046	Sensor limit exceeded	1. Inspect sensor 2. Check process condition	S	Alarm ¹⁾
062	Sensor connection	1. Change main electronic module 2. Change sensor	F	Alarm
082	Data storage	1. Check module connections 2. Contact service	F	Alarm


Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
083	Memory content	1. Restart device 2. Contact service	F	Alarm
140	Sensor signal	1. Check or change main electronics 2. Change sensor	S	Alarm ¹⁾
190	Special event 1	Contact service	F	Alarm
191	Special event 5	Contact service	F	Alarm
192	Special event 9	Contact service	F	Alarm ¹⁾
Diagnostic of electronic				
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
274	Main electronic failure	Change electronic	S	Warning ¹⁾
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
391	Special event 6	Contact service	F	Alarm
392	Special event 10	Contact service	F	Alarm ¹⁾
Diagnostic of configuration				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
442	Frequency output 1 to n	1. Check process 2. Check frequency output settings	S	Warning ¹⁾
443	Pulse output 1 to n	1. Check process 2. Check pulse output settings	S	Warning ¹⁾
453	Flow override	Deactivate flow override	C	Warning
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
590	Special event 3	Contact service	F	Alarm
591	Special event 7	Contact service	F	Alarm
592	Special event 11	Contact service	F	Alarm ¹⁾



Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of process				
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾
862	Partly filled pipe	1. Check for gas in process 2. Adjust detection limits	S	Warning
910	Tubes not oscillating	1. Check electronic 2. Inspect sensor	F	Alarm
912	Medium inhomogeneous	1. Check process cond. 2. Increase system pressure	S	Warning ¹⁾
912	Inhomogeneous		S	Warning ¹⁾
913	Medium unsuitable	1. Check process conditions 2. Check electronic modules or sensor	S	Alarm ¹⁾
948	Tube damping too high	Check process conditions	S	Warning
990	Special event 4	Contact service	F	Alarm
991	Batch time exceeded	Check process conditions	F	Warning ¹⁾
991	Special event 8	Contact service	F	Alarm
991	Maximum flow rate exceeded	Check process conditions	F	Warning ¹⁾
992	Special event 12	Contact service	F	Alarm ¹⁾



1) Diagnostic behavior can be changed.

12.6 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.






 To call up the measures to rectify a diagnostic event:

- Via "FieldCare" operating tool →  56
- Via "DeviceCare" operating tool →  56


 Other pending diagnostic events can be displayed in the **Diagnostic list** submenu →  60

Navigation

"Diagnostics" menu

 Diagnostics	
Actual diagnostics	→  60
Previous diagnostics	→  60
Operating time from restart	→  60
Operating time	→  60

Parameter overview with brief description




Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occurred diagnostic event along with its diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	–	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	–	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.7 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.




Navigation path

Diagnostics → Diagnostic list

-  To call up the measures to rectify a diagnostic event:
- Via "FieldCare" operating tool →  56
 - Via "DeviceCare" operating tool →  56

12.8 Event logbook

12.8.1 Event history

-  To call up the measures to rectify a diagnostic event:
- Via "FieldCare" operating tool →  56
 - Via "DeviceCare" operating tool →  56

-  For filtering the displayed event messages →  60

12.8.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1111	Density adjust failure
I1151	History reset
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok

12.9 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

12.9.1 Function scope of the "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	All the parameters are reset to their factory settings.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

12.10 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu → Device information

► Device information

Device tag

Serial number

Firmware version

Device name





→ ⓘ 62

→ ⓘ 62

→ ⓘ 62

Order code	→ ⓘ 62
Extended order code 1	→ ⓘ 62
Extended order code 2	→ ⓘ 62
Extended order code 3	→ ⓘ 62
ENP version	→ ⓘ 62

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Dosimass
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	–
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	–
Order code	Shows the device order code.  It can be found in the "Order code" field on the nameplate.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	–
Extended order code 1	Shows the 1st part of the extended order code.  It can be found in the "Ext. ord. cd." field on the nameplate.	Character string	–
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
Extended order code 3	Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00

12.11 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
09.2015	03.00.zz	Option A	No change in firmware	Operating Instructions	BA01320D/06/EN/02.15
08.2014	03.00.zz	Option A	<ul style="list-style-type: none"> ■ Original firmware ■ Can be operated via FieldCare and DeviceCare 	Operating Instructions	BA01320D/06/EN/01.14



For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

- In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
- Specify the following details:
 - Product root: e.g. 8RE
The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

Observe the following points for CIP and SIP cleaning:

- Use only cleaning agents to which the process-wetted materials are adequately resistant.
- Observe the maximum permitted medium temperature for the measuring device .

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment:

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring device cannot be converted.
- If the measuring device is defective, the entire device is replaced.
- It is possible to replace seals.

Information on replacing wear parts (seals)

Please note the following when replacing wear parts:

- Use only original Endress+Hauser spare parts.
- Replace the part according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter (→ 62) in the **Device information** submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the website for more information:
<http://www.endress.com/support/return-material>
2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.

⚠ WARNING**Danger to persons from process conditions.**

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device**⚠ WARNING****Danger to personnel and environment from fluids that are hazardous to health.**

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.




Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ▶ Ensure proper separation and reuse of the device components.

15 Accessories



Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Communication-specific accessories

Accessories	Description
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  For details, see Operating Instructions BA00027S and BA00059S
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices.  For details, see Innovation brochure IN01047S
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.  For details, see the "Technical Information" document TI405C/07
Adapter connection	Adapter connections for installation on other electrical connections: <ul style="list-style-type: none"> ▪ Adapter FXA291 (order number: 71035809) ▪ Adapter RSE8 (order number: 50107169) RSE8 connection jack, 8-pin adapter (RSE8), 24 V DC, pulse, status ▪ Adapter RSE5 (order number: 50107168) RSE8 connection jack, 5-pin adapter (RSE5), 24 V DC, pulse, status ▪ Adapter RSE4 (order number: 50107167) RSE8 connection jack, 4-pin adapter (RSE4), 24 V DC, pulse
Connecting cable RSE8	Cable RKWTN8-56/5 P92, length: 5 m (Order number: 50107895)

15.2 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: <ul style="list-style-type: none"> ▪ Choice of measuring devices for industrial requirements ▪ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. ▪ Graphic illustration of the calculation results ▪ Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. Applicator is available: <ul style="list-style-type: none"> ▪ Via the Internet: https://portal.endress.com/webapp/applicator ▪ As a downloadable DVD for local PC installation.
W@M	W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle. W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime. Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, visit www.endress.com/lifecyclemanagement

Accessories	Description
FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> Operating Instructions BA00027S and BA00059S</p>
DeviceCare	<p>Tool to connect and configure Endress+Hauser field devices.</p> <p> Innovation brochure IN01047S</p>
Commubox FXA291	<p>Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.</p>

16 Technical data

16.1 Application



The measuring device is suitable for flow measurement of liquids and gases only.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Mass flow measurement based on the Coriolis measuring principle
---------------------	---

Measuring system	<p>The device consists of a transmitter and a sensor.</p> <p>The device is available as a compact version: The transmitter and sensor form a mechanical unit.</p> <p>For information on the structure of the device →  11 →  11</p>
------------------	---



16.3 Input

Measured variable	<p>Direct measured variables</p> <ul style="list-style-type: none"> ▪ Mass flow ▪ Density ▪ Temperature <p>Calculated measured variables</p> <p>Volume flow</p>
-------------------	--



Measuring range	Flow values in SI units	
	DN [mm]	Measuring range full scale values $\dot{m}_{\min(F)}$ to $\dot{m}_{\max(F)}$ [kg/h]
	8	0 to 2 000
	15	0 to 6 500
	25	0 to 18 000

Flow values in US units

DN [in]	Measuring range full scale values $\dot{m}_{\min(F)}$ to $\dot{m}_{\max(F)}$ [lb/min]
$\frac{3}{8}$	0 to 73.50
$\frac{1}{2}$	0 to 238.9
1	0 to 661.5

 To calculate the measuring range, use the *Applicator* sizing tool →  67

Recommended measuring range

 Flow limit →  76

Operable flow range	Over 1000 : 1. Flow rates above the preset full scale value do not override the electronics unit, with the result that the totalizer values are registered correctly.
---------------------	--

Input signal	Status input The batching process is controlled by the automation system via the device's status input. <table><tr><td>Maximum input values</td><td><ul style="list-style-type: none">■ DC 30 V■ 6 mA</td></tr><tr><td>Response time</td><td>Adjustable: 10 to 200 ms</td></tr><tr><td>Input signal level</td><td><ul style="list-style-type: none">■ Low level: 0 to 1.5 V■ High level: 3 to 30 V</td></tr><tr><td>Assignable functions</td><td><ul style="list-style-type: none">■ Off■ Start batching process■ Start and stop batching process■ Reset totalizers 1-3 separately■ Reset all totalizers■ Flow override</td></tr></table>	Maximum input values	<ul style="list-style-type: none">■ DC 30 V■ 6 mA	Response time	Adjustable: 10 to 200 ms	Input signal level	<ul style="list-style-type: none">■ Low level: 0 to 1.5 V■ High level: 3 to 30 V	Assignable functions	<ul style="list-style-type: none">■ Off■ Start batching process■ Start and stop batching process■ Reset totalizers 1-3 separately■ Reset all totalizers■ Flow override
Maximum input values	<ul style="list-style-type: none">■ DC 30 V■ 6 mA								
Response time	Adjustable: 10 to 200 ms								
Input signal level	<ul style="list-style-type: none">■ Low level: 0 to 1.5 V■ High level: 3 to 30 V								
Assignable functions	<ul style="list-style-type: none">■ Off■ Start batching process■ Start and stop batching process■ Reset totalizers 1-3 separately■ Reset all totalizers■ Flow override								

16.4 Output

Output signal	Modbus RS485 <table><tr><td>Physical interface</td><td>In accordance with EIA/TIA-485-A standard</td></tr></table>	Physical interface	In accordance with EIA/TIA-485-A standard
Physical interface	In accordance with EIA/TIA-485-A standard		

Switch output (batch: valve control)

Depending on the device version, the device has one or two switch outputs.

Switch output	
Version	Active, open emitter
Maximum input values	<ul style="list-style-type: none">■ DC 30 V■ 500 mA
Switching behavior	Binary, conductive or non-conductive

Number of switching cycles	Unlimited
Assignable functions	<ul style="list-style-type: none"> ▪ Open ▪ Closed ▪ Batching

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from: <ul style="list-style-type: none"> ▪ Actual value ▪ No pulses
Frequency output	
Failure mode	Choose from: <ul style="list-style-type: none"> ▪ Actual value ▪ 0 Hz ▪ Defined value: 0 to 10 000 Hz
Switch output	
Failure mode	Choose from: <ul style="list-style-type: none"> ▪ Current status ▪ Open ▪ Closed

Modbus RS485

Failure mode	Choose from: <ul style="list-style-type: none"> ▪ NaN value instead of current value ▪ Last valid value
--------------	---

Low flow cut off

The switch points for low flow cut off are user-selectable.



Galvanic isolation

- Device version: Modbus RS485, 1 switch output (batch), 1 status input (Order code for "Output, input": option 4)
Switch outputs (batch) and status input on supply potential
- Device version: Modbus RS485, 2 switch outputs (batch), 1 status input (Order code for "Output, input", option 5:)
 - Switch outputs (batch) on supply potential.
 - Status input, galvanically isolated.





Protocol-specific data


Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1
Device type	Slave
Slave address range	1 to 247
Broadcast address range	0

Function codes	<ul style="list-style-type: none">▪ 03: Read holding register▪ 04: Read input register▪ 06: Write single registers▪ 08: Diagnostics▪ 16: Write multiple registers▪ 23: Read/write multiple registers▪ 43: Read device identification
Broadcast messages	Supported by the following function codes: <ul style="list-style-type: none">▪ 06: Write single registers▪ 16: Write multiple registers▪ 23: Read/write multiple registers
Supported baud rate	<ul style="list-style-type: none">▪ 1 200 BAUD▪ 2 400 BAUD▪ 4 800 BAUD▪ 9 600 BAUD▪ 19 200 BAUD▪ 38 400 BAUD▪ 57 600 BAUD▪ 115 200 BAUD
Data transfer mode	<ul style="list-style-type: none">▪ ASCII▪ RTU
Data access	Each device parameter can be accessed via Modbus RS485.  For Modbus register information →  81

16.5 Power supply

Terminal assignment	→  24						
Pin assignment, device plug	→  25						
Supply voltage	<div>DC 24 V (nominal voltage: DC 20 to 30 V)</div> <div> <ul style="list-style-type: none">▪ The power unit must be tested to ensure that it meets safety requirements (e.g. PELV, SELV).▪ The supply voltage must not exceed a maximum short-circuit current of 50 A.</div>						
Power consumption	3.5 W						
Current consumption	<table><tr><th>Order code for "Output, input":</th><th>Maximum Current consumption</th></tr><tr><td>Option 4: Modbus RS485, 1 switch output (batch), 1 status input</td><td>175 mA + 500 mA ¹⁾</td></tr><tr><td>Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input</td><td>175 mA + 1000 mA ¹⁾</td></tr></table> <div>1) Additional 500 mA per switch output (batch) used.</div> <div> Switch-on current: max. 1 A (< 6 ms)</div>	Order code for "Output, input":	Maximum Current consumption	Option 4: Modbus RS485, 1 switch output (batch), 1 status input	175 mA + 500 mA ¹⁾	Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input	175 mA + 1000 mA ¹⁾
Order code for "Output, input":	Maximum Current consumption						
Option 4: Modbus RS485, 1 switch output (batch), 1 status input	175 mA + 500 mA ¹⁾						
Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input	175 mA + 1000 mA ¹⁾						
Power supply failure	<ul style="list-style-type: none">▪ Totalizers stop at the last value measured.▪ Depending on the device version, the configuration is retained in the device memory or in the pluggable data memory (HistoROM DAT).▪ Error messages (incl. total operated hours) are stored.						

Electrical connection →  27

Potential equalization

Requirements

No special measures for potential equalization are required.



For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

Cable specification

→  24


16.6 Performance characteristics

Reference operating conditions

Error limits based on ISO 11631

- Water with +15 to +45 °C (+59 to +113 °F) at 2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- Accuracy based on accredited calibration rigs that are traced to ISO 17025.



To obtain measured errors, use the *Applicator* sizing tool →  67

Maximum measured error

o.r. = of reading; 1 g/cm³ = 1 kg/l; T = medium temperature

Base accuracy

Mass flow and volume flow (liquids)

- ±0.15 % o.r.
- ±0.30 % ± [(zero point stability : measured value) · 100] % o.r.
- ±5 % ± [(zero point stability : measured value) · 100] % o.r.

Density (liquids)

- Reference conditions: ±0.0005 g/cm³
- Field density calibration: ±0.0005 g/cm³
(after field density calibration under process conditions)
- Standard density calibration: ±0.02 g/cm³
(valid over the entire temperature range and density range)

Temperature

±0.5 °C ± 0.005 · T °C (±0.9 °F ± 0.003 · (T – 32) °F)

Zero point stability

DN		Zero point stability	
[mm]	[in]	[kg/h]	[lb/min]
8	³ / ₈	0.20	0.007
15	¹ / ₂	0.65	0.024
25	1	1.80	0.066

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6 500	650	325	130	65	13
25	18 000	1 800	900	360	180	36

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
$\frac{3}{8}$	73.50	7.350	3.675	1.470	0.735	0.147
$\frac{1}{2}$	238.9	23.89	11.95	4.778	2.389	0.478
1	661.5	66.15	33.08	13.23	6.615	1.323

Repeatability

Base repeatability

Dosing time [s]	Standard deviation [%]
≥ 0.75	0.2
≥ 1.5	0.1
≥ 3.0	0.05

Density (liquids) $\pm 0.00025 \text{ g/cm}^3$ **Temperature** $\pm 0.25 \text{ }^\circ\text{C} \pm 0.0025 \cdot T \text{ }^\circ\text{C} (\pm 0.45 \text{ }^\circ\text{F} \pm 0.0015 \cdot (T-32) \text{ }^\circ\text{F})$

Response time

The response time depends on the configuration (damping).

Influence of ambient temperature

Influence of medium temperature

Mass flow

If there is a differential between the temperature during zero point adjustment and the process temperature, the typical measured error of the sensor is $\pm 0.0003 \text{ %}$ of the full scale value/ $^\circ\text{C}$ ($\pm 0.00015 \text{ %}$ of the full scale value/ $^\circ\text{F}$).

Temperature $\pm 0.005 \cdot T \text{ }^\circ\text{C} (\pm 0.005 \cdot (T - 32) \text{ }^\circ\text{F})$

Influence of medium pressure

A difference between the calibration pressure and process pressure does not affect accuracy.

16.7 Installation

"Mounting requirements"

16.8 Environment

Ambient temperature range

Temperature tables



Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature

Degree of protection

As standard: IP67, type 4X enclosure

Vibration resistance

- Oscillation, sinusoidal, following IEC 60068-2-6
 - 2 to 8.4 Hz, 3.5 mm peak
 - 8.4 to 2 000 Hz, 1 g peak
- Oscillation, broadband noise following IEC 60068-2-64
 - 10 to 200 Hz, 0.003 g²/Hz
 - 200 to 2 000 Hz, 0.001 g²/Hz
 - Total: 1.54 g rms
- Vibration, sinusoidal according to IEC 60068-2-6
 - 2 to 8.4 Hz, 7.5 mm peak
 - 8.4 to 2 000 Hz, 2 g peak
- Vibration broad-band random, according to IEC 60068-2-64
 - 10 to 200 Hz, 0.01 g²/Hz
 - 200 to 2 000 Hz, 0.003 g²/Hz
 - Total: 2.70 g rms

Shock resistance

Shock, half-sine according to IEC 60068-2-27
6 ms 30 g

Shock resistance

Shock due to rough handling following IEC 60068-2-31

Interior cleaning

- Cleaning in place (CIP)
- Sterilization in place (SIP)

Options

Oil- and grease-free version for wetted parts, without declaration
Order code for "Service", option HA



Observe the maximum fluid temperatures → 76









Electromagnetic compatibility (EMC)

As per IEC/EN 61326



Details are provided in the Declaration of Conformity.

16.9 Process

Medium temperature range	<p>Sensor -40 to +125 °C (-40 to +257 °F)</p> <p>Cleaning +150 °C (+302 °F) / 60 min for CIP and SIP processes</p> <p>Seals No internal seals</p>
Medium pressure range (nominal pressure)	max. 40 bar (580 psi), depending on process connection
Density	0 to 5 000 kg/m ³ (0 to 312 lb/cf)
Pressure-temperature ratings	 An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document
Sensor housing	<p>The sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.</p> <p>The housing does not have a pressure rating classification.</p> <p>Reference value for the pressure loading capacity of the sensor housing: 16 bar (232 psi)</p> <p> For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section</p>
Flow limit	<p>Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.</p> <p> For an overview of the full scale values for the measuring range, see the "Measuring range" section →  69</p> <ul style="list-style-type: none"> ■ The minimum recommended full scale value is approx. 1/20 of the maximum full scale value ■ In most applications, 20 to 50 % of the maximum full scale value can be considered ideal ■ A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s). <p> To calculate the flow limit, use the <i>Applicator</i> sizing tool →  67</p>
Pressure loss	 To calculate the pressure loss, use the <i>Applicator</i> sizing tool →  67
Heating	<p>NOTICE</p> <p>Electronics can overheat due to elevated ambient temperature!</p> <ul style="list-style-type: none"> ▶ Observe maximum permitted ambient temperature for the transmitter . ▶ Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE**Danger of overheating when heating**

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- ▶ Ensure that sufficient convection takes place at the transmitter neck.
- ▶ Ensure that a sufficiently large area of the transmitted neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

Using an electrical trace heating system

If heating is regulated via phase angle control or pulse packages, magnetic fields can affect the measured values (= for values that are greater than the values permitted by the EN standard (sine 30 A/m)).

For this reason, the sensor must be magnetically shielded: the sensor housing can be shielded with tin plates or electric sheets without a privileged direction (e.g. V330-35A).

The sheet must have the following properties:

- Relative magnetic permeability $\mu_r \geq 300$
- Plate thickness $d \geq 0.35 \text{ mm}$ ($d \geq 0.014 \text{ in}$)

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

16.10 Mechanical construction

Design, dimensions



For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.

Weight

Compact version

Weight in SI units

DN [mm]	Weight [kg]
8	3.5
15	4.0
25	4.5

Weight in US units

DN [in]	Weight [lbs]
$\frac{3}{8}$	7.7
$\frac{1}{2}$	8.8
1	9.9

Materials

Transmitter housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4308 (304)

Device plugs

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none"> ■ Socket: Stainless steel, 1.4404 (316L) ■ Contact housing: Polyamide ■ Contacts: Gold-plated brass

Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tubes

Stainless steel, 1.4539 (904L)

Process connections

- Flanges according to EN (DIN):
Stainless steel, 1.4404 (316/316L)
- Flanges according to DIN 32676:
Stainless steel, 1.4435 (316L)
- All other process connections:
Stainless steel, 1.4404 (316L)



List of all available process connections

Surface quality (parts in contact with medium)

- $Ra_{max} = 0.4 \mu m$ (16 μin)
- $Ra_{max} = 0.8 \mu m$ (32 μin)

Seals

Welded process connections without internal seals

Process connections

- Fixed flange connections:
 - EN 1092-1 (DIN 2512N) flange
- Clamp connections:
 - Tri-Clamp (OD tubes), DIN 11866 series C
 - DIN 32676 clamp, DIN 11866 series A
- Thread:
 - DIN 11851 thread, DIN 11866 series A
 - SMS 1145 thread
 - ISO 2853 thread, ISO 2037
 - DIN 11864-1 Form A thread, DIN 11866 series A



Process connection materials → 78

Surface roughness

All data relate to parts in contact with fluid. The following surface roughness quality can be ordered.

16.11 Operability


Local operation

This device cannot be operated locally using a display or operating elements.

Remote operation**Using service adapter and Commubox FXA291**

Operation and configuration can be performed using the Endress+Hauser FieldCare or DeviceCare service and configuration software.

The device is connected to the USB port of the computer via the service adapter and Commubox FXA291.




- 1 Supply voltage 24 V DC
- 2 Service adapter
- 3 Commubox FXA291
- 4 Measuring device
- 5 Computer with "FieldCare" or "DeviceCare" operating tool



The service adapter, cable and Commubox FXA291 are not included in the delivery. These components can be ordered as accessories → 67.

16.12 Certificates and approvals

 Currently available certificates and approvals can be called up via the product configurator.

CE mark	<p>The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
RCM-Tick mark	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.</p>
Sanitary compatibility	<ul style="list-style-type: none"> ■ 3-A approval Only devices with the order code for "Additional approval", option LP "3A" have 3-A approval. ■ EHEDG-tested Only devices with the order code for "Additional approval", option LT "EHEDG" have been tested and meet the requirements of the EHEDG. To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy Cleanable Pipe Couplings and Process Connections" (www.ehedg.org).
Pressure Equipment Directive	<ul style="list-style-type: none"> ■ With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU. ■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU.
Other standards and guidelines	<ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosures (IP code) ■ EN 61010-1 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use ■ IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). ■ EN 61000-4-3 (IEC 1000-4-3) Operating behavior A with shielded connecting cable possible (shielding connected as short as possible on both sides), otherwise operating behavior B ■ NAMUR NE 21 Electromagnetic compatibility of industrial process and laboratory control equipment ■ CAN/CSA C22.2 No. 61010-1-12 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use, Part 1: General Requirements

16.13 Accessories



Overview of accessories available for order → 67

16.14 Supplementary documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Dosimass	KA00043D

Description of device parameters

Measuring device	Documentation code
	Modbus RS485 option 4 and 5
Dosimass	GP01047D

Technical Information

Measuring device	Documentation code
Dosimass	TI00065D

Supplementary device-dependent documentation

Safety Instructions

Contents	Documentation code
ATEX Ex nA	XA00079D
cCSAus	FES0232

Index

0 ... 9	
3-A approval	80
A	
About this document	5
Accuracy	73
Adapting the diagnostic behavior	57
Ambient temperature	
Influence	74
Ambient temperature range	19
Application	69
Approvals	80
Auto scan buffer	
see Modbus RS485 Modbus data map	
C	
CE mark	9, 80
Certificates	80
Check	
Connection	28
Installation	23
Checklist	
Post-connection check	28
Post-installation check	23
Cleaning	
Cleaning in place (CIP)	64
Exterior cleaning	64
Interior cleaning	64
Sterilization in place (SIP)	64
Cleaning in place (CIP)	75
Commissioning	37
Configuring error response mode, Modbus RS485	56
Connecting cable	24
Connecting the measuring device	27
Grounding	27
Connecting the transmitter	27
Connection	
see Electrical connection	
Connection conditions	24
Current consumption	72
D	
Declaration of Conformity	9
Degree of protection	28, 75
Density	76
Designated use	8
Device components	11
Device description files	32
Device documentation	
Supplementary documentation	7
Device locking, status	48
Device name	
Sensor	13
DeviceCare	31
Device description file	32
Diagnostic information	
Communication interface	56
Design, description	55
DeviceCare	54
FieldCare	54
Overview	57
Remedial measures	57
Diagnostic list	60
Display values	
For locking status	48
Disposal	65
Document	
Function	5
Symbols used	5
Document function	5
Down pipe	16
E	
EHDEG-certified	80
Electrical connection	
Degree of protection	28
Measuring device	24
Electromagnetic compatibility	75
Endress+Hauser services	
Maintenance	64
Repair	65
Environment	
Shock resistance	75
Storage temperature	75
Vibration resistance	75
Error messages	
see Diagnostic messages	
Event history	60
Events list	60
Ex approval	80
Extended order code	
Sensor	13
Exterior cleaning	64
F	
FDA	80
Field of application	
Residual risks	9
FieldCare	30
Device description file	32
Establishing a connection	30
Function	30
User interface	31
Filtering the event logbook	60
Firmware	
Release date	32
Version	32
Firmware history	63
Flow direction	17, 23
Flow limit	76
Food Contact Materials Regulation	80

Function check	37	Menu	
Function codes	32	Diagnostics	59
Functions		Operation	48
see Parameter		Setup	37, 38
G		Modbus RS485	
Galvanic isolation	71	Configuring error response mode	56
I		Diagnostic information	56
Identifying the measuring device	12	Function codes	32
Incoming acceptance	12	Modbus data map	35
Influence		Read access	32
Ambient temperature	74	Reading out data	36
Medium pressure	74	Register addresses	33
Medium temperature	74	Register information	33
Inlet runs	18	Response time	33
Input	69	Scan list	35
Inspection		Write access	32
Received goods	12	Mounting	16
Installation		Mounting dimensions	
Mounting	22	see Installation dimensions	
Installation conditions		Mounting location	16
Down pipe	16	Mounting preparations	22
Inlet and outlet runs	18	Mounting tools	22
Installation dimensions	19	N	
Mounting location	16	Nameplate	
Orientation	17	Sensor	13
Sensor heating	20, 76	O	
System pressure	19	Operable flow range	70
Thermal insulation	19	Operation	48
Vibrations	20, 77	Operation options	29
Installation dimensions	19	Operational safety	9
Interior cleaning	64, 75	Order code	13
L		Orientation	
Local operation	79	Filling systems	18
Low flow cut off	71	Orientation (vertical, horizontal)	17
M		Outlet runs	18
Maintenance tasks	64	Output	70
Manufacturing date	13	Output signal	70
Materials	78	P	
Maximum measured error	73	Packaging disposal	15
Measured values		Parameter settings	
see Process variables		Advanced setup (Submenu)	44
Measuring and test equipment	64	Batch output (Submenu)	40
Measuring device	32	Batching (Submenu)	51
Disposal	66	Communication (Submenu)	41
Mounting the sensor	23	Device information (Submenu)	61
Preparing for mounting	22	Diagnostics (Menu)	59
Removing	65	For the status input	39
structure	11	Input values (Submenu)	50
Switching on	37	Low flow cut off (Submenu)	42
Measuring principle	69	Operation (Menu)	48
Measuring range, recommended	76	Partially filled pipe detection (Submenu)	43
Measuring system	69	Process variables (Submenu)	48
Medium pressure		Sensor adjustment (Submenu)	44
Influence	74	Settings batch profile 1 to n (Submenu)	40
Medium temperature		Setup (Menu)	38
Influence	74	Simulation (Submenu)	46

Status input (Submenu)	39	Shock resistance	75
System units (Submenu)	38	Signal on alarm	71
Totalizer (Submenu)	49	Spare parts	65
Totalizer 1 to n (Submenu)	45	Standards and guidelines	80
Totalizer handling (Submenu)	50	Status signals	55
Performance characteristics	73	Sterilization in place (SIP)	75
Pin assignment, device plug	25	Storage conditions	15
Post-connection check (checklist)	28	Storage temperature	15
Post-installation check	37	Storage temperature range	75
Post-installation check (checklist)	23	structure	
Potential equalization	73	Measuring device	11
Power consumption	72	Submenu	
Power supply failure	72	Advanced setup	44
Pressure Equipment Directive	80	Batch output	40
Pressure loss	76	Batching	51
Pressure range		Communication	41
Medium pressure	76	Device information	61
Pressure-temperature ratings	76	Events list	60
Process connections	79	Input values	50
Process variables		Low flow cut off	42
Calculated	69	Partially filled pipe detection	43
Measured	69	Process variables	48
Product safety	9	Sensor adjustment	44
R		Settings batch profile 1 to n	40
RCM-Tick mark	80	Simulation	46
Reading measured values	48	Status input	39
Reading out diagnostic information, Modbus RS485	56	System units	38
Recalibration	64	Totalizer	49
Reference operating conditions	73	Totalizer 1 to n	45
Registered trademarks	7	Totalizer handling	50
Remote operation	79	Supplementary documentation	81
Repair	65	Supply unit	
Repeatability	74	Requirements	27
Replacement		Supply voltage	27, 72
Device	65	Surface roughness	79
Wear parts	65	Switch output	70
Requirements for personnel	8	System design	
Response time	74	Measuring system	69
Return	65	see Measuring device design	
S		System integration	32
Safety	8	System pressure	19
Sanitary compatibility	80	T	
Seals		Technical data, overview	69
Medium temperature range	76	Temperature range	
Sensor		Medium temperature	76
Medium temperature range	76	Storage temperature	15
Mounting	23	Terminal assignment	24
Sensor heating	20, 76	Thermal insulation	19
Sensor housing	76	Tools	
Serial number	13	Installation	22
Settings		Transport	15
Communication interface	41	Transporting the measuring device	15
Device reset	61	Troubleshooting	
Resetting the totalizer	50	General	54
Status input	39	U	
Tag name	38	Use of the measuring device	
Totalizer reset	50	Borderline cases	8

Incorrect use	8
see Designated use	
User interface	
Current diagnostic event	59
Previous diagnostic event	59
V	
Vibration resistance	75
Vibrations	20, 77
W	
W@M	64
W@M Device Viewer	12, 65
Weight	
SI units	78
Transport (notes)	15
US units	78
Workplace safety	9

www.addresses.endress.com
