

Description of Device Parameters

Proline Prosonic Flow 500

HART

Ultrasonic time-of-flight flowmeter




Table of contents

1 About this document	4	3.8 "Diagnostics" submenu	199
1.1 Document function	4	3.8.1 "Diagnostic list" submenu	202
1.2 Target group	4	3.8.2 "Event logbook" submenu	206
1.3 Using this document	4	3.8.3 "Device info" submenu	208
1.3.1 Information on the document structure	4	3.8.4 "Main elec.+I/O1" submenu	212
1.3.2 Structure of a parameter description	6	3.8.5 "Sens. electronic" submenu	213
1.4 Symbols used	6	3.8.6 "I/O module 1" submenu	214
1.4.1 Symbols for certain types of information	6	3.8.7 "I/O module 2" submenu	215
1.4.2 Symbols in graphics	7	3.8.8 "I/O module 3" submenu	216
1.5 Documentation	7	3.8.9 "I/O module 4" submenu	218
1.5.1 Standard documentation	7	3.8.10 "Display module" submenu	219
1.5.2 Supplementary device-dependent documentation	7	3.8.11 "Data logging" submenu	220
2 Overview of the Expert operating menu	8	3.8.12 "Heartbeat" submenu	228
3 Description of Device Parameters ...	11	3.8.13 "Simulation" submenu	228
3.1 "System" submenu	13	4 Country-specific factory settings ..	239
3.1.1 "Display" submenu	14	4.1 SI units	239
3.1.2 "Configuration backup" submenu	27	4.1.1 System units	239
3.1.3 "Diagn. handling" submenu	30	4.1.2 Full scale values	239
3.1.4 "Administration" submenu	41	4.1.3 Output current span	239
3.2 "Sensor" submenu	46	4.1.4 Pulse value	240
3.2.1 "Measured val." submenu	46	4.1.5 On value low flow cut off	240
3.2.2 "System units" submenu	62	4.2 US units	240
3.2.3 "Process param." submenu	74	4.2.1 System units	240
3.2.4 "Measurement mode" submenu	78	4.2.2 Full scale values	241
3.2.5 "External comp." submenu	85	4.2.3 Output current span	241
3.2.6 "Sensor adjustm." submenu	87	4.2.4 Pulse value	241
3.2.7 "Calibration" submenu	97	4.2.5 On value low flow cut off	241
3.3 "I/O configuration" submenu	99	5 Explanation of abbreviated units ..	243
3.4 "Input" submenu	101	5.1 SI units	243
3.4.1 "Current input 1 to n" submenu	101	5.2 US units	244
3.4.2 "Status input 1 to n" submenu	104	5.3 Imperial units	244
3.5 "Output" submenu	106	Index	246
3.5.1 "Current output 1 to n" submenu	107		
3.5.2 "Pulse/frequency/switch output 1 to n" submenu	119		
3.5.3 "Relay output 1 to n" submenu	139		
3.5.4 "Double pulse output" submenu	145		
3.6 "Communication" submenu	150		
3.6.1 "HART input" submenu	150		
3.6.2 "HART output" submenu	156		
3.6.3 "Web server" submenu	173		
3.6.4 "Diag. config." submenu	176		
3.6.5 "WLAN settings" submenu	186		
3.7 "Application" submenu	192		
3.7.1 "Totalizer 1 to n" submenu	193		
3.7.2 "Inventory count." submenu	198		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions
- Operating concept of the operating menus: Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
Navigation path to the parameter via the operating tool
The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Prosonic Flow G 500	BA01836D

1.5.2 Supplementary device-dependent documentation

Special documentation

Content	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Advanced gas analysis	SD02351D
Functional Safety Manual	SD02308D
Heartbeat Technology	SD02304D
Web server	SD02311D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access status (0005)	→ 13
Ent. access code (0003)	→ 13
▶ System	→ 13
▶ Display	→ 14
▶ Config. backup	→ 27
▶ Diagn. handling	→ 30
▶ Administration	→ 41
▶ Sensor	→ 46
▶ Measured val.	→ 46
▶ System units	→ 62
▶ Process param.	→ 74
▶ Measurement mode	→ 78
▶ External comp.	→ 85
▶ Sensor adjustm.	→ 87
▶ Calibration	→ 97
▶ I/O config.	→ 99
I/O 1 to n terminals (3902–1 to n)	→ 99
I/O 1 to n info (3906–1 to n)	→ 99
I/O 1 to n type (3901–1 to n)	→ 100

Apply I/O config (3907)	→ 100
Alteration code (2762)	→ 101
▶ Input	→ 101
▶ Current input 1 to n	→ 101
▶ Status input 1 to n	→ 104
▶ Output	→ 106
▶ Curr.output 1 to n	→ 107
▶ PFS output 1 to n	→ 119
▶ Relay output 1 to n	→ 139
▶ Double pulse out	→ 145
▶ Communication	→ 150
▶ HART input	→ 150
▶ HART output	→ 156
▶ Web server	→ 173
▶ Diag. config.	→ 176
▶ WLAN settings	→ 186
▶ Application	→ 192
Reset all tot. (2806)	→ 193
▶ Totalizer 1 to n	→ 193
▶ Diagnostics	→ 199
Actual diagnos. (0691)	→ 199
Prev.diagnostics (0690)	→ 200
Time fr. restart (0653)	→ 201
Operating time (0652)	→ 201
▶ Diagnostic list	→ 202

▶ Event logbook	→ 206
▶ Device info	→ 208
▶ Main elec.+I/O1	→ 212
▶ Sens. electronic	→ 213
▶ I/O module 2	→ 215
▶ I/O module 3	→ 216
▶ I/O module 4	→ 218
▶ Display module	→ 219
▶ Data logging	→ 220
▶ Heartbeat	→ 228
▶ Simulation	→ 228

3 Description of Device Parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Locking status (0004)	→ 12
Access status (0005)	→ 13
Ent. access code (0003)	→ 13
Direct access (0106)	→ 11
▶ System	→ 13
▶ Sensor	→ 46
▶ I/O config.	→ 99
▶ Input	→ 101
▶ Output	→ 106
▶ Communication	→ 150
▶ Application	→ 192
▶ Diagnostics	→ 199

Direct access



Navigation

Expert → Direct access (0106)

Description

Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.


User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
Example: Enter 00914 → **Assign variable** parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign variable** parameter

Locking status

Navigation

  Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- SIL locked
- CT act.-def.par.
- CT act.-all par.
- Temp. locked

Additional information

Display

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Selection

Options	Description
None	The access status displayed in the Access status parameter (→ 13) applies . Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) .
SIL locked (priority 2)	The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).
Temp. locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.


Access status

Navigation	 Expert → Access status (0005)
Description	Displays the access authorization to the parameters via the local display, Web browser or operating tool.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Ent. access code parameter (→  13).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>Display</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device</p>

Ent. access code

Navigation	 Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

<i>Navigation</i>	 Expert → System
	
▶ System	
▶ Display	→  14
▶ Config. backup	→  27
▶ Diagn. handling	→  30
▶ Administration	→  41

3.1.1 "Display" submenu

Navigation

Expert → System → Display

Display language (0104)	→ 15
Format display (0098)	→ 15
Value 1 display (0107)	→ 18
0% bargraph 1 (0123)	→ 19
100% bargraph 1 (0125)	→ 19
Decimal places 1 (0095)	→ 19
Value 2 display (0108)	→ 20
Decimal places 2 (0117)	→ 21
Value 3 display (0110)	→ 21
0% bargraph 3 (0124)	→ 22
100% bargraph 3 (0126)	→ 22
Decimal places 3 (0118)	→ 23
Value 4 display (0109)	→ 23
Decimal places 4 (0119)	→ 24
Display interval (0096)	→ 24
Display damping (0094)	→ 25
Header (0097)	→ 25
Header text (0112)	→ 26
Separator (0101)	→ 26
Contrast display (0105)	→ 27
Backlight (0111)	→ 27

Display language

Navigation  Expert → System → Display → Display language (0104)

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык(Ru)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية(Ara)
- Bahasa Indonesia
- ภาษาไทย (Thai)
- tiếng Việt (Viet)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display (0098)

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max.
- Bagr. + 1 value
- 2 values
- Val. large+2val.
- 4 values

Factory setting 1 value, max.

Additional information*Description*


The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 24).


Possible measured values shown on the local display:

"1 value, max." option




A0016529

"Bagr. + 1 value" option



A0016530


"2 values" option



A0016531




"Val. large+2val." option



A0016532

"4 values" option



A0016533

Value 1 display**Navigation**

Expert → System → Display → Value 1 display (0107)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

- Volume flow *
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Curr.output 1 *
- Curr.output 2 *
- Curr.output 3 *
- Curr.output 4 *

Factory setting

Volume flow

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.

The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

* Visibility depends on order options or device settings

0% bargraph 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-dependent
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 62).

100% bargraph 1

Navigation	Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 239
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 62).

Decimal places 1

Navigation	Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is specified in the Value 1 display parameter (→ 18).

Description Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display



Navigation  Expert → System → Display → Value 2 display (0108)

Prerequisite A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection

- None
- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Curr.output 1 *
- Curr.output 2 *
- Curr.output 3 *
- Curr.output 4 *

* Visibility depends on order options or device settings

Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 62).</p>

Decimal places 2



Navigation	  Expert → System → Display → Decimal places 2 (0117)
Prerequisite	A measured value is specified in the Value 2 display parameter (→ 20).
Description	Use this function to select the number of decimal places for measured value 2.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 3 display



Navigation	  Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	For the picklist, see the Value 2 display parameter (→ 20)
Factory setting	None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

0% bargraph 3**Navigation**

  Expert → System → Display → 0% bargraph 3 (0124)

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

Country-dependent

Additional information*Description*

 The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

100% bargraph 3**Navigation**

  Expert → System → Display → 100% bargraph 3 (0126)

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

Decimal places 3**Navigation**

Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 21).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display**Navigation**

Expert → System → Display → Value 4 display (0109)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 2 display** parameter (→ 20)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

Decimal places 4**Navigation**

 Expert → System → Display → Decimal places 4 (0119)

Prerequisite

A measured value is specified in the **Value 4 display** parameter (→ 23).

Description

Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval**Navigation**

 Expert → System → Display → Display interval (0096)

Prerequisite

A local display is provided.

Description

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry

1 to 10 s

Factory setting

5 s

Additional information*Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

Display damping**Navigation**

Expert → System → Display → Display damping (0094)

Prerequisite

A local display is provided.

Description

Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

Header**Navigation**

Expert → System → Display → Header (0097)

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection

- Device tag
- Free text


Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.

1) proportional transmission behavior with first order delay



A0029422

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 209).
- Free text
Is defined in the **Header text** parameter (→ 26).

Header text



Navigation

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 25), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.

User entry


Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information

Description

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator



Navigation

Expert → System → Display → Separator (0101)

Prerequisite

A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation  Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Backlight

Navigation  Expert → System → Display → Backlight (0111)

Prerequisite One of the following conditions is met:

- Order code for "Display; operation", option F "4-line, illum.; touch control"
- Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN"

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

3.1.2 "Configuration backup" submenu

Navigation  Expert → System → Config. backup

▶ Config. backup		
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">Operating time (0652)</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">Last backup (2757)</div>	→  28	

Config. managem. (2758)	→ 28
Backup state (2759)	→ 29
Compar. result (2760)	→ 29

Operating time

Navigation Expert → System → Config. backup → Operating time (0652)

Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

Last backup

Navigation Expert → System → Config. backup → Last backup (2757)

Description Displays the time since a backup copy of the data was last saved to the device memory.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Config. managem.



Navigation Expert → System → Config. backup → Config. managem. (2758)

Description Use this function to select an action to save the data to the device memory.

Selection

- Cancel
- Execute backup
- Restore *
- Compare *
- Clear backup

Factory setting

Cancel

* Visibility depends on order options or device settings

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device. The following message appears on local display: Backup active, please wait!
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device. The following message appears on local display: Restore active! Do not interrupt power supply!
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup. The following message appears on local display: Comparing files The result can be viewed in Compar. result parameter.
Clear backup	The backup copy of the device configuration is deleted from the memory of the device. The following message appears on local display: Deleting file

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state**Navigation**
 Expert → System → Config. backup → Backup state (2759)
Description

Displays the status of the data backup process.

User interface

- None
- Backup in progr.
- Restore in progr
- Delete in progr.
- Comp. in progr.
- Restoring failed
- Backup failed

Factory setting

None

Compar. result**Navigation**
 Expert → System → Config. backup → Compar. result (2760)
Description

Displays the last result of the comparison of the data records in the device memory and in the HistoROM.

User interface

- Set. identical
- Set. not ident.
- No backup

- Backup corrupt
- Check not done
- Dataset incomp.

Factory setting Check not done

Additional information *Description*

i The comparison is started via the **Compare** option in the **Config. managem.** parameter (→ 28).

Selection

Options	Description
Set. identical	The current device configuration of the HistoROM is identical to the backup copy in the device memory. If the transmitter configuration of another device has been transmitted to the device via HistoROM in the Config. managem. parameter, the current device configuration of the HistoROM is only partially identical to the backup copy in the device memory: The settings for the transmitter are not identical.
Set. not ident.	The current device configuration of the HistoROM is not identical to the backup copy in the device memory.
No backup	There is no backup copy of the device configuration of the HistoROM in the device memory.
Backup corrupt	The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the device memory.
Check not done	The device configuration of the HistoROM has not yet been compared to the backup copy in the device memory.
Dataset incomp.	The backup copy in the device memory is not compatible with the device.


HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagn. handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay**Navigation**

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- △S452 Calc. error
- 832 Electronic temp.
- 833 Electronic temp.
- 834 Process temp.
- 835 Process temp.
- △S836 Process pressure
- △S837 Process pressure
- △S840 Sensor range
- △S870 Meas. inaccuracy
- △S930 Process fluid
- △S931 Process fluid

"Diagn. behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagn. behavior** submenu (→ 31).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 206) (Event list submenu (→ 207)) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.



For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Navigation Expert → System → Diagn. handling → Diagn. behavior

► Diagn. behavior	
Diagnostic no. 124 (0774)	→  33
Diagnostic no. 125 (0775)	→  33
Diagnostic no. 160 (0776)	→  33
Diagnostic no. 302 (0742)	→  34
Diagnostic no. 441 (0657)	→  34
Diagnostic no. 442 (0658)	→  34
Diagnostic no. 443 (0659)	→  35
Diagnostic no. 444 (0740)	→  35
Diagnostic no. 452 (0713)	→  35
Diagnostic no. 543 (0643)	→  36
Diagnostic no. 832 (0675)	→  36
Diagnostic no. 833 (0676)	→  37
Diagnostic no. 834 (0677)	→  37
Diagnostic no. 835 (0678)	→  37
Diagnostic no. 837 (0714)	→  38
Diagnostic no. 840 (0680)	→  38
Diagnostic no. 842 (0638)	→  38
Diagnostic no. 870 (0726)	→  39
Diagnostic no. 881 (0724)	→  39
Diagnostic no. 930 (0639)	→  40
Diagnostic no. 931 (0640)	→  40
Diagnostic no. 953 (0636)	→  40
Diagnostic no. 954 (0637)	→  41

Diagnostic no. 124 (Rel.sig.strength)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 124 (0774)
Description	Option for changing the diagnostic behavior of the diagnostic message 124 Rel.sig.strength .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 31

Diagnostic no. 125 (Rel. sound vel.)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 125 (0775)
Description	Option for changing the diagnostic behavior of the diagnostic message 125 Rel. sound vel. .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 31

Diagnostic no. 160 (Signal path off)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)
Description	Option for changing the diagnostic behavior of the diagnostic message 160 Signal path off .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 31

Diagnostic no. 302 (Verific. active)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0742)
Description	Option for changing the diagnostic behavior of the diagnostic message 302 Verific. active .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 31

Diagnostic no. 441 (Curr.output 1 to n)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)
Description	Option for changing the diagnostic behavior of the diagnostic message 441 Curr.output 1 to n .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 31

Diagnostic no. 442 (Freq. output 1 to n)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Option for changing the diagnostic behavior of the diagnostic message 442 Freq. output 1 to n .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 443 (Pulse output)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Option for changing the diagnostic behavior of the diagnostic message **443 Pulse output**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Selection



Detailed description of the options available for selection: → [31](#)

Diagnostic no. 444 (Current input 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 444 (0740)

Prerequisite

The device has one current input.

Description

Option for changing the diagnostic behavior of the diagnostic message **444 Current input 1 to n**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 452 (Calc. error)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 452 (0713)

Description

Option for changing the diagnostic behavior of the diagnostic message **452 Calc. error**.

Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 31

Diagnostic no. 543 (Double pulse out)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 543 (0643)
Description	Option for changing the diagnostic behavior of the diagnostic message 543 Double pulse out .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 31

Diagnostic no. 832 (Electronic temp.)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)
Description	Option for changing the diagnostic behavior of the diagnostic message 832 Electronic temp. .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 31

Diagnostic no. 833 (Electronic temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
Description	Option for changing the diagnostic behavior of the diagnostic message 833 Electronic temp..
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 31

Diagnostic no. 834 (Process temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)
Description	Option for changing the diagnostic behavior of the diagnostic message 834 Process temp..
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i> Detailed description of the options available for selection: → 31

Diagnostic no. 835 (Process temp.)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)
Description	Option for changing the diagnostic behavior of the diagnostic message 835 Process temp..
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook only
Factory setting	Warning

Additional information*Selection*

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 837 (Process pressure)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 837 (0714)

Description

Option for changing the diagnostic behavior of the diagnostic message **837 Process pressure**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 841 (Sensor range)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 840 (0680)

Description

Option for changing the diagnostic behavior of the diagnostic message **841 Sensor range**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 842 (Process limit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)

Description

Option for changing the diagnostic behavior of the diagnostic message **△S842 Process limit**.

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
------------------	--

Factory setting	Off
------------------------	-----

Additional information	 Detailed description of the options available for selection: → 31
-------------------------------	---

Diagnostic no. 870 (Meas. inaccuracy)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 870 (0726)
Description	Option for changing the diagnostic behavior of the diagnostic message 870 Meas. inaccuracy .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	<i>Selection</i>  Detailed description of the options available for selection: → 31

Diagnostic no. 881 (Sen.sig. path 1 to n)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 881 (0724)
Description	Option for changing the diagnostic behavior of the diagnostic message 881 Sen.sig. path 1 to n .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 31

Diagnostic no. 930 (Process fluid)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 930 (0639)

Description

Option for changing the diagnostic behavior of the diagnostic message **△S930 Process fluid**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Alarm

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 931 (Process fluid)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 931 (0640)

Description

Option for changing the diagnostic behavior of the diagnostic message **△S931 Process fluid**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Alarm

Additional information

Detailed description of the options available for selection: → [31](#)

Diagnostic no. 953 (Asy.noise path 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 953 (0636)

Description

Option for changing the diagnostic behavior of the diagnostic message **△M953 Asy.noise path 1 to n**.

Selection

- Off
- Alarm
- Warning
- Logbook only

Factory setting

Warning

Additional information


Detailed description of the options available for selection: → [31](#)

Diagnostic no. 954 (Sound v. dev. hi)

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 954 (0637)
Description	Option for changing the diagnostic behavior of the diagnostic message △S954 Sound v. dev. hi.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 31

3.1.4 "Administration" submenu*Navigation*


Expert → System → Administration

**"Def. access code" wizard**

The **Def. access code** wizard (→ [41](#)) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Def. access code** parameter can be found directly in the **Administration** submenu. There is no **Confirm code** parameter if the device is operated via the operating tool.

Navigation Expert → System → Administration → Def. access code



Def. access code



Navigation Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the device configuration against any inadvertent modifications via the local display, Web browser, FieldCare or DeviceCare (via CDI-RJ45 service interface).

User entry

Max. 16-digit character string comprising numbers, letters and special characters

Additional information

Description

The write protection affects all parameters in the document marked with the symbol. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Ent. access code** parameter (→ 13).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm code



Navigation Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

Max. 16-digit character string comprising numbers, letters and special characters

"Reset access code" submenu**Navigation**  Expert → System → Administration → Reset acc. code**► Reset acc. code**

Operating time (0652)

→  43

Reset acc. code (0024)

→  43

Operating time

Navigation  Expert → System → Administration → Reset acc. code → Operating time (0652)**Description**

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

Reset acc. code

Navigation  Expert → System → Administration → Reset acc. code → Reset acc. code (0024)**Description**

Use this function to enter a reset code to reset the user-specific release code to the factory setting.

User entry

Character string comprising numbers, letters and special characters

Factory setting

0x00

Additional information*Description* For a reset code, contact your Endress+Hauser service organization.*User entry*

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via interface CDI RJ45)
- Fieldbus

Additional parameters in the "Administration" submenu

Device reset



Navigation

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery set.
- Restart device

Factory setting

Cancel

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery set.	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Rest.S-DATBackup	Restore the data that are saved on the S-DAT. The data record is restored from the electronics memory to the S-DAT. This option is displayed only in an alarm condition.

Activate SW opt.



Navigation

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information

Description

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ Once the activation code has been entered, check if the new software option is displayed in the **SW option overv.** parameter (→  45).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- ▶ If the code entered is incorrect or invalid, enter the old activation code .
- ▶ Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

-  The software options currently enabled are displayed in the **SW option overv.** parameter (→  45).

Web browser

-  Once a software option has been activated, the page must be loaded again in the Web browser.

SW option overv.

Navigation

 Expert → System → Administration → SW option overv. (0015)

Description

Displays all the software options that are enabled in the device.

User interface

- Extend. HistoROM
- SIL
- HBT Monitoring
- HBT Verification
- Ad. gas analysis

Additional information**Description**

Displays all the options that are available if ordered by the customer.

"Extend. HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"SIL" option

Order code for "Additional approval", option LA "SIL"

"HBT Verification" option and "HBT Monitoring" option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

"Ad. gas analysis" option

Order code for "Application package", option EF "Advanced gas analysis"

3.2 "Sensor" submenu

Navigation

Expert → Sensor

► Sensor	
► Measured val.	→ 46
► System units	→ 62
► Process param.	→ 74
► Measurement mode	→ 78
► External comp.	→ 85
► Sensor adjustm.	→ 87
► Calibration	→ 97

3.2.1 "Measured val." submenu

Navigation

Expert → Sensor → Measured val.

► Measured val.	
► Process variab.	→ 47
► System values	→ 52

▶ Totalizer	→ 54
▶ Input values	→ 56
▶ Output values	→ 58

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

▶ Process variab.	
Volume flow (1838)	→ 47
Correct.vol.flow (1857)	→ 50
Mass flow (1847)	→ 48
Flow velocity (1852)	→ 49
Sound velocity (1850)	→ 48
Temperature (1853)	→ 49
Pressure (1872)	→ 48
Dry CH ₄ in % (1863)	→ 50
Molar mass (1864)	→ 51
Density (1865)	→ 51
Dynam. viscosity (1887)	→ 52
Calorific value (1893)	→ 52
Wobbe index (1854)	→ 50
Energy flow (1851)	→ 49

Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description

Displays the volume flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Volume flow unit** parameter (→ [63](#))

Mass flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description Displays the mass flow currently calculated.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Mass flow unit** parameter (→ [67](#))

Sound velocity

Navigation  Expert → Sensor → Measured val. → Process variab. → Sound velocity (1850)

Description Displays the sound velocity that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Velocity unit** parameter (→ [68](#))

Pressure

Navigation  Expert → Sensor → Measured val. → Process variab. → Pressure (1872)

Prerequisite For the following order code:

"Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→ [45](#)).

Description Displays the pressure that is currently measured.

User interface Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ [69](#))

Energy flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Energy flow (1851)

Description

Displays the energy flow that is currently calculated.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Energy flow unit** parameter (→ [72](#))

Flow velocity

Navigation

Expert → Sensor → Measured val. → Process variab. → Flow velocity (1852)

Description

Displays the flow velocity that is currently measured.

User interface

Signed floating-point number

Temperature

Navigation

Expert → Sensor → Measured val. → Process variab. → Temperature (1853)

Prerequisite

For the following order codes:

- "Measuring tube; Transducer; Sensor version", option AB "316L; Titanium Gr. 2; temperature measurement integrated"
- "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated"



The software options currently enabled are displayed in the **SW option overv.** parameter (→ [45](#)).

Description

Displays the medium temperature that is currently measured.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ [69](#))

Wobbe index

Navigation  Expert → Sensor → Measured val. → Process variab. → Wobbe index (1854)

Prerequisite For the following order code:
"Application package", option EF "Advanced gas analysis"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→  45).

Description Displays the Wobbe index that is currently calculated.

User interface Signed floating-point number

Additional information *Description*

The Wobbe index compares the combustion energy output of different composition fuel gases in an appliance. If two fuels have identical Wobbe indices then for given pressure and valve settings the energy output will also be identical.

The Wobbe index is the ratio of the calorific value (heating value) and the square root of the gases' relative density (often called specific gravity). The relative density is the ratio of the density of the gas and the density of dry air under the same pressure and temperature conditions. This index refers to the gross calorific value (sometimes called gross energy or upper heating value or higher calorific value) or net calorific value (sometimes called net energy or lower heating value or lower calorific value).

Dependency

 The unit is taken from the **Cal. value unit** parameter (→  71)

Correct.vol.flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1857)

Description Displays the corrected volume flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Cor.volflow unit** parameter (→  66)

Dry CH₄ in %

Navigation  Expert → Sensor → Measured val. → Process variab. → Dry CH₄ in % (1863)

Prerequisite For the following order code:
"Application package", option EF "Advanced gas analysis"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→  45).

Description Displays the methane content in Mol% that is currently calculated.

User interface Signed floating-point number

Additional information *Dependency*



The unit is taken from the **Velocity unit** parameter (→ 68)

Molar mass

Navigation Expert → Sensor → Measured val. → Process variab. → Molar mass (1864)

Prerequisite For the following order code:
"Application package", option EF "Advanced gas analysis"



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 45).

Description Displays the molar mass in g/mol that is currently calculated.

User interface Signed floating-point number

Density

Navigation Expert → Sensor → Measured val. → Process variab. → Density (1865)

Prerequisite For the following order code:
"Application package", option EF "Advanced gas analysis"



The software options currently enabled are displayed in the **SW option overv.** parameter (→ 45).

Description Displays the density that is currently calculated.

Dependency

The unit is taken from the **Density unit** parameter (→ 70).

User interface Signed floating-point number

Additional information *Dependency*



The unit is taken from the **Density unit** parameter (→ 70)

Dynam. viscosity

Navigation

Expert → Sensor → Measured val. → Process variab. → Dynam. viscosity (1887)

Prerequisite

For the following order code:
"Application package", option EF "Advanced gas analysis"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→ [45](#)).

Description

Displays the dynamic viscosity that is currently calculated.

User interface

Signed floating-point number

Additional information

Dependency

 The unit is taken from the **Dyn. visc. unit** parameter (→ [71](#)).

Calorific value

Navigation

Expert → Sensor → Measured val. → Process variab. → Calorific value (1893)

Prerequisite

For the following order code:
"Application package", option EF "Advanced gas analysis"

 The software options currently enabled are displayed in the **SW option overv.** parameter (→ [45](#)).

Description

Displays the calorific value that is currently calculated.

User interface

Signed floating-point number

Additional information


Dependency

 The unit is taken from the **Cal. value unit** parameter (→ [71](#))

"System values" submenu

Navigation

Expert → Sensor → Measured val. → System values



[Turbulence \(2907\)](#)→ [54](#)[Flow asymmetry \(2913\)](#)→ [54](#)

Signal strength

Navigation	  Expert → Sensor → Measured val. → System values → Signal strength (2914)
Description	Displays the current signal strength.
User interface	Signed floating-point number
Additional information	<i>Description</i> A drop in the signal strength over time can be an indicator of deposit buildup on the converter or high ultrasonic damping in the gas.

SNR

Navigation	  Expert → Sensor → Measured val. → System values → SNR (2917)
Description	Displays the current signal-to-noise ratio.
User interface	Signed floating-point number
Additional information	<i>Description</i> A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality.

Acceptance rate

Navigation	  Expert → Sensor → Measured val. → System values → Acceptance rate (2912)
Description	Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted. Multipath measuring devices only: Displays the minimum of all acceptance rates measured.
User interface	0 to 100 %

Turbulence


Navigation	  Expert → Sensor → Measured val. → System values → Turbulence (2907)
Description	Displays the current turbulence.
User interface	Signed floating-point number
Additional information	<i>Description</i> A high turbulence value indicates a disturbance in the flow profile.

Flow asymmetry

Navigation	  Expert → Sensor → Measured val. → System values → Flow asymmetry (2913)
Prerequisite	 Only available from nominal diameter DN 50 (2").
Description	Displays the asymmetry of the flow velocity between signal path 1 and signal path 2.
User interface	Signed floating-point number
Additional information	<i>Limit values</i> If the value 0 is displayed, both flow velocities are the same. The higher the displayed value, the greater the difference between the two measured values of the signal paths.

"Totalizer" submenu

Navigation   Expert → Sensor → Measured val. → Totalizer



Totalizer val. 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [194](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Correct.vol.flow
- Mass flow
- Energy flow

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information*Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Tot. overflow 1 to n** parameter if the display range is exceeded.

In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ [197](#)).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Operation mode** parameter (→ [196](#)).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [194](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer val. 1** parameter: 1 968 457 m³
- Value in the **Tot. overflow 1** parameter: 1 · 10⁷ (1 overflow) = 10 000 000 [m³]
- Current totalizer reading: 11 968 457 m³

Tot. overflow 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910–1 to n)

Prerequisite

One of the following options is selected in the **Assign variable** parameter (→ [194](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Correct.vol.flow
- Mass flow
- Energy flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information**Description**

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer val. 1 to n** parameter.

User interface

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [194](#)).


Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:


- Value in the **Totalizer val. 1** parameter: 1968457 m³
- Value in the **Tot. overflow 1** parameter: $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

"Input values" submenu*Navigation*

Expert → Sensor → Measured val. → Input values

**"Current input 1 to n" submenu***Navigation*

Expert → Sensor → Measured val. → Input values → Current input 1 to n

**Measured val. 1 to n****Navigation**

Expert → Sensor → Measured val. → Input values → Current input 1 to n
→ Measured val. 1 to n (1603-1 to n)

Description

Displays the current input value.

User interface Signed floating-point number

Additional information *Dependency*



The unit is taken from the **Pressure unit** parameter (→ 69)

Measur. curr. 1 to n

Navigation Expert → Sensor → Measured val. → Input values → Current input 1 to n → Measur. curr. 1 to n (1604–1 to n)

Description Displays the current value of the current input.

User interface 0 to 22.5 mA

"Value status input 1 to n" submenu

Navigation

Expert → Sensor → Measured val. → Input values → Val.stat.inp. 1 to n

► Val.stat.inp. 1 to n

Val.stat.inp. (1353–1 to n)

→ 57



Val.stat.inp.

Navigation Expert → Sensor → Measured val. → Input values → Val.stat.inp. 1 to n → Val.stat.inp. (1353–1 to n)

Description Displays the current input signal level.

User interface

- High
- Low

"Output values" submenu**Navigation** Expert → Sensor → Measured val. → Output values**"Value current output 1 to n" submenu****Navigation** Expert → Sensor → Measured val. → Output values → Value curr.out 1 to n

Output curr. 1 to n**Navigation** Expert → Sensor → Measured val. → Output values → Value curr.out 1 to n → Output curr. 1 to n (0361-1 to n)**Description**

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measur. curr. 1 to n**Navigation** Expert → Sensor → Measured val. → Output values → Value curr.out 1 to n → Measur. curr. 1 to n (0366-1 to n)**Description**

Use this function to display the actual measured value of the output current.


User interface

0 to 30 mA

"Pulse/frequency/switch output 1 to n" submenu

Navigation

Expert → Sensor → Measured val. → Output values → PFS output 1 to n



Output freq. 1 to n

Navigation

Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Output freq. 1 to n (0471-1 to n)

Prerequisite

In the **Operating mode** parameter (→ 121), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Pulse output 1 to n

Navigation

Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Pulse output 1 to n (0456-1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 121) parameter.

Description

Displays the pulse frequency currently output.


User interface

Positive floating-point number

Additional information

Description

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.



- 0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 138) i.e. the transistor does not conduct for the duration of the pulse.


In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 125)) can be configured.

Switch status 1 to n

Navigation	Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Switch status 1 to n (0461-1 to n)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 121).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ■ Open ■ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ■ Open The switch output is not conductive. ■ Closed The switch output is conductive.

"Relay output 1 to n" submenu

Navigation Expert → Sensor → Measured val. → Output values → Relay output 1 to n



Switch status

Navigation	 Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch status (0801-1 to n)
Description	Displays the current status of the relay output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The relay output is not conductive. ▪ Closed The relay output is conductive.

Switch cycles

Navigation	 Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch cycles (0815-1 to n)
Description	Displays all the switch cycles performed.
User interface	Positive integer

Max. cycles no.

Navigation	 Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Max. cycles no. (0817-1 to n)
Description	Displays the maximum number of guaranteed switch cycles.
User interface	Positive integer

"Double pulse output" submenu

Navigation  Expert → Sensor → Measured val. → Output values → Double pulse out

► Double pulse out

Pulse output (0987)

→  62

Pulse output

Navigation

Expert → Sensor → Measured val. → Output values → Double pulse out → Pulse output (0987)

Description

Displays the pulse frequency of the double pulse output which is currently output.

User interface

Positive floating-point number

Additional information

 For a detailed description and example: **Pulse output** parameter (→ 59)

3.2.2 "System units" submenu

Navigation

Expert → Sensor → System units

► System units	
Volume flow unit (0553)	→ 63
Volume unit (0563)	→ 65
Cor.volflow unit (0558)	→ 66
Corr. vol. unit (0575)	→ 66
Mass flow unit (0554)	→ 67
Mass unit (0574)	→ 68
Velocity unit (0566)	→ 68
Temperature unit (0557)	→ 69
Pressure unit (0564)	→ 69
Density unit (0555)	→ 70
Energy unit (0559)	→ 70
Dyn. visc. unit (0577)	→ 71
Cal. value unit (0552)	→ 71
Energy flow unit (0565)	→ 72
Length unit (0551)	→ 72

SpecHeatCapaUnit (0604)

→ 73

Date/time format (2812)

→ 73

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ cm ³ /s	■ af/s	■ gal/s (imp)
	■ cm ³ /min	■ af/min	■ gal/min (imp)
	■ cm ³ /h	■ af/h	■ gal/h (imp)
	■ cm ³ /d	■ af/d	■ gal/d (imp)
	■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)
	■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)
	■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)
	■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)
	■ m ³ /s	■ MMft ³ /s	■ bbl/s (imp;beer)
	■ m ³ /min	■ MMft ³ /min	■ bbl/min (imp;beer)
	■ m ³ /h	■ MMft ³ /h	■ bbl/h (imp;beer)
	■ m ³ /d	■ Mft ³ /d	■ bbl/d (imp;beer)
	■ ml/s	■ fl oz/s (us)	■ bbl/s (imp;oil)
	■ ml/min	■ fl oz/min (us)	■ bbl/min (imp;oil)
	■ ml/h	■ fl oz/h (us)	■ bbl/h (imp;oil)
	■ ml/d	■ fl oz/d (us)	■ bbl/d (imp;oil)
	■ l/s	■ gal/s (us)	
	■ l/min	■ gal/min (us)	
	■ l/h	■ gal/h (us)	
	■ l/d	■ gal/d (us)	
	■ hl/s	■ Mgal/s (us)	
	■ hl/min	■ Mgal/min (us)	
	■ hl/h	■ Mgal/h (us)	
	■ hl/d	■ Mgal/d (us)	
	■ Ml/s	■ bbl/s (us;liq.)	
	■ Ml/min	■ bbl/min (us;liq.)	
	■ Ml/h	■ bbl/h (us;liq.)	
	■ Ml/d	■ bbl/d (us;liq.)	
		■ bbl/s (us;beer)	
		■ bbl/min (us;beer)	
		■ bbl/h (us;beer)	
		■ bbl/d (us;beer)	
		■ bbl/s (us;oil)	
		■ bbl/min (us;oil)	
		■ bbl/h (us;oil)	
		■ bbl/d (us;oil)	
		■ bbl/s (us;tank)	
		■ bbl/min (us;tank)	
		■ bbl/h (us;tank)	
		■ bbl/d (us;tank)	
		■ kgal/s (us)	
		■ kgal/min (us)	
		■ kgal/h (us)	
		■ kgal/d (us)	
Factory setting	Country-specific:		
	■ m ³ /h		
	■ ft ³ /h		

Additional information*Result*

The selected unit applies for:
Volume flow parameter (→ 47)

Selection

For an explanation of the abbreviated units: → 243

Customer-specific units

The unit for the customer-specific volume is specified in the **Volume text** parameter.

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- /cm³
- dm³
- /dm³
- m³
- /m³
- ml
- /ml
- l
- /l
- hl
- /hl
- Ml Mega
- /Ml

US units

- af
- /af
- ft³
- /ft³
- Mft³
- /MMft³
- fl oz (us)
- /fl oz (us)
- gal (us)
- /gal (us)
- kgal (us)
- /kgal (us)
- Mgal (us)
- /Mgal (us)
- bbl (us;oil)
- /bbl (us;oil)
- bbl (us;liq.)
- /bbl (us;liq.)
- bbl (us;beer)
- /bbl (us;beer)
- bbl (us;tank)
- /bbl (us;tank)

Imperial units

- gal (imp)
- /gal (imp)
- Mgal (imp)
- /Mgal (imp)
- bbl (imp;beer)
- /bbl (imp;beer)
- bbl (imp;oil)
- /bbl (imp;oil)

Factory setting

Country-specific:

- m³
- ft³

Additional information*Selection*

For an explanation of the abbreviated units: → 243

Cor.volflow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nhl/s
- Nhl/min
- Nhl/h
- Nhl/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sl/s
- Sl/min
- Sl/h
- Sl/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- MSft³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- MMSft³/s
- MMSft³/min
- MMSft³/h
- Sbbl/s (us;oil)
- Sbbl/min (us;oil)
- Sbbl/h (us;oil)
- Sbbl/d (us;oil)

Imperial units

- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting

Country-specific:

- Nm³/h
- Sft³/h

Additional information*Result*

The selected unit applies for:
Correct.vol.flow (→ 50)

Selection

For an explanation of the abbreviated units: → 243

Corr. vol. unit**Navigation**

Expert → Sensor → System units → Corr. vol. unit (0575)

Description

Use this function to select the unit for the corrected volume.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ Nl	■ Sft ³	■ Sgal (imp)
	■ /Nl	■ /Sft ³	■ /Sgal (imp)
	■ Nhl	■ MMSft ³	
	■ /Nhl	■ /MMSft ³	
	■ Nm ³	■ Sgal (us)	
	■ /Nm ³	■ /Sgal (us)	
	■ SI	■ Sbbl (us;liq.)	
	■ /SI	■ /Sbbl (us;liq.)	
	■ Sm ³	■ Sbbl (us;oil)	
	■ /Sm ³	■ /Sbbl (us;oil)	
Factory setting	Country-specific:		
	■ Nm ³		
	■ Sft ³		
Additional information	<i>Selection</i>		
	 For an explanation of the abbreviated units: → 243		

Mass flow unit

Navigation  Expert → Sensor → System units → Mass flow unit (0554)

Description Use this function to select the unit for the mass flow.

Selection	<i>SI units</i>	<i>US units</i>
	■ g/s	■ oz/s
	■ g/min	■ oz/min
	■ kg/s	■ lb/s
	■ kg/min	■ lb/min
	■ kg/h	■ lb/h
	■ kg/d	■ lb/d
	■ t/h	■ STon/h
	■ t/d	■ STon/d

Factory setting Country-specific:

- kg/h
- lb/h

Additional information *Result*

The selected unit applies for:

Mass flow parameter (→ [48](#))

Selection

 For an explanation of the abbreviated units: → [243](#)

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- /g
- kg
- /kg
- t
- /t

US units

- oz
- /oz
- lb
- /lb
- STon
- /STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → 243

Velocity unit**Navigation**

Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection*SI units*

m/s

US units

ft/s

Factory setting

Country-specific:

- m/s
- ft/s

Additional information*Result*

The selected unit applies for:

- Flow velocity (→ 49)
- Sound velocity (→ 48)
- Maximum value
- Minimum value

Selection

For an explanation of the abbreviated units: → 243

Temperature unit

Navigation Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection	<i>SI units</i>	<i>US units</i>
	▪ °C	▪ °F
	▪ K	▪ °R

Factory setting Country-specific:

- °C
- °F

Additional information *Result*

The selected unit applies for:
Temperature (→ 49)

Selection

For an explanation of the abbreviated units: → 243

Pressure unit

Navigation Expert → Sensor → System units → Pressure unit (0564)

Description Use this function to select the unit for the pipe pressure.

Selection	<i>SI units</i>	<i>US units</i>
	▪ MPa	psi
	▪ kPa	
	▪ Pa	
	▪ bar	

Factory setting Country-specific:

- bar a
- psi a

Additional information *Result*

The unit is taken from:
Process pressure parameter (5640)

Selection

For an explanation of the abbreviated units: → 243

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/m³
- lb/ft³

Additional information

Selection

For an explanation of the abbreviated units: → [243](#)

Energy unit**Navigation**

Expert → Sensor → System units → Energy unit (0559)

Description

Use this function to select the unit for energy.

Selection*SI units*

- kWh
- MWh
- GWh
- kJ
- MJ
- GJ
- kcal
- Mcal

Imperial units

- Btu
- MBtu
- MMBtu

Factory setting

Country-specific:

- kWh
- Btu

Additional information

Selection

For an explanation of the abbreviated units: → [243](#)

Dyn. visc. unit

Navigation Expert → Sensor → System units → Dyn. visc. unit (0577)

Description Use this function to select the unit for dynamic viscosity.

Selection *SI units*

- cP
- mPa s
- Pa s
- P

Factory setting Pa s

Additional information *Result*

The selected unit applies for:

Dynam. viscosity parameter (gases)

Additional information *Selection*

For an explanation of the abbreviated units: → 243

Cal. value unit

Navigation Expert → Sensor → System units → Cal. value unit (0552)

Description Use this function to select the unit for the calorific value.

Selection *SI units*

- kJ/Nm³
- MJ/Nm³
- kWh/Nm³
- kWh/Sm³
- kJ/Sm³

Imperial units

- Btu/Sm³
- MBtu/Sm³
- Btu/Sft³
- MBtu/Sft³

Factory setting Country-specific:

- kWh/Nm³
- Btu/Sft³

Additional information *Result*

The selected unit applies for:

- **Calorific value** parameter (→ 49)
- **Wobbe index** parameter (→ 50)

Selection

For an explanation of the abbreviated units: → 243

Energy flow unit**Navigation**

Expert → Sensor → System units → Energy flow unit (0565)

Description

Use this function to select the unit for the energy flow.

Selection*SI units*

- kW
- MW
- kJ/s
- kJ/min
- kJ/h
- kJ/d
- MJ/h
- MJ/d
- kcal/s
- kcal/min
- kcal/h
- kcal/d

Imperial units

- Btu/s
- Btu/min
- Btu/h
- Btu/day
- MBtu/min
- MBtu/h
- MBtu/d
- MMBtu/h
- MMBtu/d

Factory setting

Country-specific:

- kW
- Btu/h

Additional information*Selection*

For an explanation of the abbreviated units: → [243](#)

Length unit**Navigation**

Expert → Sensor → System units → Length unit (0551)

Description

Use this function to select the unit of length for the nominal diameter.

Selection*SI units*

- m
- mm
- µm

US units

- ft
- in

Factory setting

Country-specific:

- mm
- in

Additional information*Selection*

For an explanation of the abbreviated units: → [243](#)

SpecHeatCapaUnit**Navigation**

Expert → Sensor → System units → SpecHeatCapaUnit (0604)

Prerequisite

The following conditions are met:

Selected medium:

The **User-spec. gas** option is selected in the **Select gas type** parameter parameter.

Description

Use this function to select the unit for the specific heat capacity.

Selection*SI units*

- J/(kgK)
- kJ/(kgK)
- MJ/(kgK)
- kWh/(kgK)
- kcal/(kgK)

Imperial units

Btu/(lb°R)

Factory setting

J/(kgK)

Additional information*Result*

The selected unit applies for:

Spec. heat cap. parameter

Selection

For an explanation of the abbreviated units: → [243](#)

**Date/time format**

Expert → Sensor → System units → Date/time format (2812)

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy am/pm
- mm/dd/yy hh:mm
- mm/dd/yy am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

For an explanation of the abbreviated units: → [243](#)

3.2.3 "Process param." submenu

Navigation

Expert → Sensor → Process param.

▶ Process param.	
Flow override (1839)	→ 74
Flow damping (1802)	→ 74
Gas prop. damp. (1888)	→ 75
Temp. damping (1803)	→ 76
Pressure damping (1889)	→ 76
▶ Low flow cut off	→ 76

Flow override



Navigation

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

Flow override is active

- The diagnostic message **△C453 Flow override** is output.
- Output values
 - Temperature: continues to be output
 - Pressure: continues to be output
 - Sound velocity: continues to be output
 - Totalizers 1-3: stop being totalized

i The **Flow override** option can also be activated in the **Status input** submenu: **Assign stat.inp.** parameter (→ 105).

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping (1802)

Description

Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose,

the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 1 s

Additional information *Description*

 The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

 Damping is switched off if **0** is entered (factory setting).

Result

 The damping affects the following variables of the device:

- Outputs → [106](#)
- Low flow cut off → [76](#)
- Totalizers → [193](#)

Gas prop. damp.



Navigation  Expert → Sensor → Process param. → Gas prop. damp. (1888)

Description Use this function to enter the time constant for gas properties damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 1 s

Additional information *Result*

 The damping has an effect on the following outputs:

- Correct.vol.flow (→ [50](#))
- Density (→ [51](#))
- Dry CH₄ in % (→ [50](#))
- Dynam. viscosity (→ [52](#))
- Calorific value (→ [52](#))
- Wobbe index (→ [50](#))
- Energy flow (→ [49](#))

2) Proportional behavior with first-order lag

Temp. damping



Navigation Expert → Sensor → Process param. → Temp. damping (1803)

Description Enter the value for damping the temperature value and the sound velocity.

User entry 0 to 999.9 s

Factory setting 10 s

Additional information *Description*

The damping is performed by a PT1 element³⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if **0** is entered (factory setting).

Pressure damping



Navigation Expert → Sensor → Process param. → Pressure damping (1889)


Description Enter value for damping the pressure.

User entry 0 to 999.9 s

Factory setting 0 s

"Low flow cut off" submenu

Navigation Expert → Sensor → Process param. → Low flow cut off



3) Proportional behavior with first-order lag

Assign variable

Navigation Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

Description Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity *
- Energy flow *

Factory setting Volume flow

On value

Navigation Expert → Sensor → Process param. → Low flow cut off → On value (1805)

Prerequisite A process variable is selected in the **Assign variable** parameter (→ [77](#)).

Description Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → [77](#).

User entry Positive floating-point number

Factory setting Depends on country and nominal diameter → [240](#)

Additional information

Dependency

The unit depends on the process variable selected in the **Assign variable** parameter (→ [77](#)).

Off value

Navigation Expert → Sensor → Process param. → Low flow cut off → Off value (1804)


Prerequisite A process variable is selected in the **Assign variable** parameter (→ [77](#)).

Description Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → [77](#).

User entry 0 to 100.0 %

Factory setting 50 %

* Visibility depends on order options or device settings

Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.4 "Measurement mode" submenu

Navigation

Expert → Sensor → Measurement mode

► Measurement mode	
Select gas type (3109)	→ 78
Density calc. (3102)	→ 79
Enthalpy calc. (3103)	→ 79
Ref. conditions (3155)	→ 79
Ref. pressure (3146)	→ 80
Ref. temperature (3147)	→ 80
Ref. comb. temp. (3165)	→ 80
► Medium property	
	→ 81

Select gas type

Navigation

Expert → Sensor → Measurement mode → Select gas type (3109)

Description

Select measured gas type.

Selection	<ul style="list-style-type: none"> ■ Single gas * ■ Gas mixture * ■ Coal gas/bio gas * ■ Natur.gas (std) * ■ Nat.gas (s.vel.) * ■ User-spec. gas
------------------	--

Factory setting	User-spec. gas
------------------------	----------------

Density calc.

Navigation	Expert → Sensor → Measurement mode → Density calc. (3102)
Description	Select the norm the density calculation is based on.
Selection	<ul style="list-style-type: none"> ■ AGA Nx19 ■ ISO 12213- 2 ■ ISO 12213- 3
Factory setting	ISO 12213- 3

Cal.value calc.

Navigation	Expert → Sensor → Measurement mode → Cal.value calc. (3103)
Description	Select the standard used for calculating the calorific value.
Selection	<ul style="list-style-type: none"> ■ AGA5 ■ ISO 6976
Factory setting	ISO 6976

Ref. conditions

Navigation	Expert → Sensor → Measurement mode → Ref. conditions (3155)
Description	Select reference conditions for calculation of the corrected volume flow.
Selection	<ul style="list-style-type: none"> ■ 1013.25hPa, 0°C ■ 1013.25hPa, 15°C ■ 1013.25hPa, 20°C ■ 1013.25hPa, 25°C ■ 1000.00hPa, 0°C ■ 1000.00hPa, 15°C

* Visibility depends on order options or device settings

- 1000.00hPa, 20°C
- 1000.00hPa, 25°C
- 14.696Psi, 59°F
- 14.696Psi, 60°F
- 14.730Psi, 60°F
- Others

Factory setting 1013.25hPa, 0°C

Ref. pressure



Navigation Expert → Sensor → Measurement mode → Ref. pressure (3146)

Prerequisite The **Others** option is selected in the **Ref. conditions** parameter (→ 79).

Description Select reference conditions for the corrected volume flow.

User entry 0 to 250 bar

Factory setting 1.01325 bar

Ref. temperature



Navigation Expert → Sensor → Measurement mode → Ref. temperature (3147)

Prerequisite The **Others** option is selected in the **Ref. conditions** parameter (→ 79).

Description Select reference conditions for the corrected volume flow.

User entry -200 to 450 °C

Factory setting 0 °C

Ref. comb. temp.



Navigation Expert → Sensor → Measurement mode → Ref. comb. temp. (3165)

Description Select ref. temp. (reference combustion temperature) for calculating the gas energy value.

Selection

- 0 °C
- 15 °C
- 20 °C
- 25 °C
- 60 °F

Factory setting

25 °C

"Medium properties" submenu*Navigation*

Expert → Sensor → Measurement mode → Medium property

► Medium property	
Calorif.val.type (3101)	→ 81
Humidity type (3156)	→ 82
Ref.density (3144)	→ 82
Ref. GrossCalVal (3145)	→ 82
Ref. Z-factor (3148)	→ 82
Relative density (3149)	→ 83
Spec. heat cap. (3162)	→ 83
Calorific value (3105)	→ 83
Z-factor (3108)	→ 83
Dynam. viscosity (3106)	→ 84
Add. gas compon. (3154)	→ 84
St.vol.fl. cal. (3164)	→ 84

Calorif.val.type**Navigation**

Expert → Sensor → Measurement mode → Medium property → Calorif.val.type (3101)

Description

Select calculation based on gross calorific value or net calorific value.

Selection

- GrossCalorValVol
- NetCalorValVol

Factory setting

GrossCalorValVol

Humidity type

Navigation Expert → Sensor → Measurement mode → Medium property → Humidity type (3156)

Description Select the input value for the gas humidity.

Selection

- Rel. humidity
- Water fraction
- Dew point

Factory setting Depends on the selected gas type.

Ref.density

Navigation Expert → Sensor → Measurement mode → Medium property → Ref.density (3144)

Description Enter fixed value for reference density.

User entry 0.01 to 100 kg/m³

Factory setting 1 kg/m³

Ref. GrossCalVal

Navigation Expert → Sensor → Measurement mode → Medium property → Ref. GrossCalVal (3145)

Description Enter the reference gross calorific value of the gas.

User entry 0 to 1 000 MJ/Nm³

Factory setting 40 MJ/Nm³

Ref. Z-factor

Navigation Expert → Sensor → Measurement mode → Medium property → Ref. Z-factor (3148)

Description Enter real gas constant Z for gas under reference conditions.

User entry 0.1 to 2

Factory setting 1

Relative density

Navigation	Expert → Sensor → Measurement mode → Medium property → Relative density (3149)
Description	Enter the relative density of the gas.
User entry	0.5 to 1.0
Factory setting	0.58

Spec. heat cap.

Navigation	Expert → Sensor → Measurement mode → Medium property → Spec. heat cap. (3162)
Description	Enter the specific heat capacity of the medium.
User entry	0 to 50 000 J/(kgK)
Factory setting	Depends on the selected gas type.

Calorific value

Navigation	Expert → Sensor → Measurement mode → Medium property → Calorific value (3105)
Description	Enter gross calorific value to calculate the energy flow.
User entry	0 to 1000 MJ/Nm ³
Factory setting	40 MJ/Nm ³

Z-factor

Navigation	Expert → Sensor → Measurement mode → Medium property → Z-factor (3108)
Description	Enter real gas constant Z for gas under operation conditions.
User entry	0.1 to 2.0
Factory setting	1

Dynam. viscosity

Navigation	Expert → Sensor → Measurement mode → Medium property → Dynam. viscosity (3106)
Description	Value of the dynamic viscosity for user-specific gas.
User entry	0 to 0.001 Pa s
Factory setting	0.000015 Pa s

Add. gas compon.

Navigation	Expert → Sensor → Measurement mode → Medium property → Add. gas compon. (3154)
Prerequisite	The Coal gas/bio gas option is selected in the Select gas type parameter (→ 78).
Description	Specify the additional gas component of the gas.
Selection	<ul style="list-style-type: none">▪ None▪ Hydrogen H₂▪ Hydrot.sulf. H₂S
Factory setting	None

St.vol.fl. cal.

Navigation	Expert → Sensor → Measurement mode → Medium property → St.vol.fl. cal. (3164)
Prerequisite	The Coal gas/bio gas option is selected in the Select gas type parameter (→ 78).
Description	Setting specifying how the corrected volume flow is calculated for wet coal gas/biogas.
Selection	<ul style="list-style-type: none">▪ Wet gas▪ Dry gas
Factory setting	Dry gas

3.2.5 "External comp." submenu

Navigation

Expert → Sensor → External comp.

▶ External comp.	
Pressure compen. (3023)	→ 85
Pressure (3022)	→ 85
Ext. press.meas. (3033)	→ 86
Atmosph. press. (3024)	→ 86
Temp. compensat. (3025)	→ 86
Medium temp. (2925)	→ 87

Pressure compen.



Navigation

Expert → Sensor → External comp. → Pressure compen. (3023)

Description

Select pressure compensation type.

Selection

- Fixed value
- Internal value *
- External value *
- Current input 1 *
- Current input 2 *
- Current input 3 *

Factory setting

Fixed value

Pressure

Navigation

Expert → Sensor → External comp. → Pressure (3022)

Description

Enter fixed value for the process pressure.

User entry

0 to 250 bar

Factory setting

5 bar

* Visibility depends on order options or device settings

Ext. press.meas.

Navigation  Expert → Sensor → External comp. → Ext. press.meas. (3033)

Description Select pressure type for external pressure measurement.

Selection

- Abs. pressure
- Gauge pressure

Factory setting Abs. pressure

Atmosph. press.

Navigation  Expert → Sensor → External comp. → Atmosph. press. (3024)

Prerequisite The **External value** option or **Current input 1...3** option is selected in the **Pressure compen.** parameter (→  85).

The **Gauge pressure** option is selected in the **Ext. press.meas.** parameter (→  86).

Description Enter atmospheric pressure value to be used for pressure correction.

User entry 0.7 to 1.1 bar

Factory setting 1.01325 bar

Temp. compensat.

Navigation  Expert → Sensor → External comp. → Temp. compensat. (3025)

Description Select temperature mode for temperature compensation.

Selection

- Fixed value
- Internal value *
- External value *
- Current input 1 *
- Current input 2 *
- Current input 3 *

Factory setting Fixed value

* Visibility depends on order options or device settings

Medium temp.

Navigation Expert → Sensor → External comp. → Medium temp. (2925)

Description Enter a fixed value for process temperature.

User entry -50 to 150 °C

Factory setting 20 °C

3.2.6 "Sensor adjustm." submenu

Navigation Expert → Sensor → Sensor adjustm.

► Sensor adjustm.	
Install. direct. (1809)	→ 87
Ref. pressure (5670)	→ 88
Press. cell adj. (5669)	→ 88
p cell offs.val (5671)	→ 88
► Variable adjust	→ 88

Install. direct.

Navigation Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description Use this function to change the sign of the medium flow direction.

Selection

- In arrow direct.
- Against arrow

Factory setting In arrow direct.

Additional information *Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Ref. pressure**Navigation**

Expert → Sensor → Sensor adjustm. → Ref. pressure (5670)

Description

Enter the reference pressure for calculating the offset for the internal pressure measuring cell.

User entry

Positive floating-point number

Factory setting

1.01325 bar

Press. cell adj.**Navigation**

Expert → Sensor → Sensor adjustm. → Press. cell adj. (5669)

Description

Select process for the offset adjustment for the integrated pressure measurement.

Selection

- Yes
- Discard offset
- Cancel

Factory setting

Cancel

p cell offs.val**Navigation**

Expert → Sensor → Sensor adjustm. → p cell offs.val (5671)

Description

Displays the offset value currently used by the device to correct the pressure measured value that is measured internally.

User interface

Signed floating-point number

Factory setting

0 bar

"Process variable adjustment" submenu**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust

► Variable adjust

Vol. flow offset (1831)

→ 90

Vol. flow factor (1832)

→ 90

Corr. vol offset (1855)	→ 90
Corr. vol factor (1856)	→ 91
Mass flow offset (1841)	→ 91
Mass flow factor (1846)	→ 91
S. veloc. offset (1848)	→ 92
S. veloc. factor (1849)	→ 92
Temp. offset (1870)	→ 92
Temp. factor (1871)	→ 93
Pressure offset (1881)	→ 93
Pressure factor (1882)	→ 93
Methane offset (1873)	→ 94
Methane factor (1874)	→ 94
Molar mass offs. (1875)	→ 94
Mol mass factor (1876)	→ 94
Density offset (1877)	→ 95
Density factor (1878)	→ 95
Dyn.visc. offset (1898)	→ 95
Dyn.visc. factor (1897)	→ 95
Cal. val. offs. (1899)	→ 96
Cal. val. fact. (1900)	→ 96
Wobbe index offs (1879)	→ 96
Wobbe index fact (1880)	→ 96
En. flow offset (1866)	→ 97
En. flow factor (1867)	→ 97

Vol. flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/h

Additional information*Description*

Corrected value = (factor × value) + offset

Vol. flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Corr. vol offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1855)

Description

Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.

User entry

Signed floating-point number

Factory setting

0 Sm³/h

Additional information*Description*

Corrected value = (factor × value) + offset

Corr. vol factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1856)

Description Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in Kelvin.

User entry Positive floating-point number

Factory setting 1

Mass flow offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/h.

User entry Signed floating-point number

Factory setting 0 kg/h

Additional information *Description*



Corrected value = (factor × value) + offset

Mass flow factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)

Description Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*



Corrected value = (factor × value) + offset

S. veloc. offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. offset (1848)

Description Use this function to enter the zero point shift for the sound velocity trim. The sound velocity unit on which the shift is based is m/s.

User entry Signed floating-point number

Factory setting 0 m/s

Additional information *Description*

Corrected value = (factor × value) + offset

S. veloc. factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. factor (1849)

Description Use this function to enter a quantity factor (without time) for the sound velocity. This multiplication factor is applied over the sound velocity range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

Temp. offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1870)

Description Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is K.

User entry Signed floating-point number

Factory setting 0 K

Additional information *Description*

Corrected value = (factor × value) + offset

Temp. factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1871)
Description	Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in K.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Pressure offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Pressure offset (1881)
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is 1 kg/s.
User entry	Signed floating-point number
Factory setting	0 bar
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Pressure factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Pressure factor (1882)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1

Methane offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Methane offset (1873)

Description Use this function to enter the zero point shift for the methane fraction trim.

User entry Signed floating-point number

Factory setting 0 %

Methane factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Methane factor (1874)

Description Use this function to enter a quantity factor for the methane fraction.

User entry Positive floating-point number

Factory setting 1

Molar mass offs.

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Molar mass offs. (1875)

Description Use this function to enter the zero point shift for the molar mass trim.

User entry Signed floating-point number

Factory setting 0 g/mol

Mol mass factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mol mass factor (1876)

Description Use this function to enter a quantity factor for the molar mass.

User entry Positive floating-point number

Factory setting 1

Density offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Density offset (1877)
Description	Use this function to enter the zero point shift for the density trim.
User entry	Signed floating-point number
Factory setting	0 kg/m ³

Density factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Density factor (1878)
Description	Use this function to enter a quantity factor for the density.
User entry	Positive floating-point number
Factory setting	1

Dyn.visc. offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Dyn.visc. offset (1898)
Description	Use this function to enter the zero point shift for the dynamic viscosity trim.
User entry	Signed floating-point number
Factory setting	0 Pa s

Dyn.visc. factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Dyn.visc. factor (1897)
Description	Use this function to enter a quantity factor for the dynamic viscosity.
User entry	Positive floating-point number
Factory setting	1

Cal. val. offs.

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Cal. val. offs. (1899)

Description Use this function to enter the zero point shift for the calorific value trim.

User entry Signed floating-point number

Factory setting 0 MJ/Nm³

Cal. val. fact.

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Cal. val. fact. (1900)

Description Use this function to enter a quantity factor for the calorific value.

User entry Positive floating-point number

Factory setting 1

Wobbe index offs

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Wobbe index offs (1879)

Description Use this function to enter the zero point shift for the Wobbe index trim.

User entry Signed floating-point number

Factory setting 0 MJ/Nm³

Additional information *Description*

Corrected value = (factor × value) + offset

Wobbe index fact

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Wobbe index fact (1880)

Description Use this function to enter a quantity factor for the Wobbe index factor.

User entry Positive floating-point number

Factory setting 1


Additional information	Description
	 Corrected value = (factor × value) + offset

En. flow offset

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → En. flow offset (1866)
Description	Use this function to enter the zero point shift for the energy flow trim. The energy flow unit on which the shift is based is 1 W.
User entry	Signed floating-point number
Factory setting	0 kW
Additional information	Description
	 Corrected value = (factor × value) + offset

En. flow factor

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → En. flow factor (1867)
Description	Use this function to enter a quantity factor (without time) for the energy flow. This multiplication factor is applied over the energy flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	Description
	 Corrected value = (factor × value) + offset

3.2.7 "Calibration" submenu**Navigation** Expert → Sensor → Calibration

Zero point (2921)	→ 98
Nominal diameter (2807)	→ 98

Cal. factor

Navigation Expert → Sensor → Calibration → Cal. factor (2920)

Description Displays the current calibration factor for the sensor.

User interface Signed floating-point number

Factory setting 1

Zero point

Navigation Expert → Sensor → Calibration → Zero point (2921)

Description Displays the current zero point correction value for the sensor.

User interface Signed floating-point number

Factory setting 0

Nominal diameter

Navigation Expert → Sensor → Calibration → Nominal diameter (2807)

Description Displays the nominal diameter of the sensor.

User interface DNxx / x"

Factory setting Depends on the size of the sensor

Additional information *Description*

The value is also specified on the sensor nameplate.

3.3 "I/O configuration" submenu

Navigation

◀ ▶ Expert → I/O config.

▶ I/O config.	
I/O 1 to n terminals (3902-1 to n)	→ 99
I/O 1 to n info (3906-1 to n)	→ 99
I/O 1 to n type (3901-1 to n)	→ 100
Apply I/O config (3907)	→ 100
I/O alterat.code (2762)	→ 101

I/O 1 to n terminals

Navigation

◀ ▶ Expert → I/O config. → I/O 1 to n terminals (3902-1 to n)

Description

Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

I/O 1 to n info

Navigation

◀ ▶ Expert → I/O config. → I/O 1 to n info (3906-1 to n)

Description

Displays information about the plugged in I/O module.

User interface

- Not plugged
- Invalid
- Not configurable
- Configurable
- HART

* Visibility depends on order options or device settings

Additional information	<p><i>"Not plugged"</i> option The I/O module is not plugged in.</p> <p><i>"Invalid"</i> option The I/O module is not plugged correctly.</p> <p><i>"Not configurable"</i> option The I/O module is not configurable.</p> <p><i>"Configurable"</i> option The I/O module is configurable.</p> <p><i>"Fieldbus"</i> option The I/O module is configured for HART.</p>
-------------------------------	---

I/O 1 to n type

Navigation	Expert → I/O config. → I/O 1 to n type (3901-1 to n)
Prerequisite	For the following order code: <ul style="list-style-type: none">■ "Output; input 2", option D "Configurable I/O initial setting off"■ "Output; input 3", option D "Configurable I/O initial setting off"■ "Output; input 4", option D "Configurable I/O initial setting off"
Description	Use this function to select the I/O module type for the configuration of the I/O module.
Selection	<ul style="list-style-type: none">■ Off■ Curr.output *■ Current input *■ Status input *■ PFS output■ Double pulse out *■ Relay output *
Factory setting	Off

Apply I/O config

Navigation	Expert → I/O config. → Apply I/O config (3907)
Description	Use this function to activate the newly configured I/O module type.
Selection	<ul style="list-style-type: none">■ No■ Yes
Factory setting	No

* Visibility depends on order options or device settings

I/O alterat.code**Navigation**

Expert → I/O config. → I/O alterat.code (2762)

Description

Use this function to enter the ordered activation code to activate the I/O configuration change.

User entry Positive integer

Factory setting 0


Additional information *Description*

The I/O configuration is changed in the **I/O type** parameter (→ 100).

3.4 "Input" submenu

Navigation


Expert → Input



3.4.1 "Current input 1 to n" submenu

Navigation

Expert → Input → Current input 1 to n



Terminal no.

Navigation   Expert → Input → Current input 1 to n → Terminal no. (1611-1 to n)

Description Displays the terminal numbers used by the current input module.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

Additional information "Not used" option
The current input module does not use any terminal numbers.

Signal mode



Navigation   Expert → Input → Current input 1 to n → Signal mode (1610-1 to n)

Prerequisite The measuring device is **not** approved for use in the hazardous area with type of protection Ex-i.

Description Use this function to select the signal mode for the current input.

Selection

- Passive
- Active

Factory setting Active

Current span



Navigation   Expert → Input → Current input 1 to n → Current span (1605-1 to n)

Description Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

Selection

- 4...20 mA
- 4...20 mA NAMUR
- 4...20 mA US
- 0...20 mA

Factory setting Country-specific:

- 4...20 mA NAMUR
- 4...20 mA US

* Visibility depends on order options or device settings

Additional information*Examples*Sample values for the current range: **Current span** parameter (→ 109)**0/4 mA value****Navigation**

Expert → Input → Current input 1 to n → 0/4 mA value (1606–1 to n)

Description

Use this function to enter a value for the 4 mA current.

User entry

Signed floating-point number

Factory setting

0

Additional information*Current input behavior*

The current input behaves differently depending on the settings configured in the following parameters:

- Current span (→ 102)
- Failure mode (→ 103)

Configuration examplesPay attention to the configuration examples for **4 mA value** parameter (→ 110).**20 mA value****Navigation**

Expert → Input → Current input 1 to n → 20 mA value (1607–1 to n)

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Configuration examples*Pay attention to the configuration examples for **4 mA value** parameter (→ 110).**Failure mode****Navigation**

Expert → Input → Current input 1 to n → Failure mode (1601–1 to n)

DescriptionUse this function to select the input behavior when measuring a current outside the configured **Current span** parameter (→ 102).

Selection	<ul style="list-style-type: none"> ▪ Alarm ▪ Last valid value ▪ Defined value
Factory setting	Alarm
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Alarm An error message is set. ▪ Last valid value The last valid measured value is used. ▪ Defined value A user-defined measured value is used (Failure value parameter (→ 104)).

Failure value	
----------------------	---

Navigation	 Expert → Input → Current input 1 to n → Failure value (1602–1 to n)
Prerequisite	In the Failure mode parameter (→ 103), the Defined value option is selected.
Description	Use this function to enter the value that the device uses if it does not receive an input signal from the external device, or if the input signal is invalid.
User entry	Signed floating-point number
Factory setting	0

3.4.2 "Status input 1 to n" submenu

Navigation  Expert → Input → Status input 1 to n

 Status input 1 to n	
Terminal no. (1358–1 to n)	→ 105
Assign stat.inp. (1352–1 to n)	→ 105
Val.stat.inp. (1353–1 to n)	→ 106
Active level (1351–1 to n)	→ 106
Response time (1354–1 to n)	→ 106

Terminal no.

Navigation  Expert → Input → Status input 1 to n → Terminal no. (1358–1 to n)

Description Displays the terminal numbers used by the status input module.

- User interface**
- Not used
 - 24-25 (I/O 2)
 - 22-23 (I/O 3)
 - 20-21 (I/O 4) *

Additional information "Not used" option

The status input module does not use any terminal numbers.

Assign stat.inp.

Navigation  Expert → Input → Status input 1 to n → Assign stat.inp. (1352–1 to n)

Description Use this function to select the function for the status input.

- Selection**
- Off
 - Reset totaliz. 1
 - Reset totaliz. 2
 - Reset totaliz. 3
 - Reset all tot.
 - Flow override

Factory setting Off

Additional information Selection

- Off
The status input is switched off.

- Reset totaliz. 1...3
The individual totalizers are reset.

- Reset all tot.
All totalizers are reset.

- Flow override
The Flow override (→ 74) is activated.

 Note on the Flow override (→ 74):

- The Flow override (→ 74) is enabled as long as the level is at the status input (continuous signal).
- All other assignments react to a change in level (pulse) at the status input.

* Visibility depends on order options or device settings

Val.stat.inp.

Navigation   Expert → Input → Status input 1 to n → Val.stat.inp. (1353-1 to n)

Description Displays the current input signal level.

User interface

- High
- Low

Active level

Navigation   Expert → Input → Status input 1 to n → Active level (1351-1 to n)

Description Use this function to determine the input signal level at which the assigned function is activated.

Selection

- High
- Low

Factory setting High

Response time

Navigation   Expert → Input → Status input 1 to n → Response time (1354-1 to n)


Description Use this function to enter the minimum time period for which the input signal level must be present before the selected function is activated.

User entry 5 to 200 ms

Factory setting 50 ms

3.5 "Output" submenu

Navigation   Expert → Output



► Relay output 1 to n	→ 139
► Double pulse out	→ 145

3.5.1 "Current output 1 to n" submenu

Navigation

Expert → Output → Curr.output 1 to n

► Curr.output 1 to n	
Terminal no. (0379–1 to n)	→ 107
Signal mode (0377–1 to n)	→ 108
Assign curr. 1 to n (0359–1 to n)	→ 108
Current span (0353–1 to n)	→ 109
Fixed current (0365–1 to n)	→ 110
0/4 mA value (0367–1 to n)	→ 110
20 mA value (0372–1 to n)	→ 112
Measuring mode (0351–1 to n)	→ 113
Damping out. 1 to n (0363–1 to n)	→ 117
Failure mode (0364–1 to n)	→ 118
Failure current (0352–1 to n)	→ 119
Output curr. 1 to n (0361–1 to n)	→ 119
Measur. curr. 1 to n (0366–1 to n)	→ 119

Terminal no.

Navigation

Expert → Output → Curr.output 1 to n → Terminal no. (0379–1 to n)

Description

Displays the terminal numbers used by the current output module.

User interface	<ul style="list-style-type: none"> ■ Not used ■ 26-27 (I/O 1) ■ 24-25 (I/O 2) ■ 22-23 (I/O 3) ■ 20-21 (I/O 4) *
Additional information	<p>"Not used" option</p> <p>The current output module does not use any terminal numbers.</p>

Signal mode	
Navigation	  Expert → Output → Curr.output 1 to n → Signal mode (0377-1 to n)
Description	Use this function to select the signal mode for the current output.
Selection	<ul style="list-style-type: none"> ■ Passive ■ Active
Factory setting	Active

Assign curr. 1 to n	
Navigation	  Expert → Output → Curr.output 1 to n → Assign curr. 1 to n (0359-1 to n)
Description	Use this function to select a process variable for the current output.
Selection	<ul style="list-style-type: none"> ■ Off * ■ Volume flow ■ Correct.vol.flow * ■ Mass flow ■ Flow velocity ■ Sound velocity * ■ Temperature * ■ Pressure * ■ Methane fraction * ■ Molar mass * ■ Density * ■ Dynam. viscosity * ■ Calorific value * ■ Wobbe index * ■ Energy flow ■ Signal strength * ■ SNR * ■ Acceptance rate * ■ Turbulence * ■ Flow asymmetry * ■ Electronic temp.

* Visibility depends on order options or device settings

Factory setting Volume flow

Current span



Navigation Expert → Output → Curr.output 1 to n → Current span (0353-1 to n)

Description Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

- Selection**
- 4...20 mA NAMUR
 - 4...20 mA US
 - 4...20 mA
 - 0...20 mA
 - Fixed current

Factory setting Country-specific:

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Additional information *Description*


■ In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 118).
 ■ If the measured value is outside the measuring range, the diagnostic message **△S441 Curr.output 1 to n** is displayed.
 ■ The measuring range is specified via the **0/4 mA value** parameter (→ 110) and **20 mA value** parameter (→ 112).

"Fixed current" option

- This option is used for a HART Multidrop network.
- It can only be used for the 4...20 mA HART current output (current output 1).
- The current value is set via the **Fixed current** parameter (→ 110).

Example

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:



A0034351

- 1 Current span for process value
- 2 Lower level for signal on alarm
- 3 Upper level for signal on alarm

Selection

Selection	1	2	3
4...20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA

Selection	1	2	3
4...20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA	0 to 20.5 mA	< 0 mA	> 21.95 mA

 If the flow exceeds or falls below the upper or lower signal on alarm level, the diagnostic message **△S441 Curr.output 1 to n** is displayed.

Fixed current



Navigation  Expert → Output → Curr.output 1 to n → Fixed current (0365–1 to n)

Prerequisite The **Fixed current** option is selected in the **Current span** parameter (→ [109](#)).

Description Use this function to enter a constant current value for the current output.

User entry 0 to 22.5 mA

Factory setting 22.5 mA

0/4 mA value



Navigation  Expert → Output → Curr.output 1 to n → 0/4 mA value (0367–1 to n)

Prerequisite In the **Current span** parameter (→ [109](#)), one of the following options is selected:

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description Use this function to enter a value for the 0/4 mA current.

User entry Signed floating-point number

Factory setting Country-specific:

- m³/h
- ft³/h

Additional information *Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign curr.** parameter (→ [108](#)). In addition, the value can be greater than or

smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 112).

Dependency

i The unit depends on the process variable selected in the **Assign curr.** parameter (→ 108).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 109)
- Failure mode (→ 118)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measuring mode with **Forward flow** option

- **0/4 mA value** parameter (→ 110) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 112) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




Q Flow
 I Current
 1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **0/4 mA value** parameter (→ 110) and **20 mA value** parameter (→ 112). If the effective flow exceeds or falls below this operational range, the diagnostic message **△S441 Curr.output 1 to n** is displayed.

Configuration example B

Measuring mode with **Forward/Reverse** option



I Current
 Q Flow
 1 Value assigned to the 0/4 mA current
 2 Forward flow
 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 110) and **20 mA value** parameter (→ 112) must have the same sign. The value for the **20 mA value** parameter (→ 112) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 112) (e.g. forward flow).

Configuration example C

Measuring mode with **Rev. flow comp.** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → 113.

20 mA value



Navigation

Expert → Output → Curr.output 1 to n → 20 mA value (0372-1 to n)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 109):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign curr.** parameter (→ 108). In addition, the value can be greater than or smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→ 110).

Dependency

The unit depends on the process variable selected in the **Assign curr.** parameter (→ 108).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse** option is selected in the **Measuring mode** parameter (→ 113), different signs cannot be entered for the values of the **0/4 mA value** parameter (→ 110) and **20 mA value** parameter (→ 112). The diagnostic message **△S441 Curr.output 1 to n** is displayed.

Configuration examples

Observe the configuration examples for the **0/4 mA value** parameter (→ 110).

Measuring mode**Navigation**

Expert → Output → Curr.output 1 to n → Measuring mode (0351-1 to n)

Prerequisite

In the **Current span** parameter (→ 109), one of the following options is selected:

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse *
- Rev. flow comp.

Factory setting

Forward flow

Additional information*Description*

The process variable that is assigned to the current output via the **Assign curr.** parameter (→ 108) is displayed below the parameter.


"Forward flow" option

The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Both values are defined such that they are not equal to zero flow e.g.:

- 0/4 mA current value = -5 m³/h
- 20 mA current value = 10 m³/h

"Forward/Reverse" option

- | | |
|----------|--------------------------------------|
| <i>I</i> | <i>Current</i> |
| <i>Q</i> | <i>Flow</i> |
| 1 | Value assigned to the 0/4 mA current |
| 2 | Forward flow |
| 3 | Reverse flow |

* Visibility depends on order options or device settings

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (\rightarrow 110) and **20 mA value** parameter (\rightarrow 112) must have the same sign.
- The value for the **20 mA value** parameter (\rightarrow 112) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (\rightarrow 112) (e.g. forward flow).

"Rev. flow comp." option

The **Rev. flow comp.** option is primarily used to compensate for abrupt reverse flow which can occur in connection with positive displacement pumps as a result of wear or high viscosity. The reverse flows are recorded in a buffer and balanced against forward flow the next time flow is in the forward direction.

Flow values can aggregate in the buffer in the event of prolonged and unwanted fluid reverse flow. However, these flows are not taken into consideration by the current output configuration, i.e. the reverse flow is not compensated.

If this option is set, the measuring device does not attenuate the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1

Defined measuring range: lower range value and upper range value with the **same** sign




Fig. 3 Measuring range

- | | |
|---|--|
| I | Current |
| Q | Flow |
| 1 | Lower range value (value assigned to 0/4 mA current) |
| 2 | Upper range value (value assigned to 20 mA current) |

With the following flow response:





Fig. 4 Flow response

- | | |
|---|------|
| Q | Flow |
| t | Time |

With **Forward flow** option


The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output.:



I Current
t Time

With Forward/Reverse option


The current output signal is independent of the direction of flow.



I Current
t Time

With Rev. flow comp. option


Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



I Current
t Time
S Flow components saved
A Balancing of saved flow components

Example 2


Defined measuring range: lower range value and upper range value with **different** signs



5 Measuring range

- I* Current
Q Flow
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With flow a (—) outside, b (- -) inside the measuring range



A0028098


 Q Flow t Time

1 Lower range value (value assigned to 0/4 mA current)

2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

- a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output.
- b (- -): The current output signal is proportional to the process variable assigned.




A0028100

 I Current t TimeWith **Forward/Reverse** option

This option is not possible in this case as the values for the **0/4 mA value** parameter (→ 110) and **20 mA value** parameter (→ 112) have different signs.

With **Rev. flow comp.** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0028101

 I Current t Time S Flow components saved A Balancing of saved flow components

Damping out. 1 to n**Navigation**

Expert → Output → Curr.output 1 to n → Damping out. 1 to n (0363–1 to n)

Prerequisite

A process variable is selected in the **Assign curr.** parameter (→ [108](#)) and one of the following options is selected in the **Current span** parameter (→ [109](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

1.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element⁴⁾) for current output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Damping is switched off if **0** is entered (factory setting).

Response time**Navigation**

Expert → Output → Curr.output 1 to n → Response time (0378–1 to n)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ [109](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

Additional information

Description

The response time is made up of the time specified for the following dampings:

- Current output damping → [117](#)
and
- Depending on the measured variable assigned to the output.
Flow damping

4) proportional transmission behavior with first order delay

Failure mode**Navigation**

Expert → Output → Curr.output 1 to n → Failure mode (0364–1 to n)

Prerequisite

A process variable is selected in the **Assign curr.** parameter (→ [108](#)) and one of the following options is selected in the **Current span** parameter (→ [109](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- 0...20 mA

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

Factory setting

Max.

Additional information*Description*

This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ [109](#)).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ [109](#)).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

The measured value is defined via the **Failure current** parameter (→ [119](#)).

Failure current

Navigation Expert → Output → Curr.output 1 to n → Failure current (0352–1 to n)

Prerequisite The **Defined value** option is selected in the **Failure mode** parameter (→ [118](#)).

Description Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry 0 to 22.5 mA

Factory setting 22.5 mA

Output curr. 1 to n

Navigation Expert → Output → Curr.output 1 to n → Output curr. 1 to n (0361–1 to n)

Description Displays the current value currently calculated for the current output.

User interface 3.59 to 22.5 mA

Measur. curr. 1 to n

Navigation Expert → Output → Curr.output 1 to n → Measur. curr. 1 to n (0366–1 to n)

Description Use this function to display the actual measured value of the output current.

User interface 0 to 30 mA

3.5.2 "Pulse/frequency/switch output 1 to n" submenu

Navigation

Expert → Output → PFS output 1 to n

► PFS output 1 to n

Terminal no. (0492–1 to n)

→ [121](#)

Signal mode (0490–1 to n)

→ [121](#)

Operating mode (0469–1 to n)

→ [121](#)

Assign pulse 1 to n (0460–1 to n)

→ [123](#)

Pulse scaling (0455-1 to n)	→ 123
Pulse width (0452-1 to n)	→ 124
Measuring mode (0457-1 to n)	→ 125
Failure mode (0480-1 to n)	→ 125
Pulse output 1 to n (0456-1 to n)	→ 126
Assign freq. (0478-1 to n)	→ 127
Min. freq. value (0453-1 to n)	→ 127
Max. freq. value (0454-1 to n)	→ 128
Val. at min.freq (0476-1 to n)	→ 128
Val. at max.freq (0475-1 to n)	→ 128
Measuring mode (0479-1 to n)	→ 129
Damping out. 1 to n (0477-1 to n)	→ 129
Response time (0491-1 to n)	→ 130
Failure mode (0451-1 to n)	→ 130
Failure freq. (0474-1 to n)	→ 131
Output freq. 1 to n (0471-1 to n)	→ 131
Switch out funct (0481-1 to n)	→ 131
Assign diag. beh (0482-1 to n)	→ 132
Assign limit (0483-1 to n)	→ 133
Switch-on value (0466-1 to n)	→ 135
Switch-off value (0464-1 to n)	→ 135
Assign dir.check (0484-1 to n)	→ 136
Assign status (0485-1 to n)	→ 136
Switch-on delay (0467-1 to n)	→ 137
Switch-off delay (0465-1 to n)	→ 137

Failure mode (0486-1 to n)	→ 137
Switch status 1 to n (0461-1 to n)	→ 138
Invert outp.sig. (0470-1 to n)	→ 138

Terminal no.

Navigation Expert → Output → PFS output 1 to n → Terminal no. (0492-1 to n)

Description Displays the terminal numbers used by the pulse/frequency/switch output module.

- User interface**
- Not used
 - 24-25 (I/O 2)
 - 22-23 (I/O 3)
 - 20-21 (I/O 4) *

Additional information "Not used" option
The pulse/frequency/switch output module does not use any terminal numbers.

Signal mode



Navigation Expert → Output → PFS output 1 to n → Signal mode (0490-1 to n)

Description Use this function to select the signal mode for the pulse/frequency/switch output.

- Selection**
- Passive
 - Active
 - Passive NAMUR

Factory setting Passive

Operating mode



Navigation Expert → Output → PFS output 1 to n → Operating mode (0469-1 to n)

Description Use this function to select the operating mode of the output as a pulse, frequency or switch output.

- Selection**
- Pulse
 - Frequency
 - Switch

* Visibility depends on order options or device settings

Factory setting Pulse


Additional information "Pulse" option

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume or mass is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s



■ 6 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, mass flow, temperature, sound velocity, flow velocity, acceptance rate, flow asymmetry, turbulence, signal strength or signal-to-noise ratio.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz




■ 7 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




A0026884

8 No alarm, high level

Example

Alarm response in case of alarm



A0026885

9 Alarm, low level

Assign pulse 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Assign pulse 1 to n (0460-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 121) parameter.**Description**

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Correct.vol.flow *
- Mass flow
- Energy flow *

Factory setting

Off

Pulse scaling**Navigation**

Expert → Output → PFS output 1 to n → Pulse scaling (0455-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign pulse** parameter (→ 123).**Description**

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating point number

* Visibility depends on order options or device settings

Factory setting Depends on country and nominal diameter → [240](#)

Additional information *User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width



Navigation Expert → Output → PFS output 1 to n → Pulse width (0452-1 to n)

Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (→ [121](#)) and a process variable is selected in the **Assign pulse** parameter (→ [123](#)).


Description Use this function to enter the duration of the output pulse.

User entry 0.05 to 2 000 ms

Factory setting 100 ms

Additional information *Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to n**.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max} = 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max} = 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode

Navigation Expert → Output → PFS output 1 to n → Measuring mode (0457–1 to n)

Description Use this function to select the measuring mode for the pulse output.

- Selection**
- Forward flow
 - Forward/Reverse
 - Reverse flow
 - Rev. flow comp.

Factory setting Forward flow

Additional information *Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Rev. flow comp.
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.

For a detailed description of the options available, see the **Measuring mode** parameter (→ 113)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 113)

Failure mode

Navigation Expert → Output → PFS output 1 to n → Failure mode (0480–1 to n)

Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign pulse** parameter (→ 123).

Description Use this function to select the failure mode of the pulse output in the event of a device alarm.

- Selection**
- Actual value
 - No pulses

Factory setting No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

*Selection***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Pulse output 1 to n (0456-1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 121) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description***■ The pulse output is an open collector output.**

This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.



0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert outp.sig.** parameter (→ 138) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 125)) can be configured.

Assign freq.**Navigation**

Expert → Output → PFS output 1 to n → Assign freq. (0478–1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121).

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.

Factory setting

Off

Min. freq. value**Navigation**

Expert → Output → PFS output 1 to n → Min. freq. value (0453–1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign freq.** parameter (→ 127).

Description

Use this function to enter the minimum frequency.

User entry

0.0 to 10 000.0 Hz

Factory setting

0.0 Hz

* Visibility depends on order options or device settings

Max. freq. value

Navigation Expert → Output → PFS output 1 to n → Max. freq. value (0454–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign freq.** parameter (→ 127).

Description Use this function to enter the end value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 10 000.0 Hz

Val. at min.freq

Navigation Expert → Output → PFS output 1 to n → Val. at min.freq (0476–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign freq.** parameter (→ 127).

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Dependency*

The entry depends on the process variable selected in the **Assign freq.** parameter (→ 127).

Val. at max.freq

Navigation Expert → Output → PFS output 1 to n → Val. at max.freq (0475–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign freq.** parameter (→ 127).

Description Use this function to enter the measured value for the end value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information*Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

 The entry depends on the process variable selected in the **Assign freq.** parameter (→ 127).

Measuring mode**Navigation**

 Expert → Output → PFS output 1 to n → Measuring mode (0479–1 to n)

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse
- Rev. flow comp.

Factory setting

Forward flow

Additional information*Selection*

 For a detailed description of the options available, see the **Measuring mode** parameter (→ 113)

Examples

 For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 113)

Damping out. 1 to n**Navigation**

 Expert → Output → PFS output 1 to n → Damping out. 1 to n (0477–1 to n)

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element⁵⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

 Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time**Navigation**

 Expert → Output → PFS output 1 to n → Response time (0491–1 to n)

Description

Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

Additional information*Description*

The response time is made up of the time specified for the following dampings:

- Damping of pulse/frequency/switch output →  117
and
- Depending on the measured variable assigned to the output.
 - Flow damping
 - or
 - Temperature damping

Failure mode**Navigation**

 Expert → Output → PFS output 1 to n → Failure mode (0451–1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→  121) and a process variable is selected in the **Assign freq.** parameter (→  127).

Description

Use this function to select the failure mode of the frequency output in the event of a device alarm.

Selection

- Actual value
- Defined value
- 0 Hz

Factory setting

0 Hz

5) proportional transmission behavior with first order delay

Additional information*Selection*

■ Actual value

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

■ Defined value

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure freq. (→ 131) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

■ 0 Hz

In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Failure freq.**Navigation**

Expert → Output → PFS output 1 to n → Failure freq. (0474-1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121) and a process variable is selected in the **Assign freq.** parameter (→ 127).

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 12 500.0 Hz

Factory setting

0.0 Hz

Output freq. 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Output freq. 1 to n (0471-1 to n)

Prerequisite

In the **Operating mode** parameter (→ 121), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Switch out funct**Navigation**

Expert → Output → PFS output 1 to n → Switch out funct (0481-1 to n)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 121).

Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none">■ Off■ On■ Diag. behavior■ Limit■ Fl. direct.check■ Status
Factory setting	Off
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">■ Off The switch output is permanently switched off (open, non-conductive).■ On The switch output is permanently switched on (closed, conductive).■ Diag. behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.■ Status Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diag. beh



Navigation	Expert → Output → PFS output 1 to n → Assign diag. beh (0482-1 to n)
Prerequisite	<ul style="list-style-type: none">■ In the Operating mode parameter (→ 121), the Switch option is selected.■ In the Switch out funct parameter (→ 131), the Diag. behavior option is selected.
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none">■ Alarm■ Alarm or warning■ Warning
Factory setting	Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to n → Assign limit (0483–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch out funct** parameter (→ 131).

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting


Volume flow

* Visibility depends on order options or device settings

Additional information**Description**

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



1 Switch-on value

2 Switch-off value

3 Conductive


4 Non-conductive

A Process variable

B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive



1 Switch-off value

2 Switch-on value

3 Conductive


4 Non-conductive

A Process variable

B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output 1 to n → Switch-on value (0466-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [121](#)).
- The **Limit** option is selected in the **Switch out funct** parameter (→ [131](#)).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-dependent

Additional information

Description

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ [133](#)).

Switch-off value



Navigation

Expert → Output → PFS output 1 to n → Switch-off value (0464-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [121](#)).
- The **Limit** option is selected in the **Switch out funct** parameter (→ [131](#)).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting	Country-dependent
Additional information	<p>Description</p> <p>Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p> <p>Dependency</p> <p> The unit depends on the process variable selected in the Assign limit parameter (→ 133).</p>

Assign dir.check

Navigation	  Expert → Output → PFS output 1 to n → Assign dir.check (0484-1 to n)
Prerequisite	<ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter (→ 121). The Fl. direct.check option is selected in the Switch out funct parameter (→ 131).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	<ul style="list-style-type: none"> Off Volume flow Correct.vol.flow * Mass flow Flow velocity * Energy flow *
Factory setting	Volume flow

Assign status

Navigation	  Expert → Output → PFS output 1 to n → Assign status (0485-1 to n)
Prerequisite	<ul style="list-style-type: none"> The Switch option is selected in the Operating mode parameter (→ 121). The Status option is selected in the Switch out funct parameter (→ 131).
Description	Use this function to select a device status for the switch output.
Selection	<ul style="list-style-type: none"> Off Low flow cut off
Factory setting	Low flow cut off

* Visibility depends on order options or device settings

Additional information*Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay**Navigation**

Expert → Output → PFS output 1 to n → Switch-on delay (0467-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch out funct** parameter (→ 131).

Description

Use this function to enter a delay time for switching on the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Switch-off delay**Navigation**

Expert → Output → PFS output 1 to n → Switch-off delay (0465-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch out funct** parameter (→ 131).

Description

Use this function to enter a delay time for switching off the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Failure mode**Navigation**

Expert → Output → PFS output 1 to n → Failure mode (0486-1 to n)

Description

Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Options*

■ Actual status

In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.

■ Open

In the event of a device alarm, the switch output's transistor is set to **non-conductive**.

■ Closed

In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Switch status 1 to n (0461-1 to n)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 121).

Description

Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

■ Open

The switch output is not conductive.

■ Closed

The switch output is conductive.

Invert outp.sig.**Navigation**

Expert → Output → PFS output 1 to n → Invert outp.sig. (0470-1 to n)

Description

Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting


No

Additional information*Selection*

No option (passive - negative)



Yes option (passive - positive)



3.5.3 "Relay output 1 to n" submenu

Navigation

Expert → Output → Relay output 1 to n

► Relay output 1 to n	
Terminal no.	→ 139
Relay outp.func.	→ 140
Assign dir.check	→ 140
Assign limit	→ 141
Assign diag. beh	→ 142
Assign status	→ 142
Switch-off value	→ 142
Switch-off delay	→ 143
Switch-on value	→ 143
Switch-on delay	→ 144
Failure mode	→ 144
Switch status	→ 144
Powerless relay	→ 145

Terminal no.

Navigation

Expert → Output → Relay output 1 to n → Terminal no. (0812-1 to n)

Description

Displays the terminal numbers used by the relay output module.

User interface	<ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 22-23 (I/O 3) ■ 20-21 (I/O 4)
Additional information	<p><i>"Not used" option</i></p> <p>The relay output module does not use any terminal numbers.</p>

Relay outp.func.



Navigation	  Expert → Output → Relay output 1 to n → Relay outp.func. (0804–1 to n)
Description	Use this function to select an output function for the relay output.
Selection	<ul style="list-style-type: none"> ■ Closed ■ Open ■ Diag. behavior ■ Limit ■ Fl. direct.check ■ Digital Output
Factory setting	Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Closed The relay output is permanently switched on (closed, conductive). ■ Open The relay output is permanently switched off (open, non-conductive). ■ Diag. behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ■ Fl. direct.check Indicates the flow direction (forward or reverse flow). ■ Digital Output Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign dir.check



Navigation	  Expert → Output → Relay output 1 to n → Assign dir.check (0808–1 to n)
Prerequisite	In the Relay outp.func. parameter (→  140), the Fl. direct.check option is selected.
Description	Use this function to select a process variable for monitoring the flow direction.

Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Correct.vol.flow * ■ Mass flow ■ Flow velocity * ■ Energy flow
------------------	---

Factory setting	Volume flow
------------------------	-------------

Assign limit

Navigation Expert → Output → Relay output 1 to n → Assign limit (0807–1 to n)

Prerequisite The **Limit** option is selected in the **Relay outp.func.** parameter (→ 140).

Description Use this function to select a process variable for the limit value function.

Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Correct.vol.flow * ■ Mass flow ■ Flow velocity ■ Sound velocity * ■ Temperature * ■ Pressure * ■ Methane fraction * ■ Molar mass * ■ Density * ■ Dynam. viscosity * ■ Calorific value * ■ Wobbe index * ■ Energy flow * ■ Signal strength * ■ SNR * ■ Acceptance rate * ■ Turbulence * ■ Flow asymmetry * ■ Electronic temp. ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3
------------------	---

Factory setting	Volume flow
------------------------	-------------

* Visibility depends on order options or device settings

Assign diag. beh



Navigation

Expert → Output → Relay output 1 to n → Assign diag. beh (0806–1 to n)

Prerequisite

In the **Relay outp.func.** parameter (→ 140), the **Diag. behavior** option is selected.

Description

Use this function to select the category of the diagnostic events that are displayed for the relay output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting

Alarm

Additional information

Description

If no diagnostic event is pending, the relay output is closed and conductive.

Selection

- Alarm
The relay output signals only diagnostic events in the alarm category.
- Alarm or warning
The relay output signals diagnostic events in the alarm and warning category.
- Warning
The relay output signals only diagnostic events in the warning category.

Assign status



Navigation

Expert → Output → Relay output 1 to n → Assign status (0805–1 to n)

Prerequisite

In the **Relay outp.func.** parameter (→ 140), the **Digital Output** option is selected.

Description

Use this function to select the device status for the relay output.

Selection

- Off
- Low flow cut off

Factory setting

Off

Switch-off value



Navigation

Expert → Output → Relay output 1 to n → Switch-off value (0809–1 to n)

Prerequisite

In the **Relay outp.func.** parameter (→ 140), the **Limit** option is selected.

Description

Use this function to enter the measured value for the switch-off point.

User entry	Signed floating-point number
Factory setting	0 m ³ /h
Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p>
	<p><i>Dependency</i></p> <p> The unit is dependent on the process variable selected in the Assign limit parameter (→ 141).</p>

Switch-off delay



Navigation	 Expert → Output → Relay output 1 to n → Switch-off delay (0813-1 to n)
Prerequisite	In the Relay outp.func. parameter (→ 140), the Limit option is selected.
Description	Use this function to enter a delay time for switching off the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Switch-on value



Navigation	 Expert → Output → Relay output 1 to n → Switch-on value (0810-1 to n)
Prerequisite	The Limit option is selected in the Relay outp.func. parameter (→ 140).
Description	Use this function to enter the measured value for the switch-on point.
User entry	Signed floating-point number
Factory setting	0 m ³ /h
Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p>
	<p><i>Dependency</i></p> <p> The unit is dependent on the process variable selected in the Assign limit parameter (→ 141).</p>

Switch-on delay

Navigation	Expert → Output → Relay output 1 to n → Switch-on delay (0814–1 to n)
Prerequisite	In the Relay outp.func. parameter (→ 140), the Limit option is selected.
Description	Use this function to enter a delay time for switching on the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Failure mode

Navigation	Expert → Output → Relay output 1 to n → Failure mode (0811–1 to n)
Description	Use this function to select the failure mode of the relay output in the event of a device alarm.
Selection	<ul style="list-style-type: none">■ Actual status■ Open■ Closed
Factory setting	Open
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">■ Actual status In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the relay output. The Actual status option behaves in the same way as the current input value.■ Open In the event of a device alarm, the relay output's transistor is set to non-conductive.■ Closed In the event of a device alarm, the relay output's transistor is set to conductive.

Switch status

Navigation	Expert → Output → Relay output 1 to n → Switch status (0801–1 to n)
Description	Displays the current status of the relay output.
User interface	<ul style="list-style-type: none">■ Open■ Closed

Additional information*User interface*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

Powerless relay**Navigation**

Expert → Output → Relay output 1 to n → Powerless relay (0816–1 to n)

Description

Use this function to select the quiescent state for the relay output.

Selection

- Open
- Closed

Factory setting

Open

Additional information*Selection*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

3.5.4 "Double pulse output" submenu*Navigation*

Expert → Output → Double pulse out

► Double pulse out	
Master term. no. (0981)	→ 146
Slave term. no. (0990)	→ 146
Signal mode (0991)	→ 146
Assign pulse 1 (0982–1)	→ 147
Value per pulse (0983)	→ 147
Pulse width (0986)	→ 147
Phase shift (0992)	→ 148
Measuring mode (0984)	→ 148

Failure mode (0985)	→ 149
Pulse output (0987)	→ 149
Invert outp.sig. (0993)	→ 149

Master term. no.

Navigation Expert → Output → Double pulse out → Master term. no. (0981)

Description Displays the master terminal number for the double pulse output.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information "Not used" option
The double pulse output does not use any terminal numbers.

Slave term. no.

Navigation Expert → Output → Double pulse out → Slave term. no. (0990)

Description Displays the slave terminal number for the double pulse output.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information "Not used" option
The double pulse output does not use any terminal numbers.

Signal mode

Navigation Expert → Output → Double pulse out → Signal mode (0991)

Description Use this function to select the signal mode for the double pulse output.

Selection

- Passive
- Active
- Passive NAMUR

Factory setting Passive

Assign pulse 1

Navigation	Expert → Output → Double pulse out → Assign pulse 1 (0982-1)
Description	Use this function to select a process variable for the double pulse output.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Correct.vol.flow * ■ Mass flow ■ Energy flow *
Factory setting	Off

Value per pulse

Navigation	Expert → Output → Double pulse out → Value per pulse (0983)
Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<p><i>User entry</i></p> <p>Weighting of the pulse output with a quantity. The lower the pulse value, the</p> <ul style="list-style-type: none"> ■ better the resolution. ■ the higher the frequency of the pulse response.

Pulse width

Navigation	Expert → Output → Double pulse out → Pulse width (0986)
Description	Use this function to enter the duration of the output pulse.
User entry	0.5 to 2 000 ms
Factory setting	0.5 ms
Additional information	For a detailed description and example: Pulse width parameter (→ 124)

* Visibility depends on order options or device settings

Phase shift**Navigation**

Expert → Output → Double pulse out → Phase shift (0992)

Description

Use this function to select the degree of phase shift.

Selection

- 90°
- 180°

Factory setting

90°

Additional information*Selection*

- 90°
Phase shift by a quarter period.
- 180°
Phase shift by a half period, which is equivalent to a phase reversal.

Measuring mode**Navigation**

Expert → Output → Double pulse out → Measuring mode (0984)

Description

Use this function to select the measuring mode for the double pulse output.

Selection

- Forward flow
- Forward/Reverse
- Reverse flow
- Rev. flow comp.

Factory setting

Forward flow

Additional information*Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Rev. flow comp.
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.

For a detailed description of the options available, see the **Measuring mode** parameter (→ 113)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 113)

Failure mode**Navigation**

Expert → Output → Double pulse out → Failure mode (0985)

Description

Use this function to select the failure mode of the double pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the double pulse output shows a predefined behavior in the event of a device alarm.

Selection

- Actual value

In the event of a device alarm, the double pulse output continues on the basis of the current flow measurement. The fault is ignored.

- No pulses

In the event of a device alarm, the double pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output**Navigation**

Expert → Output → Double pulse out → Pulse output (0987)

Description

Displays the pulse frequency of the double pulse output which is currently output.

User interface

Positive floating-point number

Additional information

For a detailed description and example: **Pulse output** parameter (→ 59)

Invert outp.sig.**Navigation**

Expert → Output → Double pulse out → Invert outp.sig. (0993)

Description

Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting


No

Additional information*Selection*

No option (passive - negative)




Yes option (passive - positive)



3.6 "Communication" submenu

Navigation


Expert → Communication



3.6.1 "HART input" submenu

Navigation

Expert → Communication → HART input



"Configuration" submenu*Navigation*

Expert → Communication → HART input → Configuration

► Configuration	
Capture mode (7001)	→ 151
Device ID (7007)	→ 152
Device type (7008)	→ 152
Manufacturer ID (7009)	→ 152
Burst command (7006)	→ 153
Slot number (7010)	→ 153
Timeout (7005)	→ 154
Failure mode (7011)	→ 154
Failure value (7012)	→ 155

Capture mode**Navigation**

Expert → Communication → HART input → Configuration → Capture mode (7001)

Description

Use this function to select the capture mode via burst or master communication.

Selection

- Off
- Burst network
- Master network

Factory setting

Off

Additional information*"Burst network" option*

The device records data transmitted via burst in the network.

An external pressure sensor must be in the burst mode.

"Master network" option

In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.

Device ID**Navigation**

Expert → Communication → HART input → Configuration → Device ID (7007)

Prerequisite

The **Master network** option is selected in the **Capture mode** parameter (→ 151).

Description

Use this function to enter the device ID of the HART slave device whose data are to be recorded.

User entry

6-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting

0

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type**Navigation**

Expert → Communication → HART input → Configuration → Device type (7008)

Prerequisite

In the **Capture mode** parameter (→ 151), the **Master network** option is selected.

Description

Use this function to enter the device type of the HART slave device whose data are to be recorded.

User entry

2-digit hexadecimal number

Factory setting

0x00

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Manufacturer ID**Navigation**

Expert → Communication → HART input → Configuration → Manufacturer ID (7009)

Prerequisite

The **Master network** option is selected in the **Capture mode** parameter (→ 151).

Description

Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.

User entry

2-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting	0
-----------------	---

Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.
------------------------	--

Burst command



Navigation	 Expert → Communication → HART input → Configuration → Burst command (7006)
Prerequisite	The Burst network option or the Master network option are selected in the Capture mode parameter (→  151).
Description	Use this function to select the burst command to be recorded.
Selection	<ul style="list-style-type: none">■ Command 1■ Command 3■ Command 9■ Command 33
Factory setting	Command 1
Additional information	<i>Selection</i> <ul style="list-style-type: none">■ Command 1 Use this function to capture the primary variable.■ Command 3 Use this function to capture the dynamic HART variables and the current.■ Command 9 Use this function to capture the dynamic HART variables including the associated status.■ Command 33 Use this function to capture the dynamic HART variables including the associated unit.

Slot number



Navigation	 Expert → Communication → HART input → Configuration → Slot number (7010)
Prerequisite	The Burst network option or the Master network option is selected in the Capture mode parameter (→  151).
Description	Use this function to enter the position of the process variable to be recorded in the burst command.
User entry	1 to 8
Factory setting	1

Additional information*User entry*

Slot	Command			
	1	3	9	33
1	PV	PV	HART variable (slot 1)	HART variable (slot 1)
2	-	SV	HART variable (slot 2)	HART variable (slot 2)
3	-	TV	HART variable (slot 3)	HART variable (slot 3)
4	-	QV	HART variable (slot 4)	HART variable (slot 4)
5	-	-	HART variable (slot 5)	-
6	-	-	HART variable (slot 6)	-
7	-	-	HART variable (slot 7)	-
8	-	-	HART variable (slot 8)	-

Timeout**Navigation**

Expert → Communication → HART input → Configuration → Timeout (7005)

Prerequisite

The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→ 151).

Description

Use this function to enter the maximum permitted interval between two HART frames.

User entry

1 to 120 s

Factory setting

5 s

Additional information*Description*

- If the interval is exceeded, the measuring device displays the diagnostic message **⊗F882 Input signal**.

Failure mode**Navigation**

Expert → Communication → HART input → Configuration → Failure mode (7011)

Prerequisite

In the **Capture mode** parameter (→ 151), the **Burst network** option or **Master network** option is selected.

Description

Use this function to select the device behavior if no data are recorded within the maximum permitted interval.

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information*Options*

- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used: (**Failure value** parameter (→ 155)).

Failure value**Navigation**

Expert → Communication → HART input → Configuration → Failure value (7012)

Prerequisite

The following conditions are met:

- In the **Capture mode** parameter (→ 151), the **Burst network** option or **Master network** option is selected.
- In the **Failure mode** parameter (→ 154), the **Defined value** option is selected.

Description

Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.

User entry

Signed floating-point number

Factory setting

1.01325 bar

Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ 69)

"Input" submenu*Navigation*

Expert → Communication → HART input → Input

► Input		
Value (7003)	→ 155	
Status (7004)	→ 156	

Value**Navigation**

Expert → Communication → HART input → Input → Value (7003)

Description

Displays the value of the device variable recorded by the HART input.

User interface Signed floating-point number

Status

Navigation  Expert → Communication → HART input → Input → Status (7004)

Description Displays the value of the device variable recorded by the HART input in accordance with the HART specification.

User interface

- Manual/Fixed
- Good
- Poor accuracy
- Bad

Additional information *Description*

If the measuring device reads in an invalid pressure measured value, the diagnostic message **XF882 Input signal** is output

3.6.2 "HART output" submenu

Navigation  Expert → Communication → HART output

► HART output	
► Configuration	→  156
► Burst config.	→  158
► Information	→  165
► Output	→  168

"Configuration" submenu

Navigation  Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→  157
Device tag (0215)	→  157
HART address (0219)	→  157

No. of preambles (0217)	→ 158
Fieldb.writ.acc. (0273)	→ 158

HART short tag

Navigation	Expert → Communication → HART output → Configuration → HART short tag (0220)
Description	Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).
Factory setting	PROSONIC

Device tag

Navigation	Expert → Communication → HART output → Configuration → Device tag (0215)
Description	Use this function to enter the name for the measuring point.
User entry	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	Prosonic Flow

HART address

Navigation	Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0
Additional information	<i>Description</i> For addressing in a HART Multidrop network, the Fixed current option must be set in the Current span parameter (→ 109) (current output 1).

No. of preambles

Navigation Expert → Communication → HART output → Configuration → No. of preambles (0217)

Description Use this function to enter the number of preambles in the HART protocol.

User entry 2 to 20

Factory setting 5

Additional information *User entry*

As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.

Fieldb.writ.acc.

Navigation Expert → Communication → HART output → Configuration → Fieldb.writ.acc. (0273)

Description Use this function to restrict access to the measuring device via fieldbus (HART interface).

Selection

- Read + write
- Read only

Factory setting Read + write

Additional information *Description*

If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.

Selection

- Read + write
The parameters are readable and writable.
- Read only
The parameters are only readable.

"Burst configuration 1 to n" submenu

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n

► Burst config.

► Burst config. 1 to n

Burst mode 1 to n (2032-1 to n)

→ 159

Burst command 1 to n (2031-1 to n)	→ 160
Burst variable 0 (2033)	→ 161
Burst variable 1 (2034)	→ 162
Burst variable 2 (2035)	→ 162
Burst variable 3 (2036)	→ 162
Burst variable 4 (2037)	→ 162
Burst variable 5 (2038)	→ 163
Burst variable 6 (2039)	→ 163
Burst variable 7 (2040)	→ 163
Trigger mode (2044-1 to n)	→ 163
Trigger level (2043-1 to n)	→ 164
Min. upd. per. (2042-1 to n)	→ 164
Max. upd. per. (2041-1 to n)	→ 165

Burst mode 1 to n

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst mode 1 to n (2032-1 to n)
Description	Use this function to select whether to activate the HART burst mode for burst message X.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Off The measuring device transmits data only when requested by the HART master. ■ On The measuring device transmits data regularly without being requested.

Burst command 1 to n

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst command 1 to n (2031–1 to n)

Description Use this function to select the HART command that is sent to the HART master.

Selection

- Command 1
- Command 2
- Command 3
- Command 9
- Command 33
- Command 48

Factory setting Command 2

Additional information *Selection*

- Command 1
Read out the primary variable.
- Command 2
Read out the current and the main measured value as a percentage.
- Command 3
Read out the dynamic HART variables and the current.
- Command 9
Read out the dynamic HART variables including the related status.
- Command 33
Read out the dynamic HART variables including the related unit.
- Command 48
Read out the complete device diagnostics.

"Command 33" option

The HART device variables are defined via Command 107.

The following measured variables (HART device variables) can be read out:

- Volume flow
- Mass flow
- Temperature
- Totalizer 1...3
- Sound velocity
- Flow velocity
- Acceptance rate *
- Turbulence *
- Signal strength *
- SNR *
- Percent of range
- Measur. curr.
- Primary var (PV)

* Visibility depends on order options or device settings

- Second.var(SV)
- Tertiary var(TV)
- Quaterna.var(QV)

Commands



- Information about the defined details of the command: HART specifications
- The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 106).

Burst variable 0



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 0 (2033)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Percent of range
- Measur. curr.
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input
- Primary var (PV)
- Second.var(SV)
- Tertiary var(TV)
- Quaterna.var(QV)
- Not used

Factory setting

Volume flow

* Visibility depends on order options or device settings

Additional information*Selection*

The **Not used** option is set if a burst message is not configured.

Burst variable 1**Navigation**

④ ⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 1 (2034)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ ④ 161).

Factory setting

Not used

Burst variable 2**Navigation**

④ ⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 2 (2035)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ ④ 161).

Factory setting

Not used

Burst variable 3**Navigation**

④ ⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 3 (2036)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ ④ 161).

Factory setting

Not used

Burst variable 4**Navigation**

④ ⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 4 (2037)

Description

For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 161).

Factory setting Not used

Burst variable 5



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 5 (2038)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 161).

Factory setting Not used

Burst variable 6



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 6 (2039)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 161).

Factory setting Not used

Burst variable 7



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 7 (2040)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 161).

Factory setting Not used

Trigger mode



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Trigger mode (2044-1 to n)

Description Use this function to select the event that triggers burst message X.

Selection	<ul style="list-style-type: none"> ▪ Continuous ▪ Window ▪ Rising ▪ Falling ▪ On change
Factory setting	Continuous
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min per parameter (→ 164). ▪ Window The message is sent if the specified measured value has changed by the value in the Trigger level parameter (→ 164). ▪ Rising The message is sent if the specified measured value exceeds the value in the Trigger level parameter (→ 164). ▪ Falling The message is sent if the specified measured value drops below the value in the Trigger level parameter (→ 164). ▪ On change The message is sent if a measured value changes in the burst message.

Trigger level

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Trigger level (2043–1 to n)
Description	For entering the burst trigger value.
User entry	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>Together with the option selected in the Trigger mode parameter (→ 163) the burst trigger value determines the time of burst message X.</p>

Min. upd. per.

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Min. upd. per. (2042–1 to n)
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	1 000 ms

Max. upd. per.

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Max. upd. per. (2041-1 to n)
Description	Use this function to enter the maximum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	2 000 ms

"Information" submenu

Navigation  Expert → Communication → HART output → Information

 Information	
Device revision (0204)	→  165
Device ID (0221)	→  166
Device type (0209)	→  166
Manufacturer ID (0259)	→  166
HART revision (0205)	→  167
HART descriptor (0212)	→  167
HART message (0216)	→  167
Hardware rev. (0206)	→  167
Software rev. (0224)	→  168
HART date code (0202)	→  168

Device revision

Navigation	 Expert → Communication → HART output → Information → Device revision (0204)
Description	Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface	2-digit hexadecimal number
Factory setting	1
Additional information	<i>Description</i>  The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation	 Expert → Communication → HART output → Information → Device ID (0221)
Description	Use this function to view the device ID for identifying the measuring device in a HART network.
User interface	6-digit hexadecimal number
Additional information	<i>Description</i>  In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	 Expert → Communication → HART output → Information → Device type (0209)
Description	Displays the device type with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x3B (for Prosonic Flow 300/500)
Additional information	<i>Description</i>  The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID

Navigation	 Expert → Communication → HART output → Information → Manufacturer ID (0259)
Description	Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

HART revision

Navigation	 Expert → Communication → HART output → Information → HART revision (0205)
Description	Use this function to display the HART protocol revision of the measuring device.
User interface	5 to 7
Factory setting	7

HART descriptor



Navigation	 Expert → Communication → HART output → Information → HART descriptor (0212)
Description	Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	Pros.Flow300/500

HART message



Navigation	 Expert → Communication → HART output → Information → HART message (0216)
Description	Use this function to enter a HART message which is sent via the HART protocol when requested by the master.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	Pros.Flow300/500

Hardware rev.

Navigation	 Expert → Communication → HART output → Information → Hardware rev. (0206)
Description	Displays the hardware revision of the measuring device.
User interface	0 to 30
Factory setting	1

Software rev.

Navigation   Expert → Communication → HART output → Information → Software rev. (0224)

Description Displays the software revision of the measuring device.

User interface 0 to 255

Factory setting 1

HART date code

Navigation   Expert → Communication → HART output → Information → HART date code (0202)

Description Use this function to enter the date information for individual use.

User entry Date entry format: yyyy-mm-dd

Factory setting 2009-07-20

Additional information *Example*

Device installation date

"Output" submenu

Navigation

  Expert → Communication → HART output → Output

 Output	
Assign PV (0234)	→  169
Primary var (PV) (0201)	→  169
Assign SV (0235)	→  170
Second.var(SV) (0226)	→  170
Assign TV (0236)	→  171
Tertiary var(TV) (0228)	→  172
Assign QV (0237)	→  172
Quaterna.var(QV) (0203)	→  173

Assign PV**Navigation**

Expert → Communication → HART output → Output → Assign PV (0234)

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Off *
- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.

Factory setting

Volume flow

Primary var (PV)**Navigation**

Expert → Communication → HART output → Output → Primary var (PV) (0201)

Description

Displays the current measured value of the primary dynamic variable (PV).

User interface

Signed floating-point number

Additional information

User interface

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→ 169).

Dependency



The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

* Visibility depends on order options or device settings

Assign SV**Navigation**

Expert → Communication → HART output → Output → Assign SV (0235)

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input

Factory setting

Totalizer 1

Second.var(SV)**Navigation**

Expert → Communication → HART output → Output → Second.var(SV) (0226)

Description

Displays the current measured value of the secondary dynamic variable (SV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (→ 170).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 62).

Assign TV**Navigation**

Expert → Communication → HART output → Output → Assign TV (0236)

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Volume flow
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input

Factory setting

Totalizer 2

* Visibility depends on order options or device settings

Tertiary var(TV)

Navigation  Expert → Communication → HART output → Output → Tertiary var(TV) (0228)

Description Displays the current measured value of the tertiary dynamic variable (TV).

User interface Signed floating-point number

Additional information *User interface*

The measured value displayed depends on the process variable selected in the **Assign TV** parameter (→  171).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  62).

Assign QV



Navigation  Expert → Communication → HART output → Output → Assign QV (0237)

Description Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Volume flow *
- Correct.vol.flow *
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Methane fraction *
- Molar mass *
- Density *
- Dynam. viscosity *
- Calorific value *
- Wobbe index *
- Energy flow *
- Signal strength *
- SNR *
- Acceptance rate *
- Turbulence *
- Flow asymmetry *
- Electronic temp.
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input

* Visibility depends on order options or device settings

Factory setting Totalizer 3

Quaterna.var(QV)

Navigation  Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)

Description Displays the current measured value of the quaternary dynamic variable (QV).

User interface Signed floating-point number

Additional information *User interface*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→  172).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  62).

3.6.3 "Web server" submenu

Navigation  Expert → Communication → Web server

 Web server	
Webserv.language (7221)	→  174
MAC Address (7214)	→  174
DHCP client (7212)	→  174
IP address (7209)	→  175
Subnet mask (7211)	→  175
Default gateway (7210)	→  175
Webserver funct. (7222)	→  176
Login page (7273)	→  176

Webserv.language

Navigation	  Expert → Communication → Web server → Webserv.language (7221)
Description	Use this function to select the Web server language setting.
Selection	<ul style="list-style-type: none">■ English■ Deutsch■ Français■ Español■ Italiano■ Nederlands■ Portuguesa■ Polski■ русский язык(Ru)■ Svenska■ Türkçe■ 中文 (Chinese)■ 日本語 (Japanese)■ 한국어 (Korean)■ الْعَرَبِيَّةُ (Ara)■ Bahasa Indonesia■ ภาษาไทย (Thai)■ tiếng Việt (Viet)■ čeština (Czech)
Factory setting	English

MAC Address

Navigation	  Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁶⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format 00:07:05:10:01:5F

DHCP client



Navigation	  Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.

6) Media Access Control

Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off
Additional information	<p><i>Result</i></p> <p>If the DHCP client functionality of the Web server is activated, the IP address (→ 175), Subnet mask (→ 175) and Default gateway (→ 175) are set automatically.</p>
	 <ul style="list-style-type: none"> ■ Identification is via the MAC address of the measuring device. ■ The IP address (→ 175) in the IP address parameter (→ 175) is ignored as long as the DHCP client parameter (→ 174) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→ 175) in the parameter of the same name is only used if the DHCP client parameter (→ 174) is inactive.

IP address

Navigation	 Expert → Communication → Web server → IP address (7209)
Description	Display or enter the IP address of the Web server integrated in the measuring device.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

Subnet mask

Navigation	 Expert → Communication → Web server → Subnet mask (7211)
Description	Display or enter the subnet mask.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	255.255.255.0

Default gateway

Navigation	 Expert → Communication → Web server → Default gateway (7210)
Description	Display or enter the Default gateway (→ 175).
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	0.0.0.0

Webserver funct.**Navigation**

Expert → Communication → Web server → Webserver funct. (7222)

Description

Use this function to switch the Web server on and off.

Selection

- Off
- HTML Off
- On

Factory setting

On

Additional information*Description*

Once disabled, the Webserver funct. can only be re-enabled via or the operating tool FieldCare.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ▪ The web server is completely disabled. ▪ Port 80 is locked.
HTML Off	The HTML version of the web server is not available.
On	<ul style="list-style-type: none"> ▪ The complete functionality of the web server is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Expert → Communication → Web server → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.6.4 "Diag. config." submenu

For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Assign a category to the particular diagnostic event:

Category	Meaning
Failure (F)	A device error is present. The measured value is no longer valid.
Funct. check (C)	The device is in service mode (e.g. during a simulation).

Category	Meaning
Out of spec. (S)	The device is being operated: ■ Outside its technical specification limits (e.g. outside the process temperature range) ■ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
Mainten. req.(M)	Maintenance is required. The measured value is still valid.
No effect (N)	Has no effect on the condensed status ¹⁾ .

1) Condensed status according to NAMUR recommendation NE107

Navigation

Expert → Communication → Diag. config.

► Diag. config.	
Event category 124 (0270)	→ 178
Event category 125 (0271)	→ 178
Event category 160 (0272)	→ 178
Event category 441 (0210)	→ 179
Event category 442 (0230)	→ 179
Event category 443 (0231)	→ 180
Event category 444 (0211)	→ 180
Event category 452 (0265)	→ 180
Event category 543 (0276)	→ 181
Event category 832 (0218)	→ 181
Event category 833 (0225)	→ 182
Event category 834 (0227)	→ 182
Event category 835 (0229)	→ 182
Event category 837 (0266)	→ 183
Event category 840 (0267)	→ 183
Event category 842 (0295)	→ 183
Event category 881 (0268)	→ 184
Event category 930 (0296)	→ 184

Event category 931 (0297)	→ 185
Event category 953 (0292)	→ 185
Event category 954 (0293)	→ 185

Event category 124 (Rel.sig.strength)



Navigation

Expert → Communication → Diag. config. → Event category 124 (0270)

Description

Use this function to select a category for the diagnostic message **124 Rel.sig.strength**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Mainten. req.(M)

Additional information

For a detailed description of the event categories available for selection: → 176

Event category 125 (Rel. sound vel.)



Navigation

Expert → Communication → Diag. config. → Event category 125 (0271)

Description

Use this function to select a category for the diagnostic message **125 Rel. sound vel.**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Mainten. req.(M)

Additional information

For a detailed description of the event categories available for selection: → 176

Event category 160 (Signal path off)



Navigation

Expert → Communication → Diag. config. → Event category 160 (0272)

Description

Use this function to select a category for the diagnostic message **160 Signal path off**.

Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Mainten. req.(M)
Additional information	 For a detailed description of the event categories available for selection: → 176

Event category 441 (Curr.output 1 to n)

Navigation	 Expert → Communication → Diag. config. → Event category 441 (0210)
Description	Use this function to select a category for the diagnostic message 441 Curr.output 1 to n .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	 For a detailed description of the event categories available for selection: → 176

Event category 442 (Freq. output 1 to n)

Navigation	 Expert → Communication → Diag. config. → Event category 442 (0230)
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select a category for the diagnostic message 442 Freq. output 1 to n .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	 For a detailed description of the event categories available for selection: → 176

Event category 443 (Pulse output 1 to n)

Navigation	Expert → Communication → Diag. config. → Event category 443 (0231)
Prerequisite	The pulse/frequency/switch output is available.
Description	Use this function to select a category for the diagnostic message 443 Pulse output 1 to n .
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Funct. check (C)▪ Out of spec. (S)▪ Mainten. req.(M)▪ No effect (N)
Factory setting	Out of spec. (S)
Additional information	For a detailed description of the event categories available for selection: → 176

Event category 444 (Current input 1 to n)

Navigation	Expert → Communication → Diag. config. → Event category 444 (0211)
Prerequisite	The current input is available.
Description	Use this function to select a category for the diagnostic message 444 Current input 1 to n .
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Funct. check (C)▪ Out of spec. (S)▪ Mainten. req.(M)▪ No effect (N)
Factory setting	Out of spec. (S)
Additional information	<i>Selection</i> For a detailed description of the event categories available for selection: → 176

Event category 452 (Calc. error)

Navigation	Expert → Communication → Diag. config. → Event category 452 (0265)
Description	Use this function to select a category for the diagnostic message 452 Calc. error .

Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	 For a detailed description of the event categories available for selection: → 176

Event category 543 (Double pulse out)

Navigation	 Expert → Communication → Diag. config. → Event category 543 (0276)
Description	Use this option to select a category for the diagnostic message 543 Double pulse out .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	 For a detailed description of the event categories available for selection: → 176

Event category 832 (Electronic temp.)

Navigation	 Expert → Communication → Diag. config. → Event category 832 (0218)
Description	Use this function to select a category for the diagnostic message 832 Electronic temp. .
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	<i>Selection</i>  For a detailed description of the event categories available for selection: → 176

Event category 833 (Electronic temp.)

Navigation	Expert → Communication → Diag. config. → Event category 833 (0225)
Description	Use this option to select a category for the diagnostic message 833 Electronic temp..
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	<i>Selection</i> For a detailed description of the event categories available for selection: → 176

Event category 834 (Process temp.)

Navigation	Expert → Communication → Diag. config. → Event category 834 (0227)
Description	Use this option to select a category for the diagnostic message 834 Process temp..
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)
Additional information	<i>Selection</i> For a detailed description of the event categories available for selection: → 176

Event category 835 (Process temp.)

Navigation	Expert → Communication → Diag. config. → Event category 835 (0229)
Description	Use this option to select a category for the diagnostic message 835 Process temp..
Selection	<ul style="list-style-type: none">■ Failure (F)■ Funct. check (C)■ Out of spec. (S)■ Mainten. req.(M)■ No effect (N)
Factory setting	Out of spec. (S)

Additional information*Selection*For a detailed description of the event categories available for selection: → [176](#)**Event category 837 (Process pressure)****Navigation**

Expert → Communication → Diag. config. → Event category 837 (0266)

DescriptionUse this function to select a category for the diagnostic message **837 Process pressure**.**Selection**

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional informationFor a detailed description of the event categories available for selection: → [176](#)**Event category 841 (Sensor range)****Navigation**

Expert → Communication → Diag. config. → Event category 840 (0267)

DescriptionUse this function to select a category for the diagnostic message **841 Sensor range**.**Selection**

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional informationFor a detailed description of the event categories available for selection: → [176](#)**Event category 842 (Process limit)****Navigation**

Expert → Communication → Diag. config. → Event category 842 (0295)

DescriptionUse this function to select a category for the diagnostic message **△S842 Process limit**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information*Selection* For a detailed description of the event categories available for selection: → [176](#)**Event category 881 (Sen.sig. path 1 to n)****Navigation** Expert → Communication → Diag. config. → Event category 881 (0268)**Description**Use this function to select a category for the diagnostic message **881 Sen.sig. path 1 to n.****Selection**

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Mainten. req.(M)

Additional information For a detailed description of the event categories available for selection: → [176](#)**Event category 930 (Process fluid)****Navigation** Expert → Communication → Diag. config. → Event category 930 (0296)**Description**Use this function to select a category for the diagnostic message **△S930 Process fluid.****Selection**

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting

Out of spec. (S)

Additional information*Selection* For a detailed description of the event categories available for selection: → [176](#)

Event category 931 (Process fluid)

Navigation Expert → Communication → Diag. config. → Event category 931 (0297)

Description Use this function to select a category for the diagnostic message **△S931 Process fluid**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information *Selection*

For a detailed description of the event categories available for selection: → [176](#)

Event category 953 (Asy.noise path 1 to n)

Navigation Expert → Communication → Diag. config. → Event category 953 (0292)

Description Use this function to select a category for the diagnostic message **△M953 Asy.noise path 1 to n**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Mainten. req.(M)

Additional information *Selection*

For a detailed description of the event categories available for selection: → [176](#)

Event category 954 (Sound v. dev. hi)

Navigation Expert → Communication → Diag. config. → Event category 954 (0293)

Description Use this function to select a category for the diagnostic message **△S954 Sound v. dev. hi**.

Selection

- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- No effect (N)

Factory setting Out of spec. (S)

Additional information *Selection*

 For a detailed description of the event categories available for selection: → [176](#)

3.6.5 "WLAN settings" submenu

Navigation

 Expert → Communication → WLAN settings

► WLAN settings	
WLAN (2702)	→ 187
WLAN mode (2717)	→ 187
SSID name (2714)	→ 187
Network security (2705)	→ 188
Sec. identific. (2718)	→ 188
User name (2715)	→ 188
WLAN password (2716)	→ 189
WLAN IP address (2711)	→ 189
WLAN MAC address (2703)	→ 189
WLAN subnet mask (2709)	→ 189
WLAN MAC address (2703)	→ 189
WLAN passphrase (2706)	→ 190
WLAN MAC address (2703)	→ 189
Assign SSID name (2708)	→ 190
SSID name (2707)	→ 190
WLAN channel (2704)	→ 191
Select antenna (2713)	→ 191
Connection state (2722)	→ 191

Rec.sig.strength (2721)	→ 192
WLAN IP address (2711)	→ 189
Gateway IP addr. (2719)	→ 192
IP address DNS (2720)	→ 192

WLAN

Navigation Expert → Communication → WLAN settings → WLAN (2702)

Description Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting Enable

WLAN mode

Navigation Expert → Communication → WLAN settings → WLAN mode (2717)

Description Use this function to select the WLAN mode.

Selection

- Access point
- WLAN Client

Factory setting Access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP MSCHAP2 *
- EAP-PEAP NoAuth.*
- EAP-TLS*

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.

Sec. identific.

Navigation Expert → Communication → WLAN settings → Sec. identific. (2718)

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

User interface

- Trust. iss.cert.
- Device certific.
- Dev. private key

User name

Navigation Expert → Communication → WLAN settings → User name (2715)

Description Use this function to enter the username of the WLAN network.

User entry

–

Factory setting

–

* Visibility depends on order options or device settings

WLAN password

Navigation Expert → Communication → WLAN settings → WLAN password (2716)

Description Use this function to enter the WLAN password for the WLAN network.

User entry –

Factory setting –

WLAN IP address

Navigation Expert → Communication → WLAN settings → WLAN IP address (2711)

Description Use this function to enter the IP address of the measuring device's WLAN connection.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 192.168.1.212

WLAN MAC address

Navigation Expert → Communication → WLAN settings → WLAN MAC address (2703)

Description Displays the MAC⁷⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

Factory setting Each measuring device is given an individual address.

Additional information *Example*

For the display format

00:07:05:10:01:5F

WLAN subnet mask

Navigation Expert → Communication → WLAN settings → WLAN subnet mask (2709)

Description Use this function to enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

7) Media Access Control

Factory setting 255.255.255.0

WLAN passphrase



Navigation Expert → Communication → WLAN settings → WLAN passphrase (2706)

Prerequisite The **WPA2-PSK** option is selected in the **Security type** parameter (→ 188).

Description Use this function to enter the network key.

User entry 8 to 32-digit character string comprising numbers, letters and special characters (without spaces)

Factory setting Serial number of the measuring device (e.g. L100A802000)

Assign SSID name



Navigation Expert → Communication → WLAN settings → Assign SSID name (2708)

Description Use this function to select which name is used for the SSID⁸⁾.

Selection

- Device tag
- User-defined

Factory setting User-defined

Additional information *Selection*

- Device tag
The device tag name is used as the SSID.
- User-defined
A user-defined name is used as the SSID.

SSID name



Navigation Expert → Communication → WLAN settings → SSID name (2707)

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (→ 190).
- The **Access point** option is selected in the **WLAN mode** parameter (→ 187).

Description Use this function to enter a user-defined SSID name.

User entry Max. 32-digit character string comprising numbers, letters and special characters

8) Service Set Identifier

Factory setting	EH_device designation_last 7 digits of the serial number (e.g. EH_Prosonic_Flow_500_A802000)
------------------------	---

WLAN channel



Navigation Expert → Communication → WLAN settings → WLAN channel (2704)

Description Use this function to enter the WLAN channel.

User entry 1 to 11

Factory setting 6

Additional information *Description*



- It is only necessary to enter a WLAN channel if multiple WLAN devices are in use.
- If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna



Navigation Expert → Communication → WLAN settings → Select antenna (2713)

Description Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting Internal antenna

Connection state

Navigation Expert → Communication → WLAN settings → Connection state (2722)

Description The connection status is displayed.

User interface

- Connected
- Not connected

Factory setting Not connected

Rec.sig.strength

Navigation	  Expert → Communication → WLAN settings → Rec.sig.strength (2721)
Description	Displays the signal strength received.
User interface	<ul style="list-style-type: none">■ Low■ Medium■ High
Factory setting	High

Gateway IP addr.

Navigation	  Expert → Communication → WLAN settings → Gateway IP addr. (2719)
Description	Use this function to enter the IP address of the gateway.
Factory setting	192.168.1.212

IP address DNS

Navigation	 Expert → Communication → WLAN settings → IP address DNS (2720)
	 Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
Factory setting	192.168.1.212

3.7 "Application" submenu

Navigation	  Expert → Application
 Application	
Reset all tot. (2806)	→  193
 Totalizer 1 to n	→  193
Assign variable (0914-1 to n)	→  194
Unit totalizer 1 to n (0915-1 to n)	→  194

Operation mode (0908-1 to n)	→ 196
Control Tot. 1 to n (0912-1 to n)	→ 196
Preset value 1 to n (0913-1 to n)	→ 197
Failure mode (0901-1 to n)	→ 197

Reset all tot.**Navigation**
 Expert → Application → Reset all tot. (2806)
Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.7.1 "Totalizer 1 to n" submenu*Navigation*
 Expert → Application → Totalizer 1 to n

► Totalizer 1 to n	
Assign variable (0914-1 to n)	→ 194
Unit totalizer 1 to n (0915-1 to n)	→ 194
Operation mode (0908-1 to n)	→ 196
Control Tot. 1 to n (0912-1 to n)	→ 196
Preset value 1 to n (0913-1 to n)	→ 197
Failure mode (0901-1 to n)	→ 197

Assign variable**Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (0914–1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Correct.vol.flow *
- Mass flow
- Energy flow *

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

*Selection*If the **Off** option is selected, only **Assign variable** parameter (→ 194) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.**Unit totalizer 1 to n****Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915–1 to n)

PrerequisiteA process variable is selected in the **Assign variable** parameter (→ 194) of the **Totalizer 1 to n** submenu.**Description**

Use this function to select the process variable unit for the Totalizer 1 to n (→ 193).

Selection*SI units*

- g *
- kg *
- t

US units

- oz *
- lb *
- STon *

* Visibility depends on order options or device settings

or

* Visibility depends on order options or device settings

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ *	■ af*	■ gal (imp)*
■ dm ³ *	■ ft ³ *	■ Mgal (imp)*
■ m ³ *	■ Mft ³ *	■ bbl (imp;beer)*
■ ml*	■ fl oz (us)*	■ bbl (imp;oil)*
■ l*	■ gal (us)*	
■ hl*	■ kgal (us)*	
■ Ml Mega*	■ Mgal (us)*	
	■ bbl (us;liq.)*	
	■ bbl (us;beer)*	
	■ bbl (us;oil)*	
	■ bbl (us;tank)*	

* Visibility depends on order options or device settings

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ NI*	■ Sft ³ *	Sgal (imp)*
■ Nhl*	■ MMSft ³ *	
■ Nm ³ *	■ Sgal (us)*	
■ SI*	■ Sbbl (us;liq.)*	
■ Sm ³ *	■ Sbbl (us;oil)*	

* Visibility depends on order options or device settings

or

<i>SI units</i>	<i>Imperial units</i>
■ kWh*	■ Btu*
■ MWh*	■ MBtu*
■ GWh*	■ MMBtu*
■ kJ*	
■ MJ*	
■ GJ*	
■ kcal*	
■ Mcal*	
■ Gcal*	

* Visibility depends on order options or device settings

or

<i>Other units</i>
None*

* Visibility depends on order options or device settings

Factory setting

Country-specific:

- m³
- ft³

Additional information*Description*

 The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 62).

Selection

The selection is dependent on the process variable selected in the **Assign variable** parameter (→ 194).

Operation mode**Navigation**

 Expert → Application → Totalizer 1 to n → Operation mode (0908-1 to n)

Prerequisite

A process variable is selected in the **Assign variable** parameter (→ 194) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward total
- Reverse total

Factory setting

Net flow total

Additional information*Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward total
Only the flow in the forward flow direction is totalized.
- Reverse total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Tot. 1 to n**Navigation**

 Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912-1 to n)

Prerequisite

A process variable is selected in the **Assign variable** parameter (→ 194) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset+totalize
- Hold

Factory setting

Totalize

Additional information*Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset+totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

Preset value 1 to n**Navigation**

Diagram: Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913–1 to n)

Prerequisite

A process variable is selected in the **Assign variable** parameter (→ 194) of the **Totalizer 1 to n** submenu.

Description

Use this function to enter a start value for the Totalizer 1 to n.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³
- 0 ft³

Additional information*User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 194).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode**Navigation**

Diagram: Expert → Application → Totalizer 1 to n → Failure mode (0901–1 to n)

Prerequisite

A process variable is selected in the **Assign variable** parameter (→ 194) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how a totalizer behaves in the event of a device alarm.


Selection

- Stop
- Actual value
- Last valid value

Factory setting	Stop
Additional information	<i>Description</i>
	 This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.
	<i>Selection</i>
	<ul style="list-style-type: none"> ■ Stop The totalizer is stopped in the event of a device alarm. ■ Actual value The totalizer continues to count based on the actual measured value; the device alarm is ignored. ■ Last valid value The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.7.2 "Inventory count." submenu

Navigation

 Expert → Application → Inventory count.


Unit

Navigation

 Expert → Application → Inventory count. → Unit (0974)

Description

Displays the unit of the inventory counter.

User interface

	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ cm ³	■ ft ³	■ gal (imp)
	■ dm ³	■ af	■ Mgal (imp)
	■ m ³	■ fl oz (us)	■ bbl (imp;beer)
	■ ml	■ gal (us)	■ bbl (imp;oil)
	■ l	■ kgal (us)	
	■ hl	■ Mgal (us)	
	■ Ml Mega	■ bbl (us;oil)	
		■ bbl (us;liq.)	
		■ bbl (us;beer)	
		■ bbl (us;tank)	

Additional information

Description
 The parameter cannot be configured or reset.

3.8 "Diagnostics" submenu

Navigation

Expert → Diagnostics

▶ Diagnostics	
Actual diagnos. (0691)	→ 199
Prev.diagnostics (0690)	→ 200
Time fr. restart (0653)	→ 201
Operating time (0652)	→ 201
▶ Diagnostic list	→ 202
▶ Event logbook	→ 206
▶ Device info	→ 208
▶ Main elec.+I/O1	→ 212
▶ Sens. electronic	→ 213
▶ I/O module 2	→ 215
▶ I/O module 3	→ 216
▶ I/O module 4	→ 218
▶ Display module	→ 219
▶ Data logging	→ 220
▶ Heartbeat	→ 228
▶ Simulation	→ 228

Actual diagnos.

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ [202](#)).

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:
F271 Main electronics

Timestamp**Navigation**

 Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Actual diagnos.** parameter (→ [199](#)).

Example

For the display format:
24d12h13m00s

Prev.diagnostics**Navigation**

  Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite

Two diagnostic events have already occurred.

Description

Displays the diagnostic message that occurred before the current message.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:
F271 Main electronics

Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Prev.diagnostics parameter (→  200).
	<i>Example</i> For the display format: 24d12h13m00s

Time fr. restart

Navigation	  Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)


Operating time

Navigation	  Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.8.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

i Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the **E** key.

Examples

For the display format:

- **F271** Main electronics
- **F276** I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 202).

Example

For the display format:

24d12h13m00s

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

Description

Displays the current diagnostics message with the second-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- F271 Main electronics
- F276 I/O module

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 203).

Example

For the display format:

24d12h13m00s

Diagnostics 3

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Displays the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: <ul style="list-style-type: none">▪  F271 Main electronics▪  F276 I/O module

Timestamp

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  204).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronics
-  F276 I/O module

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (→  204).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronics
-  F276 I/O module

Timestamp

Navigation

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

i The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ [205](#)).


Example

For the display format:
24d12h13m00s

3.8.2 "Event logbook" submenu

Navigation

█ Expert → Diagnostics → Event logbook



Filter options**Navigation**

█ Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information*Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Funct. check (C)
- Out of spec. (S)
- Mainten. req.(M)
- Information (I)

Factory setting

All

Additional information*Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu

The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation

Expert → Diagnostics → Event logbook → Event list



Event list**Navigation**

 Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→  206).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The following symbols indicate whether an event has occurred or has ended:

-  Occurrence of the event
-  End of the event

Examples

For the display format:

- I1091 Configuration modified
 24d12h13m00s
-  F271 Main electronics
 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.8.3 "Device info" submenu*Navigation*

  Expert → Diagnostics → Device info

 Device info	
Device tag (0011)	→  209
Serial number (0009)	→  209
Firmware version (0010)	→  210
Device name (0020)	→  210
Order code (0008)	→  210

Ext. order cd. 1 (0023)	→ 211
Ext. order cd. 2 (0021)	→ 211
Ext. order cd. 3 (0022)	→ 211
Config. counter (0233)	→ 211
ENP version (0012)	→ 212

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Prosonic Flow

Additional information

User interface



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation

Expert → Diagnostics → Device info → Serial number (0009)

Description

Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation

Expert → Diagnostics → Device info → Firmware version (0010)

Description

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name

Navigation

Expert → Diagnostics → Device info → Device name (0020)

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Prosonic Flow 500

Order code

**Navigation**

Expert → Diagnostics → Device info → Order code (0008)

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Ext. order cd. 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Ext. order cd. 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 211)

Ext. order cd. 3**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Ext. order cd. 1** parameter (→ 211)

Config. counter**Navigation**

Expert → Diagnostics → Device info → Config. counter (0233)

Description

Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface


0 to 65 535

ENP version

Navigation	  Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
User interface	Character string
Factory setting	2.02.00
Additional information	<i>Description</i> This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.8.4 "Main elec.+I/O1" submenu

Navigation   Expert → Diagnostics → Mainboard I/O1



Software rev.

Navigation	  Expert → Diagnostics → Mainboard I/O1 → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

Build no. softw.

Navigation	  Expert → Diagnostics → Mainboard I/O1 → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader rev.

Navigation   Expert → Diagnostics → Mainboard I/O1 → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.5 "Sens. electronic" submenu

Navigation

  Expert → Diagnostics → Sens. electronic



Software rev.

Navigation   Expert → Diagnostics → Sens. electronic → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. softw.

Navigation   Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader rev.


Navigation   Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.6 "I/O module 1" submenu

Navigation   Expert → Diagnostics → I/O module 1



I/O 1 terminals

Navigation   Expert → Diagnostics → I/O module 1 → I/O 1 terminals (3902-1)

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

Software rev.

Navigation   Expert → Diagnostics → I/O module → Software rev. (0072)

Description Use this function to display the software revision of the module.

* Visibility depends on order options or device settings

User interface Positive integer

Build no. softw.

Navigation  Expert → Diagnostics → I/O module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader rev.


Navigation  Expert → Diagnostics → I/O module → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.7 "I/O module 2" submenu

Navigation  Expert → Diagnostics → I/O module 2



I/O 2 terminals

Navigation  Expert → Diagnostics → I/O module 2 → I/O 2 terminals (3902-2)

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

Software rev.**Navigation**

  Expert → Diagnostics → I/O module → Software rev. (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. softw.**Navigation**

  Expert → Diagnostics → I/O module → Build no. softw. (0079)

Description

Use this function to display the software build number of the module.

User interface

Positive integer

Bootloader rev.**Navigation**

  Expert → Diagnostics → I/O module → Bootloader rev. (0073)

Description

Use this function to display the bootloader revision of the software.


User interface

Positive integer

3.8.8 "I/O module 3" submenu

Navigation

  Expert → Diagnostics → I/O module 3



* Visibility depends on order options or device settings

Build no. softw. (0079)	→ 217
Bootloader rev. (0073)	→ 217

I/O 3 terminals

Navigation Expert → Diagnostics → I/O module 3 → I/O 3 terminals (3902-3)

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

Software rev.

Navigation Expert → Diagnostics → I/O module → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. softw.

Navigation Expert → Diagnostics → I/O module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader rev.

Navigation Expert → Diagnostics → I/O module → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

* Visibility depends on order options or device settings

User interface

Positive integer

3.8.9 "I/O module 4" submenu

Navigation Expert → Diagnostics → I/O module 4

I/O 4 terminals

Navigation Expert → Diagnostics → I/O module 4 → I/O 4 terminals (3902-4)**Description**

Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)
- 20-21 (I/O 4) *

Software rev.

Navigation Expert → Diagnostics → I/O module → Software rev. (0072)**Description**

Use this function to display the software revision of the module.

User interface

Positive integer

* Visibility depends on order options or device settings

Build no. softw.

Navigation   Expert → Diagnostics → I/O module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader rev.


Navigation   Expert → Diagnostics → I/O module → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.10 "Display module" submenu

Navigation   Expert → Diagnostics → Display module



Software rev.

Navigation   Expert → Diagnostics → Display module → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. softw.

Navigation   Expert → Diagnostics → Display module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader rev.

Navigation   Expert → Diagnostics → Display module → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.11 "Data logging" submenu

Navigation   Expert → Diagnostics → Data logging

 Data logging	
Assign chan. 1 (0851)	→  221
Assign chan. 2 (0852)	→  222
Assign chan. 3 (0853)	→  222
Assign chan. 4 (0854)	→  223
Logging interval (0856)	→  223
Clear logging (0855)	→  224
Data logging (0860)	→  224
Logging delay (0859)	→  224
Data log.control (0857)	→  225
Data log. status (0858)	→  225
Logging duration (0861)	→  226

► Displ.channel 1	→ 226
► Displ.channel 2	→ 227
► Displ.channel 3	→ 227
► Displ.channel 4	→ 228

Assign chan. 1**Navigation**

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **SW option overv.** parameter (→ 45).

Description

Use this function to select a process variable for the data logging channel.

Selection

- Off
- Volume flow
- Correct.vol.flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Methane fraction*
- Molar mass*
- Density*
- Dynam. viscosity*
- Calorific value*
- Wobbe index*
- Energy flow
- Signal strength*
- SNR*
- Acceptance rate*
- Turbulence*
- Flow asymmetry*
- Electronic temp.
- Curr.output 2*
- Curr.output 3*
- Curr.output 4*
- Curr.output 1

Factory setting

Off

* Visibility depends on order options or device settings

Additional information**Description**

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

Assign chan. 2**Navigation**

 Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **SW option overv.** parameter (→  45).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→  221)

Factory setting

Off

Assign chan. 3**Navigation**

 Expert → Diagnostics → Data logging → Assign chan. 3 (0853)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **SW option overv.** parameter (→  45).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→  221)

Factory setting

Off

Assign chan. 4

Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available.
	The software options currently enabled are displayed in the SW option overv. parameter (→ 45).
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→ 221)
Factory setting	Off

Logging interval

Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available.
	The software options currently enabled are displayed in the SW option overv. parameter (→ 45).
Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	0.1 to 3 600.0 s
Factory setting	1.0 s
Additional information	<p><i>Description</i></p> <p>This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log}:</p> <ul style="list-style-type: none"> ▪ If 1 logging channel is used: $T_{log} = 1000 \times t_{log}$ ▪ If 2 logging channels are used: $T_{log} = 500 \times t_{log}$ ▪ If 3 logging channels are used: $T_{log} = 333 \times t_{log}$ ▪ If 4 logging channels are used: $T_{log} = 250 \times t_{log}$ <p>Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{log} always remains in the memory (ring memory principle).</p> <p> The log contents are cleared if the length of the logging interval is changed.</p> <p><i>Example</i></p> <p>If 1 logging channel is used:</p> <ul style="list-style-type: none"> ▪ $T_{log} = 1000 \times 1 \text{ s} = 1\,000 \text{ s} \approx 15 \text{ min}$ ▪ $T_{log} = 1000 \times 10 \text{ s} = 10\,000 \text{ s} \approx 3 \text{ h}$ ▪ $T_{log} = 1000 \times 80 \text{ s} = 80\,000 \text{ s} \approx 1 \text{ d}$ ▪ $T_{log} = 1000 \times 3\,600 \text{ s} = 3\,600\,000 \text{ s} \approx 41 \text{ d}$

Clear logging



Navigation

Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **SW option overv.** parameter (→ 45).

Description

Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information

Selection

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

Data logging



Navigation

Expert → Diagnostics → Data logging → Data logging (0860)

Description

Use this function to select the data logging method.

Selection

- Overwriting
- Not overwriting

Factory setting

Overwriting

Additional information

Selection

- Overwriting
The device memory applies the FIFO principle.
- Not overwriting
Data logging is canceled if the measured value memory is full (single shot).

Logging delay



Navigation

Expert → Diagnostics → Data logging → Logging delay (0859)

Prerequisite

In the **Data logging** parameter (→ 224), the **Not overwriting** option is selected.

Description

Use this function to enter the time delay for measured value logging.

User entry

0 to 999 h

Factory setting 0 h

Additional information *Description*

Once measured value logging has been started with the **Data log.control** parameter (→ 225), the device does not save any data for the duration of the time delay entered.

Data log.control



Navigation Expert → Diagnostics → Data logging → Data log.control (0857)

Prerequisite In the **Data logging** parameter (→ 224), the **Not overwriting** option is selected.

Description Use this function to start and stop measured value logging.

Selection

- None
- Delete + start
- Stop

Factory setting None

Additional information *Selection*

- None
Initial measured value logging status.
- Delete + start
All the measured values recorded for all the channels are deleted and measured value logging starts again.
- Stop
Measured value logging is stopped.

Data log. status

Navigation Expert → Diagnostics → Data logging → Data log. status (0858)

Prerequisite In the **Data logging** parameter (→ 224), the **Not overwriting** option is selected.

Description Displays the measured value logging status.

User interface

- Done
- Delay active
- Active
- Stopped

Factory setting Done

Additional information*Selection*

- Done
Measured value logging has been performed and completed successfully.
- Delay active
Measured value logging has been started but the logging interval has not yet elapsed.
- Active
The logging interval has elapsed and measured value logging is active.
- Stopped
Measured value logging is stopped.

Logging duration

Navigation Expert → Diagnostics → Data logging → Logging duration (0861)**Prerequisite**In the **Data logging** parameter (→ 224), the **Not overwriting** option is selected.**Description**


Displays the total logging duration.

User interface

Positive floating-point number

Factory setting


0 s

"Displ.channel 1" submenu*Navigation* Expert → Diagnostics → Data logging → Displ.channel 1

Display channel 1

Navigation Expert → Diagnostics → Data logging → Displ.channel 1**Prerequisite**The **Extended HistoROM** application package is available. The software options currently enabled are displayed in the **SW option overv.** parameter (→ 45).**Description**

Displays the measured value trend for the logging channel in the form of a chart.

Additional information*Description***图 10** Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Displ.channel 2" submenu*Navigation*

Expert → Diagnostics → Data logging → Displ.channel 2

**Display channel 2****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is defined in the **Assign chan. 2** parameter.

Description

See the **Display channel 1** parameter → 226

"Displ.channel 3" submenu*Navigation*

Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation

Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign chan. 3** parameter.

Description

See the **Display channel 1** parameter → [226](#)

"Displ.channel 4" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign chan. 4** parameter.

Description

See the **Display channel 1** parameter → [226](#)

3.8.12 "Heartbeat" submenu

For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** refer to the Special Documentation for the device → [7](#)

Navigation


Expert → Diagnostics → Heartbeat



3.8.13 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation



Proc. var. value (1811)	→ 230
Status inp.sim (1355)	→ 230
Signal level (1356)	→ 231
Curr.inp 1 to n sim. (1608-1 to n)	→ 231
Value curr.inp 1 to n (1609-1 to n)	→ 232
Curr.out. 1 to n sim. (0354-1 to n)	→ 232
Value curr.out 1 to n (0355-1 to n)	→ 233
FreqOutputSim 1 to n (0472-1 to n)	→ 233
Freq value 1 to n (0473-1 to n)	→ 233
Puls.outp.sim. 1 to n (0458-1 to n)	→ 234
Pulse value 1 to n (0459-1 to n)	→ 234
Switch sim. 1 to n (0462-1 to n)	→ 235
Switch status 1 to n (0463-1 to n)	→ 235
Relay out. 1 to n sim (0802-1 to n)	→ 236
Switch status 1 to n (0803-1 to n)	→ 236
Puls.outp.sim. (0988)	→ 237
Pulse value (0989)	→ 237
Dev. alarm sim. (0654)	→ 237
Event category (0738)	→ 238
Diag. event sim. (0737)	→ 238

Assign proc.var.**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Correct.vol.flow * ■ Mass flow ■ Flow velocity ■ Sound velocity * ■ Temperature * ■ Pressure * ■ Methane fraction * ■ Molar mass * ■ Density * ■ Dynam. viscosity * ■ Calorific value * ■ Wobbe index * ■ Energy flow *
------------------	---

Factory setting	Off
------------------------	-----

Additional information	<i>Description</i>
	<p> The simulation value of the process variable selected is defined in the Proc. var. value parameter (→ 230).</p>

Proc. var. value	
-------------------------	---

Navigation	 Expert → Diagnostics → Simulation → Proc. var. value (1811)
Prerequisite	A process variable is selected in the Assign proc.var. parameter (→ 229).
Description	Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.
User entry	Depends on the process variable selected
Factory setting	0
Additional information	<i>User entry</i>
	<p> The unit of the displayed measured value is taken from the System units submenu (→ 62).</p>

Status inp.sim 1 to n	
------------------------------	---

Navigation	 Expert → Diagnostics → Simulation → Status inp.sim 1 to n (1355–1 to n)
Description	Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

* Visibility depends on order options or device settings

Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Signal level parameter (→ 231).</p>
	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ Off Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ On Simulation for the status input is active.

Signal level 1 to n



Navigation	 Expert → Diagnostics → Simulation → Signal level 1 to n (1356-1 to n)
Prerequisite	In the Status inp.sim parameter (→ 230), the On option is selected.
Description	Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units.
Selection	<ul style="list-style-type: none">▪ High▪ Low

Curr.inp 1 to n sim.



Navigation	 Expert → Diagnostics → Simulation → Curr.inp 1 to n sim. (1608-1 to n)
Description	Option for switching simulation of the current input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
	<p> The desired simulation value is defined in the Value curr.inp 1 to n parameter.</p>
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off

Additional information*Selection*

■ Off

Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

■ On

Current simulation is active.

Value curr.inp 1 to n**Navigation**

Expert → Diagnostics → Simulation → Value curr.inp 1 to n (1609–1 to n)

Prerequisite

In the **Curr.inp 1 to n sim.** parameter, the **On** option is selected.

Description

Use this function to enter the current value for the simulation. In this way, users can verify the correct configuration of the current input and the correct function of upstream feed-in units.

User entry

0 to 22.5 mA

Curr.out. 1 to n sim.**Navigation**

Expert → Diagnostics → Simulation → Curr.out. 1 to n sim. (0354–1 to n)

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

■ Off

■ On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Value curr.out 1 to n** parameter.

Selection

■ Off

Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

■ On

Current simulation is active.

Value curr.out 1 to n

Navigation	Expert → Diagnostics → Simulation → Value curr.out 1 to n (0355–1 to n)
Prerequisite	In the Curr.out. 1 to n sim. parameter, the On option is selected.
Description	Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.
User entry	3.59 to 22.5 mA
Additional information	<i>Dependency</i> The input range is dependent on the option selected in the Current span parameter (→ 109).

FreqOutputSim 1 to n

Navigation	Expert → Diagnostics → Simulation → FreqOutputSim 1 to n (0472–1 to n)
Prerequisite	In the Operating mode parameter (→ 121), the Frequency option is selected.
Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<i>Description</i> The desired simulation value is defined in the Freq value 1 to n parameter. <i>Selection</i> <ul style="list-style-type: none">▪ Off Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ On Frequency simulation is active.

Freq value 1 to n

Navigation	Expert → Diagnostics → Simulation → Freq value 1 to n (0473–1 to n)
Prerequisite	In the FreqOutputSim 1 to n parameter, the On option is selected.

Description Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 12 500.0 Hz

Puls.outp.sim. 1 to n



Navigation Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n (0458–1 to n)

Prerequisite In the **Operating mode** parameter (→ 121), the **Pulse** option is selected.

Description Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-count. val.

Factory setting Off

Additional information *Description*

The desired simulation value is defined in the **Pulse value 1 to n** parameter.

Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 124).
- Down-count. val.
The pulses specified in the **Pulse value** parameter (→ 234) are output.

Pulse value 1 to n



Navigation Expert → Diagnostics → Simulation → Pulse value 1 to n (0459–1 to n)

Prerequisite In the **Puls.outp.sim. 1 to n** parameter, the **Down-count. val.** option is selected.

Description Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry 0 to 65 535

Switch sim. 1 to n

Navigation Expert → Diagnostics → Simulation → Switch sim. 1 to n (0462-1 to n)

Prerequisite In the **Operating mode** parameter (→ 121), the **Switch** option is selected.

Description Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

The desired simulation value is defined in the **Switch status 1 to n** parameter.

Selection

- Off
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Switch simulation is active.

Switch status 1 to n

Navigation Expert → Diagnostics → Simulation → Switch status 1 to n (0463-1 to n)

Description Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information *Selection*

- Open
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Closed
Switch simulation is active.

Relay out. 1 to n sim



Navigation

Expert → Diagnostics → Simulation → Relay out. 1 to n sim (0802–1 to n)

Description

Use this function to switch simulation of the relay output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Switch status 1 to n** parameter.

Selection

- Off
Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Relay simulation is active.

Switch status 1 to n



Navigation

Expert → Diagnostics → Simulation → Switch status 1 to n (0803–1 to n)

Prerequisite

The **On** option is selected in the **Switch sim. 1 to n** parameter parameter.

Description

Use this function to select a relay value for the simulation. In this way, users can verify the correct adjustment of the relay output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information

Selection

- Open
Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Closed
Relay simulation is active.

Puls.outp.sim.**Navigation**

Expert → Diagnostics → Simulation → Puls.outp.sim. (0988)

Description

Use this function to switch simulation of the double pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-count. val.

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value** parameter (→ 237).

Selection

- Off
Simulation of the double pulse output is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 147).
- Down-count. val.
The pulses specified in the **Pulse value** parameter (→ 237) are output.

Pulse value**Navigation**

Expert → Diagnostics → Simulation → Pulse value (0989)

Prerequisite

In the **Puls.outp.sim.** parameter (→ 237), the **Down-count. val.** option is selected.

Description

Use this function to enter a pulse value for simulation of the double pulse output. In this way, users can verify the correct adjustment of the double pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Dev. alarm sim.**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Event category



Navigation Expert → Diagnostics → Simulation → Event category (0738)

Description Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diag. event sim.** parameter (→ 238).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting Process

Diag. event sim.



Navigation Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Event category** parameter (→ 238).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Corrected volume	Nm ³
Corrected volume flow	Nm ³ /h
Density	kg/l
Reference density	kg/Nl
Energy	kWh
Energy flow	kW
Calorific value	kWh/Nm ³
Velocity	m/s
Dynamic viscosity	Pa s
Spec. heat capacity	kJ/(kgK)
Temperature	°C
Pressure	mbar a

4.1.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [mm]	[m ³ /h]
25	50
50	210
80	460
100	800
150	1 800
200	3 200
250	5 000
300	7 100

4.1.3 Output current span

Current output 1 to n	4 to 20 mA NAMUR
-----------------------	------------------

4.1.4 Pulse value

Nominal diameter [mm]	[m ³ /pulse]
25	0.007
50	0.03
80	0.06
100	0.1
150	0.3
200	0.4
250	0.7
300	1.0

4.1.5 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	Switch-on point [m ³ /h]
25	0.17
50	0.68
80	1.5
100	2.7
150	6.0
200	11
250	17
300	24

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft ³
Volume flow	ft ³ /min
Corrected volume	Sft ³
Corrected volume flow	Sft ³ /h
Density	lb/ft ³
Reference density	lb/Sft ³
Energy	Btu
Energy flow	Btu/h
Calorific value	Btu/Sft ³
Velocity	ft/s

Temperature	°F
Pressure	psi a

4.2.2 Full scale values

i The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

Nominal diameter [in]	[ft ³ /hr]
1	1800
2	7300
3	16000
4	28000
6	64000
8	110000
10	180000
12	250000

4.2.3 Output current span

Current output 1 to n	4 to 20 mA US
-----------------------	---------------

4.2.4 Pulse value

Nominal diameter [in]	[ft ³ /pulse]
1	0.2
2	1
3	2
4	4
6	9
8	16
10	25
12	35

4.2.5 On value low flow cut off

i The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	Switch-on point [ft ³ /hr]
1	5.9
2	24
3	54
4	94

Nominal diameter [in]	Switch-on point [ft ³ /hr]
6	213
8	374
10	588
12	832

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Corrected volume	Nl, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Corrected volume flow	Nl/s, Nl/min, Nl/h, Nl/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Density	kg/l	Kilogram/liter
Reference density	kg/Nl	Kilogram/standard liter
Energy	kWh, MWh, GWh	Kilowatt hour, megawatt hour, gigawatt hour
	kJ, MJ, GJ	Kilojoule, megajoule, gigajoule
	kcal, Mcal	Kilocalories, megacalories
Energy flow	kW, MW	Kilowatt, megawatt
	kJ/s, kJ/min, kJ/h, kJ/d	Kilojoule/time unit
	MJ/h, MJ/d	Megajoule/time unit
	kcal/s, kcal/min, kcal/h, kcal/d	Kilocalories/time unit
	Mcal/h, Mcal/d	Megacalories/time unit
Calorific value	kWh/Nm ³ , kJ/Nm ³	Kilowatt hour/standard cubic meter, kilojoule/standard cubic meter
	kWh/Sm ³ , kJ/Sm ³	Kilowatt hour/standard cubic meter, kilojoule/standard cubic meter
Velocity	m/s	Meter/time unit
Dynamic viscosity	Pa s	Pascal second
Specific heat capacity	kJ/(kgK)	Kilojoule/(kilogram Kelvin)
Temperature	°C, K	Celsius, Kelvin
Pressure	Pa, kPa, MPa	Pascal, kilopascal, megapascal
	mbar, bar	Millibar, bar
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Volume	ft ³	Cubic foot
Volume flow	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
Corrected volume	Sft ³	Standard cubic foot
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
Density	lb/ft ³	Pound/cubic foot
Reference density	lb/Sft ³	Pound/standard cubic foot
Energy	kWh, MWh, GWh	Kilowatt hour, megawatt hour, gigawatt hour
	kJ, MJ, GJ	Kilojoule, megajoule, gigajoule
	kcal, Mcal	Kilocalories, megacalories
Energy flow	kW, MW	Kilowatt, megawatt
	kJ/s, kJ/min, kJ/h, kJ/d	Kilojoule/time unit
	MJ/h, MJ/d	Megajoule/time unit
	kcal/s, kcal/min, kcal/h, kcal/d	Kilocalories/time unit
	Mcal/h, Mcal/d	Megacalories/time unit
Calorific value	kWh/Sft ³ , kJ/Sft ³	Kilowatt hour/standard cubic foot, kilojoule/standard cubic foot
Velocity	ft/s	Foot/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Pressure	psi a	Psi absolute
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Energy	Btu, MBtu, MMBtu	British thermal unit, thousand British thermal units, million British thermal units
Energy flow	Btu/s, Btu/min, Btu/h, Btu/day	British thermal unit/time unit
	MBtu/min, MBtu/h, MBtu/d	Thousand British thermal units/time unit
	MMBtu/h, MMBtu/d	Million British thermal units/time unit
Calorific value	Btu/Sm ³ , MBtu/Sm ³	British thermal unit/standard cubic meter, thousand British thermal units/standard cubic meter

Process variable	Units	Explanation
	Btu/Sft ³ , MBtu/Sft ³	British thermal unit/standard cubic foot, thousand British thermal units/standard cubic foot
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

- 0/4 mA value (Parameter) 103, 110
0% bargraph value 1 (Parameter) 19
0% bargraph value 3 (Parameter) 22
2.4 GHz WLAN channel (Parameter) 191
20 mA value (Parameter) 103, 112
100% bargraph value 1 (Parameter) 19
100% bargraph value 3 (Parameter) 22

A

- Acceptance rate (Parameter) 53
Access status (Parameter) 13
Activate SW option (Parameter) 44
Active level (Parameter) 106
Actual diagnostics (Parameter) 199
Additional gas component (Parameter) 84
Administration (Submenu) 41
Alarm delay (Parameter) 31
Application (Submenu) 192
Apply I/O configuration (Parameter) 100
Assign behavior of diagnostic no. 124 (Parameter) 33
Assign behavior of diagnostic no. 125 (Parameter) 33
Assign behavior of diagnostic no. 160 (Parameter) 33
Assign behavior of diagnostic no. 302 (Parameter) 34
Assign behavior of diagnostic no. 441 (Parameter) 34
Assign behavior of diagnostic no. 442 (Parameter) 34
Assign behavior of diagnostic no. 443 (Parameter) 35
Assign behavior of diagnostic no. 444 (Parameter) 35
Assign behavior of diagnostic no. 452 (Parameter) 35
Assign behavior of diagnostic no. 543 (Parameter) 36
Assign behavior of diagnostic no. 832 (Parameter) 36
Assign behavior of diagnostic no. 833 (Parameter) 37
Assign behavior of diagnostic no. 834 (Parameter) 37
Assign behavior of diagnostic no. 835 (Parameter) 37
Assign behavior of diagnostic no. 837 (Parameter) 38
Assign behavior of diagnostic no. 840 (Parameter) 38
Assign behavior of diagnostic no. 842 (Parameter) 38
Assign behavior of diagnostic no. 870 (Parameter) 39
Assign behavior of diagnostic no. 881 (Parameter) 39
Assign behavior of diagnostic no. 930 (Parameter) 40
Assign behavior of diagnostic no. 931 (Parameter) 40
Assign behavior of diagnostic no. 953 (Parameter) 40
Assign behavior of diagnostic no. 954 (Parameter) 41
Assign channel 1 (Parameter) 221
Assign channel 2 (Parameter) 222
Assign channel 3 (Parameter) 222
Assign channel 4 (Parameter) 223
Assign current output 1 to n (Parameter) 108
Assign diagnostic behavior (Parameter) 132, 142
Assign flow direction check (Parameter) 136, 140
Assign frequency output (Parameter) 127
Assign limit (Parameter) 133, 141
Assign process variable (Parameter) 77, 194
Assign pulse output 1 (Parameter) 147
Assign pulse output 1 to n (Parameter) 123
Assign PV (Parameter) 169

- Assign QV (Parameter) 172
Assign simulation process variable (Parameter) 229
Assign SSID name (Parameter) 190
Assign status (Parameter) 136, 142
Assign status input (Parameter) 105
Assign SV (Parameter) 170
Assign TV (Parameter) 171
Atmospheric pressure (Parameter) 86

B

- Backlight (Parameter) 27
Backup state (Parameter) 29
Bootloader revision (Parameter) 213, 214, 215, 216, 217, 219, 220
Build no. software (Parameter) 212, 213, 215, 216, 217, 219, 220
Burst command (Parameter) 153
Burst command 1 to n (Parameter) 160
Burst configuration 1 to n (Submenu) 158
Burst mode 1 to n (Parameter) 159
Burst trigger level (Parameter) 164
Burst trigger mode (Parameter) 163
Burst variable 0 (Parameter) 161
Burst variable 1 (Parameter) 162
Burst variable 2 (Parameter) 162
Burst variable 3 (Parameter) 162
Burst variable 4 (Parameter) 162
Burst variable 5 (Parameter) 163
Burst variable 6 (Parameter) 163
Burst variable 7 (Parameter) 163

C

- Calibration (Submenu) 97
Calibration factor (Parameter) 98
Calorific value (Parameter) 52, 83
Calorific value calculation (Parameter) 79
Calorific value factor (Parameter) 96
Calorific value offset (Parameter) 96
Calorific value type (Parameter) 81
Calorific value unit (Parameter) 71
Capture mode (Parameter) 151
Clear logging data (Parameter) 224
Communication (Submenu) 150
Comparison result (Parameter) 29
Configuration (Submenu) 151, 156
Configuration backup (Submenu) 27
Configuration counter (Parameter) 211
Configuration management (Parameter) 28
Confirm access code (Parameter) 42
Connection state (Parameter) 191
Contrast display (Parameter) 27
Control Totalizer 1 to n (Parameter) 196
Corrected volume flow (Parameter) 50
Corrected volume flow factor (Parameter) 91
Corrected volume flow offset (Parameter) 90
Corrected volume flow unit (Parameter) 66

Corrected volume unit (Parameter)	66
Current input 1 to n (Submenu)	56, 101
Current input 1 to n simulation (Parameter)	231
Current output 1 to n (Submenu)	107
Current output 1 to n simulation (Parameter)	232
Current span (Parameter)	102, 109
D	
Damping output 1 to n (Parameter)	117, 129
Data logging (Parameter)	224
Data logging (Submenu)	220
Data logging control (Parameter)	225
Data logging status (Parameter)	225
Date/time format (Parameter)	73
Decimal places 1 (Parameter)	19
Decimal places 2 (Parameter)	21
Decimal places 3 (Parameter)	23
Decimal places 4 (Parameter)	24
Default gateway (Parameter)	175
Define access code (Parameter)	42
Define access code (Wizard)	41
Density (Parameter)	51
Density calculation (Parameter)	79
Density factor (Parameter)	95
Density offset (Parameter)	95
Density unit (Parameter)	70
Device alarm simulation (Parameter)	237
Device ID (Parameter)	152, 166
Device information (Submenu)	208
Device name (Parameter)	210
Device reset (Parameter)	44
Device revision (Parameter)	165
Device tag (Parameter)	157, 209
Device type (Parameter)	152, 166
DHCP client (Parameter)	174
Diagnostic behavior (Submenu)	31
Diagnostic configuration (Submenu)	176
Diagnostic event category (Parameter)	238
Diagnostic event simulation (Parameter)	238
Diagnostic handling (Submenu)	30
Diagnostic list (Submenu)	202
Diagnostics (Submenu)	199
Diagnostics 1 (Parameter)	202
Diagnostics 2 (Parameter)	203
Diagnostics 3 (Parameter)	204
Diagnostics 4 (Parameter)	204
Diagnostics 5 (Parameter)	205
Direct access	
0/4 mA value	
Current input 1 to n (1606-1 to n)	103
Current output 1 to n (0367-1 to n)	110
0% bargraph value 1 (0123)	19
0% bargraph value 3 (0124)	22
2.4 GHz WLAN channel (2704)	191
20 mA value	
Current input 1 to n (1607-1 to n)	103
Current output 1 to n (0372-1 to n)	112
100% bargraph value 1 (0125)	19
100% bargraph value 3 (0126)	22

Acceptance rate (2912)	53
Access status (0005)	13
Activate SW option (0029)	44
Active level	
Status input 1 to n (1351-1 to n)	106
Actual diagnostics (0691)	199
Additional gas component (3154)	84
Alarm delay (0651)	31
Apply I/O configuration (3907)	100
Assign behavior of diagnostic no. 124 (0774)	33
Assign behavior of diagnostic no. 125 (0775)	33
Assign behavior of diagnostic no. 160 (0776)	33
Assign behavior of diagnostic no. 302 (0742)	34
Assign behavior of diagnostic no. 441 (0657)	34
Assign behavior of diagnostic no. 442 (0658)	34
Assign behavior of diagnostic no. 443 (0659)	35
Assign behavior of diagnostic no. 444 (0740)	35
Assign behavior of diagnostic no. 452 (0713)	35
Assign behavior of diagnostic no. 543 (0643)	36
Assign behavior of diagnostic no. 832 (0675)	36
Assign behavior of diagnostic no. 833 (0676)	37
Assign behavior of diagnostic no. 834 (0677)	37
Assign behavior of diagnostic no. 835 (0678)	37
Assign behavior of diagnostic no. 837 (0714)	38
Assign behavior of diagnostic no. 840 (0680)	38
Assign behavior of diagnostic no. 842 (0638)	38
Assign behavior of diagnostic no. 870 (0726)	39
Assign behavior of diagnostic no. 881 (0724)	39
Assign behavior of diagnostic no. 930 (0639)	40
Assign behavior of diagnostic no. 931 (0640)	40
Assign behavior of diagnostic no. 953 (0636)	40
Assign behavior of diagnostic no. 954 (0637)	41
Assign channel 1 (0851)	221
Assign channel 2 (0852)	222
Assign channel 3 (0853)	222
Assign channel 4 (0854)	223
Assign current output 1 to n (0359-1 to n)	108
Assign diagnostic behavior	
Pulse/frequency/switch output 1 to n (0482-1 to n)	132
Relay output 1 to n (0806-1 to n)	142
Assign flow direction check	
Pulse/frequency/switch output 1 to n (0484-1 to n)	136
Relay output 1 to n (0808-1 to n)	140
Assign frequency output	
Pulse/frequency/switch output 1 to n (0478-1 to n)	127
Assign limit	
Pulse/frequency/switch output 1 to n (0483-1 to n)	133
Relay output 1 to n (0807-1 to n)	141
Assign process variable	
Totalizer 1 to n (0914-1 to n)	194
Assign process variable (1837)	77
Assign pulse output 1 (0982-1)	147
Assign pulse output 1 to n (0460-1 to n)	123
Assign PV (0234)	169
Assign QV (0237)	172

Assign simulation process variable (1810)	229	Control Totalizer 1 to n (0912–1 to n)	196
Assign SSID name (2708)	190	Corrected volume flow (1857)	50
Assign status		Corrected volume flow factor (1856)	91
Pulse/frequency/switch output 1 to n (0485–1 to n)	136	Corrected volume flow offset (1855)	90
Relay output 1 to n (0805–1 to n)	142	Corrected volume flow unit (0558)	66
Assign status input		Corrected volume unit (0575)	66
Status input 1 to n (1352–1 to n)	105	Current input 1 to n simulation (1608–1 to n) . .	231
Assign SV (0235)	170	Current output 1 to n simulation (0354–1 to n) .	232
Assign TV (0236)	171	Current span	
Atmospheric pressure (3024)	86	Current input 1 to n (1605–1 to n)	102
Backlight (0111)	27	Current output 1 to n (0353–1 to n)	109
Backup state (2759)	29	Damping output 1 to n (0363–1 to n)	117
Bootloader revision		Damping output 1 to n (0477–1 to n)	129
I/O module (0073)	215, 216, 217, 219	Data logging (0860)	224
Mainboard I/O1 (0073)	213	Data logging control (0857)	225
Bootloader revision (0073)	214, 220	Data logging status (0858)	225
Build no. software		Date/time format (2812)	73
I/O module (0079)	215, 216, 217, 219	Decimal places 1 (0095)	19
Mainboard I/O1 (0079)	212	Decimal places 2 (0117)	21
Build no. software (0079)	213, 220	Decimal places 3 (0118)	23
Burst command (7006)	153	Decimal places 4 (0119)	24
Burst command 1 to n (2031–1 to n)	160	Default gateway (7210)	175
Burst mode 1 to n (2032–1 to n)	159	Density (1865)	51
Burst trigger level		Density calculation (3102)	79
Burst configuration 1 to n (2043–1 to n)	164	Density factor (1878)	95
Burst trigger mode		Density offset (1877)	95
Burst configuration 1 to n (2044–1 to n)	163	Density unit (0555)	70
Burst variable 0		Device alarm simulation (0654)	237
Burst configuration 1 to n (2033)	161	Device ID (0221)	166
Burst variable 1		Device ID (7007)	152
Burst configuration 1 to n (2034)	162	Device name (0020)	210
Burst variable 2		Device reset (0000)	44
Burst configuration 1 to n (2035)	162	Device revision (0204)	165
Burst variable 3		Device tag (0011)	209
Burst configuration 1 to n (2036)	162	Device tag (0215)	157
Burst variable 4		Device type (0209)	166
Burst configuration 1 to n (2037)	162	Device type (7008)	152
Burst variable 5		DHCP client (7212)	174
Burst configuration 1 to n (2038)	163	Diagnostic event category (0738)	238
Burst variable 6		Diagnostic event simulation (0737)	238
Burst configuration 1 to n (2039)	163	Diagnostics 1 (0692)	202
Burst variable 7		Diagnostics 2 (0693)	203
Burst configuration 1 to n (2040)	163	Diagnostics 3 (0694)	204
Calibration factor (2920)	98	Diagnostics 4 (0695)	204
Calorific value (1893)	52	Diagnostics 5 (0696)	205
Calorific value (3105)	83	Direct access (0106)	11
Calorific value calculation (3103)	79	Display damping (0094)	25
Calorific value factor (1900)	96	Display interval (0096)	24
Calorific value offset (1899)	96	Display language (0104)	15
Calorific value type (3101)	81	Dry methane in % (1863)	50
Calorific value unit (0552)	71	Dynamic viscosity (1887)	52
Capture mode (7001)	151	Dynamic viscosity (3106)	84
Clear logging data (0855)	224	Dynamic viscosity factor (1897)	95
Comparison result (2760)	29	Dynamic viscosity offset (1898)	95
Configuration counter (0233)	211	Dynamic viscosity unit (0577)	71
Configuration management (2758)	28	Energy flow (1851)	49
Connection state (2722)	191	Energy flow factor (1867)	97
Contrast display (0105)	27	Energy flow offset (1866)	97
		Energy flow unit (0565)	72

Energy unit (0559)	70	Flow velocity (1852)	49
ENP version (0012)	212	Format display (0098)	15
Enter access code (0003)	13	Frequency output simulation 1 to n (0472-1 to n)	233
Entire logging duration (0861)	226	Frequency value 1 to n (0473-1 to n)	233
Event category 124 (0270)	178	Gas properties damping (1888)	75
Event category 125 (0271)	178	Gateway IP address (2719)	192
Event category 160 (0272)	178	Hardware revision (0206)	167
Event category 441 (0210)	179	HART address (0219)	157
Event category 442 (0230)	179	HART date code (0202)	168
Event category 443 (0231)	180	HART descriptor (0212)	167
Event category 444 (0211)	180	HART message (0216)	167
Event category 452 (0265)	180	HART revision (0205)	167
Event category 543 (0276)	181	HART short tag (0220)	157
Event category 832 (0218)	181	Header (0097)	25
Event category 833 (0225)	182	Header text (0112)	26
Event category 834 (0227)	182	Humidity type (3156)	82
Event category 835 (0229)	182	I/O alteration code (2762)	101
Event category 837 (0266)	183	I/O module 1 terminal numbers (3902-1)	214
Event category 840 (0267)	183	I/O module 1 to n information (3906-1 to n)	99
Event category 842 (0295)	183	I/O module 1 to n terminal numbers (3902-1 to n)	99
Event category 881 (0268)	184	I/O module 1 to n type (3901-1 to n)	100
Event category 930 (0296)	184	I/O module 2 terminal numbers (3902-2)	215, 218
Event category 931 (0297)	185	I/O module 3 terminal numbers (3902-3)	215, 218
Event category 953 (0292)	185	I/O module 4 terminal numbers (3902-4)	215, 218
Event category 954 (0293)	185	Input signal level 1 to n (1356-1 to n)	231
Extended order code 1 (0023)	211	Installation direction (1809)	87
Extended order code 2 (0021)	211	Invert output signal	
Extended order code 3 (0022)	211	Pulse/frequency/switch output 1 to n (0470-1 to n)	138
External pressure measurement (3033)	86	Invert output signal (0993)	149
Failure current		IP address (7209)	175
Current output 1 to n (0352-1 to n)	119	IP address domain name server (2720)	192
Failure frequency		Last backup (2757)	28
Pulse/frequency/switch output 1 to n (0474-1 to n)	131	Length unit (0551)	72
Failure mode		Locking status (0004)	12
Current input 1 to n (1601-1 to n)	103	Logging delay (0859)	224
Current output 1 to n (0364-1 to n)	118	Logging interval (0856)	223
Pulse/frequency/switch output 1 to n (0451-1 to n)	130	Login page (7273)	176
Pulse/frequency/switch output 1 to n (0480-1 to n)	125	MAC address (7214)	174
Pulse/frequency/switch output 1 to n (0486-1 to n)	137	Manufacturer ID (0259)	166
Relay output 1 to n (0811-1 to n)	144	Manufacturer ID (7009)	152
Totalizer 1 to n (0901-1 to n)	197	Mass flow (1847)	48
Failure mode (0985)	149	Mass flow factor (1846)	91
Failure mode (7011)	154	Mass flow offset (1841)	91
Failure value		Mass flow unit (0554)	67
Current input 1 to n (1602-1 to n)	104	Mass unit (0574)	68
Failure value (7012)	155	Master terminal number (0981)	146
Fieldbus writing access (0273)	158	Max. switch cycles number	
Filter options	207	Relay output 1 to n (0817-1 to n)	61
Filter options (0705)	206	Max. update period	
Firmware version (0010)	210	Burst configuration 1 to n (2041-1 to n)	165
Fixed current		Maximum frequency value	
Current output 1 to n (0365-1 to n)	110	Pulse/frequency/switch output 1 to n (0454-1 to n)	128
Flow asymmetry (2913)	54		
Flow damping (1802)	74		
Flow override (1839)	74		

Measured current 1 to n (0366–1 to n)	58, 119	Pulse output simulation 1 to n (0458–1 to n)	234
Measured current 1 to n (1604–1 to n)	57	Pulse scaling	
Measured values 1 to n (1603–1 to n)	56	Pulse/frequency/switch output 1 to n (0455–1 to n)	123
Measuring mode		Pulse value (0989)	237
Current output 1 to n (0351–1 to n)	113	Pulse value 1 to n (0459–1 to n)	234
Pulse/frequency/switch output 1 to n (0457–1 to n)	125	Pulse width	
Pulse/frequency/switch output 1 to n (0479–1 to n)	129	Pulse/frequency/switch output 1 to n (0452–1 to n)	124
Measuring mode (0984)	148	Pulse width (0986)	147
Measuring value at maximum frequency		Quaternary variable (QV) (0203)	173
Pulse/frequency/switch output 1 to n (0475–1 to n)	128	Received signal strength (2721)	192
Measuring value at minimum frequency		Reference combustion temperature (3165)	80
Pulse/frequency/switch output 1 to n (0476–1 to n)	128	Reference conditions (3155)	79
Medium temperature (2925)	87	Reference density (3144)	82
Methane fraction factor (1874)	94	Reference gross calorific value (3145)	82
Methane fraction offset (1873)	94	Reference pressure (3146)	80
Min. update period		Reference pressure (5670)	88
Burst configuration 1 to n (2042–1 to n)	164	Reference temperature (3147)	80
Minimum frequency value		Reference Z-factor (3148)	82
Pulse/frequency/switch output 1 to n (0453–1 to n)	127	Relative density (3149)	83
Mol mass factor (1876)	94	Relay output 1 to n simulation (0802–1 to n)	236
Molar mass (1864)	51	Relay output function	
Molar mass offset (1875)	94	Relay output 1 to n (0804–1 to n)	140
Network security (2705)	188	Reset access code (0024)	43
No. of preambles (0217)	158	Reset all totalizers (2806)	193
Nominal diameter (2807)	98	Response time	
Off value low flow cutoff (1804)	77	Current output 1 to n (0378–1 to n)	117
On value low flow cutoff (1805)	77	Pulse/frequency/switch output 1 to n (0491–1 to n)	130
Operating mode		Response time status input	
Pulse/frequency/switch output 1 to n (0469–1 to n)	121	Status input 1 to n (1354–1 to n)	106
Operating time (0652)	28, 43, 201	Secondary variable (SV) (0226)	170
Operating time from restart (0653)	201	Security identification (2718)	188
Order code (0008)	210	Select antenna (2713)	191
Output current 1 to n (0361–1 to n)	58, 119	Select gas type (3109)	78
Output frequency 1 to n (0471–1 to n)	59, 131	Separator (0101)	26
Phase shift (0992)	148	Serial number (0009)	209
Powerless relay status		Signal mode	
Relay output 1 to n (0816–1 to n)	145	Current input 1 to n (1610–1 to n)	102
Preset value 1 to n (0913–1 to n)	197	Current output 1 to n (0377–1 to n)	108
Pressure (1872)	48	Pulse/frequency/switch output 1 to n (0490–1 to n)	121
Pressure (3022)	85	Signal mode (0991)	146
Pressure cell adjustment (5669)	88	Signal strength (2914)	53
Pressure cell offset value (5671)	88	Signal to noise ratio (2917)	53
Pressure compensation (3023)	85	Slave terminal number (0990)	146
Pressure damping (1889)	76	Slot number (7010)	153
Pressure factor (1882)	93	Software option overview (0015)	45
Pressure offset (1881)	93	Software revision	
Pressure unit (0564)	69	I/O module (0072)	214, 216, 217, 218
Previous diagnostics (0690)	200	Mainboard I/O (0072)	212
Primary variable (PV) (0201)	169	Software revision (0072)	213, 219
Process variable value (1811)	230	Software revision (0224)	168
Pulse output (0987)	62, 149	Sound velocity (1850)	48
Pulse output 1 to n (0456–1 to n)	59, 126	Sound velocity factor (1849)	92
Pulse output simulation (0988)	237	Sound velocity offset (1848)	92
		Specific heat capacity (3162)	83
		Specific heat capacity unit (0604)	73

SSID name (2707)	190	Value 2 display (0108)	20																																																				
SSID name (2714)	187	Value 3 display (0110)	21																																																				
Standard volume flow calculation (3164)	84	Value 4 display (0109)	23																																																				
Status (7004)	156	Value current input 1 to n (1609–1 to n)	232																																																				
Status input simulation 1 to n (1355–1 to n)	230	Value current output 1 to n (0355–1 to n)	233																																																				
Subnet mask (7211)	175	Value per pulse (0983)	147																																																				
Switch cycles		Value status input																																																					
Relay output 1 to n (0815–1 to n)	61	Status input 1 to n (1353–1 to n)	106																																																				
Switch output function		Value status input 1 to n (1353–1 to n)	57																																																				
Pulse/frequency/switch output 1 to n (0481–1 to n)	131	Velocity unit (0566)	68																																																				
Switch output simulation 1 to n (0462–1 to n)	235	Volume flow (1838)	47																																																				
Switch status		Volume flow factor (1832)	90																																																				
Relay output 1 to n (0801–1 to n)	61, 144	Volume flow offset (1831)	90																																																				
Switch status 1 to n (0461–1 to n)	60, 138	Volume flow unit (0553)	63																																																				
Switch status 1 to n (0463–1 to n)	235	Volume unit (0563)	65																																																				
Switch status 1 to n (0803–1 to n)	236	Web server functionality (7222)	176																																																				
Switch-off delay		Web server language (7221)	174																																																				
Pulse/frequency/switch output 1 to n (0465–1 to n)	137	WLAN (2702)	187																																																				
Relay output 1 to n (0813–1 to n)	143	WLAN IP address (2711)	189																																																				
Switch-off value		WLAN MAC address (2703)	189																																																				
Pulse/frequency/switch output 1 to n (0464–1 to n)	135	WLAN mode (2717)	187																																																				
Relay output 1 to n (0809–1 to n)	142	WLAN passphrase (2706)	190																																																				
Switch-on delay		WLAN password (2716)	189																																																				
Pulse/frequency/switch output 1 to n (0467–1 to n)	137	WLAN subnet mask (2709)	189																																																				
Relay output 1 to n (0814–1 to n)	144	Wobbe index (1854)	50																																																				
Switch-on value		Wobbe index factor (1880)	96																																																				
Pulse/frequency/switch output 1 to n (0466–1 to n)	135	Wobbe index offset (1879)	96																																																				
Relay output 1 to n (0810–1 to n)	143	Z-factor (3108)	83																																																				
Temperature (1853)	49	Zero point (2921)	98																																																				
Temperature compensation (3025)	86	Direct access (Parameter)	11																																																				
Temperature damping (1803)	76	Display (Submenu)	14																																																				
Temperature factor (1871)	93	Display channel 1 (Submenu)	226																																																				
Temperature offset (1870)	92	Display channel 2 (Submenu)	227																																																				
Temperature unit (0557)	69	Display channel 3 (Submenu)	227																																																				
Terminal number		Display channel 4 (Submenu)	228																																																				
Current input 1 to n (1611–1 to n)	102	Display damping (Parameter)	25																																																				
Current output 1 to n (0379–1 to n)	107	Display interval (Parameter)	24																																																				
Pulse/frequency/switch output 1 to n (0492–1 to n)	121	Display language (Parameter)	15																																																				
Relay output 1 to n (0812–1 to n)	139	Display module (Submenu)	219																																																				
Status input 1 to n (1358–1 to n)	105	Document																																																					
Tertiary variable (TV) (0228)	172	Explanation of the structure of a parameter		Timeout (7005)	154	description	6	Timestamp	200, 201, 202, 203, 204, 205, 206	Function	4	Totalizer operation mode		Structure	4	Totalizer 1 to n (0908–1 to n)	196	Symbols used	6	Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71
Explanation of the structure of a parameter																																																							
Timeout (7005)	154	description	6	Timestamp	200, 201, 202, 203, 204, 205, 206	Function	4	Totalizer operation mode		Structure	4	Totalizer 1 to n (0908–1 to n)	196	Symbols used	6	Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71				
description	6																																																						
Timestamp	200, 201, 202, 203, 204, 205, 206	Function	4	Totalizer operation mode		Structure	4	Totalizer 1 to n (0908–1 to n)	196	Symbols used	6	Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71								
Function	4																																																						
Totalizer operation mode		Structure	4	Totalizer 1 to n (0908–1 to n)	196	Symbols used	6	Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71												
Structure	4																																																						
Totalizer 1 to n (0908–1 to n)	196	Symbols used	6	Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71																
Symbols used	6																																																						
Totalizer overflow 1 to n (0910–1 to n)	55	Target group	4	Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71																				
Target group	4																																																						
Totalizer value 1 to n (0911–1 to n)	55	Using the document	4	Turbulence (2907)	54	Document function	4	Unit (0974)	198	Double pulse output (Submenu)	61, 145	Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50	User name (2715)	188	Dynamic viscosity (Parameter)	52, 84	Value (7003)	155	Dynamic viscosity factor (Parameter)	95	Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95			Dynamic viscosity unit (Parameter)	71																								
Using the document	4																																																						
Turbulence (2907)	54	Document function	4																																																				
Unit (0974)	198	Double pulse output (Submenu)	61, 145																																																				
Unit totalizer 1 to n (0915–1 to n)	194	Dry methane in % (Parameter)	50																																																				
User name (2715)	188	Dynamic viscosity (Parameter)	52, 84																																																				
Value (7003)	155	Dynamic viscosity factor (Parameter)	95																																																				
Value 1 display (0107)	18	Dynamic viscosity offset (Parameter)	95																																																				
		Dynamic viscosity unit (Parameter)	71																																																				

E

Energy flow (Parameter)	49
Energy flow factor (Parameter)	97
Energy flow offset (Parameter)	97

Energy flow unit (Parameter)	72
Energy unit (Parameter)	70
ENP version (Parameter)	212
Enter access code (Parameter)	13
Entire logging duration (Parameter)	226
Event category 124 (Parameter)	178
Event category 125 (Parameter)	178
Event category 160 (Parameter)	178
Event category 441 (Parameter)	179
Event category 442 (Parameter)	179
Event category 443 (Parameter)	180
Event category 444 (Parameter)	180
Event category 452 (Parameter)	180
Event category 543 (Parameter)	181
Event category 832 (Parameter)	181
Event category 833 (Parameter)	182
Event category 834 (Parameter)	182
Event category 835 (Parameter)	182
Event category 837 (Parameter)	183
Event category 840 (Parameter)	183
Event category 842 (Parameter)	183
Event category 881 (Parameter)	184
Event category 930 (Parameter)	184
Event category 931 (Parameter)	185
Event category 953 (Parameter)	185
Event category 954 (Parameter)	185
Event list (Submenu)	207
Event logbook (Submenu)	206
Extended order code 1 (Parameter)	211
Extended order code 2 (Parameter)	211
Extended order code 3 (Parameter)	211
External compensation (Submenu)	85
External pressure measurement (Parameter)	86

F

Factory settings	239
SI units	239
US units	240
Failure current (Parameter)	119
Failure frequency (Parameter)	131
Failure mode (Parameter)	103, 118, 125, 130, 137, 144, 149, 154, 197
Failure value (Parameter)	104, 155
Fieldbus writing access (Parameter)	158
Filter options (Parameter)	206, 207
Firmware version (Parameter)	210
Fixed current (Parameter)	110
Flow asymmetry (Parameter)	54
Flow damping (Parameter)	74
Flow override (Parameter)	74
Flow velocity (Parameter)	49
Format display (Parameter)	15
Frequency output simulation 1 to n (Parameter)	233
Frequency value 1 to n (Parameter)	233
Function see Parameter	

G

Gas properties damping (Parameter)	75
--	----

Gateway IP address (Parameter)	192
--	-----

H

Hardware revision (Parameter)	167
HART address (Parameter)	157
HART date code (Parameter)	168
HART descriptor (Parameter)	167
HART input (Submenu)	150
HART message (Parameter)	167
HART output (Submenu)	156
HART revision (Parameter)	167
HART short tag (Parameter)	157
Header (Parameter)	25
Header text (Parameter)	26
Heartbeat (Submenu)	228
Humidity type (Parameter)	82

I

I/O alteration code (Parameter)	101
I/O configuration (Submenu)	99
I/O module 1 (Submenu)	214
I/O module 1 terminal numbers (Parameter)	214
I/O module 1 to n information (Parameter)	99
I/O module 1 to n terminal numbers (Parameter)	99
I/O module 1 to n type (Parameter)	100
I/O module 2 (Submenu)	215
I/O module 2 terminal numbers (Parameter)	215, 217, 218
I/O module 3 (Submenu)	216
I/O module 3 terminal numbers (Parameter)	215, 217, 218
I/O module 4 (Submenu)	218
I/O module 4 terminal numbers (Parameter)	215, 217, 218
Information (Submenu)	165
Input (Submenu)	101, 155
Input signal level 1 to n (Parameter)	231
Input values (Submenu)	56
Installation direction (Parameter)	87
Inventory counter (Submenu)	198
Invert output signal (Parameter)	138, 149
IP address (Parameter)	175
IP address domain name server (Parameter)	192

L

Last backup (Parameter)	28
Length unit (Parameter)	72
Locking status (Parameter)	12
Logging delay (Parameter)	224
Logging interval (Parameter)	223
Login page (Parameter)	176
Low flow cut off (Submenu)	76

M

MAC address (Parameter)	174
Mainboard I/O1 (Submenu)	212
Manufacturer ID (Parameter)	152, 166
Mass flow (Parameter)	48
Mass flow factor (Parameter)	91
Mass flow offset (Parameter)	91

Mass flow unit (Parameter)	67	Process variable adjustment (Submenu)	88
Mass unit (Parameter)	68	Process variable value (Parameter)	230
Master terminal number (Parameter)	146	Process variables (Submenu)	47
Max. switch cycles number (Parameter)	61	Pulse output (Parameter)	62, 149
Max. update period (Parameter)	165	Pulse output 1 to n (Parameter)	59, 126
Maximum frequency value (Parameter)	128	Pulse output simulation (Parameter)	237
Measured current 1 to n (Parameter)	57, 58, 119	Pulse output simulation 1 to n (Parameter)	234
Measured values (Submenu)	46	Pulse scaling (Parameter)	123
Measured values 1 to n (Parameter)	56	Pulse value (Parameter)	237
Measurement mode (Submenu)	78	Pulse value 1 to n (Parameter)	234
Measuring mode (Parameter)	113, 125, 129, 148	Pulse width (Parameter)	124, 147
Measuring value at maximum frequency (Parameter)	128	Pulse/frequency/switch output 1 to n (Submenu)	59, 119
Measuring value at minimum frequency (Parameter)	128		
Medium properties (Submenu)	81	Q	
Medium temperature (Parameter)	87	Quaternary variable (QV) (Parameter)	173
Methane fraction factor (Parameter)	94	R	
Methane fraction offset (Parameter)	94	Received signal strength (Parameter)	192
Min. update period (Parameter)	164	Reference combustion temperature (Parameter)	80
Minimum frequency value (Parameter)	127	Reference conditions (Parameter)	79
Mol mass factor (Parameter)	94	Reference density (Parameter)	82
Molar mass (Parameter)	51	Reference gross calorific value (Parameter)	82
Molar mass offset (Parameter)	94	Reference pressure (Parameter)	80, 88
N		Reference temperature (Parameter)	80
Network security (Parameter)	188	Reference Z-factor (Parameter)	82
No. of preambles (Parameter)	158	Relative density (Parameter)	83
Nominal diameter (Parameter)	98	Relay output 1 to n (Submenu)	60, 139
O		Relay output 1 to n simulation (Parameter)	236
Off value low flow cutoff (Parameter)	77	Relay output function (Parameter)	140
On value low flow cutoff (Parameter)	77	Reset access code (Parameter)	43
Operating mode (Parameter)	121	Reset access code (Submenu)	43
Operating time (Parameter)	28, 43, 201	Reset all totalizers (Parameter)	193
Operating time from restart (Parameter)	201	Response time (Parameter)	117, 130
Order code (Parameter)	210	Response time status input (Parameter)	106
Output (Submenu)	106, 168	S	
Output current 1 to n (Parameter)	58, 119	Secondary variable (SV) (Parameter)	170
Output frequency 1 to n (Parameter)	59, 131	Security identification (Parameter)	188
Output values (Submenu)	58	Select antenna (Parameter)	191
P		Select gas type (Parameter)	78
Parameter		Sensor (Submenu)	46
Structure of a parameter description	6	Sensor adjustment (Submenu)	87
Phase shift (Parameter)	148	Sensor electronic module (ISEM) (Submenu)	213
Powerless relay status (Parameter)	145	Separator (Parameter)	26
Preset value 1 to n (Parameter)	197	Serial number (Parameter)	209
Pressure (Parameter)	48, 85	Signal mode (Parameter)	102, 108, 121, 146
Pressure cell adjustment (Parameter)	88	Signal strength (Parameter)	53
Pressure cell offset value (Parameter)	88	Signal to noise ratio (Parameter)	53
Pressure compensation (Parameter)	85	Simulation (Submenu)	228
Pressure damping (Parameter)	76	Slave terminal number (Parameter)	146
Pressure factor (Parameter)	93	Slot number (Parameter)	153
Pressure offset (Parameter)	93	Software option overview (Parameter)	45
Pressure unit (Parameter)	69	Software revision (Parameter)	168, 212, 213, 214, 216, 217, 218, 219
Previous diagnostics (Parameter)	200	Sound velocity (Parameter)	48
Primary variable (PV) (Parameter)	169	Sound velocity factor (Parameter)	92
Process parameters (Submenu)	74	Sound velocity offset (Parameter)	92
		Specific heat capacity (Parameter)	83

Specific heat capacity unit (Parameter)	73
SSID name (Parameter)	187, 190
Standard volume flow calculation (Parameter)	84
Status (Parameter)	156
Status input 1 to n (Submenu)	104
Status input simulation 1 to n (Parameter)	230
Submenu	
Administration	41
Application	192
Burst configuration 1 to n	158
Calibration	97
Communication	150
Configuration	151, 156
Configuration backup	27
Current input 1 to n	56, 101
Current output 1 to n	107
Data logging	220
Device information	208
Diagnostic behavior	31
Diagnostic configuration	176
Diagnostic handling	30
Diagnostic list	202
Diagnostics	199
Display	14
Display channel 1	226
Display channel 2	227
Display channel 3	227
Display channel 4	228
Display module	219
Double pulse output	61, 145
Event list	207
Event logbook	206
External compensation	85
HART input	150
HART output	156
Heartbeat	228
I/O configuration	99
I/O module 1	214
I/O module 2	215
I/O module 3	216
I/O module 4	218
Information	165
Input	101, 155
Input values	56
Inventory counter	198
Low flow cut off	76
Mainboard I/O1	212
Measured values	46
Measurement mode	78
Medium properties	81
Output	106, 168
Output values	58
Process parameters	74
Process variable adjustment	88
Process variables	47
Pulse/frequency/switch output 1 to n	59, 119
Relay output 1 to n	60, 139
Reset access code	43
Sensor	46

Sensor adjustment	87
Sensor electronic module (ISEM)	213
Simulation	228
Status input 1 to n	104
System	13
System units	62
System values	52
Totalizer	54
Totalizer 1 to n	193
Value current output 1 to n	58
Value status input 1 to n	57
Web server	173
WLAN settings	186
Subnet mask (Parameter)	175
Switch cycles (Parameter)	61
Switch output function (Parameter)	131
Switch output simulation 1 to n (Parameter)	235
Switch status (Parameter)	61, 144
Switch status 1 to n (Parameter)	60, 138, 235, 236
Switch-off delay (Parameter)	137, 143
Switch-off value (Parameter)	135, 142
Switch-on delay (Parameter)	137, 144
Switch-on value (Parameter)	135, 143
System (Submenu)	13
System units (Submenu)	62
System values (Submenu)	52

T

Target group	4	
Temperature (Parameter)	49	
Temperature compensation (Parameter)	86	
Temperature damping (Parameter)	76	
Temperature factor (Parameter)	93	
Temperature offset (Parameter)	92	
Temperature unit (Parameter)	69	
Terminal number (Parameter)	102, 105, 107, 121, 139	
Tertiary variable (TV) (Parameter)	172	
Timeout (Parameter)	154	
Timestamp (Parameter)	200, 201, 202, 203, 204, 205,	206
Totalizer (Submenu)	54	
Totalizer 1 to n (Submenu)	193	
Totalizer operation mode (Parameter)	196	
Totalizer overflow 1 to n (Parameter)	55	
Totalizer value 1 to n (Parameter)	55	
Turbulence (Parameter)	54	

U

Unit (Parameter)	198
Unit totalizer 1 to n (Parameter)	194
User name (Parameter)	188

V

Value (Parameter)	155
Value 1 display (Parameter)	18
Value 2 display (Parameter)	20
Value 3 display (Parameter)	21
Value 4 display (Parameter)	23
Value current input 1 to n (Parameter)	232

Value current output 1 to n (Parameter)	233
Value current output 1 to n (Submenu)	58
Value per pulse (Parameter)	147
Value status input (Parameter)	57, 106
Value status input 1 to n (Submenu)	57
Velocity unit (Parameter)	68
Volume flow (Parameter)	47
Volume flow factor (Parameter)	90
Volume flow offset (Parameter)	90
Volume flow unit (Parameter)	63
Volume unit (Parameter)	65

W

Web server (Submenu)	173
Web server functionality (Parameter)	176
Web server language (Parameter)	174
Wizard	
Define access code	41
WLAN (Parameter)	187
WLAN IP address (Parameter)	189
WLAN MAC address (Parameter)	189
WLAN mode (Parameter)	187
WLAN passphrase (Parameter)	190
WLAN password (Parameter)	189
WLAN settings (Submenu)	186
WLAN subnet mask (Parameter)	189
Wobbe index (Parameter)	50
Wobbe index factor (Parameter)	96
Wobbe index offset (Parameter)	96

Z

Z-factor (Parameter)	83
Zero point (Parameter)	98

www.addresses.endress.com
