
BA01695D/06/EN/02.20 71483621 2020-06-01

Valid as of version 01.01.zz (Device firmware)

Operating Instructions **Proline Prowirl O 200 FOUNDATION Fieldbus**

Vortex flowmeter







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document
1.1 1.2 1.3	Document function6Symbols61.2.1Safety symbols61.2.2Electrical symbols61.2.3Communication symbols61.2.4Tool symbols71.2.5Symbols for certain types of information71.2.6Symbols in graphics7Documentation8
1.9	1.3.1 Standard documentation 8 1.3.2 Supplementary device-dependent documentation 8
1.4	Registered trademarks 8
2	Safety instructions
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Requirements for the personnel9Designated use9Workplace safety10Operational safety10Product safety10IT security10IT security11Device-specific IT security112.7.1Protecting access via hardware write protectionprotecting112.7.2Protecting access via a password112.7.3Access via fieldbus11
3	Product description 12
3.1	Product design 12
4	Incoming acceptance and product
	identification 13
4.1 4.2	Incoming acceptance13Product identification134.2.1Transmitter nameplate4.2.2Sensor nameplate4.2.3Symbols on measuring device17
5	Storage and transport 18
5.1 5.2	Storage conditions18Transporting the product185.2.1Measuring devices without liftinghuge18
5.3	lugs185.2.2Measuring devices with lifting lugs195.2.3Transporting with a fork lift19Packaging disposal19

6.1 Installation conditions 20 6.1.1 Mounting position 20 6.1.2 Environment and process 22 6.1.3 Special mounting instructions 24 6.2 Mounting the measuring device 25 6.2.1 Required tools 25 6.2.2 Preparing the measuring device 25 6.2.3 Mounting the sensor 25 6.2.4 Mounting the transmitter of the remote version 26 6.2.5 Turning the transmitter housing 27 6.2.6 Turning the display module 27 6.3 Post-installation check 28 7 Electrical connection 29 7.1.1 Required tools 29 7.1.2 Connecting cable requirements 29 7.1.3 Connecting cable for remote 29 7.1.4 Terminal assignment 31 7.1.5 Pin assignment of device plug 31 7.1.6 Shielding and grounding 33 7.1.7 Requirements for the supply unit 33 7.1.8 Preparing the measur	6	Installation	20
requirements226.1.3Special mounting instructions246.2Mounting the measuring device256.2.1Required tools256.2.2Preparing the measuring device256.2.3Mounting the sensor256.2.4Mounting the transmitter of the remote version266.2.5Turning the display module276.3Post-installation check287Electrical connection297.1Connecting cable requirements297.1.2Connecting cable for remote version297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device347.2.1Connecting the compact version347.2.2Connecting the remote version347.2.3Ensuring potential equalization407.3Ensuring the degree of protection407.4Post-connection check40	6.1	6.1.1 Mounting position	
6.2 Mounting the measuring device 25 6.2.1 Required tools 25 6.2.2 Preparing the measuring device 25 6.2.3 Mounting the sensor 25 6.2.4 Mounting the transmitter of the remote version 26 6.2.5 Turning the transmitter housing 27 6.2.6 Turning the display module 27 6.3 Post-installation check 28 7 Electrical connection 29 7.1.1 Required tools 29 7.1.2 Connecting cable requirements 29 7.1.3 Connecting cable for remote version 29 7.1.4 Terminal assignment 31 7.1.5 Pin assignment of device plug 31 7.1.6 Shielding and grounding 33 7.1.8 Preparing the measuring device 33 7.2 Connecting the compact version 34 7.2.1 Connecting the remote version 34 7.2.2 Connecting the remote version 34 7.2.1 Connecting the remote version 34 7.2.2		requirements	
6.2.2Preparing the measuring device256.2.3Mounting the sensor256.2.4Mounting the transmitter of the remote version266.2.5Turning the transmitter housing276.2.6Turning the display module276.3Post-installation check287Electrical connection297.1Connection conditions297.1.1Required tools297.1.2Connecting cable requirements297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device347.2.1Connecting the compact version347.2.3Ensuring potential equalization407.3Ensuring the degree of protection407.4Post-connection check40	6.2	Mounting the measuring device	25
remote version		6.2.2 Preparing the measuring device6.2.3 Mounting the sensor	25
6.2.6Turning the display module		remote version	
7Electrical connection297.1Connection conditions297.1.1Required tools297.1.2Connecting cable requirements297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device347.2.1Connecting the compact version347.2.3Ensuring potential equalization407.4Post-connection check408Operation options41	()	6.2.6 Turning the display module	27
7.1Connection conditions297.1.1Required tools297.1.2Connecting cable requirements297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device337.2Connecting the measuring device347.2.1Connecting the remote version347.2.3Ensuring potential equalization407.4Post-connection check408Operation options41	6.3		28
7.1.1Required tools297.1.2Connecting cable requirements297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device347.2.1Connecting the compact version347.2.2Connecting the remote version357.2.3Ensuring potential equalization407.4Post-connection check408Operation options41	-		-
7.1.2Connecting cable requirements297.1.3Connecting cable for remote version297.1.4Terminal assignment317.1.5Pin assignment of device plug317.1.6Shielding and grounding317.1.7Requirements for the supply unit337.1.8Preparing the measuring device347.2.1Connecting the compact version347.2.2Connecting the remote version357.2.3Ensuring potential equalization407.4Post-connection check408Operation options41	7.1		
7.1.4Terminal assignment		7.1.2 Connecting cable requirements	29
7.1.5Pin assignment of device plug 317.1.6Shielding and grounding 317.1.7Requirements for the supply unit 337.1.8Preparing the measuring device			
7.1.6Shielding and grounding			
7.1.8Preparing the measuring device337.2Connecting the measuring device347.2.1Connecting the compact version347.2.2Connecting the remote version357.2.3Ensuring potential equalization407.4Post-connection check408Operation options41			
 7.2 Connecting the measuring device			
7.2.1Connecting the compact version347.2.2Connecting the remote version357.2.3Ensuring potential equalization407.3Ensuring the degree of protection407.4Post-connection check408Operation options41		1 5 5	
7.2.2Connecting the remote version	7.2		
7.2.3Ensuring potential equalization407.3Ensuring the degree of protection407.4Post-connection check408Operation options41			
 7.3 Ensuring the degree of protection		5	
7.4 Post-connection check	73		
8.1 Overview of operation options	8		41
8.2 Structure and function of the operating	8.1 8.2	Overview of operation options Structure and function of the operating	41
menu			
8.2.1 Structure of the operating menu 42			
 8.2.2 Operating philosophy	8.3	Access to the operating menu via the local	
8.3.1 Operational display			
8.3.2 Navigation view		1 1 5	
8.3.3 Editing view		5	
8.3.4 Operating elements		-	48
8.3.5 Opening the context menu 49		8.3.5 Opening the context menu	49
8.3.6 Navigating and selecting from list 51		5 5 5	
8.3.7 Calling the parameter directly 51		5 1 5	
8.3.8 Calling up help text			
8.3.9 Changing the parameters 53		5 5 1	53
8.3.10 User roles and related access authorization			

	8.3.11	Disabling write protection via access	
		code	54
	8.3.12	5 5 51	
- ·		lock	55
8.4		to the operating menu via the	
	-	ng tool	55
	8.4.1	Connecting the operating tool	55
	8.4.2 8.4.3	Field Xpert SFX350, SFX370FieldCare	57 57
	8.4.4	DeviceCare	58
	8.4.5	AMS Device Manager	58
	8.4.6	Field Communicator 475	59
	0.1.0		
9	Syster	m integration	60
	-	_	
9.1	9.1.1	w of device description files Current version data for the device	60 60
	9.1.1 9.1.2	Operating tools	60 60
9.2		ata transmission	60
2.2	9.2.1	Block model	60
	9.2.2	Description of the modules	61
	9.2.3	Execution times	64
	9.2.4	Methods	64
10	Comm	nissioning	66
10.1	Functio	on check	66
10.2		ng on the measuring device	66
10.3		the operating language	66
10.4	Configu	ring the measuring device	67
	10.4.1	Defining the tag name	67
	10.4.2	Setting the system units	68
	10.4.3	Selecting and setting the medium	72
	10.4.4	Configuring the analog inputs	75
	10.4.5	Configuring the local display	75
10.5	10.4.6	Configuring the low flow cut off	77 79
10.5	10.5.1	red settings	80
	10.5.2	Performing external compensation	93
	10.5.3	Carrying out a sensor adjustment	95
	10.5.4	Configuring the pulse/frequency/	
		switch output	96
	10.5.5		.01
	10.5.6	Carrying out additional display	
		5	.03
	10.5.7	5	.05
	10.5.8	Using parameters for device	0.7
10.6	Cimulat		.07
10.6 10.7		tion	.08
10.7		5 5	.10
			.10
	10.7.1	-	
			.11
	10.7.3		
		operation 1	.12
10.8		uring the measuring device via	
			.13
	10.8.1	Block configuration 1	.13

	10.8.2 Scaling the measured value in the	11/
	Analog Input Block	114
10.9	Application-specific commissioning	115
	10.9.1 Steam application	115
	10.9.2 Liquid application	115
	10.9.3 Gas applications	116
	10.9.4 Calculation of the measured	
	variables	120
11	Operation	124
11.1	Reading the device locking status	124
11.2	Adjusting the operating language	124
11.3	Configuring the display	124
11.4	Reading measured values	124
	11.4.1 Process variables	125
	11.4.2 "Totalizer" submenu	127
	11.4.3 Output values	127
11.5	Adapting the measuring device to the process	
1112	conditions	128
11.6	Performing a totalizer reset	128
11.0	11.6.1 Function scope of the "Control	120
	Totalizer" parameter	129
	11.6.2 Function scope of the "Reset all	127
	totalizers" parameter	129
11.7	Showing data logging	129
11.7		127
12	Diagnostics and troubleshooting	132
12.1		
12.1	General troubleshooting	132
12.1 12.2	Diagnostic information on local display	132 134
	Diagnostic information on local display	134
	Diagnostic information on local display 12.2.1 Diagnostic message	134 134
12.2	Diagnostic information on local display 12.2.1 Diagnostic message	134 134
12.2	Diagnostic information on local display 12.2.1 Diagnostic message	134 134 136
12.2	Diagnostic information on local display 12.2.1 Diagnostic message	134 134 136 136
12.2 12.3	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information	134 134 136 136 136 138
12.2	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.2Adapting the diagnostic information	134 134 136 136 136 138 138
12.2 12.3	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.4Calling up remedy information12.4.1Adapting the diagnostic behavior	134 134 136 136 136 138 138
12.2 12.3	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.4Adapting the diagnostic information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal	134 134 136 136 136 138 138
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.4Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signalOverview of diagnostic information	134 134 136 136 136 138 138 138 139
12.2 12.3 12.4	Diagnostic information on local display 12.2.1 Diagnostic message	134 134 136 136 138 138 138 139 143
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.2Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal0verview of diagnostic information12.5.1Diagnostic of sensor12.5.2Diagnostic of electronic	134 136 136 136 138 138 138 138 139 143 143 147
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.3Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal0verview of diagnostic information12.5.1Diagnostic of sensor12.5.2Diagnostic of configuration12.5.3Diagnostic of configuration	134 136 136 138 138 138 138 138 138 143 143 147 154
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.2Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal0verview of diagnostic information12.5.1Diagnostic of sensor12.5.2Diagnostic of configuration12.5.4Diagnostic of process	134 136 136 136 138 138 138 138 139 143 143 147
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.2Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal0verview of diagnostic information12.5.1Diagnostic of sensor12.5.2Diagnostic of configuration12.5.3Diagnostic of configuration12.5.4Diagnostic of process12.5.5Operating conditions for displaying	134 136 136 138 138 138 138 138 138 143 143 147 154
12.2 12.3 12.4	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.2Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal12.5.1Diagnostic of sensor12.5.2Diagnostic of sensor12.5.3Diagnostic of configuration12.5.4Diagnostic of process12.5.5Operating conditions for displaying the following diagnostics	134 136 136 136 138 138 138 139 143 143 147 154 160
12.2 12.3 12.4	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 138 138 138 138 138 138 143 143 147 154
12.2 12.3 12.4	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 138 138 138 138 138 143 143 147 154 160 168
12.2 12.3 12.4 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 138 138 138 138 138 138 143 143 143 147 154 160 168 168
12.2 12.3 12.4 12.5 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 138 138 138 138 138 143 143 147 154 160 168
12.2 12.3 12.4 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 138 138 138 139 143 143 147 154 160 168 168
12.2 12.3 12.4 12.5 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 136 138 138 138 139 143 143 147 154 160 168 168 168
12.2 12.3 12.4 12.5 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 136 138 138 138 139 143 143 143 147 154 160 168 168 168 169 169
12.2 12.3 12.4 12.5 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 136 138 138 138 139 143 143 143 147 154 160 168 168 168 169 169 170
12.2 12.3 12.4 12.5 12.5	Diagnostic information on local display12.2.1Diagnostic message12.2.2Calling up remedial measuresDiagnostic information in FieldCare orDeviceCare12.3.1Diagnostic options12.3.2Calling up remedy information12.3.3Calling up remedy information12.4.1Adapting the diagnostic behavior12.4.2Adapting the status signal0verview of diagnostic information12.5.1Diagnostic of sensor12.5.2Diagnostic of configuration12.5.3Diagnostic of configuration12.5.4Diagnostic of process12.5.5Operating conditions for displaying the following diagnostics information12.5.6Emergency mode in event of temperature compensationPending diagnostic eventsDiagnostic fistDiagnostic listDiagnostic list2.9.1Reading out the event logbook	134 136 136 136 138 138 138 138 139 143 143 143 147 154 160 168 168 168 168 169 169 170 170
12.2 12.3 12.4 12.5 12.5	 Diagnostic information on local display 12.2.1 Diagnostic message	134 136 136 136 138 138 138 139 143 143 143 147 154 160 168 168 168 169 169 170

12.10	Resetting the measuring device 12.10.1 Function scope of the "Restart"	172
	parameter	172
	12.10.2 Function scope of the "Service reset"	1, 1
	parameter	172
12.11	Device information	172
	Firmware history	174
12.12		
13		175
13.1	Maintenance tasks	175
	13.1.1 Exterior cleaning	175
	13.1.2 Interior cleaning	175
	13.1.3 Replacing seals	175
13.2	Measuring and test equipment	175
13.3	Endress+Hauser services	175
14	Repair	176
14.1	General notes	176
1 1.1	14.1.1 Repair and conversion concept	176
	14.1.2 Notes for repair and conversion	176
14.2	Spare parts	176
14.3	Endress+Hauser services	177
14.4	Return	177
14.5	Disposal	177
1 1.2	14.5.1 Removing the measuring device	177
	14.5.2 Disposing of the measuring device	178
15	Accessories	179
15 15.1	Device-specific accessories	179
	Device-specific accessories 15.1.1 For the transmitter	179 179
15.1	Device-specific accessories15.1.1For the transmitter15.1.2For the sensor	179 179 180
15.1 15.2	Device-specific accessories15.1.1For the transmitter15.1.2For the sensorCommunication-specific accessories	179 179 180 180
15.1	Device-specific accessories15.1.1For the transmitter15.1.2For the sensor	179 179 180
15.1 15.2 15.3 15.4	Device-specific accessories 15.1.1 For the transmitter 15.1.2 For the sensor Communication-specific accessories Service-specific accessories System components	179 179 180 180 181 181
15.1 15.2 15.3 15.4 16	Device-specific accessories 15.1.1 For the transmitter 15.1.2 For the sensor Communication-specific accessories Service-specific accessories System components Technical data	179 179 180 180 181 181 182
15.1 15.2 15.3 15.4 16 16.1	Device-specific accessories	179 179 180 180 181 181 181 182 182
15.1 15.2 15.3 15.4 16 16.1 16.2	Device-specific accessories	179 179 180 180 181 181 182 182 182
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 188
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5	Device-specific accessories	179 179 180 181 181 182 182 182 182 182 188 191
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 188 191 193
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7	Device-specific accessories	179 179 180 180 181 181 182 182 182 182 182 182 182 183 191 193 196
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8	Device-specific accessories	179 179 180 180 181 181 182 182 182 182 182 182 182 183 191 193 196 196
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9	Device-specific accessories	179 179 180 180 181 181 182 182 182 182 182 182 182 182 183 191 193 196 196
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 182 182 183 191 193 196 196 198 199
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10 16.11	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 182 182 182 183 191 193 196 196 198 199 205
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10 16.11 16.12	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 183 191 193 196 196 198 199 205 206
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10 16.11 16.12 16.13	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 182 182 183 191 193 196 196 198 199 205 206 207
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10 16.11 16.12 16.13 16.14	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 182 182 183 191 193 196 196 198 199 205 206 207 208
15.1 15.2 15.3 15.4 16 16.1 16.2 16.3 16.4 16.5 16.6 16.7 16.8 16.9 16.10 16.11 16.12 16.13 16.14	Device-specific accessories	179 179 180 181 181 181 182 182 182 182 182 182 182 182 183 191 193 196 196 198 199 205 206 207

1 About this document

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
\sim	Alternating current
\sim	Direct current and alternating current
<u>+</u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device:Inner ground terminal: Connects the protectiv earth to the mains supply.Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Communication symbols

Symbol	Meaning
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.

1.2.4 Tool symbols

Symbol	Meaning
0	Flat blade screwdriver
$\bigcirc \not \sqsubseteq$	Allen key
Ŕ	Open-ended wrench

1.2.5 Symbols for certain types of information

Symbol	Meaning
\checkmark	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
Ĩ	Reference to documentation.
	Reference to page.
	Reference to graphic.
•	Notice or individual step to be observed.
1., 2., 3	Series of steps.
ـ►	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area
X	Safe area (non-hazardous area)
≈⇒	Flow direction

1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Detailed list of the individual documents along with the documentation code $\rightarrow \cong 208$

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.
	Incoming acceptance and product identificationStorage and transportInstallation
Transmitter Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).
	 Product description Installation Electrical connection Operation options System integration Commissioning Diagnostic information
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

KALREZ[®], VITON[®]

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

GYLON®

Registered trademark of Garlock Sealing Technologies, Palmyar, NY, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- Follow the instructions in this manual.

2.2 Designated use

Application and media

The measuring device described in this manual is intended only for flow measurement of liquids with a minimum conductivity of 20 $\mu S/cm.$

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified pressure and temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- Verify the compatibility of the process fluid with the sensor material.
- Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

WARNING

The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

 Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

• Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

• Due to the increased risk of electric shock, gloves must be worn.

2.4 Operational safety

Risk of injury.

- Operate the device in proper technical condition and fail-safe condition only.
- ► The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

► If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- Carry out repairs on the device only if they are expressly permitted.
- ► Observe federal/national regulations pertaining to repair of an electrical device.
- ► Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

2.7.1 Protecting access via hardware write protection

Write access to the device parameters via the local display or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

2.7.2 Protecting access via a password

A password can be used to protect against write access to the device parameters.

This password locks write access to the device parameters via the local display or another operating tool (e.g. FieldCare, DeviceCare) and, in terms of functionality, is equivalent to hardware write protection. If the service interface CDI RJ-45 is used, read access is only possible if the password is entered.

User-specific access code

Write access to the device parameters via the local display or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ($\rightarrow \triangleq 110$).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.

2.7.3 Access via fieldbus


Cyclic fieldbus communication (read and write, e.g. measured value transmission) with a higher-order system is not affected by the restrictions mentioned above.

3 Product description

The device consists of a transmitter and a sensor.

- Two device versions are available:
- Compact version transmitter and sensor form a mechanical unit.
- Remote version transmitter and sensor are mounted in separate locations.


3.1 Product design



- 1 Important components of a measuring device
- 1 Electronics compartment cover
- 2 Display module
- 3 Main electronics module
- 4 Cable glands
- 5 Transmitter housing (incl. HistoROM)
- 6 I/O electronics module
- 7 Terminals (spring loaded terminals, pluggable)
- 8 Connection compartment cover
- 9 Sensor

4 Incoming acceptance and product identification

4.1 Incoming acceptance



4.2 Product identification


The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in the *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the device is displayed.
- Enter the serial number from nameplates in the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate using the *Endress+Hauser Operations App*: All information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer*: enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.


4.2.1 Transmitter nameplate



• 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Type of cable glands
- 8 Permitted ambient temperature (T_a)
- 9 Firmware version (FW) from the factory
- 10 CE mark, C-Tick
- 11 Additional information on version: certificates, approvals
- 12 Permitted temperature range for cable
- 13 Manufacturing date: year-month
- 14 Degree of protection
- 15 Approval information for explosion protection
- 16 Document number of safety-related supplementary documentation
- 17 2-D matrix code

4.2.2 Sensor nameplate




Order code for "Housing" option B "GT18 dual compartment, 316L, compact" and option K "GT18 dual compartment, 316L, remote"

■ 3 Example of a sensor nameplate


- 1 Name of the sensor
- 2 Nominal diameter of sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Serial number (ser. no.)
- 5 Measuring tube material
- 6 Measuring tube material
- 7 Maximum permitted volume flow (gas/steam): $Q_{max} \rightarrow \square 183$
- 8 Test pressure of the sensor: $OPL \rightarrow \square 198$
- 9 Seal material
- 10 Document number of safety-related supplementary documentation $\rightarrow \square 208$
- 11 Ambient temperature range
- 12 CE mark
- 13 Medium temperature range
- 14 Degree of protection

Order code for "Housing" option C "GT20 dual compartment, aluminum, coated, compact"



E 4 Example of a sensor nameplate

- 1 Nominal diameter of sensor
- 2 Flange nominal diameter/nominal pressure
- 3 Measuring tube material
- 4 Measuring tube material
- 5 Serial number (ser. no.)
- 6 Maximal permitted volume flow (gas/steam)
- 7 Test pressure of the sensor
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive → 🖺 208
- 10 CE mark
- 11 Seal material
- 12 Medium temperature range
- 13 Ambient temperature range



Order code for "Housing" option J "GT20 dual compartment, aluminum, coated, remote"

■ 5 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Nominal diameter of sensor
- 3 Flange nominal diameter/nominal pressure
- 4 Order code
- 5 Serial number (ser. no.)
- 6 Extended order code (Ext. ord. cd.)
- 7 Maximal permitted volume flow (gas/steam)
- 8 Degree of protection
- 9 Approval information for explosion protection and Pressure Equipment Directive
- 10 Ambient temperature range
- 11 Document number of safety-related supplementary documentation \rightarrow \cong 208
- 12 Test pressure of the sensor
- 13 Measuring tube material
- 14 Measuring tube material
- 15 Seal material
- 16 Medium temperature range



The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on measuring device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
Ĩ	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature: -50 to +80 °C (-58 to +176 °F)

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- Observe the weight specified on the packaging (stick-on label).



5.2.2 Measuring devices with lifting lugs

ACAUTION

Special transportation instructions for devices with lifting lugs

- Only use the lifting lugs fitted on the device or flanges to transport the device.
- The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:


- Outer packaging of device
- Polymer stretch wrap that complies with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material Paper pads

6 Installation

6.1 Installation conditions

6.1.1 Mounting position

Mounting location



Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Vortex meters require a fully developed flow profile as a prerequisite for correct volume flow measurement. Therefore, please note the following:

	Orientation	Compact version	Remote version	
A	Vertical orientation	A0015545	۲۲ ¹⁾	~~
В	Horizontal orientation, transmitter head up	A0015589	× × ^{2) 3)}	~~
С	Horizontal orientation, transmitter head down	A0015590	// ⁴⁾	~~
D	Horizontal orientation, transmitter head at side	A0015592	VV	~~

 In the case of liquids, there should be upward flow in vertical pipes to avoid partial pipe filling (Fig. A). Disruption in flow measurement! In the case of vertical orientation and downward flowing liquid, the pipe always needs to be completely filled to ensure correct liquid flow measurement.


2) Danger of electronics overheating! If the fluid temperature is ≥ 200 °C (392 °F), orientation B is not permitted for the wafer version (Prowirl D) with nominal diameters of DN 100 (4") and DN 150 (6").

3) In the case of hot media (e.g. steam or fluid temperature (TM) ≥ 200 °C (392 °F): orientation C or D

4) In the case of very cold media (e.g. liquid nitrogen): orientation B or D

Inlet and outlet runs

To attain the specified level of accuracy of the measuring device, the inlet and outlet runs mentioned below must be maintained at the very minimum.



■ 6 *Minimum inlet and outlet runs with various flow obstructions*


- *h* Difference in expansion
- 1 Reduction by one nominal diameter size
- *2* Single elbow (90° elbow)
- 3 Double elbow $(2 \times 90^{\circ} \text{ elbows, opposite})$
- 4 Double elbow 3D ($2 \times 90^{\circ}$ elbows, opposite, not on one plane)
- 5 T-piece
- 6 Expansion
- 7 Control valve
- 8 Two measuring devices in a row where $DN \le 25$ (1"): directly flange on flange
- 9 Two measuring devices in a row where $DN \ge 40 (1\frac{1}{2})$: for spacing, see graphic

• If there are several flow disturbances present, the longest specified inlet run must be maintained.

Flow conditioner

If the inlet runs cannot be observed, the use of a flow conditioner is recommended.

The flow conditioner is fitted between two pipe flanges and centered by the mounting bolts. Generally this reduces the inlet run needed to $10 \times DN$ with full accuracy.



1 Flow conditioner

The pressure loss for flow conditioners is calculated as follows: $\Delta p \text{ [mbar]} = 0.0085 \cdot \rho \text{ [kg/m^3]} \cdot v^2 \text{ [m/s]}$


Example for steam	Example for H_2O condensate (80 °C)
p = 10 bar abs.	$\rho = 965 \text{ kg/m}^3$
t = 240 °C $\rightarrow \rho$ = 4.39 kg/m ³	v = 2.5 m/s
v = 40 m/s	$\Delta p = 0.0085 \cdot 965 \cdot 2.5^2 = 51.3 \text{ mbar}$
$\Delta p = 0.0085 \cdot 4.394.39 \cdot 40^{2} = 59.7 \text{ mbar}$	

 ρ : density of the process medium v: average flow velocity abs. = absolute

For the dimensions of the flow conditioner, see the "Technical Information" document, "Mechanical construction" section

Outlet runs when installing external devices

If installing an external device, observe the specified distance.



PT Pressure

TT Temperature device

Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.

6.1.2 Environment and process requirements

Ambient temperature range

Compact version

Measuring device	Non-hazardous area:	-40 to +80 °C (-40 to +176 °F) ¹⁾		
	Ex i, Ex nA, Ex ec:	-40 to +70 °C (-40 to +158 °F) ¹⁾		

	Ex d, XP:	-40 to +60 °C (-40 to +140 °F) ¹⁾	
	Ex d, Ex ia:	-40 to $+60$ °C (-40 to $+140$ °F) $^{1)}$	
Local display		-40 to +70 °C (-40 to +158 °F) ^{2) 1)}	

1) Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature – 50 °C (-58 °F)".

 At temperatures < -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

Remote version

Transmitter	Non-hazardous area:	-40 to +80 °C (-40 to +176 °F) ¹⁾		
Ex i, Ex nA, Ex ec:		-40 to +80 °C (-40 to +176 °F) ¹⁾		
	Ex d:	-40 to +60 °C (-40 to +140 °F) ¹⁾		
	Ex d, Ex ia:	-40 to +60 °C (-40 to +140 °F) ¹⁾		
Sensor	Non-hazardous area:	-40 to +85 °C (-40 to +185 °F) ¹⁾		
	Ex i, Ex nA, Ex ec:	-40 to +85 °C (-40 to +185 °F) ¹⁾		
	Ex d:	-40 to +85 °C (-40 to +185 °F) ¹⁾		
	Ex d, Ex ia:	-40 to +85 °C (-40 to +185 °F) ¹⁾		
Local display	·	-40 to +70 °C (-40 to +158 °F) ^{2) 1)}		

1) Additionally available as order code for "Test, certificate", option JN "Transmitter ambient temperature – 50 $^{\circ}$ C (–58 $^{\circ}$ F)".

2) At temperatures < -20 °C (-4 °F), depending on the physical characteristics involved, it may no longer be possible to read the liquid crystal display.

► If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.



You can order a weather protection cover from Endress+Hauser. $\rightarrow \cong 179$.


Thermal insulation

For optimum temperature measurement and mass calculation, heat transfer at the sensor must be avoided for some fluids. This can be ensured by installing thermal insulation. A wide range of materials can be used for the required insulation.

This applies for:

- Compact version
- Remote sensor version

The maximum insulation height permitted is illustrated in the diagram:



- 1 Maximum insulation height
- ► When insulating, ensure that a sufficiently large area of the housing support remains exposed.

The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

NOTICE

Electronics overheating on account of thermal insulation!

- Observe the maximum permitted insulation height of the transmitter neck so that the transmitter head and/or the connection housing of the remote version is completely free.
- Observe information on the permissible temperature ranges.
- Note that a certain orientation might be required, depending on the fluid temperature.


6.1.3 Special mounting instructions

Installation for delta heat measurements

- Order code for "Sensor version", option CD "mass; Alloy 718; 316L (integrated temperature measurement), -200 to +400 °C (-328 to +750 °F)"
- Order code for "Sensor version", option DC "mass steam; Alloy 718; 316L (integrated pressure/temperature measurement), -200 to +400 °C (-328 to +750 °F)"
- Order code for "Sensor version", option DD "mass gas/liquid; Alloy 718; 316L (integrated pressure/temperature measurement), -40 to +100 °C (-40 to +212 °F)"

The second temperature measurement is taken using a separate temperature sensor. The measuring device reads in this value via a communication interface.

- In the case of saturated steam delta heat measurements, the measuring device must be installed on the steam side.
- In the case of water delta heat measurements, the device can be installed on the cold or warm side.



☑ 7 Layout for delta heat measurement of saturated steam and water

- 1 Measuring device
- 2 Temperature sensor
- 3 Heat exchanger
- Q Heat flow

Protective cover

Observe the following minimum head clearance: 222 mm (8.74 in)

 $fere{1}$ For information on the weather protection cover, see o 🖺 179

6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

- For turning the transmitter housing: Open-ended wrench8 mm
- For opening the securing clamps: Allen key3 mm

For sensor

For flanges and other process connections: Corresponding mounting tools

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.

- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the sensor


WARNING

Danger due to improper process sealing!

- Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- Ensure that the gaskets are clean and undamaged.
- Install the gaskets correctly.

1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.

- 2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
- 3. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Mounting the transmitter of the remote version

ACAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature .
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

ACAUTION


Excessive force can damage the housing!

Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:


- Wall mounting
- Pipe mounting

Wall mounting



🖻 8 mm (in)


Post mounting



🖻 9 mm (in)

6.2.5 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- 1. Release the fixing screw.
- 2. Turn the housing to the desired position.
- 3. Firmly tighten the securing screw.

6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.



- 1. Loosen the securing clamp of the electronics compartment cover using an Allen key.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Optional: pull out the display module with a gentle rotational movement.
- 4. Turn the display module to the desired position: max. $8 \times 45^{\circ}$ in every direction.
- 5. Without display module pulled out:

Allow display module to engage at desired position.

- 6. With display module pulled out:Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.
- 7. Reverse the removal procedure to reassemble the transmitter.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	
 Does the measuring device conform to the measuring point specifications? For example: Process temperature Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document → 208) Ambient temperature Measuring range → 183 	
 Has the correct orientation for the sensor been selected → ⁽¹⁾ 20? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids) 	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping $\rightarrow \square 20$?	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected against precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	
Has the maximum permitted insulation height been observed?	

7 Electrical connection

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver \leq 3 mm (0.12 in)

7.1.2 Connecting cable requirements

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Signal cable

Pulse/frequency/switch output

Standard installation cable is sufficient.

FOUNDATION Fieldbus

Twisted, shielded two-wire cable.

For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

Cable diameter

- Cable glands supplied:
 - M20 × 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Plug-in spring terminals for device version without integrated overvoltage protection: wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Screw terminals for device version with integrated overvoltage protection: wire crosssections 0.2 to 2.5 mm² (24 to 14 AWG)

7.1.3 Connecting cable for remote version

Connecting cable (standard)

Standard cable	$2\times2\times0.5~mm^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) $^{1)}$
Flame resistance	According to DIN EN 60332-1-2

Oil-resistance According to DIN EN 60811-2-1		
Shielding Galvanized copper-braid, opt. density approx.85 %		
Cable length	5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft)	
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)	

1) UV radiation may cause damage to the outer jacket of the cable. Protect the cable from exposure to sun as much as possible.

Connecting cable (reinforced)


Cable, reinforced	$2\times2\times0.34~mm^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) and additional steel-wire braided sheath $^{1)}$	
Flame resistance According to DIN EN 60332-1-2		
Oil-resistance	According to DIN EN 60811-2-1	
Shielding	Galvanized copper-braid, opt. density approx. 85%	
Strain relief and reinforcement	Steel-wire braid, galvanized	
Cable length	5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft)	
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ C$ (–58 to +221 $^\circ F); when cable can move freely: –25 to +105 ^\circ C (–13 to +221 ^\circ F)$	

1) UV radiation may cause damage to the outer jacket of the cable. Protect the cable from exposure to sun as much as possible.

7.1.4 Terminal assignment

Transmitter

Connection version for FOUNDATION Fieldbus, pulse/frequency/switch output



Order code for "Output"	Terminal numbers			
	Output 1		Output 2	
	1 (+)	2 (-)	3 (+)	4 (-)
Option E ¹⁾²⁾	FOUNDATION Fieldbus		Pulse/frequency/switch output (passive)	

1) Output 1 must always be used; output 2 is optional.

2) FOUNDATION Fieldbus with integrated reverse polarity protection.

7.1.5 Pin assignment of device plug

Pin		Assignment	Coding	Plug/socket
1	+	Signal +	А	Plug
2	-	Signal –		
3		Grounding		
4		Not assigned		

7.1.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 % is ideal.

- **1.** To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.

- **1.** Observe national installation requirements and guidelines during installation.
- 2. Where there are large differences in potential between the individual grounding points,

connect only one point of the shielding directly to the reference ground.

3. In systems without potential equalization,


the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- Insulate the shield that is not connected.



10 Connection example for FOUNDATION Fieldbus

- 1 Control system (e.g. PLC)
- 2 Power conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

7.1.7 Requirements for the supply unit

Supply voltage

Transmitter

An external power supply is required for each output.

The following supply voltage values apply for the outputs available:

Supply voltage for a compact version without a local display¹⁾

Order code for "Output"	Minimum terminal voltage ²⁾	Maximum terminal voltage	
Option E : FOUNDATION Fieldbus, pulse/ frequency/switch output	≥ DC 9 V	DC 32 V	

1) In event of external supply voltage of the power conditioner

2) The minimum terminal voltage increases if local operation is used: see the following table

Increase in minimum terminal voltage

Local operation	Increase in minimum terminal voltage
Order code for "Display; Operation", option C : Local operation SD02	+ DC 1 V
Order code for "Display; Operation", option E : Local operation SD03 with lighting (backlighting not used)	+ DC 1 V
Order code for "Display; Operation", option E : Local operation SD03 with lighting (backlighting used)	+ DC 3 V

7.1.8 Preparing the measuring device

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Connection housing, sensor: Connect connecting cable.
- **3.** Transmitter: Connect connecting cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- **3.** If the measuring device is supplied with cable glands:

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ► Have electrical connection work carried out by appropriately trained specialists only.
- ► Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the compact version

Connecting the transmitter

Connection via terminals



- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect cable in accordance with terminal assignment $\rightarrow \square$ 31.
- 6. **WARNING**


Housing degree of protection may be voided due to insufficient sealing of the housing.

 Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Firmly tighten the cable glands.

7. Reverse the removal procedure to reassemble the transmitter.

Removing a cable



 To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes while simultaneously pulling the cable end out of the terminal.

7.2.2 Connecting the remote version

WARNING

Risk of damaging the electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.

The following procedure (in the action sequence given) is recommended for the remote version:

- 1. Mount the sensor and transmitter.
- 2. Connect the connecting cable for the remote version.
- 3. Connect the transmitter.

How the connecting cable is connected in the transmitter housing depends on the measuring device approval and the version of the connecting cable used.

In the following versions, only terminals can be used for connection in the transmitter housing:

• Certain approvals: Ex nA, Ex ec, Ex tb and Division 1


Use of reinforced connecting cable

In the following versions, an M12 device connector is used for connection in the transmitter housing:

- All other approvals
- Use of connecting cable (standard)


Terminals are always used to connect the connecting cable in the sensor connection housing (tightening torques for screws for cable strain relief: 1.2 to 1.7 Nm).

Connecting the sensor connection housing



1. Loosen the securing clamp.

2. Unscrew the housing cover.



🗷 11 Sample graphic

Connecting cable (standard, reinforced)

- **3.** Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
- 4. Wire the connecting cable:
 - Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = yellow cable
 - Terminal 4 = green cable
- 5. Connect the cable shield via the cable strain relief.
- 6. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 7. Reverse the removal procedure to reassemble the connection housing.


Connecting cable (option "mass pressure-/temperature-compensated")

3. Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).

- 4. Wire the connecting cable:
 - └ Terminal 1 = brown cable
 - Terminal 2 = white cable
 - Terminal 3 =green cable
 - Terminal 4 = red cable Terminal 5 = black cable
 - Terminal 6 = yellow cable
 - Terminal 7 = blue cable
- 5. Connect the cable shield via the cable strain relief.
- 6. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 7. Reverse the removal procedure to reassemble the connection housing.


Connecting the transmitter

Connecting transmitter via plug




► Connect the plug.

Connecting transmitter via terminals





- **1.** Loosen the securing clamp of the electronics compartment cover.
- 2. Unscrew the electronics compartment cover.
- **3.** Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.



4. Loosen the locking screw of the transmitter housing.

5. Loosen the securing clamp of the transmitter housing.






6. Turn the transmitter housing to the right until it reaches the marking.

7. NOTICE


The connection board of the wall housing is connected to the electronics board of the transmitter via a signal cable!

> Pay attention to the signal cable when lifting the transmitter housing!

Lift the transmitter housing.







🖻 14 Sample graphic

Connecting cable (standard, reinforced)

- 8. Disconnect the signal cable from the connection board of the wall housing . by pressing in the locking clip on the connector. Remove the transmitter housing.
- **9.** Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).
- **10.** Wire the connecting cable:
 - ➡ Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = yellow cable Terminal 4 = green cable
- 11. Connect the cable shield via the cable strain relief.
- 12. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 13. Reverse the removal procedure to reassemble the transmitter housing.

Connecting cable (option "mass pressure-/temperature-compensated")

- 8. Disconnect both signal cables from the connection board of the wall housing. by pressing in the locking clip on the connector. Remove the transmitter housing.
- **9.** Guide the connecting cable through the cable entry and into the connection housing (if using a connecting cable without an M12 device plug, use the shorter stripped end of the connecting cable).

10. Wire the connecting cable:

- Terminal 1 = brown cable Terminal 2 = white cable Terminal 3 = green cable Terminal 4 = red cable Terminal 5 = black cable Terminal 6 = yellow cable Terminal 7 = blue cable
- **11.** Connect the cable shield via the cable strain relief.
- 12. Tighten the screws for the cable strain relief using a torque in the range of 1.2 to 1.7 Nm.
- 13. Reverse the removal procedure to reassemble the transmitter housing.

7.2.3 Ensuring potential equalization

Requirements

Please consider the following to ensure correct measurement:


- Same electrical potential for the fluid and sensor
- Remote version: same electrical potential for the sensor and transmitter
- Company-internal grounding concepts
- Pipe material and grounding

7.3 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.
- To ensure that moisture does not enter the cable entry: Route the cable so that it loops down before the cable entry ("water trap").




6. Insert dummy plugs into unused cable entries.

7.4 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables used meet the requirements $\rightarrow \square$ 29?	
Do the mounted cables have adequate strain relief?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" $\rightarrow {} 40?$	
Depending on the device version, are all the device plugs firmly tightened $\rightarrow \square 34$?	
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	
Does the supply voltage match the specifications on the transmitter nameplate $\rightarrow \square$ 33?	
Is the terminal assignment correct ?	
If supply voltage is present, do values appear on the display module?	
Are all the housing covers installed and tightened?	
Is the securing clamp tightened correctly?	
Have the screws for the cable strain relief been tightened using the correct torque \rightarrow \cong 35?	

Operation options 8

8.1 **Overview of operation options**




- 1
- Local operation via display module Computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) 2
- 3 4 Field Xpert SFX350 or SFX370 Field Communicator 475
- 5 Control system (e.g. PLC)
- 6 VIATOR Bluetooth modem with connecting cable

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: "Description of Device Parameters" document supplied with the device



 $\blacksquare 15$ Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Men	u/parameter	User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuring the operational	Defining the operating languageResetting and controlling totalizers
Operation		 configuring the operational display Reading measured values 	 Configuring the operational display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup		 "Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs 	 Wizards for fast commissioning: Setting the system units Defining the medium Configuring the current input Configuring the outputs Configuring the operational display Defining the output conditioning Setting the low flow cut off Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuring the WLAN settings Administration (define access code, reset measuring device)
Diagnostics		 "Maintenance" role Fault elimination: Diagnostics and elimination of process and device errors Measured value simulation 	Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device. Measured values Contains all current measured values. Data logging submenu with "Extended HistoROM" order option Storage and visualization of measured values Heartbeat The functionality of the device is checked on demand and the verification results are documented. Simulation Is used to simulate measured values or output values.
Expert	function-oriented	 Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases 	 Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-order device parameters which do not concern the measurement or the communication interface. Sensor Configuration of the measurement. Output Configure the pulse/frequency/switch output. Communication Configuration of the digital communication interface. Submenus for function blocks (e.g. "Analog Inputs") Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



- 1 Operational display
- 2 Device tag $\rightarrow \square 67$
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements $\rightarrow \cong 48$

Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 134
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- Diagnostic behavior → 🗎 135
 - 🛛 🐼: Alarm
 - M: Warning
- $\widehat{\square}$: Locking (the device is locked via the hardware)
- +: Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured values

Symbol	Meaning
Ú	Volume flow
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.

Measurement channel numbers


Symbol	Meaning
14	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols $\rightarrow \cong 135$


The number and display format of the measured values can be configured via the **Format display** parameter ($\rightarrow \cong 77$).

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



For more information about the icons in the menu, refer to the "Display area" section $\rightarrow \cong 46$

Status area

The following appears in the status area of the navigation view in the top right corner: • In the submenu

- The direct access code for the parameter you are navigating to (e.g. 0022-1)
- If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
- If a diagnostic event is present, the diagnostic behavior and status signal
- For information on the diagnostic behavior and status signal →
 For information on the function and entry of the direct access code →
 51

Display area

Menus

Symbol	Meaning
Ŵ	Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu
۶	Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
ų	Diagnostics Appears: In the menu next to the "Diagnostics" selection At the left in the navigation path in the Diagnostics menu
-3 ^e	 Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
<u>⊳</u>	Wizard
Ø	Parameters within a wizard Image: No display symbol exists for parameters in submenus.


Locking

Symbol	Meaning
ô	 Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. By a user-specific access code By the hardware write protection switch

Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
\checkmark	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 Editing view



Input mask

The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
0 9	Selection of numbers from 0 to 9.
·	Inserts decimal separator at the input position.
_	Inserts minus sign at the input position.
	Confirms selection.
+	Moves the input position one position to the left.
	Exits the input without applying the changes.
C	Clears all entered characters.

Text editor

Symbol	Meaning
(Aa1@)	Toggle • Between upper-case and lower-case letters • For entering numbers • For entering special characters
ABC_ XYZ	Selection of letters from A to Z.

abc _ xyz	Selection of letters from a to z.
···· ··· ~& _	Selection of special characters.
\checkmark	Confirms selection.
₩C +→	Switches to the selection of the correction tools.
X	Exits the input without applying the changes.
C	Clears all entered characters.

Correction symbols under **∞***c*+→

Symbol	Meaning
C	Clears all entered characters.
Ð	Moves the input position one position to the right.
Ð	Moves the input position one position to the left.
×.	Deletes one character immediately to the left of the input position.

8.3.4 Operating elements

Operating key(s)	Meaning
	Minus key
	<i>In a menu, submenu</i> Moves the selection bar upwards in a picklist.
	With a Wizard Confirms the parameter value and goes to the previous parameter.
	With a text and numeric editor In the input screen, moves the selection bar to the left (backwards).
	Plus key
+	In a menu, submenu Moves the selection bar downwards in a picklist.
	<i>With a Wizard</i> Confirms the parameter value and goes to the next parameter.
	With a text and numeric editor Moves the selection bar to the right (forwards) in an input screen.

Operating key(s)	Meaning		
	Enter key		
	For operational display Pressing the key for 2 s opens the context menu.		
Ē	 In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter. 		
	<i>With a Wizard</i> Opens the editing view of the parameter.		
	 With a text and numeric editor Pressing the key briefly: Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value. 		
	Escape key combination (press keys simultaneously)		
⊕+⊕	 In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). 		
	<i>With a Wizard</i> Exits the wizard and takes you to the next higher level.		
	With a text and numeric editor Closes the text or numeric editor without applying changes.		
	Plus/Enter key combination (press and hold down the keys simultaneously)		
	Increases the contrast (darker setting).		
	Minus/Plus/Enter key combination (press the keys simultaneously)		
-+++E	For operational display Enables or disables the keypad lock (only SD02 display module).		

8.3.5 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Configuration backup display
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the \Box and \Box keys for longer than 3 seconds.
 - └ The context menu opens.

XX	XXXXXXXX	
Üſ	Setup	
Ň	Conf.backup disp	
P (1 Simulation	
₿(1 Keylock on	

- 2. Press \Box + \pm simultaneously.
 - ← The context menu is closed and the operational display appears.

A0034284-EN

Calling up the menu via the context menu

1. Open the context menu.


- 2. Press \pm to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - └ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\rightarrow \cong 45$


Example: Setting the number of displayed measured values to "2 values"



8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path Expert \rightarrow Direct access The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically. Example: Enter 00914 → Assign process variable parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.

Example: Enter $00914\text{-}2 \rightarrow Assign \ process \ variable \ parameter$

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

8.3.8 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

← The help text for the selected parameter opens.




16 Example: Help text for parameter "Enter access code"

- 2. Press \Box + \pm simultaneously.
 - ← The help text is closed.

8.3.9 Changing the parameters

For a description of the editing view - consisting of the text editor and numeric editor - with symbols $\rightarrow \cong 47$, for a description of the operating elements $\rightarrow \cong 48$

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A message is displayed if the value entered is outside the permitted value range.

Ent. acc	ess code
Invalid c	or out of range input
value	
Min:0	
Max:999	9

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access .

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- Define the access code.
 - ← The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	1)

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	1)

 Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

The user role with which the user is currently logged on is indicated by the **Access** status display parameter. Navigation path: Operation \rightarrow Access status display

8.3.11 Disabling write protection via access code

If the @-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\rightarrow @$ 110.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter via the respective access option.

1. After you press 🗉, the input prompt for the access code appears.

2. Enter the access code.

└ The B -symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

For the SD03 display only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press the \Box and \blacksquare keys for 3 seconds.

- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- ► The keypad lock is switched on. Press the □ and □ keys for 3 seconds.
 - ← The keypad lock is switched off.


8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.4.1 Connecting the operating tool

Via FOUNDATION Fieldbus network


This communication interface is available in device versions with FOUNDATION Fieldbus.



🖻 17 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring device

Via service interface (CDI)



1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring device

- 2 Commubox FXA291
- 3 Computer with FieldCare operating tool with COM DTM CDI Communication FXA291

8.4.2 Field Xpert SFX350, SFX370

Function range

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

Source for device description files

See information $\rightarrow \cong 60$

8.4.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information $\rightarrow \cong 60$

Establishing a connection

For additional information, see Operating Instructions BA00027S and BA00059S

5 6 7 2 3 4 D 🗳 🖬 🖨 🖨 💭 📖 🗽 🐂 😭 🖉 🖉 🦉 • 10 - 1 Xxxxxx/.../.../ **Device name** kg/h Xxxxxxx Mass flow: 2 12.34 Device tag: Xxxxxx *C* 12.34 1 Volume flow: m³/h 65 Good Status: 🖸 📝 ピ 🎯 🧔 kg/h 🔽 D Xxxxxx Mass flow unit: --P Access status tooling Maintenance m³/h 🔽 Volume flow unit: 🖶 … 🛅 Operation 🖶 🗁 🛱 -P Device tag Xxxxxx ---P System units kg/h 9 8 Volume flow unit m³/h 🗄 … 🛅 Select medium ... 🗂 ⊟ •--. ⊞…. ☐ Advanced setup ·📁 Diagnostics --- Expert Ė٩. 🔹 | 🔲 | User Role: Planning eng scted 3 10 11 A0021051-EN

User interface

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal $\rightarrow \square 137$
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.4.4 DeviceCare

Function scope

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.

For details, see Innovation Brochure IN01047S

Source for device description files

See information $\rightarrow \square 60$

8.4.5 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via FOUNDATION Fieldbus H1 protocol.

Source for device description files

See data $\rightarrow \square 60$

8.4.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via FOUNDATION Fieldbus H1 protocol.

Source for device description files

See data $\rightarrow \textcircled{1}{60}$ 60

9 System integration

9.1 **Overview of device description files**

9.1.1 Current version data for the device

Firmware version	01.01.00	 On the title page of the Operating Instructions On the transmitter nameplate Firmware version parameter Diagnostics → Device information → Firmware version 	
Release date of firmware version	01.2018		
Manufacturer ID	452B48 hex	Manufacturer ID parameter Diagnostics → Device information → Manufacturer ID	
Device type ID	0x1038	Device type parameter Diagnostics \rightarrow Device information \rightarrow Device type	
Device revision	2	 On the transmitter nameplate Device revision parameter Diagnostics → Device information → Device revision 	
DD revision	Information and files under: • www.endress.com • www.fieldbus.org		
CFF revision			

For an overview of the different firmware versions for the device

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via FOUNDATION Fieldbus	Sources for obtaining device descriptions
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
Field Xpert SFX350Field Xpert SFX370	Use update function of handheld terminal
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal

9.2 Cyclic data transmission

Cyclic data transmission when using the device description files (DD).

9.2.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a FOUNDATION Fieldbus master (Class 1), e.g. a control system etc.

Display text (xxxx = serial number)	Base index	Description
RESOURCE_ xxxxxxxxx	400	Resource block
SETUP_ xxxxxxxxx	600	"Setup" Transducer block
DISPLAY_ xxxxxxxxx	800	"Display" Transducer block
HISTOROM_ xxxxxxxxx	1000	"HistoROM" Transducer block
DIAGNOSTIC_xxxxxxxxx	1200	"Diagnostic" Transducer block
EXPERT_CONFIG_xxxxxxxxxx	1400	"Expert configuration" Transducer block
SERVICE_SENSOR_xxxxxxxxxx	1600	"Service sensor" Transducer block
TOTAL_INVENTORY_COUNTER_xxxxxxx xxx	1800	"Totalizer" Transducer block
HEARTBEAT_TECHNOLOGY_xxxxxxxxxx	2000	"Heartbeat" Transducer block
ANALOG_INPUT_1_xxxxxxxxxx	3600	Analog Input function block 1 (AI)
ANALOG_INPUT_2_xxxxxxxxxx	3800	Analog Input function block 2 (AI)
ANALOG_INPUT_3_xxxxxxxxxx	4000	Analog Input function block 3 (AI)
ANALOG_INPUT_4_xxxxxxxxxx	4200	Analog Input function block 4 (AI)
MULTI_ANALOG_OUTPUT_ xxxxxxxxxx	4400	Multiple Analog Output block (MAO)
DIGITAL_INPUT_1_xxxxxxxxxx	4600	Discrete Input function block 1 (DI)
DIGITAL_INPUT_2_xxxxxxxxxx	4800	Discrete Input function block 2 (DI)
MULTI_DIGITAL_OUTPUT_ xxxxxxxxx	5000	Multiple Discrete Output block (MDO)
PID_xxxxxxxxxx	5200	PID function block (PID)
INTEGRATOR_xxxxxxxxx	5400	Integrator function block (INTG)

9.2.2 Description of the modules

The input value of a module/function block is defined via the **Channel** parameter.

AI module (Analog Input)

Four Analog Input blocks are available.

Channel	Measured variable
0	Uninitialized (factory setting)
7	Temperature
9	Volume flow
11	Mass flow
13	Corrected volume flow
14	Density
16	Totalizer 1
17	Totalizer 2
18	Totalizer 3
20	Pressure
21	Specific volume
37	Flow velocity
38	Energy flow
45	Calculated saturated steam pressure
46	Total mass flow

Channel	Measured variable
47	Condensate mass flow
49	Heat flow difference
50	Reynolds number
74	Degree of overheating

MAO module (Multiple Analog Output)

Channel	Designation
121	Channel_0

Structure

Channel_0							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Values	Measured variable
Value 1	External pressure ¹⁾
Value 2	Relative pressure
Value 3	Density
Value 4	Temperature
Value 5	2nd temperature heat difference
Value 6	Not assigned
Value 7	Not assigned
Value 8	Not assigned

1) The compensation variables must be transmitted to the device in the SI basic unit

The selection is made via: Expert \rightarrow Sensor \rightarrow External compensation

DI module (Discrete Input)

Two Discrete Input blocks are available.

Channel	Device function	State
0	Uninitialized (factory setting)	-
101	Switch output state	0 = Not active1 = Active

Channel	Device function	State
103	Low flow	0 = Not active1 = Active
105	Status verification ¹⁾	<pre>Verification status Verification: 0 = Not done 1 = Failed 2 = Being performed 3 = Finished Overall result of the verification Verification: 4 = Failed 5 = Passed 6 = Not done 7 = Not used Status; result 17 = Status: Not done; Result: failed 18 = Status: failed; Result: failed 20 = Status: being performed; Result: failed 33 = Status: Not done; Result: passed 34 = Status: failed; Result: passed 40 = Status: being performed; Result: passed 40 = Status: Not done; Result: passed 40 = Status: finished; Result: passed 65 = Status: Not done; Result: passed 66 = Status: being performed; Result: passed 66 = Status: being performed; Result: passed 66 = Status: Not done; Result: Not done 66 = Status: Not done; Result: Not done; Result: Not done 68 = Status: being performed; Result: Not done 72 = Status: finished; Result: Not done </pre>

1) Only available with the Heartbeat Verification application package

MDO module (Multiple Discrete Output)

Channel	Designation
122	Channel_DO

Structure

Channel_DO							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Value	Device function	State
Value 1	Reset totalizer 1	0 = off, 1 = execute
Value 2	Reset totalizer 2	0 = off, 1 = execute
Value 3	Reset totalizer 3	0 = off, 1 = execute
Value 4	Flow override	0 = off, 1 = active

Value	Device function	State
Value 5	Start heartbeat verification ¹⁾	0 = off, 1 = start
Value 6	Status switch output	0 = off, 1 = on
Value 7	Not assigned	-
Value 8	Not assigned	-

1) Only available with the Heartbeat Verification application package

9.2.3 Execution times

Function block	Execution time (ms)
Analog Input function block (AI)	14
Discrete Input function block (DI)	12
PID function block (PID)	13
Multiple Analog Output block (MAO)	11
Multiple Discrete Output block (MDO)	14
Integrator function block (INTG)	16

9.2.4 Methods

Method	Block	Navigation	Description
Set to "AUTO" mode	Resource block	Via menu: Expert → Communication → Resource block → Target mode	This method sets the Resource Block and all the Transducer Blocks to the AUTO (Automatic) mode.
Set to "OOS" mode	Resource block	Via menu: Expert \rightarrow Communication \rightarrow Resource block \rightarrow Target mode	This method sets the Resource Block and all the Transducer Blocks to the OOS (Out of service) mode.
Restart	Resource block	Via menu: Expert → Communication → Resource block → Restart	This method is used to select the configuration for the Restart parameter in the Resource Block. This resets device parameters to a specific value.
			The following options are supported: • Uninitialized • Run • Resource • Defaults • Processor • To delivery settings
ENP parameter	Resource block	Via menu: Actions → Methods→ Calibrate → ENP parameter	This method is used to display and configure the parameters of the electronic nameplate (ENP).
Overview diagnostics - Remedy information	Diagnostic Transducer Block	Via link: Namur symbol	This method is used to display the diagnostic event with the highest priority that is currently active and the corresponding remedial measures.
Actual diagnostics – Remedy information	Diagnostic Transducer Block	 Via menu: Configure/Setup → Diagnostics → Actual diagnostics Device/Diagnostics → Diagnostics 	This method is used to display remedial measures for the diagnostic event with the highest priority that is currently active. This method is available only if an appropriate diagnostic event has occurred.
Previous diagnostics – Remedy information	Diagnostic Transducer Block	 Via menu: Configure/Setup → Diagnostics → Previous diagnostics Device/Diagnostics → Diagnostics 	This method is used to display remedial measures for the previous diagnostic event. This method is available only if an appropriate diagnostic event has occurred.

Method	Block	Navigation	Description
Diagnostics 1 – Remedy information	Diagnostic Transducer Block	 Via menu: Configure/Setup → Diagnostics → Diagnostic list → Diagnostics 1 Via menu Device/Diagnostics → Diagnostics list Instrument health status → Diagnostic list 	This method is used to display remedial measures for the diagnostic event with the highest priority that is currently active. This method is available only if an appropriate diagnostic event has occurred.
Diagnostics 2 – Remedy information	Diagnostic Transducer Block	 Via menu: Configure/Setup → Diagnostics → Diagnostic list → Diagnostics 2 Via menu: Device/Diagnostics → Diagnostics list Instrument health status → Diagnostic list 	This method is used to display remedial measures for an additional active diagnostic event. This method is available only if an appropriate diagnostic event has occurred.

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist \rightarrow 🗎 28
- "Post-connection check" checklist $\rightarrow \oplus 40$


10.2 Switching on the measuring device

- ► After a successful function check, switch on the measuring device.
 - ← After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" $\rightarrow \cong 132$.

10.3 Setting the operating language


Factory setting: English or ordered local language




I8 Taking the example of the local display

10.4 Configuring the measuring device

- The Setup menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu




19 Taking the example of the local display



10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



■ 20 Header of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool $\rightarrow \square 58$

Navigation

"Setup" menu \rightarrow Device tag

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /)	EH_Prowirl_200_xxxxxxxxxx

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

Navigation

"Setup" menu → System units

► System units	
Volume flow unit	→ 🗎 69
Volume unit	→ 🗎 69
Mass flow unit	→ 🗎 69
Mass unit) → 🗎 69
Corrected volume flow unit	→ 🗎 69
Corrected volume unit) → 🗎 69
Pressure unit) → 🗎 70
Temperature unit	→ 🗎 70

Energy flow unit	→ 曽 70
Energy unit	→ 🗎 70
Calorific value unit	→ 🗎 70
Calorific value unit	→ 🗎 70
Velocity unit	→ 🗎 71
Density unit	→ 🗎 71
Specific volume unit	→ 曽 71
Dynamic viscosity unit	→ 曽 71
	→ 🗎 71
Length unit	→ □/1

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	-	Select volume flow unit. Result The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • m ³ /h • ft ³ /min
Volume unit	-	Select volume unit.	Unit choose list	Country-specific: • m ³ • ft ³
Mass flow unit	-	Select mass flow unit. Result The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: kg/h lb/min
Mass unit	-	Select mass unit.	Unit choose list	Country-specific: • kg • lb
Corrected volume flow unit	-	Select corrected volume flow unit. Result The selected unit applies for: Corrected volume flow parameter ($\rightarrow \square$ 125)	Unit choose list	Country-specific: • Nm³/h • Sft³/h
Corrected volume unit	-	Select corrected volume unit.	Unit choose list	Country-specific: • Nm ³ • Sft ³

Parameter	Prerequisite	Description	Selection	Factory setting
Pressure unit	With order code for "Sensor version": option "Mass (integrated temperature measurement)"	 Select process pressure unit. <i>Result</i> The unit is taken from: Calculated saturated steam pressure Atmospheric pressure Maximum value Fixed process pressure Pressure Reference pressure 	Unit choose list	Country-specific: • bar • psi
Temperature unit		Select temperature unit. <i>Result</i> The selected unit applies for: • Temperature • Maximum value • Minimum value • Average value • Maximum value • Minimum value • Minimum value • Minimum value • Atemperature delta heat • Fixed temperature • Reference combustion temperature • Reference temperature • Saturation temperature	Unit choose list	Country-specific: • °C • °F
Energy flow unit	With order code for "Sensor version": option "Mass (integrated temperature measurement)"	Select energy flow unit. <i>Result</i> The selected unit applies for: • Heat flow difference parameter • Energy flow parameter	Unit choose list	Country-specific: • kW • Btu/h
Energy unit	With order code for "Sensor version": option "Mass (integrated temperature measurement)"	Select energy unit.	Unit choose list	Country-specific: • kWh • Btu
Calorific value unit	 The following conditions are met: Order code for "Sensor version", option "Mass (integrated temperature measurement)" The Gross calorific value volume option or the Net calorific value volume option is selected in the Calorific value type parameter. 	Select calorific value unit. <i>Result</i> The selected unit applies for: Reference gross calorific value	Unit choose list	Country-specific: • kJ/Nm ³ • Btu/Sft ³
Calorific value unit (Mass)	 The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" The Gross calorific value mass option or the Net calorific value mass option is selected in the Calorific value type parameter. 	Select calorific value unit.	Unit choose list	Country-specific: • kJ/kg • Btu/lb

Parameter	Prerequisite	Description	Selection	Factory setting
Velocity unit	-	Select velocity unit. <i>Result</i> The selected unit applies for: • Flow velocity • Maximum value	Unit choose list	Country-specific: • m/s • ft/s
Density unit	-	Select density unit. <i>Result</i> The selected unit applies for: • Output • Simulation process variable	Unit choose list	Country-specific: • kg/m ³ • lb/ft ³
Specific volume unit	With order code for "Sensor version": Option "Mass (integrated temperature measurement)"	Select the unit for the specific volume. <i>Result</i> The selected unit applies for: Specific volume	Unit choose list	Country-specific: • m³/kg • ft³/lb
Dynamic viscosity unit	-	Select dynamic viscosity unit. Result The selected unit applies for: • Dynamic viscosity parameter (gases) • Dynamic viscosity parameter (liquids)	Unit choose list	Pa s
Length unit	-	Select length unit for nominal diameter. <i>Result</i> The selected unit applies for: Inlet run Mating pipe diameter	Unit choose list	Country-specific: mm in

10.4.3 Selecting and setting the medium

The **Medium selection** wizard systematically guides the user through all the parameters that must be configured in order to select and set the medium.

Navigation

"Setup" menu \rightarrow Medium selection

► Medium selection	on	
	Select medium	→ 🗎 72
	Select gas type	→ 🗎 72
	Gas type	→ 🖺 73
	Relative humidity	→ 🗎 73
	Liquid type	→ 🗎 73
	Steam calculation mode	→ 🗎 73
	Enthalpy calculation	→ 🗎 74
	Density calculation	→ 🖺 74
	Enthalpy type	→ 🗎 74

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Select medium	-	Select medium type.	GasLiquidSteam	Steam
Select gas type	 The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" The Gas option is selected in the Select medium parameter parameter. 	Select measured gas type.	 Single gas Gas mixture Air Natural gas User-specific gas 	User-specific gas

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Gas type	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Single gas option is selected. 	Select measured gas type.	 Hydrogen H2 Helium He Neon Ne Argon Ar Krypton Kr Xenon Xe Nitrogen N2 Oxygen O2 Chlorine Cl2 Ammonia NH3 Carbon monoxide CO Carbon dioxide CO2 Sulfur dioxide SO2 Hydrogen sulfide H2S Hydrogen chloride HCI Methane CH4 Ethane C2H6 Propane C3H8 Butane C4H10 Ethylene C2H4 Vinyl Chloride C2H3Cl 	Methane CH4
Relative humidity	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Air option is selected. 	Enter humidity content of air in %.	0 to 100 %	0 %
Steam calculation mode	The Steam option is selected in the Select medium parameter parameter.	Select calculation mode of steam: based on saturated steam (T-compensated) or automatic detection (p-/T- compensated).	 Saturated steam (T-compensated) Automatic (p-/T- compensated) 	Saturated steam (T- compensated)
Liquid type	 The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" The Liquid option is selected in the Select medium parameter parameter. 	Select measured liquid type.	 Water LPG (Liquefied Petroleum Gas) User-specific liquid 	Water
Fixed process pressure	 The following conditions are met: Order code for "Sensor version", Option "Mass flow (integrated temperature measurement)" In the External value parameter (→ 94) the Pressure option is not selected. 	 Enter fixed value for process pressure. Dependency The unit is taken from the Pressure unit parameter. In For detailed information on the calculation of the measured variables with steam: → ■ 120 	0 to 250 bar abs.	0 bar abs.

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Enthalpy calculation	 The following conditions are met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" In the Select medium parameter, the Gas option is selected and in the Select gas type parameter, the Natural gas option is selected. 	Select the norm the enthalpy calculation is based on.	• AGA5 • ISO 6976	AGA5
Density calculation	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. 	Select the norm the density calculation is based on.	 AGA Nx19 ISO 12213- 2 ISO 12213- 3 	AGA Nx19
Enthalpy type	 The following conditions are met: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the User-specific liquid option is selected. 	Define which kind of enthalpy is used.	HeatCalorific value	Heat

10.4.4 Configuring the analog inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

Navigation

"Setup" menu \rightarrow Analog inputs

► Analog inputs	
► Analog input 1 to n	
Block tag	→ 🗎 75
Channel	→ 🗎 75
Process Value Filter Time	→ 🗎 75

Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Block tag	Unique name of the measuring device.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /).	ANALOG_INPUT_1 4_Serial number
Channel	Use this function to select the process variable.	 Uninitialized Mass flow Flow velocity Volume flow Corrected volume flow Temperature Calculated saturated steam pressure* Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Totalizer 1 Totalizer 2 Totalizer 3 Density* Pressure* Specific volume* Degrees of superheat* 	Uninitialized
Process Value Filter Time	Enter the filter time specification for the filtering of the unconverted input value (PV).	Positive floating-point number	0 s

* Visibility depends on order options or device settings

10.4.5 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation "Setup" menu → Display

► Display		
	Format display	→ 🗎 77
	Value 1 display	→ 🗎 77
	0% bargraph value 1	→ 🗎 77
	100% bargraph value 1	→ 🗎 77
	Value 2 display	→ 🗎 77
	Value 3 display	→ 🗎 77
	0% bargraph value 3	→ 🗎 77
	100% bargraph value 3	→ 🗎 77
	Value 4 display	→ 🗎 77

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure* Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Density* Pressure* Specific volume* Degrees of superheat* Totalizer 1 Totalizer 2 Totalizer 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 77)	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 77$)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 77$)	None

* Visibility depends on order options or device settings

10.4.6 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

The measuring signal must have a certain minimum signal amplitude so that the signals can be evaluated without any errors. Using the nominal diameter, the corresponding flow can also be derived from this amplitude. The minimum signal amplitude depends on the setting for the sensitivity of the DSC sensor (s), the steam quality (x) and the force of the vibrations present (a). The value mf corresponds to the lowest measurable flow velocity without vibration (no wet steam) at a density of 1 kg/m^3 (0.0624 lbm/ft^3). The value mf can be set in the range from 6 to 20 m/s (1.8 to 6 ft/s) (factory setting 12 m/s (3.7 ft/s)) with the **Sensitivity** parameter (value range 1 to 9, factory setting 5).

Navigation

"Setup" menu \rightarrow Low flow cut off


► Low flow cut off	
Sensitivity	→ 🗎 78
Turn down	→ 🖹 78

Parameter	Description	User entry	Factory setting
Sensitivity	Adjust sensitivity of the device in the lower flow range. Lower sensitivity leads to more robustness against external interference.	1 to 9	5
	The parameter determines the level of sensitivity at the lower end of the measuring range (start of measuring range). Low values can improve the robustness of the device with regard to external influences. The start of measuring range is then set to a higher value. The smallest specified measuring range is when sensitivity is at a maximum.		
Turn down	Adjust the turn down. Lower turn down increases the minimum measureable flow frequency.	50 to 100 %	100 %
	The measuring range can be limited with this parameter, if necessary. The upper end of the measuring range is not affected. The start of the low end of the measuring range can be changed to a higher flow value, making it possible to cut off low flows, for example.		

10.5 Advanced settings

The Advanced setup submenu together with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




The number of submenus can vary depending on the device version. Some submenus are not dealt with in the Operating Instructions. These submenus and the parameters they contain are explained in the Special Documentation for the device.

Navigation

"Setup" menu \rightarrow Advanced setup

► Advanced setup	
Enter access code	
► Medium properties	→ 🗎 80
► External compensation	→ ⇒ 93
► Sensor adjustment	→ 🗎 95
Pulse/frequency/switch output	→ 🗎 96



10.5.1 Setting the medium properties

In the **Medium properties** submenu the reference values for the measuring application can be set.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Medium properties

► Medium properties	
Enthalpy type] → 🖹 81
Calorific value type] → 🗎 81
Reference combustion temperature] → 🖹 81
Reference density] → 🖹 81
Reference gross calorific value] → 🗎 81
Reference pressure] → 🗎 82
Reference temperature] → 🗎 82
Reference Z-factor] → 🗎 82
Linear expansion coefficient] → 🗎 82
Relative density] → 🗎 82
Specific heat capacity] → 🖹 82
Calorific value] → 🗎 83
Z-factor] → 🗎 83
Dynamic viscosity] → 🗎 83

Dynamic viscosity	→ 🖺 83
► Gas composition	→ 🗎 83

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Enthalpy type	The following conditions are met: In the Select gas type parameter, the User- specific gas option is selected. Or In the Liquid type parameter, the User- specific liquid option is selected.	Define which kind of enthalpy is used.	HeatCalorific value	Heat
Calorific value type	The Calorific value type parameter is visible.	Select calculation based on gross calorific value or net calorific value.	 Gross calorific value volume Net calorific value volume Gross calorific value mass Net calorific value mass 	Gross calorific value mass
Reference combustion temperature	The Reference combustion temperature parameter is visible.	Enter reference combustion temperature to calculate the natural gas energy value. <i>Dependency</i> The unit is taken from the Temperature unit parameter	−200 to 450 °C	20 °C
Reference density	 The following conditions are met: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the Water option or User-specific liquid option is selected. 	Enter fixed value for reference density. <i>Dependency</i> The unit is taken from the Density unit parameter	0.01 to 15 000 kg/m ³	1 000 kg/m³
Reference gross calorific value	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. 	Enter reference gross calorific value of the natural gas. <i>Dependency</i> The unit is taken from the Calorific value unit parameter	Positive floating- point number	50 000 kJ/Nm ³

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Reference pressure	The following conditions are met: • Order code for "Sensor version", Option "Mass (integrated temperature measurement)" • The Gas option is selected in the Select medium parameter parameter.	Enter reference pressure for the calulation of the reference density. <i>Dependency</i> The unit is taken from the Pressure unit parameter.	0 to 250 bar	1.01325 bar
Reference temperature	The following conditions are met: The Gas option is selected in the Select medium parameter. Or The Liquid option is selected in the Select medium parameter.	Enter reference temperature for calculating the reference density. <i>Dependency</i> The unit is taken from the Temperature unit parameter	-200 to 450 °C	20 °C
Reference Z-factor	In the Select gas type parameter, the User-specific gas option is selected.	Enter real gas constant Z for gas under reference conditions.	0.1 to 2	1
Linear expansion coefficient	 The following conditions are met: The Liquid option is selected in the Select medium parameter. The User-specific liquid option is selected in the Liquid type parameter. 	Enter linear, medium-specific expansion coefficient for calculating the reference density.	1.0 · 10 ⁻⁶ to 2.0 · 10 ⁻³	2.06 · 10-4
Relative density	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-3 option is selected. 	Enter a relative density of the natural gas.	0.55 to 0.9	0.664
Specific heat capacity	 The following conditions are met: Selected medium: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Heat option is selected. 	Enter the specific heat capacity of the medium. <i>Dependency</i> The unit is taken from the Specific heat capacity unit parameter	0 to 50 kJ/(kgK)	4.187 kJ/(kgK)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Calorific value	 The following conditions are met: Selected medium: In the Select gas type parameter, the User-specific gas option is selected. Or In the Liquid type parameter, the User-specific liquid option is selected. In the Enthalpy type parameter, the Calorific value option is selected. In the Calorific value type parameter, the Gross calorific value volume option or Gross calorific value mass option is selected. 	Enter gross calorific value to calculate the energy flow.	Positive floating- point number	50 000 kJ/kg
Z-factor	In the Select gas type parameter, the User-specific gas option is selected.	Enter real gas constant Z for gas under operation conditions.	0.1 to 2.0	1
Dynamic viscosity (Gases)	 The following conditions are met: Order code for "Sensor version", Option "Volume" or Option "Volume high temperature" The Gas option or the Steam option is selected in the Select medium parameter. or The User-specific gas option is selected in the Select gas type parameter. 	Enter fixed value for dynamic viscosity for a gas/steam. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter.	Positive floating- point number	0.015 cP
Dynamic viscosity (Liquids)	 The following conditions are met: Order code for "Sensor version", Option "Volume" or Option "Volume high temperature" The Liquid option is selected in the Select medium parameter parameter. or The User-specific liquid option is selected in the Liquid type parameter. 	Enter fixed value for dynamic viscosity for a liquid. <i>Dependency</i> The unit is taken from the Dynamic viscosity unit parameter.	Positive floating- point number	1 cP

Configuring the gas composition

In the **Gas composition** submenu the gas composition for the measuring application can be set.

Navigation "Setup" menu \rightarrow Advanced setup \rightarrow Medium properties \rightarrow Gas composition

► Gas composition		
Gas mixture		86
Mol% Ar		86
Mol% C2H3Cl		86
Mol% C2H4		87
Mol% C2H6		87
Mol% C3H8		87
Mol% CH4		87
Mol% Cl2		88
Mol% CO		88
Mol% CO2		88
Mol% H2		88
Mol% H2O		89
Mol% H2S		89
Mol% HCl		89
Mol% He		89
Mol% i-C4H10		90
Mol% i-C5H12		90
Mol% Kr		9 0
Mol% N2		9 0
Mol% n-C10H22		90
Mol% n-C4H10		91
Mol% n-C5H12		91

Mol% n-C6H14		→ 🗎 91
Mol% n-C7H16		→ 🖺 91
Mol% n-C8H18		→ 🗎 92
Mol% n-C9H20		→ 🗎 92
Mol% Ne		→ 🖺 92
Mol% NH3		→ 🗎 92
Mol% O2		→ 🗎 92
Mol% SO2]	→ 🗎 93
Mol% Xe]	→ 🗎 93
Mol% other gas		→ 🗎 93

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Gas mixture	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. 	Select measured gas mixture.	 Hydrogen H2 Helium He Neon Ne Argon Ar Krypton Kr Xenon Xe Nitrogen N2 Oxygen O2 Chlorine Cl2 Ammonia NH3 Carbon monoxide CO Carbon dioxide CO2 Sulfur dioxide SO2 Hydrogen sulfide H2S Hydrogen chloride HCI Methane CH4 Ethane C2H6 Propane C3H8 Butane C4H10 Ethylene C2H4 Vinyl Chloride C2H3CI Others 	Methane CH4
Mol% Ar	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Argon Ar option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C2H3Cl	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Vinyl Chloride C2H3Cl option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% C2H4	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Ethylene C2H4 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C2H6	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Ethane C2H6 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% C3H8	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Propane C3H8 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% CH4	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Methane CH4 option is selected. Or In the Select gas type parameter, the Natural gas option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	100 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% Cl2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Chlorine Cl2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% CO	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon monoxide CO option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% CO2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Carbon dioxide CO2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% H2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen H2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option is not selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% H2O	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% H2S	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Hydrogen sulfide H2S option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% HCl	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Hydrogen chloride HCl option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% He	The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Helium He option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected.	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% i-C4H10	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% i-C5H12	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Kr	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Krypton Kr option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% N2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Nitrogen N2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the AGA Nx19 option or the ISO 12213- 2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C10H22	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% n-C4H10	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Butane C4H10 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213- 2 option is selected. Or In the Select medium parameter, the Liquid option is selected and in the Liquid type parameter, the LPG option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C5H12	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C6H14	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C7H16	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% n-C8H18	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% n-C9H2O	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Natural gas option is selected. In the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Ne	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Neon Ne option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% NH3	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Ammonia NH3 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% O2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected and in the Gas mixture parameter, the Oxygen O2 option is selected. Or In the Select gas type parameter, the Natural gas option is selected and in the Density calculation parameter, the ISO 12213-2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Mol% SO2	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Sulfur dioxide SO2 option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% Xe	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Xenon Xe option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %
Mol% other gas	 The following conditions are met: In the Select medium parameter, the Gas option is selected. In the Select gas type parameter, the Gas mixture option is selected. In the Gas mixture parameter, the Others option is selected. 	Enter amount of substance for the gas mixture.	0 to 100 %	0 %

10.5.2 Performing external compensation

The **External compensation** submenu contains parameters which can be used to enter external or fixed values. These values are used for internal calculations.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow External compensation

► External compensation	
External value	→ 🗎 94
Atmospheric pressure	→ 🗎 94
Delta heat calculation	→ 🗎 94
Fixed density	→ 🗎 94
Fixed density	→ 曽94
Fixed temperature	→ 🗎 94

	2nd temperature delta heat	→ 🗎 94
[Fixed process pressure	→ 🖺 94

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
External value	With order code for "Sensor version": Option "Mass (integrated temperature measurement)"	 Assign variable from external device to process variable. For detailed information on the calculation of the measured variables with steam: → 120 	 Off Pressure Gauge pressure Density Temperature 2nd temperature delta heat 	Off
Atmospheric pressure	In the External value parameter, the Gauge pressure option is selected.	Enter atmospheric pressure value to be used for pressure correction. <i>Dependency</i> The unit is taken from the Pressure unit parameter	0 to 250 bar	1.01325 bar
Delta heat calculation	The Delta heat calculation parameter is visible.	Calculates the transferred heat of a heat exchanger (= delta heat).	 Off Device on cold side Device on warm side 	Device on warm side
Fixed density	With order code for "Sensor version": Option "Volume high temperature"	Enter fixed value for medium density. Dependency The unit is taken from the Density unit parameter.	0.01 to 15 000 kg/m ³	1000 kg/m ³
Fixed density	With order code for "Sensor version": Option "Volume high temperature"	Enter fixed value for medium density. <i>Dependency</i> The unit is taken from the Density unit parameter.	0.01 to 15 000 kg/m ³	5 kg/m ³
Fixed temperature	-	Enter a fixed value for process temperature. <i>Dependency</i> The unit is taken from the Temperature unit parameter	-200 to 450 °C	20 °C
2nd temperature delta heat	The 2nd temperature delta heat parameter is visible.	Enter 2nd temperature value to calculate the delta heat. <i>Dependency</i> The unit is taken from the Temperature unit parameter	-200 to 450 °C	20 °C
Fixed process pressure	 The following conditions are met: Order code for "Sensor version", Option "Mass flow (integrated temperature measurement)" In the External value parameter (→ 94) the Pressure option is not selected. 	 Enter fixed value for process pressure. Dependency The unit is taken from the Pressure unit parameter. Image: For detailed information on the calculation of the measured variables with steam: → Image: 120 	0 to 250 bar abs.	0 bar abs.

10.5.3 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment

► Sensor adjustment	
Inlet configuration	→ 🗎 95
Inlet run	→ 🗎 95
Mating pipe diameter	→ 🗎 95
Installation factor	→ 🗎 95

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Inlet configuration	 The inlet run correction feature: Is a standard feature and can only be used in Prowirl F 200. Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (1 to 6") EN (DIN) ASME B16.5, Sch. 40/80 	Select inlet configuration.	 Off Single elbow Double elbow Double elbow 3D Reduction 	Off
Inlet run	 The inlet run correction feature: Is a standard feature and can only be used in Prowirl F 200. Can be used for the following pressure ratings and nominal diameters: DN 15 to 150 (1 to 6") EN (DIN) ASME B16.5, Sch. 40/80 	Define length of the straight inlet run. <i>Dependency</i> The unit is taken from the Length unit parameter	0 to 20 m	0 m
Mating pipe diameter	_	Enter diameter of mating pipe to enable diameter mismatch correction. Detailed information on diameter mismatch correction: $\rightarrow \cong 96$ <i>Dependency</i> The unit is taken from the Length unit parameter.	0 to 1 m (0 to 3 ft) Input value = 0: Diameter mismatch correction is disabled.	Country-specific: • 0 m • 0 ft
Installation factor	-	Enter factor to adjust for installation conditions.	Positive floating- point number	1.0

Diameter mismatch correction

The measuring device is calibrated according to the ordered process connection. This calibration takes account of the edge at the transition from the mating pipe to the process connection. If the mating pipe used deviates from the ordered process connection, a diameter mismatch correction can compensate for the effects. The difference between the internal diameter of the ordered process connection and the internal diameter of the mating pipe used must be taken into consideration.

The measuring device can correct shifts in the calibration factor which are caused, for example, by a diameter mismatch between the device flange (e.g. ASME B16.5/Sch. 80, DN 50 (2")) and the mating pipe (e.g. ASME B16.5/Sch. 40, DN 50 (2")). Only apply diameter mismatch correction within the following limit values (listed below) for which test measurements have also been performed.

Flange connection:

- DN 15 ($\frac{1}{2}$): ±20 % of the internal diameter
- DN 25 (1"): ±15 % of the internal diameter
- DN 40 (1½"): ±12 % of the internal diameter
- $DN \ge 50$ (2"): ±10 % of the internal diameter

If the standard internal diameter of the ordered process connection differs from the internal diameter of the mating pipe, an additional measuring uncertainty of approx. 2 % o.r. must be expected.

Example

Influence of the diameter mismatch without using the correction function:

- Mating pipe DN 100 (4"), Schedule 80
- Device flange DN 100 (4"), Schedule 40
- This installation position results in a diameter mismatch of 5 mm (0.2 in). If the correction function is not used, an additional measuring uncertainty of approx. 2 % o.r. must be expected.
- If the basic conditions are met and the feature is enabled, the additional measuring uncertainty is 1 % o.r.

10.5.4 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu → Pulse/frequency/switch output

Pulse/frequency/switch output	
Operating mode	→ 🖺 96

Parameter	Description	Selection	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse

Configuring the pulse output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output	
Assign pulse output 1	→ 🗎 97
Value per pulse) → 🗎 97
Pulse width) → 🗎 97
Failure mode	→ 🗎 97
Invert output signal	→ 🗎 97

Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign pulse output	The Pulse option is selected in the Operating mode parameter parameter.	Select process variable for pulse output.	 Off Volume flow Corrected volume flow Mass flow Total mass flow* Energy flow* Heat flow difference* 	Volume flow
Value per pulse	The Pulse option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \boxdot 97$).	Enter measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bigoplus$ 96) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \bigoplus$ 97).	Define time width of the output pulse.	5 to 2 000 ms	100 ms
Failure mode	The Pulse option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \boxdot 97$).	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	-	Invert the output signal.	NoYes	No

* Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output



Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign frequency output	The Frequency option is selected in the Operating mode parameter (→ 🗎 96).	Select process variable for frequency output.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Temperature Pressure Calculated saturated steam pressure* Total mass flow* Energy flow* Heat flow difference* 	Off
Minimum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \square 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \square 98$).	Enter minimum frequency.	0 to 1 000 Hz	0 Hz

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Maximum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \boxdot 98$).	Enter maximum frequency.	0 to 1 000 Hz	1 000 Hz
Measuring value at minimum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \boxdot 98$).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \boxdot 98$).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The Frequency option is selected in the Operating mode parameter ($\rightarrow \square 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \square 98$).	Define output behavior in alarm condition.	 Actual value Defined value 0 Hz 	0 Hz
Failure frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \boxdot 96$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \boxdot 98$).	Enter frequency output value in alarm condition.	0.0 to 1250.0 Hz	0.0 Hz
Invert output signal	-	Invert the output signal.	NoYes	No

* Visibility depends on order options or device settings

Configuring the switch output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output	
Switch output function	→ 🗎 100
Assign diagnostic behavior	r → 🗎 100
Assign limit	→ 🗎 100
Assign flow direction chec	k → 🗎 100
Assign status	→ 🗎 100

2	Switch-on value	÷	₿ 101
5	Switch-off value	→	101
5	Switch-on delay	<i>→</i>	101
5	Switch-off delay	\rightarrow	101
I	Failure mode	÷	₿ 101
[1	Invert output signal	\rightarrow	101

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	 Off On Diagnostic behavior Limit Status 	Off
Assign diagnostic behavior	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. 	Select diagnostic behavior for switch output.	AlarmAlarm or warningWarning	Alarm
Assign limit	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Select process variable for limit function.	 Volume flow Corrected volume flow Mass flow Flow velocity Temperature Pressure Calculated steam pressure* Total mass flow* Energy flow* Heat flow difference* Reynolds number* Totalizer 1 Totalizer 2 Totalizer 3 	Volume flow
Assign flow direction check	 The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. 	Select process variable for flow direction monitoring.	 Off Volume flow Mass flow Corrected volume flow 	Volume flow
Assign status	 The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. 	Select device status for switch output.	Low flow cut offDigital output 6	Low flow cut off

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Switch-on value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
Switch-off value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
Switch-on delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Switch-off delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open
Invert output signal	-	Invert the output signal.	NoYes	No

* Visibility depends on order options or device settings

10.5.5 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable) → 🗎 102
Unit totalizer 1 to n) → 🗎 102
Failure mode) → 🗎 102

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	 Off Volume flow Corrected volume flow Mass flow Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* 	 Totalizer 1: Volume flow Totalizer 2: Mass flow Totalizer 3: Corrected volume flow
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie$ 102) of the Totalizer 1 to n submenu.	Select process variable totalizer unit.	Unit choose list	Country-specific: • m ³ • ft ³
Totalizer operation mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie$ 102) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	Net flow total
Failure mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie 102$) of the Totalizer 1 to n submenu.	Define totalizer behavior in alarm condition.	StopActual valueLast valid value	Stop

* Visibility depends on order options or device settings

10.5.6 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display			
	Format display]	→ 🗎 104
	Value 1 display]	→ 🗎 104
	0% bargraph value 1]	→ 🗎 104
	100% bargraph value 1]	→ 🗎 104
	Decimal places 1]	→ 🗎 104
	Value 2 display]	→ 🗎 104
	Decimal places 2]	→ 🗎 104
	Value 3 display		→ 🗎 104
	0% bargraph value 3]	→ 🗎 104
	100% bargraph value 3		→ 🗎 104
	Decimal places 3]	→ 🗎 105
	Value 4 display]	→ 🗎 105
	Decimal places 4		→ 🗎 105
	Language		→ 🖺 105
	Display interval		→ 🗎 105
	Display damping		→ 🗎 105
	Header		→ 🗎 105
	Header text		→ 🗎 105
	Separator		→ 🗎 105
	Backlight]	→ 🗎 105

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure* Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Density* Pressure Specific volume* Degrees of superheat* Totalizer 1 Totalizer 2 Totalizer 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 77)	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXX X.XXXX 	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🗎 77)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m ³ /h • 0 ft ³ /h
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 77$)	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxx x.xxxx 	x.xx
Language	A local display is provided.	Set display language.	 English Deutsch* Français* Español* Italiano* Nederlands* Portuguesa* Polski* pycский язык (Russian)* Svenska Türkçe* 中文 (Chinese)* 日本語 (Japanese)* 한국어 (Korean)* 환국어 (Korean)* 파과기배 (Arabic)* Bahasa Indonesia* สาษาไทย (Thai)* tiếng Việt (Vietnamese)* čeština (Czech)* 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	Device tagFree text	Device tag
Header text	In the Header parameter, the Free text option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	 . (point) , (comma) 	. (point)
Backlight	Order code for "Display; operation", option E "SD03 4- line, illum.; touch control + data backup function"	Switch the local display backlight on and off.	DisableEnable	Disable

* Visibility depends on order options or device settings

10.5.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup display** submenu.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Configuration backup display

► Configuration backup display	
Operating time) → 🗎 106
Last backup	→ 🗎 106
Configuration management	→ 🗎 106
Comparison result	→ 🗎 106

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface / Selection	Factory setting
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Last backup	A local display is provided.	Indicates when the last data backup was saved to the display module.	Days (d), hours (h), minutes (m) and seconds (s)	-
Configuration management	A local display is provided.	Select action for managing the device data in the display module.	 Cancel Execute backup Restore Duplicate Compare Clear backup data Display incompatible 	Cancel
Comparison result	A local display is provided.	Comparison between present device data and display backup.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible 	Check not done

Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the display module of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the display module to the device's HistoROM backup. The backup copy includes the transmitter data of the device.

Options	Description
Compare	The device configuration saved in the display module is compared with the current device configuration of the HistoROM backup.
Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
Clear backup data	The backup copy of the device configuration is deleted from the display module of the device.
Display incompatible	This option is displayed if the display module is incompatible. All of the other options are not available. Selection is therefore not possible. This option is displayed if it is not possible to save the device and fieldbus data. The display module should be updated to the latest software version so that the data can be saved.



📔 HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.5.8 Using parameters for device administration

The Administration submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

► Administration	
► Define access code	
Define access code	→ 🗎 107
Confirm access code	→ 🗎 107
Restart	→ ● 108
Service reset	→ 🗎 108

Parameter	Description	User entry / Selection	Factory setting
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes via the local display.	0 to 9999	0
Confirm access code	Confirm the entered access code.	0 to 9999	0

Parameter	Description	User entry / Selection	Factory setting
Restart	Restart or reset device manually.	 Uninitialized Run Resource Defaults Processor To delivery settings 	Uninitialized
Service reset		UninitializedTo delivery settings + MIBENP restart	Uninitialized

10.6 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu \rightarrow Simulation

► Simulation	
Assign simulation process variable) → 🗎 109
Process variable value	→ 🗎 109
Frequency output simulation	→ 🗎 109
Frequency value	→ 🗎 109
Pulse output simulation) → 🗎 109
Pulse value	→ 🗎 109
Switch output simulation	→ 🗎 109
Switch status	→ 🗎 109
Device alarm simulation) → 🗎 109
Diagnostic event category] → 🗎 110
Diagnostic event simulation	→ 🗎 110

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	 Off Mass flow Flow velocity Volume flow Corrected volume flow Temperature Calculated steam pressure* Total mass flow* Condensate mass flow* Energy flow Heat flow difference* Reynolds number 	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter $(\rightarrow \cong 109).$	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Frequency output simulation	In the Operating mode parameter, the Frequency option is selected.	Switch the simulation of the frequency output on and off.	OffOn	Off
Frequency value	In the Frequency output simulation parameter, the On option is selected.	Enter the frequency value for the simulation.	0.0 to 1250.0 Hz	0.0 Hz
Pulse output simulation	In the Operating mode parameter, the Pulse option is selected.	 Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (→	 Off Fixed value Down-counting value 	Off
Pulse value	In the Pulse output simulation parameter $(\rightarrow \cong 109)$, the Down- counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation	In the Operating mode parameter, the Switch option is selected.	Switch the simulation of the switch output on and off.	OffOn	Off
Switch status	In the Switch output simulation parameter $(\rightarrow \cong 109)$ Switch output simulation 1 to n parameter Switch output simulation 1 to n parameter, the On option is selected.	Select the status of the status output for the simulation.	OpenClosed	Open
Device alarm simulation	-	Switch the device alarm on and off.	OffOn	Off

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off

* Visibility depends on order options or device settings

10.7 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code
- Write protection via write protection switch
- Write protection via keypad lock
- FOUNDATION Fieldbus: write protection via block operation \rightarrow 🗎 112

10.7.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.

Defining the access code via local display

- 1. Navigate to the **Enter access code** parameter.
- 2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the to confirm the code.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

If parameter write protection is activated via an access code, it can also only be deactivated via this access code →
 54.

The user role with which the user is currently logged on via the local display
 → ● 54 is indicated by the Access status display parameter. Navigation path:
 Operation → Access status display

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.


	Parameters for configuring the local display	Parameters for configuring the totalizer
	\downarrow	\downarrow
Language	Format display	Control Totalizer
	Contrast display	Preset value
	Display interval	Reset all totalizers

10.7.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.

The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via FOUNDATION Fieldbus







1. Loosen the securing clamp.

2. Unscrew the electronics compartment cover.

- **3.** Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.
 - └ Display module is attached to the edge of the electronics compartment.



- **4.** Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter . In addition, on the local display the B-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If the hardware write protection is disabled: No option is displayed in the **Locking status** parameter . On the local display, the 🖻-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

10.7.3 Write protection via block operation

Locking via block operation:

- Block: DISPLAY (TRDDISP); parameter: Define access code
- Block: EXPERT_CONFIG (TRDEXP); parameter: Enter access code

10.8 Configuring the measuring device via FOUNDATION Fieldbus

10.8.1 Block configuration

Preparation

The correct Cff and device description files are needed for preparatory purposes.

- 1. Switch on the device.
- 2. Make a note of the **DEVICE_ID**.
- 3. Open the configuration program.
- 4. Load Cff and device description files into the host system or the configuration program.
- 5. Identify the device using the **DEVICE_ID**.
- 6. Assign the desired tag name to the device via the Pd-tag/FF_PD_TAG parameter.

Configuring the Resource Block

- 1. Open the Resource Block.
- 2. Disable the lock for device operation.
- 3. Change the block name (optional). Factory setting: RB-xxxxxxxxx (RB2)
- 4. Assign a description to the block via the **Description of the identification tag/ TAG_DESC** parameter.
- 5. Change other parameters as required.

Configuring the Transducer Blocks

The measurement and the display module are configured via the Transducer Blocks.

The basic procedure is the same for all Transducer Blocks.

- 1. Open the specific Transducer Block.
- 2. Change the block name (optional).
- 3. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- 4. Configure the device in accordance with the measuring task
- 5. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- The block mode must be set to **Auto** to ensure the smooth operation of the device.

Configuring the Analog Input Blocks

- 1. Open the Analog Input Block.
- 2. Change the block name (optional).
- 3. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- 4. Via the **Channel/CHANNEL** parameter, select the process variable which should be used as the input value for the Analog Input Block.


- 5. Via the **Transducer scale/XD_SCALE** parameter, select the desired unit and the block input range for the process variable. The selected unit must suit the selected process variable. If the process variable does not suit the unit, the **Block error/ BLOCK_ERR** parameter reports *Block Configuration Error* and the block mode cannot be set to **Auto**.
- 6. Via the Linearization type/L_TYPE parameter, select the type of linearization for the input variable (factory setting: Direct). In the Direct linearization mode, the settings for the Transducer scale/XD_SCALE and Output scale/OUT_SCALE parameters must be identical. If the values do not suit the units, the Block error/BLOCK_ERR parameter reports *Block Configuration Error* and the block mode cannot be set to Auto.
- 7. Enter the alarms and critical alarm messages via the **High alarm limit/ HI_HI_LIM**, **High early warning limit/HI_LIM**, **Low alarm limit/ LO_LO_LIM** and **Low early warning limit/LO_LIM** parameters. The limit values entered must be within the value range specified for the **Output scale/OUT_SCALE** parameter.
- 8. Specify the alarm priorities via the Priority for high limit value alarm/HI_HI_PRI,
 Priority for high early warning/HI_PRI, Priority for low limit value alarm/
 LO_LO_PRI and Priority for low limit value early warning/LO_PRI parameters.
 Reporting to the field host system only takes place with alarms with a priority greater than 2.
- 9. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element. For this purpose, the Resource Block must also be set to the **Auto** block mode.

Additional configuration

- 1. Link the function blocks and output blocks.
- 2. After specifying the active LAS, download all the data and parameters to the field device.

10.8.2 Scaling the measured value in the Analog Input Block

The measured value can be scaled if the **L_TYPE = Indirect** linearization type has been selected in the Analog Input Block. **XD_SCALE** defines the input range with the **EU_0** and **EU_100** elements. This is mapped linearly to the output range, defined by **OUT_SCALE** also with the elements **EU_0** and **EU_100**.



🖻 21 Scaling the measured value in the Analog Input Block

- 1 XD SCALE
- 2 OUT SCALE
- 2 OUT_VALUE
 - If you have selected the **Direct** mode in the L_TYPE parameter, you cannot change the values and units for XD_SCALE and OUT_SCALE.
 - The L_TYPE, XD_SCALE and OUT_SCALE parameters can only be changed in the OOS block mode.

10.9 Application-specific commissioning

10.9.1 Steam application

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Steam** option.
- When pressure measured value is read in ¹):
 In the Steam calculation mode parameter, select the Automatic (p-/T-compensated) option.
- If pressure measured value is not read in: In the Steam calculation mode parameter, select the Saturated steam (T-compensated) option.
- In the Steam quality value parameter, enter the steam quality present in the pipe.
 Measuring device uses this value to calculate the mass flow of the steam.

Configuring the analog input (AI)

6. Configuring the analog input (AI).

10.9.2 Liquid application

User-specific liquid, e.g. heat carrier oil

¹⁾ Sensor version option "mass (integrated pressure and temperature measurement)", Pressure read in via FF

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Liquid** option.
- 3. In the **Liquid type** parameter, select the **User-specific liquid** option.
- 4. In the **Enthalpy type** parameter, select the **Heat** option.
 - Heat option: Non-flammable liquid that serves as a heat carrier.
 Calorific value option: Flammable liquid whose combustion energy is calculated.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 5. Call up the **Medium properties** submenu.
- 6. In the **Reference density** parameter, enter the reference density of the fluid.
- 7. In the **Reference temperature** parameter, enter the fluid temperature associated with the reference density.
- 8. In the **Linear expansion coefficient** parameter, enter the expansion coefficient of the fluid.
- 9. In the **Specific heat capacity** parameter, enter the heat capacity of the fluid.
- 10. In the **Dynamic viscosity** parameter, enter the viscosity of the fluid.

10.9.3 Gas applications

For accurate mass or corrected volume measurement, it is recommended to use the pressure-/temperature-compensated sensor version. If this sensor version is not available, read in the pressure via the FF. If neither of these two options is possible, the pressure can also be entered as a fixed value in the **Fixed process pressure** parameter.

Flow computer available only with the order code for "Sensor version", option "mass" (integrated temperature measurement)" or option "mass (integrated pressure/ temperature measurement)".

Single gas

Combustion gas, e.g. methane CH₄

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.
- 3. In the **Select gas type** parameter, select the **Single gas** option.
- 4. In the **Gas type** parameter, select the **Methane CH4** option.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

5. Call up the **Medium properties** submenu.

6. In the **Reference combustion temperature** parameter, enter the reference combustion temperature of the fluid.

7.

Configuring the analog input (AI)

8. Configure the Analog Input (AI) for the "energy flow" process variable..

Configuring optional fluid properties for output of corrected volume flow

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

9. Call up the **Medium properties** submenu.

10. In the **Reference pressure** parameter, enter the reference pressure of the fluid.

11. In the **Reference temperature** parameter, enter the reference temperature of the fluid.

Gas mixture

Forming gas for steel mills and rolling mills, e. g. N_2/H_2

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.
- 3. In the **Select gas type** parameter, select the **Gas mixture** option.

Configuring gas composition

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties \rightarrow Gas composition

4. Call up the **Gas composition** submenu.

- 5. In the **Gas mixture** parameter, select the **Hydrogen H2** option and the **Nitrogen N2** option.
- 6. In the **Mol% H2** parameter, enter the quantity of hydrogen.
- 7. In the **Mol% N2** parameter, enter the quantity of nitrogen.
 - All quantities must add up to 100 %.
 The density is determined according to NEL 40.

Configuring optional fluid properties for output of corrected volume flow

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

8. Call up the **Medium properties** submenu.

- 9. In the **Reference pressure** parameter, enter the reference pressure of the fluid.
- **10.** In the **Reference temperature** parameter, enter the reference temperature of the fluid.

Air

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- **2.** In the **Select medium** parameter ($\rightarrow \triangleq 72$), select the **Gas** option.
- **3.** In the **Select gas type** parameter ($\rightarrow \square 72$), select the **Air** option.
 - ← The density is determined according to NEL 40.
- **4.** Enter the value in the **Relative humidity** parameter ($\rightarrow \square 73$).
 - └ The relative humidity is entered as a %. The relative humidity is converted internally to absolute humidity and is then factored into the density calculation according to NEL 40.
- 5. In the **Fixed process pressure** parameter ($\rightarrow \square 73$), enter the value of the process pressure present.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 6. Call up the **Medium properties** submenu.
- 7. In the **Reference pressure** parameter ($\rightarrow \triangleq 82$) enter the reference pressure for calculating the reference density.
 - Pressure that is used as a static reference for combustion. This makes it possible to compare combustion processes at different pressures.
- 8. In the **Reference temperature** parameter ($\rightarrow \implies 82$) enter the temperate for calculating the reference density.

Endress+Hauser recommends the use of active pressure compensation. This fully rules out the risk of measured errors due to pressure variations and incorrect entries .

Natural gas

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- **2.** In the **Select medium** parameter ($\rightarrow \triangleq 72$), select the **Gas** option.
- 3. In the **Select gas type** parameter ($\rightarrow \square 72$), select the **Natural gas** option.
- 4. In the **Fixed process pressure** parameter ($\Rightarrow \square 73$), enter the value of the process pressure present.
- **5.** In the **Enthalpy calculation** parameter ($\rightarrow \square 74$), select one of the following options:
 - ↦ AGA5

ISO 6976 option (contains GPA 2172)

- 6. In the **Density calculation** parameter ($\rightarrow \square 74$), select one of the following options.
 - → AGA Nx19
 ISO 12213- 2 option (contains AGA8-DC92)
 ISO 12213- 3 option (contains SGERG-88, AGA8 Gross Method 1)

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

7. Call up the **Medium properties** submenu.

- 8. In the **Calorific value type** parameter, select one of the options.
- 9. n the **Reference gross calorific value** parameter, enter the reference gross calorific value of the natural gas.
- 10. In the **Reference pressure** parameter ($\rightarrow \square 82$) enter the reference pressure for calculating the reference density.
 - Pressure that is used as a static reference for combustion. This makes it possible to compare combustion processes at different pressures.
- **11.** In the **Reference temperature** parameter ($\Rightarrow \square 82$) enter the temperate for calculating the reference density.
- 12. In the **Relative density** parameter, enter the relative density of the natural gas.

Endress+Hauser recommends the use of active pressure compensation. This fully rules out the risk of measured errors due to pressure variations and incorrect entries .

Ideal gas

The unit "corrected volume flow" is often used to measure industrial gas mixtures, in particular natural gas. To do so, the calculated mass flow is divided by a reference density. To calculate the mass flow, knowledge of the exact composition of the gas is essential. In practice, however, this information is often not available (e. g. as it varies over time). In this case, it can be useful to regard the gas as an ideal gas. This means that only the operating temperature and operating pressure variables as well as the reference temperature and reference pressure variables are needed to calculate the corrected volume flow. The error resulting from this assumption (typically 1 to 5 %) is often considerably smaller than the error caused by inaccurate composition data. This method should not be used for condensing gases (e. g. saturated steam).

Select medium

Navigation:

Setup \rightarrow Medium selection

- 1. Call up the **Medium selection** wizard.
- 2. In the **Select medium** parameter, select the **Gas** option.
- 3. In the **Select gas type** parameter, select the **User-specific gas** option.
- 4. For non-flammable gas:

In the **Enthalpy type** parameter, select the **Heat** option.

Configuring fluid properties

Navigation:

Setup \rightarrow Advanced setup \rightarrow Medium properties

- 5. Call up the **Medium properties** submenu.
- 6. In the **Reference density** parameter, enter the reference density of the fluid.
- 7. In the **Reference pressure** parameter, enter the reference pressure of the fluid.
- 8. In the **Reference temperature** parameter, enter the fluid temperature associated with the reference density.
- 9. In the **Reference Z-factor** parameter, enter the value **1**.
- **10.** If specific heat capacity is to be measured:

In the **Specific heat capacity** parameter, enter the heat capacity of the fluid.

- 11. In the **Z-factor** parameter, enter the value **1**.
- **12.** In the **Dynamic viscosity** parameter, enter the viscosity of the fluid under operating conditions.

10.9.4 Calculation of the measured variables

A flow computer can be found in the electronics of the measuring device with order code for "Sensor version", option "mass (integrated temperature measurement)" and option "mass (integrated pressure/temperature measurement)". This computer can calculate the following secondary measured variables directly from the primary measured variables recorded using the pressure value (entered or external) and/or temperature value (measured or entered).

Mass flow and corrected volume flow

Medium	Fluid	Standards	Explanation
Steam ¹⁾	Water vapor	IAPWS-IF97/ ASME	 For integrated temperature measurement For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via FOUNDATION Fieldbus
	Single gas	NEL40	For fixed process pressure, pressure measured directly at the meter
	Gas mixture	NEL40	body or if the pressure is read in via FOUNDATION Fieldbus
	Air	NEL40	
	Natural gas	as ISO 12213-2 • Contains AGA8-DC92 • For fixed process pressure, pressure measured dia meter body or if the pressure is read in via FOUN Fieldbus	
Gas		AGA NX-19	For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via FOUNDATION Fieldbus
	ISO 12213-3 • Contains S • For fixed		 Contains SGERG-88, AGA8 Gross Method 1 For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via FOUNDATION Fieldbus
	Other gases	Linear equation	 Ideal gases For fixed process pressure, pressure measured directly at the meter body or if the pressure is read in via FOUNDATION Fieldbus
	Water	IAPWS-IF97/ ASME	-
Liquids	Liquefied gas	Tables	Propane and butane mixture
	Other liquid	Linear equation	Ideal liquids

1) The measuring device is capable of calculating the volume flow, and other measured variables derived from the volume flow, across all steam types with full compensation using the pressure and temperature. To configure device behavior $\rightarrow \square 93$

Mass flow calculation

Volume flow × operating density

- Operating density for saturated steam, water and other liquids: depends on the temperature
- Operating density for superheated steam and all other gases: depends on the temperature and process pressure

Corrected volume flow calculation

(Volume flow × operating density)/reference density

- Operating density for water and other liquids: depends on the temperature
- Operating density for all other gases: depends on the temperature and process pressure

Energy flow

Medium	Fluid	Standards	Explanation	Heat/energy option
Steam 1)	-	IAPWS- IF97/ASME	For fixed process pressure or if the pressure is read in via FOUNDATION Fieldbus	
	Single gas	ISO 6976 ISO		
	Gas mixture	ISO 6976	 Contains GPA 2172 For fixed process pressure or if the pressure is read in via FOUNDATION Fieldbus 	Heat Gross calorific value ²⁾ in relation to mass
Gas	Air	NEL40	For fixed process pressure or if the pressure is read in via FOUNDATION Fieldbus	Net calorific value ³⁾ in relation to mass Gross calorific value ²⁾ in relation to corrected volume Net calorific value ³⁾ in relation to corrected
	Natural gas	ISO 6976	 Contains GPA 2172 For fixed process pressure or if the pressure is read in via FOUNDATION Fieldbus 	volume
		AGA 5	-	
	Water	IAPWS- IF97/ASME	-	
Liquids	Liquefied gas	ISO 6976	Contains GPA 2172	
	Other liquid	Linear equation	-	

- Gross calorific value: combustion energy + condensation energy of the flue gas (gross calorific value > net calorific value)
- 3) Net calorific value: only combustion energy

Mass flow and energy flow calculation

Steam is calculated based on the following factors:

- Fully compensated calculation of density using the "pressure" and "temperature" measured variables

Optional configuration of diagnostic behavior to the **Alarm** option or **Warning** option $\rightarrow \cong$ 138 option.

At 2 K above saturation, activation of the ${\rm \ensuremath{\Delta}S871}$ Near steam saturation limit diagnostic message.

- The smaller of the following two pressure values is always used to calculate the density:
 - Pressure measured directly at meter body or pressure read in via FOUNDATION Fieldbus
 - Saturated steam pressure, which is derived from the saturated steam line (IAPWS-IF97/ASME)
- Depending on setting in the **Steam calculation mode** parameter ($\rightarrow \square 73$)
 - If **Saturated steam (T-compensated)** option is selected, the measuring device only calculates on the saturated steam curve using temperature compensation.
 - If **Automatic (p-/T-compensated)** option is selected, the device calculates using full compensation either along the saturation line or in the superheated region, depending on the steam state.

For detailed information on how to perform external compensation, see $\rightarrow \square$ 93.

Calculated value

The unit calculates the mass flow, heat flow, energy flow, density and specific enthalpy from the measured volume flow and the measured temperature and/or the pressure based on international standard IAPWS-IF97/ASME.

Formulae for calculation:

- Mass flow: $\dot{m} = \dot{v} \cdot \rho$ (T, p)
- Heat flow: $\dot{Q} = \dot{v} \cdot \rho (T, p) \cdot h_D (T, p)$
- \dot{m} = Mass flow
- Q = Heat flow
- \dot{v} = Volume flow (measured)
- h_D = Specific enthalpy
- T = Process temperature (measured)
- p = Process pressure
- $\rho = \text{Density}^{2}$

Pre-programmed gases

The following gases are pre-programmed in the flow computer:

Hydrogen ¹⁾	Helium 4	Neon	Argon
Krypton	Xenon	Nitrogen	Oxygen
Chlorine	Ammonia	Carbon monoxide ¹⁾	Carbon dioxide
Sulfur dioxide	Hydrogen sulfide ¹⁾	Hydrogen chloride	Methane ¹⁾

²⁾ From steam data as per IAPWS-IF97 (ASME), for the measured temperature and the specified pressure

Ethane ¹⁾	Propane ¹⁾	Butane 1)	Ethylene (ethene) ¹⁾
Vinyl chloride	Mixtures of up to 8 components	s of these gases ¹⁾	

1) The energy flow is calculated as per ISO 6976 (contains GPA 2172) or AGA5 - in relation to the net calorific value or gross calorific value .

Energy flow calculation

Volume flow × operating density × specific enthalpy

- Operating density for saturated steam and water: depends on the temperature
- Operating density for superheated steam, natural gas ISO 6976 (contains GPA 2172), natural gasAGA5: depends on the temperature and pressure

Heat flow difference

- Between saturated steam upstream from a heat exchanger and condensate downstream from the heat exchanger (second temperature read in via FOUNDATION Fieldbus) in accordance with IAPWS-IF97/ASME $\rightarrow \bigoplus 24$
- Between warm and cold water (second temperature read in via FOUNDATION Fieldbus) in accordance with IAPWS-IF97/ASME

Vapor pressure and steam temperature

The measuring device can perform the following in saturated steam measurements between the feed line and return line of any heating liquid (second temperature read in via FOUNDATION Fieldbus and Cp value entered:

- Calculation of saturation pressure of steam from the measured temperature and output in accordance with IAPWS-IF97/ASME
- Calculation of saturation temperature of steam from the preset pressure and output in accordance with IAPWS-IF97/ASME

11 Operation

11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation \rightarrow Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter applies $\rightarrow {}$ 54. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \bigoplus 111$.
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Petailed information:

- To configure the operating language $\rightarrow \square 66$
- For information on the operating languages supported by the measuring device $\rightarrow~\textcircled{}$ 205

11.3 Configuring the display

Detailed information:

- On the basic settings for the local display \rightarrow 75
- On the advanced settings for the local display \rightarrow 🗎 103

11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Measured values	
► Process variables) → 🗎 125
► Totalizer) → 🗎 127
► Output values) → 🗎 127

11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Process variables	
Volume flow	→ 🗎 125
Corrected volume flow	→ 🗎 125
Mass flow	→ 🗎 126
Flow velocity	→ 🗎 126
Temperature	→ 🗎 126
Calculated saturated steam pressure	→ 🗎 126
Energy flow	→ 🗎 126
Heat flow difference	→ 🗎 126
Reynolds number	→ 🗎 126
Density	→ 🗎 126
Specific volume	→ 🗎 126
Pressure	→ 🗎 126
Compressibility factor	→ 🗎 127
Degrees of superheat	→ 🗎 127

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Volume flow	-	Displays the volume flow that is currently measured.	Signed floating-point number
		Dependency The unit is taken from the Volume flow unit parameter ($\rightarrow \square 69$).	
Corrected volume flow	-	Displays the corrected volume flow that is currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Corrected volume flow unit parameter $(\rightarrow \cong 69).$	

Parameter	Prerequisite	Description	User interface
Mass flow	-	Displays the mass flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Mass flow unit parameter ($\rightarrow \square 69$).	
Flow velocity	-	Displays the flow velocity that is currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Velocity unit parameter ($\rightarrow \square 71$).	
Temperature	-	Displays the temperature that is currently measured.	Signed floating-point number
		Dependency The unit is taken from the Temperature unit parameter $(\rightarrow \square 70)$.	
Calculated saturated steam pressure	 The following conditions are met: Order code for "Sensor version", option "Mass (integrated temperature measurement)" The Steam option is selected in the Select medium parameter (→	Displays the saturated steam pressure that is currently calculated. Dependency The unit is taken from the Pressure unit parameter ($\rightarrow \square$ 70).	Signed floating-point number
Energy flow	With order code for "Sensor version": option "Mass (integrated temperature measurement)"	Displays the energy flow that is currently calculated. Dependency The unit is taken from the Energy flow unit parameter ($\rightarrow \square$ 70).	Signed floating-point number
Heat flow difference	 The following conditions are met: Order code for "Sensor version" option "Mass (integrated temperature measurement)" In the Select gas type parameter (→	Displays the heat flow difference that is currently calculated. Dependency The unit is taken from the Energy flow unit parameter ($\rightarrow \square$ 70).	Signed floating-point number
Reynolds number	With order code for "Sensor version": option "Mass (integrated temperature measurement)"	Displays the Reynolds number that is currently calculated.	Signed floating-point number
Density	With order code for "Sensor version": Option "Mass (integrated temperature	Displays the density currently measured.	Positive floating-point number
	measurement)"	Dependency The unit is taken from the Density unit parameter.	
Specific volume	With order code for "Sensor version": Option "Mass (integrated temperature	Displays the current value for the specific volume.	Positive floating-point number
	measurement)"	Dependency The unit is taken from the Specific volume unit parameter.	
Pressure	 One of the following conditions is met: Order code for "Sensor version", Option "Mass (integrated temperature measurement)" or The Pressure option is selected in the External value parameter parameter. 	Displays the current process pressure. <i>Dependency</i> The unit is taken from the Pressure unit parameter.	0 to 250 bar

Parameter	Prerequisite	Description	User interface
Compressibility factor	The following conditions are met: Order code for "Sensor version" Option "Mass (integrated temperature measurement)"	Displays the compressibility factor currently calculated.	0 to 2
	The Gas option or the Steam option is selected in the Select medium parameter.		
Degrees of superheat	In the Select medium parameter, the Steam option is selected.	Displays the degree of superheating currently calculated.	0 to 500 K

11.4.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer

► Totalizer	
Totalizer value 1 to n	→ 🗎 127
Totalizer overflow 1 to n	→ 🗎 127

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	One of the following options is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu: Volume flow Corrected volume flow Mass flow Total mass flow Condensate mass flow Energy flow Heat flow difference	Displays the current totalizer counter value.	Signed floating-point number
Totalizer overflow 1 to n	One of the following options is selected in the Assign process variable parameter (→	Displays the current totalizer overflow.	Integer with sign


* Visibility depends on order options or device settings

11.4.3 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values



Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Terminal voltage 1	-	Displays the current terminal voltage that is applied at the output.	0.0 to 50.0 V
Pulse output			Positive floating-point number
Output frequency	In the Operating mode parameter, the Frequency option is selected.	Displays the value currently measured for the frequency output.	0 to 1250 Hz
Switch status	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	 Open Closed

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu ($\rightarrow \cong 67$)
- Advanced settings using the **Advanced setup** submenu ($\rightarrow \square$ 79)

11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu \rightarrow Totalizer handling

► Totalizer handling				
Control Totalizer 1 to n	→ 🗎 129			
Preset value 1 to n	→ 🗎 129			
Reset all totalizers	→ 🗎 129			

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 102) of the Totalizer 1 to n submenu.	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize Hold 	Totalize
Preset value 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \bigoplus 102$) of the Totalizer 1 to n submenu.	 Specify start value for totalizer. Dependency The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 102). 	Signed floating-point number	Country-specific: • 0 m ³ • 0 ft ³
Reset all totalizers	-	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

Parameter overview with brief description

Function scope of the "Control Totalizer" parameter 11.6.1

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.

11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

11.7 Showing data logging

The Extended HistoROM application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.




Data logging is also available via:

Plant Asset Management Tool FieldCare $\rightarrow \square 57$.

Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Displays the measured value trend for each logging channel in the form of a chart



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu \rightarrow Data logging

► Data logging			
	Assign channel 1]	→ 🖺 131
	Assign channel 2]	→ 🖺 131
	Assign channel 3]	→ 🖺 131
	Assign channel 4		→ 🖺 131
	Logging interval		→ 🖺 131
	Clear logging data		→ 🖺 131
	► Display channel 1		
	► Display channel 2		
	► Display channel 3		
	► Display channel 4		

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure* Steam quality* Total mass flow* Condensate mass flow* Energy flow* Heat flow difference* Reynolds number* Density* Pressure* Specific volume Vortex frequency Electronic temperature Reference density 	Off
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🗎 131)	Off
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🗎 131)	Off
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🗎 131)	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	1.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data	Cancel

Parameter overview with brief description

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Solution
Local display dark and no output signals	Supply voltage does not match the value indicated on the nameplate.	Apply the correct supply voltage $\rightarrow \cong 34$.
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.	Order spare part $\rightarrow \square$ 176.
Local display dark and output signals in failure current	Sensor short-circuit, electronics module short-circuit	1. Contact service.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing + E. Set the display darker by simultaneously pressing + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🗎 176.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 143$
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press \Box + $$ for 2 s ("home position"). 2. Press \blacksquare . 3. Set the desired language in the Display language parameter ($\rightarrow \blacksquare$ 105).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part →

For output signals

Error	Possible causes	Solution
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🗎 176.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	 Check and correct parameter configuration. Observe limit values specified in the "Technical Data".


For access

Error	Possible causes	Solution	
No write access to parameters	Hardware write protection enabled	Set the write protection switch on main electronics module to the OFF position $\rightarrow \textcircled{B}$ 111.	
No write access to parameters	Current user role has limited access authorization	1. Check user role $\rightarrow \bigoplus 54$. 2. Enter correct customer-specific access code $\rightarrow \bigoplus 54$.	
No connection via service interface	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox. FXA291: Document "Technical Information" T100405C	

12.2 Diagnostic information on local display

12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.


Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 168$
- Via submenus →
 [™]
 [™]
 169

Status signals

•

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).



= Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
М	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior

Symbol	Meaning
8	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.


Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Кеу	Meaning		
+	Plus key <i>In a menu, submenu</i> Opens the message about remedy information.		
E	Enter key <i>In a menu, submenu</i> Opens the operating menu.		



12.2.2 Calling up remedial measures

- 3 Service ID
- Diagnostic behavior with diagnostic code 4 5 Operation time of occurrence
- 6 Remedial measures
- 1. The user is in the diagnostic message.

Press 🛨 (① symbol).

- └ The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \mathbb{E} .
 - └ The message about the remedial measures opens.
- 3. Press \Box + \pm simultaneously.
 - └ The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the Diagnostic list submenu or Previous diagnostics parameter.

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- **2.** Press \Box + \pm simultaneously.
 - └ The message for the remedial measures closes.

12.3 Diagnostic information in FieldCare or DeviceCare

12.3.1 **Diagnostic options**

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

D 🛩 🔛 🚑 🕋 🎰 🔍 📖 🗽 🗟 Xxxxxx//	\$
Device name: XXXXXXX Device tag: XXXXXXX Status signal: V F	Mass flow: 2 12.34 kg/h Volume flow: 2 12.34 m ³ /h
➤ XXXXXX ····P□ Diagnostics 1: C	C485 Simu Deactivate
	Wainenance Sealure (F) Image: Sealure (F) Function check (C) Diagnostics 1: C485 Simulation measured vari Image: Simulation (Service Image: Simulation (Serv
	Maintenance required (M)

- 1 Status area with status signal $\rightarrow \square 134$
- 2 Diagnostic information $\rightarrow \square 135$
- 3 Remedy information with Service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 168$
- Via submenu →
 [™]
 [™]
 169

Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
\otimes	Failure A device error has occurred. The measured value is no longer valid.
Ŵ	Function check The device is in service mode (e.g. during a simulation).
?	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

On the home page

Remedy information is displayed in a separate field below the diagnostics information.

In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.

2. On the right in the working area, mouse over the parameter.

► A tool tip with remedy information for the diagnostic event appears.

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior

인, //Dia	gn. behavior	0723-1
Diagno	ostic no. 044	
		Warning
Diagno	ostic no. 274	
Diagno	ostic no. 801	

23 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.

A0014048-EN

Options	Description
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (Event list submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.4.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic** event category submenu.

Expert \rightarrow Communication \rightarrow Diagnostic event category

Available status signals

Configuration as per FOUNDATION Fieldbus Specification (FF912), in accordance with NAMUR NE107.

Symbol	Meaning		
F 40013956	Failure A device error is present. The measured value is no longer valid.		
C	Function check The device is in service mode (e.g. during a simulation).		
S A0013958	 Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value) 		
A0013957	Maintenance required Maintenance is required. The measured value is still valid.		

Enabling the configuration of the diagnostic information according to FF912

For compatibility reasons, the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912 is not enabled when the device is delivered from the factory.

Enabling the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912

- 1. Open the Resource block.
- 2. In Feature Selection parameter, select Multi-bit Alarm (Bit-Alarm) Support option.
 - └ The diagnostic information can be configured according to FOUNDATION Fieldbus Specification FF912.

Grouping the diagnostic information

Diagnostic information is assigned to different groups. The groups differ depending on the weighting (severity) of the diagnostic event:

- Highest weighting
- High weighting
- Low weighting

H

Assignment of the diagnostic information (factory setting)

The assignment of the diagnostic information ex-works is indicated in the following tables.

The individual ranges of the diagnostic information can be assigned to another status signal $\rightarrow \textcircled{B}$ 140.

Some diagnostic information can be assigned individually, irrespective of their range $\rightarrow \cong 142$.

Overview and description of all diagnostic information $\rightarrow \square 143$

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Highest	Failure (F)	Sensor	F000 to 199
		Electronics	F200 to 399
		Configuration	F400 to 700
		Process	F800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
High	Function check (C)	Sensor	C000 to 199
		Electronics	C200 to 399
		Configuration	C400 to 700
		Process	C800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Out of specification (S)	Sensor	S000 to 199
		Electronics	S200 to 399
		Configuration	S400 to 700
		Process	S800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Maintenance required (M)	Sensor	M000 to 199
		Electronics	M200 to 399
		Configuration	M400 to 700
		Process	M800 to 999

Changing the assignment of the diagnostic information

The individual ranges of the diagnostic information can be assigned to another status signal. This is done by changing the bit in the associated parameter. The bit change always applies for the entire range of the diagnostic information.

Some diagnostic information can be assigned individually, irrespective of their range $\rightarrow \cong 142$

Each status signal has a parameter in the Resource Block in which it is possible to define the diagnostic event for which the status signal is transmitted:

- Failure (F): FD_FAIL_MAP parameter
- Function check (C): **FD_CHECK_MAP** parameter
- Out of specification (S): FD_OFFSPEC_MAP parameter
- Maintenance required (M): **FD_MAINT_MAP** parameter

Structure and assignment of the parameters for the status signals (factory setting)

Weighting	Allocation	Bit	FD_ FAIL_ MAP	FD_ CHECK_ MAP	FD_ OFFSPEC_ MAP	FD_ MAINT_ MAP
Highest	Sensor	31	1	0	0	0
	Electronics	30	1	0	0	0
	Configuration	29	1	0	0	0
	Process	28	1	0	0	0
High	Sensor	27	0	1	0	0
	Electronics	26	0	1	0	0
	Configuration	25	0	1	0	0
	Process	24	0	1	0	0
Low	Sensor	23	0	0	1	0
	Electronics	22	0	0	1	0
	Configuration	21	0	0	1	0
	Process	20	0	0	1	0
Low	Sensor	19	0	0	0	1
	Electronics	18	0	0	0	1
	Configuration	17	0	0	0	1
	Process	16	0	0	0	1
Configurable range $\rightarrow \square 142$		15 to 1	0	0	0	0
Reserved (Fieldbus Foundation)		0	0	0	0	0

Changing the status signal for a range of diagnostic information

Example: The status signal for the diagnostic information for electronics with the "Highest" weighting is to be changed from failure (F) to function check (C).

- 1. Set the Resource Block to the **OOS** block mode.
- 2. Open the **FD_FAIL_MAP** parameter in the Resource Block.
- 3. Change **Bit 30** to **0** in the parameter.
- 4. Open the **FD_CHECK_MAP** parameter in the Resource Block.
- 5. Change **Bit 26** to **1** in the parameter.
 - If a diagnostic event occurs for electronics with the "Highest weighting", the diagnostic information to this effect is displayed with the function check (C) status signal.
- 6. Set the Resource Block to the **AUTO** block mode.

NOTICE

No status signal is assigned to an area of diagnostic information.

If a diagnostic event occurs in this area, no status signal is transmitted to the control system.

 If you are changing the parameters, make sure that a status signal is assigned to all areas.

If FieldCare is used, the status signal is enabled and disabled using the check box of the particular parameter.

Assigning diagnostic information individually to a status signal

Some diagnostic information can be individually assigned to a status signal, irrespective of their original range.

Assigning diagnostic information individually to a status signal via FieldCare.

- In the FieldCare navigation window: Expert → Communication → Field diagnostics
 → Alarm detection enable
- Select the desired diagnostic information from one of the fields Configurable Area Bits 1 to Configurable Area Bits 15.
- 3. Press Enter to confirm.
- When selecting the desired status signal (e.g. Offspec Map), also select the Configurable Area Bit 1 to Configurable Area Bit 15 that was assigned previously to the diagnostic information (step 2).
- 5. Press Enter to confirm.
 - ← The diagnostic event of the selected diagnostic information is recorded.
- 6. In the FieldCare navigation window: Expert → Communication → Field diagnostics → Alarm broadcast enable
- 7. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.
- 8. Press Enter to confirm.
- 9. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 7).
- 10. Press Enter to confirm.
 - The selected diagnostic information is transmitted over the bus when a diagnostic event to this effect occurs.

A change in the status signal does not affect diagnostic information that already exists. The new status signal is only assigned if this error occurs again after the status signal has changed.

Transmitting the diagnostic information over the bus

Prioritizing diagnostic information for transmission over the bus

Diagnostic information is only transmitted over the bus if its priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Diagnostic information with priority 0 (factory setting) is ignored.

It is possible to change the priority individually for the different status signals. The following parameters of the Resource Block are used for this purpose:

- FD FAIL PRI
- FD CHECK PRI
- FD OFFSPEC PRI
- FD_MAINT_PRI

Suppressing certain diagnostic information

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare **Expert** \rightarrow **Communication** \rightarrow **Field diagnostics** \rightarrow **Alarm broadcast enable**. The mask is a negative selection mask, i.e. if a field is selected the associated diagnostic information is not transmitted over the bus.

12.5 Overview of diagnostic information

The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information $\rightarrow \square 138$

12.5.1 Diagnostic of sensor

Diagnostic information		Remedy instructions	Influenced measured	
No.	No. Short text			variables
004			 Check plug connections Change pre-amplifier 	 Calculated saturated steam pressure Energy flow
	Mongurod variable status		3. Change DSC sensor	
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Sensor failure		 Low flow cut off
	Status signal [from the factory] ¹⁾	F		 Mass flow Condensate mass flow Total mass flow
	Diagnostic behavior	Alarm		 For the second second

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
022	Management reprinting from the factor 1/		1. Check plug connections	 Calculated saturated steam pressure Energy flow
			 Change pre-amplifier Change DSC sensor 	
	Quality	Good		Heat flow differenceMass flow
	Quality substatus	Non specific		 Mass flow Condensate mass flow
				 Total mass flow
	Status signal [from the factory] ²⁾	F		 Reynolds number
	Diagnostic behavior [from the factory] ³⁾	Alarm		Corrected volume flowSteam qualityTemperature

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Influenced measured	
No.	No. Short text			variables	
046			1. Check plug connections	Calculated saturated	
	Management reprinting		 Change pre-amplifier Change DSC sensor 	steam pressureEnergy flow	
	Quality	Good		Flow velocityHeat flow difference	
	Quality substatus	Non specific		Low flow cut offMass flowCondensate mass flow	
	Status signal [from the factory] ¹⁾	S			
	Diagnostic behavior	Warning		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow 	

1) Status signal can be changed.

Diagnostic information			Remedy instructions	Influenced measured
No.	o. Short text			variables
062			1. Check plug connections	 Calculated saturated steam pressure Energy flow
	Mongurod wariable status		 Change pre-amplifier Change DSC sensor 	
	Quality	Bad		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Sensor failure		
				 Mass flow
	Status signal [from the factory] ¹⁾	F	 Total mas Switch out 	 Condensate mass flow
	Die groetie heberrier	Alarma		 Total mass flow
	Diagnostic behavior	Alarm		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

1) Status signal can be changed.

No.	J	information nort text	Remedy instructions	Influenced measured variables
082			 Check module connections Contact service 	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Bad Sensor failure		 Flow velocity Heat flow difference Low flow cut off Mass flow
	Status signal [from the factory] ¹⁾ Diagnostic behavior	F Alarm		 Mass now Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

1) Status signal can be changed.

N	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	nort text		
083	3 Memory content		1. Restart device	 Calculated saturated
	Mongurod variable status		 Restore S-Dat data Change sensor 	steam pressureEnergy flow
	Quality	Bad	 Heat flow d 	Flow velocityHeat flow difference
	Quality substatus	Sensor failure		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
114	Sensor leaky Measured variable status		Change DSC sensor	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Bad Sensor failure		 Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow
	Status signal [from the factory] ¹⁾	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

No.	Diagnostic information		Remedy instructions	Influenced measured variables
122	Temperature sensor defective		1. Check plug connections	Calculated saturated
	Measured variable status [from	the factory] ¹⁾	 Change pre-amplifier Change DSC sensor 	steam pressure • Energy flow • Heat flow difference
	Quality	Good		 Heat flow difference Mass flow
	Quality substatus	Non specific		 Condensate mass flow
	Status signal [from the factory] ²⁾	M		Total mass flowCorrected volume flow
	Diagnostic behavior [from the factory] ³⁾	Warning	-	Steam qualityTemperature

1) Quality can be changed. This causes the overall status of the measured variable to change.

2)

Status signal can be changed. Diagnostic behavior can be changed. 3)

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
170	0 Pressure cell connection defective		1. Check plug connections	Energy flow
	Measured variable status		2. Replace pressure cell	 Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number
	Quality	Bad		
	Quality substatus	Sensor failure		
	Status signal [from the factory] ¹⁾	F		
	Diagnostic behavior	Alarm		Corrected volume flowSteam quality

	Diagnostic	information	Remedy instructions	Influenced measured variables
No.	SI	nort text		variables
171	Ambient temperature too low		Increase ambient temperature	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	S		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
172	Ambient temperature too high		Reduce ambient temperature	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	S		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
173			1. Check process cond.	 Energy flow
	Measured variable status		2. Increase system pressure	 Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow
	Quality	Uncertain		
	Quality substatus	Sensor conversion not accurate		
				 Switch output status
	Status signal [from the factory] ¹⁾	S		 Reynolds number Corrected volume flow
	Diagnostic behavior	Warning		Corrected volume flowSteam quality

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
174	Pressure cell electronics defective		Replace pressure cell	Energy flow
	Measured variable status			Heat flow differenceLow flow cut off
	Quality	Bad		Mass flowCondensate mass flow
	Quality substatus	Sensor failure		 Total mass flow
				Switch output statusReynolds number
	Status signal [from the factory] ¹⁾	P	-	 Reynolds number Corrected volume flow
	Diagnostic behavior	Alarm		 Steam quality

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
175	Pressure cell deactivated		Enable pressure cell	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	M		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

12.5.2 Diagnostic of electronic

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	nort text		variables
242	Software incompatible		1. Check software	 Calculated saturated
	Measured variable status		2. Flash or change main electronics module	steam pressure Energy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		 Low flow cut off
	Status signal [from the factory] ¹⁾	F		 Mass flow Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
252	Modules incompatible		1. Check if correct electronic modul	 Calculated saturated
	Measured variable status		is plugged 2. Replace electronic module	steam pressureEnergy flow
	Quality	Bad	_	Flow velocityHeat flow difference
	Quality substatus	Device failure		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
		A.1		 Total mass flow
	Diagnostic behavior	Alarm		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
261	Electronic modules		1. Restart device	 Calculated saturated
	Management reprinting		 Check electronic modules Change I/O Modul or main 	steam pressureEnergy flow
	Quality	Bad	electronics	Flow velocityHeat flow difference
	Quality substatus	Device failure		Heat now differenceLow flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm	-	Total mass flowSwitch output status
	5			 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
262			1. Check module connections	 Calculated saturated
			2. Change electronic modules	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		 Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	Sł	nort text		Variables
270	0 Main electronic failure		Change main electronic module	 Calculated saturated
	Measured variable status			steam pressure Energy flow
	Quality	Bad		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Device failure		
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
271	Main electronic failure		1. Restart device	 Calculated saturated
	Measured variable status		2. Change main electronic module	steam pressure Energy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		 Low flow cut off
	Status signal [from the factory] ¹⁾	F		 Mass flow Condensate mass flow Total mass flow
	Diagnostic behavior	Alarm		 Fotal mass now Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
272	2 Main electronic failure		1. Restart device	 Calculated saturated
	Measured variable status		2. Contact service	steam pressure Energy flow
	Quality	Bad	FlowHeat	 Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow
	Quality substatus	Device failure		
	Status signal [from the factory] ¹⁾	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
272	ECC settings faulty Measured variable status		1. Restart device	 Calculated saturated
			2. Contact service	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
273	Main electronic failure		1. Emergency operation via display	 Calculated saturated
	Measured variable status		2. Change main electronics	steam pressureEnergy flow
	Quality	Bad	-	Flow velocityHeat flow difference
	Quality substatus	Device failure		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow
	Diagnostic Denavior	AldIII		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
275	I/O module defective		Change I/O module	 Calculated saturated
	Measured variable status			steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Device failure		
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

N.	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	nort text		
276			1. Restart device	 Calculated saturated
	Measured variable status		2. Change I/O module	steam pressureEnergy flow
	Quality	Bad	Low flow cut ofMass flow	Flow velocityHeat flow difference
	Quality substatus	Device failure		 Low flow cut off
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
276			1. Restart device	 Calculated saturated
			2. Change I/O module	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Device failure		
	Status signal [from the factory] ¹⁾	F		 Mass flow Condensate mass flow Tatal mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured variables	
No.	SI	hort text		variables	
277			1. Change pre-amplifier	 Calculated saturated 	
	Measured variable status		2. Change main electronic module	steam pressureEnergy flow	
	Quality	Bad		Flow velocityHeat flow differenceLow flow cut off	
	Quality substatus	Device failure			
				 Mass flow 	
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow 	
	Diagnostic behavior	Alarm			

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
282	2 Data storage Measured variable status		1. Restart device	 Calculated saturated
			2. Contact service	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
283	Memory content		1. Transfer data or reset device	 Calculated saturated
	Measured variable status		2. Contact service	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Device failure		 Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow
		Alaliii		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	Sł	nort text		variables
302	Device verification active		Device verification active, please	 Calculated saturated
	Measured variable status		wait.	steam pressure Energy flow
	Quality	Good		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Non specific		
		-		 Mass flow
	Status signal [from the factory] ¹⁾	С		 Condensate mass flow Total mass flow
	Diagnostic behavior	Warning		 Switch output status
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

No.	-	nformation 10rt text	Remedy instructions	Influenced measured variables
311	Electronic failure Measured variable status		Maintenance required! 1. Do not perform reset 2. Contact service	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Bad Device failure	2. Contact service	Flow velocityHeat flow differenceLow flow cut off
	Status signal [from the factory] ¹⁾ Diagnostic behavior	M Warning		 Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
350	Pre-amplifier defective	4 6	Change pre-amplifier	 Calculated saturated steam pressure
	Measured variable status [from Quality	Good		Energy flowFlow velocityHeat flow difference
	Quality substatus Status signal [from the factory] ²⁾	Non specific F		 Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow
	Diagnostic behavior [from the factory] ³⁾	Alarm		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	l S	nformation nort text	Remedy instructions	Influenced measured variables
351	1 Pre-amplifier defective C Measured variable status C		stear	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Bad Device failure	- FI - H - Lc - M - Cc - Tc - St - Rc - Cc - St - St	 Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow
	Status signal [from the factory] ¹⁾ Diagnostic behavior	F Alarm		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
370	Pre-amplifier defective		1. Check plug connections	 Calculated saturated
	Measured variable status		2. Check cabel connection of remote version	steam pressureEnergy flow
	Quality	Bad	3. Change pre-amplifier or main electronic module	Flow velocityHeat flow difference
	Quality substatus	Device failure		 Heat now difference Low flow cut off Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
371	Temperature sensor defective		1. Check plug connections	 Calculated saturated
	Measured variable status [from	the factory] ¹⁾	 Change pre-amplifier Change DSC sensor 	steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		Heat now differenceLow flow cut off
				 Mass flow
	Status signal [from the factory] ²⁾	Μ		 Condensate mass flow
	Dia ana ati a haharai an (fuana tha		-	 Total mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		 Switch output status
	ractory] -/			 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

Status signal can be changed.

2) 3) Diagnostic behavior can be changed.

Diagnostic of configuration 12.5.3

	Diagnostic	information	Remedy instructions	Influenced measured variables
No.	SI	hort text		, and the
410	Data transfer		1. Check connection	 Calculated saturated
	Measured variable status		2. Retry data transfer	steam pressureEnergy flow
-	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Configuration error		 Low flow cut off
	Status signal [from the factory] ¹⁾	F		Mass flowCondensate mass flow
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
412	Processing download		Download active, please wait	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
437	Configuration incompatible		1. Restart device	 Calculated saturated 	
	Measured variable status		2. Contact service	steam pressureEnergy flow	
	Quality	Bad		Flow velocityHeat flow difference	
	Quality substatus	Configuration error		 Low flow cut off 	
	Status signal [from the factory] ¹⁾	F		 Mass flow Condensate mass flow Tatal mass flow 	
	Diagnostic behavior	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow 	

1) Status signal can be changed.

No.	l S	nformation nort text	Remedy instructions	Influenced measured variables
438	Mensured verifiable status			 Calculated saturated steam pressure
	Quality Quality substatus	Uncertain Non specific	3. Up- and download new configuration	 Energy flow Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow
	Status signal [from the factory] ¹⁾ Diagnostic behavior	M Warning		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
442	Frequency output		1. Check process	-
	Measured variable status		2. Check frequency output settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	S		
	Diagnostic behavior [from the factory] ²⁾	Warning		

1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

No.	J	nformation 10rt text	Remedy instructions	Influenced measured variables
443	Pulse output		1. Check process	-
	Measured variable status		2. Check pulse output settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	S		
	Diagnostic behavior [from the factory] $^{2)}$	Warning		

1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
453	Flow override		Deactivate flow override	 Calculated saturated
	Measured variable status			steam pressureEnergy flow
	Quality	Good		 Flow velocity Heat flow difference Low flow cut off Mass flow
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	С		 Condensate mass flow Total mass flow
	Diagnostic behavior	Warning		 Fotal mass now Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic i	nformation	Remedy instructions	Influenced measured variables
No.	SI	nort text		
484	4 Failure mode simulation		Deactivate simulation	 Calculated saturated
	Measured variable status			steam pressureEnergy flow
	Quality	Bad		 Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Corrected volume flow Steam quality Temperature Volume flow
	Quality substatus	Configuration error		
	Status signal [from the factory] ¹⁾	С		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
485	Measured variable simulation		Deactivate simulation	Calculated saturated
	Measured variable status			steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		 Low flow cut off
	Status signal [from the factory] ¹⁾	С		Mass flowCondensate mass flow
	Diagnostic behavior	Warning		 Total mass flow Switch output status Corrected volume flow Steam quality Temperature Volume flow

1) Status signal can be changed.

No.	Diagnostic i	nformation 10rt text	Remedy instructions	Influenced measured variables
492	Simulation frequency output		Deactivate simulation frequency	Calculated saturated
492	Measured variable status		output	 Calculated saturated steam pressure Energy flow
	Quality	Good		 Flow velocity Heat flow difference Low flow cut off Mass flow
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	C		 Condensate mass flow Total mass flow
	Diagnostic behavior	Warning		 Fotal mass now Switch output status Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
493	93 Simulation pulse output		Deactivate simulation pulse output	 Calculated saturated steam pressure
	Measured variable status			 Energy flow
	Quality	Good		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	С		 Mass flow Condensate mass flow Tatal wave flow
	Diagnostic behavior	Warning		 Total mass flow Switch output status Corrected volume flow Steam quality Temperature Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
494	94 Switch output simulation		Deactivate simulation switch output	Calculated saturated
	Measured variable status			steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		 Low flow cut off Mass flow
	Status signal [from the factory] ¹⁾	С		 Condensate mass flow
	Diagnostic behavior	Warning		 Total mass flow Switch output status Corrected volume flow Steam quality Temperature Volume flow

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
495	Diagnostic event simulation		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾			
	Diagnostic behavior	Warning		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
497	Simulation block output		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] $^{1)}$	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
538	Flow computer configuration inco	rrect	Check input value (pressure,	 Calculated saturated 	
	Measured variable status		temperature)	steam pressure Energy flow Heat flow difference Low flow cut off	*
	Quality	Good			
	Quality substatus	Non specific		 Low now cut on Mass flow 	
				 Condensate mass flow 	
	Status signal [from the factory] ¹⁾	S		 Total mass flow Switch systems atoms 	
	Diagnostic behavior	Warning		Switch output statusCorrected volume flowSteam quality	

1) Status signal can be changed.

No.	J	nformation nort text	Remedy instructions	Influenced measured variables	
539	Flow computer configuration incom	rrect	 Check input value (pressure, temperature) 	 Calculated saturated steam pressure 	
	Measured variable status		2. Check allowed values of the	 Energy flow 	
	Quality Bad medium properties	medium properties	Flow velocityHeat flow difference		
Sta	Quality substatus	Configuration error		 Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow 	
	Status signal [from the factory] ¹⁾	S			
	Diagnostic behavior	Alarm			

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
540	Flow computer configuration inco	rrect	Check entered reference value using	 Calculated saturated
	Measured variable status		the document Operating Instructions	steam pressureEnergy flow
	Quality	Good		 Heat flow difference Low flow cut off
	Quality substatus	Non specific		 Low now cut on Mass flow
				 Condensate mass flow
	Status signal [from the factory] ¹⁾	S		 Total mass flow
	Diagnostic behavior	Warning		Switch output statusCorrected volume flowSteam quality

	Diagnostic	information	Remedy instructions	Influenced measured	
No.	Short text			variables	
570	Inverted delta heat		Check configuration of mounting	Heat flow difference	
	Measured variable status		location (parameter Installation direction)	Installation	
	Quality	Bad			
	Quality substatus	Configuration error			
	Status signal [from the factory] ¹⁾	F			
	Diagnostic behavior	Alarm			

Status signal can be changed. 1)

Diagnostic of process 12.5.4

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
801	Supply voltage too low		Increase supply voltage	 Calculated saturated
	Measured variable status [from the factory] 1)			steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		 Low flow cut off
	Status signal [from the factory] ²⁾	F		Mass flowCondensate mass flow
	Diagnostic behavior [from the factory] ³⁾	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. Status signal can be changed.

1) 2) 3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured variables
No.	Sł	lort text		Variables
828	Ambient temperature too low		Increase ambient temperature of	 Calculated saturated
	Measured variable status [from the factory] 1)		pre-amplifier	steam pressureEnergy flow
	Quality	Good	-	Flow velocityHeat flow difference
	Quality substatus	Non specific		Low flow cut off
				 Mass flow
	Status signal [from the factory] $^{2)}$	S		 Condensate mass flow
	Diagnostic behavior [from the	Monning		 Total mass flow
	factory] ³⁾	Warning		 Switch output status
	lactory] */			 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

2)

Status signal can be changed. Diagnostic behavior can be changed. 3)

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
829	Ambient temperature too high		Reduce ambient temperature of pre-	 Calculated saturated
	Measured variable status [from the factory] ¹⁾		amplifier	steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		 Low flow cut off
	Status signal [from the factory] ²⁾	S		Mass flowCondensate mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

Status signal can be changed. 2)

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
832	Electronic temperature too high Measured variable status [from	the factoryl ¹⁾	Reduce ambient temperature	 Calculated saturated steam pressure
	Quality	Good		Energy flowFlow velocityHeat flow difference
	Quality substatus	Non specific		Low flow cut offMass flow
	Status signal [from the factory] ²⁾	S		 Condensate mass flow Total mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

2) 3)

Status signal can be changed. Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
833	Electronic temperature too low		Increase ambient temperature	Calculated saturated
	Measured variable status [from the factory] ¹⁾			steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Non specific		
	Status signal [from the factory] ²⁾	S		 Mass flow Condensate mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Temperature Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

Status signal can be changed.

2) 3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
834	B4 Process temperature too high I Measured variable status [from the factory] ¹)		Reduce process temperature	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Good Non specific		 Flow velocity Heat flow difference Low flow cut off Mass flow
	Status signal [from the factory] ²⁾ Diagnostic behavior [from the factory] ³⁾	S Warning		 Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
835	5 Process temperature too low Measured variable status [from the factory] ¹)		Increase process temperature	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Good Non specific		Flow velocityHeat flow differenceLow flow cut off
	Status signal [from the factory] ²)	S		 Mass flow Condensate mass flow Total mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		 Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
841	1 Flow velocity too high F Measured variable status [from the factory] ¹ F		Reduce flow velocity	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Good Non specific	 Flow velocity Heat flow diffe Low flow cut of Mass flow Condensate may Total mass flow Switch output so Reynolds number 	Flow velocityHeat flow differenceLow flow cut off
	Status signal [from the factory] ²⁾ Diagnostic behavior [from the factory] ³⁾	S Warning		 Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
842	Process limit		Low flow cut off active!	 Calculated saturated
	Measured variable status		 Check low flow cut off configuration 	steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	S		 Condensate mass flow
	Dia any artic haharaian	TAT		 Total mass flow
	Diagnostic behavior	Warning		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
844	<u> </u>	• 1)	Reduce flow velocity	 Calculated saturated steam pressure
	Measured variable status [from	the factory] ¹⁾		 Energy flow
	Quality	Good		Flow velocityHeat flow difference
	Quality substatus	Non specific		 Low flow cut off Mass flow Condensate mass flow Total mass flow
	Status signal [from the factory] ²⁾	S		
	Diagnostic behavior [from the factory] ³⁾	Warning		 For the second second

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
870	Measuring inaccuracy increased Measured variable status [from	the factory] ¹⁾	 Check process Increase flow volume 	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Good Non specific		 Flow velocity Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow
	Status signal [from the factory] ²⁾ Diagnostic behavior [from the factory] ³⁾	S Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
871	Near steam saturation limit		Check process conditions	 Calculated saturated
	Measured variable status [from	the factory] ¹⁾		steam pressureEnergy flow
	Quality	Good		Heat flow differenceLow flow cut off
	Quality substatus	Non specific		 Mass flow
	Status signal [from the factory] ²⁾	S	-	 Condensate mass flow Total mass flow
	Diagnostic behavior [from the factory] ³⁾	Warning		Switch output statusCorrected volume flowSteam quality

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
872	Wet steam detected		1. Check process	 Energy flow 	
	Measured variable status [from	the factory] ¹⁾	2. Check plant	 Heat flow difference Low flow cut off Condensate mass flow Total mass flow Switch output status 	
	Quality	Good			
	Quality substatus	Non specific			
				 Corrected volume flow 	
	Status signal [from the factory] ²⁾	S		 Steam quality 	
	Diagnostic behavior [from the factory] ³⁾	Warning			

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	l S	nformation nort text	Remedy instructions	Influenced measured variables
873	Water detected Measured variable status [from	the factory] ¹⁾	Check process (water in piping)	 Calculated saturated steam pressure Energy flow Heat flow difference Low flow cut off Mass flow Condensate mass flow Total mass flow Switch output status Corrected volume flow Steam quality
	Quality Quality substatus	Good Non specific		
	Status signal [from the factory] ²⁾ Diagnostic behavior [from the factory] ³⁾	S Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
874	X% spec invalid		1. Check pressure, temperature	 Calculated saturated
	Measured variable status		 Check flow velocity Check for flow fluctuation 	steam pressureEnergy flow
	Quality	Uncertain		 Heat flow difference Low flow cut off
	Quality substatus	Non specific		 Low now cut on Mass flow
				 Condensate mass flow
	Status signal [from the factory] ¹⁾	S		 Total mass flow
	Diagnostic behavior	Warning	-	Switch output statusCorrected volume flowSteam quality

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
882	Input signal		1. Check input configuration	 Calculated saturated
	Measured variable status		2. Check external device or process conditions	steam pressureEnergy flow
	Quality	Bad		Flow velocityHeat flow difference
	Quality substatus	Non specific		Low flow cut off
				 Mass flow
	Status signal [from the factory] ¹⁾	F		 Condensate mass flow
		A 1	-	 Total mass flow
	Diagnostic behavior	Alarm		 Switch output status
				 Reynolds number
				 Corrected volume flow
				 Steam quality
				 Temperature
				 Volume flow

Status signal can be changed. 1)

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
945	Sensor range exceeded Measured variable status [from	the factory] ¹⁾	Check immediately process conditions (pressure-temperature rating)	 Calculated saturated steam pressure Energy flow
	Quality Quality substatus	Good Non specific		Flow velocityHeat flow differenceLow flow cut off
	Status signal [from the factory] ²⁾ Diagnostic behavior [from the factory] ³⁾	S Warning		 Mass flow Condensate mass flow Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

Quality can be changed. This causes the overall status of the measured variable to change. 1)

- 2) 3)
- Status signal can be changed. Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
946	Vibration detected Measured variable status		Check installation	 Calculated saturated steam pressure
	Quality	Uncertain		 Energy flow Flow velocity Heat flow difference
	Quality substatus	Non specific		 Low flow cut off Mass flow
	Status signal [from the factory] ¹⁾	S		 Condensate mass flow
	Diagnostic behavior	Warning		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
947	Vibration exceeded		Check installation	 Calculated saturated
	Measured variable status [from	asured variable status [from the factory] ¹⁾		steam pressureEnergy flow
	Quality	Good		Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Non specific		
	Status signal [from the factory] ²⁾	S		 Mass flow Condensate mass flow Tatal mass flow
	Diagnostic behavior [from the factory] ³⁾	Alarm		 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	Sł	nort text		variables
948	Signal quality bad		1. Check process conditions: wet	 Calculated saturated
	Measured variable status		gas, pulsation 2. Check installation: vibration	steam pressureEnergy flow
	Quality	Uncertain	-	Flow velocityHeat flow differenceLow flow cut off
	Quality substatus	Non specific		
				 Mass flow
	Status signal [from the factory] $^{1)}$	S		 Condensate mass flow
	Diagnostic behavior	Warning	•	 Total mass flow Switch output status Reynolds number Corrected volume flow Steam quality Volume flow

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
972	egrees of superheat limit exceeded 1. Controll process conditions	-		
	Measured variable status	e status 2. Install pressure transmitter or enter correct fixed pressure value		
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] ¹⁾	S		
	Diagnostic behavior [from the factory] ²⁾	Warning		

2) Diagnostic behavior can be changed.

12.5.5 Operating conditions for displaying the following diagnostics information

P Operating conditions for displaying the following diagnostics information:

- 871 Near steam saturation limit diagnostic message: The process temperature is less than 2K from the saturated steam line.
 - Diagnostics information 872: The measured steam quality has dropped below the configured limit value for the steam quality (limit value: Expert → System → Diagnostic handling → Diagnostic limits → Steam quality limit).
 - Diagnostics information 873: The process temperature is ≤ 0 °C.
 - Diagnostics information 972: The degree of superheat has exceeded the configured limit value (limit value: Expert → System → Diagnostic handling → Diagnostic limits → Degrees of superheat limit).

12.5.6 Emergency mode in event of temperature compensation

- Change temperature measurement: PT1+PT2 to the PT1 option, PT2 option or the Off option.
 - └ If the **Off** option is selected, the measuring device calculates by using the fixed process pressure.

12.6 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \cong 136$

Other pending diagnostic events can be displayed in the **Diagnostic list** submenu $\rightarrow \cong 169$

Navigation

"Diagnostics" menu

얺 Diagnostics			
	Actual diagnostics		→ 🖺 169

Previous diagnostics	→ 🗎 169
Operating time from restart	→ 🗎 169
Operating time	→ 🗎 169

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	nostic event has occurred. Shows the current occured diagnostic event along with its diagnostic information.	
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.7 Diagnostic messages in the DIAGNOSTIC Transducer Block


- The Actual diagnostics parameter (actual diagnostics) displays the message with the highest priority.
- A list of the active alarms can be viewed via the Diagnostics 1 parameter (diagnostics_1) to Diagnostics 5 (diagnostics 5). If more than 5 messages are pending, the messages with the highest priority are shown on the display.
- You can view the last alarm that is no longer active via the **Previous diagnostics** parameter (**previous_diagnostics**).

12.8 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics \rightarrow Diagnostic list



24 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \square 136$


12.9 Event logbook

12.9.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu \rightarrow **Event logbook** submenu \rightarrow Event list



25 Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events $\rightarrow \triangleq 143$
- Information events $\rightarrow \triangleq 171$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - \odot : Occurrence of the event
 - \bullet \bigcirc : End of the event
- Information event

 \odot : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \square 136$
- Via "FieldCare" operating tool →
 [™]
 138

For filtering the displayed event messages $\rightarrow \cong 170$

12.9.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.9.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
11090	Configuration reset
I1091	Configuration changed
I1092	HistoROM backup deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1227	Sensor emergency mode activated
I1228	Sensor emergency mode failed
I1256	Display: access status changed
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1459	I/O module verification failed
I1461	Sensor verification failed
I1512	Download started
I1513	Download finished
I1514	Upload started

Info number	Info name
I1515	Upload finished
I1552	Failed: Main electronic verification
I1553	Failed: Pre-amplifier verification

12.10 Resetting the measuring device

Using the **Restart** parameter ($\Rightarrow \square 108$) it is possible to reset the entire device configuration or some of the configuration to a defined state.

12.10.1 Function scope of the "Restart" parameter

Options	Description
Uninitialized	The selection has no effect on the device.
Run	The selection has no effect on the device.
Resource	The selection has no effect on the device.
Defaults	All FOUNDATION Fieldbus blocks are reset to their factory settings. Example: Analog Input Channel to the Uninitialized option.
Processor	The device is restarted.
To delivery settings	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information) and device parameters for which a customer-specific default setting was ordered are reset to this customer-specific value.

12.10.2 Function scope of the "Service reset" parameter

Options	Description
Uninitialized	The selection has no effect on the device.
To delivery settings + MIB	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information, device tag and device address) and the device parameters for which a customer-specific default setting was ordered, are reset to this customer-specific value.
ENP restart	The parameters of the electronic name plate are reset. The device is restarted.

12.11 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information

► Device information		
Device tag	→ 🗎 173	
Serial number	→ 🗎 173	
Firmware version	→ 🗎 173	

-		
	Order code	→ 🗎 173
	Extended order code 1	→ 🖺 173
	Extended order code 2	→ 🖺 173
	ENP version	→ 🖺 173
	Device revision	→ 🖺 173
	Device type	→ 🖺 173

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /)	EH_Prowirl_200_xxxxxxxxx
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string with the following format: xx.yy.zz	-
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).	Character string in the format xx.yy.zz	-
Device type	Shows the device type with which the measuring device is registered with the FOUNDATION Fieldbus.	Prowirl 200	-
Device revision	Manufacturer revision number associated with the resource - used by an interface device to locate the DD file for the resource.	0 to 255	2

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
01.2018	01.01.zz	Option 71	 No need to restart device after parameter download Additional process variables: Density Condensate mass flow Pressure Degree of overheating Specific volume Process variables interconnectable with local display and data logger (trend) Verification progress indicator (0 to 100 %) New Wet Steam Measurement application package Operation in steam simplified More robust signal processing in event of low flow rates in wet steam Update to FF-Stack Update to Heartbeat Verification application package New Iow flow menu structure New Transducer Block structure Event logbook and trend display 	Operating Instructions	BA01695D/06/E N/01.18

12.12 Firmware history

It is possible to flash the firmware to the current version or the previous version using the service interface.

- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 7F2C
 - The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

NOTICE

The use of unsuitable equipment or cleaning liquids can damage the transducer.

Do not use pigs to clean the pipe.

13.1.3 Replacing seals

Replacing sensor seals

NOTICE

Seals in contact with fluid must always be replaced!

• Only Endress+Hauser sensor seals may be used: replacement seals

Replacing housing seals

NOTICE

When using the device in a dusty atmosphere:

• only use the associated Endress+Hauser housing seals.

- 1. Replace defect seals only with original seals from Endress+Hauser.
- 2. The housing seals must be clean and undamaged when inserted into their grooves.
- **3.** Dry, clean or replace the seals if necessary.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \square 181$

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ► Document every repair and each conversion and enter them into the *W*@*M* life cycle management database.


14.2 Spare parts

Instructions.

Some interchangeable measuring device components are listed on an overview sign in the connection compartment cover.


The spare part overview sign contains the following information:

- A list of the most important spare parts for the measuring device, including their ordering information.
- The URL for the W@M Device Viewer (www.endress.com/deviceviewer): All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation



Example for "Spare part overview sign" in connection compartment cover

- 1 Measuring device name
- 2 Measuring device serial number



- Is located on the device nameplate and the spare part overview sign.
- Can be read out via the **Serial number** parameter in the **Device information** submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the website for more information: http://www.endress.com/support/return-material
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal

X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to persons from process conditions.

- ► Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description	
Prowirl 200 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: Approvals Output, Input Display/operation Housing Software Installation Instructions EA01056D (Order number: 7X2CXX) 	
Remote display FHX50	 FHX50 housing for accommodating a display module . FHX50 housing suitable for: SD02 display module (push buttons) SD03 display module (touch control) Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft)) The measuring device can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes: Order code for measuring device, feature 030: Option L or M "Prepared for FHX50 display" Order code for FHX50 housing, feature 050 (device version): Option A "Prepared for FHX50 display" Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation): Option C: for an SD02 display module (push buttons) Option E: for an SD03 display module (touch control) The FHX50 housing can also be ordered as a retrofit kit. The measuring device display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing. Feature 050 (measuring device version): option B "Not prepared for FHX50 display" 	
Overvoltage protection for 2-wire devices	Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, feature 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting. OVP10: For 1-channel devices (feature 020, option A): Special Documentation SD01090F (Order number OVP10: 71128617) (Order number OVP20: 71128619)	

Accessories	Description
Protective cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight or extreme cold in winter.
Connecting cable for remote version	 Connecting cable available in various lengths: 5 m (16 ft) 10 m (32 ft) 20 m (65 ft) 30 m (98 ft) Armored cables available on request. Standard length: 5 m (16 ft) Is always supplied if no other cable length has been ordered.
Post mounting kit	Post mounting kit for transmitter.

15.1.2 For the sensor

Accessories	Description	
Flow conditioner	Is used to shorten the necessary inlet run. (Order number: DK7ST)	

15.2 Communication-specific accessories

Accessories	Description
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.
	Technical Information TI405C/07
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices
	 Technical Information TI01297S Operating Instructions BA01778S Product page: www.endress.com/fxa42
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. • Technical Information TI01342S • Operating Instructions BA01709S
	 Product page: www.endress.com/smt70
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.
	 Technical Information TI01418S Operating Instructions BA01923S Product page: www.endress.com/smt77

Accessories	Description	
Applicator	 Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices for industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. 	
	Applicator is available:Via the Internet: https://portal.endress.com/webapp/applicatorAs a downloadable DVD for local PC installation.	
W@M	W@M Life Cycle ManagementImproved productivity with information at your fingertips. Data relevant to aplant and its components is generated from the first stages of planning andduring the asset's complete life cycle.W@M Life Cycle Management is an open and flexible information platformwith online and on-site tools. Instant access for your staff to current, in-depthdata shortens your plant's engineering time, speeds up procurement processesand increases plant uptime.Combined with the right services, W@M Life Cycle Management boostsproductivity in every phase. For more information, visitwww.endress.com/lifecyclemanagement	
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.	
	Operating Instructions BA00027S and BA00059S	
DeviceCare	Tool to connect and configure Endress+Hauser field devices.	

15.3 Service-specific accessories

15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick. The memory and also on a SD card or

16 Technical data

16.1 Application

The measuring device is intended only for the flow measurement of liquids with a minimum conductivity of 20 $\mu S/cm.$

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Vortex meters work on the principle of the Karman vortex street.	
Measuring system	The device consists of a transmitter and a sensor.	
	 Two device versions are available: Compact version – transmitter and sensor form a mechanical unit. Remote version - transmitter and sensor are mounted in separate locations. 	
	For information on the structure of the device $\rightarrow \cong 12$	

16.3 Input

Measured variable

Direct measured variables

Order code for "Sensor version; DSC sensor; measuring tube"		
Option	Description Measured variable	
BD	Volume high-temperature; Alloy 718; 316L	Volume flow

Order code for "Sensor version; DSC sensor; measuring tube"			
Option	Description	Measured variable	
CD	Mass; Alloy 718; 316L (integrated temperature measurement)	Volume flowTemperature	

Calculated measured variables

Order coo	Order code for "Sensor version; DSC sensor; measuring tube"	
Option	Description	Measured variable
BD	Volume high-temperature; Alloy 718; 316L	Under constant process conditions: • Mass flow ¹⁾ • Corrected volume flow The totalized values for: • Volume flow • Mass flow • Corrected volume flow

1) A fixed density must be entered for calculating the mass flow (Setup menu \rightarrow Advanced setup submenu \rightarrow External compensation submenu \rightarrow Fixed density parameter).

Order c	ode for "Sensor version; DSC sensor; measuring tube"	
Option	Description	Measured variable
CD	Mass; Alloy 718; 316L (integrated temperature measurement)	Corrected volume flowMass flow
DC	Mass steam; Alloy 718; 316L (integrated pressure/ temperature measurement)	 Calculated saturated steam pressure Energy flow Heat flow difference
DD	Mass gas/liquid; Alloy 718; 316L (integrated pressure/ temperature measurement)	Specific volumeDegrees of superheat

Measuring range

The measuring range is dependent on the nominal diameter, the fluid and environmental influences.

The following specified values are the largest possible flow measuring ranges (Q_{min} to Q_{max}) for each nominal diameter. Depending on the fluid properties and environmental influences, the measuring range may be subject to additional restrictions. Additional restrictions apply to both the lower range value and the upper range value.


Flow measuring ranges in SI units

DN [mm]	Liquids [m³/h]	Gas/steam [m³/h]
15	0.1 to 4.9	0.52 to 25
25	0.32 to 15	1.6 to 130
40	0.63 to 30	3.1 to 250
50	0.99 to 47	4.9 to 620
80	2.4 to 110	12 to 1 500
100	4.1 to 190	20 to 2 600
150	9.3 to 440	47 to 5 900
200	18 to 760	90 to 10 000
250	28 to 1200	140 to 16 000
300	40 to 1700	200 to 22 000

Flow measuring ranges in US units

DN	Liquids	Gas/steam
[in]	[ft ³ /min]	[ft³/min]
1/2	0.061 to 2.9	0.31 to 15
1	0.19 to 8.8	0.93 to 74
11/2	0.37 to 17	1.8 to 150
2	0.58 to 28	2.9 to 370
3	1.4 to 67	7 to 900
4	2.4 to 110	12 to 1 500
6	5.5 to 260	27 to 3 500
8	11 to 450	53 to 6 000
10	17 to 700	84 to 9300
12	24 to 1000	120 to 13000

Flow velocity



D_i Internal diameter of measuring tube (corresponds to dimension *K*)

v Velocity in measuring tube

Q Flow

The internal diameter of measuring tube D_{i} is denoted in the dimensions as dimension K.

For detailed information, see the Technical Information. \rightarrow 🗎 208

Calculation of flow velocity:

$$v [m/s] = \frac{4 \cdot Q [m^3/h]}{\pi \cdot D_i [m]^2} \cdot \frac{1}{3600 [s/h]}$$
$$v [ft/s] = \frac{4 \cdot Q [ft^3/min]}{\pi \cdot D_i [ft]^2} \cdot \frac{1}{60 [s/min]}$$

Lower range value

A restriction applies to the lower range value due to the turbulent flow profile, which only occurs with Reynolds numbers greater than 5000. The Reynolds number is dimensionless and indicates the ratio of the inertia force of a fluid to its viscous force when flowing and is used as a characteristic variable for pipe flows. In the case of pipe flows with Reynolds numbers less than 5000, periodic vortices are no longer generated and flow rate measurement is no longer possible.

The Reynolds number is calculated as follows:

$$Re = \frac{4 \cdot Q [m^{3}/s] \cdot \rho [kg/m^{3}]}{\pi \cdot D_{i} [m] \cdot \mu [Pa \cdot s]}$$
$$Re = \frac{4 \cdot Q [ft^{3}/s] \cdot \rho [lbm/ft^{3}]}{\pi \cdot D_{i} [ft] \cdot \mu [lbf \cdot s/ft^{2}]}$$

Re Reynolds number

Q Flow

- *D_i* Internal diameter of measuring tube (corresponds to dimension K)
- μ Dynamic viscosity
- ρ Density


The Reynolds number, 5000 together with the density and viscosity of the fluid and the nominal diameter, is used to calculate the corresponding flow rate.

$$\begin{aligned} Q_{\text{Re}=5000} \left[\text{m}^{3}/\text{h} \right] &= \frac{5000 \cdot \pi \cdot \text{D}_{i} \left[\text{m} \right] \cdot \mu \left[\text{Pa} \cdot \text{s} \right]}{4 \cdot \rho \left[\text{kg/m}^{3} \right]} \cdot 3600 \left[\text{s/h} \right] \\ Q_{\text{Re}=5000} \left[\text{ft}^{3}/\text{h} \right] &= \frac{5000 \cdot \pi \cdot \text{D}_{i} \left[\text{ft} \right] \cdot \mu \left[\text{lbf} \cdot \text{s/ft}^{2} \right]}{4 \cdot \rho \left[\text{lbm/ft}^{3} \right]} \cdot 60 \left[\text{s/min} \right] \end{aligned}$$

 $Q_{Re=5000}$ Flow rate is dependent on the Reynolds number

D_i	Internal diameter of measuring tube (corresponds to dimension K	
μ	Dynamic viscosity	
ρ	Density	

The measuring signal must have a certain minimum signal amplitude so that the signals can be evaluated without any errors. Using the nominal diameter, the corresponding flow can also be derived from this amplitude. The minimum signal amplitude depends on the setting for the sensitivity of the DSC sensor (s), the steam quality (x) and the force of the vibrations present (a). The value mf corresponds to the lowest measurable flow velocity without vibration (no wet steam) at a density of 1 kg/m^3 (0.0624 lbm/ft^3). The value mf can be set in the range from 6 to 20 m/s (1.8 to 6 ft/s) (factory setting 12 m/s (3.7 ft/s)) with the **Sensitivity** parameter (value range 1 to 9, factory setting 5).



*v*_{AmpMin} Minimum measurable flow velocity based on signal amplitude

- mf Sensitivity
- x Steam quality
- ρ Density

$$\begin{aligned} Q_{AmpMin} \left[m^{3}/h \right] &= \frac{v_{AmpMin} \left[m/s \right] \cdot \pi \cdot D_{i} \left[m \right]^{2}}{4 \cdot \sqrt{\frac{\rho \left[kg/m^{3} \right]}{1 \left[kg/m^{3} \right]}}} \cdot 3600 \left[s/h \right]} \\ Q_{AmpMin} \left[ft^{3}/min \right] &= \frac{v_{AmpMin} \left[ft/s \right] \cdot \pi \cdot D_{i} \left[ft \right]^{2}}{4 \cdot \sqrt{\frac{\rho \left[lbm/ft^{3} \right]}{0.0624 \left[lbm/ft^{3} \right]}}}} \cdot 60 \left[s/min \right] \end{aligned}$$

A003430

<i>Q_{AmpMin}</i>	Minimum measurable flow rate based on signal amplitude
V _{AmpMin}	Minimum measurable flow velocity based on signal amplitude
D_i	Internal diameter of measuring tube (corresponds to dimension K)
ρ	Density

The effective lower range value Q_{Low} is determined using the largest of the three values $Q_{min},\,Q_{Re\,=\,5000}$ and $Q_{AmpMin}.$

	$\operatorname{Aax} \begin{cases} Q_{\min} [m^{3}/h] \\ Q_{\operatorname{Re}=5000} [m^{3}/h] \\ Q_{\operatorname{AmpMin}} [m^{3}/h] \end{cases}$
Q _{Low} [ft ³ /min] = m	$ax \begin{cases} Q_{min} [ft^3/min] \\ Q_{Re=5000} [ft^3/min] \\ Q_{AmpMin} [ft^3/min] \end{cases}$

Q_{Low}	Effective lower range value
Q _{min}	Minimum measurable flow rate
$Q_{Re = 5000}$	Flow rate is dependent on the Reynolds number
<i>Q_{AmpMin}</i>	Minimum measurable flow rate based on signal amplitude

The Applicator is available for calculation purposes.

Upper range value

The measuring signal amplitude must be below a certain limit value to ensure that the signals can be evaluated without error. This results in a maximum permitted flow rate Q_{AmpMax} :

$$Q_{AmpMax} [m^{3}/h] = \frac{350 [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4 \cdot \sqrt{\frac{\rho [kg/m^{3}]}{1 [kg/m^{3}]}}} \cdot 3600 [s/h]$$
$$Q_{AmpMax} [ft^{3}/min] = \frac{1148 [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4 \cdot \sqrt{\frac{\rho [lbm/ft^{3}]}{0.0624 [lbm/ft^{3}]}}} \cdot 60 [s/min]$$

A003431

 Q_{AmpMax} Maximum measurable flow rate based on signal amplitude

D_i Internal diameter of measuring tube (corresponds to dimension K)

ρ Density

For gas applications, an additional restriction applies to the upper range value with regard to the Mach number in the measuring device, which must be less than 0.3. The Mach number Ma describes the ratio of the flow velocity v to the sound velocity c in the fluid.

A0034321

$$Ma = \frac{v [m/s]}{c [m/s]}$$
$$Ma = \frac{v [ft/s]}{c [ft/s]}$$

Ма	Mach	number

- v Flow velocity
- c Sound velocity

The corresponding flow rate can be derived using the nominal diameter.

$$Q_{Ma=0.3} [m^{3}/h] = \frac{0.3 \cdot c [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4} \cdot 3600 [s/h]$$
$$Q_{Ma=0.3} [ft^{3}/min] = \frac{0.3 \cdot c [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4} \cdot 60 [s/min]$$

 $Q_{Ma=0.3}$ Restricted upper range value is dependent on Mach number

- c Sound velocity
- *D_i* Internal diameter of measuring tube (corresponds to dimension K)
- ρ Density

The effective upper range value Q_{High} is determined using the smallest of the three values $Q_{max},\,Q_{AmpMax}$ and $Q_{Ma=0.3}.$

$$Q_{High} [m^{3}/h] = \min \begin{cases} Q_{max} [m^{3}/h] \\ Q_{AmpMax} [m^{3}/h] \\ Q_{Ma=0.3} [m^{3}/h] \end{cases}$$
$$Q_{High} [ft^{3}/min] = \min \begin{cases} Q_{max} [ft^{3}/min] \\ Q_{AmpMax} [ft^{3}/min] \\ Q_{Ma=0.3} [ft^{3}/min] \end{cases}$$

A0034338


Q_{High} Effective upper range value

Q_{max} Maximum measurable flow rate

 Q_{AmpMax} Maximum measurable flow rate based on signal amplitude

 $Q_{Ma=0.3}$ Restricted upper range value is dependent on Mach number

For liquids, the occurrence of cavitation may also restrict the upper range value.



Operable flow range

The value, which is typically up to 49: 1, may vary depending on the operating conditions (ratio between upper range value and lower range value)

Input signal	External measured values
	 To increase the accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring device: Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S) Medium temperature to increase accuracy (e.g. iTEMP) Reference density for calculating the corrected volume flow
	 Various pressure measuring devices can be ordered as accessories from Endress+Hauser. If using pressure measuring devices, pay attention to outlet runs when installing external devices →
	If the measuring device does not have pressure or temperature compensation ³⁾ , it is recommended that external pressure measurement values be read in so that the following measured variables can be calculated: • Energy flow • Mass flow • Corrected volume flow
	Digital communication
	The measured values are written from the automation system to the measuring device via FOUNDATION Fieldbus.

16.4 Output

Output signal

Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output	
Version	Passive, open collector	
Maximum input values	 DC 35 V 50 mA 	
Voltage drop	 For ≤ 2 mA: 2 V For 10 mA: 8 V 	
Residual current	≤ 0.05 mA	
Pulse output		
Pulse width	Adjustable: 5 to 2 000 ms	
Maximum pulse rate	100 Impulse/s	
Pulse value	Adjustable	
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Total mass flow Energy flow Heat flow difference 	
Frequency output		
Output frequency	Adjustable: 0 to 1 000 Hz	
Damping	Adjustable: 0 to 999 s	
Pulse/pause ratio	1:1	

³⁾ Order code for "Sensor option", option DC, DD

Assignable measured variables	 Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure Total mass flow Energy flow Heat flow difference Pressure 	
Switch output		
Switching behavior	Binary, conductive or non-conductive	
Switching delay	Adjustable: 0 to 100 s	
Number of switching cycles	Unlimited	
Assignable functions	 Off On Diagnostic behavior Limit value Volume flow Corrected volume flow Mass flow Flow velocity Temperature Calculated saturated steam pressure Total mass flow Energy flow Heat flow difference Pressure Reynolds number Totalizer 1-3 Status Status of low flow cut off 	

FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s
Current consumption	15 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Pulse/frequency/switch output

Pulse output	
Failure mode	No pulses
Frequency output	
Failure mode	Choose from: • Actual value • 0 Hz • Defined value: 0 to 1250 Hz

Switch output	
Failure mode	Choose from: • Current status • Open • Closed

FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

Local display

Plain text display	With information on cause and remedial measures
Backlight	Additionally for device version with SD03 local display: red lighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication: FOUNDATION Fieldbus
- Via service interface CDI service interface

Plain text display

With information on cause and remedial measures

Low flow cut off

The switch points for low flow cut off are preset and can be configured.

Galvanic isolation

All inputs and outputs are galvanically isolated from one another.

Protocol-specific data	Manufacturer ID	0x452B48
	Ident number	0x1038
	Device revision	2
	DD revision	Information and files under:
	CFF revision	www.endress.comwww.fieldbus.org
	Device Tester Version (ITK version)	6.2.0
	ITK Test Campaign Number	Information: • www.endress.com • www.fieldbus.org
	Link Master capability (LAS)	Yes
	Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device
	Node address	Factory setting: 247 (0xF7)

Supported functions	The following methods are supported: Restart ENP Restart Diagnostic Read events Read trend data
Virtual Communication Relation	nships (VCRs)
Number of VCRs	44
Number of link objects in VFD	50
Permanent entries	1
Client VCRs	0
Server VCRs	10
Source VCRs	43
Sink VCRs	0
Subscriber VCRs	43
Publisher VCRs	43
Device Link Capabilities	
Slot time	4
Min. delay between PDU	8
Max. response delay	Min. 5
System integration	For information on system integration, see .
	 Cyclic data transmission Description of the modules Execution times Methods

16.5 Power supply

Terminal assignment → 🗎 31 → 🗎 31 Pin assignment, device plug Supply voltage Transmitter An external power supply is required for each output. The following supply voltage values apply for the outputs available: Supply voltage for a compact version without a local display ¹⁾ Order code for "Output; input" Minimum Maximum terminal voltage²⁾ terminal voltage Option E: FOUNDATION Fieldbus, pulse/ \geq DC 9 V DC 32 V frequency/switch output 1) In event of external supply voltage of the power conditioner 2) The minimum terminal voltage increases if local operation is used: see the following table

	Order code for "Display; operation"		Increase in minimum terminal voltage		
	Option C : Local operation SD02		+ DC 1 V		
	Option E : Local operation SD03 with lighting (backlighting not used)		+ DC 1 V		
	Option E : Local operation SD03 with lighting (backlighting used)		+ DC 3 V		
Power consumption	Transmitter				
	Order code for "Output; input"	Maximum pow	er consumption		
		Option E: FOUNDATION Fieldbus, pulse/			
Current consumption	FOUNDATION Fieldbus				
	15 mA				
Power supply failure	 Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored. 				
Electrical connection	→ 🗎 34				
Potential equalization	→ 🗎 40				
Terminals	 For device version without integrated overvoltage protection: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) For device version with integrated overvoltage protection: screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG) 				
Cable entries	 Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) Thread for cable entry: NPT ¹/₂" G ¹/₂" 				
Cable specification	→ 🗎 29				
Overvoltage protection	The device can be ordered with ir Order code for "Accessory mounte				
	Input voltage range Val	ues correspond to supply voltage speci	fications $\rightarrow \square 191^{1)}$		
	Resistance per channel 2 · 0).5 Ω max.			
	DC sparkover voltage 400 to 700 V				
	Trip surge voltage < 800 V				

Increase in minimum terminal voltage

Capacitance at 1 MHz	< 1.5 pF
Nominal discharge current (8/20 μs)	10 kA
Temperature range	-40 to +85 °C (-40 to +185 °F)

The voltage is reduced by the amount of the internal resistance $I_{\text{min}} \cdot R_i$ 1)



Depending on the temperature class, restrictions apply to the ambient temperature for device versions with overvoltage protection .


For detailed information on the temperature tables, see the "Safety Instructions" (XA) for the device.

Performance characteristics 16.6

Reference operating conditions	 Error limits following ISO/DIN 11631 +20 to +30 °C (+68 to +86 °F) 2 to 4 bar (29 to 58 psi) Calibration system traceable to national standards Calibration with the process connection corresponding to the particular standard
	To obtain measured errors, use the <i>Applicator</i> sizing tool $\rightarrow \square$ 181

Maximum measured error **Base accuracy**

o.r. = of reading



Reynolds	Reynolds number		
Re ₁	5000		
Re ₂	10 000		
Re _{min}	Reynolds number for minimum permitted volume flow in measuring tube		
	Standard		

Reynolds	number
	$Q_{AmpMin} [m^{3}/h] = \frac{v_{AmpMin} [m/s] \cdot \pi \cdot D_{i} [m]^{2}}{4 \cdot \sqrt{\frac{\rho [kg/m^{3}]}{1 [kg/m^{3}]}}} \cdot 3600 [s/h]$
	$Q_{AmpMin} [ft^{3}/min] = \frac{v_{AmpMin} [ft/s] \cdot \pi \cdot D_{i} [ft]^{2}}{4 \cdot \sqrt{\frac{\rho [lbm/ft^{3}]}{0.0624 [lbm/ft^{3}]}}} \cdot 60 [s/min]$
Re _{max}	Defined by internal diameter of measuring tube, Mach number and maximum permitted velocity in measuring tube $Re_{max} = \frac{\rho \cdot 4 \cdot Q_{Heigh}}{\mu \cdot \cdot K}$
	Further information on effective upper range value $Q_{High} \rightarrow \square 186$

Volume flow

Medium type		Incompressible	Compressible
Reynolds number range	Measured value deviation	Standard	Standard
Re ₂ to Re _{max}	A1	< 0.75 %	< 1.0 %
Re ₁ to Re ₂	A2	< 5.0 %	< 5.0 %

Temperature

- Saturated steam and liquids at room temperature, if T > 100 °C (212 °F): < 1 °C (1.8 °F)
- Gas: < 1 % o.r. [K]
- Volume flow: 70 m/s (230 ft/s): 2 % o.r.
- Rise time 50 % (stirred under water, following IEC 60751): 8 s

Mass flow saturated steam

			Mass (integrated temperature measurement)	Mass (integrated pressure/ temperature measurement) ¹⁾	
Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number range	Measured value deviation	Standard	Standard
> 4.76	20 to 50 (66 to 164)	Re_2 to Re_{max}	A1	< 1.7 %	< 1.5 %
> 3.62	10 to 70 (33 to 230)	Re_2 to Re_{max}	A1	< 2.0 %	< 1.8 %
In all cases not specified here, the following applies: < 5.7 %					

1) Sensor version available only for measuring devices in HART communication mode.

*Mass flow of superheated steam/gases*⁴⁾

				Mass (integrated pressure/ temperature measurement) ¹⁾	Mass (integrated temperature measurement) + external pressure compensation ²⁾
Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number range	Measured value deviation	Standard	Standard
< 40	All velocities	Re_2 to Re_{\max}	A1	< 1.5 %	< 1.7 %
< 120		Re_2 to Re_{max}	A1	< 2.4 %	< 2.6 %
In all cases not specified here, the following applies: < 6.6 %					

1) Sensor version available only for measuring devices in HART communication mode.

2) The use of a Cerabar S is required for the measured errors listed in the following section. The measured error used to calculate the error in the measured pressure is 0.15 %.

Water mass flow

Sensor version			Mass (integrated temperature measurement)	
Process pressure [bar abs.]	Flow velocity [m/s (ft/s)]	Reynolds number range	Measured value deviation	Standard
All pressures	All velocities	Re ₂ to Re _{max}	A1	< 0.85 %
		Re1 to Re2	A2	< 2.7 %

Mass flow (user-specific liquids)

To specify the system accuracy, Endress+Hauser requires information about the type of liquid and its operating temperature or information in table form about the dependency between the liquid density and the temperature.

Example

- Acetone is to be measured at fluid temperatures from +70 to +90 °C (+158 to +194 °F).
- For this purpose, the **Reference temperature** parameter (7703) (here 80 °C (176 °F)), **Reference density** parameter (7700) (here 720.00 kg/m³) and **Linear expansion coefficient** parameter (7621) (here 18.0298 × 10⁻⁴ 1/°C) must be entered in the transmitter.
- The overall system uncertainty, which is less than 0.9 % for the example above, is comprised of the following measurement uncertainties: uncertainty of volume flow measurement, uncertainty of temperature measurement, uncertainty of the density-temperature correlation used (including the resulting uncertainty of density).

Mass flow (other media)

Depends on the selected fluid and the pressure value, which is specified in the parameters. Individual error analysis must be performed.

Accuracy of outputs

The outputs have the following base accuracy specifications.

Pulse/frequency output

o.r. = of reading

Accuracy Max. ±100 ppm o.r.

⁴⁾ single gas, gas mixture, air: NEL40; natural gas: ISO 12213-2 contains AGA8-DC92, AGA NX-19, ISO 12213-3 contains SGERG-88 and AGA8 Gross Method 1

Repeatability

o.r. = of reading

	$r = \left\{\frac{100 \cdot D_i^3}{V}\right\}^{1/2}$ % o.r.				
	1004212 [% o.r.] 0.40				
	0.35 0.30 0.25 0.20 0.15 0.10 0.05				
	0 V / D _i ³ 1000 10000 100000				
Response time	The repeatability can be improved if the measured volume is increased. Repeatability is n a device characteristic but a statistical variable that is dependent on the boundary conditions indicated. If all the configurable functions for filter times (flow damping, display damping, current output time constant, frequency output time constant, status output time constant) are so to 0, in the event of vortex frequencies of 10 Hz and higher a response time of max(T _v , 100 ms) can be expected. In the event of measuring frequencies < 10 Hz, the response time is > 100 ms and can be				
	up to 10 s. T_v is the average vortex period duration of the flowing fluid.				
Influence of ambient temperature	Pulse/frequency output o.r. = of reading				
	Temperature coefficient Max. ±100 ppm o.r.				
	16.7 Installation				
Installation conditions	→ 🗎 20				
	16.8 Environment				
Ambient temperature range	→ 🗎 22				

range

	Temperature tables
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.
	For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
Storage temperature	All components apart from the display modules: -50 to +80 °C (-58 to +176 °F)
	Display modules
	All components apart from the display modules: −50 to +80 °C (−58 to +176 °F)
	Remote display FHX50: −50 to +80 °C (−58 to +176 °F)
Climate class	DIN EN 60068-2-38 (test Z/AD)
Degree of protection	 Transmitter As standard: IP66/67, type 4X enclosure When housing is open: IP20, type 1 enclosure Display module: IP20, type 1 enclosure
	Sensor IP66/67, type 4X enclosure
	Connector IP67, only in screwed situation
Vibration resistance	 Vibration, sinusoidal according to IEC 60068-2-6 Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact", J "GT20 two-chamber, aluminum, coated, remote", K "GT18 two-chamber, 316L, remote" 2 to 8.4 Hz, 7.5 mm peak 8.4 to 500 Hz, 2 g peak Order code for "Housing", option B "GT18 two-chamber, 316L, compact" 2 to 8.4 Hz, 3.5 mm peak 8.4 to 500 Hz, 1 g peak
	 Vibration broad-band random, according to IEC 60068-2-64 Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact", J "GT20 two-chamber, aluminum, coated, remote", K "GT18 two-chamber, 316L, remote" 10 to 200 Hz, 0.01 g²/Hz 200 to 500 Hz, 0.003 g²/Hz Total 2.7 g rms Order code for "Housing", option B "GT18 two-chamber, 316L, compact" 10 to 200 Hz, 0.003 g²/Hz 200 to 500 Hz, 0.003 g²/Hz Total 1.54 g rms
Shock resistance	 Shock, half-sine according to IEC 60068-2-27 Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact", J "GT20 two-chamber, aluminum, coated, remote", K "GT18 two-chamber, 316L, remote" 6 ms, 50 g Order code for "Housing", option B "GT18 two-chamber, 316L, compact" 6 ms, 30 g

Shock resistance	Shock due to rough handling following IEC 60068-2-31
Electromagnetic compatibility (EMC)	Details are provided in the Declaration of Conformity.

16.9 **Process**

Medium temperature range DSC sensor 1)

Order code for "Sensor version; DSC sensor; measuring tube"			
Option Description Medium temperature range		Medium temperature range	
BD	Volume high-temperature; Alloy 718; 316L	-200 to +400 °C (-328 to +752 °F), PN 63 to 160/ Class 600	
CD	Mass; Alloy 718; 316L	–200 to +400 °C (–328 to +752 °F)	
Special version for very high fluid temperatures (on request)		-200 to +440 °C (-328 to +824 °F), version for hazardous areas	

1) Capacitance sensor

Seals

	Order code for "DSC sensor seal"			
	Option	Description	Medium temperatu	ire range
	А	Graphite (standard) -200 to +400 °C (-328 to +752 °F)		28 to +752 °F)
	В	Viton	−15 to +175 °C (+5 t	to +347 °F)
	С	Gylon	−200 to +260 °C (−3	28 to +500 °F)
	D	Kalrez	−20 to +275 °C (−4 t	co +527 °F)
Pressure-temperature ratings for the process connectings for the process connectings for the process connecting provided in the "Technical Information" document		he process connections is		
Nominal pressure of sensor	The following overpressure resistance values apply to the sensor shaft in the event of a membrane rupture:			
	Sensor version; DSC sensor; measuring tube		Overpressure, sensor shaft in [bar a]	
	Volume hig	Jh-temperature		375
	Mass (integrated temperature measurement)		nt)	375
	Mass steam (integrated pressure/temperature measurement) Mass gas/liquid (integrated pressure/temperature measurement)		375	
Pressure specifications	For c	rder code for "Sensor vers	ion; DSC sensor; measu	ring tube", option DA "Mass
	 steam" and DB "Mass gas/liquid", the following applies: Only available for measuring devices with the HART communication protocol Oil-free or grease-free cleaning is not possible 			
	The OPL (over pressure limit = sensor overload limit) for the measuring device depends on			

the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the appropriate standards and further information . The OPL may only be applied for a limited period of time.

The MWP (maximum working pressure) for the sensors depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the measuring cell. Also observe pressure-temperature dependency. For the appropriate standards and further information . The MWP may be applied at the device for an unlimited period. The MWP can also be found on the nameplate.

WARNING

The maximum pressure for the measuring device depends on the lowest-rated element with regard to pressure.

- ► Note specifications regarding pressure range.
- ► The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP of the device.
- ► MWP: The MWP is indicated on the nameplate. This value refers to a reference temperature of +20 °C (+68°F) and may be applied to the device for an unlimited time. Note temperature dependence of MWP.
- ► OPL: The test pressure corresponds to the over pressure limit of the sensor and may be applied only temporarily to ensure that the measurement is within the specifications and no permanent damage occurs. In the case of sensor range and process connection combinations where the OPL of the process connection is less than the nominal value of the sensor, the device is set at the factory, at the very maximum, to the OPL value of the process connection. If using the entire sensor range, select a process connection with a higher OPL value.

Sensor	nsor Maximum sensor measuring range		MWP	OPL
	Lower (LRL)	Upper (URL)		
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]
40 bar (600 psi)	0 (0)	+40 (+600)	100 (1500)	160 (2 400)
100 bar (1 500 psi)	0 (0)	+100 (+1500)	100 (1500)	160 (2 400)
160 bar (2 300 psi)	0 (0)	+160 (+2 300)	400 (6000)	600 (9000)

Pressure loss

For a precise calculation, use the Applicator \rightarrow 🗎 181.

Vibrations

16.10 Mechanical construction

Design, dimensions	For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.
Weight	Compact version
	 Weight data: Including the transmitter: Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact" 1.8 kg (4.0 lb): Order code for "Housing", option B "GT18 two-chamber, 316L, compact"4.5 kg (9.9 lb): Excluding packaging material

Weight in SI units

All values (weight) refer to devices with EN (DIN), PN 250 flanges. Weight information in [kg].

DN	Weight [kg]		
[mm]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact"	Order code for "Housing", option B "GT18 two-chamber, 316L, compact"	
15	15.1	17.8	
25	16.1	18.8	
40	21.1	23.8	
50	23.1	28	
80	41.1	43.8	
100	64.1	66.8	
150	152.1	154.8	

Weight in US units

All values (weight) refer to devices with ASME B16.5, Class 1500/Sch. 80 flanges. Weight information in [lbs].

DN	Weight [lbs]		
[in]	Order code for "Housing", option C "GT20 two-chamber, aluminum, coated, compact"	Order code for "Housing", option B "GT18 two-chamber, 316L, compact"	
1/2	29.0	34.9	
1	37.8	43.7	
1½	44.4	50.3	
2	66.5	72.4	
3	108.3	114.3	
4	156.8	162.8	
6	381.7	387.7	

Transmitter remote version

Wall-mount housing

Dependent on the material of wall-mount housing:

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"2.4 kg (5.2 lb):
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote"6.0 kg (13.2 lb):

Sensor remote version

Weight data:

- Including sensor connection housing:
 - Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote"0.8 kg (1.8 lb):
 - Order code for "Housing", option K "GT18 two-chamber, 316L, remote"2.0 kg (4.4 lb):
- Excluding the connecting cable
- Excluding packaging material

Weight in SI units

All values (weight) refer to devices with EN (DIN), PN 250 flanges. Weight information in [kg].

DN	Weight [kg]		
[mm]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote"	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote"	
15	14.1	15.3	
25	15.1	16.3	
40	20.1	21.3	
50	22.1	23.3	
80	40.1	41.3	
100	63.1	64.3	
150	151.1	152.3	

Weight in US units

All values (weight) refer to devices with ASME B16.5, Class 1500/Sch. 80 flanges. Weight information in [lbs].

DN	Weight [lbs]		
[in]	sensor connection housing Order code for "Housing", option J "GT20 two-chamber, aluminum, coated, remote"	sensor connection housing Order code for "Housing", option K "GT18 two-chamber, 316L, remote"	
1/2	26.6	29.4	
1	35.4	38.2	
1½	42.0	44.8	
2	64.1	66.8	
3	105.9	108.7	
4	154.5	157.2	
6	379.3	382.1	

Accessories

Flow conditioner

Weight in SI units

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
15	PN 63	0.05
25	PN 63	0.2
40	PN 63	0.4
50	PN 63	0.6
80	PN 63	1.4
100	PN 63	2.4
150	PN 63	7.8

1) EN (DIN)

DN ¹⁾ [mm]	Pressure rating	Weight [kg]
15	40K	0.06
25	40K	0.1
40	40K	0.3
50	40K	0.5
80	40K	1.3
100	40K	2.1
150	40K	6.2

1) JIS

Materials

Transmitter housing


Compact version

- Order code for "Housing", option B "GT18 two-chamber, 316L, compact": Stainless steel, CF3M
- Order code for "Housing", option C "GT20, two-chamber, aluminum, coated, compact": Aluminum, AlSi10Mg, coated
- Window material: glass

Remote version

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": For maximum corrosion resistance: Stainless steel, CF3M
- Window material: glass

Cable entries/cable glands



28 Possible cable entries/cable glands

- 1 Female thread M20 × 1.5
- 2 Cable gland $M20 \times 1.5$
- 3 Adapter for cable entry with female thread $G \frac{1}{2}$ or NPT $\frac{1}{2}$ "
- 4 Device plugs

Order code for "Housing", option B "GT18 dual compartment, 316L, compact" option K "GT18 dual compartment, 316L, remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	 Non-hazardous area Ex ia Ex ic Ex nA, Ex ec Ex tb 	Stainless steel ,1.4404
Adapter for cable entry with female thread G ½"	Non-hazardous area and hazardous area (except for XP)	Stainless steel, 1.4404 (316L)
Adapter for cable entry with female thread NPT ½"	Non-hazardous area and hazardous area	

Order code for "Housing": option C "GT20 dual compartment, aluminum, coated, compact", option J "GT20 dual compartment, aluminum, coated remote"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	Non-hazardous areaEx iaEx ic	Plastic
	Adapter for cable entry with female thread G ½"	Nickel-plated brass
Adapter for cable entry with female thread NPT ½"	Non-hazardous area and hazardous area (except for XP)	Nickel-plated brass
Thread NPT ½" via adapter	Non-hazardous area and hazardous area	

Connecting cable for remote version

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor connection housing

The material of the sensor connection housing is dependent on the material selected for the transmitter housing.

- Order code for "Housing" option J "GT20 two-chamber, aluminum, coated, remote": Coated aluminum AlSi10Mg
- Order code for "Housing", option K "GT18 two-chamber, 316L, remote": Stainless cast steel, 1.4408 (CF3M) Compliant with:
 - NACE MR0175
 - NACE MR0103

Measuring tubes

DN 15 to 300 (½ to 12"), pressure ratings PN160/250, Class 900/1500: Stainless cast steel, CF3M/1.4408

- Compliant with:
- NACE MR0175
- NACE MR0103
- DN15 to 150 (½ to 6"): AD2000, permitted temperature range -10 to +400 °C (+14 to +752 °F) restricted)

DSC sensor

Order code for "Sensor version; DSC sensor; measuring tube", option BD, CD

Pressure ratings PN 160/250, Class 900/1500:

Parts in contact with medium (marked as "wet" on the DSC sensor flange):


- UNS N07718 similar to Alloy 718/2.4668
- Compliant with:
 - NACE MR01752003
 - NACE MR01032003

Parts not in contact with medium: Stainless steel 1.4301 (304)

Process connections

Pressure ratings PN 160/250, Class 900/1500:

Stainless steel, triple-certified material, 1.4404/F316/F316L



Seals

- Graphite (standard)
 Sigraflex foilTM (BAM-tested for oxygen applications, "high-grade in the context of TA-Luft Clean Air Guidelines")
- FPM (VitonTM)
- Kalrez 6375TM
- Gylon 3504TM (BAM-tested for oxygen applications, "high-grade in the context of TA-Luft clean air guidelines")

Housing support

Stainless steel, 1.4408 (CF3M)

Screws for DSC sensor

- Order code for "Sensor version", option BD, CD, DC, DD Stainless steel, A2-80 according to ISO 3506-1 (304)
- On request Stainless steel, 1.4980 according to EN 10269 (Gr. 660 B)

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

Flow conditioner

- Stainless steel, multiple certifications, 1.4404 (316, 316L)
- Compliant with:
 - NACE MR0175-2003
 - NACE MR0103-2003

Process connections

Pressure ratings PN 160/250, Class 900/1500:

Stainless steel, triple-certified material, 1.4404/F316/F316L

📭 Available process connections

16.11 Operability

Languages	Can be operated in the following languages:
	Via local display:
	English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Swedish,
	Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech
	Via "FieldCare" operating tool:
	English, German, French, Spanish, Italian, Chinese, Japanese

Local operation

Via display module

Two display modules are available:

Order code for "Display; Operation", option C "SD02"	Order code for "Display; Operation", option E "SD03"
A0032219	A0032221
1 Operation with pushbuttons	1 Operation with touch control

Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.

Operating elements

- External operation via touch control (3 optical keys) without opening the housing: $\boxplus, ~\boxdot, ~ \boxtimes$
- Operating elements also accessible in the various zones of the hazardous area


Additional functionality

- Data backup function
- The device configuration can be saved in the display module.
- Data comparison function
 - The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function

The transmitter configuration can be transmitted to another device using the display module.

Via remote display FHX50

The remote display FHX50 can be ordered as an optional extra $\rightarrow \cong 179$.



☑ 29 FHX50 operating options

1 SD02 display and operating module, push buttons: cover must be opened for operation

2 SD03 display and operating module, optical buttons: operation possible through cover glass

Display and operating elements

The display and operating elements correspond to those of the display module .

Remote operation	→ 🗎 55	
Service interface	→ 🗎 56	
	16.12 Certificates and approvals	
	Currently available certificates and approvals can be called up via the product configurator.	
CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.	
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.	
RCM-tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".	
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.	

FOUNDATION Fieldbus	FOUNDATION Fieldbus interface
certification	 The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications: Certified in accordance with FOUNDATION Fieldbus H1 Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request) Physical Layer Conformance Test The device can also be operated with certified devices of other manufacturers (interoperability)
Pressure Equipment Directive	 With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU. Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU.
Experience	The Prowirl 200 measuring system is the official successor to Prowirl 72 and Prowirl 73.
Other standards and guidelines	 EN 60529 Degrees of protection provided by enclosures (IP code) DIN ISO 13359 Measurement of conductive liquid flow in closed conduits - Flanged-type electromagnetic flowmeters - Overall length EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices NAMUR NE 107 Self-monitoring and diagnosis of field devices NAMUR NE 131 Requirements for field devices for standard applications
	16.13 Application packages
	Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Detailed information on the application packages: Special Documentation for the device

16.14 Accessories

Overview of accessories available for order \rightarrow 179

16.15 Supplementary documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Standard documentation

Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Prowirl O 200	KA01324D

Brief Operating Instructions for transmitter

Measuring device	Documentation code
Prowirl 200	KA01327D

Technical Information

Measuring device	Documentation code
Prowirl O 200	TI01334D

Description of Device Parameters

Measuring device	Documentation code
Prowirl 200	GP01111D

Supplementary devicedependent documentation

Safety instructions

ContentDocumentation codeATEX/IECEx Ex d, Ex tbXA01635DATEX/IECEx Ex ia, Ex tbXA01636DATEX/IECEx Ex ic, Ex ecXA01637DcCSA_{US} XPXA01638DcCSA_{US} ISXA01639DNEPSI Ex dXA01643D

Content	Documentation code
NEPSI Ex i	XA01644D
NEPSI Ex ic, Ex nA	XA01645D
INMETRO Ex d	XA01642D
INMETRO Ex i	XA01640D
INMETRO Ex nA	XA01641D
EAC Ex d	XA01684D
EAC Ex nA	XA01685D
JPN Ex d	XA01766D

Special documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D

Contents	Documentation code		
	HART	FOUNDATION Fieldbus	PROFIBUS PA
Heartbeat Technology	SD02029D	SD02030D	SD02031D

Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via W@M Device Viewer → ^B 176 Accessories available for order with Installation Instructions → ^B 179

Designated use 9 Device description files 60

Device documentation

Index

Α

Access authorization to p	parameters
---------------------------	------------

Read access	4
Write access	4
Access code	4
Incorrect input	4
Adapting the diagnostic behavior	8
Adapting the status signal	
Ambient temperature	
Influence	6
Ambient temperature range 2	2
AMS Device Manager	
Function	8
Application	52
Applicator	3
Approvals	16

С

Cable entries
Technical data
Cable entry
Degree of protection
CE mark
Certificates
CFF revision
Check
Connection
Installation
Checklist
Post-connection check
Post-installation check
Cleaning
Exterior cleaning
Interior cleaning
Replacing housing seals
Replacing seals
Replacing sensor seals
Climate class
Commissioning
Advanced settings
Configuring the measuring device 67
Connecting cable
Connecting the measuring device
Connection
see Electrical connection
Connection preparations
Connection tools
Context menu
Calling up
Closing
Explanation
Current consumption
Cyclic data transmission 60
D

Supplementary documentation
Device locking, status
Device name
Sensor
Transmitter
Device repair
Device revision
Device type ID
DeviceCare
Device description file
Diagnostic behavior
Explanation
Symbols
Diagnostic information
Design, description
DeviceCare
FieldCare
Local display
Overview
Remedial measures
Diagnostic list
Diagnostic message
DIAGNOSTIC Transducer Block 169
Diagnostics
Symbols
DIP switches
see Write protection switch
Direct access
Direct access code
Disabling write protection
Display
see Local display
Display area
For operational display
In the navigation view
Display values
For locking status
Disposal
Document
Function
Symbols
Document function 6
Е
Electrical connection
Commubox FXA291

DD revision					60
-------------	--	--	--	--	----

Operating tools
Via FOUNDATION Fieldbus network 55
Via service interface (CDI)
Electromagnetic compatibility
Enabling write protection
Enabling/disabling the keypad lock
Endress+Hauser services
Maintenance
Repair
Environment
Ambient temperature
Shock resistance
Storage temperature
Vibration resistance
Error messages
see Diagnostic messages
Event list
Event logbook
Ex approval
Experience
Extended order code
Sensor
Transmitter
Exterior cleaning

F

Field Communicator
Function
Field Communicator 475
Field of application
Residual risks
Field Xpert
Function
Field Xpert SFX350 57
FieldCare 57
Device description file
Establishing a connection
Function
User interface
Filtering the event logbook
Firmware
Release date
Version
Firmware history
Flow direction
FOUNDATION Fieldbus block structure
FOUNDATION Fieldbus certification
Function check
Function range
Field Xpert
Function scope
AMS Device Manager
Field Communicator
Field Communicator 475
Functions
see Parameters
C

G

Galvanic isolation	90
--------------------	----

Н
Hardware write protection
Help text
Calling up
Closing
Explanation
HistoROM
Ι
I/O electronics module
Identifying the measuring device
Incoming acceptance
Influence
Ambient temperature
Information on the document
Inlet runs
Input
Input mask
Inspection
Received goods
Installation
Installation conditions
Inlet and outlet runs
Installation dimensions
Mounting location
Orientation
Thermal insulation
Installation dimensions
Interior cleaning
L

Languages, operation options	5
Line recorder	9
Local display	5
Editing view	7
Navigation view	5
see Diagnostic message	
see In alarm condition	
see Operational display	
Low flow cut off	0

М

Main electronics module
Maintenance tasks
Managing the device configuration
Manufacturer ID
Manufacturing date
Materials
Maximum measured error
Measured values
Calculated
Measured variables
Measured
see Process variables
Measuring and test equipment
Measuring device
Configuration
Conversion
Disposal

Index

Mounting the sensor25Preparing for electrical connection33Preparing for mounting25Removing177Repairs176Structure12Switch-on66Measuring principle182Measuring range183Measuring system182Medium temperature range198Menu198	P
Diagnostics	
MenusFor measuring device configurationFor specific settingsYounting dimensionssee Installation dimensionsMounting location20Mounting preparations25Mounting tools	
N Nameplate Sensor	P
Navigation view45In the submenu45In the wizard45Nominal pressure5Sensor198Numeric editor47	P P P P P
O Operable flow range	P P P
Operating menu42Menus, submenus42Structure42Submenus and user roles43Operating philosophy43Operation124Operation options41Operational display44Operational safety10Order code13, 14, 15Orientation (vertical, horizontal)20Output188Output signal188	P P R R R R R R R R R R R R R R R R
P Packaging disposal	F

Entering a value	. 53
Parameter settings	
Administration (Submenu)	107
Analog inputs (Submenu)	
Configuration backup display (Submenu)	105
Data logging (Submenu)	129
Device information (Submenu)	172
Diagnostics (Menu)	168
Display (Submenu)	103
Display (Wizard)	75
External compensation (Submenu)	
Gas composition (Submenu)	
Low flow cut off (Wizard)	
Medium properties (Submenu)	. 80
Medium selection (Wizard)	72
Output values (Submenu)	127
Process variables (Submenu)	125
Pulse/frequency/switch output (Wizard) 96, 97,	
98,	99
Sensor adjustment (Submenu)	95
Setup (Menu)	. 67
Simulation (Submenu)	108
System units (Submenu)	. 68
Totalizer (Submenu)	127
Totalizer 1 to n (Submenu)	101
Totalizer handling (Submenu)	128
Performance characteristics	193
Post-connection check (checklist)	40
Post-installation check	66
Post-installation check (checklist)	
Potential equalization	
Power consumption	192
Power supply failure	192
Pressure Equipment Directive	207
Pressure loss	199
Pressure-temperature ratings	198
Process	170
Pressure loss	199
Process conditions	1))
Medium temperature	198
Product safety	
Protecting parameter settings	
	110
R	
RCM-tick symbol	206
Read access	
	174

Read access	54
Reading measured values	24
Recalibration	75
Reference operating conditions 1	93
Registered trademarks	. 8
Remedial measures	
Calling up	36
Closing	36
Remote operation	06
Remote version	
Connecting the connecting cable	35
Repair	76
Repair of a device	76

Repairs

Notes	176
Repeatability	196
Replacement	
Device components	176
Replacing seals	175
Requirements for personnel	9
Response time	196
Return	177

S

Safety
Sensor
Mounting
Serial number
Setting the operating language 66
Settings
Adapting the measuring device to the process
conditions
Administration
Advanced display configurations
Analog input
Device reset
Device tag
External compensation
Gas composition
Local display
Low flow cut off
Managing the device configuration 105
Medium
Medium properties
Operating language
Pulse output
Pulse/frequency/switch output
Resetting the totalizer
Restart device
Sensor adjustment
Simulation
Switch output
System units
Totalizer
Totalizer reset
Shock resistance
Showing data logging
Signal on alarm
Spare part
Spare parts
Standards and guidelines
Status area
For operational display
In the navigation view
Status signals 134, 137
Storage conditions
Storage temperature 18
Storage temperature range
Structure
Measuring device
Operating menu
operating menu

Submenu		
Administration		107
Advanced setup		. 79
Analog inputs		
Configuration backup display		
Data logging		129
Device information		172
Display		
Event list		
External compensation		
Gas composition		
Medium properties		
Output values		
Overview		
Process variables		
Sensor adjustment		
Simulation		108
System units		68
Totalizer		127
Totalizer 1 to n		
		128
Totalizer handling		208
Supplementary documentation		200
		22
Requirements		
Supply voltage	. 55,	191
Symbols		1. 1.
For communication		44
For correction		
For diagnostic behavior		44
For locking		
For measured variable		
For measurement channel number		
For menus		
For parameters		
For status signal		
For submenu		. 46
For wizard		
In the status area of the local display		
In the text and numeric editor		. 4/
System design		100
Measuring system		182
see Measuring device design		
System integration		60
Т		
-		107
Technical data, overview		182
Temperature range		10
Storage temperature		
Terminal assignment		
Terminals		
Text editor		
Thermal insulation		23

Tool tip see Help text

Tools	
Electrical connection	29
Installation	25
Transport	18

Configuration
Transmitter
Connecting the signal cables
Turning the display module
Turning the housing
Transporting the measuring device
Troubleshooting
General
Turning the display module
Turning the electronics housing
see Turning the transmitter housing
Turning the transmitter housing
U
Use of the measuring device
Borderline cases
Incorrect use
see Designated use
User interface
Current diagnostic event
Previous diagnostic event
User roles
0.561 10165
V
• Version data for the device 60
Vibration resistance
Vibration resistance
Vibration resistance
Vibration resistance
Vibration resistance 197 W 175, 176 W@M Device Viewer 13, 176
Vibration resistance 197 W W@M W@M Device Viewer 175, 176 W@M Device Viewer 13, 176 Weight 13, 176
Vibration resistance
Vibration resistance
Vibration resistance
Vibration resistance197WW@M175, 176W@M Device Viewer13, 176Weight199SI units200US units200Flow conditioner201
Vibration resistance
Vibration resistance
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 US units 201
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 US units 201 Transport (notes) 18
Vibration resistance
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 SI units 201 Veransport (notes) 18 Wizard 75
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 SI units 201 Transport (notes) 18 Wizard 75 Low flow cut off 77
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 SI units 201 Vibration remote version 18 Wizard 75 Low flow cut off 77 Medium selection 72
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 SI units 201 Transport (notes) 18 Wizard 75 Low flow cut off 77
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 SI units 201 Vibration remote version 18 Wizard 75 Low flow cut off 77 Medium selection 72
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 US units 201 Transport (notes) 18 Wizard 75 Display 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 US units 201 Transport (notes) 18 Wizard 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99 Workplace safety 10
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 Sunits 201 Transport (notes) 18 Wizard 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99 Workplace safety 10 Write access 54
Vibration resistance 197 W 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 Sunits 201 Transport (notes) 18 Wizard 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99 Workplace safety 10 Write access 54
Vibration resistance 197 W 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 Sunits 201 Transport (notes) 18 Wizard 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99 Workplace safety 10 Write access 54 Write protection 110
Vibration resistance 197 W 175, 176 W@M 175, 176 W@M Device Viewer 13, 176 Weight 13, 176 Compact version 199 SI units 200 US units 200 Flow conditioner 201 Sensor remote version 201 Us units 201 Transport (notes) 18 Wizard 75 Low flow cut off 77 Medium selection 72 Pulse/frequency/switch output 96, 97, 98, 99 Workplace safety 10 Write access 54 Write protection 110 Via access code 110 Via block operation 112

www.addresses.endress.com

