BA01565D/06/EN/02.21 71506059 2021-01-01 Valid as of version (Device firmware)

# Operating Instructions Proline Promass O 500

Coriolis flowmeter FOUNDATION Fieldbus







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

# Table of contents

1	About this document $\ldots \ldots \ 6$
1.1 1.2	Document function6Symbols61.2.1Safety symbols61.2.2Electrical symbols61.2.3Communication symbols61.2.4Tool symbols71.2.5Symbols for
1.3	certain types of information71.2.6Symbols in graphics7Documentation81.3.1Standard documentation81.3.2Supplementary device-dependent documentation8Registered trademarks8
2	Safety instructions 10
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Safety instructions10Requirements for the personnel10Designated use10Workplace safety11Operational safety11Product safety12IT security12Device-specific IT security122.7.1Protecting access via hardware write protection2.7.2Protecting access via a password122.7.3Access via Web server13
3	Product description 14
3.1	Product design       14         3.1.1       Proline 500 – digital       14         3.1.2       Proline 500       15
4	Incoming acceptance and product
4.1 4.2	identification16Incoming acceptance16Product identification164.2.1Transmitter nameplate174.2.2Sensor nameplate194.2.3Symbols on measuring device20
5	Storage and transport 21
5.1 5.2	Storage conditions21Transporting the product215.2.1Measuring devices without lifting lugs215.2.2Measuring devices with lifting lugs225.2.3Transporting with a fork lift22
5.3	Packaging disposal 22

6	Instal	lation	22
6.1	Installa	tion conditions	22
	6.1.1	Mounting position	22
	6.1.2	Environmental and process	
		requirements	25
	613	Special mounting instructions	26
62	Mounti	ng the measuring device	29
0.2	6 2 1	Required tools	29
	622	Droparing the manufing device	20
	0.4.4	Mounting the measuring device	29
	0.2.5	Mounting the measuring device	29
	6.2.4	Mounting the transmitter housing:	20
		Proline 500 – digital	30
	6.2.5	Mounting the transmitter housing:	
		Proline 500	31
	6.2.6	Turning the transmitter housing:	
		Proline 500	33
	6.2.7	Turning the display module: Proline	
		500	34
6.3	Post-in	stallation check	34
0.5	1 000 111		21
7	Electr	ical connection	35
7.1	Connec	tion conditions	35
	7.1.1	Required tools	35
	7.1.2	Requirements for connecting cable	35
	7.1.3	Terminal assignment	39
	7.1.4	Device plugs available	39
	715	Pin assignment of device plug	39
	716	Shielding and grounding	40
	717	Proparing the measuring device	41
7 2	Connor	ting the manufing device: Droling	41
1.2		inig the measuring device. Frome	4.2
	500 - u		42
	/.Z.1	Connecting the connecting cable	42
	7.2.2	Connecting the signal cable and the	
		supply voltage cable	47
7.3	Connec	ting the measuring device: Proline	
	500		49
	7.3.1	Connecting the connecting cable	49
	7.3.2	Connecting the signal cable and the	
		supply voltage cable	53
7.4	Ensurin	ng potential equalization	55
	7.4.1	Requirements	55
75	Special	connection instructions	56
1.5	7 5 1	Connection examples	56
76	7.J.I Encurin	the degree of protection	50
7.0	Doct co	ny the degree of protection	59
1.1	Post-co		29
8	Opera	tion options	60
8.1	Overvie	w of operation options	60
8.2	Structur	re and function of the operating	
5.2	menii	te and function of the operating	61
	8 7 1	Structure of the operating monu	61
	9.2.1 8.7.7	Operating philosophy	67
	0.4.4	operating philosophy	02

8.3	Access	to the operating menu via the local	
	display	•••••••••••••••••••••••••••••••••	63
	8.3.1	Operational display	63
	8.3.2	Navigation view	65
	8.3.3	Editing view	67
	8.3.4	Operating elements	. 69
	8.3.5	Opening the context menu	. 69
	8.3.6	Navigating and selecting from list	71
	837	Calling the parameter directly	71
	838	Calling up help text	72
	839	Changing the parameters	72
	0.J.J 8 3 10	User roles and related access	12
	0.9.10	authorization	73
	0211	Disphing write protection via access	ני
	0.5.11	bisability write protection via access	70
	0 2 1 2	Coue	15
	8.3.12	Enabling and disabiling the Reypad	7/
0 (	•		/4
8.4	Access	to the operating menu via the Web	
	browse	r	. /4
	8.4.1	Function range	74
	8.4.2	Prerequisites	. 75
	8.4.3	Establishing a connection	76
	8.4.4	Logging on	78
	8.4.5	User interface	79
	8.4.6	Disabling the Web server	. 80
	8.4.7	Logging out	. 80
8.5	Access	to the operating menu via the	
	operati	ng tool	81
	8.5.1	Connecting the operating tool	81
	8.5.2	Field Xpert SFX350. SFX370	84
	8.5.3	FieldCare	84
	8.5.4	DeviceCare	85
	855	AMS Device Manager	86
	856	Field Communicator 475	86
	0.9.0		. 00
q	Suctor	m integration	87
<b>,</b>	Jyster		07
9.1	Overvie	ew of device description files	. 87
	9.1.1	Current version data for the device	. 87
	9.1.2	Operating tools	87
9.2	Cyclic d	lata transmission	87
	9.2.1	Block model	87
	9.2.2	Description of the modules	88
	9.2.3	Execution times	. 91
	9.2.4	Methods	92
10	Comn	nissioning	93
10 1	Functio	on check	93
10.1	Switchi	ing on the measuring device	93
10.2	Connor	ting via FieldCare	. )) 02
10.2 10 /	Sottine C	the operating language	75 00
10.4 10 r	Config	une operating language	• 75 • •
10.5		Defining the transmission	. 94
	10.5.1	Defining the tag name	. 95
	10.5.2	Setting the system units	95
	10.5.3	Selecting and setting the medium	98
	10.5.4	Configuring the analog inputs	100
	10.5.5	Displaying the I/O configuration	100
	10.5.6	Configuring the current input	101
	10.5.7	Configuring the status input	102

	10.5.8 10.5.9	Configuring the current output Configuring the pulse/frequency/	103
		switch output	106
	10.5.10	) Configuring the relay output	113
	10 5 11	Configuring the local display	115
	10.5.12	Configuring the low flow cut off	110
	10.5.13	Configuring the partial filled pipe	110
		detection	119
10.6	Advanc	ed settings	120
	10.6.1	Using the parameter to enter the	
		access code	121
	10.6.2	Calculated values	121
	10.6.3	Carrying out a sensor adjustment	122
	10.6.4	Configuring the totalizer	123
	10.6.5	Carrying out additional display	
		configurations	125
	1066	WI AN configuration	128
	10.0.0	Configuration management	120
	10.0.7	Using parameters for device	129
	10.0.0		120
10 7	<b>.</b>		130
10.7	Simulat	tion	132
10.8	Protect	ing settings from unauthorized access	134
	10.8.1	Write protection via access code	134
	10.8.2	Write protection via write protection	
		switch	136
	10.8.3	Write protection via block operation	137
11	Opera	tion	138
111	Reading	a the device locking status	138
11.1	Adjusti	ng the operating language	138
11.2 11 3	Adjusti	ng the operating language	138 138
11.2 11.3	Adjusti Configu	ng the operating language	138 138
11.2 11.3 11.4	Adjusti Configu Reading	ng the operating language nring the display g measured values	138 138 138
11.2 11.3 11.4	Adjusti Configu Reading 11.4.1	ng the operating language nring the display g measured values "Measured variables" submenu	138 138 138 138 139
11.2 11.3 11.4	Adjusti Configu Reading 11.4.1 11.4.2	ng the operating language uring the display g measured values "Measured variables" submenu "Totalizer" submenu	138 138 138 139 140
11.2 11.3 11.4	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3	ng the operating language	138 138 138 139 140 141
11.2 11.3 11.4	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4	ng the operating language	138 138 138 139 140 141 142
11.2 11.3 11.4	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptin conditio	ng the operating language	138 138 138 139 140 141 142 144
11.2 11.3 11.4 11.5 11.5	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptir conditio Perform	ng the operating language	138 138 138 139 140 141 142 144
11.2 11.3 11.4 11.5 11.6	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1	ng the operating language ng the display g measured values "Measured variables" submenu "Totalizer" submenu "Input values" submenu Output values ng the measuring device to the process ons hing a totalizer reset Function scope of the "Control	138 138 138 139 140 141 142 144 144
11.2 11.3 11.4 11.5 11.6	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1	ng the operating language ng the display g measured values "Measured variables" submenu "Totalizer" submenu "Input values" submenu Output values ng the measuring device to the process ons ning a totalizer reset Function scope of the "Control Totalizer" parameter	138 138 138 139 140 141 142 144 144
11.2 11.3 11.4 11.5 11.6	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1	ng the operating language ng the display g measured values "Measured variables" submenu "Totalizer" submenu "Input values" submenu Output values ng the measuring device to the process ons hing a totalizer reset Function scope of the "Control Totalizer" parameter Function scope of the "Reset all	138 138 138 139 140 141 142 144 144 144
11.2 11.3 11.4 11.5 11.6	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2	ng the operating language ng the display g measured values "Measured variables" submenu "Totalizer" submenu "Input values" submenu Output values ng the measuring device to the process ons Function scope of the "Control Totalizer" parameter Function scope of the "Reset all totalizers" parameter	138 138 138 139 140 141 142 144 144 144
11.2 11.3 11.4 11.5 11.6	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showim	ng the operating language	138 138 138 139 140 141 142 144 144 145 145
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin	ng the operating language ng the display g measured values "Measured variables" submenu "Totalizer" submenu "Input values" submenu Output values ng the measuring device to the process ons hing a totalizer reset Function scope of the "Control Totalizer" parameter Function scope of the "Reset all totalizers" parameter g data logging	138 138 138 139 140 141 142 144 144 145 145 145
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b> 12.1	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 145 149
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b> 12.1 12.2	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin Genera Diagno	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 145 149
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b> 12.1 12.2	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin Genera Diagno diodes	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 149 149 151
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b> 12.1 12.2	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> General Diagnos diodes 12.2.1	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 149 151 151
11.2 11.3 11.4 11.5 11.6 11.7 <b>12</b> 12.1 12.2	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> General Diagnos diodes 12.2.1 12.2.2	ng the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 149 151 151 151
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> </ul>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera Diagnos diodes 12.2.1 12.2.2 Diagnos	In the device foculing status sectors and the operating language	138 138 138 139 140 141 142 144 144 145 145 145 145 145 149 151 151 153 155
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> </ul>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera Diagnos 12.2.1 12.2.2 Diagnos 12.3.1	In the device foculing status	138 138 138 139 140 141 142 144 144 145 145 145 145 145 145 149 151 151 153 155 155
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> </ul>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera Diagnos 12.2.1 12.2.2 Diagnos 12.3.1 12.3.2	In the device focusing status	138 138 138 139 140 141 142 144 144 145 145 145 145 145 145 149 151 151 151 155 155 155
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> <li>12.4</li> </ul>	Adjusti Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera Diagnos diodes 12.2.1 12.2.2 Diagnos	<pre>ng the device totaling status</pre>	138 138 138 139 140 141 142 144 144 145 145 145 145 145 145 149 151 151 151 155 155 157 157
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> <li>12.4</li> </ul>	Adjusti: Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptin conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera Diagnos diodes 12.2.1 12.2.2 Diagnos 12.3.1 12.3.2 Diagnos	<pre>ng the device totaling status</pre>	138 138 138 139 140 141 142 144 145 145 145 145 145 145 149 151 151 151 155 155 157 157
<ul> <li>11.2</li> <li>11.3</li> <li>11.4</li> <li>11.5</li> <li>11.6</li> <li>11.7</li> <li>12.1</li> <li>12.2</li> <li>12.3</li> <li>12.4</li> </ul>	Adjusti: Configu Reading 11.4.1 11.4.2 11.4.3 11.4.4 Adaptir conditio Perform 11.6.1 11.6.2 Showin <b>Diagn</b> Genera: Diagnos diodes 12.2.1 12.2.2 Diagnos 12.3.1 12.3.2 Diagnos 12.4.1 12.4.2	<pre>ng the device totaling status</pre>	138 138 138 139 140 141 142 144 145 145 145 145 145 145 145 149 151 151 155 155 157 157

DeviceCare       158         12.5.1       Diagnostic options       158         12.5.2       Calling up remedy information       159         12.6       Adapting the diagnostic information       160         12.6.2       Adapting the status signal       160         12.6.2       Diagnostic of sensor       167         12.7.3       Diagnostic of process       180         12.8       Pending diagnostic events       185         12.9       Diagnostic messages in the DIAGNOSTIC       187         12.10       Diagnostic list       186         12.11       Event l
12.5.1Diagnostic options13812.5.2Calling up remedy information15912.6Adapting the diagnostic information16012.6.1Adapting the status signal16012.6.2Adapting the status signal16012.7Overview of diagnostic information16412.7.1Diagnostic of sensor16512.7.2Diagnostic of electronic16712.7.3Diagnostic of configuration17312.7.4Diagnostic of process18012.8Pending diagnostic events18512.9Diagnostic messages in the DIAGNOSTICTransducer Block18612.10Diagnostic list18612.11Event logbook18712.11.1Reading out the event logbook18712.12.2Filtering the event logbook18812.12Filtering the event logbook18812.12.1Function scope of the "Restart"18912.12.2Function scope of the "Service reset"19012.13Device information19012.14Firmware history19213Maintenance19313.1Exterior cleaning19313.2Measuring and test equipment19313.3Endress+Hauser services19314Repair19414.1Repair and conversion concept194
12.6       Adapting the diagnostic information 160         12.6.1       Adapting the diagnostic behavior 160         12.6.2       Adapting the status signal 160         12.7       Overview of diagnostic information 164         12.7.1       Diagnostic of sensor 165         12.7.2       Diagnostic of sensor
12.6.1       Adapting the diagnostic behavior       160         12.6.2       Adapting the status signal
12.6.2 Adapting the status signal 160         12.7 Overview of diagnostic information 164         12.7.1 Diagnostic of sensor 165         12.7.2 Diagnostic of electronic 167         12.7.3 Diagnostic of configuration
12.7       Overview of diagnostic information       164         12.7.1       Diagnostic of sensor       165         12.7.2       Diagnostic of electronic       167         12.7.3       Diagnostic of process       180         12.8       Pending diagnostic events       185         12.9       Diagnostic messages in the DIAGNOSTIC       186         12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       188         12.11.2       Filtering the event logbook       188         12.12.1       Function scope of the "Restart"       189         12.12.1       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       Repair       193         13.5       Endress+Hauser services
12.7.1       Diagnostic of sensor       103         12.7.2       Diagnostic of electronic       167         12.7.3       Diagnostic of configuration       173         12.7.4       Diagnostic of process       180         12.8       Pending diagnostic events       185         12.9       Diagnostic messages in the DIAGNOSTIC       186         12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       188         12.12       Filtering the event logbook       188         12.12.1       Function scope of the "Restart"       189         12.12.1       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       General notes       194         14.1       General notes       194<
12.7.3       Diagnostic of configuration       173         12.7.4       Diagnostic of process       180         12.8       Pending diagnostic events       185         12.9       Diagnostic messages in the DIAGNOSTIC       186         12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       188         12.12.1       Function growth of information events       188         12.12.1       Function scope of the "Restart"       189         12.12.2       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         14       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.7.4 Diagnostic of process       180         12.8 Pending diagnostic events       185         12.9 Diagnostic messages in the DIAGNOSTIC       186         12.10 Diagnostic list       186         12.11 Event logbook       187         12.12.11.1 Reading out the event logbook       187         12.11.2 Filtering the event logbook       188         12.12.1 Function scope of the "Restart"       189         12.12.2 Function scope of the "Service reset"       190         12.13 Device information       190         12.14 Firmware history       192         13 Maintenance tasks       193         13.1 Maintenance tasks       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 Repair and conversion concept       194
12.8       Pending diagnostic events       185         12.9       Diagnostic messages in the DIAGNOSTIC       186         12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       187         12.11.2       Filtering the event logbook       188         12.11.3       Overview of information events       188         12.12       Resetting the measuring device       189         12.12.1       Function scope of the "Restart"       parameter         parameter       190       12.12         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.9       Diagnostic messages in the DIAGNOSTIC         Transducer Block       186         12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       187         12.11.2       Filtering the event logbook       188         12.11.3       Overview of information events       188         12.12       Resetting the measuring device       189         12.12.1       Function scope of the "Restart"       189         12.12.2       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.10       Diagnostic list       186         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       188         12.12.1       Function scope of the "Restart"       189         12.12.1       Function scope of the "Service reset"       189         12.12.2       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.11       Event logbook       187         12.11       Event logbook       187         12.11.1       Reading out the event logbook       187         12.11.2       Filtering the event logbook       187         12.11.2       Filtering the event logbook       188         12.11.2       Filtering the event logbook       188         12.11.3       Overview of information events       188         12.12       Resetting the measuring device       189         12.12.1       Function scope of the "Restart"       189         12.12.2       Function scope of the "Service reset"       190         12.12.2       Function scope of the "Service reset"       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         13.4       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.11.1 Reading out the event logbook       187         12.11.2 Filtering the event logbook       188         12.11.3 Overview of information events       188         12.12 Resetting the measuring device       189         12.12.1 Function scope of the "Restart"       189         12.12.2 Function scope of the "Service reset"       190         12.13 Device information       190         12.14 Firmware history       192         13 Maintenance       193         13.1 Maintenance tasks       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 General notes       194
12.11.2 Filtering the event logbook       188         12.11.3 Overview of information events       188         12.12 Resetting the measuring device       189         12.12.1 Function scope of the "Restart"       189         12.12.2 Function scope of the "Service reset"       189         12.12.2 Function scope of the "Service reset"       190         12.13 Device information       190         12.14 Firmware history       192         13 Maintenance       193         13.1 Maintenance tasks       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 General notes       194
12.11.3 Overview of information events 188         12.12 Resetting the measuring device
12.12       Resetting the measuring device
12.112.11 unition scope of the 'Restart'         parameter         12.12.2 Function scope of the "Service reset"         parameter         190         12.13 Device information         190         12.14 Firmware history         191         13 Maintenance         192         13 Maintenance tasks         193         13.1 Maintenance tasks         193         13.1 Exterior cleaning         193         13.2 Measuring and test equipment         193         13.3 Endress+Hauser services         193         14 Repair       194         14.1 General notes       194         14.1.1 Repair and conversion concept       194
12.12.2 Function scope of the "Service reset"         parameter       190         12.13 Device information       190         12.14 Firmware history       192         13 Maintenance       193         13.1 Maintenance tasks       193         13.1 Exterior cleaning       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 General notes       194         14.1.1 Repair and conversion concept       194
parameter       190         12.13       Device information       190         12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.1       Exterior cleaning       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         14       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
12.13 Device information       190         12.14 Firmware history       192         13 Maintenance       193         13.1 Maintenance tasks       193         13.1 Maintenance tasks       193         13.1 Exterior cleaning       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 General notes       194         14.1.1 Repair and conversion concept       194
12.14       Firmware history       192         13       Maintenance       193         13.1       Maintenance tasks       193         13.1.1       Exterior cleaning       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         14       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
13       Maintenance       193         13.1       Maintenance tasks       193         13.1       Exterior cleaning       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         14       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
13.1       Maintenance tasks       193         13.1.1       Exterior cleaning       193         13.2       Measuring and test equipment       193         13.3       Endress+Hauser services       193         14       Repair       194         14.1       General notes       194         14.1.1       Repair and conversion concept       194
13.1.1 Exterior cleaning       193         13.2 Measuring and test equipment       193         13.3 Endress+Hauser services       193         14 Repair       194         14.1 General notes       194         14.1.1 Repair and conversion concept       194
13.2       Measuring and test equipment
13.5       Endress (nadser services
14         Repair         194           14.1         General notes         194           14.1.1         Repair and conversion concept         194
14.1         General notes         194           14.1.1         Repair and conversion concept         194
14.1.1 Repair and conversion concept 194
1/12 Notes for more in an 1 and 10/
14.1.2 Notes for repair and conversion 194
14.3 Endress+Hauser services
14.4 Return 194
14.5 Disposal 195
14.5.1 Removing the measuring device 195
14.5.2 Disposing of the measuring device 195
15 Accessories 196
15.1 Device-specific accessories 196
15.1.1 For the transmitter 196
15.1.2 For the sensor
15.3 Service-specific accessories
15.4 System components 198
16 Technical data 199
16         Technical data         199           16.1         Application         199

16.3       Input       200         16.4       Output       203         16.5       Power supply       208         16.6       Performance characteristics       210         16.7       Installation       213         16.8       Environment       214         16.9       Process       215         16.10       Mechanical construction       217         16.11       Human interface       220         16.12       Certificates and approvals       224         16.13       Application packages       226         16.14       Accessories       227         16.15       Supplementary documentation       228
---

Index..... 230

# 1 About this document

# 1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

# 1.2 Symbols

#### 1.2.1 Safety symbols

#### **DANGER**

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

#### A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

#### **A** CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

#### NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

## 1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
$\sim$	Alternating current
$\sim$	Direct current and alternating current
<u> </u>	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	<b>Protective Earth (PE)</b> A terminal which must be connected to ground prior to establishing any other connections.
	<ul><li>The ground terminals are situated inside and outside the device:</li><li>Inner ground terminal: Connects the protectiv earth to the mains supply.</li><li>Outer ground terminal: Connects the device to the plant grounding system.</li></ul>

## 1.2.3 Communication symbols

Symbol	Meaning
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
	LED Light emitting diode is off.

Symbol	Meaning
	LED Light emitting diode is on.
	LED Light emitting diode is flashing.

# 1.2.4 Tool symbols

Symbol	Meaning
	Torx screwdriver
•	Phillips head screwdriver
Ŕ	Open-ended wrench

# 1.2.5 Symbols for certain types of information

Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.
×	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
i	<b>Tip</b> Indicates additional information.
	Reference to documentation.
	Reference to page.
	Reference to graphic.
►	Notice or individual step to be observed.
1., 2., 3	Series of steps.
4	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

# **1.2.6** Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
X	Safe area (non-hazardous area)
≈➡	Flow direction

# 1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Detailed list of the individual documents along with the documentation code  $\rightarrow \cong 228$ 

### 1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	<b>Planning aid for your device</b> The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	<ul> <li>Guides you quickly to the 1st measured value - Part 1</li> <li>The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.</li> <li>Incoming acceptance and product identification</li> <li>Storage and transport</li> </ul>
	Installation
Transmitter Brief Operating Instructions	<b>Guides you quickly to the 1st measured value - Part 2</b> The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).
	<ul> <li>Product description</li> <li>Installation</li> <li>Electrical connection</li> <li>Operation options</li> <li>System integration</li> <li>Commissioning</li> <li>Diagnostic information</li> </ul>
Description of Device Parameters	<b>Reference for your parameters</b> The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

## 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

# 1.4 Registered trademarks

#### **FOUNDATION™** Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

#### TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

# 2 Safety instructions

# 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ► Follow the instructions in this manual.

# 2.2 Designated use

#### Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified pressure and temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation → 
   8.
- Protect the measuring device permanently against corrosion from environmental influences.

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### **WARNING**

#### Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ► Verify the compatibility of the process fluid with the sensor material.
- Ensure the resistance of all fluid-wetted materials in the process.
- Keep within the specified pressure and temperature range.

#### NOTICE

#### Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### **Residual risks**

#### **WARNING**

# The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

#### **WARNING**

#### Danger of housing breaking due to measuring tube breakage!

If a measuring tube ruptures, the pressure inside the sensor housing will rise according to the operating process pressure.

► Use a rupture disk.

#### **WARNING**

#### Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

• Take precautions to prevent injury and material damage if the rupture disk is actuated.

# 2.3 Workplace safety

For work on and with the device:

 Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

• Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

• Due to the increased risk of electric shock, gloves must be worn.

# 2.4 Operational safety

Risk of injury.

- Operate the device in proper technical condition and fail-safe condition only.
- The operator is responsible for interference-free operation of the device.

#### Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

#### Repair

To ensure continued operational safety and reliability,

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to repair of an electrical device.
- Use original spare parts and accessories from Endress+Hauser only.

# 2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

# 2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

# 2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \square 12$	Not enabled.	On an individual basis following risk assessment.
Access code (also applies for Web server login or FieldCare connection) $\rightarrow \bigoplus 13$	Not enabled (0000).	Assign a customized access code during commissioning.
WLAN (order option in display module)	Enabled.	On an individual basis following risk assessment.
WLAN security mode	Enabled (WPA2- PSK)	Do not change.
WLAN passphrase (password) → 🗎 13	Serial number	Assign an individual WLAN passphrase during commissioning.
WLAN mode	Access Point	On an individual basis following risk assessment.
Web server → 🗎 13	Enabled.	On an individual basis following risk assessment.
CDI-RJ45 service interface	-	On an individual basis following risk assessment.

# 2.7.1 Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered  $\rightarrow \square$  136.

## 2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

User-specific access code

Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.

- WLAN passphrase The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode
   When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

#### User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ( $\rightarrow \square$  134).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

#### WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface ( $\Rightarrow \boxtimes 82$ ), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter ( $\rightarrow \square$  128).

#### Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

#### General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, see the "Write protection via access code" section → 
   <sup>1</sup> 134

#### 2.7.3 Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server ( $\rightarrow \square 74$ ). The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

For detailed information on device parameters, see: The "Description of Device Parameters" document  $\rightarrow \cong 228$ .

# **3** Product description

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

# 3.1 Product design

Two versions of the transmitter are available.

### 3.1.1 Proline 500 – digital

Signal transmission: digital

Order code for "Integrated ISEM electronics", option A "Sensor"

For use in applications not required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the sensor, the device is ideal: For simple transmitter replacement.

- A standard cable can be used as the connecting cable.
- Not sensitive to external EMC interference.



■ 1 Important components of a measuring device

- *1 Electronics compartment cover*
- 2 Display module
- 3 Transmitter housing
- 4 Sensor connection housing with integrated ISEM electronics: connecting cable connection
- 5 Sensor

### 3.1.2 Proline 500

Signal transmission: analog Order code for "Integrated ISEM electronics", option **B** "Transmitter"

For use in applications required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the transmitter, the device is ideal in the event of:

- Strong vibrations at the sensor.
- Sensor operation in underground installations.
- Permanent sensor immersion in water.



- Important components of a measuring device
- 1 Connection compartment cover
- 2 Display module
- *3* Transmitter housing with integrated ISEM electronics
- 4 Electronics compartment cover
- 5 Sensor
- 6 Sensor connection housing: connecting cable connection
- 7 Connection compartment cover: connecting cable connection

# 4 Incoming acceptance and product identification

# 4.1 Incoming acceptance



# 4.2 Product identification

The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in the *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the device is displayed.
- Enter the serial number from nameplates in the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate using the *Endress+Hauser Operations App*: All information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer*: enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

#### 4.2.1 Transmitter nameplate

#### Proline 500 – digital



*Example of a transmitter nameplate*

- *1 Name of the transmitter*
- 2 Manufacturing location
- 3 Space for approvals: use in hazardous areas
- 4 Degree of protection
- 5 Electrical connection data: available inputs and outputs
- 6 Permitted ambient temperature  $(T_a)$
- 7 2-D matrix code
- 8 Space for approvals and certificates: e.g. CE mark, C-Tick
- 9 Permitted temperature range for cable
- 10 Manufacturing date: year-month
- 11 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 12 Document number of safety-related supplementary documentation
- 13 Space for additional information in the case of special products
- 14 Available inputs and outputs, supply voltage
- 15 Electrical connection data: supply voltage
- 16 Extended order code (ext. ord. cd.)
- 17 Serial number (ser. no.)
- 18 Order code

#### Proline 500



#### E 4 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Manufacturing date: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, C-Tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature  $(T_a)$
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

#### 4.2.2 Sensor nameplate



E 5 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of the sensor; flange nominal diameter/nominal pressure; sensor test pressure; medium temperature range; material of measuring tube and manifold; sensor-specific information: e.g. pressure range of sensor housing, wide-range density specification (special density calibration)
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Flow direction
- 9 Manufacturing date: year-month
- 10 2-D matrix code
- 11 Document number of safety-related supplementary documentation
- 12 CE mark, C-Tick
- 13 Surface roughness
- 14 Permitted ambient temperature  $(T_a)$



#### he monguring device is re-

The measuring device is reordered using the order code.

#### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	<b>Reference to documentation</b> Refers to the corresponding device documentation.
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.

# 4.2.3 Symbols on measuring device

# 5 Storage and transport

# 5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ► Do not store outdoors.

Storage temperature  $\rightarrow \cong 214$ 

# 5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

## 5.2.1 Measuring devices without lifting lugs

#### **WARNING**

# Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- Observe the weight specified on the packaging (stick-on label).



Endress+Hauser

### 5.2.2 Measuring devices with lifting lugs

### 

#### Special transportation instructions for devices with lifting lugs

- Only use the lifting lugs fitted on the device or flanges to transport the device.
- The device must always be secured at two lifting lugs at least.

### 5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

# 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:

- Outer packaging of device
- Polymer stretch wrap that complies with EU Directive 2002/95/EC (RoHS)
- Packaging
  - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
  - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Filler material Paper pads

# 6 Installation

# 6.1 Installation conditions

## 6.1.1 Mounting position

#### Mounting location



To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

#### Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



🛃 6 Installation in a down pipe (e.g. for batching applications)

- Supply tank 1
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve 5
- Batching tank

DN		Ø orifice plate, pipe restriction	
[mm]	[in]	[mm]	[in]
80	3	50	1.97
100	4	65	2.60
150	6	90	3.54
250	10	150	5.91

#### Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orientation			Recommendation
A	Vertical orientation		<b>√ √</b> <sup>1)</sup>
		A0015591	
В	Horizontal orientation, transmitter at top		$\mathbf{\nabla} \mathbf{\nabla}^{2}$ Exceptions: $\rightarrow \mathbf{\overline{C}}$ 7, $\mathbf{\widehat{E}}$ 24
		A0015589	

Orientation			Recommendation
С	Horizontal orientation, transmitter at bottom	A0015590	<b>⊠ ⊠</b> <sup>3)</sup> Exceptions: → <b>⊡</b> 7, <b>≌</b> 24
D	Horizontal orientation, transmitter at side	A0015592	×

- 1) This orientation is recommended to ensure self-draining.
- 2) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 3) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.



☑ 7 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.
- 2 Avoid this orientation for outgassing fluids: Risk of gas accumulating.

#### Inlet and outlet runs

No special precautions need to be taken for fittings that create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs  $\rightarrow \cong 25$ .



#### Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .

#### 6.1.2 Environmental and process requirements

#### Ambient temperature range

Measuring device	<ul> <li>-40 to +60 °C (-40 to +140 °F)</li> <li>Order code for "Test, certificate", option JP: -50 to +60 °C (-58 to +140 °F)</li> </ul>
Readability of the local	-20 to $+60$ °C ( $-4$ to $+140$ °F)
display	The readability of the display may be impaired at temperatures outside the temperature range.

Dependency of ambient temperature on medium temperature  $\rightarrow$  🖺 215

► If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.

You can order a weather protection cover from Endress+Hauser.  $\rightarrow \square$  196.

#### System pressure

It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- Ensure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



#### Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.

The following device versions are recommended for versions with thermal insulation: Version with extended neck:

Order code for "Measuring tube material", option FA with an extended neck length of 105 mm (4.13 in).

### NOTICE

#### Electronics overheating on account of thermal insulation!

- Recommended orientation: horizontal orientation, sensor connection housing pointing downwards.
- Do not insulate the sensor connection housing.
- Maximum permissible temperature at the lower end of the sensor connection housing: 80 °C (176 °F)
- Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.



8 Thermal insulation with extended neck free

#### Heating

#### NOTICE

#### Electronics can overheat due to elevated ambient temperature!

- ► Observe maximum permitted ambient temperature for the transmitter .
- Depending on the fluid temperature, take the device orientation requirements into account .

#### NOTICE

#### Danger of overheating when heating

- ► Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- Ensure that sufficient convection takes place at the transmitter neck.
- Ensure that a sufficiently large area of the transmitter neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.
- ► When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

#### Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

#### Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

#### 6.1.3 Special mounting instructions

#### Drainability

The measuring tubes can be completely drained and protected against solids build-up in vertical orientation.

#### Sanitary compatibility

When installing in hygienic applications, please refer to the information in the "Certificates and approvals/hygienic compatibility" section

#### Rupture disk

Information that is relevant to the process:  $\rightarrow \cong 217$ .

#### **WARNING**

#### Danger from medium escaping!

Medium escaping under pressure can cause injury or material damage.

- Take precautions to prevent danger to persons and damage if the rupture disk is actuated.
- Observe information on the rupture disk sticker.
- Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- Do not use a heating jacket.
- Do not remove or damage the rupture disk.

The position of the rupture disk is indicated by a sticker beside it.

The transportation guard must be removed.

The existing connecting nozzles are not intended for the purpose of rinsing or pressure monitoring, but instead serve as the mounting location for the rupture disk.

In the event of a failure of the rupture disk, a drain device can be screwed onto the female thread of the rupture disk in order to drain off any escaping medium.



1 Rupture disk label

- 2 Rupture disk with 1/2" NPT female thread and 1" width across flat
- 3 Transportation guard



For information on the dimensions: see the "Mechanical construction" section of the "Technical Information" document

#### Zero point adjustment

All measuring devices are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions  $\rightarrow \textcircled{B} 210$ . Therefore, a zero point adjustment in the field is generally not required.

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).



#### **Protective cover**

9 Protective cover for Proline 500 – digital; engineering unit mm (in)



☑ 10 Protective cover for Proline 500; engineering unit mm (in)

#### Cover locking: Proline 500

#### NOTICE

Order code for "Transmitter housing", option L "Cast, stainless": The covers of the transmitter housing are provided with a borehole to lock the cover.

The cover can be locked using screws and a chain or cable provided by the customer.

- It is recommended to use stainless steel cables or chains.
- ► If a protective coating is applied, it is recommended to use a heat shrink tube to protect the housing paint.



*1 Cover borehole for the securing screw* 

2 Securing screw to lock the cover

# 6.2 Mounting the measuring device

#### 6.2.1 Required tools

#### For transmitter

For mounting on a post:

- Proline 500 digital transmitter
  - Open-ended wrench AF 10
- Torx screwdriver TX 25
- Proline 500 transmitter
   Open-ended wrench AF 13

For wall mounting: Drill with drill bit Ø 6.0 mm

#### For sensor

For flanges and other process connections: Corresponding mounting tools

#### 6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.

- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

#### 6.2.3 Mounting the measuring device

#### **WARNING**

#### Danger due to improper process sealing!

- Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- Ensure that the seals are clean and undamaged.
- Secure the seals correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.

2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



### 6.2.4 Mounting the transmitter housing: Proline 500 – digital

#### **A**CAUTION

#### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ► Do not exceed the permitted maximum ambient temperature .
- If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

#### **A**CAUTION

#### Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

#### Post mounting

#### **WARNING**

#### Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)



I1 Engineering unit mm (in)

#### Wall mounting



■ 12 Engineering unit mm (in)

L Depends on order code for "Transmitter housing"

Order code for "Transmitter housing"

- Option **A**, aluminum coated: L =14 mm (0.55 in)
- Option **D**, polycarbonate: L = 13 mm (0.51 in)

1. Drill the holes.

- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the securing screws slightly at first.
- 4. Fit the transmitter housing over the securing screws and mount in place.
- 5. Tighten the securing screws.

#### 6.2.5 Mounting the transmitter housing: Proline 500

#### **A**CAUTION

#### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- $\blacktriangleright~$  Do not exceed the permitted maximum ambient temperature .
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

#### 

#### Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

#### Wall mounting



Engineering unit mm (in)

- 1. Drill the holes.
- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the securing screws slightly at first.
- 4. Fit the transmitter housing over the securing screws and mount in place.
- 5. Tighten the securing screws.

#### Post mounting

#### **WARNING**

# Order code for "Transmitter housing", option L "Cast, stainless": cast transmitters are very heavy.

They are unstable if they are not mounted on a secure, fixed post.

• Only mount the transmitter on a secure, fixed post on a stable surface.



■ 14 Engineering unit mm (in)

#### 6.2.6 Turning the transmitter housing: Proline 500

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- **1.** Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.

3. Release the fixing screw.

- 4. Turn the housing to the desired position.
- 5. Firmly tighten the securing screw.
- 6. Screw on the connection compartment cover.

**7.** Depending on the device version: Attach the securing clamp of the connection compartment cover.

#### 6.2.7 Turning the display module: Proline 500

The display module can be turned to optimize display readability and operability.



- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Turn the display module to the desired position: max.  $8 \times 45^{\circ}$  in each direction.
- 4. Screw on the connection compartment cover.
- **5.** Depending on the device version: Attach the securing clamp of the connection compartment cover.

# 6.3 Post-installation check

Is the device undamaged (visual inspection)?	
<ul> <li>Does the measuring device conform to the measuring point specifications?</li> <li>For example:</li> <li>Process temperature →  <sup>(1)</sup> 215</li> <li>Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)</li> <li>Ambient temperature</li> <li>Measuring range</li> </ul>	
Has the correct orientation for the sensor been selected ? <ul> <li>According to sensor type</li> <li>According to medium temperature</li> <li>According to medium properties (outgassing, with entrained solids)</li> </ul>	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping $\rightarrow \bigoplus 23$ ?	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

# **Electrical connection**

#### NOTICE

7

#### The measuring device does not have an internal circuit breaker.

- ► For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- ► Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 10 A) should be integrated into the system installation.

# 7.1 Connection conditions

#### 7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver  $\leq$  3 mm (0.12 in)

### 7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

#### **Electrical safety**

In accordance with applicable federal/national regulations.

#### Protective ground cable

Cable  $\geq 2.08 \text{ mm}^2$  (14 AWG)

The grounding impedance must be less than  $1 \Omega$ .

#### Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

#### Power supply cable

Standard installation cable is sufficient.

#### Signal cable

#### FOUNDATION Fieldbus

Twisted, shielded two-wire cable.

For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

#### Cable diameter

- Cable glands supplied: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm<sup>2</sup> (24 to 12 AWG).

#### Choice of connecting cable between the transmitter and sensor

Depends on the type of transmitter and the installation zones



- 1 Proline 500 digital transmitter
- 2 Proline 500 transmitter
- 3 Sensor Promass
- 4 Non-hazardous area
- 5 Hazardous area: Zone 2; Class I, Division 2
- 6 Hazardous area: Zone 1; Class I, Division 1
- A Standard cable to 500 digital transmitter → 🗎 37 Transmitter installed in the non-hazardous area or hazardous area: Zone 2; Class I, Division 2 / sensor installed in the hazardous area: Zone 2; Class I, Division 2
- B Standard cable to 500 digital transmitter → 
   B 37 Transmitter installed in the hazardous area: Zone 2; Class I, Division 2 / sensor installed in the hazardous area: Zone 1; Class I, Division 1
- C Signal cable to 500 transmitter → 🗎 39 Transmitter and sensor installed in the hazardous area: Zone 2; Class I, Division 2 oder Zone 1; Class I, Division 1
# A: Connecting cable between sensor and transmitter: Proline 500 – digital Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4 cores (2 pairs); uninsulated stranded CU wires; pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover $\ge$ 85 %
Loop resistance	Power supply line (+, –): maximum 10 $\Omega$
Cable length	Maximum 300 m (1000 ft), see the following table.

Cross-section	Cable length [max.]
0.34 mm <sup>2</sup> (AWG 22)	80 m (270 ft)
0.50 mm <sup>2</sup> (AWG 20)	120 m (400 ft)
0.75 mm <sup>2</sup> (AWG 18)	180 m (600 ft)
1.00 mm <sup>2</sup> (AWG 17)	240 m (800 ft)
1.50 mm <sup>2</sup> (AWG 15)	300 m (1000 ft)

#### Optionally available connecting cable

Design	$2 \times 2 \times 0.34$ mm <sup>2</sup> (AWG 22) PVC cable <sup>1)</sup> with common shield (2 pairs, uninsulated stranded CU wires; pair-stranded)
Flame resistance	According to DIN EN 60332-1-2
Oil-resistance	According to DIN EN 60811-2-1
Shielding	Tin-plated copper-braid, optical cover $\ge 85 \%$
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)
Available cable length	Fixed: 20 m (65 ft); variable: up to maximum 50 m (165 ft)

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

# *B:* Connecting cable between sensor and transmitter: Proline 500 - digital Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4, 6, 8 cores (2, 3, 4 pairs); uninsulated stranded CU wires; pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover $\ge$ 85 %
Capacitance C	Maximum 760 nF IIC, maximum 4.2 µF IIB
Inductance L	Maximum 26 µH IIC, maximum 104 µH IIB
Inductance/resistance ratio (L/R)	Maximum 8.9 $\mu H/\Omega$ IIC, maximum 35.6 $\mu H/\Omega$ IIB (e.g. in accordance with IEC 60079-25)
Loop resistance	Power supply line (+, –): maximum 5 $\Omega$
Cable length	Maximum 150 m (500 ft), see the following table.

Cross-section	Cable length [max.]	Termination
$2 \times 2 \times 0.50 \text{ mm}^2$	50 m (165 ft)	2 x 2 x 0.50 mm <sup>2</sup> (AWG 20)
(AWU 20)		BN WT YE GN - - A B GY
		<ul> <li>+, - = 0.5 mm<sup>2</sup></li> <li>A, B = 0.5 mm<sup>2</sup></li> </ul>
3 x 2 x 0.50 mm <sup>2</sup> (AWG 20)	100 m (330 ft)	3 x 2 x 0.50 mm <sup>2</sup> (AWG 20)
		BN WT GY PK YE GN
		GY GY
		<ul> <li>+, - = 1.0 mm<sup>2</sup></li> <li>A, B = 0.5 mm<sup>2</sup></li> </ul>
4 x 2 x 0.50 mm <sup>2</sup> (AWG 20)	150 m (500 ft)	4 x 2 x 0.50 mm <sup>2</sup> (AWG 20)
		BN WT GY PK RD BU + - - - - - - - - - - - - - - - - - -
		<ul> <li>+, -= 1.5 mm<sup>2</sup></li> <li>A, B = 0.5 mm<sup>2</sup></li> </ul>

# *Optionally available connecting cable*

Connecting cable for	Zone 1; Class I, Division 1
Standard cable	$2\times2\times0.5~mm^2$ (AWG 20) PVC cable $^{1)}$ with common shield (2 pairs, pair-stranded)
Flame resistance	According to DIN EN 60332-1-2
Oil-resistance	According to DIN EN 60811-2-1
Shielding	Tin-plated copper-braid, optical cover $\ge$ 85 %
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)
Available cable length	Fixed: 20 m (65 ft); variable: up to maximum 50 m (165 ft)

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

Standard cable	$6 \times 0.38 \mbox{ mm}^2$ PVC cable $^{1)}$ with common shield and individually shielded cores
Conductor resistance	≤50 Ω/km (0.015 Ω/ft)
Capacitance: core/shield	<420 pF/m (128 pF/ft)
Cable length (max.)	20 m (65 ft)
Cable lengths (available for order)	5 m (15 ft), 10 m (32 ft), 20 m (65 ft)
Operating temperature	max. 105 °C (221 °F)

*C*: *Connecting cable between sensor and transmitter*: *Proline 500* 

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

# 7.1.3 Terminal assignment

#### Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply	voltage Input/output 1		Input/output 2		Input/output 3		Input/output 4		
1 (+)	2 (-)	26 (A)	27 (B)	24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)
		Device-specific terminal assignment: adhesive label in terminal cover.							

## Transmitter and sensor connection housing: connecting cable

The sensor and transmitter, which are mounted in separate locations, are interconnected by a connecting cable. The cable is connected via the sensor connection housing and the transmitter housing.

Terminal assignment and connection of the connecting cable:

- Proline 500 digital  $\rightarrow \cong 42$
- Proline 500  $\rightarrow \textcircled{1}{2}$  49

# 7.1.4 Device plugs available

Provice plugs may not be used in hazardous areas!

Order code for "Input; output 1", option SA "FOUNDATION Fieldbus"

Order code for	Cable entry/connection			
"Electrical connection"	2	3		
M, 3, 4, 5	7/8" connector	_		

# 7.1.5 Pin assignment of device plug

Pi	in	Assignment	Coding	Plug/socket
3 1	L +	Signal +	А	Plug
/ 4 2	2 -	Signal –		

3	Grounding
4	Not assigned

# 7.1.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 % is ideal.

- **1.** To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus guaranteed.

**1.** Observe national installation requirements and guidelines during installation.

2. Where there are large differences in potential between the individual grounding points,

connect only one point of the shielding directly to the reference ground.

3. In systems without potential equalization,

the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

## NOTICE

# In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- Insulate the shield that is not connected.



- 15 Connection example for FOUNDATION Fieldbus
- 1 Control system (e.g. PLC)
- 2 Power conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

# 7.1.7 Preparing the measuring device

Carry out the steps in the following order:

1. Mount the sensor and transmitter.

- 2. Connection housing, sensor: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

# NOTICE

#### Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.

# 7.2 Connecting the measuring device: Proline 500 - digital

# NOTICE

# Limitation of electrical safety due to incorrect connection!

- ► Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.

# 7.2.1 Connecting the connecting cable

# **WARNING**

## Risk of damaging the electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

#### Connecting cable terminal assignment



- 1 Cable entry for cable on transmitter housing
- 2 Protective earth (PE)
- 3 Connecting cable ISEM communication
- 4 Grounding via ground connection; on device plug versions grounding is through the plug itself
- 5 Cable entry for cable or connection of device plug on sensor connection housing
- 6 Protective earth (PE)

#### Connecting the connecting cable to the sensor connection housing

- Connection via terminals with order code for "Sensor connection housing":

  - Option **B** "Stainless"  $\rightarrow \square 44$
  - Option L "Cast, stainless"→ 🖺 43

## Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals  $\rightarrow \square$  46.

#### Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing":

- Option A "Aluminum coated"
- Option L "Cast, stainless"



- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- **3.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.

# **WARNING**

#### Housing degree of protection voided due to insufficient sealing of the housing.

- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- 9. Tighten the securing clamp of the housing cover.

## Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing": Option **B** "Stainless"



- 1. Release the securing screw of the housing cover.
- 2. Open the housing cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.
- 8. Close the housing cover.
- **9**. Tighten the securing screw of the housing cover.

### Connecting the sensor connection housing via the connector

For the device version with the order code for "Sensor connection housing": Option **C** "Ultra-compact hygienic, stainless"





2. Connect the connector.



#### Connecting the connecting cable to the transmitter

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- **7.** Connect the cable in accordance with the connecting cable terminal assignment  $\rightarrow \cong 42$ .
- 8. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.
- 9. Close the housing cover.
- **10.** Tighten the securing screw of the housing cover.
- **11.** After connecting the connecting cable: Connect the signal cable and the supply voltage cable  $\rightarrow \cong 47$ .

# 7.2.2 Connecting the signal cable and the supply voltage cable



- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output
- 4 Terminal connection for connecting cable between sensor and transmitter
- 5 Terminal connection for signal transmission, input/output; optional: connection for external WLAN antenna
- 6 Protective earth (PE)



- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 7. Connect the cable in accordance with the terminal assignment .
  - Signal cable terminal assignment: The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
     Supply voltage terminal assignment: Adhesive label in the terminal cover or → 
     ⇒ 39.
- 8. Firmly tighten the cable glands.
  - └ This concludes the cable connection process.
- 9. Close the terminal cover.
- **10.** Close the housing cover.

# **WARNING**

# Housing degree of protection may be voided due to insufficient sealing of the housing.

• Screw in the screw without using any lubricant.

## **WARNING**

# Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- ► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)
- **11.** Tighten the 4 fixing screws on the housing cover.

#### Removing a cable



#### E 16 Engineering unit mm (in)

- **1.** To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

# 7.3 Connecting the measuring device: Proline 500

# NOTICE

## Limitation of electrical safety due to incorrect connection!

- ► Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.

# 7.3.1 Connecting the connecting cable

## **WARNING**

#### Risk of damaging the electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

#### Connecting cable terminal assignment



- *1 Protective earth (PE)*
- 2 Cable entry for connecting cable on transmitter connection housing
- 3 Connecting cable
- 4 Cable entry for connecting cable on sensor connection housing
- 5 Protective earth (PE)

#### Connecting the connecting cable to the sensor connection housing

Connection via terminals with order code for "Housing":

- Option **B** "Stainless"  $\rightarrow$  🖺 51
- Option L "Cast, stainless"  $\rightarrow \square 50$

#### Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals  $\rightarrow \square 52$ .

## Connecting the sensor connection housing via terminals

For the device version with the order code for "Housing": Option **L** "Cast, stainless"



- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.

# **WARNING**

#### Housing degree of protection voided due to insufficient sealing of the housing.

- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- **9.** Tighten the securing clamp of the housing cover.

#### Connecting the sensor connection housing via terminals

For the device version with the order code for "Housing": Option  ${\bf B}$  "Stainless"



- 1. Release the securing screw of the housing cover.
- 2. Open the housing cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.
- 8. Close the housing cover.
- 9. Tighten the securing screw of the housing cover.



#### Connecting the connecting cable to the transmitter

- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment  $\rightarrow \cong 49$ .
- 7. Firmly tighten the cable glands.
  - └ This concludes the process for connecting the connecting cable.
- 8. Screw on the connection compartment cover.
- 9. Tighten the securing clamp of the connection compartment cover.
- **10.** After connecting the connecting cable: After connecting the connecting cables: Connect the signal cable and the supply voltage cable  $\rightarrow \cong 53$ .

# 7.3.2 Connecting the signal cable and the supply voltage cable



- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45)
- 4 Protective earth (PE)



- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.



- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.



- 7. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9. Connect the protective ground.



- **10.** Connect the cable in accordance with the terminal assignment .
- **11.** Firmly tighten the cable glands.
  - $\blacktriangleright$  This concludes the cable connection process.
- 12. Close the terminal cover.
- **13.** Fit the display module holder in the electronics compartment.
- **14.** Screw on the connection compartment cover.
- **15.** Secure the securing clamp of the connection compartment cover.

## Removing a cable



☑ 17 Engineering unit mm (in)

**1.** To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes

2. while simultaneously pulling the cable end out of the terminal.

# 7.4 Ensuring potential equalization

# 7.4.1 Requirements

No special measures for potential equalization are required.

# 7.5 Special connection instructions

# 7.5.1 Connection examples

# **FOUNDATION Fieldbus**



■ 18 Connection example for FOUNDATION Fieldbus

- 1 Control system (e.g. PLC)
- 2 Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line

# Current output 4-20 mA



■ 19 Connection example for 4-20 mA current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load
- 3 Transmitter



- 20 Connection example for 4-20 mA current output (passive)
- *1 Automation system with current input (e.g. PLC)*
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load
- 4 Transmitter

#### Pulse/frequency output



☑ 21 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \triangleq 204$

#### Switch output



■ 22 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \cong 204$

## Relay output



■ 23 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \cong 205$

#### **Current input**



■ 24 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- *3 External measuring device (to read in pressure or temperature, for instance)*
- 4 Transmitter

# Status input



■ 25 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter

# 7.6 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.

 To ensure that moisture does not enter the cable entry: Route the cable so that it loops down before the cable entry ("water trap").



6. Insert dummy plugs into unused cable entries.

# 7.7 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables used meet the requirements?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" $\rightarrow \square$ 59?	

# 8 Operation options



# 8.1 Overview of operation options

1 Local operation via display module

2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)

3 Field Xpert SFX350 or SFX370

4 Field Xpert SMT70

5 Mobile handheld terminal

6 Control system (e.g. PLC)

# 8.2 Structure and function of the operating menu

# 8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: "Description of Device Parameters" document supplied with the device  $\rightarrow \cong 228$ 



■ 26 Schematic structure of the operating menu

# 8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

For custody transfer, once the device has been put into circulation or sealed, its operation is restricted.

Menu/parameter		User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: • Configuring the operational	<ul><li>Defining the operating language</li><li>Defining the Web server operating language</li><li>Resetting and controlling totalizers</li></ul>
Operation		<ul> <li>Reading measured values</li> </ul>	<ul><li>Configuring the operational display (e.g. display format, display contrast)</li><li>Resetting and controlling totalizers</li></ul>
Setup		<ul> <li>"Maintenance" role</li> <li>Commissioning:</li> <li>Configuration of the measurement</li> <li>Configuration of the inputs and outputs</li> <li>Configuration of the communication interface</li> </ul>	<ul> <li>Wizards for fast commissioning:</li> <li>Setting the system units</li> <li>Configuration of the communication interface</li> <li>Defining the medium</li> <li>Displaying the I/O/configuration</li> <li>Configuring the inputs</li> <li>Configuring the outputs</li> <li>Configuration of the operational display</li> <li>Setting the low flow cut off</li> <li>Configuring partial and empty pipe detection</li> <li>Advanced setup</li> <li>For more customized configuration of the measurement (adaptation to special measuring conditions)</li> <li>Configuring the WLAN settings</li> <li>Administration (define access code, reset measuring device)</li> </ul>
Diagnostics		<ul> <li>"Maintenance" role</li> <li>Fault elimination:</li> <li>Diagnostics and elimination of process and device errors</li> <li>Measured value simulation</li> </ul>	<ul> <li>Contains all parameters for error detection and analyzing process and device errors:</li> <li>Diagnostic list Contains up to 5 currently pending diagnostic messages.</li> <li>Event logbook Contains event messages that have occurred.</li> <li>Device information Contains information for identifying the device.</li> <li>Measured values Contains all current measured values.</li> <li>Data logging submenu with "Extended HistoROM" order option Storage and visualization of measured values</li> <li>Heartbeat The functionality of the device is checked on demand and the verification results are documented.</li> <li>Simulation Is used to simulate measured values or output values.</li> </ul>

Menu/parameter		User role and tasks	Content/meaning
Expert	function-oriented	<ul> <li>Tasks that require detailed knowledge of the function of the device:</li> <li>Commissioning measurements under difficult conditions</li> <li>Optimal adaptation of the measurement to difficult conditions</li> <li>Detailed configuration of the communication interface</li> <li>Error diagnostics in difficult cases</li> </ul>	<ul> <li>Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:</li> <li>System Contains all higher-order device parameters which do not concern the measurement or the communication interface.</li> <li>Sensor Configuration of the measurement.</li> <li>Output Configure the pulse/frequency/switch output.</li> <li>Input Configuration of the status input.</li> <li>Output Configuration of the analog current outputs as well as the pulse/frequency and switch output.</li> <li>Communication Configuration of the digital communication interface and the Web server.</li> <li>Submenus for function blocks.</li> <li>Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer).</li> <li>Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.</li> </ul>

# 8.3 Access to the operating menu via the local display

# 8.3.1 Operational display



- 1 Operational display
- 2 Device tag
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements  $\rightarrow \square 69$

# Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🖺 155
  - F: Failure
  - C: Function check
  - S: Out of specification
  - M: Maintenance required
- Diagnostic behavior  $\rightarrow$  🗎 156
  - 🛛 🐼: Alarm
  - <u>M</u>: Warning
- 🛱: Locking (the device is locked via the hardware )
- 🖘: Communication (communication via remote operation is active)

## Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured values

Symbol	Meaning
'n	Mass flow
Ú	<ul><li>Volume flow</li><li>Corrected volume flow</li></ul>
ρ	<ul><li>Density</li><li>Reference density</li></ul>
4	Temperature
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.
Ð	Status input

#### Measurement channel numbers

Symbol	Meaning	
14	Measurement channel 1 to 4	
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).		

#### Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols  $\rightarrow \square 156$ 

The number and display format of the measured values can be configured via the **Format display** parameter ( $\rightarrow \cong 116$ ).

# 8.3.2 Navigation view



# Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



For more information about the icons in the menu, refer to the "Display area" section  $\rightarrow \cong 66$ 

## Status area

The following appears in the status area of the navigation view in the top right corner: • In the submenu

- The direct access code for the parameter you are navigating to (e.g. 0022-1)
- If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
- If a diagnostic event is present, the diagnostic behavior and status signal



• For information on the function and entry of the direct access code  $\rightarrow \square 71$ 

# Display area

## Menus

Symbol	Meaning
RA RA	Operation         Appears:         In the menu next to the "Operation" selection         At the left in the navigation path in the Operation menu
بر	Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
પ્	Diagnostics         Appears:         In the menu next to the "Diagnostics" selection         At the left in the navigation path in the Diagnostics menu
÷ <b>*</b>	Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
₩.	Wizard
Ø	Parameters within a wizard           Image: No display symbol exists for parameters in submenus.

# Locking

Symbol	Meaning
Ĥ	<ul><li>Parameter locked</li><li>When displayed in front of a parameter name, indicates that the parameter is locked.</li><li>By a user-specific access code</li><li>By the hardware write protection switch</li></ul>

# Wizard operation

Symbol	Meaning
-	Switches to the previous parameter.
$\checkmark$	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

#### 8.3.3 **Editing view**

#### Numeric editor



E 27 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 **Operating elements**

#### Text editor



🖻 28 For entering text in parameters (e.g. tag name)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 **Operating elements** 5
- Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

#### Using the operating elements in the editing view

Operating key(s)	Meaning
$\bigcirc$	Minus key Move the entry position to the left.
+	Plus key Move the entry position to the right.

Operating key(s)	Meaning
E	<ul><li>Enter key</li><li>Press the key briefly: confirm your selection.</li><li>Press the key for 2 s: confirm the entry.</li></ul>
-++	<b>Escape key combination (press keys simultaneously)</b> Close the editing view without accepting the changes.

# Input screens

Symbol	Meaning
A	Upper case
а	Lower case
1	Numbers
+*	Punctuation marks and special characters: = + – * / <sup>2</sup> <sup>3</sup> <sup>1</sup> / <sub>4</sub> <sup>1</sup> / <sub>2</sub> <sup>3</sup> / <sub>4</sub> ( ) [ ] < > { }
0	Punctuation marks and special characters: ' " ` ^. , ; : ? ! % $\mu$ ° $\in$ \$ £ ¥ § @ # / \ I ~ & _
ä	Umlauts and accents

# Controlling data entries

Symbol	Meaning
←→	Move entry position
X	Reject entry
4	Confirm entry
**	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

# 8.3.4 **Operating elements**

	Minus key
1	
Θ	<i>In a menu, submenu</i> Moves the selection bar upwards in a picklist.
	With a Wizard Confirms the parameter value and goes to the previous parameter.
	<i>With a text and numeric editor</i> Move the entry position to the left.
+	Plus key
	<i>In a menu, submenu</i> Moves the selection bar downwards in a picklist.
	<i>With a Wizard</i> Confirms the parameter value and goes to the next parameter.
	<i>With a text and numeric editor</i> Move the entry position to the right.
E	Enter key
	For operational display Pressing the key briefly opens the operating menu.
	<ul> <li>In a menu, submenu</li> <li>Pressing the key briefly:</li> <li>Opens the selected menu, submenu or parameter.</li> <li>Starts the wizard.</li> <li>If help text is open, closes the help text of the parameter.</li> <li>Pressing the key for 2 s for parameter:</li> </ul>
	If present, opens the help text for the function of the parameter. With a Wizard
	Opens the editing view of the parameter.
	<ul> <li>Press the key briefly: confirm your selection.</li> <li>Press the key for 2 s: confirm the entry.</li> </ul>
1	Escape key combination (press keys simultaneously)
(□+⊕	<ul> <li>In a menu, submenu</li> <li>Pressing the key briefly: <ul> <li>Exits the current menu level and takes you to the next higher level.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s returns you to the operational display ("home position").</li> </ul>
	<i>With a Wizard</i> Exits the wizard and takes you to the next higher level.
	With a text and numeric editor Close the editing view without accepting the changes.
	Minus/Enter key combination (press the keys simultaneously)
<b>()</b> + <b>(E)</b>	<ul> <li>If the keypad lock is active: Press the key for 3 s: deactivate the keypad lock.</li> <li>If the keypad lock is not active: Press the key for 3 s: the context menu opens along with the option for activating the keypad lock.</li> </ul>

# 8.3.5 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation

# Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the  $\Box$  and  $\blacksquare$  keys for longer than 3 seconds.
  - └ The context menu opens.



**2.** Press  $\Box$  +  $\pm$  simultaneously.

└ The context menu is closed and the operational display appears.

# Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press  $\pm$  to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
  - └ The selected menu opens.

# 8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements  $\rightarrow \cong 65$ 

Example: Setting the number of displayed measured values to "2 values"



# 8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

**Navigation path** Expert  $\rightarrow$  Direct access The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



<sup>1</sup> Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically. Example: Enter 00914 → Assign process variable parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.

Example: Enter  $00914\text{-}2 \rightarrow Assign \ process \ variable \ parameter$ 

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

# 8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

## Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

← The help text for the selected parameter opens.



29 Example: Help text for parameter "Enter access code"

- **2.** Press + + simultaneously.
  - └ The help text is closed.

# 8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.
Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

For a description of the editing view - consisting of the text editor and numeric editor - with symbols → 🗎 67, for a description of the operating elements → 🗎 69

#### 8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access  $\rightarrow \cong 134$ .

#### Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ► Define the access code.
  - └ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	<i>v</i>	✓ <sup>1)</sup>

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	1)

 Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

The user role with which the user is currently logged on is indicated by the **Access status** parameter. Navigation path: Operation → Access status

#### 8.3.11 Disabling write protection via access code

If the @-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation  $\Rightarrow @$  134.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ( $\rightarrow \square$  121) via the respective access option.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

→ The @-symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

### 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

#### Switching on the keypad lock

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

#### To activate the keylock manually:

1. The device is in the measured value display.

- Press the  $\boxdot$  and  $\blacksquare$  keys for 3 seconds.
- 2. In the context menu select the **Keylock on** option.
  - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

#### Switching off the keypad lock

- The keypad lock is switched on.
  - Press the  $\Box$  and  $\blacksquare$  keys for 3 seconds.
  - └ The keypad lock is switched off.

### 8.4 Access to the operating menu via the Web browser

#### 8.4.1 Function range

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device  $\rightarrow \cong 229$ 

#### 8.4.2 Prerequisites

### Computer hardware

Hardware	Interface		
	CDI-RJ45	WLAN	
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.	
Connection	Standard Ethernet cable with RJ45 connector.	Connection via Wireless LAN.	
Screen	Recommended size: ≥12" (depends on the screen resolution)		

#### Computer software

Software	Interface	
	CDI-RJ45	WLAN
Recommended operating systems	<ul> <li>Microsoft Windows 7 or higher.</li> <li>Mobile operating systems: <ul> <li>iOS</li> <li>Android</li> </ul> </li> <li>Microsoft Windows XP is supported</li> </ul>	
Web browsers supported	<ul> <li>Microsoft Internet Explorer 8 or higher</li> <li>Microsoft Edge</li> <li>Mozilla Firefox</li> <li>Google Chrome</li> <li>Safari</li> </ul>	

#### Computer settings

Settings	Interface		
	CDI-RJ45	WLAN	
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).		
Proxy server settings of the Web browser	The Web browser setting <i>Use a Proxy Server for Your LAN</i> must be <b>deselected</b> .		
JavaScript	JavaScript must be enabled.		
	If JavaScript cannot be enabled: enter http://192.168.1.212/basic.html in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.		
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under <b>Internet options</b> .		
Network connections	Only the active network connections to the measuring device should be used.		
	Switch off all other network connections such as WLAN.	Switch off all other network connections.	



In the event of connection problems:  $\rightarrow \cong 150$ 

#### Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface
Measuring device	The measuring device has an RJ45 interface.
Web server	Web server must be enabled; factory setting: ON <b>1</b> For information on enabling the Web server $\rightarrow \triangleq 80$

#### *Measuring device: via WLAN interface*

Device	WLAN interface	
Measuring device	<ul><li>The measuring device has a WLAN antenna:</li><li>Transmitter with integrated WLAN antenna</li><li>Transmitter with external WLAN antenna</li></ul>	
Web server	Web server and WLAN must be enabled; factory setting: ON For information on enabling the Web server →   80	

### 8.4.3 Establishing a connection

#### Via service interface (CDI-RJ45)

*Preparing the measuring device* 

Proline 500 – digital

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- **3.** The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 connector via the standard Ethernet connecting cable .

#### Proline 500

- Depending on the housing version: Release the securing clamp or securing screw of the housing cover.
- 2. Depending on the housing version: Unscrew or open the housing cover.
- The location of the connection socket depends on the measuring device and the communication protocol:
   Connect the computer to the RJ45 connector via the standard Ethernet connecting cable .

#### *Configuring the Internet protocol of the computer*

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- **2.** Connect to the computer using a cable  $\rightarrow \cong 81$ .
- 3. If a 2nd network card is not used, close all the applications on the notebook.
  - Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 $\rightarrow$ e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

#### Via WLAN interface

Configuring the Internet protocol of the mobile terminal

#### NOTICE

#### If the WLAN connection is lost during the configuration, settings made may be lost.

• Make sure that the WLAN connection is not disconnected while configuring the device.

#### NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

#### Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:

Select the measuring device using the SSID (e.g. EH\_Promass\_500\_A802000).

- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
  - The serial number can be found on the nameplate.
  - To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

#### Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

#### Starting the Web browser

1. Start the Web browser on the computer.

# 2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212

└ The login page appears.



- 1 Picture of device
- 2 Device name
- 3 Device tag
- 4 Status signal5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code ( $\rightarrow \square 131$ )

If a login page does not appear, or if the page is incomplete  $\rightarrow \cong 150$ 

### 8.4.4 Logging on

**1.** Select the preferred operating language for the Web browser.

- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code	0000 (factory setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

#### 8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

#### Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal  $\rightarrow \square 158$
- Current measured values

#### **Function** row

Functions	Meaning
Measured values	Displays the measured values of the measuring device
Menu	<ul> <li>Access to the operating menu from the measuring device</li> <li>The structure of the operating menu is the same as for the local display</li> <li>For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device</li> </ul>
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	<ul> <li>Data exchange between PC and measuring device:</li> <li>Device configuration:</li> <li>Load settings from the device (XML format, save configuration)</li> <li>Save settings to the device (XML format, restore configuration)</li> <li>Logbook - Export Event logbook (.csv file)</li> <li>Documents - Export documents:</li> <li>Export backup data record (.csv file, create documentation of the measuring point configuration)</li> <li>Verification report (PDF file, only available with the "Heartbeat Verification" application package)</li> <li>File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring device: FOUNDATION Fieldbus: DD file</li> <li>Firmware update - Flashing a firmware version</li> </ul>
Network configuration	<ul> <li>Configuration and checking of all the parameters required for establishing the connection to the measuring device:</li> <li>Network settings (e.g. IP address, MAC address)</li> <li>Device information (e.g. serial number, firmware version)</li> </ul>
Logout	End the operation and call up the login page

#### Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

#### Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

#### 8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

#### Navigation

"Expert" menu  $\rightarrow$  Communication  $\rightarrow$  Web server

#### Parameter overview with brief description

Parameter	Description	Selection
Web server functionality	Switch the Web server on and off.	<ul><li>Off</li><li>HTML Off</li><li>On</li></ul>

#### Function scope of the "Web server functionality" parameter

Option	Description
Off	<ul><li>The web server is completely disabled.</li><li>Port 80 is locked.</li></ul>
On	<ul> <li>The complete functionality of the web server is available.</li> <li>JavaScript is used.</li> <li>The password is transferred in an encrypted state.</li> <li>Any change to the password is also transferred in an encrypted state.</li> </ul>

#### Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

### 8.4.7 Logging out

Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.

- └ The home page with the Login box appears.
- 2. Close the Web browser.
- **3.** If no longer needed: Reset modified properties of the Internet protocol (TCP/IP)  $\rightarrow \square$  76.

### 8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

### 8.5.1 Connecting the operating tool

#### Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.



30 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring device

#### Service interface

*Via service interface (CDI-RJ45)* 

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.



An adapter for RJ45 and the M12 connector is optionally available: Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.

#### Proline 500 – digital transmitter



☑ 31 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Proline 500 transmitter



☑ 32 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)		
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)		
Configurable WLAN channels	1 to 11		
Degree of protection	IP67		
Available antennas	<ul> <li>Internal antenna</li> <li>External antenna (optional) In the event of poor transmission/reception conditions at the place of installation.</li> <li>Only one antenna active in each case!</li> </ul>		
Range	<ul> <li>Internal antenna: typically 10 m (32 ft)</li> <li>External antenna: typically 50 m (164 ft)</li> </ul>		
Materials (external antenna)	<ul> <li>Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel- plated brass</li> <li>Adapter: Stainless steel and nickel-plated brass</li> <li>Cable: Polyethylene</li> <li>Connector: Nickel-plated brass</li> <li>Angle bracket: Stainless steel</li> </ul>		

Configuring the Internet protocol of the mobile terminal

#### NOTICE

#### If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

### NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:

Select the measuring device using the SSID (e.g. EH\_Promass\_500\_A802000).

- 2. If necessary, select the WPA2 encryption method.
- **3.** Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
- The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

#### 8.5.2 Field Xpert SFX350, SFX370

#### **Function range**

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

#### Source for device description files

See information  $\rightarrow \cong 87$ 

#### 8.5.3 FieldCare

#### Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- CDI-RJ45 service interface  $\rightarrow \cong 81$
- WLAN interface  $\rightarrow \cong 82$

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

#### Source for device description files

See information  $\rightarrow \cong 87$ 

#### Establishing a connection

For additional information, see Operating Instructions BA00027S and BA00059S

#### User interface



- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal  $\rightarrow \square 158$
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

### 8.5.4 DeviceCare

#### Function scope

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure IN01047S

#### Source for device description files

See information  $\rightarrow$   $\blacksquare$  87

#### 8.5.5 **AMS Device Manager**

#### **Function scope**

Program from Emerson Process Management for operating and configuring measuring devices via FOUNDATION Fieldbus H1 protocol.

#### Source for device description files

See data  $\rightarrow \blacksquare 87$ 

#### 8.5.6 **Field Communicator 475**

#### **Function scope**

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via FOUNDATION Fieldbus H1 protocol.

#### Source for device description files

See data  $\rightarrow \cong 87$ 

# 9 System integration

## 9.1 Overview of device description files

### 9.1.1 Current version data for the device

Firmware version	01.00.zz	<ul> <li>On the title page of the Operating instructions</li> <li>On the transmitter nameplate</li> <li>Firmware version         Diagnostics → Device information → Firmware version     </li> </ul>
Release date of firmware version	02.2017	
Manufacturer ID	0x452B48 (hex)	Manufacturer ID Diagnostics → Device information → Manufacturer ID
Device type ID	0x103B (hex)	Device type Diagnostics → Device information → Device type
Device revision	1	<ul> <li>On the transmitter nameplate</li> <li>Device revision</li> <li>Diagnostics → Device information → Device revision</li> </ul>
DD revision	Information and files under: • www.endress.com • www.fieldbus.org	
CFF revision		

For an overview of the different firmware versions for the device  $\rightarrow$  🗎 192

### 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via FOUNDATION Fieldbus	Sources for obtaining device descriptions	
FieldCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>	
DeviceCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>	
<ul><li>Field Xpert SFX350</li><li>Field Xpert SFX370</li></ul>	Use update function of handheld terminal	
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area	
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal	

## 9.2 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

### 9.2.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a FOUNDATION Fieldbus master (Class 1), e.g. a control system etc.

Display text (xxxx = serial number)	Base index	Description
RESOURCE_ xxxxxxxxx	400	Resource block
SETUP_ xxxxxxxxx	600	"Setup" Transducer block
TRDDISP_ xxxxxxxxx	800	"Display" Transducer block
TRDHROM_ xxxxxxxxx	1000	"HistoROM" Transducer block
TRDDIAG_ xxxxxxxxx	1200	"Diagnostic" Transducer block
EXPERT_CONFIG_xxxxxxxxxx	1400	"Expert configuration" Transducer block
SERVICE_SENSOR_xxxxxxxxxx	1600	"Service sensor" Transducer block
TRDTIC_xxxxxxxxx	1800	"Totalizer" Transducer block
TRDHBT_ xxxxxxxxx	2000	Transducer block "Heartbeat results"
ANALOG_INPUT_1_xxxxxxxxxx	3400	Analog Input function block 1 (AI)
ANALOG_INPUT_2_xxxxxxxxxx	3600	Analog Input function block 2 (AI)
ANALOG_INPUT_3_xxxxxxxxxx	3800	Analog Input function block 3 (AI)
ANALOG_INPUT_4_xxxxxxxxxx	4000	Analog Input function block 4 (AI)
ANALOG_INPUT_5_xxxxxxxxxx	4200	Analog Input function block 5 (AI)
ANALOG_INPUT_6_xxxxxxxxxx	4400	Analog Input function block 6 (AI)
ANALOG_INPUT_7_xxxxxxxxxx	4600	Analog Input function block 7 (AI)
ANALOG_INPUT_8_xxxxxxxxxx	4800	Analog Input function block 8 (AI)
MAO_ xxxxxxxxx	5000	Multiple Analog Output block (MAO)
DIGITAL_INPUT_1_ xxxxxxxxx	5200	Digital Input function block 1 (DI)
DIGITAL_INPUT_2_ xxxxxxxxx	5400	Digital Input function block 2 (DI)
MDO_xxxxxxxxx	5600	Multiple Digital Output block (MDO)
PID_ xxxxxxxxx	5800	PID function block (PID)
INTEGRATOR_xxxxxxxxx	6000	Integrator function block (INTG)

### 9.2.2 Description of the modules

The input value of a module/function block is defined via the CHANNEL parameter.

### AI module (Analog Input)

Eight Analog Input blocks are available.

CHANNEL	Measured variable
0	Uninitialized (factory setting)
7	Temperature
9	Volume flow
10	Concentration <sup>1)</sup>
11	Mass flow
13	Corrected volume flow
14	Density
15	Reference density
16	Totalizer 1
17	Totalizer 2
18	Totalizer 3
33	Oscillation frequency <sup>1)</sup>

CHANNEL	Measured variable
43	Frequency fluctuation <sup>1)</sup>
51	Carrier pipe temperature <sup>1)</sup>
57	Carrier mass flow 1)
58	Target mass flow 1)
63	Oscillation damping <sup>1)</sup>
65	Electronic temperature
66	Tube damping fluctuation <sup>1)</sup>
68	Exciter current <sup>1)</sup>
81	HBSI <sup>1)</sup>
99	Current input 1 <sup>1)</sup>

1) Visible depending on the order options or device settings

#### MAO module (Multiple Analog Output)

Channel	Description
121	Channel_0

#### Structure

Channel_0							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Values	Measured variable
Value 1	External pressure <sup>1)</sup>
Value 2	External temperature <sup>1)</sup>
Value 3	External reference density <sup>1)</sup>
Value 4	Not assigned
Value 5	Not assigned
Value 6	Not assigned
Value 7	Not assigned
Value 8	Not assigned

1) The external measured values must be transmitted to the device in the SI basic unit

**F** The selection is made via: Expert  $\rightarrow$  Sensor  $\rightarrow$  External compensation

#### DI module (Discrete Input)

Two Discrete Input blocks are available.

CHANNEL	Device function	State
0	Uninitialized (factory setting)	-
101	Switch output state	0 = off, 1 = active
103	Low flow cut off	0 = off, 1 = active

CHANNEL	Device function	State		
104	Empty pipe detection	0 = off, 1 = active		
105	Verification status <sup>1)</sup>	Overall result of the verification Verification: <ul> <li>16 = Failed</li> <li>32 = Passed</li> <li>64 = Not performed</li> </ul>		
		<ul> <li>Verification status</li> <li>Verification: <ul> <li>1 = Not performed</li> <li>2 = Failed</li> <li>4 = Being performed</li> <li>8 = Finished</li> </ul> </li> </ul>		
		<pre>Status; result 17 = Status: not performed; Result: failed 18 = Status: failed; Result: failed 20 = Status: being performed; Result: failed 24 = Status: finished; Result: failed 33 = Status: not performed; Result: passed 34 = Status: failed; Result: passed 40 = Status: being performed; Result: passed 40 = Status: not performed; Result: passed 65 = Status: not performed; Result: not performed 66 = Status: failed; Result: not performed 72 = Status: finished; Result: not performed </pre>		

1) Only available with the Heartbeat Verification application package

### MDO module (Multiple Discrete Output)

Channel	Description
122	Channel_DO

#### Structure

Channel_DO							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Value	Device function	State
Value 1	Reset totalizer 1	0 = off, 1 = execute
Value 2	Reset totalizer 2	0 = off, 1 = execute
Value 3	Reset totalizer 3	0 = off, 1 = execute
Value 4	Flow override	0 = off, 1 = active
Value 5	Start heartbeat verification <sup>1)</sup>	0 = off, 1 = start
Value 6	Status output	0 = off, 1 = active

Value	Device function	State
Value 7	Zero point adjustment	0 = off, 1 = on
Value 8	Not assigned	-

1) Only available with the Heartbeat Verification application package

### 9.2.3 Execution times

Function block	Execution time (ms)
Analog Input function block (AI)	6
Digital Input function block (DI)	4
PID function block (PID)	5
Multiple Analog Output block (MAO)	4
Multiple Digital Output block (MDO)	4
Integrator function block (INTG)	5

Method	Block	Navigation	Description
Set to "AUTO" mode	Resource block	Via menu: Expert → Communication → Resource block → Target mode	This method sets the Resource Block and all the Transducer Blocks to the AUTO (Automatic) mode.
Set to "OOS" mode	Resource block	Via menu: Expert → Communication → Resource block → Target mode	This method sets the Resource Block and all the Transducer Blocks to the OOS (Out of service) mode.
Restart	Resource block	Via menu: Expert $\rightarrow$ Communication $\rightarrow$ Resource block $\rightarrow$ Restart	This method is used to select the configuration for the <b>Restart</b> parameter in the Resource Block. This resets device parameters to a specific value.
			The following options are supported: • Uninitialized • Run • Resource • Defaults • Processor • To delivery settings
ENP parameter	Resource block	Via menu: Actions → Methods→ Calibrate → ENP parameter	This method is used to display and configure the parameters of the electronic nameplate (ENP).
Overview diagnostics - Remedy information	Diagnostic Transducer Block	Via link: Namur symbol	This method is used to display the diagnostic event with the highest priority that is currently active and the corresponding remedial measures.
Actual diagnostics – Remedy information	Diagnostic Transducer Block	<ul> <li>Via menu:</li> <li>Configure/Setup → Diagnostics → Actual diagnostics</li> <li>Device/Diagnostics → Diagnostics</li> </ul>	This method is used to display remedial measures for the diagnostic event with the highest priority that is currently active. This method is available only if an appropriate diagnostic event has occurred.
Previous diagnostics – Remedy information	Diagnostic Transducer Block	<ul> <li>Via menu:</li> <li>Configure/Setup → Diagnostics → Previous diagnostics</li> <li>Device/Diagnostics → Diagnostics</li> </ul>	This method is used to display remedial measures for the previous diagnostic event. This method is available only if an appropriate diagnostic event has occurred.

### 9.2.4 Methods

## 10 Commissioning

### **10.1** Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist  $\rightarrow$   $\cong$  34
- "Post-connection check" checklist  $\rightarrow \square 59$

### **10.2** Switching on the measuring device

- After a successful function check, switch on the measuring device.
  - ← After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" → 🗎 149.

### 10.3 Connecting via FieldCare

- For FieldCare  $\rightarrow \cong 81$  connection
- For connecting via FieldCare  $\rightarrow \cong 85$
- For the FieldCare  $\rightarrow \cong$  85 user interface

### **10.4** Setting the operating language

Factory setting: English or ordered local language



■ 33 Taking the example of the local display

Endress+Hauser

### **10.5** Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu



34 Taking the example of the local display

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

🖌 Setup		
Device tag	] .	→ 🗎 95
► System units	] .	→ 🖺 95
► Medium selection	] .	→ 🗎 98
► Analog inputs	] .	→ 🗎 100
► I/O configuration	] .	→ 🗎 100
► Current input 1	] .	→ 🗎 101
► Status input 1	]	
► Current output 1	] .	→ 🗎 103
► Pulse/frequency/switch output 1	] -	→ 🗎 106
► Relay output 1	] .	→ 🗎 113
► Display	] .	→ 🖺 115

► Low flow cut off	→ 🗎 118
► Partially filled pipe detection	→ 🗎 119
► Advanced setup	→ 🗎 120

### 10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



35 Header of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool  $\rightarrow \cong 85$ 

Navigation "Setup" menu → Device tag

#### Parameter overview with brief description

Parameter	Description	User entry
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

### 10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

#### Navigation

"Setup" menu → System units

► System units			
Mass flow u	nit	÷	₿ 96
Mass unit		$\rightarrow$	₿ 96
Volume flow	r unit	÷	₿ 96
Volume unit		÷	₿ 96

Corrected volume flow unit	] → 🗎 96
Corrected volume unit	] → 🗎 96
Density unit	] → 🗎 96
Reference density unit	] → 🗎 96
Temperature unit	→ 🗎 97
Pressure unit	→ 🗎 97

Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • kg/h • lb/min
Mass unit	Select mass unit.	Unit choose list	Country-specific: • kg • lb
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: <ul> <li>l/h</li> <li>gal/min (us)</li> </ul>
Volume unit	Select volume unit.	Unit choose list	Country-specific: • l (DN > 150 (6"): m <sup>3</sup> option) • gal (us)
Corrected volume flow unit	Select corrected volume flow unit. <i>Result</i> The selected unit applies for: <b>Corrected volume flow</b> parameter $(\rightarrow \square 139)$	Unit choose list	Country-specific: NI/h Sft <sup>3</sup> /min
Corrected volume unit	Select corrected volume unit.	Unit choose list	Country-specific: • Nl • Sft <sup>3</sup>
Density unit	Select density unit. <i>Result</i> The selected unit applies for: • Output • Simulation process variable • Density adjustment ( <b>Expert</b> menu)	Unit choose list	Country-specific: • kg/l • lb/ft <sup>3</sup>
Reference density unit	Select reference density unit.	Unit choose list	Country-dependent • kg/Nl • lb/Sft <sup>3</sup>

Parameter	Description	Selection	Factory setting
Temperature unit	<ul> <li>Select temperature unit.</li> <li><i>Result</i></li> <li>The selected unit applies for:</li> <li>Electronic temperature parameter (6053)</li> <li>Maximum value parameter (6051)</li> <li>Minimum value parameter (6108)</li> <li>Minimum value parameter (6109)</li> <li>Carrier pipe temperature parameter (6027)</li> <li>Maximum value parameter (6030)</li> <li>Reference temperature parameter (1816)</li> <li>Temperature parameter</li> </ul>	Unit choose list	Country-specific: • °C • °F
Pressure unit	<ul> <li>Select process pressure unit.</li> <li><i>Result</i></li> <li>The unit is taken from:</li> <li><b>Pressure value</b> parameter (→ ● 99)</li> <li><b>External pressure</b> parameter (→ ● 99)</li> <li>Pressure value</li> </ul>	Unit choose list	Country-specific: • bar a • psi a

### 10.5.3 Selecting and setting the medium

The **Select medium** wizard submenu contains parameters that must be configured in order to select and set the medium.

#### Navigation

"Setup" menu → Select medium

► Medium selection	
Select medium	→ 🗎 99
Select gas type	→ 🗎 99
Reference sound velocity	→ 🗎 99
Temperature coefficient sound velocity	→ 🗎 99
Pressure compensation	→ 🗎 99
Pressure value	→ 🗎 99
External pressure	→ 🗎 99

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Select medium	-	Select medium type.	<ul><li>Liquid</li><li>Gas</li></ul>	-
Select gas type	The <b>Gas</b> option is selected in the <b>Select medium</b> parameter.	Select measured gas type.	<ul> <li>Air</li> <li>Ammonia NH3</li> <li>Argon Ar</li> <li>Sulfur hexafluoride SF6</li> <li>Oxygen O2</li> <li>Ozone O3</li> <li>Nitrogen oxide NOX</li> <li>Nitrogen N2</li> <li>Nitrous oxide N2O</li> <li>Methane CH4</li> <li>Hydrogen H2</li> <li>Helium He</li> <li>Hydrogen chloride HCI</li> <li>Hydrogen sulfide H2S</li> <li>Ethylene C2H4</li> <li>Carbon monoxide CO</li> <li>Chlorine CI2</li> <li>Butane C4H10</li> <li>Propane C3H8</li> <li>Propylene C3H6</li> <li>Ethane C2H6</li> <li>Others</li> </ul>	
Reference sound velocity	In the <b>Select gas type</b> parameter, the <b>Others</b> option is selected.	Enter sound velocity of gas at 0 °C (32 °F).	1 to 99999.9999 m/ s	-
Temperature coefficient sound velocity	The <b>Others</b> option is selected in the <b>Select gas type</b> parameter.	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	0 (m/s)/K
Pressure compensation	-	Select pressure compensation type.	<ul> <li>Off</li> <li>Fixed value</li> <li>External value</li> <li>Current input 1<sup>*</sup></li> </ul>	-
Pressure value	The <b>Fixed value</b> option or the <b>Current input 1n</b> option is selected in the <b>Pressure compensation</b> parameter.	Enter process pressure to be used for pressure correction.	Positive floating- point number	-
External pressure	The <b>Fixed value</b> option or the <b>Current input 1n</b> option is selected in the <b>Pressure compensation</b> parameter.	Shows the external process pressure value.	Positive floating- point number	-

\* Visibility depends on order options or device settings

### 10.5.4 Configuring the analog inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

#### Navigation

"Setup" menu → Analog inputs

<ul><li>▶ Analog inputs</li><li>▶ Analog input 1 to n</li></ul>	
Block tag	→ 🗎 100
Channel	→ 🗎 100
Process Value Filter Time	→ 🗎 100

#### Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Block tag	Unique name of the measuring device.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /).	ANALOG_INPUT_1 4_Serial number
Channel	Use this function to select the process variable.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow *</li> <li>Carrier mass flow *</li> <li>Density</li> <li>Reference density</li> <li>Concentration *</li> <li>Temperature</li> <li>Carrier pipe temperature *</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>HBSI *</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Current input 1 *</li> <li>Uninitialized</li> </ul>	-
Process Value Filter Time	Enter the filter time specification for the filtering of the unconverted input value (PV).	Positive floating-point number	-

Visibility depends on order options or device settings

### 10.5.5 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

#### Navigation

"Setup" menu  $\rightarrow$  I/O configuration

► I/O configuration	
I/O module 1 to n terminal numbers	→ 🗎 101
I/O module 1 to n information	→ 🗎 101
I/O module 1 to n type	→ 🗎 101
Apply I/O configuration	→ 🗎 101
Conversion code	→ 🗎 101

#### Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry
I/O module terminal numbers	Shows the terminal numbers used by the I/O module.	<ul> <li>Not used</li> <li>26-27 (I/O 1)</li> <li>24-25 (I/O 2)</li> </ul>
I/O module information	Shows information of the plugged I/O module.	<ul> <li>Not plugged</li> <li>Invalid</li> <li>Not configurable</li> <li>Configurable</li> <li>Fieldbus</li> </ul>
I/O module type	Shows the I/O module type.	<ul> <li>Off</li> <li>Current output *</li> <li>Current input *</li> <li>Status input *</li> <li>Pulse/frequency/switch output *</li> </ul>
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	<ul><li>No</li><li>Yes</li></ul>
Conversion code	Enter the code in order to change the I/O configuration.	Positive integer

\* Visibility depends on order options or device settings

### 10.5.6 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

#### Navigation

"Setup" menu → Current input

► Current input 1	
Terminal number	→ 🗎 102
Signal mode	→ 🗎 102

0/4 mA value	→ 🗎 102
20 mA value	→ 🗎 102
Current span	→ 🗎 102
Failure mode	→ 🗎 102
Failure value	→ 🗎 102

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	_
Signal mode	The measuring device is <b>not</b> approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	<ul><li>Passive</li><li>Active</li></ul>	Active
0/4 mA value	-	Enter 4 mA value.	Signed floating-point number	-
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	<ul> <li>420 mA</li> <li>420 mA NAMUR</li> <li>420 mA US</li> <li>020 mA</li> </ul>	Country-specific: • 420 mA NAMUR • 420 mA US
Failure mode	-	Define input behavior in alarm condition.	<ul><li>Alarm</li><li>Last valid value</li><li>Defined value</li></ul>	_
Failure value	In the <b>Failure mode</b> parameter, the <b>Defined value</b> option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	-

### 10.5.7 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

#### Navigation

"Setup" menu → Status input

► Status input 1 to n	 
Assign status input	→ 🗎 103
Terminal number	→ 🗎 103

Activ	e level	→ 🗎	103
Term	inal number	$\rightarrow$ $\square$	103
Respo	onse time status input		103
Term	inal number	$\rightarrow$	103

Parameter	Description	User interface / Selection / User entry
Terminal number	Shows the terminal numbers used by the status input module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>
Assign status input	Select function for the status input.	<ul> <li>Off</li> <li>Reset totalizer 1</li> <li>Reset totalizer 2</li> <li>Reset totalizer 3</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>
Active level	Define input signal level at which the assigned function is triggered.	<ul><li>High</li><li>Low</li></ul>
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms

### **10.5.8** Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

#### Navigation

"Setup" menu  $\rightarrow$  Current output

► Current output 1	
Terminal number	→ 🗎 104
Signal mode	→ 🗎 104
Assign current output 1	→ 🗎 104
Current span	→ 🗎 104
0/4 mA value	→ 🗎 104
20 mA value	→ 🗎 104
Fixed current	→ <a>☐ 105</a>

Failure mode	$\rightarrow$	105 🗎
Failure current	] →	• 🖺 105

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	<ul> <li>Not used</li> <li>24-25 (I/O 2)</li> </ul>	-
Signal mode	-	Select the signal mode for the current output.	<ul><li>Passive</li><li>Active</li></ul>	Active
Assign current output		Select process variable for current output.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> <li>Density</li> <li>Reference density</li> <li>Concentration*</li> <li>Temperature</li> <li>Carrier pipe temperature*</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation amplitude 0*</li> <li>Frequency fluctuation 0</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>HBS1*</li> </ul>	
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	<ul> <li>420 mA NAMUR</li> <li>420 mA US</li> <li>420 mA</li> <li>020 mA</li> <li>Fixed current</li> </ul>	Country-specific: • 420 mA NAMUR • 420 mA US
0/4 mA value	One of the following options is selected in the <b>Current span</b> parameter (→ 🗎 104): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Enter 4 mA value.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
20 mA value	One of the following options is selected in the <b>Current span</b> parameter (→ 🗎 104): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Fixed current	The <b>Fixed current</b> option is selected in the <b>Current span</b> parameter ( $\rightarrow \square$ 104).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA
Damping output	A process variable is selected in the <b>Assign current output</b> parameter ( $\rightarrow \boxdot 104$ ) and one of the following options is selected in the <b>Current span</b> parameter ( $\rightarrow \boxdot 104$ ): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	-
Failure mode	A process variable is selected in the <b>Assign current output</b> parameter ( $\rightarrow \boxdot 104$ ) and one of the following options is selected in the <b>Current span</b> parameter ( $\rightarrow \boxdot 104$ ): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Define output behavior in alarm condition.	<ul> <li>Min.</li> <li>Max.</li> <li>Last valid value</li> <li>Actual value</li> <li>Defined value</li> </ul>	-
Failure current	The <b>Defined value</b> option is selected in the <b>Failure mode</b> parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA

\* Visibility depends on order options or device settings

### 10.5.9 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Pulse/frequency/switch output

Pulse/frequency/ 1 to n	switch output	
	Operating mode	→ 🗎 106

#### Parameter overview with brief description

Parameter	Description	Selection
Operating mode	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>

#### Configuring the pulse output

#### Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output

<ul> <li>Pulse/frequency/switch output</li> <li>1 to n</li> </ul>	
Operating mode	) → 🗎 107
Terminal number	] → 🗎 107
Signal mode	) → 🗎 107
Assign pulse output	) → 🗎 107
Value per pulse	→ 🗎 107
Pulse width	] → 🗎 107
Failure mode	) → 🗎 107
Invert output signal	→ 🗎 107

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	-
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul> <li>Not used</li> <li>24-25 (I/O 2)</li> </ul>	-
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	-
Assign pulse output 1 to n	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Select process variable for pulse output.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> </ul>	-
Value per pulse	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 106$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \boxminus 107$ ).	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxdot 106$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \boxdot 107$ ).	Define time width of the output pulse.	0.05 to 2 000 ms	-
Failure mode	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 106$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \boxminus 107$ ).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>No pulses</li></ul>	-
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

\* Visibility depends on order options or device settings

#### Configuring the frequency output

#### Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 108
Terminal number	→ 🗎 108
Signal mode	→ 🗎 108

→ 🗎 109	Assign frequency output
→ 🗎 109	Minimum frequency value
→ ➡ 109	Maximum frequency value
→ <a>Phi 109</a>	Measuring value at minimum
	rrequency
$\rightarrow \equiv 109$	Measuring value at maximum frequency
→ ➡ 109	Failure mode
→ 🗎 110	Failure frequency
→ 🗎 110	Invert output signal
<ul> <li>→ 🖹 109</li> <li>→ 🖺 109</li> <li>→ 🗎 109</li> <li>→ 🗎 109</li> <li>→ 🗎 109</li> <li>→ 🗎 110</li> <li>→ 🖺 110</li> </ul>	Maximum frequency value         Measuring value at minimum         frequency         Measuring value at maximum         frequency         Failure mode         Failure frequency         Invert output signal

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	_
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul> <li>Not used</li> <li>24-25 (I/O 2)</li> </ul>	-
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	-
Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
---	--	--	---	---
Assign frequency output	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 106) parameter.	Select process variable for frequency output.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow *</li> <li>Carrier mass flow *</li> <li>Density</li> <li>Reference density</li> <li>Concentration *</li> <li>Temperature</li> <li>Carrier pipe temperature</li> <li>Carrier pipe temperature</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation amplitude 0</li> <li>Frequency fluctuation 0</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>HBSI *</li> </ul>	-
Minimum frequency value	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \bowtie 106$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \bowtie 109$ ).	Enter minimum frequency.	0.0 to 10000.0 Hz	-
Maximum frequency value	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \square$ 106) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \square$ 109).	Enter maximum frequency.	0.0 to 10000.0 Hz	-
Measuring value at minimum frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 106$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\rightarrow \boxminus 109$ ).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \bowtie 106$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \bigoplus 109$ ).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \boxdot 106$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \boxdot 109$ ).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>Defined value</li><li>0 Hz</li></ul>	-

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Failure frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\Rightarrow \square 106$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\Rightarrow \square 109$ ).	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	_
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

\* Visibility depends on order options or device settings

## Configuring the switch output

## Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output

<ul> <li>Pulse/frequency/switch output</li> <li>1 to n</li> </ul>	
Operating mode	] → 🗎 111
Terminal number	] → 🗎 111
Signal mode	] → 🗎 111
Switch output function	] → 🗎 112
Assign diagnostic behavior	] → 🗎 112
Assign limit	) → 🗎 112
Assign flow direction check	] → 🗎 112
Assign status	) → 🗎 112
Switch-on value	→ 🗎 112
Switch-off value	) → 🗎 112
Switch-on delay	→ 🗎 112
Switch-off delay	) → 🗎 113
Failure mode	] → 🗎 113
Invert output signal	] → 🗎 113

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	_
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	_
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	-

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Select function for switch output.	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Status</li> </ul>	-
Assign diagnostic behavior	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Diagnostic behavior option is selected.</li> </ul>	Select diagnostic behavior for switch output.	<ul><li> Alarm</li><li> Alarm or warning</li><li> Warning</li></ul>	_
Assign limit	<ul> <li>The Switch option is selected in the Operating mode parameter parameter.</li> <li>The Limit option is selected in the Switch output function parameter parameter.</li> </ul>	Select process variable for limit function.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> <li>Density</li> <li>Reference density</li> <li>Concentration*</li> <li>Temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Oscillation damping</li> </ul>	_
Assign flow direction check	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Flow direction check option is selected in the Switch output function parameter.</li> </ul>	Select process variable for flow direction monitoring.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> </ul>	-
Assign status	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Status option is selected in the Switch output function parameter.</li> </ul>	Select device status for switch output.	<ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> <li>Digital output 6</li> </ul>	-
Switch-on value	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Limit option is selected.</li> </ul>	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-off value	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Limit option is selected.</li> </ul>	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-on delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-on of status output.	0.0 to 100.0 s	-

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-off of status output.	0.0 to 100.0 s	_
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	-
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

\* Visibility depends on order options or device settings

## **10.5.10** Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

#### Navigation

"Setup" menu  $\rightarrow$  Relay output 1 to n

► RelaisOutput 1 to n	
Switch output function	→ 🗎 114
Assign flow direction check	→ 🗎 114
Assign limit	) → 🗎 114
Assign diagnostic behavior	→ 🗎 114
Assign status	→ 🗎 114
Switch-off value	→ 🗎 114
Switch-on value	→ 🗎 114
Failure mode	→ 🗎 114

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Relay output function	-	Select the function for the relay output.	<ul> <li>Closed</li> <li>Open</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Digital Output</li> </ul>	-
Terminal number	-	Shows the terminal numbers used by the relay output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Assign flow direction check	In the <b>Relay output function</b> parameter, the <b>Flow direction</b> <b>check</b> option is selected.	Select process variable for flow direction monitoring.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li><li> Corrected volume flow</li></ul>	-
Assign limit	The <b>Limit</b> option is selected in the <b>Relay output function</b> parameter parameter.	Select process variable for limit function.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> <li>Density</li> <li>Reference density</li> <li>Concentration*</li> <li>Temperature</li> <li>Totalizer 1</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Oscillation damping</li> </ul>	-
Assign diagnostic behavior	In the <b>Relay output function</b> parameter, the <b>Diagnostic</b> <b>behavior</b> option is selected.	Select diagnostic behavior for switch output.	<ul><li>Alarm</li><li>Alarm or warning</li><li>Warning</li></ul>	-
Assign status	In the <b>Relay output function</b> parameter, the <b>Digital Output</b> option is selected.	Select device status for switch output.	<ul><li>Partially filled pipe detection</li><li>Low flow cut off</li><li>Digital output 6</li></ul>	-
Switch-off value	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-off delay	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Define delay for the switch-off of status output.	0.0 to 100.0 s	-
Switch-on value	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-on delay	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Define delay for the switch-on of status output.	0.0 to 100.0 s	-
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	-

\* Visibility depends on order options or device settings

## 10.5.11 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

## Navigation

"Setup" menu  $\rightarrow$  Display

► Display		
	Format display	→ 🗎 116
	Value 1 display	→ <a>Pmilling</a> 116
	0% bargraph value 1	→ 🗎 116
	100% bargraph value 1	→ 🗎 116
	Value 2 display	→ 🗎 116
	Value 3 display	→ 🗎 116
	0% bargraph value 3	→ 🗎 116
	100% bargraph value 3	→ 🗎 117
	Value 4 display	→ 🗎 117

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> <li>Density</li> <li>Reference density</li> <li>Concentration*</li> <li>Temperature</li> <li>Carrier pipe temperature*</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation amplitude 0*</li> <li>Frequency fluctuation 0</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>Totalizer 1</li> <li>Totalizer 3</li> <li>Current output 1</li> </ul>	
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter $(\rightarrow \cong 116)$	-
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter $(\rightarrow \cong 116)$	-

\* Visibility depends on order options or device settings

## 10.5.12 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

## Navigation

"Setup" menu  $\rightarrow$  Low flow cut off



Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> </ul>	-
On value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \square$ 118).	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \square$ 118).	Enter off value for low flow cut off.	0 to 100.0 %	-
Pressure shock suppression	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \square$ 118).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	-

## **10.5.13** Configuring the partial filled pipe detection

The **Partial filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

#### Navigation

"Setup" menu  $\rightarrow$  Partially filled pipe detection



Parameter	Prerequisite	Description	Selection / User entry
Assign process variable	-	Select process variable for partially filled pipe detection.	<ul><li> Off</li><li> Density</li><li> Reference density</li></ul>
Low value partial filled pipe detection	A process variable is selected in the <b>Assign process variable</b> parameter $( \rightarrow \cong 119).$	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number
High value partial filled pipe detection	A process variable is selected in the <b>Assign process variable</b> parameter $( \rightarrow \cong 119).$	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number
Response time part. filled pipe detect.	A process variable is selected in the <b>Assign process variable</b> parameter $(\rightarrow \cong 119)$ .	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s

# 10.6 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu



The number of submenus can vary depending on the device version. Some submenus are not dealt with in the Operating Instructions. These submenus and the parameters they contain are explained in the Special Documentation for the device.

#### Navigation

"Setup" menu → Advanced setup

► Advanced setup	
Enter access code	→ 🗎 121
► Calculated values	→ 🗎 121
► Sensor adjustment	→ 🗎 122
► Totalizer 1 to n	→ 🗎 123
► Display	→ 🗎 125



## 10.6.1 Using the parameter to enter the access code

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup

## Parameter overview with brief description

Parameter	Description	User entry	
Enter access code	Enter access code to disable write protection of parameters.	0 to 9999	

## 10.6.2 Calculated values

The **Calculated values** submenu contains parameters for calculating the corrected volume flow.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Calculated values

► Calculated values		
► Co	prrected volume flow calculation	
	Corrected volume flow calculation	→ 🖺 122
	External reference density	→ 🗎 122
	Fixed reference density	→ 🗎 122
	Reference temperature	→ 🗎 122
	Linear expansion coefficient	→ 🗎 122
	Square expansion coefficient	→ 🗎 122

Parameter overview w	with brief	description
----------------------	------------	-------------

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	<ul> <li>Fixed reference density</li> <li>Calculated reference density</li> <li>Reference density by API table 53</li> <li>External reference density</li> <li>Current input 1<sup>*</sup></li> </ul>	-
External reference density	-	Shows external reference density.	Floating point number with sign	-
Fixed reference density	The <b>Fixed reference density</b> option is selected in the <b>Corrected volume flow</b> <b>calculation</b> parameter parameter.	Enter fixed value for reference density.	Positive floating- point number	-
Reference temperature	The <b>Calculated reference</b> <b>density</b> option is selected in the <b>Corrected volume flow</b> <b>calculation</b> parameter parameter.	Enter reference temperature for calculating the reference density.	-273.15 to 99999 ℃	Country-specific: • +20 °C • +68 °F
Linear expansion coefficient	The <b>Calculated reference</b> <b>density</b> option is selected in the <b>Corrected volume flow</b> <b>calculation</b> parameter parameter.	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	-
Square expansion coefficient	The <b>Calculated reference</b> <b>density</b> option is selected in the <b>Corrected volume flow</b> <b>calculation</b> parameter parameter.	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	-

\* Visibility depends on order options or device settings

## 10.6.3 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Sensor adjustment

► Sensor adjustment	
Installation direction	→ 🗎 123
► Zero point adjustment	→ 🗎 123

Parameter	Description	Selection
Installation direction	Set sign of flow direction to match the direction of the arrow on	<ul> <li>Flow in arrow direction</li> </ul>
	the sensor.	<ul> <li>Flow against arrow direction</li> </ul>

#### Zero point adjustment

All measuring devices are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions  $\rightarrow \textcircled{B} 210$ . Therefore, a zero point adjustment in the field is generally not required.

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Sensor adjustment  $\rightarrow$  Zero point adjustment

► Zero point adjustment	
Zero point adjustment control	→ 🗎 123
Progress	→ 🗎 123

## Parameter overview with brief description

Parameter	Description	Selection / User interface	Factory setting
Zero point adjustment control	Start zero point adjustment.	<ul><li>Cancel</li><li>Busy</li><li>Zero point adjust failure</li><li>Start</li></ul>	-
Progress	Shows the progress of the process.	0 to 100 %	-

## 10.6.4 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable	→ 🗎 124
Unit totalizer 1 to n	→ 🗎 124
Totalizer operation mode	→ 🗎 124
Failure mode	→ 🗎 124

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Target mass flow*</li> <li>Carrier mass flow*</li> </ul>	-
Unit totalizer 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \bowtie 124$ ) of the <b>Totalizer 1 to n</b> submenu.	Select process variable totalizer unit.	Unit choose list	Country-specific: • kg • lb
Totalizer operation mode	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \bowtie 124$ ) of the <b>Totalizer 1 to n</b> submenu.	Select totalizer calculation mode.	<ul><li>Net flow total</li><li>Forward flow total</li><li>Reverse flow total</li></ul>	-
Failure mode	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \implies 124$ ) of the <b>Totalizer 1 to n</b> submenu.	Define totalizer behavior in alarm condition.	<ul><li>Stop</li><li>Actual value</li><li>Last valid value</li></ul>	-

\* Visibility depends on order options or device settings

## 10.6.5 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Display

► Display	
Format display	→ 🗎 126
Value 1 display	) → 🗎 126
0% bargraph value 1	] → 🗎 126
100% bargraph value 1	] → 🗎 126
Decimal places 1	→ 🗎 126
Value 2 display	→ 🗎 126
Decimal places 2	) → 🗎 126
Value 3 display	) → 🗎 126
0% bargraph value 3	) → 🗎 127
100% bargraph value 3	→ 🗎 127
Decimal places 3	) → 🗎 127
Value 4 display	) → 🗎 127
Decimal places 4	] → 🗎 127
Display language	] → 🗎 127
Display interval	) → 🗎 127
Display damping	) → 🗎 127
Header	] → 🗎 127
Header text	] → 🗎 127
Separator	] → 🗎 128
Backlight	] → 🗎 128

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Target mass flow *</li> <li>Carrier mass flow *</li> <li>Density</li> <li>Reference density</li> <li>Concentration *</li> <li>Temperature</li> <li>Carrier pipe temperature *</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation amplitude 0*</li> <li>Frequency fluctuation 0</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>Totalizer 1</li> <li>Totalizer 3</li> <li>Current output 1</li> </ul>	
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the <b>Value 1 display</b> parameter.	Select the number of decimal places for the display value.	<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	-
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter	-
Decimal places 2	A measured value is specified in the <b>Value 2 display</b> parameter.	Select the number of decimal places for the display value.	<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter $(\rightarrow \cong 116)$	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
100% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Decimal places 3	A measured value is specified in the <b>Value 3 display</b> parameter.	Select the number of decimal places for the display value.	<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter $(\rightarrow \cong 116)$	-
Decimal places 4	A measured value is specified in the <b>Value 4 display</b> parameter.	Select the number of decimal places for the display value.	<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	-
Display language	A local display is provided.	Set display language.	<ul> <li>English</li> <li>Deutsch</li> <li>Français</li> <li>Español</li> <li>Italiano</li> <li>Nederlands</li> <li>Portuguesa</li> <li>Polski</li> <li>Pycский язык (Russian)</li> <li>Svenska</li> <li>Türkçe</li> <li>中文 (Chinese)</li> <li>日本語 (Japanese)</li> <li>한국 어 (Korean)</li> <li>Bahasa Indonesia</li> <li>tiếng Việt (Vietnamese)</li> <li>čeština (Czech)</li> </ul>	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	-
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	-
Header	A local display is provided.	Select header contents on local display.	<ul><li> Device tag</li><li> Free text</li></ul>	-
Header text	In the <b>Header</b> parameter, the <b>Free text</b> option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	<ul> <li>. (point)</li> <li>, (comma)</li> </ul>	. (point)
Backlight	One of the following conditions is met: • Order code for "Display; operation", option <b>F</b> "4-line, illum.; touch control" • Order code for "Display; operation", option <b>G</b> "4-line, illum.; touch control +WLAN"	Switch the local display backlight on and off.	<ul><li>Disable</li><li>Enable</li></ul>	-

\* Visibility depends on order options or device settings

## 10.6.6 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  WLAN Settings

► WLAN settings	
WLAN IP address	) → 🗎 128
Security type	→ 🗎 128
WLAN passphrase	→ 🗎 128
Assign SSID name	) → 🗎 129
SSID name	→ 🗎 129
Apply changes	→ 🗎 129

Parameter	Prerequisite	Description	User entry / Selection	Factory setting
WLAN IP address	-	Enter IP address of the device WLAN interface.	4 octet: 0 to 255 (in the particular octet)	-
Security type	-	Select the security type of the WLAN interface.	<ul><li>Unsecured</li><li>WPA2-PSK</li></ul>	-
WLAN passphrase	The <b>WPA2-PSK</b> option is selected in the <b>Security type</b> parameter.	Enter the network key (8 to 32 characters). The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters	Serial number of the measuring device (e.g. L100A802000)

Parameter	Prerequisite	Description	User entry / Selection	Factory setting
Assign SSID name	-	Select which name will be used for SSID: device tag or user- defined name.	<ul><li>Device tag</li><li>User-defined</li></ul>	_
SSID name	<ul> <li>The User-defined option is selected in the Assign SSID name parameter.</li> <li>The WLAN access point option is selected in the WLAN mode parameter.</li> </ul>	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Promass_500_A 802000)
Apply changes	-	Use changed WLAN settings.	<ul><li>Cancel</li><li>Ok</li></ul>	-

## 10.6.7 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup** submenu.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Configuration backup

► Configuration backup	
Operating time	→ 🗎 129
Last backup	→ 🗎 129
Configuration management	→ 🗎 129
Backup state	→ 🗎 130
Comparison result	→ 🗎 130

Parameter	Description	User interface / Selection
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Last backup	Shows when the last data backup was saved to embedded HistoROM.	Days (d), hours (h), minutes (m) and seconds (s)
Configuration management	Select action for managing the device data in the embedded HistoROM.	<ul> <li>Cancel</li> <li>Execute backup</li> <li>Restore</li> <li>Compare</li> <li>Clear backup data</li> </ul>

Parameter	Description	User interface / Selection
Backup state	Shows the current status of data saving or restoring.	<ul> <li>None</li> <li>Backup in progress</li> <li>Restoring in progress</li> <li>Delete in progress</li> <li>Compare in progress</li> <li>Restoring failed</li> <li>Backup failed</li> </ul>
Comparison result	Comparison of current device data with embedded HistoROM.	<ul> <li>Settings identical</li> <li>Settings not identical</li> <li>No backup available</li> <li>Backup settings corrupt</li> <li>Check not done</li> <li>Dataset incompatible</li> </ul>

## Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.

HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

## 10.6.8 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration

► Administration	
► Define access code	→ 🗎 131
► Reset access code	→ 🗎 131
Device reset	→ 🗎 132

## Using the parameter to define the access code

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Define access code

► Define access code	
Define access code	→ 🗎 131
Confirm access code	→ 🗎 131

## Parameter overview with brief description

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the entered access code.	Max. 16-digit character string comprising numbers, letters and special characters

#### Using the parameter to reset the access code

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Reset access code

► Reset access code	
Operating time	] → 🗎 131
Reset access code	] → 🗎 131

## Parameter overview with brief description

Parameter	Description	User interface / User entry
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Reset access code	Reset access code to factory settings. For a reset code, contact your Endress+Hauser service organization.	Character string comprising numbers, letters and special characters
	<ul><li>The reset code can only be entered via:</li><li>Web browser</li><li>DeviceCare, FieldCare (via service interface CDI-RJ45)</li><li>Fieldbus</li></ul>	

## Using the parameter to reset the device

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration

Parameter	Description	Selection
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul> <li>Cancel</li> <li>To delivery settings</li> <li>Restart device</li> <li>Restore S-DAT backup</li> <li>ENP restart</li> </ul>

# 10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

## Navigation

"Diagnostics" menu  $\rightarrow$  Simulation

► Simulation	
Assign simulation process variable	→ 🗎 133
Process variable value	→ 🗎 133
Status input simulation	→ 🗎 133
Input signal level	→ 🗎 133
Current input 1 to n simulation	→ 🗎 133
Value current input 1 to n	→ 🗎 133
Current output 1 to n simulation	→ 🗎 133
Value current output 1 to n	→ 🗎 133
Frequency output simulation 1 to n	→ 🗎 133
Frequency value 1 to n	→ 🗎 133
Pulse output simulation 1 to n	→ 🗎 133
Pulse value 1 to n	→ 🗎 133
Switch output simulation 1 to n	→ 🗎 133
Switch status 1 to n	→ 🗎 134
Relay output 1 to n simulation	→ 🗎 134

Switch status 1 to n	→ 🗎 134
Device alarm simulation	→ 🗎 134
Diagnostic event category	→ 🗎 134
Diagnostic event simulation	→ 🗎 134

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Target mass flow *</li> <li>Carrier mass flow *</li> <li>Concentration *</li> </ul>
Process variable value	A process variable is selected in the <b>Assign simulation process variable</b> parameter ( $\rightarrow \square$ 133).	Enter the simulation value for the selected process variable.	Depends on the process variable selected
Status input simulation	-	Switch simulation of the status input on and off.	<ul><li>Off</li><li>On</li></ul>
Input signal level	In the <b>Status input simulation</b> parameter, the <b>On</b> option is selected.	Select the signal level for the simulation of the status input.	<ul><li>High</li><li>Low</li></ul>
Current input simulation	-	Switch simulation of the current input on and off.	<ul><li>Off</li><li>On</li></ul>
Value current input	In the <b>Current input 1 to n simulation</b> parameter, the <b>On</b> option is selected.	Enter the current value for simulation.	0 to 22.5 mA
Current output simulation	-	Switch the simulation of the current output on and off.	<ul><li>Off</li><li>On</li></ul>
Value current output	In the <b>Current output 1 to n</b> <b>simulation</b> parameter, the <b>On</b> option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA
Frequency output simulation	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Switch the simulation of the frequency output on and off.	• Off • On
Frequency value	In the <b>Frequency output simulation</b> <b>1 to n</b> parameter, the <b>On</b> option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz
Pulse output simulation	In the <b>Operating mode</b> parameter, the <b>Pulse</b> option is selected.	<ul> <li>Set and switch off the pulse output simulation.</li> <li>For Fixed value option: Pulse width parameter (→          107) defines the pulse width of the pulses output.</li> </ul>	<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>
Pulse value	In the <b>Pulse output simulation 1 to n</b> parameter, the <b>Down-counting value</b> option is selected.	Enter the number of pulses for simulation.	0 to 65 535
Switch output simulation	In the <b>Operating mode</b> parameter, the <b>Switch</b> option is selected.	Switch the simulation of the switch output on and off.	Off     On

Parameter	Prerequisite	Description	Selection / User entry / User interface
Switch status	-	Select the status of the status output for the simulation.	<ul><li> Open</li><li> Closed</li></ul>
Relay output simulation	-	Switch simulation of the relay output on and off.	<ul><li>Off</li><li>On</li></ul>
Switch status	The <b>On</b> option is selected in the <b>Switch</b> <b>output simulation 1 to n</b> parameter parameter.	Select status of the relay output for the simulation.	<ul><li> Open</li><li> Closed</li></ul>
Pulse output simulation	-	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>
Pulse value	In the <b>Pulse output simulation</b> parameter, the <b>Down-counting value</b> option is selected.	Set and switch off the pulse output simulation.	0 to 65 535
Device alarm simulation	-	Switch the device alarm on and off.	<ul><li>Off</li><li>On</li></ul>
Diagnostic event category	-	Select a diagnostic event category.	<ul><li>Sensor</li><li>Electronics</li><li>Configuration</li><li>Process</li></ul>
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	<ul> <li>Off</li> <li>Diagnostic event picklist (depends on the category selected)</li> </ul>
Logging interval	-	Define the logging interval tlog for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s

\* Visibility depends on order options or device settings

# **10.8** Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code  $\rightarrow \implies 134$
- Protect access to local operation via key locking  $\rightarrow$   $\cong$  74
- Protect access to measuring device via write protection switch  $\rightarrow \square 136$
- Protect access to parameters via block operation  $\rightarrow \implies 137$

## 10.8.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

## Defining the access code via local display

**1.** Navigate to the **Define access code** parameter ( $\rightarrow \triangleq 131$ ).

2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.

- **3.** Enter the access code again in the **Confirm access code** parameter ( $\rightarrow \implies 131$ ) to confirm the code.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

- If parameter write protection is activated via an access code, it can also only be deactivated via this access code  $\rightarrow \cong 73$ .
  - The user role with which the user is currently logged on via the local display is indicated by the → 
     <sup>(2)</sup>
     73 Access status parameter. Navigation path: Operation → Access status

#### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



## Defining the access code via the Web browser

- 1. Navigate to the **Define access code** parameter ( $\rightarrow \square$  131).
- 2. Define a max. 16-digit numeric code as an access code.
- **3.** Enter the access code again in the **Confirm access code** parameter ( $\rightarrow \implies 131$ ) to confirm the code.
  - └ The Web browser switches to the login page.

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

- If parameter write protection is activated via an access code, it can also only be deactivated via this access code  $\rightarrow \cong 73$ .
  - The user role with which the user is currently logged on via Web browser is indicated by the Access status parameter. Navigation path: Operation → Access status

#### Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

## Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

For a reset code, contact your Endress+Hauser service organization.

1. Navigate to the **Reset access code** parameter ( $\rightarrow \square$  131).

2. Enter the reset code.

→ The access code has been reset to the factory setting **0000**. It can be redefined  $\rightarrow \cong 134$ .

## 10.8.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via FOUNDATION Fieldbus

## Proline 500 – digital

## **WARNING**

#### **Excessive tightening torque applied to the fixing screws!** Risk of damaging the plastic transmitter.

► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)



- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.
- **4.** Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.
  - In the Locking status parameter the Hardware locked option is displayed
     → 138. In addition, on the local display the 圖-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



- **5.** Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

#### Proline 500



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

In the Locking status parameter the Hardware locked option is displayed
 → ■ 138. In addition, on the local display the @-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



- 2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
  - Image: No option is displayed in the Locking status parameter → 138. On the local display, the @-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

## 10.8.3 Write protection via block operation

Locking via block operation:

- Block: DISPLAY (TRDDISP); parameter: Define access code
- Block: EXPERT\_CONFIG (TRDEXP); parameter: Enter access code

# 11 Operation

# 11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation  $\rightarrow$  Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the <b>Access status</b> parameter applies $\Rightarrow {}$ 73. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) .
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

# 11.2 Adjusting the operating language

**1** Detailed information:

- To configure the operating language  $\rightarrow \implies 93$
- For information on the operating languages supported by the measuring device  $\rightarrow~\textcircled{B}$  220

# 11.3 Configuring the display

Detailed information:

- On the basic settings for the local display  $\rightarrow \square 115$
- On the advanced settings for the local display  $\rightarrow \square 125$

# 11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

## Navigation

"Diagnostics" menu → Measured values

► Measured values	
► Measured variables	) → 🗎 139
► Input values	) → 🗎 141
► Output values	) → 🗎 142
► Totalizer	) → 🗎 140

## 11.4.1 "Measured variables" submenu

The **Measured variables** submenu contains all the parameters needed to display the current measured values for each process variable.

## Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Measured variables

► Measured variables	
Mass flow	→ 🗎 139
Volume flow	→ 🗎 139
Corrected volume flow	→ 🗎 139
Density	→ 🗎 139
Reference density	→ 🗎 140
Temperature	→ 🗎 140
Pressure value	→ 🗎 140
Concentration	→ 🗎 140
Target mass flow	→ 🗎 140
Carrier mass flow	→ 🗎 140

Parameter	Prerequisite	Description	User interface
Mass flow	-	Displays the mass flow currently measured.	Signed floating-point number
		Dependency The unit is taken from the <b>Mass flow</b> <b>unit</b> parameter ( $\rightarrow \square 96$ ).	
Volume flow	-	Displays the volume flow currently calculated.	Signed floating-point number
		<i>Dependency</i> The unit is taken from the <b>Volume flow unit</b> parameter ( $\rightarrow$ 🗎 96).	
Corrected volume flow	-	Displays the corrected volume flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the <b>Corrected</b> <b>volume flow unit</b> parameter $(\rightarrow \cong 96).$	
Density	-	Shows the density currently measured.	Signed floating-point
		Dependency The unit is taken from the <b>Density unit</b> parameter ( $\rightarrow \cong$ 96).	number

Parameter	Prerequisite	Description	User interface
Reference density	-	Displays the reference density currently calculated.	Signed floating-point number
		Dependency The unit is taken from the <b>Reference</b> <b>density unit</b> parameter ( $\rightarrow \square 96$ ).	
Temperature	-	Shows the medium temperature currently measured.	Signed floating-point number
		Dependency The unit is taken from the <b>Temperature unit</b> parameter $(\rightarrow \cong 97)$ .	
Pressure value	-	Displays either a fixed or external pressure value.	Signed floating-point number
		Dependency The unit is taken from the <b>Pressure</b> <b>unit</b> parameter ( $\rightarrow \textcircled{P}$ 97).	
Concentration	For the following order code: Order code for "Application package",	Displays the concentration currently calculated.	Signed floating-point number
	option ED "Concentration" The software options currently enabled are displayed in the Software option overview parameter.	Dependency The unit is taken from the <b>Concentration unit</b> parameter.	
Target mass flow	With the following conditions: Order code for "Application package",	Displays the mass flow currently measured for the target medium.	Signed floating-point number
opti	option <b>ED</b> "Concentration"	Dependency	
	<b>1</b> The software options currently enabled are displayed in the <b>Software option overview</b> parameter.	The unit is taken from the <b>Mass flow unit</b> parameter ( $\rightarrow \square 96$ ).	
Carrier mass flow	With the following conditions: Order code for "Application package",	Displays the mass flow currently measured for the carrier medium.	Signed floating-point number
	The software options currently enabled are displayed in the Software option overview parameter.	Dependency The unit is taken from the <b>Mass flow</b> <b>unit</b> parameter ( $\rightarrow \square 96$ ).	

## 11.4.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

## Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Totalizer

► Totalizer			
Total	lizer value 1 to n	÷	• 🗎 141
Total	lizer overflow 1 to n		• 🗎 141

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter $(\rightarrow \bigoplus 124)$ of the <b>Totalizer 1 to n</b> submenu.	Displays the current totalizer counter value.	Signed floating-point number
Totalizer overflow 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter $(\rightarrow \cong 124)$ of the <b>Totalizer 1 to n</b> submenu.	Displays the current totalizer overflow.	Integer with sign

## 11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

## Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values

► Input values	
► Current input 1 to n	) → 🗎 141
► Status input 1 to n	) → 🗎 141

## Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values  $\rightarrow$  Current input 1 to n



## Parameter overview with brief description

Parameter	Description	User interface
Measured values	Displays the current input value.	Signed floating-point number
Measured current	Displays the current value of the current input.	0 to 22.5 mA

## Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values  $\rightarrow$  Status input 1 to n

► Status input 1 to n		
Value status input		→ 🗎 142

#### Parameter overview with brief description

Parameter	Description	User interface
Value status input	Shows the current input signal level.	<ul><li>High</li><li>Low</li></ul>

## 11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values



#### Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Value current output 1 to n



Parameter	Description	User interface
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

## Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Pulse/frequency/switch output 1 to n

Pulse/frequency/switch output 1 to n		
Output frequency 1 to n	→ 🗎 143	
Pulse output 1 to n	→ 🗎 143	
Switch status 1 to n	→ 🗎 143	

#### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Output frequency	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch status	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Displays the current switch output status.	<ul><li> Open</li><li> Closed</li></ul>

## Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

## Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Relay output 1 to n

► Relay output 1 to n		
Switch status	→ 🗎 144	
Switch cycles	→ 🗎 144	
Max. switch cycles number	→ 🗎 144	

Parameter	Description	User interface	
Switch status	Shows the current relay switch status.	<ul><li> Open</li><li> Closed</li></ul>	
Switch cycles	Shows number of all performed switch cycles.	Positive integer	
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer	

# 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

Basic settings using the Setup menu (→ 
 <sup>⊕</sup> 94)

• Advanced settings using the Advanced setup submenu ( $\rightarrow \square 120$ )

# **11.6** Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

## Navigation

"Operation" menu  $\rightarrow$  Totalizer handling



Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \boxdot 124$ ) of the <b>Totalizer 1 to n</b> submenu.	Control totalizer value.	<ul> <li>Totalize</li> <li>Reset + hold</li> <li>Preset + hold</li> <li>Reset + totalize</li> <li>Preset + totalize</li> <li>Hold</li> </ul>	-
Preset value 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \bowtie$ 124) of the <b>Totalizer 1 to n</b> submenu.	<ul> <li>Specify start value for totalizer.</li> <li>Dependency</li> <li>The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→          124).     </li> </ul>	Signed floating-point number	Country-specific: • 0 kg • 0 lb
Reset all totalizers	-	Reset all totalizers to 0 and start.	<ul><li>Cancel</li><li>Reset + totalize</li></ul>	-
Options	Description			
-------------------	---	--		
Totalize	The totalizer is started or continues running.			
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.			
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value</b> parameter.			
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.			
Preset + totalize	The totalizer is set to the defined start value from the <b>Preset value</b> parameter and the totaling process is restarted.			
Hold	Totalizing is stopped.			

### 11.6.1 Function scope of the "Control Totalizer" parameter

### 11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

# **11.7** Showing data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

Data logging is also available via:

- Plant Asset Management Tool FieldCare  $\rightarrow \cong 84$ .
- Web browser

### Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



■ 36 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation "Diagnostics" menu → Data logging

► Data logging	
Assign channel 1	→ 🗎 147
Assign channel 2	) → 🗎 147
Assign channel 3	) → 🗎 147
Assign channel 4	] → 🗎 147
Logging interval	) → 🗎 147
Clear logging data	) → 🗎 147
Data logging	) → 🖺 147
Logging delay	) → 🗎 147
Data logging control	) → 🖺 147
Data logging status	] → 🖺 148
Entire logging duration	] → 🗎 148
► Display channel 1	]
► Display channel 2	]
► Display channel 3	]
► Display channel 4	]

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign channel 1	The <b>Extended HistoROM</b> application package is available.	Assign process variable to logging channel.	<ul> <li>Off</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Carrier mass flow*</li> <li>Density</li> <li>Reference density</li> <li>Concentration*</li> <li>Temperature</li> <li>Carrier pipe temperature*</li> <li>Electronic temperature</li> <li>Oscillation frequency 0</li> <li>Frequency fluctuation 0</li> <li>Oscillation amplitude*</li> <li>Oscillation damping 0</li> <li>Oscillation damping fluctuation 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>Current output 1</li> <li>Current output 2*</li> <li>Current output 3*</li> <li>Current output 4*</li> <li>HBSI*</li> </ul>
Assign channel 2	The <b>Extended HistoROM</b> application package is available. The software options currently enabled are displayed in the <b>Software option overview</b> parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> <b>channel 1</b> parameter (→ ≌ 147)
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> channel 1 parameter (→ ≌ 147)
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> channel 1 parameter (→ ≌ 147)
Logging interval	The <b>Extended HistoROM</b> application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 999.0 s
Clear logging data	The <b>Extended HistoROM</b> application package is available.	Clear the entire logging data.	<ul><li>Cancel</li><li>Clear data</li></ul>
Data logging	-	Select the data logging method.	<ul><li> Overwriting</li><li> Not overwriting</li></ul>
Logging delay	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Enter the time delay for measured value logging.	0 to 999 h
Data logging control	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Start and stop measured value logging.	<ul><li>None</li><li>Delete + start</li><li>Stop</li></ul>

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface
Data logging status	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the measured value logging status.	<ul><li>Done</li><li>Delay active</li><li>Active</li><li>Stopped</li></ul>
Entire logging duration	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the total logging duration.	Positive floating-point number

\* Visibility depends on order options or device settings

# 12 Diagnostics and troubleshooting

# 12.1 General troubleshooting

### For local display

Error	Possible causes	Solution
Local display dark and no output signals	Supply voltage does not match the value indicated on the nameplate.	Apply the correct supply voltage .
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective. Main electronics module is defective.	Order spare part → 🗎 194.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	<ol> <li>Check the connection of the electrode cable and correct if necessary.</li> <li>Check the connection of the coil current cable and correct if necessary.</li> </ol>
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul> <li>Set the display brighter by simultaneously pressing  + E.</li> <li>Set the display darker by simultaneously pressing  + E.</li> </ul>
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🗎 194.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 164$
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	<ol> <li>Press □ + ★ for 2 s ("home position").</li> <li>Press E.</li> <li>Set the desired language in the <b>Display language</b> parameter (→ ≅ 127).</li> </ol>
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul> <li>Check the cable and the connector between the main electronics module and display module.</li> <li>Order spare part →</li></ul>

### For output signals

Error	Possible causes	Solution
Signal output outside the valid range	Main electronics module is defective.	Order spare part $\rightarrow \square$ 194.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol> <li>Check and correct parameter configuration.</li> <li>Observe limit values specified in the "Technical Data".</li> </ol>

### For access

Error	Possible causes	Solution
No write access to parameters	Hardware write protection enabled	Set the write protection switch on main electronics module to the <b>OFF</b> position $\rightarrow \textcircled{B}$ 136.
No write access to parameters	Current user role has limited access authorization	1. Check user role $\rightarrow \square$ 73. 2. Enter correct customer-specific access code $\rightarrow \square$ 73.
No connection via FOUNDATION Fieldbus	Device plug connected incorrectly	Check the pin assignment of the connector .
Not connecting to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary→ 🗎 80.
	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) → 🗎 76→ 🗎 76. 2. Check the network settings with the IT manager.
Not connecting to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 $\rightarrow \square$ 76 $\rightarrow \square$ 76
Not connecting to Web server	Incorrect WLAN access data	<ul> <li>Check WLAN network status.</li> <li>Log on to the device again using WLAN access data.</li> <li>Verify that WLAN is enabled on the measuring device and operating device →</li></ul>
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	<ul> <li>Check if WLAN reception is present: LED on display module is lit blue</li> <li>Check if WLAN connection is enabled: LED on display module flashes blue</li> <li>Switch on instrument function.</li> </ul>
Network connection not present or unstable	WLAN network is weak.	<ul> <li>Operating device is outside of reception range: Check network status on operating device.</li> <li>To improve network performance, use an external WLAN antenna.</li> </ul>
	Parallel WLAN and Ethernet communication	<ul> <li>Check network settings.</li> <li>Temporarily enable only the WLAN as an interface.</li> </ul>

Error	Possible causes	Solution
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	<ol> <li>Check cable connection and power supply.</li> <li>Refresh the Web browser and restart if necessary.</li> </ol>
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	<ol> <li>Use the correct Web browser version →</li></ol>
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	<ul><li> JavaScript not enabled</li><li> JavaScript cannot be enabled</li></ul>	1. Enable JavaScript. 2. Enter http://XXX.XXX.X.XXX/ basic.html as the IP address.
Operation with FieldCare or DeviceCare via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.

# 12.2 Diagnostic information via light emitting diodes

### 12.2.1 Transmitter

### Proline 500 – digital

Different LEDs in the transmitter provide information on the device status.



- Supply voltage Device status 1
- 2
- 3 Not used
- 4 Communication 5
- Service interface (CDI) active

1. Open the housing cover.

- 2. Remove the display module.
- 3. Fold open the terminal cover.

LED		Color	Meaning
1	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.
2	Device status (normal	Red	Problem
operation)	operation)	Flashing red	Warning
2 Device status (during	Flashes red slowly	If > 30 seconds: problem with the boot loader.	
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	White	Communication active.
5	Service interface (CDI)	Yellow	Connection established.
		Flashing yellow	Communication active.
		Off	No connection.

### Proline 500

Different LEDs in the transmitter provide information on the device status.



- Supply voltage Device status 1
- 2
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

LED		Color	Meaning
1	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.
2	Device status (normal	Red	Problem
	operation)	Flashing red	Warning
2 Device status (during start-up)	Flashes red slowly	If $>$ 30 seconds: problem with the boot loader.	
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	White	Communication active.
5	Service interface (CDI)	Yellow	Connection established.
		Flashing yellow	Communication active.
		Off	No connection.

#### 12.2.2 Sensor connection housing

### Proline 500 - digital

Various light emitting diodes (LED) on the ISEM electronics (Intelligent Sensor Electronic Module) in the sensor connection housing provide information on the device status.



- 1 Communication
- 2 Device status
- 3 Supply voltage

LED		Color	Meaning
1	Communication	White	Communication active.
2	Device status (normal	Red	Problem
	operation)	Flashing red	Warning
2 Device status (du	Device status (during	Flashes red slowly	If $>$ 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.

#### 12.3 Diagnostic information on local display

#### 12.3.1 **Diagnostic message**

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter  $\rightarrow \square$  185
- Via submenus → 
   <sup>1</sup>
   <sup>186</sup>

### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).



The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required

Symbol	Meaning
F	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
С	<b>Function check</b> The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
М	Maintenance required Maintenance is required. The measured value remains valid.

### Diagnostic behavior

Symbol	Meaning		
8	<ul> <li>Alarm</li> <li>Measurement is interrupted.</li> <li>Signal outputs and totalizers assume the defined alarm condition.</li> <li>A diagnostic message is generated.</li> </ul>		
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.		

### **Diagnostic information**

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### **Operating elements**

Кеу	Meaning	
	Plus key	
(+)	<i>In a menu, submenu</i> Opens the message about remedy information.	
	Enter key	
E	In a menu, submenu Opens the operating menu.	



### 12.3.2 Calling up remedial measures

Press 🗄 (① symbol).

- └ The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with  $\pm$  or  $\Box$  and press  $\mathbb{E}$ .
  - └ The message about the remedial measures opens.
- 3. Press = +  $\pm$  simultaneously.
  - └ The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

- 1. Press E.
  - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press + + simultaneously.
  - $\blacktriangleright$  The message for the remedial measures closes.

## 12.4 Diagnostic information in the Web browser

### 12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedy information with Service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter  $\rightarrow \triangleq 185$
- Via submenu → 
   <sup>™</sup>
   <sup>™</sup>
   186

### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning		
FailureA device error has occurred. The measured value is no longer valid.			
Ŵ	<b>Function check</b> The device is in service mode (e.g. during a simulation).		
<u>^?</u>	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)		
$\diamond$	Maintenance required Maintenance is required. The measured value is still valid.		

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

### 12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

## 12.5 Diagnostic information in FieldCare or DeviceCare

### 12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

D 🛩 🖬   🍜   📾   👼   🔍   📖  🗽 Xxxxxx//	12	
Device name: XXXXXXX Device tag: XXXXXXX Status signal:	Mass flow:       I 12.34       kg/h         Volume flow:       I 12.34       m³/h         Function check (C)       IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	
XXXXXX      PDiagnostics 1:      Panedu information:	C485 Simu Descrivate	
Access status tooling:     Operation     Setup     Diagnostics     Expert	Mainenance       Failure (F)         Function check (C)       Diagnostics 1:         Remedy information:       Deactivate Simulation (Service)         Out of spezification (S)       Maintenance required (M)	ari V 2 V

- 1 Status area with status signal  $\rightarrow \square$  155
- 2 Diagnostic information  $\rightarrow \square 156$
- 3 Remedy information with Service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter  $\rightarrow \square$  185
- Via submenu → 🗎 186

#### **Diagnostic information**

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### 12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
- Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu

Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
  - ← A tool tip with remedy information for the diagnostic event appears.

## 12.6 Adapting the diagnostic information

### 12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

 $\texttt{Expert} \rightarrow \texttt{System} \rightarrow \texttt{Diagnostic} \text{ handling} \rightarrow \texttt{Diagnostic} \text{ behavior}$ 

오 //Diagn. behavior	0723-1	
Diagnostic no. 044		
	Warning	
Diagnostic no. 274		
Diagnostic no. 801		
		A00140

■ 38 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the <b>Event logbook</b> submenu ( <b>Event list</b> submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

### 12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic** event category submenu.

Expert  $\rightarrow$  Communication  $\rightarrow$  Diagnostic event category

### Available status signals

Configuration as per FOUNDATION Fieldbus Specification (FF912), in accordance with NAMUR NE107.

Symbol	Meaning
F 40013956	Failure A device error is present. The measured value is no longer valid.
C 40013959	<b>Function check</b> The device is in service mode (e.g. during a simulation).

	Symbol	Meaning		
A0013958       Out of specification         The device is being operated:       • Outside its technical specification limits (e.g. outside the process         • Outside of the configuration carried out by the user (e.g. maxim: 20 mA value)		<ul> <li>Out of specification</li> <li>The device is being operated:</li> <li>Outside its technical specification limits (e.g. outside the process temperature range)</li> <li>Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)</li> </ul>		
	A0013957	Maintenance required Maintenance is required. The measured value is still valid.		

#### Enabling the configuration of the diagnostic information according to FF912

For compatibility reasons, the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912 is not enabled when the device is delivered from the factory.

# Enabling the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912

1. Open the Resource block.

- 2. In Feature Selection parameter, select Multi-bit Alarm (Bit-Alarm) Support option.
  - └ The diagnostic information can be configured according to FOUNDATION Fieldbus Specification FF912.

### Grouping the diagnostic information

Diagnostic information is assigned to different groups. The groups differ depending on the weighting (severity) of the diagnostic event:

- Highest weighting
- High weighting
- Low weighting

Assignment of the diagnostic information (factory setting)

The assignment of the diagnostic information ex-works is indicated in the following tables.

The individual ranges of the diagnostic information can be assigned to another status signal  $\rightarrow \cong 162$ .

Some diagnostic information can be assigned individually, irrespective of their range  $\rightarrow \cong 163$ .

P Overview and description of all diagnostic information → 🗎 164

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Highest	Failure (F)	Sensor	F000 to 199
		Electronics	F200 to 399
		Configuration	F400 to 700
		Process	F800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
High	Function check (C)	Sensor	C000 to 199
		Electronics	C200 to 399

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
		Configuration	C400 to 700
		Process	C800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Out of specification (S)	Sensor	S000 to 199
		Electronics	S200 to 399
		Configuration	S400 to 700
		Process	S800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Maintenance required (M)	Sensor	M000 to 199
		Electronics	M200 to 399
		Configuration	M400 to 700
		Process	M800 to 999

### Changing the assignment of the diagnostic information

The individual ranges of the diagnostic information can be assigned to another status signal. This is done by changing the bit in the associated parameter. The bit change always applies for the entire range of the diagnostic information.

Some diagnostic information can be assigned individually, irrespective of their range  $\rightarrow \cong 163$ 

Each status signal has a parameter in the Resource Block in which it is possible to define the diagnostic event for which the status signal is transmitted:

- Failure (F): **FD\_FAIL\_MAP** parameter
- Function check (C): **FD\_CHECK\_MAP** parameter
- Out of specification (S): FD\_OFFSPEC\_MAP parameter
- Maintenance required (M): FD\_MAINT\_MAP parameter

Structure and assignment of the parameters for the status signals (factory setting)

Weighting	Allocation	Bit	FD_ FAIL_ MAP	FD_ CHECK_ MAP	FD_ OFFSPEC_ MAP	FD_ MAINT_ MAP
Highest	Sensor	31	1	0	0	0
	Electronics	30	1	0	0	0
	Configuration	29	1	0	0	0
	Process	28	1	0	0	0
High	Sensor	27	0	1	0	0
	Electronics	26	0	1	0	0
	Configuration	25	0	1	0	0
	Process	24	0	1	0	0
Low	Sensor	23	0	0	1	0
	Electronics	22	0	0	1	0
	Configuration	21	0	0	1	0

Weighting	Allocation	Bit	FD_ FAIL_ MAP	FD_ CHECK_ MAP	FD_ OFFSPEC_ MAP	FD_ MAINT_ MAP
	Process	20	0	0	1	0
Low	Sensor	19	0	0	0	1
	Electronics	18	0	0	0	1
	Configuration	17	0	0	0	1
	Process	16	0	0	0	1
Configurable range → 🗎 163		15 to 1	0	0	0	0
Reserved (Fieldbus Foundat	ion)	0	0	0	0	0

### Changing the status signal for a range of diagnostic information

Example: The status signal for the diagnostic information for electronics with the "Highest" weighting is to be changed from failure (F) to function check (C).

- 1. Set the Resource Block to the **OOS** block mode.
- 2. Open the **FD\_FAIL\_MAP** parameter in the Resource Block.
- 3. Change **Bit 30** to **0** in the parameter.
- 4. Open the **FD\_CHECK\_MAP** parameter in the Resource Block.
- 5. Change **Bit 26** to **1** in the parameter.
  - If a diagnostic event occurs for electronics with the "Highest weighting", the diagnostic information to this effect is displayed with the function check (C) status signal.
- 6. Set the Resource Block to the **AUTO** block mode.

### NOTICE

#### No status signal is assigned to an area of diagnostic information.

If a diagnostic event occurs in this area, no status signal is transmitted to the control system.

 If you are changing the parameters, make sure that a status signal is assigned to all areas.

If FieldCare is used, the status signal is enabled and disabled using the check box of the particular parameter.

Assigning diagnostic information individually to a status signal

Some diagnostic information can be individually assigned to a status signal, irrespective of their original range.

Assigning diagnostic information individually to a status signal via FieldCare.

In the FieldCare navigation window: Expert → Communication → Field diagnostics
 → Alarm detection enable

2. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.

- 3. Press Enter to confirm.
- When selecting the desired status signal (e.g. Offspec Map), also select the Configurable Area Bit 1 to Configurable Area Bit 15 that was assigned previously to the diagnostic information (step 2).
- 5. Press Enter to confirm.
  - └ The diagnostic event of the selected diagnostic information is recorded.

- 6. In the FieldCare navigation window: **Expert** → **Communication** → **Field diagnostics** → **Alarm broadcast enable**
- Select the desired diagnostic information from one of the fields Configurable Area Bits 1 to Configurable Area Bits 15.
- 8. Press Enter to confirm.
- 9. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 7).
- 10. Press Enter to confirm.
  - └ The selected diagnostic information is transmitted over the bus when a diagnostic event to this effect occurs.
- A change in the status signal does not affect diagnostic information that already exists. The new status signal is only assigned if this error occurs again after the status signal has changed.

#### Transmitting the diagnostic information over the bus

Prioritizing diagnostic information for transmission over the bus

Diagnostic information is only transmitted over the bus if its priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Diagnostic information with priority 0 (factory setting) is ignored.

It is possible to change the priority individually for the different status signals. The following parameters of the Resource Block are used for this purpose:

- FD\_FAIL\_PRI
- FD\_CHECK\_PRI
- FD\_OFFSPEC\_PRI
- FD\_MAINT\_PRI

Suppressing certain diagnostic information

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare **Expert**  $\rightarrow$  **Communication**  $\rightarrow$  **Field diagnostics**  $\rightarrow$  **Alarm broadcast enable**. The mask is a negative selection mask, i.e. if a field is selected the associated diagnostic information is not transmitted over the bus.

## 12.7 Overview of diagnostic information

• The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

• All of the measured variables affected in the entire Promass instrument family are always listed under "Measured variables affected". The measured variables available for the device in question depend on the device version. When assigning the measured variables to the device functions, for example to the individual outputs, all of the measured variables available for the device version in question are available for selection.



## 12.7.1 Diagnostic of sensor

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
022	Temperature sensor defective		1. Check or replace sensor	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		electronic module (ISEM) 2. If available: Check connection	<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Bad cable between sensor and	cable between sensor and	<ul> <li>Switch output status</li> </ul>
	Quality substatus	Sensor failure	3. Replace sensor	<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

#### 1) Status signal can be changed.

	Diagnostic	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
046	Sensor limit exceeded		1. Inspect sensor	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from the factory] 1)		2. Check process condition	<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
			-	
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
062	Sensor connection faulty		1. Check or replace sensor	<ul> <li>Empty pipe detection option</li> <li>Low flow cut off option</li> </ul>
	Measured variable status		electronic module (ISEM) 2. If available: Check connection cable between sensor and	
	Quality Bad	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Sensor failure 3. Replace sensor	3. Replace sensor	<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] $^{1)}$	F		
	Diagnostic behavior	Alarm		

	Diagnostic	nformation	Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
063	Exciter current faulty		1. Check or replace sensor	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status		2. If available: Check connection	<ul><li> Low flow cut off option</li></ul>	
	Quality	Bad	cable between sensor and transmitter 3. Replace sensor		
	Quality substatus	Sensor failure			
	Status signal [from the factory] $^{1)}$	S			
	Diagnostic behavior	Alarm			

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
082	Data storage	ita storage		<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Contact service	<ul> <li>Description</li> <li>Low flow cut off option</li> <li>Switch output status</li> <li>Option</li> </ul>
	Quality	Bad		
	Quality substatus	Sensor failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
083	Memory content	ntent	1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Restore HistoROM S-DAT backup ('Device reset' parameter)	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad	3. Replace HistoROM S-DAT	<ul> <li>Switch output status</li> </ul>
	Quality substatus	Sensor failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

Status signal can be changed. 1)

	Diagnostic	information	Remedy instructions	Influenced measured	
No.	S	hort text		variables	
140	Sensor signal asymmetrical		1. Check or replace sensor	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status [from	the factory] <sup>1)</sup>	electronic module (ISEM) 2. If available: Check connection cable between sensor and transmitter 3. Replace sensor	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> </ul>	
	Quality	Good			
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>	
	Status signal [from the factory] <sup>2)</sup>	S			
	Diagnostic behavior [from the factory] <sup>3)</sup>	Alarm			

Quality can be changed. This causes the overall status of the measured variable to change. Status signal can be changed. 1)

2)

3) Diagnostic behavior can be changed.

Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables
144	Measuring error too high		1. Check or change sensor	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>	2. Check process conditions	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> </ul>
	Quality	Good		
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	F		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Alarm		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

## 12.7.2 Diagnostic of electronic

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
201	Device failure		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Contact service op	<ul> <li>Low flow cut off option</li> </ul>
	Quality	Bad		<ul> <li>Switch output status option</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
242	Software incompatible		1. Check software	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Flash or change main electronics module	<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status ontion</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
			-	
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	nformation	Remedy instructions	Influenced measured	
No.	Short text			variables	
252	Modules incompatible		1. Check electronic modules	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status		2. Change electronic modules	<ul> <li>Low flow cut off option</li> </ul>	
	Quality	Bad		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>	
	Quality substatus	Device failure			
	Status signal [from the factory] $^{1)}$	F			
	Diagnostic behavior	Alarm			

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
262	Sensor electronic connection fault	у	1. Check or replace connection	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		cable between sensor electronic module (ISEM) and main	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad	electronics 2. Check or replace ISEM or main electronics	<ul> <li>Pressure option</li> </ul>
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
270	Main electronic failure		Change main electronic module	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] $^{1)}$	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
271	Main electronic failure		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Change main electronic module	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic	nformation	Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
272	Main electronic failure		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status		2. Contact service option  Low flow cut off op	2. Contact service option   Low flow cut of	<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>	
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>	
	Status signal [from the factory] <sup>1)</sup>	F			
	Diagnostic behavior	Alarm			

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
273	Main electronic failure		Change electronic	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

### 1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
275	I/O module 1 to n defective		Change I/O module	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul> <li>Description</li> <li>Low flow cut off option</li> </ul>
	Quality	Bad		<ul> <li>Switch output status</li> <li>option</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
276	I/O module 1 to n faulty       Measured variable status		1. Restart device	<ul> <li>Empty pipe detection option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
			2. Change I/O module	
	Quality	Uncertain		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
276	I/O module 1 to n faulty		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		Low flow cut off option	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Device failure		
			-	
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
283	Memory content		1. Reset device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Contact service option  Low flow cut o	<ul><li><b>Low flow cut off</b> option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
			1	
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
302	Device verification active		Device verification active, please	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		wait.	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Device failure		
	Status signal [from the factory] $^{1)}$	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
311	1 Electronic failure	1. Do not reset device	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status		2. Contact service	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	M		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
332	Writing in embedded HistoROM fa	ailed	Replace user interface board	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		Ex d/XP: replace transmitter	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status</li> <li>option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
361	I/O module 1 to n faulty		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Check electronic modules 3. Change I/O Modul or main electronics • Low flow cut off • Switch output sta option • Pressure option	<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

### 1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
372	Sensor electronic (ISEM) faulty		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		<ol> <li>Check if failure recurs</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status</li> <li>option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
		· T		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
373	873     Sensor electronic (ISEM) faulty       Measured variable status	1. Transfer data or reset device	<ul> <li>Empty pipe detection</li> </ul>	
			2. Contact service	option <ul> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

Diagnostic information		Remedy instructions	Influenced measured		
No.	SI	nort text		variables	
374	Sensor electronic (ISEM) faulty		1. Restart device	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status [from	the factory] <sup>1)</sup>	<ol> <li>Check if failure recurs</li> <li>Replace sensor electronic module</li> </ol>	<ul> <li>Low flow cut off option</li> </ul>	
	Quality	Good	(ISEM)	<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>	
	Quality substatus	Non specific			
	Status signal [from the factory] $^{2)}$	S			
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning			

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) 3) Status signal can be changed.

Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
375	I/O- 1 to n communication failed	I/O- 1 to n communication failed 1. Restart device	1. Restart device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		<ol> <li>Check if failure recurs</li> <li>Replace module rack inclusive</li> </ol>	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad	electronic modules	<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Device failure		
	Status signal [from the factory] $^{1)}$	F		
	Diagnostic behavior	Alarm		

#### Status signal can be changed. 1)

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
382	2 Data storage		1. Insert T-DAT	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Replace T-DAT	<ul> <li>• Low flow cut off option</li> <li>• Pressure option</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

Status signal can be changed. 1)

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
383	Memory content .	1. Restart device	<ul> <li>Empty pipe detection option</li> <li>Low flow cut off option</li> </ul>	
	Measured variable status			2. Delete T-DAT via 'Reset device' parameter
	Quality	Bad	3. Replace T-DAT	<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Device failure		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

Diagnostic information		Remedy instructions	Influenced measured	
No.	S	hort text		variables
387	Embedded HistoROM failed		Contact service organization	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul> <li>Dow flow cut off option</li> <li>Switch output status</li> </ul>
	Quality	Bad		
	Quality substatus	Device failure		<ul> <li>Pressure option</li> </ul>
		· -		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

## 12.7.3 Diagnostic of configuration

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
303	I/O 1 to n configuration changed		1. Apply I/O module configuration	-
	Measured variable status		(parameter 'Apply 1/O configuration')	
	Quality	Good	2. Afterwards reload device	
	Quality substatus	Non specific		
		1		
	Status signal [from the factory] <sup>1)</sup>	M		
	Diagnostic behavior	Warning		

### 1) Status signal can be changed.

No.	Diagnostic information Short text		Remedy instructions	Influenced measured variables
330	Flash file invalid		1. Update firmware of device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Restart device option • Low flow cut off option	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Configuration error		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	М		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
331	Firmware update failed		1. Update firmware of device	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Restart device	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status ontion</li> </ul>
	Quality substatus	Configuration error		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Warning		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
410	Data transfer		1. Check connection	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Retry data transfer	<ul><li>Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Configuration error		
	Status signal [from the factory] <sup>1</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
412	Processing download		Download active, please wait	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul><li> Low flow cut off option</li></ul>
	Quality	Uncertain		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific	-	<ul> <li>Pressure option</li> </ul>
			1	
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
431	Trim 1 to n		Carry out trim	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
437	Configuration incompatible		1. Restart device	<ul> <li>Empty pipe detection option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Measured variable status		2. Contact service	
	Quality	Bad		
	Quality substatus	Configuration error		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
438	Dataset :		1. Check data set file	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		<ol> <li>Check device configuration</li> <li>Up- and download new</li> </ol>	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status</li> </ul>
	Quality	Uncertain	configuration	<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	М		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
441	Current output 1 to n		1. Check process	-
	Measured variable status		2. Check current output settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] $^{1)}$	S		
	Diagnostic behavior [from the factory] $^{2)}$	Warning		

#### 1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
442	Frequency output 1 to n		1. Check process	-
	Measured variable status		2. Check frequency output settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	S		
	Diagnostic behavior [from the factory] <sup>2)</sup>	Warning		

1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
443	Pulse output 1 to n		1. Check process	-
	Measured variable status		2. Check pulse output settings	
	Quality	Good		
	Quality substatus	Non specific		
			-	
	Status signal [from the factory] <sup>1)</sup>	S		
	Diagnostic behavior [from the factory] <sup>2)</sup>	Warning		

1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
444	Current input 1 to n		1. Check process	-
	Measured variable status		2. Check current input settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	S		
	Diagnostic behavior [from the factory] <sup>2)</sup>	Warning		

1)

Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
453	Flow override		Deactivate flow override	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		-	<ul> <li>option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
463	Analog input 1 to n selection inva	lid	1. Check module/channel	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		2. Check I/O module configuration • Low flow cut o	<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Configuration error		
			1	
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
484	Failure mode simulation		Deactivate simulation	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul><li> Low flow cut off option</li></ul>
	Quality	Bad		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Configuration error		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	C		
	Diagnostic behavior	Alarm		

### 1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
485	Measured variable simulation		Deactivate simulation	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status option</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	C		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
486	Current input 1 to n simulation		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] "	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Influenced measured
No.	SI	nort text		variables
491	Current output 1 to n simulation		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] $^{1)}$	С		
	Diagnostic behavior	Warning		

Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	hort text		variables
492	Simulation frequency output 1 to a	n	Deactivate simulation frequency	-
	Measured variable status		output	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] $^{1)}$	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
493	Simulation pulse output 1 to n		Deactivate simulation pulse output	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
494	Switch output simulation 1 to n		Deactivate simulation switch output	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	C		
	Diagnostic behavior	Warning		

Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	hort text		variables
495	Diagnostic event simulation		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
496	Status input simulation		Deactivate simulation status input	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
			1	
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

### 1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		Variables
497	Simulation block output		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
520	I/O 1 to n hardware configuration	invalid	1. Check I/O hardware	-
	Measured variable status		configuration 2. Replace wrong I/O module 3. Plug the module of double pulse output on correct slot	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
537	Configuration		<ol> <li>Check IP addresses in network</li> <li>Change IP address</li> </ol>	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Influenced measured
No.	Short text			variables
594	Relay output simulation         Measured variable status		Deactivate simulation switch output	-
	Quality	Good		
	Quality substatus	Non specific		
			1	
	Status signal [from the factory] <sup>1)</sup>	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

## 12.7.4 Diagnostic of process

Diagnostic information			Remedy instructions	Influenced measured variables
No.	Short text			
803	Current loop 1 to n		<ol> <li>Check wiring</li> <li>Change I/O module</li> </ol>	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1</sup>	F		
	Diagnostic behavior	Alarm		
	Diagnostic i	nformation	Remedy instructions	Influenced measured
-----	--	----------------------------	---------------------------------	--
No.	SI	nort text		variables
830	Sensor temperature too high		Reduce ambient temp. around the	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from t	the factory] <sup>1)</sup>	sensor housing	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
831	Sensor temperature too low		Increase ambient temp. around the	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>	sensor housing	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific	-	<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
832	Electronic temperature too high		Reduce ambient temperature	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>	<ul> <li>option</li> <li>Low flow cut off op</li> </ul>	<ul><li>Description</li><li>Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured	
No.	SI	hort text		variables	
833	Electronic temperature too low		Increase ambient temperature	<ul> <li>Empty pipe detection</li> </ul>	
	Measured variable status [from	the factory] <sup>1)</sup>		<ul><li>Low flow cut off option</li></ul>	
	Quality	Good		<ul> <li>Switch output status</li> </ul>	
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>	
	Status signal [from the factory] <sup>2)</sup>	S			
	Diagnostic behavior [from the factory] $^{3)}$	Warning			

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
834	Process temperature too high		Reduce process temperature	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>		<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) 3) Status signal can be changed.

Diagnostic behavior can be changed.

No.	Diagnostic i Sł	nformation nort text	Remedy instructions	Influenced measured variables
835	Process temperature too low		Increase process temperature  Increa	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>		<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Quality substatus	Non specific		
	Status signal (from the factory) <sup>2</sup>	c.		
	Status signal [ITOIII the factory]	3		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
842	Process limit		Low flow cut off active!	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status		1. Check low flow cut off configuration	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status option</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>1)</sup>	S		
	Diagnostic behavior	Warning		

#### 1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
843	Process limit		Check process conditions	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status			<ul><li>option</li><li>Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
			]	
	Status signal [from the factory] <sup>1)</sup>	S		
	Diagnostic behavior	Alarm		

## 1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		Variables
862	Partly filled pipe		1. Check for gas in process	-
	Measured variable status [from the factory] 1)		2. Adjust detection limits	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

No.	Diagnostic i SI	information hort text	Remedy instructions	Influenced measured variables
882	Input signal		1. Check input configuration	-
	Measured variable status		2. Check external device or process conditions	
	Quality	Bad		
	Quality substatus	Non specific		
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
910	Tubes not oscillating		1. Check electronic	<ul> <li>Empty pipe detection option</li> <li>Low flow cut off option</li> <li>Switch output status option</li> <li>Pressure option</li> </ul>
	Measured variable status		2. Inspect sensor	
	Quality	Bad		
	Quality substatus	Non specific		
			-	
	Status signal [from the factory] <sup>1)</sup>	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
912	Medium inhomogeneous		1. Check process cond.	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from t	the factory] <sup>1)</sup>	<ul> <li>2. Increase system pressure option</li> <li>Low flow cut off op</li> </ul>	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) 3) Status signal can be changed.

Diagnostic behavior can be changed.

Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables
913	Medium unsuitable		1. Check process conditions	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>	2. Check electronic modules or sensor	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2)</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

Quality can be changed. This causes the overall status of the measured variable to change. 1)

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables
944	Monitoring failed		Check process conditions for	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>	Heartbeat Monitoring	<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] <sup>2</sup>	S		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
948	Oscillation damping too high		Check process conditions	<ul> <li>Empty pipe detection</li> </ul>
	Measured variable status [from	the factory] <sup>1)</sup>		<ul><li> Low flow cut off option</li></ul>
	Quality	Good		<ul> <li>Switch output status</li> </ul>
	Quality substatus	Non specific		<ul> <li>Pressure option</li> </ul>
	Status signal [from the factory] 27	5		
	Diagnostic behavior [from the factory] <sup>3)</sup>	Warning		

1) Quality can be changed. This causes the overall status of the measured variable to change.

2) Status signal can be changed.

3) Diagnostic behavior can be changed.

# 12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

To call up the measures to rectify a diagnostic event:

- Via local display  $\rightarrow \square 157$
- Via Web browser → 
   <sup>1</sup> 158
- Via "FieldCare" operating tool → 
   <sup>(1)</sup>
   <sup>(2)</sup>
   <sup>(</sup>
- Via "DeviceCare" operating tool → 
   <sup>™</sup>
   <sup>™</sup>
   159

Other pending diagnostic events can be displayed in the **Diagnostic list** submenu  $\rightarrow \cong 186$ 

## Navigation

"Diagnostics" menu

Ċ Diagnostics			
	Actual diagnostics		→ 🗎 186
	Previous diagnostics		→ 🗎 186

Operating time from restart		→ 🖺 186
Operating time	]	→ 🗎 186

## Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

# 12.9 Diagnostic messages in the DIAGNOSTIC Transducer Block

- The Actual diagnostics parameter (actual diagnostics) displays the message with the highest priority.
- A list of the active alarms can be viewed via the Diagnostics 1 parameter (diagnostics\_1) to Diagnostics 5 (diagnostics 5). If more than 5 messages are pending, the messages with the highest priority are shown on the display.
- You can view the last alarm that is no longer active via the **Previous diagnostics** parameter (**previous\_diagnostics**).

# 12.10 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

## Navigation path

Diagnostics  $\rightarrow$  Diagnostic list

오 //Diagnose list
Diagnostics
SF273 Main electronic
Diagnostics 2
Diagnostics 3

39 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- ′ Via local display → 🖺 157
- Via Web browser → 
   <sup>1</sup> 158
- Via "DeviceCare" operating tool  $\rightarrow \triangleq 159$

# 12.11 Event logbook

## 12.11.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

#### Navigation path

**Diagnostics** menu  $\rightarrow$  **Event logbook** submenu  $\rightarrow$  Event list



<sup>■ 40</sup> Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events  $\rightarrow \square 164$
- Information events  $\rightarrow \triangleq 188$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - $\mathfrak{D}$ : Occurrence of the event
- 🕞: End of the event
- Information event

 $\odot$ : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display  $\rightarrow \implies 157$
- Via Web browser → 

   <sup>™</sup>
   158
- Via "FieldCare" operating tool  $\rightarrow \square$  159

For filtering the displayed event messages → 
<sup>188</sup>

## 12.11.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

## Navigation path

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Filter options

## Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

## 12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Embedded HistoROM deleted
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1184	Display connected
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1256	Display: access status changed
I1278	I/O module reset detected
I1335	Firmware changed
I1361	Web server login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1447	Record application reference data
I1448	Application reference data recorded
I1449	Recording application ref. data failed
I1450	Monitoring off

Info number	Info name
I1451	Monitoring on
I1457	Measured error verification failed
I1459	I/O module verification failed
I1460	HBSI verification failed
I1461	Sensor verification failed
I1462	Sensor electronic module verific. failed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1618	I/O module replaced
I1619	I/O module replaced
I1621	I/O module replaced
I1622	Calibration changed
I1624	Reset all totalizers
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server login successful
I1628	Display login successful
I1629	CDI login successful
I1631	Web server access changed
I1632	Display login failed
I1633	CDI login failed
I1634	Parameter factory reset
I1635	Parameter delivery reset
I1637	FOUNDATION Fieldbus specific reset done
I1639	Max. switch cycles number reached
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1712	New flash file received
I1725	Sensor electronic module (ISEM) changed
I1726	Configuration backup failed

# 12.12 Resetting the measuring device

Using the **Restart** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

## 12.12.1 Function scope of the "Restart" parameter

Options	Description
Uninitialized	The selection has no effect on the device.
Run	The selection has no effect on the device.
Resource	The selection has no effect on the device.

Options	Description
Defaults       All FOUNDATION Fieldbus blocks are reset to their factory settings         Example: Analog Input Channel to the Uninitialized option.	
Processor	The device is restarted.
To delivery settings	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information) and device parameters for which a customer-specific default setting was ordered are reset to this customer-specific value.

## 12.12.2 Function scope of the "Service reset" parameter

Options	Description
Uninitialized	The selection has no effect on the device.
To delivery settings + MIB	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information, device tag and device address) and the device parameters for which a customer-specific default setting was ordered, are reset to this customer-specific value.
ENP restart	The parameters of the electronic name plate are reset. The device is restarted.

# 12.13 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

## Navigation

"Diagnostics" menu  $\rightarrow$  Device information

► Device information	
Device tag	] → 🗎 191
Serial number	→ 🗎 191
Device name	) → 🗎 191
Firmware version	) → 🗎 191
Order code	] → 🗎 191
Extended order code 1	) → 🗎 191
Extended order code 2	) → 🗎 191
ENP version	] → 🗎 191

Parameter	Description	User entry / User interface	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /)	-
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Promass 300/500	-
Firmware version	Shows the device firmware version installed.	Character string with the following format: xx.yy.zz	-
Order code	Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).	Character string in the format xx.yy.zz	-

## Parameter overview with brief description

# 12.14 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
02.2017	01.00.zz	Option <b>74</b>	Original firmware	Operating Instructions	BA01565D/06/EN/01.16

It is possible to flash the firmware to the current version or the previous version using the service interface.

For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

- The manufacturer's information is available:
  - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
  - Specify the following details:
    - Product root: e.g. 805B
       The product root is the first part of the order code: see the nameplate on the device.
    - Text search: Manufacturer's information
    - Media type: Documentation Technical Documentation

# 13 Maintenance

## 13.1 Maintenance tasks

No special maintenance work is required.

## 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

# 13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment:  $\rightarrow \square 196 \rightarrow \square 198$ 

# 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

# 14 Repair

# 14.1 General notes

## 14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

## 14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ► Document every repair and each conversion and enter them into the *W*@*M* life cycle management database.

# 14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

P Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu.

# 14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

# 14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the website for more information: http://www.endress.com/support/return-material
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

# 14.5 Disposal

## X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.

## 14.5.1 Removing the measuring device

1. Switch off the device.

## **WARNING**

## Danger to persons from process conditions.

 Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

## 14.5.2 Disposing of the measuring device

## **WARNING**

## Danger to personnel and environment from fluids that are hazardous to health.

 Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

# 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

# 15.1 Device-specific accessories

# 15.1.1 For the transmitter

Accessories	Description	
Transmitter • Proline 500 – digital • Proline 500	Transmitter for replacement or storage. Use the order code to define the following specifications: • Approvals • Output • Input • Display/operation • Housing • Software	
	<ul> <li>Profine 500 - digital transmitter: Order number: 8X5BXX-*****A</li> <li>Proline 500 transmitter: Order number: 8X5BXX-******B</li> </ul>	
	Proline 500 transmitter for replacement: It is essential to specify the serial number of the current transmitter when ordering. Based on the serial number, the device-specific data (e.g., calibration factors) of the replacement device can be used for the new transmitter.	
	<ul> <li>Proline 500 - digital transmitter: Installation Instructions EA01151D</li> <li>Proline 500 transmitter: Installation Instructions EA01152D</li> </ul>	
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area".	
	<ul> <li>applications.</li> <li>Further information on the WLAN interface →  ■ 82.</li> </ul>	
	Order number: 71351317	
	Installation Instructions EA01238D	
Pipe mounting set	Pipe mounting set for transmitter.	
	Order number: 71346427	
	Installation Instructions EA01195D	
	Proline 500 transmitter Order number: 71346428	
Protective cover Transmitter	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.	
<ul><li>Proline 500 - digital</li><li>Proline 500</li></ul>	<ul> <li>Proline 500 - digital transmitter Order number: 71343504</li> <li>Proline 500 transmitter Order number: 71343505</li> </ul>	
	Installation Instructions EA01191D	

Display guard Proline 500 – digital	Is used to protect the display against impact or scoring from sand in desert areas. Order number: 71228792 Installation Instructions EA01093D
Connecting cable Proline 500 – digital Sensor – Transmitter	<ul> <li>The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection) or as an accessory (order number DK8012).</li> <li>The following cable lengths are available: order code for "Cable, sensor connection"</li> <li>Option B: 20 m (65 ft)</li> <li>Option E: User configurable up to max. 50 m</li> <li>Option F: User configurable up to max. 165 ft</li> <li>Maximum possible cable length for a Proline 500 – digital connecting cable: 300 m (1000 ft)</li> </ul>
Connecting cable Proline 500 Sensor – Transmitter	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection") or as an accessory (order number DK8012). The following cable lengths are available: order code for "Cable, sensor connection" • Option 1: 5 m (16 ft) • Option 2: 10 m (32 ft) • Option 3: 20 m (65 ft) Possible cable length for a Proline 500 connecting cable: max. 20 m (65 ft)

# 15.1.2 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids.
	If using oil as a heating medium, please consult with Endress+Hauser.
	Special Documentation SD02159D

# 15.2 Communication-specific accessories

Accessories	Description
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices
	<ul> <li>Technical Information TI01297S</li> <li>Operating Instructions BA01778S</li> <li>Product page: www.endress.com/fxa42</li> </ul>
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.
	<ul> <li>Technical Information TI01342S</li> <li>Operating Instructions BA01709S</li> <li>Product page: www.endress.com/smt70</li> </ul>
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.
	<ul> <li>Technical Information TI01418S</li> <li>Operating Instructions BA01923S</li> <li>Product page: www.endress.com/smt77</li> </ul>

Accessories	Description
Applicator	<ul> <li>Software for selecting and sizing Endress+Hauser measuring devices:</li> <li>Choice of measuring devices for industrial requirements</li> <li>Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy.</li> <li>Graphic illustration of the calculation results</li> <li>Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</li> </ul>
	<ul> <li>Applicator is available:</li> <li>Via the Internet: https://portal.endress.com/webapp/applicator</li> <li>As a downloadable DVD for local PC installation.</li> </ul>
W@M	W@M Life Cycle ManagementImproved productivity with information at your fingertips. Data relevant to aplant and its components is generated from the first stages of planning andduring the asset's complete life cycle.W@M Life Cycle Management is an open and flexible information platformwith online and on-site tools. Instant access for your staff to current, in-depthdata shortens your plant's engineering time, speeds up procurement processesand increases plant uptime.Combined with the right services, W@M Life Cycle Management boostsproductivity in every phase. For more information, visitwww.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices.

# 15.3 Service-specific accessories

# 15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	<ul> <li>Technical Information TI00133R</li> <li>Operating Instructions BA00247R</li> </ul>
Cerabar M	<ul> <li>The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.</li> <li>Technical Information TI00426P and TI00436P</li> <li>Operating Instructions BA00200P and BA00382P</li> </ul>
Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature. () "Fields of Activity" document FA00006T

# 16 Technical data

# 16.1 Application

The measuring device is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

# 16.2 Function and system design

Measuring principle	Mass flow measurement based on the Coriolis measuring principle
Measuring system	The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.
	For information on the structure of the device $\rightarrow  extsf{b}  extsf{14}$

# 16.3 Input

# Measured variable Direct measured variables Mass flow Density Temperature Calculated measured variables

## Volume flow

- Corrected volume flow
- Reference density

## Measuring range

## Measuring range for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
80	3	0 to 180 000	0 to 6615
100	4	0 to 350 000	0 to 12860
150	6	0 to 800 000	0 to 29400
250	10	0 to 2 200 000	0 to 80850

## Measuring range for gases

The full scale value depends on the density and the sound velocity of the gas used and can be calculated with the formula below:

 $\dot{m}_{max(G)}$  = minimum ( $\dot{m}_{max(F)} \cdot \rho_G : x$ ;  $\rho_G \cdot c_G \cdot \pi/2 \cdot (d_i)^2 \cdot 3600$ )

m <sub>max(G)</sub>	Maximum full scale value for gas [kg/h]
m <sub>max(F)</sub>	Maximum full scale value for liquid [kg/h]
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{max(G)}$ can never be greater than $\dot{m}_{max(F)}$
ρ <sub>G</sub>	Gas density in [kg/m <sup>3</sup> ] at operating conditions
x	Constant dependent on nominal diameter
c <sub>G</sub>	Sound velocity (gas) [m/s]
d <sub>i</sub>	Measuring tube internal diameter [m]

DN		x
[mm]	[in]	[kg/m <sup>3</sup> ]
80	3	110
100	4	130
150	6	200
250	10	200

## Calculation example for gas

- Sensor: Promass O, DN 80
- Gas: Air with a density of 60.3 kg/m<sup>3</sup> (at 20  $^\circ\!C$  and 50 bar)
- Measuring range (liquid): 180000 kg/h
- x = 130 kg/m<sup>3</sup> (for Promass O, DN 80)

Maximum possible full scale value:

 $\dot{m}_{max(G)} = \dot{\dot{m}}_{max(F)} \cdot \rho_G : x = 180\,000 \text{ kg/h} \cdot 60.3 \text{ kg/m}^3 : 130 \text{ kg/m}^3 = 83\,500 \text{ kg/h}$ 

## Recommended measuring range



Operable flow range	Over 1000 : 1.	
	Flow rates above the pr result that the totalizer	eset full scale value do not override the electronics unit, with the values are registered correctly.
Input signal	External measured va	lues
	To increase the accurac flow for gases, the auto the measuring device: • Operating pressure to pressure measuring d • Medium temperature • Reference density for	y of certain measured variables or to calculate the corrected volume mation system can continuously write different measured values to o increase accuracy (Endress+Hauser recommends the use of a levice for absolute pressure, e.g. Cerabar M or Cerabar S) to increase accuracy (e.g. iTEMP) calculating the corrected volume flow for gases
	Various pressure a +Hauser: see "Acce	nd temperature measuring devices can be ordered from Endress sories" section $\rightarrow \cong 198$
	It is recommended to re flow.	ead in external measured values to calculate the corrected volume
	Current input	
	The measured values an the current input $\rightarrow \square$	re written from the automation system to the measuring device via 201.
	Digital communication	
	The measured values an FOUNDATION Fieldbus	re written from the automation system to the measuring device via
	Current input 0/4 to 2	0 mA
	Current input	0/4 to 20 mA (active/passive)
	Current span	<ul> <li>4 to 20 mA (active)</li> <li>0/4 to 20 mA (passive)</li> </ul>
	Resolution	1 μΑ
	Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
	Maximum input voltage	< 30 V (passive)
	Open-circuit voltage	< 28.8 V (active)
	Possible input variables	<ul><li>Pressure</li><li>Temperature</li><li>Density</li></ul>
	Status input	
	Marrimeren immederatura	- DC 2 to 20 M

Maximum input values	<ul> <li>DC -3 to 30 V</li> <li>If status input is active (ON): R<sub>i</sub> &gt;3 kΩ</li> </ul>
Response time	Configurable: 5 to 200 ms

Input signal level	<ul> <li>Low signal: DC -3 to +5 V</li> <li>High signal: DC 12 to 30 V</li> </ul>
Assignable functions	<ul><li>Off</li><li>Reset the individual totalizers separately</li><li>Reset all totalizers</li><li>Flow override</li></ul>

# 16.4 Output

## Output signal

## **FOUNDATION Fieldbus**

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s
Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

## Current output 4 to 20 mA

Signal mode	Can be set to: • Active
	■ Passive
Current span	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • 0 to 20 mA (only if the signal mode is active) • Fixed current
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Electronics temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation damping 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

## Current output 4 to 20 mA Ex i passive

Order code	"Output; input 2" (21), "Output; input 3" (022): Option C: current output 4 to 20 mA Ex i passive
Signal mode	Passive
Current span	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • Fixed current
Maximum output values	22.5 mA
Maximum input voltage	DC 30 V

Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Electronics temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation damping 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>In the range of options increases if the measuring device has one or more application packages.</li> </ul>

## Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector Can be set to: • Active • Passive • Passive NAMUR Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	<ul><li>Mass flow</li><li>Volume flow</li><li>Corrected volume flow</li></ul>
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to 10000 Hz (f $_{max}$ = 12500 Hz)
Damping	Configurable: 0 to 999.9 s
Pulse/pause ratio	1:1

Assignable measured variables	<ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Electronics temperature</li> <li>Oscillation frequency 0</li> <li>Oscillation damping 0</li> <li>Signal asymmetry</li> <li>Exciter current 0</li> <li>Image of options increases if the measuring device has one or more application packages.</li> </ul>
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value</li> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Totalizer 1-3</li> <li>Flow direction monitoring</li> <li>Status</li> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> <li>Image of options increases if the measuring device has one or more application packages.</li> </ul>

## Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: • NO (normally open), factory setting • NC (normally closed)

Maximum switching capacity (passive)	<ul> <li>DC 30 V, 0.1 A</li> <li>AC 30 V, 0.5 A</li> </ul>
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value <ul> <li>Mass flow</li> <li>Volume flow</li> <li>Corrected volume flow</li> <li>Density</li> <li>Reference density</li> <li>Temperature</li> <li>Totalizer 1-3</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status <ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> </ul> </li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

## User-configurable input/output

**One** specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm

Depending on the interface, failure information is displayed as follows:

#### FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

## Current output 0/4 to 20 mA

#### 4 to 20 mA

Failure mode	<ul> <li>Choose from:</li> <li>4 to 20 mA in accordance with NAMUR recommendation NE 43</li> <li>4 to 20 mA in accordance with US</li> <li>Min. value: 3.59 mA</li> <li>Max. value: 22.5 mA</li> <li>Freely definable value between: 3.59 to 22.5 mA</li> </ul>
	<ul> <li>Freely definable value between: 3.59 to 22.5 mA</li> <li>Actual value</li> <li>Last valid value</li> </ul>

## 0 to 20 mA

Failure mode	Choose from:
	Maximum alarm: 22 mA
	<ul> <li>Freely definable value between: 0 to 20.5 mA</li> </ul>

## Pulse/frequency/switch output

Pulse output		
Failure mode	Choose from: • Actual value • No pulses	
Frequency output		
Failure mode	Choose from: • Actual value • 0 Hz • Defined value (f <sub>max</sub> 2 to 12 500 Hz)	
Switch output		
Failure mode	Choose from: • Current status • Open • Closed	

#### **Relay output**

Failure mode	Choose from:
	<ul> <li>Current status</li> </ul>
	<ul> <li>Open</li> </ul>
	<ul> <li>Closed</li> </ul>

## Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

## Interface/protocol

- Via digital communication: FOUNDATION Fieldbus
- Via service interface
- CDI-RJ45 service interface
- WLAN interface

Plain text display	With information on cause and remedial measures
•	

## Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

## Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes					
	<ul> <li>The following information is displayed depending on the device version:</li> <li>Supply voltage active</li> <li>Data transmission active</li> <li>Device alarm/error has occurred</li> <li>Diagnostic information via light emitting diodes → 151</li> </ul>					

Low flow cut off	The switch points for low flow cut off are user-selectable.			
Galvanic isolation	The outputs are galvanically isolated from one another and from earth (PE).			
Protocol-specific data	Manufacturer ID	0x452B48 (hex)		
	Ident number	0x103B (hex)		
	Device revision	1		
	DD revision	Information and files under:		
	CFF revision	<ul><li>www.endress.com</li><li>www.fieldbus.org</li></ul>		
	Interoperability Test Kit (ITK)	Version 6.2.0		
	ITK Test Campaign Number	Information: • www.endress.com • www.fieldbus.org		
	Link Master capability (LAS)	Yes		
	Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device		
	Node address	Factory setting: 247 (0xF7)		
	Supported functions	The following methods are supported: • Restart • ENP Restart • Diagnostic • Set to OOS • Set to AUTO • Read trend data • Read event logbook		
	Virtual Communication Relation	onships (VCRs)		
	Number of VCRs	44		
	Number of link objects in VFD	50		
	Permanent entries	1		
	Client VCRs	0		
	Server VCRs	10		
	Source VCRs	43		
	Sink VCRs	0		
	Subscriber VCRs	43		
	Publisher VCRs	43		
	Device Link Capabilities			
	Slot time	4		
	Min. delay between PDU	8		
	Max. response delay	16		
	System integration	Information regarding system integration $\rightarrow \square 87$ .		
		<ul> <li>Cyclic data transmission</li> <li>Description of the modules</li> <li>Execution times</li> <li>Methods</li> </ul>		

# 16.5 Power supply

Terminal assignment

Device plugs available	→ 🖺 39				
 Pin assignment, device plu	g → 🗎 39				
Supply voltage	Order code for "Power supply"	Terminal voltage	2	Frequency range	
	Option <b>D</b>	DC 24 V	±20%	-	
	Option <b>E</b>	AC 100 to 240 V	-15 to +10%	50/60 Hz	
	On tion I	DC 24 V	±20%	-	
	Option I	AC 100 to 240 V	-15 to +10%	50/60 Hz	
Power consumption	<b>Transmitter</b> Max. 10 W (active p switch-on current	oower) Max. 36 A (<5 ms) as per	NAMUR Recom	mendation NE 21	
Current consumption	<b>Transmitter</b> • Max. 400 mA (24 • Max. 200 mA (11	<b>Transmitter</b> • Max. 400 mA (24 V) • Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)			
Power supply failure	<ul> <li>Totalizers stop at</li> <li>Depending on the the pluggable data</li> <li>Error messages (in</li> </ul>	<ul> <li>Totalizers stop at the last value measured.</li> <li>Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT).</li> <li>Error messages (incl. total operated hours) are stored.</li> </ul>			
Electrical connection	→ 🗎 49	→ 🗎 49			
Potential equalization	→ 🗎 55	→ 🗎 55			
Terminals	Spring-loaded termi Conductor cross-sec	Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm <sup>2</sup> (24 to 12 AWG).			
Cable entries	<ul> <li>Cable gland: M20</li> <li>Thread for cable e <ul> <li>NPT ¼"</li> <li>G ½"</li> <li>M20</li> </ul> </li> <li>Device plug for dig</li> <li>Device plug for con A device plug is all connection housing</li> </ul>	× 1.5 with cable Ø 6 to 1 ntry: gital communication: M12 nnecting cable: M12 ways used for the device ug", option <b>C</b> "Ultra-compa	2 mm (0.24 to 2 version with t ct, hygienic, s	o 0.47 in) he order code for "Sensor tainless".	
Cable specification	→ 🗎 35				

Reference operating conditions	<ul> <li>Error limits based on ISO 11631</li> <li>Water with +15 to +45 °C (+59 to +113 °F) at2 to 6 bar (29 to 87 psi)</li> <li>Specifications as per calibration protocol</li> <li>Accuracy based on accredited calibration rigs that are traced to ISO 17025.</li> </ul>					
	1 To obtain measured error	To obtain measured errors, use the <i>Applicator</i> sizing tool $\rightarrow \triangleq 198$				
Maximum measured error	o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature					
	Base accuracy					
	Design fundamentals → <sup>●</sup> 213					
	Mass flow and volume flow (liquids)					
	$\pm 0.05$ % o.r. (PremiumCal; order code for "Calibration flow", option D, for mass flow) $\pm 0.10$ % o.r.					
	Mass flow (gases)					
	±0.35 % o.r.					
	Density (liquids)	Density (liquids)				
	Under reference conditions	Standard density calibration <sup>1)</sup>	Wide-range Density specification $^{2)}$ <sup>3)</sup>			

#### 16.6 **Performance characteristics**

Standard density calibration <sup>2</sup>	Wide-range Density specification <sup>2) 3)</sup>
[g/cm <sup>3</sup> ]	[g/cm³]
±0.01	±0.001
	[g/cm <sup>3</sup> ] ±0.01

1) Valid over the entire temperature and density range

2) 3) Valid range for special density calibration: 0 to 2 g/cm<sup>3</sup>, +5 to +80 °C (+41 to +176 °F) Order code for "Application package", option EE "Special density"

## Temperature

 $\pm 0.5 \ ^{\circ}C \pm 0.005 \cdot T \ ^{\circ}C \ (\pm 0.9 \ ^{\circ}F \pm 0.003 \cdot (T - 32) \ ^{\circ}F)$ 

## Zero point stability

DN		Zero point stability		
[mm]	[in]	[kg/h]	[lb/min]	
80	3	9	0.330	
100	4	14	0.514	
150	6	32	1.17	
250	10	88	3.23	

## Flow values

Flow values as turndown parameter depending on nominal diameter.

#### SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
80	180000	18000	9000	3 600	1800	360
100	350000	35000	17 500	7 000	3 500	700
150	800000	80000	40000	16000	8000	1600
250	2 200 000	220000	110000	44000	22000	4 400

#### US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3	6615	661.5	330.8	132.3	66.15	13.23
4	12860	1286	643.0	257.2	128.6	25.72
6	29400	2940	1470	588	294	58.80
10	80850	8085	4043	1617	808.5	161.7

#### Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA
,	

*Pulse/frequency output* 

o.r. = of reading

Accuracy Max. ±50 ppm o.	r. (over the entire ambient temperature range)
--------------------------	--

#### Repeatability

o.r. = of reading;  $1 \text{ g/cm}^3 = 1 \text{ kg/l}$ ; T = medium temperature

## **Base repeatability**



Mass flow and volume flow (liquids) ±0.025 % o.r. (PremiumCal, for mass flow) ±0.05 % o.r.

Mass flow (gases)

±0.25 % o.r.

Density (liquids) ±0.00025 g/cm<sup>3</sup>

*Temperature* ±0.25 °C ± 0.0025 · T °C (±0.45 °F ± 0.0015 · (T−32) °F)

Response time	The response time depends on the configuration (damping).		
Influence of ambient temperature	Current output		
	Temperature coefficient	Max. 1 µA/°C	
	Pulse/frequency output		
	Temperature coefficient	No additional effect. Included in accuracy.	
Influence of medium temperature	Mass flow and volume f	low	
	When there is a difference process temperature, the o.f.s./°C (±0.0001 % o. f.s.	ce between the temperature for zero point adjustment and the additional measured error of the sensor is typically $\pm 0.0002$ % s./°F).	
	The effect is reduced if ze	ero point adjustment is performed at process temperature.	
	<b>Density</b> When there is a different temperature, the typical ±0.00005 g/cm <sup>3</sup> /°C (±0.	ce between the density calibration temperature and the process measured error of the sensor is .000025 g/cm³ /°F). Field density calibration is possible.	
	<b>Wide-range density spe</b> If the process temperatur ±0.00005 g/cm <sup>3</sup> /°C (±0.	cification (special density calibration) re is outside the valid range ( $\rightarrow \cong 210$ ) the measured error is .000025 g/cm <sup>3</sup> /°F)	
	[kg/m <sup>3</sup> ] 10 8 6 4 2 0 -4 -80 -4 1 Field density calibration, fr 2 Special density calibration	$\begin{array}{c} & & & \\$	
	<b>Temperature</b> ±0.005 · T ℃ (± 0.005 · (	T – 32) °F)	
Influence of medium pressure	The table below shows th calibration pressure and o.r. = of reading	ne effect on accuracy of mass flow due to a difference between process pressure.	
	It is possible to comp Reading in the cur Specifying a fixed	pensate for the effect by: rent pressure measured value via the current input. value for the pressure in the device parameters.	
	Dperating Instructio	ns.	

DN		[% o.r./bar]	[% o.r./psi]
[mm]	[in]		
80	3	-0.0055	-0.0004
100	4	-0.0035	-0.0002
150	6	-0.002	-0.0001
250	10	-0.002	-0.0001

#### Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability

## Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	, (17300X
< <u>ZeroPoint</u> · 100	$\pm \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021333	A0021334

## Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	± BaseRepeat
A0021335	A0021340
$< \frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	$\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021336	A0021337

#### Example for maximum measured error



*E* Maximum measured error in % o.r. (example)

*Q* Flow rate in % of maximum full scale value

# 16.7 Installation

Installation conditions  $\rightarrow \cong 22$ 

Ambient temperature range	$\rightarrow \textcircled{2} 25 \rightarrow \textcircled{2} 25$
	Temperature tables
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.
	For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
Storage temperature	–50 to +80 °C (–58 to +176 °F)
Climate class	DIN EN 60068-2-38 (test Z/AD)
Degree of protection	Transmitter • As standard: IP66/67, type 4X enclosure • When housing is open: IP20, type 1 enclosure • Display module: IP20, type 1 enclosure
	<ul> <li>Sensor</li> <li>As standard: IP66/67, type 4X enclosure</li> <li>With the order code for "Sensor options", option CM: IP69 can also be ordered</li> </ul>
	<b>External WLAN antenna</b> IP67
Vibration- and shock-	Vibration sinusoidal, in accordance with IEC 60068-2-6
resistance	Sensor: order code for "Meas. tube mat., wetted parts surface", option LA, SD, SE, SF, TH, TT, TU • 2 to 8.4 Hz, 3.5 mm peak • 8.4 to 2 000 Hz, 1 g peak
	Sensor: order code for "Meas. tube mat., wetted parts surface", option HA, SA, SB, SC 2 to 8.4 Hz, 7.5 mm peak 8.4 to 2 000 Hz, 2 g peak
	Transmitter • 2 to 8.4 Hz, 7.5 mm peak • 8.4 to 2 000 Hz, 2 g peak
	Vibration broad-band random, according to IEC 60068-2-64
	Sensor: order code for "Meas. tube mat., wetted parts surface", option LA, SD, SE, SF, TH, TT, TU • 10 to 200 Hz, 0.003 g <sup>2</sup> /Hz • 200 to 2 000 Hz, 0.001 g <sup>2</sup> /Hz • Total: 1.54 g rms
	Sensor: order code for "Meas. tube mat., wetted parts surface", option HA, SA, SB, SC • 10 to 200 Hz, 0.01 g <sup>2</sup> /Hz • 200 to 2 000 Hz, 0.003 g <sup>2</sup> /Hz • Total: 2.70 g rms
	Transmitter • 10 to 200 Hz, 0.01 g <sup>2</sup> /Hz • 200 to 2 000 Hz, 0.003 g <sup>2</sup> /Hz • Total: 2.70 g rms

# 16.8 Environment

	Shock half-sine, according to IEC 60068-2-27
	<ul> <li>Sensor: order code for "Meas. tube mat., wetted parts surface", option LA, SD, SE, SF, TH, TT, TU 6 ms 30 g</li> <li>Sensor: order code for "Meas. tube mat., wetted parts surface", option HA, SA, SB, SC 6 ms 50 g</li> <li>Transmitter 6 ms 50 g</li> <li>Rough handling shocks, according to IEC 60068-2-31</li> </ul>
Mechanical load	Never use the transmitter housing as a ladder or climbing aid.
Electromagnetic compatibility (EMC)	Details are provided in the Declaration of Conformity.

## 16.9 Process

Medium temperature range -4

-40 to +205 °C (-40 to +401 °F)

## Dependency of ambient temperature on medium temperature



*Exemplary representation, values in the table below.*

- *T<sub>a</sub>* Ambient temperature range
- *T<sub>m</sub> Medium temperature*
- A Maximum permitted medium temperature  $T_m$  at  $T_{a max} = 60 \degree C$  (140 °F); higher medium temperatures  $T_m$  require a reduced ambient temperature  $T_a$
- *B* Maximum permitted ambient temperature  $T_a$  for the maximum specified medium temperature  $T_m$  of the sensor



Values for devices used in the hazardous area: Separate Ex documentation (XA) for the device  $\Rightarrow \square 228$ .

	Not insulated			Insulated					
	A		в		А		В		
Version	Ta	T <sub>m</sub>	Ta	T <sub>m</sub>	Ta	T <sub>m</sub>	Ta	T <sub>m</sub>	
Promass O 500 – digital	60 °C (140 °F)	205 °C (401 °F)	-	-	60 °C (140 °F)	150 ℃ (302 ℉)	55 ℃ (131 °F)	205 ℃ (401 °F)	
Promass O 500	-								
					1				
Density	0 to 5 000 kg/m <sup>3</sup> (0 to 312 lb/cf)								
Pressure-temperature ratings	An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document								
Sensor housing	The sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.								
	If a measuring tube fails (e.g. due to process characteristics like corrosive or abrasive fluids), the fluid will initially be contained by the sensor housing.								
	In the eve according burst pres rupture di housing. T involving is greater	In the event of a tube failure, the pressure level inside the sensor housing will rise according to the operating process pressure. If the user judges that the sensor housing burst pressure does not provide an adequate safety margin, the device can be fitted with a rupture disk. This prevents excessively high pressure from forming inside the sensor housing. Therefore, the use of a rupture disk is strongly recommended in applications involving high gas pressures, and particularly in applications in which the process pressure is greater than 2/3 of the sensor housing burst pressure.							
	If there is fitted with	<ul> <li>If there is a need to drain the leaking medium into a discharge device, the sensor should be fitted with a rupture disk. Connect the discharge to the additional threaded connection .</li> <li>If the sensor is to be purged with gas (gas detection), it should be equipped with purge connections.</li> <li>Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low pressure to purge.</li> <li>Maximum pressure: <ul> <li>DN 80 to 150 (3 to 6"): 5 bar (72.5 psi)</li> <li>DN 250 (10"): 3 bar (43.5 psi)</li> </ul> </li> <li>Burst pressure of the sensor housing <ul> <li>The following sensor housing burst pressures are only valid for standard devices and/or devices equipped with closed purge connections (not opened/as delivered).</li> <li>If a device fitted with purge connections (order code for "Sensor option", option CH "Purge connection") is connected to the purge system, the maximum pressure is determined by the purge system itself or by the device, depending on which component has the lower pressure classification.</li> <li>If the device is fitted with a rupture disk (order code for "Sensor option", option CA "Rupture disk"), the rupture disk trigger pressure is decisive .</li> </ul> </li> </ul>							
	If the sense connection								
	Do no with								
	Maxi ■ DN ■ DN								
	Burst pre								
	The follov devices eq								
	If a device connectio purge syst pressure c								
	If the devi disk"), the								

The sensor housing burst pressure refers to a typical internal pressure which is reached prior to mechanical failure of the sensor housing and which was determined during type
testing. The corresponding type test declaration can be ordered with the device (order code for "Additional approval", option LN "Sensor housing burst pressure, type test").

	D	DN		Sensor housing burst pressure			
	[mm]	[in]	[bar]	[psi]			
	80	3	120	1740			
	100	4	95	1370			
	150	6	75	1080			
	250	10	50	720			
	For information Technical Infor	n on the dimensions "mation" document	: see the "Mechanical cons	struction" section of the			
Rupture disk	To increase the level of 10 to 15 bar (145 "rupture disk").	l of safety, a device v 5 to 217.5 psi)can be	version with a rupture dis e used (order code for "Ser	k with a trigger pressure asor option", option CA			
	For information construction" se	For information on the dimensions of the rupture disk: see the "Mechanical construction" section of the "Technical Information" document					
Flow limit	Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.						
	For an overview of the full scale values for the measuring range, see the "Measuring range" section $\rightarrow \cong 200$						
	<ul> <li>The minimum recommended full scale value is approx. 1/20 of the maximum full scale value</li> <li>In most applications, 20 to 50 % of the maximum full scale value can be considered ideal</li> <li>A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity &lt; 1 m/s (&lt; 3 ft/s).</li> <li>For gas measurement the following rules apply: <ul> <li>The flow velocity in the measuring tubes should not exceed half the sound velocity (0.5 Mach).</li> <li>The maximum mass flow depends on the density of the gas: formula → 200</li> </ul> </li> </ul>						
Pressure loss	To calculate the pressure loss, use the Applicator sizing tool $\rightarrow \square$ 198						
System pressure	→ 🗎 25						
	16.10 Mecha	anical constru	iction				
Design, dimensions	For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.						
Weight	All values (weight exclusive of packaging material) refer to devices with ASME B16.5 Class 900 flanges.						

# Transmitter

- Proline 500 digital polycarbonate: 1.4 kg (3.1 lbs)
- Proline 500 digital aluminum: 2.4 kg (5.3 lbs)
- Proline 500 aluminum: 6.5 kg (14.3 lbs)
- Proline 500 cast, stainless: 15.6 kg (34.4 lbs)

#### Sensor

- Sensor with aluminum connection housing version: see the information in the following table
- Sensor with cast connection housing version, stainless: +3.7 kg (+8.2 lbs)

### Weight in SI units

DN [mm]	Weight [kg]			
80	75			
100	141			
150	246			
250	572			

### Weight in US units

DN [in]	Weight [lbs]		
3	165		
4	311		
6	542		
10	1261		

Materials

## Transmitter housing

Housing of Proline 500 – digital transmitter

Order code for "Transmitter housing":

- Option **A** "Aluminum coated": aluminum, AlSi10Mg, coated
- Option D "Polycarbonate": polycarbonate

Housing of Proline 500 transmitter

Order code for "Transmitter housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option L "Cast, stainless": cast, stainless steel, 1.4409 (CF3M) similar to 316L

#### Window material

Order code for "Transmitter housing":

- Option A "Aluminum, coated": glass
- Option **D** "Polycarbonate": plastic
- Option L "Cast, stainless": glass

#### Fastening components for mounting on a post

- Screws, threaded bolts, washers, nuts: stainless A2 (chrome-nickel steel)
- Metal plates: stainless steel, 1.4301 (304)

#### Sensor connection housing

Order code for "Sensor connection housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option **B** "Stainless":
- Stainless steel 1.4301 (304)
- Optional: Order code for "Sensor feature", option CC "Hygienic version, for maximum corrosion resistance": stainless steel, 1.4404 (316L)
- Option **C** "Ultra-compact, stainless":
- Stainless steel 1.4301 (304)
- Optional: Order code for "Sensor feature", option **CC** "Hygienic version, for maximum corrosion resistance": stainless steel, 1.4404 (316L)
- Option L "Cast, stainless": 1.4409 (CF3M) similar to 316L

#### Cable entries/cable glands

Cable entries and adapters	Material		
Cable gland M20 × 1.5	Plastic		
<ul> <li>Adapter for cable entry with female thread G <sup>1</sup>/<sub>2</sub>"</li> <li>Adapter for cable entry with female thread NPT <sup>1</sup>/<sub>2</sub>"</li> </ul>	Nickel-plated brass		
<ul> <li>Only available for certain device versions:</li> <li>Order code for "Transmitter housing":</li> <li>Option A "Aluminum, coated"</li> <li>Option D "Polycarbonate"</li> <li>Order code for "Sensor connection housing":</li> <li>Proline 500 - digital: Option A "Aluminum coated"</li> <li>Option B "Stainless"</li> <li>Proline 500: Option B "Stainless"</li> <li>Proline 500: Option B "Stainless"</li> <li>Option B "Stainless"</li> <li>Option B "Stainless"</li> <li>Option L "Cast, stainless"</li> </ul>			
<ul> <li>Adapter for cable entry with female thread G <sup>1</sup>/<sub>2</sub>"</li> <li>Adapter for cable entry with female thread NPT <sup>1</sup>/<sub>2</sub>"</li> </ul>	Stainless steel, 1.4404 (316L)		
<ul> <li>Only available for certain device versions:</li> <li>Order code for "Transmitter housing": Option L "Cast, stainless"</li> <li>Order code for "Sensor connection housing": Option L "Cast, stainless"</li> </ul>			
Adapter for device plug	Stainless steel, 1.4404 (316L)		
Device plug for digital communication: Only available for certain device versions .			

#### Device plug

Electrical connection	Material		
Plug M12x1	<ul> <li>Socket: Stainless steel, 1.4404 (316L)</li> <li>Contact housing: Polyamide</li> <li>Contacts: Gold-plated brass</li> </ul>		

#### **Connecting cable**

UV rays can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Connecting cable for sensor - Proline 500 – digital transmitter PVC cable with copper shield Connecting cable for sensor - Proline 500 transmitter

- Standard cable: PVC cable with copper shield
- Armored cable: PVC cable with copper shield and additional steel wire braided jacket

#### Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel, 1.4404 (316L)

#### Measuring tubes

Stainless steel, 1.4410/UNS S32750 25Cr Duplex (Super Duplex)

#### **Process connections**

Stainless steel, 1.4410/F53 25Cr Duplex (Super Duplex)

#### Seals

Welded process connections without internal seals

### Accessories

#### Protective cover

Stainless steel, 1.4404 (316L)

### External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Process connections	Fixed flange connections: • EN 1092-1 (DIN 2512N) flange • ASME B16.5 flange • JIS B2220 flange		
	Process connection materials $\rightarrow \triangleq 220$		
Surface roughness	All data relate to parts in contact with fluid. The following surface roughness quality can be ordered.		

Not polished

# 16.11 Human interface

Languages	Can be operated in the following languages:
	<ul> <li>Via local operation</li> </ul>
	English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish,
	Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
	<ul> <li>Via Web browser</li> </ul>
	English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish,
	Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
	<ul> <li>Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian,</li> </ul>
	Chinese, Japanese

### Local operation

#### Via display module

#### Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"

Information about WLAN interface  $\rightarrow \cong 82$ 



#### Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.

#### **Operating elements**

- External operation via touch control (3 optical keys) without opening the housing:  $\boxdot$  ,  $\boxdot$  ,  $\boxdot$
- Operating elements also accessible in the various zones of the hazardous area

Remote operation	→ 🖹 81
Service interface	→ 🖹 81
Supported operating tools	Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information	
Web browser	Notebook, PC or tablet with Web browser	<ul> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> </ul>	Special Documentation for device $\rightarrow \cong 229$	
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	<ul> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>Fieldbus protocol</li> </ul>	→ ➡ 198	
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	<ul> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>Fieldbus protocol</li> </ul>	→ ● 198	
Device Xpert	Field Xpert SFX 100/350/370	HART and FOUNDATION Fieldbus fieldbus protocol	Operating Instructions BA01202S Device description files: Use update function of handheld terminal	

Other operating tools based on FDT technology with a device driver such as DTM/ iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) by Rockwell Automation → www.rockwellautomation.com
- Asset Management Solutions (AMS) by Emerson → www.emersonprocess.com
- FieldCommunicator 375/475 by Emerson  $\rightarrow$  www.emersonprocess.com
- Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
- FieldMate by Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com  $\rightarrow$  Downloads

### Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

#### Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)

- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration

Web server special documentation → 
<sup>△</sup> 229

HistoROM data management The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.

When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

#### Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	<ul> <li>Event logbook such as diagnostic events for example</li> <li>Parameter data record backup</li> <li>Device firmware package</li> <li>Driver for system integration for exporting via Web server, e.g: DD for FOUNDATION Fieldbus</li> </ul>	<ul> <li>Measured value logging ("Extended HistoROM" order option)</li> <li>Current parameter data record (used by firmware at run time)</li> <li>Peakhold indicator (min/max values)</li> <li>Totalizer values</li> </ul>	<ul> <li>Sensor data: nominal diameter etc.</li> <li>Serial number</li> <li>Calibration data</li> <li>Device configuration (e.g. SW options, fixed I/O or multi I/O)</li> </ul>
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

#### Data backup

#### Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

#### Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function Backup and subsequent restoration of a device configuration in the device memory HistoROM backup
- Data comparison function Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

# Data transfer

# Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.: DD for FOUNDATION Fieldbus

# **Event list**

# Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

# Data logging

### Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

# 16.12 Certificates and approvals

Currently available certificates and approvals can be called up via the product configurator.

CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.				
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.				
RCM-tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".				
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.				
FOUNDATION Fieldbus	FOUNDATION Fieldbus interface				
certification	<ul> <li>The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:</li> <li>Certified in accordance with FOUNDATION Fieldbus H1</li> <li>Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request)</li> <li>Physical Layer Conformance Test</li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> </ul>				

Pressure Equipment Directive	<ul> <li>With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU.</li> <li>Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU.</li> </ul>						
Radio approval	The me	asuring device has radio	appro	val.			
	For detailed information regarding radio approval, see Special Docum $\rightarrow \textcircled{B} 229$					nentation	
Additional certification	CRN ap	proval					
	Some d approva	evice versions have CRN al must be ordered for a	approv CRN-aj	val. A CRN oproved de	-approve evice.	d process conne	ection with a CSA
	Tests a	nd certificates					
	<ul> <li>Pressure testing, internal procedure, inspection certificate</li> <li>PMI test (XRF), internal procedure, wetted parts, test report</li> <li>EN10204-2.1 confirmation of compliance with the order and EN10204-2.2 test report</li> <li>Testing of welded connections</li> </ul>						
	Option	Test	standard	l		Component	
		ISO 23277 AL2x (PT) ISO 10675-1 AL1 (RT, DR)	ASME B31.3 NFS	ASME VIII Div.1 Appx. 4+8	NORSOK M-601	Measuring tube	Process connection
	CF	X				PT	RT
	KK		x			PT	RT
	KP			х		PT	RT
	KR				х	VT, PT	VT, RT
	K1	х				PT	DR
	K2		x			PT	DR
	К3			x		PT	DR
	K4				х	VT, PT	VT, DR
	PT = penetrant testing, RT = radiographic testing, VT = visual testing, DR = digital radiography All options with test report						
Other standards and auidelines	■ EN 60 Degre	0529 ees of protection provide	ed by er	nclosures (	IP code)		

- IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal). ■ IEC/EN 60068-2-31
- Environmental influences: Test procedure Test Ec: shocks due to rough handling, primarily for devices.
- EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements
- IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

 NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

- NAMUR NE 32
   Data retention in the event of a power failure in field and control instruments with microprocessors
- NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.
- NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics
- NAMUR NE 80
- The application of the pressure equipment directive to process control devices
- NAMUR NE 105
- Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107
   Self-monitoring and diagnosis of field devices
- NAMUR NE 131
  - Requirements for field devices for standard applications
- NAMUR NE 132
- Coriolis mass meter
- NACE MR0103 Materials resistant to sulfide stress cracking in corrosive petroleum refining environments.
- NACE MR0175/ISO 15156-1 Materials for use in H2S-containing Environments in Oil and Gas Production.

# 16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: <a href="https://www.endress.com">www.endress.com</a>.

Detailed information on the application packages: Special Documentation for the device  $\rightarrow \square 228$ 

Diagnostics functions	Package	Description
	Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
		Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
		<ul> <li>Data logging (line recorder):</li> <li>Memory capacity for up to 1000 measured values is activated.</li> <li>250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.</li> </ul>

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	<ul> <li>Heartbeat Verification</li> <li>Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter</li> <li>7.6 a) "Control of monitoring and measuring equipment".</li> <li>Functional testing in the installed state without interrupting the process.</li> <li>Traceable verification results on request, including a report.</li> <li>Simple testing process via local operation or other operating interfaces.</li> <li>Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.</li> <li>Extension of calibration intervals according to operator's risk assessment.</li> </ul>
		<ul> <li>Heartbeat Monitoring</li> <li>Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:</li> <li>Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time.</li> <li>Schedule servicing in time.</li> <li>Monitor the process or product quality, e.g. gas pockets.</li> </ul>

Concentration	Package	Description
	Concentration	Calculation and outputting of fluid concentrations
		<ul> <li>The measured density is converted to the concentration of a substance of a binary mixture using the "Concentration" application package:</li> <li>Choice of predefined fluids (e.g. various sugar solutions, acids, alkalis, salts, ethanol etc.)</li> <li>Common or user-defined units (°Brix, °Plato, % mass, % volume, mol/l etc.) for standard applications.</li> <li>Concentration calculation from user-defined tables.</li> </ul>

Special density	Package	Description
	Special density	Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system. The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.

Petroleum	Package	Description
	Petroleum	The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package.
		<ul> <li>Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1"</li> <li>Water content, based on density measurement</li> <li>Weighted mean of the density and temperature</li> </ul>

# 16.14 Accessories

Overview of accessories available for order  $\rightarrow \implies 196$ 

# 16.15 Supplementary documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Standard documentation Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Promass O	KA01285D

#### Brief Operating Instructions for transmitter

Measuring device	Documentation code
Proline 500 – digital	KA01233D
Proline 500	KA01291D

### **Technical Information**

Measuring device	Documentation code
Promass O 500	TI01285D

### **Description of Device Parameters**

Measuring device	Documentation code
Promass 500	GP01096D

Device-dependent additional documentation Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
	Measuring device
ATEX/IECEx Ex i	XA01473D
ATEX/IECEx Ex ec	XA01474D
cCSAus IS	XA01475D
cCSAus Ex i	XA01509D
cCSAus Ex nA	XA01510D
INMETRO Ex i	XA01476D
INMETRO Ex ec	XA01477D
NEPSI Ex i	XA01478D
NEPSI Ex nA	XA01479D
NEPSI Ex i	XA01658D
NEPSI Ex nA	XA01659D
JPN	XA01780D

# **Special Documentation**

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Web server	SD01669D
Heartbeat Technology	SD01703D
Concentration measurement	SD01709D
Petroleum	-

# Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	<ul> <li>Access the overview of all the available spare part sets via W@M Device Viewer →  194</li> <li>Accessories available for order with Installation Instructions →  196</li> </ul>

# Index

# Α

	Access	authorization	to	parameters
--	--------	---------------	----	------------

Read access	73
Write access	73
Access code	73
Incorrect input	73
Accuracy	10
Adapting the diagnostic behavior 1	60
Adapting the status signal	60
Additional certification	25
Ambient temperature	
Influence	12
AMS Device Manager	86
Function	86
Application	99
Application packages	26
Applicator	00
Approvals	24

# **C**

Degree of protection
Density
Design fundamentals
Maximum measured error
Repeatability
Designated use 10
Device components
Device description files
Device documentation
Supplementary documentation
Device locking, status
Device name
Sensor
Transmitter
Device repair
Device revision
Device type ID
DeviceCare
Device description file
Diagnostic behavior
Explanation
Symbols
Diagnostic information
Design description 156 159
DeviceCare 158
FieldCare 158
Light emitting diodes 151
Light cliniting aloues
Ωυριτιόνω 164
Remedial measures
Wah browser 157
Diagnostic list
Diagnostic moscago 155
DIAGNOSTIC Transducor Block 186
Diagnostics
Sumbola 155
DIP SWITCH
Direct access
Direct access
Direct access code
Disabiling write protection
Display
see Unsite display
Display area
For operational display
In the navigation view

Display values
For locking status
Disposal
Document
Function
Symbols
Document function
Down pipe

# Ε

Editing view
Input screen
Using operating elements 67, 68
Electrical connection
Degree of protection
Measuring device
Operating tools
Via FOUNDATION Fieldbus network 81
Via service interface (CDI-RJ45) 81
Via WLAN interface
Web server
WLAN interface
Electromagnetic compatibility
Electronics module
Enabling write protection 134
Enabling/disabling the keypad lock
Endress+Hauser services
Maintenance
Repair
Environment
Mechanical load
Storage temperature
Vibration- and shock-resistance
Error messages
see Diagnostic messages
Event list
Event logbook
Ex approval
Extended order code
Sensor
Transmitter
Exterior cleaning

# F

Firmware Release date
Version
Firmware history
Flow direction
Flow limit 217
FOUNDATION Fieldbus certification 224
Function check 93
Function range
Field Yport 8/
AMC Duries Manager
Field Communicator
Field Communicator 4/5
Functions
see Parameter
C
Calvania isolation 200
Н
Hardware write protection
Help text
Calling up 72
Closing 72
Evaluation 72
HISTOROIM
T
I Identifying the measuring device 16
I         Identifying the measuring device         Incoming acceptance         16
I         Identifying the measuring device         Incoming acceptance         Influence
I Identifying the measuring device
I Identifying the measuring device
I Identifying the measuring device
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       6         Received goods       16
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       6         Received goods       16         Inspection check       16
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       16         Received goods       16         Inspection check       59
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       16         Received goods       16         Inspection check       59         Installation       22
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Inspection check       59         Installation       22         Installation       22
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Inspection check       59         Installation       22         Installation conditions       202         Down pipe       23
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       26         Inspection check       59         Installation       22         Installation conditions       23         Down pipe       23         Inlet and outlet runs       24
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       24         Inspection check       6         Connection       59         Installation       22         Installation conditions       23         Down pipe       23         Inlet and outlet runs       24         Installation dimensions       24
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Ambient temperature       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Inspection check       6         Connection       59         Installation       22         Installation conditions       23         Down pipe       23         Inlet and outlet runs       24         Installation dimensions       24         Mounting location       22
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Ambient temperature       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       26         Inspection check       59         Installation       22         Installation conditions       24         Inlet and outlet runs       24         Installation dimensions       24         Installation dimensions       24         Mounting location       22         Orientation       22
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Ambient temperature       212         Medium pressure       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       26         Received goods       16         Inspection check       59         Connection       59         Installation       22         Installation conditions       24         Mounting location       24         Mounting location       24         Supture disk       27
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       26         Received goods       16         Inspection check       59         Connection       59         Installation       22         Installation conditions       24         Mounting location       24         Mounting location       24         Sensor heating       26
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Inspection check       59         Connection       59         Installation       22         Installation       23         Inlet and outlet runs       24         Installation dimensions       24         Mounting location       22         Orientation       23         Rupture disk       27         Sensor heating       26         System pressure       27
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Inspection check       200         Connection       59         Installation       22         Installation conditions       24         Mounting location       24         Mounting location       24         Sensor heating       25         Thermal insulation       25
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Received goods       16         Inspection check       200         Connection       59         Installation       22         Installation conditions       24         Mounting location       24         Mounting location       24         Installation dimensions       24         Installation dimensions       24         Installation dimensions       24         Mounting location       23         Rupture disk       27         Sensor heating       26         System pressure       25         Thermal insulation       25
I         Identifying the measuring device       16         Incoming acceptance       16         Influence       212         Medium pressure       212         Medium temperature       212         Medium temperature       212         Information on the document       6         Inlet runs       24         Input       200         Inspection       200         Received goods       16         Inspection check       200         Connection       59         Installation conditions       22         Installation dimensions       24         Mounting location       22         Orientation       23         Rupture disk       27         Sensor heating       26         System pressure       25         Thermal insulation       25         Vibrations       26         System pressure       25         Thermal insulation       26         System pressure       25         Thermal insulation       26         System pressure       25         Thermal insulation       26 <tr td="">         Installation dimension</tr>

# L

Languages, operation options	220
Line recorder	145

Local display	221
Navigation view	. 65
see Diagnostic message	
see In alarm condition	
see Operational display	
Low flow cut off	208

# М

Main electronics module
Maintenance tasks
Managing the device configuration
Manufacturer ID
Manufacturing date
Materials 218
Maximum measured error 210
Measured values
see Process variables
Measuring and test equipment 193
Measuring device
Configuration 9/
Conversion 10/
Disposal 105
Mounting the concer
Mounting the sensor
Preparing for electrical connection
Preparing for mounting
Removing
Repairs
Structure
Switch-on
Measuring principle
Measuring range
Calculation example for gas
For gases
For liquids
Measuring range, recommended
Measuring system
Mechanical load
Medium pressure
Influence
Medium temperature
Influence
Menu
Diagnostics
Setup
Menus
For measuring device configuration
For specific settings
Mounting dimensions
see Installation dimensions
Mounting location
Mounting preparations
Mounting tools
g g g g g
Ν
Nameplate
Sensor
Transmitter

Navigation view In the submenu	. 65 . 65 . 67
<b>O</b> nsite display	
Numeric editor	. 67 . 67 201
Operating keys	, 100
see Operating elements	
Operating menu	<b>C</b> 1
Menus, submenus	. 61
Structure	. 01
Operating philosophy	. 04 67
Operating philosophy	. 02 138
Operation ontions	150
Operational display	. 00
Operational safety	. 11
Order code	7.19
Orientation (vertical, horizontal)	. 23
Outlet runs	. 24
Output	203
Output signal	203
ס	
<b>r</b> Packaging disposal	. 22
<b>r</b> Packaging disposal	. 22
<b>r</b> Packaging disposal	. 22 . 72
r         Packaging disposal         Parameter         Changing         Entering values or text         Description continues	. 22 . 72 . 72
r         Packaging disposal	. 22 . 72 . 72
r         Packaging disposal         Parameter         Changing         Entering values or text         Parameter settings         Administration (Submenu)         Advanced setup (Submenu)	. 22 . 72 . 72 131
r         Packaging disposal         Parameter         Changing         Entering values or text         Parameter settings         Administration (Submenu)         Advanced setup (Submenu)         Analog inputs (Submenu)	. 22 . 72 . 72 131 121 100
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 129
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current input	. 22 . 72 . 72 131 121 100 121 129 101
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 129 101 101
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 129 101 101 141
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current inputCurrent input 1 to n (Submenu)Current output	. 22 . 72 . 72 131 121 100 121 129 101 101 141 103
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 101 141 103 103
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 103 145
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 103 145 131 190
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 101 103 145 131 190 185 125
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125 115
r         Packaging disposal	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125 115 100 100
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current inputCurrent input (Wizard)Current outputCurrent outputCurrent outputData logging (Submenu)Device information (Submenu)Display (Submenu)Display (Submenu)Low flow cut off (Wizard)	. 22 . 72 . 72 131 121 100 121 101 101 101 103 145 131 190 185 125 115 100 100 118
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current inputCurrent inputCurrent input 1 to n (Submenu)Current output (Wizard)Current output (Wizard)Data logging (Submenu)Device information (Submenu)Display (Submenu)Display (Wizard)Low flow cut off (Wizard)Low flow cut off (Wizard)Measured variables (Submenu)	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125 115 100 100 118 139
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current inputCurrent input (Wizard)Current outputCurrent output (Wizard)Data logging (Submenu)Device information (Submenu)Device information (Submenu)Display (Submenu)Display (Wizard)Low flow cut off (Wizard)Measured variables (Submenu)Partially filled pipe detection (Wizard)	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125 100 100 118 139 119
rPackaging disposalParameterChangingEntering values or textParameter settingsAdministration (Submenu)Advanced setup (Submenu)Analog inputs (Submenu)Analog inputs (Submenu)Calculated values (Submenu)Calculated values (Submenu)Configuration backup (Submenu)Current inputCurrent input (Wizard)Current outputCurrent outputCurrent outputData logging (Submenu)Define access code (Wizard)Device information (Submenu)Display (Submenu)Display (Wizard)Low flow cut off (Wizard)Low flow cut off (Wizard)Measured variables (Submenu)Partially filled pipe detection (Wizard)Pulse/frequency/switch output	. 22 . 72 . 72 131 121 100 121 101 101 141 103 145 131 190 185 125 115 100 100 118 139 119 106

..... 106, 107, 111 Pulse/frequency/switch output 1 to n (Submenu) 143

Relay output	113
Relay output 1 to n (Submenu)	143
Relay output 1 to n (Wizard)	113
Reset access code (Submenu)	131
Select medium (Wizard)	. 98
Sensor adjustment (Submenu)	122
Setup (Menu)	. 95
Simulation (Submenu)	132
Status input	102
Status input (Submenu)	102
Status input 1 to n (Submenu)	141
System units (Submenu)	. 95
Totalizer (Submenu)	140
Totalizer 1 to n (Submenu)	123
Totalizer handling (Submenu)	144
Value current output 1 to n (Submenu)	142
Web server (Submenu)	. 80
WLAN Settings (Submenu)	128
Zero point adjustment (Submenu)	123
Performance characteristics	210
Post-connection check (checklist)	59
Post-installation check	93
Post-installation check (checklist)	34
Potential equalization	55
Power consumption	209
Power supply failure	209
Pressure Equipment Directive	225
Pressure loss	217
Pressure-temperature ratings	216
Process connections	220
Process variables	200
	200
Measured	200
Product safety	. 12
Proline 500 – digital transmitter	17
Connecting the signal cable/supply voltage cable.	. 47
Proline 500 connecting cable terminal assignment	4.0
Sensor connection nousing	. 49
Proline 500 transmitter	ГЭ
Connecting the signal cable/supply voltage cable .	. 55 154
Protecting parameter settings	134
R	

Radio approval	225 224 . 73
Reading measured values	138
Recalibration	193
Reference operating conditions	210
Registered trademarks	8
Remedial measures	
Calling up	157
Closing	157
Remote operation	221
Repair	194
Repair of a device	194
Repairs	
Notes	194
Repeatability	211

Replacement
Device components
Requirements for personnel
Response time
Return
Rupture disk
Safety instructions
Triggering pressure
S
Safety
Sensor
Mounting
Sensor heating
Sensor housing
Serial number
Setting the operating language
Settings
Adapting the measuring device to the process
conditions
Administration
Advanced display configurations
Analog input
Current input
Current output
Device reset
Device tag
I/O configuration
Local display
Low flow
Managing the device configuration
Managing the device configuration
Managing the device configuration    129      Medium    98      Operating language    93
Managing the device configuration       129         Medium       98         Operating language       93         Partial filled pipe detection       119
Managing the device configuration
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144WLAN128Showing data logging145
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144WLAN128Showing data logging145Signal on alarm206
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Spare parts194
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Special connection instructions56
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer123Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare parts194Special connection instructions56Special mounting instructions56
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Special connection instructions56Special mounting instructions56Special mounting instructions27
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer124WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Special connection instructions56Special mounting instructions27Standards and guidelines225
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Special connection instructions56Special mounting instructions27Status area225Status area24
Managing the device configuration129Medium98Operating language93Partial filled pipe detection119Pulse output106Pulse/frequency/switch output106, 107Relay output113Resetting the totalizer144Restart device189Sensor adjustment122Simulation132Status input102Switch output111System units95Totalizer reset144WLAN128Showing data logging145Signal on alarm206Software release87Spare part194Special connection instructions56Special mounting instructions56Special mounting instructions225Status areaFor operational display64

Status signals	8
Storage concept	3
Storage conditions	1
Storage temperature	1
Storage temperature range 214	4
Structure	
Measuring device $\ldots \ldots 1^4$	4
Operating menu	1
Submenu	
Administration	1
Advanced setup 120, 12	1
Analog inputs 100	n
Calculated values 12	1
Configuration backup 12	g
Current input 1 to n	1
Data logging	5
Data logging 14.	ך ח
	5
Display	ע ד
Evenit list	
	J 1
Input values	L
	5
Measured variables	9
	2
Overview	2
Process variables	1
Pulse/frequency/switch output 1 to n	3
Relay output 1 to n	3
Reset access code	1
Sensor adjustment	2
Simulation	2
Status input	2
Status input 1 to n	1
System units	5
Totalizer	C
Totalizer 1 to n	3
Totalizer handling	4
Value current output 1 to n	2
Web server	0
WLAN Settings	8
Zero point adjustment	3
Supply voltage	9
Surface roughness	0
Switch output	5
Symbols	
Controlling data entries	8
For communication	4
For diagnostic behavior	4
For locking	4
For measured variable	4
For measurement channel number 64	4
For menus	б
For parameters	б
For status signal	4
For submenu	б
For wizard	б
In the status area of the local display 64	4
Input screen	8
Operating elements	7

System design	
Measuring system	199
see Measuring device design	
System integration	87
System pressure	25
T	
Technical data, overview	199
Temperature range	
Ambient temperature range for display	221
Medium temperature	215
Storage temperature	21
Terminal assignment	39
Terminal assignment of connecting cable for Proline	
500- digital	
Sensor connection housing	42
Terminals	209
Tests and certificates	225
Text editor	67
Thermal insulation	25
Tool tip	
see Help text	
Tools	
Electrical connection	35
For mounting	29
Transport	21
Totalizer	
	123
Transmitter	<b>.</b>
Turning the display module	34
Turning the housing	33
Transporting the measuring device	21
Troubleshooting	
General	149
Turning the display module	34
i urning the electronics nousing	
see Turning the transmitter housing	22
I urning the transmitter housing	33
II	
Use of the measuring device	
Bordorlino casos	10
	10
	10
Lisor interface	
Current diagnostic event	195
Drovious diagnostic event	195
	67
0.561 10165	02
V	
Version data for the device	87
Vibration- and shock-resistance	214
Vibrations	2.6
	_0
W	
W@M 193, 1	194
W@M Device Viewer 16, 1	194
Weight	
SI units	218
Transport (notes)	21

US units
Wizard
Current input
Current output 103
Define access code
Display
Low flow cut off
Partially filled pipe detection
Pulse/frequency/switch output 106, 107, 111
Relay output 1 to n
Select medium
WLAN settings
Workplace safety 11
Write access
Write protection
Via access code
Via block operation
Via write protection switch
Write protection switch



www.addresses.endress.com

