

Description of Device Parameters

Cerabar PMP71B

Process pressure measurement
HART




Table of contents

- 1 About this document 4**
 - 1.1 Document function 4
 - 1.2 Target audience 4
 - 1.3 Using this document 4
 - 1.4 Symbols used 5
 - 1.5 Documentation 5
- 2 Overview of the operating menu 6**
- 3 Description of device parameters ... 15**
 - 3.1 "Guidance" menu 17
 - 3.2 "Diagnostics" menu 33
 - 3.3 "Application" menu 44
 - 3.4 "System" menu 52
- Index 69**

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target audience

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and their parameters that are available when the **"Maintenance" option** user role is activated.



For the operating concept of the operating menus, see the Operating Instructions.

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Factory setting: Default setting on leaving the factory
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Additional information: 

Reference to documentation: 

Operation via local display: 

Operation via operating tool: 

Write-protected parameter: 

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

 The Operating Instructions are available on the Internet at: www.endress.com →
Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

 The Special Documentation is available on the Internet at: www.endress.com →
Download

2 Overview of the operating menu

Guidance	→ 17
► Commissioning	→ 17
Device tag	→ 17
Assign PV	→ 17
Assign SV	→ 17
Damping	→ 18
Pressure unit	→ 18
Temperature unit	→ 18
Zero adjustment	→ 19
Pressure	→ 19
Output current transfer function	→ 19
Scaled variable unit	→ 20
Free text	→ 20
Temperature unit	→ 18
Zero adjustment	→ 19
Pressure	→ 19
Scaled variable transfer function	→ 21
Table not available	→ 21
Pressure value 1	→ 21
Scaled variable value 1	→ 22
Pressure value 2	→ 22
Scaled variable value 2	→ 22
Lower range value output	→ 22
Pressure	→ 19

Upper range value output	→ 23
Pressure	→ 19
Lower range value output	→ 22
Scaled variable	→ 23
Upper range value output	→ 23
Scaled variable	→ 23
Current range output	→ 23
Failure behavior current output	→ 23
► SIL confirmation	→ 24
Proof test via Bluetooth allowed?	→ 24
Enter SIL locking code	→ 24
SIL status	→ 24
Character test string	→ 25
Device tag	→ 25
Device name	→ 25
Serial number	→ 26
CRC device configuration	→ 26
Stored CRC device configuration	→ 26
Timestamp stored CRC device config.	→ 26
Operating time	→ 27
Configuration counter	→ 27
Zero adjustment offset	→ 27
Zero adjustment offset	→ 27
HP/LP swap	→ 27
Damping	→ 28

Sensor pressure range behavior	→ 28
Output current transfer function	→ 28
Output current transfer function	→ 28
Low cutoff	→ 28
Failure behavior current output	→ 28
Current range output	→ 29
Measuring mode current output	→ 29
Lower range value output	→ 29
Upper range value output	→ 29
Assign PV	→ 30
Enter SIL locking code	→ 24
Code incorrect	→ 30
Locking status	→ 30
► Deactivate SIL	→ 31
Enter SIL unlocking code	→ 31
Code incorrect	→ 31
Locking status	→ 32
Diagnostics	→ 33
► Active diagnostics	→ 33
Active diagnostics	→ 33
Timestamp	→ 33
Previous diagnostics	→ 34
Timestamp	→ 34
Operating time from restart	→ 34
Operating time	→ 35

► Minimum/maximum values	→ 35
Pressure min	→ 35
Pressure max	→ 35
Counter limit underruns sensor Pmin	→ 35
Counter limit overruns sensor Pmax	→ 35
Counter underruns of user limit Pmin	→ 36
Counter overruns of user limit Pmax	→ 36
Reset user defined counters P and T	→ 36
Minimum sensor temperature	→ 36
Maximum sensor temperature	→ 36
Counter limit overruns sensor Tmax	→ 36
Counter limit underruns sensor Tmin	→ 37
Counter underruns of user limit Tmin	→ 37
Counter overruns of user limit Tmax	→ 37
Minimum terminal voltage	→ 37
Maximum terminal voltage	→ 37
Minimum electronics temperature	→ 37
Maximum electronics temperature	→ 38
► Simulation	→ 38
Simulation	→ 38
Value pressure simulation	→ 38
Value current output	→ 38
Diagnostic event category	→ 38
Diagnostic event simulation	→ 39
► Heartbeat Technology	→ 39

▶ Heartbeat Verification	→ 39
Start verification	→ 39
Operating time (Verification)	→ 40
Verification result	→ 40
Status	→ 40
▶ Loop diagnostics	→ 40
Rebuild baseline	→ 40
Tolerated deviation +/-	→ 41
806 Alarm delay	→ 41
Baseline status	→ 41
Loop diagnostics	→ 41
Terminal voltage 1	→ 42
Clamping voltage lower threshold	→ 42
Clamping voltage upper threshold	→ 42
▶ Statistical Sensor Diagnostics	→ 42
SSD: Statistical Sensor Diagnostics	→ 42
System status	→ 43
Signal status	→ 43
Signal noise status	→ 43
Application	→ 44
▶ Measured values	→ 44
Terminal voltage 1	→ 44
Terminal current	→ 44
Electronics temperature	→ 44
Pressure	→ 45

Scaled variable	→ 45
Sensor temperature	→ 45
► Sensor	→ 45
► Sensor configuration	→ 47
Output current transfer function	→ 47
Damping	→ 47
► Wet calibration	→ 48
► Zero	→ 48
Zero	→ 48
Pressure	→ 48
Pressure value 1	→ 48
Lower range value output	→ 48
► Span	→ 49
Span	→ 49
Pressure	→ 49
Pressure value 2	→ 49
Upper range value output	→ 49
► HART output	→ 50
► Configuration	→ 50
HART address	→ 50
HART short tag	→ 50
Device tag	→ 50
No. of preambles	→ 51
Loop current mode	→ 51
System	→ 52

▶ Device management	→ 52
Device tag	→ 52
Locking status	→ 52
Configuration counter	→ 53
Reset device	→ 53
▶ User management	→ 54
User role	→ 54
▶ Change user role	→ 54
Enter access code	→ 54
▶ Change user role	→ 55
Start	→ 55
Password	→ 55
Status password entry	→ 55
▶ Define password	→ 56
Start	→ 56
New password	→ 56
Status password entry	→ 56
Confirm new password	→ 57
Status password entry	→ 56
▶ Change password	→ 57
Start	→ 57
Old password	→ 57
Status password entry	→ 57
New password	→ 58
Status password entry	→ 57

Confirm new password	→ 58
Status password entry	→ 57
► Delete password	→ 58
Start	→ 58
Old password	→ 58
Status password entry	→ 59
► Reset password	→ 59
Start	→ 59
Reset password	→ 59
Status password entry	→ 59
► Logout	→ 60
Start	→ 60
User role	→ 60
► Bluetooth configuration	→ 61
Bluetooth activation	→ 61
► Display	→ 15
Language	→ 15
Format display	→ 62
Value 1 display	→ 62
Value 2 display	→ 63
Value 3 display	→ 63
Value 4 display	→ 64
Contrast display	→ 64
► Information	→ 66
Device name	→ 66

Manufacturer	→ 66
Serial number	→ 67
Order code	→ 67
Firmware version	→ 67
Hardware version	→ 68
Checksum	→ 68
► Software configuration	→ 65
CRC device configuration	→ 65
Stored CRC device configuration	→ 65
Timestamp stored CRC device config.	→ 65
Activate SW option	→ 65

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

 The parameter description of the operating tool is contained in the operating tool.

Navigation  System → Display

Language	
Navigation	 System → Display → Language
Prerequisite	A local display is provided.
Description	Use this function to select the configured language on the local display.
Selection	■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ Bahasa Indonesia ■ tiếng Việt (Vietnamese) ■ čeština (Czech)
Factory setting	English (alternatively, the ordered language is preset in the device)

Access status display	
Navigation	 System → Display → Access stat.disp
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	■ Operator ■ Maintenance

Additional information*Description*

If the -symbol appears in front of a parameter, the parameter cannot be modified via the local display with the current access authorization.



Access authorization can be modified via the **Enter access code** parameter.



For the **Enter access code** parameter: See the "Disabling write protection via the access code" section of the Operating Instructions for the device.



If additional write protection is active, this restricts the current access authorization even further.

User interface

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1 "Guidance" menu

Navigation  Guidance

3.1.1 "Commissioning" wizard

Navigation  Guidance → Commissioning

Device tag 	
Navigation	 Guidance → Commissioning → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (#32)
Assign PV 	
Navigation	 Guidance → Commissioning → Assign PV
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).
Selection	■ Pressure ■ Scaled variable
Assign SV 	
Navigation	 Guidance → Commissioning → Assign SV
Description	Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).
Selection	■ Pressure ■ Scaled variable ■ Sensor temperature ■ Sensor pressure ■ Electronics temperature ■ Terminal current * ■ Terminal voltage 1 * ■ Median of pressure signal *

* Visibility depends on order options or device settings

- Noise of pressure signal *
- Percent of range
- Loop current
- Not used

Additional information

Selection

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Damping

Navigation

  Guidance → Commissioning → Damping

Description

Enter damping constant.
The damping constant affects the speed at which the measured value reacts to pressure changes.

User entry

0 to 999.0 s

Pressure unit

Navigation

  Guidance → Commissioning → Pressure unit

Description

Use this function to select the unit for the pipe pressure.

Selection

SI units	US units	Other units
■ MPa	psi	■ inH2O
■ kPa		■ inH2O (4°C)
■ Pa		■ mmH2O
■ bar		■ mmH2O (4°C)
■ mbar a		■ mH2O
■ torr		■ mH2O (4°C)
■ atm		■ ftH2O
■ kgf/cm²		■ inHg
■ gf/cm²		■ mmHg

Temperature unit

Navigation

  Guidance → Commissioning → Temperature unit

Description

Use this function to select the unit for the temperature.

* Visibility depends on order options or device settings

Selection	<i>SI units</i> ■ °C ■ K	<i>US units</i> °F
Factory setting	Country-specific: ■ °C ■ °F	
Additional information	<i>Selection</i>	

Zero adjustment



Navigation	Guidance → Commissioning → Zero adjustment
Description	Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.
Selection	■ No ■ Confirm

Pressure

Navigation	Guidance → Commissioning → Pressure
-------------------	-------------------------------------

Output current transfer function



Navigation	Guidance → Commissioning → Curr. trans.func
Description	'Linear' The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. 'Square root - differential pressure only' The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.
Selection	■ Linear ■ Square root *
Additional information	<i>Selection</i> "Square root" option Is used when a linear output proportional to the flow is required. The flow calculation is done internally in the transmitter.

* Visibility depends on order options or device settings

Scaled variable unit

Navigation	 Guidance → Commissioning → SV unit		
Description	Use 'Free text', first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.		
Selection	<i>SI units</i> ■ % ■ mm ■ cm ■ m ■ l ■ hl ■ m³ ■ g ■ kg ■ t ■ g/s ■ kg/s ■ kg/min ■ kg/h ■ t/min ■ t/h ■ t/d ■ m³/s ■ m³/min ■ m³/h ■ m³/d ■ l/s ■ l/min ■ l/h ■ Nm³/h ■ Nl/h ■ Sm³/s ■ Sm³/min ■ Sm³/h ■ Sm³/d ■ Nm³/s ■ g/cm³ ■ kg/m³ <i>Custom-specific units</i> Free text	<i>US units</i> ■ ft ■ in ■ ft³ ■ gal (us) ■ bbl (us;oil) ■ oz ■ lb ■ STon ■ lb/s ■ lb/min ■ lb/h ■ STon/min ■ STon/h ■ STon/d ■ ft³/s ■ ft³/min ■ ft³/h ■ ft³/d ■ gal/s (us) ■ gal/min (us) ■ gal/h (us) ■ gal/d (us) ■ bbl/s (us;oil) ■ bbl/min (us;oil) ■ bbl/h (us;oil) ■ bbl/d (us;oil) ■ Sft³/min ■ Sft³/h ■ Sft³/d	<i>Imperial units</i> ■ gal (imp) ■ gal/s (imp) ■ gal/min (imp) ■ gal/h (imp)

Free text

Navigation	 Guidance → Commissioning → Free text
User entry	Character string comprising numbers, letters and special characters (#32)

Scaled variable transfer function


Navigation	Guidance → Commissioning → Scal. v. trans.
Description	'Linear' The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. Deviating from the bar graph (current output), the digital value on the display shows continues to be the eradicated value. 'Square root' The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol. 'Table' The output ist defined according to the scaled variable / pressure table entered.
Selection	■ Linear ■ Square root * ■ Table
Additional information	<i>Selection</i> "Square root" option Is used when a linear output porportional to the flow is required. The flow calcualtion is done internally in the transmitter.

Table not available

Navigation	Guidance → Commissioning → Table not avail.
User interface	Character string comprising numbers, letters and special characters (#2)

Pressure value 1


Navigation	Guidance → Commissioning → P. value 1
Description	Enter pressure for the first scaling point. 'Scaled variable value 1' will be allocated to this pressure.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Scaled variable value 1



Navigation  Guidance → Commissioning → Sc. var.value 1

Description Enter value for the first scaling point. This value is allocated to 'Pressure value 1'.

User entry Signed floating-point number

Pressure value 2



Navigation  Guidance → Commissioning → P. value 2

Description Enter pressure for the second scaling point. 'Scaled variable value 2' will be allocated to this pressure.

User entry Signed floating-point number

Scaled variable value 2



Navigation  Guidance → Commissioning → Sc. var.value 2

Description Enter value for the second scaling point. This value is allocated to 'Pressure value 2'.

User entry Signed floating-point number

Lower range value output



Navigation  Guidance → Commissioning → Low.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

Pressure

Navigation   Guidance → Commissioning → Pressure

Upper range value output

Navigation   Guidance → Commissioning → Upp.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

Scaled variable

Navigation   Guidance → Commissioning → Scaled variable

User interface Signed floating-point number

Current range output

Navigation   Guidance → Commissioning → Cur.range outp

Description Define the current range used to transmit the measured or calculated value.
In brackets are indicated the “low saturation value” and the “high saturation value”.
If Measured value ≤ “low saturation”, the output current is set to “low saturation”.
If Measured value ≥ “high saturation”, the output current is set to “high saturation”.

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4... 20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Failure behavior current output

Navigation   Guidance → Commissioning → Fail.behav.out

Description Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: >21.5 mA

- Selection
- Min.

■ Max.

3.1.2

"SIL confirmation" wizard

Navigation



Guidance → SIL confirmation

Proof test via Bluetooth allowed?

Navigation



Guidance → SIL confirmation → Bluetooth

Description

After completion of the SIL activation/deactivation wizard, the device will be write protected via software lock.

To use the proof test wizard (optional) where alarm currents are simulated, the device does not have to be unlocked.

It must be defined, if the proof test wizard via Bluetooth is allowed.

- Selection
- No

■ Yes

Enter SIL locking code

Navigation



Guidance → SIL confirmation → SIL locking code

Description

Enter the locking code to start the SIL/WHG locking sequence.

User entry

0 to 65 535

- Additional information
- Locking codes

■ WHG: 7450

■ SIL: 7452

■ SIL and WHG: 7454

SIL status

Navigation



Guidance → SIL confirmation → SIL status

- User interface
- Not active

■ SIL sequence active

■ Active

■ Failed


■ Finished

Character test string

Navigation	 Guidance → SIL confirmation → Char.test string
Description	Check the shown character string for correct representations of the characters and digits.
User interface	Character string comprising numbers, letters and special characters (#14)

Device tag

Navigation	 Guidance → SIL confirmation → Device tag
Description	Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.
User interface	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).
Additional information	<i>User interface</i>



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Device name

Navigation	 Guidance → SIL confirmation → Device name
Description	Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.
User interface	Max. 32 characters such as letters or numbers.

Serial number 	
Navigation	 Guidance → SIL confirmation → Serial number
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number ▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer
CRC device configuration	
Navigation	 Guidance → SIL confirmation → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535
Stored CRC device configuration	
Navigation	 Guidance → SIL confirmation → Stored CRC conf.
Description	Stored CRC after the last SIL lock. Factory delivery is 65535 means that the device has not yet been SIL locked.
User interface	0 to 65 535
Timestamp stored CRC device config.	
Navigation	 Guidance → SIL confirmation → TS stored CRC
Description	Gives the time stamp when the CRC was last stored following completion of the SIL-Mode Wizard.
User interface	Character string comprising numbers, letters and special characters (#20)

Operating time

Navigation  Guidance → SIL confirmation → Operating time

Description Indicates how long the device has been in operation.

Additional information Maximum time: 9 999 d (≈ 27 years)

Configuration counter

Navigation  Guidance → SIL confirmation → Config. counter

Description Displays the counter for changes to the device parameters.
 Additional information:
 - If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
 - When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
 - Once the counter has reached the value 65535, it restarts at 0.

User interface 0 to 65 535

Zero adjustment offset

Navigation   Guidance → SIL confirmation → Zero adj. offset

Description Assigned value of zero adjustment due to mounting position.

User interface Character string comprising numbers, letters and special characters (#20)

HP/LP swap

Navigation  Guidance → SIL confirmation → HP/LP swap

Description Assigned setting high pressure / low pressure.

User interface

- No
- Yes

Damping

Navigation	 Guidance → SIL confirmation → Damping
Description	Assigned damping value.
User interface	Character string comprising numbers, letters and special characters (#20)

Sensor pressure range behavior

Navigation	 Guidance → SIL confirmation → P-range behavior
Description	Assigned event behavior in case of over/under pressure outside of measuring range.
User interface	■ Alarm ■ Warning ■ Remark ■ Special

Output current transfer function

Navigation	  Guidance → SIL confirmation → Curr. trans.func
Description	Assigned transfer function for current output.
User interface	■ Linear ■ Square root

Low cutoff

Navigation	 Guidance → SIL confirmation → Low cutoff
User interface	Character string comprising numbers, letters and special characters (#20)

Failure behavior current output

Navigation	 Guidance → SIL confirmation → Fail.behav.out
Description	Assigned value of current output in case of an error.
User interface	■ Min. ■ Max.

Current range output

Navigation	 Guidance → SIL confirmation → Cur.range outp
Description	Assigned current range used to transmit the measured value.
User interface	■ 4...20 mA (4... 20.5 mA) ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ Customer specific

Measuring mode current output

Navigation	 Guidance → SIL confirmation → Meas.mode outp
Description	Assigned setting of curve form of current output.
User interface	■ Standard ■ Inverse ■ Bi-directional

Lower range value output

Navigation	 Guidance → SIL confirmation → Low.range outp
Description	Assigned value 4 mA.
User interface	Character string comprising numbers, letters and special characters (#20)

Upper range value output

Navigation	 Guidance → SIL confirmation → Upp.range outp
Description	Assigned value 20 mA.
User interface	Character string comprising numbers, letters and special characters (#20)

Assign PV

Navigation	 Guidance → SIL confirmation → Assign PV
Description	Identifies the process variable linked with the primary variable. Primary variable is used in HART as current output.
User interface	■ Pressure ■ Scaled variable

Enter SIL locking code



Navigation	  Guidance → SIL confirmation → SIL locking code
Description	Enter the locking code to start the SIL/WHG locking sequence.
User entry	0 to 65 535
Additional information	Locking codes ■ WHG: 7450 ■ SIL: 7452 ■ SIL and WHG: 7454

Code incorrect



Navigation	 Guidance → SIL confirmation → Code incorrect
Description	Abort SIL confirmation sequence or reenter SIL locking code.
Selection	■ Reenter code ■ Abort sequence

Locking status

Navigation	 Guidance → SIL confirmation → Locking status
Description	Displays the active write protection.
User interface	■ Hardware locked ■ SIL locked ■ Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter (→  15) applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

3.1.3 "Deactivate SIL" wizard

Navigation  Guidance → Deactivate SIL

Enter SIL unlocking code

Navigation	 Guidance → Deactivate SIL → SIL unlock. code
Description	The SIL locking/unlocking code can be found in the corresponding safety manual.
User entry	0 to 65 535

Code incorrect

Navigation	 Guidance → Deactivate SIL → Code incorrect
Description	Abort SIL confirmation sequence or reenter SIL locking code.
Selection	■ Reenter code ■ Abort sequence

Locking status

Navigation

 Guidance → Deactivate SIL → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- SIL locked
- Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter (→  15) applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

3.2 "Diagnostics" menu

Navigation  Diagnostics

3.2.1 "Active diagnostics" submenu

Navigation  Diagnostics → Active diagnos.

Active diagnostics

Navigation	  Diagnostics → Active diagnos. → Active diagnos.
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i>  Additional pending diagnostic messages can be viewed in the Diagnostic list submenu. <i>Example</i> For the display format: ⊗F271 Main electronic failure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Actual diagnostics parameter (→  33). <i>Example</i> For the display format: 24d12h13m00s

Previous diagnostics

Navigation	  Diagnostics → Active diagnos. → Prev.diagnostics
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Example</i> For the display format:  F271 Main electronic failure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  34). <i>Example</i> For the display format: 24d12h13m00s

Operating time from restart

Navigation	  Diagnostics → Active diagnos. → Time fr. restart
Description	Shows the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	  Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time: 9 999 d ($\approx$ 27 years)

3.2.2 "Minimum/maximum values" submenu

Navigation  Diagnostics → Min/max val.

Pressure min

Navigation	  Diagnostics → Min/max val. → Pressure min
User interface	Signed floating-point number

Pressure max

Navigation	  Diagnostics → Min/max val. → Pressure max
User interface	Signed floating-point number

Counter limit underruns sensor Pmin

Navigation	  Diagnostics → Min/max val. → Counter P < Pmin
User interface	0 to 65 535

Counter limit overruns sensor Pmax

Navigation	  Diagnostics → Min/max val. → Counter P > Pmax
User interface	0 to 65 535

Counter underruns of user limit Pmin

Navigation   Diagnostics → Min/max val. → Counter < P user

User interface 0 to 65 535

Counter overruns of user limit Pmax

Navigation   Diagnostics → Min/max val. → Counter > P user

User interface 0 to 65 535

Reset user defined counters P and T



Navigation   Diagnostics → Min/max val. → Reset count. P T

Selection

- Cancel
- Confirm

Minimum sensor temperature

Navigation   Diagnostics → Min/max val. → Min. sensor temp

User interface -273.15 to 9 726.85 °C

Maximum sensor temperature

Navigation   Diagnostics → Min/max val. → Max. Sensor temp

User interface -273.15 to 9 726.85 °C

Counter limit overruns sensor Tmax

Navigation   Diagnostics → Min/max val. → Counter T > Tmax

User interface 0 to 65 535

Counter limit underruns sensor Tmin

Navigation   Diagnostics → Min/max val. → Counter T < Tmin

User interface 0 to 65 535

Counter underruns of user limit Tmin

Navigation   Diagnostics → Min/max val. → Counter < T user

User interface 0 to 65 535

Counter overruns of user limit Tmax

Navigation   Diagnostics → Min/max val. → Counter > T user

User interface 0 to 65 535

Minimum terminal voltage

Navigation   Diagnostics → Min/max val. → Min.term.volt.

User interface 0.0 to 50.0 V

Maximum terminal voltage

Navigation   Diagnostics → Min/max val. → Max.term.voltage

User interface 0.0 to 50.0 V

Minimum electronics temperature

Navigation   Diagnostics → Min/max val. → Min.electr.temp.

User interface Signed floating-point number

Maximum electronics temperature

Navigation	  Diagnostics → Min/max val. → Max.electr.temp.
User interface	Signed floating-point number

3.2.3 "Simulation" submenu

Navigation

 Diagnostics → Simulation

Simulation

Navigation	  Diagnostics → Simulation → Simulation
Selection	■ Off ■ Pressure ■ Current output ■ Diagnostic event simulation

Value pressure simulation

Navigation	  Diagnostics → Simulation → Value pressure
User entry	Signed floating-point number

Value current output

Navigation	  Diagnostics → Simulation → Val. curr.outp
Description	Defines the value of the simulated output current.
User entry	3.59 to 23 mA

Diagnostic event category

Navigation	 Diagnostics → Simulation → Event category
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Diagnostic event simulation parameter (→  39).

- Selection**
- Sensor
 - Electronics
 - Configuration
 - Process

Diagnostic event simulation



Navigation Diagnostics → Simulation → Diag. event sim.

Description Use this function to select a diagnostic event for the simulation process that is activated.

- Selection**
- Off
 - Diagnostic event picklist (depends on the category selected)

Additional information *Description*



For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→ 38).

3.2.4 "Heartbeat Technology" submenu

Navigation Diagnostics → HBT

"Heartbeat Verification" submenu

Navigation Diagnostics → HBT → HBT Verification

Start verification



Navigation Diagnostics → HBT → HBT Verification → Start verificat.

Description Start verification.
To carry out a complete verification, select the selection parameters individually. Once the external measured values have been recorded, verification is started using the **Start** option.

- Selection**
- or
- Cancel
 - Start

Additional information

Operating time (Verification)

Navigation	  Diagnostics → HBT → HBT Verification → Operating time
Description	Indicates how long the device has been in operation.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation	  Diagnostics → HBT → HBT Verification → Verific. result
User interface	■ Not done ■ Passed ■ Not done ■ Failed

Status

Navigation	  Diagnostics → HBT → HBT Verification → Status
Description	Displays the current status of the verification.
User interface	■ Done ■ Busy ■ Failed ■ Not done

"Loop diagnostics" submenu

Navigation	 Diagnostics → HBT → Loop diagn.
------------	---

Rebuild baseline

Navigation	 Diagnostics → HBT → Loop diagn. → Reb. baseline
Description	Notice The current output is simulated. Bridge the PLC or take other appropriate measures to prevent an erroneous triggering of alarm messages or changes in the control loop behavior. The baseline should be rebuilt if planned changes have been made in the loop.

- Selection**
- No
 - Yes

Tolerated deviation +/-



Navigation Diagnostics → HBT → Loop diagn. → Toler. deviation

Description A value should be chosen to ensure that normal voltage deviations do not lead to unwanted messages.

Default
1.5 V DC

User entry 0.5 to 3.0 V

806 Alarm delay



Navigation Diagnostics → HBT → Loop diagn. → 806 Alarm delay

User entry 0 to 60 s

Baseline status

Navigation Diagnostics → HBT → Loop diagn. → Baseline status

Description 'Failed'
Means, baseline is not available or creation not possible.

'Passed'
Baseline is available.

- User interface**
- Failed
 - Success

Loop diagnostics



Navigation Diagnostics → HBT → Loop diagn. → Loop diagn.

- Selection**
- Disable
 - Enable

Terminal voltage 1

Navigation	 Diagnostics → HBT → Loop diagn. → Terminal volt. 1
Description	Shows the current terminal voltage that is applied at the output.
User interface	0.0 to 50.0 V

Clamping voltage lower threshold

Navigation	 Diagnostics → HBT → Loop diagn. → Lower threshold
User interface	0.0 to 50.0 V

Clamping voltage upper threshold

Navigation	 Diagnostics → HBT → Loop diagn. → Upper threshold
User interface	0.0 to 50.0 V

"Statistical Sensor Diagnostics" submenu

Navigation

 Diagnostics → HBT → SSD

SSD: Statistical Sensor Diagnostics

Navigation	 Diagnostics → HBT → SSD → Stat. Sens. Diag
Description	Enable or disable SSD. After selecting 'Disable', no statistical sensor diagnosis takes place. No diagnostic messages are output.
Selection	■ Disable ■ Enable

System status

Navigation   Diagnostics → HBT → SSD → System status

User interface

- Idle
- No sufficient signal noise
- Stable
- Not stable
- Verify System Dynamics

Signal status

Navigation   Diagnostics → HBT → SSD → Signal status

User interface

- Idle
- Building Baseline
- Verifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Signal noise status

Navigation   Diagnostics → HBT → SSD → Noise status

User interface

- Idle
- Building Baseline
- Verifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Counter Baseline creation SSD

Navigation   Diagnostics → HBT → SSD → Counter Baseline

Description Specifies how often the baseline has been rebuilt.

User interface Positive integer

3.3 "Application" menu

Navigation  Application

3.3.1 "Measured values" submenu

Navigation  Application → Measured values

Terminal voltage 1

Navigation	 Application → Measured values → Terminal volt. 1
Description	Shows the current terminal voltage that is applied at the output.
User interface	0.0 to 50.0 V

Terminal current

Navigation	 Application → Measured values → Terminal curr.
Description	Shows the current value of the current output which is currently measured.
User interface	0 to 30 mA

Electronics temperature

Navigation	 Application → Measured values → Electronics temp
User interface	Signed floating-point number

Pressure

Navigation  Application → Measured values → Pressure

Scaled variable

Navigation  Application → Measured values → Scaled variable

User interface Signed floating-point number

Sensor temperature

Navigation  Application → Measured values → Sensor temp.

User interface -273.15 to 9726.85 °C

3.3.2 "Sensor" submenu

Navigation  Application → Sensor

"Sensor calibration" submenu

Navigation  Application → Sensor → Sensor cal.

Zero adjustment



Navigation  Application → Sensor → Sensor cal. → Zero adjustment

Description Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Calibration offset		
Navigation	 Application → Sensor → Sensor cal. → Calibr offset	
Prerequisite	Absolute pressure sensor	
User entry	Signed floating-point number	
Zero adjustment offset		
Navigation	 Application → Sensor → Sensor cal. → Zero adj. offset	
User entry	Signed floating-point number	
Sensor Trim Reset		
Navigation	 Application → Sensor → Sensor cal. → Sen. Trim Reset	
Selection	■ No ■ Confirm	
Lower sensor trim		
Navigation	 Application → Sensor → Sensor cal. → LowerSensor trim	
User entry	Signed floating-point number	
Upper sensor trim		
Navigation	 Application → Sensor → Sensor cal. → UpperSensor trim	
User entry	Signed floating-point number	

"Sensor configuration" submenu

Navigation  Application → Sensor → Sensor conf.

Output current transfer function

Navigation	  Application → Sensor → Sensor conf. → Curr. trans.func
Description	'Linear' The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. 'Square root - differential pressure only' The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.
Selection	■ Linear ■ Square root *
Additional information	<i>Selection</i> "Square root" option Is used when a linear output proportional to the flow is required. The flow calculation is done internally in the transmitter.

Damping

Navigation	  Application → Sensor → Sensor conf. → Damping
Description	Enter damping constant. The damping constant affects the speed at which the measured value reacts to pressure changes.
User entry	0 to 999.0 s

* Visibility depends on order options or device settings

"Wet calibration" submenu

Navigation  Application → Sensor → Wet calibration

"Zero" wizard

Navigation  Application → Sensor → Wet calibration → Zero

Zero

Navigation  Application → Sensor → Wet calibration → Zero → Zero

Selection

- No
- Confirm

Pressure

Navigation  Application → Sensor → Wet calibration → Zero → Pressure

Pressure value 1

Navigation  Application → Sensor → Wet calibration → Zero → P. value 1

Description Enter pressure for the first scaling point. 'Scaled variable value 1' will be allocated to this pressure.

User entry Signed floating-point number

Lower range value output

Navigation  Application → Sensor → Wet calibration → Zero → Low.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

"Span" wizard

Navigation  Application → Sensor → Wet calibration → Span

Span

Navigation  Application → Sensor → Wet calibration → Span → Span

Selection

- No
- Confirm

Pressure

Navigation  Application → Sensor → Wet calibration → Span → Pressure

Pressure value 2

Navigation  Application → Sensor → Wet calibration → Span → P. value 2

Description Enter pressure for the second scaling point. 'Scaled variable value 2' will be allocated to this pressure.

User entry Signed floating-point number

Upper range value output

Navigation  Application → Sensor → Wet calibration → Span → Upp.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

3.3.3 "HART output" submenu

Navigation  Application → HART output

"Configuration" submenu

Navigation  Application → HART output → Configuration

HART address

Navigation	  Application → HART output → Configuration → HART address
Description	Define the HART address of the device.
User entry	0 to 63
Additional information	■ The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode). ■ Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0. ■ All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.

HART short tag

Navigation	  Application → HART output → Configuration → HART short tag
Description	Defines the short tag for the measuring point. Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

Device tag

Navigation	  Application → HART output → Configuration → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (#32)

No. of preambles		
Navigation	  Application → HART output → Configuration → No. of preambles	
Description	Defines the number of preambles in the HART telegram.	
User entry	5 to 20	
Loop current mode		
Navigation	  Application → HART output → Configuration → Loop curr mode	
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.	
Selection	■ Disable ■ Enable	

3.4 "System" menu

Navigation  System

3.4.1 "Device management" submenu

Navigation  System → Device manag.

Device tag



Navigation   System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (#32)

Locking status

Navigation   System → Device manag. → Locking status

Description Displays the active write protection.

User interface

- Hardware locked
- SIL locked
- Temporarily locked

Additional information *User interface*
If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.
 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter (→  15) applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Configuration counter

Navigation  System → Device manag. → Config. counter

Description Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65535, it restarts at 0.

User interface 0 to 65 535

Reset device



Navigation  System → Device manag. → Reset device

Description Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Additional information *Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to its factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

* Visibility depends on order options or device settings

3.4.2 "User management" submenu

Navigation  System → User manag.

User role

Navigation	 System → User manag. → User role
Description	Displays the access authorization to the parameters via the operating tool.
User interface	■ Operator ■ Maintenance ■ Expert
Additional information	<i>Description</i>  Access authorization can be modified via the Enter access code parameter.  If additional write protection is active, this restricts the current access authorization even further. <i>User interface</i>  Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

"Change user role" wizard

Navigation  System → User manag. → Change user role

Enter access code

Navigation	 System → User manag. → Change user role → Ent. access code
Description	Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.
User entry	0 to 9 999

"Change user role" wizard

Navigation  System → User manag. → Change user role

Start

Navigation  System → User manag. → Change user role → Start

User interface Character string comprising numbers, letters and special characters (#14)

Password

Navigation  System → User manag. → Change user role → Password

Description Enter the password for the 'Maintenance' user role to get access to the functionality of this role.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation  System → User manag. → Change user role → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Define password" wizard

Navigation  System → User manag. → Define password

Start

Navigation  System → User manag. → Define password → Start

User interface Character string comprising numbers, letters and special characters (#14)

New password

Navigation  System → User manag. → Define password → New password

Description If the factory setting is not changed, the device works without write-protection, using userrole 'Maintenance'. The configuration data of the device can always be modified. Once the password has been defined, write-protected devices can only be set to maintenance mode if a correct password is entered in the parameter 'Password'. A new password is valid, after it has been confirmed within the parameter 'Confirm new password'. Any new password must consist of at least 4 and a maximum of 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation   System → User manag. → Define password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Confirm new password



Navigation	 System → User manag. → Define password → Conf. new passw.
Description	Enter the new password again to confirm.
User entry	Character string comprising numbers, letters and special characters (#16)

"Change password" wizard

Navigation  System → User manag. → Change password

Start

Navigation	 System → User manag. → Change password → Start
User interface	Character string comprising numbers, letters and special characters (#14)

Old password



Navigation	 System → User manag. → Change password → Old password
Description	Enter the current password, to subsequently change the existing password.
User entry	Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation	  System → User manag. → Change password → Status pw entry
Description	Use this function to display the status of the password verification.
User interface	■ ----- ■ Wrong password ■ Password rule violated ■ Password accepted ■ Permission denied ■ Confirm PW mismatch ■ Reset password accepted ■ Invalid user role ■ Wrong sequence of entry

New password 	
Navigation	 System → User manag. → Change password → New password
Description	If the factory setting is not changed, the device works without write-protection, using userrole 'Maintenance'. The configuration data of the device can always be modified. Once the password has been defined, write-protected devices can only be set to maintenance mode if a correct password is entered in the parameter 'Password'. A new password is valid, after it has been confirmed within the parameter 'Confirm new password'. Any new password must consist of at least 4 and a maximum of 16 characters and can contain letters and numbers.
User entry	Character string comprising numbers, letters and special characters (#16)
Confirm new password 	
Navigation	 System → User manag. → Change password → Conf. new passw.
Description	Enter the new password again to confirm.
User entry	Character string comprising numbers, letters and special characters (#16)
"Delete password" wizard	
<i>Navigation</i>	 System → User manag. → Delete password
Start	
Navigation	 System → User manag. → Delete password → Start
User interface	Character string comprising numbers, letters and special characters (#14)
Old password 	
Navigation	 System → User manag. → Delete password → Old password
Description	Enter the current password, to subsequently change the existing password.
User entry	Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation  System → User manag. → Delete password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Reset password" wizard

Navigation  System → User manag. → Reset password

Start

Navigation  System → User manag. → Reset password → Start

User interface Character string comprising numbers, letters and special characters (#14)

Reset password

Navigation  System → User manag. → Reset password → Reset password

Description Enter a code to reset the current password.
CAUTION: Use this function only if the current password is lost. Contact your Endress+Hauser Sales Center.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation  System → User manag. → Reset password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Logout" wizard

Navigation  System → User manag. → Logout

Start**Navigation**

 System → User manag. → Logout → Start

User interface

Character string comprising numbers, letters and special characters (#14)

User role**Navigation**

 System → User manag. → Logout → User role

Description

Displays the access authorization to the parameters via the operating tool.

User interface

- Operator
- Maintenance
- Expert

Additional information*Description*

Access authorization can be modified via the **Enter access code** parameter.



If additional write protection is active, this restricts the current access authorization even further.

User interface

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.4.3 "Bluetooth configuration" submenu

Navigation  System → Bluetooth conf.

Bluetooth activation

Navigation   System → Bluetooth conf. → Bluetooth active

Selection

- Disable
- Enable

3.4.4 "Display" submenu

Navigation  System → Display

Language

Navigation   System → Display → Language

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- Bahasa Indonesia
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation	  System → Display → Format display
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values
Additional information	<i>Description</i> The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.  The Value 1 display parameter (→  62) to Value 4 display parameter (→  64) are used to specify which measured values are shown on the local display and in what order. ■ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the Display interval parameter.

Value 1 display

Navigation	  System → Display → Value 1 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.  The Format display parameter (→  62) is used to specify how many measured values are displayed simultaneously and how. <i>Dependency</i>  The unit of the displayed measured value is taken from the System units submenu.

Value 2 display



Navigation	System → Display → Value 2 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	■ None ■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 62) is used to specify how many measured values are displayed simultaneously and how. <i>Dependency</i> The unit of the displayed measured value is taken from the System units submenu.

Value 3 display



Navigation	System → Display → Value 3 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	■ None ■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 62) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu.

Value 4 display 	
Navigation	  System → Display → Value 4 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	■ None ■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.  The Format display parameter (→  62) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i>  The unit of the displayed measured value is taken from the System units submenu.
Contrast display	
Navigation	  System → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).
User entry	20 to 80 %
Factory setting	Depends on the display
Additional information	 Set the contrast via the push-buttons: ■ Weaker: Press the  and  buttons simultaneously ■ Stronger: Press the  and  buttons simultaneously

3.4.5 "Software configuration" submenu

Navigation  System → Softw. config.

CRC device configuration

Navigation	  System → Softw. config. → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535

Stored CRC device configuration

Navigation	  System → Softw. config. → Stored CRC conf.
Description	Stored CRC after the last SIL lock. Factory delivery is 65535 means that the device has not yet been SIL locked.
User interface	0 to 65 535

Timestamp stored CRC device config.

Navigation	  System → Softw. config. → TS stored CRC
Description	Gives the time stamp when the CRC was last stored following completion of the SIL-Mode Wizard.
User interface	Character string comprising numbers, letters and special characters (#20)

Activate SW option

Navigation	  System → Softw. config. → Activate SW opt.
Description	Use this function to enter an activation code to enable an additional, ordered software option.
User entry	Max. 10-digit string of numbers.
Factory setting	Depends on the software option ordered

Additional information	<i>Description</i> If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory. <i>User entry</i>  To activate a software option subsequently, please contact your Endress+Hauser sales organization. NOTE! The activation code is linked to the serial number of the measuring device and varies according to the device and software option. If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated. ▶ Before you enter a new activation code, make a note of the current activation code from the parameter protocol. ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered. ▶ If the code entered is incorrect or invalid, enter the old activation code from the parameter protocol. ▶ Have the Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again. <i>Example for a software option</i> Order code for "Application package", option EA "Extended HistoROM"
------------------------	--

3.4.6 "Information" submenu

Navigation  System → Information

Device name	
Navigation	 System → Information → Device name
Description	Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.
User interface	Max. 32 characters such as letters or numbers.
Manufacturer	
Navigation	 System → Information → Manufacturer
User interface	Character string comprising numbers, letters and special characters (#32)

Serial number 	
Navigation	  System → Information → Serial number
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number ■ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ■ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer
Order code 	
Navigation	  System → Information → Order code
Description	Shows the device order code.
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).
Factory setting	–
Additional information	<i>Description</i> The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.  Uses of the order code ■ To order an identical spare device. ■ To identify the device quickly and easily, e.g. when contacting Endress+Hauser.
Firmware version	
Navigation	  System → Information → Firmware version
Description	Displays the device firmware version that is installed.
User interface	Character string in the format xx.yy.zz
Additional information	<i>User interface</i>  The Firmware version is also located: ■ On the title page of the Operating instructions ■ On the transmitter nameplate

Hardware version

Navigation	 System → Information → Hardware version
Description	Displays the hardware revision of the module.
User interface	Max. 16 characters, such as letters, numbers or special characters (e.g. @, %, /)

XML build number

Navigation	 System → Information → XML build no.
User interface	Positive integer

Checksum

Navigation	 System → Information → Checksum
User interface	Positive integer

Index

0 ... 9

806 Alarm delay (Parameter) 41

A

Access status display (Parameter) 15
 Activate SW option (Parameter) 65
 Active diagnostics (Parameter) 33
 Active diagnostics (Submenu) 33
 Application (Menu) 44
 Assign PV (Parameter) 17, 30
 Assign SV (Parameter) 17

B

Baseline status (Parameter) 41
 Bluetooth activation (Parameter) 61
 Bluetooth configuration (Submenu) 61

C

Calibration offset (Parameter) 46
 Change password (Wizard) 57
 Change user role (Wizard) 54, 55
 Character test string (Parameter) 25
 Checksum (Parameter) 68
 Clamping voltage lower threshold (Parameter) 42
 Clamping voltage upper threshold (Parameter) 42
 Code incorrect (Parameter) 30, 31
 Commissioning (Wizard) 17
 Configuration (Submenu) 50
 Configuration counter (Parameter) 27, 53
 Confirm new password (Parameter) 57, 58
 Contrast display (Parameter) 64
 Counter Baseline creation SSD (Parameter) 43
 Counter limit overruns sensor Pmax (Parameter) 35
 Counter limit overruns sensor Tmax (Parameter) 36
 Counter limit underruns sensor Pmin (Parameter) ... 35
 Counter limit underruns sensor Tmin (Parameter) ... 37
 Counter overruns of user limit Pmax (Parameter) 36
 Counter overruns of user limit Tmax (Parameter) 37
 Counter underruns of user limit Pmin (Parameter) ... 36
 Counter underruns of user limit Tmin (Parameter) ... 37
 CRC device configuration (Parameter) 26, 65
 Current range output (Parameter) 23, 29

D

Damping (Parameter) 18, 28, 47
 Deactivate SIL (Wizard) 31
 Define password (Wizard) 56
 Delete password (Wizard) 58
 Description of device parameters 15
 Device management (Submenu) 52
 Device name (Parameter) 25, 66
 Device tag (Parameter) 17, 25, 50, 52
 Diagnostic event category (Parameter) 38
 Diagnostic event simulation (Parameter) 39
 Diagnostics (Menu) 33
 Direct access
 Access status display 15

Display (Submenu) 15, 61

Document

Design 4
 Explanation of the structure of a parameter
 description 4
 Function 4
 Symbols used 5
 Target audience 4
 Using the document 4
 Document function 4

E

Electronics temperature (Parameter) 44
 Enter access code (Parameter) 54
 Enter SIL locking code (Parameter) 24, 30
 Enter SIL unlocking code (Parameter) 31

F

Failure behavior current output (Parameter) 23, 28
 Firmware version (Parameter) 67
 Format display (Parameter) 62
 Free text (Parameter) 20
 Function
 see Parameter

G

Guidance (Menu) 17

H

Hardware version (Parameter) 68
 HART address (Parameter) 50
 HART output (Submenu) 50
 HART short tag (Parameter) 50
 Heartbeat Technology (Submenu) 39
 Heartbeat Verification (Submenu) 39
 HP/LP swap (Parameter) 27

I

Information (Submenu) 66

L

Language (Parameter) 15, 61
 Locking status (Parameter) 30, 32, 52
 Logout (Wizard) 60
 Loop current mode (Parameter) 51
 Loop diagnostics (Parameter) 41
 Loop diagnostics (Submenu) 40
 Low cutoff (Parameter) 28
 Lower range value output (Parameter) 22, 29, 48
 Lower sensor trim (Parameter) 46

M

Manufacturer (Parameter) 66
 Maximum electronics temperature (Parameter) 38
 Maximum sensor temperature (Parameter) 36
 Maximum terminal voltage (Parameter) 37
 Measured values (Submenu) 44

Measuring mode current output (Parameter)	29
Menu	
Application	44
Diagnostics	33
Guidance	17
System	52
Minimum electronics temperature (Parameter)	37
Minimum sensor temperature (Parameter)	36
Minimum terminal voltage (Parameter)	37
Minimum/maximum values (Submenu)	35

N

New password (Parameter)	56, 58
No. of preambles (Parameter)	51

O

Old password (Parameter)	57, 58
Operating time (Parameter)	27, 35
Operating time (Verification) (Parameter)	40
Operating time from restart (Parameter)	34
Order code (Parameter)	67
Output current transfer function (Parameter)	19, 28, 47

P

Parameter	
Structure of a parameter description	4
Password (Parameter)	55
Pressure (Parameter)	19, 23, 45, 48, 49
Pressure max (Parameter)	35
Pressure min (Parameter)	35
Pressure unit (Parameter)	18
Pressure value 1 (Parameter)	21, 48
Pressure value 2 (Parameter)	22, 49
Previous diagnostics (Parameter)	34
Proof test via Bluetooth allowed? (Parameter)	24

R

Rebuild baseline (Parameter)	40
Reset device (Parameter)	53
Reset password (Parameter)	59
Reset password (Wizard)	59
Reset user defined counters P and T (Parameter)	36

S

Scaled variable (Parameter)	23, 45
Scaled variable transfer function (Parameter)	21
Scaled variable unit (Parameter)	20
Scaled variable value 1 (Parameter)	22
Scaled variable value 2 (Parameter)	22
Sensor (Submenu)	45
Sensor calibration (Submenu)	45
Sensor configuration (Submenu)	47
Sensor pressure range behavior (Parameter)	28
Sensor temperature (Parameter)	45
Sensor Trim Reset (Parameter)	46
Serial number (Parameter)	26, 67
Signal noise status (Parameter)	43
Signal status (Parameter)	43
SIL confirmation (Wizard)	24
SIL status (Parameter)	24

Simulation (Parameter)	38
Simulation (Submenu)	38
Software configuration (Submenu)	65
Span (Parameter)	49
Span (Wizard)	49
SSD: Statistical Sensor Diagnostics (Parameter)	42
Start (Parameter)	55, 56, 57, 58, 59, 60
Start verification (Parameter)	39
Statistical Sensor Diagnostics (Submenu)	42
Status (Parameter)	40
Status password entry (Parameter)	55, 56, 57, 59
Stored CRC device configuration (Parameter)	26, 65
Submenu	
Active diagnostics	33
Bluetooth configuration	61
Configuration	50
Device management	52
Display	15, 61
HART output	50
Heartbeat Technology	39
Heartbeat Verification	39
Information	66
Loop diagnostics	40
Measured values	44
Minimum/maximum values	35
Sensor	45
Sensor calibration	45
Sensor configuration	47
Simulation	38
Software configuration	65
Statistical Sensor Diagnostics	42
User management	54
Wet calibration	48
System (Menu)	52
System status (Parameter)	43

T

Table not available (Parameter)	21
Target audience	4
Temperature unit (Parameter)	18
Terminal current (Parameter)	44
Terminal voltage 1 (Parameter)	42, 44
Timestamp (Parameter)	33, 34
Timestamp stored CRC device config. (Parameter)	26, 65
Tolerated deviation +/- (Parameter)	41

U

Upper range value output (Parameter)	23, 29, 49
Upper sensor trim (Parameter)	46
User management (Submenu)	54
User role (Parameter)	54, 60

V

Value 1 display (Parameter)	62
Value 2 display (Parameter)	63
Value 3 display (Parameter)	63
Value 4 display (Parameter)	64
Value current output (Parameter)	38
Value pressure simulation (Parameter)	38

Verification result (Parameter) 40

W

Wet calibration (Submenu) 48

Wizard

Change password 57

Change user role 54, 55

Commissioning 17

Deactivate SIL 31

Define password 56

Delete password 58

Logout 60

Reset password 59

SIL confirmation 24

Span 49

Zero 48

X

XML build number (Parameter) 68

Z

Zero (Parameter) 48

Zero (Wizard) 48

Zero adjustment (Parameter) 19, 45

Zero adjustment offset (Parameter) 27, 46



www.addresses.endress.com
