Safety Instructions iTHERM TM111, iTHERM TM131

EAC: Ga/Gb Ex ia IIC T6...T1 X Ex ia IIIC T85°C...450°C Da/Db X







iTHERM TM111, iTHERM TM131

Table of contents

| Associated documentation | 4 |
|---|---|
| Supplementary Documentation | 4 |
| Certificates | 4 |
| Safety instructions | 5 |
| Safety Instructions: General | 5 |
| Safety instructions: Installation in equipment of Group III | 6 |
| Safety instructions: Intrinsic safety | 6 |
| Safety instructions: Special conditions | 7 |
| Safety instructions: Partition wall | 7 |
| Thermal data | 8 |

Associated documentation

This document is an integral part of the following Operating Instructions and Technical Information:

Associated documentation for iTHERM TM111

Operating instructions: BA01915T/09Technical information: TI01445T/09

Associated documentation for iTHERM TM131

Operating instructions: BA01915T/09Technical information: TI01373T/09

Supplementary Documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available: In the download area of the Endress+Hauser website: www.endress.com \rightarrow Download \rightarrow Advanced \rightarrow Documentation code: CP000217.

Certificates

EAC certificate of conformity according to TR CU 012/2011

The thermometers meet the fundamental health and safety requirements for the design and construction of devices and protective systems intended for use in potentially explosive atmospheres.

Certification body:

НАНИО "ЦСВЭ"


Certificate number:

EA3C RU C-DE AA87 B 00767/21

Affixing the certificate number certifies conformity with the following standards:

- GOST 31610.0-2014 (IEC 60079-0:2011)
- GOST 31610.11-2014 (IEC 60079-11:2011)
- GOST 31610.26-2012 / IEC 60079-26:2006

Safety instructions



A0046895

Safety Instructions: General

- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations (e.g. GOST 30852.13 (IEC 60079-14)).
- The housing of the thermometer must be connected to the local potential equalization or installed in a grounded metallic piping or tank respectively.
- It cannot be taken for granted that when using compression fittings with non metallic olives that there is a secure grounding when installing in a metal system. This means that an additional safe connection to the local potential equalization needs to be used.
- For using of a plug-in connector (e.g. PA-connector by Weidmüller) is to be observed that the requirements for the respective category and the operating temperature are followed.

Safety instructions: Installation in equipment of Group III

- Sensors for thermometers without thermowell (e.g. TM111) are to be mechanically protected by thermowell providing a degree of protection of at least IP5X and in compliance with the enclosure requirements to GOST 31610.0 (IEC 60079-0).
- Seal the cable entries tight with certified cable glands (min. IP6X)
 IP6X according to IEC/EN 60529.
- The provided cable entries to option code glands are suitable ATEX/ IECEx Ex certified glands with a temperature range of -20 to +95 °C.
- For operating the thermometer at an ambient temperature under −20 °C, appropriate cables, cable entries and sealing facilities permitted for this application must be used.
- For ambient temperatures higher than +70 °C, use suitable heatresisting cables or wires, cable entries and sealing facilities for Ta +5K above surrounding.
- For using of a plug-in connector (e.g. PA-connector by Weidmüller) is to be observed that the requirements for the respective category and the operating temperature are followed.
- The thermometer must be installed and maintained so, that even in the event of rare incidents, an ignition source due to impact or friction between the housing and iron/steel is excluded.

A WARNING

Explosive atmosphere

► In an explosive atmosphere, do not open the device when voltage is supplied (ensure that at least IP6X is maintained during operation).

Safety instructions: Intrinsic safety

- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations (e.g. GOST 30852.13 (IEC 60079-14)).
- Observe the safety instructions for the used transmitters.
- The display, type TID10, may only be installed in Zone 1 (EPL Gb) or Zone 2 (EPL Gc).
- The type of protection changes as follows when the devices are connected to certified intrinsically safe circuits of Category ib: Ex ib IIC.
 - When connecting to an intrinsically safe ib circuit, do not operate the sensor at Zone 0 without any thermowell according to GOST 31610.26 (IEC 60079-26).
- The inserts with dual circuits (Ø3 mm and 6 mm) and Ø3 mm are not isolated to the metallic sheath in conformance with GOST 31610.11 (IEC 60079-11) chapter 6.3.13.

- When connecting dual sensors make sure that the potential equalizations are at the same local potential equalization.
- Inserts with 3 mm diameter or grounded inserts, e.g. type TSx11 must be connected to the local potential equalization.
- For inserts with 3 mm diameter or grounded inserts, e.g. type TSx11 an intrinsically safe supply with galvanic isolation must be used.

Safety instructions: Special conditions

- The thermometer must be installed so, that even in the event of rare incidents, an ignition source due to impact or friction between the housing and iron/steel is excluded.
- Avoid electrostatic charging of the plastic housing (do not rub dry).

Safety instructions: Partition wall

Install the thermometer in a partition wall which is in compliance with GOST 31610.26 (IEC 60079-26) in reference to its ultimate application.

Thermal data

Associated intrinsically safe power supply unit with maximum electrical specifications below the characteristic values of the assembled transmitter:

| Transmitter | Ui | Ii | Pi | Ci | Li | | |
|--------------------|------|--------------------|---------|------------------|----|--|--|
| TMT71/TMT72 | 30 V | 100 mA | 800 mW | 0 | 0 | | |
| TMT82 | 30 V | 130 mA | 800 mW | 0 | 0 | | |
| TMT142/ TMT142B | 30 V | 130 mA | 800 mW | 5 nF | 0 | | |
| TMT162 HART | 30 V | 300 mA | 1000 mW | 0 | 0 | | |
| TMT162 PA/FF | | FISCO field device | | | | | |
| TMT84, TMT85 | | FISCO field device | | | | | |
| Terminal block | 30 V | 140 mA | 1000 mW | See tables below | | | |
| Flying leads | 30 V | 140 mA | 1000 mW | See tables below | | | |

| Sensor type | Insertion Length IL | | Flying leads | | Terminal block | |
|-------------|---------------------|-------------------|----------------|--------|----------------|-------|
| | C _i /m | L _i /m | C _i | Li | C _i | Li |
| Single | 200 pF | 1 μH | 56.4 pF | 282 nH | 4.6 pF | 23 nH |
| Dual | 400 pF | 2 μΗ | 113 pF | 564 nH | 9.2 pF | 46 nH |

Calculation formula for options with flying leads only:

- $C_i = C_i$ Insertion length IL x IL + C_i Flying leads
- $L_i = L_i$ Insertion length IL x IL + L_i Flying leads

Calculation formula for options with terminal block only:

- $\quad \bullet \ \ \, C_i = C_{i \ Insertion \ length \ IL} \ x \ IL + C_{i \ Terminal \ block}$
- $L_i = L_i$ Insertion length IL \times IL + L_i Terminal block

| Type of protection (EAC) | Туре |
|---|--------------|
| Ga/Gb Ex ia IIC T6T1 X Ex ia IIIC T85°C450°C Da/Db X | TM111, TM131 |

The dependency of the ambient and process temperatures upon the temperature class for assembly with transmitters:

| Туре | Assembled Transmitter | Temperature class | Ambient temperature range housing | Maximum surface temperature housing |
|------------------------------|-------------------------------|-------------------|-----------------------------------|-------------------------------------|
| TM111, TM131 TS111, TS211 | TMT84, TMT85 TMT162 PA, FF | T6 | -40 °C ≤ Ta ≤ +55 °C | T85 ℃ |
| | | T5 | -40 °C ≤ Ta ≤ +70 °C | T100°C |
| | | T4 | -40 °C ≤ Ta ≤ +85 °C | T135℃ |

| Туре | Assembled Transmitter | Temperature class | Ambient temperature range housing | Maximum surface temperature housing |
|-------------------|---------------------------|----------------------|-----------------------------------|-------------------------------------|
| | TMT71, TMT72 | T6 | -50 °C ≤ Ta ≤ +55 °C | T85 ℃ |
| | TMT162 HART | T5 | -50 °C ≤ Ta ≤ +70 °C | T100 ℃ |
| TMT142/142B HART | T4 | -50 °C ≤ Ta ≤ +85 °C | T135 ℃ | |
| | TMT82 1) | T6 | -50 °C ≤ Ta ≤ +58 °C | T85 ℃ |
| | | T5 | -50 °C ≤ Ta ≤ +75 °C | T100 ℃ |
| | | T4 | -50 °C ≤ Ta ≤ +85 °C | T135 ℃ |
| | | T6 | -40 °C ≤ Ta ≤ +55 °C | T85 ℃ |
| TMT8x, display | TMT8x, TMT7x with display | T5 | -40 °C ≤ Ta ≤ +70 °C | T100 ℃ |
| | | T4 | -40 °C ≤ Ta ≤ +85 °C | T135 ℃ |

1) Ambient temperature -52 °C is possible for TMT82 head transmitter with marking Ex ia IIIC 85°C...120°C Da/Db X without display and in the case of TA30H, TA30A, TA30D and with marking Ga/Gb Ex ia IIC T6...T1 X without display.

| Туре | Assembled Transmitter | Insert diameter | Process temperature range | Temperature class/ maximum surface temperature sensor |
|--------------|--|-----------------|---------------------------|---|
| | | 3 mm, 3 mm dual | -50 °C ≤ Tp ≤ +66 °C | T6/T85 ℃ |
| | | or 6 mm dual | -50 °C ≤ Tp ≤ +81 °C | T5/T100 ℃ |
| | | | -50 °C ≤ Tp ≤ +116 °C | T4/T135 ℃ |
| | TMT8x ¹⁾ , TMT7x TMT142/142B HART | | -50 °C ≤ Tp ≤ +181 °C | T3/T200 ℃ |
| | | | -50 °C ≤ Tp ≤ +276 °C | T2/T300 ℃ |
| TM111, TM131 | | | -50 °C ≤ Tp ≤ +426 °C | T1/T450 ℃ |
| TS111, TS211 | | 6 mm | -50 °C ≤ Tp ≤ +73 °C | T6/T85 ℃ |
| | | | -50 °C ≤ Tp ≤ +88 °C | T5/T100 ℃ |
| | | | -50 °C ≤ Tp ≤ +123 °C | T4/T135 ℃ |
| | | | -50 °C ≤ Tp ≤ +188 °C | T3/T200 ℃ |
| | | | -50 °C ≤ Tp ≤ +283 °C | T2/T300 ℃ |
| | | | -50 °C ≤ Tp ≤ +433 °C | T1/T450 ℃ |

¹⁾ Ambient temperature -52 °C is possible for TMT82 head transmitter with marking Ex ia IIIC 85°C...120°C Da/Db X without display and in the case of TA30H, TA30A, TA30D and with marking Ga/Gb Ex ia IIC T6...T1 X without display.

| Туре | Assembled Transmitter | Insert diameter | Process temperature range | Temperature class/maximum surface temperature sensor |
|-------|--------------------------|-----------------|---------------------------|--|
| | | 3 mm, 3 mm dual | -50 °C ≤ Tp ≤ +64 °C | T6/T85 ℃ |
| | | or 6 mm dual | -50 °C ≤ Tp ≤ +79 °C | T5/T100 ℃ |
| | | | -50 °C ≤ Tp ≤ +114 °C | T4/T135 ℃ |
| | | | -50 °C ≤ Tp ≤ +179 °C | T3/T200 ℃ |
| | TM131 | | -50 °C ≤ Tp ≤ +279 °C | T2/T300 ℃ |
| TM131 | | | -50 °C ≤ Tp ≤ +424 °C | T1/T450 ℃ |
| TS211 | TMT162 | 6 mm | -50 °C ≤ Tp ≤ +71 °C | T6/T85 ℃ |
| | | | -50 °C ≤ Tp ≤ +86 °C | T5/T100 ℃ |
| | | | -50 °C ≤ Tp ≤ +121 °C | T4/T135 ℃ |
| | | | -50 °C ≤ Tp ≤ +186 °C | T3/T200 ℃ |
| | | | -50 °C ≤ Tp ≤ +286 °C | T2/T300 ℃ |
| | | | -50 °C ≤ Tp ≤ +431 °C | T1/T450 ℃ |



For thermocouple inserts, the temperature class T6...T1 and the maximum surface temperature T85 °C...T450 °C are equal to the process temperature.

The dependency of the ambient and process temperatures upon the temperature class for assembly without transmitter (terminal block):

| Insert | Temperature class/ | Tp (process) - maximum allowed process temperature (sensor) | | | | | |
|--------------------|-----------------------------|---|-------------|-------------|-------------|-------------|--|
| diameter | Maximum surface temperature | Pi ≤ 50 mW | Pi ≤ 100 mW | Pi ≤ 200 mW | Pi ≤ 500 mW | Pi ≤ 650 mW | |
| | T1/T450 ℃ | 426 ℃ | 415 °C | 396℃ | 343 ℃ | 333 ℃ | |
| _ | T2/T300 ℃ | 276 ℃ | 265 ℃ | 246 °C | 193℃ | 183 ℃ | |
| 3 mm, 3 mm dual | T3/T200 ℃ | 181℃ | 170 ℃ | 151℃ | 98℃ | 88 °C | |
| or 6 mm dual | T4/T135 ℃ | 116℃ | 105℃ | 86 ℃ | 33℃ | 23 ℃ | |
| daar | T5/T100 °C | 81 °C | 70 °C | 51℃ | −2 °C | −12 °C | |
| | T6/T85 ℃ | 66 ℃ | 55 ℃ | 36 ℃ | −17 °C | −27 °C | |
| 6 mm | T1/T450 ℃ | 433 ℃ | 428 ℃ | 420 °C | 398℃ | 388 ℃ | |
| | T2/T300°C | 283 ℃ | 278℃ | 270 °C | 248℃ | 238℃ | |
| | T3/T200 ℃ | 188℃ | 183 ℃ | 175℃ | 153℃ | 143 ℃ | |
| | T4/T135 ℃ | 123 ℃ | 118℃ | 110 °C | 88°C | 78℃ | |
| | T5/T100 ℃ | 88 ℃ | 83 ℃ | 75 ℃ | 53 ℃ | 43 ℃ | |
| | T6/T85 ℃ | 73 ℃ | 68 °C | 60 °C | 38°C | 28℃ | |

| Insert diameter | Temperature class/ Maximum surface | Tp (process) - n (sensor) | naximum allowed p | rocess temperature | Ta (ambient) - |
|-------------------------------|---------------------------------------|------------------------------|-------------------|--------------------|--|
| | temperature | Pi ≤ 750 mW | Pi ≤ 800 mW | Pi ≤ 1000 mW | ambient temperatur e (housing) 1) |
| | T1/T450 ℃ | 320℃ | 312 ℃ | 280 °C | |
| | T2/T300 ℃ | 170 ℃ | 162 °C | 130℃ | -40 °C ≤ Ta ≤ +130 °C |
| 2 | T3/T200 °C | 75 °C | 62 °C | 30 °C | |
| 3 mm, 3 mm dual or 6 mm | T4/T135 ℃ | 10 °C | 2 ℃ | −30 °C | -40 °C ≤ Ta ≤ +116 °C |
| dual | T5/T100 °C | −25 °C | -33 °C | - | -40 °C ≤ Ta ≤ +81 °C |
| | T6/T85 ℃ | −40 °C | - | - | -40 °C ≤ Ta ≤ +66 °C |
| 6 mm | T1/T450 °C | 381℃ | 377 ℃ | 361 ℃ | |
| | T2/T300 °C | 231 °C | 227 °C | 211°C | -40 °C ≤ Ta ≤ +130 °C |
| | T3/T200 °C | 136 ℃ | 127 °C | 111 °C | |
| | T4/T135 ℃ | 71 °C | 67 °C | 51 °C | -40 °C ≤ Ta ≤ +123 °C |
| | T5/T100 °C | 36℃ | 32 ℃ | 16 °C | -40 °C ≤ Ta ≤ +88 °C |
| | T6/T85 ℃ | 21℃ | 17 °C | 1°C | -40 °C ≤ Ta ≤ +73 °C |

¹⁾ The ambient temperature at the terminal head may be directly influenced by the process temperature, but its restricted to the range -40 to +130 °C, besides tor types TA30A, TA30D and TA30H with a restricted range -50 to +130 °C. For thermometers with two mounted head transmitters the allowed ambient temperature is up to 12 Klower than each head transmitter's certified ambient temperature.



For thermocouple inserts, the temperature class T6...T1 and the maximum surface temperature T85 °C...T450 °C are equal to the process temperature.



www.addresses.endress.com