

Description of Device Parameters

iTEMP TMT31

Temperature transmitter




Table of contents

1	About this document	4
1.1	Document function	4
1.2	Target group	4
1.3	Using this document	4
1.3.1	Symbols for certain types of information	4
1.3.2	Information on the document structure	4
1.3.3	Structure of a parameter description ..	5
1.4	Documentation	5
2	Overview of the operating menu	6
3	"Guidance" menu	7
3.1	"Commissioning" submenu	7
4	"Diagnostics" menu	10
4.1	"Active diagnostics" submenu	10
4.2	"Simulation" submenu	11
5	"Application" menu	12
5.1	"Measured values" submenu	13
5.2	"Sensor" submenu	14
5.3	"Current output" submenu	18
6	"System" menu	21
6.1	"Device management" submenu	22
6.2	"User management" submenu	22
6.3	"Device" submenu	23

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the operating menus.

It is used to perform tasks that require detailed knowledge of the function of the device:








- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.





1.3 Using this document

1.3.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
 <small>A0028662</small>	Operation via local display
 <small>A0028663</small>	Operation via operating tool
 <small>A0028665</small>	Write-protected parameter




1.3.2 Information on the document structure

The parameters of all the operating menus and the commissioning wizard are described in this document.

- **Guidance** menu with the **Commissioning** wizard (→  7), which guides the user automatically through all the device parameters that are needed for commissioning
- **Diagnostics** menu (→  10)
- **Application** menu (→  12)
- **System** menu (→  21)

1.3.3 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the operating tool  The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ■ Option 1 ■ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works (if not explicitly selected)
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ■ For individual options ■ For display values/data ■ For the input range ■ For the factory setting ■ For the parameter function

1.4 Documentation

The Description of Device Parameters is part of the following documentation:

 Measuring device iTEMP TMT31: **BA02157T**

2 Overview of the operating menu









Guidance	→ 7
Diagnostics	→ 10
Application	→ 12
System	→ 21

3 "Guidance" menu

The Guidance main menu contains functions enable users to perform basic tasks swiftly, e.g. commissioning.

These are primarily guided wizards and cross-subject special functions.

Navigation  Guidance

Guidance	
▶ Commissioning	→  7
Unit	→  7
Sensor type	→  8
Connection type	→  8
2-wire compensation	→  8
Lower range value output	→  9
Upper range value output	→  9
Failure mode	→  9


Documentation ¹⁾
Save/restore ¹⁾
Compare datasets ¹⁾

1) These parameters only appear in FDT/DTM-based operating tools, such as Endress+Hauser's FieldCare and DeviceCare

3.1 "Commissioning" submenu

Navigation  Guidance → Commissioning


Unit

Navigation  Guidance → Commissioning → Unit


Description Selection of the unit for all measured values.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K <i>Custom-specific units</i> <ul style="list-style-type: none"> °F
------------------	--


Sensor type

Navigation	 Guidance → Commissioning → Sensor type
Description	Use this function to select the sensor type for the sensor input. Info: Please observe the terminal assignment when connecting the sensor.
Selection	<ul style="list-style-type: none"> ■ Pt100 IEC60751, a=0.00385 (1) ■ Pt1000 IEC60751, a=0.00385 (4) ■ Pt100 JIS C1604, a=0.003916 (5) ■ Pt100 GOST 6651-94, a=0.00391 (9) ■ RTD Platinum (Callendar/van Dusen)
Factory setting	Pt100 IEC60751, a=0.00385 (1)


Connection type

Navigation	 Guidance → Commissioning → Connection type
Description	Use this function to select the connection type for the sensor.
Selection	<ul style="list-style-type: none"> ■ 2- wire ■ 3- wire ■ 4- wire
Factory setting	4- wire


2-wire compensation

Navigation	 Guidance → Commissioning → 2-wire compensation
Description	Use this function to specify the resistance value for two-wire compensation in RTDs.
User entry	0.0 to 30.0 Ohm
Factory setting	0 Ohm


Lower range value output

Navigation	 Guidance → Commissioning → Lower range value output
Description	Use this function to assign a measured value to the current value 4 mA. Info: The set point that can be set depends on the sensor type used in the Sensor type parameter.
User entry	-50 000.0 to 50 000.0
Factory setting	0.0

Upper range value output

Navigation	 Guidance → Commissioning → Upper range value output
Description	Use this function to assign a measured value to the current value 20 mA. Info: The set point that can be set depends on the sensor type used in the Sensor type parameter.
User entry	-50 000.0 to 50 000.0
Factory setting	100


Failure mode

Navigation	 Guidance → Commissioning → Failure mode
Description	Use this function to select the signal on alarm level of the current output in the event of an error.
Selection	<ul style="list-style-type: none"> ■ Max. ■ Min.
Factory setting	Low alarm

4 "Diagnostics" menu


Settings and information concerning diagnostics as well as help for troubleshooting

Navigation  Diagnostics



4.1 "Active diagnostics" submenu

Navigation  Diagnostics → Active diagnostics



Actual diagnostics


Navigation  Diagnostics → Active diagnostics → Actual diagnostics

Description Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.


User interface Symbol for diagnostic behavior, diagnostic code and short message.

Previous diagnostics


Navigation	 Diagnostics → Active diagnostics → Previous diagnostics
Description	Displays the diagnostic message for the last diagnostic event that has ended.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

4.2 "Simulation" submenu


Navigation  Diagnostics → Simulation



Current output simulation

Navigation	 Diagnostics → Simulation → Current output simulation
Description	Use this function to switch simulation of the current output on and off. While simulation is in progress the display a diagnostics message of the "function check" category (C).
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off






















Current output value

Navigation	 Diagnostics → Simulation → Current output value
Description	Use this function to set a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.
User entry	3.58 to 23.0 mA
Factory setting	3.58 mA

5 "Application" menu

Functions for detailed process adaptation to integrate the device optimally into your application

Navigation  Application

Application	
▶ Measured values	→  13
Sensor value	→  13
Output current	→  13
Percent of range	→  13
Device temperature	→  14
▶ Sensor	→  14
Unit	→  15
Sensor type	→  15
Connection type	→  15
2-wire compensation	→  16
Sensor offset	→  16
Damping	→  16
Call./v. Dusen coeff. R0	→  16
Call./v. Dusen coeff. A	→  17
Call./v. Dusen coeff. B	→  17
Call./v. Dusen coeff. C	→  17
Sensor lower limit	→  17
Sensor upper limit	→  18
▶ Current output	→  18
Lower range value output	→  18
Upper range value output	→  19

Failure mode	→ 📄 19
Current trimming 4 mA	→ 📄 19
Current trimming 20 mA	→ 📄 19

5.1 "Measured values" submenu

Navigation 📄 Application → Measured values

▶ Measured values	
Sensor value	→ 📄 13
Output current	→ 📄 13
Percent of range	→ 📄 13
Device temperature	→ 📄 14

Sensor value

Navigation 📄 Application → Measured values → Sensor value

Description Use this function to display the current measured value at the sensor input.

User interface Signed floating-point number

Output current

Navigation 📄 Application → Measured values → Output current

Description Use this function to view the calculated output current in mA.

User interface 3.58 to 23.0 mA

Percent of range

Navigation 📄 Application → Measured values → Percent of range

Description Use this function to display the measured value in % of the span.

User interface Signed floating-point number

Device temperature













Navigation  Application → Measured values → Device temperature

Description Use this function to display the current electronics temperature.


User interface Signed floating-point number

5.2 "Sensor" submenu


Navigation  Application → Sensor

► Sensor	
Unit	→  15
Sensor type	→  15
Connection type	→  15
2-wire compensation	→  16
Sensor offset	→  16
Damping	→  16
Call./v. Dusen coeff. RO	→  16
Call./v. Dusen coeff. A	→  17
Call./v. Dusen coeff. B	→  17
Call./v. Dusen coeff. C	→  17
Sensor lower limit	→  17
Sensor upper limit	→  18


Unit

Navigation	 Application → Sensor → Unit
Description	Selection of the unit for all measured values.
Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K <i>Custom-specific units</i> <ul style="list-style-type: none"> °F


Sensor type

Navigation	 Application → Sensor → Sensor type
Description	Use this function to select the sensor type for the sensor input. Info: Please observe the terminal assignment when connecting the sensor.
Selection	<ul style="list-style-type: none"> ■ Pt100 IEC60751, a=0.00385 (1) ■ Pt1000 IEC60751, a=0.00385 (4) ■ Pt100 JIS C1604, a=0.003916 (5) ■ Pt100 GOST 6651-94, a=0.00391 (9) ■ RTD Platinum (Callendar/van Dusen)
Factory setting	Pt100 IEC60751, a=0.00385 (1)


Connection type

Navigation	 Application → Sensor → Connection type
Description	Use this function to select the connection type for the sensor.
Selection	<ul style="list-style-type: none"> ■ 2- wire ■ 3- wire ■ 4- wire
Factory setting	4- wire


2-wire compensation

Navigation	 Application → Sensor → 2-wire compensation
Description	Use this function to specify the resistance value for two-wire compensation in RTDs.
User entry	0.0 to 30.0 Ohm
Factory setting	0 Ohm


Sensor offset

Navigation	 Application → Sensor → Sensor offset
Description	Use this function to set the zero point correction (offset) of the sensor measured value. The value indicated is added to the measured value.
User entry	-10.0 to 10.0
Factory setting	0


Damping

Navigation	 Application → Sensor → Damping
Description	Use this function to set the time constant for the damping of the measured value.
User entry	0 to 120 s
Factory setting	0 s


Call./v. Dusen coeff. R0

Navigation	 Application → Sensor → Call./v. Dusen coeff. R0
Description	Use this function to set the R0 value for sensor linearization with the Callendar/Van Dusen polynomial.
User entry	10.0 to 4 000.0 Ohm
Factory setting	100 Ohm


Call./v. Dusen coeff. A

Navigation	 Application → Sensor → Call./v. Dusen coeff. A
Description	Use this function to set the coefficients for sensor linearization with the Callendar/Van Dusen polynomial.
User entry	3.0E-03 to 4.0E-03
Factory setting	3.9083E-03


Call./v. Dusen coeff. B

Navigation	 Application → Sensor → Call./v. Dusen coeff. B
Description	Use this function to set the coefficients for sensor linearization with the Callendar/Van Dusen polynomial.
User entry	-2.0E-06 to 2.0E-06
Factory setting	-5.775E-07


Call./v. Dusen coeff. C

Navigation	 Application → Sensor → Call./v. Dusen coeff. C
Description	Use this function to set the coefficients for sensor linearization with the Callendar/Van Dusen polynomial.
User entry	-1.0E-09 to 1.0E-09
Factory setting	-4.183E-12

Sensor lower limit






Navigation	 Application → Sensor → Sensor lower limit
Prerequisite	The RTD platinum (Callendar/Van Dusen) option is enabled in the Sensor type parameter
Description	Use this function to set the lower calculation limit for special sensor linearization.
User entry	Depends on the sensor type selected
Factory setting	Depends on the sensor type selected

Sensor upper limit


Navigation	 Application → Sensor → Sensor upper limit
Prerequisite	The RTD platinum (Callendar/Van Dusen) option is enabled in the Sensor type parameter
Description	Use this function to set the upper calculation limit for special sensor linearization.
User entry	Depends on the sensor type selected
Factory setting	Depends on the sensor type selected

5.3 "Current output" submenu


Navigation  Application → Current output

▶ Current output	
Lower range value output	→  18
Upper range value output	→  19
Failure mode	→  19
Current trimming 4 mA	→  19
Current trimming 20 mA	→  19


Lower range value output

Navigation	 Application → Current output → Lower range value output
Description	Use this function to assign a measured value to the current value 4 mA. Info: The set point that can be set depends on the sensor type used in the Sensor type parameter.
User entry	-50 000.0 to 50 000.0
Factory setting	0.0


Upper range value output

Navigation	 Application → Current output → Upper range value output
Description	Use this function to assign a measured value to the current value 20 mA. Info: The set point that can be set depends on the sensor type used in the Sensor type parameter.
User entry	-50 000.0 to 50 000.0
Factory setting	100


Failure mode

Navigation	 Application → Current output → Failure mode
Description	Use this function to select the signal on alarm level of the current output in the event of an error.
Selection	<ul style="list-style-type: none"> ▪ Max. ▪ Min.
Factory setting	Low alarm

Current trimming 4 mA

Navigation	 Application → Current output → Current trimming 4 mA
Description	Use this function to set the correction value for the current output at the start of the measuring range at 4 mA.
User entry	3.85 to 4.15 mA
Factory setting	4 mA

Current trimming 20 mA

Navigation	 Application → Current output → Current trimming 20 mA
Description	Use this function to set the correction value for the current output at the end of the measuring range at 20 mA.
User entry	19.85 to 20.15 mA









Factory setting

20 mA

6 "System" menu



System settings concerning device management, user administration or safety

Navigation  System

System	
▶ Device management	→  22
Device tag	→  22
Device reset	→  22
▶ User management	→  22
Access status	→  23
Define software write protection code	→  23
Enter access code	→  23
▶ Information	
▶ Device	→  23
Serial number	→  24
Order code	→  24
Firmware version	→  24
Hardware revision	→  25
Extended order code 1	→  25
Extended order code 2	→  25
Device name	→  25

6.1 "Device management" submenu

Navigation  System → Device management

▶ Device management	
Device tag	→  22
Device reset	→  22

Device tag

Navigation  System → Device management → Device tag

Description Displays the name for the measuring point.

User entry Character string comprising numbers, letters and special characters (32)

Device reset

Navigation  System → Device management → Device reset

Description Use this function to reset the device configuration to a defined state.




Selection

- Not active
- Restart device
- To factory defaults


Factory setting Not active

6.2 "User management" submenu


Navigation  System → User management

▶ User management	
Access status	→  23
Define software write protection code	→  23
Enter access code	→  23


Access status

Navigation	 System → User management → Access status
Description	Shows the access authorization to the parameters via the operating tool
User interface	<ul style="list-style-type: none"> ■ Operator ■ Maintenance
Factory setting	Maintenance

Define software write protection code


Navigation	 System → User management → Define software write protection code
Description	Enter the code to protect the device from unauthorized access
User entry	0 to 9999
Factory setting	0






Enter access code

Navigation	 System → User management → Enter access code
Description	Entering the defined code to cancel the device protection
User entry	0 to 9999
Factory setting	0

6.3 "Device" submenu


Navigation  System → Information → Device



Firmware version	→  24
Hardware revision	→  25
Extended order code 1	→  25
Extended order code 2	→  25
Device name	→  25

Serial number

Navigation

 System → Information → Device → Serial number

Description

Displays the serial number of the measuring device. The serial number can be used to identify the measuring device and to retrieve further information on the measuring device, such as the related documentation, via the Device Viewer or Operations app.

Additional information:

The serial number can also be found on the nameplate of the sensor and transmitter.

User interface

Character string comprising numbers, letters and special characters

Order code

Navigation

 System → Information → Device → Order code

Description

Displays the device order code.

Additional information:


The order code can be used for instance to order a replacement or spare device or to verify that the device features specified on the order form match the shipping note.

User interface

Character string comprising numbers, letters and special characters

Firmware version

Navigation

 System → Information → Device → Firmware version


Description

Use this function to view the device firmware version installed.


User interface

Character string comprising numbers, letters and special characters


Hardware revision

Navigation	 System → Information → Device → Hardware revision
Description	Use this function to display the hardware revision of the device.
User interface	Character string comprising numbers, letters and special characters


Extended order code 1

Navigation	 System → Information → Device → Extended order code 1
Description	<p>Displays the first, second and/or third part of the extended order code. Due to character length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model.</p> <p>Additional information: The extended order code can also be found on the nameplate.</p>
User interface	Character string comprising numbers, letters and special characters

Extended order code 2

Navigation	 System → Information → Device → Extended order code 2
Description	<p>Displays the first, second and/or third part of the extended order code. Due to character length restrictions, the extended order code is split into a maximum of 3 parameters. The extended order code indicates for each feature in the product structure the selected option, thereby uniquely identifying the device model.</p> <p>Additional information: The extended order code can also be found on the nameplate.</p>
User interface	Character string comprising numbers, letters and special characters

Device name

Navigation	 System → Information → Device → Device name
Description	<p>Displays the name of the transmitter.</p> <p>Additional information: The name can also be found on the transmitter's nameplate.</p>

User interface

Character string comprising numbers, letters and special characters



www.addresses.endress.com
