# Operating Instructions **Proline Prosonic Flow I 400**

Ultrasonic transit time flowmeter HART



BA02085D/06/EN/01.21

71542314 2022-01-11 Valid as of version 01.00.zz (Device firmware)





- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

## Table of contents

1	About	this document	. 6
1.1 1.2		ent function s Safety symbols Electrical symbols Communication-specific symbols Tool symbols Symbols for certain types of information	• 6 6 6 • 6
1.3	1.2.6 Docume 1.3.1 1.3.2	Symbols in graphics	. 7 8 8
1.4	Register	documentation	
2	Safety	instructions	9
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Intende Workpla Operatio Product IT secur Device-s 2.7.1	ments for the personnel	9 10 10 10 10 11 11
	2.7.2	Access via Web server	12
3		Access via Web server	12 13
<b>3</b> 3.1	Produ		
-	<b>Produ</b> ct	ct description	13
3.1	Product Product Incom Incomin Product	<b>ct description</b> design	13
3.1 <b>4</b> 4.1	Product Product Incomin Product 4.2.1 4.2.2 4.2.3	ct description design ing acceptance and product fication ig acceptance identification Transmitter nameplate Sensor nameplate Symbols on measuring device	<ul> <li>13</li> <li>14</li> <li>15</li> <li>15</li> <li>16</li> <li>16</li> </ul>
3.1 <b>4</b> 4.1 4.2	Product Product Incomin Product 4.2.1 4.2.2 4.2.3 Storage Transpo 5.2.1	ct description         design         ing acceptance and product         fication         ng acceptance         identification         Transmitter nameplate         Sensor nameplate	<ol> <li>13</li> <li>14</li> <li>15</li> <li>15</li> <li>16</li> <li>16</li> <li>17</li> </ol>
3.1 4 4.1 4.2 5 5.1 5.2	Product Product Incomin Product 4.2.1 4.2.2 4.2.3 Storage Transpo 5.2.1 Packagi	ct description         design         ing acceptance and product         fication         identification         identification         Transmitter nameplate         Sensor nameplate         Symbols on measuring device         ge and transport         conditions         orting the product         Transporting with a fork lift	<ol> <li>14</li> <li>15</li> <li>15</li> <li>16</li> <li>16</li> <li>17</li> <li>18</li> <li>18</li> <li>18</li> <li>18</li> </ol>
3.1 4 4.1 4.2 5 5.1 5.2 5.3	Product Product Incomin Product 4.2.1 4.2.2 4.2.3 Storage Transpo 5.2.1 Packagi	ct description         design         ing acceptance and product         fication         identification         identification         Transmitter nameplate         Sensor nameplate         Symbols on measuring device         ge and transport         conditions         orting the product         Transporting with a fork lift	<ol> <li>13</li> <li>14</li> <li>15</li> <li>15</li> <li>16</li> <li>17</li> <li>18</li> <li>18</li> <li>18</li> <li>18</li> </ol>

6.2	<ul> <li>6.1.4 Special mounting instructions</li> <li>Mounting the measuring device</li> <li>6.2.1 Required tools</li> <li>6.2.2 Preparing the measuring device</li> <li>6.2.3 Mounting the sensor</li> <li>6.2.4 Mounting the transmitter</li> <li>6.2.5 Turning the display module</li> <li>Post-mounting check</li> </ul>	24 24 24 24 30 32 32
7	Electrical connection	34
7.1	Electrical safety	34 34
7.2	Connection conditions7.2.1Required tools	54 34
	7.2.2 Requirements for connecting cable	34 34
	7.2.3 Terminal assignment	35
	7.2.4 Preparing the measuring device	36
7.3	Connecting the measuring device	36
	7.3.1 Connecting the sensor and	
	transmitter	36
	7.3.2 Connecting the transmitter	38
_ /	7.3.3 Potential equalization	39
7.4	Special connection instructions	39
7.5	7.4.1 Connection examples	39 41
ر./	Ensuring the degree of protection 7.5.1 Degree of protection IP66/67, Type	41
	4X enclosure	41
7.6	Post-connection check	41
8	Operation options	42
	1 1	
<b>8</b> 8.1 8.2	<b>Operation options</b> Overview of operation methods Structure and function of the operating	<b>42</b> 42
8.1	Overview of operation methods Structure and function of the operating menu	
8.1	Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu	42 43 43
8.1 8.2	Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophy	42 43
8.1	Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the local	42 43 43 44
8.1 8.2	Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay	42 43 43 44 45
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display	42 43 43 44 45 45
8.1 8.2	Image: Construction of the operation of the operatingStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view	42 43 43 44 45 45 46
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display	42 43 43 44 45 45
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu	42 43 43 44 45 45 45 46 48
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list	<ul> <li>42</li> <li>43</li> <li>43</li> <li>44</li> <li>45</li> <li>45</li> <li>46</li> <li>48</li> <li>50</li> <li>50</li> <li>52</li> </ul>
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling the parameter directly	42 43 43 44 45 45 46 48 50 50 52 52 52
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text	42 43 43 44 45 45 46 48 50 50 52 52 52 52
8.1 8.2	Image: Constructure of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text8.3.9Changing the parameters	42 43 43 44 45 45 46 48 50 50 52 52 52
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling the parameter directly8.3.8Calling up help text8.3.9Changing the parameters8.3.10User roles and related access	42 43 43 44 45 46 48 50 50 52 53 54
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text8.3.8Calling up help text8.3.10User roles and related access authorization	42 43 43 44 45 45 46 48 50 50 52 52 52 52
8.1 8.2	Image: Constructure of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text8.3.9Changing the parameters8.3.10User roles and related access authorization8.3.11Disabling write protection via access	42 43 43 44 45 46 48 50 50 52 53 54
8.1 8.2	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text8.3.8Calling up help text8.3.10User roles and related access authorization	42 43 43 44 45 46 48 50 52 52 53 54 55
8.1 8.2 8.3	1Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling the parameter directly8.3.8Calling up help text8.3.10User roles and related access authorization8.3.11Disabling write protection via access code8.3.12Enabling and disabling the keypad lock	42 43 43 44 45 46 48 50 52 52 53 54 55
8.1 8.2 8.3	AOverview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling up help text8.3.9Changing the parameters8.3.10User roles and related access authorization8.3.11Disabling write protection via access code8.3.12Enabling and disabling the keypad locklockAccess to the operating menu via the Web	42 43 44 45 46 48 50 52 53 54 55 55 55 56
8.1 8.2	1Overview of operation methodsStructure and function of the operatingmenu8.2.1Structure of the operating menu8.2.2Operating philosophyAccess to the operating menu via the localdisplay8.3.1Operational display8.3.2Navigation view8.3.3Editing view8.3.4Operating elements8.3.5Opening the context menu8.3.6Navigating and selecting from list8.3.7Calling the parameter directly8.3.8Calling up help text8.3.10User roles and related access authorization8.3.11Disabling write protection via access code8.3.12Enabling and disabling the keypad lock	42 43 44 45 46 48 50 52 52 53 54 55 55

	8.4.2 Requirements	56
	8.4.3 Establishing a connection	57
	8.4.4 Logging on	59
	8.4.5 User interface	60
	8.4.6 Disabling the Web server	61
	8.4.7 Logging out	61
8.5	Access to the operating menu via the	
	operating tool	61
	8.5.1 Connecting the operating tool	62
	8.5.2 FieldCare	64
	8.5.3 DeviceCare	65
	8.5.4 Field Xpert SMT70, SMT77	65
	8.5.5 AMS Device Manager	66
	8.5.6 SIMATIC PDM	66
9	System integration	67
9.1	Overview of device description files	67
~·· <b>⊥</b>	9.1.1 Current version data for the device	67
	9.1.2 Operating tools	67
9.2	Measured variables via HART protocol	67
9.3	Other settings	69
	, j	
10	Commissioning	71
10.1	Function check	71
10.2	Switching on the measuring device	71
10.3	Setting the operating language	71
10.4	Configuring the measuring device	71
	10.4.1 Defining the tag name	72
	10.4.2 Setting the system units	73
	10.4.3 Configuring the measuring point	74
	10.4.4 Checking the installation status	76
	10.4.5 Configuring the status input	77
	10.4.6 Configuring the current output	79
	10.4.7 Configuring the pulse/frequency/	00
	switch output	80 80
	10.4.8 Configuring the local display	85
10.5	10.4.9 Configuring the low flow cut off	87 89
10.2	Advanced settings	09
	access code	۹n
	access code	90 90
	10.5.2 Carrying out a sensor adjustment	90
	<ul><li>10.5.2 Carrying out a sensor adjustment</li><li>10.5.3 Configuring the totalizer</li></ul>	
	<ul><li>10.5.2 Carrying out a sensor adjustment</li><li>10.5.3 Configuring the totalizer</li><li>10.5.4 Carrying out additional display</li></ul>	90 90
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> </ul>	90 90 92
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> </ul>	90 90 92 94
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> </ul>	90 90 92
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> </ul>	90 90 92 94
10.6	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device</li> </ul>	90 90 92 94 96
10.6 10.7	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device administration</li> <li>Simulation</li> </ul>	90 90 92 94 96 97
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device administration</li> <li>Simulation</li> <li>Protecting settings from unauthorized access</li> <li>10.7.1 Write protection via access code</li> </ul>	90 90 92 94 96 97 99
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device administration</li> <li>Simulation</li> <li>Protecting settings from unauthorized access</li> <li>10.7.1 Write protection via access code</li> <li>10.7.2 Write protection via write protection</li> </ul>	90 90 92 94 96 97 99 101
	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device administration</li> <li>Simulation</li> <li>Protecting settings from unauthorized access</li> <li>10.7.1 Write protection via access code</li> <li>10.7.2 Write protection via write protection</li> </ul>	90 90 92 94 96 97 99 101
10.7	<ul> <li>10.5.2 Carrying out a sensor adjustment</li> <li>10.5.3 Configuring the totalizer</li> <li>10.5.4 Carrying out additional display configurations</li> <li>10.5.5 WLAN configuration</li> <li>10.5.6 Performing Heartbeat basic setup</li> <li>10.5.7 Using parameters for device administration</li> <li>Simulation</li> <li>Protecting settings from unauthorized access</li> <li>10.7.1 Write protection via access code</li> <li>10.7.2 Write protection via write protection switch</li> </ul>	90 90 92 94 96 97 99 101 101
10.7 11	10.5.2       Carrying out a sensor adjustment         10.5.3       Configuring the totalizer	90 90 92 94 96 97 99 101 101 102 102
10.7	10.5.2       Carrying out a sensor adjustment         10.5.3       Configuring the totalizer	90 90 92 94 96 97 99 101 101

11.3 11.4	Configuring the displayReading off measured values11.4.1Process variables	104 104 105
	11.4.1Process variables11.4.2System values	105
	11.4.3 Input values	105
	11.4.4 Output values	107
	11.4.5 "Totalizer" submenu	108
11.5	Adapting the measuring device to the process	
11 (	conditions	108
11.6	Performing a totalizer reset 11.6.1 Function scope of the "Control	108
	11.6.1 Function scope of the "Control Totalizer" parameter	109
	11.6.2 Function scope of the "Reset all	107
	totalizers" parameter	109
11.7	Show data logging	110
12	Diagnostics and troubleshooting	113
12.1	General troubleshooting	113
12.2	Diagnostic information via light emitting	115
	diodes 12.2.1 Transmitter	115 115
12.3	Diagnostic information on local display	115
12.9	12.3.1 Diagnostic message	116
	12.3.2 Calling up remedial measures	118
12.4	Diagnostic information in the Web browser .	118
	12.4.1 Diagnostic options	118
10 5	12.4.2 Calling up remedy information	119
12.5	Diagnostic information in FieldCare or	120
	DeviceCare	120
	12.5.2 Calling up remedy information	120
12.6	Adapting the diagnostic information	121
	12.6.1 Adapting the diagnostic behavior	121
	12.6.2 Adapting the status signal	121
12.7	Overview of diagnostic information	122
12.8 12.9	Pending diagnostic events	125
	Diagnostic list Event logbook	126 127
12.10	12.10.1 Reading out the event logbook	127
	12.10.2 Filtering the event logbook	128
	12.10.3 Overview of information events	128
12.11	Resetting the measuring device	129
	12.11.1 Function scope of the "Device reset"	100
10 10	parameter Device information	129 129
	Firmware history	131
		100
13	Maintenance	132
13.1	Maintenance tasks	132
100	13.1.1 Exterior cleaning	132 132
13.2 13.3	Measuring and test equipment Endress+Hauser services	132
10.0		174
14	Repair	133
14.1	General information	133
	14.1.1 Repair and conversion concept	133
	14.1.2 Notes for repair and conversion	133

14.2	Spare parts	133
14.3	Endress+Hauser services	133
14.4	Return	133
14.5	Disposal	134
	14.5.1 Removing the measuring device	134
	14.5.2 Disposing of the measuring device	134
15	Accessories	135
15.1	Device-specific accessories	135
	15.1.1 For the transmitter	135
	15.1.2 For the sensor	135
15.2	Communication-specific accessories	136
15.3	Service-specific accessories	137
15.4	System components	137
16	Technical data	138
16.1	Application	138
16.2	Function and system design	138
16.3	Input	138
16.4	Output	139
16.5	Power supply	142
16.6	Performance characteristics	143
16.7	Installation	145
16.8	Environment	145
16.9	Process	146
16.10	Mechanical construction	147
16.11	Operability	148
16.12	Certificates and approvals	151
16.13	Application packages	153
16.14	Accessories	153
16.15	Documentation	153
Index	٢	155

## 1 About this document

## 1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

## 1.2 Symbols

### 1.2.1 Safety symbols

#### **DANGER**

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

#### A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

#### **A** CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

#### NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

### 1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
$\sim$	Alternating current
$\sim$	Direct current and alternating current
<u>+</u>	<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	<ul><li>The ground terminals are situated inside and outside the device:</li><li>Inner ground terminal: Connects the protectiv earth to the mains supply.</li><li>Outer ground terminal: Connects the device to the plant grounding system.</li></ul>

### 1.2.3 Communication-specific symbols

Symbol	Meaning
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
8	Bluetooth Wireless data transmission between devices over a short distance.
	LED Light emitting diode is off.

Symbol	Meaning
-X-	<b>LED</b> Light emitting diode is on.
	<b>LED</b> Light emitting diode is flashing.

## 1.2.4 Tool symbols

Symbol	Meaning
€	Torx screwdriver
•	Phillips head screwdriver
Ń	Open-ended wrench

## 1.2.5 Symbols for certain types of information

Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.
×	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
1	<b>Tip</b> Indicates additional information.
Ĩ	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
1., 2., 3	Series of steps
4	Result of a step
?	Help in the event of a problem
	Visual inspection

### **1.2.6** Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
×	Safe area (non-hazardous area)
≈⇒	Flow direction

## 1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code on the nameplate

P Detailed list of the individual documents along with the documentation code

### 1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	<b>Planning aid for your device</b> The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	<b>Getting the 1st measured value quickly - Part 1</b> The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.
	<ul><li>Incoming acceptance and product identification</li><li>Storage and transport</li><li>Installation</li></ul>
Transmitter Brief Operating Instructions	Getting the 1st measured value quickly - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).
	<ul> <li>Product description</li> <li>Installation</li> <li>Electrical connection</li> <li>Operation options</li> <li>System integration</li> <li>Commissioning</li> <li>Diagnostic information</li> </ul>
Description of Device Parameters	<b>Reference for your parameters</b> The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

### 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

## 1.4 Registered trademarks

#### HART®

Registered trademark of the FieldComm Group, Austin, USA

## 2 Safety instructions

## 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

## 2.2 Intended use

#### Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are marked accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Protect the measuring device permanently against corrosion from environmental influences.

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### **Residual risks**

#### **WARNING**

If the temperature of the media or electronics unit is high or low, this may cause the surfaces of the device to become hot or cold. This poses a risk of burns or frostbite!

► In the case of hot or cold medium temperatures, install appropriate protection against contact.

## 2.3 Workplace safety

For work on and with the device:

• Wear the required personal protective equipment according to national regulations.

For welding work on the piping:

• Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

• Due to the increased risk of electric shock, wear suitable gloves.

## 2.4 Operational safety

Risk of injury.

- Operate the device in proper technical condition and fail-safe condition only.
- ► The operator is responsible for interference-free operation of the device.

#### Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

► If, despite this, modifications are required, consult with Endress+Hauser.

#### Repair

To ensure continued operational safety and reliability,

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to repair of an electrical device.
- ► Use original spare parts and accessories from Endress+Hauser only.

## 2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

Furthermore, the device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards.

By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com

## 2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

## 2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section:

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch	Not enabled	On an individual basis following risk assessment
Access code (also applies for Web server login or FieldCare connection) $\rightarrow \cong 11$	Not enabled (0000)	Assign a customized access code during commissioning
WLAN (order option in display module)	Enabled	On an individual basis following risk assessment
WLAN security mode	Enabled (WPA2- PSK)	Do not change
WLAN passphrase (password) → 🗎 11	Serial number	Assign a customized WLAN passphrase during commissioning
WLAN mode	Access point	On an individual basis following risk assessment
Web server $\rightarrow \square 12$	Enabled	On an individual basis following risk assessment
CDI-RJ45 service interface	-	On an individual basis following risk assessment

## 2.7.1 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- WLAN passphrase The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.

#### User-specific access code

Write access to the device parameters via the local display or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ( $\rightarrow \cong 101$ ).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

#### WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface ( $\Rightarrow \boxtimes 62$ ), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter ( $\rightarrow \cong$  96).

#### General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see the "Write protection via access code" section → 
   <sup>(1)</sup> 101

### 2.7.2 Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server ( $\rightarrow \bigoplus 56$ ). The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.


For detailed information on device parameters, see: The "Description of Device Parameters" document .

## **3** Product description

The measuring system consists of a transmitter and one or two sensor sets. The transmitter and sensor sets are mounted in physically separate locations. They are interconnected by sensor cables.

The sensors function as sound generators and sound receivers. The sensors in a sensor pair are always arranged opposite one another and send/receive the ultrasonic signals directly (1-traverse positioning)  $\rightarrow \square 22$ .

The transmitter serves to control the sensor sets, to prepare, process and evaluate the measuring signals, and to convert the signals to the desired output variable.




## 3.1 Product design

☑ 1 Important components

- 1 Display module
- 2 Smart sensor electronics module
- 3 HistoROM DAT (plug-in memory)
- 4 Main electronics module
- 5 Terminals (screw terminals, some available as plug-in terminals) or fieldbus connectors
- 6 Transmitter housing
- 7 Cable glands
- 8 Sensor (2 versions)

## 4 Incoming acceptance and product identification

4.1 Incoming acceptance



## 4.2 Product identification


The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial numbers from the nameplates in W@M Device Viewer (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations App* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations App*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device"  $\rightarrow \cong 8$  and "Supplementary device-dependent documentation"  $\rightarrow \cong 8$
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.


#### 4.2.1 Transmitter nameplate



#### ☑ 2 Example of a transmitter nameplate

- 1 Place of manufacture
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Permitted ambient temperature  $(T_a)$
- 7 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 8 Degree of protection
- 9 Permitted temperature range for cable
- 10 2-D matrix code
- 11 Date of manufacture: year-month
- 12 CE mark, RCM-Tick mark
- 13 Electrical connection data, e.g. available inputs and outputs, supply voltage

## 4.2.2 Sensor nameplate



Example of sensor nameplate, "front"

- 1 Name of sensor
- 2 Place of manufacture
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Type
- 6 Medium temperature range
- 7 Date of manufacture: year-month
- 8 Document number of safety-related supplementary documentation
- 9 Additional information



#### Example of sensor nameplate, "back"

1 CE mark, RCM-Tick mark, approval information on explosion protection and degree of protection

### 📔 Order code

The measuring device is reordered using the order code.

#### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXX-ABCDE +).

### 4.2.3 Symbols on measuring device

Symbol	Meaning
	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. To determine the nature of the potential hazard and the measures required to avoid it, consult the documentation accompanying the measuring device.
Ĩ	<b>Reference to documentation</b> Refers to the corresponding device documentation.
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.

## 5 Storage and transport

## 5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ► Do not store outdoors.

Storage temperature → 🗎 146

## 5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.

## 5.2.1 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

## 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:


- Outer packaging of device
- Polymer stretch wrap, complying with EU Directive 2002/95/EC (RoHS)
- Packaging
  - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
  - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Filler material Paper pads

## 6 Mounting

## 6.1 Mounting requirements

### 6.1.1 Mounting position


#### Mounting location



To prevent measuring errors arising from accumulation of gas bubbles in the measuring pipe, avoid the following mounting locations in the piping:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

#### Orientation



#### Ø 5 Orientation views

- 1 Channel 1 upstream
- 2 Channel 1 downstream
- 3 Channel 2 upstream4 Channel 2 downstream
- 4 Channel 2 downstreamA Recommended orientation with upward direction of flow
- B Non-recommended installation range with horizontal orientation (60°)
- *C Recommended installation range max.* 120°

#### Vertical


Recommended orientation with upward direction of flow (View A). With this orientation, entrained solids will sink and gases will rise away from the sensor area when the medium is not flowing. Furthermore, the pipe can be completely drained and protected against the buildup of deposits.

#### Horizontal

In the recommended installation range with a horizontal orientation (View B), gas and air accumulations at the top of the pipe and interference from deposit buildup at the bottom of the pipe can influence the measurement to a lesser degree.

#### Inlet and outlet runs

If possible, the sensor should be installed upstream from valves, T-sections, pumps etc. If this is not possible, the inlet and outlet runs indicated below must be maintained at the very minimum in order to attain the specified level of accuracy of the measuring device. If there are several flow disturbances present, the longest specified inlet run must be maintained.




- 6 Minimum inlet and outlet runs for various flow obstructions (A: single-path measurement, B: two-path measurement)
- 1 Pipe bend
- 2 Two pipe bends (on one plane)
- 3 Two pipe bends (on two planes)
- 4a Reduction
- 4b Extension
- 5 Control valve (2/3 open)
- 6 Pump

#### Operation

Single-path measurement

→ 💽 6, 🖺 21

#### Two-path measurement



Two-path measurement: example for the horizontal arrangement of the sensor sets at a measuring point

#### Dimensions


For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section


#### 6.1.2 Sensor set selection and arrangement


If mounting horizontally, always mount the sensor set so that it is offset at an angle of at least  $\pm 30^{\circ}$  to the top of the measuring pipe to avoid incorrect measurements caused by empty space at the top of the pipe.

The sensors can be arranged in different ways:

- Mounting arrangement for measurement with 1 sensor set (1 measuring path): The sensors are located on opposite sides of the pipe (offset by 180°)
- Mounting arrangement for measurement with 2 sensor sets (2 measuring paths):
   1 sensor of each sensor set is located on the opposite side of the pipe







### 6.1.3 Environment and process requirements

#### Ambient temperature range

Transmitter	-40 to +60 °C (-40 to +140 °F)
Readability of the local display	$-20$ to $+60\ensuremath{^\circ}\text{C}$ (-4 to $+140\ensuremath{^\circ}\text{F}$ ) The readability of the display may be impaired at temperatures outside the temperature range.

Sensor	Standard: -40 to +80 °C (-40 to +176 °F)
Sensor cable (connection between transmitter and sensor)	Standard: TPE halogen-free: -40 to +80 °C (-40 to +176 °F)

- In principle, it is permitted to insulate the sensors mounted on the pipe. In the case of insulated sensors, make sure that the process temperature does not exceed or drop below the specified cable temperature.
- If operating outdoors: Avoid direct sunlight, particularly in warm climatic regions.

#### Medium pressure range

Maximum nominal pressure PN 16 (16 bar (232 psi))

### 6.1.4 Special mounting instructions

#### **Display guard**

► To ensure that the display guard can be easily opened, maintain the following minimum head clearance: 350 mm (13.8 in)

## 6.2 Mounting the measuring device

### 6.2.1 Required tools

#### For transmitter

- Torque wrench
- For wall mounting:
- Open-ended wrench for hexagonal screw max. M5
- For pipe mounting:
  - Open-ended wrench AF 8
  - Phillips head screwdriver PH 2

#### For sensor

For installation on the measuring pipe: use a suitable mounting tool

### 6.2.2 Preparing the measuring device

- 1. Remove all remaining transport packaging.
- 2. Remove stick-on label on the electronics compartment cover.

#### 6.2.3 Mounting the sensor


#### Sensor configuration and settings

DN 200 to 4000 (8 to 160")		
Single-path version [mm (in)]	Two-path version [mm (in)]	
Sensor distance <sup>1)</sup>	Sensor distance <sup>1)</sup>	
Path length → 🖲 8, 🗎 25	Path length → 🖻 8, 🗎 25 Arc length → 🖻 8, 🖺 25	

1) Depends on the conditions at the measuring point (measuring pipe etc.). The sensor mounting position can be determined via FieldCare or Applicator. See also the **Result Sensor Type / Sensor Distance** parameter in the **Measuring point** submenu

#### Determining the sensor mounting positions

Mounting description




8 Sensor mounting: terminology

- 1 Single-path version
- 2 Two-path version
- a Sensor distance
- b Arc length
- c Path length
- d Measuring pipe outer diameter


Sensor holder for single-path version

Procedure:


- **1.** Determine the mounting area (e) on the pipe section (space required at measuring point approx. 1x pipe diameter).
- 2. Draw a center line on the measuring pipe at the mounting location and mark the first drill hole (drill hole diameter: 65 mm (2.56 in)). Make the center line longer than the hole to be drilled.



- 3. Cut the first drill hole with a plasma cutter for example. Measure the wall thickness of the measuring pipe if it is not already known.
- 4. Determine the sensor distance  $\rightarrow \cong 25$ .




- 5. Starting from the center line of the first drill hole, plot the sensor distance (a).
- 6. Project the center line onto the rear of the measuring pipe and draw the line.




7. Mark the drill hole on the rear center line.


8. Cut out the second drill hole and prepare the holes (deburr, clean) to weld in the sensor holders.



- **10.** Spot-weld both sensor holders. To align the path rod, screw the two guides into the sensor holders.



- **11.** Weld in both sensor holders.
- 12. Check the distance between the drill holes again and determine the path length  $\rightarrow \cong 25$ .
- 13. Screw the sensors into the sensor holders by hand. If using a tool, do not tighten by more than 30 Nm.
- **14.** Guide the sensor cable plugs into the openings provided for this purpose and tighten the plugs manually to the end stop.




A004495


Sensor holder for two-path version

#### Procedure:


- **1.** Determine the mounting area (e) on the pipe section (space required at measuring point approx. 1x pipe diameter).
- 2. Mark the center line on the measuring pipe at the mounting location.



- 3. At the mounting location of the sensor holder, mark the arc length (b) to one side of the center line. Take approximately 1/12 of the pipe circumference as the measure for the length of the arc. Mark the first drill hole (drill hole diameter: 81 to 82 mm (3.19 to 3.23 in)). Make the center line longer than the hole to be drilled.
- 4. Cut the first drill hole with a plasma cutter for example. Measure the wall thickness of the measuring pipe if it is not already known.



- **5.** Determine the sensor distance and arc length  $\rightarrow \cong 25$ .
- 6. Correct the center line with the arc length determined.




7. Project the corrected center line onto the opposite side of the pipe and draw the line (half pipe circumference).


A0044959

8. Mark the sensor distance on the center line and project it onto the center line on the rear of the pipe.

- 9. Mark the length of the arc to both sides of the center line and mark the drill holes.
- 10. Cut out the drill holes and prepare the holes (deburr, clean) to weld in the sensor holders. The holes for the sensor holders are in pairs (CH 1 CH 1 and CH 2 CH 2).



 Insert sensor holders into the first two drill holes and align with the path rod (alignment tool). Spot-weld with the welding machine and then securely weld both sensor holders. To align the path rod, screw the two guides into the sensor holders.




12. Weld in both sensor holders.


∟.

**13.** Check the path length, sensor distances and arc lengths once again. Any deviations from the correct length can be entered later as correction factors when commissioning the measuring point.

14. Insert the second pair of sensor holders into the two remaining drill holes as explained in step 11 and then weld in place.



- 15. Screw the sensors into the sensor holders by hand. If using a tool, do not tighten by more than 30 Nm.
- **16.** Guide the sensor cable plugs into the openings provided for this purpose and tighten the plugs manually to the end stop.



### 6.2.4 Mounting the transmitter

#### **A**CAUTION

#### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature  $\rightarrow \cong 23$ .
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

#### **A**CAUTION


#### Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

#### Wall mounting



*Engineering unit mm (in)*

### 1. Drill the holes.

- 2. Insert wall plugs into the drilled holes.
- **3**. Screw the securing screws in slightly.
- 4. Fit the transmitter housing over the securing screws and mount in place.
- 5. Tighten the securing screws.


#### Post mounting

#### **WARNING**

### Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.


▶ Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)



■ 10 Engineering unit mm (in)

### 6.2.5 Turning the display module

The display module can be turned to optimize display readability and operability.



- 1. Loosen the fixing screws of the housing cover.
- 2. Open the housing cover.
- 3. Unlock the display module.
- 4. Pull out the display module and turn it to the desired position in increments of 90°.

#### Mounting the transmitter housing

#### **WARNING**

# **Excessive tightening torque applied to the fixing screws!** Damage to the transmitter.

- Tighten the fixing screws with the specified torques.
- 1. Insert the display module and lock it when doing so.
- 2. Close the housing cover.
- **3.** Tighten the fixing screws of the housing cover: tightening torque for aluminum housing 2.5 Nm (1.8 lbf ft) plastic housing 1 Nm (0.7 lbf ft).

## 6.3 Post-mounting check

Is the device undamaged (visual inspection)?	
Does the measuring device meet the measuring point specifications? For example: • Process temperature →  ■ 146 • Inlet run conditions • Ambient temperature • Measuring range	
<ul> <li>Has the correct orientation for the sensor been selected →</li></ul>	
Are the sensors correctly connected to the transmitter (upstream/downstream) $\rightarrow \blacksquare 5$ , 🗎 20?	
Are the sensors mounted correctly (distance, path length, arc length) $\rightarrow \square 22?$	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	

Are the securing screw and securing clamp tightened securely?	
Is potential equalization established at the sensor holder (in the event of different potentials between the sensor holder and transmitter) ?	

## 7 Electrical connection

### NOTICE

#### The measuring device does not have an internal circuit breaker.

- ► For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- ► Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 16 A) should be integrated into the system installation.

## 7.1 Electrical safety

In accordance with applicable national regulations.

## 7.2 Connection conditions

### 7.2.1 Required tools

- Torque wrench
- For cable entries: Use corresponding tools
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule

### 7.2.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

#### Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

#### Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

#### Signal cable

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

#### Sensor cable for sensor - transmitter

Standard cable	TPE halogen-free: -40 to +80 °C (-40 to +176 °F)
Cable length (max.)	30 m (90 ft)

Cable lengths (available for order)	5 m (15 ft), 10 m (30 ft), 15 m (45 ft), 30 m (90 ft)
Operating temperature	<ul> <li>Depends on the device version and how the cable is installed: Standard version:</li> <li>Cable, fixed installation <sup>1)</sup>: minimum -40 °C (-40 °F)</li> <li>Cable, movable: minimum -25 °C (-13 °F)</li> </ul>

1) Compare details under the "Standard cable" row

#### Cable diameter

Cable glands supplied:

- For standard cable: M20 × 1.5 with cable  $\phi$  6 to 12 mm (0.24 to 0.47 in)
- For reinforced cable: M20 × 1.5 with cable  $\phi$  9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)

#### 7.2.3 Terminal assignment

#### Transmitter

The sensor can be ordered with terminals.

Connection methods available		Describle entires for order code
Outputs	Power supply	Possible options for order code "Electrical connection"
Terminals	Terminals	<ul> <li>Option A: coupling M20x1</li> <li>Option B: thread M20x1</li> <li>Option C: thread G <sup>1</sup>/<sub>2</sub>"</li> <li>Option D: thread NPT <sup>1</sup>/<sub>2</sub>"</li> </ul>

#### Supply voltage

Order code "Power supply"	Terminal numbers	terminal voltage	Frequency range		
Option <b>L</b> (wide range power unit)	1 (L+/L), 2 (L-/N)	DC 24 V	±25%	-	
		AC 24 V	±25%	50/60 Hz, ±4 Hz	
		AC 100 to 240 V	-15 to +10%	50/60 Hz, ±4 Hz	

Signal transmission for current output 0 to 20 mA/4 to 20 mA HART and other outputs and inputs

Order code for "Output" and "Input"	Terminal numbers									
	Output 1		Output 2		Output 3		Input			
-	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)		
Option <b>H</b>	Current output 4 to 20 mA HART (active) 0 to 20 mA (active)		Pulse/frequency output (passive)		Switch output (passive)		-			
Option I	Current ou 4 to 20 (active) 0 to 20 (active)	mA HART	switch	equency/ output sive)	Pulse/frequency/ switch output (passive)		Status input			

#### 7.2.4 Preparing the measuring device

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Sensor connection housing: Connect sensor cable.
- 3. Transmitter: Connect sensor cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

#### NOTICE

#### Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- If the measuring device is supplied with cable glands:
   Observe requirements for connecting cables → 
   <sup>(a)</sup> 34.

### 7.3 Connecting the measuring device

#### **WARNING**

#### Risk of electric shock! Components carry dangerous voltages!

- ► Have electrical connection work carried out by correspondingly trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- Observe grounding concept of the plant.
- ▶ Never mount or wire the measuring device while it is connected to the supply voltage.
- Before the supply voltage is applied, connect the protective ground to the measuring device.

#### 7.3.1 Connecting the sensor and transmitter


#### **WARNING**

#### Risk of damaging electronic components!

- ► Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.

The following sequence of steps is recommended when connecting:

- 1. Mount the sensor and transmitter.
- 2. Connect the sensor cable.
- 3. Connect the transmitter.



#### Connecting the sensor cable to the transmitter

- 11 Transmitter: main electronics module with terminals
- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- **3.** Route the two sensor cables of channel 1 through the slackened top union nut of the cable entry. To ensure tight sealing, mount a sealing insert on the sensor cables (push the cables through the slotted sealing insert).
- 4. Mount the screw part in the center cable entry at the top and then guide both sensor cables through the entry. Then fit the coupling nut with the sealing insert on the screw part and tighten. Ensure that the sensor cables are positioned in the cut-outs provided in the screw part.
- 5. Connect sensor cable to channel 1 upstream.
- 6. Connect sensor cable to channel 1 downstream.
- 7. For a two-path measurement: proceed as per steps 3+4
- 8. Connect sensor cable to channel 2 upstream.
- 9. Connect sensor cable to channel 2 downstream.
- **10.** Tighten the cable gland(s).
  - └ This concludes the process for connecting the sensor cable(s).

#### 11. **WARNING**

# Housing degree of protection may be voided due to insufficient sealing of the housing.

• Screw in the screw without using any lubricant.

Reverse the removal procedure to reassemble the transmitter.

### 7.3.2 Connecting the transmitter

#### **WARNING**


#### Housing degree of protection may be voided due to insufficient sealing of the housing.

Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Tightening torques for plastic housing

Housing cover fixing screw	1 Nm (0.7 lbf ft)
Cable entry	5 Nm (3.7 lbf ft)
Ground terminal	2.5 Nm (1.8 lbf ft)

When connecting the cable shield to the ground terminal, observe the grounding concept of the facility.



■ 12 Connecting the supply voltage and 0-20 mA/4-20 mA HART with additional outputs and inputs

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- **3.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the cable according to the terminal assignment  $\rightarrow \square$  35. For supply voltage: open the shock protection cover.
- 6. Firmly tighten the cable glands.

#### Reassembling the transmitter

- 1. Close the shock protection cover.
- 2. Close the housing cover.

#### 3. **A WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

► Screw in the screw without using any lubricant.

Tighten the 4 fixing screws on the housing cover.

#### 7.3.3 Potential equalization

#### Requirements


For potential equalization:

- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Connect the sensor and transmitter to the same electrical potential
- Use a ground cable with a minimum cross-section of 6 mm<sup>2</sup> (0.0093 in<sup>2</sup>) for the potential equalization connections

### 7.4 Special connection instructions

#### 7.4.1 Connection examples


#### Current output 4 to 20 mA HART



13 Connection example for 4 to 20 mA HART current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Ground the cable shield at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Connection for HART operating devices  $\rightarrow \cong 62$
- 4 Resistor for HART communication ( $\geq 250 \Omega$ ): observe maximum load  $\rightarrow \cong 139$
- 5 Analog display unit: observe maximum load  $\rightarrow \square 139$
- 6 Transmitter


#### Pulse/frequency output



☑ 14 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \square 139$


#### Switch output



15 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values  $\rightarrow \square 139$

#### Status input



If Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter


### 7.5 Ensuring the degree of protection

### 7.5.1 Degree of protection IP66/67, Type 4X enclosure

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- **1.** Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
- 2. Tighten all housing screws and screw covers.
- 3. Firmly tighten the cable glands.
- **4.** To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



**5.** Insert dummy plugs (corresponding to the housing degree of protection) into unused cable entries.

### NOTICE


Standard dummy plugs used for transportation do not have the appropriate degree of protection and can result in damage to the device!

• Use suitable dummy plugs corresponding to the degree of protection.

### 7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables comply with the requirements $\rightarrow {34?}$	
Do the cables have adequate strain relief?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" $\rightarrow \cong 41$ ?	
Does the supply voltage match the specifications on the transmitter nameplate $\rightarrow \square$ 142?	
Is the terminal assignment correct $\rightarrow \square$ 35?	
If supply voltage is present, do values appear on the display module?	
Are all housing covers installed and the screws tightened with the correct tightening torque?	

# 8 Operation options




### 8.1 Overview of operation methods

- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Communicator 475
- 4 Field Xpert SFX350 or SFX370
- 5 Field Xpert SMT70
- 6 Mobile handheld terminal
- 7 Control system (e.g. PLC)

### 8.2 Structure and function of the operating menu

### 8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device  $\rightarrow \square 154$ 



 $\blacksquare 17$  Schematic structure of the operating menu


### 8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu/parameter		User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuration of the operational	<ul> <li>Definition of the operating language</li> <li>Definition of the Web server operating language</li> <li>Resetting and controlling totalizers</li> </ul>
Operation		display • Reading off measured values	<ul> <li>Configuration of the operational display (e.g. display format, display contrast)</li> <li>Resetting and controlling totalizers</li> </ul>
Setup		<ul> <li>"Maintenance" role</li> <li>Commissioning:</li> <li>Configuration of the measurement</li> <li>Configuration of the outputs</li> </ul>	<ul> <li>Wizards for fast commissioning:</li> <li>Configuration of the measuring point</li> <li>Configuration of the system units</li> <li>Configuration of the input</li> <li>Configuration of the outputs</li> <li>Configuration of the operational display</li> <li>Definition of output conditioning</li> <li>Setting the low flow cut off</li> </ul>
			<ul> <li>Advanced setup</li> <li>For more customized configuration of the measurement (adaptation to special measuring conditions)</li> <li>Configuration of the totalizers</li> <li>Configuration of WLAN settings</li> <li>Administration (define access code, reset measuring device)</li> </ul>
Diagnostics		<ul> <li>"Maintenance" role Troubleshooting:</li> <li>Diagnostics and elimination of process and device errors</li> <li>Measured value simulation</li> </ul>	<ul> <li>Contains all parameters for error detection and analyzing process and device errors:</li> <li>Diagnostic list Contains up to 5 currently pending diagnostic messages.</li> <li>Event logbook Contains event messages that have occurred.</li> <li>Device information Contains information for identifying the device.</li> <li>Measured values Contains all current measured values.</li> <li>Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values</li> <li>Heartbeat The functionality of the device is checked on demand and the verification results are documented.</li> <li>Simulation Is used to simulate measured values or output values.</li> </ul>
Expert	function-oriented	<ul> <li>Tasks that require detailed knowledge of the function of the device:</li> <li>Commissioning measurements under difficult conditions</li> <li>Optimal adaptation of the measurement to difficult conditions</li> <li>Detailed configuration of the communication interface</li> <li>Error diagnostics in difficult cases</li> </ul>	<ul> <li>Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:</li> <li>System Contains all higher-order device parameters that do not pertain either to the measurement or measured value communication.</li> <li>Sensor Configuration of the measurement.</li> <li>Input Configuration of the status input.</li> <li>Output Configuration of the analog current outputs as well as the pulse/frequency and switch output.</li> <li>Communication Configuration of the digital communication interface and the Web server.</li> <li>Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer).</li> <li>Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.</li> </ul>

### 8.3 Access to the operating menu via the local display

### 8.3.1 Operational display



- 1 Operational display
- 2 Device tag  $\rightarrow \square 72$
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements  $\rightarrow \square 50$


#### Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals  $\rightarrow$  🗎 116
  - F: Failure
  - **C**: Function check
  - S: Out of specification
  - M: Maintenance required
- Diagnostic behavior  $\rightarrow \square 117$ 
  - 🔉: Alarm
  - <u>A</u>: Warning
- 🛱: Locking (the device is locked via the hardware )
- •: Communication (communication via remote operation is active)

#### Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



#### Measured variables

Symbol	Meaning
Ü	Volume flow
ṁ	Mass flow

С	Speed of sound
ゼ	Flow velocity
SNR	Signal to noise ratio
	Signal strength
Σ	Totalizer         Image: The measurement channel number indicates which of the three totalizers is displayed.
Ģ	Output          Output         Image: The measurement channel number indicates which of the outputs is displayed.
Ð	Status input

Measurement channel numbers


Symbol	Meaning	
14	Measurement channel 1 to 4	
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).		

#### Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols  $\rightarrow \square 117$ 


The number and display format of the measured values can be configured via the **Format display** parameter ( $\Rightarrow \boxtimes 86$ ).

### 8.3.2 Navigation view



#### Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:




For more information about the icons in the menu, refer to the "Display area" section  $\rightarrow \cong 47$ 

#### Status area

The following appears in the status area of the navigation view in the top right corner: • In the submenu

- The direct access code for the parameter you are navigating to (e.g. 0022-1)
- If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
  - If a diagnostic event is present, the diagnostic behavior and status signal



#### Display area

Menus

Symbol	Meaning
P	Operation         Appears:         In the menu next to the "Operation" selection         At the left in the navigation path in the Operation menu
ų	Setup         Appears:         In the menu next to the "Setup" selection         At the left in the navigation path in the Setup menu
ų	Diagnostics         Appears:         In the menu next to the "Diagnostics" selection         At the left in the navigation path in the Diagnostics menu
÷ <b>*</b>	<ul> <li>Expert</li> <li>Appears:</li> <li>In the menu next to the "Expert" selection</li> <li>At the left in the navigation path in the Expert menu</li> </ul>

#### Submenus, wizards, parameters

Symbol	Meaning
►	Submenu
⊳.	Wizard
<u></u>	Parameters within a wizard           Image: State of the


#### Locking

Symbol	Meaning
â	<ul> <li>Parameter locked</li> <li>When displayed in front of a parameter name, indicates that the parameter is locked.</li> <li>By a user-specific access code</li> <li>By the hardware write protection switch</li> </ul>

#### Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
<b>~</b>	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

### 8.3.3 Editing view



#### Input mask

The following input symbols are available in the input mask of the numeric and text editor:

#### Numeric editor

Symbol	Meaning
0  9	Selection of numbers from 0 to 9.
·	Inserts decimal separator at the input position.
_	Inserts minus sign at the input position.
$\checkmark$	Confirms selection.
+	Moves the input position one position to the left.

C	Х	
	С	

X	Exits the input without applying the changes.
	Clears all entered characters.

#### Text editor

Symbol	Meaning
(Aa1@)	Toggle • Between upper-case and lower-case letters • For entering numbers • For entering special characters
ABC_  XYZ	Selection of letters from A to Z.
(abc _)  Xyz	Selection of letters from a to z.
···· ··· ···	Selection of special characters.
	Confirms selection.
<b>+×C+→</b>	Switches to the selection of the correction tools.
X	Exits the input without applying the changes.
C	Clears all entered characters.

### 

Symbol	Meaning
C	Clears all entered characters.
Ð	Moves the input position one position to the right.
Ð	Moves the input position one position to the left.
×.	Deletes one character immediately to the left of the input position.

Кеу	Meaning		
	Minus key		
	<i>In menu, submenu</i> Moves the selection bar upwards in a picklist.		
$\bigcirc$	With a wizard Confirms the parameter value and goes to the previous parameter.		
	For text and numeric editor In the input mask, moves the selection bar to the left (backwards).		
	Plus key		
	<i>In menu, submenu</i> Moves the selection bar downwards in a picklist.		
(+)	With a wizard Confirms the parameter value and goes to the next parameter.		
	For text and numeric editor In the input mask, moves the selection bar to the right (forwards).		
	Enter key		
	<i>For operational display</i> Pressing the key for 2 s opens the context menu including the selection for activating the keypad lock.		
Ē	<ul> <li>In menu, submenu</li> <li>Pressing the key briefly: <ul> <li>Opens the selected menu, submenu or parameter.</li> <li>Starts the wizard.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s in a parameter: <ul> <li>If present, opens the help text for the function of the parameter.</li> </ul> </li> </ul>		
	With a wizard Opens the editing view of the parameter.		
	<ul> <li>For text and numeric editor</li> <li>Pressing the key briefly:</li> <li>Opens the selected group.</li> <li>Carries out the selected action.</li> <li>Pressing the key for 2 s confirms the edited parameter value.</li> </ul>		
	Escape key combination (press keys simultaneously)		
<b>-</b> + <b>+</b>	<ul> <li>In menu, submenu</li> <li>Pressing the key briefly: <ul> <li>Exits the current menu level and takes you to the next level up.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s returns you to the operational display ("home position").</li> </ul>		
	With a wizard Exits the wizard and takes you to the next level up.		
	<i>For text and numeric editor</i> Closes the text or numeric editor without applying changes.		
-+++E	Minus/Plus/Enter key combination (press and hold down the keys simultaneously) For operational display Enables or disables the keypad lock (only SD02 display module).		

### 8.3.4 Operating elements

### 8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Simulation

#### Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the  $\Box$  and  $\blacksquare$  keys for longer than 3 seconds.
  - └ The context menu opens.



2. Press - + + simultaneously.

└ The context menu is closed and the operational display appears.

#### Calling up the menu via the context menu

1. Open the context menu.

**2.** Press  $\pm$  to navigate to the desired menu.

**3.** Press E to confirm the selection.


└ The selected menu opens.

### 8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements  $\rightarrow \cong 46$ 

Example: Setting the number of displayed measured values to "2 values"




### 8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

#### Navigation path

Expert  $\rightarrow$  Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter **"914"** instead of **"00914"**
- If no channel number is entered, channel 1 is opened automatically.
- Example: Enter  $00914 \rightarrow Assign \ process \ variable$  parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter 00914-2  $\rightarrow$  Assign process variable parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

### 8.3.8 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

#### Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

└ The help text for the selected parameter opens.




- 18 Example: Help text for parameter "Enter access code"
- 2. Press + + simultaneously.
  - └ The help text is closed.

#### 8.3.9 Changing the parameters

For a description of the editing view - consisting of the text editor and numeric editor - with symbols → 🗎 48, for a description of the operating elements → 🗎 50

**Example:** Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A message is displayed if the value entered is outside the permitted value range.

E	nt. access code
In	valid or out of range input
Vá	alue
M	in:0
M	ax:9999

#### 8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access  $\rightarrow \cong 101$ .

#### Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
  - └ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ <sup>1)</sup>

1) The user only has write access after entering the access code.

#### Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	1)

 Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

The user role with which the user is currently logged on is indicated by the Access status display parameter. Navigation path: Operation  $\rightarrow$  Access status display

#### 8.3.11 Disabling write protection via access code

If the B-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation  $\rightarrow$  B 101.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ( $\rightarrow \square 90$ ) via the respective access option.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

└ The B -symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

### 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

#### Switching on the keypad lock

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

#### To activate the keylock manually:

1. The device is in the measured value display.

- Press the  $\Box$  and  $\blacksquare$  keys for 3 seconds.
- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
  - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

#### Switching off the keypad lock

The keypad lock is switched on.

Press the  $\boxdot$  and  $\blacksquare$  keys for 3 seconds.

└ The keypad lock is switched off.

### 8.4 Access to the operating menu via the Web browser

#### 8.4.1 Function scope

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via a standard Ethernet switch (RJ45) or via a WLAN interface. The structure of the operating menu is the same as the menu on the local display. In addition to the measured values, status information about the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display", option G "4-line, illuminated; Touch Control +WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device  $\rightarrow \implies 154$ 

### 8.4.2 Requirements

Computer hardware

Interface	The computer must have an RJ45 interface.
Connection	Standard Ethernet cable with RJ45 connector.
Screen	Recommended size: $\geq$ 12" (depends on the screen resolution)

#### *Computer software*

Recommended operating systems	Microsoft Windows 7 or higher.  Microsoft Windows XP is supported.
Web browsers supported	<ul> <li>Microsoft Internet Explorer 8 or higher</li> <li>Microsoft Edge</li> <li>Mozilla Firefox</li> <li>Google Chrome</li> <li>Safari</li> </ul>

#### Computer settings

User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).		
Proxy server settings of the Web browser	The Web browser setting <i>Use proxy server for LAN</i> must be <b>disabled</b> .		
JavaScript	JavaScript must be enabled.		
	If JavaScript cannot be enabled: enter http://192.168.1.212/basic.html in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.		
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under <b>Internet options</b> .		
Network connections	Only the active network connections to the measuring device should be used.		
	Switch off all other network connections such as WLAN.		

In the event of connection problems:  $\rightarrow \cong 114$ 

### Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface	
Measuring device	The measuring device has an RJ45 interface.	
Web server	Web server must be enabled; factory setting: ON For information on enabling the Web server →   61	

Measuring device: via	WLAN	interface
-----------------------	------	-----------

Device	WLAN interface	
Measuring device	The measuring device has a WLAN antenna: Transmitter with integrated WLAN antenna	
Web server	Web server and WLAN must be enabled; factory setting: ON	
	For information on enabling the Web server $\rightarrow \textcircled{B} 61$	

### 8.4.3 Establishing a connection

#### Via service interface (CDI-RJ45)

Preparing the measuring device

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- 2. Connect to the computer using a cable .
- 3. If a 2nd network card is not used, close all the applications on the notebook.
  - ← Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	ss         192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 → e.           192.168.1.213	
Subnet mask 255.255.0		
Default gateway	192.168.1.212 or leave cells empty	

#### Via WLAN interface

Configuring the Internet protocol of the mobile terminal

#### NOTICE

- If the WLAN connection is lost during the configuration, settings made may be lost.
- Make sure that the WLAN connection is not disconnected while configuring the device.

#### NOTICE

# In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

#### Preparing the mobile terminal

Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- In the WLAN settings of the mobile terminal: Select the measuring device using the SSID (e.g. EH Prosonic Flow 400 A802000).
- 2. If necessary, select the WPA2 encryption method.
- **3.** Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
- P The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the SSID name to the measuring point (e.g. tag name) as it is displayed as the WLAN network.

#### Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

#### Starting the Web browser

1. Start the Web browser on the computer.

- 2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212
  - └ The login page appears.

1 Device name: Device tag: Status signal:	2 3 4 5 Volume flow: Mass flow: Conductivity:
Web server language	i English 9
Access status Enter access code	Maintenance         7           i         8
Reset access code	<u>Login</u> 9 9

- 1 Picture of device
- 2 Device name 3 Device tag ( $\rightarrow \square 73$ )
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code ( $\rightarrow \square 98$ )

If a login page does not appear, or if the page is incomplete  $\rightarrow \implies 114$ 


### 8.4.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code	0000 (factory setting); can be changed by customer
	sooo (lactory setting), can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

# 8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

#### Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal  $\rightarrow \cong 119$
- Current measured values

#### Function row

Functions	Meaning
Measured values	Displays the measured values of the device
Menu	<ul> <li>Access to the operating menu from the measuring device</li> <li>The structure of the operating menu is the same as for the local display</li> <li>For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device</li> </ul>
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	<ul> <li>Data exchange between PC and measuring device:</li> <li>Device configuration:</li> <li>Load settings from the device (XML format, save configuration)</li> <li>Save settings to the device (XML format, restore configuration)</li> <li>Logbook - Export Event logbook (.csv file)</li> <li>Documents - Export documents:</li> <li>Export backup data record (.csv file, create documentation of the measuring point configuration)</li> <li>Verification report (PDF file, only available with the "Heartbeat Verification" application package)</li> </ul>
Network configuration	<ul> <li>Configuration and checking of all the parameters required for establishing the connection to the measuring device:</li> <li>Network settings (e.g. IP address, MAC address)</li> <li>Device information (e.g. serial number, firmware version)</li> </ul>
Logout	End the operation and call up the login page

#### Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

#### Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

#### 8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

#### Navigation

"Expert" menu  $\rightarrow$  Communication  $\rightarrow$  Web server

#### Parameter overview with brief description

Parameter	Description	Selection
Web server functionality	Switch the Web server on and off.	• Off
		• On

#### Function scope of the "Web server functionality" parameter

Option	Description
Off	<ul><li>The web server is completely disabled.</li><li>Port 80 is locked.</li></ul>
On	<ul><li>The complete functionality of the web server is available.</li><li>JavaScript is used.</li><li>The password is transferred in an encrypted state.</li><li>Any change to the password is also transferred in an encrypted state.</li></ul>

#### Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

#### 8.4.7 Logging out

Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.

└ The home page with the Login box appears.

- 2. Close the Web browser.
- 3. If no longer needed:

Reset modified properties of the Internet protocol (TCP/IP)  $\rightarrow \square 57$ .


### 8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is identical to operation via the local display.

### 8.5.1 Connecting the operating tool

#### Via HART protocol


This communication interface is available in device versions with a HART output.



Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter

#### Via service interface (CDI-RJ45)




☑ 20 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



- 1 Transmitter with integrated WLAN antenna
- 2 LED lit constantly: WLAN reception is enabled on measuring device
- 3 LED flashing: WLAN connection established between operating unit and measuring device
- 4 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 5 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 6 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)	
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)	
Configurable WLAN channels	1 to 11	
Degree of protection	IP67	
Available antenna	Internal antenna	
Range	Typically 10 m (32 ft)	

Configuring the Internet protocol of the mobile terminal

#### NOTICE

- If the WLAN connection is lost during the configuration, settings made may be lost.
- ▶ Make sure that the WLAN connection is not disconnected while configuring the device.

#### NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

#### Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:

Select the measuring device using the SSID (e.g. EH\_Prosonic Flow\_400\_A802000).

2. If necessary, select the WPA2 encryption method.

- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.

The serial number can be found on the nameplate.

To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the SSID name to the measuring point (e.g. tag name) as it is displayed as the WLAN network.

#### Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

#### 8.5.2 FieldCare

#### **Function scope**

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- HART protocol
- CDI-RJ45 service interface

Typical functions:

- Parameterization of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S


#### Source for device description files

See information  $\rightarrow \square 67$ 

#### Establishing a connection

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
  - └ The **Add device** window opens.
- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.
  - ➡ The CDI Communication TCP/IP (Configuration) window opens.
- 6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
- 7. Establish the online connection to the device.
- For additional information, see Operating Instructions BA00027S and BA00059S

#### User interface



1 Device name

2 Tag name


- 3 Status area with status signal  $\rightarrow \square 119$
- 4 Display area for current measured values
- 5 Edit bar with additional functions
- 6 Navigation area with operating menu structure

#### 8.5.3 DeviceCare

#### Function scope

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



#### Source for device description files


See information  $\rightarrow \cong 67$ 

#### 8.5.4 Field Xpert SMT70, SMT77

#### Field Xpert SMT70

The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.

This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.



Operating Instructions BA01709S

Product page: www.endress.com/smt70

Source for device description files:  $\rightarrow \square 67$ 

#### Field Xpert SMT77

The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.

- Technical Information TI01418S
  - Operating Instructions BA01923S
  - Product page: www.endress.com/smt77

Source for device description files:  $\rightarrow \square 67$ 

#### 8.5.5 AMS Device Manager

#### Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

#### Source for device description files

See data  $\rightarrow \blacksquare 67$ 

#### 8.5.6 SIMATIC PDM

#### Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

#### Source for device description files

See information on  $\rightarrow \square 67$ 

# 9 System integration

### 9.1 Overview of device description files

### 9.1.1 Current version data for the device

Firmware version	01.00.zz	<ul> <li>On the title page of the Operating Instructions</li> <li>On the transmitter nameplate</li> <li>Firmware version         Diagnostics → Device information → Firmware version     </li> </ul>
Release date of firmware version	12.2021	
Manufacturer ID	0x11	Manufacturer ID Diagnostics $\rightarrow$ Device information $\rightarrow$ Manufacturer ID
Device type ID	0x5D	Device type Diagnostics $\rightarrow$ Device information $\rightarrow$ Device type
HART protocol revision	7	
Device revision	1	<ul> <li>On the transmitter nameplate</li> <li>Device revision</li> <li>Diagnostics → Device information → Device revision</li> </ul>

For an overview of the various firmware versions for the device  $\rightarrow \cong 131$ 

### 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via HART protocol	Sources for obtaining device descriptions	
FieldCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>	
DeviceCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>	
<ul><li>Field Xpert SMT70</li><li>Field Xpert SMT77</li></ul>	Use update function of handheld terminal	
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area	
SIMATIC PDM (Siemens)	www.endress.com → Download Area	
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal	

### 9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Volume flow
Secondary dynamic variable (SV)	Totalizer 1
Tertiary dynamic variable (TV)	Totalizer 2
Quaternary dynamic variable (QV)	Totalizer 3

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert  $\rightarrow$  Communication  $\rightarrow$  HART output  $\rightarrow$  Output  $\rightarrow$  Assign PV
- Expert  $\rightarrow$  Communication  $\rightarrow$  HART output  $\rightarrow$  Output  $\rightarrow$  Assign SV
- Expert  $\rightarrow$  Communication  $\rightarrow$  HART output  $\rightarrow$  Output  $\rightarrow$  Assign TV
- Expert  $\rightarrow$  Communication  $\rightarrow$  HART output  $\rightarrow$  Output  $\rightarrow$  Assign QV

The following measured variables can be assigned to the dynamic variables:

#### Measured variables for PV (primary dynamic variable)

- Measured variables which are generally available:
  - Volume flow
  - Mass flow
  - Flow velocity
  - Sound velocity
  - Electronics temperature
- Additional measured variables with the Heartbeat Verification + Monitoring application package:
  - Signal strength
  - Signal to noise ratio
  - Acceptance rate
  - Turbulence

# Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Measured variables which are always available:
  - Volume flow
  - Mass flow
  - Flow velocity
  - Sound velocity
  - Electronics temperature
  - Totalizer 1
  - Totalizer 2
  - Totalizer 3
  - HART input
  - Current input 1<sup>1)</sup>
  - Current input 2<sup>1)</sup>
  - Current input 3<sup>1)</sup>
- Additional measured variables with the Heartbeat Verification + Monitoring application package:
  - Signal strength
  - Signal to noise ratio
  - Acceptance rate
  - Turbulence

<sup>1)</sup> Visible depending on the order options or device settings

### 9.3 Other settings

Burst mode functionality in accordance with HART 7 Specification:

#### Navigation

"Expert" menu  $\rightarrow$  Communication  $\rightarrow$  HART output  $\rightarrow$  Burst configuration  $\rightarrow$  Burst configuration 1 to n

► Burst configuration 1 to n	
Burst mode 1 to n	] → 🗎 69
Burst command 1 to n	] → 🗎 69
Burst variable 0	] → 🗎 70
Burst variable 1	] → 🗎 70
Burst variable 2	] → 🗎 70
Burst variable 3	] → 🗎 70
Burst variable 4	] → 🗎 70
Burst variable 5	] → 🗎 70
Burst variable 6	] → 🗎 70
Burst variable 7	] → 🗎 70
Burst trigger mode	] → 🗎 70
Burst trigger level	] → 🗎 70
Min. update period	] → 🗎 70
Max. update period	] → 🗎 70

### Parameter overview with brief description

Parameter	Description	Selection / User entry
Burst mode 1 to n	Activate the HART burst mode for burst message X.	<ul><li>Off</li><li>On</li></ul>
Burst command 1 to n	Select the HART command that is sent to the HART master.	<ul> <li>Command 1</li> <li>Command 2</li> <li>Command 3</li> <li>Command 9</li> <li>Command 33</li> <li>Command 48</li> </ul>

Parameter	Description	Selection / User entry
Burst variable 0	For HART command 9 and 33: select the HART device variable or the process variable.	<ul> <li>Not used</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength *</li> <li>Signal to noise ratio *</li> <li>Turbulence *</li> <li>Acceptance rate *</li> <li>Temperature *</li> <li>Density *</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Measured current</li> <li>Percent of range</li> <li>Primary variable (PV)</li> <li>Quaternary variable (QV)</li> <li>Secondary variable (SV)</li> <li>Tertiary variable (TV)</li> </ul>
Burst variable 1	For HART command 9 and 33: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 2	For HART command 9 and 33: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 3	For HART command 9 and 33: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 4	For HART command 9: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 5	For HART command 9: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 6	For HART command 9: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst variable 7	For HART command 9: select the HART device variable or the process variable.	See the <b>Burst variable 0</b> parameter.
Burst trigger mode	Select the event that triggers burst message X.	<ul> <li>Continuous</li> <li>Window*</li> <li>Rising*</li> <li>Falling*</li> <li>On change</li> </ul>
Burst trigger level	Enter the burst trigger value.	Signed floating-point number
	Together with the option selected in the <b>Burst trigger mode</b> parameter the burst trigger value determines the time of burst message X.	
Min. update period	Enter the minimum time span between two burst commands of burst message X.	Positive integer
Max. update period	Enter the maximum time span between two burst commands of burst message X.	Positive integer

\* Visibility depends on order options or device settings

## 10 Commissioning

### 10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist  $\rightarrow$   $\cong$  32
- "Post-connection check" checklist  $\rightarrow \cong 41$


### **10.2** Switching on the measuring device

- ► After a successful function check, switch on the measuring device.
  - ← After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting"  $\rightarrow \cong 113$ .

### **10.3** Setting the operating language


Factory setting: English or ordered local language



■ 21 Taking the example of the local display


### **10.4** Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu




22 Taking the example of the local display

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).



### 10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



- E 23 Header of the operational display with tag name
- 1 Tag name

Enter the tag name in the "FieldCare" operating tool  $\rightarrow \cong 65$ 

#### Navigation

"Setup" menu  $\rightarrow$  Device tag

#### Parameter overview with brief description

Parameter	Description	User entry
Device tag	51	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

## 10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

#### Navigation

"Setup" menu → System units

► System units		
Volume flow unit		→ 🗎 74
Volume unit		→ 🗎 74
Mass flow unit		→ 🗎 74
Mass unit		→ 🖺 74
Velocity unit		→ 🗎 74
Temperature unit		→ 🗎 74
Density unit		→ 🖺 74
Length unit		→ 🗎 74

Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • m <sup>3</sup> /h • ft <sup>3</sup> /min
Volume unit	Select volume unit.	Unit choose list	Country-specific: • m <sup>3</sup> • ft <sup>3</sup>
Mass flow unit	Select mass flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • kg/h • lb/min
Mass unit	Select mass unit.	Unit choose list	Country-specific: • kg • lb
Velocity unit	Select velocity unit. <i>Effect</i> The selected unit applies for: • Flow velocity • Sound velocity	Unit choose list	Country-specific: • m/s • ft/s
Temperature unit	Select temperature unit.         Effect         The selected unit applies for:         • Temperature         • Electronic temperature parameter (6053)         • External temperature parameter (6080)         • Reference temperature parameter (1816)	Unit choose list	Country-specific: • °C • °F
Density unit	Select density unit. <i>Effect</i> The selected unit applies for: • Output • Simulation process variable	Unit choose list	Country-specific: • kg/dm <sup>3</sup> • lb/ft <sup>3</sup>
Length unit	Select the unit of length.	Unit choose list	Country-specific: • mm • in

## **10.4.3** Configuring the measuring point

The **"Measuring point " wizard** guides you systematically through all the parameters that must be set for the configuration of the measuring point.

#### Navigation

"Setup" menu → Measuring point

► Measuring poin	t	 
	Measuring point configuration	→ 🗎 75

	Process fluid	-	→ 🗎 75
	Medium temperature	-	→ 🖺 75
	Sound velocity	-	→ 🗎 76
	Viscosity	-	→ 🗎 76
	Pipe dimensions	]	→ 🖺 76
	Pipe circumference	]	→ 🗎 76
	Pipe outer diameter	-	→ 🗎 76
	Pipe wall thickness	-	→ 🗎 76
	Liner material	-	→ 🗎 76
	Liner sound velocity	-	→ 🗎 76
	Liner thickness	-	→ 🖺 76
	Sensor type	-	→ 🖺 76
	Cable length	-	→ 🖺 76
	Result sensor type / sensor distance	-	→ 🖺 76
	Result path length / arc length	- 	→ 🗎 76
L			

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Measuring point configuration	-	Select configuration for the measuring point.	<ul> <li>1 measuring point <ul> <li>signal path 1</li> </ul> </li> <li>1 measuring point <ul> <li>signal path 2*</li> </ul> </li> <li>1 measuring point <ul> <li>2 signal paths*</li> </ul> </li> </ul>	Depending on the sensor version
Process fluid	-	Select process fluid.	<ul> <li>Water</li> <li>Sea water</li> <li>Distilled water</li> <li>Ammonia NH3</li> <li>Benzene</li> <li>Ethanol</li> <li>Glycol</li> <li>Milk</li> <li>Methanol</li> <li>User-specific liquid</li> </ul>	-
Medium temperature	-	Enter a fixed value for process temperature.	−200 to 550 °C	-

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Sound velocity	The <b>User-specific liquid</b> option is selected in the <b>Process fluid</b> parameter.	Enter sound velocity of fluid.	200 to 3 000 m/s	_
Viscosity	The <b>User-specific liquid</b> option is selected in the <b>Process fluid</b> parameter.	Enter medium viscosity at installation temperature.	1E-10 to 0.01 m <sup>2</sup> /s	-
Pipe dimensions	-	Select if pipe dimensions are defined by diameter or circumference.	<ul><li>Diameter</li><li>Pipe circumference</li></ul>	-
Pipe circumference	The <b>Pipe circumference</b> option is selected in the <b>Pipe</b> <b>dimensions</b> parameter.	Define the pipe circumference.	30 to 62 800 mm	-
Pipe outer diameter	The <b>Diameter</b> option is selected in the <b>Pipe dimensions</b> parameter.	Define the outer diameter of the pipe.	10 to 5000 mm	100 mm
Pipe wall thickness	-	Enter the pipe wall thickness.	Positive floating point number	3 mm
Liner material	-	Select liner material.	<ul> <li>None</li> <li>Cement</li> <li>Rubber</li> <li>Epoxy resin</li> <li>Unknown liner material</li> </ul>	-
Liner sound velocity	The <b>Unknown liner material</b> option is selected in the <b>Liner material</b> parameter.	Define the sound velocity of liner material.	800.0 to 3 800.0 m/s	-
Liner thickness	One of the following options is selected in the <b>Liner material</b> parameter: • Cement • Rubber • Epoxy resin • Unknown liner material	Define the thickness of liner.	0 to 100 mm	-
Sensor type	-	Select sensor type.	I-100-A*	I-100-A
Cable length	-	Enter length of sensor cables.	0 to 200 000 mm	As per order
Result sensor type / sensor distance	-	Shows the sensor type and sensor distance calculated for installation.	Character string comprising numbers, letters and special characters	_
Result path length / arc length	-	Shows the path length calculated and (if applicable) the calculated arc length.	Character string comprising numbers, letters and special characters	-

\* Visibility depends on order options or device settings

## 10.4.4 Checking the installation status

The status of individual parameters can be checked in the **Installation status** submenu.

#### Navigation

"Setup" menu  $\rightarrow$  Installation status


Installation status

Installation status	→ 🗎 77
Signal strength	→ 🗎 77
Signal to noise ratio	→ 🗎 77
Sound velocity	→ 🗎 77

Parameter	Description	User interface
Installation status	<ul> <li>Shows the device status on installation based on the measured values displayed.</li> <li>Displays the device status after installation according to the displayed measured values.</li> <li>Good option: No further optimization required</li> <li>Acceptable option: Measuring performance ok, optimize if possible. You should always aim for the status Good option.</li> <li>Bad option: Optimization is required. Poor and unstable measuring performance.</li> <li>Check the following points to optimize the sensor installation: <ul> <li>Sensor distance</li> <li>Alignment of sensors</li> <li>Check the measuring point parameters in the configuration</li> </ul> </li> </ul>	<ul> <li>Good</li> <li>Acceptable</li> <li>Bad</li> </ul>
Signal strength	Displays the current signal strength (0 to 100 dB). Assessment of the signal strength: • < 10 dB: bad • > 90 dB: very good	Signed floating-point number
Signal to noise ratio	Displays the current signal to noise ratio (0 to 100 dB). Assessment of the signal to noise ratio: • < 20 dB: bad • > 50 dB: very good	Signed floating-point number
Sound velocity	Displays the sound velocity that is currently measured. Assessment of the sound velocity: • < 1 %: Good • 1 to 2 %: Acceptable • > 2 %: Bad	Signed floating-point number

## 10.4.5 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.



Navigation "Setup" menu → Status input

#### Structure of the submenu

► Status input	
Assign status input	→ 🗎 78
Active level	→ 🗎 78
Response time status input	→ 🖹 78

Parameter	Description	Selection / User entry
Assign status input	Select function for the status input.	<ul> <li>Off</li> <li>Reset totalizer 1</li> <li>Reset totalizer 2</li> <li>Reset totalizer 3</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>
Active level	Define input signal level at which the assigned function is triggered.	<ul><li>High</li><li>Low</li></ul>
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms

## **10.4.6** Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

#### Navigation

"Setup" menu  $\rightarrow$  Current output 1

► Current output 1	
Process variable current output	) → 🗎 79
Current range output	) → 🗎 79
Lower range value output	) → 🗎 80
Upper range value output	] → 🖺 80
Fixed current	] → 🗎 80
Damping current output	] → 🖺 80
Failure behavior current output	) → 🖺 80
Failure current	] → 🖺 80

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Process variable current output	-	Select process variable for current output.	<ul> <li>Off*</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength*</li> <li>Signal to noise ratio*</li> <li>Turbulence*</li> <li>Acceptance rate*</li> <li>Temperature*</li> <li>Density*</li> <li>Electronics temperature</li> </ul>	-
Current range output	-	Select current range for process value output and upper/lower level for alarm signal.	<ul> <li>420 mA NE (3.820.5 mA)</li> <li>420 mA US (3.920.8 mA)</li> <li>420 mA (4 20.5 mA)</li> <li>020 mA (0 20.5 mA)</li> <li>Fixed value</li> </ul>	Country-specific: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Lower range value output	<ul> <li>One of the following options is selected in the Current span parameter (→ ) 79):</li> <li>420 mA NE (3.820.5 mA)</li> <li>420 mA US (3.920.8 mA)</li> <li>420 mA (4 20.5 mA)</li> <li>020 mA (0 20.5 mA)</li> </ul>	Enter lower range value for the measured value range.	Signed floating-point number	Country-specific: • m <sup>3</sup> /h • ft <sup>3</sup> /h
Upper range value output	<ul> <li>In the <b>Current span</b> parameter</li> <li>(→ ● 79), one of the</li> <li>following options is selected:</li> <li>420 mA NE (3.820.5 mA)</li> <li>420 mA US (3.920.8 mA)</li> <li>420 mA (4 20.5 mA)</li> <li>020 mA (0 20.5 mA)</li> </ul>	Enter upper range value for the measured value range.	Signed floating-point number	Depends on country and nominal diameter
Fixed current	The <b>Fixed current</b> option is selected in the <b>Current span</b> parameter ( $\rightarrow \square$ 79).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA
Damping current output	<ul> <li>A process variable is selected in the Assign current output parameter (→ ) 79) and one of the following options is selected in the Current span parameter (→ ) 79):</li> <li>420 mA NE (3.820.5 mA)</li> <li>420 mA US (3.920.8 mA)</li> <li>420 mA (4 20.5 mA)</li> <li>020 mA (0 20.5 mA)</li> </ul>	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	-
Failure behavior current output	A process variable is selected in the Assign current output parameter ( $\rightarrow \boxdot 79$ ) and one of the following options is selected in the Current span parameter ( $\rightarrow \boxdot 79$ ): • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (4 20.5 mA) • 020 mA (0 20.5 mA)	Define output behavior in alarm condition.	<ul> <li>Min.</li> <li>Max.</li> <li>Last valid value</li> <li>Actual value</li> <li>Fixed value</li> </ul>	-
Failure current	The <b>Defined value</b> option is selected in the <b>Failure mode</b> parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	-

\* Visibility depends on order options or device settings

## 10.4.7 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

## Configuring the pulse output

#### Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output 1 to n

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 81
Assign pulse output	→ 🗎 81
Value per pulse	→ 🖺 81
Pulse width	→ 🗎 81
Failure mode	→ 🗎 81
Invert output signal	→ 🗎 81

## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul> <li>Pulse<sup>*</sup></li> <li>Frequency<sup>*</sup></li> <li>Switch<sup>*</sup></li> </ul>	-
Assign pulse output	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter.	Select process variable for pulse output.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li></ul>	-
Pulse scaling	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \bowtie 81$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \bowtie 81$ ).	Enter quantity for measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \bowtie 81$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \bowtie 81$ ).	Define time width of the output pulse.	0.05 to 2 000 ms	-
Failure mode	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \bowtie 81$ ) and a process variable is selected in the <b>Assign pulse output</b> parameter ( $\rightarrow \bowtie 81$ ).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>No pulses</li></ul>	-
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

\* Visibility depends on order options or device settings

## Configuring the frequency output

## Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output 1 to n

<ul> <li>Pulse/frequency/switch output</li> <li>1 to n</li> </ul>	
Operating mode	→ 🗎 82
Assign frequency output	→ 🖺 82
Minimum frequency value	→ 🖺 82
Maximum frequency value	→ 🗎 83
Measuring value at minimum frequency	→ 🗎 83
Measuring value at maximum frequency	→ 🗎 83
Failure mode	→ 🗎 83
Failure frequency	→ 🗎 83
Invert output signal	→ 🗎 83

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul> <li>Pulse *</li> <li>Frequency *</li> <li>Switch *</li> </ul>	-
Assign frequency output	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 81).	Select process variable for frequency output.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength*</li> <li>Signal to noise ratio*</li> <li>Turbulence*</li> <li>Acceptance rate*</li> <li>Temperature*</li> <li>Density*</li> <li>Electronics temperature</li> </ul>	_
Minimum frequency value	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \boxminus 81$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\rightarrow \boxminus 82$ ).	Enter minimum frequency.	0.0 to 10000 Hz	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Maximum frequency value	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \cong 81$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \cong 82$ ).	Enter maximum frequency.	0.0 to 10000 Hz	-
Measuring value at minimum frequency	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \cong 81$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \cong 82$ ).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \boxdot 81$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \boxdot 82$ ).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \cong 81$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \cong 82$ ).	Define output behavior in alarm condition.	<ul> <li>Actual value</li> <li>Defined value</li> <li>0 Hz</li> </ul>	-
Failure frequency	The <b>Frequency</b> option is selected in the <b>Operating</b> <b>mode</b> parameter ( $\rightarrow \boxdot 81$ ) and a process variable is selected in the <b>Assign</b> <b>frequency output</b> parameter ( $\rightarrow \boxdot 82$ ).	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	-
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	-

\* Visibility depends on order options or device settings

## Configuring the switch output

## Navigation

"Setup" menu  $\rightarrow$  Pulse/frequency/switch output 1 to n

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 84
Switch output function	→ 🗎 84
Assign diagnostic behavior	→ 🗎 84
Assign limit	→ 🗎 84

Assign fl	ow direction check		<b>1</b> 85
Assign st	atus		85
Switch-o	n value		85
Switch-o	ff value		85
Switch-o	n delay	] → @	<b>1</b> 85
Switch-o	ff delay	→ @	<b>à</b> 85
Failure n	node		85
Invert ou	tput signal		<b>ì</b> 85

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul> <li>Pulse<sup>*</sup></li> <li>Frequency<sup>*</sup></li> <li>Switch<sup>*</sup></li> </ul>	-
Switch output function	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter parameter.	Select function for switch output.	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Status</li> </ul>	-
Assign diagnostic behavior	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Diagnostic behavior option is selected.</li> </ul>	Select diagnostic behavior for switch output.	<ul> <li>Alarm</li> <li>Alarm or warning</li> <li>Warning</li> </ul>	-
Assign limit	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Select process variable for limit function.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength*</li> <li>Signal to noise ratio*</li> <li>Turbulence*</li> <li>Acceptance rate*</li> <li>Temperature*</li> <li>Density*</li> <li>Electronics temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> </ul>	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign flow direction check	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Flow direction check option is selected in the Switch output function parameter.</li> </ul>	Select process variable for flow direction monitoring.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li><li> Flow velocity</li></ul>	-
Assign status	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Status option is selected in the Switch output function parameter.</li> </ul>	Select device status for switch output.	<ul><li> Off</li><li> Low flow cut off</li></ul>	-
Switch-on value	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific
Switch-off value	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific
Switch-on delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-on of status output.	0.0 to 100.0 s	-
Switch-off delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-off of status output.	0.0 to 100.0 s	-
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	-
Invert output signal	-	Invert the output signal.	• No • Yes	-

\* Visibility depends on order options or device settings

## 10.4.8 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

#### Navigation

"Setup" menu → Display

► Display		
For	rmat display	→ 🗎 86

Value 1 display		→ 🗎 86
0% bargraph value 1		→ 🖺 86
100% bargraph value 1	]	→ 🗎 86
Value 2 display	]	→ 🖺 86
Value 3 display		→ 🖺 86
0% bargraph value 3		→ 🗎 86
100% bargraph value 3		→ 🗎 87
Value 4 display	]	→ 🗎 87

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength*</li> <li>Signal to noise ratio*</li> <li>Turbulence*</li> <li>Acceptance rate*</li> <li>Temperature*</li> <li>Density*</li> <li>Electronics temperature</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Current output 1</li> </ul>	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist, see <b>Value 1</b> <b>display</b> parameter	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist, see <b>Value 1</b> <b>display</b> parameter	-
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist, see <b>Value 1</b> <b>display</b> parameter	-

\* Visibility depends on order options or device settings

## 10.4.9 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

#### Structure of the wizard



🖻 24 "Low flow cutoff" wizard in the "Setup" menu

#### Navigation

"Setup" menu  $\rightarrow$  Low flow cut off


► Low flow cut off		
Assign process variable	) → 🗎 88	
On value low flow cutoff	) → 🗎 88	
Off value low flow cutoff	] → 🗎 88	

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	<ul><li>Off</li><li>Volume flow</li><li>Mass flow</li><li>Flow velocity</li></ul>	Flow velocity
On value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \textcircled{B} 88$ ).	Enter on value for low flow cut off.	Positive floating- point number	0.3 m/s
Off value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \blacksquare$ 88).		0 to 100.0 %	_

## **10.5** Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup

► Advanced setup	
Enter access code	→ 🗎 90
► Sensor adjustment	→ 🗎 90
► Totalizer 1 to n	→ 🗎 90
► Display	→ 🗎 92



## 10.5.1 Using the parameter to enter the access code

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup

#### Parameter overview with brief description

Parameter	Description	User entry
Enter access code	1 1	Max. 16-digit character string comprising numbers, letters and special characters

## 10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Sensor adjustment

► Sensor adjustment		
Installation direction	m	→ 🗎 90

#### Parameter overview with brief description

Parameter	Description	Selection
Installation direction	Select sign of flow direction.	<ul><li>Forward flow</li><li>Reverse flow</li></ul>

## 10.5.3 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable	→ 🗎 91
Unit totalizer 1 to n	→ 🗎 91

Totalizer operation mode	→ 🗎 91
Failure mode	→ 🗎 91

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li></ul>	Volume flow
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter (→ ● 91) of the Totalizer 1 to n submenu.	Select the unit for the process variable of the totalizer.	<pre>g* kg kg t oz STon* cm<sup>3</sup>* dm<sup>3</sup>* ml* nl* nl* nl* nl* nl* nl* nl* nl* nl* n</pre>	Country-specific: • m <sup>3</sup> • ft <sup>3</sup>
Totalizer operation mode	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \boxdot 91$ ) of the <b>Totalizer 1 to n</b> submenu.	Select totalizer calculation mode.	<ul><li>Net flow total</li><li>Forward flow total</li><li>Reverse flow total</li></ul>	Net flow total
Failure mode	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \square$ 91) of the <b>Totalizer 1 to n</b> submenu.	Select totalizer behavior in the event of a device alarm.	<ul><li>Stop</li><li>Actual value</li><li>Last valid value</li></ul>	Stop

\* Visibility depends on order options or device settings

## 10.5.4 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Display

► Display		
	Format display	→ 🖺 93
	Value 1 display	→ 🗎 93
	0% bargraph value 1	→ 🗎 93
	100% bargraph value 1	→ 🗎 93
	Decimal places 1	→ 🗎 93
	Value 2 display	→ 🗎 93
	Decimal places 2	→ 🗎 93
	Value 3 display	→ 🖺 93
	0% bargraph value 3	→ 🖺 93
	100% bargraph value 3	→ 🖺 93
	Decimal places 3	→ 🗎 93
	Value 4 display	→ 🗎 93
	Decimal places 4	→ 🖺 94
	Display language	→ 🖺 94
	Display interval	→ 🖺 94
	Display damping	→ 🗎 94
	Header	→ 🗎 94
	Header text	→ 🗎 94
	Separator	→ 🗎 94
	Backlight	→ 🖺 94

#### Parameter Prerequisite Description Selection / User Factory setting entry Format display A local display is provided. Select how measured values 1 value, max. size 1 value, max. size 1 bargraph + 1 are shown on the display. value 2 values 1 value large + 2 values 4 values Select the measured value that Volume flow Volume flow Value 1 display A local display is provided. is shown on the local display. Mass flow Sound velocity Flow velocity Signal strength<sup>\*</sup> Signal to noise ratio Turbulence<sup>\*</sup> Acceptance rate<sup>\*</sup> Temperature Density Electronics temperature Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 0% bargraph value 1 A local display is provided. Enter 0% value for bar graph Signed floating-point Country-specific display. number Enter 100% value for bar 100% bargraph value 1 A local display is provided. Signed floating-point Depends on country graph display. number and nominal diameter Decimal places 1 A measured value is defined in Select the number of decimal • X x.xx the Value 1 display places for the display value. • X.X parameter. x.xx x.xxx x.xxxx Value 2 display A local display is provided. Select the measured value that Picklist, see Value 1 is shown on the local display. display parameter Decimal places 2 A measured value is specified Select the number of decimal • X in the Value 2 display places for the display value. • x.x parameter. x.xx x.xxx x.xxxx Value 3 display A local display is provided. Select the measured value that Picklist, see Value 1 is shown on the local display. display parameter 0% bargraph value 3 A selection was made in the Enter 0% value for bar graph Signed floating-point Country-specific Value 3 display parameter. display. number 100% bargraph value 3 Enter 100% value for bar A selection was made in the Signed floating-point Value 3 display parameter. graph display. number Decimal places 3 A measured value is specified Select the number of decimal • X in the Value 3 display places for the display value. • x.x parameter. x.xx x.xxx x.xxxx Value 4 display A local display is provided. Select the measured value that Picklist, see Value 1 is shown on the local display. display parameter

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Decimal places 4	A measured value is specified in the <b>Value 4 display</b> parameter.	Select the number of decimal places for the display value.	<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	-
Display language	A local display is provided.	Set display language.	<ul> <li>English</li> <li>Deutsch</li> <li>Français</li> <li>Español</li> <li>Italiano</li> <li>Nederlands</li> <li>Portuguesa</li> <li>Polski</li> <li>pycский язык (Russian)</li> <li>Svenska</li> <li>Türkçe</li> <li>中文 (Chinese)</li> <li>日本語 (Japanese)</li> <li>한국어 (Korean)</li> <li>Bahasa Indonesia</li> <li>tiếng Việt (Vietnamese)</li> <li>čeština (Czech)</li> </ul>	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	-
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	-
Header	A local display is provided.	Select header contents on local display.	<ul><li> Device tag</li><li> Free text</li></ul>	-
Header text	In the <b>Header</b> parameter, the <b>Free text</b> option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	-
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	<ul> <li>. (point)</li> <li>, (comma)</li> </ul>	. (point)
Backlight	A local display is provided.	Switch the local display backlight on and off.	<ul><li>Disable</li><li>Enable</li></ul>	-

\* Visibility depends on order options or device settings

## 10.5.5 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  WLAN settings

► WLAN settings	
WLAN	) → 🗎 95
WLAN mode	] → 🗎 95

SSID name		→ 🗎 95
Network security	]	→ 🖺 95
Security identification	]	→ 🖺 95
User name	]	→ 🗎 95
WLAN password	]	→ 🗎 95
WLAN IP address	]	→ 🗎 95
WLAN MAC address	]	→ 🗎 96
WLAN passphrase	]	→ 🗎 96
Assign SSID name	]	→ 🖺 96
SSID name	]	→ 🖺 96
Connection state	]	→ 🖺 96
Received signal strength		→ 🖺 96

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN	-	Switch WLAN on and off.	<ul><li>Disable</li><li>Enable</li></ul>	-
WLAN mode	-	Select WLAN mode.	WLAN access point	-
SSID name	The client is activated.	Enter the user-defined SSID name (max. 32 characters).	-	-
Network security	-	Select the security type of the WLAN network.	<ul> <li>Unsecured</li> <li>WPA2-PSK</li> <li>EAP-PEAP with MSCHAPv2*</li> <li>EAP-PEAP MSCHAPv2 no server authentic.*</li> <li>EAP-TLS*</li> </ul>	-
Security identification	-	Select security settings and download these settings via menu Data management > Security > WLAN.	<ul> <li>Trusted issuer certificate</li> <li>Device certificate</li> <li>Device private key</li> </ul>	-
User name	-	Enter user name.	-	-
WLAN password	-	Enter WLAN password.	-	-
WLAN IP address	-	Enter IP address of the WLAN interface of the device.	4 octet: 0 to 255 (in the particular octet)	-

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN MAC address	-	Enter MAC address of the WLAN interface of the device.	Unique 12-digit character string comprising letters and numbers	Each measuring device is given an individual address.
WLAN passphrase	The <b>WPA2-PSK</b> option is selected in the <b>Security type</b> parameter.	Enter the network key (8 to 32 characters).  The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user- defined name.	<ul><li>Device tag</li><li>User-defined</li></ul>	-
SSID name	<ul> <li>The User-defined option is selected in the Assign SSID name parameter.</li> <li>The WLAN access point option is selected in the WLAN mode parameter.</li> </ul>	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Prosonic_Flow_4 00_A802000)
Connection state	-	Displays the connection status.	<ul><li>Connected</li><li>Not connected</li></ul>	-
Received signal strength	-	Shows the received signal strength.	<ul><li>Low</li><li>Medium</li><li>High</li></ul>	_
Apply changes	-	Use changed WLAN settings.	<ul><li>Cancel</li><li>Ok</li></ul>	-

\* Visibility depends on order options or device settings

#### 10.5.6 Performing Heartbeat basic setup

**Heartbeat setup** submenu guides the user systematically through all the parameters that can be used for the Heartbeat basic setup.

The wizard only appears if the device has the Heartbeat Verification +Monitoring application package.

#### Navigation

 $\texttt{"Setup"} \texttt{menu} \rightarrow \texttt{Advanced setup} \rightarrow \texttt{Heartbeat setup}$ 

► Heartbeat setup	
► Heartbeat base settings	→ 🗎 97

#### "Heartbeat base settings" submenu

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Heartbeat setup  $\rightarrow$  Heartbeat base settings

► Heartbeat base settings	
Plant operator	) → 🗎 97
Location	) → 🗎 97

#### Parameter overview with brief description

Parameter	Description	User entry
Plant operator	1 1	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)
Location		Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

## 10.5.7 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration

► Administration	
► Define access code	→ 🗎 97
► Reset access code	→ 🗎 98
Device reset	→ 🗎 98

#### Using the parameter to define the access code

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Define access code

► Define access code		
Define access code		→ 🗎 98
Confirm access code	]	→ 🗎 98

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the entered access code.	Max. 16-digit character string comprising numbers, letters and special characters

#### Using the parameter to reset the access code

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Reset access code

► Reset access code	
Operating time	→ 🗎 98
Reset access code	→ 🗎 98

#### Parameter overview with brief description

Parameter	Description	User interface / User entry
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Reset access code	Reset access code to factory settings. For a reset code, contact your Endress+Hauser service organization.	Character string comprising numbers, letters and special characters
	<ul><li>The reset code can only be entered via:</li><li>Web browser</li><li>DeviceCare, FieldCare (via CDI-RJ45 service interface)</li><li>Fieldbus</li></ul>	

#### Using the parameter to reset the device

#### Navigation

 $"Setup" menu \rightarrow Advanced setup \rightarrow Administration$ 

#### Parameter overview with brief description

Parameter	Description	Selection
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul> <li>Cancel</li> <li>To delivery settings</li> <li>Restart device</li> <li>Restore S-DAT backup *</li> </ul>

\* Visibility depends on order options or device settings

## 10.6 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

- The parameters displayed depend on:
  - The selected device order
  - The set operating mode of the pulse/frequency/switch outputs

#### Navigation

"Diagnostics" menu → Simulation

► Simulation			
	Assign simulation process variable		→ 🖺 100
	Process variable value		→ 🗎 100
	Status input simulation 1		→ 🖺 100
	Input signal level 1	]	→ 🗎 100
	Current output 1 simulation		→ 🗎 100
	Current output value		→ 🗎 100
	Frequency output 1 to n simulation		→ 🗎 100
	Frequency output 1 to n value		→ 🗎 100
	Pulse output simulation 1 to n		→ 🗎 100
	Pulse value 1 to n		→ 🗎 100
	Switch output simulation 1 to n		→ 🗎 100
	Switch state 1 to n		→ 🗎 100
	Device alarm simulation		→ 🗎 100
		]	
	Diagnostic event category	]	→ 🗎 100
	Diagnostic event simulation		→ 🗎 100

Parameter	Prerequisite	Description	Selection / User entry
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Temperature*</li> <li>Density*</li> </ul>
Process variable value	A process variable is selected in the <b>Assign simulation process variable</b> parameter ( $\rightarrow \cong 100$ ).	Enter the simulation value for the selected process variable.	Depends on the process variable selected
Status input simulation 1	For the following order code: "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"	Switch simulation of the status input on and off.	<ul><li>Off</li><li>On</li></ul>
Input signal level 1	In the <b>Status input simulation</b> parameter, the <b>On</b> option is selected.	Select the signal level for the simulation of the status input.	<ul><li>High</li><li>Low</li></ul>
Current output 1 simulation	-	Switch the simulation of the current output on and off.	<ul><li>Off</li><li>On</li></ul>
Current output value	In the <b>Current output simulation</b> parameter, the <b>On</b> option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA
Frequency output 1 to n simulation	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Switch the simulation of the frequency output on and off.	<ul><li>Off</li><li>On</li></ul>
Frequency output 1 to n value	ncy output 1 to n value In the <b>Frequency simulation 1 to n</b> parameter, the <b>On</b> option is selected.		0.0 to 12 500.0 Hz
Pulse output simulation 1 to n	ulse output simulation 1 to n In the <b>Operating mode</b> parameter, the <b>Pulse</b> option is selected. Set and switch off the simulation.		<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>
-		Enter the number of pulses for simulation.	0 to 65 535
Switch output simulation 1 to n	In the <b>Operating mode</b> parameter, the <b>Switch</b> option is selected.	Switch the simulation of the switch output on and off.	<ul><li>Off</li><li>On</li></ul>
Switch state 1 to n –		Select the status of the status output for the simulation.	<ul><li> Open</li><li> Closed</li></ul>
Device alarm simulation	vice alarm simulation -		<ul><li>Off</li><li>On</li></ul>
Diagnostic event category –		Select a diagnostic event category.	<ul><li>Sensor</li><li>Electronics</li><li>Configuration</li><li>Process</li></ul>
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	<ul> <li>Off</li> <li>Diagnostic event picklist (depends on the category selected)</li> </ul>

\* Visibility depends on order options or device settings

## **10.7** Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code for the local display and Web browser
- Write protection via write protection switch
- Write protection via keypad lock

#### 10.7.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.

#### Defining the access code via local display

**1**. Navigate to the **Define access code** parameter ( $\rightarrow \square 98$ ).

- 2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the to confirm the code.
  - ← The 🖻-symbol appears in front of all write-protected parameters.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

• If parameter write protection is activated via an access code, it can also only be deactivated via this access code  $\rightarrow \cong 55$ .

The user role with which the user is currently logged on via the local display
 → ● 55 is indicated by the Access status display parameter. Navigation path:
 Operation → Access status display

#### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.

	Parameters for configuring the local display	Parameters for configuring the totalizer
	$\downarrow$	$\downarrow$
Language	Format display	Control Totalizer
	Contrast display	Preset value
	Display interval	Reset all totalizers

#### Defining the access code via the Web browser

- 1. Navigate to the **Define access code** parameter ( $\rightarrow \square 98$ ).
- 2. Define a max. 16-digit numeric code as an access code.

3. Enter the access code again in the to confirm the code.

└ The Web browser switches to the login page.

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


- If parameter write protection is activated via an access code, it can also only be deactivated via this access code  $\rightarrow \cong 55$ .
  - The user role with which the user is currently logged on via Web browser is indicated by the Access status tooling parameter. Navigation path: Operation → Access status tooling

## 10.7.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via service interface (CDI-RJ45)
- Via HART protocol



1. Loosen the 4 fixing screws on the housing cover and open the housing cover.

- 2. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables the hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables the hardware write protection.
  - If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter . In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled: No option is displayed in the **Locking status** parameter . On the local display, the 🖻 symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

## 3. **A WARNING**

**Excessive tightening torque applied to the fixing screws!** Risk of damaging the plastic transmitter.

• Tighten the fixing screws as per the tightening torque .

Reverse the removal procedure to reassemble the transmitter.

# 11 Operation

## 11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation  $\rightarrow$  Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the <b>Access status display</b> parameter applies $\rightarrow \square$ 55. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \bigoplus 102$ .
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

## 11.2 Adjusting the operating language

Petailed information:

- To configure the operating language  $\rightarrow$   $\cong$  71
- For information on the operating languages supported by the measuring device  $\rightarrow \ \textcircled{} 148$

## 11.3 Configuring the display

Detailed information:

- On the basic settings for the local display  $\rightarrow \cong 85$
- On the advanced settings for the local display  $\rightarrow$   $\cong$  92

## 11.4 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values

► Measured values	
► Process variables	→ 🗎 105
► System values	→ 🗎 105
► Input values	→ 🗎 106
► Output values	→
► Totalizer	→ 🗎 108

## 11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Process variables

► Process variables	
Volume flow	→ 🗎 105
Mass flow	→ 🗎 105
Sound velocity	) → 🗎 105
Density	) → 🗎 105
Flow velocity	→ 🗎 105
Temperature	→ 🗎 105

#### Parameter overview with brief description


Parameter Description		User interface
Volume flow	Displays the volume flow that is currently measured.	Signed floating-point number
	Dependency The unit is taken from: <b>Volume flow unit</b> parameter ( $\rightarrow \textcircled{B} 74$ )	
Mass flow	Displays the mass flow that is currently calculated.	Signed floating-point number
	Dependency The unit is taken from the <b>Mass flow unit</b> parameter $(\rightarrow \square 74)$ .	
Sound velocity	Displays the sound velocity that is currently measured.	Signed floating-point number
	<i>Dependency</i> The unit is taken from the <b>Velocity unit</b> parameter.	
Density	Displays the density that is currently calculated.	Signed floating-point number
	<i>Dependency</i> The unit is taken from the <b>Density unit</b> parameter.	
Flow velocity	Displays the average flow velocity that is currently calculated.	Signed floating-point number
	<i>Dependency</i> The unit is taken from the <b>Velocity unit</b> parameter.	
Temperature	Displays the temperature that is currently measured.	Signed floating-point number
	<i>Dependency</i> The unit is taken from the <b>Temperature unit</b> parameter.	

## 11.4.2 System values

The **System values** submenu contains all the parameters needed to display the current measured values for every system value.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  System values



## Parameter overview with brief description

Parameter	Description	User interface
Signal strength	Displays the current signal strength (0 to 100 dB).Signed floating-point isAssessment of the signal strength:< 10 dB: bad	
Acceptance rate	Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted.	0 to 100 %
Signal to noise ratio	Displays the current signal to noise ratio (0 to 100 dB). Assessment of the signal to noise ratio: • < 20 dB: bad • > 50 dB: very good	Signed floating-point number
Turbulence	Displays the current turbulence.	Signed floating-point number

#### 11.4.3 Input values

The **Input values** submenu guides you systematically to the individual input values.

The submenu appears only if the device was ordered with a status input  $\rightarrow \cong 35$ .

#### Navigation


"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values

► Input values			
	Value status input		→ 🗎 107

Parameter	Prerequisite	Description	User interface
Value status input	<ul> <li>For the following order code:</li> <li>"Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"</li> <li>"Output; input", option J "4-20mA HART, certified pulse output, switch output; status input"</li> </ul>	Shows the current input signal level.	<ul><li>High</li><li>Low</li></ul>

## 11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.



- The selected device order
- The set operating mode of the pulse/frequency/switch outputs

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values

► Output values	
Output current 1	→ 🗎 107
Measured current 1	) → 🗎 107
Pulse output 1	] → 🗎 107
Output frequency 1	] → 🗎 108
Switch state 1	] → 🗎 108
Output frequency 2	) → 🗎 108
Pulse output 2	) → 🗎 107
Switch state 2	] → 🗎 108

Parameter	Prerequisite	Description	User interface
Output current	-	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	-	Displays the current value currently measured for the current output.	0 to 30 mA
Pulse output 1 to n	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number


Parameter	Prerequisite	Description	User interface
Output frequency 1 to n	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Switch state 1 to n	In the <b>Operating mode</b> parameter, the <b>Switch</b> option is selected.	Displays the current switch output status.	<ul><li> Open</li><li> Closed</li></ul>

## 11.4.5 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

#### Navigation

"Diagnostics" menu → Measured values → Totalizer



#### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	<ul> <li>One of the following options is selected in the Assign process variable parameter (→ ● 91) of the Totalizer</li> <li>1 to n submenu:</li> <li>Volume flow</li> <li>Mass flow</li> </ul>	Displays the current totalizer counter reading.	Signed floating-point number
Totalizer overflow 1 to n	<ul> <li>One of the following options is selected in the Assign process variable parameter (→ ● 91) of the Totalizer</li> <li>1 to n submenu:</li> <li>Volume flow</li> <li>Mass flow</li> </ul>	Displays the current totalizer overflow.	Integer with sign

# 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (→ 
  Participation 71)
- Advanced settings using the **Advanced setup** submenu ( $\rightarrow \square 89$ )

## **11.6** Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

#### Navigation

"Operation" menu  $\rightarrow$  Totalizer handling

► Totalizer handling	
Control Totalizer 1 to n	) → 🗎 109
Preset value 1 to n	→ 🗎 109
Reset all totalizers	→ 🗎 109

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow {}$ 91) of the <b>Totalizer 1 to n</b> submenu.	Control totalizer value.	<ul> <li>Totalize</li> <li>Reset + hold</li> <li>Preset + hold</li> <li>Reset + totalize</li> <li>Preset + totalize</li> <li>Hold</li> </ul>	-
Preset value 1 to n	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \cong 91$ ) of the <b>Totalizer 1 to n</b> submenu.	<ul> <li>Specify start value for totalizer.</li> <li>Dependency</li> <li>The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ ● 91).</li> </ul>	Signed floating-point number	Country-specific: • 0 m <sup>3</sup> • 0 ft <sup>3</sup>
Reset all totalizers	-	Reset all totalizers to 0 and start.	<ul><li>Cancel</li><li>Reset + totalize</li></ul>	-

### 11.6.1 Function scope of the "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value</b> parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value from the <b>Preset value</b> parameter and the totaling process is restarted.

## 11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

## 11.7 Show data logging


The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

🚹 Data logging is also available via:

- Plant Asset Management Tool FieldCare  $\rightarrow \cong 64$ .
- Web browser

### Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Data logging

► Data logging	
Assign channel 1	) → 🗎 111
Assign channel 2	→ 🗎 111
Assign channel 3	→ 🗎 111
Assign channel 4	→ 🗎 111
Logging interval	→ 🗎 111
Clear logging data	→ 🗎 111
Data logging	→ 🗎 111
Logging delay	) → 🗎 111
Data logging control	) → 🗎 111

Data logging status	→ 🗎 112
Entire logging duration	→ 🖺 112

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign channel 1	The <b>Extended HistoROM</b> application package is available.	Assign process variable to logging channel.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Signal strength *</li> <li>Signal to noise ratio *</li> <li>Turbulence *</li> <li>Acceptance rate *</li> <li>Temperature *</li> <li>Density *</li> <li>Electronics temperature</li> <li>Current output 1</li> </ul>
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the <b>Assign channel 1</b> parameter ( $\rightarrow \square$ 111)
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the <b>Assign channel 1</b> parameter ( $\rightarrow \square$ 111)
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the <b>Assign channel 1</b> parameter (→ 🗎 111)
Logging interval	The <b>Extended HistoROM</b> application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3 600.0 s
Clear logging data	The <b>Extended HistoROM</b> application package is available.	Clear the entire logging data.	<ul><li>Cancel</li><li>Clear data</li></ul>
Data logging	-	Select the data logging method.	<ul><li>Overwriting</li><li>Not overwriting</li></ul>
Logging delay	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Enter the time delay for measured value logging.	0 to 999 h
Data logging control	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Start and stop measured value logging.	<ul><li>None</li><li>Delete + start</li><li>Stop</li></ul>

Parameter	Prerequisite	Description	Selection / User entry / User interface
Data logging status	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the measured value logging status.	<ul><li>Done</li><li>Delay active</li><li>Active</li><li>Stopped</li></ul>
Entire logging duration	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the total logging duration.	Positive floating-point number

\* Visibility depends on order options or device settings

# 12 Diagnostics and troubleshooting

## 12.1 General troubleshooting

### For local display

Error	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $\rightarrow \textcircled{B} 38.$
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	Main electronics module is defective.	Order spare part → 🗎 133.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	<ol> <li>Check the connection of the electrode cable and correct if necessary.</li> <li>Check the connection of the coil current cable and correct if necessary.</li> </ol>
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul> <li>Set the display brighter by simultaneously pressing ± + E.</li> <li>Set the display darker by simultaneously pressing □ + E.</li> </ul>
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🗎 133.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 122$
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press 2 s $\Box$ + $\oplus$ ("home position"). 2. Press $E$ . 3. Set the desired language in the <b>Display language</b> parameter ( $\rightarrow \cong$ 94).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul> <li>Check the cable and the connector between the main electronics module and display module.</li> <li>Order spare part →</li></ul>

### For output signals

Error	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🗎 133.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parametrization errors	Check parameterization and correct it.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol> <li>Check and correct parameter configuration.</li> <li>Observe limit values specified in the "Technical Data".</li> </ol>

#### For access

Error	Possible causes	Remedial action
No write access to parameters	Hardware write protection enabled	Set the write protection switch on main electronics module to the <b>OFF</b> position $\rightarrow \bigoplus 102$ .
No write access to parameters	Current user role has limited access authorization	1. Check user role $\rightarrow \boxdot 55$ . 2. Enter correct customer-specific access code $\rightarrow \boxdot 55$ .
No connection via HART protocol	Communication resistor missing or incorrectly installed.	Install the communication resistor (250 $\Omega$ ) correctly. Observe the maximum load $\rightarrow \cong$ 139.
No connection via HART protocol	Commubox Connected incorrectly Configured incorrectly Drivers not installed correctly USB interface on computer configured incorrectly	Observe the documentation for the Commubox. FXA195 HART: Document "Technical Information" TI00404F
No connection to Web server	Web server disabled	Via the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled and enable it if necessary→ 🗎 61.
	Incorrect settings for the Ethernet interface of the computer	<ol> <li>Check the properties of the Internet protocol (TCP/IP)</li> <li>⇒          <sup>(1)</sup>→          <sup>(2)</sup>→          <sup></sup></li></ol>
No connection to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 → 🗎 57→ 🗎 57
No connection to Web server	Incorrect WLAN access data	<ul> <li>Check WLAN network status.</li> <li>Log on to the device again using WLAN access data.</li> <li>Check that WLAN is enabled on the measuring device and operating device .</li> </ul>
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	<ul> <li>Check if WLAN reception is present: LED on display module is lit blue</li> <li>Check if WLAN connection is enabled: LED on display module flashes blue</li> <li>Switch on instrument function.</li> </ul>
Network connection not present or unstable	WLAN network is weak.	Operating device is outside of reception range: Check network status on operating device.
	Parallel WLAN and Ethernet communication	<ul> <li>Check network settings.</li> <li>Temporarily enable only the WLAN as an interface.</li> </ul>
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	<ol> <li>Check cable connection and power supply.</li> <li>Refresh the Web browser and restart if necessary.</li> </ol>
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	<ol> <li>Use the correct Web browser version →</li></ol>

Error	Possible causes	Remedial action
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	<ul><li> JavaScript not enabled</li><li> JavaScript cannot be enabled</li></ul>	1. Enable JavaScript. 2. Enter http://192.168.1.212/ basic.html as the IP address.
Operation with FieldCare or DeviceCare via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.

## 12.2 Diagnostic information via light emitting diodes

### 12.2.1 Transmitter


Different LEDs in the transmitter provide information on the device status.

LED	Color	Meaning	
Supply voltage	Off	Supply voltage is off or too low	
	Green	Supply voltage is ok	
Link/Activity	Orange	Link available but no activity	
	Flashing orange	Activity present	
Communication	Flashing white	HART communication is active.	
Alarm	Green	Measuring device is ok	
	Flashing green	Measuring device not configured	
	Off	Firmware error	
	Red	Main error	
	Flashing red	Error	
	Flashing red/green	Start measuring device	

## 12.3 Diagnostic information on local display

### 12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.


Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter  $\rightarrow \square 125$
- Via submenus  $\rightarrow \square$  126

#### Status signals

•

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).



= Maintenance Required


Symbol	Meaning
F	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
С	<b>Function check</b> The device is in service mode (e.g. during a simulation).
S	Out of specification         The device is operated:         • Outside its technical specification limits (e.g. outside the process temperature range)         • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
М	Maintenance required Maintenance is required. The measured value remains valid.

#### Diagnostic behavior

Symbol	Meaning
۲	<ul> <li>Alarm</li> <li>Measurement is interrupted.</li> <li>Signal outputs and totalizers assume the defined alarm condition.</li> <li>A diagnostic message is generated.</li> <li>The background lighting changes to red.</li> </ul>
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.


#### **Diagnostic information**

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



#### **Operating elements**

Кеу	Meaning
+	Plus key In a menu, submenu Opens the message about remedy information.
E	Enter key In a menu, submenu Opens the operating menu.



#### 12.3.2 Calling up remedial measures

- Diagnostic information
- 2 Short text
- 3 Service ID
- Diagnostic behavior with diagnostic code 4 5 Operation time of occurrence
- 6 Remedial measures
- 1. The user is in the diagnostic message.

Press 🛨 (① symbol).

- └ The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with  $\pm$  or  $\Box$  and press  $\mathbb{E}$ .
  - └ The message about the remedial measures opens.
- 3. Press  $\Box$  +  $\pm$  simultaneously.
  - └ The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the Diagnostic list submenu or Previous diagnostics parameter.

- 1. Press E.
  - └ The message for the remedial measures for the selected diagnostic event opens.
- **2.** Press  $\Box$  +  $\pm$  simultaneously.
  - └ The message for the remedial measures closes.

#### 12.4 Diagnostic information in the Web browser

#### 12.4.1 **Diagnostic options**

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostics information  $\rightarrow \square 117$
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter  $\rightarrow \square 125$
- Via submenu → 
   <sup>™</sup>
   <sup>™</sup>
   126

#### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
$\otimes$	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
V	<b>Function check</b> The device is in service mode (e.g. during a simulation).
	Out of specification         The device is operated:         • Outside its technical specification limits (e.g. outside the process temperature range)         • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

### 12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

## 12.5 Diagnostic information in FieldCare or DeviceCare

### 12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

Device tag Pro Device name	Status signal Out of specification (S)	Volume flow 502.6548 cm <sup>3</sup>	Mass flow /s 502.6548 g/s	Endress+Hauser 대
Pro	Locking status 🔂 Unlocked			
☆ > Diagnostics				
Diagnostics	Actual diagnostics S441 Current output	1 &	·	
Diagnostic list	Timestamp		Actual di	agnostics
Event logbook	154d21h21m12s	£		the currently active diagnostic
Custody transfer logbook	Previous diagnostics			s more than one pending diagnostic
Device information		£		e message for the diagnostic event highest priority is displayed.
Measured values	Timestamp		S441 Cur	rrent output 1
Data logging	Od00h00m00s Operating time from	<u>ل</u>		process 2. Check current output (Service ID:153)
Heartbeat Technology	0d00h41m31s	⊕		


- 1 Status area with status signal  $\rightarrow \square 116$
- 2 Diagnostics information  $\rightarrow \implies 117$
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter  $\rightarrow \square 125$
- Via submenu → 
   <sup>™</sup>
   <sup>™</sup>
   126

#### **Diagnostic information**

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### 12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
  - Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
   Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.


- 2. On the right in the working area, mouse over the parameter.
  - └ A tool tip with remedy information for the diagnostic event appears.

## 12.6 Adapting the diagnostic information

### 12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert  $\rightarrow$  System  $\rightarrow$  Diagnostic handling  $\rightarrow$  Diagnostic behavior



🖻 26 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the <b>Event logbook</b> submenu ( <b>Event list</b> submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

### 12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic** event category submenu.

Expert  $\rightarrow$  Communication  $\rightarrow$  Diagnostic event category

#### Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning
A0013956	Failure A device error is present. The measured value is no longer valid.
<b>C</b>	<b>Function check</b> The device is in service mode (e.g. during a simulation).
<b>S</b>	<ul> <li>Out of specification</li> <li>The device is being operated:</li> <li>Outside its technical specification limits (e.g. outside the process temperature range)</li> <li>Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)</li> </ul>
A0013957	Maintenance required Maintenance is required. The measured value is still valid.
N	Has no effect on the condensed status.
A0023076	

## 12.7 Overview of diagnostic information

The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information  $\rightarrow \square 121$ 

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]	
Diagnostic of	sensor				
019	Device initialization active	Device initialization in progress, please wait	S	Warning <sup>1)</sup>	
082	Data storage	<ol> <li>Check module connections</li> <li>Change electronic modules</li> </ol>	F	Alarm	
083	Memory content	<ol> <li>Restart device</li> <li>Restore HistoROM S-DAT backup ('Device reset' parameter)</li> <li>Replace HistoROM S-DAT</li> </ol>	F	Alarm	
104	Sensor signal path 1 to n	<ol> <li>Check process conditions</li> <li>Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on)</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm	
105	Downstream transducer path 1 to n defective	<ol> <li>Check connection to the downstream transducer</li> <li>Replace downstream transducer</li> </ol>	F	Alarm	
106	Upstream transducer path 1 to n defective	<ol> <li>Check connection to the upstream transducer</li> <li>Replace upstream transducer</li> </ol>	F	Alarm	
160	Signal path switched off	Contact service	М	Warning <sup>1)</sup>	
Diagnostic of	Diagnostic of electronic				
201	Device failure	Restart device	F	Alarm	

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
242	Software incompatible	<ol> <li>Check software</li> <li>Flash or change main electronic module</li> </ol>	F	Alarm
252	Modules incompatible	<ol> <li>Check electronic modules</li> <li>Check if correct modules are available (e.g. NEx, Ex)</li> <li>Replace electronic modules</li> </ol>	F	Alarm
252	Modules incompatible	<ol> <li>Check if correct electronic module is plugged</li> <li>Replace electronic module</li> </ol>	F	Alarm
261	Electronic modules	<ol> <li>Restart device</li> <li>Check electronic modules</li> <li>Change I/O module or main electronics</li> </ol>	F	Alarm
262	Sensor electronics connection faulty	<ol> <li>Check/replace connection cable between sensor electronic module (ISEM) and main electr.</li> <li>Check/replace module cartridge, ISEM, main electr.</li> </ol>	F	Alarm
270	Main electronics failure	Change main electronic module	F	Alarm
271	Main electronics failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronics failure	Restart device	F	Alarm
273	Main electronics failure	Change electronics	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	1. Restart device 2. Change I/O module	F	Alarm
281	Electronic initialization	Firmware update active, please wait!	F	Alarm
283	Memory content	Reset device	F	Alarm
283	Memory content	Restart device	F	Alarm
302	Device verification in progress	Device verification active, please wait.	С	Warning
311	Electronic failure	<ol> <li>Do not reset device</li> <li>Contact service</li> </ol>	М	Warning
372	Sensor electronics (ISEM) faulty	<ol> <li>Restart device</li> <li>Check if failure recurs</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm
373	Sensor electronics (ISEM) faulty	Transfer data or reset device	F	Alarm
375	I/O- communication failed	<ol> <li>Restart device</li> <li>Check if failure recurs</li> <li>Replace module rack inclusive electronic modules</li> </ol>	F	Alarm
378	Supply voltage ISEM faulty	Check supply voltage to the ISEM	F	Alarm
382	Data storage	1. Insert T-DAT 2. Replace T-DAT	F	Alarm
383	Memory content	<ol> <li>Restart device</li> <li>Delete T-DAT via 'Reset device' parameter</li> <li>Replace T-DAT</li> </ol>	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
384	Transmitter circuit	<ol> <li>Restart device</li> <li>Check if failure recurs</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm
385	Amplifier circuit	<ol> <li>Restart device</li> <li>Check if failure recurs</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm
386	Time of flight	<ol> <li>Restart device</li> <li>Check if failure recurs</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm
387	HistoROM data faulty	Contact service organization	F	Alarm
Diagnostic of o	configuration	1	1	1
410	Data transfer	<ol> <li>Check connection</li> <li>Retry data transfer</li> </ol>	F	Alarm
412	Processing download	Download active, please wait	С	Warning
431	Trim 1	Carry out trim	С	Warning
437	Configuration incompatible	Restart device	F	Alarm
438	Dataset	<ol> <li>Check data set file</li> <li>Check device configuration</li> <li>Up- and download new configuration</li> </ol>	М	Warning
441	Current output	<ol> <li>Check process</li> <li>Check current output settings</li> </ol>	S	Warning <sup>1)</sup>
442	Frequency output 1 to n	<ol> <li>Check process</li> <li>Check frequency output settings</li> </ol>	S	Warning <sup>1)</sup>
443	Pulse output 1 to n	<ol> <li>Check process</li> <li>Check pulse output settings</li> </ol>	S	Warning <sup>1)</sup>
453	Flow override	Deactivate flow override	С	Warning
484	Failure mode simulation	Deactivate simulation	С	Alarm
485	Measured variable simulation	Deactivate simulation	С	Warning
491	Current output 1 simulation	Deactivate simulation	С	Warning
492	Simulation frequency output 1 to n	Deactivate simulation frequency output	С	Warning
493	Pulse output 1 to n simulation active	Deactivate pulse output simulation	С	Warning
494	Switch output simulation 1 to n	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation	Deactivate simulation	С	Warning
496	Status input simulation	Deactivate simulation status input	С	Warning
537	Configuration	<ol> <li>Check IP addresses in network</li> <li>Change IP address</li> </ol>	F	Warning
Diagnostic of J	process			
803	Current loop	1. Check wiring 2. Change I/O module	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
832	Electronics temperature too high	Reduce ambient temperature	S	Warning <sup>1)</sup>
833	Electronics temperature too low	Increase ambient temperature	S	Warning <sup>1)</sup>
840	Sensor range	Check flow velocity	S	Warning <sup>1)</sup>
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning <sup>1)</sup>
870	Measuring inaccuracy increased	<ol> <li>Check process conditions</li> <li>Increase flow velocity</li> </ol>	S	Warning <sup>1)</sup>
881	Sensor signal path 1 to n	<ol> <li>Check process conditions</li> <li>Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on)</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm
882	Input signal	<ol> <li>Check input configuration</li> <li>Check external device or process conditions</li> </ol>	F	Alarm
930	Sound velocity too high	<ol> <li>Check process conditions</li> <li>Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on)</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	S	Warning <sup>1)</sup>
931	Sound velocity too low	<ol> <li>Check process conditions</li> <li>Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on)</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	S	Warning <sup>1)</sup>
953	Asymmetry noise signal too high path 1 to n	<ol> <li>Check process conditions</li> <li>Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on)</li> <li>Replace sensor electronic module (ISEM)</li> </ol>	F	Alarm

1) Diagnostic behavior can be changed.

## 12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.


To call up the measures to rectify a diagnostic event:

- Via local display  $\rightarrow \square 118$
- Via web browser → 
   <sup>1</sup> 119
- Via "FieldCare" operating tool  $\rightarrow \implies 121$
- Via "DeviceCare" operating tool → 🗎 121

Other pending diagnostic events can be displayed in the **Diagnostic list** submenu  $\rightarrow \cong 126$ 

#### Navigation

"Diagnostics" menu



#### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics		Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

## 12.9 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

### Navigation path

 $\text{Diagnostics} \rightarrow \text{Diagnostic list}$ 

오 //Diagnose list
Diagnostics
SF273 Main electronic
Diagnostics 2
Diagnostics 3

■ 27 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display  $\rightarrow \cong 118$
- Via web browser  $\rightarrow \square 119$
- Via "FieldCare" operating tool  $\rightarrow \square$  121


### 12.10 Event logbook

### 12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

#### Navigation path

**Diagnostics** menu  $\rightarrow$  **Event logbook** submenu  $\rightarrow$  Event list



<sup>■ 28</sup> Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events  $\rightarrow$  🗎 122
- Information events  $\rightarrow \triangleq 128$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - ①: Occurrence of the event
- 🕞: End of the event
- Information event

 $\odot$ : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display  $\rightarrow \square 118$
- Via web browser  $\rightarrow \triangleq 119$
- Via "FieldCare" operating tool  $\rightarrow \implies 121$
- Via "DeviceCare" operating tool → 
  <sup>(1)</sup> 121

For filtering the displayed event messages → 
<sup>128</sup>

### 12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

### Navigation path

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Filter options

#### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

### 12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	HistoROM backup deleted
I1137	Electronics changed
I1151	History reset
I1155	Reset electronics temperature
I1156	Memory error trend
I1157	Memory error event list
I1256	Display: access status changed
I1278	I/O module restarted
I1327	Zero point adjust failed signal path
I1335	Firmware changed
I1361	Web server: login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1457	Measurement error verification failed
I1459	I/O module verification failed
I1461	Sensor verification failed
I1462	Sensor electronic module verific. failed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished

Info number	Info name
I1622	Calibration changed
I1624	All totalizers reset
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server: login successful
I1628	Display: login successful
I1629	CDI: login successful
I1631	Web server access changed
I1632	Display: login failed
I1633	CDI: login failed
I1634	Reset to factory settings
I1635	Reset to delivery settings
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1725	Sensor electronic module (ISEM) changed

## 12.11 Resetting the measuring device

Using the **Device reset** parameter ( $\rightarrow \square 98$ ) it is possible to reset the entire device configuration or some of the configuration to a defined state.

12.11.1	Function scope	of the "Device re	eset" parameter
---------	----------------	-------------------	-----------------

Options	Description	
Cancel	No action is executed and the user exits the parameter.	
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.	
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.	

## 12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

### Navigation

"Diagnostics" menu  $\rightarrow$  Device information

► Device information	
Device tag	→ 🗎 130
Serial number	→ 🗎 130

Firmware version	) → 🗎 130
Order code	) → 🗎 130
Extended order code 1	) → 🗎 130
Extended order code 2	) → 🗎 130
Extended order code 3	) → 🗎 131
ENP version	) → 🗎 131
Device revision	→ 🗎 131
Device ID	→ 🗎 131
Device type	→ 🗎 131
Manufacturer ID	) → 🗎 131

### Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	-
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name     Shows the name of the transmitter.     Max. 32 characters such as letters or numbers.       Image: The name can be found on the nameplate of the transmitter.     Image: The name can be found on the nameplate of the transmitter.		-	
Order code Shows the device order code. The order code can be found on nameplate of the sensor and transmitter in the "Order code" fi		Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-

Parameter	Description	User interface	Factory setting
Extended order code 3	Shows the 3rd part of the extended order code.	Character string	-
	The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.		
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	-
Device revision	Shows the device revision with which the device is registered with the HART Communication Foundation.	2-digit hexadecimal number	-
Device ID	Shows the device ID for identifying the device in a HART network.	6-digit hexadecimal number	-
Device type	Shows the device type with which the measuring device is registered with the HART Communication Foundation.	2-digit hexadecimal number	0x69 (for Prosonic Flow I 400)
Manufacturer ID	Shows the device's manufacturer ID registered with the HART Communication Foundation.	2-digit hexadecimal number	0x11 (for Endress+Hauser)

## 12.13 Firmware history

Rele dat		Firmwar e version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
12.20	021	01.00.00	Option <b>78</b>	Original firmware	Operating Instructions	BA02085D/06

It is possible to flash the firmware to the current version or the previous version using the service interface.

For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

• In the Download Area of the Endress+Hauser web site: www.endress.com  $\rightarrow$ Downloads

Specify the following details:

- Product root: e.g. 9I4B
  - The product root is the first part of the order code: see the nameplate on the device.
- Text search: Manufacturer's information
- Media type: Documentation Technical Documentation

## 13 Maintenance

### 13.1 Maintenance tasks

No special maintenance work is required.

### 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

## 13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment:  $\rightarrow \square 137 \rightarrow \square 135$ 

### 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

## 14 Repair

## 14.1 General information

### 14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

### 14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ► Document every repair and each conversion and enter them into the *W*@*M* life cycle management database and Netilion Analytics.

## 14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

P Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the Serial number parameter (→ 
   <sup>(⇒)</sup> 130) in the Device information submenu.

## 14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

## 14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the website for more information: http://www.endress.com/support/return-material

2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

## 14.5 Disposal

## X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.

### 14.5.1 Removing the measuring device

1. Switch off the device.

### **WARNING**

### Danger to persons from process conditions!

• Pay attention to high temperatures.

2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

### 14.5.2 Disposing of the measuring device

Observe the following notes during disposal:

- ► Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

## 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

## 15.1 Device-specific accessories

### 15.1.1 For the transmitter

Accessories	Description
Transmitter Prosonic Flow 400	Transmitter for replacement or storage. Use the order code to define the following specifications: • Approvals • Output / input • Display/operation • Housing • Software For details, see Installation Instructions EA00104D
Post mounting kit	Post mounting kit for transmitter.
External WLAN antenna	<ul> <li>External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area".</li> <li>The external WLAN antenna is not suitable for use in hygienic applications.</li> <li>Additional information regarding the WLAN interface → </li> <li>62.</li> <li>Order number: 71351317</li> <li>Installation Instructions EA01238D</li> </ul>
Sensor cable Proline 400 Sensor – transmitter	The sensor cable can be ordered directly with the measuring device (order code for "Cable") or as an accessory (order number DK9017). The following cable lengths are available: Temperature: -40 to +80 °C (-40 to +176 °F) • Option AA: 5 m (15 ft) • Option AB: 10 m (30 ft) • Option AC: 15 m (45 ft) • Option AD: 30 m (90 ft) • Possible cable length for a Proline 400 sensor cable: Max. 30 m (90 ft)

### 15.1.2 For the sensor

Accessories	Description
Sensor set (DK9018)	Sensor set 1 MHz (I-100)
Sensor holder set (DK9014)	Sensor holder set 1 MHz
Installation set (DK9016)	<ul> <li>Installation set, DN200-DN1800, 8"-72"</li> <li>Installation set, DN1800-DN4000, 72"-160"</li> </ul>
Conduit adapter set (DK9003)	<ul> <li>Without conduit adapter + sensor cable gland</li> <li>Conduit adapter M20x1.5 + sensor cable gland</li> <li>Conduit adapter NPT1/2" + sensor cable gland</li> <li>Conduit adapter G1/2" + sensor cable gland</li> </ul>

Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop. Technical Information TI405C/07
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.  Technical Information TI00429F Operating Instructions BA00371F
Wireless HART adapter SWA70	Is used for the wireless connection of field devices. The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity. Operating Instructions BA00061S
	Operating Instructions BA00061S
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices
	<ul> <li>Technical Information TI01297S</li> <li>Operating Instructions BA01778S</li> <li>Product page: www.endress.com/fxa42</li> </ul>
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver librar and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. • Technical Information TI01342S • Operating Instructions BA01709S • Product page: www.endress.com/smt70
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.
	<ul> <li>Technical Information TI01418S</li> <li>Operating Instructions BA01923S</li> <li>Product page: www.endress.com/smt77</li> </ul>

# 15.2 Communication-specific accessories

Accessory	Description
Applicator	<ul> <li>Software for selecting and sizing Endress+Hauser measuring devices:</li> <li>Choice of measuring devices with industrial requirements</li> <li>Calculation of all the necessary data for identifying the optimum flowmeter:</li> <li>e.g. nominal diameter, pressure loss, flow velocity and accuracy.</li> <li>Graphic illustration of the calculation results</li> <li>Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</li> <li>Applicator is available:</li> </ul>
	<ul> <li>Via the Internet: https://portal.endress.com/webapp/applicator</li> <li>As a downloadable DVD for local PC installation.</li> </ul>
W@M	W@M Life Cycle ManagementImproved productivity with information at your fingertips. Data relevant to aplant and its components is generated from the first stages of planning andduring the asset's complete life cycle.W@M Life Cycle Management is an open and flexible information platformwith online and on-site tools. Instant access for your staff to current, in-depthdata shortens your plant's engineering time, speeds up procurement processesand increases plant uptime.Combined with the right services, W@M Life Cycle Management boostsproductivity in every phase. For more information, see:www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Operating Instructions BA00027S and BA00059S
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices.

# 15.3 Service-specific accessories

## 15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.

## 16 Technical data

## 16.1 Application

The measuring device is only suitable for flow measurement of liquids.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

## 16.2 Function and system design

Measuring principle	Proline Prosonic Flow uses a measurement method based on the transit time difference.
Measuring system	The measuring system consists of a transmitter and one or two sensor sets. The transmitter and sensor sets are mounted in physically separate locations. They are interconnected by sensor cables.
	The sensors function as sound generators and sound receivers. The sensors in a sensor pair are always arranged opposite one another and send/receive the ultrasonic signals directly (1-traverse positioning) $\rightarrow \square 22$ .
	The transmitter serves to control the sensor sets, to prepare, process and evaluate the measuring signals, and to convert the signals to the desired output variable.
	Information on the structure of the device $\rightarrow \cong 13$

## 16.3 Input

Measured variable	Direct measured variables
	<ul> <li>Volume flow</li> </ul>
	<ul> <li>Flow velocity</li> </ul>
	<ul> <li>Sound velocity</li> </ul>
	Calculated measured variables
	Mass flow
Measuring range	v = 0 to 15 m/s (0 to 50 ft/s)
Operable flow range	Over 150 : 1
Input signal	External measured values
	Interfaces that allow externally measured variables (temperature, density) to be transmitted to the measuring device are optionally available for the device.
	HART protocol
	The measured values are written from the automation system to the measuring device via the HART protocol. The temperature and density measuring device must support the following protocol-specific functions: • HART protocol • Burst mode

#### Status input

Maximum input values	<ul> <li>DC 30 V</li> <li>6 mA</li> </ul>
Response time	Configurable: 5 to 200 ms
Input signal level	<ul> <li>Low signal (low): DC -3 to +5 V</li> <li>High signal (high): DC 12 to 30 V</li> </ul>
Assignable functions	<ul> <li>Off</li> <li>Reset totalizers 1-3 separately</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>

## 16.4 Output

Output signal

### **Current output**

Current output	Can be set as: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA HART • 0 to 20 mA
Maximum output values	<ul> <li>DC 24 V (no flow)</li> <li>22.5 mA</li> </ul>
Load	250 to 700 Ω
Resolution	0.38 µA
Damping	Adjustable: 0 to 999.9 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Electronic temperature</li> <li>The range of options increases if the measuring device has one or more application packages.</li> </ul>

### Pulse/frequency/switch output

Function	<ul> <li>With the order code for "Output; Input", option H: output 2 can be set as a pulse or frequency output</li> <li>With the order code for "Output; Input", option I: output 2 and 3 can be set as a pulse, frequency or switch output</li> </ul>
Version	Passive, open collector
Maximum input values	<ul> <li>DC 30 V</li> <li>250 mA</li> </ul>
Voltage drop	At 25 mA: ≤ DC 2 V
Pulse output	
Pulse width	Adjustable: 0.05 to 2 000 ms
Maximum pulse rate	10000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	<ul><li>Volume flow</li><li>Mass flow</li></ul>
Frequency output	
Output frequency	Adjustable: 0 to 12 500 Hz

Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Electronic temperature</li> </ul>
Switch output	
Switching behavior	Binary, conductive or non-conductive
Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value <ul> <li>Volume flow</li> <li>Mass flow</li> <li>Sound velocity</li> <li>Flow velocity</li> <li>Flow velocity</li> <li>Electronic temperature</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status <ul> <li>Low flow cut off</li> </ul> </li> </ul>

Signal on alarm

Depending on the interface, failure information is displayed as follows:

### Current output 4 to 20 mA

### 4 to 20 mA

Failure mode	Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Freely definable value between: 3.59 to 22.5 mA Actual value Last valid value
--------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

### 0 to 20 mA

Failure mode	Choose from:
	<ul> <li>Maximum alarm: 22 mA</li> <li>Freely definable value between: 0 to 22.5 mA</li> </ul>
	-

#### HART current output

Device diagnostics	Device condition can be read out via HART Command 48
--------------------	------------------------------------------------------

### Pulse/frequency/switch output

Pulse output		
Failure mode	Choose from: • Actual value • No pulses	

Frequency output				
Failure mode	Choose from: • Actual value • 0 Hz • Defined value: 0 to 12 500 Hz			
Switch output				
Failure mode	Choose from: • Current status • Open • Closed			

#### Local display

Plain text display	With information on cause and remedial measures
Backlight         Red backlighting indicates a device error.	

Status signal as per NAMUR recommendation NE 107

#### Interface/protocol

- Via digital communication:
- HART protocol
- Via service interface
  - CDI-RJ45 service interface
  - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	-------------------------------------------------

#### Web browser

Plain text display	With information on cause and remedial measures
--------------------	-------------------------------------------------

#### Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes			
	<ul> <li>The following information is displayed depending on the device version:</li> <li>Supply voltage active</li> <li>Data transmission active</li> <li>Device alarm/error has occurred</li> <li>Diagnostic information via light emitting diodes → 115</li> </ul>			

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

- The following connections are galvanically isolated from each other:
- Inputs
- Outputs
- Power supply

Protocol-specific data


### HART

Manufacturer ID	0x11			
Device type ID	0x1169			
HART protocol revision	7			
Device description files (DTM, DD)	Information and files under: www.endress.com			
HART load	Min. 250 Ω			
Dynamic variables PV, SV, TV, QV	<ul> <li>Read out the dynamic variables via HART command 3</li> <li>The measured variables can be freely assigned to the dynamic variables</li> </ul>			
Device variables	<ul> <li>Read out the device variables via HART command 9</li> <li>The measured variables can be freely assigned</li> <li>A maximum of 8 device variables can be transmitted</li> </ul>			
System integration				

# 16.5 Power supply

Terminal assignment	→ 🗎 35						
Supply voltage	Transmitter						
	Order code for "Power supply"	terminal vo	ltage	Frequency range			
		DC 24 V	±25%	-			
	Option <b>L</b>	AC 24 V	±25%	50/60 Hz, ±4 Hz			
		AC 100 to 2	40 V -15 to +10%	50/60 Hz, ±4 Hz			
Power consumption	Order code for "Outpu	Maximum power consumption					
	Option <b>H</b> : 4-20mA HART, pulse/frequ switch output	30 VA/8 W					
	Option I: 4-20mA HART, 2 x pulse/fre output, status input	30 VA/8 W					
Current consumption	Transmitter Order code for "Power supply"		Maximum Current consumption	Maximum switch-on current			
	Option <b>L</b> : AC 100 to 240 V	145 mA	25 A (< 5 ms)				
	Option L: AC/DC 24 V	350 mA	27 A (< 5 ms)				
Power supply failure	<ul> <li>Totalizers stop at the last val</li> <li>Depending on the device vers the pluggable data memory (</li> <li>Error messages (incl. total op</li> <li>→</li></ul>	sion, the config HistoROM DA	Γ).	he device memoryo			
	· = )0						
Potential equalization	→ 🗎 39						

Terminals	<b>Transmitter</b> Supply voltage cable: plug-in spring terminals for wire cross-sections 0.5 to $2.5$ mm <sup>2</sup> (20 to 14 AWG)					
Cable entries	Cable entry thread • M20 x 1.5 • Via adapter: • NPT <sup>1</sup> / <sub>2</sub> " • G <sup>1</sup> / <sub>2</sub> "					
	<b>Cable gland</b> M20 × 1.5 with cable $\phi$ 6 to 12 mm (0.24 to 0.47 in)					
	If metal cable entries are used, use a grounding plate.					
Cable specification	→ 🖹 34					
	16.6 Performance characteristics					
Reference operating conditions	<ul> <li>Error limits following ISO/DIS 11631</li> <li>Specifications as per measurement report</li> <li>Accuracy information is based on accredited calibration rigs that are traced to ISO 17025.</li> </ul>					
	To obtain measured errors, use the <i>Applicator</i> sizing tool $\rightarrow \square$ 137					
Maximum measured error	o.r. = of reading					
	The measured error depends on a number of factors. A distinction is made between the measured error of the device ( $0.5\%$ o.r.) and an additional installation-specific measured error (typically $1.5\%$ o.r.) that is independent of the device.					
	The installation-specific measured error depends on the installation conditions on site, such as the nominal diameter, accuracy of sensor mounting (sensor holder welding), real					



■ 29 Example of the measured error in a pipe with a nominal diameter DN > 200 (8")

- 1 Measured error of measuring device: 0.5% o.r. ± 3 mm/s (0.12 in/s)
- 2 Measured error due to installation conditions: typically 1.5% o.r.
- 3 Measured error at the measuring point: 0.5% o.r. ± 3 mm/s (0.12 in/s) + 1.5% o.r. = 2% o.r. ± 3 mm/s (0.12 in/s)

#### Measured error at the measuring point

The measured error at the measuring point is made up of the measured error of the device (0.5% o.r.) and the measured error resulting from the installation conditions on site. With a flow velocity > 0.3 m/s (1 ft/s) and a Reynolds number > 10000, the following are typical error limits:

Nominal diameter	Device error limits	+	Installation-specific error limits (typical)	→	Error limits at the measuring point (typical)	Field calibration <sup>1)</sup>
≥ DN 200 (8")	±0.5% o.r. ± 3 mm/s (0.12 in/s)	+	±1.5% o.r.	$\rightarrow$	±2% o.r. ± 3 mm/s (0.12 in/s)	±0.5% o.r. ± 3 mm/s (0.12 in/s)

1) Adjustment in relation to a reference with correction values written back to the transmitter

#### Measurement report


If required, the device can be supplied with a factory measurement report. A measurement is performed under reference conditions to verify the performance of the device. Here, the sensors are mounted on a pipe with a nominal diameter of DN 250 (10") or 400 (16").

With a flow velocity of > 0.3 m/s (1 ft/s) and a Reynolds number > 10000, the following error limits are guaranteed with the measurement report:

Nominal diameter	Device error limits			
250 (10"); single-path	±0.5% o.r. ± 3 mm/s (0.12 in/s)			
400 (16"); dual-path	±0.5% o.r. ± 3 mm/s (0.12 in/s)			

The specification applies for Reynolds numbers  $\text{Re} \ge 10\,000$ . Larger measured errors can occur for Reynolds numbers  $\text{Re} < 10\,000$ .

## Example for max. measured error (volume flow)



Storage temperature	The storage temperature for all components (except display modules) corresponds to the ambient temperature range $\rightarrow \cong 23$ .
Degree of protection	Transmitter
	<ul> <li>IP66/67, Type 4X enclosure, suitable for pollution degree 4</li> <li>When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2</li> <li>Display module: IP20, Type 1 enclosure, suitable for pollution degree 2</li> </ul>
	Sensor
	<ul> <li>Standard: IP66/67, Type 4X enclosure, suitable for pollution degree 4</li> <li>Optionally available: IP68, Type 6P enclosure, suitable for pollution degree 4</li> </ul>
	External WLAN antenna
	IP67
Vibration- and shock-	Vibration sinusoidal, according to IEC 60068-2-6
resistance	<ul> <li>2 to 8.4 Hz, 7.5 mm peak</li> <li>8.4 to 2 000 Hz, 2 g peak</li> </ul>
	Vibration broad-band random, according to IEC 60068-2-64
	<ul> <li>10 to 200 Hz, 0.01 g<sup>2</sup>/Hz</li> <li>200 to 2 000 Hz, 0.003 g<sup>2</sup>/Hz</li> <li>Total: 2.70 g rms</li> </ul>
	Shock half-sine, according to IEC 60068-2-27
	6 ms 50 g
	Rough handling shocks according to IEC 60068-2-31
Electromagnetic compatibility (EMC)	<ul> <li>As per IEC/EN 61326</li> <li>Complies with emission limits for industry as per EN 55011 (Class A)</li> <li>Details are provided in the Declaration of Conformity.</li> </ul>

## 16.9 Process

Medium temperature range	Sensor version	Frequency	Temperature
	I-100-A	1 MHz	−40 to +80 °C (−40 to +176 °F)
Sound velocity range	600 to 2 100 m/s (1969 to 6 890 ft/s)		
Medium pressure range	Maximum nominal press	ure PN 16 (16 bar	(232 psi))
Pressure loss	There is no pressure loss.		


## 16.10 Mechanical construction

Design, dimensions	For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section
Weight	Weight specifications excluding packaging material.
	Transmitter Proline 400 polycarbonate plastic: 1.2 kg (2.65 lb) Proline 400 aluminum, coated: 6.0 kg (13.2 lb)
	<ul> <li>Sensor</li> <li>Including mounting material</li> <li>Single path installation version: 4.5 kg (9.92 lb)</li> <li>Two-path installation version: 9 kg (19.9 lb)</li> </ul>
Materials	

#### Remote version (wall-mount housing)

- Order code for "Housing", option **P** "Remote, alu, coated": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option N: polycarbonate plastic
- Window material:
  - For order code for "Housing", option **P**: glass
  - For order code for "Housing", option N: plastic

## Cable entries/cable glands



■ 31 Possible cable entries/cable glands

- 1 Female thread M20 × 1.5
- 2 Cable gland M20  $\times$  1.5
- 3 Adapter for cable entry with female thread G  $\frac{1}{2}$  or NPT  $\frac{1}{2}$

#### remote version

Cable entry/cable gland	Material
Cable gland M20 × 1.5	<ul><li>Plastic</li><li>Nickel-plated brass</li></ul>
Cable gland of sensor cable	Nickel-plated brass
Power cable gland	Plastic
Adapter for cable entry with female thread G $^{1\!\!/}_{2"}$ or NPT $^{1\!\!/}_{2"}$	Nickel-plated brass

#### Sensor - transmitter cable

UV rays can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Sensor cable, TPE halogen-free

- Cable sheath: TPE halogen-free
- Cable plug: nickel-plated brass

#### Ultrasonic transducer

- Holder: stainless steel 1.4301 (304), 1.4404 (316L)
- Housing: stainless steel 1.4301 (304), 1.4404 (316L)

#### Accessories

External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

## 16.11 Operability

Languages	<ul> <li>Can be operated in the following languages:</li> <li>Via local operation: English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech, Swedish</li> <li>Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese</li> <li>Via Web browser English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech, Swedish</li> </ul>
Local operation	Via display module
	<ul> <li>Equipment:</li> <li>Standard features 4-line, illuminated, graphic display; touch control</li> <li>Order code for "Display; operation", option G "4-line, illuminated; Touch Control +WLAN" offers standard equipment features in addition to access via Web browser</li> </ul>
	Information about WLAN interface $\rightarrow $ 🗎 62

32 Operation with touch control

A0032074

	Display elements			
	<ul> <li>Format for display</li> </ul>	l, graphic display l lighting; switches to r ring measured variable		
		t temperature for the c the display may be imj		(-4 to +140 °F) es outside the temperature
	Operating elements			
	-, E			opening the housing: 🛨,
	<ul> <li>Operating element</li> </ul>	ts also accessible in the	e various zones of the	hazardous area
Remote operation	→ 🖺 62			
Service interface	→ 🗎 62			
Supported operating tools	Depending on the op via a variety of inter	perating tool used, acce		to the measuring device. fferent operating units an
Supported operating tools	Depending on the op	perating tool used, acce		
Supported operating tools	Depending on the op via a variety of inter Supported operating	perating tool used, acce faces.	ess is possible with di	fferent operating units an Additional information
Supported operating tools	Depending on the op via a variety of inter Supported operating tools	perating tool used, acce faces. Operating unit Notebook, PC or tablet	<ul> <li>Interface</li> <li>CDI-RJ45 service interface</li> </ul>	fferent operating units an Additional information Special Documentation for the
Supported operating tools	Depending on the op via a variety of inter Supported operating tools Web browser	perating tool used, acce faces.           Operating unit           Notebook, PC or tablet with Web browser           Notebook, PC or tablet with Microsoft Windows	<ul> <li>Interface</li> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>WLAN interface</li> </ul>	fferent operating units an Additional information Special Documentation for the device
Supported operating tools	Depending on the op via a variety of inter Supported operating tools Web browser DeviceCare SFE100	perating tool used, accellate         faces.         Operating unit         Notebook, PC or tablet         with Web browser         Notebook, PC or tablet         with Microsoft Windows         system         Notebook, PC or tablet         with Microsoft Windows	<ul> <li>Interface</li> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>WLAN interface</li> <li>Fieldbus protocol</li> <li>CDI-RJ45 service interface</li> <li>WLAN interface</li> <li>WLAN interface</li> <li>WLAN interface</li> </ul>	fferent operating units and Additional information Special Documentation for the device  →  137

Other operating tools based on FDT technology with a device driver such as DTM/ iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
- Process Device Manager (PDM) from Siemens → www.siemens.com
- Asset Management Solutions (AMS) from Emerson  $\rightarrow$  www.emersonprocess.com
- FieldCommunicator 375/475 from Emerson  $\rightarrow$  www.emersonprocess.com
- Field Device Manager (FDM) from Honeywell  $\rightarrow$  www.honeywellprocess.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The related device description files are available: www.endress.com  $\rightarrow$  Downloads

## Web server

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via a standard Ethernet switch (RJ45) or via a WLAN interface. The structure of the operating menu is the same as the menu on the local display. In addition to the measured values, status information about the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display", option G "4-line, illuminated; Touch Control +WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

#### Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, create configuration back-up)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration
- Display up to 1000 saved measured values (only available with the **Extended HistoROM** application package  $\rightarrow \triangleq 153$ )

Web server special documentation

HistoROMThe measuring device features HistoROM data management. HistoROM data managementdata managementcomprises both the storage and import/export of key device and process data, making<br/>operation and servicing far more reliable, secure and efficient.

#### Additional information on the data storage concept

*There are different types of data storage units in which device data are stored and used by the device:* 

	HistoROM backup	T-DAT	S-DAT
Available data	<ul> <li>Event logbook such as diagnostic events for example</li> <li>Device firmware package</li> </ul>	<ul> <li>Measured value logging ("Extended HistoROM" order option)</li> <li>Current parameter data record (used by firmware at run time)</li> <li>Peakhold indicator (min/max values)</li> <li>Totalizer values</li> </ul>	<ul> <li>Sensor data: etc.</li> <li>Serial number</li> <li>Device configuration (e.g. SW options, fixed I/O or multi I/O)</li> </ul>
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	Fixed on the sensor connection board

## Data backup

#### Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors

#### Data transmission

## Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

## Event list

## Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

## Data logging

#### Manual

- If the **Extended HistoROM** application package (order option) is enabled:
- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

## 16.12 Certificates and approvals

Current certificates and approvals for the product are available via the Product Configurator at www.endress.com.

**1.** Select the product using the filters and search field.

2. Open the product page.

The **Configuration** button opens the Product Configurator.

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

UKCA markingThe device meets the legal requirements of the applicable UK regulations (Statutory<br/>Instruments). These are listed in the UKCA Declaration of Conformity along with the<br/>designated standards. By selecting the order option for UKCA marking, Endress+Hauser<br/>confirms a successful evaluation and testing of the device by affixing the UKCA mark.

CE mark

	Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com
RCM mark	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Control Drawing" document. Reference is made to this document on the nameplate.
HART certification	HART interface
	<ul> <li>The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:</li> <li>Certified according to HART 7</li> <li>The device can also be operated with certified devices of other manufacturers (interoperability)</li> </ul>
Radio approval	The measuring device has radio approval.
	For detailed information regarding radio approval, see the Special Documentation $\rightarrow \cong 154$
Other standards and guidelines	<ul> <li>EN 60529 Degrees of protection provided by enclosures (IP code)</li> <li>EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements</li> <li>IEC/EN 61326-2-3 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).</li> <li>ANSI/ISA-61010-1 (82.02.01) Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements</li> <li>CAN/CSA-C22.2 No. 61010-1-12 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements</li> <li>CAN/CSA-C22.2 No. 61010-1-12 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements</li> <li>NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors</li> <li>NAMUR NE 33 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.</li> <li>NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics</li> <li>NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices</li> <li>NAMUR NE 107 Self-monitoring and diagnosis of field devices</li> <li>NAMUR NE 131 Requirements for field devices for standard applications</li> </ul>

## 16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Detailed information on the application packages: Special Documentation for the device  $\rightarrow \cong 154$ 

Diagnostics functions	Package	Description
	Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
		Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
		<ul> <li>Data logging (line recorder):</li> <li>Memory capacity for up to 1000 measured values is activated.</li> <li>250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.</li> </ul>

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	Heartbeat Verification         Meets the requirement for traceable verification to DIN ISO 9001:2008         Chapter 7.6 a) "Control of monitoring and measuring equipment".         Functional testing in the installed state without interrupting the process.         Traceable verification results on request, including a report.         Simple testing process via local operation or other operating interfaces.         Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.         Extension of calibration intervals according to operator's risk assessment.
		<ul> <li>Heartbeat Monitoring</li> <li>Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:</li> <li>Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time.</li> <li>Schedule servicing in time.</li> <li>Monitor the process or product quality, e.g. gas pockets.</li> </ul>

## 16.14 Accessories

Overview of accessories available for order  $\rightarrow$  🗎 135

## 16.15 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code on the nameplate

## Standard documentation

## **Brief Operating Instructions**

## Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Prosonic Flow I	KA01511D

## Brief Operating Instructions for the transmitter

Measuring device	Documentation code
Proline 400	KA01510D

#### **Technical Information**

Measuring device	Documentation code
Prosonic Flow I 400	TI01567D

## Description of device parameters

	Documentation code
Measuring device	HART
Prosonic Flow I 400	GP01166D

Supplementary device- dependent documentationSpecial Documentation	
Contents	Documentation code
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Heartbeat Technology	SD02712D
Web server	SD02713D

## Installation Instructions

Content	Comment
Installation instructions for spare part sets and accessories	<ul> <li>Access the overview of all the available spare part sets via W@M Device Viewer →  <sup>1</sup> 133</li> <li>Accessories available for order with Installation Instructions →  <sup>1</sup> 135</li> </ul>

# Index

## 

A
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Adapting the diagnostic behavior
Adapting the status signal
Ambient temperature
Influence
Ambient temperature range
AMS Device Manager
11
Application packages
Applicator
Approvals
<b>D</b>
В
Burst mode
0
C
Cable entries
Technical data
Cable entry
Degree of protection
CE mark
Certificates
Check
Connection
Installation status
Mounting
Checklist
Post-connection check
Post-mounting check
Cleaning
Exterior cleaning
Commissioning
J
Configuring the measuring device
Communication-specific data
Connecting cable
Connecting the measuring device
Connection
see Electrical connection
Connection preparations
Connection tools
Context menu
Calling up
Closing
Explanation
Current consumption
•
D

	_
1	
	-

Date of manufacture	 	•		•			•		•	 16
Declaration of Conformity	 • •	•		•	 •	•	•	•	• •	 10

Define access code	
Degree of protection	40
Design	1 /
Measuring device	
Device components	
Device description files	67
Device documentation	
Supplementary documentation	
Device locking, status	04
Device name	
Sensor	16
Transmitter	16
Device repair	33
Device revision	
Device type ID	
DeviceCare	
Device description file	
Diagnostic behavior	-
Explanation	17
Symbols	
Diagnostic information	1/
Design, description	20
	20
	20 20
5 5	15
1 5	16
	22
	22
	18
5	26
5	16
Diagnostics	
Symbols	
Dimensions	22
DIP switch	
see Write protection switch	
Direct access	52
Direct access code	47
Disabling write protection	01
Display	
see Local display	
Display area	
For operational display	45
In the navigation view	
Display values	
For locking status	ſЦ
Disposal	
Disposar	74
Function	۴
Symbols	
Document function	
Document information	6
F	

# E

Electrica	l connection					
Comr	nubox FXA1	95 (USB)	 	 	 	62

Degree of protection
Field Communicator 475 62
Field Xpert SFX350/SFX370 62
Measuring device
Operating tool (e.g. FieldCare, AMS Device
Manager, SIMATIC PDM)
Operating tools
Via HART protocol
Via service interface (CDI-RJ45) 62
Via WLAN interface
VIATOR Bluetooth modem 62
Web server
WLAN interface
Electromagnetic compatibility
Enabling write protection
Enabling/disabling the keypad lock
Endress+Hauser services
Maintenance
Repair
Environment
Storage temperature
Vibration- and shock-resistance
Error messages
see Diagnostic messages
Event list
Event logbook
Ex approval
Extended order code
Sensor
Transmitter
Exterior cleaning

## F

Field of application
Residual risks
Field Xpert SMT70 65
Field Xpert SMT77 66
FieldCare 64
Device description file
Establishing a connection
Function
User interface
Filtering the event logbook
Firmware
Release date
Version
Firmware history
Flow direction
FlowDC
Function check
Function scope
AMS Device Manager
SIMATIC PDM
Functions
see Parameters

## G

Galvanic isolation		•	•	•		•	•	•	•			•	•	•	•	•	•	•	•	• •	1	41	
--------------------	--	---	---	---	--	---	---	---	---	--	--	---	---	---	---	---	---	---	---	-----	---	----	--

## Н

Hardware write protection102HART certification152
HART protocol
Device variables
Measured variables
Help text
Calling up
Closing
Explanation
Ţ
I
I/O electronics module
Identifying the measuring device
Incoming acceptance
Influence
Ambient temperature
Inlet runs
Input 138
Input mask
Inspection
Received goods
Installation conditions
Dimensions
Intended use
L
Languages, operation options
Line recorder
Local display
Editing view
Navigation view
see Diagnostic message
see In alarm condition
see Operational display
Low flow cut off
Μ
Main electronics module
Maintenance
Maintenance tasks 132
Manufacturer ID
Materials
Maximum measured error
Measured variables
Calculated
Measured
see Process variables
Measuring and test equipment 132
Measuring and test equipment
Measuring and test equipment 132

Design14Disposal134Preparing for electrical connection36Preparing for mounting24

Measuring principle       138         Measuring range       138         Measuring system       138	8
Menu	_
Diagnostics	
Setup	2
Menus	
For measuring device configuration	1
For specific settings	9
Mounting	9
Mounting dimensions	
see Dimensions	
Mounting location	9
Mounting preparations	4
Mounting requirements	
Inlet and outlet runs	0
Mounting location	9
Orientation	0
Mounting tool	4

## N

Nameplate	
Sensor	16
Transmitter	16
Navigation path (navigation view)	46
Navigation view	
In the submenu	46
In the wizard	46
Numeric editor	48

0
Operable flow range
Operating elements
Operating keys
see Operating elements
Operating menu
Menus, submenus
Structure
Submenus and user roles
Operating philosophy
Operation
Operation methods
Operation options
Operational display
Operational safety
Order code
Orientation (vertical, horizontal) 20
Outlet runs
Output
Output signal         139

## Ρ

Packaging disposal	18
Parameter	
Changing	54
Entering a value	54
Parameter settings	
Administration (Submenu)	98
Advanced setup (Submenu)	90

Burst configuration 1 to n (Submenu)69Current output 1 (Wizard)79Data logging (Submenu)110Define access code (Wizard)97Device information (Submenu)129Diagnostics (Menu)125Display (Submenu)92Display (Submenu)92Display (Wizard)85For the status input77Heartbeat base settings (Submenu)97Input values (Submenu)106Installation status (Submenu)76Low flow cut off (Submenu)74Output values (Submenu)107Process variables (Submenu)105Pulse/frequency/switch output 1 to n (Wizard)72Simulation (Submenu)98Sensor adjustment (Submenu)99Setus input (Submenu)72Simulation (Submenu)73System values (Submenu)73System values (Submenu)90Totalizer 1 to n (Submenu)90Totalizer 1 to n (Submenu)90Totalizer 1 to n (Submenu)94Performance characteristics41Post-installation check71Post-installation check (checklist)41Post-installation check71Power consumption42Power consumption42Power supply failure42Pressure loss446
Power consumption142Power supply failure142
Pressure loss    146      Product safety    10      Protecting parameter settings    101
_

## R

Radio approval	52
RCM mark	
Read access	55
Reading off measured values	)4
Recalibration	32
Reference operating conditions	έ3
Registered trademarks	8
Remedial measures	
Calling up	18
Closing 11	18
Remote operation	ʻ <sub>1</sub> 9
Remote version	
Connecting the signal cables	36
Repair	33
Notes	33
Repair of a device	33
Repeatability	

Proline Prosonio	Flow I 4	100 HART
------------------	----------	----------

Replacement	
Device components	133
Requirements for personnel	9
Return	133
_	
S	
Safety	9
Sensor set selection and arrangement	22
Serial number	16
Setting the operating language	71
Settings	
Adapting the measuring device to the pro	cess
conditions	108
Administration	97
Advanced display configurations	92
Current output	79
Device reset	
Local display	85
Low flow cut off	
Measuring point	
Operating language	
Pulse output	
Pulse/frequency/switch output	
Resetting the totalizer	
Sensor adjustment	
Simulation	
Status input	
Switch output	
System units	
Tag name	
Totalizer	
Totalizer reset	
WLAN	
Show data logging	
Signal on alarm	
SIMATIC PDM	
Function	
Software release	
Sound velocity range	
Spare part	
Spare parts	
Special connection instructions	
Standards and guidelines	
Status area	
For operational display	45
In the navigation view	
Status signals	
Storage concept	
Storage conditions	
Storage temperature	
Storage temperature range	140
Structure	4.7
Operating menu	43
Submenu	07 00
Administration	
Advanced setup	
Burst configuration 1 to n	
Data logging	
Device information	129

Event list	27
Heartbeat base settings	97
Heartbeat setup	96
Input values	)6
Installation status	76
Low flow cut off	37
Measured values	)4
Output values	)7
Overview	<sub>4</sub> 4
Process variables	)5
Reset access code	98
Sensor adjustment	90
	99
Status input	7
- )	73
System values	
Totalizer	)8
Totalizer 1 to n	90
Totalizer handling	)8
Web server	51
Supply voltage	ŧ2
Symbols	
For communication	ŧ5
For correction	ŧ8
,	ŧ5
For locking	ŧ5
For measured variable	ŧ5
For measurement channel number 4	ŧ5
For menus	ŧ7
For parameters	ŧ7
For status signal	ŧ5
For submenu	ŧ7
For wizard	ŧ7
In the status area of the local display 4	ŧ5
In the text and numeric editor	ŧ8
System design	
Measuring system	88
see Measuring device design	
System integration 6	57
_	
Т	
Technical data, overview	88
Temperature range	
Ambient temperature	
Ambient temperature range for display 14	
Medium temperature	
Storage temperature	
Terminal assignment	
Terminals	12
Text editor	ŧ٦
	18 18
Tool	£8
Tool For mounting	£8
Tool For mounting	£8
Tool For mounting	£8
Tool For mounting	¥8 24
Tool For mounting	¥8 24 34
Tool For mounting	¥8 24 34

Totalizer
Configuring
Transmitter
Connecting the signal cables
Turning the display module
Transporting the measuring device 18
Troubleshooting
General
Turning the display module
U
UKCA marking 151
Use of the measuring device
Borderline cases
Incorrect use
see Intended use
User interface
Current diagnostic event
Previous diagnostic event
User roles
V
Version data for the device
Vibration- and shock-resistance
W
W@M 132, 133
W@M Device Viewer 15, 133
Weight
Transport (notes)
Wizard
Current output 1
Define access code
Display
Low flow cut off
Measuring point
Pulse/frequency/switch output 1 to n 81, 82, 83
WLAN settings
WLAN settings
Workplace safety 10
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com

