01.03.zz (Device firmware)

Products Solutions

lutions Services


# Operating Instructions Levelflex FMP50 HART

Guided wave radar









Levelflex FMP50 HART Table of contents

# Table of contents

1	Important document information 5	6.2	Mounting the measuring device	
1.1	Purpose of this document 5		6.2.1 Tool list	
1.2	Symbols 5		6.2.2 Shortening the probe	
1.2	1.2.1 Safety symbols 5		6.2.3 Mounting the device	33
	1.2.2 Electrical symbols 5		6.2.4 Mounting the "Sensor, remote"	
	1.2.3 Tool symbols 5		version	34
	1.2.4 Symbols for certain types of		6.2.5 Turning the transmitter housing	36
			6.2.6 Turning the display	37
1 2	information and graphics 6	6.3	Post-installation check	37
1.3	Documentation			
	1.3.1 Technical Information (TI)	7	Electrical connection	39
	1.3.2 Brief Operating Instructions (KA) 7			
	1.3.3 Safety Instructions (XA)	7.1	Connecting requirements	
1 /	1.3.4 Functional Safety Manual (FY) 7		7.1.1 Terminal assignment	
1.4	Terms and abbreviations		7.1.2 Cable specification	
1.5	Registered trademarks 8		7.1.3 Device plug	
			7.1.4 Supply voltage	
2	Basic safety instructions 9		7.1.5 Overvoltage protection	48
2.1	Requirements for the personnel 9	7.2	Connecting the device	48
2.2	Intended use		7.2.1 Opening cover	
2.3	Workplace safety		7.2.2 Connecting	49
2.4	Operational safety		7.2.3 Plug-in spring-force terminals	49
2.5	Product safety		7.2.4 Closing the cover of the connection	
۵.۶	2.5.1 CE mark		compartment	
	2.5.2 EAC conformity 10	7.3	Post-connection check	50
	21.7.12 22.10 comorning			
3	Product description	8	Operation methods	51
	-	8.1	Overview	51
3.1	Product design		8.1.1 Local operation	51
	3.1.1 Levelflex FMP50		8.1.2 Operation with remote display and	
	3.1.2 Electronics housing 12		operating module FHX50	52
			8.1.3 Operation via Bluetooth® wireless	
4	Incoming acceptance and product		technology	53
	identification		8.1.4 Remote operation	54
, 1		8.2	Structure and function of the operating	
4.1	Incoming acceptance		menu	55
4.2	Product identification		8.2.1 Structure of the operating menu	55
	4.2.1 Nameplate		8.2.2 User roles and related access	
			authorization	57
5	Storage, transport 15		8.2.3 Data access - Security	57
5.1	Storage temperature	8.3	Display and operating module	62
5.2	Transporting the product to the measuring		8.3.1 Display	62
	point		8.3.2 Operating elements	65
	r		8.3.3 Entering numbers and text	66
6	Mounting		8.3.4 Opening the context menu	67
	_		8.3.5 Envelope curve display on the display	
6.1	Mounting requirements		and operating module	69
	6.1.1 Suitable mounting position 16			
	6.1.2 Mounting under confined conditions . 18	9	Device integration via the HART	
	6.1.3 Notes on the mechanical load of the		_	70
	probe	<b>6</b> -	-	
	6.1.4 Information concerning the process	9.1	Overview of the Device Description files (DD).	70
	connection	9.2	HART device variables and measuring values.	70
	6.1.5 Securing the probe			
	6.1.6 Special installation situations 25			

Table of contents

Levelflex FMP50 HART

10	Commissioning via SmartBlue	
	(App)	
10.1	Prerequisites	71
10.2 10.3	SmartBlue App	71 71
10.5	Envelope curve display in Smartblue	/ 1
11	Commissioning using the	
	Commissioning Wizard	73
12	Commissioning via operating	
	menu	74
12.1	Function check	74
12.2	Setting the operating language	74
12.3	Configuring level measurement	75
12.4	Recording the reference envelope curve	77
12.5	Configuring the local display	78
	level measurements	78
	12.5.2 Adjusting the local display	78
12.6	Configuring the current outputs	79
	12.6.1 Factor setting of current outputs for	70
	level measurements	79 79
12.7	Configuration management	80
12.8	Protecting settings from unauthorized access .	81
13	Diagnostics and troubleshooting	82
13.1	General troubleshooting	82
	13.1.1 General errors	82
	13.1.2 Error - SmartBlue operation	84 85
13.2	13.1.3 Parametrization errors Diagnostic information on local display	86
17.2	13.2.1 Diagnostic message	86
	13.2.2 Calling up remedial measures	88
13.3	Diagnostic event in the operating tool	89
13.4	Diagnostic list	90
13.5	List of diagnostic events	91
13.6	Event logbook	93 93
	13.6.2 Filtering the event logbook	93
	13.6.3 Overview of information events	93
13.7	Firmware history	95
14	Maintenance	96
14.1	Exterior cleaning	96
14.2	General cleaning instructions	96
15	Repair	97
15.1	General information	97
	15.1.1 Repair concept	97
	15.1.2 Repair of Ex-certified devices	97
	15.1.3 Replacing electronics modules	97
1	15.1.4 Replacing a device	97
15.2	Spare parts	98

15.3 15.4	Return				
16	Accessories	99			
16.1	Device-specific accessories				
	housing	100			
	16.1.3 Mounting kit, insulated	101			
	16.1.4 Centering star	102 102			
	16.1.6 Overvoltage protection	103			
	16.1.7 Bluetooth module BT10 for HART				
	devices	104			
16.2	Communication-specific accessories	105			
16.3 16.4	Service-specific accessories	106 106			
10.4	System components	100			
17	Operating menu	107			
17.1	Overview of the operating menu (SmartBlue)	107			
17.2	Overview of the operating menu (display				
170	module)	112			
17.3	Overview of the operating menu (operating tool)	119			
17.4	"Setup" menu	126			
17.1	17.4.1 "Mapping" wizard	133			
	17.4.2 "Advanced setup" submenu	134			
17.5	"Diagnostics" menu	181			
	17.5.1 "Diagnostic list" submenu	183			
	17.5.2 "Event logbook" submenu	184			
	17.5.3 "Device information" submenu	185 188			
	17.5.4 Weasured values submenu	190			
	17.5.6 "Simulation" submenu	193			
	17.5.7 "Device check" submenu	198			
	17.5.8 "Heartbeat" submenu	200			
Index 20					

# 1 Important document information

# 1.1 Purpose of this document

These Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

# 1.2 Symbols

# 1.2.1 Safety symbols

# **⚠** DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

### **WARNING**

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

# **A** CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

### NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

# 1.2.2 Electrical symbols



Alternating current



Direct current and alternating current



Direct current



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

# Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

# 1.2.3 Tool symbols



Phillips head screwdriver



Flat blade screwdriver



Torx screwdriver



Allen key



Open-ended wrench

# 1.2.4 Symbols for certain types of information and graphics

# **✓** Permitted

Procedures, processes or actions that are permitted

# **✓** ✓ Preferred

Procedures, processes or actions that are preferred

# **X** Forbidden

Procedures, processes or actions that are forbidden

# 1 Tip

Indicates additional information



Reference to documentation



Reference to graphic



Notice or individual step to be observed

# 1., 2., 3.

Series of steps

Result of a step



Visual inspection



Operation via operating tool



Write-protected parameter

# 1, 2, 3, ...

Item numbers

# A, B, C, ...

Views

# $\triangle \rightarrow \square$ Safety instructions

Observe the safety instructions contained in the associated Operating Instructions

# Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

### 1.3 **Documentation**

The following types of documentation are available in the Download Area of the Endress +Hauser website (www.endress.com/downloads):



For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

### 1.3.1 **Technical Information (TI)**

# Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.


### 1.3.2 Brief Operating Instructions (KA)

# Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

### 1.3.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.



### 1.3.4 **Functional Safety Manual (FY)**

Depending on the SIL approval, the Functional Safety Manual (FY) is an integral part of the Operating Instructions and applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions.



The different requirements that apply for the protective function are described in the Functional Safety Manual (FY).

### 1.4 Terms and abbreviations

# BA

Document type "Operating Instructions"

# KA

Document type "Brief Operating Instructions"

Document type "Technical Information"

Document type "Special Documentation"

Document type "Safety Instructions"

Nominal pressure

# **MWP**

Maximum working pressure

The MWP is indicated on the nameplate.

### ToF

Time of Flight

### FieldCare

Scalable software tool for device configuration and integrated plant asset management solutions

### **DeviceCare**

Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices

### DTM

Device Type Manager

### DD

Device Description for HART communication protocol

# $\varepsilon_r$ (Dk value)

Relative dielectric constant

### PI.C

Programmable logic controller (PLC)

### CD

Common Data Interface

# Operating tool

The term "operating tool" is used in place of the following operating software:

- FieldCare / DeviceCare, for operation via HART communication and PC
- SmartBlue app, for operation using an Android or iOS smartphone or tablet

### BD

Blocking Distance; no signals are analyzed within the BD.

### PLC

Programmable logic controller (PLC)

### CDI

Common Data Interface

### **PFS**

Pulse Frequency Status (Switch output)

# 1.5 Registered trademarks

# **HART®**

Registered trademark of the FieldComm Group, Austin, Texas, USA

### Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

# $Apple^{\mathbb{R}}$

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

# Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

# KALREZ®, VITON®

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

### **TEFLON®**

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

### TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

Levelflex FMP50 HART Basic safety instructions

# 2 Basic safety instructions

# 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

# 2.2 Intended use

# Application and media

The measuring device described in this manual is intended only for the level measurement of liquids. Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

If the limit values specified in the "Technical data" and the conditions listed in the instructions and additional documentation are observed, the measuring device may be used for the following measurements only:

- ► Measured process variables: level
- ► Calculable process variables: volume or mass in any shape of vessel (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Use the measuring device only for media to which the process-wetted materials have an adequate level of resistance.
- ▶ Observe the limit values in the "Technical data".

## Incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Clarification of borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

# Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies contained therein (e.g. display module, main electronics module and I/O electronics module) may rise up to 80  $^{\circ}$ C (176  $^{\circ}$ F). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► In the event of high medium temperatures, ensure protection against contact to prevent burns.

Basic safety instructions

Levelflex FMP50 HART

# 2.3 Workplace safety

When working on and with the device:

▶ Wear the required protective equipment according to federal or national regulations.

# 2.4 Operational safety

Risk of injury!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ► The operator is responsible for the interference-free operation of the device.

### Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

### Repair

To ensure continued operational safety and reliability:

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories from the manufacturer.

### Hazardous area

To eliminate danger to persons or the installation when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ► Check the nameplate to verify whether the ordered device can be put to its intended use in the hazardous area.
- ► Observe the specifications in the separate supplementary documentation, which is an integral part of this manual.

# 2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets the general safety standards and legal requirements.

# NOTICE

## Loss of degree of protection by opening of the device in humid environments

▶ If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

# 2.5.1 **CE mark**

The measuring system meets the legal requirements of the applicable EU directives. These are listed in the corresponding EU Declaration of Conformity together with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the CE mark.

# 2.5.2 EAC conformity

The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity along with the standards applied.


The manufacturer confirms successful testing of the device by affixing to it the EAC mark.

Levelflex FMP50 HART Product description

# **3** Product description

# 3.1 Product design

# 3.1.1 Levelflex FMP50




A

■ 1 Design of the Levelflex

- 1 Electronics housing
- 2 Process connection (Thread)
- 3 Rope probe
- 4 End-of-probe weight
- 5 Rod probe

Product description Levelflex FMP50 HART

### 3.1.2 **Electronics housing**



**₽** 2 Design of the electronics housing

- ${\it Electronics\ compartment\ cover}$
- 2 Display module
- Main electronics module 3
- Cable glands (1 or 2, depending on instrument version)
- Nameplate
  I/O electronics module
- Terminals (pluggable spring terminals)
  Connection compartment cover
- Grounding terminal

# 4 Incoming acceptance and product identification

# 4.1 Incoming acceptance

Check the following during incoming acceptance:


- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): are the Safety Instructions (XA) provided?
- If one of these conditions is not met, please contact your Endress+Hauser sales office.

# 4.2 Product identification

The following options are available for the identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial number from the nameplate in *W@M Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial number on the nameplate into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information about the measuring device is displayed.

# 4.2.1 Nameplate



■ 3 Nameplate of the Levelflex; engineering unit: mm (in)

- 1 Device name
- 2 Manufacturer address
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference length
- 8 Certificate symbol
- 9 Certificate- and approval-related data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication protocol): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Materials in contact with process
- 22 Permitted ambient temperature  $(T_a)$
- 23 Size of the cable gland thread
- 24 Probe length
- 25 Signal outputs
- 26 Supply voltage

Up to 33 characters of the extended order code are indicated on the nameplate. If the extended order code contains additional characters, these cannot be displayed. However, the complete extended order code can also be displayed via the device operating menu: **Extended order code 1 to 3** parameter

Levelflex FMP50 HART Storage, transport

# 5 Storage, transport

# 5.1 Storage temperature

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use original packaging.

# 5.2 Transporting the product to the measuring point

# **▲** WARNING

Housing or rod may become damaged or pull off.

Danger of injury!

- ► Transport the measuring device to the measuring point in its original packaging or by the process connection.
- Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or probe. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.
- ► Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs) (IEC 61010).




A0014264

# 6 Mounting

# 6.1 Mounting requirements

# **6.1.1** Suitable mounting position



 $\blacksquare$  4 Installation conditions for Levelflex

Spacing requirements when mounting

- Distance (A) between the vessel wall and rod and rope probes:
  - For smooth metallic walls: > 50 mm (2 in)
  - For plastic walls: > 300 mm (12 in) to metallic parts outside the vessel
  - For concrete walls: > 500 mm (20 in), otherwise the permitted measuring range may be reduced.
- Distance (B) between rod probes and internal fittings (3): > 300 mm (12 in)
- When using more than one Levelflex:
   Minimum distance between the sensor axes: 100 mm (3.94 in)
- Distance (C) from the end of the probe to the bottom of the vessel:
  - Rope probe: > 150 mm (6 in)
  - Rod probe: > 10 mm (0.4 in)

Levelflex FMP50 HART Mounting

# Additional conditions


 When mounting outdoors, a weather protection cover (1) can be used to protect the device against extreme weather conditions.

- In metallic vessels, preferably do not mount the probe in the center of the vessel (2), as
  this would lead to increased interference echoes.
   If a central mounting position cannot be avoided, it is essential to perform interference
  echo suppression (mapping) after commissioning the device.
- Do not mount the probe in the filling curtain (3).
- Avoid buckling the rope probe during installation or operation (e.g. as a result of product movement against silo wall) by selecting a suitable mounting location.
- In the case of freely suspended rope probes (probe end not fixed at the bottom), the distance between the probe rope and internal fittings, which can change due to the movement of the product, must never be less than 300 mm (12 in). Occasional contact between the probe end weight and the cone of the vessel, however, does not influence the measurement provided that the dielectric constant is at least DC = 1.8.
- When the housing is mounted in a recess (e.g. in a concrete ceiling), observe a minimum distance of 100 mm (4 in) between the cover of the connection compartment/electronics compartment and the wall. Otherwise the connection compartment/electronics compartment will not be accessible after installation.

# 6.1.2 Mounting under confined conditions

# Mounting with remote probe

The device version with a remote probe is suitable for applications with restricted mounting space. In this case, the electronics housing is mounted at a separate position from the probe.



A001479

- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered
- Product structure, feature 600 "Probe design":
  - Version MB "Sensor remote, 3m cable"
  - Version MC "Sensor remote, 6m cable"
  - Version MD "Sensor remote, 9m cable"
- The connecting cable is included in the delivery with these versions. Minimum bending radius: 100 mm (4 inch)
- The mounting bracket for the electronics housing is included in the delivery with these versions. Mounting options:
  - Wall mounting
  - Mounting on DN32 to DN50 (1-1/4 to 2 inch) post or pipe
- The connection cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

Levelflex FMP50 HART Mounting

# 6.1.3 Notes on the mechanical load of the probe

# Tensile loading capacity of rope probes

FMP50

Rope 4mm (1/6") 316

2 kN

# Lateral loading capacity (flexural strength) of rod probes

FMP50

Rod 8mm (1/3") 316L

10 Nm

Lateral load (bending moment) from flow conditions

The formula for calculating the bending moment M acting on the probe:

$$M = c_w \times \rho/2 \times v^2 \times d \times L \times (L_N - 0.5 \times L)$$

With:

c<sub>w</sub>: coefficient of friction

 $\rho$  [kg/m<sup>3</sup>]: density of the medium

v [m/s]: flow velocity of the medium, perpendicular to the probe rod

d [m]: diameter of the probe rod

L [m]: level

LN [m]: probe length


# Sample calculation


Coefficient of friction  $c_{\rm w}$  0.9 (assuming turbulent flow - high Reynolds number)

Density  $\rho$  [kg/m<sup>3</sup>] 1000 (e.g. water)

Probe diameter d [m] 0.008

 $L = L_N$  (unfavorable conditions)






Levelflex FMP50 HART Mounting

### 6.1.4 Information concerning the process connection

Probes are mounted on the process connection with threaded connections or flanges. If there is the danger with this installation that the probe end moves so much that it occasionally touches the vessel floor or cone, the probe may need to be shortened at the lower end and fixed in place.

### Threaded connection



**₽** 5 Mounting with threaded connection; flush with the vessel ceiling

Seal


The thread and the type of seal comply with DIN 3852 Part 2, screwed plug, form A.

The following types of sealing ring can be used:

For thread G3/4": According to DIN 7603 with dimensions 27 mm  $\times$  32 mm

Use a sealing ring according to this standard in form A, C or D and of a material that offers appropriate resistance for the application.

### Nozzle installation




Length of the centering rod or the rigid part of the rope probe

- Permissible nozzle diameter: ≤ 150 mm (6 in) For larger diameters, the near-range measuring capability may be reduced. For large nozzles, see the section "Mounting in nozzles ≥ DN300"
- Permissible nozzle height: ≤ 150 mm (6 in) For larger heights, the near-range measuring capability may be reduced.
- The end of the nozzle should be flush with the tank ceiling in order to avoid ringing effects.
- In thermally insulated vessels, the nozzle should also be insulated in order to prevent condensate formation.

# *Mounting in nozzles* $\geq$ *DN300*

If installation in nozzles  $\geq$  300 mm (12 in) is unavoidable, installation must be carried out in accordance with the following diagram in order to avoid interference signals in the near range.




A0014199

- 1 Lower edge of the nozzle
- 2 Approximately flush with the lower edge of the nozzle (±50 mm)
- 3 Plate, nozzle Ø 300 mm (12 in) = plate Ø 280 mm (11 in); nozzle Ø  $\geq$  400 mm (16 in) = plate Ø  $\geq$  350 mm (14 in)
- 4 Pipe Ø 150 to 180 mm

Levelflex FMP50 HART Mounting

# 6.1.5 Securing the probe

# Securing rope probes




- A Rope sag:  $\geq 10 \text{ mm/(1 m probe length)} [0.12 \text{ in/(1 ft probe length)}]$
- B Reliably grounded end of probe
- C Reliably insulated end of probe
- 1 Fastener in female thread of probe end weight
- 2 Insulated fastening kit
- The end of the rope probe must be secured (fixed down) under the following conditions: If the probe would otherwise temporarily come into contact with the vessel wall, the cone, internal fittings/beams or another part of the installation
- A female thread is provided in the probe weight to secure the end of the probe: Rope 4 mm (1/6"), 316: M 14
- When fixed down, the end of the probe must be either reliably grounded or reliably insulated. Use an insulated fastening kit if it is not otherwise possible to secure the probe with a reliably insulated connection.
- If grounded fastening is used, the search for a positive probe end echo must be activated.
   Otherwise, automatic probe length correction is not possible.

Navigation: Expert  $\rightarrow$  Sensor  $\rightarrow$  EOP evaluation  $\rightarrow$  EOP search mode Setting: **Positive EOP** option

# Securing rod probes

- For WHG approval: A support is required for probe lengths  $\geq$  3 m (10 ft).
- In general, rod probes must be secured in the event of horizontal flow (e.g. from an agitator) or strong vibrations.
- Only secure rod probes directly at the end of the probe.



A0014127

- 1
- 2 Sleeve with narrow bore to ensure electrical contact between the sleeve and the rod.
- Short metal pipe, e.g. welded in place

# Probe Ø 8 mm (0.31 in)

- $\bullet$  a < Ø 14 mm (0.55 in)
- $b = \emptyset 8.5 \text{ mm } (0.34 \text{ in})$

# **NOTICE**

# Poor grounding of the probe end may cause incorrect measurements.

▶ Use a sleeve with a narrow bore to ensure good electrical contact between the sleeve and the probe rod.

# NOTICE

# Welding can damage the main electronics module.


▶ Before welding: Ground the probe rod and remove the electronics.


Levelflex FMP50 HART Mounting

# 6.1.6 Special installation situations

# Bypasses and stilling wells

The use of centering disks/stars/weights (available as accessories) is recommended in bypass and stilling well applications.





A001412


- 1 Mounting in stilling well
- 2 Mounting in bypass
- 3 Minimum distance between probe end and lower edge of bypass 10 mm (0.4 in)
- Pipe diameter: > 40 mm (1.6 in) (for rod probes).
- A rod probe can be installed in pipes with a diameter of up to 150 mm (6 in). The use of FMP51 with a coax probe is recommended for larger pipe diameters.
- Side outlets, holes, slots and welds with a maximum inward projection of 5 mm (0.2 in)
   do not affect the measurement.
- There should not be any changes in the diameter of the pipe.
- The probe must be 100 mm (4 in) longer than the lower outlet.
- The probes must not touch the pipe wall within the measuring range. Support or brace the probe if necessary. All rope probes are prepared for bracing in vessels (tensioning weight with anchor hole).
- For bypasses with condensate formation (water) and a medium with a low dielectric constant (e.g. hydrocarbons):

Over time, the bypass fills with condensate up to the lower outlet. When levels are low, the level echo is masked by the echo of the condensate as a result. In this range, the level of the condensate is output and the correct value is only output when levels are higher. For this reason, ensure that the lower outlet is 100 mm (4 in) below the lowest level to be measured and fit a metal centering disk at the level of the lower edge of the lower outlet.

In thermally insulated vessels, the bypass should also be insulated in order to prevent condensate formation.

Assignment of centering disk/centering star/centering weight to the pipe diameter

# Underground tanks




A0014142

In the case of nozzles with large diameters, use FMP51 with a coax probe to avoid reflections at the nozzle wall.

Levelflex FMP50 HART Mounting

# Mounting at an angle




A0014145

- For mechanical reasons, the probe should be installed as vertically as possible.
- If the probe is installed at an angle, the length of the probe must be reduced depending on the angle of installation.

  - $\alpha$  5°: LN<sub>max.</sub> 4 m (13.1 ft)  $\alpha$  10°: LN<sub>max.</sub> 2 m (6.6 ft)  $\alpha$  30°: LN<sub>max.</sub> 1 m (3.3 ft)

# Non-metal vessels




- 1 Non-metal vessel
- 2 Metal sheet or metal flange

To ensure good measurement results when mounting on non-metal vessels, at the process connection mount a metal sheet with a diameter of at least  $200\,$  mm (8 in) at a right angle to the probe.

Levelflex FMP50 HART Mounting

# Plastic and glass vessels: Mounting the probe on the outside wall

In the case of plastic and glass vessels, the probe can also be mounted on the outside wall under certain conditions.



A001/(150

- 1 Plastic or glass vessel
- 2 Metal plate with screw-in sleeve
- 3 No space between vessel wall and probe!

# Requirements

- Dielectric constant of the medium:  $\varepsilon_r > 7$ .
- Non-conductive vessel wall.
- Maximum wall thickness (a):
  - Plastic: < 15 mm (0.6 in)
  - Glass: < 10 mm (0.4 in)
- No metal reinforcements on the vessel.

### Note the following when mounting the device:

- Mount the probe directly on the vessel wall without any space between the wall and probe.
- To prevent any influence on the measurement, fit a plastic half pipe with a diameter of at least 200 mm (8 in), or a similar protective unit, on the probe.
- For vessel diameters less than 300 mm (12 in):
   On the opposite side of the vessel, fit a grounding plate that is conductively connected to the process connection and covers around half of the vessel's circumference.
- For vessel diameters of 300 mm (12 in) and higher: At the process connection, fit a metal plate with a diameter of at least 200 mm (8 in) at a right angle to the probe (see above).

# Adjustment when mounting on the vessel exterior

When the probe is mounted on the outside of the vessel wall, the speed of propagation of the signal is reduced. There are two ways to compensate for this.

# Compensation via gas phase compensation factor

The effect of the dielectric wall is comparable to the effect of a dielectric gas phase and can therefore be corrected in the same way. The correction factor is calculated as the quotient of the actual probe length LN and the probe length measured when the vessel is empty.

- The device determines the position of the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.
- Parameter Expert → Sensor → Gas phase compensation → GPC mode
   Select the Const. GPC factor option.

Parameter Expert → Sensor → Gas phase compensation → Const. GPC factor
 Ouotient: Enter "(actual probe length)/(measured probe length)".

# Compensation via the calibration parameters


If it is necessary to actually compensate for a gas phase, the gas phase compensation function is not available for the correction of external mounting. The calibration parameters (**Empty calibration** and **Full calibration**) must be adjusted in this case. Furthermore, a value that is greater than the actual probe length must be entered in the **Present probe length** parameter. In all three cases, the correction factor is the quotient of the probe length measured when the vessel is empty and the actual probe LN.

- The device searches for the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.
- 1. Parameter Setup → Empty calibration
  - Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- 2. Parameter Setup → Full calibration
  - Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- 3. Parameter Setup → Advanced setup → Probe settings → Probe length correction → Confirm probe length
  - ► Select the **Manual input** option.
- 4. Parameter Setup → Advanced setup → Probe settings → Probe length correction → Present probe length
  - ► Enter the measured probe length.

Levelflex FMP50 HART Mounting

# Vessel with thermal insulation

If process temperatures are high, the device must be included in normal vessel insulation (1) in order to prevent the electronics heating up as a result of thermal radiation or convection. The insulation may not go beyond the points labeled "MAX" in the drawings.




■ 6 Process connection with thread

- 1 Vessel insulation
- 2 Compact device
- 3 Sensor, remote

Levelflex FMP50 HART Mounting

### 6.2 Mounting the measuring device

### 6.2.1 Tool list



- To shorten rope probes: use a saw or bolt cutters
- To shorten rod or coax probes: use a saw
- For flanges and other process connections: use an appropriate mounting tool


### 6.2.2 Shortening the probe

# Shortening rod probes

Rod probes must be shortened if the distance to the vessel floor or outlet cone is less than 10 mm (0.4 in). To shorten, saw off the bottom end of the rod probe.

# Shortening rope probes

Rope probes must be shortened if the distance to the vessel floor or outlet cone is less than 150 mm (6 in).



# Rope material 316

- A:
  - 4 mm (0.16 in)
- B:
- 40 mm (1.6 in)
- C:
  - 3 mm; 5 Nm (3.69 lbf ft)
- 1. Using an Allen key, loosen the set screws on the rope weight. Note: The setscrews have a clamping coating in order to prevent them from becoming loose accidentally. A higher torque is therefore required to loosen the screws.
- 2. Remove the released rope from the weight.

Levelflex FMP50 HART Mounting


- 3. Measure off the new rope length.
- 4. At the point to be shortened, wrap adhesive tape around the rope to prevent it from fraying.
- 5. Saw off the rope at a right angle or cut it off with a bolt cutter.
- 6. Insert the rope completely into the weight.
- 7. Screw the setscrews back into place. Due to the clamping coating of the setscrews, it is not necessary to apply a locking compound.

# Entering the new probe length

After shortening the probe:

1. Go to the **Probe settings** submenu and perform a probe length correction.






Field for the new probe length

For documentation purposes, enter the new probe length into the quick reference quide which can be found in the electronics housing behind the display module.

### 6.2.3 Mounting the device

# Mounting devices with a threaded connection



Screw the device with the threaded connection into a sleeve or flange and then secure it to the process vessel via the sleeve/flange.



- When screwing into place, turn by the hex bolt only:
  - Thread 3/4": 6 36 mm
  - Thread 1-1/2": 


    55 mm
- Maximum permissible tightening torque:
  - Thread 3/4": 45 Nm
  - Thread 1-1/2": 450 Nm
- Recommended torque when using the supplied aramid fiber seal and a process pressure of 40 bar (only FMP51, no seal is included with FMP54):
  - Thread 3/4": 25 Nm
  - Thread 1-1/2": 140 Nm
- When installing in metal vessels, ensure there is good metal contact between the process connection and the vessel.

# Mounting rope probes

# NOTICE

# Electrostatic discharge can damage the electronics.

▶ Ground the housing before lowering the rope probe into the vessel.



A0012852

Pay attention to the following when introducing the rope probe into the vessel:

- Uncoil the rope slowly and lower it carefully into the vessel.
- Make sure the rope does not bend or buckle.
- Avoid uncontrolled swinging of the weight, as this could damage internal fittings in the vessel.

# 6.2.4 Mounting the "Sensor, remote" version

This section only applies for devices with the version "Probe design" = "Sensor, remote" (feature 600, version MB/MC/MD).

The following is included in the delivery with the version "Probe design" = "Remote":

- The probe with process connection
- The electronics housing
- The mounting bracket for mounting the electronics housing on a wall or post
- The connection cable (length as ordered). The cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.

Levelflex FMP50 HART Mounting


# **A** CAUTION

Mechanical stress can damage the plugs of the connection cable or cause them to become loose.

- ► Mount the probe and the electronics housing securely before connecting the connecting cable.
- ► Lay the connecting cable in such a way that it is not exposed to mechanical stress. Minimum bending radius: 100 mm (4 in).
- ▶ When connecting the cable, connect the straight plug before you connect the angled plug. Torque for the union nuts of both plugs: 6 Nm.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

In the event of strong vibrations, a locking compound, e.g. Loctite 243, can also be used on the plug-in connectors.

# Mounting the electronics housing




■ 7 Mounting the electronics housing with the mounting bracket. Unit of measurement mm (in)

A Wall mounting

B Post mounting

# Connecting the connecting cable






- Connecting the connecting cable. The cable can be connected in the following ways:. Unit of measurement mm (in)
- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered

# 6.2.5 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned:




A00322

- 1. Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- 3. Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).

Levelflex FMP50 HART Mounting

# 6.2.6 Turning the display


### Opening the cover



A0021430

- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the electronics compartment cover and check the cover seal; replace it if necessary.


#### Turning the display module



A0036403

- 1. Pull out the display module with a gentle rotational movement.
- 2. Turn the display module to the desired position: Max.  $8 \times 45^{\circ}$  in each direction.
- 3. Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

# Closing the cover of the electronics compartment



A0021451

- 1. Screw down the cover of the electronics compartment.
- 2. Turn the securing clamp 90 ° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the electronics compartment cover with 2.5 Nm.

# 6.3 Post-installation check

☐ Is the device undamaged (visual inspection)?

Mounting Levelflex FMP50 HART

□ Does the device comply with the measuring point specifications?
■ Process temperature
■ Process pressure
■ Ambient temperature range
■ Measuring range
□ Are the measuring point identification and labeling correct (visual inspection)?
□ Is the device adequately protected against precipitation and direct sunlight?
□ Is the device adequately protected against impact?
□ Are all mounting and safety screws securely tightened?
□ Is the device properly secured?


Levelflex FMP50 HART Electrical connection

# 7 Electrical connection

# 7.1 Connecting requirements

# 7.1.1 Terminal assignment


#### Terminal assignment, 2-wire: 4 to 20 mA HART



■ 9 Terminal assignment, 2-wire: 4 to 20 mA HART

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection 4 to 20 mA, HART passive: terminals 1 and 2, without integrated overvoltage protection
- Connection 4 to 20 mA, HART passive: terminals 1 and 2, with integrated overvoltage protection
- 3 Terminal for cable shield

# Block diagram, 2-wire: 4 to 20 mA HART




■ 10 Block diagram, 2-wire: 4 to 20 mA HART

- 1 Active barrier for power supply (e.g. RN221N); observe terminal voltage
- Resistor for HART communication ( $\geq 250 \Omega$ ); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device

Electrical connection Levelflex FMP50 HART


# Terminal assignment, 2-wire: 4 to 20 mA HART, switch output



**■** 11 Terminal assignment, 2-wire: 4 to 20 mA HART, switch output

- Α Without integrated overvoltage protection В With integrated overvoltage protection
- Connection 4 to 20 mA, HART passive: terminals 1 and 2, without integrated overvoltage protection 1
- Connection, switch output (open collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection, switch output (open collector): terminals 3 and 4, with integrated overvoltage protection
- Connection 4 to 20 mA, HART passive: terminals 1 and 2, with integrated overvoltage protection
- Terminal for cable shield


#### Block diagram, 2-wire: 4 to 20 mA HART, switch output



#### ■ 12 Block diagram, 2-wire: 4 to 20 mA HART, switch output

- Active barrier for power supply (e.g. RN221N); observe terminal voltage 1
- 2 Resistor for HART communication ( $\geq 250 \Omega$ ); observe maximum load
- Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem) 3
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- Switch output (open collector)

### Terminal assignment, 2-wire: 4 to 20 mA HART, 4 to 20 mA



A0036500


■ 13 Terminal assignment, 2-wire: 4 to 20 mA HART, 4 to 20 mA

- Α Without integrated overvoltage protection
- With integrated overvoltage protection R
- 1 Connection current output 1, 4 to 20 mA HART passive: terminals 1 and 2, without integrated overvoltage protection
- Connection current output 2, 4 to 20 mA: terminals 3 and 4, without integrated overvoltage protection
- 3 Connection current output 2, 4 to 20 mA: terminals 3 and 4, with integrated overvoltage protection
- Connection current output 1, 4 to 20 mA HART passive: terminals 1 and 2, with integrated overvoltage 4 protection

Terminal for cable shield

Levelflex FMP50 HART Electrical connection

# Block diagram, 2-wire: 4 to 20 mAHART, 4 to 20 mA




A0036502

■ 14 Block diagram, 2-wire: 4 to 20 mAHART, 4 to 20 mA

- 1 Active barrier for power supply (e.g. RN221N), current output 1; observe terminal voltage
- Resistor for HART communication ( $\geq 250 \Omega$ ); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Analog display unit; observe maximum load
- 8 Active barrier for power supply (e.g. RN221N), current output 2; observe terminal voltage

# Terminal assignment, 4-wire: 4 to 20 mA HART (10.4 to 48 $V_{DC}$ )




A003651

 $\blacksquare$  15 Terminal assignment, 4-wire: 4 to 20 mA HART (10.4 to 48  $V_{DC}$ )

- Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- 3 Terminal for cable shield

# Block diagram, 4-wire: 4 to 20 mA HART (10.4 to 48 V<sub>DC</sub>)




 $\blacksquare$  16 Block diagram, 4-wire: 4 to 20 mA HART (10.4 to 48  $V_{DC}$ )

- 1 Evaluation unit, e.g. PLC
- 2 Resistor for HART communication ( $\geq 250 \Omega$ ); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Supply voltage; observe terminal voltage, observe cable specification

Electrical connection Levelflex FMP50 HART

# Terminal assignment, 4-wire: 4 to 20 mA HART (90 to 253 V<sub>AC</sub>)




- **■** 17 Terminal assignment, 4-wire: 4 to 20 mAHART (90 to 253  $V_{AC}$ )
- 1 Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- Terminal for cable shield

### **A** CAUTION

# To ensure electrical safety:

- ▶ Do not disconnect the protective ground connection.
- Disconnect the device from the supply voltage before disconnecting the protective ground.
- Connect protective ground to the inner ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the outer ground
- In order to ensure electromagnetic compatibility (EMC): do **not** ground the device exclusively via the protective ground conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

# Block diagram, 4-wire: 4 to 20 mA HART (90 to 253 V<sub>AC</sub>)




- Block diagram, 4-wire: 4 to 20 mA HART (90 to 253  $V_{AC}$ )
- Evaluation unit, e.g. PLC
- Resistor for HART communication ( $\geq 250 \Omega$ ); observe maximum load 2
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- Analog display unit; observe maximum load
- Cable screen; observe cable specification
- Measuring device
- Supply voltage; observe terminal voltage, observe cable specification


Levelflex FMP50 HART Electrical connection

# Connection examples for the switch output

For HART devices, the switch output is available as an option.



■ 19 Connection of a relay



■ 20 Connection to a digital input

- 1 Pull-up resistor
- 2 Digital input

For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or pull-up resistor) of  $< 1000 \Omega$ .

# 7.1.2 Cable specification

- Devices without integrated overvoltage protection
  Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection
   Screw terminals for wire cross-sections 0.2 to 2.5 mm<sup>2</sup> (24 to 14 AWG)
- For ambient temperature  $T_{IJ} \ge 60$  °C (140 °F): use cable for temperature  $T_{IJ} + 20$  K.


# **HART**

- A normal device cable suffices if only the analog signal is used.
- A shielded cable is recommended if using the HART protocol. Observe grounding concept of the plant.
- For 4-wire devices: Standard device cable is sufficient for the power line.

# 7.1.3 Device plug


In the case of the device versions with a plug, the housing does not need to be opened to connect the signal cable.

Electrical connection Levelflex FMP50 HART



■ 21 Pin assignment of M12 plug

- 1 Signal +
- Not assigned Signal -2
- 3
- Ground



■ 22 Pin assignment of 7/8" plug


- 1
- 2 3
- Signal -Signal + Not assigned Shielding

Levelflex FMP50 HART Electrical connection

# 7.1.4 Supply voltage

### 2-wire, 4-20mA HART, passive

2-wire; 4-20mA HART 1)



- 1) Feature 020 in the product structure: option  $\boldsymbol{A}$
- 2) Feature 010 in the product structure
- At ambient temperatures  $T_a \le -30$  °C, a terminal voltage  $U \ge 14$  V is required to start the device with the minimum failure current (3.6 mA). At ambient temperatures  $T_a > 60$  °C, a terminal voltage  $U \ge 12$  V is required to start the device with the minimum failure current (3.6 mA). The start-up current can be configured. If the device is operated with a fixed current  $I \ge 4.5$  mA (HART Multidrop mode), a voltage  $U \ge 11.5$  V in the entire ambient temperature range suffices.
- 4) If the Bluetooth module is used, the minimum supply voltage increases by 2  $\,\mathrm{V}.$
- 5) At ambient temperatures  $T_a \le -30$  °C, a terminal voltage  $U \ge 16$  V is required to start the device with the minimum failure current (3.6 mA).


Electrical connection Levelflex FMP50 HART

# 2-wire; 4-20 mA HART, switch output 1)

"Approval" <sup>2)</sup>	Terminal voltage U at device	Maximum load R, depending on the supply voltage $\mathbf{U}_0$ of the power supply unit
<ul> <li>Non-hazardous</li> <li>Ex nA</li> <li>Ex nA(ia)</li> <li>Ex ic</li> <li>Ex ic[ia]</li> <li>Ex d[ia] / XP</li> <li>Ex ta / DIP</li> <li>CSA GP</li> </ul>	13.5 to 35 V <sup>3) 4)</sup>	R [Ω]
<ul> <li>Ex ia / IS</li> <li>Ex ia + Ex d[ia] / IS + XP</li> </ul>	13.5 to 30 V <sup>3) 4)</sup>	0 10 20 30 U <sub>0</sub> [V] 13.5 24.5 35

- 1) Feature 020 in the product structure: option B
- 2) Feature 010 in the product structure
- At ambient temperatures  $T_a \le -30$  °C, a terminal voltage  $U \ge 16$  V is required to start the device with the minimum failure current (3.6 mA).
- 4) If the Bluetooth module is used, the minimum supply voltage increases by 2 V.

# 2-wire; 4-20mA HART, 4-20mA 1)



- 1) Feature 020 in the product structure: option C
- 2) Feature 010 in the product structure
- At ambient temperatures  $T_a \le -30$  °C, a terminal voltage  $U \ge 16$  V is required to start the device with the minimum failure current (3.6 mA).
- 4) At ambient temperatures  $T_a \le -40$  °C, the maximum terminal voltage must be limited to  $U \le 28$  V.
- 5) If the Bluetooth module is used, the minimum supply voltage increases by 2  $\,\mathrm{V}.$

Levelflex FMP50 HART Electrical connection

Integrated polarity reversal protection	Yes
Permitted residual ripple with f = 0 to 100 Hz	$U_{SS} < 1 \text{ V}$
Permitted residual ripple with f = 100 to 10000 Hz	U <sub>SS</sub> < 10 mV

Electrical connection Levelflex FMP50 HART

#### 4-wire, 4-20mA HART, active

"Power supply; output" 1)	Terminal voltage U	Maximum load R <sub>max</sub>
<b>K:</b> 4-wire 90-253VAC; 4-20mA HART	90 to 253 $V_{\text{AC}}$ (50 to 60 Hz), overvoltage category II	500 Ω
L: 4-wire 10.4-48VDC; 4-20mA HART	10.4 to 48 V <sub>DC</sub>	

Feature 020 in the product structure 1)

#### 7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse 8/20 µs), an overvoltage protection module has to be installed.

### Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	2 × 0.5 Ω max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 μs)	10 kA	

#### External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.



For detailed information please refer to the following documents:

■ HAW562: TI01012K ■ HAW569: TI01013K

#### 7.2 Connecting the device

#### **MARNING**

### **Explosion Hazard!**


- ▶ Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ▶ Use specified cable glands only.
- ► Check to ensure that the power supply matches the information on the nameplate.
- Switch off the power supply before connecting the device.
- ► Connect the potential matching line to the outer ground terminal before applying the power supply.

#### Required tools/accessories:

- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.

Levelflex FMP50 HART Electrical connection


# 7.2.1 Opening cover



A0021490


- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the connection compartment cover and check the cover seal; replace it if necessary.

# 7.2.2 Connecting



A003641

- 23 Engineering unit: mm (in)
- 1. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- 3. Strip the cable ends 10 mm (0.4 in). In the case of stranded cables, also fit wire end ferrules.
- 4. Firmly tighten the cable glands.
- 5. Connect the cable according to the terminal assignment.




A0034682

6. If using shielded cables: Connect the cable shield to the ground terminal.

# 7.2.3 Pluq-in spring-force terminals

The electrical connection of device versions without an integrated overvoltage protection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.

Electrical connection Levelflex FMP50 HART




■ 24 Engineering unit: mm (in)

A0013661

To remove the cable from the terminal again:

- 1. Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. Simultaneously pull the cable end out of the terminal.

# 7.2.4 Closing the cover of the connection compartment



A002149

- 1. Screw down the cover of the connection compartment.
- 2. Turn the securing clamp 90 ° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the connection compartment cover with 2.5 Nm.

# 7.3 Post-connection check

- ☐ Is the device or cable undamaged (visual inspection)?
- $\square$  Do the cables used comply with the requirements?
- ☐ Do the mounted cables have adequate strain relief?
- □ Are all the cable glands installed, firmly tightened and leak-tight?
- ☐ Does the supply voltage match the specifications on the nameplate?
- ☐ Is the terminal assignment correct?
- □ If necessary, has a protective ground connection been established?
- ☐ If supply voltage is present, is the device ready for operation and do values appear on the display module?
- ☐ Are all the housing covers installed and tightened?
- ☐ Is the securing clamp firmly tightened?

# 8 Operation methods


# 8.1 Overview

# 8.1.1 Local operation

Operation with	Pushbuttons	Touch Control
Order code for "Display; Operation"	Option C "SD02"	Option <b>E</b> "SD03"
Display elements	A-line display	4-line display white background lighting; switches to red in event of device error
	Format for displaying measured variables and st	catus variables can be individually configured
	Permitted ambient temperature for the display: The readability of the display may be impaired a range.	
Operating elements	local operation with 3 push buttons $( \boxdot, \boxdot, \sqsubseteq )$	external operation via touch control; 3 optical keys: ⊞, ⊡, 區
	Operating elements also accessible in various ha	izardous areas
Additional functionality	Data backup function The device configuration can be saved in the dis	play module.
	Data comparison function The device configuration saved in the display moton configuration.	odule can be compared to the current device
	Data transfer function The transmitter configuration can be transmitte	d to another device using the display module.

Operation methods Levelflex FMP50 HART

#### 8.1.2 Operation with remote display and operating module FHX50




**■** 25 *FHX50* operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover Display and operating module SD02, push buttons; cover must be removed

# 8.1.3 Operation via Bluetooth® wireless technology

# Requirements




■ 26 Device with Bluetooth module

- l Electronics housing of the device
- 2 Bluetooth module

This operation option is only available for devices with Bluetooth module. There are the following options:

- The device has been ordered with a Bluetooth module:
   Feature 610 "Accessory Mounted", option NF "Bluetooth"
- The Bluetooth module has been ordered as an accessory (ordering number: 71377355) and has been mounted. See Special Documentation SD02252F.

# Operation via SmartBlue (app)




A00349

■ 27 Operation via SmartBlue (app)

- 1 Transmitter power supply unit
- 2 Smartphone / tablet with SmartBlue (app)
- 3 Transmitter with Bluetooth module

#### 8.1.4 Remote operation


# Via HART protocol



**28 2** Options for remote operation via HART protocol

- 1 PLC (programmable logic controller)
- Transmitter power supply unit, e.g., RN42 2
- 3 Connection for Commubox FXA195 and AMS  $Trex^{TM}$  device communicator
- AMS  $Trex^{TM}$  device communicator 4
- 5 Computer with operating tool (e.g., DeviceCare/FieldCare, AMS Device View, SIMATIC PDM)
- 6 Commubox FXA195 (USB)
- Field Xpert SMT70
- Bluetooth modem with connecting cable (e.g., VIATOR)
- Transmitter

# Via service interface (CDI)



A0039148

- Computer with FieldCare/DeviceCare operating tool
- 2 Commubox FXA291
- Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)

# 8.2 Structure and function of the operating menu

# 8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Language <sup>1)</sup>	Defines the operating language of the local display
Commissioning <sup>2)</sup>		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1  Parameter N	Once values have been set for these parameters, the measurement should generally be completely configured.
	Advanced setup	Contains additional submenus and parameters:  For more customized configuration of the measurement (adaptation to special measuring conditions).  For converting the measured value (scaling, linearization).  For scaling the output signal.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat 4)	Contains all the wizards for the <b>Heartbeat Verification</b> and <b>Heartbeat Monitoring</b> application packages.
Expert 5) Contains all the parameters of the device (including those that are already contained in one of the other menus). This menu is	System	Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication.
organized according to the function blocks of the device.	Sensor	Contains all parameters needed to configure the measurement.
The parameters of the Expert menu are described in: GP01000F (HART)	Output	<ul> <li>Contains all parameters needed to configure the analog current output.</li> <li>Contains all parameters needed to configure the switch output (PFS).</li> </ul>

Operation methods Levelflex FMP50 HART

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

- 1) If you are operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup ri you are operating via operating tools (e.g. FieldCare), the Language parameter is located under Setup

  → Advanced setup → Display"

  Only if operating via an FDT/DTM system

  Only available if operating via the local display

  Only available if operating via DeviceCare or FieldCare

  When you call up the "Expert" menu, you are always asked for an access code. If a customer-specific access
- 2)
- 3)
- 4) 5) code has not been defined, "0000" must be entered.

#### 8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access (Verweisziel existiert nicht, aber @y.link.required='true').

Access authorization to parameters

User role	Read access		Write	access
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	~	V	
Maintenance	V	~	V	~

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.



The user role with which the user is currently logged on is indicated by the **Access status display** parameter (for display operation) or **Access status tooling** parameter (for tool operation).

# 8.2.3 Data access - Security

#### Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

#### Define access code via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
   Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the numeric code in the **Confirm access code** parameter to confirm it.
  - ightharpoonup The ightharpoonup-symbol appears in front of all write-protected parameters.

#### Define access code via operating tool (e.g. FieldCare)

- 1. Navigate to: Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Define access code
- 2. Define a max. 4-digit numeric code as an access code.
  - ▶ Write protection is active.

#### Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. If the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after 60 s.



- In the "Description of Device Parameters" documents, each write-protected parameter is identified with the 🛍-symbol.

Operation methods Levelflex FMP50 HART

### Disabling write protection via access code

If the  $\square$  symbol appears in front of a parameter on the local display, the parameter is write-protected by a device-specific access code and its value cannot currently be changed via the local display  $\rightarrow \square$  57.

The locking of the write access via local operation can be disabled by entering the device-specific access code.

- 1. After you press E, the input prompt for the access code appears.
- 2. Enter the access code.
  - The \( \mathbb{O}\)-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

### Deactivation of the write protection via access code

# Via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
   Define access code
- 2. Enter **0000**.
- 3. Repeat **0000** in the **Confirm access code** parameter to confirm.
  - The write protection is deactivated. Parameters can be changed without entering an access code.

#### Via an operating tool (e.g. FieldCare)


- 1. Navigate to: Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Define access code
- 2. Enter **0000**.
  - The write protection is deactivated. Parameters can be changed without entering an access code.

# Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display"** parameter.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via service interface (CDI)
- Via HART protocol



1000/455

- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.




A0036086

Operation methods Levelflex FMP50 HART

4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter. In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter. On the local display, the  $\square$  symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

### Enabling and disabling the keypad lock

Access to the entire operating menu via local operation can be locked via the keypad lock. When access is locked, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via a context menu.

Switching on the keypad lock

# SD03 display module only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

### To activate the keylock manually:

1. The device is in the measured value display.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
  - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock off** option.
  - ► The keypad lock is switched off.

### Bluetooth® wireless technology


Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue app
- Only one point-to-point connection between one sensor and one smartphone or tablet is established

Operation methods Levelflex FMP50 HART

# 8.3 Display and operating module

# 8.3.1 Display



■ 29 Display format on the display and operating module

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (bar graph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Parameter display (here: parameter with picklist)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Picklist;  $\square$  marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

# Display symbols for the submenus

Symbol	Meaning
A0018367	Display/operat. Is displayed: In the main menu next to the "Display/operat." selection In the header on the left in the "Display/operat." menu
A0018364	Setup Is displayed: In the main menu next to the "Setup" selection In the header on the left in the "Setup" menu
A0018365	Expert Is displayed: In the main menu next to the "Expert" selection In the header on the left in the "Expert" menu
A0018366	Diagnostics Is displayed: In the main menu next to the "Diagnostics" selection In the header on the left in the "Diagnostics" menu

# Status signals

Symbol	Meaning
A0032902	<b>"Failure"</b> A device error has occurred. The measured value is no longer valid.
<b>C</b>	<b>"Function check"</b> The device is in the service mode (e.g. during a simulation).
<b>S</b>	<ul> <li>"Out of specification"</li> <li>The device is operated:</li> <li>Outside of its technical specifications (e.g. during startup or a cleaning)</li> <li>Outside of the configuration performed by the user (e.g. level outside the configured range)</li> </ul>
<b>M</b>	"Maintenance required" Maintenance is required. The measured value is still valid.

# Display symbols for locking status

Symbol	Meaning
A0013148	Read-only parameter The parameter shown is only for display purposes and cannot be edited.
	Device locked
A0013150	<ul> <li>In front of a parameter name: The device is locked via software and/or hardware.</li> <li>In the header of the measured value screen: The device is locked via hardware.</li> </ul>

Operation methods Levelflex FMP50 HART

# Measured value symbols


Symbol	Meaning
Measured values	
<b> </b> ~~	Level
A0032892	
A0032893	Distance
<b>(</b>	Current output
A0032908	
(A)	Measured current
A0032894	
(V)	Terminal voltage
A0032895	
1	Electronics or sensor temperature
A0032896	
Measuring channels	
<u>(1)</u>	Measuring channel 1
A0032897	
2	Measuring channel 2
A0032898	
Status of the measure	d value
	"Alarm" status
A0018361	The measurement is interrupted. The output assumes the defined alarm condition. A diagnostic message is generated.
$\wedge$	"Warning" status
A0018360	The device continues to measure. A diagnostic message is generated.

# 8.3.2 Operating elements

Key	Meaning
A0018330	Minus key
	In a menu, submenu Moves the selection bar upwards in a picklist.
	In the text and numeric editor In the input mask, moves the selection bar to the left (backwards).
	Plus key
A0018329	In a menu, submenu Moves the selection bar downwards in a picklist.
	In the text and numeric editor In the input mask, moves the selection bar to the right (forwards).
	Enter key
A0018328	For measured value display  ■ Pressing the key briefly opens the operating menu.  ■ Pressing the key for 2 s opens the context menu.
	<ul> <li>In a menu, submenu</li> <li>Pressing the key briefly: Opens the selected menu, submenu or parameter. </li> <li>Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter.</li> </ul>
	<ul> <li>In the text and numeric editor</li> <li>Pressing the key briefly:</li> <li>Opens the selected group.</li> <li>Carries out the selected action.</li> <li>Pressing the key for 2 s confirms the edited parameter value.</li> </ul>
	Escape key combination (press keys simultaneously)
— + <b>+</b>	<ul> <li>In a menu, submenu</li> <li>Pressing the key briefly:</li> <li>Exits the current menu level and takes you to the next higher level.</li> <li>If help text is open, closes the help text of the parameter.</li> <li>Pressing the key for 2 s returns you to the measured value display ("home position").</li> </ul>
	In the text and numeric editor Closes the text or numeric editor without applying changes.
—+E	Minus/Enter key combination (press and hold down the keys simultaneously)
	Reduces the contrast (brighter setting).
++E A0032911	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).

Operation methods Levelflex FMP50 HART

# 8.3.3 Entering numbers and text



# Input mask


The following input and operating symbols are available in the input mask of the numeric and text editor:

# Numeric editor

Symbol	Meaning	
0	Selection of numbers from 0 to 9.	
<b>9</b> A0013998		
A0016619	Inserts decimal separator at the cursor position.	
A0016620	Inserts minus sign at the cursor position.	
A0013985	Confirms selection.	
A0016621	Moves the input position one position to the left.	
X A0013986	Exits the input without applying the changes.	
<b>C</b>	Clears all entered characters.	

# Text editor

Symbol	Meaning
ABCXYZ	Selection of letters from A to Z



*Text correction under ₹C←∃* 

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
4	Moves the input position one position to the left.
A0018326	
<b>₹</b> ×	Deletes one character immediately to the left of the input position.
A0032906	

# 8.3.4 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Envelope curve
- Keylock on

# Calling up and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
  - ► The context menu opens.



A003787

- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - └ The context menu is closed and the operational display appears.

# Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.


Operation methods Levelflex FMP50 HART

3. Press **E** to confirm the selection.

► The selected menu opens.

# 8.3.5 Envelope curve display on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be shown on the display and operating module:



# 9 Device integration via the HART protocol

# 9.1 Overview of the Device Description files (DD)

#### HART

Manufacturer ID	0x11
Device type	0x1122
HART specification	7.0
DD files	For information and files see:  www.endress.com www.fieldcommgroup.org

# 9.2 HART device variables and measuring values

On delivery the following measuring values are assigned to the HART device varaibles:

Device variables for level measurements

Device variable	Measuring value
Primary variable (PV)	Level linearized
Secondary variable (SV)	Unfiltered distance
Tertiary variable (TV)	Absolute echo amplitude
Quaternary variable (QV)	Relative echo amplitude

The allocation of the measuring values to the device variables can be changed in the following submenu:

Expert  $\rightarrow$  Communication  $\rightarrow$  Output

# 10 Commissioning via SmartBlue (App)

# 10.1 Prerequisites

#### **System requirements**

The SmartBlue app is available for download for use with a smartphone or tablet.

- iOS devices: iPhone 5S or higher from iOS11; iPad 5th generation or higher from iOS11; iPod Touch 6th generation or higher from iOS11
- Devices with Android: from Android 6.0 and Bluetooth® 4.0

### Initial password

The serial number of the device serves as the initial password when the connection is established for the first time.

Note the following if the Bluetooth module is removed from one device and installed in another device: the password that is changed by the user is only saved in the Bluetooth module and not in the device itself.

# 10.2 SmartBlue App

1. Scan the QR code or enter "SmartBlue" in the search field of the App Store.



A003918


- 30 Download link
- 2. Start SmartBlue.
- 3. Select device from livelist displayed.
- 4. Enter the login data:
  - User name: admin Password: serial number of the device
- 5. Tap the icons for more information.
- After logging in for the first time, change the password!

# 10.3 Envelope curve display in SmartBlue

Envelope curves can be displayed and recorded in SmartBlue.

In addition to the envelope curve, the following values are displayed:

- D = Distance
- L = Level
- A = Absolute amplitude
- With screenshots, the displayed section (zoom function) is saved
- With video sequences, the whole area without zoom function is saved all the time



🖪 31 Envelope curve display (sample) in SmartBlue for Android

- 1 Record video
- 2 Create screenshot
- 3 Display mapping menu
- 4 Start/stop video recording
- 5 Move time on time axis




■ 32 Envelope curve display (sample) in SmartBlue for iOS

- 1 Record video
- 2 Create screenshot
- 3 Display mapping menu
- 4 Start/stop video recording
- Move time on time axis

# 11 Commissioning using the Commissioning Wizard

A Wizard is provided in FieldCare and DeviceCare <sup>1)</sup> that guides the user through the initial commissioning process.

- 1. Connect the device with FieldCare or DeviceCare.
- 2. Open the device in FieldCare or DeviceCare.
  - ► The dashboard (homepage) of the device is displayed:



A002586

- 1 "Commissioning" button calls up the wizard
- 3. Click "Commissioning" to launch the Wizard.
- 4. Enter the appropriate value in each parameter or select the appropriate option. These values are written directly to the device.
- 5. Click "Next" to go to the next page.
- 6. Once all the pages have been completed, click "Finish" to close the Wizard.
- If you cancel the Wizard before all the necessary parameters have been entered, the device may be in an undefined state. In such situations, it is advisable to reset the device to the factory default settings.

<sup>1)</sup> DeviceCare is available for download at www.software-products.endress.com. To download the software, it is necessary to register in the Endress +Hauser software portal.


## 12 Commissioning via operating menu

### 12.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:


### 12.2 Setting the operating language

Factory setting: English or ordered local language



33 Taking the example of the local display

### 12.3 Configuring level measurement



34 Configuration parameters for level measurement in liquids

- LN Probe length
- R Reference point of measurement
- D Distance
- L Level
- E Empty calibration (= zero point)
- F Full calibration (= span)
- If the  $\varepsilon_r$  value is lower than 7 in the case of rope probes, measurement is not possible in the area of the tensioning weight. The empty calibration E should not exceed LN 250 mm (LN 10 in) in these cases.
- 1. Setup → Device tag
  - ► Enter device tag.
- 2. Navigate to: Setup  $\rightarrow$  Distance unit
  - ► Select the distance unit.
- 3. Navigate to: Setup → Tank type
  - ► Select tank type.
- 4. For **Tank type** parameter = Bypass / pipe:

Navigate to: Setup → Tube diameter

- ► Specify the diameter of the bypass or stilling well.
- 5. Navigate to: Setup → Medium group
  - ► Specify the medium group: (Water based (DC >= 4) or Others)
- 6. Navigate to: Setup → Empty calibration
  - ► Specify the empty distance E (distance from reference point R to 0% mark).
- 7. Navigate to: Setup  $\rightarrow$  Full calibration
  - ► Specify the full distance F (distance from the 0% mark to the 100% mark).
- 8. Navigate to: Setup → Level
  - ► Displays the measured level L.
- 9. Navigate to: Setup → Distance
  - └ Displays the distance D between the reference point R and the level L.
- 10. Navigate to: Setup  $\rightarrow$  Signal quality
  - └ Displays the signal quality of the analyzed level echo.

11. Operation via local display:

Navigate to: Setup → Mapping → Confirm distance

- Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).
- 12. Operation via operating tool:

Navigate to: Setup → Confirm distance

Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).

### 12.4 Recording the reference envelope curve

After the measurement has been configured, it is recommended to record the current envelope curve as a reference envelope curve. This can then be used later for diagnostic purposes. The **Save reference curve** parameter is used to record the envelope curve.

#### Path in the menu

Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Envelope diagnostics  $\rightarrow$  Save reference curve

### Meaning of the options

- No
  - No action
- Yes

The current envelope curve is saved as a reference curve.

- This submenu is only visible for the "Service" user role in devices supplied with software version 01.00.zz or 01.01.zz.
- The reference envelope curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. The "Load Reference Curve" function in FieldCare is used for this.



■ 35 "Load Reference Curve" function

## 12.5 Configuring the local display

### 12.5.1 Factory setting of local display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

### 12.5.2 Adjusting the local display

The local display can be adjusted in the following submenu: Setup  $\to$  Advanced setup  $\to$  Display

## 12.6 Configuring the current outputs

### 12.6.1 Factor setting of current outputs for level measurements

<b>Current output</b>	Assigned measured value	4mA value	20mA value
1	Level linearized	0% or the corresponding linearized value	100% or the corresponding linearized value
2 1)	Relative echo amplitude	0 mV	2 000 mV

<sup>1)</sup> For devices with two current outputs

### 12.6.2 Adjusting the current outputs

The current outputs can be adjusted in the following submenus:

### **Basic settings**

Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Current output 1 to 2

### Advanced settings

Expert  $\rightarrow$  Output  $\overset{\frown}{1}$  to  $\overset{\frown}{2}$   $\rightarrow$  Current output 1 to 2 See "Description of Device Parameters" GP01000F

### 12.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and the options available.

#### Path in the menu

Setup → Advanced setup → Configuration backup display → Configuration management

### Meaning of the options

#### Cancel

No action is executed and the user exits the parameter.

#### Execute backup

A backup copy of the current device configuration is saved from the HistoROM (integrated in the device) to the display module of the device.

#### Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

### Duplicate

The transmitter configuration of the device is duplicated to another device using the display module. The following parameters, which characterize the individual measuring point are **not** transferred:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type

### Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of the comparison is displayed in the **Comparison result** parameter.

### Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup copy is restored on a device other than the original device using the **Restore** option, in some cases individual device functions may not be available. In some cases it is also not possible to restore the original state by resetting to the "asdelivered" state.

The **Duplicate** option should always be used to copy the configuration to another device.

## 12.8 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in two ways:

- Locking via parameters (software locking)
- Locking via write protection switch (hardware locking)

## 13 Diagnostics and troubleshooting

## 13.1 General troubleshooting

### 13.1.1 General errors

Error	Possible cause	Solution
Device does not respond.	Supply voltage does not match the value indicated on the nameplate.	Connect the correct voltage.
	The polarity of the supply voltage is wrong.	Correct the polarity.
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.
Values on the display invisible	Contrast setting is too weak or too strong.	<ul> <li>Increase contrast by pressing ± and E simultaneously.</li> <li>Decrease contrast by pressing □ and E simultaneously.</li> </ul>
	The plug of the display cable is not connected correctly.	Connect the plug correctly.
	Display is defective.	Replace display.
"Communication error" is	Electromagnetic interference	Check grounding of the device.
indicated on the display when starting the device or connecting the display.	Broken display cable or display plug.	Replace display.
Duplication of parameters via display from one device to another not working. Only the "Save" and "Cancel" options are available.	Display with backup is not properly detected if a data backup was not carried out on the new device previously.	Connect display (with backup) and restart device.
Output current <3.6 mA	Signal cable connection incorrect.	Check connection.
	Electronics module is defective.	Replace electronics.
HART communication does not function.	Communication resistor missing or incorrectly installed.	Install the communication resistor (250 $\Omega$ ) correctly.
	Commubox is connected incorrectly.	Connect Commubox correctly.
	Commubox is not set to "HART".	Set Commubox selector switch to "HART".
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.
Device measures incorrectly.	Parameter configuration error	Check and correct the parameter configuration.
No communication with device via SmartBlue	No Bluetooth connection	Enable Bluetooth function on smartphone or tablet
	The device is already connected with another smartphone/tablet	Disconnect the device from the other smartphone/tablet
	Bluetooth module not connected	Connect Bluetooth module (see SD02252F).
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of Bluetooth module) and change it

Error	Possible cause	Solution
Device cannot be operated via SmartBlue	Incorrect password entered	Enter the correct password, paying attention to lower/upper case
Device cannot be operated via SmartBlue	Password forgotten	Contact Endress+Hauser Service (www.addresses.endress.com)

## 13.1.2 Error - SmartBlue operation

Error	Possible cause	Solution
Device is not visible in the	No Bluetooth	Enable Bluetooth® function on smartphone or tablet
live list	connection	Bluetooth® function of sensor disabled, perform recovery sequence
Device is not visible in the live list	The device is already connected with another smartphone/tablet	Only <b>one</b> point-to-point connection is established between a sensor and a smartphone or tablet
Device is visible in the live list but cannot be accessed via	Android end device	Is the location function enabled for the app, was it approved the first time?
SmartBlue		GPS or positioning function must be activated for certain Android versions in conjunction with Bluetooth®
		Activate GPS - close the app fully and restart - enable the positioning function for the app
Device is visible in the live list but cannot be accessed via SmartBlue	Apple end device	Log in as standard Enter user name "admin" Enter initial password (ID of the Bluetooth module) paying attention to lower/upper case
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of the Bluetooth module) and change; paying attention to lower/upper case
Device cannot be operated via SmartBlue	Incorrect password entered	Enter correct password
Device cannot be operated via SmartBlue	Password forgotten	Contact the Endress+Hauser Service department (www.addresses.endress.com)

### 13.1.3 Parametrization errors


Parametrization errors for level measurements

Problem	Possible cause	Remedy
Measured value is incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	<ul> <li>Check the Empty calibration parameter (→</li></ul>
	If measured distance (Setup → Distance) does not match the real distance: An interference echo is present.	Carry out mapping ( <b>Confirm distance</b> parameter (→ 🖺 131)).
No change of measured value on filling/emptying	An interference echo is present.	Carry out mapping ( <b>Confirm distance</b> parameter (→ 🖺 131)).
	Buildup at the probe.	Clean the probe.
	Error in the echo tracking.	Deactivate echo tracking (Expert → Sensor → Echo tracking → Evaluation mode = <b>History off</b> ).
Echo lost diagnostic message appears after the supply voltage is switched on.	Echo threshold too high.	Check the <b>Medium group</b> parameter $(\rightarrow \boxminus 127)$ . If necessary, select a more detailed setting with the <b>Medium property</b> parameter $(\rightarrow \boxminus 136)$ .
	Level echo suppressed.	Delete the map and record it again if necessary ( <b>Record map</b> parameter (→ 🖺 132)).
Device displays a level when the tank is empty.	Incorrect probe length	Perform probe length correction (Confirm probe length parameter (→ 🖺 157)).
	Interference echo	Carry out mapping over the entire probe length when the tank is empty ( <b>Confirm distance</b> parameter (→ 🖺 131)).
Wrong slope of the level over the entire measuring range	Wrong tank type selected.	Select the correct <b>Tank type</b> parameter $(\rightarrow \ \ \ )$ 126).

## 13.2 Diagnostic information on local display

### 13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



### Status signals


A0032902	"Failure (F)" option A device error has occurred. The measured value is no longer valid.
<b>C</b>	"Function check (C)" option The device is in the service mode (e.g. during a simulation).
<b>S</b>	<ul> <li>"Out of specification (S)" option</li> <li>The device is operated:</li> <li>Outside of its technical specifications (e.g. during startup or a cleaning)</li> <li>Outside of the configuration performed by the user (e.g. level outside the configured range)</li> </ul>
<b>M</b>	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

### Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs adopt the defined alarm condition. A diagnostic message is generated.
Δ	"Warning" status The device continues to measure. A diagnostic message is generated.

### Diagnostic event and event text

The fault can be identified by means of the diagnostic event. The event text helps you by providing information about the fault. In addition, the associated status symbol is displayed in front of the diagnostic event.



If two or more diagnostic events occur simultaneously, only the diagnostic message with the highest priority is shown. Additional queued diagnostic messages can be shown in the **Diagnostic list** submenu.



Past diagnostic messages that are no longer pending are shown as follows:


- On the local display:
- In the **Event logbook** submenu
- In FieldCare:

Via the "Event List /HistoROM" function.

### Operating elements

Operating functions in menu, submenu	
+	Plus key Opens the message about the remedial measures.
E	Enter key Opens the operating menu.

### 13.2.2 Calling up remedial measures



A0029431-EN

- 36 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (① symbol).
  - ► The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with  $\pm$  or  $\Box$  and press  $\Box$ .
  - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** or in **Previous diagnostics**.

- 1. Press E.
  - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.

88


### 13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)


### A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
  - In the **Actual diagnostics** parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.




A tool tip with remedial measures for the diagnostic event appears.

### B: Via the "Create documentation" function




Select the "Create documentation" function.



Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
  - └ The protocol contains the diagnostic messages and remedy information.

### C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.



Select the "Load Eventlist" function.

The list of events, including remedy information, is shown in the "Data overview" window.

### 13.4 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

### Navigation path

Diagnostics → Diagnostic list

### Calling up and closing the remedial measures

- 1. Press E.
  - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.

## 13.5 List of diagnostic events

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of s	ensor			
003	Broken probe detected	1. Check map 2. Check sensor	F	Alarm
046	Build-up detected	Clean sensor	F	Alarm
104	HF cable	and check sealing  1. Dry HF cable connection  2. Change HF cable	F	Alarm
105	HF cable	Tighten HF cable connection     Check sensor     Change HF cable	F	Alarm
106	Sensor	Check sensor     Check HF cable     Contact service	F	Alarm
Diagnostic of e	lectronic		l.	<b>'</b>
242	Software incompatible	Check software     Flash or change main electronics module	F	Alarm
252	Modules incompatible	Check if correct electronic modul is plugged     Replace electronic module	F	Alarm
261	Electronic modules	Restart device     Check electronic modules     Change I/O Modul or main electronics	F	Alarm
262	Module connection	Check module connections     Change electronic modules	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	Restart device     Change main electronic module	F	Alarm
272	Main electronic failure	Restart device     Contact service	F	Alarm
273	Main electronic failure	Emergency operation via display     Change main electronics	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	1. Restart device	F	Alarm
276	I/O module faulty	2. Change I/O module	F	Alarm
282	Data storage	Restart device     Contact service	F	Alarm
283	Memory content	Transfer data or reset device     Contact service	F	Alarm
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	M	Warning
Diagnostic of c	onfiguration			
410	Data transfer	Check connection     Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
412	Processing download	Download active, please wait	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
431	Trim 1 to 2	Carry out trim	С	Warning
435	Linearization	Check linearization table	F	Alarm
437	Configuration incompatible	Restart device     Contact service	F	Alarm
438	Dataset	Check data set file     Check device configuration     Up- and download new configuration	М	Warning
441	Current output 1 to 2	Check process     Check current output settings	S	Warning
484	Failure mode simulation	Deactivate simulation	С	Alarm
485	Simulation measured value	Deactivate simulation	С	Warning
491	Current output 1 to 2 simulation	Deactivate simulation	С	Warning
494	Switch output simulation	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation	Deactivate simulation	С	Warning
585	Simulation distance	Deactivate simulation	С	Warning
Diagnostic of pr	rocess			1
801	Energy too low	Increase supply voltage	S	Warning
803	Current loop	Check wiring     Change I/O module	F	Alarm
825	Operating temperature	Check ambient temperature	S	Warning
825	Operating temperature	2. Check process temperature	F	Alarm
921	Change of reference	Check reference configuration     Check pressure     Check sensor	S	Warning
936	EMC interference	Check installation on EMC	F	Alarm
941	Echo lost	Check parameter 'DC value'	F	Alarm 1)
942	In safety distance	Check level     Check safety distance     Reset self holding	S	Alarm 1)
943	In blocking distance	Reduced accuracy Check level	S	Warning
944	Level range	Reduced accuracy Level at process connection	S	Warning
950	Advanced diagnostic 1 to 2 occured	Maintain your diagnostic event	М	Warning <sup>1)</sup>

<sup>1)</sup> Diagnostic behavior can be changed.

### 13.6 Event logbook

### 13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu <sup>2)</sup>.

#### Navigation path

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - ᢒ: Event has occurred
  - 🕒: Event has ended
- Information event
  - €: Event has occurred

### Calling up and closing the remedial measures

- 1. Press E
  - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.

### 13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

#### Navigation path

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Filter options

### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

### 13.6.3 Overview of information events

Info number	Info name
11000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed


<sup>2)</sup> This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Info number	Info name		
I1092	Embedded HistoROM deleted		
I1110	Write protection switch changed		
I1137	Electronic changed		
I1151	History reset		
I1154	Reset terminal voltage min/max		
I1155	Reset electronic temperature		
I1156	Memory error trend		
I1157	Memory error event list		
I1184	Display connected		
I1185	Display backup done		
I1186	Restore via display done		
I1187	Settings downloaded with display		
I1188	Display data cleared		
I1189	Backup compared		
I1256	Display: access status changed		
I1264	Safety sequence aborted		
I1335	Firmware changed		
I1397	Fieldbus: access status changed		
I1398	CDI: access status changed		
I1512	Download started		
I1513	Download finished		
I1514	Upload started		
I1515	Upload finished		
I1554	Safety sequence started		
I1555	Safety sequence confirmed		
I1556	Safety mode off		

## 13.7 Firmware history

Date	Firmware version	Modifications	Documentation (FMP50, HART)		
			Operating Instructions	Description of Device Parameters	Technical Information
07.2010	01.00.zz	Original software	BA01000F/00/EN/05.10	GP01000F/00/EN/05.10	TI01000F/00/EN/05.10
01.2011	01.01.zz	<ul> <li>SIL integrated</li> <li>Improvements and bugfixes</li> <li>Additional languages</li> </ul>	<ul> <li>BA01000F/00/EN/10.10</li> <li>BA01000F/00/EN/13.11</li> <li>BA01000F/00/EN/14.12</li> </ul>	• GP01000F/00/EN/10.10 • GP01000F/00/EN/13.11	<ul> <li>TI01000F/00/EN/10.10</li> <li>TI01000F/00/EN/13.11</li> <li>TI01000F/00/EN/14.12</li> <li>TI01000F/00/EN/15.12</li> </ul>
02.2014	01.02.zz	<ul> <li>Support of SD03</li> <li>Additional languages</li> <li>HistoROM functionality enhanced</li> <li>"Advanced Diagnostics" function block integrated</li> <li>Improvements and bugfixes</li> </ul>	<ul><li>BA01000F/00/EN/15.13</li><li>BA01000F/00/EN/16.14</li></ul>	• GP01000F/00/EN/14.13 • GP01000F/00/EN/15.14	■ TI01000F/00/EN/16.13 ■ TI01000F/00/EN/17.14
04.2016	01.03.zz	<ul> <li>Update to HART 7</li> <li>All 17 languages available in the device</li> <li>Improvements and bugfixes</li> </ul>	<ul> <li>BA01000F/00/EN/17.16</li> <li>BA01000F/00/EN/ 18.16 1)</li> <li>BA01000F/00/EN/ 20.18 2)</li> </ul>	GP01000F/00/EN/16.16	<ul> <li>TI01000F/00/EN/18.16</li> <li>TI01000F/00/EN/20.16 <sup>1)</sup></li> <li>TI01000F/00/EN/22.18 <sup>2)</sup></li> </ul>

- 1) Contains information on the Heartbeat wizards available in the current DTM version for DeviceCare and FieldCare.
- 2) Contains information on the Bluetooth interface.



Maintenance Levelflex FMP50 HART

### 14 Maintenance

No special maintenance work is required.

### 14.1 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not corrode the surface of the housing and the seals.

### 14.2 General cleaning instructions

Dirt or buildup may form on the probe depending on the application. A thin, even layer has little impact on the measurement. Thick layers can dampen the signal and reduce the measuring range. Very uneven deposit formation or caking (e.g. due to crystallization) can result in incorrect measurements. In such cases, use a non-contact measuring principle, or regularly inspect the probe for contamination.

Cleaning with sodium hydroxide solution (e.g. in CIP procedures): if the coupling is wetted, larger measurement errors can occur than under reference operating conditions. Wetting can cause temporary incorrect measurements.

Levelflex FMP50 HART Repair

## 15 Repair

### 15.1 General information

### 15.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs can be carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

### 15.1.2 Repair of Ex-certified devices

### **A** WARNING

### Incorrect repair can compromise electrical safety!

Explosion Hazard!

- ► Repairs to Ex-certified devices must be carried out by Endress+Hauser Service or by specialist personnel according to national regulations.
- Relevant standards and national regulations on hazardous areas, safety instructions and certificates must be observed.
- ▶ Use only original Endress+Hauser spare parts.
- ► Please note the device designation on the nameplate. Only identical parts may be used as replacements.
- ► Carry out repairs according to the instructions.
- ▶ Only the Endress+Hauser service team is permitted to modify a certified device and convert it to another certified version.

### 15.1.3 Replacing electronics modules

When electronics modules have been replaced the device does not need to be recalibrated as the parameters are saved in the HistoROM inside the housing. It may be necessary when replacing the main electronics to record a new interference echo suppression.

### 15.1.4 Replacing a device

Once a complete device has been replaced, the parameters can be transferred back into the device using one of the following methods:

- Using the display module
   Prerequisite: The configuration of the old device was saved previously to the display module.
- Via FieldCare
   Prerequisite: The configuration of the old device was saved previously to the computer using FieldCare.

You can continue measuring without performing a new calibration. Only interference echo suppression may need to be carried out once again.


Repair Levelflex FMP50 HART

### 15.2 Spare parts

• Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.

- In the connection compartment cover of the device there is a spare part nameplate which contains the following information:
  - A list of the most important spare parts for the measuring device, including their ordering information.
  - The URL to the W@M Device Viewer (www.endress.com/deviceviewer):

    All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



A00149

■ 37 Example for spare part nameplate in the connection compartment cover

- Measuring device serial number:
  - Located on the device and spare part nameplate.
  - Can be read out via the "Serial number" parameter in the "Device information" submenu.

### 15.3 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the web page for information: http://www.endress.com/support/return-material
  - ► Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

### 15.4 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.


Levelflex FMP50 HART Accessories

## 16 Accessories


## 16.1 Device-specific accessories

### 16.1.1 Weather protection cover

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.



🖪 38 Height. Unit of measurement mm (in)



 $\blacksquare$  39 Dimensions. Unit of measurement mm (in)

### Material


316L

### Order number for accessories:

71162242


Accessories Levelflex FMP50 HART

### 16.1.2 Mounting bracket for electronics housing




Levelflex FMP50 HART Accessories

### 16.1.3 Mounting kit, insulated




Accessories Levelflex FMP50 HART

### 16.1.4 Centering star



### 16.1.5 Remote display FHX50



Levelflex FMP50 HART Accessories

#### Technical data

- Material:
  - Plastic PBT
  - 316L/1.4404
  - Aluminum
- Degree of protection: IP68 / NEMA 6P and IP66 / NEMA 4x
- Suitable for display modules:
  - SD02 (push buttons)
  - SD03 (touch control)
- Connecting cable:
  - Cable supplied with device up to 30 m (98 ft)
  - Standard cable supplied by customer up to 60 m (196 ft)
- Ambient temperature:-40 to 80 °C (-40 to 176 °F)

### **Ordering information**

• If the remote display is to be used, the device version "Prepared for display FHX50" must be ordered.

For the FHX50, the option "Prepared for display FHX50" must be selected under "Measuring device version".

- If a measuring device has not been ordered with the version "Prepared for display FHX50" and is to be retrofitted with an FHX50, the version "Not prepared for display FHX50" must be ordered for the FHX50 under "Measuring device version". In this case, a retrofit kit for the device is supplied with the FHX50. The kit can be used to prepare the device so that the FHX50 can be used.
- Use of the FHX50 may be restricted for transmitters with an approval. A device may only be retrofitted with the FHX50 if the option "Prepared for FHX50" is listed in the associated Safety Instructions (XA) under *Basic specifications*, "Display, operation".

Also pay attention to the Safety Instructions (XA) of the FHX50.

Retrofitting is not possible on transmitters with:


- An approval for use in areas with flammable dust (dust ignition-proof approval)
- Type of protection Ex nA
- For details, see the "Special Documentation" SD01007F

### 16.1.6 Overvoltage protection

The surge arrester for loop-powered devices can be ordered together with the device via the "Accessory mounted" section of the product order structure.

The surge arrester can be used for loop-powered devices.

- 1-channel devices OVP10
- 2-channel devices OVP20



A0021734

Accessories Levelflex FMP50 HART

#### Technical data

- Resistance per channel:  $2 \times 0.5 \Omega_{max}$
- Threshold DC voltage: 400 to 700 V
- Threshold surge voltage: < 800 V
- Capacitance at 1 MHz: < 1.5 pF
- Nominal leakage current (8/20 μs): 10 kA
- Suitable for conductor cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)


### If retrofitting:

- Order number for 1-channel devices (OVP10): 71128617
- Order number for 2-channel devices (OVP20): 71128619
- The use of the OVP module may be restricted depending on the transmitter approval. A device may only be retrofitted with the OVP module if the option *NA* (overvoltage protection) is listed under *Optional specifications* in the Safety Instructions (XA) associated with the device.
- In order to keep the necessary safety distances when using the surge arrester module, the housing cover also needs to be replaced when the device is retrofitted.
   Depending on the housing type, the suitable cover can be ordered using the following order number:
  - Housing GT18: 71185516Housing GT19: 71185518
  - Housing GT20: 71185517

 $oxed{\mathbb{R}}$  For details, see the "Special Documentation" SD01090F

### 16.1.7 Bluetooth module BT10 for HART devices

The Bluetooth module BT10 can be ordered together with the device via the "Accessory mounted" section of the product order structure.



A0036493

### Technical data

- Quick and easy setup with the SmartBlue app
- No additional tools or adapters needed
- Signal curve via SmartBlue (app)
- Encrypted single point-to-point data transmission (tested by Fraunhofer Institute) and password-protected communication via Bluetooth® wireless technology
- Range under reference conditions:> 10 m (33 ft)
- When the Bluetooth module is used, the minimum supply voltage of the device increases by up to 3 V.

Levelflex FMP50 HART Accessories

### If retrofitting:

• Order number: 71377355

■ The use of the Bluetooth module may be restricted depending on the transmitter approval. A device may only be retrofitted with the Bluetooth module if the option NF (Bluetooth module) is listed under Optional specifications in the Safety Instructions (XA) associated with the device.



For details, see the "Special Documentation" SD02252F

#### 16.2 Communication-specific accessories

#### Commubox FXA195 HART

For intrinsically safe HART communication with FieldCare via the USB interface



For details, see "Technical Information" TI00404F

### Commubox FXA291

Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop Order number: 51516983



For details, see "Technical Information" TI00405C

#### HART Loop Converter HMX50

Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values

Order number: 71063562



For details, see "Technical Information" TI00429F and Operating Instructions BA00371F

#### WirelessHART adapter SWA70

- Is used for the wireless connection of field devices
- The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks



For details, see Operating Instructions BA00061S

#### Fieldgate FXA42

Fieldgates enable communication between connected 4 to 20 mA, Modbus RS485 and Modbus TCP devices and SupplyCare Hosting or SupplyCare Enterprise. The signals are transmitted either via Ethernet TCP/IP, WLAN or mobile communications (UMTS). Advanced automation capabilities are available, such as an integrated Web-PLC, OpenVPN and other functions.



For details, see "Technical Information" TI01297S and Operating Instructions BA01778S.

#### SupplyCare Enterprise SCE30B

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

This Web-based software is installed on a local server and can also be visualized and operated with mobile terminals such as a smartphone or tablet.



For details, see Technical Information TI01228S and Operating Instructions BA00055S

#### SupplyCare Hosting SCH30

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and

Levelflex FMP50 HART Accessories

> transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

SupplyCare Hosting is offered as a hosting service (Software as a Service, SaaS). In the Endress+Hauser portal, the user is provided with the data over the Internet.



For details, see Technical Information TI01229S and Operating Instructions BA00050S

### Field Xpert SFX350

Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex** area.



For details, see Operating Instructions BA01202S

#### Field Xpert SFX370

Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area and the Ex area.



For details, see Operating Instructions BA01202S

#### 16.3 Service-specific accessories

#### DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices



Technical Information TI01134S

### FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



Technical Information TI00028S

#### 16.4 System components

#### Memograph M graphic data manager

The Memograph M graphic data manager provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.



Technical Information TI00133R and Operating Instructions BA00247R

### **RN221N**

Active barrier with power supply for safe separation of 4 to 20 mA standard signal circuits. Offers bidirectional HART transmission.



Technical Information TI00073R and Operating Instructions BA00202R

### RN221

Supply unit for powering two 2-wire measuring devices solely in the non-Ex area. Bidirectional communication is possible via the HART communication jacks.




Technical Information TI00081R and Brief Operating Instructions KA00110R

Levelflex FMP50 HART Operating menu

## 17 Operating menu

## 17.1 Overview of the operating menu (SmartBlue)

Navigation SmartBlue



Operating menu Levelflex FMP50 HART

	Medium property	→ 🗎 136
	Process property	→ 🖺 137
	Advanced process conditions	→ 🖺 138
	Level unit	→ 🖺 139
	Blocking distance	→ 🖺 139
	Level correction	→ 🖺 140
► Linearization		→ 🖺 142
	Linearization type	→ 🖺 144
	Unit after linearization	→ 🖺 145
	Free text	→ 🖺 146
	Level linearized	→ 🖺 147
	Maximum value	→ 🖺 147
	Diameter	→ 🖺 147
	Intermediate height	→ 🖺 148
	Table mode	→ 🖺 148
	Table number	→ 🖺 149
	Level	→ 🖺 149
	Level	→ 🖺 150
	Customer value	→ 🖺 150
	Activate table	→ 🖺 150
▶ Probe settings		→ 🖺 156
- 1 1000 Sectings	Probe grounded	→ 🖺 156
	Present probe length	→ 🖺 156
	Confirm probe length	→ 🖺 157

► Safety setting	gs	→ 🗎 151
	Output echo lost	→ 🖺 151
	Value echo lost	→ 🖺 151
	Ramp at echo lost	→ 🖺 152
	Blocking distance	→ 🖺 139
► Current outp	ut 1 to 2	→ 🖺 159
	Assign current output	→ 🖺 159
	Current span	→ 🖺 160
	Fixed current	→ 🖺 160
	Damping output	→ 🖺 161
	Failure mode	→ 🖺 161
	Failure current	→ 🖺 162
	Output current 1 to 2	→ 🖺 162
► Switch outpu	ıt	→ 🖺 163
	Switch output function	→ 🖺 163
	Assign status	→ 🖺 164
	Assign limit	→ 🖺 164
	Assign diagnostic behavior	→ 🖺 164
	Switch-on value	→ 🖺 165
	Switch-on delay	→ 🖺 166
	Switch-off value	→ 🖺 166
	Switch-off delay	→ 🖺 167
	Failure mode	→ 🖺 167

		Switch status	<del>.</del> ;	→ 🖺 167
		Invert output signal	<del>,</del>	→ 🗎 167
♥ Diagnostics			<del>.</del>	→ 🖺 181
Actual diagnostics			<del>.</del>	→ 🖺 181
Timestamp			<del>.</del>	→ 🖺 181
Previous diagnostic	rs .		<del>.</del>	→ 🖺 181
Timestamp			-,	→ 🖺 182
Operating time from	m restart		<u> </u>	→ 🖺 182
Operating time			<del>)</del>	→ 🖺 175
▶ Diagnostic list			<del>)</del>	→ 🖺 183
	Diagnostics 1 to 5		÷	→ 🗎 183
	Timestamp 1 to 5		<del>?</del>	→ 🖺 183
► Measured value	es .		<del>?</del>	→ 🖺 188
	Distance		<del>?</del>	→ 🖺 129
	Level linearized		<del>?</del>	→ 🖺 147
	Output current 1 to	2	<del>?</del>	→ 🖺 162
	Measured current 1		<del>?</del>	→ 🖺 189
	Terminal voltage 1		<del>?</del>	→ 🖺 189
▶ Device informat	ion		<del>?</del>	→ 🖺 185
	Device tag		<del>.</del>	→ 🖺 185
	Serial number		<del>.</del>	→ 🖺 185
	Firmware version		<del>?</del>	→ 🖺 185
	Device name		<del>?</del>	→ 🖺 185
	Order code		÷	→ 🖺 186
	Extended order code	e 1 to 3	<del>,</del>	→ 🗎 186

	Device revision	→ 🖺 186
	Device ID	→ 🖺 186
	Device type	→ 🖺 187
	Manufacturer ID	→ 🖺 187
► Simulation		→ 🖺 194
	Assign measurement variable	→ 🖺 195
	Process variable value	→ 🖺 195
	Current output 1 to 2 simulation	→ 🖺 195
	Value current output 1 to 2	→ 🖺 196
	Switch output simulation	→ 🖺 196
	Switch status	→ 🖺 196
	Device alarm simulation	→ 🖺 197

# 17.2 Overview of the operating menu (display module)

Language		
<b>⊁</b> Setup		→ 🖺 126
Device tag		→ 🖺 126
Distance unit		→ 🖺 126
Tank type		→ 🖺 126
Tube diameter		→ 🖺 127
Medium group		→ 🖺 127
Empty calibration	n	→ 🖺 128
Full calibration		→ 🖺 128
Level		→ 🖺 129
Distance		→ 🖺 129
Signal quality		→ 🖺 130
► Mapping		→ 🖺 133
	Confirm distance	→ 🖺 133
	Mapping end point	→ 🖺 133
	Record map	→ 🖺 133
	Distance	→ 🖺 133
► Advanced set	up	→ 🖺 134
	Locking status	→ 🖺 134
	Access status display	→ 🖺 135
	Enter access code	→ 🖺 135
	▶ Level	→ 🖺 136
	Medium type	→ 🖺 136

	Medium property	→ 🖺 136
	Process property	→ 🖺 137
	Advanced process conditions	→ 🖺 138
	Level unit	→ 🖺 139
	Blocking distance	→ 🖺 139
	Level correction	→ 🖺 140
▶ Lineari	zation	→ 🖺 142
	Linearization type	→ 🖺 144
	Unit after linearization	→ 🖺 145
	Free text	→ 🖺 146
	Maximum value	→ 🖺 147
	Diameter	→ 🖺 147
	Intermediate height	→ 🖺 148
		→ 🖺 148
	Table mode	→ 🗎 148
	► Edit table	_
	Level	
	Customer value	
	Activate table	→ 🖺 150
► Safety	settings	→ 🖺 151
	Output echo lost	→ 🖺 151
	Value echo lost	→ 🖺 151
	Ramp at echo lost	→ 🖺 152
	Blocking distance	→ 🖺 139
► SIL/WH	IG confirmation	→ 🖺 154

► Deactivate SIL/V	WHG		→ 🖺 155
	Reset write protect	ion	→ 🖺 155
	Code incorrect		→ 🖺 155
► Probe settings			→ 🖺 156
	Probe grounded		→ 🖺 156
	► Probe length co	rrection	→ 🗎 158
		Confirm probe length	→ 🖺 158
		Present probe length	→ 🖺 158
► Current output	1 to 2		→ 🗎 159
	Assign current out	put	→ 🖺 159
	Current span		→ 🖺 160
	Fixed current		→ 🖺 160
	Damping output		→ 🖺 161
	Failure mode		→ 🖺 161
	Failure current		→ 🖺 162
	Output current 1 to	2	→ 🖺 162
► Switch output			→ 🖺 163
	Switch output func	tion	→ 🖺 163
	Assign status		→ 🖺 164
	Assign limit		→ 🖺 164
	Assign diagnostic b	pehavior	→ 🖺 164
		, and the second	
	Switch-on value		→ 🖺 165
	Switch-on delay		→ 🖺 166
	Switch-off value		→ 🖺 166
	Switch-off delay		→ 🖺 167

Failure mode	→ 🖺 167
Switch status	→ 🖺 167
Invert output signal	→ 🖺 167
<b>▶</b> Display	→ 🖺 169
Language	→ 🖺 169
Format display	→ 🖺 169
Value 1 to 4 display	→ 🖺 171
Decimal places 1 to 4	→ 🗎 171
Display interval	→ 🖺 171
Display damping	→ 🖺 172
Header	→ 🖺 172
Header text	→ 🖺 172
Separator	→ 🖺 173
Number format	→ 🖺 173
Decimal places menu	→ 🖺 173
Backlight	→ 🗎 173
Contrast display	→ 🗎 174
► Configuration backup display	→ 🗎 175
Operating time	→ 🖺 175
Last backup	→ 🖺 175

		Configuration mana	agement	→ 🗎 175
		Comparison result		→ 🖺 176
	► Administration		]	→ 🖺 178
		▶ Define access co	de	→ 🖺 180
			Define access code	→ 🖺 180
			Confirm access code	→ 🖺 180
		Device reset		→ 🖺 178
	-	Device reser		, = 1,0
억 Diagnostics				→ 🗎 181
Actual diagnostics				→ 🖺 181
Previous diagnostic	S			→ 🖺 181
Operating time from	n restart			→ 🖺 182
Operating time				→ 🖺 175
<b>▶</b> Diagnostic list				→ 🖺 183
	Diagnostics 1 to 5			→ 🖺 183
► Event logbook				→ 🖺 184
	Filter options		]	
			]	\ <del>F</del> 104
	► Event list	1		→ 🖺 184
► Device informat	ion			→ 🖺 185
	Device tag			→ 🖺 185
	Serial number		]	→ 🖺 185
	Firmware version		]	→ 🖺 185
	Device name			→ 🖺 185
	Order code			→ 🖺 186
	Extended order cod	e 1 to 3		→ 🖺 186
	Device revision			→ 🖺 186

	Device	ce ID		$\rightarrow$	₿ 186
	Device	ce type		$\rightarrow$	<b>187</b>
	Manu	ufacturer ID		$\rightarrow$	<b>187</b>
	► Measured values			$\rightarrow$	<b>188</b>
	Distar	nco		_	<b>129</b>
	Distai			,	
	Level	linearized		$\rightarrow$	₿ 147
	Outpu	ut current 1 to 2		$\rightarrow$	<b>162</b>
	Meas	sured current 1		$\rightarrow$	₿ 189
	Termi	ninal voltage 1		$\rightarrow$	<b>189</b>
	► Data logging			$\rightarrow$	₿ 190
	Assig	n channel 1 to 4		$\rightarrow$	₿ 190
	Loggi	ing interval		$\rightarrow$	₿ 191
	Clear	logging data		$\rightarrow$	<b>191</b>
	▶ Dis	splay channel 1 to	) 4	$\rightarrow$	₿ 192
	► Simulation			$\rightarrow$	₿ 194
	Assig	gn measurement va	ariable	$\rightarrow$	₿ 195
	Proce	ess variable value		$\rightarrow$	₿ 195
	Curre	ent output 1 to 2 si	mulation	$\rightarrow$	<b>195</b>
	Value	e current output 1	to 2	$\rightarrow$	<b>196</b>
	Switch	ch output simulatio	on	$\rightarrow$	₿ 196
	Switch	ch status		$\rightarrow$	₿ 196
	Device	ce alarm simulation	n	$\rightarrow$	₿ 197
	► Device check			$\rightarrow$	₿ 198
	Start	device check		$\rightarrow$	<b>198</b>
	Resul	lt device check		$\rightarrow$	₿ 198
-					

I	ast check time	→ 🖺 198
L	.evel signal	→ 🖺 199
L	aunch signal	→ 🖺 199

# 17.3 Overview of the operating menu (operating tool)

<b>≯</b> Setup			→ 🖺 126
Device tag			→ 🖺 126
Distance unit			→ 🖺 126
Tank type			→ 🖺 126
Tube diameter			→ 🖺 127
Medium group			→ 🖺 127
Empty calibration			→ 🖺 128
Full calibration			→ 🖺 128
Level			→ 🖺 129
Distance			→ 🖺 129
Signal quality			→ 🖺 130
Confirm distance			→ 🖺 131
Present mapping			→ 🖺 132
Mapping end poir	nt		→ 🖺 132
Record map			→ 🖺 132
► Advanced setu	ıp		→ 🖺 134
	Locking status		→ 🖺 134
	Access status toolir	ng	→ 🖺 134
	Enter access code		→ 🖺 135
	► Level		→ 🖺 136
		Medium type	→ 🖺 136
		Medium property	→ 🖺 136
		Process property	→ 🖺 137

	Advanced process conditions	<b>→</b>	₿ 138
	Level unit	$\rightarrow$	<b>1</b> 39
	Blocking distance	$\rightarrow$	<b>1</b> 39
	Level correction	$\rightarrow$	<b>140</b>
▶ Linearization		$\rightarrow$	<b>1</b> 42
			<b>P</b> 1//
	Linearization type	$\rightarrow$	🗎 144
	Unit after linearization	$\rightarrow$	₿ 145
	Free text	$\rightarrow$	₿ 146
	Level linearized	$\rightarrow$	<b>147</b>
	Maximum value	$\rightarrow$	<b>147</b>
	Diameter	_	<b>1</b> 47 <b>□</b>
	Diameter	7	□ 14/
	Intermediate height	$\rightarrow$	₿ 148
	Table mode	$\rightarrow$	<b>148</b>
	Table number	$\rightarrow$	<b>1</b> 49
	Level	$\rightarrow$	<b>1</b> 49
	Level	<b>→</b>	<b>1</b> 50
	Customer value	$\rightarrow$	<b>1</b> 50 <b>1</b> 50
	Activate table	$\rightarrow$	<b>150</b>
	retivate table	,	<b>1</b> 70
► Safety settings		$\rightarrow$	₿ 151
	Output echo lost	$\rightarrow$	<b>1</b> 51 <b>1</b> 51
	Value echo lost	$\rightarrow$	<b>1</b> 51 <b>1</b> 51
	Ramp at echo lost	$\rightarrow$	<b>1</b> 52 <b>1</b> 52
	Blocking distance	$\rightarrow$	<b>1</b> 39
► SIL/WHG confir	mation	$\rightarrow$	<b>1</b> 54 <b>1</b>

► Deactivate SIL/	WHG	→ 🖺 155
	Reset write protection	→ 🗎 155
	Code incorrect	→ 🗎 155
► Probe settings		→ 🖺 156
	Probe grounded	→ 🖺 156
	Present probe length	→ 🖺 156
	Confirm probe length	→ 🗎 157
► Current output	1 to 2	→ 🖺 159
	Assign current output	→ 🖺 159
	Current span	→ 🖺 160
	Fixed current	→ 🖺 160
	Damping output	→ 🖺 161
	Failure mode	→ 🖺 161
	Failure current	→ 🗎 162
	Output current 1 to 2	→ 🖺 162
► Switch output		→ 🖺 163
	Switch output function	→ 🖺 163
	Assign status	→ 🖺 164
	Assign limit	→ 🖺 164
	Assign diagnostic behavior	→ 🖺 164
	Switch-on value	→ 🖺 165
	Switch-on delay	→ 🖺 166
	Switch-off value	→ 🖺 166
	Switch-off delay	→ 🖺 167
	Failure mode	→ 🖺 167
	ranute mode	7 目 10/

	Switch status	→ 🖺 167
	Invert output signal	→ 🖺 167
<b>▶</b> Display		→ 🖺 169
	Language	→ 🖺 169
	Format display	→ 🖺 169
	Value 1 to 4 display	→ 🖺 171
	Decimal places 1 to 4	→ 🖺 171
	Display interval	→ 🖺 171
	Display damping	→ 🖺 172
	Header	→ 🖺 172
	Header text	→ 🖺 172
	Separator	→ 🖺 173
	Number format	→ 🖺 173
	Decimal places menu	→ 🖺 173
	Backlight	→ 🖺 173
	Contrast display	→ 🖺 174
► Configuration b	backup display	→ 🖺 175
	Operating time	→ 🖺 175
	Last backup	→ 🖺 175
	Configuration management	→ 🖺 175
	configuration management	, 6117

		Backup state	→ 🖺 176
		Comparison result	→ 🖺 176
	► Administration		→ 🖺 178
		Define access code	
		Device reset	→ 🖺 178
♥ Diagnostics			→ 🖺 181
C Diagnostics			7 目 101
Actual diagnostics			→ 🖺 181
Timestamp			→ 🖺 181
Previous diagnostic	CS CS		→ 🖺 181
Timestamp			→ 🗎 182
Operating time from	m restart		→ 🖺 182
Operating time			→ 🖺 175
▶ Diagnostic list		]	→ 🖺 183
	Diagnostics 1 to 5	-	→ 🖺 183
	Timestamp 1 to 5		→ 🗎 183
➤ Device informat		]	→ 🖺 185
P Device informati	11011		/ 目 10)
	Device tag		→ 🖺 185
	Serial number		→ 🖺 185
	Firmware version		→ 🖺 185
	Device name		→ 🖺 185
	Order code		→ 🖺 186
	Extended order cod	e 1 to 3	→ 🖺 186
	Device revision		→ 🖺 186
	Device ID		→ 🖺 186

		Device type	→ 🖺 187
		Manufacturer ID	→ 🖺 187
	► Measured value	es	→ 🖺 188
		Distance	→ 🖺 129
		Level linearized	→ 🖺 147
		Output current 1 to 2	→ 🖺 162
		Measured current 1	→ 🖺 189
		Terminal voltage 1	→ 🖺 189
	► Data logging		→ 🖺 190
		Assign channel 1 to 4	→ 🖺 190
		Logging interval	→ 🖺 191
		Clear logging data	→ 🖺 191
	► Simulation		→ 🖺 194
		Assign measurement variable	→ 🖺 195
		Process variable value	→ 🖺 195
		Current output 1 to 2 simulation	→ 🖺 195
		Value current output 1 to 2	→ 🖺 196
		Switch output simulation	→ 🖺 196
		Switch status	→ 🖺 196
		Device alarm simulation	→ 🖺 197
	► Device check		→ 🖺 198
		Start device check	→ 🖺 198
		Result device check	→ 🖺 198
		Last check time	→ 🖺 198
L			

Level signal
⇒ ₱ 199

Launch signal
⇒ ₱ 199

▶ Heartbeat
⇒ ₱ 200

#### "Setup" menu 17.4



- 🗟 : Indicates how to navigate to the parameter using the display and operating module
  - ☐: Indicates how to navigate to the parameter using operating tools (e.g. FieldCare)
  - 🗈 : Indicates parameters that can be locked via the access code.

Navigation ■ ■ Setup

Device tag		
Navigation		
Description	Enter a unique name for the measuring point to identify the device quickly within plant.	the
User entry	Character string comprising numbers, letters and special characters (32)	
Distance unit		
Navigation		
Description	Used for the basic calibration (Empty / Full).	
Selection	SI units  mm  ft  m  in	
Tank type		
Navigation	Setup → Tank type	
Prerequisite	Medium type (→ 🖺 136) = Liquid	
Description	Select tank type.	
Selection	<ul><li>Metallic</li><li>Bypass / pipe</li><li>Non metallic</li></ul>	

126 Endress+Hauser

Mounted outside

Depending on the probe

Coaxial

**Factory setting** 

# Additional information

 Depending on the probe some of the options mentioned above may not be available or there may be additional options.

• For coax probes and probes with metallic center washer **Tank type** parameter corresponds to the type of probe and cannot be changed.

Tube diameter

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Tube diameter

Prerequisite Tank type (→ 🖺 126) = Bypass / pipe

**Description** Specify diameter of bypass or stilling well.

**User entry** 0 to 9.999 m

Medium group

Prerequisite Medium type ( $\rightarrow \equiv 136$ ) = Liquid

**Description** Select medium group.

**Selection** • Others

■ Water based (DC >= 4)

#### Additional information

This parameter roughly specifies the dielectric constant (DC) of the medium. For a more detailed definition of the DC use the **Medium property** parameter ( $\rightarrow \implies 136$ ).

The **Medium group** parameter presets the **Medium property** parameter ( $\rightarrow \implies 136$ ) as follows:

Medium group	Medium property (→ 🗎 136)
Others	Unknown
Water based (DC >= 4)	DC 4 7

The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.

The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.

Empty calibration


**Navigation**  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Empty calibr.

**Description** Distance between process connection and minimum level (0%).

**User entry** Depending on the probe

**Factory setting** Depending on the probe

Additional information



 $\blacksquare$  42 Empty calibration (E) for level measurements in liquids

Full calibration


**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Full calibr.

**Description** Distance between minimum level (0%) and maximum level (100%).

**User entry** Depending on the probe

**Factory setting** Depending on the probe

# Additional information



■ 43 Full calibration (F) for level measurements in liquids

Level


Navigation

Setup → Level

Description

Displays measured level  $L_L$  (before linearization).

Additional information



■ 44 Level in case of liquid measurements

The unit is defined in the **Level unit** parameter ( $\rightarrow \implies 139$ ).


Distance

Navigation

Description

Displays the measured distance  $D_L$  between the reference point (lower edge of the flange or threaded connection) and the level.

#### Additional information



**■** 45 Distance for liquid measurements

The unit is defined in the **Distance unit** parameter ( $\rightarrow \triangleq 126$ ).

## Signal quality

**Navigation** 

Setup → Signal quality

Description

Displays the signal quality of the evaluated echo.

#### Additional information

#### Meaning of the display options

Strong

The evaluated echo exceeds the threshold by at least  $10\ mV$ .

Medium

The evaluated echo exceeds the threshold by at least 5 mV.

Weak

The evaluated echo exceeds the threshold by less than 5 mV.

No signal

The device does not find a usable echo.

The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo <sup>3)</sup> or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets.

- In case of a lost echo (**Signal quality = No signal**) the device generates the following error message:
  - F941, for Output echo lost ( $\rightarrow$  🗎 151) = Alarm.
  - S941, if another option has been selected in **Output echo lost** (→ 🖺 **151**).

<sup>3)</sup> Of these two echos the one with the lower quality is indicated.

Confirm distance

#### **Navigation**

Setup → Confirm distance

#### Description

Specify, whether the measured distance matches the real distance.

Depending on the selection the device automatically sets the range of mapping.

#### Selection

- Manual map
- Distance ok
- Distance unknown
- Distance too small
- Distance too big
- Tank empty
- Delete map

#### Additional information

# Meaning of the options

#### Manual map

To be selected if the range of mapping is to be defined manually in the **Mapping end point** parameter ( $\Rightarrow \implies 132$ ). In this case it is not necessary to confirm the distance.

#### ■ Distance ok

To be selected if the measured distance matches the actual distance. The device performs a mapping.

## ■ Distance unknown

To be selected if the actual distance is unknown. A mapping can not be performed in this case.

#### Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

# ■ Distance too big 4)

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

# Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range.

# Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

- When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.
- If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.

<sup>\*</sup> Visibility depends on order options or device settings

<sup>4)</sup> Only available for "Expert → Sensor → Echo tracking → **Evaluation mode** parameter" = "Short time history" or "Long time history"

# **Present mapping Navigation** Setup → Present mapping Description Indicates up to which distance a mapping has already been recorded. Mapping end point **Navigation** Setup $\rightarrow$ Map. end point **Prerequisite Confirm distance (→ 🖺 131) = Manual map or Distance too small** Description Specify new end of the mapping. User entry 0 to 200 000.0 m Additional information This parameter defines up to which distance the new mapping is to be recorded. The distance is measured from the reference point, i.e. from the lower edge of the mounting flange or the threaded connection. For reference purposes the **Present mapping** parameter ( $\rightarrow \equiv 132$ ) is displayed together with this parameter. It indicates up to which distance a mapping has already been recorded. Record map Navigation Setup → Record map **Prerequisite** Confirm distance ( $\rightarrow \equiv 131$ ) = Manual map or Distance too small Description Start recording of the map. Selection No Record map ■ Delete map Additional information Meaning of the options No The map is not recorded. Record map The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing $\square$ . Delete map The mapping (if one exists) is deleted and the device displays the recalculated measured

Endress+Hauser

be confirmed by pressing  $\mathbf{Z}$ .

distance and the mapping range. When operating via the local display, these values must

# 17.4.1 "Mapping" wizard

The **Mapping** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the **Setup** menu (→ ≅ 126).

In the **Mapping** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Confirm distance		
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🗎 131	
Mapping end point		â
Navigation	Setup → Mapping → Map. end point	
Description	→ 🖺 132	
Record map		<u> </u>
Navigation	Setup → Mapping → Record map	
Description	→ 🗎 132	
Distance		
Navigation	Setup → Mapping → Distance	
Description	→ ■ 129	

# 17.4.2 "Advanced setup" submenu

Navigation  $\square$  Setup  $\rightarrow$  Advanced setup

#### Locking status

Navigation

Description

Indicates the write protection with the highest priority that is currently active.

User interface

- Hardware locked
- SIL locked
- CT active defined parameters
- WHG locked
- Temporarily locked

#### Additional information

## Meaning and priorities of the types of write protection

■ Hardware locked (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.

SIL locked (priority 2)

The SIL mode is activated. Writing access to the relevant parameters is denied.

WHG locked (priority 3)

The WHG mode is activated. Writing access to the relevant parameters is denied.

■ Temporarily locked (priority 4)

Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.

On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

## Access status tooling

**Navigation** 

 $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Access stat.tool

Description

Shows the access authorization to the parameters via the operating tool.

Additional information

The access authorization can be changed via the **Enter access code** parameter  $(\rightarrow \implies 135)$ .

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ( $\Rightarrow \implies 134$ ).

# Access status display

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Access stat.disp

**Prerequisite** The device has a local display.

**Description** Indicates access authorization to parameters via local display.

Additional information

The access authorization can be changed via the **Enter access code** parameter  $(\rightarrow \implies 135)$ .

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ( $\rightarrow \implies 134$ ).

#### Enter access code

**Navigation**  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Ent. access code

**Description** Enter access code to disable write protection of parameters.

**User entry** 0 to 9 999

Additional information

- The customer-specific access code that was defined in the **Define access code** parameter
   (→ ≦ 178) must be entered for local operation.
- If an incorrect access code is entered, users retain their current access authorization.
- The write protection affects all parameters marked with the ③ symbol in the document. On the local display, the ⑤ symbol in front of a parameter indicates that the parameter is write-protected.
- If no key is pressed for 10 minutes or the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the writeprotected parameters after another 60 s.
- Please contact your Endress+Hauser Sales Center if you lose your access code.

#### "Level" submenu

*Navigation*  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level

Medium type

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level  $\rightarrow$  Medium type

**Description** Specify type of medium.

**User interface** ■ Liquid

■ Solid

Factory setting FMP50, FMP51, FMP52, FMP53, FMP54, FMP55: Liquid

Additional information

This parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended not

to change the factory setting.

Medium property

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level  $\rightarrow$  Medium property

Prerequisite EOP level evaluation ≠ Fix DC

**Description** Specify the dielectric constant  $\varepsilon_r$  of the medium.

Selection ■ Unknown ■ DC 1.4 ... 1.6

■ DC 1.6 ... 1.9

■ DC 1.9 ... 2.5

■ DC 2.5 ... 4

■ DC 4 ... 7

■ DC 7 ... 15

■ DC > 15

Factory setting Depends on the Medium type ( $\rightarrow \triangleq 136$ ) and Medium group ( $\rightarrow \triangleq 127$ ) parameters.

#### Additional information

Dependency of "Medium type" and "Medium group"

Medium type (→ 🗎 136)	Medium group (→ 🖺 127)	Medium property
Solid		Unknown
Liquid	Water based (DC >= 4)	DC 4 7
	Others	Unknown

- For the dielectric constants (DC values) of many media commonly used in industry, please refer to:
  - Dielectric constant (DC value) Compendium CP01076F
  - The Endress+Hauser "DC Values app" (available for Android and iOS)
- If **EOP level evaluation** = **Fix DC**, the exact dielectric constant must be specified in the **DC value** parameter. The **Medium property** parameter therefore does not apply in this case.

Process property	

#### **Navigation**

# Description

Specify typical rate of level change.

#### Selection

# For "Medium type" = "Liquid"

- Very fast > 10 m (400 in)/min
- Fast > 1 m (40 in)/min
- Standard < 1 m (40in) /min
- Medium < 10 cm (4in) /min
- Slow < 1 cm (0.4in) /min
- No filter / test

# For "Medium type" = "Solid"

- Very fast > 100 m (333 ft) /h
- Fast > 10 m (33 ft) /h
- Standard < 10 m (33 ft) /h
- Medium < 1 m (3ft) /h
- Slow < 0.1 m (0.3ft) /h
- No filter / test

#### Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

For "Operating mode" = "Level" and "Medium type" = "Liquid"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	14
Medium < 10 cm (4in) /min	39
Slow < 1 cm (0.4in) /min	76
No filter / test	< 1

# For "Operating mode" = "Level" and "Medium type" = "Solid"

Process property	Step response time / s
Very fast > 100 m (333 ft) /h	37
Fast > 10 m (33 ft) /h	37
Standard < 10 m (33 ft) /h	74
Medium < 1 m (3ft) /h	146
Slow < 0.1 m (0.3ft) /h	290
No filter / test	< 1

# For "Operating mode" = "Interface" or "Interface with capacitance"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	23
Medium < 10 cm (4in) /min	47
Slow < 1 cm (0.4in) /min	81
No filter / test	2.2

#### Advanced process conditions

## Navigation

## Description

Specify additional process conditions (if required).

# Selection

- None
- Oil/Water condensate
- Probe near tank bottom
- Build up
- Foam (>5cm/0,16ft)

#### Additional information

## Meaning of the options

Oil/Water condensate (only Medium type = Liquid)

Makes sure that in the case of two-phase media only the total level is detected (example: oil/condensate application).

■ Probe near tank bottom (only for Medium type = Liquid)

Improves the empty detection, especially if the probe is mounted close to the tank bottom.

Build up

Enables a safe empty-detection even if the end-of-probe signal has shifted due to build-

■ Foam (>5cm/0,16ft) (only for Medium type = Liquid)

Optimizes the signal evaluation in applications with foam formation.

138

Level unit

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level  $\rightarrow$  Level unit

**Description** Select level unit.

Selection SI units US units

• %

• ft

• m • in

Additional information

The level unit may differ from the distance unit defined in the **Distance unit** parameter  $(\rightarrow \implies 126)$ :

■ The unit defined in the **Distance unit** parameter is used for the basic calibration (**Empty calibration** ( $\rightarrow \implies 128$ ) and **Full calibration** ( $\rightarrow \implies 128$ ).

• The unit defined in the **Level unit** parameter is used to display the (unlinearized) level.

Blocking distance

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level  $\rightarrow$  Blocking dist.

**Description** Specify upper blocking distance UB.

**User entry** 0 to 200 m

**Factory setting** • For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

• For rod and rope probes above 8 m (26 ft): 0.025 \* Sondenlänge

Additional information


Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

This behavior is only valid if the following two conditions are met:

- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
- Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 46 Blocking distance (UB) for liquid measurements

Level correction


**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Level  $\rightarrow$  Level correction

**Description** Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

**Additional information** The value specified in this parameter is added to the measured level (before linearization).

## "Linearization" submenu



47 Linearization: Conversion of the level and, if applicable, interface into a volume or a weight; the conversion depends on the vessel shape

- 1 Selection of linearization type and unit
- 2 Configuration of the linearization
- A Linearization type ( $\rightarrow \blacksquare 144$ ) = None
- *B* Linearization type ( $\rightarrow \blacksquare 144$ ) = Linear
- C Linearization type ( $\Rightarrow \triangle 144$ ) = Table
- D Linearization type (→ 🖺 144) = Pyramid bottom
- E Linearization type ( $\rightarrow = 144$ ) = Conical bottom
- *F* Linearization type ( $\rightarrow \equiv 144$ ) = Angled bottom
- *H* Linearization type ( $\rightarrow$  🖺 144) = Sphere
- I For "Operating mode" = "Interface" or "Interface with capacitance": interface before linearization (measured in the level unit)
- I' For "Operating mode" = "Interface" or "Interface with capacitance": interface after linearization (corresponds to volume or weight)
- L Level before linearization (measured in level unit)
- M Maximum value (→ 🖺 147)
- d Diameter ( $\rightarrow = 147$ )
- h Intermediate height ( $\rightarrow \stackrel{\cdot}{\blacksquare} 148$ )

Structure of the submenu on the local display

Navigation  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization

► Linearization					
I	Linearization type				
J	Unit after linearization				
F	Free text				
1	Maximum value				
Ι	Diameter				
I	Intermediate height				
]	Table mode				
ı	► Edit table				
		Level			
		Customer value			
	Activate table				

Structure of the submenu in the operating tool (e.g. FieldCare)

*Navigation*  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization

► Linearization		
	Linearization type	
	Unit after linearization	
	Free text	
	Level linearized	
	Maximum value	
	Diameter	
	Intermediate height	
	Table mode	
	Table number	
	Level	
	Level	
	Customer value	
	Activate table	

# *Description of the parameters*

*Navigation*  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization

# Linearization type


**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization  $\rightarrow$  Lineariz. type

**Description** Select linearization type.

**Selection** ■ None

- Linear
- Table
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

# Additional information



■ 48 Linearization types

- A None
- B Table
- C Pyramid bottom
- D Conical bottom
- E Angled bottom
- F Sphere
- G Horizontal cylinder

## Meaning of the options

#### None

The level is output in the level unit without being converted (linearized) beforehand.

#### Linear

The output value (volume/weight) is proportional to the level L. This applies, for example, to vertical cylindrical tanks and silos. The following parameters must also be specified:

- Maximum value (→ 🖺 147): maximum volume or weight

#### ■ Table

The relationship between the measured level L and the output value (volume/weight) is defined by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight" respectively. The following parameters must also be specified:

- **■** Table mode (→ 🗎 148)
- For every point in the table: **Level (→ 🖺 149)**
- For every point in the table: **Customer value** (→ 🖺 **150**)

#### Pyramid bottom

The output value corresponds to the volume or weight in a silo with a pyramid bottom. The following parameters must also be specified:

- Maximum value (→ 🗎 147): maximum volume or weight
- Intermediate height ( $\rightarrow$  🗎 148): the height of the pyramid

#### Conical bottom

The output value corresponds to the volume or weight in a tank with a conical bottom. The following parameters must also be specified:

- Maximum value ( $\rightarrow \triangleq 147$ ): maximum volume or weight
- **Intermediate height (→** 🖺 **148)**: the height of the cone

## Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following parameters must also be specified:

- Maximum value (→ 🖺 147): maximum volume or weight
- **Intermediate height (→** 🗎 **148)**: height of the angled bottom

#### Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following parameters must also be specified:

- Maximum value (→ 🖺 147): maximum volume or weight
- **■** Diameter (→ 🗎 147)

#### Sphere

The output value corresponds to the volume or weight in a spherical tank. The following parameters must also be specified:

- **Maximum value** (→ 🖺 **147**): maximum volume or weight
- **■** Diameter (→ 🗎 147)

Unit after linearization

Navigation

Prerequisite

**Linearization type** ( $\rightarrow$   $\stackrel{\triangle}{=}$  144) ≠ None

## Description

Select the unit for the linearized value.

#### Selection

Selection/input (uint16)

- 1095 = [short Ton]
- 1094 = [lb]
- 1088 = [kg]
- 1092 = [Ton]
- 1048 = [US Gal.]
- 1049 = [Imp. Gal.]
- $1043 = [ft^3]$
- $\bullet$  1571 = [cm<sup>3</sup>]
- $\blacksquare$  1035 = [dm<sup>3</sup>]
- $1034 = [m^3]$
- 1038 = [l]
- 1041 = [hl]
- **■** 1342 = [%]
- 1010 = [m]
- 1012 = [mm]
- 1018 = [ft]
- 1019 = [inch]
- $\blacksquare 1351 = [1/s]$
- 1352 = [l/min]
- 1353 = [l/h]
- $-1347 = [m^3/s]$
- $1348 = [m^3/min]$
- $\blacksquare$  1349 =  $[m^3/h]$
- $\blacksquare$  1356 = [ft<sup>3</sup>/s]
- $1357 = [ft^3/min]$
- $1358 = [ft^3/h]$
- 1362 = [US Gal./s]
- 1363 = [US Gal./min]
- 1364 = [US Gal./h]
- 1367 = [Imp. Gal./s]
- 1358 = [Imp. Gal./min]
- 1359 = [Imp. Gal./h]
- $\blacksquare$  32815 = [Ml/s]
- $\blacksquare$  32816 = [Ml/min]
- 32817 = [Ml/h]
- 1355 = [Ml/d]

# Additional information

The selected unit is only used for display purposes. The measured value is **not** converted on the basis of the selected unit.



Distance-to-distance linearization is also possible, i.e. a linearization from the level unit to another length unit. Select the **Linear** linearization mode for this purpose. To specify the new level unit, select the Free text option in the Unit after linearization parameter and enter the unit in the **Free text** parameter ( $\rightarrow \equiv 146$ ).

Free text

**Navigation** 

Prerequisite

Unit after linearization ( $\rightarrow \equiv 145$ ) = Free text

Description

Enter unit symbol.

146

**User entry** Up to 32 alphanumerical characters (letters, numbers, special characters)

Level linearized

**Navigation**  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization  $\rightarrow$  Level linearized

**Description** Displays linearized level.

Additional information

The unit is defined by the **Unit after linearization** parameter  $\rightarrow \implies 145$ .

Maximum value

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization  $\rightarrow$  Maximum value

**Prerequisite** Linearization type (→ 🗎 144) has one of the following values:

■ Linear

Pyramid bottomConical bottomAngled bottomHorizontal cylinder

Sphere

**Description** Linearized value corresponding to a level of 100%.

**User entry** -50 000.0 to 50 000.0 %

Diameter

**Navigation**  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization  $\rightarrow$  Diameter

**Prerequisite** Linearization type ( $\rightarrow \implies 144$ ) has one of the following values:

Horizontal cylinder

■ Sphere

**Description** Diameter of the cylindrical or spherical tank.

**User entry** 0 to 9 999.999 m

**Additional information** The unit is defined in the **Distance unit** parameter ( $\rightarrow \triangle$  126).

Intermediate height

Navigation

Prerequisite

**Linearization type** ( $\rightarrow = 144$ ) has one of the following values:

Pyramid bottom

Conical bottom

Angled bottom


Description

Height of the pyramid, conical or angled bottom.

User entry

0 to 200 m

#### Additional information



H Intermediate height

The unit is defined in the **Distance unit** parameter ( $\Rightarrow \triangleq 126$ ).

Table mode

**Navigation** 

Prerequisite

Linearization type ( $\rightarrow = 144$ ) = Table

Description

Select editing mode of the linearization table.

Selection

- Manual
- Semiautomatic
- Clear table
- Sort table

## Additional information

## Meaning of the options

#### Manual

The level and the associated linearized value are entered manually for each linearization point.

#### Semiautomatic

The level is measured by the device for each linearization point. The associated linearized value is entered manually.

#### Clear table

Deletes the existing linearization table.

# Sort table

Rearranges the linerization points into an ascending order.

#### Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.
- Before entering a linearization table, the values for **Empty calibration** ( $\rightarrow \triangleq 128$ ) and **Full calibration** ( $\rightarrow \triangleq 128$ ) must be set correctly.

If values of the table need to be changed after the full or empty calibration have been changed, a correct evaluation is only ensured if the existing table is deleted and the complete table is entered again. To do so delete the existing table (**Table mode**  $(\rightarrow \ \ \ )$  **148**) = **Clear table**). Then enter a new table.

# How to enter the table

■ Via FieldCare

The table points can be entered via the **Table number** ( $\rightarrow$   $\cong$  **149**), **Level** ( $\rightarrow$   $\cong$  **149**) and **Customer value** ( $\rightarrow$   $\cong$  **150**) parameters. As an alternative, the graphic table editor may be used: Device Operation  $\rightarrow$  Device Functions  $\rightarrow$  Additional Functions  $\rightarrow$  Linearization (Online/Offline)

- Via local display
   Select the Edit table submenu to call up the graphic table editor. The table is displayed and can be edited line by line.
- The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter  $( \rightarrow \implies 139)$  beforehand.
- If a decreasing table is entered, the values for 20 mA and 4 mA of the current output are interchanged. That means: 20 mA refers to the lowest level, whereas 4 mA refers to the highest level.

Table number		
Navigation		
Prerequisite	Linearization type ( $\rightarrow \triangleq 144$ ) = Table	
Description	Select table point you are going to enter or change.	
User entry	1 to 32	
Level (Manual)		<u> </u>

Level (Manual)	
Navigation	
Prerequisite	<ul> <li>Linearization type (→ 🗎 144) = Table</li> <li>Table mode (→ 🖺 148) = Manual</li> </ul>
Description	Enter level value of the table point (value before linearization).
User entry	Signed floating-point number

Level (Semiautomatic)		
Navigation		
Prerequisite	<ul> <li>Linearization type (→ 🖺 144) = Table</li> <li>Table mode (→ 🖺 148) = Semiautomatic</li> </ul>	
Description	Displays measured level (value before linearization). This value is transmitted to the table	
Customer value		
Navigation	$egin{array}{ll} & & & \\ & &$	
Prerequisite	Linearization type (→ 🗎 144) = Table	
Description	Enter linearized value for the table point.	
User entry	Signed floating-point number	
Activate table		
Navigation		
Prerequisite	Linearization type (→ 🖺 144) = Table	
Description	Activate (enable) or deactivate (disable) the linearization table.	
Selection	■ Disable ■ Enable	
Additional information	<ul> <li>Meaning of the options</li> <li>Disable         The measured level is not linearized.         If Linearization type (→ □ 144) = Table at the same time, the device issues error message F435.     </li> <li>Enable         The measured level is linearized according to the table.     </li> <li>When editing the table, the Activate table parameter is automatically reset to Disable and must be reset to Enable after the table has been entered.</li> </ul>	

# "Safety settings" submenu

*Navigation*  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.

Output echo lost

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.  $\rightarrow$  Output echo lost

**Description** Output signal in case of a lost echo.

**Selection** • Last valid value

Ramp at echo lostValue echo lost

Alarm

## Additional information Meaning of the options

Last valid value

The last valid value is kept in the case of a lost echo.

Ramp at echo lost 5)

In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the **Ramp at echo lost** parameter ( $\rightarrow \implies 152$ ).

■ Value echo lost 5)

In the case of a lost echo the output assumes the value defined in the **Value echo lost** parameter ( $\Rightarrow \triangleq 151$ ).

Alarm

Value echo lost

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.  $\rightarrow$  Value echo lost

Prerequisite Output echo lost  $(\Rightarrow \triangleq 151)$  = Value echo lost

**Description** Output value in case of a lost echo

**User entry** 0 to 200 000.0 %

**Additional information** Use the unit which has been defined for the measured value output:

Ramp at echo lost


**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.  $\rightarrow$  Ramp echo lost

Prerequisite Output echo lost (→ 🖺 151) = Ramp at echo lost

**Description** Slope of the ramp in the case of a lost echo

**User entry** Signed floating-point number

## Additional information



- A Delay time echo lost
- *B* Ramp at echo lost ( $\rightarrow \square$  152) (positive value)
- *C* Ramp at echo lost ( $\rightarrow \Box$  152) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuously increased until it reaches 100%.

Blocking distance	

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.  $\rightarrow$  Blocking dist.

**Description** Specify upper blocking distance UB.

**User entry** 0 to 200 m

**Factory setting** • For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

■ For rod and rope probes above 8 m (26 ft): 0.025 \* Sondenlänge


**Additional information** Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance

due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- This behavior is only valid if the following two conditions are met:
  - Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
  - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 49 Blocking distance (UB) for liquid measurements

## "SIL/WHG confirmation" wizard



The SIL/WHG confirmation wizard is only available for devices with SIL or WHG approval (Feature 590: "Additional Approval", option LA: "SIL" or LC: "WHG overfill prevention") which are currently **not** in the SIL- or WHG-locked state.

The **SIL/WHG** confirmation wizard is required to lock the device according to SIL or WHG. For details refer to the "Functional Safety Manual" of the respective device, which describes the locking procedure and the parameters of the sequence.

Navigation 

## "Deactivate SIL/WHG" wizard

i

Reenter codeAbort sequence

Selection

The **Deactivate SIL/WHG** wizard ( $\rightarrow \triangleq 155$ ) is only visible if the device is SIL-locked or WHG-locked. For details refer to the "Functional Safety Manual" of the respective device.

Navigation  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Deactiv. SIL/WHG

 Reset write protection

 Navigation
 Setup → Advanced setup → Deactiv. SIL/WHG → Res. write prot.

 Description
 Enter unlocking code.

 User entry
 0 to 65 535

 Code incorrect

 Navigation
 Setup → Advanced setup → Deactiv. SIL/WHG → Code incorrect

 Description
 Indicates that a wrong unlocking code has been entered. Select procedure.

# "Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** ( $\rightarrow$  157) = **Manual input** in order to enter the value manually.

- If a mapping (interference echo suppression) has been recorded after shortening the probe, it is no longer possible to perform an automatic probe length correction. In this case there are two options:
  - Delete the map using the **Record map** parameter ( $\rightarrow \boxminus 132$ ) before performing the automatic probe length correction. After the probe length correction, a new map can be recorded using the **Record map** parameter ( $\rightarrow \boxminus 132$ ).
  - Alternative: Select Confirm probe length (→ 157) = Manual input and enter the probe length manually into the Present probe length parameter → 156.
- An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ( $\rightarrow \implies 156$ ).

*Navigation*  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Probe settings

Probe grounded		
Navigation		
Prerequisite	Operating mode = Level	
Description	Specify whether the probe is grounded.	
Selection	■ No ■ Yes	
Present probe length		
- Tresent probe length		
Navigation		
Description	<ul> <li>In most cases:         Displays the length of the probe according to the currently measured end-of-probe signal.</li> <li>For Confirm probe length (→          \begin{align*} \text{157} = Manual input:         Enter actual length of probe.</li> </ul>	
User entry	0 to 200 m	

# Confirm probe length

## Navigation

#### Description

Select, whether the value displayed in the **Present probe length** parameter  $\rightarrow \triangleq 156$  matches the actual length of the probe. Based on this input, the device performs a probe length correction.

#### Selection

- Probe length OK
- Probe length too small
- Probe length too big
- Probe covered
- Manual input
- Probe length unknown

#### Additional information

#### Meaning of the options

#### ■ Probe length OK

To be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.

## ■ Probe length too small

To be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the **Present probe length** parameter  $\rightarrow \implies 156$ . This procedure has to be repeated until the displayed value matches the actual length of the probe.

#### Probe length too big

To be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the **Present probe length** parameter  $\rightarrow \implies 156$ . This procedure has to be repeated until the displayed value matches the actual length of the probe.

## ■ Probe covered

To be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device guits the sequence.

## Manual input

To be selected if no automatic probe length correction is to be performed. Instead, the actual length of the probe must be entered manually into the **Present probe length** parameter  $\rightarrow \implies 156^{6}$ .

#### Probe length unknown

To be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device quits the sequence.

Endress+Hauser 157

•

<sup>6)</sup> When operated via FieldCare, the **Manual input** option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited.

"Probe length correction" wizard

The **Probe length correction** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the probe length correction are located directly in the **Probe settings** submenu ( $\rightarrow \blacksquare 156$ ).

Navigation

Confirm probe length		
Navigation		
Description	→  ☐ 157	
Present probe length		
Navigation		
Description	→ 🖺 156	

# "Current output 1 to 2" submenu

The **Current output 2** submenu ( $\rightarrow \triangleq 159$ ) is only available for devices with two current outputs.

*Navigation*  $\blacksquare \square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2

#### Assign current output 1 to 2

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Assign curr.

**Description** Select process variable for current output.

**Selection** • Level linearized

Distance

Electronic temperatureRelative echo amplitude

Analog output adv. diagnostics 1Analog output adv. diagnostics 2

Factory setting For level measurements

Current output 1: Level linearized
 Current output 2 7): Level linearized

Additional information

Definition of the current range for the process variables

Process variable	4 mA value	20 mA value
Level linearized	0 % <sup>1)</sup> or the associated linearized value	$100~\%^{2)}$ or the associated linearized value
Distance	0 (i.e. level is at the reference point)	<b>Empty calibration (→ 🖺 128)</b> (i.e. level is at 0 %)
Electronic temperature	-50 °C (-58 °F)	100 °C (212 °F)
Relative echo amplitude	0 mV	2 000 mV
Analog output adv. diagnostics 1/2	depending on the parar	netrization of the Advanced Diagnostics

- 1) the 0% level is defined by **Empty calibration** parameter ( $\rightarrow \triangleq 128$ )
- 2) The 100% level is defined by **Full calibration** parameter ( $\Rightarrow \implies 128$ )

It may be necessary to adjust the 4mA and 20mA values to the application (especially in the case of the **Analog output adv. diagnostics 1/2** option).

This can be done by the following parameters:

- Expert  $\rightarrow$  Output  $\rightarrow$  Current output 1 to 2  $\rightarrow$  Turn down
- Expert  $\rightarrow$  Output  $\rightarrow$  Current output 1 to 2  $\rightarrow$  4 mA value
- Expert  $\rightarrow$  Output  $\rightarrow$  Current output 1 to 2  $\rightarrow$  20 mA value

<sup>7)</sup> only for devices with two current outputs

Current span

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Current span

**Description** Determines the current range used to transmit the measured value.

'4...20mA':

Measured variable: 4 ... 20 mA

'4...20mA NAMUR':

Measured variable: 3.8 ... 20.5 mA

'4...20mA US':

Measured variable: 3.9 ... 20.8 mA

'Fixed current':

Measured variable transmitted via HART only

Note:

Currents below 3.6 mA or above 21.95 mA can be used to signal an alarm.

Selection ■ 4...20 mA

■ 4...20 mA NAMUR

■ 4...20 mA US

Fixed current

#### Additional information

## *Meaning of the options*

Option	Current range for process variable	Lower alarm signal level	Upper alarm signal level
420 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA US	3.9 to 20.8 mA	< 3.6 mA	> 21.95 mA
Fixed current	Constant current, defined in the <b>Fixed current</b> parameter ( $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$		

- In the case of an error, the output current assumes the value defined in the **Failure** mode parameter  $(\rightarrow \ \ \ \ \ \ \ \ \ )$  161).
  - If the measured value is out of the measuring range, Current output diagnostic message is issued.
- In a HART multidrop loop only one device can use the analog current to transmit a signal. For all other devices one must set:
  - **■** Current span = Fixed current
  - Fixed current (> 🖺 160) = 4 mA

Fixed current	

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Fixed current

Prerequisite Current span ( $\rightarrow \equiv 160$ ) = Fixed current

**Description** Define constant value of the output current.

**User entry** 4 to 22.5 mA

Damping output

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Damping out.

**Description** Reaction time of the output signal on fluctuation in the measured value.

**User entry** 0.0 to 999.9 s

**Additional information** Fluctuations of the measured value affect the output current with an exponential delay,

the time constant  $\tau$  of which is defined in this parameter. With a small time constant the output reacts immediately to changes of the measured value. With a big time constant the reaction of the output is more delayed. For  $\tau = 0$  (factory setting) there is no damping.

Failure mode

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Failure mode

Prerequisite Current span ( $\rightarrow \triangleq 160$ )  $\neq$  Fixed current

**Description** Defines which current the output assumes in the case of an error.

'Min.': < 3.6mA 'Max.': > 21.95mA

'Last valid value':

Last valid value before occurrence of the error.

'Actual value':

Output current is equal to the measured value; error is ignored.

'Defined value': User defined value.

**Selection** ■ Min.

Max.

■ Last valid value

Actual value

■ Defined value

## Additional information

## Meaning of the options

Min.

The current output adopts the value of the lower alarm level according to the **Current span** parameter ( $\rightarrow \triangleq 160$ ).

Max.

The current output adopts the value of the upper alarm level according to the **Current span** parameter ( $\Rightarrow \triangleq 160$ ).

Last valid value

The current remains constant at the last value it hat before the error occurred.

Actual value

The output current follows the actual measured value; the error is ignored.

Defined value

The output current assumes the value defined in the **Failure current** parameter  $(\rightarrow \implies 162)$ .

The error behavior of other output channels is not influenced by these settings but is defined in separate parameters.

Failure current		
Navigation		
Prerequisite	Failure mode (→ 🗎 161) = Defined value	
Description	Defines which current the output assumes in case of an error.	
User entry	3.59 to 22.5 mA	
Output current 1 to 2	2	
Output current 1 to 2	2	

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Curr.output 1 to 2  $\rightarrow$  Output curr. 1 to 2

**Description** Shows the actual calculated value of the output current.

## "Switch output" submenu

i

The **Switch output** submenu ( $\rightarrow \triangleq 163$ ) is only visible for devices with switch output. <sup>8)</sup>

*Navigation* 

#### Switch output function

## **Navigation**

#### Description

Defines the function of the switch output.

'Off'

The switch output is always open (non-conductive)

'On'

The switch output is always closed (conductive).

'Diagnostic behavior'

The switch output is normally closed and is only opened if a diagnostic event is present.

'Limit'

The switch output is normally closed and is only opened if a measured variable exceeds a defined limit.

'Digital output'

The switch output is controlled by one of the digital output blocks of the device.

#### Selection

- Off
- On
- Diagnostic behavior
- Limit
- Digital Output

#### Additional information

#### Meaning of the options

Off

The output is always open (non-conductive).

■ On

The output is always closed (conductive).

Diagnostic behavior

The output is normally closed and is only opened if a diagnostic event is present. The **Assign diagnostic behavior** parameter ( $\rightarrow \implies 164$ ) determines for which type of event the output is opened.

Limit

The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters:

- **■** Switch-on value (→ 🗎 165)
- **■** Switch-off value (→ 🖺 166)
- Digital Output

The switching state of the output tracks the output value of a DI function block. The function block is selected in the **Assign status** parameter ( $\Rightarrow \implies 164$ ).

i

The **Off** and **On** options can be used to simulate the switch output.

<sup>8)</sup> Ordering feature 020 "Power supply; Output", option B, E or G

Assign status

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Assign status

Prerequisite Switch output function (→ 🖺 163) = Digital Output

**Description** Assigns a Discrete Output Block or an Advanced Diagnostic Block to the switch output.

Selection ■ Off

Digital output AD 1Digital output AD 2

Additional information The Digital output AD 1 and Digital output AD 2 options refer to the Advanced

Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the

switch output.

Assign limit

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Assign limit

Prerequisite Switch output function ( $\rightarrow \triangleq 163$ ) = Limit

**Description** Defines which process variable will be checked for limit violation.

Selection ■ Off

Level linearized

Distance

• Interface linearized \*

• Interface distance <sup>2</sup>

Thickness upper layer \*

■ Terminal voltage

■ Electronic temperature

Measured capacitance <sup>3</sup>

■ Relative echo amplitude

Relative interface amplitude \*

Absolute echo amplitude

Absolute interface amplitude \*

Assign diagnostic behavior

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Assign diag. beh

Prerequisite Switch output function (→ 🖺 163) = Diagnostic behavior

**Description** Defines to which behavior of diagnostic events the switch output reacts.

<sup>\*</sup> Visibility depends on order options or device settings

Selection

Alarm

Alarm or warning

Warning

Switch-on value

Navigation 

Prerequisite Switch output function ( $\rightarrow \equiv 163$ ) = Limit

Description Defines the switch-on point.

The output is closed if the assigned process variable rises above this point.


User entry Signed floating-point number

Additional information

The switching behavior depends on the relative position of the **Switch-on value** and Switch-off value parameters:

## Switch-on value > Switch-off value


- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.



- Α Switch-on value
- В Switch-off value
- Output closed (conductive)
- Output opened (non-conductive)

## Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on delay	

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Switch-on delay

Prerequisite ■ Switch output function (→ 🖺 163) = Limit

■ Assign limit (→ 🖺 164) ≠ Off

**Description** Defines the delay applied before the output is switched on.

**User entry** 0.0 to 100.0 s

Switch-off value	

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Switch-off value

Prerequisite Switch output function (→ 🖺 163) = Limit

**Description** Defines the switch-off point.

The output is opened if the assigned process variable falls below this point.

**User entry** Signed floating-point number

**Additional information** The switching behavior depends on the relative position of the **Switch-on value** and

Switch-off value parameters; description: see the Switch-on value parameter

(→ 🖺 165).

Switch-off delay

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Switch-off delay

Prerequisite • Switch output function ( $\rightarrow \stackrel{\triangle}{=} 163$ ) = Limit

■ Assign limit (→ 🖺 164) ≠ Off

**Description** Defines the delay applied before the output is switched off.

**User entry** 0.0 to 100.0 s

Failure mode

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Failure mode

Prerequisite Switch output function (→ 🗎 163) = Limit or Digital Output

**Description** Defines the state of the switch output in case of an error.

**Selection** • Actual status

OpenClosed

Additional information

Switch status

**Navigation**  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Switch status

**Description** Current status of the switch output.

Invert output signal

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Switch output  $\rightarrow$  Invert outp.sig.

**Description** 'No'

The switch output behaves as per its parameter setting.

'Yes'

The switching behavior is inverted as compared to its parameter setting.

Selection ■ No

Yes

# Additional information

# Meaning of the options

No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

# "Display" submenu

**Pisplay** submenu is only visible if a display module is connected to the device.

Navigation 

Language

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Language

Description Set display language.

Selection ■ English

Deutsch

Français ■ Español

■ Italiano

Nederlands

Portuguesa ■ Polski

**■** русский язык (Russian) \*

Svenska

Türkçe

■ 中文 (Chinese) \*

■ 日本語 (Japanese) \*

■ 한국어 (Korean) \*
■ Bahasa Indonesia \*

tiếng Việt (Vietnamese) \*

čeština (Czech)

**Factory setting** The language selected in feature 500 of the product structure.

If no language has been selected: English

#### Additional information

## Format display

Navigation 

Description Select how measured values are shown on the display.

■ 1 value, max. size Selection

■ 1 bargraph + 1 value

■ 2 values

■ 1 value large + 2 values


4 values

Visibility depends on order options or device settings


## Additional information




■ 50 "Format display" = "1 value, max. size"




■ 51 "Format display" = "1 bargraph + 1 value"



■ 52 "Format display" = "2 values"



■ 53 "Format display" = "1 value large + 2 values"



■ 54 "Format display" = "4 values"

• If more measured values are specified than the current display mode permits, the values alternate on the device display. The display time until the next change is configured in the **Display interval** parameter ( $\rightarrow \implies 171$ ).

Value 1 to 4 display

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Value 1 display

**Description** Select the measured value that is shown on the local display.

**Selection** • Level linearized

Distance

Interface linearized \*
 Interface distance \*

Thickness upper layer <sup>7</sup>

• Current output 1

Measured current

Current output 2Terminal voltage

Electronic temperature

Measured capacitance \*

Analog output adv. diagnostics 1Analog output adv. diagnostics 2

Factory setting For level measurements

ullet Value 1 display: Level linearized

■ Value 2 display: Distance

■ Value 3 display: Current output 1

Value 4 display: None

Decimal places 1 to 4

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Decimal places 1

**Description** This selection does not affect the measurement and calculation accuracy of the device.

Selection • x

x.xx.xx

X.XXX

x.xxxx

**Additional information** The setting does not affect the measuring or computational accuracy of the device.

Display interval

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Display interval

**Description** Set time measured values are shown on display if display alternates between values.

**User entry** 1 to 10 s

<sup>\*</sup> Visibility depends on order options or device settings

#### Additional information

This parameter is only relevant if the number of selected measuring values exceeds the number of values the selected display format can display simultaneously.

Display damping

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Display damping

**Description** Set display reaction time to fluctuations in the measured value.

**User entry** 0.0 to 999.9 s

Header 🗈


**Navigation**  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Header

**Description** Select header contents on local display.

**Selection** ■ Device tag

■ Free text

## Additional information



l Position of the header text on the display

*Meaning of the options* 

- Device tag
- Is defined in the **Device tag** parameter ( $\rightarrow \triangleq 126$ ).
- Free text

Is defined in the **Header text** parameter ( $\rightarrow \implies 172$ ).

Header text

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Header text

Prerequisite Header (→ 🖺 172) = Free text

**Description** Enter display header text.

**User entry** Character string comprising numbers, letters and special characters (12)

**Additional information** The number of characters which can be displayed depends on the characters used.

Separator

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Separator

**Description** Select decimal separator for displaying numerical values.

Selection •

■ ,

Number format

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Number format

**Description** Choose number format for the display.

Selection ■ Decimal ■ ft-in-1/16"

**Additional information** The **ft-in-1/16"** option is only valid for distance units.

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Dec. places menu

**Description** Select number of decimal places for the representation of numbers within the operating

menu.

Selection ■ x

x.x x.xx x.xxx x.xxx

Additional information

Decimal places menu

■ Is only valid for numbers in the operating menu (e.g. **Empty calibration**, **Full calibration**), but not for the measured value display. The number of decimal places for the measured value display is defined in the **Decimal places 1 to 4** → 🖺 171

parameters.

• The setting does not affect the accuracy of the measurement or the calculations.

**Backlight** 

**Navigation**  $\blacksquare \blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Backlight

**Prerequisite** The device has the SD03 local display (with optical keys).

**Description** Switch the local display backlight on and off.

Selection

■ Disable

■ Enable

## Additional information

# Meaning of the options

Disable

Switches the backlight off.

Enable

Switches the backlight on.

i

Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

# Contrast display

**Navigation** Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Display  $\rightarrow$  Contrast display

**Description** Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

**Factory setting** Dependent on the display.

Additional information

Setting the contrast via push-buttons:

■ Darker: press the 🔘 🖲 buttons simultaneously.

■ Brighter: press the 🕒 📵 buttons simultaneously.

174

# "Configuration backup display" submenu

i

This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

Navigation  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Conf.backup disp

Operating time

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Conf.backup disp  $\rightarrow$  Operating time

**Description** Indicates how long the device has been in operation.

**Additional information** *Maximum time* 

9999 d (≈ 27 years)

Last backup

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Conf.backup disp  $\rightarrow$  Last backup

**Description** Indicates when the last data backup was saved to the display module.

**Configuration management** 

**Navigation**  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Conf.backup disp  $\rightarrow$  Config. managem.

**Description** Select action for managing the device data in the display module.

Selection • Cancel

Execute backup

■ Restore

Duplicate

lacktriangle Compare

Clear backup data

#### Additional information

## Meaning of the options

#### Cancel

No action is executed and the user exits the parameter.

## Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

#### Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

#### Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type

## Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ( $\rightarrow \implies 176$ ).

## Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state	
Navigation	
Description	Displays which backup action is currently in progress.
Comparison result	
Navigation	
Description	Comparison between present device data and display backup.

#### Additional information

## Meaning of the display options

# Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

## Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

## ■ No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

## Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

#### Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

## ■ Dataset incompatible

The data sets are incompatible and can not be compared.

To start the comparison, set **Configuration management** ( $\rightarrow \triangleq 175$ ) = **Compare**.

If the transmitter configuration has been duplicated from a different device by Configuration management (→ 🗎 175) = Duplicate, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be Settings not identical.

## "Administration" submenu

*Navigation*  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration

Define access code

**Navigation**  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Def. access code

**Description** Define release code for write access to parameters.

**User entry** 0 to 9 999

#### Additional information

- If the factory setting is not changed or if "0" is entered, the parameters are not write-protected and the device configuration data can therefore always be modified. The user is logged on in the "Maintenance" role.
- The write protection affects all parameters marked with the fall symbol in the document. On the local display, the fall symbol in front of a parameter indicates that the parameter is write-protected.
- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter  $( \rightarrow \implies 135)$ .
- Please contact your Endress+Hauser Sales Center if you lose the access code.
- If operating via the local display: the new access code is only valid once it has been confirmed in the **Confirm access code** parameter ( $\Rightarrow \triangleq 180$ ).

Device reset

**Navigation**  $\blacksquare \Box$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Device reset

**Description** Reset the device configuration - either entirely or in part - to a defined state.

Selection • Cancel

- To factory defaults
- To delivery settings
- Of customer settings
- To transducer defaults
- Restart device

#### Additional information

# Meaning of the options

Cancel

No action

■ To factory defaults

All parameters are reset to the order-code specific factory setting.

To delivery settings

All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered.

This option is only visible if customer specific settings have been ordered.

178

## Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

## ■ To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

## Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

"Define access code" wizard

i

The **Define access code** wizard is only available when operating via the local display. When operating via an operating tool, the **Define access code** parameter is located directly in the **Administration** submenu. The **Confirm access code** parameter is not available for operation via operating tool.

Navigation

Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Def. access code

Define access code		<u> </u>
Navigation	Setup → Advanced setup → Administration → Def. access code → Def. access code	ode
Description	→ 🖺 178	
Confirm access code		
Navigation	Setup → Advanced setup → Administration → Def. access code → Confirm code	ē
Description	Confirm the entered access code.	
User entry	0 to 9999	

## 17.5 "Diagnostics" menu

#### **Actual diagnostics**

**Navigation**  $\Box$  Diagnostics  $\rightarrow$  Actual diagnos.

**Description** Displays current diagnostic message.

**Additional information** The display consists of:

- Symbol for event behavior
- Code for diagnostic behavior
- Operating time of occurrence
- Event text
- If several messages are active at the same time, the messages with the highest priority is displayed.
- Information on what is causing the message, and remedy measures, can be viewed via the  $\mathfrak{G}$  symbol on the display.

#### **Timestamp**

**Navigation** □ Diagnostics → Timestamp

**Description** Displays the timestamp for the currently active diagnostic message.

#### Previous diagnostics

**Description** Displays the last diagnostic message which has been active before the current message.

**Additional information** The display consists of:

- Symbol for event behavior
- Code for diagnostic behavior
- Operating time of occurrence
- Event text
- The condition displayed may still apply. Information on what is causing the message, and remedy measures, can be viewed via the ① symbol on the display.

**Timestamp** 

**Navigation** □ Diagnostics → Timestamp

**Description** Shows the timestamp of the previous diagnostic message.

Operating time from restart

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Time fr. restart

**Description** Displays the time the device has been in operation since the last device restart.

Operating time

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Operating time

**Description** Indicates how long the device has been in operation.

**Additional information** *Maximum time* 

9999 d (≈ 27 years)

## 17.5.1 "Diagnostic list" submenu

Navigation  $\Box$  Diagnostics  $\rightarrow$  Diagnostic list

Diagnostics 1 to 5

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Diagnostic list  $\rightarrow$  Diagnostics 1

**Description** Display the current diagnostics messages with the highest to fifth-highest priority.

**Additional information** The display consists of:

Symbol for event behaviorCode for diagnostic behaviorOperating time of occurrence

■ Event text

Timestamp 1 to 5

**Navigation** Diagnostics  $\rightarrow$  Diagnostic list  $\rightarrow$  Timestamp 1 to 5

**Description** Timestamp of the diagnostic message.

## 17.5.2 "Event logbook" submenu



The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Filter options

Navigation

Diagnostics → Event logbook → Filter options

Description

Define which category of event messages is shown in the Events list submenu.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

## Additional information



- This parameter is only used for operation via the local display.
- The status signals are categorized according to NAMUR NE 107.

#### "Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ( $\rightarrow \implies 184$ ). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- 🕒: Event has ended
- Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

#### Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation  $\square$  Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Event list

## 17.5.3 "Device information" submenu

*Navigation*  $\square$  Diagnostics  $\rightarrow$  Device info

Device tag

**Navigation**  $\square$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Device tag

**Description** Enter the name for the measuring point.

**User interface** Character string comprising numbers, letters and special characters

Serial number

**Navigation**  $\blacksquare \square$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Serial number

**Description** Shows the serial number of the measuring device.

Additional information

Uses of the serial number

- To identify the device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer
- The serial number is also indicated on the nameplate.

Firmware version

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Firmware version

**Description** Shows the device firmware version installed.

User interface xx.yy.zz

**Additional information** For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.

Device name

**Navigation**  $\blacksquare \square$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Device name

**Description** Shows the name of the transmitter.

Order code

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Order code

**Description** Shows the device order code.

**User interface** Character string comprising numbers, letters and special characters

**Additional information** The order code is generated from the extended roder code, which defines all device

features of the product structure. In contrast, the device features can not be read directly

from the order code.

Extended order code 1 to 3

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Ext. order cd. 1

**Description** Display the three parts of the extended order code.

**User interface** Character string comprising numbers, letters and special characters

**Additional information** The extended order code indicates the version of all the features of the product structure

and thus uniquely identifies the device.

Device revision

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Device revision

**Description** Shows the device revision with which the device is registered with the HART

Communication Foundation.

**Additional information** The device revision is used to allocate the correct Device Description file (DD) to the device.

**Device ID** 

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Device ID

**Description** Shows the device ID for identifying the device in a HART network.

**Additional information** In addition to the Device type and Manufacturer ID, the Device ID is part of the unique

device identification (Unique ID) which characterizes each HART device unambiguously.

Device type

**Navigation**  $\Box$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Device type

**Description** Shows the device type with which the measuring device is registered with the HART

Communication Foundation.

Additional information

Manufacturer ID

**Navigation**  $\Box$  Diagnostics  $\rightarrow$  Device info  $\rightarrow$  Manufacturer ID

**Description** Use this function to view the manufacturer ID with which the measuring device is

registered with the HART Communication Foundation.

**User interface** 2-digit hexadecimal number

**Factory setting** 0x11 (for Endress+Hauser)

## 17.5.4 "Measured values" submenu


*Navigation*  $\blacksquare \Box$  Diagnostics  $\rightarrow$  Measured val.

**Distance** 

**Navigation**  $\blacksquare \Box$  Diagnostics  $\rightarrow$  Measured val.  $\rightarrow$  Distance

or threaded connection) and the level.

Additional information



■ 55 Distance for liquid measurements

The unit is defined in the **Distance unit** parameter ( $\rightarrow \triangleq 126$ ).

Level linearized

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Measured val.  $\rightarrow$  Level linearized

**Description** Displays linearized level.

**Additional information** The unit is defined by the **Unit after linearization** parameter  $\rightarrow \triangleq 145$ .

Output current 1 to 2

**Navigation**  $\blacksquare \blacksquare$  Diagnostics  $\rightarrow$  Measured val.  $\rightarrow$  Output curr. 1 to 2

**Description** Shows the actual calculated value of the output current.

#### Measured current 1

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Measured val.  $\rightarrow$  Measur. curr. 1

**Description** Shows the current value of the current output which is currently measured.

## Terminal voltage 1

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Measured val.  $\rightarrow$  Terminal volt. 1

**Description** Shows the current terminal voltage that is applied at the output.

## 17.5.5 "Data logging" submenu

#### Assign channel 1 to 4

#### Navigation

#### Description

Assign a process variable to logging channel.

#### Selection

- Off
- Level linearized
- Distance
- Unfiltered distance
- Interface linearized
- Interface distance
- Unfiltered interface distance
- Thickness upper layer <sup>7</sup>
- Current output 1
- Measured current
- Current output 2
- Terminal voltage
- Electronic temperature
- Measured capacitance \*
- Absolute echo amplitude
- Relative echo amplitude
- Absolute interface amplitude \*
- Relative interface amplitude
- Absolute EOP amplitude
- EOP shift
- Noise of signal
- Calculated DC value \*
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2

## Additional information

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The logged data are deleted if a new option is selected in this parameter.

<sup>\*</sup> Visibility depends on order options or device settings

Logging interval

**Navigation**  $\square$  Diagnostics  $\rightarrow$  Data logging  $\rightarrow$  Logging interval

Diagnostics → Data logging → Logging interval

**Description** Define the logging interval tlog for data logging. This value defines the time interval

between the individual data points in the memory.

**User entry** 1.0 to 3 600.0 s

#### Additional information

This parameter defines the interval between the individual data points in the data log, and thus the maximum loggable process time  $T_{log}$ :

- $\blacksquare$  If 1 logging channel is used: T  $_{log}$  = 1000  $\cdot$  t  $_{log}$
- If 2 logging channels are used:  $T_{log} = 500 \cdot t_{log}$
- If 3 logging channels are used:  $T_{log} = 333 \cdot t_{log}$
- If 4 logging channels are used:  $T_{log} = 250 \cdot t_{log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T  $_{log}$  always remains in the memory (ring memory principle).

🎦 The logged data are deleted if this parameter is changed.

Example

## When using 1 logging channel

- $T_{log} = 1000 \cdot 1 \text{ s} = 1000 \text{ s} \approx 16.5 \text{ min}$
- $T_{log} = 1000 \cdot 10 \text{ s} = 1000 \text{ s} \approx 2.75 \text{ h}$
- $T_{log} = 1000 \cdot 80 \text{ s} = 80000 \text{ s} \approx 22 \text{ h}$
- $\bullet$  T<sub>log</sub> = 1000 · 3600 s = 3600000 s ≈ 41 d

Clear logging data

**Navigation** □ Diagnostics → Data logging → Clear logging

Diagnostics → Data logging → Clear logging

**Description** Clear the entire logging data.

Selection • Cancel


Clear data

## "Display channel 1 to 4" submenu




The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.



Navigation

□ Diagnostics → Data logging → Displ.channel 1 to 4

## 17.5.6 "Simulation" submenu

The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.

Conditions which can be simulated

Condition to be simulated	Associated parameters
Specific value of a process variable	<ul> <li>Assign measurement variable (→ 🖺 195)</li> <li>Process variable value (→ 🖺 195)</li> </ul>
Specific value of the output current	<ul> <li>Current output simulation (→  ☐ 195)</li> <li>Value current output (→  ☐ 196)</li> </ul>
Specific state of the switch output	<ul> <li>Switch output simulation (→ 🖺 196)</li> <li>Switch status (→ 🖺 196)</li> </ul>
Existence of an alarm	Device alarm simulation (→ 🖺 197)

## Structure of the submenu

Navigation  $\blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation

<b>▶</b> Simulation	
Assign measurement variable	→ 🖺 195
Process variable value	→ 🖺 195
Current output 1 to 2 simulation	→ 🖺 195
Value current output 1 to 2	→ 🖺 196
Switch output simulation	→ 🖺 196
Switch status	→ 🖺 196
Device alarm simulation	→ 🖺 197

### Description of parameters

 $\blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation **Navigation** 

#### Assign measurement variable

**Navigation** 

Description Defines the process variable to be simulated.

Selection Off

- Level
- Interface
- Thickness upper layer <sup>7</sup> ■ Level linearized ■ Interface linearized Thickness linearized

#### Additional information

- The value of the variable to be simulated is defined in the **Process variable value** parameter ( $\rightarrow \blacksquare 195$ ).
- If **Assign measurement variable**  $\neq$  **Off**, a simulation is active. This is indicated by a diagnotic message of the *Function check (C)* category.

Process variable value

Navigation Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Proc. var. value

**Prerequisite** Assign measurement variable ( $\rightarrow \equiv 195$ )  $\neq \text{ Off}$ 

Description Defines the value of the selected variable.

The outputs assume values or states according to this value.

**User entry** Signed floating-point number

Additional information Downstream measured value processing and the signal output use this simulation value. In

this way, users can verify whether the measuring device has been configured correctly.

## Current output 1 to 2 simulation

**Navigation**  $\blacksquare$  Expert → Diagnostics → Simulation → Curr.out. 1 to 2 sim.

Description Switch the simulation of the current output on and off.

Visibility depends on order options or device settings

Selection ■ Off

■ On

**Additional information** An active simulation is indicated by a diagnostic message of the *Function check (C)* 

category.

Value current output 1 to 2

**Navigation**  $\blacksquare \blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Value curr.out 1 to 2

Prerequisite Current output simulation (→ 🗎 195) = On

**Description** Defines the value of the simulated output current.

**User entry** 3.59 to 22.5 mA

**Additional information** The current output assumes the value specified in this parameter. In this way, users can

verify the correct adjustment of the current output and the correct function of connected

control units.

Switch output simulation

**Navigation**  $\blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Switch sim.

**Description** Switch the simulation of the switch output on and off.

**Selection** ■ Off

On

Switch status

**Navigation**  $\blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Switch status

Prerequisite Switch output simulation ( $\rightarrow \equiv 196$ ) = On

**Description** Current status of the switch output.

**Selection** ■ Open

Closed

Additional information

The switch status assumes the value defined in this parameter. This helps to check correct

operation of connected control units.

Device alarm simulation

**Navigation**  $\blacksquare \blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Dev. alarm sim.

**Description** Switch the device alarm on and off.

Selection ■ Off

■ On

**Additional information** When selecting the **On** option, the device generates an alarm. This helps to check the

correct output behavior of the device in the case of an alarm.

An active simulation is indicated by the **♥C484 Failure mode simulation** diagnostic

message.

Diagnostic event simulation

**Navigation**  $\blacksquare$  Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation  $\rightarrow$  Diag. event sim.

**Description** Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select 'Off'.

**Additional information** When operated via the local display, the selection list can be filtered according to the event

categories (Diagnostic event category parameter).

## 17.5.7 "Device check" submenu

Navigation  $\Box$  Diagnostics  $\rightarrow$  Device check

 Start device check

 Navigation
 □ Diagnostics → Device check → Start dev. check

 Description
 Start a device check.

Selection ■ No ■ Yes

**Additional information** In the case of a lost echo a device check can not be performed.

Result device check

**Navigation**  $\blacksquare \Box$  Diagnostics  $\rightarrow$  Device check  $\rightarrow$  Result dev.check

**Description** Displays the result of the device check.

Additional information Meaning of the display options

Installation ok

Measurement possible without restrictions.

Accuracy reduced

A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes.

■ Measurement capability reduced

A measurement is currently possible. However, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.

Check not done

No device check has been performed.

Last check time

**Navigation**  $\blacksquare$  Diagnostics  $\rightarrow$  Device check  $\rightarrow$  Last check time

**Description** Displays the operating time at which the last device check has been performed.

**User interface** Character string comprising numbers, letters and special characters

#### Level signal

**Navigation**  $\Box$  Diagnostics  $\rightarrow$  Device check  $\rightarrow$  Level signal

**Prerequisite** Device check has been performed.

**Description** Displays result of the device check for the level signal.

**User interface** ■ Check not done

Check not OKCheck OK

Additional information

For **Level signal** = **Check not OK**: Check the mounting position of the device and the

dielectric constant of the medium.

### Launch signal

**Navigation**  $\blacksquare \square$  Diagnostics  $\rightarrow$  Device check  $\rightarrow$  Launch signal

**Prerequisite** Device check has been performed.

**Description** Displays result of the display check for the launch signal.

**User interface** ■ Check not done

Check not OKCheck OK

Additional information

For **Launch signal** = **Check not OK**: Check the mounting position of the device. In non-

metallic vessels use a metal plate or a metal flange.

#### 17.5.8 "Heartbeat" submenu



The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

## **Detailed description**

SD01872F

Navigation  $\Box \Box$  Diagnostics  $\rightarrow$  Heartbeat

Levelflex FMP50 HART Index

# Index

Α	Deactivate SIL/WHG (Wizard)	
Access authorization to parameters	Decimal places 1 (Parameter)	
Read access	Decimal places menu (Parameter)	
Write access	Define access code (Parameter) 178,	
Access code	Define access code (Wizard)	
Incorrect input	Define the access code	
Access status display (Parameter)	Device alarm simulation (Parameter)	
Access status tooling (Parameter)	Device check (Submenu)	
Accessories	Device Descriptions	
Communication-specific	Device ID (Parameter)	
Device-specific	Device information (Submenu)	
Service-specific	Device name (Parameter)	
System components	Device replacement	
Activate table (Parameter)	Device reset (Parameter)	
Actual diagnostics (Parameter)	Device revision (Parameter)	
Administration (Submenu)	Device tag (Parameter)	
Advanced process conditions (Parameter)	Device type (Parameter)	
Advanced setup (Submenu)	Diagnostic event	
Application	In the operating tool	
Assign channel 1 to 4 (Parameter)	Diagnostic event simulation (Parameter)	
Assign current output (Parameter)	Diagnostic list	
Assign diagnostic behavior (Parameter)	Diagnostic list (Submenu)	
Assign limit (Parameter)	Diagnostic message	
Assign measurement variable (Parameter)	Diagnostics	. 00
Assign status (Parameter)	Symbols	86
В	Diagnostics (Menu)	
Backlight (Parameter)	Diagnostics 1 (Parameter)	
Backup state (Parameter)	Diameter (Parameter)	
Blocking distance (Parameter)	DIP switch	
Bluetooth® wireless technology 53	see Write protection switch	
Bluetooth® wireless technology	see Write protection switch Display (Submenu)	169
Bypass	see Write protection switch Display (Submenu)	
<del></del>	Display (Submenu)	52
Bypass	Display (Submenu)	52 192
Bypass       25         C       Cleaning       96         Clear logging data (Parameter)       191	Display (Submenu)	52 192 172
Bypass       25         C       Cleaning       96         Clear logging data (Parameter)       191         Code incorrect (Parameter)       155	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)	52 192 172 171
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)	52 192 172 171 62
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal	52 192 172 171 62 . 63 98
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal  Distance (Parameter)  129, 133,	52 192 172 171 62 . 63 98 188
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal  Distance (Parameter)  129, 133,	52 192 172 171 62 . 63 98 188
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal  Distance (Parameter)  Distance unit (Parameter)  Document	52 192 172 171 62 . 63 98 188 126
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal  Distance (Parameter)  129, 133,	52 192 172 171 62 . 63 98 188 126
Bypass	Display (Submenu)  Display and operating module FHX50  Display channel 1 to 4 (Submenu)  Display damping (Parameter)  Display interval (Parameter)  Display module  Display symbols  Disposal  Distance (Parameter)  Distance unit (Parameter)  Document  Purpose	52 192 172 171 62 . 63 98 188 126
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Distance unit (Parameter) Document Purpose	52 192 172 171 62 . 63 98 188 126
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Distance unit (Parameter) Document Purpose  E Electronics housing	52 192 172 171 62 . 63 98 188 126
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design	52 192 172 171 62 . 63 98 188 126 . 5
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Display symbols Distance (Parameter) Distance unit (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter)	52 192 172 171 62 . 63 98 188 126 . 5
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Distance unit (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter)	52 192 172 171 62 . 63 98 188 126 . 5
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Distance unit (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display	52 192 172 171 62 . 63 98 188 126 5
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display Event history	52 192 172 171 62 . 63 98 188 126 5
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display Event history Event level	52 192 172 171 62 . 63 98 188 126 5 12 128 135 . 69 . 93
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display Event history Event level Explanation	52 192 172 171 62 . 63 98 188 126 5 12 128 135 . 69 . 93
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display Event history Event level Explanation Symbols	52 192 172 171 62 . 63 98 188 126 5 12 128 135 . 69 . 93 86 . 86
Bypass	Display (Submenu) Display and operating module FHX50 Display channel 1 to 4 (Submenu) Display damping (Parameter) Display interval (Parameter) Display module Display symbols Disposal Distance (Parameter) Document Purpose  E Electronics housing Design Empty calibration (Parameter) Enter access code (Parameter) Envelope curve display Event history Event level Explanation	52 192 172 171 62 . 63 98 188 126 5 12 128 135 . 69 . 93 86 . 86 184

Index Levelflex FMP50 HART

Event text	Locking status
Events list	Locking status (Parameter)
Extended order code 1 (Parameter)	Logging interval (Parameter)
	M
F	Maintenance
Failure current (Parameter) 162	Managing the device configuration 80
Failure mode (Parameter) 161, 167	Manufacturer ID (Parameter) 187
FHX50	Mapping (Wizard)
Field of application	Mapping end point (Parameter) 132, 133
Residual risks	Maximum value (Parameter) 147
Filter options (Parameter)	Measured current 1 (Parameter)
Filtering the event logbook 93	Measured value symbols 64
Firmware version (Parameter) 185	Measured values (Submenu) 188
Fixed current (Parameter) 160	Media
Format display (Parameter)	Medium group (Parameter)
Free text (Parameter)	Medium property (Parameter) 136
Full calibration (Parameter)	Medium type (Parameter) 136
Functional Safety Manual (FY)	Menu
FV (HART device variable) 70	Diagnostics
TT	Setup
H	Mounting outside the vessel
Hardware write protection	Mounting position for level measurements 16
HART device variables	N
HART protocol	
HART-Integration	Non-metal vessels
Header (Parameter)	Number format (Parameter) 173
Header text (Parameter)	0
Heartbeat (Submenu) 200	Operating elements
Housing 12	Diagnostic message
Design	Operating module
Turning	Operating inodule:
I	Operating time from restart (Parameter)
Input mask	Operational safety
Intended use	Order code (Parameter)
Intermediate height (Parameter)	Output current 1 to 2 (Parameter) 162, 188
Invert output signal (Parameter)	Output echo lost (Parameter)
mivere output signar (r draineter)	Overvoltage protection
K	General information
Keypad lock	
Disabling 61	P
Enabling 61	Present mapping (Parameter) 132
-	Present probe length (Parameter) 156, 158
L	Previous diagnostics (Parameter) 181
Language (Parameter)	Probe grounded (Parameter) 156
Last backup (Parameter)	Probe length correction (Wizard) 158
Last check time (Parameter)	Probe settings (Submenu)
Launch signal (Parameter)	Process property (Parameter) 137
Level (Parameter)	Process variable value (Parameter) 195
Level (Submenu)	Product safety
Level correction (Parameter)	Purpose of this document
Level linearized (Parameter)	PV (HART device variable) 70
Level signal (Parameter)	n.
Level unit (Parameter)	R
Linearization (Submenu) 142, 143, 144	Ramp at echo lost (Parameter)
Linearization type (Parameter)	Read access
Local display	Record map (Parameter) 132, 133
see Diagnostic message	Registered trademarks
see In alarm condition	

Levelflex FMP50 HART Index

Remedial measures	Heartbeat
Calling up	Level
Closing	Linearization
Remote operation	Measured values
Repair concept	Probe settings
Replacing a device	Safety settings
Requirements for personnel	Simulation
Reset write protection (Parameter) 155	Switch output
Result device check (Parameter)	SV (HART device variable) 70
Return	Switch output (Submenu)
Rod probe	Switch output function (Parameter)
Design	Switch output simulation (Parameter)
Rod probes	Switch status (Parameter) 167, 196
Lateral loading capacity	Switch-off delay (Parameter)
Shortening	Switch-off value (Parameter)
Rope probe	Switch-on delay (Parameter)
Design	Switch-on value (Parameter)
5	, ,
Rope probes	Symbols
Mounting	For correction
Shortening	In the text and numeric editor
Tensile loading capacity	System components
S	T
Safety instructions	Table mode (Parameter)
Basic	Table number (Parameter)
Safety Instructions (XA)	Tank type (Parameter)
Safety settings (Submenu)	Terminal voltage 1 (Parameter)
Securing rod probes	Thermal insulation
Securing rope probes	Threaded connection
Separator (Parameter)	Timestamp (Parameter)
Serial number (Parameter)	Timestamp 1 to 5 (Parameter)
Service interface (CDI)	Tool
Setting the operating language	Transmitter
Settings	Turning the display
Managing the device configuration 80	Turning the display module
Operating language	Transmitter housing
Setup (Menu)	Turning
Signal quality (Parameter)	
	Troubleshooting
SIL/WHG confirmation (Wizard)	Tube diameter (Parameter)
Simulation (Submenu)	Turning the display
Spare parts	Turning the display module
Nameplate	TV (HART device variable)
Start device check (Parameter)	U
Status signals 63, 86	_
Stilling well	Underground tanks
Submenu	Unit after linearization (Parameter)
Administration	Use of the measuring device
Advanced setup	see Intended use
Configuration backup display 175	Use of the measuring devices
Current output 1 to 2	Borderline cases
Data logging	Incorrect use
Device check	77
Device information	V
Diagnostic list	Value 1 display (Parameter)
Display	Value current output 1 to 2 (Parameter) 196
Display channel 1 to 4	Value echo lost (Parameter)
Event list	TAT
Event logbook	W
Events list	Wizard
	Deactivate SIL/WHG

Index Levelflex FMP50 HART

Define access code
Mapping
Probe length correction
SIL/WHG confirmation
Workplace safety
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com