Operating Instructions Micropilot FMR66B PROFINET with Ethernet-APL

Free space radar









- Make sure the document is stored in a safe place such that it is always available when working on or with the device
- Avoid danger to individuals or the facility: read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures

The manufacturer reserves the right to modify technical data without prior notice. The Endress+Hauser sales organization will supply you with current information and updates to these instructions.

Table of contents

1	About this document 5
1.1 1.2	Purpose of this document5Symbols51.2.1Safety symbols51.2.2Symbols for certain types of
1.3 1.4	Information and graphics5Terms and abbreviations6Documentation61.4.1Technical Information (TI)1.4.2Brief Operating Instructions (KA)61.4.3Safety Instructions (XA)6
1.5	Registered trademarks
2 2.1 2.2 2.3 2.4 2.5 2.6 2.7	Basic safety instructions8Requirements for personnel8Intended use8Workplace safety9Operational safety9Product safety9IT security9Device-specific IT security92.7.1Protecting access via a password102.7.2Access via Web server10
3	Product description 12
5.1	2
4	Incoming acceptance and product identification
4 4.1 4.2	Incoming acceptance and productidentification13Incoming acceptance13Product identification134.2.1Nameplate134.2.2Manufacturer address14
4 4.1 4.2 4.3	Incoming acceptance and productidentification13Incoming acceptance13Product identification134.2.1Nameplate134.2.2Manufacturer address14Storage and transport144.3.1Storage conditions144.3.2Transporting the product to the measuring point14
4 4.1 4.2 4.3 5	Incoming acceptance and productidentification13Incoming acceptance13Product identification134.2.1Nameplate134.2.2Manufacturer address14Storage and transport144.3.1Storage conditions144.3.2Transporting the product to the measuring point14Mounting15
4 4.1 4.2 4.3 5 5.1 5.2	Incoming acceptance and product identification 13 Incoming acceptance 13 Product identification 13 4.2.1 Nameplate 13 4.2.2 Manufacturer address 14 Storage and transport 14 4.3.1 Storage conditions 14 4.3.2 Transporting the product to the measuring point 14 Mounting 15 General instructions 15 5.2.1 Internal vessel fittings 15 5.2.2 Avoiding interference echoes 16 5.2.3 Vertical alignment of antenna axis 16 5.2.4 Radial alignment of the antenna 16
 4.1 4.2 4.3 5.1 5.2 5.3 	Incoming acceptance and product identification 13 Incoming acceptance 13 Product identification 13 4.2.1 Nameplate 13 4.2.2 Manufacturer address 14 Storage and transport 14 4.3.1 Storage conditions 14 4.3.2 Transporting the product to the measuring point 14 Mounting 15 General instructions 15 S.2.1 Internal vessel fittings 15 5.2.2 Avoiding interference echoes 16 5.2.3 Vertical alignment of antenna axis 16 5.2.4 Radial alignment of the antenna 16 5.2.5 Optimization options 16 Mounting the device 16 16
 4.1 4.2 4.3 5.1 5.2 5.3 	Incoming acceptance and productidentification13Incoming acceptance13Product identification13 $4.2.1$ Nameplate13 $4.2.2$ Manufacturer address14Storage and transport14 $4.3.1$ Storage conditions14 $4.3.2$ Transporting the product to the measuring point14Mounting15General instructions15 $5.2.1$ Internal vessel fittings15 $5.2.2$ Avoiding interference echoes16 $5.2.3$ Vertical alignment of antenna axis16 $5.2.4$ Radial alignment of the antenna16 $5.2.5$ Optimization options16 $5.3.1$ Encapsulated antenna, PVDF 40 mm (1.5 in)16 $5.3.2$ Drip-off antenna PTFE 50 mm (2 in)17

	5.3.4 Turning the display module 18	
	5.3.5 Changing the installation position of	
	the display module 19	
F /	5.3.6 Closing the housing covers	
5.4	Post-mounting check	
6	Electrical connection 22	
6.1	Connecting requirements 22	
	6.1.1 Cover with securing screw 22	
()	6.1.2 Potential equalization	
0.2	Connecting the device	
	6.2.1 Supply voltage	
	6.2.3 Overvoltage protection	
	6.2.4 Wiring	
	6.2.5 Terminal assignment 26	
	6.2.6 Cable entries	
	6.2.7 Available device plugs 27	
6.3	Ensuring the degree of protection 28	
<i>с</i> 1	6.3.1 Cable entries	
6.4	Post-connection check	
7	Operation options 29	
7.1	Overview of operation options 29	
7.2	Operating keys and DIP switches on the	
7 0	electronic insert	
1.3	Structure and function of the operating	
	7.3.1 User roles and related access	
	authorization	
7.4	Access to operating menu via local display 30	
	7.4.1 Device display (optional) 30	
	7.4.2 Operation via Bluetooth [®] wireless	
	technology (optional) 30	
7.5	Access to operating menu via Web browser . 31	
	7.5.1 FullCliofi Scope	
	7.5.2 Requirements	
	7.5.4 User interface	
	7.5.5 Disabling the Web server	
	7.5.6 Logging out	
7.6	Access to the operating menu via the	
	operating tool 36	
	7.6.1 Connecting the operating tool 37	
7.7	FieldCare	
70	/./.1 Function range	
7.0	7.8.1 Function scope 38	
8	System integration 39	
8.1	Overview of device description files 39	
	8.1.1 Current version data for the device 39	
	8.1.2 Operating tools	

8.2	Device master file (GSD) 8.2.1 File name of the device master file	39
8.3	(GSD)Cyclic data transmission8.3.1Overview of the modules8.3.2Description of the modules8.3.3Status coding8.3.4Startup configuration	40 41 41 41 42 43
8.4	System redundancy S2	43
9	Commissioning	44
9.1	Preliminaries	44
9.2 9.3	Function check	44
	9.3.1 Via DPOFINET protocol	44
	9.3.2 Via service interface (CDI)	44 45
	9.3.3 Hardware settings	45
	9.3.4 Configuring the communication	τJ
	parameters via the software	45
9.4	Configuring the operating language	46
	9.4.1 Local display	46
	9.4.2 Operating tool	46
	9.4.3 Web server	46
9.5	Configuring the device	47
	9.5.1 Level measurement in bulk solids	4/
	9.5.2 Commissioning with the	1.7
0.6	Commissioning wizard	4/
9.6 9.7	"Simulation" submenu	47 48
9.6 9.7 10	"Simulation" submenu	47 48 4 9
9.6 9.7 10	"Simulation" submenu Operation	47 48 49
9.6 9.7 10 10.1	"Simulation" submenu Operation Reading off the device locking status	47 48 49 49
9.6 9.7 10 10.1 10.2	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to proceed or ditions	47 48 49 49 49
9.6 9.7 10 10.1 10.2 10.3	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions	47 48 49 49 49 49
9.6 9.7 10 10.1 10.2 10.3 11	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting	47 48 49 49 49 49 49 50
9.6 9.7 10 10.1 10.2 10.3 11 11.1	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting General troubleshooting	47 48 49 49 49 49 50 50
9.6 9.7 10 10.1 10.2 10.3 11 11.1	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors	47 48 49 49 49 49 49 50 50 50
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2	"Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostics	47 48 49 49 49 49 50 50 50 50 50
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting General troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message	 47 48 49 49 49 49 50 50 50 50 51
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local	 47 48 49 49 49 49 50 50 50 51 52
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display	 47 48 49 49 49 49 50 50 50 51 52
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Operation Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool	 47 48 49 49 49 49 50 50 50 51 52 52 52
9.0 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting I1.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal	 47 48 49 49 49 49 50 50 50 51 52 52 52 52
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text	 47 48 49 49 49 49 50 50 50 51 52 52 52 52 53
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up	47 48 49 49 49 50 50 50 50 51 52 52 53
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys	47 48 49 49 49 50
9.0 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu	 47 48 49 49 49 49 50 50 50 51 52 52 53 53 54
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3 11.4 11.4	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu Adapting the diagnostic information	47 48 49 49 49 50 50 50 50 51 52 53 53 53 53 53 53 54
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3 11.4 11.4	Netoriality the Echo curve "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Nemedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu Adapting the diagnostic information	47 48 49 49 49 50 50 50 51 52 53 53 54 54
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3 11.4 11.5 11.6 11.7	Needoning the Echo curve "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu Adapting the diagnostic information	47 48 49 49 49 50 50 51 52 52 53 53 54 54
9.0 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3 11.4 11.4 11.5 11.6 11.7	Needoning the Echo curve "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu Adapting the diagnostic information List of diagnostic events List of diagnostic events List of diagnostic events List of diagnostic events List of diagnostic events	47 48 49 49 49 50 50 51 52 53 54 56 57 52 53 54 56
9.6 9.7 10 10.1 10.2 10.3 11 11.1 11.2 11.3 11.4 11.5 11.6 11.7	"Simulation" submenu "Simulation" submenu Reading off the device locking status Reading off measured values Adapting the device to process conditions Adapting the device to process conditions Diagnostics and troubleshooting 11.1.1 General errors Error - SmartBlue operation Diagnostic message 11.3.1 Diagnostic information on local display 11.3.2 Diagnostic information in the operating tool 11.3.3 Status signal 11.3.4 Diagnostic event and event text Remedy informationCalling up 11.4.1 Graphic display with keys 11.4.2 Operating menu Adapting the diagnostic information List of diagnostic events Event logbook 11.7.1 Event history 11.7.2 Filtering the event logbook	47 48 49 49 49 50 50 51 52 53 54 56 57 52 53 54 56 57

11.8	Resetting the device	58 58 58
	electronic insert	58
11.9	Device information	59
11.10	Firmware history	59
12	Maintenance	60
12.1	Exterior cleaning	60
12.2	Seals	60
13	Renair	61
12 1	Concerd information	61
15.1	13 1 1 Repair concept	01 61
	13.1.2 Repair of Fx-certified devices	61
13.2	Spare parts	61
13.3	Replacement	61
	13.3.1 HistoROM	62
13.4	Return	62
13.5	Disposal	62
14	Accessories	63
14 1	Weather protection cover 316I	63
14.2	Plastic weather protection cover	63
14.3	Adjustable flange seal	64
	14.3.1 Seal, adjustable, DN80	64
	14.3.2 Seal, adjustable, DN100	64
	14.3.3 Seal, adjustable, DN150	65
	14.3.4 Seal, adjustable, ASME 3"/ JIS 80A	65
	14.3.5 Seal, adjustable, ASME 4"	66
144	14.3.6 Seal, adjustable, ASME 6"/ JIS 150A	66
14.4	Mounting bracket, adjustable	67
	14.4.1 Dimensions \dots $14.4.2$ Scope of delivery	68
14.5	M12 socket	68
14.6	Remote display FHX50B	69
14.7	Gas-tight feedthrough	71
14.8	Field Xpert SMT70	71
14.9	DeviceCare SFE100	71
14.10	FieldCare SFE500	71
15	Technical data	72
15.1	Input	72
15.2	Output	73
15.3	Environment	74
15.4	Process	79
Index	٢	82

1 About this document

1.1 Purpose of this document

These Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Symbols for certain types of information and graphics

Permitted

Procedures, processes or actions that are permitted

🔀 Forbidden

Procedures, processes or actions that are forbidden

🚹 Tip

Indicates additional information

Reference to documentation

Reference to page

Reference to graphic

Notice or individual step to be observed

1., 2., 3.

Series of steps

L► Result of a step

1, 2, 3, ... Item numbers

A, B, C, ... Views

Endress+Hauser

1.3 Terms and abbreviations

MWP

Maximum working pressure The MWP is indicated on the nameplate.

 $\epsilon_{\rm r}$ (Dk value)

Relative dielectric constant

CDI

Common Data Interface

1.4 Documentation

The following document types are available in the Downloads section of the Endress +Hauser website (www.endress.com/downloads):

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

1.4.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.4.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.4.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

The nameplate indicates the Safety Instructions (XA) that are relevant to the device.

1.5 Registered trademarks

PROFINET®

-

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

Bluetooth®

The *Bluetooth*[®] word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple®

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ[®], VITON[®] Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

2 Basic safety instructions

2.1 Requirements for personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Personnel must be authorized by the plant owner/operator.
- ▶ Be familiar with federal/national regulations.
- Before starting work: personnel must read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Personnel must follow instructions and comply with general policies.

The operating personnel must fulfill the following requirements:

- Personnel are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- Personnel follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in these Operating Instructions is intended for continuous, non-contact level measurement primarily in bulk solids. Because of its operating frequency of approx. 80 GHz, a maximum radiated peak power of 6.3 mW and an average output power of 63 μ W, unrestricted use outside of closed, metallic vessels is also permitted (for example over heaps). Operation does not pose any danger whatsoever to humans and animals.

If the limit values specified in the "Technical data" and the conditions listed in the instructions and additional documentation are observed, the measuring device may be used for the following measurements only:

- Measured process variables: level, distance, signal strength
- Calculable process variables: volume or mass in any shape of vessel

To ensure that the measuring device remains in proper condition for the operation time:

- Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ Observe the limit values in the "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Avoid mechanical damage:

• Do not touch or clean device surfaces with pointed or hard objects.

Clarification of borderline cases:

 For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies it contains (e.g. display module, main electronics module and I/O electronics module) may rise to 80 $^{\circ}$ C (176 $^{\circ}$ F). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

When working on and with the device:

- Wear the required personal protective equipment according to federal/national regulations.
- ► Switch off the supply voltage before connecting the device.

2.4 Operational safety

Risk of injury!

- Operate the device only if it is in proper technical condition, free from errors and faults.
- ▶ The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to the repair of an electrical device.
- Use only original spare parts and accessories from the manufacturer.

Hazardous area

To eliminate danger to persons or the installation when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- Check the nameplate to verify whether the ordered device can be put to its intended use in the hazardous area.
- ► Observe the specifications in the separate supplementary documentation, which is an integral part of this manual.

2.5 Product safety

This device is designed in accordance with good engineering practice to meet state-of-theart safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets the general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings. IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

2.7 Device-specific IT security

The device offers specific functions to support protective measures by the operator. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section:

- Write protection via hardware write protection switch
- Access code to change user role (applies to operation via display, Bluetooth or FieldCare, DeviceCare, asset management tools (e.g., AMS, PDM and Web server)

Function/interface	Factory setting	Recommendation
Access code (also applies to Web server login or FieldCare connection)	Not enabled (0000)	Assign a customized access code during commissioning
Web server	Enabled	On an individual basis following risk assessment
Service interface (CDI)	Enabled	On an individual basis following risk assessment
Write protection via hardware write protection switch	Not enabled	On an individual basis following risk assessment

2.7.1 Protecting access via a password

Different passwords are available to protect write access to the parameters of the device.

Protect write access to the parameters of the device via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.

User-specific access code

Write access to the parameters of the device via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected using the editable, user-specific access code.

When delivered, the device does not have an access code and this code corresponds to 0000 (open).

General notes on the use of passwords

- During commissioning, change the access code used when the device was delivered
- When defining and managing the access code, comply with the general rules for the generation of a secure password
- The user is responsible for managing the access code and for using the code with due care
- \square For further information, see → \blacksquare Resetting the device

2.7.2 Access via Web server

Thanks to the integrated Web server, the device can be operated and configured using a Web browser and via PROFINET with Ethernet-APL. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

Access to the network is required for the PROFINET with Ethernet-APL connection.

Supported functions

Data exchange between the operating unit (such as a notebook, for example,) and measuring device:

- Export parameter settings (PDF file, create documentation of the measuring point configuration)
- Export the Heartbeat Technology verification report (PDF file, only available with the "Heartbeat Verification" application package)
- Download driver (GSDML) for system integration

The Web server is enabled when the device is delivered. The Web server can be disabled via the **Web server functionality** parameter if necessary (e.g., after commissioning).

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

Description of device parameters.

Product description 3

3.1 Product design



• 1 Design of the Micropilot FMR66B

- 1 Electronics housing
- Encapsulated antenna, PVDF, 40 mm (1.5 in), threaded process connection 2
- Encapsulated antenna, PVDF, 40 mm (1.5 in), flange process connection Drip-off antenna 50 mm (2 in), threaded process connection 3
- 4
- 5 Drip-off antenna 50 mm (2 in), flange process connection

4 Incoming acceptance and product identification

4.1 Incoming acceptance



Check the following during incoming acceptance:

- Is the order code on the delivery note (1) identical to the order code on the product sticker (2)?
- Are the goods undamaged?
- Do the data on the nameplate correspond to the order specifications and the delivery note?
- Is the documentation provided?
- If required (see nameplate): are the Safety Instructions (XA) provided?

If one of these conditions is not met, please contact the manufacturer's sales office.

4.2 Product identification

The following options are available for identification of the device:

- Nameplate specifications
- Extended order code with breakdown of the device features on the delivery note
- Device Viewer(www.endress.com/deviceviewer); manually enter the serial number from the nameplate.
 - ← All the information about the measuring device is displayed.
- *Endress+Hauser Operations app*; manually enter the serial number indicated on the nameplate or scan the 2D matrix code on the nameplate.
 - ← All the information about the measuring device is displayed.

4.2.1 Nameplate

The information that is required by law and is relevant to the device is shown on the nameplate, e.g.:

- Manufacturer identification
- Order number, extended order code, serial number
- Technical data, degree of protection
- Firmware version, hardware version
- Approval-related information, reference to Safety Instructions (XA)
- DataMatrix code (information about the device)

4.2.2 Manufacturer address

Endress+Hauser SE+Co. KG Hauptstraße 1 79689 Maulburg, Germany Place of manufacture: See nameplate.

4.3 Storage and transport

4.3.1 Storage conditions

- Use the original packaging
- Store the device in clean and dry conditions and protect from damage caused by shocks

Storage temperature range

See Technical Information.

4.3.2 Transporting the product to the measuring point

WARNING

Incorrect transport!

The housing or sensor can be damaged or pull off. Risk of injury!

- Transport the device to the measuring point in its original packaging or by the process connection.
- ► Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or sensor. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.

5 Mounting

5.1 General instructions

WARNING

Loss of protection rating if the device is opened in a wet environment.

- Only open the device in a dry environment!
- 1. Install the device or turn the housing so that the cable entries do not point upwards.



- 2. Always firmly tighten the housing cover and the cable entries.
- 3. Counter-tighten the cable entries.
- 4. A drip loop must be provided when laying the cables.

5.2 Mounting requirements

5.2.1 Internal vessel fittings



Avoid internal fittings (point level switches, temperature sensors, struts, vacuum rings, heating coils, baffles etc.) inside the signal beam. Pay attention to the beam angle α .



5.2.2 Avoiding interference echoes

Metal deflector plates, installed at an angle to scatter the radar signals, help prevent interference echoes.

5.2.3 Vertical alignment of antenna axis

Align the antenna so that it is perpendicular to the product surface.

The maximum reach of the antenna can be reduced, or additional interference signals can occur, if the antenna is not installed perpendicular to the product.

5.2.4 Radial alignment of the antenna

Based on the directional characteristic, radial alignment of the antenna is not necessary.

5.2.5 Optimization options

Mapping

Measurement can be optimized by electronically suppressing interference echoes. See the **Confirm distance** parameter.

5.3 Mounting the device

5.3.1 Encapsulated antenna, PVDF 40 mm (1.5 in)

Information concerning threaded connections

- When screwing in, turn by the hex bolt only.
- Tool: open-ended wrench 50 mm
- Maximum permissible torque: 30 Nm (22 lbf ft)

Information about the mounting nozzle

The maximum nozzle length H_{max} depends on the nozzle diameter *D*.

Maximum nozzle length H_{max} as a function of the nozzle diameter D



In the case of longer nozzles, reduced measuring performance must be expected. Please note the following:

- The end of the nozzle must be smooth and free from burrs.
- The edge of the nozzle should be rounded.
- Mapping must be performed.
- Please contact the manufacturer's support department for applications with nozzles that are higher than indicated in the table.

5.3.2 Drip-off antenna PTFE 50 mm (2 in)

Information concerning threaded connections

- When screwing in, turn by the hex bolt only.
- Tool: open-ended wrench 55 mm
- Maximum permissible torque: 50 Nm (36 lbf ft)

Information about the mounting nozzle

The maximum nozzle length H_{max} depends on the nozzle diameter *D*.

Maximum nozzle length H_{max} as a function of the nozzle diameter D





In the case of longer nozzles, reduced measuring performance must be expected.

Please note the following:

- The end of the nozzle must be smooth and free from burrs.
- The edge of the nozzle should be rounded.
- Mapping must be performed.
- Please contact the manufacturer's support department for applications with nozzles that are higher than indicated in the table.

5.3.3 Turning the housing

The housing can be rotated up to 380° by loosening the locking screw.

Your benefits

- Easy installation due to optimum alignment of housing
- Easily accessible device operation
- Optimum readability of the local display (optional)



A Plastic single compartment housing (no locking screw)

B Aluminum single compartment housing

- C Single compartment housing, 316L, hygiene (no locking screw)
- D Dual compartment housing
- E Dual compartment housing, L-form
- 1 Locking screw

NOTICE

The housing cannot be unscrewed fully.

- Loosen the external locking screw by a maximum of 1.5 turns. If the screw is unscrewed too much or completely (beyond the screw anchor point), small parts (counter disk) can become loose and fall out.
- ► Tighten the securing screw (hexagon socket 4 mm (0.16 in)) with maximum 3.5 Nm (2.58 lbf ft) ± 0.3 Nm (0.22 lbf ft).

5.3.4 Turning the display module

WARNING

Supply voltage switched on!

Risk of electric shock and/or explosion!

► Switch off the supply voltage before opening the measuring device.



- **1.** If fitted: release the screw of the cover lock for the electronics compartment cover using the Allen key.
- 2. Unscrew the electronics compartment cover from the transmitter housing and check the cover seal.
- 3. Press the release mechanism and remove the display module.

4. Turn the display module to the desired position: maximum $4 \times 90^{\circ}$ in each direction. Fit the display module on the electronics compartment in the desired position until it clicks into place. Screw the electronics compartment cover back onto the transmitter housing. If fitted: tighten the screw of the cover lock using the Allen key 0.7 Nm (0.52 lbf ft)±0.2 Nm (0.15 lbf ft).

5.3.5 Changing the installation position of the display module

The installation position of the display can be changed in the case of the dual compartment housing, L-form.



WARNING

Supply voltage switched on!

Risk of electric shock and/or explosion!

► Switch off the supply voltage before opening the measuring device.



 If fitted: release the screw of the cover lock for the display cover using the Allen key.



 Unscrew the display cover and check the cover seal.



 Press the release mechanism, remove the display module.



 If fitted: release the screw of the cover lock for the connection compartment cover using the Allen key.



Unscrew the connection compartment cover, check the cover seal. Screw this cover onto the electronics compartment instead of the display cover. If fitted: tighten the screw of the cover lock using the Allen key

A0046924



- Plug in the connection for the display module in the connection compartment.
- Fit the display module in the desired position until it clicks into place.



 Screw the display cover firmly back onto the housing. If fitted: tighten the screw of the cover lock using the Allen key 0.7 Nm (0.52 lbf ft).

5.3.6 Closing the housing covers

NOTICE

Thread and housing damaged from dirt!

- Remove dirt (e.g. sand) on the cover and housing thread.
- If you encounter resistance when closing the cover, check the thread for dirt and clean it.

Housing thread

The threads of the electronics and connection compartment can be coated with an anti-friction coating.

The following applies for all housing materials:

Do not lubricate the housing threads.

5.4 Post-mounting check

- □ Is the device free from damage (visual inspection)?
- □ Are the measuring point identification and labeling correct (visual inspection)?

- □ Is the measuring device protected against precipitation and sunlight?
- □ Are the securing screws and cover lock tightened securely?

□ Does the measuring device comply with the measuring point specifications? For example:

- Process temperature
- D Process pressure
- 🗆 Ambient temperature
- D Measuring range

6 Electrical connection

6.1 Connecting requirements

6.1.1 Cover with securing screw

In the case of devices for use in the hazardous area with a certain type of protection, the cover is sealed by a securing screw.

NOTICE

If the securing screw is not positioned correctly, the cover cannot provide secure sealing.

- Open the cover: slacken the screw of the cover lock with a maximum of 2 turns so that the screw does not fall out. Fit the cover and check the cover seal.
- Close the cover: screw the cover securely onto the housing, making sure that the securing screw is positioned correctly. There should not be any gap between the cover and housing.



2 Cover with securing screw



☑ 3 Cover with securing screw; hygiene housing (only for dust explosion protection)

6.1.2 Potential equalization

The protective ground on the device must not be connected. If necessary, the potential matching line can be connected to the outer ground terminal of the transmitter before the device is connected.



- Α Single compartment housing, plastic
- В Single compartment housing, aluminum
- Single compartment housing, 316L hygiene (Ex device) С
- D Dual compartment housing
- Ε Dual compartment housing, L-form
- 1 Ground terminal for connecting the potential matching line

WARNING

Explosion Hazard!

► Please refer to the separate documentation on applications in hazardous areas for the safety instructions.

For optimum electromagnetic compatibility:

- Keep the potential matching line as short as possible
- Observe a cross-section of at least 2.5 mm² (14 AWG)

6.2 Connecting the device



- Α Plastic single compartment housing
- В Aluminum single compartment housing
- С Single compartment housing, 316L hygiene
- D Dual compartment housing
- Ε Dual compartment housing, L-form
- 1 Connection compartment cover

Devices with a single compartment housing, 316L hygiene, and conduit gland must be connected as end-of-line devices. Only one conduit entry must be used.

Housing thread

The threads of the electronics and connection compartment can be coated with an anti-friction coating.

The following applies for all housing materials:

🔀 Do not lubricate the housing threads.

6.2.1 Supply voltage

APL performance class A (9.6 to $15 V_{DC} 540 \text{ mW}$)



The APL field switch must be tested to ensure it meets safety requirements (e.g., PELV, SELV, Class 2) and must comply with the relevant protocol specifications.

6.2.2 Cable specification

Rated cross-section

- Supply voltage
- 0.5 to 2.5 mm² (20 to 13 AWG)
- Protective earth or grounding of the cable shield
 > 1 mm² (17 AWG)
- External ground terminal
 0.5 to 4 mm² (20 to 12 AWG)

Cable outer diameter

The cable outer diameter depends on the cable gland used

- Coupling, plastic:
- Ø5 to 10 mm (0.2 to 0.38 in)
- Coupling, nickel-plated brass:
 Ø7 to 10.5 mm (0.28 to 0.41 in)
- Coupling, stainless steel:
 Ø7 to 12 mm (0.28 to 0.47 in)

PROFINET with Ethernet-APL

The reference cable type for APL segments is fieldbus cable type A, MAU type 1 and 3 (specified in IEC 61158-2). This cable meets the requirements for intrinsically safe applications according to IEC TS 60079-47 and can also be used in non-intrinsically safe applications.

Cable type	A
Cable capacitance	45 to 200 nF/km
Loop resistance	15 to 150 Ω/km
Cable inductance	0.4 to 1 mH/km

Further details are provided in the Ethernet-APL Engineering Guideline (https://www.ethernet-apl.org).

6.2.3 Overvoltage protection

The overvoltage protection can optionally be ordered as a "Mounted accessory" via the product structure

Devices without optional overvoltage protection

The equipment fulfills the requirements of the product standard IEC / DIN EN 61326-1 (Table 2 Industrial Environment).

Depending on the type of port (DC power supply, input/output port) different testing levels according to IEC / DIN EN 61326-1 against transient overvoltages (Surge) are applied (IEC / DIN EN 61000-4-5 Surge):

Test level on DC power ports and input/output ports is $1\,000$ V line to earth

Devices with optional overvoltage protection

- Spark-over voltage: min. 400 V_{DC}
- Tested according to IEC / DIN EN 60079-14 sub chapter 12.3 (IEC / DIN EN 60060-1 chapter 7)
- Nominal discharge current: 10 kA

NOTICE

Device could be destroyed

► Always ground device with integrated overvoltage protection.

Overvoltage category

Overvoltage category II

6.2.4 Wiring

WARNING

Supply voltage might be connected!

Risk of electric shock and/or explosion!

- ► If the device is used in hazardous areas, make sure to comply with national standards and the specifications in the Safety Instructions (XAs). The specified cable gland must be used.
- The supply voltage must match the specifications on the nameplate.
- Switch off the supply voltage before connecting the device.
- ► If necessary, the potential matching line can be connected to the outer ground terminal of the device before the power supply lines are connected.
- ► A suitable circuit breaker should be provided for the device in accordance with IEC/EN 61010.
- The cables must be adequately insulated, with due consideration given to the supply voltage and the overvoltage category.
- The connecting cables must offer adequate temperature stability, with due consideration given to the ambient temperature.
- Only operate the measuring device with the covers closed.

Connect the device in the following order:

- 1. Release the cover lock (if provided).
- 2. Unscrew the cover.
- 3. Guide the cables into the cable glands or cable entries.
- 4. Connect the cables.
- 5. Tighten the cable glands or cable entries so that they are leak-tight. Counter-tighten the housing entry.
- 6. Screw the cover securely back onto the connection compartment.
- If provided: tighten the screw of the cover lock using the Allen key 0.7 Nm (0.52 lbf ft) ±0.2 Nm (0.15 lbf ft).

6.2.5 Terminal assignment

Single compartment housing



Connection terminals and ground terminal in the connection compartment

- 1 Positive terminal
- 2 Negative terminal
- 3 Internal ground terminal

Dual compartment housing



■ 5 Connection terminals and ground terminal in the connection compartment

- 1 Positive terminal
- 2 Negative terminal
- 3 Internal ground terminal

Dual compartment housing, L-form



6 Connection terminals and ground terminal in the connection compartment

- 1 Positive terminal
- 2 Negative terminal
- 3 Internal ground terminal

6.2.6 Cable entries



- A Single compartment housing, plastic
- *B* Single compartment housing, aluminum
- C Single compartment housing, 316L hygiene
- D Dual compartment housing
- E Dual compartment housing, L-form
- 1 Cable entry
- 2 Dummy plug

The type of cable entry depends on the device version ordered.

Always route connecting cables downwards so that moisture cannot penetrate the connection compartment.

If necessary, create a drip loop or use a weather protection cover.



2.7 Available device plugs

In the case of devices with a plug, it is not necessary to open the housing for connection purposes.

Use the enclosed seals to prevent the penetration of moisture into the device.

Devices with M12 plug



■ 7 View of the plug-in connection on the device

- 1 APL signal -
- 2 APL signal +
- 3 Shielding
- 4 Not assigned

Various M12 sockets are available as accessories for devices with M12 plugs.

6.3 Ensuring the degree of protection

6.3.1 Cable entries

- M20 coupling, plastic, IP66/68 NEMA TYPE 4X/6P
- M20 coupling, nickel-plated brass, IP66/68 NEMA TYPE 4X/6P
- M20 coupling, 316L, IP66/68 NEMA TYPE 4X/6P
- M20 thread, IP66/68 NEMA Type 4X/6P
- G1/2 thread, IP66/68 NEMA Type 4X/6P If the G1/2 thread is selected, the device is delivered with an M20 thread as standard and a G1/2 adapter is included with the delivery, along with the corresponding documentation
- NPT 1/2 thread, IP66/68 NEMA Type 4X/6P
- Dummy plug transport protection: IP22, NEMA TYPE 2
- M12 plug
 - When housing is closed and connecting cable is plugged in: IP66/67, NEMA Type 4X
 - When housing is open or connecting cable is not plugged in: IP20, NEMA Type 1

NOTICE

M12 plug: Loss of IP protection class due to incorrect installation!

- The degree of protection only applies if the connecting cable used is plugged in and screwed tight.
- The degree of protection only applies if the connecting cable used is specified according to IP67, NEMA Type 4X.
- ► The IP protection classes are only maintained if the dummy cap is used or the cable is connected.

6.4 Post-connection check

- □ Are the device or cables undamaged (visual inspection)?
- Do the cables used comply with the requirements?
- Do the mounted cables have strain relief?
- □ Cable glands mounted, securely tightened and leak-tight?
- Does the supply voltage correspond to the specifications on the nameplate?
- □ No reverse polarity, terminal assignment correct?
- □ Cover screwed down correctly?
- □ Cover lock tightened correctly?

7 Operation options

7.1 Overview of operation options

- Operation via operating keys and DIP switches on the electronic insert
- Operation via optical operating keys on the device display (optional)
- Operation via Bluetooth[®] wireless technology (with optional device display with
- Bluetooth) with SmartBlue app or FieldXpert, DeviceCare

 Operation via Web server
- Operation via operating tool (Endress+Hauser FieldCare/DeviceCare) or FDI Hosts (e.g., PDM)

7.2 Operating keys and DIP switches on the electronic insert



Image: B Operating keys and DIP switches on the Ethernet-APL electronic insert

- 1 Operating key for Reset password and Reset device
- 2 DIP switch for setting the service IP address
- 3 DIP switch for locking and unlocking the device

The setting of the DIP switches on the electronic insert has priority over the settings made via other operation methods (e.g. FieldCare/DeviceCare).

7.3 Structure and function of the operating menu

The differences between the structure of the operating menus of the local display and the Endress+Hauser FieldCare or DeviceCare operating tools can be summarized as follows:

The local display is suitable for configuring simple applications.

The operating tools (FieldCare, DeviceCare, SmartBlue, AMS, PDM, etc.) can be used to configure the parameters of wide-ranging applications.

More elaborate applications can be configured with the Web server.

Wizards help the user to commission the various applications. The user is guided through the individual configuration steps.

7.3.1 User roles and related access authorization

The two user roles **Operator** and **Maintenance** (as-delivered state) have different write access to the parameters if a device-specific access code has been defined. This access code protects the device configuration from unauthorized access.

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.

7.4 Access to operating menu via local display

7.4.1 Device display (optional)

Possible to operate the optical operating keys through the cover. No need to open the device.

Functions:

- Display of measured values and fault and notice messages
- Background lighting, which switches from green to red in the event of an error
- The device display can be removed for easier operation

Backlighting is switched on or off depending on the supply voltage and the current consumption.

The device display is also optionally available with Bluetooth[®] wireless technology.



- Key 🕂
 - Navigate downwards in the picklist
 - Edit the numerical values or characters within a function
- Key 🗆
 - Navigate upwards in the picklist
 - Edit the numerical values or characters within a function
- Key 🗉
 - Change from main display to main menu
 - Confirm entry
 - Jump to the next item
 - Select a menu item and activate the edit mode
 - Unlock/lock the display operation
 - Press and hold the E key to display a short description of the selected parameter (if available)
- 🗄 key and 🗆 key (ESC function)
 - Exit edit mode for a parameter without saving the changed value
 - Menu at a selection level: pressing the keys simultaneously takes the user back up a level in the menu
 - Press and hold the keys simultaneously to return to the upper level

7.4.2 Operation via Bluetooth[®] wireless technology (optional)

Prerequisite

- Device with device display including Bluetooth
- Smartphone or tablet with Endress+Hauser SmartBlue app or PC with DeviceCare from version 1.07.05 or FieldXpert SMT70

The connection has a range of up to 25 m (82 ft). The range can vary depending on environmental conditions such as attachments, walls or ceilings.

The operating keys on the display are locked as soon as the device is connected via Bluetooth.

A flashing Bluetooth symbol indicates that a Bluetooth connection is available.

SmartBlue app

1. Scan the QR code or enter "SmartBlue" in the search field of the App Store or Google Play.



2. Start the SmartBlue app.

3. Select device from livelist displayed.

4. Login:

└→ Enter the user name: admin Password: serial number of the device.

5. Change the password after logging in for the first time!

Prerequisites

System requirements

The SmartBlue app is available to download for smartphones or tablets. Please see the "App Store (Apple)" or "Google Play Store" for information regarding the compatibility of the SmartBlue app with mobile terminals.

Initial password

The serial number of the device serves as the initial password when the connection is established for the first time.

Please note the following

- If the Bluetooth display is removed from one device and installed in another device:
- All the log-in data are only saved in the Bluetooth display and not in the device
- The password changed by the user is also saved in the Bluetooth display

7.5 Access to operating menu via Web browser

7.5.1 Function scope

Thanks to the integrated Web server the device can be operated and configured via a Web browser. The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed and allows users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

7.5.2 Requirements

Computer software

Recommended operating systems

- Microsoft Windows 7 or higher.
- Mobile operating systems:
 - iOS
 - Android

Microsoft Windows XP is supported.

Web browsers supported

- Microsoft Internet Explorer 8 or higher
- Microsoft Edge
- Mozilla Firefox
- Google Chrome
- Safari

Computer settings

User rights

Corresponding user rights (e.g., administrator rights) for TCP/IP and proxy server settings are required (for changing the IP address, subnet mask etc.).

Proxy server settings of the Web browser

The Web browser *Use proxy server for LAN* setting must be **disabled**.

JavaScript

JavaScript must be enabled.

When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under **Internet options**.

7.5.3 Establishing a connection

Via PROFINET with Ethernet-APL network



10 Options for remote operation via PROFINET with Ethernet-APL network: star topology

- 1 Automation system, e.g., Simatic S7 (Siemens)
- 2 Ethernet switch
- 3 Computer with Web browser (e.g., Microsoft Edge) for accessing the integrated device Web server or computer with operating tool (e.g., FieldCare, DeviceCare, SIMATIC PDM) with iDTM Profinet Communication
- 4 APL power switch (optional)5 APL field switch
- 6 APL field switch
- o APL Jiela devic

Call up the website via the computer in the network. The IP address of the device must be known.

The IP address can be assigned to the device in a variety of ways:

Dynamic Configuration Protocol (DCP), factory setting

The automation system (e.g., Siemens S7) automatically assigns the IP address to the device

Software addressing

The IP address is entered via the IP address parameter

- DIP switch for service
 - The device then has the fixed IP address 192.168.1.212
 - **1** The IP address is only adopted following a restart.

The IP address can now be used to establish the connection to the network

The default setting is that the device uses the Dynamic Configuration Protocol (DCP). The automation system (e.g., Siemens S7) automatically assigns the IP of the device.

Starting the Web browser and logging in

1. Start the Web browser on the computer.

2. Enter the IP address of the device in the address line of the Web browser

└ The login page appears.



🖻 11 Web browser login

- 1 Device tag
- 2 Device name
- 3 Status signal
- 4 Locking status
- 5 Current measured values
- 6 Select the language
- 7 Enter the "Password" parameter
- 8 Login

1. Select the preferred **Language** parameter for the Web browser.

2. Enter the **Password** parameter (factory setting 0000).

3. Confirm entry with Login .

7.5.4 User interface



■ 12 User interface with sample contents

- 1 Header
- 2 Working area
- 3 Navigation area

Header

The following information appears in the header:

- Device tag
- Device name
- Status signal
- Locking status
- Current measured values

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate within the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configure parameters
- Read measured values
- Call up help text

Adopting a value



■ 13 Example of Enter button

1 Enter button in the operating tool

The value entered is only adopted by pressing the Enter key or clicking on the Enter button (1).

7.5.5 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"System" menu \rightarrow Connectivity \rightarrow Interfaces

Parameter overview with brief description

Parameter	Description	Selection
Web server functionality	Switch web server on and off, switch off HTML.	DisableEnable

Range of functions of "Web server functionality" parameter

Option	Description
Disable	The Web server is completely disabled.Port 80 is locked.
Enable	 The complete functionality of the Web server is available. JavaScript is used. The password is transferred in an encrypted state. Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled, it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via the "FieldCare" operating tool
- Via the "DeviceCare" operating tool
- Via the PROFINET startup record

7.5.6 Logging out

1. Select the **Logout** entry in the function bar.

- ← The home page with the Login box appears.
- 2. Close the Web browser.
- Once communication with the Web server is established via the standard IP address 192.168.1.212, the DIP switch must be reset (from **ON** \rightarrow **OFF**). Following a reboot, the configured IP address of the device is once again active for network communication.

7.6 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display. The range of functions is different however.
7.6.1 Connecting the operating tool

Via PROFINET with Ethernet-APL network



14 Options for remote operation via PROFINET with Ethernet-APL network: star topology

- 1 Automation system, e.g., Simatic S7 (Siemens)
- 2 Ethernet switch
- 3 Computer with Web browser (e.g., Microsoft Edge) for accessing the integrated device Web server or computer with operating tool (e.g., FieldCare, DeviceCare, SIMATIC PDM) with iDTM Profinet Communication
- 4 APL power switch (optional)
- 5 APL field switch6 APL field device
- o APL Jiela devic

Call up the website via the computer in the network. The IP address of the device must be known.

The IP address can be assigned to the device in a variety of ways:

Dynamic Configuration Protocol (DCP), factory setting

The automation system (e.g., Siemens S7) automatically assigns the IP address to the device

Software addressing

The IP address is entered via the IP address parameter

- DIP switch for service
 - The device then has the fixed IP address 192.168.1.212
 - **1** The IP address is only adopted following a restart.

The IP address can now be used to establish the connection to the network

The default setting is that the device uses the Dynamic Configuration Protocol (DCP). The automation system (e.g., Siemens S7) automatically assigns the IP of the device.

Service interface



- 1 Computer with FieldCare/DeviceCare operating tool
- 2 Commubox FXA291
- 3 Service interface (CDI) of the device (= Endress+Hauser Common Data Interface)

To update (flash) the device firmware, the device must be powered via the power supply terminals.

7.7 FieldCare

7.7.1 Function range

FDT-based plant asset management tool from Endress+Hauser. FieldCare can configure all smart field devices in a system and helps you manage them. By using the status information, FieldCare is also a simple but effective way of checking their status and condition.

Access is via:

- CDI service interface
- PROFINET interface

Typical functions:

- Configuration of transmitter parameters
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

7.8 DeviceCare

7.8.1 Function scope

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs), DeviceCare presents a convenient, comprehensive solution.

I

For details, see Innovation Brochure IN01047S

8 System integration

8.1 Overview of device description files

8.1.1 Current version data for the device

Firmware version	01.00.zz	 On the title page of the Operating Instructions On the transmitter nameplate System → Information → Firmware version
Firmware version parameter release date	04.2023	-
Manufacturer ID	ID: 0x11	Guidance \rightarrow Commissioning \rightarrow Device identification \rightarrow Manufacturer ID
Device ID	ID: A1C1	Guidance \rightarrow Commissioning \rightarrow Device identification \rightarrow Device ID On the transmitter nameplate
Profile 4 device ID	B321	On the transmitter nameplate
Device revision	1	On the transmitter nameplate
PROFINET version	2.4x	-
PA profile version	4.0x	Application \rightarrow PROFINET \rightarrow Information \rightarrow PA profile version

8.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via Service interface (CDI)	Sources for obtaining device descriptions
FieldCare	 www.endress.com → Downloads section CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	 www.endress.com → Downloads section CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
SMT70	Use update function of handheld terminal
AMS Device Manager (Emerson Process Management)	www.endress.com \rightarrow Downloads section
SIMATIC PDM (Siemens)	www.endress.com \rightarrow Downloads section

8.2 Device master file (GSD)

In order to integrate field devices into a bus system, the PROFINET with Ethernet-APL system needs a description of the device parameters, such as output data, input data, data format and data volume.

These data are available in the device master file (GSD) which is provided to the automation system when the communication system is commissioned. In addition device bit maps, which appear as icons in the network structure, can also be integrated.

The device master file (GSD) is in XML format, and the file is created in the GSDML description markup language.

Downloading the device master file (GSD)

- Via Web server: Menu path System \rightarrow Device drivers
- Via www.endress.com/download

8.2.1 File name of the device master file (GSD)

Example of the name of a device master file:

GSDML-V2.43-EH-Micropilot-202304dd.xml (dd corresponds to the release day)

GSDML	Description language
V2.43	Version of the PROFINET specification
ЕН	Endress+Hauser
Micropilot	Instrument family
20230422	Date of issue (year, month, day)
.xml	File name extension (XML file)

8.3 Cyclic data transmission

8.3.1 Overview of the modules

The following graphic shows which modules are available to the device for cyclic data exchange. Cyclic data exchange is performed with an automation system.

Application \rightarrow PROFINET \rightarrow Analog input \rightarrow Analog input 1 to 11 \rightarrow Assign process variable

Device Slot		Direction	Control system	
		Data flow		
Analog input Level	1	<i>→</i>		
Analog input Distance	2	<i>→</i>		
Analog input Volume	3	<i>→</i>		
Analog input Sensor temperature	20	<i>→</i>		
Analog input Electronics temperature	21	<i>→</i>		
Analog input Absolute echo amplitude	22	<i>→</i>		
Analog input Relative echo amplitude	23	<i>→</i>	DDOEINET	
Analog input Percent of range	24	<i>→</i>	FROFINET	
Analog input (Area of incoupling)	25	<i>→</i>		
Analog input Build-up index	26	<i>→</i>		
Analog input Foam index	27	<i>→</i>		
Binary input Heartbeat Technology	80	<i>→</i>		
Binary input (Build up/Foam)	81	<i>→</i>		
Binary output Heartbeat Technology	210	÷		

8.3.2 Description of the modules

The data structure is described from the perspective of the automation system:

- Input data: are sent from the device to the automation system
- Output data: are sent from the automation system to the device

Module: Analog input

Transmission of input variables from the device to the automation system:

Analog input modules cyclically transmit the selected input variables, including the status, from the device to the automation system. The input variable is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains status information pertaining to the input variable. The Analog input module Level in slot 1 is contained in the Level PA PROFILE GSD, the other Analog input modules can only be used with the manufacturer's GSD.

Module: Binary output

The Binary output module can cyclically receive discrete output values from the automation system. The device implements an 8-bit type as described in PA PROFILE 4.0x. Of this, 1 bit is used to signal to the device that Heartbeat Verification should be started.

Bit	Function	Description
0	Start verification	Start the verification
1-7	-	-

Module: Binary input

The Binary input module can cyclically send discrete values from the device to the automation system. The status of the Heartbeat Verification is transmitted for the device:

Module: Binary input Heartbeat Technology slot 80

Bit	Function	Description
0	Status parameter Not done option	Verification not carried out
1	Status parameter Failed option	The device has not passed the verification. At least one test group was outside the specifications.
2	Status parameter Busy option	Verification in progress
3	Status parameterDone option	Verification carried out
4	Verification result parameter Failed option	The device has not passed the verification. At least one test group is outside the specifications.
5	Verification result parameter Passed option	The device has passed the verification. All of the verified test groups corresponded to the specifications.
6	The verification result is also "Passed" if the result for an individual test group is "Failed" and the result for all other test groups is "Passed".	
7	Verification result parameter Not done option	Verification not carried out

Module: Binary input Sensor diagnostics slot 81

Bit	Function	Description
0	Buildup on the sensor	Buildup detected on the sensor
1	Foam generation	Foam generation detected
2-7	-	

8.3.3 Status coding

Status	Coding (hex)	Meaning
BAD - Maintenance alarm	0x24	No measured value available, as a device error has occurred.
BAD - Process related	0x28	No measured value available, as the process conditions are not within the device's technical specification limits.
BAD - Function check	0x3C	A function check is active (e.g. cleaning or calibration)
UNCERTAIN - Initial value	0x4F	A predefined value is output until a correct measured value is available again or corrective measures have been performed that change this status.
UNCERTAIN - Maintenance demanded	0x68	Wear and tear has been detected. Maintenance is needed shortly to ensure the device remains operational. The measured value might be invalid. The use of the measured value depends on the application.
UNCERTAIN - Process related	0x78	The process conditions are not within the device's technical specification limits. This could have a negative impact on the quality and accuracy of the measured value. The use of the measured value depends on the application.
GOOD - OK	0x80	No error has been diagnosed.
GOOD - Maintenance demanded	0xA8	The measured value is valid. It is highly advisable to service the device in the near future.
GOOD - Function check	0xBC	The measured value is valid. The device performs an internal function check. The function check does not have any noticeable effect on the process.

Startup configuration	The automation system adopts the configuration of the most important parameters of the device.
(NSU)	 Interfaces:
	Display operation
	Web server functionality
	Bluetooth activation
	Service (UART-CDI)
	System units:
	Level unit
	Volume unit
	Temperature unit
	Application:
	Maximum value
	 Intermediate height
	 Medium type
	 Full calibration
	Empty calibration
	 Diameter
	Diagnostic settings:
	Diagnostic behavior for diverse diagnostic information
	Analog inputs:
	Damping
1	

8.3.4 Startup configuration

8.4 System redundancy S2

A redundant layout with two automation systems is necessary for processes that are in continuous operation. If one system fails the second system guarantees continued, uninterrupted operation. The device supports S2 system redundancy and can communicate simultaneously with both automation systems.



■ 15 Example of the layout of a redundant system (S2): star topology

- 1 Automation system 1
- 2 Synchronization of automation systems
- 3 Automation system 2
- 4 Ethernet-APL Field Switch
- 5 Device



All the devices in the network must support S2 system redundancy.

9 Commissioning

All configuration tools provide a commissioning assistant that supports the user when setting the most important configuration parameters (**Guidance** menu **Commissioning** wizard).

9.1 Preliminaries

The measuring range and the unit in which the measured value is transmitted correspond to the data on the nameplate.

9.2 Function check

Before commissioning the measuring point, check whether the post-installation and postconnection checks have been performed.

 $\bullet \rightarrow \textcircled{Post-installation check}$

• $\rightarrow \blacksquare$ Post-connection check

9.3 Establishing a connection via FieldCare and DeviceCare



9.3.1 Via PROFINET protocol

16 Options for remote operation via PROFINET protocol

1 Computer with Web browser or with operating tool (e.g.,, DeviceCare)

2 Automation system

3 Field Xpert SMT70

4 Mobile handheld terminal

5 Local operation via display module

9.3.2 Via service interface (CDI)



- 1 Computer with FieldCare/DeviceCare operating tool
- 2 Commubox FXA291
- 3 Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)

9.3.3 Hardware settings

Setting the device name

A measuring point can be quickly identified within a plant on the basis of the **Device tag** parameter and **PROFINET device name** parameter. The **Device tag** parameter, which is specified ex works or defined when ordering, can be changed in the operating menu.

Configuring the "Device tag" parameter via the operating menu

The **Device tag** parameter can be adapted via the operating menu or automation system.

System \rightarrow Device management

Configuring the "PROFINET device name" parameter via the operating menu

Application \rightarrow PROFINET \rightarrow Configuration

Configuring the "PROFINET device name" parameter via the automation system

The **PROFINET device name** parameter can be adapted individually via the automation system.

i

When assigning the **PROFINET device name** parameter via the automation system: assign the device name in lower case letters.

Activating the default IP address

Activating the default IP address via the DIP switch

The device can be set to the default IP address 192.168.1.212 via DIP switches.

1. Set DIP switch 2 on the electronic insert from **OFF** \rightarrow **ON**.

2. Reconnect the device to the power supply.

└ The default IP address is used once the device is restarted.

9.3.4 Configuring the communication parameters via the software

- IP address
- Subnet mask
- Default gateway

Menu path: System \rightarrow Connectivity \rightarrow Ethernet

9.4 Configuring the operating language

9.4.1 Local display

Setting the operating language

To set the operating language, the display first needs to be unlocked:

- 1. Press the 🗉 key for at least 2 s.
- 2. Unlock the display operation.
- 3. Select the **Language** parameter in the main menu.
- 4. Press the 🗉 key.
- **5.** Select the desired language with the \pm or \Box key.
- 6. Press the 🗉 key.

Display operation locks automatically (except in the **Safety mode** wizard):

- after 1 min on the main page if no key has been pressed
- after 10 min within the operating menu if no key has been pressed

9.4.2 Operating tool

Set display language

 $System \rightarrow Display \rightarrow Language$

Selection in Language parameter; Visibility depends on order options or device settings

Device tag		Status signal I OK	Pressure 987.77 mbar	Scaled variable 49.39	mm	Endress+Hauser
Device name		Locking statu Unlocked	s Scaled variable transfer function		1	
$\widehat{\Box}$ > Application >	Measured v	values			Per	n 🐣 🔒 Maintenance
Measured values		Electronics temperature			Min/Max: -	273.15 / 9726.85
Measuring Units		32.3 °C		۵		
Sensor	>	Pressure				
PROFINET	>	987.77 mbar		A		
		Scaled variable				
		49.39 mm		۵	4	
		Sensor temperature			•	
		23.5°C		品		

9.4.3 Web server

1 Language setting

9.5 Configuring the device

9.5.1 Level measurement in bulk solids



■ 17 Configuration parameters for level measurement in bulk solids

- *R Reference point of measurement*
- A Length of antenna + 10 mm (0.4 in)
- D Distance
- L Level
- *E* "Empty calibration" parameter (= 0 %)
- F "Full calibration" parameter (= 100 %)

9.5.2 Commissioning with the Commissioning wizard

In FieldCare, DeviceCare, SmartBlue and on the display, the **Commissioning** wizard is available to guide the user through the initial commissioning steps.

Complete this wizard to commission the device.

For each parameter, enter the appropriate value or select the appropriate option.

NOTE

If you exit the wizard before completing all required parameters, the changes you have made will be saved. For this reason, the device may then be in an undefined state! In this case, a reset to the default settings is recommended.

9.6 Recording the Echo curve

Record the current Echo curve as a reference echo curve for subsequent diagnostic purposes

After the measurement has been configured, it is recommended to record the current Echo curve as a reference echo curve.

The **Save reference curve** parameter in the **Echo curve** submenu is used to record the Echo curve.

Diagnostics \rightarrow Echo curve \rightarrow Save reference curve

Under the Save reference curve parameter, activate the Customer reference curve option

9.7 "Simulation" submenu

Simulation of a process variable, a pulse output or a diagnostic event.

10 Operation

10.1 Reading off the device locking status

Displaying active write protection:

- In the Locking status parameter Menu path of local display: at the top operating level Menu path of operating tool: System → Device management
- In the operating tool in the header

10.2 Reading off measured values

Many measured values can be read off in the header of the Web server.

All the measured values can be read off using the **Measured values** submenu.

Navigation

"Application" menu \rightarrow Measured values

10.3 Adapting the device to process conditions

The following menus are available for this purpose:

- Basic settings in the **Guidance** menu
- Advanced settings in:
 - Diagnostics menu
 - Application menu
 - System menu

11 Diagnostics and troubleshooting

11.1 General troubleshooting

11.1.1 General errors

Device is not responding

- Possible cause: Supply voltage does not match the specification on the nameplate Remedial action: Apply the correct voltage
- Possible cause: The connecting cables are not in contact with the terminals Remedial action: Check the electrical contact between cables and correct if necessary

Values not visible on the display

 Possible cause: Display setting is too bright or too dark Remedy:

Use the **Contrast display** parameter to increase or reduce contrast Navigation path: System \rightarrow Display \rightarrow Contrast display

- Possible cause: The plug of the display cable is not connected correctly Remedial action: Connect the plug correctly
- Possible cause: Display is defective Remedial action: Replace the display

"Communication error" is indicated on the display when the device is started or the display is connected

- Possible cause: Electromagnetic interference influence Remedial action: Check grounding of the device
- Possible cause: Defective cable connection or display plug Remedial action: Replace the display

Communication via CDI interface not working

Possible cause: Wrong setting of the COM port on the computer Remedial action: Check the setting of the COM port on the computer and correct it if necessary

Device measuring incorrectly

Possible cause: Parameter configuration error Remedial action: Check and correct the parameter configuration

11.2 Error - SmartBlue operation

Operation via SmartBlue is only possible on devices that have a display with Bluetooth (optionally available).

Device is not visible in the live list

- Possible cause: No Bluetooth connection available Remedial action: Enable Bluetooth in the field device via display or software tool and/or in the smartphone/tablet
- Possible cause: Bluetooth signal outside range Remedial action: Reduce distance between field device and smartphone/tablet The connection has a range of up to 25 m (82 ft).
 Operating radius with intervisibility 10 m (33 ft)
- Possible cause: Geopositioning is not enabled on Android devices or is not permitted for the SmartBlue app

Remedial action: Enable/permit the geopositioning service on Android device for the SmartBlue app

Display does not have Bluetooth

Device appears in the live list but a connection cannot be established

- Possible cause: The device is already connected with another smartphone/tablet via Bluetooth
- Only one point-to-point connection is permitted Remedial action: Disconnect the smartphone/tablet from the device
- Possible cause: Incorrect user name and password Remedial action: The standard user name is "admin" and the password is the device serial number indicated on the device nameplate (only if the password was not changed by the user beforehand)

If the password has been forgotten, contact Endress+Hauser Service (www.addresses.endress.com)

Connection via SmartBlue not possible

- Possible cause: Incorrect password entered
 Pomodial action: Enter the correct password
- Remedial action: Enter the correct password, paying attention to lower/upper case
 Possible cause: Forgotten password
 Remedial action: Contact Endress+Hauser Service (www.addresses.endress.com)

Login via SmartBlue not possible

- Possible cause: Device is being put into operation for the first time Remedial action: Enter the user name "admin" and the password (device serial number), paying attention to lower/upper case
- Possible cause: The electric current and voltage are not correct. Remedial action: Increase the supply voltage.

Device cannot be operated via SmartBlue

- Possible cause: Incorrect password entered
- Remedial action: Enter the correct password, paying attention to lower/upper case • Possible cause: Forgotten password
- Remedial action: Contact Endress+Hauser Service (www.addresses.endress.com)

 Possible cause: Operator option has no authorization
- Remedial action: Change to **Maintenance** option

11.3 Diagnostic message

Faults detected by the self-monitoring system of the device are displayed as a diagnostic message in alternation with the measured value.



I8 Diagnostic message displayed in alternating sequence with the measured value

If two or more diagnostic events occur simultaneously, only the diagnostic message with the highest priority is shown.



11.3.1 Diagnostic information on local display

If Segment display without keys

- 1 Status symbol for event level
- 2 Status signal with diagnostic event



🖻 20 Graphic display with keys

- 1 Status signal
- 2 Status symbol with diagnostic event and preceding symbol for event level
- 3 Event text

11.3.2 Diagnostic information in the operating tool

If a diagnostic event has occurred in the device, the status signal appears in the top left status area of the operating tool together with the corresponding symbol for the event level according to NAMUR NE 107.

Click the status signal to see the detailed status signal.

Pending diagnostic messages can also be displayed in the Active diagnostics parameter.

The diagnostic events and remedial measures can be printed out in the **Diagnostic list** submenu.

11.3.3 Status signal

F

```
Failure (F)
```

A device error has occurred. The measured value is no longer valid.

С

```
Function check (C)
```

The device is in the service mode (e.g. during a simulation).

S

Out of specification (S)

- Device operation:
- Outside of the technical specifications (e.g. during startup or a cleaning)
- Outside of the configuration performed by the user (e.g. sensor frequency outside the configured span)

М

Maintenance required (M) Maintenance required. The measured value is still valid.

11.3.4 Diagnostic event and event text

The fault can be identified by means of the diagnostic event. The event text helps you by providing information about the fault. In addition, the associated status symbol is displayed in front of the diagnostic event.



- 1 Diagnostic message
- 2 Symbol for event level
- 3 Status signal
- 4 Short text
- 5 Symbol for event level, status signal, diagnostic number
- 6 Remedial measure
- 7 Service ID
- 8 Operating time of occurrence

Symbol for event level

❸ "Alarm" status

Measurement is interrupted. The signal outputs adopt the defined alarm state. A diagnostic message is generated.

\triangle "Warning" status

The device continues to measure. A diagnostic message is generated.

11.4 Remedy informationCalling up

11.4.1 Graphic display with keys



• Open the **Diagnostic list** submenu

A0051132

Diagnostic list A S Diagnostics 1 A S801 Supply voltage Diagnostics 2 Diagnostics 3	2 >	
A S801 Supply voltage Diagnostics 2 Diagnostics 3		Diagnostic list <u>A</u> S
		▲ S801 Supply voltage Diagnostics 2 Diagnostics 3

► Select the diagnostic event and confirm

3	
	Supply voltage (ID:203)
	▲ S801 0d00h02m25s
	Increase supply voltage
	\ominus + \oplus
	A0051133

Remedy informationClosing

11.4.2 Operating menu

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

Diagnostics \rightarrow Diagnostic list

Queued diagnostic messages are also displayed in the Active diagnostics parameter.

Navigation: Diagnostics \rightarrow Active diagnostics

11.5 Adapting the diagnostic information

The event level can be configured:

Navigation: Diagnostics \rightarrow Diagnostic settings \rightarrow Configuration

11.6 List of diagnostic events

If Remedy information **Contact the Service Department** is displayed (www.addresses.endress.com), be ready with the **service ID** shown.

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of sensor				
062	Sensor connection faulty	Check sensor connection	F	Alarm
151	Sensor electronic failure	 Restart device Contact service 	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
168	Build-up detected	Check process conditions	М	Warning ¹⁾
Diagnostic of el	ectronic			
232	Real time clock defective	Replace main electronics	М	Warning
242	Firmware incompatible	 Check software Flash or change main electronic module 	F	Alarm
252	Module incompatible	 Check if correct electronic module is plugged Replace electronic module 	F	Alarm
270	Main electronics defective	Replace main electronics	F	Alarm
272	Main electronics faulty	 Restart device Contact service 	F	Alarm
273	Main electronics defective	Replace main electronics	F	Alarm
282	Data storage inconsistent	Restart device	F	Alarm
283	Memory content inconsistent	 Restart device Contact service 	F	Alarm
287	Memory content inconsistent	 Restart device Contact service 	М	Warning
331	Firmware update failed	 Update firmware of device Restart device 	М	Warning
388	Electronics and HistoROM defective	 Restart device Replace electronics and HistoROM Contact service 	F	Alarm
Diagnostic of co	onfiguration			
410	Data transfer failed	 Retry data transfer Check connection 	F	Alarm
412	Processing download	Download active, please wait	С	Warning
435	Linearization faulty	Check linearization table	F	Alarm
436	Date/time incorrect	Check date and time settings.	М	Warning ¹⁾
437	Configuration incompatible	 Update firmware Execute factory reset 	F	Alarm
438	Dataset different	 Check dataset file Check device parameterization Download new device parameterization 	М	Warning
484	Failure mode simulation active	Deactivate simulation	С	Alarm
485	Process variable simulation active	Deactivate simulation	С	Warning
495	Diagnostic event simulation active	Deactivate simulation	S	Warning
538	Configuration Sensor Unit invalid	 Check sensor configuration Check device configuration 	F	Alarm
585	Simulation distance	Deactivate simulation	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
586	Record map	Recording of mapping please wait	С	Warning
Diagnostic of process				
801	Supply voltage too low	Increase supply voltage	S	Warning
802	Supply voltage too high	Decrease supply voltage	S	Warning
825	Electronics temperature	 Check ambient temperature Check process temperature 	S	Warning
826	Sensor temperature out of range	 Check ambient temperature Check process temperature 	S	Warning
941	Echo lost	Check parameter 'DC value'	S	Warning ¹⁾
942	In safety distance	 Check level Check safety distance Reset self holding 	S	Warning ¹⁾
952	Foam detected	Check process conditions	S	Warning ¹⁾
968	Level limited	 Check level Check limit parameters 	S	Warning

1) Diagnostic behavior can be changed.

11.7 Event logbook

11.7.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event logbook** submenu. This submenu only exists if operating via the local display with keys. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Navigation:

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

The event history includes entries for:

- Diagnostic events
- Information events

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostic event
 - $\overline{\mathfrak{O}}$: Occurrence of the event
 - \bigcirc : End of the event
- Information event

 \odot : Occurrence of the event

Calling up and closing the remedial measures

1. Press E.

└ The message for the remedial measures for the selected diagnostic event opens.

- 2. Press \Box + \pm simultaneously.
 - └ The message about the remedial measures closes.

11.7.2 Filtering the event logbook

Filters can be used to determine which category of event messages is displayed in the **Event list** submenu.

Navigation: Diagnostics \rightarrow Event logbook

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

11.7.3 Overview of information events

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I11036	Date/time set successfully
I11074	Device verification active
I1110	Write protection switch changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronics temperature
I1157	Memory error event list
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1440	Main electronic module changed
I1444	Device verification passed
I1445	Device verification failed
I1461	Sensor verification failed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1551	Assignment error fixed
I1552	Failed: Main electronic verification
I1554	Safety sequence started
I1555	Safety sequence confirmed
I1556	Safety mode off
I1663	Power off

Info number	Info name
I1666	Clock synchronized
I1712	New flash file received
I1956	Reset

11.8 Resetting the device

11.8.1 Reset password via operating tool

Enter a code to reset the current 'Maintenance' password. The code is deliverd by your local support.

Navigation: System \rightarrow User management \rightarrow Reset password \rightarrow Reset password

Solution For detailed information on the **Reset password** parameter: Description of device parameters.

11.8.2 Reset device via operating tool

Reset the device configuration - either entirely or in part - to a defined state

Navigation: System \rightarrow Device management \rightarrow Reset device

Solution For detailed information on the **Reset device** parameter: Description of device parameters.

11.8.3 Resetting the device via keys on the electronic insert

Resetting the password



■ 21 Sequence for resetting the password

Delete/reset the password

1. Press operating key I three times.

└ The reset password function is started, the LED flashes.

2. Press operating key I once within 15 s.

└ The password is reset, the LED flashes briefly.

If operating key ${\bf I}$ is not pressed within 15 s, the action is canceled and the LED is no longer lit.

Resetting the device to the factory setting



🖻 22 Sequence - Factory setting

Reset the device to the factory setting

- ▶ Press operating key I for at least 12 s.
 - └ Device data are reset to the factory setting, the LED flashes briefly.

11.9 Device information

All device information is contained in the **Information** submenu.

Navigation: System \rightarrow Information

For detailed information on the **Information** submenu: Description of device parameters.

11.10 Firmware history

The firmware version can explicitly be ordered via the product structure. This makes it possible to ensure the compatibility of the firmware version with an existing or planned system integration.

Version

01.00.00

- Initial software
- Valid from: 01.05.2023

12 Maintenance

No special maintenance work is required.

12.1 Exterior cleaning

Notes on cleaning

- The cleaning agents used should not corrode the surfaces and the seals
- Observe the degree of protection of the device

12.2 Seals

The process seals, located on the process connection of the device, should be replaced periodically. The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

13 Repair

13.1 General information

13.1.1 Repair concept

Endress+Hauser repair concept

- The devices have a modular design
- Repairs can be carried out by Endress+Hauser Service or by appropriately trained customers
- Spare parts are grouped into logical kits with the associated replacement instructions

For more information on service and spare parts, please contact your Endress+Hauser sales representative.

13.1.2 Repair of Ex-certified devices

WARNING

Incorrect repair can compromise electrical safety!

Risk of explosion!

- ► Only specialist personnel or the Endress+Hauser service team may carry out repairs on Ex-certified devices in accordance with national regulations.
- Relevant standards and national regulations on hazardous areas, safety instructions and certificates must be observed.
- ▶ Use only original Endress+Hauser spare parts.
- Please note the device designation on the nameplate. Only identical parts may be used as replacements.
- Carry out repairs according to the instructions.
- Only the Endress+Hauser service team is permitted to modify a certified device and convert it to another certified version.

13.2 Spare parts

- Some replaceable device components are identified by a spare part nameplate. This contains information about the spare part.
- All the spare parts for the measuring device, along with the order code, are listed in the *Device Viewer* (www.endress.com/deviceviewer) and can be ordered. If available, users can also download the associated Installation Instructions.

Device serial number or QR code:

Located on the device and spare part nameplate.

13.3 Replacement

ACAUTION

Data upload/download is not permitted if the device is used for safety-related applications.

After an entire device or an electronics module has been replaced, the parameters can be downloaded to the device again via the communication interface. For this, the data must have been uploaded to the PC beforehand using the "FieldCare/DeviceCare" software.

13.3.1 HistoROM

It is not necessary to perform a new device calibration after replacing the display or transmitter electronics.

The spare part is supplied without HistoROM.

After removing the transmitter electronics, remove HistoRom and insert it into the new spare part.

13.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the web page for information: http://www.endress.com/support/return-material

- └ Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

13.5 Disposal

X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14 Accessories

14.1 Weather protection cover 316L

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.

It is used to protect against direct sunlight, precipitation and ice.

Weather protection cover 316L is suitable for the dual compartment housing made of aluminum or 316L. The delivery includes the holder for direct mounting on the housing.



☑ 23 Dimensions. Unit of measurement mm (in)

Material

- Weather protection cover: 316L
- Clamping screw: A4
- Holder: 316L

Order number for accessories:

71438303

14.2 Plastic weather protection cover

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.

It is used to protect against direct sunlight, precipitation and ice.

The plastic weather protection cover is suitable for the single compartment housing made of aluminum. The delivery includes the holder for direct mounting on the housing.



24 Dimensions. Unit of measurement mm (in)

Material

Plastic

Order number for accessories: 71438291

14.3 Adjustable flange seal

The adjustable flange seal is used to align the sensor to the surface of the product. It can be ordered directly with the device via the product structure "Accessory enclosed" or individually via the specific order number.

14.3.1 Seal, adjustable, DN80

The seal, adjustable, DN80 is compatible with flanges EN DN80 PN10/PN40



Technical data

- Material: EPDM
- Recommended screw size: M14
- Recommended screw length: 100 mm (3.9 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71074263

14.3.2 Seal, adjustable, DN100

The seal, adjustable, DN100 is compatible with flanges EN DN100 PN10/PN16



- Material: EPDM
- Recommended screw size: M14
- Recommended screw length: 100 mm (3.9 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71074264

14.3.3 Seal, adjustable, DN150

The seal, adjustable, DN150 is compatible with flanges EN DN150 PN10/PN19



Technical data

- Material: EPDM
- Recommended screw size: M18
- Recommended screw length: 110 mm (4.3 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71074265

14.3.4 Seal, adjustable, ASME 3"/ JIS 80A

The seal, adjustable, ASME 3"/ JIS 80A is compatible with flanges ASME 3" 150 lbs and JIS 80A 10K



- Material: EPDM
- Recommended screw size: M14
- Recommended screw length: 100 mm (3.9 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71249070

14.3.5 Seal, adjustable, ASME 4"

The seal, adjustable, ASME 4" is compatible with flanges ASME 4" 150 lbs



Technical data

- Material: EPDM
- Recommended screw size: M14
- Recommended screw length: 100 mm (3.9 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71249072

14.3.6 Seal, adjustable, ASME 6"/ JIS 150A

The seal, adjustable, ASME 6"/ JIS 150A is compatible with flanges ASME 6" 150 lbs and JIS 150A 10K



- Material: EPDM
- Recommended screw size: M18
- Recommended screw length: 100 mm (3.9 in)
- Process pressure: -0.1 to 0.1 bar (-1.45 to 1.45 psi)
- Process temperature: -40 to +80 °C (-40 to +176 °F)

Ordering information

- The flange seal can be ordered together with the device via the "Accessory enclosed" product structure.
- Order number: 71249073

14.4 Mounting bracket, adjustable

The device can be mounted on a wall or ceiling with the mounting bracket.

The device can be aligned with the product surface with the swivel function.

The mounting bracket can be ordered together with the device via the product structure "Accessory enclosed".

Suitable for device with single compartment housing or dual compartment aluminum housing, L-form, in combination with encapsulated antenna, PVDF, 40 mm (1.5 in) or drip-off antenna 50 mm (2 in) with threaded process connection.



■ 25 Ceiling or wall mounting

There is **no** conductive connection between the mounting bracket and the transmitter housing. The bracket should be included in local potential equalization to prevent any electrostatic charge.

Fasten only to stable materials (e.g. metal, brick, concrete) with suitable fastening fixtures (provided by the customer).

Order number for accessories:

71597288



14.4.1 Dimensions

☑ 26 Dimensions of mounting bracket. Unit of measurement mm (in)

14.4.2 Scope of delivery



☑ 27 Scope of delivery of mounting bracket, adjustable

- 1 × mounting bracket, 316L (1.4404)
- 2 × holder, 316L (1.4404)
- 6 × screws, A4
- 4 × lock washer, A4

14.5 M12 socket



🖻 28 M12 socket, straight

M12 socket, straight

- Material:
- Body: PBT; union nut: nickel-plated die-cast zinc; seal: NBR
- Degree of protection (fully locked): IP67
- Pg coupling: Pg7
- Order number: 52006263



🖻 29 M12 socket, angled

M12 socket, angled

- Material:
- Body: PBT; union nut: nickel-plated die-cast zinc; seal: NBR
- Degree of protection (fully locked): IP67
- Pg coupling: Pg7
- Order number: 71114212



■ 30 M12 socket, angled, cable

M12 socket, angled, 5 m (16 ft) cable

- M12 socket material:
 - Body: TPU
 - Union nut: nickel-plated die-cast zinc
- Cable material:
 - PVC
- Cable Li Y YM 4×0.34 mm² (20 AWG)
- Cable colors
 - 1 = BN = brown
 - 2 = WH = white
 - 3 = BU = blue
 - 4 = BK = black
- Order number: 52010285

14.6 Remote display FHX50B

The remote display is ordered via the Product Configurator.

If the remote display is to be used, the device version **Prepared for display FHX50B** must be ordered.



- A Plastic single compartment housing, remote display
- *B* Aluminum single compartment housing, remote display
- *C* Single compartment housing, 316L hygiene, remote display
- D Device side, plastic single compartment housing prepared for display FHX50B
- *E* Device side, aluminum single compartment housing prepared for display FHX50B
- F Device side, dual compartment housing, L-form, prepared for display FHX50B
- G Device side, single compartment housing, 316L hygiene, prepared for display FHX50B

Material of single compartment housing, remote display

- Aluminum
- Plastic

Degree of protection:

- IP68 / NEMA 6P
- IP66 / NEMA 4x

Connecting cable:

- Connecting cable (option) up to 30 m (98 ft)
- Customer-supplied standard cable up to 60 m (197 ft)
 - Recommendation: EtherLine[®]-P CAT.5e from LAPP.

Specification of customer-supplied connecting cable

Push-in CAGE CLAMP[®], connection technology, push actuation

- Conductor cross-section:
 - Solid conductor 0.2 to 0.75 mm² (24 to 18 AWG)
 - Fine-stranded conductor 0.2 to 0.75 mm² (24 to 18 AWG)
 - Fine-stranded conductor; with insulated ferrule 0.25 to 0.34 mm²
 - Fine-stranded conductor; without insulated ferrule 0.25 to 0.34 mm²
- Stripping length 7 to 9 mm (0.28 to 0.35 in)
- Outer diameter: 6 to 10 mm (0.24 to 0.4 in)
- Maximum cable length: 60 m (197 ft)

Ambient temperature:

- -40 to +80 °C (-40 to +176 °F)
- Option: -50 to +80 °C (-58 to +176 °F)

14.7 Gas-tight feedthrough

Chemically inert glass feedthrough, which prevents gases from entering the electronics housing.

Can optionally be ordered as "Accessory mounted" via the product structure.

14.8 Field Xpert SMT70

Universal, high-performance tablet PC for device configuration in Ex Zone 2 and non-Ex areas

For details, see "Technical Information" TI01342S

14.9 DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices

Technical Information TI01134S

14.10 FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Technical Information TI00028S

15.1 Input

Measured variable	The measured variable is the distance between the reference point and the product surface. The level is calculated based on "E", the empty distance entered.
Measuring range	The start of the measuring range is the point where the beam hits the floor. Levels below this point cannot be measured, particularly in the case of conical outlets. An alignment unit can be used to increase the maximum measuring range in such applications.

Maximum measuring range

The maximum measuring range depends on the antenna size and design.

Antenna	Maximum measuring range	
Encapsulated, PVDF, 40 mm (1.5 in)	30 m (98 ft)	
Drip-off, PTFE, 50 mm (2 in)	50 m (164 ft)	

Usable measuring range

The usable measuring range depends on the antenna size, the medium's reflective properties, the installation position and any possible interference reflections.

In principle, measurement is possible up to the tip of the antenna.

Depending on the position of the product (angle of repose) and to avoid any material damage from abrasive media and deposit buildup on the antenna, the end of the measuring range should be selected 10 mm (0.4 in) before the tip of the antenna.



- A Length of antenna + 10 mm (0.4 in)
- B Usable measuring range
- H Silo height
- *R Reference point of measurement, varies depending on the antenna system*
| | 📵 For further information | on the reference point, see $\rightarrow \cong$ Mechanical construction. | | |
|--------------------------------|---|--|--|--|
| | For the dielectric cons
please refer to:
• Dielectric constant (
• The Endress+Hause | tants (DC values) of many media commonly used in industry,
DC value) Compendium CP01076F
r "DC Values app" (available for Android and iOS) | | |
| Operating frequency | Approx. 80 GHz | | | |
| | Up to 8 devices can be insta
another. | alled in a tank without the devices mutually influencing one | | |
| Transmission power | Peak power: 6.3 mWAverage output power: 6 | 3 μW | | |
| | 15.2 Output | | | |
| PROFINET-APL | PROFINET with Ethernet -10BASE-T1L, 2-wire 10 M | -APL
/bit/s | | |
| Signal on alarm | Local display
Status signal (in accordance with NAMUR Recommendation NE 107):
Plain text display | | | |
| | Operating tool via service interface (CDI)
Status signal (in accordance with NAMUR Recommendation NE 107):
Plain text display | | | |
| | Operating tool via PROFINET with Ethernet-APL According to "Application layer protocol for decentralized periphery", Version 2.4 Diagnostics according to PROFINET PA Profile 4.02 | | | |
| Linearization | The linearization function of the device allows the conversion of the measured value into any unit of length, weight, flow or volume. | | | |
| | Pre-programmed linearization curves Linearization tables for calculating the volume in the following vessels are preprogrammed into the device: Pyramid bottom Conical bottom Angled bottom Horizontal cylinder Sphere Other linearization tables of up to 32 value pairs can be entered manually. | | | |
| PROFINET with Ethernet-
APL | Protocol | Application layer protocol for decentral device periphery and distributed automation, Version 2.4 | | |

Communication type	Ethernet Advanced Physical Layer 10BASE-T1L
Conformance Class	Conformance Class B
Netload Class	Netload Class II
Baud rates	Automatic 10 Mbit/s with full-duplex detection
Cycle times	From 32 ms
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs

Media Redundancy Protocol (MRP)	Yes
System redundancy support	System redundancy S2 (2 AR with 1 NAP)
Device profile	Application interface identifier 0xB321 Generic device
Manufacturer ID	0x11
Device type ID	0xA1C1
Device description files (GSD, FDI, DTM, DD)	Information and files available at: • www.endress.com On the product page for the device: Documents/Software → Device drivers • www.profibus.org
Supported connections	 2 x AR (IO Controller AR) 1 x AR (IO-Supervisor Device AR connection allowed) 1 x Input CR (Communication Relation) 1 x Output CR (Communication Relation) 1 x Alarm CR (Communication Relation)
Configuration options for device	 Manufacturer-specific software (FieldCare, DeviceCare) Web browser Device master file (GSD), can be read out via the integrated Web server of the device DIP switch for setting the service IP address
Configuration of the device name	DCP protocolProcess Device Manager (PDM)Integrated Web server
Supported functions	 Identification & maintenance Simple device identification via: Control system Nameplate Measured value status The process variables are communicated with a measured value status Blinking feature via the local display for simple device identification and assignment Device operation via operating tools (e.g., FieldCare, DeviceCare, SIMATIC PDM)
System integration	For information on system integration, see 🔳 Operating Instructions
	 Cyclic data transmission Overview and description of the modules Status coding Startup configuration Factory setting

15.3 Environment

Ambient temperature range
The following values apply up to a process temperature of +85 °C (+185 °F). At higher process temperatures, the permitted ambient temperature is reduced.
Without LCD display: Standard: -40 to +85 °C (-40 to +185 °F)
With LCD display: -40 to +85 °C (-40 to +185 °F) with limitations in optical properties such as display speed and contrast for example. Can be used without limitations up to -20 to +60 °C (-4 to +140 °F)
If operating outdoors in strong sunlight:
Mount the device in the shade.
Avoid direct sunlight, particularly in warm climatic regions.
Use a weather protection cover (see accessories).

Ambient temperature limitsThe permitted ambient temperature (T_a) depends on the selected housing material
(Product Configurator \rightarrow Housing; Material \rightarrow) and the selected process temperature range
(Product Configurator \rightarrow Application \rightarrow).

In the event of temperature (T_p) at the process connection, the permitted ambient temperature (T_a) is reduced.

The following information only takes functional aspects into consideration. Additional restrictions may apply for certified device versions.

Plastic housing

Plastic housing; process temperature -40 to +80 °C (-40 to +176 °F)



A0032024

A0048826

Image: Barbar Straight StraightStraight Straight Straight Straight Straight Straight Stra

 $\begin{array}{rcl} P1 &=& T_{p}: \ -40 \ ^{\circ}C \ (-40 \ ^{\circ}F) &\mid & T_{a}: \ +76 \ ^{\circ}C \ (+169 \ ^{\circ}F) \\ P2 &=& T_{p}: \ +76 \ ^{\circ}C \ (+169 \ ^{\circ}F) &\mid & T_{a}: \ +76 \ ^{\circ}C \ (+169 \ ^{\circ}F) \\ P3 &=& T_{p}: \ +80 \ ^{\circ}C \ (+176 \ ^{\circ}F) &\mid & T_{a}: \ +75 \ ^{\circ}C \ (+167 \ ^{\circ}F) \\ P4 &=& T_{p}: \ +80 \ ^{\circ}C \ (+176 \ ^{\circ}F) &\mid & T_{a}: \ -40 \ ^{\circ}C \ (-40 \ ^{\circ}F) \\ P5 &=& T_{p}: \ -40 \ ^{\circ}C \ (-40 \ ^{\circ}F) \end{array}$



In the case of devices with a plastic housing and CSA C/US approval, the selected process temperature of

-40 to +80 °C (-40 to +176 °F) is limited to 0 to +80 °C (+32 to +176 °F).

Restriction to a process temperature of 0 to +80 $^\circ C$ (+32 to +176 $^\circ F) with CSA C/US approval and plastic housing$



☑ 32 Plastic housing; process temperature 0 to +80 °C (+32 to +176 °F) with CSA C/US approval

- $P5 = T_p: 0 \ ^{\circ}C \ (+32 \ ^{\circ}F) \ | \ T_a: 0 \ ^{\circ}C \ (+32 \ ^{\circ}F)$

Plastic housing; process temperature -40 to +130 °C (-40 to +266 °F)



■ 33 Plastic housing; process temperature -40 to +130 °C (-40 to +266 °F)

In the case of devices with a plastic housing and CSA C/US approval, the selected process temperature of −40 to +130 °C (−40 to +266 °F) is limited to 0 to +130 °C (+32 to +266 °F).

Restriction to a process temperature of 0 to +130 $^\circ C$ (+32 to +266 $^\circ F) with CSA C/US approval and plastic housing$



■ 34 Plastic housing; process temperature 0 to +130 °C (+32 to +266 °F) with CSA C/US approval

 $\begin{array}{rcl} P1 & = & T_p: \ 0 \ ^{\circ} C \ (+32 \ ^{\circ} F) & | & T_a: \ +76 \ ^{\circ} C \ (+169 \ ^{\circ} F) \\ P2 & = & T_p: \ +76 \ ^{\circ} C \ (+169 \ ^{\circ} F) & | & T_a: \ +76 \ ^{\circ} C \ (+169 \ ^{\circ} F) \\ P3 & = & T_p: \ +130 \ ^{\circ} C \ (+266 \ ^{\circ} F) & | & T_a: \ +41 \ ^{\circ} C \ (+106 \ ^{\circ} F) \\ P4 & = & T_p: \ +130 \ ^{\circ} C \ (+266 \ ^{\circ} F) & | & T_a: \ 0 \ ^{\circ} C \ (+32 \ ^{\circ} F) \\ P5 & = & T_p: \ 0 \ ^{\circ} C \ (+32 \ ^{\circ} F) \\ P5 & = & T_p: \ 0 \ ^{\circ} C \ (+32 \ ^{\circ} F) \end{array}$

Aluminum housing, coated

Aluminum housing; process temperature -40 to +80 °C (-40 to +176 °F)



A0032024

A0048826

A0032024

■ 35 Aluminum housing, coated; process temperature -40 to +80 °C (-40 to +176 °F)

Aluminum housing; process temperature -40 to +130 $^{\circ}$ C (-40 to +266 $^{\circ}$ F)



A0032024

A0032024

A0032024

■ 36 Aluminum housing, coated; process temperature -40 to +130 °C (-40 to +266 °F)

P1 = T_p : -40 °C (-40 °F) | T_a : +79 °C (+174 °F) $P2 = T_p: +79 \ ^{\circ}C \ (+174 \ ^{\circ}F) \ | \ T_a: +79 \ ^{\circ}C \ (+174 \ ^{\circ}F)$ $P3 = T_p: +130 \ ^{\circ}C \ (+266 \ ^{\circ}F) \ | \ T_a: +55 \ ^{\circ}C \ (+131 \ ^{\circ}F)$ $P4 = T_p: +130 \ ^{\circ}C (+266 \ ^{\circ}F) | T_a: -40 \ ^{\circ}C (-40 \ ^{\circ}F)$ $P5 = T_p: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F) | T_a: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F)$

316L housing

316L housing; process temperature -40 to +80 °C (-40 to +176 °F)



Image: Bar and Bar

P1 = T_p : -40 °C (-40 °F) | T_a : +77 °C (+171 °F) $P2 = T_p: +77 \ ^{\circ}C \ (+171 \ ^{\circ}F) \ | \ T_a: +77 \ ^{\circ}C \ (+171 \ ^{\circ}F)$ $P3 = T_p: +80 \ ^{\circ}C \ (+176 \ ^{\circ}F) \ | \ T_a: +77 \ ^{\circ}C \ (+171 \ ^{\circ}F)$ $P4 = T_p: +80 \ ^{\circ}C \ (+176 \ ^{\circ}F) \ | \ T_a: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F)$ $P5 = T_p: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F) \ | T_a: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F)$

316L housing; process temperature -40 to +130 °C (-40 to +266 °F)



P1 = T_p : -40 °C (-40 °F) | T_a : +77 °C (+171 °F) $P2 = T_p: +77 \ ^{\circ}C \ (+171 \ ^{\circ}F) \ | \ T_a: +77 \ ^{\circ}C \ (+171 \ ^{\circ}F)$ $P3 = T_p: +130 \ ^{\circ}C \ (+266 \ ^{\circ}F) \ | \ T_a: +54 \ ^{\circ}C \ (+129 \ ^{\circ}F)$ $P4 = T_p: +130 \ ^{\circ}C \ (+266 \ ^{\circ}F) \mid T_a: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F)$

A0032024

316L housing, hygiene

316L housing, hygiene; process temperature -40 to +80 °C (-40 to +176 °F)



 \blacksquare 39 316L housing, hygiene; process temperature -40 to +80 °C (-40 to +176 °F)

P1	= T_p : -40 °C (-40 °F) T_a : +76 °C (+169 °F)
P2	$= T_p: +76 \ ^{\circ}C \ (+169 \ ^{\circ}F) \ T_a: +76 \ ^{\circ}C \ (+169 \ ^{\circ}F)$
Р3	= T_p : +80 °C (+176 °F) T_a : +75 °C (+167 °F)
P4	$= T_p: +80 \degree C (+176 \degree F) T_a: -40 \degree C (-40 \degree F)$
Р5	= T_p : -40 °C (-40 °F) T_a : -40 °C (-40 °F)

316L housing, hygiene; process temperature -40 to +130 °C (-40 to +266 °F)



A0032024 $P1 = T_p: -40 \ ^{\circ}C (-40 \ ^{\circ}F) | T_a: +76 \ ^{\circ}C (+169 \ ^{\circ}F)$ $P2 = T_p: +76 \ ^{\circ}C \ (+169 \ ^{\circ}F) | T_a: +76 \ ^{\circ}C \ (+169 \ ^{\circ}F)$ $P3 = T_p: +130 \ ^{\circ}C \ (+266 \ ^{\circ}F) \ | \ T_a: +55 \ ^{\circ}C \ (+131 \ ^{\circ}F)$ $P4 = T_p: +130 \ ^{\circ}C \ (+266 \ ^{\circ}F) | T_a: -40 \ ^{\circ}C \ (-40 \ ^{\circ}F)$ $P5 = T_p: -40 \ ^{\circ}C (-40 \ ^{\circ}F) | T_a: -40 \ ^{\circ}C (-40 \ ^{\circ}F)$ ■ Without LCD display: -40 to +90 °C (-40 to +194 °F) Storage temperature ■ With LCD display: -40 to +85 °C (-40 to +185 °F) Climate class DIN EN 60068-2-38 (test Z/AD) Installation height as per Generally up to 5000 m (16404 ft) above sea level IEC61010-1 Ed.3 Degree of protection Test as per IEC 60529 and NEMA 250-2014 Housing IP66/68, NEMA TYPE 4X/6P IP68 test condition: 1.83 m under water for 24 hours. **Cable entries** Gland M20, plastic, IP66/68 NEMA TYPE 4X/6P

- Gland M20, nickel-plated brass, IP66/68 NEMA TYPE 4X/6P
- Gland M20, 316L, IP66/68 NEMA TYPE 4X/6P

	 Gland M20, hygiene, IP66/68/69 NEMA Type 4X/6P Thread M20, IP66/68 NEMA TYPE 4X/6P Thread G1/2, IP66/68 NEMA TYPE 4X/6P If the G1/2 thread is selected, the device is delivered with an M20 thread as standard and a G1/2 adapter is included with the delivery, along with the corresponding documentation Thread NPT1/2, IP66/68 NEMA TYPE 4X/6P M12 plug When housing is closed and connecting cable is plugged in: IP66/67 NEMA TYPE 4X When housing is open or connecting cable is not plugged in: IP20, NEMA TYPE 1
	 NOTICE M12 plug: Loss of IP protection class due to incorrect installation! The degree of protection only applies if the connecting cable used is plugged in and screwed tight. The degree of protection only applies if the connecting cable used is specified according to IP66/67 NEMA 4X. The protection classes are only maintained if the dummy cap is used or the cable is connected.
Vibration resistance	DIN EN 60068-2-64 / IEC 60068-2-64 for 5 to 2000 Hz: 1.5 (m/s ²) ² /Hz
Electromagnetic compatibility (EMC)	 Electromagnetic compatibility as per EN 61326 series and NAMUR recommendation EMC (NE21) Maximum measured error during EMC testing: < 0.5 % of the current digital measured value For more details refer to the EU Declaration of Conformity.

Process pressure range	 WARNING The maximum pressure for the device depends on the lowest-rated component with regard to pressure (components are: process connection, optional mounted parts or accessories). Only operate the device within the specified limits for the components! MWP (Maximum Working Pressure): The MWP is specified on the nameplate. This value refers to a reference temperature of +20 °C (+68 °F) and may be applied to the device for an unlimited time. Note temperature dependence of MWP. For flanges, refer to the following standards for the permitted pressure values at higher temperatures:
	 EN 1092-1 (with regard to their stability/temperature property, the materials 1.4435 and 1.4404 are grouped together under EN 1092-1; the chemical composition of the two materials can be identical), ASME B16.5, JIS B2220 (the latest version of the standard applies in each case). MWP data that deviate from this are provided in the relevant sections of the Technical Information. The Pressure Equipment Directive (2014/68/EU) uses the abbreviation PS . This corresponds to the maximum working pressure (MWP) of the device. The following tables show the dependencies between the seal material, process temperature (T_P) and process pressure range for each process connection that can be selected for the antenna used

Encapsulated antenna, PVDF, 40 mm (1.5 in)

Process connection thread 1-1/2"

	Seal	T _p	Process pressure range
	PVDF encapsulated	-40 to +80 ℃ (-40 to +176 ℉)	-1 to 3 bar (-14.5 to 43.5 psi)
	PVDF encapsulated	-40 to +130 ℃ (-40 to +266 ℉)	-1 to 3 bar (-14.5 to 43.5 psi)
	The following temperature restriction applies for devices with the dust ignition-proof approval category 1D, 2D or 3D		
A0047831	PVDF encapsulated	-20 to +80 °C (-4 to +176 °F)	-1 to 3 bar (-14.5 to 43.5 psi)

Process connection UNI flange PP

	Seal	T _p	Process pressure range
	PVDF encapsulated	−40 to +80 ℃ (−40 to +176 ℉)	-1 to 3 bar (-14.5 to 43.5 psi)
	The following temperature restriction applies for devices with the dust ignition-proof approval category 1D, 2D or 3D		
A0047947	PVDF encapsulated	-20 to +80 °C (-4 to +176 °F)	-1 to 3 bar (-14.5 to 43.5 psi)

The pressure range may be further restricted in the event of a CRN approval.

Drip-off antenna 50 mm (2 in)

Process connection thread

	Seal	T _p	Process pressure range
	FKM Viton GLT	-40 to +80 °C (-40 to +176 °F)	-1 to 16 bar (-14.5 to 232 psi)
	FKM Viton GLT	-40 to +130 °C (-40 to +266 °F)	-1 to 16 bar (-14.5 to 232 psi)
A0047447			

Process connection UNI flange PP

	Seal	T _p	Process pressure range
A0047726	FKM Viton GLT	-40 to +80 °C (-40 to +176 °F)	−1 to 3 bar (−14.5 to 43.5 psi)

Process connection UNI flange 316L

	Seal	T _p	Process pressure range
	FKM Viton GLT	–40 to +80 °C (–40 to +176 °F)	-1 to 3 bar (-14.5 to 43.5 psi)
	FKM Viton GLT	–40 to +130 °C (–40 to +266 °F)	–1 to 3 bar (–14.5 to 43.5 psi)
A0047726			



The pressure range may be further restricted in the event of a CRN approval.

Index

Symbols

•	
"Device ID" parameter	39
"Device revision" parameter	39
"Firmware version" parameter	39
"Manufacturer ID" parameter	39

Α

Access authorization to parameters Read access	29 29 29 29
B	. 0
Bluetooth [®] wireless technology	30

С

-	
CE mark (Declaration of Conformity)	. 9
Cleaning	60
Climate class	78
Cyclic data transmission	41

D

Declaration of Conformity
Device description files
Device locking, status
Device master file
GSD
Device Viewer
DeviceCare
Device description file
Diagnostic event
Display values
For locking status
Disposal
Document
Purpose

Ε

Event history	56
Event list	56
Event text	53
Exterior cleaning	50

F

1
Field of application
Residual risks
FieldCare
Device description file
Function
Filtering the event logbook 57
Firmware
Release date
T
1
Intended use

M Media
O Operation
PProduct safety
RRead access29Reading off measured values49Registered trademarks6Repair concept61Requirements concerning the staff8Return62
S Safety instructions Basic
Settings
Service interface (CDI) 38, 45 Settings Adapting the measuring device to the process conditions 49 Software release 39 Spare parts 61 Nameplate 61 Status signal 52
Service interface (CDI)38, 45SettingsAdapting the measuring device to the process conditions49Software release39Spare parts61Nameplate61Status signal52Submenu56Interfaces35Measured values49System redundancy S243
Service Interface (CDI)38, 45SettingsAdapting the measuring device to the process conditions49Software release39Spare parts61Nameplate61Status signal52Submenu52Event list56Interfaces35Measured values49System redundancy S243T50Turning the display module18
Service interface (CDI) 38, 45 Settings Adapting the measuring device to the process conditions 49 Software release 39 Spare parts 61 Nameplate 61 Status signal 52 Submenu 52 Event list 56 Interfaces 35 Measured values 49 System redundancy S2 43 T Troubleshooting 50 Turning the display module 18 U Use of the measuring device see Intended use Use of the measuring devices 8 8

W	
Workplace safety	9
Write access	29



www.addresses.endress.com

