Valid as of version 01.02.zz (Device firmware) Products Solutions

Services

Operating Instructions **Proline Prosonic Flow G 500**

Ultrasonic time-of-flight flowmeter HART







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document	6	6	Mounting	21
1.1 1.2 1.3	Document function	. 6 6 6 6 7 . 7 . 7 8 8	6.2	Mounting requirements 6.1.1 Mounting position 6.1.2 Environmental and process requirements 6.1.3 Special mounting instructions Mounting the measuring device 6.2.1 Required tools 6.2.2 Preparing the measuring device 6.2.3 Mounting the measuring device 6.2.4 Mounting the transmitter housing: Proline 500 – digital Post-mounting check	23 24 25 25 26 26
2	Safety Instructions		7	Electrical connection	29
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Requirements for the personnel	9 9 10 10 10	7.1 7.2 7.3 7.4 7.5	Electrical safety	29 29 33 33 34 34 37 38 38 39
3	Product description		7.6	7.5.1 Connection examples	43
3.1	Product design		7.7	Post-connection check	43
4	Incoming acceptance and product		8	Operation options	
		15	8.1 8.2	Overview of operation options Structure and function of the operating	45
5 5 5 5 5 5 5 5 5 5	4.2.2 Sensor nameplate	15 16 17 18 19 19 19 20 20	8.3	menu	55

3.4	8.3.12 Enabling and disabling the keypad lock 60 Access to operating menu via web browser 60 8.4.1 Function range 60	1	LO.7	5 5	117 117 119
	8.4.2 Requirements 61 8.4.3 Connecting the device 62	1	11	Operation	21
	8.4.4 Logging on	1	l1.1 l1.2	Reading off the device locking status	121 121 121
3.5	8.4.7 Logging out			Reading off measured values	121
	operating tool 67 8.5.1 Connecting the operating tool 67				122 124
	8.5.2 Field Xpert SFX350, SFX370 70			<u>*</u>	125 126
	8.5.3 FieldCare		11 5	11.4.5 "Totalizer" submenu	128
	8.5.5 AMS Device Manager	_ _ I			129
	8.5.7 SIMATIC PDM	1	l1.6	11.6.1 Function scope of "Control Totalizer"	129 130
9	System integration			11.6.2 Function range of "Reset all	
9.1	Overview of device description files	1	L1.7	*	131 131
9.2 9.3	Measured variables via HART protocol]	12	Diagnosis and troubleshooting 1	34
<i>.</i>	Other Settings			General troubleshooting	
10	Commissioning 80	1		12.2.1 Transmitter	137
10.1 10.2	Post-mounting and post-connection check 80 Switching on the measuring device 80	1	12.3	12.2.2 Sensor connection housing	138 139
10.3 10.4	Setting the operating language 80 Configuring the measuring device 80			3	139 141
10.1	10.4.1 Defining the tag name 82	1	L2.4	Diagnostic information in the web browser 3	142
	10.4.2 Setting the system units			3 1	142 143
	10.4.4 Configuring the status input 85 10.4.5 Configuring the current input 86	1		Diagnostic information in FieldCare or DeviceCare	144
	10.4.6 Configuring the current output 87			12.5.1 Diagnostic options	144
	10.4.7 Configuring the pulse/frequency/ switch output 90	1	12.6	3 1	145 146
	10.4.8 Configuring the relay output 96 10.4.9 Configuring the double pulse output 98			1 3 3	146 146
	10.4.10 Configuring the local display 99	1		Overview of diagnostic information	148
	10.4.11 Configuring the low flow cut off 101 10.4.12 Gas analysis configuration 102			3 3	153 153
10.5	Advanced settings			Event logbook	155
	10.5.1 Using the parameter to enter the access code			5	155 155
	10.5.2 Carrying out a sensor adjustment 105	1	12 11		156
	10.5.3 Configuring the totalizer 10510.5.4 Carrying out additional display]	14.11	Resetting the measuring device	158
	configurations	1	12 12	-	158 159
	10.5.6 Configuration management 11210.5.7 Using parameters for device			Firmware history	
10.6	administration 113 Simulation 115				

13	Maintenance	162
13.1	Maintenance tasks	162
	13.1.1 Exterior cleaning	162
13.2	Measuring and test equipment	162
13.3	Endress+Hauser services	162
14	Repair	163
14.1	General notes	163
	14.1.1 Repair and conversion concept	163
	14.1.2 Notes for repair and conversion	163
14.2	Spare parts	163
14.3	Endress+Hauser services	163
14.4	Return	163
14.5	Disposal	164
	14.5.1 Removing the measuring device	164
	14.5.2 Disposing of the measuring device	164
15	Accessories	165
15.1	Device-specific accessories	165
	15.1.1 For the transmitter	165
15.2	$Communication \hbox{-specific accessories} \dots \dots$	166
15.3	Service-specific accessories	167
15.4	System components	167
16	Technical data	168
16.1	Application	168
16.2	Function and system design	168
16.3	Input	169
16.4	Output	172
16.5	Power supply	178
16.6	Performance characteristics	179
16.7	Mounting	182
16.8	Environment	182
16.9	Process	183
16.10	Mechanical construction	185
	Display and user interface	189 192
	Application packages	192
	Accessories	196
	Supplemental documentation	196
Indox	-	100

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

⚠ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

▲ WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
===	Direct current
~	Alternating current
\sim	Direct current and alternating current
=	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Potential equalization connection (PE: protective earth) Ground terminals that must be connected to ground prior to establishing any other connections.
	The ground terminals are located on the interior and exterior of the device: Interior ground terminal: potential equalization is connected to the supply network. Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Communication-specific symbols

Symbol	Meaning
	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
•	LED Light emitting diode is off.

Symbol	Meaning	
举	LED Light emitting diode is on.	
	LED Light emitting diode is flashing.	

1.2.4 Tool symbols

Symbol	Meaning	
\$	Torx screwdriver	
Phillips head screwdriver		
Ó	Open-ended wrench	

1.2.5 Symbols for certain types of information

Symbol	Meaning
✓	Permitted Procedures, processes or actions that are permitted.
✓ ✓	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
•	Notice or individual step to be observed
1., 2., 3	Series of steps
L	Result of a step
?	Help in the event of a problem
	Visual inspection

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning	
Safe area (non-hazardous area)		
≈ → Flow direction		

1.3 Documentation



- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- Endress+Hauser Operations app: Enter serial number from nameplate or scan matrix code on nameplate.

1.3.1 Document function

The following documentation may be available depending on the version ordered:

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions (KA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Your reference document The Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.
Safety Instructions (XA)	Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. The Safety Instructions are an integral part of the Operating Instructions.
	Information on the Safety Instructions (XA) relevant to the device is provided on the nameplate.
Supplementary device-dependent documentation (SD/FY)	Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

2 Safety Instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the flow measurement of gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in explosive atmospheres, in hygienic applications or where there is a high risk of pressures, are labeled accordingly on the nameplate.

To ensure that the measuring device is in proper condition during the operation period:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ► Refer to the nameplate to check whether the ordered metering system can be operated for the intended application in areas requiring specific approvals (e.g. explosion protection, pressure equipment safety).
- ► Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ Keep within the specified pressure and temperature range.
- ▶ Keep within the specified ambient temperature range.
- ► Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

A WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

A CAUTION

Risk of hot or cold burns! The use of media and electronics with high or low temperatures can produce hot or cold surfaces on the device.

- ► Mount suitable touch protection.
- ▶ Use suitable protective equipment.

A WARNING

Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

► Take precautions to prevent injury and material damage if the rupture disk is actuated.

2.3 Workplace safety

When working on and with the device:

▶ Wear the required personal protective equipment as per national regulations.

2.4 Operational safety

Damage to the device!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. The manufacturer confirms this by affixing the CE mark to the device..

2.6 IT security

Our warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater inoperation safety if used correctly. The following list provides an overview of the most important functions:

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	Not enabled	On an individual basis following risk assessment
Access code (also applies to web server login or FieldCare connection) → 🖺 12	Not enabled (0000)	Assign a customized access code during commissioning
WLAN (order option in display module)	Enabled	On an individual basis following risk assessment
WLAN security mode	Enabled (WPA2- PSK)	Do not change
WLAN passphrase (Password) → 🖺 12	Serial number	Assign an individual WLAN passphrase during commissioning
WLAN mode	Access point	On an individual basis following risk assessment
Web server → 🗎 12	Enabled	On an individual basis following risk assessment
CDI-RJ45 service interface→ 🗎 13	-	On an individual basis following risk assessment

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code
 - Protect write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- WLAN passphrase
 - The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode
 - When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ($\rightarrow \equiv 117$).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

WLAN passphrase: Operation as WLAN access point

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter $(\rightarrow \implies 111)$.

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning for safety reasons.
- Follow the general rules for generating a secure password when defining and managing the access code and network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see "Write protection via access code" → 🖺 117.

2.7.3 Access via web server

The web server is enabled when the device is delivered. The web server can be disabled via the **Web server functionality** parameter if necessary (e.g., after commissioning).

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

For detailed information on device parameters, see: "Description of device parameters" document .

2.7.4 Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

Transmitters with an Ex de approval may not be connected via the service interface (CDI-RJ45)!

Product description 3

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

3.1 Product design

3.1.1 Proline 500 – digital


Signal transmission: digital

Order code for "Integrated ISEM electronics", option A "Sensor"

For use in applications not required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the sensor, the device is ideal: For simple transmitter replacement.

- A standard cable can be used as the connecting cable.
- Not sensitive to external EMC interference.




■ 1 Important components of a measuring device

- 1 Electronics compartment cover
- Display module
- 3 Transmitter housing
- Sensor connection housing with integrated ISEM electronics: connecting cable connection 4

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.

4.2 Product identification

The following options are available for identification of the device:


- Nameplate
- Order code with details of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations app* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations app*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard documentation on the device" and "Supplementary device-dependent documentation" sections
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations app*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Transmitter nameplate


Proline 500 - digital



■ 2 Example of a transmitter nameplate

- 1 Name of the transmitter
- 2 Manufacturer address/certificate holder
- 3 Space for approvals: use in hazardous areas
- 4 Degree of protection
- 5 Electrical connection data: available inputs and outputs
- 6 Permitted ambient temperature (T_a)
- 7 2-D matrix code
- 8 Space for approvals and certificates: e.g. CE mark, RCM tick
- 9 Permitted temperature range for cable
- 10 Date of manufacture: year-month
- 11 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 12 Document number of safety-related supplementary documentation
- 13 Space for additional information in the case of special products
- 14 Available inputs and outputs, supply voltage
- 15 Electrical connection data: supply voltage
- 16 Extended order code (ext. ord. cd.)
- 17 Serial number (Ser. no.)
- 18 Order code

4.2.2 Sensor nameplate



■ 3 Example of sensor nameplate

- 1 Name of sensor
- 2 Manufacturer address/certificate holder
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of the sensor; flange nominal diameter/nominal pressure; sensor test pressure; medium temperature range; material of measuring pipe and flanges; sensor-specific data
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Flow direction
- 9 2D-Matrixcode
- 10 Date of manufacture: year-month
- 11 Document number of safety-related supplementary documentation $\Rightarrow riangleq riangleq riangleq 197$
- 12 CE mark, RCM-Tick mark
- 13 Permitted ambient temperature (T_a)

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on the device

Symbol	Meaning
\triangle	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. Please consult the documentation for the measuring device to discover the type of potential danger and measures to avoid it.
	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal that must be connected to the ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight. Avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ▶ Do not store outdoors.

Storage temperature $\rightarrow \triangleq 182$

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0029252

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

A WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ► Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0029214

5.2.2 Measuring devices with lifting lugs

A CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ► The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Outer packaging of device
 Stretch wrap made of polymer in accordance with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wood crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62/EC, recyclability confirmed by Resy symbol
- Transport material and fastening fixtures
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material Paper pads

Mounting 6

6.1 Mounting requirements

6.1.1 Mounting position

Mounting location



Orientation

The direction of the arrow on the sensor helps you to install the sensor according to the flow direction (direction of medium flow through the piping).




- Install the measuring device in a parallel plane free of external mechanical stress.
 - The internal diameter of the pipe must match the internal diameter of the sensor: see the "Technical Information" device document, "Design and dimensions" section



	Compact version		
A	Vertical orientation	A0015545	
В	Horizontal orientation, transmitter head up ¹⁾	A0015589	₩₩
С	Horizontal orientation, transmitter head down ¹⁾	A0015590	V
D	Horizontal orientation, transmitter head at side	A0015592	X


The horizontal alignment of the transducers may only deviate by a maximum of $\pm 5^{\circ}$, particularly if a liquid is present in the medium (wet gas).



Inlet and outlet runs


If possible, install the sensors upstream of assemblies such as valves, T-pieces, elbows, and pumps. If this is not possible, the specified measurement accuracy of the measuring device is achieved by observing the specified minimum inlet and outlet runs with optimum sensor configuration.

Single-path version: DN 25 (1")




 \blacksquare 4 Single-path version: Minimum inlet and outlet runs with various flow obstructions. For order code for "Flow calibration", option A "1 %".

Two-path version: DN 50 to 300 (2 to 12")



 \blacksquare 5 Two-path version: minimum inlet and outlet runs with various flow obstructions For order code for "Flow calibration", option A "1 %" ".



■ 6 Two-path version: minimum inlet and outlet runs with various flow obstructions For order code for "Flow calibration", option C "0.50%" and option D "0.50%, traceable to ISO/IEC17025".

Dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .

6.1.2 Environmental and process requirements

Ambient temperature range

Measuring device	 Standard: -40 to +60 °C (-40 to +140 °F) Optional order code for "Test, certificate", option JP: -50 to +60 °C (-58 to +140 °F)
Readability of the local display	-20 to $+60$ °C (-4 to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.

► If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.

Medium pressure range

Min. medium pressure: 0.7 bar (10.2 psi) absolute

The maximum permitted medium pressure is defined by the pressure/temperature curves (see the "Technical Information" document) and the pressure specifications of the integrated pressure measuring cell (optional; order code for "Measuring tube; transducer; sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated").

A WARNING

The maximum pressure for the measuring device depends on the lowest-rated element with regard to pressure.

- ▶ Note specifications regarding the pressure range of the pressure measuring cell.
- ► The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the pressure measuring cell.
- ► The MWP for the pressure measuring cell depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection must be taken into consideration in addition to the pressure measuring cell. Also take the pressure/temperature dependency into consideration.
- ► The MWP may be applied at the device for an unlimited period. The MWP is indicated on the nameplate. This value refers to a reference temperature of +20 °C (+68 °F) and may be applied to the pressure measuring cell for an unlimited time.
- ► The OPL (over pressure limit = sensor overload limit) for the measuring device depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the pressure measuring cell. Also take the pressure/temperature dependency into consideration.
- ► The test pressure corresponds to the over pressure limit of the pressure measuring cell and may be applied only temporarily to ensure that the measurement is within the specifications and no permanent damage occurs.

Pressure measuring cell	Maximum senso	r measuring range	MWP	OPL
	Lower (LRL)	.ower (LRL) Upper (URL)		
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]
2 bar (30 psi)	0 (0)	+2 (+30)	6.7 (100.5)	10 (150)
4 bar (60 psi)	0 (0)	+4 (+60)	10.7 (160.5)	16 (240)
10 bar (150 psi)	0 (0)	+10 (+150)	25 (375)	40 (600)
40 bar (600 psi)	0 (0)	+40 (+600)	100 (1500)	160 (2400)
100 bar (1500 psi)	0 (0)	+100 (+1500)	100 (1500)	160 (2400)

Thermal insulation

For optimum measurement performance, make sure that no heat transfer (heat loss or heat supply) can take place at the sensor. This can be ensured by installing thermal insulation. The formation of condensation in the measuring device can also be limited in this way.


Thermal insulation is particularly recommended in situations in which the difference between the process temperature and ambient temperature is large. This difference leads to an error during temperature measurement that is caused by heat conduction (known as the "heat conduction error").

WARNING

Electronics overheating on account of thermal insulation!

- ► Recommended orientation: horizontal orientation, sensor connection housing pointing downwards.
- ▶ Do not insulate the sensor connection housing.
- Maximum permissible temperature at the lower end of the sensor connection housing: $80 \,^{\circ}\text{C} (176 \,^{\circ}\text{F})$
- ► Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.

The thermal insulation should never cover the transmitter housing and the pressure measuring cell.



A003767

 \blacksquare 7 Thermal insulation with free extended neck and pressure measuring cell


1 Pressure measuring cell

6.1.3 Special mounting instructions

Rupture disk


Process-related information: $\rightarrow \blacksquare 184$.

The position of the rupture disk is indicated on a sticker applied over it. If the rupture disk is triggered, the sticker is destroyed. The disk can therefore be visually monitored.



Rupture disk label

Weather protection cover



₽8 Weather protection cover for Proline 500 – digital; engineering unit mm (in)

6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

For mounting on a post:

Proline 500 – digital transmitter

- Open-ended wrench AF 10
- Torx screwdriver TX 25

For wall mounting:

Drill with drill bit Ø 6.0 mm

For sensor

For flanges and other process connections: use a suitable mounting tool

Endress+Hauser 25

A0029552

6.2.2 Preparing the measuring device


- 1. Remove all remaining transport packaging.
- 2. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the measuring device

A WARNING

Danger due to improper process sealing!

- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the seals are clean and undamaged.
- ► Secure the seals correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the medium.
- 2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Mounting the transmitter housing: Proline 500 – digital

A CAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature \rightarrow $\stackrel{\triangle}{=}$ 23.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

A CAUTION

Excessive force can damage the housing!

▶ Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

Pipe mounting

Required tools:


- Open-ended wrench AF 10
- Torx screwdriver TX 25

A WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

▶ Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)




■ 9 Engineering unit mm (in)

Wall mounting

Required tools:

Drill with drill bit \emptyset 6.0 mm



■ 10 Engineering unit mm (in)

L Depends on order code for "Transmitter housing"

Order code for "Transmitter housing"

- Option **A**, aluminum, coated: L = 14 mm (0.55 in)
- Option **D**, polycarbonate: L = 13 mm (0.51 in)
- 1. Drill the holes.
- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the fixing screws slightly.
- 4. Fit the transmitter housing over the fixing screws and mount in place.

Endress+Hauser 27

A002905

5. Tighten the fixing screws.

6.3 Post-mounting check

Is the measuring device undamaged (visual inspection)?	
Does the measuring device correspond to the measuring point specifications? For example: Process temperature → 🖺 183 Pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document on the CD-ROM provided) Ambient temperature Measuring range	
Has the correct orientation for the sensor been selected → 🗎 21? • According to sensor type • According to medium temperature • According to medium properties (outgassing, with entrained solids)	
Does the arrow on the sensor match the actual direction of flow of the medium through the piping $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	
Is the tag name and labeling correct (visual inspection)?	
Is the device sufficiently protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

7 Electrical connection

▲ WARNING

Live parts! Incorrect work performed on the electrical connections can result in an electric shock.

- ► Set up a disconnecting device (switch or power-circuit breaker) to easily disconnect the device from the supply voltage.
- ▶ In addition to the device fuse, include an overcurrent protection unit with max. 10 A in the plant installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: use appropriate tool
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: flat blade screwdriver ≤ 3 mm (0.12 in)

7.2.2 Requirements for connection cable

The connecting cables provided by the customer must fulfill the following requirements.

Protective grounding cable for the outer ground terminal

Conductor cross-section < 2.1 mm² (14 AWG)

The use of a cable lug enables the connection of larger cross-sections.

The grounding impedance must be less than 2 Ω .

Permitted temperature range

- The installation quidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

Current output 0/4 to 20 mA

Standard installation cable is sufficient

Pulse /frequency /switch output

Standard installation cable is sufficient

Double pulse output

Standard installation cable is sufficient

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient

Status input


Standard installation cable is sufficient

Cable diameter

- Cable glands supplied: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules.
 Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Choice of connecting cable between the transmitter and sensor

Depends on the type of transmitter and the installation zones



A0035795

- 1 Proline 500 digital transmitter
- 2 Prosonic Flow sensor
- 3 Non-hazardous area
- 4 Hazardous area: Zone 2; Class I, Division 2
- 5 Hazardous area: Zone 1; Class I, Division 1
- A Standard cable to transmitter 500 − digital → 🖺 31

 Transmitter installed in the non-hazardous area or hazardous area: Zone 2; Class I, Division 2/sensor installed in the hazardous area: Zone 2; Class I, Division 2
- B Standard cable to transmitter 500 digital → 🖺 31
 Transmitter installed in the hazardous area: Zone 2; Class I, Division 2/sensor installed in the hazardous area:
 Zone 1; Class I, Division 1

A: Connecting cable between sensor and transmitter: Proline 500 – digital Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4 cores; uninsulated stranded CU wires; with common shield		
Shielding	Tin-plated copper braid, optical cover ≥ 85 %		
Loop resistance	Power supply line (+, $-$): maximum 10 Ω		
Cable length	Maximum 300 m (900 ft), see the following table.		
Device plug, side 1	M12 socket, 5-pin, A-coded.		
Device plug, side 2	M12 plug, 5-pin, A-coded.		

Cross-section	Cable length [max.]
0.34 mm ² (AWG 22)	80 m (240 ft)
0.50 mm ² (AWG 20)	120 m (360 ft)
0.75 mm ² (AWG 18)	180 m (540 ft)
1.00 mm ² (AWG 17)	240 m (720 ft)
1.50 mm ² (AWG 15)	300 m (900 ft)


Optionally available connecting cable

Flame resistance	As per DIN EN 60332-1-2
Oil-resistance	According to DIN EN 60811-2-1
Shielding	Tin-plated copper braid, optical cover ≥ 85 %

B: Connecting cable between sensor and transmitter: Proline 500 - digital Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4, 6, 8 cores (2, 3, 4 pairs); uninsulated stranded CU wires; pair-stranded with common shield
Shielding	Tin-plated copper braid, optical cover \geq 85 %
Capacitance C	Maximum 760 nF IIC, maximum 4.2 μF IIB
Inductance L	Maximum 26 μH IIC, maximum 104 μH IIB
Inductance/resistance ratio (L/R)	Maximum 8.9 $\mu H/\Omega$ IIC, maximum 35.6 $\mu H/\Omega$ IIB (e.g. according to IEC 60079-25)
Loop resistance	Power supply line (+, –): maximum 5 Ω
Cable length	Maximum 150 m (450 ft), see the following table.



Optionally available connecting cable

Connecting cable for	Zone 1; Class I, Division 1
Standard cable	$2\times2\times0.5~\text{mm}^2$ (AWG 20) PVC cable $^{1)}$ with common shield (2 pairs, pair-stranded)
Flame resistance	According to DIN EN 60332-1-2
Oil-resistance	According to DIN EN 60811-2-1
Shielding	Tin-plated copper braid, optical cover ≥ 85 %
Operating temperature	When mounted in a fixed position: -50 to $+105$ °C (-58 to $+221$ °F); when cable can move freely: -25 to $+105$ °C (-13 to $+221$ °F)
Available cable length	Fixed: 20 m (60 ft); variable: up to maximum 50 m (150 ft)

1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

7.2.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply voltage		Input/	output l	Input/output 2		Input/output 3		Input/output 4	
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)
		Device-specific terminal assignment: adhesive label in terminal cover.							

Transmitter and sensor connection housing: connecting cable

The sensor and transmitter, which are mounted in separate locations, are interconnected by a connecting cable. The cable is connected via the sensor connection housing and the transmitter housing.

Terminal assignment and connection of the connecting cable: Proline $500 - digital \rightarrow 24$

7.2.4 Preparing the measuring device

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Sensor connection housing: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- ▶ Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- 3. If the measuring device is supplied with cable glands:
 Observe requirements for connecting cables →

 29.

7.3 Connecting the measuring device: Proline 500 digital

NOTICE

An incorrect connection compromises electrical safety!

- Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- Always connect the protective ground cable \oplus before connecting additional cables.
- When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.


7.3.1 Connecting the connecting cable

MARNING

Risk of damaging electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.

Connecting cable terminal assignment



- Cable entry for cable on transmitter housing
- 2 Protective earth (PE)
- 3 Connecting cable ISEM communication
- Grounding via ground connection; in the version with a device plug, grounding is ensured through the plug
- Cable entry for cable or connection of device plug on sensor connection housing
- Protective earth (PE)

Connecting the connecting cable to the sensor connection housing

Connection via terminals with order code for "Sensor connection housing":

- Option **L** "Cast, stainless" → 🖺 35


Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals $\rightarrow \triangleq 36$.

Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing":

- Option A "Aluminum coated"
- Option **L** "Cast, stainless"



10020616


- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- 3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
 - This concludes the process for connecting the connecting cable.

A WARNING

Housing degree of protection voided due to insufficient sealing of the housing.

- ► Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- 9. Tighten the securing clamp of the housing cover.

Connecting the connecting cable to the transmitter




A002959

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 7. Connect the cable according to the terminal assignment for the connecting cable $\rightarrow \implies 34$.
- 8. Firmly tighten the cable glands.
 - The process for connecting the connecting cable is now complete.
- 9. Close the housing cover.
- 10. Tighten the securing screw of the housing cover.
- 11. After connecting the connecting cable:Connect the signal cable and the supply voltage cable →


 37.

7.3.2 Connecting the signal cable and the supply voltage cable



A0028200

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output
- 4 Terminal connection for connecting cable between sensor and transmitter
- 5 Terminal connection for signal transmission, input/output; optional: connection for external WLAN antenna
- 6 Protective earth (PE)



A002959

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 7. Connect the cable according to the terminal assignment.
 - ► **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply voltage terminal assignment: Adhesive label in the terminal cover or $\rightarrow \implies 33$.

- 8. Firmly tighten the cable glands.
 - ► This concludes the cable connection process.
- 9. Close the terminal cover.
- 10. Close the housing cover.

A WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

► Screw in the screw without using any lubricant.

▲ WARNING


Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- ► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)
- 11. Tighten the 4 fixing screws on the housing cover.

Removing a cable

To remove a cable from the terminal:



- 11 Engineering unit mm (in)
- 1. Use a flat-blade screwdriver to press down on the slot between the two terminal holes.
- 2. Remove the cable end from the terminal.

7.4 Potential equalization

7.4.1 Requirements

For potential equalization:


- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Medium, Connect the sensor and transmitter to the same electric potential ¹⁾
- ullet Use a ground cable with a minimum cross-section of 6 mm 2 (10 AWG) and a cable lug for potential equalization connections

1)

7.5 Special connection instructions


7.5.1 Connection examples

Current output 4 to 20 mA HART



A0029055


- 12 Connection example for 4 to 20 mA HART current output (active)
- 1 Automation system with current input (e.g. PLC)
- 2 Ground cable shield at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications → 🖺 178
- 3 Connection for HART operating devices → 🗎 67
- Resistor for HART communication (≥ 250 Ω): observe maximum load \rightarrow $\stackrel{\square}{=}$ 172
- 6 Transmitter



A002876

- 13 Connection example for 4 to 20 mA HART current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Ground cable shield at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load \rightarrow $\stackrel{\triangle}{=}$ 172
- 5 Transmitter


HART input



■ 14 Connection example for HART input with a common negative (passive)


- 1 Automation system with HART output (e.g. PLC)
- Active barrier for power supply (e.g. RN221N) 2
- 3 Ground cable shield at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- Analog display unit: observe maximum load $\rightarrow \implies 172$
- Pressure measuring device (e.g. Cerabar M, Cerabar S): observe requirements
- Transmitter

Current output 4-20 mA



■ 15 Connection example for 4-20 mA current output (active)


- Automation system with current input (e.g. PLC)
- Analog display unit: observe maximum load $\rightarrow = 172$ 2
- 3 Transmitter



Connection example for 4-20 mA current output (passive)


- Automation system with current input (e.g. PLC)
- Active barrier for power supply (e.g. RN221N) 2
- 3 Analog display unit: observe maximum load $\rightarrow \square$ 172
- Transmitter

Pulse/frequency output




- **■** 17 Connection example for pulse/frequency output (passive)
- Automation system with pulse/frequency input (e.g. PLC with 10 k Ω pull-up or pull-down resistor)
- Power supply
- 3 *Transmitter: observe input values →* 173

Switch output




- € 18 Connection example for switch output (passive)
- Automation system with switch input (e.g. PLC with a 10 k Ω pull-up or pull-down resistor)
- 2 Power supply
- *Transmitter: observe input values →* 173

Double pulse output



A0029280


- **■** 19 Connection example for double pulse output (active)
- Automation system with double pulse input (e.g. PLC)
- 2 *Transmitter: observe input values →* 175
- 3 Double pulse output
- Double pulse output (slave), phase-shifted



■ 20 Connection example for double pulse output (passive)

- 1 Automation system with double pulse input (e.g. PLC with a 10 k Ω pull-up or pull-down resistor)
- 2 Power supply
- *3 Transmitter: observe input values → 🖺 175*
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


Relay output



21 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply


Current input



■ 22 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- 3 External measuring device (to read in pressure or temperature, for instance)
- 4 Transmitter

Status input



■ 23 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter


7.6 Ensuring the degree of protection

The measuring device fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To guarantee the degree of protection IP66/67, Type 4X enclosure, carry out the following steps after electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.
- 5. To ensure that moisture does not enter the cable entry:

 Route the cable so that it loops down before the cable entry ("water trap").



A002927

6. The cable glands supplied do not ensure housing protection when not in use. They must therefore be replaced by dummy plus corresponding to the housing protection.


7.7 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Is the protective earthing established correctly?	
Do the cables used comply with the requirements ?	
Are the mounted cables relieved of tension?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" → 🖺 43?	

Is the terminal assignment correct ?	
Are dummy plugs inserted in unused cable entries and have transportation plugs been replaced with dummy plugs?	

8 Operation options

8.1 Overview of operation options




A0024E12

- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device $\Rightarrow \implies 196$



 \blacksquare 24 Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (e.g. operator, maintenance etc.). Each user role contains typical tasks within the device life cycle.

Menu/pa	arameter	User role and tasks	Content/meaning
Language	Task- oriented	Role "Operator", "Maintenance" Tasks during operation: Configuration of the operational	 Defining the operating language Defining the Web server operating language Resetting and controlling totalizers
Operation		display Reading measured values	 Configuring the operational display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs Configuration of the communication interface	Wizards for fast commissioning: Configuration of the system units Displaying the I/O configuration Configuring the measuring point Configuration of the inputs Configuration of the outputs Configuration of the operational display Configuration of the low flow cut off Configuration of gas analysis
			Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers Configuration of WLAN settings Administration (define access code, reset measuring device)
Diagnostics		"Maintenance" role Troubleshooting: Diagnostics and elimination of process and device errors Measured value simulation	Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device Measured values Contains all current measured values. Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values Heartbeat Technology The functionality of the device is checked on demand and the verification results are documented. Simulation Used to simulate measured values or output values.
Expert	Function- oriented	Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases	Contains all of the device parameters and allows direct access to these by means of an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-level device parameters that do not affect measurement or measured value communication Sensor Configuration of the measurement Input Configuration of the status input Output Configuration of the analog current outputs as well as the pulse/frequency and switch output Communication Configuration of the digital communication interface and the web server Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to operating menu via local display

8.3.1 Operational display



A002934

- 1 Operational display
- 2 Device tag \rightarrow \triangleq 82
- 3 Status area
- 4 Display range for measured values (up to 4 lines)
- *5 Operating elements* → 🗎 *55*


Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 139
 - **F**: Failure
 - **C**: Function check
 - **S**: Out of specification
- **M**: Maintenance required
- Diagnostic behavior → 🖺 140
 - 🛚 🐼: Alarm
 - <u>M</u>: Warning
- 🖆: Locking (the device is locked via the hardware)
- +: Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Appears only if a diagnostics event is present for this measured variable.

Measured variables

Symbol	Meaning
Ü	Volume flowCorrected volume flow
ṁ	Mass flow

С	Sound velocity
р	Pressure
P	Energy flow
ΰ	Flow velocity
4	Temperature
М	Wobbe index
σ	Methane fraction
М	Molar mass
ρ	DensityReference density
η	Dynamic viscosity
Н	Calorific value
SNR	Signal to noise ratio
1/4	Acceptance rate
A	Asymmetry
Т	Turbulence
••	Signal strength

The number and display format of the measured variables can be configured via the **Format display** parameter ($\rightarrow \implies 100$).

Totalizer

Symbol	Meaning
~	Totalizer
	The measurement channel number indicates which of the three totalizers is displayed.

Output

Symbol	Meaning
(-)	Output The measurement channel number indicates which of the outputs is displayed.

Input

Symbol	Meaning
€	Status input

Measurement channel numbers


Symbol	Meaning
14	Measurement channel 1 to 4 The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. totalizer 1 to 3).

Diagnostic behavior

Symbol	Meaning
8	Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Δ	 Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.


8.3.2 Navigation view



Navigation path

The navigation path to the current position is displayed at the top left in the navigation view and consists of the following elements:

- The display symbol for the menu/submenu (►) or the wizard (►).
- An omission symbol (/ ../) for operating menu levels in between.
- Name of the current submenu, wizard or parameter






Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
 - The direct access code to the parameter (e.g., 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal



- For information on the diagnostic behavior and status signal $\rightarrow \triangleq 139$

Display area

Menus

Symbol	Meaning
P	Operation Is displayed: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu

۶	Setup Is displayed: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
ુ પ્	Diagnosis Is displayed: ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the Diagnostics menu
.;¢	Expert Is displayed: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
75.	Wizards
Ø.	Parameters within a wizard No display symbol exists for parameters in submenus.

Locking procedure


Symbol	Meaning
â	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. By a user-specific access code By the hardware write protection switch

Wizards

Symbol	Meaning
←	Switches to the previous parameter.
√	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 Editing view


Numeric editor



■ 25 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 Operating elements

Text editor



■ 26 For entering text in parameters (e.g. device tag)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 Operating elements
- 5 Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

Using the operating elements in the editing view

Operating key	Meaning
	Minus key Move the entry position to the left.
+	Plus key Move the entry position to the right.

Operating key	Meaning
E	 Enter key Pressing the key briefly confirms your selection. Pressing the key for 2 s confirms your entry.
-++	Escape key combination (press keys simultaneously) Close the editing view without accepting a change.

Input screens

Symbol	Meaning
Α	Upper case
a	Lower case
1	Numbers
+*.	Punctuation marks and special characters: = + - * / 2 3 4 4 4 2 3 4 () [] < > { }
0	Punctuation marks and special characters: ' " `^. , ; : ? ! % μ ° € \$ £ ¥ § @ # / \ I ~ & _
ä	Umlauts and accents

Controlling data entries

Symbol	Meaning
←→	Move entry position
X	Reject entry
4	Confirm entry
•×	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

8.3.4 Operating elements

Operating key	Meaning
	Minus key
	In menu, submenu Moves the selection bar upwards in a picklist
	In wizards Goes to previous parameter
	In the text and numeric editor Move the entry position to the left.
	Plus key
	In menu, submenu Moves the selection bar downwards in a picklist
(+)	In wizards Goes to the next parameter
	In the text and numeric editor Move the entry position to the right.
	Enter key
E	In the operational display Pressing the key briefly opens the operating menu.
	 In menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter.
	In wizards Opens the editing view of the parameter and confirms the parameter value
	 In the text and numeric editor Pressing the key briefly confirms your selection. Pressing the key for 2 s confirms your entry.
	Escape key combination (press keys simultaneously)
(a)+(+)	 In menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position").
	In wizards Exits the wizard and takes you to the next higher level
	In the text and numeric editor Exits the Editing view without applying the changes.
	Minus/Enter key combination (press and hold down the keys simultaneously)
(-)+(E)	 If keypad lock is active: Pressing the key for 3 s deactivates the keypad lock. If keypad lock is not active: Pressing the key for 3 s opens the context menu including the option for activating the keypad lock.

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display: $\frac{1}{2} \left(\frac{1}{2} \right) = \frac{1}{2} \left(\frac{1}{2} \right) \left(\frac{$

- Setup
- Data backup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- 1. Press the \Box and \Box keys for longer than 3 seconds.
 - ► The context menu opens.



A0034608-EN

- 2. Press \Box + \pm simultaneously.
 - The context menu is closed and the operational display appears.

Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.
- 3. Press **E** to confirm the selection.
 - ► The selected menu opens.


56

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\Rightarrow \implies 51$

Example: Setting the number of displayed measured values to "2 values"




8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

Expert → Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
 Example: Enter 00914 → Assign process variable parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter **00914-2** → **Assign process variable** parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

- 1. Press E for 2 s.
 - ► The help text for the selected parameter opens.



A0014002-EN

- 27 Example: Help text for parameter "Enter access code"
- 2. Press \Box + \pm simultaneously.
 - ► The help text is closed.

8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

A0014049-EN

For a description of the editing view - consisting of the text editor and numeric editor - with symbols $\rightarrow \implies 53$, for a description of the operating elements $\rightarrow \implies 55$

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access $\rightarrow \blacksquare 117$.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
 - The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ ¹⁾

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	_ 1)

- Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection as they do not affect the measurement: write protection via access code → ■ 117
- The user role with which the user is currently logged on is indicated by the **Access** status parameter. Navigation path: Operation → Access status

8.3.11 Disabling write protection via access code

If the $oxtless{1}{@}$ -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\Rightarrow \begin{center}{c} \begin{center} \begin{$

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ($\rightarrow \implies 105$) via the respective access option.

1. After you press **E**, the input prompt for the access code appears.

- 2. Enter the access code.
 - The \(\bar{\mathbb{O}}\) -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

- The keypad lock is switched on automatically:
 - If the device has not been operated via the display for > 1 minute.
 - Each time the device is restarted.

To activate the keylock manually:

- 1. The device is in the measured value display.

 Press the □ and □ keys for 3 seconds.
 - ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- ► The keypad lock is switched on. Press the □ and □ keys for 3 seconds.
 - ► The keypad lock is switched off.

8.4 Access to operating menu via web browser

8.4.1 Function range

With the integrated web server, the device can be operated and configured via a web browser service interface (CDI-RJ45) or WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

8.4.2 Requirements

Computer hardware

Hardware	Interface	
	CDI-RJ45	WLAN
Interface	The computer must have a RJ45 interface. ¹⁾	The operating unit must have a WLAN interface.
Connection	Standard Ethernet cable	Connection via Wireless LAN.
Screen	Recommended size: ≥12" (depends on the screen resolution)	

¹⁾ Recommended cable: CAT5e, CAT6 or CAT7, with shielded plug (e.g. YAMAICHI product; part no. Y-ConProfixPlug63/Prod. ID: 82-006660)

Computer software

Software	Interface		
	CDI-RJ45	WLAN	
Recommended operating systems	 Microsoft Windows 8 or higher. Mobile operating systems: iOS Android Microsoft Windows XP and Windows 7 is supported. 		
Web browsers supported	 Microsoft Internet Explorer 8 or higher Microsoft Edge Mozilla Firefox Google Chrome Safari 		

Computer settings

Settings	Interface	
	CDI-RJ45	WLAN
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (e.g. for adjusting the IP address, subnet mask etc.).	
Proxy server settings of the web browser	The web browser setting <i>Use a proxy server for your LAN</i> must be disabled .	
JavaScript	JavaScript must be enabled.	JavaScript must be enabled.
	If JavaScript cannot be enabled: Enter http://192.168.1.212/servlet/ basic.html in the address bar of the web browser. A fully functional but simplified version of the operating menu structure starts in the web browser.	The WLAN display requires JavaScript support.
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) under Internet options in the web browser.	
Network connections	Only use the active network connections to the measuring device.	
	Switch off all other network connections such as WLAN for example.	Switch off all other network connections.

Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface	
Measuring device	The measuring device has an RJ45 interface.	
Web server	Web server must be enabled; factory setting: ON	
	For information on enabling the Web server $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	

Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna: Transmitter with integrated WLAN antenna Transmitter with external WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ON For information on enabling the Web server → 66

8.4.3 Connecting the device

Via service interface (CDI-RJ45)

Preparing the measuring device

Proline 500 - digital

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol.

Connect the computer to the RJ45 plug via the standard Ethernet cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- 2. Connect the computer to the RJ45 plug via the standard Ethernet cable $\rightarrow \triangleq 68$.
- 3. If a 2nd network card is not used, close all the applications on the notebook.
 - Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 \rightarrow e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

Note the following to avoid a network conflict:

- ► Avoid accessing the measuring device simultaneously from the same mobile terminal via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

► Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

- In the WLAN settings of the mobile terminal:
 Select the measuring device using the SSID (e.g. EH_Prosonic Flow_500_A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password:

Serial number of the measuring device ex-works (e.g. L100A802000).

- The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.
- 🚹 The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.


Terminating the WLAN connection

► After configuring the device: Terminate the WLAN connection between the mobile terminal and measuring device.

Starting the web browser

1. Start the web browser on the computer.

- 2. Enter the IP address of the web server in the address line of the web browser: 192.168.1.212
 - ► The login page appears.



- 1 Picture of device
- 2 Device name
- *3 Device tag (→ 🖺 82)*
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code (→ 🖺 114)
- If a login page does not appear, or if the page is incomplete $\rightarrow \stackrel{\triangle}{=} 135$

8.4.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (factory setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal \rightarrow 🖺 142
- Current measured values

Function row

Functions	Meaning
Measured values	Displays the measured values of the device
Menu	 Access to the operating menu from the measuring device The structure of the operating menu is the same as for the local display
	Detailed information on the operating menu structure: Description of Device Parameters
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	Data exchange between computer and measuring device: Device configuration: Load settings from the device (XML format, save configuration) Save settings to the device (XML format, restore configuration) Logbook - Export Event logbook (.csv file) Documents - Export documents: Export backup data record (.csv file, create documentation of the measuring point configuration) Verification report (PDF file, only available with the "Heartbeat Verification" application package) Firmware update - Flashing a firmware version
Network	Configuration and checking of all the parameters required for establishing the connection to the measuring device: Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

The menus, the associated submenus and parameters can be selected in the navigation area.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu \rightarrow Communication \rightarrow Web server

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	OffHTML OffOn	On

Function scope of the "Web server functionality" parameter

Option	Description
Off	The Web server is completely disabled.Port 80 is locked.
HTML Off	The HTML version of the Web server is not available.
On	 The complete Web server functionality is available. JavaScript is used. The password is transferred in an encrypted state. Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

- Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.
- 1. Select the **Logout** entry in the function row.
 - ► The home page with the Login box appears.
- 2. Close the Web browser.
- 3. If no longer needed:

Reset the modified properties of the Internet protocol (TCP/IP) $\rightarrow \triangleq 62$.

66


8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool

Via HART protocol


This communication interface is available in device versions with a HART output.



A0028747

■ 28 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with web browser (e.g. Microsoft Edge) to access the integrated device web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter




₽ 29 Options for remote operation via HART protocol (passive)

- 1 Control system (e.g. PLC)
- *Transmitter power supply unit, e.g. RN221N (with communication resistor)* 2
- 3 Connection for Commubox FXA195 and Field Communicator 475
- Field Communicator 475
- Computer with web browser (e.g. Microsoft Edge) to access the integrated device web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA195 (USB)
- Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT70
- VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

Service interface

Via service interface (CDI-RJ45)


A point-to-point connection can be established to configure the device on site. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.



Order code for "Accessories", option NB: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 plug mounted in the cable entry. The connection to the service interface can be established via an M12 plug without opening the device.

Proline 500 – digital transmitter



Connection via service interface (CDI-RJ45)


- Computer with web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) to access the integrated web server or with an operating tool "FieldCare", "DeviceCare" with COM DTM "CDI Communication TCP/IP"
- Standard Ethernet connecting cable with RJ45 plug
- Service interface (CDI-RJ45) of the measuring device with access to the integrated web server

68

Via WLAN interface

The optional WLAN interface is available on the following device version:

Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



10027602

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antennas	 Internal antenna External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Only 1 antenna is active at any one time!
Range	 Internal antenna: typically 10 m (32 ft) External antenna: typically 50 m (164 ft)
Materials (external antenna)	 Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Plug: Nickel-plated brass Angle bracket: Stainless steel

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

Note the following to avoid a network conflict:

- ▶ Avoid accessing the measuring device simultaneously from the same mobile terminal via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

► Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal:

 Select the measuring device using the SSID (e.g. EH_Prosonic Flow_500_A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password:

Serial number of the measuring device ex-works (e.g. L100A802000).

- The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.
- The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Terminating the WLAN connection

► After configuring the device: Terminate the WLAN connection between the mobile terminal and measuring device.

8.5.2 Field Xpert SFX350, SFX370

Function scope

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

Source for device description files

8.5.3 FieldCare

Function range

FDT-based (Field Device Technology) plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- HART protocol → 🗎 67
- CDI-RJ45 service interface → 🖺 68
- WLAN interface → 🗎 69

Typical functions:

- Transmitter parameter configuration
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



- Operating Instructions BA00027S
- Operating Instructions BA00059S
- Source for device description files $\rightarrow \triangleq 74$


Establishing a connection

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
 - ► The **Add device** window opens.
- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.
 - ► The CDI Communication TCP/IP (Configuration) window opens.
- 6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
- 7. Establish the online connection to the device.



- Operating Instructions BA00027S
- Operating Instructions BA00059S

User interface



A0021051-EN


- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal $\rightarrow \implies 142$
- 6 Display area for current measured values
- 7 Editing toolbar with additional functions such as save/load, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Work area
- 10 Action area
- 11 Status area

8.5.4 DeviceCare

Function range

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



Source for device description files $\rightarrow \stackrel{\triangle}{=} 74$

8.5.5 AMS Device Manager

Function range

 $\label{thm:program} \mbox{ Process Management for operating and configuring measuring devices via the HART protocol.}$

Source for device description files $\rightarrow \triangleq 74$

8.5.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See information \rightarrow \blacksquare 74

8.5.7 SIMATIC PDM

Function range

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.02.zz	 On the title page of the manual On the transmitter nameplate Firmware version Diagnostics → Device information → Firmware version
Release date of firmware version	01.2024	
Manufacturer ID	0x11	Manufacturer ID Diagnostics → Device information → Manufacturer ID
Device type code	0x3B	Device type Diagnostics → Device information → Device type
HART protocol revision	7	
Device revision	3	 On the transmitter nameplate Device revision Diagnostics → Device information → Device revision

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via HART protocol	Sources for obtaining device descriptions	
FieldCare	 www.endress.com → Downloads area USB stick (contact Endress+Hauser) DVD (contact Endress+Hauser) 	
DeviceCare	 www.endress.com → Downloads area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser) 	
Field Xpert SMT70Field Xpert SMT77	Use update function of handheld terminal	
AMS Device Manager (Emerson Process Management)	www.endress.com → Downloads area	
SIMATIC PDM (Siemens)	www.endress.com → Downloads area	
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal	

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Volume flow
Secondary dynamic variable (SV)	Totalizer 1
Tertiary dynamic variable (TV)	Totalizer 2
Quaternary dynamic variable (QV)	Totalizer 3

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign PV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign SV
- Expert → Communication → HART output → Output → Assign TV
- Expert → Communication → HART output → Output → Assign QV

The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Measured variables which are generally available:
 - Volume flow
 - Corrected volume flow
 - Mass flow
 - Flow velocity
 - Sound velocity
 - Temperature ²⁾
 - Pressure ²⁾
 - Methane fraction ²⁾
 - Molar mass ²⁾
 - Density
 - Dynamic viscosity ²⁾
 - Calorific value ²⁾
 - Wobbe index ²⁾
 - Energy flow
 - Electronics temperature
- Additional measured variables with the Heartbeat Verification + Monitoring application package:
 - Signal strength
 - Signal to noise ratio
 - Acceptance rate
 - Turbulence
 - Flow asymmetry ²⁾

²⁾ Visible depending on the order options or device settings

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Measured variables which are always available:
 - Volume flow
 - Mass flow
 - Flow velocity
 - Sound velocity
 - Electronics temperature
 - Totalizer 1
 - Totalizer 2
 - Totalizer 3
 - HART input
 - Current input 1³⁾
 - Current input 2 3)
 - Current input 3 ³⁾
 - Methane fraction ³⁾
 - Molar mass ³⁾
 - Density
 - Dynamic viscosity ³⁾
 - Calorific value ³⁾
 - Wobbe index 3)
 - Corrected volume flow
 - Energy flow
 - Pressure ³⁾
 - Temperature 3)
- Additional measured variables with the Heartbeat Verification + Monitoring application package:
 - Signal strength
 - Signal to noise ratio
 - Acceptance rate
 - Turbulence
 - Flow asymmetry ³⁾

76


³⁾ Visible depending on the order options or device settings

9.3 Other settings

Burst mode functionality in accordance with HART 7 Specification:

Navigation

"Expert" menu \to Communication \to HART output \to Burst configuration \to Burst configuration 1 to n



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Burst mode 1 to n	Activate the HART burst mode for burst message X.	Off On	Off
Burst command 1 to n	Select the HART command that is sent to the HART master.	 Command 1 Command 2 Command 3 Command 9 Command 33 Command 48 	Command 2

Parameter	Description	Selection / User entry	Factory setting
Burst variable 0	For HART command 9 and 33: select the HART device variable or the process variable.	Not used Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature* Pressure* Methane fraction* Molar mass* Density Dynamic viscosity* Calorific value* Wobbe index* Energy flow Electronics temperature Signal strength* Signal to noise ratio* Acceptance rate* Turbulence* Flow asymmetry Totalizer 1 Totalizer 2 Totalizer 3 Primary variable (PV) Secondary variable (PV) Secondary variable (QV) HART input Percent of range Measured current Current input 1* Current input 2 Current input 3*	Volume flow
Burst variable 1	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 2	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 3	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 4	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 5	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 6	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 7	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst trigger mode	Select the event that triggers burst message X.	ContinuousWindowRisingFallingOn change	Continuous
Burst trigger level	Enter the burst trigger value. Together with the option selected in the Burst trigger mode parameter the burst trigger value determines the time of burst message X.	Signed floating-point number	_

Parameter	Description	Selection / User entry	Factory setting
Min. update period	Enter the minimum time span between two burst commands of burst message X.	Positive integer	1 000 ms
Max. update period	Enter the maximum time span between two burst commands of burst message X.	Positive integer	2 000 ms

^{*} Visibility depends on order options or device settings

10 Commissioning

10.1 Post-mounting and post-connection check

Before commissioning the device:


- ► Make sure that the post-installation and post-connection checks have been performed successfully.
- Checklist for "Post-mounting" check → 🗎 28
- Checklist for "Post-connection check" → 🖺 43

10.2 Switching on the measuring device

- ► Switch on the device upon successful completion of the post-mounting and post-connection check.
 - After a successful startup, the local display switches automatically from the startup display to the operational display.

10.3 Setting the operating language


Factory setting: English or ordered local language



■ 31 Taking the example of the local display


10.4 Configuring the measuring device


The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.



32 Navigation to "Setup" menu using the example of the local display


The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").





10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



■ 33 Header of the operational display with tag name

- 1 Tag name

Navigation

"Setup" menu → Device tag

Parameter overview with brief description


Parameter	Description	User entry	Factory setting
Device tag	31	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Prosonic Flow

10.4.2 Setting the system units

In the System units submenu the units of all the measured values can be set.

Navigation

"Setup" menu \rightarrow System units



Mass unit	→ 🖺 83	
Velocity unit	→ 🖺 83	
Temperature unit	→ 🖺 84	
Pressure unit	→ 🖺 84	
Density unit	→ 🖺 84	
Energy unit	→ 🖺 84	
Calorific value unit	→ 🖺 84	
Energy flow unit	→ 🗎 84	

Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. Effect The selected unit applies to: Output Low flow cut off Simulation process variable	Unit choose list	Depends on country: m³/h ft³/h
Volume unit	Select volume unit.	Unit choose list	Depends on country: m³ ft³
Corrected volume flow unit	Select corrected volume flow unit. Result The selected unit applies for: Corrected volume flow	Unit choose list	Country-specific: Nm³/h Sft³/h
Corrected volume unit	Select corrected volume unit.	Unit choose list	Country-specific: Nm³ Sft³
Mass flow unit	Select mass flow unit. Result The selected unit applies to: Output Low flow cut off Simulation process variable	Unit choose list	Depends on country: • kg/h • lb/h
Mass unit	Select mass unit.	Unit choose list	Country-specific: kg lb
Velocity unit	Select velocity unit. Effect The selected unit applies for: Flow velocity Sound velocity Maximum value Minimum value	Unit choose list	Country-specific: m/s ft/s


Parameter	Description	Selection	Factory setting
Temperature unit	Select temperature unit. Effect The selected unit applies for: Temperature Maximum value Minimum value	Unit choose list	Country-specific:
Pressure unit	Select process pressure unit. Effect The selected unit applies to: Process pressure parameter (5640)	Unit choose list	Depends on country: • bar • psi
Density unit	Select density unit. Effect The selected unit applies for: Output Simulation process variable	Unit choose list	Country-specific: • kg/m³ • lb/ft³
Energy unit	Select energy unit.	Unit choose list	Country-specific: kWh Btu
Calorific value unit	Select calorific value unit. Result The selected unit applies for: Calorific value Wobbe index	Unit choose list	Country-specific: • kWh/Nm³ • Btu/Sft³
Energy flow unit	Select energy flow unit.	Unit choose list	Country-specific: • kW • Btu/h

10.4.3 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu \rightarrow I/O configuration



84

Parameter	Description	User interface / Selection / User entry	Factory setting
I/O module 1 to n terminal numbers	Shows the terminal numbers used by the I/O module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
I/O module 1 to n information	Shows information of the plugged I/O module.	Not pluggedInvalidNot configurableConfigurableHART	-
I/O module 1 to n type	Shows the I/O module type.	 Off Current output * Current input * Status input * Pulse/frequency/switch output * 	Off
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	■ No ■ Yes	No
I/O alteration code	Enter the code in order to change the I/O configuration.	Positive integer	0


^{*} Visibility depends on order options or device settings

10.4.4 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu \rightarrow Status input 1 to n




Parameter	Description	Selection / User interface / User entry	Factory setting
Assign status input	Select function for the status input.	 Off Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override 	Off
Terminal number	Shows the terminal numbers used by the status input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Active level	Define input signal level at which the assigned function is triggered.	■ High ■ Low	High
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms	50 ms

10.4.5 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation

"Setup" menu \rightarrow Current input




Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Signal mode	The measuring device is not approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	Passive Active	Active
0/4 mA value	-	Enter 4 mA value.	Signed floating-point number	0
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA (420.5 mA) 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 020 mA (020.5 mA) 	Country-specific: 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA)
Failure mode	-	Define input behavior in alarm condition.	AlarmLast valid valueDefined value	Alarm
Failure value	In the Failure mode parameter, the Defined value option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

10.4.6 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation

"Setup" menu \rightarrow Current output



Fixed current	→ 🖺 89
Damping current output	→ 🖺 89
Failure behavior current output	→ 🖺 89
Failure current	→ 🖺 89

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Signal mode	-	Select the signal mode for the current output.	PassiveActive	Active
Process variable current output		Select the process variable for the current output.	Off* Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature Pressure Methane fraction Molar mass* Density Dynamic viscosity Calorific value Wobbe index* Energy flow Signal strength Signal to noise ratio* Acceptance rate Turbulence Flow asymmetry Electronics temperature	Volume flow
Current range output	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 420 mA (420.5 mA) 020 mA (020.5 mA) Fixed value 	Depends on country: 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA)

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Lower range value output	In Current span parameter (→ ≦ 88), one of the following options is selected: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (420.5 mA) • 020 mA (020.5 mA)	Enter lower range value for the measured value range.	Signed floating-point number	Depends on country: m³/h ft³/h
Upper range value output	In Current span parameter (→ ≅ 88), one of the following options is selected: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (420.5 mA) • 020 mA (020.5 mA)	Enter upper range value for the measured value range.	Signed floating-point number	Depends on country and nominal diameter
Fixed current	The Fixed current option is selected in the Current span parameter (→ 🖺 88).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA
Damping current output	A process variable is selected in the Assign current output parameter (→ 🗎 88) and one of the following options is selected in the Current span parameter (→ 🖺 88): ■ 420 mA NE (3.820.5 mA) ■ 420 mA US (3.920.8 mA) ■ 420 mA (420.5 mA) ■ 020 mA (020.5 mA)	Enter time constant for output damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.	0.0 to 999.9 s	1.0 s
Failure behavior current output	A process variable is selected in the Assign current output parameter (→ ■ 88) and one of the following options is selected in the Current span parameter (→ ■ 88): ■ 420 mA NE (3.820.5 mA) ■ 420 mA US (3.920.8 mA) ■ 420 mA (420.5 mA) ■ 020 mA (020.5 mA)	Select output behavior in the event of a device alarm.	 Min. Max. Last valid value Actual value Fixed value 	Max.
Failure current	The Defined value option is selected in the Failure mode parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA

^{*} Visibility depends on order options or device settings

10.4.7 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Pulse/frequency/switch output




Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output



90


Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active* Passive NE 	Passive
Assign pulse output	The Pulse option is selected in Operating mode parameter.	Select process variable for pulse output.	 Off Volume flow Corrected volume flow Mass flow Energy flow 	Off
Pulse scaling	The Pulse option is selected in the Operating mode parameter (→ 🖺 90) and a process variable is selected in the Assign pulse output parameter (→ 🖺 91).	Enter quantity for measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The Pulse option is selected in the Operating mode parameter (→ 🗎 90) and a process variable is selected in the Assign pulse output parameter (→ 🗎 91).	Define time width of the output pulse.	0.05 to 2 000 ms	100 ms
Failure mode	The Pulse option is selected in the Operating mode parameter (→ 🖺 90) and a process variable is selected in the Assign pulse output parameter (→ 🖺 91).	Select output behavior in the event of a device alarm.	Actual valueNo pulses	No pulses
Invert output signal	-	Invert the output signal.	• No • Yes	No

^{*} Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output



Assign fre	quency output	→ 🖺 92
Minimum	frequency value	→ 🖺 93
Maximum	frequency value	→ 🖺 93
Measuring frequency	ງ value at minimum	→ 🖺 93
Measuring frequency	y value at maximum	→ 🖺 93
Failure mo	ode	→ 🖺 93
Failure fre	quency	→ 🖺 93
Invert out	out signal	→ 🖺 93

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active* Passive NE 	Passive
Assign frequency output	The Frequency option is selected in Operating mode parameter (→ 🖺 90).	Select process variable for frequency output.	Off Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature* Pressure* Methane fraction * Molar mass* Density Dynamic viscosity* Calorific value* Wobbe index* Energy flow Signal strength* Signal to noise ratio* Acceptance rate* Turbulence* Flow asymmetry* Electronics temperature	Off

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Minimum frequency value	The Frequency option is selected in the Operating mode parameter (→ 🗎 90) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Enter minimum frequency.	0.0 to 10 000.0 Hz	0.0 Hz
Maximum frequency value	The Frequency option is selected in the Operating mode parameter (→ 🗎 90) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Enter maximum frequency.	0.0 to 10 000.0 Hz	10 000.0 Hz
Measuring value at minimum frequency	The Frequency option is selected in the Operating mode parameter (→ 🗎 90) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Enter measured value for minimum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The Frequency option is selected in the Operating mode parameter (→ 🗎 90) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The Frequency option is selected in the Operating mode parameter (→ 🖺 90) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Select output behavior in the event of a device alarm.	Actual valueDefined value0 Hz	0 Hz
Failure frequency	In the Operating mode parameter (→ 🖺 90), the Frequency option is selected, in the Assign frequency output parameter (→ 🖺 92) a process variable is selected, and in the Failure mode parameter, the Defined value option is selected.	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	0.0 Hz
Invert output signal	-	Invert the output signal.	■ No ■ Yes	No

^{*} Visibility depends on order options or device settings

Configuring the switch output

Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/frequent 1 to n	uency/switch output	
	Operating mode	→ 🖺 94
	Terminal number	→ 🖺 94
	Signal mode	→ 🗎 94
	Switch output function	→ 🖺 95
	Assign diagnostic behavior	→ 🖺 95
	Assign limit	→ 🖺 95
	Assign flow direction check	→ 🖺 95
	Assign status	→ 🖺 95
	Switch-on value	→ 🖺 95
	Switch-off value	→ 🖺 96
	Switch-on delay	→ 🖺 96
	Switch-off delay	→ 🖺 96
	Failure mode	→ 🖺 96
	Invert output signal	→ 🖺 96

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	 Off On Diagnostic behavior Limit Flow direction check Status 	Off
Assign diagnostic behavior	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. 	The output is switched on (closed, conductive), if there is a pending diagnostic event of the assigned behavioral category.	AlarmAlarm or warningWarning	Alarm
Assign limit	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Select the variable to monitor in case the specified limit value is exceeded. If a limit value is exceeded, the output is switched on (conductive).	■ Off ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Sound velocity ■ Temperature ■ Pressure ■ Methane fraction ■ Molar mass ■ Density ■ Dynamic viscosity ■ Calorific value ■ Wobbe index ■ Energy flow ■ Signal strength ■ Signal to noise ratio ■ Acceptance rate ■ Turbulence ■ Flow asymmetry ■ Electronics temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3	Volume flow
Assign flow direction check	 The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. 	Select process variable for flow direction monitoring.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Energy flow 	Volume flow
Assign status	 The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. 	Select the device function for which to report the status. If the function is triggered, the output is closed and conductive (standard configuration).	 Off Low flow cut off Product identification * 	Low flow cut off
Switch-on value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter limit value for switch-on point (process variable > switch-on value = closed, conductive).	Signed floating-point number	Depends on country

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter limit value for switch-off point (process variable < switch-off value = open, nonconductive).	Signed floating-point number	Depends on country
Switch-on delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter a delay before the output is switched on.	0.0 to 100.0 s	0.0 s
Switch-off delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter a delay before the output is switched off.	0.0 to 100.0 s	0.0 s
Failure mode	-	Select output behavior in the event of a device alarm.	Actual statusOpenClosed	Open
Invert output signal	_	Invert the output signal.	■ No ■ Yes	No

Visibility depends on order options or device settings

10.4.8 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu \rightarrow Relay output 1 to n

▶ Relay output 1 to n	
Terminal number	→ 🗎 97
Relay output function	→ 🖺 97
Assign flow direction check	→ 🖺 97
Assign limit	→ 🗎 97
Assign diagnostic behavior	→ 🖺 98
Assign status	→ 🖺 98
Switch-off value	→ 🖺 98
Switch-off delay	→ 🗎 98

Switch-on value	→ 🖺 98
Switch-on delay	→ 🖺 98
Failure mode	→ 🖺 98
Switch state	→ 🖺 98
Powerless relay status	→ 🖺 98

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the relay output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Relay output function	-	Select the function for the relay output.	 Closed Open Diagnostic behavior Limit Flow direction check Status 	Closed
Assign flow direction check	The Flow direction check option is selected in the Relay output function parameter.	Select process variable for flow direction monitoring.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Energy flow 	Volume flow
Assign limit	The Limit option is selected in the Relay output function parameter.	Select the variable to monitor in case the specified limit value is exceeded. If a limit value is exceeded, the output is switched on (conductive).	 Off Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature* Pressure* Methane fraction* Molar mass* Density Dynamic viscosity* Calorific value* Wobbe index* Energy flow Signal strength* Signal strength* Signal to noise ratio* Acceptance rate* Turbulence* Flow asymmetry Electronics temperature Totalizer 1 Totalizer 3 	Volume flow

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Assign diagnostic behavior	In the Relay output function parameter, the Diagnostic behavior option is selected.	The output is switched on (closed, conductive), if there is a pending diagnostic event of the assigned behavioral category.	AlarmAlarm or warningWarning	Alarm
Assign status	In the Relay output function parameter, the Digital Output option is selected.	Select the device function for which to display the status. If the switch on point is reached, the output is switched on (closed, conductive).	 Off Low flow cut off Product identification * 	Off
Switch-off value	The Limit option is selected in the Relay output function parameter.	Enter limit value for switch-off point (process variable < switch-off value = open, nonconductive).	Signed floating-point number	0 m ³ /h
Switch-off delay	In the Relay output function parameter, the Limit option is selected.	Enter a delay before the output is switched off.	0.0 to 100.0 s	0.0 s
Switch-on value	The Limit option is selected in the Relay output function parameter.	Enter measured value for the switch-on point.	Signed floating-point number	0 m ³ /h
Switch-on delay	In the Relay output function parameter, the Limit option is selected.	Enter a delay before the output is switched on.	0.0 to 100.0 s	0.0 s
Failure mode	-	Select output behavior in the event of a device alarm.	Actual statusOpenClosed	Open
Switch state	-	Indicates the current switch state of the output.	OpenClosed	-
Powerless relay status	-	Select quiescent state for relay.	OpenClosed	Open

Visibility depends on order options or device settings

10.4.9 Configuring the double pulse output

The **Double pulse output** submenu guides the user systematically through all the parameters that have to be set for configuring the double pulse output.

Navigation

"Setup" menu \rightarrow Double pulse output

► Double pulse output	
Signal mode	→ 🖺 99
Master terminal number	→ 🖺 99
Assign pulse output	→ 🖺 99
Measuring mode	→ 🗎 99
Value per pulse	→ 🖺 99

Pulse width	→ 🖺 99
Failure mode	→ 🖺 99
Invert output signal	→ 🖺 99

Parameter	Description	Selection / User interface / User entry	Factory setting
Signal mode	Select the signal mode for the double pulse output.	 Passive Active* Passive NE 	Passive
Master terminal number	Shows the terminal numbers used by the master of the double pulse output module.	Not used24-25 (I/O 2)22-23 (I/O 3)	-
Assign pulse output	Select process variable for pulse output.	OffVolume flowCorrected volume flowMass flowEnergy flow	Off
Measuring mode	Select measuring mode for pulse output.	 Forward flow Forward/Reverse flow Reverse flow Reverse flow compensation 	Forward flow
Value per pulse	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	Define time width of the output pulse.	0.5 to 2 000 ms	0.5 ms
Failure mode	Select output behavior in the event of a device alarm.	Actual valueNo pulses	No pulses
Invert output signal	Invert the output signal.	No Yes	No


Visibility depends on order options or device settings

10.4.10 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu \rightarrow Display



Value 2 display	→ 🖺 100
Value 3 display	→ 🖺 101
0% bargraph value 3	→ 🖺 101
100% bargraph value 3	→ 🖺 101
Value 4 display	→ 🖺 101

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	Mass flow Flow velocity Sound velocity Volume flow Corrected volume flow Density Dynamic viscosity Calorific value Wobbe index Energy flow Signal strength Signal to noise ratio Acceptance rate Turbulence Flow asymmetry Electronics temperature Temperature Temperature Methane fraction Molar mass Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 3 Current output 4	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0 % value for bar graph display.	Signed floating-point number	Country-specific
100% bargraph value 1	A local display is provided.	Enter 100 % value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🖺 100)	None


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0 % value for bar graph display.	Signed floating-point number	Country-specific
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100 % value for bar graph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None

Visibility depends on order options or device settings

10.4.11 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.


Structure of the wizard



■ 34 "Low flow cutoff" wizard in the "Setup" menu

Navigation

"Setup" menu \rightarrow Low flow cut off



Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Energy flow 	Off
On value low flow cutoff	A process variable is selected in the Assign process variable parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter off value for low flow cut off.	0 to 100.0 %	50 %

10.4.12 Gas analysis configuration

The **"Gas analysis" wizard** guides the user systematically through all the parameters that have to be set for configuring the gas analysis.

Navigation

"Setup" menu → Gas analysis



102

Reference density	→ 🖺 103
Calorific value	→ 🖺 103


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Select gas type	_	Select measured gas type.	 Single gas* Gas mixture* Coal gas/biogas* Natural gas - standardized calculation* Natural gas - using sound velocity* User-specific gas 	User-specific gas
Pressure compensation	-	Select pressure compensation type.	 Fixed value External value * Internal measured value * Current input 1 * Current input 2 * Current input 3 * 	Fixed value
Fixed value	The Fixed value option is selected in Pressure compensation parameter.	Enter a fixed value for the process pressure. The pressure is 0 bar(g) = 1.01325 bar under standard conditions.	0 to 250 bar	5 bar
Temperature compensation	The Calculated value option is selected in the Density source parameter.	Select temperature mode for temperature compensation.	 Fixed value Internal measured value* External value * Current input 1* Current input 2* Current input 3* 	Fixed value
Fixed value	The Fixed value option is selected in Temperature compensation parameter.	Enter a fixed value for the process temperature.	−50 to 550 °C	20℃
Reference density	-	Enter fixed value for reference density.	0.01 to 100 kg/m ³	1 kg/m³
Calorific value	-	Enter gross calorific value to calculate the energy flow.	0 to 1000 MJ/Nm ³	40 MJ/Nm³

 $^{^{\}star}$ Visibility depends on order options or device settings

10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.


Navigation to the "Advanced setup" submenu



The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

Navigation

"Setup" menu → Advanced setup



► WLAN settings	→ 🖺 110
► Configuration backup	→ 🖺 112
► Administration	→ 🖺 113

10.5.1 Using the parameter to enter the access code

Navigation

"Setup" menu → Advanced setup

Parameter overview with brief description

Parameter	Description	User entry
Enter access code		Max. 16-digit character string comprising numbers, letters and special characters

10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment



Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Installation direction	Select sign of flow direction.	Forward flowReverse flow	Forward flow

10.5.3 Configuring the totalizer

In the "Totalizer 1 to n" submenu the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable 1 to n	-	Select process variable for totalizer.	 Off Volume flow Corrected volume flow Mass flow Energy flow 	Volume flow
Process variable unit 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxtimes 106$) of the Totalizer 1 to n submenu.	Select the unit for the process variable of the totalizer.	Unit choose list	Depends on country: • m³ • ft³
Totalizer 1 to n operation mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxminus 106$) of the Totalizer 1 to n submenu.	Select totalizer operation mode, e.g. only totalize forward flow or only totalize reverse flow.	NetForwardReverse	Net
Totalizer 1 to n failure behavior	A process variable is selected in the Assign process variable parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Select totalizer behavior in the event of a device alarm.	HoldContinueLast valid value + continue	Hold

10.5.4 Carrying out additional display configurations

In the $\bf Display$ submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display			
	Format display		→ 🖺 108
	Value 1 display		→ 🖺 108
	0% bargraph value 1		→ 🖺 108
	100% bargraph value 1		→ 🖺 108
	Decimal places 1		→ 🖺 108
	Value 2 display		→ 🖺 108
	Decimal places 2		→ 🖺 108
	Value 3 display		→ 🖺 108
	0% bargraph value 3		→ 🗎 109
	100% bargraph value 3		→ 🗎 109
	Decimal places 3		→ 🗎 109
	Value 4 display		→ 🖺 109
	Decimal places 4		→ 🖺 109
	Display language		→ 🖺 109
	Display interval		→ 🖺 109
	Display damping		→ 🖺 109
	Header		→ 🖺 109
	Header text		→ 🖺 109
	Separator		→ 🖺 110
	Backlight		→ 🖺 110
		=	

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	Mass flow Flow velocity Sound velocity Volume flow Corrected volume flow Density Dynamic viscosity Calorific value Wobbe index Energy flow Signal strength Signal to noise ratio Acceptance rate Turbulence Flow asymmetry Electronics temperature Temperature Temperature Pressure Methane fraction Molar mass Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 3 Current output 4	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0 % value for bar graph display.	Signed floating-point number	Country-specific
100% bargraph value 1	A local display is provided.	Enter 100 % value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXXX	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 🖺 100)	None

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0 % value for bar graph display.	Signed floating-point number	Country-specific
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100 % value for bar graph display.	Signed floating-point number	0
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	XX.XX.XXX.XXXX.XXX	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see Value 1 display parameter (→ 100)	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXXX	x.xx
Display language	A local display is provided.	Set display language.	 English Deutsch Français Español Italiano Nederlands Portuguesa Polski русский язык (Russian) Svenska Türkçe 中文 (Chinese) 日本語 (Japanese) 한국어 (Korean) tiếng Việt (Vietnamese) čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	Device tagFree text	Device tag
Header text	The Free text option is selected in the Header parameter.	Enter display header text.	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	. (point), (comma)	. (point)
Backlight	One of the following conditions is met: Order code for "Display; operation", option F "4-line, illum.; touch control" Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN"	Switch the local display backlight on and off.	DisableEnable	Enable

^{*} Visibility depends on order options or device settings

10.5.5 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow WLAN settings

▶ WLAN settings	S	
	WLAN	→ 🖺 111
	WLAN mode	→ 🖺 111
	SSID name	→ 🖺 111
	Network security	→ 🖺 111
	Security identification	→ 🖺 111
	User name	→ 🖺 111
	WLAN password	→ 🖺 111
	WLAN IP address	→ 🖺 111
	WLAN MAC address	→ 🖺 111
	WLAN passphrase	→ 🖺 111
	Assign SSID name	→ 🖺 111
	SSID name	→ 🖺 111
	Connection state	→ 🖺 111
	Received signal strength	→ 🖺 111

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN	-	Switch WLAN on and off.	DisableEnable	Enable
WLAN mode	-	Select WLAN mode.	WLAN access pointWLAN Client	WLAN access point
SSID name	The client is activated.	Enter the user-defined SSID name (max. 32 characters).	-	-
Network security	-	Select the security type of the WLAN network.	 Unsecured WPA2-PSK EAP-PEAP with MSCHAPv2* EAP-PEAP MSCHAPv2 no server authentic.* EAP-TLS* 	WPA2-PSK
Security identification	-	Select security settings and download these settings via menu Data management > Security > WLAN.	Trusted issuer certificateDevice certificateDevice private key	-
User name	-	Enter user name.	_	_
WLAN password	-	Enter WLAN password.	_	_
WLAN IP address	-	Enter IP address of the WLAN interface of the device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
WLAN MAC address	-	Enter MAC address of the WLAN interface of the device.	Unique 12-digit character string comprising letters and numbers	Each measuring device is given an individual address.
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters). The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user-defined name.	Device tagUser-defined	User-defined
SSID name	 The User-defined option is selected in the Assign SSID name parameter. The WLAN access point option is selected in the WLAN mode parameter. 	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Prosonic_Flow_5 00_A802000)
Connection state	-	Displays the connection status.	ConnectedNot connected	Not connected
Received signal strength	-	Shows the received signal strength.	LowMediumHigh	High


^{*} Visibility depends on order options or device settings

10.5.6 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration. The device configuration is managed via the **Configuration management** parameter.

Navigation

"Setup" menu → Advanced setup → Configuration backup



Parameter overview with brief description

Parameter	Description	User interface / Selection	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Last backup	Shows when the last data backup was saved to HistoROM backup.	Days (d), hours (h), minutes (m) and seconds (s)	-
Configuration management	Select action for managing the device data in the HistoROM backup.	 Cancel Execute backup Restore* Compare* Clear backup data 	Cancel
Backup state	Shows the current status of data saving or restoring.	 None Backup in progress Restoring in progress Delete in progress Compare in progress Restoring failed Backup failed 	None
Comparison result	Comparison of current device data with HistoROM backup.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible 	Check not done

Visibility depends on order options or device settings

Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.


- HistoROM backup
 - A HistoROM is a "non-volatile" device memory in the form of an EEPROM.
- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.5.7 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu → Advanced setup → Administration




Using the parameter to define the access code

Complete this wizard to specify an access code for the Maintenance role.

Navigation

"Setup" menu → Advanced setup → Administration → Define access code



Parameter overview with brief description

Parameter	Description	User entry
Define access code	Specify an access code that is required to obtain the access rights for the Maintenance role.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the access code entered for the Maintenance role.	Max. 16-digit character string comprising numbers, letters and special characters

Using the parameter to reset the access code

Navigation

 $"Setup"\:menu \to Advanced\:setup \to Administration \to Reset\:access\:code$

► Reset access code	
Operating time	→ 🗎 114
Reset access code	→ 🖺 114

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Reset access code	Enter the code provided by Endress+Hauser Technical Support to reset the Maintenance code. For a reset code, contact your Endress+Hauser service organization.	Character string comprising numbers, letters and special characters	0x00
	The reset code can only be entered via: Web browser DeviceCare, FieldCare (via CDI-RJ45 service interface) Fieldbus		

Using the parameter to reset the device

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	 Cancel To delivery settings Restart device Restore S-DAT backup * 	Cancel

Visibility depends on order options or device settings

10.6 Simulation

Via the **Simulation** submenu, it is possible to simulate various process variables in the process and the device alarm mode and verify downstream signal chains (switching valves or closed-control loops). The simulation can be performed without a real measurement (no flow of medium through the device).

Navigation

"Diagnostics" menu \rightarrow Simulation

▶ Simulation	
Assign simulation process variable	→ 🖺 116
Process variable value	→ 🗎 116
Current input 1 to n simulation	→ 🖺 117
Value current input 1 to n	→ 🖺 117
Status input 1 to n simulation	→ 🖺 117
Input signal level 1 to n	→ 🖺 117
Current output 1 to n simulation	→ 🖺 116
Current output value	→ 🖺 116
Frequency output 1 to n simulation	→ 🖺 116
Frequency output 1 to n value	→ 🖺 116
Pulse output simulation 1 to n	→ 🖺 116
Pulse value 1 to n	→ 🖺 116
Switch output simulation 1 to n	→ 🖺 116
Switch state 1 to n	→ 🗎 116
Relay output 1 to n simulation	→ 🖺 116
Switch state 1 to n	→ 🖺 117
Pulse output simulation	→ 🖺 117
Pulse value	→ 🖺 117
Device alarm simulation	→ 🖺 117

 $\begin{array}{c} \text{Diagnostic event category} \\ \\ \rightarrow & \\ \blacksquare \ 117 \\ \\ \end{array}$ $\begin{array}{c} \Rightarrow & \\ \blacksquare \ 117 \\ \\ \end{array}$

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	Off Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature* Pressure* Methane fraction * Molar mass* Density Dynamic viscosity* Calorific value* Wobbe index* Energy flow	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter (→ 🖺 116).	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	Off On	Off
Current output value	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA	3.59 mA
Frequency output 1 to n simulation	In the Operating mode parameter, the Frequency option is selected.	Switch the simulation of the frequency output on and off.	• Off • On	Off
Frequency output 1 to n value	In the Frequency simulation 1 to n parameter, the On option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz	0.0 Hz
Pulse output simulation 1 to n	In the Operating mode parameter, the Pulse option is selected.	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (> 91) defines the pulse width of the pulses output.	OffFixed valueDown-counting value	Off
Pulse value 1 to n	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation 1 to n	In the Operating mode parameter, the Switch option is selected.	Switch the simulation of the switch output on and off.	Off On	Off
Switch state 1 to n	-	Select the status of the status output for the simulation.	OpenClosed	Open
Relay output 1 to n simulation	-	Switch simulation of the relay output on and off.	Off On	Off

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Switch state 1 to n	The On option is selected in the Switch output simulation 1 to n parameter parameter.	Select status of the relay output for the simulation.	OpenClosed	Open
Pulse output simulation	_	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	OffFixed valueDown-counting value	Off
Pulse value	In the Pulse output simulation parameter, the Down-counting value option is selected.	Set and switch off the pulse output simulation.	0 to 65 535	0
Device alarm simulation	-	Switch the device alarm on and off.	Off On	Off
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off
Current input 1 to n simulation	-	Switch simulation of the current input on and off.	Off On	Off
Value current input 1 to n	In the Current input 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	0 to 22.5 mA	0 mA
Status input 1 to n simulation	-	Switch simulation of the status input on and off.	Off On	Off
Input signal level 1 to n	In the Status input simulation parameter, the On option is selected.	Select the signal level for the simulation of the status input.	HighLow	High

^{*} Visibility depends on order options or device settings

10.7 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code → 117
- Protect access to measuring device via write protection switch \rightarrow 🗎 119

10.7.1 Write protection via access code

The effects of the user-specific access code are as follows:


- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via the local display

- 1. Navigate to the **Define access code** parameter ($\Rightarrow \triangleq 114$).
- 2. Maximum of 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the **Confirm access code** parameter ($\rightarrow \implies 114$) to confirm.
 - The symbol appears in front of all write-protected parameters.
- \blacksquare Disabling parameter write protection via access code \rightarrow \blacksquare 59.
 - If the access code is lost: Resetting the access code $\rightarrow \triangleq 119$.
 - The user role with which the user is currently logged in is displayed in **Access status** parameter.
 - Navigation path: Operation → Access status
 - User roles and their access rights $\rightarrow \triangleq 59$
- The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view.
- The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the web browser

- 1. Navigate to the **Define access code** parameter ($\Rightarrow \triangleq 114$).
- 2. Define a 16-digit (max.) numeric code as the access code.
- 3. Enter the access code again in the **Confirm access code** parameter ($\rightarrow \implies 114$) to confirm.
 - ► The web browser switches to the login page.
- ☐ In the Disabling parameter write protection via access code \rightarrow \bigcirc 59.

 - The **Access status** parameter shows which user role the user is currently logged in with
 - Navigation path: Operation → Access status

If no action is performed for 10 minutes, the web browser automatically returns to the login page.

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

- You can only obtain a reset code from your local Endress+Hauser service organization.
 The code must be calculated explicitly for every device.
- 1. Note down the serial number of the device.
- 2. Read off the **Operating time** parameter.
- 3. Contact the local Endress+Hauser service organization and tell them the serial number and the operating time.
 - └ Get the calculated reset code.
- 4. Enter the reset code in the **Reset access code** parameter ($\rightarrow \equiv 114$).
 - The access code has been reset to the factory setting **0000**. It can be redefined $\rightarrow \boxminus 118$.
- For IT security reasons, the calculated reset code is only valid for 96 hours from the specified operating time and for the specific serial number. If you cannot return to the device within 96 hours, you should either increase the operating time you read out by a few days or switch off the device.

10.7.2 Write protection via write protection switch


Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display"** parameter.

The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via HART protocol

Proline 500 - digital

Enabling/disabling write protection




A002967

- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.

4. Enable or disable write protection:

Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection/to the **OFF** position (factory setting) disables hardware write protection.

In the **Locking status** parameter, the **Hardware locked** option is displayed $\rightarrow \boxminus 121$. When hardware write protection is active, the $\boxdot 121$ symbol appears in the header of the measured value display and in the navigation view in front of the parameters.



A002942

- 5. Insert the display module.
- 6. Close the housing cover.

7. **AWARNING**

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)

Tighten the securing screws.

Operation 11

11.1 Reading off the device locking status

Device active write protection: Locking status parameter

Operation → Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access authorization displayed in the Access status parameter applies → 🖺 59. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
SIL locked	The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language



Petailed information:

- To configure the operating language \rightarrow \triangleq 80
- For information on the operating languages supported by the measuring device → 🖺 189

Configuring the display 11.3

Detailed information:


- On the basic settings for the local display $\rightarrow = 99$
- On the advanced settings for the local display $\rightarrow \triangleq 107$


11.4 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu → Measured values






11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables



Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Volume flow	-	Displays the volume flow that is currently measured. Dependency The unit is taken from: Volume flow unit parameter (→ 🖺 83)	Signed floating-point number
Mass flow	-	Displays the mass flow that is currently calculated. Dependency The unit is taken from the Mass flow unit parameter (→ 🖺 83).	Signed floating-point number
Sound velocity	_	Displays the sound velocity that is currently measured. Dependency The unit is taken from the Velocity unit parameter.	Signed floating-point number
Pressure	For the following order code: "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated" The software options currently enabled are displayed in the Software option overview parameter.	Displays the pressure that is currently measured. Dependency The unit is taken from: Pressure unit parameter	Signed floating-point number
Energy flow	-	Displays the energy flow that is currently calculated. Dependency The unit is taken from: Energy flow unit parameter (→ 🖺 84)	Signed floating-point number
Flow velocity	-	Displays the flow velocity that is currently measured. Dependency The unit is taken from: Velocity unit parameter	Signed floating-point number
Temperature	For the following order codes: "Measuring tube; Transducer; Sensor version", option AB "316L; Titanium Gr. 2; temperature measurement integrated" "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated" The software options currently enabled are displayed in the Software option overview	Displays the temperature that is currently measured. Dependency The unit is taken from: Temperature unit parameter	Signed floating-point number
Wobbe index	parameter. For the following order code: "Application package", option EF "Advanced gas analysis" The software options currently enabled are displayed in the Software option overview parameter.	Displays the Wobbe index that is currently calculated. Dependency The unit is taken from: Calorific value unit parameter (→ 🖺 84)	Signed floating-point number

Parameter	Prerequisite	Description	User interface
Corrected volume flow	-	Displays the corrected volume flow that is currently measured. Dependency	Signed floating-point number
		The unit is taken from: Corrected volume flow unit parameter	
Methane fraction	For the following order code: "Application package", option EF "Advanced gas analysis"	Shows the methane fraction of the dry gas currently calculated.	Signed floating-point number
	The software options currently enabled are displayed in the Software option overview parameter.		
Molar mass	For the following order code: "Application package", option EF "Advanced gas analysis"	Displays the molar mass in g/mol that is currently calculated.	Signed floating-point number
	The software options currently enabled are displayed in the Software option overview parameter.		
Density	-	Displays the density that is currently calculated.	Signed floating-point number
		Dependency The unit is taken from: Density unit parameter	
Dynamic viscosity	For the following order code: "Application package", option EF	Displays the dynamic viscosity that is currently calculated.	Signed floating-point number
	"Advanced gas analysis"	Dependency	
	The software options currently enabled are displayed in the Software option overview parameter.	The unit is taken from the Dynamic viscosity unit parameter.	
Calorific value	For the following order code: "Application package", option EF "Advanced gas analysis"	Displays the calorific value that is currently calculated.	Signed floating-point number
	The software options currently enabled are displayed in the Software option overview parameter.	Dependency The unit is taken from the Calorific value unit parameter.	

11.4.2 System values

The **System values** submenu contains all the parameters needed to display the current measured values for every system value.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow System values

► System values	
Signal strength	→ 🖺 125
Acceptance rate	→ 🖺 125

Signal to noise ratio	→ 🖺 125
Turbulence	→ 🖺 125

Parameter overview with brief description


Parameter	Description	User interface
Signal strength	Displays the current signal strength (0 to 100 dB). Assessment of the signal strength: < 10 dB: bad > 90 dB: very good 	Signed floating-point number
Acceptance rate	Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted.	0 to 100 %
Signal to noise ratio	Displays the current signal to noise ratio (0 to 100 dB). Assessment of the signal-to-noise ratio: < 20 dB: bad > 50 dB: very good	Signed floating-point number
Turbulence	Displays the current turbulence.	Signed floating-point number

11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values




Input values of current input

The Current input 1 to n submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Current input 1 to n



Parameter overview with brief description

Parameter	Description	User interface
Measured values 1 to n	Displays the current input value.	Signed floating-point number
	Dependency The unit is taken from the Pressure unit parameter	
Measured current 1 to n	Displays the current value of the current input.	0 to 22.5 mA

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Status input 1 to n



Parameter overview with brief description


Parameter	Description	User interface
Value status input	Shows the current input signal level.	■ High ■ Low

11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values




Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu → Measured values → Output values → Value current output 1 to n



Parameter overview with brief description


Parameter	Description	User interface
Output current	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Pulse/frequency/switch output 1 to n



Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Output frequency	In the Operating mode parameter, the Frequency option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output	The Pulse option is selected in the Operating mode parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch state	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	■ Open ■ Closed

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Relay output 1 to n



Parameter overview with brief description


Parameter	Description	User interface
Switch state	Indicates the current switch state of the output.	OpenClosed
Switch cycles	Shows number of all performed switch cycles.	Positive integer
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer

Output values for double pulse output

The **Double pulse output** submenu contains all the parameters needed to display the current measured values for every double pulse output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Double pulse output



Parameter overview with brief description

Parameter	Description	User interface
Pulse output	Shows the currently output pulse frequency.	Positive floating-point number


11.4.5 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

128

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer



Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer 1 to n value	One of the following options is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu: Volume flow Corrected volume flow Mass flow Energy flow	Displays the current totalizer counter value.	Signed floating-point number
Totalizer 1 to n overflow	One of the following options is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu: Volume flow Corrected volume flow Mass flow Energy flow	Displays the current totalizer overflow.	Integer with sign

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (→ 🖺 80)
- Advanced settings using the Advanced setup submenu (→ 🗎 104)

11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu → Totalizer handling



Totalizer value 1 to n \rightarrow 🗎 130

Reset all totalizers \rightarrow 🖺 130

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu.	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize Hold 	Totalize
Preset value 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Specify start value for totalizer. Dependency The unit of the selected process variable is defined in the Unit totalizer parameter (→ 106) for the totalizer.	Signed floating-point number	Depends on country: • 0 m³ • 0 ft³
Totalizer value	One of the following options is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu: Volume flow Corrected volume flow Mass flow Energy flow	Displays the current totalizer counter value.	Signed floating-point number	-
Reset all totalizers	_	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

11.6.1 Function scope of "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold ¹⁾	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize 1)	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

1) Visible depending on the order options or device settings

130

11.6.2 Function range of "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the previously aggregated flow values.

11.7 Displaying the measured value history

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.




Data logging is also available via:

- Web browser

Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Measured value trend for each logging channel displayed in the form of a chart



A003435

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.
- If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

▶ Data logging	
Assign channel 1	→ 🖺 132
Assign channel 2	→ 🖺 132
Assign channel 3	→ 🖺 132
Assign channel 4	→ 🖺 133
Logging interval	→ 🖺 133
Clear logging data	→ 🗎 133

Data logging	→ 🖺 133
Logging delay	→ 🖺 133
Data logging control	→ 🗎 133
Data logging status	→ 🖺 133
Entire logging duration	→ 🗎 133

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	 Off Volume flow Corrected volume flow Mass flow Flow velocity Sound velocity Temperature Pressure* Methane fraction* Molar mass* Density Current output 2* Current output 4* Dynamic viscosity Calorific value* Wobbe index* Energy flow Signal strength* Signal to noise ratio* Acceptance rate Turbulence* Flow asymmetry Electronics temperature Current output 1 	Off
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter (→ 🖺 132)	Off
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter (→ 🖺 132)	Off

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see Assign channel 1 parameter (→ 132)	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3 600.0 s	1.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data	Cancel
Data logging	-	Select the type of data logging.	OverwritingNot overwriting	Overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	NoneDelete + startStop	None
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	DoneDelay activeActiveStopped	Done
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating- point number	0 s

^{*} Visibility depends on order options or device settings

12 Diagnosis and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Remedial action
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display dark and no output signals	Supply voltage does not match the voltage specified on the nameplate.	Apply the correct supply voltage $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Ensure electrical contact between the cable and the terminal.
Local display dark and no output signals	 Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly. 	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.Main electronics module is defective.	Order spare part → 🗎 163.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display cannot be read, but signal output is within the valid range	Display is set too bright or too dark.	■ Set the display brighter by simultaneously pressing
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🖺 163.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures → 🖺 148
Text on local display appears in a language that cannot be understood.	The selected operating language cannot be understood.	1. Press □ + ₺ for 2 s ("home position"). 2. Press □. 3. Configure the required language in the Display language parameter (→ 🖺 109).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part → ■ 163.

For output signals

Error	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🖺 163.
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	Main electronics module is defective. I/O electronics module is defective.	Order spare part → 🗎 163.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parameter configuration error	Check and adjust parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access

Fault	Possible causes	Remedial action
Write access to parameters is not possible.	Hardware write protection is enabled.	Set the write protection switch on the main electronics module to the OFF position → 🖺 119.
Write access to parameters is not possible.	Current user role has limited access authorization.	 Check user role → □ 59. Enter correct customer-specific access code → □ 59.
Connection via HART protocol is not possible.	Missing or incorrectly installed communication resistor	Install the communication resistor (250 Ω) correctly. Observe the maximum load $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Connection via HART protocol is not possible.	Commubox Incorrectly connected. Incorrectly configured. Driver is not installed correctly. The USB port on the PC is incorrectly configured.	Refer to the documentation on Commubox FXA195 HART: Technical Information TI00404F
Unable to connect to the web server.	Web server is disabled.	Using the "FieldCare" or "DeviceCare" operating tool, check whether the web server of the measuring device is enabled, and enable it if necessary → 🖺 66.
	The Ethernet interface on the PC is incorrectly configured.	 Check the properties of the Internet protocol (TCP/IP)→ 62. Check the network settings with the IT manager.
Unable to connect to the web server.	The IP address on the PC is incorrectly configured.	Check the IP address: 192.168.1.212 → 🗎 62
Unable to connect to the web server.	WLAN access data are incorrect.	 Check WLAN network status. Log on to the device again using WLAN access data. Check that WLAN is enabled on the measuring device and operating unit →
	WLAN communication is disabled.	-
Unable to connect to web server, FieldCare or DeviceCare.	WLAN network is not available.	 Check if WLAN reception is present: LED on display module is lit blue. Check if WLAN connection is enabled: LED on display module flashes blue. Switch on instrument function.
Network connection not present or unstable	WLAN network is weak.	 Operating unit outside reception range: Check network status on operating unit. To improve network performance, use an external WLAN antenna.
	Parallel WLAN and Ethernet communication	 Check network settings. Temporarily enable only the WLAN as an interface.
Web browser frozen and operation no longer possible	Data transfer is active.	Wait until data transfer or current action is finished.
	Connection lost	 Check cable connection and power supply. Refresh the web browser and restart if necessary.
Display of web browser content is difficult to read or incomplete.	Web browser version used is not optimal.	 ▶ Use correct web browser version → 🖺 61. ▶ Empty the web browser cache. ▶ Restart the web browser.
	Unsuitable view settings.	Change the font size/display ratio of the web browser.
Incomplete or no display of content in the web browser	JavaScript is not enabled.JavaScript cannot be enabled.	 Enable JavaScript. Enter http://XXX.XXX.X.X.XX/servlet/basic.html as the IP address.


Fault	Possible causes	Remedial action
Operation with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000) is not possible.	Firewall of the PC or network is blocking communication.	Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.
Flashing the firmware with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000 or TFTP ports) is not possible.	Firewall of the PC or network is blocking communication.	Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.

12.2 Diagnostic information via LEDs

12.2.1 Transmitter

Proline 500 - digital

Different LEDs in the transmitter provide information on the device status.



A002968

- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active
- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.


LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is OK.
2	Device status (normal	Off	Firmware error
	operation)	Green	Device status is OK.
		Flashing green	Device is not configured.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red/green	The device restarts.
2	Device status (during	Flashes red slowly	If > 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	_	-

LED		Color	Meaning
4	Communication	Off	Communication not active.
		White	Communication active.
5	Service interface (CDI)	Off	Not connected or no connection established.
		Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

12.2.2 Sensor connection housing

Proline 500 - digital

Various light emitting diodes (LED) on the ISEM electronics unit (intelligent sensor electronics module) in the sensor connection housing provide information about the device status.



A002969


- 1 Communication
- 2 Device status
- 3 Supply voltage

LED		Color	Meaning
1	Communication	White	Communication active.
2 Device status (normal	Red	Error	
operation)		Flashing red	Warning
2	Device status (during	Flashes red slowly	If > 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
 - Via parameter → 🖺 153

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in service mode (e.g. during a simulation).
s	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
М	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior

Symbol	Meaning
8	Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Δ	 Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Operating key	Meaning
(+)	Plus key In menu, submenu Opens the message about the remedial measures.
E	Enter key In menu, submenu Opens the operating menu.

12.3.2 Calling up remedial measures



A0029431-EN

- 35 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures
- 1. The user is in the diagnostic message.
 - Press ± (① symbol).
 - The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \Box .
 - ► The message about the remedial measures opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

- 1. Press E.
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

12.4 Diagnostic information in the web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
 - Via parameter → 🖺 153

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
8	Failure A device error has occurred. The measured value is no longer valid.
	Function check The device is in service mode (e.g. during a simulation).
À	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
&	Maintenance required Maintenance is required. The measured value remains valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options


Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



- 1 Status area with status signal → \(\bigsim 139 \)
- 2 Diagnostic information \rightarrow $\stackrel{\triangle}{=}$ 140
- 3 Remedial measures with service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
 - Via parameter $\rightarrow \implies 153$
 - Via submenu \rightarrow 🗎 153

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ► A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior



■ 36 Using the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (Event list submenu) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic event category** submenu.

Expert \rightarrow Communication \rightarrow Diagnostic event category

Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning	
A0013956	Failure A device error has occurred. The measured value is no longer valid.	
C	Function check The device is in service mode (e.g. during a simulation).	
S	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)	

Symbol	Meaning
A0013957	Maintenance required Maintenance is required. The measured value remains valid.
A0023076	Has no effect on the condensed status.

12.7 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- Not all the diagnostics information is available for the device.

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of	sensor			
019	Device initialization active	Device initialization in progress, please wait	S	Warning 1)
022	Temperature sensor defective	Replace sensor electronic module (ISEM)	F	Alarm
082	Data storage inconsistent	Check module connections	F	Alarm
083	Memory content inconsistent	Restart device Restore S-DAT data Replace S-DAT	F	Alarm
104	Sensor signal path 1 to n	Check process conditions Clean or replace transducers Replace sensor electronic module (ISEM)	F	Alarm
105	Downstream transducer path 1 to n defective	Check connection to the downstream transducer Replace downstream transducer	F	Alarm
106	Upstream transducer path 1 to n defective	Check connection to the upstream transducer Replace upstream transducer	F	Alarm
124	Relative signal strength	Check process conditions Clean or replace transducers Replace sensor electronic module (ISEM)	М	Warning ¹⁾
125	Relative sound velocity	Check process conditions Clean or replace transducers Replace sensor electronic module (ISEM)	М	Warning 1)
160	Signal path switched off	Contact service	M	Warning 1)
170	Pressure cell connection defective	Check plug connections Replace pressure cell	F	Alarm
171	Ambient temperature too low	Increase ambient temperature	S	Warning
172	Ambient temperature too high	Reduce ambient temperature	S	Warning
173	Pressure cell range exceeded	Check process conditions Adapt process pressure	S	Warning
174	Pressure cell electronics defective	Replace pressure cell	F	Alarm
Diagnostic of electronic				
201	Electronics faulty	Restart device Replace electronics	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
242	Firmware incompatible	Check firmware version Flash or replace electronic module	F	Alarm
252	Module incompatible	Check electronic modules Check if correct modules are available (e.g. NEx, Ex) Replace electronic modules	F	Alarm
262	Module connection interrupted	Check or replace connection cable between sensor electronic module (ISEM) and main electronics Check or replace ISEM or main electronics	F	Alarm
270	Main electronics defective	Restart device Replace main electronic module	F	Alarm
271	Main electronics faulty	Restart device Replace main electronic module	F	Alarm
272	Main electronics faulty	Restart device	F	Alarm
273	Main electronics defective	Pay attention to display emergency operation Replace main electronics	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	Restart device Change I/O module	F	Alarm
281	Electronic initialization active	Firmware update active, please wait!	F	Alarm
283	Memory content inconsistent	Restart device	F	Alarm
302	Device verification active	Device verification active, please wait.	С	Warning 1)
303	I/O 1 to n configuration changed	Apply I/O module configuration (parameter "Apply I/O configuration") Afterwards reload device description and check wiring	М	Warning
311	Sensor electronics (ISEM) faulty	Maintenance required! Do not reset device	М	Warning
330	Flash file invalid	Update firmware of device Restart device	М	Warning
331	Firmware update failed	Update firmware of device Restart device	F	Warning
332	Writing in HistoROM backup failed	Replace user interface board Ex d/XP: replace transmitter	F	Alarm
361	I/O module 1 to n faulty	Restart device Check electronic modules Change I/O module or main electronics	F	Alarm
372	Sensor electronics (ISEM) faulty	Restart device Check if failure recurs Replace sensor electronic module (ISEM)	F	Alarm
373	Sensor electronics (ISEM) faulty	Transfer data or reset device	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
375	I/O- 1 to n communication failed	Restart device Check if failure recurs Replace module rack inclusive electronic modules	F	Alarm
378	Supply voltage ISEM faulty	If available: Check connection cable between sensor and transmitter Replace main electronic module Replace sensor electronic module (ISEM)	F	Alarm
382	Data storage	Insert T-DAT Replace T-DAT	F	Alarm
383	Memory content	Reset device	F	Alarm
384	Transmitter circuit	Restart device Check if failure recurs Replace sensor electronic module (ISEM)	F	Alarm
385	Amplifier circuit	Restart device Check if failure recurs Replace sensor electronic module (ISEM)	F	Alarm
386	Time of flight	Restart device Check if failure recurs Replace sensor electronic module (ISEM)	F	Alarm
387	HistoROM data faulty	Contact service organization	F	Alarm
Diagnostic of	configuration			
410	Data transfer failed	Retry data transfer Check connection	F	Alarm
412	Processing download	Download active, please wait	С	Warning
431	Trim 1 to n required	Carry out trim	M	Warning
437	Configuration incompatible	Update firmware Execute factory reset	F	Alarm
438	Dataset different	Check dataset file Check device parameterization Download new device parameterization	M	Warning
441	Current output 1 to n saturated	Check current output settings Check process	S	Warning ¹⁾
442	Frequency output 1 to n saturated	Check frequency output settings Check process	S	Warning 1)
443	Pulse output 1 to n saturated	Check pulse output settings Check process	S	Warning ¹⁾
444	Current input 1 to n saturated	Check current input settings Check connected device Check process	S	Warning 1)
452	Calculation error detected	Check device configuration Check process conditions	S	Warning ¹⁾
453	Flow override active	Deactivate flow override	С	Warning
484	Failure mode simulation active	Deactivate simulation	С	Alarm
485	Process variable simulation active	Deactivate simulation	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
486	Current input 1 to n Deactivate simulation simulation active		С	Warning
491	Current output 1 to n simulation active	Deactivate simulation	С	Warning
492	Frequency output 1 to n simulation active	Deactivate simulation frequency output	С	Warning
493	Pulse output simulation active	Deactivate simulation pulse output	С	Warning
494	Switch output 1 to n simulation active	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation active	Deactivate simulation	С	Warning
496	Status input 1 to n simulation active	Deactivate simulation status input	С	Warning
502	CT activation/ deactivation failed	Follow the sequence of the custody transfer activation/deactivation: First authorized user login, then set the DIP switch on the main electonic module	С	Warning
520	I/O 1 to n hardware configuration invalid	Check I/O hardware configuration Replace wrong I/O module Plug the module of double pulse output on correct slot	F	Alarm
537	Configuration	Check IP addresses in network Change IP address	F	Warning
538	Flow computer configuration incorrect	Check input value (pressure, temperature)	S	Warning
539	Flow computer configuration incorrect	Check input value (pressure, temperature) Check allowed values of the medium properties	S	Alarm
540	Custody transfer mode failed	Power off device and toggle DIP switch Deactivate custody transfer mode Reactivate custody transfer mode Check electronic components	F	Alarm
541	Flow computer configuration incorrect	Check entered reference value using the document Operating Instructions	S	Warning
543	Double pulse output	Check process Check pulse output settings	S	Warning 1)
593	Double pulse output 1 simulation	Deactivate simulation pulse output	С	Warning
594	Relay output 1 to n simulation active	Deactivate simulation switch output	С	Warning
599	Custody transfer logbook full	Deactivate custody transfer mode Clear custody transfer logbook (all 30 entries) Activate custody transfer mode	F	Warning
Diagnostic of	process			
803	Loop current 1 faulty	1. Check wiring 2. Change I/O module	F	Alarm
832	Electronics temperature too high	Reduce ambient temperature	S	Warning 1)

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
833	Electronics temperature too low	Increase ambient temperature	S	Warning 1)
834	Process temperature too high	Reduce process temperature	S	Warning 1)
835	Process temperature too low	Increase process temperature	S	Warning 1)
836	Process pressure above limit	Reduce process pressure	S	Alarm
837	Process pressure below limit	Increase process pressure	S	Warning 1)
841	Flow velocity too high	Reduce flow rate	S	Warning 1)
842	Process value below limit	Low flow cut off active! Check low flow cut off configuration	S	Warning 1)
870	Measuring inaccuracy increased	Check process Increase flow volume	F	Alarm 1)
881	Signal to noise ratio too low	Check process conditions Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on) Replace sensor electronic module (ISEM)	F	Alarm
882	Input signal faulty	Check input signal parameterization Check external device Check process conditions	F	Alarm
930	Sound velocity too high	Check process conditions Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on) Replace sensor electronic module (ISEM)	S	Warning ¹⁾
931	Sound velocity too low	Check process conditions Clean/repl. transd. (inline) / check sensor pos. and coupling (clamp on) Replace sensor electronic module (ISEM)	S	Warning ¹⁾
941	API/ASTM temperature out of specificat.	Check process temperature with selected API/ASTM commodity group Check API/ASTM-related parameters	S	Warning 1)
942	API/ASTM density out of specification	Check process density with selected API/ASTM commodity group Check API/ASTM-related parameters	S	Warning 1)
943	API pressure out of specification	Check process pressure with selected API commodity group Check API related parameters	S	Warning ¹⁾
953	Asymmetry noise signal too high path 1 to n	Check process conditions Clean or replace transducers Replace sensor electronic module (ISEM)	M	Alarm
954	Sound velocity deviation too high	Check medium configuration Check process conditions Clean or replace transducers	S	Warning 1)

¹⁾ Diagnostic behavior can be changed.

152

12.8 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event:

 Via local display → 🖺 141
 - Via web browser $\rightarrow \implies 143$
 - Via "FieldCare" operating tool → 🖺 145
 - Via "DeviceCare" operating tool → 🖺 145
- Other pending diagnostic events can be displayed in the **Diagnostic list** submenu $\Rightarrow \implies 153$

Navigation

"Diagnostics" menu



Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.9 Diagnostics list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list



■ 37 Using the example of the local display

- To call up the measures to rectify a diagnostic event:
 - Via local display → 🖺 141
 - Via web browser →

 143
 - Via "FieldCare" operating tool \rightarrow 🖺 145
 - Via "DeviceCare" operating tool → 🗎 145


12.10 Event logbook

12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu → **Event logbook** submenu → Events list



A0014008-E

■ 38 Using the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events → 🗎 148
- Information events → 🖺 156

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostics event
 - ᢒ: Occurrence of the event
 - 🕒: End of the event
- Information event
 - €: Occurrence of the event
- 🙌 To call up the measures to rectify a diagnostic event:
 - 🦥 Via local display → 🖺 141
 - Via web browser → 🖺 143
 - Via "FieldCare" operating tool → 🖺 145

12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name	
I1000	(Device ok)	
I1079	Sensor changed	
I1089	Power on	
I1090	Configuration reset	
I1091	Configuration changed	
I1092	HistoROM backup deleted	
I1137	Electronics changed	
I1151	History reset	
I1155	Reset electronics temperature	
I1156	Memory error trend	
I1157	Memory error event list	
I1256	Display: access status changed	
I1264	Safety sequence aborted	
I1278	I/O module restarted	
I1327	Zero point adjust failed signal path	
I1335	Firmware changed	
I1361	Web server: login failed	
I1397	Fieldbus: access status changed	
I1398	CDI: access status changed	
I1444	Device verification passed	
I1445	Device verification failed	
I1457	Measurement error verification failed	
I1459	I/O module verification failed	
I1461	Sensor verification failed	
I1462	Sensor electronic module verific. failed	
I1512	Download started	
I1513	Download finished	
I1514	Upload started	
I1515	Upload finished	
I1517	Custody transfer active	
I1518	Custody transfer inactive	
I1554	Safety sequence started	
I1555	Safety sequence confirmed	
I1556	Safety mode off	
I1618	I/O module 2 replaced	
I1619	I/O module 3 replaced	
I1621	I/O module 4 replaced	
I1622	Calibration changed	
I1624	All totalizers reset	

Info number	Info name
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server: login successful
I1628	Display: login successful
I1629	CDI: login successful
I1631	Web server access changed
I1632	Display: login failed
I1633	CDI: login failed
I1634	Reset to factory settings
I1635	Reset to delivery settings
I1639	Max. switch cycles number reached
I1643	Custody transfer logbook cleared
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1651	Custody transfer parameter changed
I1712	New flash file received
I1725	Sensor electronic module (ISEM) changed
I1726	Configuration backup failed

12.11 Resetting the measuring device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter ($\rightarrow \implies 114$).

12.11.1 Function range of "Device reset" parameter


Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Restore S-DAT backup	Restores the data that is saved on the S-DAT. Additional information: This function can be used to resolve the memory issue "083 Memory content inconsistent" or to restore the S-DAT data when a new S-DAT has been installed. This option is displayed only in an alarm condition.

12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information



Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Prosonic Flow
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-

Parameter	Description	User interface	Factory setting
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Prosonic Flow 500 –	
Manufacturer	Displays the manufacturer.	Character string comprising numbers, letters and special characters	
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.		
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	_
Extended order code 3	Shows the 3rd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00
Device revision	Displays the device revision with which the device is registered with the HART FieldComm Group.	2-digit hexadecimal number	0x3B
Device ID	Shows the device ID for identifying the device in a HART network.	6-digit hexadecimal number	-
Device type	Displays the device type with which the device is registered with the HART FieldComm Group.	2-digit hexadecimal number	0x3B (for Prosonic Flow G 300/500)
Manufacturer ID	Displays the device's manufacturer ID registered with the HART FieldComm Group.	2-digit hexadecimal number	0x11 (for Endress+Hauser)

12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
01.2024	01.02.zz	Option 74	Update	Operating instructions	BA01836D/06/EN/02.24
09.2019	01.00.zz	Option 78	Original firmware	Operating instructions	BA01836D/06/EN/01.19

- It is possible to flash the firmware to the current version or the previous version using the service interface.
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 9G5B
 The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.2 Measuring and test equipment

Endress+Hauser offers a variety of measuring and testing equipment, such as Netilion or device tests.

ho Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \triangleq 167$

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

162

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and conversion of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ▶ Carry out the repair according to the Installation Instructions.
- ▶ Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document all repairs and conversions and enter the details in Netilion Analytics.

14.2 Spare parts

Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

- Measuring device serial number:
 - Is located on the nameplate of the device.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the web page for information: http://www.endress.com/support/return-material
 - ► Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

A WARNING

Danger to persons from process conditions!

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

A WARNING

Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ► Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description	
Transmitter Proline 500 – digital	Transmitter for replacement or storage. Use the order code to define the following specifications: Approvals Output Input Display/operation Housing Software Proline 500 – digital transmitter: Order number: 9X5BXX-******A Proline 500 – digital transmitter: Installation Instructions EA01264D	
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area". ■ The external WLAN antenna is not suitable for use in hygienic applications. ■ Additional information regarding the WLAN interface → 🗎 69. ■ Order number: 71351317 ■ Installation Instructions EA01238D	
Pipe mounting set	Pipe mounting set for transmitter. Proline 500 – digital transmitter Order number: 71346427 Installation Instructions EA01195D	
Weather protection cover Transmitter Proline 500 – digital	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight. Proline 500 – digital transmitter Order number: 71343504 Installation Instructions EA01191D	

Display guard Proline 500 – digital	Is used to protect the display against impact or scoring, for example from sand in desert areas.
	Order number: 71228792 Installation Instructions EA01093D
Connecting cable Proline 500 – digital Sensor – Transmitter	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection) or as an accessory (order number DK9012). The following cable lengths are available: order code for "Cable, sensor connection" Option B: 20 m (65 ft) Option E: User-configurable up to max. 50 m Option F: User-configurable up to max. 165 ft
	Maximum possible cable length for a Proline 500 – digital connecting cable: 300 m (1000 ft)

15.2 Communication-specific accessories

Accessories	Description	
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB port Technical Information TI00404F	
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values. Technical Information TI00429F Operating Instructions BA00371F	
Fieldgate FXA42	Transmission of the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices Technical Information TI01297S Operating Instructions BA01778S Product page: www.endress.com/fxa42	
Field Xpert SMT50	The Field Xpert SMT50 table PC for device configuration enables mobile plant asset management. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. Technical Information TI01555S Operating Instructions BA02053S Product page: www.endress.com/smt50	
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver librar and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt70	
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1. Technical Information TI01418S Operating Instructions BA01923S Product page: www.endress.com/smt77	

15.3 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices for industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator As a downloadable DVD for local PC installation.
Netilion	lloT Ecosystem: Unlock knowledge With the Netilion lloT Ecosystem, Endress+Hauser enables you to optimize your plant performance by digitizing workflows, creating knowledge and establishing new levels of collaboration. Building decades of expertise in process automation, Endress+Hauser provides the process industry with an lloT Ecosystem that allows data-driven insights. These insights can be applied to optimize processes resulting in increased plant up-time, efficiency, reliability – and ultimately, a more profitable plant. www.netilion.endress.com
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices. Innovation brochure IN01047S

15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick. Technical Information TI00133R Operating Instructions BA00247R

16 Technical data

16.1 Application

The measuring device is intended only for the flow measurement of gases.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Proline Prosonic Flow uses a measurement method based on the transit time difference.
Measuring system	The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.
	Information on the structure of the device $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

16.3 Input

Measured variable

Direct measured variables

- Flow velocity
- Sound velocity
- Process temperature (optional): based on Pt1000 Class A platinum resistor
- Pressure (optional): based on pressure measuring cell for measuring absolute pressure

Calculated measured variables

- Volume flow
- Corrected volume flow (corrected/standard volume flow)
- Mass flow
- Energy flow
- Density

Optionally calculated measured variables

Order code for "Application package", option EF "Advanced gas analysis"

- Wobbe index
- Methane fraction
- Molar mass
- Dynamic viscosity
- Calorific value
- Optionally calculated measured variables depend on the gas type.

Measuring range

- With the specified measurement accuracy: v = 0.3 to 40 m/s (0.98 to 131.2 ft/s)
- With reduced measurement accuracy: v = 0.3 to 60 m/s (0.98 to 196.8 ft/s)

Flow characteristic values in SI units

			Factory settings			
	inal ieter	Recommended flow	Full scale value current output	Pulse value	Low flow cut off (v ~ 0.1 m/s)	
[mm]	[in]	[m³/h]	[m³/h]	[m³/pulse]	[m³/h]	
25	1	0.50 to 67	50	0.007	0.17	
50	2	2.05 to 274	210	0.03	0.68	
80	3	4.60 to 614	460	0.06	1.5	
100	4	8 to 1064	800	0.1	2.7	
150	6	18.1 to 2 414	1800	0.3	6.0	
200	8	32 to 4235	3 200	0.4	11	
250	10	50 to 6662	5 000	0.7	17	
300	12	71 to 9426	7 100	1.0	24	

Flow characteristic values in US units

			Factory settings		
Nominal diameter		Recommended flow	Full scale value current output	Pulse value	Low flow cut off (v ~ 0.1 m/s)
[in]	[mm]	[ft³/hr]	[ft³/hr]	[ft³/pulse]	[ft³/hr]
1	25	17.7 to 2358	1800	0.2	5.9
2	50	73 to 9668	7300	1	24
3	80	163 to 21694	16000	2	54
4	100	282 to 37 579	28000	4	94
6	150	639 to 85253	64000	9	213
8	200	1 122 to 149 544	110000	16	374
10	250	1764 to 235259	180 000	25	588
12	300	2 497 to 332 890	250 000	35	832

Recommended measuring range



Flow limit → 🖺 184

Operable flow range

133:1

Input signal

External measured values

To increase the measurement accuracy of certain measured variables or to calculate the corrected volume flow for gases, the use of the integrated pressure and temperature measurement function is recommended:

- Temperature measurement to increase measurement accuracy (order code for "Measuring tube; Transducer; Sensor version", option AB "316L; titanium gr. 2; integrated temperature measurement")
- Temperature and pressure measurement to increase measurement accuracy (order code for "Measuring tube; Transducer; Sensor version", option AC "316L; titanium gr. 2; integrated pressure + temperature measurement")

The measuring device provides optional interface that enable the transmission of externally measured variables (temperature, pressure, gas composition (gas composition can only be transmitted via Modbus)) to the measuring device:

- Analog inputs 4-20 mA
- Digital inputs (via HART input or Modbus)

Pressure values can be transmitted as absolute or gauge pressure. For gauge pressure, the atmospheric pressure must be specified by the customer.

i

HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

Current input

170

Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)	
Current span	 4 to 20 mA (active) 0/4 to 20 mA (passive) 	
Resolution	1 μΑ	
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)	
Maximum input voltage	≤ 30 V (passive)	
Open-circuit voltage	≤ 28.8 V (active)	
Possible input variables	PressureTemperature	

Status input

Maximum input values	 DC -3 to 30 V If status input is active (ON): R_i >3 kΩ
Response time	Configurable: 5 to 200 ms
Input signal level	 Low signal: DC -3 to +5 V High signal: DC 12 to 30 V
Assignable functions	 Off Reset the individual totalizers separately Reset all totalizers Flow override

16.4 Output

Output signal

Current output 4 to 20 mA HART

Order code	"Output; input 1" (20): Option BA: current output 4 to 20 mA HART
Signal mode	Can be set to: Active Passive
Current range	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	250 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Corrected volume flow Mass flow Energy flow Sound velocity Flow velocity Electronics temperature Methane fraction ¹⁾ Molar mass ¹⁾ Density Dynamic viscosity ¹⁾ Calorific value ¹⁾ Wobbe index ¹⁾ Pressure ²⁾ Temperature ³⁾

- 1) Only for the order code for "Application package", option EF "Advanced gas analysis" and corresponding configuration
- 2) Only for the order code for "Measuring tube; Transducer; Sensor version", option AC "316L; titanium gr. 2; pressure + temperature measurement integrated"
- 3) Only for the order code for "Measuring tube; Transducer; Sensor version", option AB "316L; titanium gr. 2; temperature measurement integrated" or AC "316L; titanium gr. 2; pressure + temperature measurement integrated"

Current output 4 to 20 mA

Order code	"Output; input 2" (21), "Output; input 3" (022) or "Output; input 4" (023): Option B: current output 4 to 20 mA
Signal mode	Can be set to: Active Passive
Current range	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)

172

Maximum input voltage	DC 30 V (passive)
Load	0 to 700 $Ω$
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Corrected volume flow Mass flow Energy flow Sound velocity Flow velocity Electronics temperature Methane fraction ¹⁾ Molar mass ¹⁾ Density Dynamic viscosity ¹⁾ Calorific value ¹⁾ Wobbe index ¹⁾ Pressure ²⁾ Temperature ³⁾

- 1) Only for the order code for "Application package", option EF "Advanced gas analysis" and corresponding configuration
- 2) Only for the order code for "Measuring tube; Transducer; Sensor version", option AC "316L; titanium gr. 2; pressure + temperature measurement integrated"
- 3) Only for the order code for "Measuring tube; Transducer; Sensor version", option AB "316L; titanium gr. 2; temperature measurement integrated" or AC "316L; titanium gr. 2; pressure + temperature measurement integrated"

Pulse/frequency/switch output

Function	Can be configured as pulse, frequency or switch output
Version	Open collector Can be set to: Active Passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Configurable
Assignable measured variables	 Volume flow Corrected volume flow Mass flow Energy flow
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Configurable: end value frequency 2 to 10 000 Hz(f $_{max}$ = 12 500 Hz)

Damping	Configurable: 0 to 999.9 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Corrected volume flow Mass flow Energy flow Sound velocity Flow velocity Electronics temperature Methane fraction 1) Molar mass 1) Density Dynamic viscosity 1) Calorific value 1) Wobbe index 1) Pressure 2) Temperature 3)
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	 Disable On Diagnostic behavior Limit Volume flow Corrected volume flow Mass flow Energy flow Flow velocity Electronics temperature Sound velocity Methane fraction 1) Molar mass 1) Density Dynamic viscosity 1) Calorific value 1) Wobbe index 1) Pressure 2) Temperature 3) Totalizer 1-3 Flow direction monitoring Status Low flow cut off

- Only for the order code for "Application package", option EF "Advanced gas analysis" and corresponding configuration
- 2) Only for the order code for "Measuring tube; Transducer; Sensor version", option AC "316L; titanium gr. 2; pressure + temperature measurement integrated"
- Only for the order code for "Measuring tube; Transducer; Sensor version", option AB "316L; titanium gr. 2; temperature measurement integrated" or AC "316L; titanium gr. 2; pressure + temperature measurement integrated"

Double pulse output

Function	Double pulse
Version	Open collector
	Can be set to: Active Passive Passive NAMUR
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Corrected volume flow Mass flow Energy flow

Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: NO (normally open), factory setting NC (normally closed)
Maximum switching capacity (passive)	■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A
Assignable functions	 Disable On Diagnostic behavior Limit Volume flow Corrected volume flow Mass flow Energy flow Flow velocity Electronics temperature Sound velocity Methane fraction 1) Molar mass 1) Density Dynamic viscosity 1) Calorific value 1) Wobbe index 1) Pressure 2) Temperature 3) Totalizer 1-3 Flow direction monitoring Status Low flow cut off

- 1) Only for the order code for "Application package", option EF "Advanced gas analysis" and corresponding configuration
- 2) Only for the order code for "Measuring tube; Transducer; Sensor version", option AC "316L; titanium gr. 2; pressure + temperature measurement integrated"
- 3) Only for the order code for "Measuring tube; Transducer; Sensor version", option AB "316L; titanium gr. 2; temperature measurement integrated" or AC "316L; titanium gr. 2; pressure + temperature measurement integrated"

User-configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Current output 0/4 to 20 mA

4 to 20 mA

Failure mode	Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Definable value between: 3.59 to 22.5 mA Actual value
	Actual value Last valid value
	- Last valid valid

0 to 20 mA

Failure mode	Choose from:
	■ Maximum alarm: 22 mA
	■ Definable value between: 0 to 20.5 mA

Pulse/frequency/switch output

Pulse output	
Fault mode	Choose from: Actual value No pulses
Frequency output	
Fault mode	Choose from: Actual value O Hz Definable value between: 2 to 12 500 Hz
Switch output	
Fault mode	Choose from: Current status Open Closed

Relay output

Failure mode	Choose from:
	Current statusOpenClosed

Local display

Plain text display	With information on cause and remedial measures	
Backlight	Red lighting indicates a device error.	



Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication: HART protocol
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	---

Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes		
	The following information is displayed depending on the device version: Supply voltage active Data transmission active Device alarm/error has occurred		
	Diagnostic information via light emitting diodes → 🖺 137		

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The outputs are galvanically isolated:

- from the power supply
- from one another
- from the potential equalization (PE) terminal

Protocol-specific data

Manufacturer ID	0x11	
Device type ID	0x5D (93)	
HART protocol revision	7	
Device description files (DTM, DD)	Information and files under: www.endress.com	
HART load	Min. 250 Ω	
System integration	Information on system integration → 🗎 74. • Measured variables via HART protocol • Burst Mode functionality	

16.5 Power supply

Terminal assignment	→ 🖺 33				
Supply voltage	Order code "Power supply"	Terminal volta	ge	Frequency range	
		DC 24 V	±20%	-	
	Option I	AC 100 to 240	V -15+10%	50/60 Hz	
Power consumption	Transmitter Max. 10 W (active po	ower)			
	switch-on current	switch-on current Max. 36 A (<5 ms) as per NAMUR Recommendation NE 21			
Current consumption	Transmitter ■ Max. 400 mA (24 V) ■ Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)				
Power supply failure	 Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memory or in the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored. 				
Overcurrent protection element	The device must be operated with a dedicated circuit breaker, as it does not have an ON/OFF switch of its own. The circuit breaker must be easy to reach and labeled accordingly. Permitted nominal current of the circuit breaker: 2 A up to maximum 10 A.				
Electrical connection	→ 🖺 34				
Potential equalization	→ 🗎 38				
Terminals	Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm ² (24 to 12 AWG).				
Cable entries	 Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) Thread for cable entry: NPT ½" G ½" M20 				
Cable specification	→ 🖺 29				
Overvoltage protection	Mains voltage fluctuation	ons -	178 18 18		

Overvoltage category

Overvoltage category II

Short-term, temporary overvoltage	Between cable and ground up to 1200 V, for max. 5 s	
Long-term, temporary overvoltage	Between cable and ground up to 500 V	

16.6 Performance characteristics

Reference operating conditions

- Maximum permissible error according to ISO/DIN 11631
- Calibration gas: dry air
- Accuracy information is based on accredited calibration rigs that are traced to ISO 17025.


Maximum measurement error

o.r. = of reading; o.f.s. = of full scale value; abs. = absolute; T = medium temperature

Volume flow

Standard Order code for "Flow calibration", option A "1%"	■ ±1.0 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±2.0 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)
Optional Order code for "Flow calibration", option C "0.50%"	■ ±0.5 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±1.0 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)
Optional Order code for "Flow calibration", option D "0.50%, traceable to ISO/IEC 17025"	■ ±0.5 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±1.0 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)

- The measuring device may be operated for flow velocities 40 to 60 m/s (131.2 to 196.8 ft/s), but larger measurement errors may then occur.
- The specification applies to Reynolds numbers Re \geq 10000. Larger measurement errors may occur for Reynolds numbers Re < 10000.



■ 39 Maximum measurement error (volume flow) in % of reading

- 1 Standard (order code for "Flow calibration", option A "1%")
- 2 Optional (order code for "Flow calibration", option C "0.50%")
- 3 Optional (order code for "Flow calibration", option D "0.50%, traceable to ISO/IEC 17025"

Corrected volume flow

Standard Order code for "Flow calibration", option A "1%"	■ ±1.2 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±2.1 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)	
Optional Order code for "Flow calibration", option C "0.50%"	■ ±0.8 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±1.2 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)	
Optional Order code for "Flow calibration", option D "0.50%, traceable to ISO/IEC 17025"	■ ±0.8 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s) ■ ±1.2 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)	

- The specification for corrected volume flow applies to the integrated temperature and pressure measurement (order code for "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; integrated pressure + temperature measurement"), when the pressure measuring cell is operated in the optimum pressure measurement range.
- The measuring device may be operated for flow velocities 40 to 60 m/s (131.2 to 196.8 ft/s), but larger measurement errors may then occur.
- The specification applies to Reynolds numbers Re \geq 10 000. Larger measurement errors may occur for Reynolds numbers Re < 10 000.

Temperature

Optional (order code for "Measuring tube; Transducer; Sensor version", option AB "316L; Titanium Gr. 2; temperature measurement integrated" or AC "316L; titanium gr. 2; integrated pressure + temperature measurement") $\pm 0.35 \,^{\circ}\text{C} \pm 0.002 \cdot \text{T} \,^{\circ}\text{C} (\pm 0.63 \,^{\circ}\text{F} \pm 0.0011 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Pressure

Optional (order code for "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; integrated pressure + temperature measurement")

The specific measurement errors refer to the position of the measurement in the measuring pipe and do not correspond to the pressure in the pipe connection line upstream or downstream from the measuring device.

Order code for "Pressure component"	Nominal value absolute [bar (psi)]	Pressure ranges and measurement errors	
		Pressure range, absolute [bar (psi)]	Measurement error, absolute
Option B "Pressure measuring cell 2bar/29psi abs"	2 bar (30 psi)	$0.01 (0.1) \le p \le 0.4 (5.8)$ $0.4 (5.8) \le p \le 2 (29)$	±0.5 % of 0.4 bar (5.8 psi) ±0.5 % o.r.
Option C "Pressure measuring cell 4bar/58psi abs"	4 bar (60 psi)	$0.01 (0.1) \le p \le 0.8 (11.6)$ $0.8 (11.6) \le p \le 4 (58)$	±0.5 % of 0.8 bar (11.6 psi) ±0.5 % o.r.
Option D "Pressure measuring cell 10bar/145psi abs"	10 bar (150 psi)	$0.01 (0.1) \le p \le 2 (29)$ 2 (29) $\le p \le 10 (145)$	±0.5 % of 2 bar (29 psi) ±0.5 % o.r.
Option E "Pressure measuring cell 40bar/580psi abs"	40 bar (600 psi)	$0.01 (0.1) \le p \le 8 (116)$ 8 (116) $\le p \le 40 (580)$	±0.5 % of 8 bar (116 psi) ±0.5 % o.r.
Option F "Pressure measuring cell 100bar/1450psi abs"	100 bar (1500 psi)	$0.01 (0.1) \le p \le 20 (290)$ $20 (290) \le p \le 100 (1450)$	±0.5 % of 20 bar (290 psi) ±0.5 % o.r.

Sound velocity

±0.2 % o.r.

180

Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

	. 5
Accuracy	l ±5 uA
	r

Pulse/frequency output

o.r. = of reading

Accuracy	Max. ±50 ppm o.r. (over the entire ambient temperature range)
----------	---

Repeatability

o.r. = of reading

Volume flow

- ±0.2 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s)
- ±0.4 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)

Corrected volume flow

- ±0.25 % o.r. for 3 to 40 m/s (9.84 to 131.2 ft/s)
- ±0.45 % o.r. for 0.3 to 3 m/s (0.98 to 9.84 ft/s)

Temperature

 ± 0.175 °C ± 0.001 · T °C (± 0.315 °F ± 0.00055 · (T - 32) °F)

Pressure

Optional (order code for "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; integrated pressure + temperature measurement")

Order code for "Pressure	Nominal value absolute	Pressure ranges and measurement errors		
component"	[bar (psi)]	Pressure range, absolute [bar (psi)]	Measurement error, absolute	
Option B "Pressure measuring cell 2bar/29psi abs"	2 bar (30 psi)	0.01 (0.1) \leq p \leq 0.4 (5.8) 0.4 (5.8) \leq p \leq 2 (29)	±0.1 % of 0.4 bar (5.8 psi) ±0.1 % o.r.	
Option C "Pressure measuring cell 4bar/58psi abs"	4 bar (60 psi)	$0.01 (0.1) \le p \le 0.8 (11.6)$ $0.8 (11.6) \le p \le 4 (58)$	±0.1 % of 0.8 bar (11.6 psi) ±0.1 % o.r.	
Option D "Pressure measuring cell 10bar/145psi abs"	10 bar (150 psi)	$0.01 (0.1) \le p \le 2 (29)$ 2 (29) $\le p \le 10 (145)$	±0.1 % of 2 bar (29 psi) ±0.1 % o.r.	
Option E "Pressure measuring cell 40bar/580psi abs"	40 bar (600 psi)	$0.01 (0.1) \le p \le 8 (116)$ 8 (116) $\le p \le 40 (580)$	±0.1 % of 8 bar (116 psi) ±0.1 % o.r.	
Option F "Pressure measuring cell 100bar/1450psi abs"	100 bar (1500 psi)	$0.01 (0.1) \le p \le 20 (290)$ $20 (290) \le p \le 100 (1450)$	±0.1 % of 20 bar (290 psi) ±0.1 % o.r.	

Sound velocity

±0.04 % o.r.

Influence of ambient temperature

Current output

Temperature coefficient Max. 1 μΑ/°C

Pulse/frequency output

Temperature coefficient	No additional effect. Included in accuracy.
-------------------------	---

16.7 Mounting

Mounting requirements

→ 🖺 21

16.8 Environment

Ambient temperature range

→ 🖺 23

Temperature tables



Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature

All components except display modules:

 $-40 \text{ to } +80 \,^{\circ}\text{C} (-40 \text{ to } +176 \,^{\circ}\text{F})$, preferably at $+20 \,^{\circ}\text{C} (+68 \,^{\circ}\text{F})$

Display modules

-40 to +80 °C (-40 to +176 °F)

Relative humidity

The device is suitable for use in outdoor and indoor areas with a relative humidity of 4 to 95%.

Operating height

According to EN 61010-1

- $\le 2000 \text{ m} (6562 \text{ ft})$
- > 2 000 m (6 562 ft) with additional overvoltage protection (e.g. Endress+Hauser HAW Series)

Degree of protection

Transmitter

- IP66/67, Type 4X enclosure, suitable for pollution degree 4
- \blacksquare When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2
- Display module: IP20, Type 1 enclosure, suitable for pollution degree 2

Sensor

- IP66/67, Type 4X enclosure, suitable for pollution degree 4
- When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2

Optional

External WLAN antenna

IP67

Shock and vibration resistance

Vibration sinusoidal, in accordance with IEC 60068-2-6

- 2 to 8.4 Hz, 7.5 mm peak
- 8.4 to 2000 Hz, 2 g peak

Vibration broad-band random, according to IEC 60068-2-64

- 10 to 200 Hz, 0.01 q²/Hz
- 200 to 2000 Hz, 0.003 g²/Hz
- Total: 2.70 g rms

Shock half-sine, according to IEC 60068-2-27

6 ms 50 g

Rough handling shocks according to IEC 60068-2-31

Electromagnetic compatibility (EMC)

As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)



Details are provided in the Declaration of Conformity.



This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.

16.9 Process

Medium temperature range

Sensor

- Without integrated pressure measuring cell: -50 to +150 °C (-58 to +302 °F)
- With integrated pressure measuring cell: -50 to +100 °C (-58 to +212 °F)

Sound velocity range

200 to 600 m/s (656 to 1969 ft/s)

Medium pressure range

Min. medium pressure: 0.7 bar (10.2 psi) absolute

The maximum permitted medium pressure is defined by the pressure/temperature curves (see the "Technical Information" document) and the pressure specifications of the integrated pressure measuring cell (optional; order code for "Measuring tube; transducer; sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated").

WARNING

The maximum pressure for the measuring device depends on the lowest-rated element with regard to pressure.

- ▶ Note specifications regarding the pressure range of the pressure measuring cell.
- The Pressure Equipment Directive (2014/68/EU) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the pressure measuring cell.
- The MWP for the pressure measuring cell depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection must be taken into consideration in addition to the pressure measuring cell. Also take the pressure/temperature dependency into consideration.
- The MWP may be applied at the device for an unlimited period. The MWP is indicated on the nameplate. This value refers to a reference temperature of $\pm 20 \, ^{\circ}\text{C}$ ($\pm 68 \, ^{\circ}\text{F}$) and may be applied to the pressure measuring cell for an unlimited time.
- ► The OPL (over pressure limit = sensor overload limit) for the measuring device depends on the lowest-rated element, with regard to pressure, of the selected components, i.e. the process connection has to be taken into consideration in addition to the pressure measuring cell. Also take the pressure/temperature dependency into consideration.
- ▶ The test pressure corresponds to the over pressure limit of the pressure measuring cell and may be applied only temporarily to ensure that the measurement is within the specifications and no permanent damage occurs.

Pressure measuring cell	Maximum sensor measuring range		MWP	OPL
	Lower (LRL)	Upper (URL)		
	[bar (psi)]	[bar (psi)]	[bar (psi)]	[bar (psi)]
2 bar (30 psi)	0 (0)	+2 (+30)	6.7 (100.5)	10 (150)
4 bar (60 psi)	0 (0)	+4 (+60)	10.7 (160.5)	16 (240)
10 bar (150 psi)	0 (0)	+10 (+150)	25 (375)	40 (600)
40 bar (600 psi)	0 (0)	+40 (+600)	100 (1500)	160 (2 400)
100 bar (1500 psi)	0 (0)	+100 (+1500)	100 (1500)	160 (2 400)

Pressure-temperature ratings



For an overview of the pressure-temperature ratings for the process connections, see the Technical Information

Rupture disk

The neck of the measuring device is always fitted with a rupture disk with a triggering pressure of 10 to 15 bar (145 to 217.5 psi). The rupture disk is used for leak detection and for the controlled release of pressure in the neck of the measuring device. The measuring device with an installed rupture disk meets the dual seal requirements of ANSI/ ISA-12.27.01.

Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor.

- For an overview of the full scale values for the measuring range, see the "Measuring range" section $\rightarrow \blacksquare 169$
- The minimum recommended full scale value is approx. 1/20 of the maximum full scale
- In most applications, 10 to 50 % of the maximum full scale value can be considered ideal

Pressure loss

No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.

Thermal insulation

For optimum measurement performance, make sure that no heat transfer (heat loss or heat supply) can take place at the sensor. This can be ensured by installing thermal insulation. The formation of condensation in the measuring device can also be limited in this way.


Thermal insulation is particularly recommended in situations in which the difference between the process temperature and ambient temperature is large. This difference leads to an error during temperature measurement that is caused by heat conduction (known as the "heat conduction error").

A WARNING

Electronics overheating on account of thermal insulation!

- ► Recommended orientation: horizontal orientation, sensor connection housing pointing downwards.
- ▶ Do not insulate the sensor connection housing.
- ▶ Maximum permissible temperature at the lower end of the sensor connection housing: $80 \,^{\circ}\text{C} (176 \,^{\circ}\text{F})$
- ► Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.

The thermal insulation should never cover the transmitter housing and the pressure measuring cell.



A003767

 \blacksquare 40 Thermal insulation with free extended neck and pressure measuring cell

1 Pressure measuring cell

16.10 Mechanical construction

Design, dimensions



For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .

Weight

Transmitter

- Proline 500 digital polycarbonate: 1.4 kg (3.1 lbs)
- Proline 500 digital aluminum: 2.4 kg (5.3 lbs)

Sensor

- Sensor with cast connection housing version, stainless: +3.7 kg (+8.2 lbs)
- Sensor with aluminum connection housing version:

Weight in SI units

Nominal di	ameter	EN (DIN) [kg]			
			Pressu	ire rating	
[mm]	[in]	PN 16	PN 40	PN 63	PN 100
25	1	10	10	12	12
50	2	15	15	19	21

Nominal diameter		EN (DIN) [kg]				
			Pressure rating			
[mm]	[in]	PN 16	PN 40	PN 63	PN 100	
80	3	21	21	25	29	
100	4	23	26	32	39	
150	6	35	42	62	76	
200	8	51	71	98	128	
250	10	77	114	143	206	
300	12	107	161	201	297	

Nominal diameter		ASME [kg]					
		Pressure rating					
[mm]	[in]	Class 150 RF Sch.40	Class 300 RF Sch.40	Class 300 RF Sch.80	Class 600 RF Sch.80		
25	1	9	10	10	11		
50	2	14	16	16	18		
80	3	21	24	24	28		
100	4	27	35	35	49		
150	6	39	55	56	89		
200	8	66	91	93	136		
250	10	93	133	133	222		
300	12	142	193	198	278		

Weight in US units

Nominal diameter		ASME [lbs]					
		Pressure rating					
[mm]	[in]	Class 150 RF Sch.40	Class 300 RF Sch.40	Class 300 RF Sch.80	Class 600 RF Sch.80		
25	1	20	22	22	24		
50	2	31	35	35	40		
80	3	46	53	53	62		
100	4	60	77	77	108		
150	6	86	121	123	196		
200	8	146	201	205	300		
250	10	205	293	293	490		
300	12	313	426	437	613		

Materials

- If the order code for "Additional approval", option LR "NACE MR0175 / ISO 15156 (wetted parts), declaration" or LS "NACE MR0103 / ISO 17945 (wetted parts), declaration" was ordered, all the metal materials used meet the NACE MR0175 and NACE MR0103 standards.
 - The seal material is tested in accordance with NACE TM0187 and NORSOK M710-B.

▲ DANGER

The ultrasonic transducer may not be leak-tight!

Toxic and/or explosive gases may escape!

- ▶ The material of the seal is not suitable for applications in pure steam.
- ► The material of the seal must not be exposed to a pressure increase at low process temperatures below -40 °C (-40 °F).

Transmitter housing

Housing of Proline 500 - digital transmitter

Order code for "Transmitter housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option **D** "Polycarbonate": polycarbonate

Window material

Order code for "Transmitter housing":


- Option A "Aluminum, coated": glass
- Option **D** "Polycarbonate": plastic

Sensor connection housing

Order code for "Sensor connection housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option L "Cast, stainless": 1.4409 (CF3M) similar to 316L

Cable entries/cable glands



A002064

- 41 Possible cable entries/cable glands
- 1 Female thread M20 \times 1.5
- 2 Cable gland $M20 \times 1.5$
- 3 Adapter for cable entry with female thread G ½" or NPT ½"

Cable entries and adapters	Material
Cable gland M20 × 1.5	Plastic
 Adapter for cable entry with female thread G ½" Adapter for cable entry with female thread NPT ½" 	Nickel-plated brass
Only available for certain device versions: Order code for "Transmitter housing": Option A "Aluminum, coated" Option D "Polycarbonate" Order code for "Sensor connection housing": Proline 500 – digital: Option A "Aluminum coated" Option L "Cast, stainless"	

Connecting cables



UV rays can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Connecting cable for sensor - Proline 500 – digital transmitter

PVC cable with copper shield

Measuring pipe

Stainless steel: 1.4408/1.4409 (CF3M)

Process connections

Stainless steel: 1.4404 (316, 316L)



Available process connections → 🗎 189

Cable for transmitter neck/ultrasonic transducer

Including connections for transmitter neck and ultrasonic transducer Stainless steel: 1.4404 (316, 316L)

Ultrasonic transducer

Grade 2 titanium

Sensor holder: stainless steel: 1.4404 (316, 316L)

Seal for ultrasonic transducer

FKM material group

Temperature sensor

Stainless steel: 1.4404 (316, 316L)

Seal for temperature sensor

Seal-free (self-sealing NPT thread with sealant)

Pressure measuring cell

Stainless steel: 1.4404 (316, 316L)

Seal for pressure measuring cell

Seal-free (self-sealing NPT thread with sealant)

Accessories

Protective cover

Stainless steel, 1.4404 (316L)


External WLAN antenna

- Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Process connections

Flanges:

- EN 1092-1-B1
- ASME B16.5



16.11 Display and user interface

Languages

Can be operated in the following languages:


- Via local operation
 English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish,
 Chinese, Japanese, Korean, Vietnamese, Czech, Swedish
- Via web browser
 English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish,
 Chinese, Japanese, Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

Local operation

Via display module

Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"
- ho Information about WLAN interface ightarrow 🗎 69



■ 42 Operation with touch control

1 Proline 500 – digital

Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured

Operating elements

- External operation via touch control (3 optical keys) without opening the housing: \boxdot , \sqsubseteq ,
- Operating elements also accessible in the various zones of the hazardous area

Endress+Hauser 189

A003725

Remote operation	→ 🖺 67
Service interface	→ 🖺 68

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with web browser	CDI-RJ45 service interfaceWLAN interface	Special Documentation for device
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🖺 167
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🖺 167
Field Xpert	SMT70/77/50	 All Fieldbus protocols WLAN interface Bluetooth CDI-RJ45 service interface 	Operating Instructions BA01202S Device description files: Use update function of handheld terminal
SmartBlue App	Smart phone or tablet with iOs or Android	WLAN	→ 🖺 167

- Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
 - FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
 - Process Device Manager (PDM) from Siemens → www.siemens.com
 - Asset Management Solutions (AMS) from Emerson → www.emersonprocess.com
 - FieldCommunicator 375/475 from Emerson → www.emersonprocess.com
 - Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
 - FieldMate from Yokogawa → www.yokogawa.com
 - PACTWare → www.pactware.com

The related device description files are available: www.endress.com → Download Area

Web server

With the integrated web server, the device can be operated and configured via a web browser service interface (CDI-RJ45) or WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook, for example,) and measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup).
- Save the configuration to the measuring device (XML format, restore configuration).
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Flash firmware version for device firmware upgrade, for example
- Download driver for system integration
- Visualize up to 1000 saved measured values (only available with the Extended HistoROM application package→

 195)

HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	HistoROM backup	T-DAT	S-DAT
Available data	 Event logbook, e.g. diagnostic events Parameter data record backup Device firmware package 	 Measured value logging ("Extended HistoROM" order option) Current parameter data record (used by firmware at run time) Indicator (minimum/maximum values) Totalizer value 	 Sensor data: e.g. nominal diameter Serial number Calibration data Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface PC board in the connection compartment	Can be plugged into the user interface PC board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
 Backup and subsequent restoration of a device configuration in the device memory
 HistoROM backup
- Data comparison function
 Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transmission

Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the Extended HistoROM application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.q. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Recording of 1 to 4 channels of up to 1000 measured values (up to 250 measured values per channel)
- User configurable recording interval
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Downloads**.

CE mark

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

UKCA marking

The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

192

Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com

RCM marking

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.

Functional safety

The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL 3 (multi-channel architecture with homogeneous redundancy) and is independently evaluated and certified in accordance with IEC 61508.

The following types of monitoring in safety equipment are possible: Volume flow



Functional safety manual with information for the SIL device

HART certification

HART interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified according to HART 7
- The device can also be operated with certified devices of other manufacturers (interoperability)

Pressure Equipment Directive

- With the marking
 - a) PED/G1/x (x = category) or
 - b) PESR/G1/x (x = category)
 - on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements"
 - a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or
 - b) Schedule 2 of Statutory Instruments 2016 No. 1105.
- Devices not bearing this marking (without PED or PESR) are designed and manufactured according to sound engineering practice. They meet the requirements of
 - a) Art. 4 Para. 3 of the Pressure Equipment Directive 2014/68/EU or
 - b) Part 1, Para. 8 of Statutory Instruments 2016 No. 1105.

The scope of application is indicated

- a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or
- b) Schedule 3, Para. 2 of Statutory Instruments 2016 No. 1105.

Radio approval

The measuring device has radio approval.



Additional certification

CRN approval

Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.

Tests and certificates

- EN10204-3.1 material certificate, wetted parts and sensor housing (order code for "Test, certificate", option JA)
- Pressure test, internal process, Heartbeat Technology verification report (order code for "Test, certificate", option JB)
- Ambient temperature -50 °C (-58 °F) (order code for "Test, certificate", option JP)
- Helium leak testing, internal procedure, Heartbeat Technology verification report (order code for "Test, certificate", option KC)
- EN10204-2.1 confirmation of compliance with the order and EN10204-2.2 test report

Testing of welds

Order code for "Test, certificate", option	Radiographic testing standard		Process connection
	ISO 10675-1 ZG1	ASME B31.3 NFS	
KE	х		RT
KI		Х	RT
K5	х		DR
К6		Х	DR
RT = Radiographic testing, DR = Digital radiography All options with test report			

External standards and quidelines

■ EN 60529

Degrees of protection provided by enclosure (IP code)

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements

■ IEC/EN 61326-2-3

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

■ NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

■ NAMUR NE 107

Self-monitoring and diagnosis of field devices

■ NAMUR NE 131

Requirements for field devices for standard applications

■ ETSI EN 300 328

Guidelines for 2.4 GHz radio components.

■ EN 301489

Electromagnetic compatibility and radio spectrum matters (ERM).

■ AGA Report No. 9

Measurement of gas by multipath ultrasonic meters.

■ ISO 17089

Measurement of fluid flow in closed conduits — Ultrasonic meters for gas.

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



Detailed information on the application packages:

Special Documentation → 🗎 197

Diagnostic functionality

Order code for "Application package", option EA "Extended HistoROM"

Comprises extended functions concerning the event log and the activation of the measured value memory.

Event log:

Memory volume is extended from 20 message entries (standard version) to up to 100 entries.

Data logging (line recorder):

- Memory capacity for up to 1000 measured values is activated.
- 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.
- Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.



For detailed information, see the Operating Instructions for the device.

Heartbeat Technology

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

Heartbeat Verification

Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".

- Functional testing in the installed state without interrupting the process.
- Traceable verification results on request, including a report.
- Simple testing process via local operation or other operating interfaces.
- Clear measuring point assessment (pass/fail) with high total test coverage within the framework of manufacturer specifications.
- Extension of calibration intervals according to operator's risk evaluation.

Heartbeat Monitoring

Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:

- Draw conclusions using these data and other information about the impact the measuring application has on the measuring performance over time.
- Schedule servicing in time.
- Monitor the process or product quality.



For detailed information, see the Special Documentation for the device.

Advanced gas analysis

Order code for "Application package", option EF "Advanced gas analysis". The application package can only be ordered in combination with the order code for "Measuring tube; Transducer; Sensor version", option AC "316L; Titanium Gr. 2; pressure + temperature measurement integrated".

The application package can be used to calculate the most important gas properties (molar mass, gross calorific value, Wobbe index etc.).

The following gas types are available:

- Single gas (known gas)
- Gas mixture (known composition)
- Coal gas/biogas (measurement of methane fraction)
- Natural gas standardized calculation (with internationally recognized gas models: AGA NX-19. ISO 12213-2. ISO 12213-3. AGA 5. ISO 6976)
- Natural gas use of sound velocity (sound velocity-based model for measuring a natural gas whose composition is unknown or variable)
- User-specific gas (generic gas or gas mixture without knowledge of the composition of the gas)

16.14 Accessories



Overview of accessories available for order $\rightarrow = 165$

16.15 Supplemental documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation

Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Prosonic Flow G	KA01374D

Brief Operating Instructions for the transmitter

Measuring device	Documentation code
Proline 500 – digital	KA01377D

Technical Information

Measuring device	Documentation code
Prosonic Flow G 500	TI01386D

Description of Device Parameters

	Documentation code	
Measuring device	HART	Modbus RS485
Prosonic Flow G 500	GP01132D	GP01133D

Supplementary devicedependent documentation

Safety Instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex ia	XA01850D
ATEX/IECEx Ex ec	XA01849D
cCSAus Ex ia	XA01852D
cCSAus Ex ec	XA01851D
cCSAus XP	XA01853D
EAC Ex ia	XA02471D
EAC Ex nA	XA02472D
JPN Ex d	XA02077D
KCs Ex d	XA03193D
INMETRO Ex ia	XA01997D
INMETRO Ex ec	XA01998D
NEPSI Ex ia	XA02045D
NEPSI Ex nA	XA02046D
UKEX Ex ia	XA02576D
UKEX Ex ec	XA02577D

Functional Safety Manual

Contents	Documentation code
Proline Prosonic Flow G 500	SD02308D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Advanced gas analysis	SD02351D
Heartbeat Technology	SD02304D
Web server	SD02311D

Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via <i>Device Viewer</i> → □ 163 Accessories available for order with Installation Instructions → □ 165

Index

A	Connection cable
Access authorization to parameters	Connection preparations
Read access	Connection tools
Write access	Context menu
Access code	Calling up
Incorrect input	Closing
Adapting the diagnostic behavior 146	Explanation
Adapting the status signal	Current consumption
Additional certification	D
Ambient conditions	D
Operating height	Date of manufacture
Relative humidity	Declaration of Conformity
Shock and vibration resistance 183	Defining the access code
Storage temperature	Degree of protection 43, 182
Ambient temperature	Design
Influence	Measuring device
Ambient temperature range 23, 182	Operating menu
AMS Device Manager	Device components
Function	Device description files
Application	Device locking, status
Application packages	Device name
Applicator	Sensor
Approvals	Transmitter
	Device repair
В	Device revision
Burst mode	Device type code
	Device Viewer
C	DeviceCare
Cable entries	Device description file
Technical data	Diagnosis
Cable entry	Symbols
Degree of protection	Diagnostic behavior
CE mark	Explanation
Certificates	Symbols
Check	Diagnostic information
Connection	Design, description 140, 144
Mounting	DeviceCare
Checklist	FieldCare
Post-connection check	LEDs
Post-mounting check	Local display
Cleaning	Overview
Exterior cleaning	Remedial measures
Commissioning	Web browser
Advanced settings	Diagnostic message
Configuring the measuring device	Diagnostics list
Communication-specific data	Dimensions
Connecting the connecting cable	DIP switch
Proline 500 – digital transmitter	see Write protection switch
Sensor connection housing, Proline 500 - digital 34	Direct access
Terminal assignment of Proline 500 - digital 34	Disabling write protection
Connecting the measuring device	Display
Proline 500 – digital	see Local display
Connecting the signal cable/supply voltage cable	Display area
Proline 500 – digital transmitter	For operational display
Connection	In the navigation view 51
see Electrical connection	

198

Display values For locking status	Function 71 User interface 72
Displaying the measured value history 131	Filtering the event logbook
Disposal	Firmware
Document	Release date
Function 6	version
Symbols 6	Firmware history
Document function 6	Flow direction
_	Flow limit
E	Function range
Editing view	AMS Device Manager
Input screen	SIMATIC PDM
Using operating elements 53, 54	Function scope
Electrical connection	Field Communicator
Commubox FXA195 (USB) 67	Field Communicator 475
Computer with web browser (e.g. Microsoft Edge) 67	Field Xpert
Degree of protection	Functional Safety (SIL)
Field Communicator 475 67	Functions
Field Xpert SFX350/SFX370 67	see Parameters
Field Xpert SMT70 67	
Measuring device	G
Operating tool (e.g. FieldCare, AMS Device	Galvanic isolation
Manager, SIMATIC PDM) 67	TT
Operating tools	H
Via HART protocol 67	Hardware write protection
Via service interface (CDI-RJ45) 68	HART certification
Via WLAN interface 69	HART protocol
VIATOR Bluetooth modem 67	Device variables
Web server	Measured variables
WLAN interface 69	Help text
Electromagnetic compatibility	Calling up
Electronics module	Closing
Enabling write protection	Explanation
Enabling/disabling the keypad lock 60	HistoROM
Endress+Hauser services	Ī
Maintenance	_
Repair	Identifying the measuring device
Error messages	Incoming acceptance
see Diagnostic messages	Indication
Event logbook	Current diagnostic event
Events list	Previous diagnostic event
Ex approval	Influence
Extended order code	Ambient temperature
Sensor	Information about this document
Transmitter	Inlet runs
Exterior cleaning	Input
r.	Inspection
F	Received goods
Field Communicator	Intended use
Function	L
Field Communicator 475	Languages, operation options
Field of application	Line recorder
Residual risks	Local display
Field Xpert	Navigation view
Function	see Diagnostic message
Field Xpert SFX350	see In alarm condition
FieldCare	see Operational display
Device description file	Text editor
Establishing a connection 71	Low flow cut off
	10 17 110 17 Cut O11

M	Numeric editor
Main electronics module	0
Maintenance	
Maintenance tasks	Onsite display
Managing the device configuration	Numeric editor
Manufacturer ID	Operable flow range
Materials	Operating elements
Maximum measurement error	Operating height
Measured variables	Operating keys
Calculated	see Operating elements
Direct	Operating menu
Optional	Design
see Process variables	Menus, submenus
Measuring and test equipment	Submenus and user roles
Measuring device	Operating philosophy
Configuring	Operation
Conversion	Operation options
Design	Operational display
Disposal	Operational safety
Mounting the sensor 26	Order code
Preparing for electrical connection	Orientation (vertical, horizontal)
Preparing for mounting	Outlet runs
Removing	Output signal
Repairs	Output variables
Switching on	Р
Measuring principle	Packaging disposal 20
Measuring range	Parameter
Measuring range, recommended	Changing
Measuring system	Entering values or text
Menu	Parameter settings
Diagnostics	Administration (Submenu)
Setup	Advanced setup (Submenu)
Menus	Burst configuration 1 to n (Submenu)
For measuring device configuration	Configuration backup (Submenu) 112
For specific settings	Current input
Mounting	Current input (Wizard)
Mounting conditions	Current input 1 to n (Submenu) 125
Thermal insulation 24, 185	Current output
Mounting dimensions see Dimensions	Current output (Wizard)
	Data logging (Submenu)
Mounting location	Define access code (Wizard)
Mounting preparations	Device information (Submenu) 159
Dimensions	Diagnostics (Menu)
Inlet and outlet runs	Display (Submenu)
Mounting location	Display (Wizard)
Orientation	Double pulse output
Rupture disk	Double pulse output (Submenu) 128
Mounting tool	Double pulse output (Wizard) 98
iviounting tool	Gas analysis (Wizard)
N	I/O configuration
Nameplate	I/O configuration (Submenu) 84
Sensor	Low flow cut off (Wizard) 101
Transmitter	Process variables (Submenu) 122
Navigation path (navigation view) 51	Pulse/frequency/switch output 90
Navigation view	Pulse/frequency/switch output (Wizard) 90, 91, 94
In the submenu 51	Pulse/frequency/switch output 1 to n (Submenu) 127
In the wizard	Relay output
Netilion	Relay output 1 to n (Submenu) 127

200

7.1	
Relay output 1 to n (Wizard)	Sensor
Reset access code (Submenu)	Mounting
Sensor adjustment (Submenu)	Serial number
Setup (Menu)	Setting the operating language
Simulation (Submenu)	Settings
Status input	Adapting the measuring device to the process
Status input 1 to n (Submenu)	conditions
Status input 1 to n (Wizard)	Administration
System units (Submenu)	Advanced display configurations 107
System values (Submenu)	Current input
Totalizer (Submenu)	Current output
Totalizer 1 to n (Submenu)	Double pulse output
Totalizer handling (Submenu)	Gas analysis
Value current output 1 to n (Submenu) 126	I/O configuration
Web server (Submenu) 66	Local display
WLAN settings (Wizard)	Low flow cut off
Performance characteristics	Managing the device configuration
Post-connection check	Operating language 80
Post-connection check (checklist) 43	Pulse output
Post-mounting check	Pulse/frequency/switch output 90, 91
Post-mounting check (checklist) 28	Relay output
Potential equalization	Resetting the device
Power consumption	Resetting the totalizer
Power supply failure	Sensor adjustment
Pressure Equipment Directive	Simulation
Pressure loss	Status input
Pressure-temperature ratings	Switch output
Process connections	System units 82
Product safety	Tag name
Proline 500 – digital transmitter	Totalizer
Connecting the signal cable/supply voltage cable 37	Totalizer reset
Protecting parameter settings	WLAN
51	Shock and vibration resistance
R	Signal on alarm
Radio approval	SIL (functional safety)
RCM marking	SIMATIC PDM
Read access	Function
Reading off measured values	Software release
Recalibration	Sound velocity range
Reference operating conditions 179	Spare part
Registered trademarks	Spare parts
Remedial measures	Special connection instructions
Calling up	Standards and quidelines
Closing	Status area
Remote operation	For operational display
Repair	In the navigation view
Notes	Status signals
Repair of a device	Storage concept
Repeatability	Storage conditions
Replacement	Storage temperature
Device components	
Requirements for personnel	Storage temperature range
Return	
Rupture disk	Administration
Safety instructions	Advanced setup
Triggering pressure	Burst configuration 1 to n
Triggering pressure	Configuration backup
S	Current input 1 to n
Safety	Data logging
Jaicly	Device information

Display10Double pulse output12Events list15I/O configuration8Input values12Measured values12Output values12Overview4Process variables12	8 5 4 5 1 6 7
Process variables12Pulse/frequency/switch output 1 to n12Relay output 1 to n12Reset access code11Sensor adjustment10Simulation11Status input 1 to n12	2774556248596
Supply voltage	8
For communication	1 8 4 3
System integration	4
T Technical data, overview	3 9 3
Terminal assignment	3
Sensor connection housing 3 Terminals 17 Tests and certificates 19 Text editor 5 Thermal insulation 24, 18	8 4 3

For mounting
Tool tip
see Help text
Tools
For electrical connection 29
Transportation
Totalizer
Configuring
Transporting the measuring device
Troubleshooting
General
U
UKCA marking
Use of measuring device
Borderline cases
Incorrect use
see Intended use
User roles
17
V
Version data for the device
W
Weight
Transport (notes)
Wizard
Current input
Define access code
Display
Display
Double pulse output
Double pulse output
Gas analysis
Gas analysis
Gas analysis102Low flow cut off103Pulse/frequency/switch output90, 91, 94
Gas analysis
Gas analysis
Gas analysis102Low flow cut off103Pulse/frequency/switch output90, 91, 94Relay output 1 to n96Status input 1 to n85WLAN settings110
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110 Workplace safety 10
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110 Workplace safety 10 Write access 59
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110 Workplace safety 10 Write access 59 Write protection 90, 91, 94 Status input 1 to n 96 Status input 1 to n 85 WLAN settings 110 Workplace safety 10 Write protection 50
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110 Workplace safety 10 Write access 59 Write protection 117 Via access code 117
Gas analysis 102 Low flow cut off 103 Pulse/frequency/switch output 90, 91, 94 Relay output 1 to n 96 Status input 1 to n 85 WLAN settings 110 WLAN settings 110 Workplace safety 10 Write access 59 Write protection 90, 91, 94 Status input 1 to n 96 Status input 1 to n 85 WLAN settings 110 Workplace safety 10 Write protection 50



www.addresses.endress.com

