

Description of Device Parameters

Proline Prosonic Flow P 500

Ultrasonic time-of-flight flowmeter
HART




Table of contents

1 About this document	4	3.8 "Diagnostics" submenu	200
1.1 Document function	4	3.8.1 "Diagnostic list" submenu	203
1.2 Target group	4	3.8.2 "Event logbook" submenu	208
1.3 Using this document	4	3.8.3 "Device information" submenu	209
1.3.1 Information on the document structure	4	3.8.4 "Main electronic module + I/O module 1" submenu	213
1.3.2 Structure of a parameter description ..	6	3.8.5 "Sensor electronic module (ISEM)" submenu	214
1.4 Symbols used	6	3.8.6 "I/O module 2" submenu	215
1.4.1 Symbols for certain types of information	6	3.8.7 "I/O module 3" submenu	216
1.4.2 Symbols in graphics	7	3.8.8 "Display module" submenu	218
1.5 Documentation	7	3.8.9 "Data logging" submenu	219
1.5.1 Standard documentation	7	3.8.10 "Heartbeat Technology" submenu ..	227
1.5.2 Supplementary device-dependent documentation	7	3.8.11 "Simulation" submenu	237
2 Overview of the Expert operating menu	8	4 Country-specific factory settings ..	248
3 Description of device parameters ...	11	4.1 SI units	248
3.1 "System" submenu	13	4.1.1 System units	248
3.1.1 "Display" submenu	14	4.1.2 Output current span	248
3.1.2 "Configuration backup" submenu	26	4.2 US units	248
3.1.3 "Diagnostic handling" submenu	29	4.2.1 System units	248
3.1.4 "Administration" submenu	38	4.2.2 Output current span	248
3.2 "Sensor" submenu	43	5 Explanation of abbreviated units ..	249
3.2.1 "Measured values" submenu	44	5.1 SI units	249
3.2.2 "System units" submenu	61	5.2 US units	249
3.2.3 "Measuring point" submenu	69	5.3 Imperial units	250
3.2.4 "Installation status" submenu	84	Index	251
3.2.5 "Process parameters" submenu	86		
3.2.6 "External compensation" submenu ..	90		
3.2.7 "Sensor adjustment" submenu	94		
3.2.8 "Calibration" submenu	98		
3.3 "I/O configuration" submenu	100		
3.4 "Input" submenu	102		
3.4.1 "Current input 1 to n" submenu	102		
3.4.2 "Status input 1 to n" submenu	105		
3.5 "Output" submenu	107		
3.5.1 "Current output 1 to n" submenu	107		
3.5.2 "Pulse/frequency/switch output 1 to n" submenu	120		
3.5.3 "Relay output 1 to n" submenu	140		
3.5.4 "Double pulse output" submenu	147		
3.6 "Communication" submenu	153		
3.6.1 "HART input" submenu	153		
3.6.2 "HART output" submenu	159		
3.6.3 "Web server" submenu	176		
3.6.4 "Diagnostic configuration" submenu ..	179		
3.6.5 "WLAN settings" wizard	188		
3.7 "Application" submenu	195		
3.7.1 "Totalizer 1 to n" submenu	195		
3.7.2 "Petroleum" submenu	200		
3.7.3 "Product identification" submenu ...	200		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code) or Web browser  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Options	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Parameter entry range
Display	Display value/data of the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display <small>A0028662</small>
	Operation via operating tool <small>A0028663</small>
	Write-protected parameter <small>A0028665</small>

1.4.2 Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Prosonic Flow P 500	BA02025D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Contents	Documentation code
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
FlowDC	SD02660D
Heartbeat Technology	SD02593D
High-temperature sensors	SD03088D
Petroleum & product identification	SD03081D
Web server	SD02603D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
User role (0005)	→ 13
Enter access code (0003)	→ 13
 System	→ 13
► Display	→ 14
► Configuration backup	→ 26
► Diagnostic handling	→ 29
► Administration	→ 38
 Sensor	→ 43
► Measured values	→ 44
► System units	→ 61
► Measuring point 1	→ 69
► Installation status	→ 84
► Process parameters	→ 86
► External compensation	→ 90
► Sensor adjustment	→ 94
► Calibration	→ 98
 I/O configuration	→ 100
I/O module 1 to n terminal numbers (3902-1 to n)	→ 100

I/O module 1 to n information (3906-1 to n)	→ 100
I/O module 1 to n type (3901-1 to n)	→ 101
Apply I/O configuration (3907)	→ 101
I/O alteration code (2762)	→ 102
▶ Input	→ 102
▶ Current input 1 to n	→ 102
▶ Status input 1 to n	→ 105
▶ Output	→ 107
▶ Current output 1 to n	→ 107
▶ Pulse/frequency/switch output 1 to n	→ 120
▶ Relay output 1 to n	→ 140
▶ Double pulse output	→ 147
▶ Communication	→ 153
▶ HART input	→ 153
▶ HART output	→ 159
▶ Diagnostic configuration	→ 179
▶ Web server	→ 176
▶ WLAN settings	→ 188
▶ Application	→ 195
Reset all totalizers (2806)	→ 195
▶ Totalizer 1 to n	→ 195

▶ Petroleum	→ 200
▶ Product identification	→ 200
▶ Diagnostics	→ 200
Actual diagnostics (0691)	→ 201
Previous diagnostics (0690)	→ 202
Operating time from restart (0653)	→ 203
Operating time (0652)	→ 203
▶ Diagnostic list	→ 203
▶ Event logbook	→ 208
▶ Device information	→ 209
▶ Main electronic module + I/O module 1	→ 213
▶ Sensor electronic module (ISEM)	→ 214
▶ I/O module 2	→ 215
▶ I/O module 3	→ 216
▶ Display module	→ 218
▶ Data logging	→ 219
▶ Heartbeat Technology	→ 227
▶ Simulation	→ 237

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
User role (0005)	→ 13
Enter access code (0003)	→ 13
▶ System	→ 13
▶ Sensor	→ 43
▶ I/O configuration	→ 100
▶ Input	→ 102
▶ Output	→ 107
▶ Communication	→ 153
▶ Application	→ 195
▶ Diagnostics	→ 200

Direct access



Navigation

Expert → Direct access (0106)

Description

Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.


User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter 00914 → **Assign process variable** parameter (0914)
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign process variable** parameter (0914)

Locking status

Navigation

 Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- SIL locked
- Temporarily locked

Additional information

Display

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7

Options

Options	Description
None	The access authorization displayed in the Access status parameter (0005) (→  13) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool).
SIL locked (priority 2)	The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

User role


Navigation	 Expert → User role (0005)
Description	Displays the access authorization to the parameters via the local display, Web browser or operating tool.
User interface	<ul style="list-style-type: none"> ▪ Maintenance ▪ Service
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Enter access code parameter (0003) (→ 13).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7</p>

Enter access code

Navigation	 Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation  Expert → System



3.1.1 "Display" submenu

Navigation

Expert → System → Display

► Display	
Display language (0104)	→ 15
Format display (0098)	→ 15
Value 1 display (0107)	→ 17
0% bargraph value 1 (0123)	→ 18
100% bargraph value 1 (0125)	→ 18
Decimal places 1 (0095)	→ 18
Value 2 display (0108)	→ 19
Decimal places 2 (0117)	→ 19
Value 3 display (0110)	→ 20
0% bargraph value 3 (0124)	→ 20
100% bargraph value 3 (0126)	→ 21
Decimal places 3 (0118)	→ 21
Value 4 display (0109)	→ 22
Decimal places 4 (0119)	→ 22
Display interval (0096)	→ 23
Display damping (0094)	→ 23
Header (0097)	→ 24
Header text (0112)	→ 24
Separator (0101)	→ 25
Contrast display (0105)	→ 25
Backlight (0111)	→ 25

Display language

Navigation   Expert → System → Display → Display language (0104)

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation   Expert → System → Display → Format display (0098)

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting 1 value, max. size

Additional information *Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 8) can be configured. This setting only applies to normal operation.

-  ■ The **Value 1 display** parameter (0107) (→  17)...**Value 8 display** parameter (0148) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (0096) (→  23).


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option



A0016530


"2 values" option



A0016531


2

"1 value large + 2 values" option



A0016532

"4 values" option



A0016533

Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select a measured value that is shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Mass flow ■ Flow velocity ■ Sound velocity ■ Volume flow ■ Density * ■ Reference density * ■ S&W volume flow * ■ GSV flow * ■ NSV flow * ■ API gravity * ■ API slope * ■ Signal strength * ■ Signal to noise ratio * ■ Acceptance rate * ■ Turbulence * ■ Electronics temperature ■ Temperature * ■ Pressure * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Current output 1 ■ Current output 2 * ■ Current output 3 * ■ Profile factor * ■ Cross flow factor *
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If there are several measured values one below the other, this appears in the first position. The value is only displayed during normal operation.</p> <p> The Format display parameter (0098) (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 61).</p>

* Visibility depends on order options or device settings

0% bargraph value 1



Navigation

Expert → System → Display → 0% bargraph 1 (0123)

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Country-specific

Additional information

Description

The **Format display** parameter (0098) (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

100% bargraph value 1



Navigation

Expert → System → Display → 100% bargraph 1 (0125)

Prerequisite

A local display is provided.

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information

Description

The **Format display** parameter (0098) (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

Decimal places 1



Navigation

Expert → System → Display → Decimal places 1 (0095)

Prerequisite

A measured value is specified in the **Value 1 display** parameter (0107) (→ 17).

Description Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*



This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 2 display



Navigation Expert → System → Display → Value 2 display (0108)

Prerequisite A local display is provided.

Description Use this function to select a measured value that is shown on the local display.

Selection For the picklist, see **Value 1 display** parameter (0107) (→ 17)

Factory setting None

Additional information *Description*



If there are several measured values one below the other, this appears in the second position. The value is only displayed during normal operation.



The **Format display** parameter (0098) (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Dependency



The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

Decimal places 2



Navigation Expert → System → Display → Decimal places 2 (0117)

Prerequisite A measured value is specified in the **Value 2 display** parameter (0108) (→ 19).

Description Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

-  This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 3 display**Navigation**  Expert → System → Display → Value 3 display (0110)**Prerequisite**

A local display is provided.

Description

Use this function to select a measured value that is shown on the local display.

SelectionFor the picklist, see **Value 1 display** parameter (0107) (→  17)**Factory setting**

None

Additional information*Description*

If several measured values are displayed one below the other, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.

-  The **Format display** parameter (0098) (→  15) is used to specify how many measured values are displayed simultaneously and how.

Options

-  The unit of the displayed measured value is taken from the **System units** submenu (→  61).

0% bargraph value 3**Navigation**  Expert → System → Display → 0% bargraph 3 (0124)**Prerequisite**A selection was made in the **Value 3 display** parameter (0110) (→  20).**Description**

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

Country-specific

Additional information*Description*

The **Format display** parameter (0098) (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

100% bargraph value 3**Navigation**

Expert → System → Display → 100% bargraph 3 (0126)

Prerequisite

A selection was made in the **Value 3 display** parameter (0110) (→ 20).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The **Format display** parameter (0098) (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

Decimal places 3**Navigation**

Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (0110) (→ 20).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 4 display

Navigation	Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.
Description	Use this function to select a measured value that is shown on the local display.
Selection	For the picklist, see Value 1 display parameter (0107) (→ 17)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed one below the other, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation. The Format display parameter (0098) (→ 15) is used to specify how many measured values are displayed simultaneously and how. <i>Options</i> The unit of the displayed measured value is taken from the System units submenu (→ 61).

Decimal places 4

Navigation	Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (0109) (→ 22).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	<ul style="list-style-type: none"><input type="checkbox"/> X<input type="checkbox"/> X.X<input type="checkbox"/> X.XX<input type="checkbox"/> X.XXX<input type="checkbox"/> X.XXXX
Factory setting	X.XX
Additional information	<i>Description</i> This setting does not affect the accuracy of the device for measuring or calculating the value.

Display interval

Navigation	 Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s
Factory setting	5 s
Additional information	<p><i>Description</i></p> <p>This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.</p> <p> ■ The Value 1 display parameter (0107) (→  17)...Value 8 display parameter (0148) are used to specify which measured values are shown on the local display.</p> <p>■ The display format for the measured values displayed is defined in the Format display parameter (0098) (→  15).</p>

Display damping



Navigation	 Expert → System → Display → Display damping (0094)
Prerequisite	A local display is provided.
Description	Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	0.0 s
Additional information	<p><i>User entry</i></p> <p>Use this function to enter a time constant (PT1 element¹⁾) for display damping:</p> <ul style="list-style-type: none"> ■ At a low time constant, the display reacts quickly to fluctuating measured variables. ■ If a high time constant is entered, the display reacts more slowly. <p> The damping is not active if the value 0 (factory setting) is entered.</p>

1) proportional transmission behavior with first order delay

Header**Navigation**

Expert → System → Display → Header (0097)

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

Selection

- Device tag
 - Is defined in the **Device tag** parameter (0011) (→ 210).
- Free text
 - Is defined in the **Header text** parameter (0112) (→ 24).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

The **Free text** option is selected in the **Header** parameter (0097) (→ 24).

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator



Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Backlight

Navigation Expert → System → Display → Backlight (0111)

Prerequisite One of the following conditions is met:

- Order code for "Display; operation", option F "4-line, illum.; touch control"
- Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN"

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

3.1.2 "Configuration backup" submenu

Navigation Expert → System → Config. backup

Configuration backup	
Operating time (0652)	→ 26
Last backup (2757)	→ 26
Configuration management (2758)	→ 27
Backup state (2759)	→ 27
Comparison result (2760)	→ 28

Operating time

Navigation Expert → System → Config. backup → Operating time (0652)

Description Displays the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Indication*

Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

Last backup

Navigation Expert → System → Config. backup → Last backup (2757)

Description Displays the time since a backup copy of the data was last saved to the device memory.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Configuration management

Navigation	Expert → System → Config. backup → Config. managem. (2758)
Description	Use this function to select an action to save the data to the device memory.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Execute backup ■ Restore * ■ Compare * ■ Clear backup data
Factory setting	Cancel
Additional information	<i>Selection</i>

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device. The following message appears on local display: Backup active, please wait!
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device. The following message appears on local display: Restore active! Do not interrupt power supply!
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup. The following message appears on local display: Comparing files The result can be viewed in Comparison result parameter (0103).
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device. The following message appears on local display: Deleting file

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state

Navigation	Expert → System → Config. backup → Backup state (2759)
Description	Displays the status of the data backup process.
User interface	<ul style="list-style-type: none"> ■ None ■ Backup in progress ■ Restoring in progress ■ Delete in progress

* Visibility depends on order options or device settings

- Compare in progress
- Restoring failed
- Backup failed

Factory setting None

Comparison result

Navigation  Expert → System → Config. backup → Compar. result (2760)

Description Displays the last result of the comparison of the data records in the device memory and in the HistoROM.

User interface

- Settings identical
- Settings not identical
- No backup available
- Backup settings corrupt
- Check not done
- Dataset incompatible

Factory setting Check not done

Additional information *Description*

 The comparison is started via the **Compare** option in the **Configuration management** parameter (2758) (→  27).

Options

Options	Description
Settings identical	The current device configuration of the HistoROM is not identical to the backup copy in the device memory. If the transformer configuration of another device has been transmitted to the device via HistoROM in Configuration management parameter (0100), the current device configuration of the HistoROM is only partially identical to the backup copy in the device memory: The settings for the transmitter are not identical.
Settings not identical	The current device configuration of the HistoROM is not identical to the backup copy in the device memory.
No backup available	There is no backup copy of the device configuration of the HistoROM in the device memory.
Backup settings corrupt	The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the device memory.
Check not done	The device configuration of the HistoROM has not yet been compared to the backup copy in the device memory.
Dataset incompatible	The backup copy in the device memory is not compatible with the device.


HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagnostic handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay



Navigation

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information

Effect

This setting affects the following diagnostic messages:

- 832 Electronics temperature too high
- 833 Electronics temperature too low
- △S841 Flow velocity too high
- △S870 Measuring inaccuracy increased

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 29).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Options	Description
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (→ 208) (Event list submenu (→ 208)) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Navigation

Expert → System → Diagn. handling → Diagn. behavior

Diagnostic behavior

Assign behavior of diagnostic no. 019 (0635)	→ 31
Assign behavior of diagnostic no. 160 (0776)	→ 31
Assign behavior of diagnostic no. 302 (0742)	→ 32
Assign behavior of diagnostic no. 441 (0657)	→ 32
Assign behavior of diagnostic no. 442 (0658)	→ 32
Assign behavior of diagnostic no. 443 (0659)	→ 33
Assign behavior of diagnostic no. 444 (0740)	→ 34
Assign behavior of diagnostic no. 543 (0643)	→ 34
Assign behavior of diagnostic no. 832 (0675)	→ 35
Assign behavior of diagnostic no. 833 (0676)	→ 35
Assign behavior of diagnostic no. 841 (0680)	→ 36
Assign behavior of diagnostic no. 842 (0638)	→ 36
Assign behavior of diagnostic no. 930 (0639)	→ 37

Assign behavior of diagnostic no. 931 (0640)	→ 37
Assign behavior of diagnostic no. 870 (0726)	→ 36
Assign behavior of diagnostic no. 941 (0783)	→ 33
Assign behavior of diagnostic no. 942 (0780)	→ 33
Assign behavior of diagnostic no. 943 (0781)	→ 34

Assign behavior of diagnostic no. 019 (Device initialization active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 019 (0635)

Description

Use this function to change the diagnostic behavior of the **△S019 Device initialization active** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available: → 29

Assign behavior of diagnostic no. 160 (Signal path switched off)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)

Description

Use this function to change the diagnostic behavior of the **160 Signal path switched off** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available: → 29

Assign behavior of diagnostic no. 302 (Device verification active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0742)

Description

Use this function to change the diagnostic behavior of the **302 Device verification active** diagnostic message.

Selection

- Off
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available: → [29](#)

Assign behavior of diagnostic no. 441 (Current output 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)

Description

Use this function to change the diagnostic behavior of the **441 Current output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Selection

For a detailed description of the options available: → [29](#)

Assign behavior of diagnostic no. 442 (Frequency output 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the **442 Frequency output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional informationFor a detailed description of the options available: → [29](#)**Assign behavior of diagnostic no. 443 (Pulse output)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

DescriptionUse this function to change the diagnostic behavior of the **443 Pulse output** diagnostic message.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information*Selection*For a detailed description of the options available: → [29](#)**Assign behavior of diagnostic no. 941****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 941 (0783)

Description

Change behavior of diagnostic event with diagnostic number 941 'API/ASTM temperature out of specifcat.'.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Assign behavior of diagnostic no. 942**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 942 (0780)

Description

Change behavior of diagnostic event with diagnostic number 942 'API/ASTM density out of specification'.

Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
------------------	--

Factory setting	Warning
------------------------	---------

Assign behavior of diagnostic no. 943



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 943 (0781)
Description	Change behavior of diagnostic event with diagnostic number 943 'API pressure out of specification'.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning

Assign behavior of diagnostic no. 444 (Current input 1 to n)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 444 (0740)
Prerequisite	The device has one current input.
Description	Use this function to change the diagnostic behavior of the 444 Current input 1 to n diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available: → 29

Assign behavior of diagnostic no. 543 (Double pulse output)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 543 (0643)
Description	Use this function to change the diagnostic behavior of the 543 Double pulse output diagnostic message.

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	 For a detailed description of the options available: → 29
-------------------------------	---

Assign behavior of diagnostic no. 832 (Electronics temperature too high)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)
-------------------	---

Description	Use this function to change the diagnostic behavior of the 832 Electronics temperature too high diagnostic message.
--------------------	--

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	 For a detailed description of the options available: → 29
-------------------------------	---

Assign behavior of diagnostic no. 833 (Electronics temperature too low)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
-------------------	---

Description	Use this function to change the diagnostic behavior of the 833 Electronics temperature too low diagnostic message.
--------------------	---

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
------------------	--

Factory setting	Warning
------------------------	---------

Additional information	<i>Selection</i>
-------------------------------	------------------

 For a detailed description of the options available: → 29

Assign behavior of diagnostic no. 841**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 841 (0680)

Description

Use this function to change the diagnostic behavior of the **841 Flow velocity too high** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available: → [29](#)

Assign behavior of diagnostic no. 842 (Process limit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)

Description

Use this function to change the diagnostic behavior of the **842 Process limit** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Off

Additional information

For a detailed description of the options available: → [29](#)

Assign behavior of diagnostic no. 870 (Measuring inaccuracy increased)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 870 (0726)

Description

Use this function to change the diagnostic behavior of the **870 Measuring inaccuracy increased** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Off

Additional information*Selection*For a detailed description of the options available: → [29](#)**Assign behavior of diagnostic no. 930 (Process fluid)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 930 (0639)

DescriptionUse this function to change the diagnostic behavior of the **△S930 Process fluid** diagnostic message.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional informationFor a detailed description of the options available: → [29](#)**Assign behavior of diagnostic no. 931 (Process fluid)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 931 (0640)

DescriptionUse this function to change the diagnostic behavior of the **△S931 Process fluid** diagnostic message.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional informationFor a detailed description of the options available: → [29](#)**Assign behavior of diagnostic no. 953 (Asymmetry noise signal too high path 1 to n)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 953 (0636)

DescriptionUse this function to change the diagnostic behavior of the **△M953 Asymmetry noise signal too high path 1 to n** diagnostic message.

Selection


- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional information For a detailed description of the options available: → [29](#)


3.1.4 "Administration" submenu

Navigation Expert → System → Administration

"Define access code" wizard

 The **Define access code** wizard (→ [38](#)) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (0093) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation Expert → System → Administration → Def. access code

Define access code**Navigation**

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the device configuration against any inadvertent modifications via the local display, Web browser, FieldCare or DeviceCare (via CDI-RJ45 service interface).

User entry

Max. 16-digit character string comprising numbers, letters and special characters

Additional information*Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (0003) (→ 13).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code**Navigation**

Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

Max. 16-digit character string comprising numbers, letters and special characters

"Reset access code" submenu*Navigation*

Expert → System → Administration → Reset acc. code

► Reset access code

Operating time (0652)	→ 40
Reset access code (0024)	→ 40

Operating time

Navigation	Expert → System → Administration → Reset acc. code → Operating time (0652)
Description	Displays the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Indication</i> Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

Reset access code

Navigation	Expert → System → Administration → Reset acc. code → Reset acc. code (0024)
Description	Use this function to enter a reset code to reset the user-specific access codes to the factory setting .
User entry	Character string comprising numbers, letters and special characters
Factory setting	0x00
Additional information	<i>Description</i> For a reset code, contact your Endress+Hauser service organization. <i>User entry</i> The reset code can only be entered via: <ul style="list-style-type: none">■ Web browser■ DeviceCare, FieldCare (via CDI RJ45 interface)■ Fieldbus

Additional parameters in the "Administration" submenu

Device reset

Navigation Expert → System → Administration → Device reset (0000)

Description Reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *

Factory setting Cancel

Additional information *Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Restore S-DAT backup	Restores the data that is saved on the S-DAT. Additional information: This function can be used to resolve the memory issue "083 Memory content inconsistent" or to restore the S-DAT data when a new S-DAT has been installed. This option is displayed only in an alarm condition.

Transmitter identifier

Navigation Expert → System → Administration → Transm. identif. (2765)

Description Select transmitter identifier.

User interface

- Unknown
- 500
- 300

Factory setting 500

* Visibility depends on order options or device settings

Activate SW option



Navigation

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string of numbers.

Factory setting

Depends on the software option ordered

Additional information

Description

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

Entering the activation code

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (0015) (→ 42).
 - ↳ The new software option is active if it is displayed.
 - ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ 42).

Web browser

Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation

Expert → System → Administration → SW option overv. (0015)

Description


Displays all the software options that are enabled in the device.

User interface	<ul style="list-style-type: none"> ▪ Extended HistoROM ▪ SIL ▪ Flow disturbance compensation * ▪ Heartbeat Monitoring ▪ Heartbeat Verification ▪ Petroleum * ▪ Product identification *
Additional information	<i>Description</i>
	Displays all the options that are available if ordered by the customer.
	<i>"Extended HistoROM" option</i>
	Order code for "Application package", option EA "Extended HistoROM"
	<i>"SIL" option</i>
	Order code for "Additional approval", option LA "SIL"
	<i>"Heartbeat Verification" option and "Heartbeat Monitoring" option</i>
	Order code for "Application package", option EB "Heartbeat Verification + Monitoring"
	<i>"Petroleum" option</i>
	Order code for "Application package", option EJ "Petroleum" or Order code for "Application package", option EQ "Petroleum & Product identification"
	<i>"Product identification" option</i>
	Order code for "Application package", option EQ "Petroleum & Product identification"
	<i>"Flow disturbance compensation" option</i>
	This option is available by default if 2 sensor pairs have been ordered.

3.2 "Sensor" submenu

Navigation

Expert → Sensor



* Visibility depends on order options or device settings

▶ Process parameters	→ 86
▶ External compensation	→ 90
▶ Sensor adjustment	→ 94
▶ Calibration	→ 98

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

▶ Measured values	
▶ Process variables	→ 44
▶ System values	→ 51
▶ Totalizer	→ 53
▶ Input values	→ 55
▶ Output values	→ 57

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

▶ Process variables	
Volume flow (1838)	→ 45
Mass flow (1847)	→ 45
Flow velocity (1852)	→ 45
Sound velocity (1850)	→ 46
Pressure (1872)	→ 46
Energy flow (1851)	→ 46
CPL (4192)	→ 47
CTL (4191)	→ 47
CTPL (4193)	→ 48

GSV flow (4157)	→ 48
NSV flow (4159)	→ 49
S&W correction value (4194)	→ 49
S&W volume flow (4161)	→ 50
API gravity (4211)	→ 50
API slope (4210)	→ 51
Reference density (4212)	→ 51

Volume flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)
Description	Displays the volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Volume flow unit parameter (0553) (→ 62)

Mass flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)
Description	Displays the mass flow that is currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Mass flow unit parameter (0554) (→ 65)

Flow velocity

Navigation	Expert → Sensor → Measured val. → Process variab. → Flow velocity (1852)
Description	Displays the average flow velocity that is currently calculated.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Velocity unit** parameter (0566) (→ [66](#))

Sound velocity

Navigation  Expert → Sensor → Measured val. → Process variab. → Sound velocity (1850)

Description Displays the sound velocity that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Velocity unit** parameter (0566) (→ [66](#))

Pressure

Navigation  Expert → Sensor → Measured val. → Process variab. → Pressure (1872)

Prerequisite For the following order code:

- "Application package", option **EJ** "Petroleum"
- The **API referenced correction** option is selected in the **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ [42](#)).

Description Shows depending on the setting the external, entered or measured pressure value.

User interface Signed floating-point number

Additional information *Dependency*

Energy flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Energy flow (1851)

Description Shows the energy flow currently calculated.

User interface Signed floating-point number

Additional information

CPL

Navigation

  Expert → Sensor → Measured val. → Process variab. → CPL (4192)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Displays the calibration factor which represents the effect of pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at reference pressure.

User interface

Positive floating-point number

Factory setting

–

CTL

Navigation

  Expert → Sensor → Measured val. → Process variab. → CTL (4191)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Displays the calibration factor which represents the effect of temperature on the fluid. This is used to convert the measured volume flow and the measured density to values at reference temperature.

User interface

Positive floating-point number

Factory setting

–

CTPL

Navigation

Expert → Sensor → Measured val. → Process variab. → CTPL (4193)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ 42).

Description

Displays the combined calibration factor which represents the effect of temperature and pressure on the fluid. This is used to convert the measured volume flow and the measured density to values at reference temperature and reference pressure.

User interface

Positive floating-point number

Factory setting

–

GSV flow

Navigation

Expert → Sensor → Measured val. → Process variab. → GSV flow (4157)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ 42).

Description

Displays the measured total volume flow, corrected to the reference temperature and the reference pressure.

Dependency

The unit is taken from: **Corrected volume flow unit** parameter (0558)

User interface

Signed floating-point number

Factory setting

–

Additional information

 The unit is taken from the **Corrected volume flow unit** parameter (0558)

NSV flow

Navigation  Expert → Sensor → Measured val. → Process variab. → NSV flow (4159)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Displays the net volume flow which is calculated from the measured total volume flow minus the value for sediment & water and minus the shrinkage.

Dependency

The unit is taken from: **Corrected volume flow unit** parameter (0558)

User interface

Signed floating-point number

Factory setting

–

Additional information

 The unit is taken from the **Corrected volume flow unit** parameter (0558)

S&W correction value

Navigation  Expert → Sensor → Measured val. → Process variab. → S&W correction (4194)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **External value** option or **Current input 1...n** option is selected in the **S&W input mode** parameter (4189).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Shows the correction value for sediment and water.

User interface

Positive floating-point number

Factory setting

–

S&W volume flow

Navigation

  Expert → Sensor → Measured val. → Process variab. → S&W volume flow (4161)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Displays the S&W volume flow which is calculated from the measured total volume flow minus the net volume flow.

Dependency

The unit is taken from: **Volume flow unit** parameter (0553) (→  62)

User interface

Signed floating-point number

Factory setting

–

Additional information

 The unit is taken from the **Volume flow unit** parameter (0553) (→  62)

API gravity

Navigation

  Expert → Sensor → Measured val. → Process variab. → API gravity (4211)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Displays the reference density in API degrees (specified depending on the option, or read in by an external device).

User interface

0.0 to 100.0 °API

Factory setting

–

API slope

Navigation  Expert → Sensor → Measured val. → Process variab. → API slope (4210)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description Shows the API slope (change of API over time). Can be used e.g. to detect different products.

User interface -10 to 100 °API/s

Factory setting -

Reference density

Navigation  Expert → Sensor → Measured val. → Process variab. → Ref.density (4212)

Prerequisite

For the following order code:

- "Application package", option EJ "Petroleum"
- "Application package", option EQ "Petroleum & Product identification"
- The **API referenced correction** option is selected in **Petroleum mode** parameter (4187).

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description Shows the reference density at the API reference conditions specified for temperature and pressure.

User interface 0 to 30 kg/Nm³

Factory setting -

"System values" submenu

Navigation  Expert → Sensor → Measured val. → System values

 **System values**

Signal strength (2914)

→  52

Signal to noise ratio (2917)	→ 52
Acceptance rate (2912)	→ 52
Turbulence (2907)	→ 53

Signal strength

Navigation Expert → Sensor → Measured val. → System values → Signal strength (2914)

Description Displays the current signal strength.

User interface Signed floating-point number

Additional information *Description*

A drop in the signal strength over time can be an indicator of process changes, such as the development of deposits in the measuring pipe at the measuring point. This can only be quantified by performing a direct process comparison with different deposit layer thicknesses and associated signal strengths.

Signal to noise ratio

Navigation Expert → Sensor → Measured val. → System values → SNR (2917)

Description Displays the current signal to noise ratio.

User interface Signed floating-point number

Additional information *Description*

A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality.

Acceptance rate

Navigation Expert → Sensor → Measured val. → System values → Acceptance rate (2912)

Description Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted.

Multipath measuring devices only: Displays the minimum of all acceptance rates measured.


User interface 0 to 100 %

Turbulence

Navigation	Expert → Sensor → Measured val. → System values → Turbulence (2907)
Description	Displays the current turbulence.
User interface	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>A high turbulence value indicates a disturbance in the flow profile.</p>

"Totalizer" submenu

Navigation Expert → Sensor → Measured val. → Totalizer



Totalizer 1 to n value

Navigation	Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n value (0911-1 to n)
Prerequisite	One of the following options is selected in the Assign process variable parameter (0914) (→ 196) of the Totalizer 1 to n submenu: ■ Volume flow ■ Mass flow
Description	Displays the current totalizer reading.
User interface	Signed floating-point number

Additional information*Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to n** parameter (0910-1 to n) if the display range is exceeded.

-  In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (0901) (→ [199](#)).

Display

The value of the process variable aggregated since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (0908) (→ [198](#)).

-  The unit of the selected process variable is defined in the **Unit totalizer** parameter (0915) (→ [197](#)) for the totalizer.

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter (0911): 1968 457 m³
- Value in the **Totalizer overflow 1** parameter (0910): $1 \cdot 10^7$ (1 overflow) = 10 000 000 m³
- Current totalizer value: 11 968 457 m³

Totalizer 1 to n overflow**Navigation**

 Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n overflow (0910-1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (0914) (→ [196](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to n** parameter (0911-1 to n).

Display

-  The unit of the selected process variable is defined in the **Unit totalizer** parameter (0915) (→ [197](#)) for the totalizer.

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter (0911): 1968 457 m³
- Value in the **Totalizer overflow 1** parameter (0910): $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer value: 21 968 457 m³

Totalizer 1 to n value

Navigation	 Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n value
Description	Shows the totalizer value reported to the controller for further processing.
User interface	Signed floating-point number
Factory setting	0 m ³

Totalizer 1 to n status


Navigation	 Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n status
Description	Shows the status of the totalizer value reported to the controller for further processing ('Good', 'Uncertain', 'Bad').
User interface	<ul style="list-style-type: none"> ■ Good ■ Uncertain ■ Bad
Factory setting	Good

Totalizer 1 to n status (Hex)

Navigation	 Expert → Sensor → Measured val. → Totalizer → Status 1 to n (Hex)
Description	Shows the status of the totalizer value reported to the controller for further processing (Hex).
User interface	0 to 255
Factory setting	128


"Input values" submenu

Navigation  Expert → Sensor → Measured val. → Input values



*"Current input 1 to n" submenu***Navigation**

Expert → Sensor → Measured val. → Input values → Current input 1 to n



Measured values 1 to n

Navigation

Expert → Sensor → Measured val. → Input values → Current input 1 to n
→ Measured val. 1 to n (1603-1 to n)

Description

Displays the current input value.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Pressure unit** parameter (0564)

Measured current 1 to n

Navigation

Expert → Sensor → Measured val. → Input values → Current input 1 to n → Measur.
curr. 1 to n (1604-1 to n)

Description


Displays the current value of the current input.

User interface

0 to 22.5 mA

*"Value status input 1 to n" submenu***Navigation**

Expert → Sensor → Measured val. → Input values → Val.stat.inp.
1 to n



Value status input

Navigation  Expert → Sensor → Measured val. → Input values → Val.stat.inp. 1 to n
→ Val.stat.inp. (1353–1 to n)


Description Displays the current input signal level.

User interface

- High
- Low


"Output values" submenu

Navigation  Expert → Sensor → Measured val. → Output values



"Value current output 1 to n" submenu

Navigation  Expert → Sensor → Measured val. → Output values → Current output 1 to n



Output current

Navigation  Expert → Sensor → Measured val. → Output values → Current output 1 to n
→ Output curr. (0361–1 to n)

Description Displays the current value currently calculated for the current output.

User interface 0 to 22.5 mA

Measured current


Navigation  Expert → Sensor → Measured val. → Output values → Current output 1 to n
→ Measur. curr. (0366-1 to n)

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA

"Pulse/frequency/switch output 1 to n" submenu

Navigation  Expert → Sensor → Measured val. → Output values → PFS output 1 to n



Output frequency

Navigation  Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Output freq. (0471-1 to n)

Prerequisite In the **Operating mode** parameter (0469) (→  122), the **Frequency** option is selected.

Description Displays the actual value of the output frequency which is currently measured.

User interface 0.0 to 12 500.0 Hz

Pulse output

Navigation  Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Pulse output (0456-1 to n)


Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (0469) (→  122) parameter.

Description Displays the pulse frequency currently output.

User interface Positive floating-point number

Additional information *Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.



A0028726

0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (0470) (→ 140) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (0480) (→ 126)) can be configured.

Switch state

Navigation Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Switch state (0461-1 to n)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (0469) (→ 122).

Description Displays the current switch status of the status output.

User interface


- Open
- Closed

Additional information *User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

*"Relay output 1 to n" submenu***Navigation**

Expert → Sensor → Measured val. → Output values → Relay output 1 to n



Switch state**Navigation**

Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch state (0801-1 to n)

Description

Displays the current status of the relay output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

Switch cycles**Navigation**

Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch cycles (0815-1 to n)

Description

Displays all the switch cycles performed.

User interface

Positive integer

Max. switch cycles number**Navigation**

Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Max. cycles no. (0817-1 to n)

Description

Displays the maximum number of guaranteed switch cycles.

User interface	Positive integer
----------------	------------------

"Double pulse output" submenu

Navigation  Expert → Sensor → Measured val. → Output values → Double pulse out

 Double pulse output
Pulse output (0987)
→  61

Pulse output

Navigation  Expert → Sensor → Measured val. → Output values → Double pulse out → Pulse output (0987)

Description Displays the pulse frequency of the double pulse output which is currently output.

User interface Positive floating-point number

Additional information  For a detailed description and example: **Pulse output** parameter (0456–1 to n) (→  58)

3.2.2 "System units" submenu

Navigation  Expert → Sensor → System units

 System units	
Volume flow unit (0553)	→  62
Volume unit (0563)	→  64
Mass flow unit (0554)	→  65
Mass unit (0574)	→  65
Velocity unit (0566)	→  66
Temperature unit (0557)	→  66

Density unit (0555)	→ 67
Reference density unit (0556)	→ 67
Kinematic viscosity unit (0578)	→ 68
Length unit (0551)	→ 68
Date/time format (2812)	→ 68

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d
- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d

- Mft³/s
- Mft³/min
- Mft³/h
- Mft³/d
- MMft³/s
- MMft³/min
- MMft³/h
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)
- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)

Factory setting

Depends on country:

- m³/h
- ft³/min

Additional information*Effect*

The selected unit applies to:
Volume flow parameter (1838) (→ 45)

Options

For an explanation of the abbreviated units: → 249

Customer-specific units

The unit for the customer-specific volume is specified in the **User volume text** parameter (0567).

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml
- af
- ft³
- Mft³
- MMft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)
- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Depends on country:

- m³
- ft³

Additional information*Options*

For an explanation of the abbreviated units: → 249

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Depends on country:

- kg/h
- lb/min

Additional information*Result*

The selected unit applies to:

Mass flow parameter (1872) (→ 46)

Selection

For an explanation of the abbreviated units: → 249

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → 249

Velocity unit**Navigation**

Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection

	<i>SI units</i>	<i>US units</i>
	m/s	ft/s

Factory setting

Country-specific:

- m/s
- ft/s

Additional information*Effect*

The selected unit applies for:

- Flow velocity (1852) (→ 45)
- Sound velocity (1850) (→ 46)

Selection

For an explanation of the abbreviated units: → 249

Temperature unit**Navigation**

Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.

Selection

	<i>SI units</i>	<i>US units</i>
	▪ °C	▪ °F
	▪ K	▪ °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Effect*

The selected unit applies for:

- Temperature (1853)
- Electronic temperature (6053)
- External temperature (6080)
- Reference temperature (1816)

Selection

For an explanation of the abbreviated units: → 249

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- SG60°F
- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/dm³
- lb/ft³

Additional information*Selection*

For an explanation of the abbreviated units: → [249](#)

Reference density unit**Navigation**

Expert → Sensor → System units → Ref. dens. unit (0556)

Description

Use this function to select the unit for the reference density.

Selection*SI units*

- kg/Nm³
- kg/Nl
- g/Scm³
- kg/Sm³
- RD15°C
- RD20°C

US units

- lb/Sft³
- RD60°F

Factory setting

kg/Nm³

Additional information*Result*

The selected unit applies for:

- **External reference density** parameter (6198)
- **Fixed reference density** parameter (1814)
- **Reference density** parameter (1852) (→ [45](#))

Selection

For an explanation of the abbreviated units: → [249](#)

Kinematic viscosity unit

Navigation Expert → Sensor → System units → Kin. visc. unit (0578)

Description Use this function to select the unit for the kinematic viscosity.

Selection *SI units*

- cSt
- St
- mm²/s
- m²/s

Factory setting Country-specific:

- m²/s
- cSt

Length unit

Navigation Expert → Sensor → System units → Length unit (0551)

Description Use this function to select the unit of length for the.

Selection *SI units*

US units

- | | |
|------|------|
| ■ m | ■ ft |
| ■ mm | ■ in |

Factory setting Country-specific:

- mm
- in

Additional information *Selection*

For an explanation of the abbreviated units: → 249

Date/time format

Navigation Expert → Sensor → System units → Date/time format (2812)

Description Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting dd.mm.yy hh:mm

Additional information*Selection*For an explanation of the abbreviated units: → [249](#)**3.2.3 "Measuring point" submenu***Navigation*

Expert → Sensor → Meas. point

► Measuring point 1	
Measuring point configuration (5675-1)	→ 71
Medium (2926-1)	→ 71
Medium temperature (3053-1)	→ 71
Sound velocity calculation mode (4202-1)	→ 72
Sound velocity (2929-1)	→ 72
API gravity (4203-1)	→ 72
Density (4204-1)	→ 73
Reference density (4205-1)	→ 73
Pressure (4206-1)	→ 73
API commodity group (4214-1)	→ 74
API table selection (4209-1)	→ 74
Alternative pressure value (4207-1)	→ 74
Alternative temperature value (4208-1)	→ 75
Viscosity (2932-1)	→ 75
Pipe material (2927-1)	→ 75
Pipe sound velocity (2933-1)	→ 76
Pipe dimensions (2943-1)	→ 76

Pipe circumference (2934-1)	→ 76
Pipe outer diameter (2910-1)	→ 77
Pipe wall thickness (2916-1)	→ 77
Liner material (2928-1)	→ 77
Liner sound velocity (2936-1)	→ 77
Liner thickness (2935-1)	→ 78
Sensor type (2924-1)	→ 78
Signal filter (3011-1)	→ 78
Sensor coupling (2957-1)	→ 79
Mounting type (2938-1)	→ 79
Cable length (2939-1)	→ 79
FlowDC inlet configuration (3049-1)	→ 80
Intermediate pipe length (2945-1)	→ 80
Inlet diameter (3054-1)	→ 81
Transition length (3065-1)	→ 81
Inlet run (3050-1)	→ 81
Relative sensor position (2985-1)	→ 82
Result sensor type / mounting type (2946-1)	→ 82
Result sensor distance / measuring aid (2947-1)	→ 82
Result sensor type / sensor distance (3066-1)	→ 82
Result path length / arc length (3067-1)	→ 83
► Mounting deviations signal path 1 to n	→ 83

Measuring point configuration

Navigation Expert → Sensor → Meas. point 1 → Meas. pt config. (5675-1)

Description Use this function to enter the measuring point configuration.

Selection

- 1 measuring point - signal path 1
- 1 measuring point - signal path 2 *
- 1 measuring point - 2 signal paths *

Factory setting Depending on the sensor version

Medium

Navigation Expert → Sensor → Meas. point 1 → Medium (2926-1)

Description Select the medium.

Selection

- Water
- Sea water
- Distilled water
- Ammonia NH₃
- Benzene
- Ethanol
- Glycol
- Kerosene
- Milk
- Methanol
- User-specific liquid
- Air *
- Liquid hydrocarbons *

Factory setting Water

Medium temperature

Navigation Expert → Sensor → Meas. point 1 → Medium temp. (3053-1)

Description Enter the medium temperature for the installation.

User entry -200 to 550 °C

Factory setting 20 °C

* Visibility depends on order options or device settings

Sound velocity calculation mode



Navigation	Expert → Sensor → Meas. point 1 → SoundVelocCalc. (4202-1)
Prerequisite	The Liquid hydrocarbons option is selected in Medium parameter (2926) (→ 71).
Description	Select the process variable to use to calculate the sound velocity at installation.
Selection	<ul style="list-style-type: none">▪ Fixed value▪ API gravity▪ Density▪ Reference density
Factory setting	API gravity

Sound velocity



Navigation	Expert → Sensor → Meas. point 1 → Sound velocity (2929-1)
Prerequisite	The User-specific liquid option is selected in Medium parameter (2926) (→ 71).
Description	Enter the sound velocity of the medium.
	If the sound velocity is not known, it can be determined with the following tools: <ul style="list-style-type: none">▪ Endress+Hauser sound velocity sensor sets▪ Prosonic Flow 93T with sound velocity sensors▪ Iterative measurement of sound velocity and distance adjustment of sensor distance using flow sensors
User entry	200 to 3 000 m/s
Factory setting	1 482.4 m/s

API gravity



Navigation	Expert → Sensor → Meas. point 1 → API gravity (4203-1)
Prerequisite	The Liquid hydrocarbons option is selected in the Medium parameter (2926) (→ 71) and the API gravity option is selected in the Sound velocity calculation mode parameter (4202) (→ 72).
Description	Enter the medium's API gravity for the installation.
User entry	0.0 to 100.0 °API
Factory setting	10.0 °API

Density

Navigation

Expert → Sensor → Meas. point 1 → Density (4204-1)

Prerequisite

The **Liquid hydrocarbons** option is selected in the **Medium** parameter (2926) (→ [71](#)) and the **Density** option is selected in the **Sound velocity calculation mode** parameter (4202) (→ [72](#)).

Description

Enter the medium's density for the installation.

User entry

Signed floating-point number

Factory setting

1 000 kg/m³

Reference density

Navigation

Expert → Sensor → Meas. point 1 → Ref.density (4205-1)

Prerequisite

The **Liquid hydrocarbons** option is selected in the **Medium** parameter (2926) (→ [71](#)) and the **Reference density** option is selected in the **Sound velocity calculation mode** parameter (4202) (→ [72](#)).

Description

Enter the medium's reference density for the installation.

User entry

Signed floating-point number

Factory setting

1 000 kg/m³

Pressure

Navigation

Expert → Sensor → Meas. point 1 → Pressure (4206-1)

Prerequisite

The **Liquid hydrocarbons** option is selected in the **Medium** parameter (2926) (→ [71](#)) and the **API gravity** option, **Density** option or **Reference density** option is selected in the **Sound velocity calculation mode** parameter (4202) (→ [72](#)).

Description

Enter the process pressure for the installation.

User entry

0.8 to 110 bar

Factory setting

1.01325 bar

API commodity group**Navigation**

Expert → Sensor → Meas. point 1 → API comm. group (4214-1)

Prerequisite

The **Liquid hydrocarbons** option is selected in the **Medium** parameter (2926) (→ 71) and the **API gravity** option or **Density** option or **Reference density** option is selected in the **Sound velocity calculation mode** parameter (4202) (→ 72).

Description

Select the medium's API commodity group.

Selection

- A - crude oil
- B - refined products
- D - lubricating oils

Factory setting

A - crude oil

API table selection**Navigation**

Expert → Sensor → Meas. point 1 → API tab. select. (4209-1)

Prerequisite

The **Liquid hydrocarbons** option is selected in the **Medium** parameter (2926) (→ 71) and the **API gravity** option, **Density** option or **Reference density** option is selected in the **Sound velocity calculation mode** parameter (4202) (→ 72).

Description

Select the API reference conditions (temperature and pressure) that apply for the reference density specified.

Selection

- API table 5/6
- API table 23/24
- API table 53/54
- API table 59/60
- Other

Factory setting

API table 23/24

Alternative pressure value**Navigation**

Expert → Sensor → Meas. point 1 → Alternat. press. (4207-1)

Description

Enter an alternative user-defined reference value for the pressure.

User entry

0.8 to 110 bar

Factory setting

1.01325 bar

Alternative temperature value

Navigation	Expert → Sensor → Meas. point 1 → Alternativ.temp. (4208-1)
Description	Enter an alternative user-defined reference value for the temperature.
User entry	-10 to 110 °C
Factory setting	29.5 °C

Viscosity

Navigation	Expert → Sensor → Meas. point 1 → Viscosity (2932-1)
Prerequisite	The User-specific liquid option is selected in Medium parameter (2926) (→ 71).
Description	Enter medium viscosity at installation temperature.
User entry	0.01 to 10 000 mm ² /s
Factory setting	1 mm ² /s

Pipe material

Navigation	Expert → Sensor → Meas. point 1 → Pipe material (2927-1)
Description	Select pipe material.
Selection	<ul style="list-style-type: none">■ Carbon steel■ Ductile cast iron■ Stainless steel■ 1.4301 (UNS S30400)■ 1.4401 (UNS S31600)■ 1.4550 (UNS S34700)■ Hastelloy C■ PVC■ PE■ LDPE■ HDPE■ GRP■ PVDF■ PA■ PP■ PTFE■ Pyrex glass■ Asbestos cement■ Copper■ Unknown pipe material

Factory setting Stainless steel

Pipe sound velocity



Navigation Expert → Sensor → Meas. point 1 → Pipe sound vel. (2933-1)

Prerequisite The **Unknown pipe material** option is selected in the **Pipe material** parameter (2927) (→ 75).

Description Enter sound velocity of pipe material.

User entry 800.0 to 3 800.0 m/s

Factory setting 3 120.0 m/s

Pipe dimensions



Navigation Expert → Sensor → Meas. point 1 → Pipe dimensions (2943-1)

Description Select if pipe dimensions are defined by diameter or circumference.

Selection

- Diameter
- Pipe circumference

Factory setting Diameter

Pipe circumference



Navigation Expert → Sensor → Meas. point 1 → Pipe circumfer. (2934-1)

Prerequisite The **Pipe circumference** option is selected in the **Pipe dimensions** parameter (2943) (→ 76).

Description Define the pipe circumference.

User entry 30 to 62 800 mm

Factory setting 314.159 mm

Pipe outer diameter

Navigation	Expert → Sensor → Meas. point 1 → Pipe outer diam. (2910-1)
Prerequisite	The Diameter option is selected in Pipe dimensions parameter (2943) (→ 76).
Description	Define the outer diameter of the pipe.
User entry	0 to 20 000 mm
Factory setting	100 mm

Pipe wall thickness

Navigation	Expert → Sensor → Meas. point 1 → Wall thickness (2916-1)
Description	Enter the pipe wall thickness.
User entry	Positive floating point number
Factory setting	3 mm

Liner material

Navigation	Expert → Sensor → Meas. point 1 → Liner material (2928-1)
Description	Select liner material.
Selection	<ul style="list-style-type: none">■ None■ Cement■ Rubber■ Epoxy resin■ Unknown liner material
Factory setting	None

Liner sound velocity

Navigation	Expert → Sensor → Meas. point 1 → Liner sound vel. (2936-1)
Prerequisite	The Unknown liner material option is selected in the Liner material parameter (2928) (→ 77).
Description	Define the sound velocity of liner material.

User entry 800.0 to 3 800.0 m/s

Factory setting 2 400.0 m/s

Liner thickness

Navigation Expert → Sensor → Meas. point 1 → Liner thickness (2935-1)

Description Define the thickness of liner.

User entry 0 to 100 mm

Factory setting 0 mm

Sensor type

Navigation Expert → Sensor → Meas. point 1 → Sensor type (2924-1)

Description Select sensor type.

Selection

- C-030-A
- C-050-A
- C-100-A
- C-100-B
- C-100-C
- C-200-A
- C-200-B
- C-200-C
- C-500-A
- CH-050-A *
- CH-100-A *

Factory setting As per order

Signal filter

Navigation Expert → Sensor → Meas. point 1 → Signal filter (3011-1)

Description Switch the signal filter on or off. The signal filter is an adaptive filter that is applied to the raw flow signal.

Selection

- Off
- On

* Visibility depends on order options or device settings

Factory setting	On
------------------------	----

Sensor coupling

Navigation Expert → Sensor → Meas. point 1 → Sensor coupling (2957-1)

Prerequisite The following option is selected in **Sensor type** parameter (2924) (→ 78):

- C-030-A
- C-050-A
- C-100-A
- C-100-B
- C-100-C
- C-200-A
- C-200-B
- C-200-C
- C-500-A

Description Select coupling medium.

Selection

- Coupling pad
- Coupling paste

Factory setting Coupling pad

Mounting type

Navigation Expert → Sensor → Meas. point 1 → Mounting type (2938-1)

Description

- (1) **direct** option: sensor arrangement with 1 traverse
- (2) **V-mounting** option: sensor arrangement with 2 traverses
- (3) **Z-Mounting** option: sensor arrangement with 3 traverses
- (4) **W-mounting** option: sensor arrangement with 4 traverses

Selection

- (1) direct
- (2) V-mounting
- (3) Z-Mounting
- (4) W-mounting
- Automatic

Factory setting Automatic

Cable length

Navigation Expert → Sensor → Meas. point 1 → Cable length (2939-1)

Description Enter length of sensor cables.

User entry 0 to 200 000 mm

Factory setting As per order

FlowDC inlet configuration



Navigation Expert → Sensor → Meas. point 1 → FlowDC inl. conf (3049-1)

Prerequisite The **1 measuring point - 2 signal paths** option is selected in the **Measuring point configuration** parameter (5675) (→ 71).

Description Select FlowDC inlet configuration.

- Selection**
- Off
 - Single elbow
 - Double elbow
 - Double elbow 3D
 - 45° bend
 - 2 x 45° bend
 - Concentric diameter change
 - Other *

Factory setting Off

Intermediate pipe length



Navigation Expert → Sensor → Meas. point 1 → Interm. pipe l. (2945-1)

Prerequisite The **1 measuring point - 2 signal paths** option is selected in **Measuring point configuration** parameter (5675) (→ 71).

Description Enter the length of the intermediate pipe between the two bends.

User entry Positive floating-point number

Factory setting 0 mm

* Visibility depends on order options or device settings

Inlet diameter**Navigation**

Expert → Sensor → Meas. point 1 → Inlet diameter (3054-1)

Prerequisite

- The **1 measuring point - 2 signal paths** option is selected in the **Measuring point configuration** parameter (5675) (→ [71](#)).
- The **Concentric diameter change** option is selected in the **Inlet configuration** parameter (→ [80](#)).

Description

Enter the outer diameter of the pipe before the cross-section change. For convenience, the same measuring pipe wall thickness as for the clamp-on system is applied.

User entry

1 to 10 000 mm

Factory setting

88.9 mm

Transition length**Navigation**

Expert → Sensor → Meas. point 1 → Transit. length (3065-1)

Prerequisite

- In the **Measuring point configuration** parameter (5675) (→ [71](#)), the **1 measuring point - 2 signal paths** option is selected.
- In the **Inlet configuration** parameter (→ [80](#)), the **Concentric diameter change** option is selected.

Description

Enter the length of the concentric change in diameter .

User entry

0 to 20 000 mm

Factory setting

0 mm

Inlet run**Navigation**

Expert → Sensor → Meas. point 1 → Inlet run (3050-1)

Prerequisite

The **1 measuring point - 2 signal paths** option is selected in **Measuring point configuration** parameter (5675) (→ [71](#)).

Description

Enter length of the available straight inlet run.

User entry

0 to 300 000 mm

Factory setting

0 mm

Relative sensor position

Navigation  Expert → Sensor → Meas. point 1 → Rel. sensor pos. (2985-1)

Prerequisite The **1 measuring point - 2 signal paths** option is selected in the **Measuring point configuration** parameter (5675) (→ 71) and the **Off** option is not selected in **FlowDC inlet configuration** parameter (3049) (→ 80).

Description Shows the correct position for the sensor.

User interface

- 90°
- 180°

Result sensor type / mounting type

Navigation  Expert → Sensor → Meas. point 1 → Sensor/mounting (2946-1)

Description Shows the selected sensor type and (if applicable automatically) selected mounting type.

User interface e.g. **C-100-A** option / **(2) V-mounting** option

Result sensor distance / measuring aid

Navigation  Expert → Sensor → Meas. point 1 → Dist./meas. aid (2947-1)

Description Shows the calculated sensor distance and vernier or wire length (if applicable) required for installation.

User interface e.g. 201.3 mm / B 21

Result sensor type / sensor distance

Navigation  Expert → Sensor → Meas. point 1 → Sens. type/dist. (3066-1)

Description Shows the sensor type and sensor distance calculated for installation.

User interface e.g. I-100-A / 500 mm


Factory setting -

Result path length / arc length

Navigation	 Expert → Sensor → Meas. point 1 → Path/arc length (3067-1)
Description	Shows the path length calculated and (if applicable) the calculated arc length.
User interface	e.g. 1085 mm / 257.56 mm
Factory setting	-

"Mounting deviations signal path 1 to n" submenu

Navigation  Expert → Sensor → Meas. point 1 → Deviat. path 1 to n



Sensor distance deviation

Navigation	 Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Sens. dist. dev. (5822-1 to n)
Description	Enter the deviation between the nominal sensor distance and the welded position.
User entry	Signed floating-point number
Factory setting	0 mm
Additional information	<p><i>Description</i></p> <p>If the welded position is greater than the nominal sensor distance, enter a positive deviation (e.g. 5 mm (0.20 in)). If the welded position is smaller than the nominal sensor distance, enter a negative deviation (e.g. -5 mm (-0.20 in)).</p>

Arc length deviation**Navigation**

Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Arc length dev.
(5876–1 to n)

Description

Enter the radial deviation between given radial distance and the real mounting position of the sensor.

User entry

Signed floating-point number

Factory setting

0 mm

Additional information*Description*

If the actual radial distance is greater than the nominal value, enter a positive deviation (e.g. 5 mm (0.20 in)). If the actual radial distance is smaller than the nominal value, enter a negative deviation (e.g. -5 mm (-0.20 in)).

Signal path length deviation**Navigation**

Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Path length dev.
(5821–1 to n)

Description

Enter the deviation between the nominal signal path length and the welded position.

User entry

Signed floating-point number

Factory setting

0 mm

Additional information*Description*

If the actual signal path length is greater than the nominal value, enter a positive deviation (e.g. 5 mm (0.20 in)). If the actual signal path length is smaller than the nominal value, enter a negative deviation (e.g. -5 mm (-0.20 in)).

3.2.4 "Installation status" submenu

Navigation

Expert → Sensor → Install. status

Installation status	
Installation status (2958)	→ 85
Signal strength (2914)	→ 85
Signal to noise ratio (2917)	→ 86

Sound velocity (2915)	→ 86
Sound velocity deviation (2986)	→ 86

Installation status

Navigation

Expert → Sensor → Install. status → Install. status (2958)

Description

Displays the device status after installation according to the displayed measured values.

- **Good** option: No further optimization required
Signal strength > 40 dB, SNR > 35, sound velocity deviation (measured to expected) < 2%
- **Acceptable** option: Measuring performance ok, optimize if possible. You should always aim for the status **Good** option.
Signal strength > 25 dB, SNR > 35, sound velocity deviation (measured to expected) < 3%
- **Bad** option: Optimization is required. Poor and unstable measuring performance.



Check the following points to optimize the sensor installation:

- Number of traverses, change if necessary (e.g. from 2 traverses to 1 traverse)
- Sensor distance
- Alignment of sensors
- Sufficient coupling medium available (coupling pad or coupling gel)
- Check the measuring point parameters in the configuration

User interface

- Good
- Acceptable
- Bad

Factory setting

Good

Signal strength

Navigation

Expert → Sensor → Install. status → Signal strength (2914)

Description

Displays the current signal strength.

User interface

Signed floating-point number

Additional information

Description

A drop in the signal strength over time can be an indicator of process changes, such as the development of deposits in the measuring pipe at the measuring point. This can only be quantified by performing a direct process comparison with different deposit layer thicknesses and associated signal strengths.

Signal to noise ratio

Navigation  Expert → Sensor → Install. status → SNR (2917)

Description Displays the current signal to noise ratio.

User interface Signed floating-point number

Additional information *Description*

A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality.

Sound velocity

Navigation  Expert → Sensor → Install. status → Sound velocity (2915)

Description Displays the sound velocity that is currently measured.

The difference between the configured sound velocity and the measured sound velocity should not be > 2 %.

User interface Signed floating-point number

Sound velocity deviation

Navigation  Expert → Sensor → Install. status → SoundVelocDeviat (2986)


Description Shows the deviation of the installation sound velocity from the measured sound velocity.

User interface Signed floating-point number

Factory setting 0 %

3.2.5 "Process parameters" submenu

Navigation  Expert → Sensor → Process param.



Flow damping (1802)	→  87
▶ Low flow cut off	→  88

Flow override



Navigation

  Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

Flow override is active

- The **453 Flow override** diagnostic message is output.
- Output values
 - Temperature: continues to be output
 - Sound velocity: continues to be output
 - Totalizer 1...3: stop being totalized

 The **Flow override** option can also be activated in the **Status input** submenu: **Assign status input** parameter (1352) (→  106).

Flow damping



Navigation

  Expert → Sensor → Process param. → Flow damping (1802)

Description

Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 999.9 s

Factory setting

1 s

Additional information*Description*

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased



Damping is switched off if **0** is entered (factory setting).


Effect

The damping affects the following variables of the device:

- Outputs → [107](#)
- Low flow cut off → [88](#)
- Totalizers → [195](#)

"Low flow cut off" submenu**Navigation**

Expert → Sensor → Process param. → Low flow cut off

**Assign process variable****Navigation**

Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity

Factory setting

Flow velocity

2) Proportional behavior with first-order lag

On value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → On value (1805)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 88).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 (→ 89).

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Dependency*

The unit depends on the process variable selected in the **Assign process variable** parameter (→ 88).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 88).

Description


Use this function to enter a switch-off value for low flow cut off. The switch-off value is entered as a positive hysteresis from the switch-on value (→ 89).

User entry

0 to 100.0 %

Factory setting

50 %

Additional information*Example*

A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.6 "External compensation" submenu

Navigation

 Expert → Sensor → External comp.

▶ External compensation	
Pressure compensation (3023)	→  90
Temperature compensation (3025)	→  91
Fixed value (2925)	→  91
External value (3058)	→  91
Density source (3048)	→  92
Fixed value (3171)	→  92
External value (3060)	→  92
Fixed reference density (3178)	→  93
Linear expansion coefficient (3153)	→  93
Square expansion coefficient (3172)	→  93
Reference temperature (3147)	→  94

Pressure compensation



Navigation

 Expert → Sensor → External comp. → Pressure compen. (3023)

Prerequisite

The **Off** option is not selected in **Petroleum mode** parameter (4187).

Description

Select pressure compensation type.

Selection

- Fixed value
- External value *
- Current input 1 *
- Current input 2 *

Factory setting

Fixed value

* Visibility depends on order options or device settings

Temperature compensation

Navigation	Expert → Sensor → External comp. → Temp. compensat. (3025)
Prerequisite	The Calculated value option is selected in the Density source parameter (3048) (→ 92).
Description	Select temperature mode for temperature compensation.
Selection	<ul style="list-style-type: none"> ■ Fixed value ■ External value * ■ Current input 1 * ■ Current input 2 *
Factory setting	Fixed value

Fixed value

Navigation	Expert → Sensor → External comp. → Fixed value (2925)
Prerequisite	The Fixed value option is selected in Temperature compensation parameter (3025) (→ 91).
Description	Enter a fixed value for the process temperature.
User entry	-50 to 550 °C
Factory setting	20 °C

External value

Navigation	Expert → Sensor → External comp. → External value (3058)
Prerequisite	The External value option or the Current input 1...n option is selected in the Temperature compensation parameter (3025) (→ 91).
Description	Shows the process temperature read from the external device.
User interface	-273.15 to 99 999 °C
Factory setting	-

* Visibility depends on order options or device settings

Density source

Navigation Expert → Sensor → External comp. → Density source (3048)

Description Select the source of the density.

- Selection**
- Fixed value
 - External value *
 - Calculated value *
 - Current input 1 *
 - Current input 2 *

Factory setting Fixed value

External value

Navigation Expert → Sensor → External comp. → External value (3060)

Prerequisite The **External value** option or the **Current input 1...n** option is selected in the **Density source** parameter (3048) (→ [92](#)).

Description Shows the density read from the external device.

User interface Positive floating-point number

Factory setting 0 kg/m³

Fixed value

Navigation Expert → Sensor → External comp. → Fixed value (3171)

Prerequisite The **Fixed value** parameter (3171) (→ [92](#)) is selected in the **Density source** parameter (3048) (→ [92](#)).

Description Enter fixed value for medium density.

User entry 0.01 to 15 000 kg/m³

Factory setting 1 000 kg/m³

* Visibility depends on order options or device settings

Linear expansion coefficient**Navigation**

Expert → Sensor → External comp. → Linear exp coeff (3153)

Description

Use this function to enter a linear, medium-specific expansion coefficient for calculating the density.

User entry $1.0 \cdot 10^{-6}$ to $2.0 \cdot 10^{-3}$

Factory setting $2.06 \cdot 10^{-4}$

Square expansion coefficient**Navigation**

Expert → Sensor → External comp. → Square exp coeff (3172)

Description

For media with a non-linear expansion pattern: use this function to enter a quadratic, medium-specific expansion coefficient for calculating the density.

User entry $1.0 \cdot 10^{-8}$ to $2.0 \cdot 10^{-3}$

Factory setting $3.8436 \cdot 10^{-6}$

Fixed reference density**Navigation**

Expert → Sensor → External comp. → Fix ref.density (3178)

Description

Use this function to enter a fixed value for the reference density.

User entry 0.01 to 15 000 kg/m³

Factory setting 1 000 kg/m³

Additional information

Reference density calculation

$$\rho = \rho_N \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0044558

- ρ : currently used density for mass flow calculation
- ρ_N : reference density
- t : currently read-in or fixed temperature according to the setting in the **Temperature compensation** parameter (3025) (→ 91)
- t_N : reference temperature at which the reference density applies (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the medium, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the medium, unit = [1/K²]

Reference temperature

Navigation Expert → Sensor → External comp. → Ref. temperature (3147)


Description Use this function to enter the reference temperature for which the Fixed reference density (3178) (→ [93](#)) applies.

User entry -200 to 450 °C

Factory setting 0 °C

3.2.7 "Sensor adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm.



Installation direction

Navigation Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description Use this function to change the sign of the medium flow direction.

Selection

- Forward flow
- Reverse flow

Factory setting Forward flow

Additional information *Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

"Process variable adjustment" submenu*Navigation*
 Expert → Sensor → Sensor adjustm. → Variable adjust

▶ Process variable adjustment	
Volume flow offset (1831)	→  95
Volume flow factor (1832)	→  96
Mass flow offset (1841)	→  96
Mass flow factor (1846)	→  96
Sound velocity offset (1848)	→  97
Sound velocity factor (1849)	→  97
Temperature offset (1870)	→  97
Temperature factor (1871)	→  98
Density offset (1877)	→  98
Density factor (1878)	→  98

Volume flow offset**Navigation**
 Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)
Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s. The value is entered in the selected volume flow unit.

User entry

Signed floating-point number

Factory setting0 m³/h**Additional information***Description*

Corrected value = (factor × value) + offset

Volume flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)
Description	Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Mass flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/h. The value is entered in the selected mass flow unit.
User entry	Signed floating-point number
Factory setting	0 kg/h
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Mass flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Sound velocity offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. offset (1848)
Description	Use this function to enter the zero point shift for the sound velocity trim. The sound velocity unit on which the shift is based is m/s. The value is entered in the selected velocity unit.
User entry	Signed floating-point number
Factory setting	0 m/s
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Sound velocity factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. factor (1849)
Description	Use this function to enter a quantity factor (without time) for the sound velocity. This multiplication factor is applied over the sound velocity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Temperature offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1870)
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Temperature factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1871)

Description Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in K.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

Density offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density offset (1877)

Description Use this function to enter the zero point shift for the density trim. The value is entered in the selected density unit.

User entry Signed floating-point number

Factory setting 0 kg/m³

Density factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Density factor (1878)


Description Use this function to enter a quantity factor for the density.

User entry Positive floating-point number

Factory setting 1

3.2.8 "Calibration" submenu

Navigation Expert → Sensor → Calibration



Zero point (2921)	→ 99
Nominal diameter (2807)	→ 99

Calibration factor

Navigation	Expert → Sensor → Calibration → Cal. factor (2920)
Description	Displays the current calibration factor for the sensor.
User interface	Signed floating-point number
Factory setting	1

Zero point

Navigation	Expert → Sensor → Calibration → Zero point (2921)
Description	Displays the current zero point correction value for the sensor.
User interface	Signed floating-point number
Factory setting	0


Nominal diameter

Navigation	Expert → Sensor → Calibration → Nominal diameter (2807)
Description	Displays the nominal diameter of the sensor.
User interface	-----
Factory setting	-----

3.3 "I/O configuration" submenu

Navigation

Expert → I/O config.



I/O module 1 to n terminal numbers

Navigation

Expert → I/O config. → I/O 1 to n terminals (3902-1 to n)

Description

Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

I/O module 1 to n information

Navigation

Expert → I/O config. → I/O 1 to n info (3906-1 to n)

Description

Displays information about the plugged in I/O module.

User interface

- Not plugged
- Invalid
- Not configurable
- Configurable
- HART

Additional information	<p><i>"Not plugged"</i> option The I/O module is not plugged in.</p> <p><i>"Invalid"</i> option The I/O module is not plugged correctly.</p> <p><i>"Not configurable"</i> option The I/O module is not configurable.</p> <p><i>"Configurable"</i> option The I/O module is configurable.</p> <p><i>"Fieldbus"</i> option The I/O module is configured for HART.</p>
-------------------------------	---

I/O module 1 to n type

Navigation	Expert → I/O config. → I/O 1 to n type (3901-1 to n)
Prerequisite	For the following order code: <ul style="list-style-type: none">■ "Output; input 2", option D "Configurable I/O initial setting off"■ "Output; input 3", option D "Configurable I/O initial setting off"■ "Output; input 4", option D "Configurable I/O initial setting off"
Description	Use this function to select the I/O module type for the configuration of the I/O module.
Selection	<ul style="list-style-type: none">■ Off■ Current output *■ Current input *■ Status input *■ Pulse/frequency/switch output *■ Double pulse output *■ Relay output *
Factory setting	Off

Apply I/O configuration

Navigation	Expert → I/O config. → Apply I/O config (3907)
Description	Use this function to activate the newly configured I/O module type.
Selection	<ul style="list-style-type: none">■ No■ Yes
Factory setting	No

* Visibility depends on order options or device settings

I/O alteration code**Navigation**

Expert → I/O config. → I/O alterat.code (2762)

Description

Use this function to enter the ordered activation code to activate the I/O configuration change.

User entry

Positive integer

Factory setting

0


Additional information*Description*

The I/O configuration is changed in the **I/O module type** parameter (3901-1 to n) (→ 101).

3.4 "Input" submenu

Navigation


Expert → Input



3.4.1 "Current input 1 to n" submenu

Navigation

Expert → Input → Current input 1 to n



Terminal number

Navigation	  Expert → Input → Current input 1 to n → Terminal no. (1611-1 to n)
Description	Displays the terminal numbers used by the current input module.
User interface	<ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 22-23 (I/O 3)
Additional information	<p><i>"Not used" option</i></p> <p>The current input module does not use any terminal numbers.</p>

Signal mode



Navigation	  Expert → Input → Current input 1 to n → Signal mode (1610-1 to n)
Description	Use this function to select the signal mode for the current input.
Selection	<ul style="list-style-type: none"> ■ Passive ■ Active *
Factory setting	Passive

Current span



Navigation	  Expert → Input → Current input 1 to n → Current span (1605-1 to n)
Description	Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.
Selection	<ul style="list-style-type: none"> ■ 4...20 mA (4...20.5 mA) ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 0...20 mA (0...20.5 mA)
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA)
Additional information	<p><i>Examples</i></p> <p> Sample values for the current range: Current span parameter (0353) (→  109)</p>

* Visibility depends on order options or device settings

0/4 mA value**Navigation**

Expert → Input → Current input 1 to n → 0/4 mA value (1606–1 to n)

Description

Use this function to enter a value for the 4 mA current.

User entry

Signed floating-point number

Factory setting

0

Additional information*Current input behavior*

The current input behaves differently depending on the settings configured in the following parameters:

- Current span (1605) (→ [103](#))
- Failure mode (1601) (→ [104](#))

Configuration examples

Pay attention to the configuration examples for **4 mA value** parameter (0367) (→ [111](#)).

20 mA value**Navigation**

Expert → Input → Current input 1 to n → 20 mA value (1607–1 to n)

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information*Configuration examples*

Pay attention to the configuration examples for **4 mA value** parameter (0367) (→ [111](#)).

Failure mode**Navigation**

Expert → Input → Current input 1 to n → Failure mode (1601–1 to n)

Description

Use this function to select the input behavior when measuring a current outside the configured **Current span** parameter (1605) (→ [103](#)).

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information*Options*

- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used (**Failure value** parameter (1602) (→ 105)).

Failure value**Navigation**

Expert → Input → Current input 1 to n → Failure value (1602-1 to n)

Prerequisite

In the **Failure mode** parameter (1601) (→ 104), the **Defined value** option is selected.

Description

Use this function to enter the value that the device uses if it does not receive an input signal from the external device, or if the input signal is invalid.

User entry

Signed floating-point number

Factory setting

0

3.4.2 "Status input 1 to n" submenu**Navigation**

Expert → Input → Status input 1 to n

► Status input 1 to n	
Terminal number (1358-1 to n)	→ 105
Assign status input (1352-1 to n)	→ 106
Value status input (1353-1 to n)	→ 106
Active level (1351-1 to n)	→ 107
Response time status input (1354-1 to n)	→ 107

Terminal number**Navigation**

Expert → Input → Status input 1 to n → Terminal no. (1358-1 to n)

Description

Displays the terminal numbers used by the status input module.

User interface	<ul style="list-style-type: none">■ Not used■ 24-25 (I/O 2)■ 22-23 (I/O 3)
Additional information	<p><i>"Not used" option</i></p> <p>The status input module does not use any terminal numbers.</p>

Assign status input	
Navigation	 Expert → Input → Status input 1 to n → Assign stat.inp. (1352–1 to n)
Description	Use this function to select the function for the status input.
Selection	<ul style="list-style-type: none">■ Off■ Reset totalizer 1■ Reset totalizer 2■ Reset totalizer 3■ Reset all totalizers■ Flow override
Factory setting	Off
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ Off The status input is switched off.■ Reset totalizer 1...3 The individual totalizers are reset.■ Reset all totalizers All totalizers are reset.■ Flow override The Flow override (→  87) is activated. <p> Note on the Flow override (→  87):</p> <ul style="list-style-type: none">■ The Flow override (→  87) is enabled as long as the level is at the status input (continuous signal).■ All other assignments react to a change in level (pulse) at the status input.

Value status input	
Navigation	 Expert → Input → Status input 1 to n → Val.stat.inp. (1353–1 to n)
Description	Displays the current input signal level.
User interface	<ul style="list-style-type: none">■ High■ Low

Active level

Navigation Expert → Input → Status input 1 to n → Active level (1351–1 to n)

Description Use this function to determine the input signal level at which the assigned function is activated.

Selection

- High
- Low

Factory setting High

Response time status input

Navigation Expert → Input → Status input 1 to n → Response time (1354–1 to n)

Description Use this function to enter the minimum time period for which the input signal level must be present before the selected function is activated.


User entry 5 to 200 ms

Factory setting 50 ms

3.5 "Output" submenu

Navigation

Expert → Output



3.5.1 "Current output 1 to n" submenu

Navigation

Expert → Output → Curr.output 1 to n



Terminal number (0379-1 to n)	→ 108
Signal mode (0377-1 to n)	→ 109
Process variable current output (0359-1 to n)	→ 109
Current range output (0353-1 to n)	→ 109
Fixed current (0365-1 to n)	→ 111
Lower range value output (0367-1 to n)	→ 111
Upper range value output (0372-1 to n)	→ 113
Measuring mode current output (0351-1 to n)	→ 113
Damping current output (0363-1 to n)	→ 118
Failure behavior current output (0364-1 to n)	→ 118
Failure current (0352-1 to n)	→ 119
Output current (0361-1 to n)	→ 119
Measured current (0366-1 to n)	→ 120

Terminal number

Navigation Expert → Output → Curr.output 1 to n → Terminal no. (0379-1 to n)

Description Displays the terminal numbers used by the current output module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information

"Not used" option

The current output module does not use any terminal numbers.

Signal mode

Navigation Expert → Output → Curr.output 1 to n → Signal mode (0377–1 to n)

Description Use this function to select the signal mode for the current output.

Selection

- Active *
- Passive *

Factory setting Active

Process variable current output

Navigation Expert → Output → Curr.output 1 to n → Proc.var. outp (0359–1 to n)

Description Use this function to select a process variable for the current output.

Selection

- Off *
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Density *
- Reference density *
- S&W volume flow *
- GSV flow *
- NSV flow *
- API gravity *
- API slope *
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature
- Profile factor *
- Cross flow factor *

Factory setting Volume flow

Current range output

Navigation Expert → Output → Curr.output 1 to n → Curr.range out (0353–1 to n)

Description Select current range for process value output and upper/lower level for alarm signal.

* Visibility depends on order options or device settings

Selection

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)
- Fixed value

Factory setting

Depends on country:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Additional information*Description*


- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (0364) (→ 118).
- If the measured value is outside the measuring range, the **△S441 Current output 1 to n** diagnostic message is displayed.
- The measuring range is specified via the **Lower range value output** parameter (0367) (→ 111) and **Upper range value output** parameter (0372) (→ 113).

"Fixed current" option

- This option is used for a HART Multidrop network.
- It can only be used for the 4...20 mA HART current output (current output 1).
- The current value is set via the **Fixed current** parameter (0365) (→ 111).

Example

Shows the relationship between the current range for the output of the process value and the two signal on alarm levels:



- 1 Current range for process value
- 2 Lower level for signal on alarm
- 3 Upper level for signal on alarm

Selection

Selection	1	2	3
4...20 mA NE (3.8...20.5 mA)	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US (3.9...20.8 mA)	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA (4...20.5 mA)	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA (0...20.5 mA)	0 to 20.5 mA	0 mA	> 21.95 mA

- If the flow exceeds or falls below the upper or lower signal on alarm level, the **△S441 Current output 1 to n** diagnostic message is displayed.

Fixed current

Navigation Expert → Output → Curr.output 1 to n → Fixed current (0365–1 to n)

Prerequisite The **Fixed current** option is selected in the **Current span** parameter (0353) (→ 109).

Description Use this function to enter a constant current value for the current output.

User entry 0 to 22.5 mA

Factory setting 22.5 mA

Lower range value output

Navigation Expert → Output → Curr.output 1 to n → Low.range outp (0367–1 to n)

Prerequisite In **Current span** parameter (0353) (→ 109), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description Use this function to enter a value for the start of measuring range.

User entry Signed floating-point number

Factory setting Depends on country:

- m³/h
- ft³/h

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (0359) (→ 109). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **Upper range value output** parameter (0372) (→ 113).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (0359) (→ 109).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:


- Current span (0353) (→ 109)
- Failure mode (0364) (→ 118)

Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.


Configuration example AMeasurement mode with **Forward flow** option

- **Lower range value output** parameter (0367) ($\rightarrow \text{图 111}$) = not equal to zero flow (e.g. $-250 \text{ m}^3/\text{h}$)
- **Upper range value output** parameter (0372) ($\rightarrow \text{图 113}$) = not equal to zero flow (e.g. $+750 \text{ m}^3/\text{h}$)
- Calculated current value = 8 mA at zero flow



Q Flow
 I Current
 1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **Lower range value output** parameter (0367) ($\rightarrow \text{图 111}$) and **Upper range value output** parameter (0372) ($\rightarrow \text{图 113}$). If the effective flow exceeds or falls below this operational range, the **$\Delta S441$ Current output 1 to n** diagnostic message is output.

Configuration example BMeasurement mode with **Forward/Reverse flow** option

I Current
 Q Flow
 1 Start of measuring range output (0/4 mA)
 2 Forward flow
 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (0367) ($\rightarrow \text{图 111}$) and **20 mA value** parameter (0372) ($\rightarrow \text{图 113}$) must have the same algebraic sign. The value for the **20 mA value** parameter (0372) ($\rightarrow \text{图 113}$) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (0372) ($\rightarrow \text{图 113}$) (e.g. flow).

Configuration example CMeasurement mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s $\rightarrow \text{图 113}$.

Upper range value output

Navigation Expert → Output → Curr.output 1 to n → Upp.range outp (0372–1 to n)

Prerequisite In **Current span** parameter (0353) (→ 109), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description Use this function to enter a value for the end of measuring range.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (0359) (→ 109). In addition, the value can be greater than or smaller than the value assigned for the 0/4 mA current in the **Lower range value output** parameter (0367) (→ 111).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (0359) (→ 109).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse flow** option is selected in the **Measuring mode** parameter (0351) (→ 113), different algebraic signs cannot be entered for the values for the **Lower range value output** parameter (0367) (→ 111) and **Upper range value output** parameter (0372) (→ 113). The **△S441 Current output 1 to n** diagnostic message is displayed.

Configuration examples

Pay attention to the configuration examples for the **Lower range value output** parameter (0367) (→ 111).

Measuring mode current output

Navigation Expert → Output → Curr.output 1 to n → Output mode (0351–1 to n)

Prerequisite One of the following options is selected in the **Assign current output** parameter (0359) (→ 109):

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity

- Temperature *
- Pressure *
- Density *
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence
- Electronics temperature

One of the following options is selected in the **Current span** parameter (0353) (→ [109](#)):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse flow *
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Description

i The process variable that is assigned to the current output via the **Assign current output** parameter (0359) (→ [109](#)) is displayed below the parameter.

"Forward flow" option


The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the **Lower range value output** parameter (0367) (→ [111](#)) and the **Upper range value output** parameter (0372) (→ [113](#)).

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Both values are defined such that they are not equal to zero flow e.g.:

- start of measuring range = -5 m³/h
- end of measuring range = 10 m³/h

"Forward/Reverse flow" option



A0013758

- | | |
|---|--|
| I | Current |
| Q | Flow |
| 1 | Start of measuring range output (0/4 mA) |
| 2 | Forward flow |
| 3 | Reverse flow |

* Visibility depends on order options or device settings

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **Lower range value output** parameter (0367) (→ 111) and **Upper range value output** parameter (0372) (→ 113) must have the same sign.
- The value for the **Upper range value output** parameter (0372) (→ 113) (e.g. reverse flow) corresponds to the mirrored value for the **Upper range value output** parameter (0372) (→ 113) (e.g. forward flow).

"Reverse flow compensation" option

The **Reverse flow compensation** option is primarily used to compensate for intermittent reverse flow that can arise with displacement pumps due to wear or high-viscosity medium. The reverse flow is recorded in a buffer memory and offset against the next forward flow.


In the event of prolonged and undesired reverse flow, flow values can accumulate in the buffer memory. Due to the configuration of the current output, these values are not factored in, however, i.e. there is no compensation for the reverse flow.

If this option is set, the measuring device does not smoothen the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1

Defined measuring range: lower range value and upper range value with the **same sign**



■ 3 Measuring range


I Current

Q Flow

1 Lower range value (Start of measuring range output)

2 Upper range value (end of measuring range output)

With the following flow response:




■ 4 Flow response

Q Flow

t Time

With **Forward flow** option


The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output..



I Current
t Time

With **Forward/Reverse flow** option


The current output signal is independent of the direction of flow.



I Current
t Time

With **Reverse flow compensation** option


Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.



I Current
t Time
S Flow components saved
A Balancing of saved flow components

Example 2


Defined measuring range: lower range value and upper range value with **different signs**



■ 5 Measuring range

- I Current
Q Flow
1 Lower range value (Start of measuring range output)
2 Upper range value (end of measuring range output)


With flow a (—) outside, b (- -) inside the measuring range



Q Flow
 t Time
 1 Lower range value (Start of measuring range output)
 2 Upper range value (end of measuring range output)

With **Forward flow** option

- a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output.
The **△S441 Current output 1 to n** diagnostic message is output.
- b (- -): The current output signal is proportional to the process variable assigned.




I Current
 t Time

With **Forward/Reverse flow** option

This option cannot be selected here since the values for the **Lower range value output** parameter (0367) (→ 111) and **Upper range value output** parameter (0372) (→ 113) have different signs.

With **Reverse flow compensation** option

Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.



I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping current output**Navigation**

Expert → Output → Curr.output 1 to n → Damp.curr.outp (0363–1 to n)

Prerequisite

A process variable is selected in the **Assign current output** parameter (0359) (→ 109) and one of the following options is selected in the **Current span** parameter (0353) (→ 109):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

1.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element³⁾) for current output damping:

- If a low time constant is entered, the current output reacts quickly to fluctuating measured variables.
- If a high time constant is entered, the current output reacts more slowly.



Damping is switched off if **0** is entered (factory setting).

Failure behavior current output**Navigation**

Expert → Output → Curr.output 1 to n → Failure behav. (0364–1 to n)

Prerequisite

A process variable is selected in the **Assign current output** parameter (0359) (→ 109) and one of the following options is selected in the **Current span** parameter (0353) (→ 109):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Fixed value

Factory setting

Max.

3) proportional transmission behavior with first order delay

Additional information*Description*

 This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (0353) (→ [109](#)).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (0353) (→ [109](#)).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (0352) (→ [119](#)).

Failure current**Navigation**

 Expert → Output → Curr.output 1 to n → Fail. current (0352–1 to n)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (0364) (→ [118](#)).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output current**Navigation**

 Expert → Output → Curr.output 1 to n → Output curr. (0361–1 to n)

Description

Displays the current value currently calculated for the current output.

User interface

3.59 to 22.5 mA

Measured current

Navigation   Expert → Output → Curr.output 1 to n → Measur. curr. (0366-1 to n)

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA

3.5.2 "Pulse/frequency/switch output 1 to n" submenu

Navigation   Expert → Output → PFS output 1 to n

 Pulse/frequency/switch output 1 to n	
Terminal number (0492-1 to n)	→  121
Signal mode (0490-1 to n)	→  122
Operating mode (0469-1 to n)	→  122
Assign pulse output (0460-1 to n)	→  124
Pulse scaling (0455-1 to n)	→  124
Pulse width (0452-1 to n)	→  125
Measuring mode (0457-1 to n)	→  126
Failure mode (0480-1 to n)	→  126
Pulse output (0456-1 to n)	→  127
Assign frequency output (0478-1 to n)	→  128
Minimum frequency value (0453-1 to n)	→  128
Maximum frequency value (0454-1 to n)	→  129
Measuring value at minimum frequency (0476-1 to n)	→  129
Measuring value at maximum frequency (0475-1 to n)	→  129

Measuring mode (0479-1 to n)	→ 130
Damping output (0477-1 to n)	→ 131
Response time (0491-1 to n)	→ 131
Failure mode (0451-1 to n)	→ 132
Failure frequency (0474-1 to n)	→ 133
Output frequency (0471-1 to n)	→ 133
Switch output function (0481-1 to n)	→ 133
Assign diagnostic behavior (0482-1 to n)	→ 134
Assign limit (0483-1 to n)	→ 135
Switch-on value (0466-1 to n)	→ 137
Switch-off value (0464-1 to n)	→ 137
Assign flow direction check (0484-1 to n)	→ 138
Assign status (0485-1 to n)	→ 138
Switch-on delay (0467-1 to n)	→ 138
Switch-off delay (0465-1 to n)	→ 139
Failure mode (0486-1 to n)	→ 139
Switch state (0461-1 to n)	→ 139
Invert output signal (0470-1 to n)	→ 140

Terminal number

Navigation

Expert → Output → PFS output 1 to n → Terminal no. (0492-1 to n)

Description

Displays the terminal numbers used by the pulse/frequency/switch output module.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information*"Not used" option*

The pulse/frequency/switch output module does not use any terminal numbers.

Signal mode**Navigation****Description**

Use this function to select the signal mode for the pulse/frequency/switch output.

Selection

- Passive *
- Active *
- Passive NE

Factory setting

Passive

Operating mode**Navigation****Description**

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse

Additional information*"Pulse" option*


Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass or volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s

* Visibility depends on order options or device settings



■ 6 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, mass flow, temperature, sound velocity, flow velocity, acceptance rate, flow asymmetry, turbulence, signal strength or signal to noise ratio.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz




■ 7 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example


Alarm response without alarm



■ 8 No alarm, high level

Example

Alarm response in case of alarm



A0026885

9 Alarm, low level

Assign pulse output



Navigation

Expert → Output → PFS output 1 to n → Assign pulse (0460–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (0469) (→ 122).

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow
- GSV flow *
- NSV flow *
- S&W volume flow *
- Product 1 volume flow *
- Product 2 volume flow *
- Product 3 volume flow *
- Product 4 volume flow *
- Product 5 volume flow *
- Product 1 mass flow *
- Product 2 mass flow *
- Product 3 mass flow *
- Product 4 mass flow *
- Product 5 mass flow *
- Product 1 NSV flow *
- Product 2 NSV flow *
- Product 3 NSV flow *
- Product 4 NSV flow *
- Product 5 NSV flow *

Factory setting

Off

Pulse scaling



Navigation

Expert → Output → PFS output 1 to n → Pulse scaling (0455–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (0469) (→ 122) and a process variable is selected in the **Assign pulse output** parameter (0460) (→ 124).

Description


Use this function to enter the value for the measured value that a pulse is equivalent to.

* Visibility depends on order options or device settings

User entry	Positive floating point number
Factory setting	Depends on country and nominal diameter
Additional information	<p><i>User entry</i></p> <p>Weighting of the pulse output with a quantity.</p> <p>The lower the pulse value, the</p> <ul style="list-style-type: none"> ■ better the resolution. ■ the higher the frequency of the pulse response.

Pulse width

Navigation	Expert → Output → PFS output 1 to n → Pulse width (0452–1 to n)
Prerequisite	The Pulse option is selected in the Operating mode parameter (0469) (→ 122) and a process variable is selected in the Assign pulse output parameter (0460) (→ 124).
Description	Use this function to enter the duration of the output pulse.
User entry	0.05 to 2 000 ms
Factory setting	100 ms
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ Define how long a pulse is (duration). ■ The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$. ■ The interval between two pulses lasts at least as long as the set pulse width. ■ The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$. ■ If the flow exceeds these limit values, the measuring device displays the 443 Pulse output 1 to n diagnostic message.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation

Expert → Output → PFS output 1 to n → Measuring mode (0457–1 to n)

Prerequisite

The "Pulse" option is selected in the "Operating mode" parameter (0469) and one of the following options is selected in the "Assign pulse output" parameter (0460):

- Volume flow
- Mass flow

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Options

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Reverse flow compensation
The flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

For a detailed description of the options available, see the **Measuring mode** parameter (0351) (→ [113](#))

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (0351) (→ [113](#))

Failure mode



Navigation

Expert → Output → PFS output 1 to n → Failure mode (0480–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (0469) (→ [122](#)) and a process variable is selected in the **Assign pulse output** parameter (0460) (→ [124](#)).

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

*Options***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The **Actual value** option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.

Pulse output**Navigation**

Expert → Output → PFS output 1 to n → Pulse output (0456–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (0469) (→ 122) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description***■ The pulse output is an open collector output.**

This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.



0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (0470) (→ 140) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (0480) (→ 126)) can be configured.

Assign frequency output



Navigation

Expert → Output → PFS output 1 to n → Assign freq. (0478–1 to n)

Prerequisite

The **Frequency** option is selected in **Operating mode** parameter (0469) (→ [122](#)).

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity
- Temperature
- Pressure *
- Density *
- Reference density *
- S&W volume flow *
- GSV flow *
- NSV flow *
- API gravity *
- API slope *
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature
- Profile factor *
- Cross flow factor *

Factory setting

Off

Minimum frequency value



Navigation

Expert → Output → PFS output 1 to n → Min. freq. value (0453–1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (0469) (→ [122](#)) and a process variable is selected in the **Assign frequency output** parameter (0478) (→ [128](#)).

Description

Use this function to enter the minimum frequency.

User entry

0.0 to 10 000.0 Hz

Factory setting

0.0 Hz

* Visibility depends on order options or device settings

Maximum frequency value

Navigation Expert → Output → PFS output 1 to n → Max. freq. value (0454–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (0469) (→ 122) and a process variable is selected in the **Assign frequency output** parameter (0478) (→ 128).

Description Use this function to enter the end value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 10 000.0 Hz

Measuring value at minimum frequency

Navigation Expert → Output → PFS output 1 to n → Val. at min.freq (0476–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (0469) (→ 122) and a process variable is selected in the **Assign frequency output** parameter (0478) (→ 128).

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Dependency*

The entry depends on the process variable selected in the **Assign frequency output** parameter (0478) (→ 128).

Measuring value at maximum frequency

Navigation Expert → Output → PFS output 1 to n → Val. at max.freq (0475–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (0469) (→ 122) and a process variable is selected in the **Assign frequency output** parameter (0478) (→ 128).

Description Use this function to enter the measured value for the end value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information*Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

 The entry depends on the process variable selected in the **Assign frequency output** parameter (0478) (→ 128).

Measuring mode**Navigation**

 Expert → Output → PFS output 1 to n → Measuring mode (0479-1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (0469) (→ 122) and one of the following options is selected in the **Assign frequency output** parameter (0478) (→ 128):

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information*Options*

 For a detailed description of the options available, see the **Measuring mode** parameter (0351) (→ 113)

Examples

 For a detailed description of the configuration examples, see the **Measuring mode** parameter (0351) (→ 113)

* Visibility depends on order options or device settings

Damping output**Navigation**

Expert → Output → PFS output 1 to n → Damping out. (0477-1 to n)

Prerequisite

The "Frequency" option is selected in the "Operating mode" parameter (0469) and one of the following options is selected in the "Assign frequency output" parameter (0478):

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element⁴⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if 0 is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time**Navigation**

Expert → Output → PFS output 1 to n → Response time (0491-1 to n)

Prerequisite

The "Frequency" option is selected in the "Operating mode" parameter (0469) and one of the following options is selected in the "Assign frequency output" parameter (0478):

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature

* Visibility depends on order options or device settings

4) proportional transmission behavior with first order delay

- Pressure*
- Density*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature

Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches 63 % of 100 % of the measured value change when the measured value changes.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p>i The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ■ Damping of pulse/frequency/switch output → 118 and ■ Depending on the measured variable assigned to the output. <ul style="list-style-type: none"> ■ Flow damping or ■ Temperature damping

Failure mode		
Navigation	 Expert → Output → PFS output 1 to n → Failure mode (0451-1 to n)	
Prerequisite	The Frequency option is selected in the Operating mode parameter (0469) (→ 122) and a process variable is selected in the Assign frequency output parameter (0478) (→ 128).	
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.	
Selection	<ul style="list-style-type: none"> ■ Actual value ■ Defined value ■ 0 Hz 	
Factory setting	0 Hz	
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored. ■ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (0474) (→ 133) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm. ■ 0 Hz In the event of a device alarm, the frequency output is "switched off". 	

* Visibility depends on order options or device settings

NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The **Actual value** option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.

Failure frequency



Navigation Expert → Output → PFS output 1 to n → Failure freq. (0474-1 to n)

Prerequisite In the **Operating mode** parameter (0469) (→ 122), the **Frequency** option is selected, in the **Assign frequency output** parameter (0478) (→ 128) a process variable is selected, and in the **Failure mode** parameter (0451) (→ 132), the **Defined value** option is selected.

Description Enter frequency output value in alarm condition.

User entry 0.0 to 12 500.0 Hz

Factory setting 0.0 Hz

Output frequency



Navigation Expert → Output → PFS output 1 to n → Output freq. (0471-1 to n)

Prerequisite In the **Operating mode** parameter (0469) (→ 122), the **Frequency** option is selected.

Description Displays the actual value of the output frequency which is currently measured.

User interface 0.0 to 12 500.0 Hz

Switch output function



Navigation Expert → Output → PFS output 1 to n → Switch out funct (0481-1 to n)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (0469) (→ 122).

Description Use this function to select a function for the switch output.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Flow direction check
- Status

Factory setting Off

Additional information*Options*

- Off
The switch output is permanently switched off (open, non-conductive).
- On
The switch output is permanently switched on (closed, conductive).
- Diagnostic behavior
Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.
- Limit
Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.
- Status
Displays the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior**Navigation**

Expert → Output → PFS output 1 to n → Assign diag. beh (0482-1 to n)

Prerequisite

- In the **Operating mode** parameter (0469) (→ 122), the **Switch** option is selected.
- In the **Switch output function** parameter (0481) (→ 133), the **Diagnostic behavior** option is selected.

Description

Use this function to select the diagnostic event category that is displayed for the switch output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting

Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to n → Assign limit (0483–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (0469) (→ [122](#)).
- The **Limit** option is selected in the **Switch output function** parameter (0481) (→ [133](#)).

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*
- NSV flow*
- API gravity*
- API slope*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Profile factor*
- Cross flow factor*

Factory setting


Volume flow

Additional information*Description*

Behavior of status output when Switch-on value (0466) > Switch-off value (0464):

- Process variable > Switch-on value (0466): transistor is conductive
- Process variable < Switch-off value (0464): transistor is non-conductive


* Visibility depends on order options or device settings



- 1 Switch-on value (0466)
- 2 Switch-off value (0464)
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value (0466) < Switch-off value (0464):


- Process variable < Switch-on value (0466): transistor is conductive
- Process variable > Switch-off value (0464): transistor is non-conductive



- 1 Switch-off value (0464)
- 2 Switch-on value (0466)
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value (0466) = Switch-off value (0464):

- Process variable > Switch-on value (0466): transistor is conductive
- Process variable < Switch-off value (0464): transistor is non-conductive



- 1 Switch-on value (0466) = Switch-off value (0464)
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value

Navigation Expert → Output → PFS output 1 to n → Switch-on value (0466-1 to n)

Prerequisite ■ The **Switch** option is selected in the **Operating mode** parameter (0469) (→ [122](#)).
■ The **Limit** option is selected in the **Switch output function** parameter (0481) (→ [133](#)).

Description Use this function to enter the measured value for the switch-on point.

User entry Signed floating-point number

Factory setting Depends on country

Additional information *Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value (0466) > Switch-off value (0464).

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (0483) (→ [135](#)).

Switch-off value

Navigation Expert → Output → PFS output 1 to n → Switch-off value (0464-1 to n)

Prerequisite ■ The **Switch** option is selected in the **Operating mode** parameter (0469) (→ [122](#)).
■ The **Limit** option is selected in the **Switch output function** parameter (0481) (→ [133](#)).

Description Use this function to enter the measured value for the switch-off point.

User entry Signed floating-point number

Factory setting Depends on country

Additional information *Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

When using a hysteresis: Switch-on value (0466) > Switch-off value (0464).

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (0483) (→ [135](#)).

Assign flow direction check



Navigation

Expert → Output → PFS output 1 to n → Assign dir.check (0484-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (0469) (→ 122).
- The **Flow direction check** option is selected in the **Switch output function** parameter (0481) (→ 133).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity

Factory setting

Volume flow

Assign status



Navigation

Expert → Output → PFS output 1 to n → Assign status (0485-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (0469) (→ 122).
- The **Status** option is selected in the **Switch output function** parameter (0481) (→ 133).

Description

Use this function to select a device status for the switch output.

Selection

- Off
- Low flow cut off
- Product identification *

Factory setting

Low flow cut off

Additional information

Options

If empty pipe detection or low flow cut off are active, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay



Navigation

Expert → Output → PFS output 1 to n → Switch-on delay (0467-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (0469) (→ 122).
- The **Limit** option is selected in the **Switch output function** parameter (0481) (→ 133).

Description

Use this function to enter a delay time for switching on the switch output.

* Visibility depends on order options or device settings

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Switch-off delay



Navigation Expert → Output → PFS output 1 to n → Switch-off delay (0465-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (0469) (→ [122](#)).
- The **Limit** option is selected in the **Switch output function** parameter (0481) (→ [133](#)).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode



Navigation Expert → Output → PFS output 1 to n → Failure mode (0486-1 to n)

Description Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting Open

Additional information *Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch state

Navigation Expert → Output → PFS output 1 to n → Switch state (0461-1 to n)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (0469) (→ [122](#)).

Description Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information *User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal



Navigation Expert → Output → PFS output 1 to n → Invert outp.sig. (0470-1 to n)


Description Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting No

Additional information *Selection*
No option (passive - negative)



Yes option (passive - positive)



3.5.3 "Relay output 1 to n" submenu

Navigation Expert → Output → Relay output 1 to n

► Relay output 1 to n

Terminal number (0812-1 to n)

→ 141

Relay output function (0804-1 to n)	→ 141
Assign flow direction check (0808-1 to n)	→ 142
Assign limit (0807-1 to n)	→ 142
Assign diagnostic behavior (0806-1 to n)	→ 143
Assign status (0805-1 to n)	→ 144
Switch-off value (0809-1 to n)	→ 144
Switch-off delay (0813-1 to n)	→ 145
Switch-on value (0810-1 to n)	→ 145
Switch-on delay (0814-1 to n)	→ 146
Failure mode (0811-1 to n)	→ 146
Switch state (0801-1 to n)	→ 146
Powerless relay status (0816-1 to n)	→ 147

Terminal number

Navigation Expert → Output → Relay output 1 to n → Terminal no. (0812-1 to n)

Description Displays the terminal numbers used by the relay output module.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information "Not used" option

The relay output module does not use any terminal numbers.

Relay output function



Navigation Expert → Output → Relay output 1 to n → Relay outp.func. (0804-1 to n)

Description Use this function to select an output function for the relay output.

Selection	<ul style="list-style-type: none"> ■ Closed ■ Open ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status
Factory setting	Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Closed The relay output is permanently switched on (closed, conductive). ■ Open The relay output is permanently switched off (open, non-conductive). ■ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ■ Flow direction check Indicates the flow direction (forward or reverse flow). ■ Digital Output Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign flow direction check



Navigation	Expert → Output → Relay output 1 to n → Assign dir.check (0808-1 to n)
Prerequisite	The Flow direction check option is selected in the Relay output function parameter (0804) (→ 141).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Flow velocity
Factory setting	Volume flow

Assign limit



Navigation	Expert → Output → Relay output 1 to n → Assign limit (0807-1 to n)
Prerequisite	The Limit option is selected in the Relay output function parameter (0804) (→ 141).
Description	Use this function to select a process variable for the limit value function.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*
- NSV flow*
- API gravity*
- API slope*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Profile factor*
- Cross flow factor*

Factory setting

Volume flow

Assign diagnostic behavior**Navigation**

Expert → Output → Relay output 1 to n → Assign diag. beh (0806–1 to n)

Prerequisite

In the **Relay output function** parameter (0804) (→ 141), the **Diagnostic behavior** option is selected.

Description

Use this function to select the category of the diagnostic events that are displayed for the relay output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting

Alarm

* Visibility depends on order options or device settings

Additional information*Description*

If no diagnostic event is pending, the relay output is closed and conductive.

Selection

- Alarm
The relay output signals only diagnostic events in the alarm category.
- Alarm or warning
The relay output signals diagnostic events in the alarm and warning category.
- Warning
The relay output signals only diagnostic events in the warning category.

Assign status**Navigation**

Expert → Output → Relay output 1 to n → Assign status (0805–1 to n)

Prerequisite

In the **Relay output function** parameter (0804) (→ 141), the **Digital Output** option is selected.

Description

Use this function to select the device status for the relay output.

Selection

- Off
- Low flow cut off
- Product identification *

Factory setting

Off

Switch-off value**Navigation**

Expert → Output → Relay output 1 to n → Switch-off value (0809–1 to n)

Prerequisite

The **Limit** option is selected in the **Relay output function** parameter (0804) (→ 141).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

0 m³/h

* Visibility depends on order options or device settings

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).



When using a hysteresis: Switch-on value (0466) > Switch-off value (0464).

Dependency

The unit is dependent on the process variable selected in the **Assign limit** parameter (0807) (→ 142).

Switch-off delay**Navigation**

Expert → Output → Relay output 1 to n → Switch-off delay (0813-1 to n)

Prerequisite

In the **Relay output function** parameter (0804) (→ 141), the **Limit** option is selected.

Description

Use this function to enter a delay time for switching off the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Switch-on value**Navigation**

Expert → Output → Relay output 1 to n → Switch-on value (0810-1 to n)

Prerequisite

The **Limit** option is selected in the **Relay output function** parameter (0804) (→ 141).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

0 m³/h

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).



When using a hysteresis: Switch-on value (0466) > Switch-off value (0464).

Dependency

The unit is dependent on the process variable selected in the **Assign limit** parameter (0807) (→ 142).

Switch-on delay

Navigation Expert → Output → Relay output 1 to n → Switch-on delay (0814–1 to n)

Prerequisite In the **Relay output function** parameter (0804) (→ 141), the **Limit** option is selected.

Description Use this function to enter a delay time for switching on the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode

Navigation Expert → Output → Relay output 1 to n → Failure mode (0811–1 to n)

Description Use this function to select the failure mode of the relay output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting Open

Additional information Selection

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the relay output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the relay output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the relay output's transistor is set to **conductive**.

Switch state

Navigation Expert → Output → Relay output 1 to n → Switch state (0801–1 to n)

Description Displays the current status of the relay output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

Powerless relay status**Navigation**

Expert → Output → Relay output 1 to n → Powerless relay (0816–1 to n)

Description

Use this function to select the quiescent state for the relay output.

Selection

- Open
- Closed

Factory setting

Open

Additional information*Selection*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

3.5.4 "Double pulse output" submenu*Navigation*

Expert → Output → Double pulse out

► Double pulse output	
Master terminal number (0981)	→ 148
Slave terminal number (0990)	→ 148
Signal mode (0991)	→ 148
Assign pulse output (0982)	→ 149
Value per pulse (0983)	→ 149
Pulse width (0986)	→ 150
Phase shift (0992)	→ 150
Measuring mode (0984)	→ 150

Failure mode (0985)	→ 151
Pulse output (0987)	→ 152
Invert output signal (0993)	→ 152

Master terminal number

Navigation Expert → Output → Double pulse out → Master term. no. (0981)

Description Displays the master terminal number for the double pulse output.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information "Not used" option
The double pulse output does not use any terminal numbers.

Slave terminal number

Navigation Expert → Output → Double pulse out → Slave term. no. (0990)

Description Displays the slave terminal number for the double pulse output.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information "Not used" option
The double pulse output does not use any terminal numbers.

Signal mode

Navigation Expert → Output → Double pulse out → Signal mode (0991)

Description Use this function to select the signal mode for the double pulse output.

Selection

- Passive
- Active *
- Passive NE

* Visibility depends on order options or device settings

Factory setting	Passive
------------------------	---------

Assign pulse output

Navigation Expert → Output → Double pulse out → Assign pulse (0982)

Description Use this function to select a process variable for the double pulse output.

Selection

- Off
- Volume flow
- Mass flow
- GSV flow *
- NSV flow *
- S&W volume flow *
- Product 1 volume flow *
- Product 2 volume flow *
- Product 3 volume flow *
- Product 4 volume flow *
- Product 5 volume flow *
- Product 1 mass flow *
- Product 2 mass flow *
- Product 3 mass flow *
- Product 4 mass flow *
- Product 5 mass flow *
- Product 1 NSV flow *
- Product 2 NSV flow *
- Product 3 NSV flow *
- Product 4 NSV flow *
- Product 5 NSV flow *

Factory setting	Off
------------------------	-----

Value per pulse

Navigation Expert → Output → Double pulse out → Value per pulse (0983)

Description Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information

User entry
Weighting of the pulse output with a quantity.
The lower the pulse value, the
■ better the resolution.
■ the higher the frequency of the pulse response.

* Visibility depends on order options or device settings

Pulse width**Navigation**

Expert → Output → Double pulse out → Pulse width (0986)

Description

Use this function to enter the duration of the output pulse.

User entry

0.5 to 2 000 ms

Factory setting

0.5 ms

Additional information For a detailed description and example: **Pulse width** parameter (0452) (→ 125)**Phase shift****Navigation**

Expert → Output → Double pulse out → Phase shift (0992)

Description

Use this function to select the degree of phase shift.

Selection

- 90°
- 180°

Factory setting

90°

Additional information*Selection*

- 90°
Phase shift by a quarter period.
- 180°
Phase shift by a half period, which is equivalent to a phase reversal.

Measuring mode**Navigation**

Expert → Output → Double pulse out → Measuring mode (0984)

Description

Use this function to select the measuring mode for the double pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information*Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Reverse flow compensation
The flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



For a detailed description of the options available, see the **Measuring mode** parameter (0351) (→ 113)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (0351) (→ 113)

Failure mode**Navigation**

Expert → Output → Double pulse out → Failure mode (0985)

Description

Use this function to select the failure mode of the double pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the double pulse output shows a predefined behavior in the event of a device alarm.

Options

- Actual value
In the event of a device alarm, the double pulse output continues on the basis of the current flow measurement. The fault is ignored.
- No pulses
In the case of the double pulse output, if a device alarm occurs one pulse output is stopped and the other pulse output runs at the maximum pulse frequency.

NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The **Actual value** option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.

Pulse output

Navigation  Expert → Output → Double pulse out → Pulse output (0987)

Description Displays the pulse frequency of the double pulse output which is currently output.

User interface Positive floating-point number

Additional information  For a detailed description and example: **Pulse output** parameter (0456–1 to n)
(→  58)

Invert output signal




Navigation  Expert → Output → Double pulse out → Invert outp.sig. (0993)

Description Use this function to select whether to invert the output signal.


Selection
■ No
■ Yes

Factory setting No

Additional information *Selection*
No option (passive - negative)




Yes option (passive - positive)



3.6 "Communication" submenu

Navigation


Expert → Communication



3.6.1 "HART input" submenu

Navigation


Expert → Communication → HART input



"Configuration" submenu

Navigation

Expert → Communication → HART input → Configuration



Failure mode (7011)	→ 157
Failure value (7012)	→ 158

Capture mode



Navigation

Expert → Communication → HART input → Configuration → Capture mode (7001)

Description

Use this function to select the capture mode via burst or master communication.

Selection

- Off
- Burst network
- Master network

Factory setting

Off

Additional information

"Burst network" option

The device records data transmitted via burst in the network.

An external pressure sensor must be in the burst mode.

"Master network" option

In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.

Device ID



Navigation

Expert → Communication → HART input → Configuration → Device ID (7007)

Prerequisite

The **Master network** option is selected in the **Capture mode** parameter (7001) (→ 154).

Description

Use this function to enter the device ID of the HART slave device whose data are to be recorded.

User entry

6-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting

0

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	Expert → Communication → HART input → Configuration → Device type (7008)
Prerequisite	In the Capture mode parameter (7001) (→ 154), the Master network option is selected.
Description	Use this function to enter the device type of the HART slave device whose data are to be recorded.
User entry	2-digit hexadecimal number
Factory setting	0x00
Additional information	In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Manufacturer ID

Navigation	Expert → Communication → HART input → Configuration → Manufacturer ID (7009)
Prerequisite	The Master network option is selected in the Capture mode parameter (7001) (→ 154).
Description	Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.
User entry	2-digit value: ■ Via local operation: enter as hexadecimal or decimal number ■ Via operating tool: enter as decimal number
Factory setting	0
Additional information	In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Burst command

Navigation	Expert → Communication → HART input → Configuration → Burst command (7006)
Prerequisite	The Burst network option or the Master network option are selected in the Capture mode parameter (7001) (→ 154).
Description	Use this function to select the burst command to be recorded.

Selection	<ul style="list-style-type: none"> ■ Command 1 ■ Command 3 ■ Command 9 ■ Command 33
Factory setting	Command 1
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Command 1 Use this function to capture the primary variable. ■ Command 3 Use this function to capture the dynamic HART variables and the current. ■ Command 9 Use this function to capture the dynamic HART variables including the associated status. ■ Command 33 Use this function to capture the dynamic HART variables including the associated unit.

Slot number																																																		
Navigation	  Expert → Communication → HART input → Configuration → Slot number (7010)																																																	
Prerequisite	The Burst network option or the Master network option is selected in the Capture mode parameter (7001) (→  154).																																																	
Description	Use this function to enter the position of the process variable to be recorded in the burst command.																																																	
User entry	1 to 8																																																	
Factory setting	1																																																	
Additional information	<i>User entry</i>																																																	
<table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">Slot</th> <th colspan="4">Command</th> </tr> <tr> <th>1</th> <th>3</th> <th>9</th> <th>33</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>PV</td> <td>PV</td> <td>HART variable (slot 1)</td> <td>HART variable (slot 1)</td> </tr> <tr> <td>2</td> <td>-</td> <td>SV</td> <td>HART variable (slot 2)</td> <td>HART variable (slot 2)</td> </tr> <tr> <td>3</td> <td>-</td> <td>TV</td> <td>HART variable (slot 3)</td> <td>HART variable (slot 3)</td> </tr> <tr> <td>4</td> <td>-</td> <td>QV</td> <td>HART variable (slot 4)</td> <td>HART variable (slot 4)</td> </tr> <tr> <td>5</td> <td>-</td> <td>-</td> <td>HART variable (slot 5)</td> <td>-</td> </tr> <tr> <td>6</td> <td>-</td> <td>-</td> <td>HART variable (slot 6)</td> <td>-</td> </tr> <tr> <td>7</td> <td>-</td> <td>-</td> <td>HART variable (slot 7)</td> <td>-</td> </tr> <tr> <td>8</td> <td>-</td> <td>-</td> <td>HART variable (slot 8)</td> <td>-</td> </tr> </tbody> </table>		Slot	Command				1	3	9	33	1	PV	PV	HART variable (slot 1)	HART variable (slot 1)	2	-	SV	HART variable (slot 2)	HART variable (slot 2)	3	-	TV	HART variable (slot 3)	HART variable (slot 3)	4	-	QV	HART variable (slot 4)	HART variable (slot 4)	5	-	-	HART variable (slot 5)	-	6	-	-	HART variable (slot 6)	-	7	-	-	HART variable (slot 7)	-	8	-	-	HART variable (slot 8)	-
Slot	Command																																																	
	1	3	9	33																																														
1	PV	PV	HART variable (slot 1)	HART variable (slot 1)																																														
2	-	SV	HART variable (slot 2)	HART variable (slot 2)																																														
3	-	TV	HART variable (slot 3)	HART variable (slot 3)																																														
4	-	QV	HART variable (slot 4)	HART variable (slot 4)																																														
5	-	-	HART variable (slot 5)	-																																														
6	-	-	HART variable (slot 6)	-																																														
7	-	-	HART variable (slot 7)	-																																														
8	-	-	HART variable (slot 8)	-																																														

Timeout**Navigation**

Expert → Communication → HART input → Configuration → Timeout (7005)

Prerequisite

The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (7001) (→ 154).

Description

Use this function to enter the maximum permitted interval between two HART frames.

User entry

1 to 120 s

Factory setting

5 s

Additional information*Description*

If the interval is exceeded, the measuring device displays the **F882 Input signal** diagnostic message.

Failure mode**Navigation**

Expert → Communication → HART input → Configuration → Failure mode (7011)

Prerequisite

In the **Capture mode** parameter (7001) (→ 154), the **Burst network** option or **Master network** option is selected.

Description

Use this function to select the device behavior if no data are recorded within the maximum permitted interval.

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information*Options*

- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used: (**Failure value** parameter (7012) (→ 158)).

Failure value**Navigation**

Expert → Communication → HART input → Configuration → Failure value (7012)

Prerequisite

The following conditions are met:

- In the **Capture mode** parameter (7001) (→ 154), the **Burst network** option or **Master network** option is selected.
- In the **Failure mode** parameter (7011) (→ 157), the **Defined value** option is selected.

Description

Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.

User entry

Signed floating-point number

Factory setting

0


Additional information

Dependency

The unit is taken from the **Pressure unit** parameter (0564)

"Input" submenu**Navigation**

Expert → Communication → HART input → Input



Value**Navigation**

Expert → Communication → HART input → Input → Value (7003)

Description

Displays the value of the device variable recorded by the HART input.

User interface

Signed floating-point number

Status**Navigation**
 Expert → Communication → HART input → Input → Status (7004)
Description

Displays the value of the device variable recorded by the HART input in accordance with the HART specification.

User interface

- Manual/Fixed
- Good
- Poor accuracy
- Bad

Additional information*Description*

If the measuring device reads in an invalid pressure measured value, the **F882 Input signal** diagnostic message is output

3.6.2 "HART output" submenu*Navigation*
 Expert → Communication → HART output

► HART output	
► Configuration	→  159
► Burst configuration	→  161
► Information	→  168
► Output	→  171

"Configuration" submenu*Navigation*
 Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→  160
Device tag (0215)	→  160
HART address (0219)	→  160
No. of preambles (0217)	→  160
Fieldbus writing access (0273)	→  161

HART short tag

Navigation	Expert → Communication → HART output → Configuration → HART short tag (0220)
Description	Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).
Factory setting	PROSONIC

Device tag

Navigation	Expert → Communication → HART output → Configuration → Device tag (0215)
Description	Use this function to enter the name for the measuring point.
User entry	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	Prosonic Flow

HART address

Navigation	Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0
Additional information	<i>Description</i> For addressing in a HART Multidrop network, the Fixed current option must be set in the Current span parameter (0353) (→ 109) (current output 1).

No. of preambles

Navigation	Expert → Communication → HART output → Configuration → No. of preambles (0217)
Description	Use this function to enter the number of preambles in the HART protocol.

User entry	2 to 20
Factory setting	5
Additional information	<p><i>User entry</i></p> <p>As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.</p>

Fieldbus writing access

Navigation	Expert → Communication → HART output → Configuration → Fieldb.writ.acc. (0273)
Description	Use this function to restrict access to the measuring device via fieldbus (HART interface).
Selection	<ul style="list-style-type: none"> ■ Read + write ■ Read only
Factory setting	Read + write
Additional information	<p><i>Description</i></p> <p>If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Read + write The parameters are readable and writable. ■ Read only The parameters are only readable.

"Burst configuration 1 to n" submenu

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n

Burst configuration 1 to n	
Burst mode 1 to n (2032–1 to n)	→ 162
Burst command 1 to n (2031–1 to n)	→ 162
Burst variable 0 (2033)	→ 163
Burst variable 1 (2034)	→ 164
Burst variable 2 (2035)	→ 165

Burst variable 3 (2036)	→ 165
Burst variable 4 (2037)	→ 165
Burst variable 5 (2038)	→ 165
Burst variable 6 (2039)	→ 166
Burst variable 7 (2040)	→ 166
Burst trigger mode (2044-1 to n)	→ 166
Burst trigger level (2043-1 to n)	→ 167
Min. update period (2042-1 to n)	→ 167
Max. update period (2041-1 to n)	→ 168

Burst mode 1 to n**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst mode 1 to n (2032-1 to n)

Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
- On

Factory setting

Off

Additional information*Options*

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Burst command 1 to n**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst command 1 to n (2031-1 to n)

Description

Use this function to select the HART command that is sent to the HART master.

Selection

- Command 1
- Command 2
- Command 3

	<ul style="list-style-type: none"> ■ Command 9 ■ Command 33 ■ Command 48
Factory setting	Command 2
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Command 1 Read out the primary variable. ■ Command 2 Read out the current and the main measured value as a percentage. ■ Command 3 Read out the dynamic HART variables and the current. ■ Command 9 Read out the dynamic HART variables including the related status. ■ Command 33 Read out the dynamic HART variables including the related unit. ■ Command 48 Read out the complete device diagnostics.

"Command 33" option

The HART device variables are defined via Command 107.

The following measured variables (HART device variables) can be read out:

- Volume flow
- Mass flow *
- Temperature *
- Totalizer 1...3
- Sound velocity
- Flow velocity
- Acceptance rate *
- Turbulence *
- Signal strength *
- Signal to noise ratio *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)

Commands



- Information about the defined details of the command: HART specifications
- The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 107).

Burst variable 0



Navigation

Diagram: Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 0 (2033)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

* Visibility depends on order options or device settings

Selection

- Not used
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*
- NSV flow*
- API gravity*
- API slope
- Electronics temperature*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Cross flow factor*
- Profile factor*
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- HART input
- Percent of range
- Measured current
- Current input 1*
- Current input 2*
- Current input 3*

Factory setting

Volume flow

Additional information*Options*

If a burst message is not configured, the **Not used** option is set.

Burst variable 1**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 1 (2034)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (2033) (→ 163).

Factory setting

Not used

* Visibility depends on order options or device settings

Burst variable 2

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 2 (2035)
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (2033) (→ 163).
Factory setting	Not used

Burst variable 3

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 3 (2036)
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (2033) (→ 163).
Factory setting	Not used

Burst variable 4

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 4 (2037)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (2033) (→ 163).
Factory setting	Not used

Burst variable 5

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 5 (2038)
Description	For HART command 9: select the HART device variable or the process variable.
Selection	See the Burst variable 0 parameter (2033) (→ 163).
Factory setting	Not used

Burst variable 6

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 6 (2039)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (2033) (→ 163).

Factory setting Not used

Burst variable 7

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 7 (2040)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (2033) (→ 163).

Factory setting Not used

Burst trigger mode

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Trigger mode (2044-1 to n)

Description Use this function to select the event that triggers burst message X.

Selection

- Continuous
- Window
- Rising
- Falling
- On change

Factory setting Continuous

Additional information*Selection*

- Continuous
The message is sent continuously, at least at intervals corresponding to the time frame specified in the **Burst min period** parameter (2042) (→ 167).
- Window
The message is sent if the specified measured value has changed by the value in the **Burst trigger level** parameter (2043) (→ 167).
- Rising
The message is sent if the specified measured value exceeds the value in the **Burst trigger level** parameter (2043) (→ 167).
- Falling
The message is sent if the specified measured value drops below the value in the **Burst trigger level** parameter (2043) (→ 167).
- On change
The message is sent if a measured value changes in the burst message.

Burst trigger level**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Trigger level (2043–1 to n)

Description

For entering the burst trigger value.

User entry

Signed floating-point number

Additional information*Description*

Together with the option selected in the **Burst trigger mode** parameter (2044) (→ 166) the burst trigger value determines the time of burst message X.

Min. update period**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Min. upd. per. (2042–1 to n)

Description

Use this function to enter the minimum time span between two burst commands of burst message X.

User entry

Positive integer

Factory setting

1 000 ms

Max. update period**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Max. upd. per. (2041–1 to n)

Description

Use this function to enter the maximum time span between two burst commands of burst message X.

User entry

Positive integer

Factory setting

2 000 ms

"Information" submenu*Navigation*

Expert → Communication → HART output → Information

▶ Information	
Device revision (0204)	→ 168
Device ID (0221)	→ 169
Device type (0209)	→ 169
Manufacturer ID (0259)	→ 169
HART revision (0205)	→ 170
HART descriptor (0212)	→ 170
HART message (0216)	→ 170
Hardware revision (0206)	→ 170
Software revision (0224)	→ 171
HART date code (0202)	→ 171

Device revision**Navigation**

Expert → Communication → HART output → Information → Device revision (0204)

Description

Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x5D

Additional information *Description*

 The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation   Expert → Communication → HART output → Information → Device ID (0221)

Description Use this function to view the device ID for identifying the measuring device in a HART network.

User interface 6-digit hexadecimal number

Additional information *Description*

 In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation   Expert → Communication → HART output → Information → Device type (0209)

Description Displays the device type with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x5D (for Prosonic Flow P 500)

Additional information *Description*

 The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID

Navigation   Expert → Communication → HART output → Information → Manufacturer ID (0259)

Description Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

HART revision

Navigation  Expert → Communication → HART output → Information → HART revision (0205)

Description Use this function to display the HART protocol revision of the measuring device.

User interface 5 to 7

Factory setting 7

HART descriptor



Navigation  Expert → Communication → HART output → Information → HART descriptor (0212)

Description Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry Max. 16 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Pros.Flow300/500

HART message



Navigation  Expert → Communication → HART output → Information → HART message (0216)

Description Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Pros.Flow300/500

Hardware revision

Navigation  Expert → Communication → HART output → Information → Hardware rev. (0206)

Description Displays the hardware revision of the measuring device.

User interface 0 to 255

Factory setting 1

Software revision

Navigation	Expert → Communication → HART output → Information → Software rev. (0224)
Description	Displays the software revision of the measuring device.
User interface	0 to 255
Factory setting	3

HART date code

Navigation	Expert → Communication → HART output → Information → HART date code (0202)
Description	Use this function to enter the date information for individual use.
User entry	Date entry format: yyyy-mm-dd
Factory setting	2009-07-20
Additional information	<p><i>Example</i></p> <p>Device installation date</p>

"Output" submenu*Navigation*

Expert → Communication → HART output → Output

► Output	
Assign PV (0234)	→ 172
Primary variable (PV) (0201)	→ 172
Assign SV (0235)	→ 173
Secondary variable (SV) (0226)	→ 173
Assign TV (0236)	→ 174
Tertiary variable (TV) (0228)	→ 175
Assign QV (0237)	→ 175
Quaternary variable (QV) (0203)	→ 176

Assign PV**Navigation**

Expert → Communication → HART output → Output → Assign PV (0234)

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Off *
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity *
- Temperature *
- Pressure *
- Density *
- Reference density *
- S&W volume flow *
- GSV flow *
- NSV flow *
- API gravity *
- API slope *
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature
- Profile factor *
- Cross flow factor *

Factory setting

Volume flow

Primary variable (PV)**Navigation**

Expert → Communication → HART output → Output → Primary var (PV) (0201)

Description

Displays the current measured value of the primary dynamic variable (PV).

User interface

Signed floating-point number

Additional information*Display*

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (0234) (→ 172).

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

* Visibility depends on order options or device settings

Assign SV**Navigation**

Expert → Communication → HART output → Output → Assign SV (0235)

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*
- NSV flow*
- API gravity*
- API slope*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current input 1*
- Current input 2*
- Current input 3*
- Profile factor*
- Cross flow factor*
- HART input

Factory setting

Totalizer 1

Secondary variable (SV)**Navigation**

Expert → Communication → HART output → Output → Second.var(SV) (0226)

Description

Displays the current measured value of the secondary dynamic variable (SV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*Display*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (0235) (→ 173).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

Assign TV**Navigation**

 Expert → Communication → HART output → Output → Assign TV (0236)

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*
- NSV flow*
- API gravity*
- API slope*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence*
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Current input 1*
- Current input 2*
- Current input 3*
- Profile factor*
- Cross flow factor*
- HART input

Factory setting

Totalizer 2

* Visibility depends on order options or device settings

Tertiary variable (TV)

Navigation	 Expert → Communication → HART output → Output → Tertiary var(TV) (0228)
Description	Displays the current measured value of the tertiary dynamic variable (TV).
User interface	Signed floating-point number
Additional information	<p><i>Display</i></p> <p>The measured value displayed depends on the process variable selected in the Assign TV parameter (0236) (→  174).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  61).</p>

Assign QV

Navigation	 Expert → Communication → HART output → Output → Assign QV (0237)
Description	Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).
Selection	<ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Flow velocity ▪ Sound velocity* ▪ Temperature* ▪ Pressure* ▪ Density* ▪ Reference density* ▪ S&W volume flow* ▪ GSV flow* ▪ NSV flow* ▪ API gravity* ▪ API slope* ▪ Signal strength* ▪ Signal to noise ratio* ▪ Acceptance rate* ▪ Turbulence* ▪ Electronics temperature ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3 ▪ Current input 1* ▪ Current input 2* ▪ Current input 3* ▪ Profile factor* ▪ Cross flow factor* ▪ HART input

* Visibility depends on order options or device settings

Factory setting Totalizer 3

Quaternary variable (QV)

Navigation  Expert → Communication → HART output → Output → Quaternary.var(QV) (0203)

Description Displays the current measured value of the quaternary dynamic variable (QV).

User interface Signed floating-point number

Additional information *Display*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (0237) (→  175).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  61).

3.6.3 "Web server" submenu

Navigation  Expert → Communication → Web server

 Web server	
Web server language (7221)	→  177
MAC address (7214)	→  177
DHCP client (7212)	→  177
IP address (7209)	→  178
Subnet mask (7211)	→  178
Default gateway (7210)	→  178
Web server functionality (7222)	→  179
Login page (7273)	→  179

Web server language

Navigation	  Expert → Communication → Web server → Webserv.language (7221)
Description	Use this function to select the language configured for the Web server.
Selection	<ul style="list-style-type: none"> ■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ tiếng Việt (Vietnamese) ■ čeština (Czech)
Factory setting	English

MAC address

Navigation	  Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁵⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<p><i>Example</i></p> <p>For the display format 00:07:05:10:01:5F</p>

DHCP client



Navigation	  Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.

5) Media Access Control

Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	On
Additional information	<p><i>Effect</i></p> <p>If the DHCP client functionality of the web server is selected, the IP address (7209) (→ 178), Subnet mask (7211) (→ 178) and Default gateway (7210) (→ 178) are set automatically.</p> <p> ▪ Identification is via the MAC address of the measuring device. ▪ The IP address (7209) (→ 178) in the IP address parameter (7209) (→ 178) is ignored as long as the DHCP client parameter (7212) (→ 177) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (7209) (→ 178) in the parameter of the same name is only used if the DHCP client parameter (7212) (→ 177) is inactive.</p>

IP address	
Navigation	 Expert → Communication → Web server → IP address (7209)
Description	Display or enter the IP address (7209) of the Web server integrated in the measuring device.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

Subnet mask	
Navigation	 Expert → Communication → Web server → Subnet mask (7211)
Description	Display or enter the subnet mask.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	255.255.255.0

Default gateway	
Navigation	 Expert → Communication → Web server → Default gateway (7210)
Description	Display or enter the Default gateway (7210) (→ 178).
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	0.0.0.0

Web server functionality

Navigation Expert → Communication → Web server → Webserver funct. (7222)

Description Use this function to switch the Web server on and off.

- Selection**
- Off
 - HTML Off
 - On

Factory setting On

Additional information *Description*

Once disabled, the Web server functionality (7222) can only be enabled again via the local display, the FieldCare operating tool or the DeviceCare operating tool.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ▪ The Web server is completely disabled. ▪ Port 80 is locked.
HTML Off	The HTML version of the Web server is not available.
On	<ul style="list-style-type: none"> ▪ The complete Web server functionality is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state.

Login page

Navigation Expert → Communication → Web server → Login page (7273)

Description Use this function to select the format of the login page.

- Selection**
- Without header
 - With header

Factory setting With header

3.6.4 "Diagnostic configuration" submenu

For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Assign a category to the particular diagnostic event:

Category	Meaning
Failure (F)	A device error has occurred. The measured value is no longer valid.
Function check (C)	The device is in the service mode (e.g. during a simulation).

Category	Meaning
Out of specification (S)	The device is being operated: ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
Maintenance required (M)	Maintenance is required. The measured value remains valid.
No effect (N)	Has no effect on the condensed status ¹⁾ .

1) Condensed status according to NAMUR recommendation NE 107

Navigation

Expert → Communication → Diag. config.

► Diagnostic configuration	
Event category 160 (0272)	→ 181
Event category 441 (0210)	→ 181
Event category 444 (0211)	→ 182
Event category 442 (0230)	→ 181
Event category 443 (0231)	→ 182
Event category 543 (0276)	→ 183
Event category 832 (0218)	→ 183
Event category 833 (0225)	→ 183
Event category 841 (0267)	→ 184
Event category 842 (0295)	→ 184
Event category 870 (0250)	→ 185
Event category 930 (0296)	→ 185
Event category 931 (0297)	→ 186
Event category 941 (0294)	→ 187
Event category 942 (0302)	→ 187
Event category 943 (0301)	→ 187

Event category 160 (Signal path switched off)



Navigation Expert → Communication → Diag. config. → Event category 160 (0272)

Description Use this function to select a category for the **160 Signal path switched off** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Maintenance required (M)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 441 (Current output 1 to n)



Navigation Expert → Communication → Diag. config. → Event category 441 (0210)

Description Use this function to select a category for the **441 Current output 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 442 (Frequency output 1 to n)



Navigation Expert → Communication → Diag. config. → Event category 442 (0230)

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select a category for the **442 Frequency output 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the event categories available for selection: →  179

Event category 443 (Pulse output 1 to n)

Navigation   Expert → Communication → Diag. config. → Event category 443 (0231)

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select a category for the **443 Pulse output 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the event categories available for selection: →  179

Event category 444 (Current input 1 to n)

Navigation   Expert → Communication → Diag. config. → Event category 444 (0211)

Prerequisite The current input is available.

Description Use this function to select a category for the **444 Current input 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*

 For a detailed description of the event categories available for selection: →  179

Event category 543 (Double pulse output)



Navigation Expert → Communication → Diag. config. → Event category 543 (0276)

Description Use this option to select a category for the **543 Double pulse output** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 832 (Electronics temperature too high)



Navigation Expert → Communication → Diag. config. → Event category 832 (0218)

Description Use this function to select a category for the **832 Electronics temperature too high** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*

For a detailed description of the event categories available for selection: → [179](#)

Event category 833 (Electronics temperature too low)



Navigation Expert → Communication → Diag. config. → Event category 833 (0225)

Description Use this option to select a category for the **833 Electronics temperature too low** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*



For a detailed description of the event categories available for selection: → [179](#)

Event category 841 (Flow velocity too high)



Navigation Expert → Communication → Diag. config. → Event category 841 (0267)

Description Use this function to assign a category to the **△S841 Flow velocity too high** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 842 (Process limit)



Navigation Expert → Communication → Diag. config. → Event category 842 (0295)

Description Use this function to assign a category to the **842 Process limit** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*



For a detailed description of the event categories available for selection: → [179](#)

Event category 870 (Measuring inaccuracy increased)

Navigation Expert → Communication → Diag. config. → Event category 870 (0250)

Description Use this function to select a category for the **870 Measuring inaccuracy increased** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting No effect (N)

Additional information *Selection*



For a detailed description of the event categories available for selection: → 179

Event category 881 (Sensor signal path 1 to n)

Navigation Expert → Communication → Diag. config. → Event category 881 (0268)

Description Use this function to select a category for the **881 Sensor signal path 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Failure (F)

Additional information For a detailed description of the event categories available for selection: → 179

Event category 930 (Process fluid)

Navigation Expert → Communication → Diag. config. → Event category 930 (0296)

Description Use this function to select a category for the **△S930 Process fluid** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*

 For a detailed description of the event categories available for selection: → [179](#)

Event category 931 (Process fluid)



Navigation  Expert → Communication → Diag. config. → Event category 931 (0297)

Description Use this function to select a category for the **△S931 Process fluid** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information *Selection*

 For a detailed description of the event categories available for selection: → [179](#)

Event category 953 (Asymmetry noise signal too high path 1 to n)



Navigation  Expert → Communication → Diag. config. → Event category 953 (0292)

Description Use this function to select a category for the **△M953 Asymmetry noise signal too high path 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Failure (F)

Additional information *Selection*

 For a detailed description of the event categories available for selection: → [179](#)

Event category 941 (API/ASTM temperature out of specification.)

Navigation Expert → Communication → Diag. config. → Event category 941 (0294)

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 942 (API/ASTM density out of specification)

Navigation Expert → Communication → Diag. config. → Event category 942 (0302)

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [179](#)

Event category 943 (API pressure out of specification)

Navigation Expert → Communication → Diag. config. → Event category 943 (0301)

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional informationFor a detailed description of the event categories available for selection: → [179](#)

3.6.5 "WLAN settings" wizard

Navigation

Expert → Communication → WLAN settings

	→ 189
► WLAN settings	
WLAN (2702)	→ 189
WLAN mode (2717)	→ 189
SSID name (2714)	→ 189
Network security (2705)	→ 190
Security identification (2718)	→ 190
User name (2715)	→ 190
WLAN password (2716)	→ 191
WLAN IP address (2711)	→ 191
WLAN MAC address (2703)	→ 191
WLAN subnet mask (2709)	→ 192
WLAN MAC address (2703)	→ 191
WLAN passphrase (2706)	→ 192
WLAN MAC address (2703)	→ 191
Assign SSID name (2708)	→ 192
SSID name (2707)	→ 193
2.4 GHz WLAN channel (2704)	→ 193
Select antenna (2713)	→ 193
Connection state (2722)	→ 194
Received signal strength (2721)	→ 194

WLAN IP address (2711)	→ 191
Gateway IP address (2719)	→ 194
IP address domain name server (2720)	→ 194

WLAN

Navigation Expert → Communication → WLAN settings → WLAN (2702)

Description Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting Enable

WLAN mode

Navigation Expert → Communication → WLAN settings → WLAN mode (2717)

Description Use this function to select the WLAN mode.

Selection

- WLAN access point
- WLAN Client

Factory setting WLAN access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.
- EAP-PEAP with MSCHAPv2
Access the WLAN connection with a password-based authentication protocol.
- EAP-PEAP MSCHAPv2 no server authentic.
Access the WLAN connection with a password-based protocol without server authentication.
- EAP-TLS
Access the WLAN connection with a certificate-based, two-way authentication of the client and network.

Security identification

Navigation Expert → Communication → WLAN settings → Sec. identific. (2718)

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

User interface

- Trusted issuer certificate
- Device certificate
- Device private key

User name

Navigation Expert → Communication → WLAN settings → User name (2715)

Description Use this function to enter the username of the WLAN network.

User entry

—

* Visibility depends on order options or device settings

Factory setting

–

WLAN password**Navigation** Expert → Communication → WLAN settings → WLAN password (2716)**Description** Use this function to enter the WLAN password for the WLAN network.**User entry** –**Factory setting** –**WLAN IP address****Navigation** Expert → Communication → WLAN settings → WLAN IP address (2711)**Description** Use this function to enter the IP address of the measuring device's WLAN connection.**User entry** 4 octet: 0 to 255 (in the particular octet)**Factory setting** 192.168.1.212**WLAN MAC address****Navigation** Expert → Communication → WLAN settings → WLAN MAC address (2703)**Description** Displays the MAC⁶⁾ address of the measuring device.**User interface** Unique 12-digit character string comprising letters and numbers**Factory setting** Each measuring device is given an individual address.**Additional information** *Example*

For the display format

00:07:05:10:01:5F

6) Media Access Control

WLAN subnet mask

Navigation	Expert → Communication → WLAN settings → WLAN subnet mask (2709)
	Expert → Communication → WLAN settings → WLAN subnet mask (2709)
Description	Use this function to enter the subnet mask.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	255.255.255.0

WLAN passphrase

Navigation	Expert → Communication → WLAN settings → WLAN passphrase (2706)
Prerequisite	The WPA2-PSK option is selected in the Security type parameter (2705) (→ 190).
Description	Use this function to enter the network key.
User entry	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)
Factory setting	Serial number of the measuring device (e.g. L100A802000)

Assign SSID name

Navigation	Expert → Communication → WLAN settings → Assign SSID name (2708)
Description	Use this function to select which name is used for the SSID ⁷⁾ .
Selection	<ul style="list-style-type: none">■ Device tag■ User-defined
Factory setting	User-defined
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">■ Device tag The device tag name is used as the SSID.■ User-defined A user-defined name is used as the SSID.

7) Service Set Identifier

SSID name**Navigation**

Expert → Communication → WLAN settings → SSID name (2707)

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (2708) (→ [192](#)).
- The **WLAN access point** option is selected in the **WLAN mode** parameter (2717) (→ [189](#)).

Description

Use this function to enter a user-defined SSID name.

User entry

Max. 32-digit character string comprising numbers, letters and special characters

Factory setting

EH_device designation_last 7 digits of the serial number (e.g.
EH_Prosonic_Flow_500_A802000)

2.4 GHz WLAN channel**Navigation**

Expert → Communication → WLAN settings → WLAN channel (2704)

Description

Use this function to enter the 2.4 GHz WLAN channel (2704).

User entry

1 to 11

Factory setting

6

Additional information*Description*

- It is only necessary to enter a 2.4 GHz WLAN channel (2704) if multiple WLAN devices are in use.
■ If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna**Navigation**

Expert → Communication → WLAN settings → Select antenna (2713)

Description

Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting

Internal antenna

Connection state

Navigation	  Expert → Communication → WLAN settings → Connection state (2722)
Description	The connection status is displayed.
User interface	<ul style="list-style-type: none">▪ Connected▪ Not connected
Factory setting	Not connected

Received signal strength

Navigation	  Expert → Communication → WLAN settings → Rec.sig.strength (2721)
Description	Displays the signal strength received.
User interface	<ul style="list-style-type: none">▪ Low▪ Medium▪ High
Factory setting	High

Gateway IP address

Navigation	  Expert → Communication → WLAN settings → Gateway IP addr. (2719)
Description	Use this function to enter the IP address of the gateway.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212


IP address domain name server

Navigation	  Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212

3.7 "Application" submenu

Navigation

Expert → Application



Reset all totalizers

Navigation

Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the previously aggregated flow values.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information


Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the previously aggregated flow values.

3.7.1 "Totalizer 1 to n" submenu

Navigation

Expert → Application → Totalizer 1 to n



Totalizer 1 to n operation mode (0908–1 to n)	→ 198
Control Totalizer 1 to n (0912–1 to n)	→ 198
Preset value 1 to n (0913–1 to n)	→ 199
Totalizer 1 to n failure behavior (0901–1 to n)	→ 199

Assign process variable 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → AssignVariab. 1 to n (0914–1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow
- S&W volume flow *
- GSV flow *
- NSV flow *
- Product 1 volume flow *
- Product 2 volume flow *
- Product 3 volume flow *
- Product 4 volume flow *
- Product 5 volume flow *
- Product 1 mass flow *
- Product 2 mass flow *
- Product 3 mass flow *
- Product 4 mass flow *
- Product 5 mass flow *
- Product 1 NSV flow *
- Product 2 NSV flow *
- Product 3 NSV flow *
- Product 4 NSV flow *
- Product 5 NSV flow *

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Options

If the **Off** option is selected, only the **Assign process variable** parameter (0914) (→ 196) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

* Visibility depends on order options or device settings

Process variable unit 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → VariableUnit 1 to n (0915–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (0914) (→ [196](#)) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ [195](#)).

Selection

- g *
- kg *
- t *
- oz *
- lb *
- STon *
- cm³ *
- dm³ *
- m³ *
- ml *
- l *
- hl *
- Ml Mega *
- af *
- ft³ *
- Mft³ *
- Mft³ *
- fl oz (us) *
- gal (us) *
- kgal (us) *
- Mgal (us) *
- bbl (us;liq.) *
- bbl (us;beer) *
- bbl (us;oil) *
- bbl (us;tank) *
- gal (imp) *
- Mgal (imp) *
- bbl (imp;beer) *
- bbl (imp;oil) *
- MSft³ *
- None *

Factory setting

Depends on country:

- m³
- ft³

Additional information*Description*

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ [61](#)).

Options

The selection is dependent on the process variable selected in the **Assign process variable** parameter (0914) (→ [196](#)).

* Visibility depends on order options or device settings

Totalizer 1 to n operation mode**Navigation**

Expert → Application → Totalizer 1 to n → Operat. mode 1 to n (0908–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (0914) (→ 196) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net
- Forward
- Reverse

Factory setting

Net flow total

Additional information*Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (0914) (→ 196) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize
- Hold

Factory setting

Totalize

Additional information*Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold ¹⁾	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.

Options	Description
Preset + totalize ¹⁾	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

1) Visible depending on the order options or device settings

Preset value 1 to n

Navigation	Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913–1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (0914) (→ 196) of the Totalizer 1 to n submenu.
Description	Use this function to enter a start value for the Totalizer 1 to n.
User entry	Signed floating-point number
Factory setting	Depends on country: ■ 0 m ³ ■ 0 ft ³
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is defined in the Unit totalizer parameter (0915) (→ 197) for the totalizer.</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Totalizer 1 to n failure behavior



Navigation	Expert → Application → Totalizer 1 to n → FailureBehav. 1 to n (0901–1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (0914) (→ 196) of the Totalizer 1 to n submenu.
Description	Use this function to select how a totalizer behaves in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Hold ■ Continue ■ Last valid value + continue
Factory setting	Stop

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop

The totalizer is stopped in the event of a device alarm.

- Actual value

The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored.

- Last valid value

The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.7.2 "Petroleum" submenu



For detailed information on the parameter descriptions for the **Petroleum** application package, refer to the Special Documentation for the device

Navigation

Expert → Application → Petroleum

► Petroleum

3.7.3 "Product identification" submenu



For detailed information on the parameter descriptions for the **Petroleum** application package, refer to the Special Documentation for the device

Navigation

Expert → Application → Product identif.

► Product identification

3.8 "Diagnostics" submenu

Navigation

Expert → Diagnostics

► Diagnostics

Actual diagnostics (0691)

→ 201

Previous diagnostics (0690)

→ 202

Operating time from restart (0653)

→ 203

Operating time (0652)

→ 203

► Diagnostic list

→ 203

▶ Event logbook	→ 208
▶ Device information	→ 209
▶ Main electronic module + I/O module 1	→ 213
▶ Sensor electronic module (ISEM)	→ 214
▶ I/O module 2	→ 215
▶ I/O module 3	→ 216
▶ Display module	→ 218
▶ Data logging	→ 219
▶ Heartbeat Technology	→ 227
▶ Simulation	→ 237

Actual diagnostics

Navigation

 Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 203).

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:

F271 Main electronic failure

Timestamp

Navigation	  Expert → Diagnostics → Timestamp (0667)
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Actual diagnostics parameter (0691) (→  201).
	<i>Example</i> For the display format: 24d12h13m00s

Previous diagnostics

Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Example</i> For the display format: ☒F271 Main electronic failure

Timestamp

Navigation	  Expert → Diagnostics → Timestamp (0672)
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Previous diagnostics** parameter (0690) (→ 202).

Example

For the display format:

24d12h13m00s

Operating time from restart**Navigation**

Expert → Diagnostics → Time fr. restart (0653)

Description

Use this function to display the time the device has been in operation since the last device restart.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Operating time**Navigation**

Expert → Diagnostics → Operating time (0652)

Description

Displays the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Indication*

Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

3.8.1 "Diagnostic list" submenu*Navigation*

Expert → Diagnostics → Diagnostic list

► Diagnostic list	
Diagnostics 1 (0692)	→ 204
Diagnostics 2 (0693)	→ 204
Diagnostics 3 (0694)	→ 205
Diagnostics 4 (0695)	→ 206
Diagnostics 5 (0696)	→ 207

Diagnostics 1

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Displays the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: <ul style="list-style-type: none">▪  F271 Main electronic failure▪  F276 I/O module failure

Timestamp 1

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp (0683)
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 1 parameter (0692) (→  204).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronic failure
-  F276 I/O module failure

Timestamp 2**Navigation**

  Expert → Diagnostics → Diagnostic list → Timestamp (0684)

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (0693) (→  204).

Example

For the display format:

24d12h13m00s

Diagnostics 3**Navigation**

  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronic failure
-  F276 I/O module failure

Timestamp 3

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp (0685)
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (0694) (→  205).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: ■  F271 Main electronic failure ■  F276 I/O module failure

Timestamp 4

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp (0686)
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (0695) (→ 206).

Example

For the display format:

24d12h13m00s

Diagnostics 5**Navigation**

 Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronic failure
-  F276 I/O module failure

Timestamp 5**Navigation**

 Expert → Diagnostics → Diagnostic list → Timestamp (0687)

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 5** parameter (0696) (→ 207).

Example

For the display format:

24d12h13m00s


3.8.2 "Event logbook" submenu

Viewing event messages

Event messages are displayed in chronological order. The event history includes both diagnostic events and information events. The symbol in front of the timestamp indicates whether the event has started or ended.

Navigation

Expert → Diagnostics → Event logbook



Filter options



Navigation

Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information

Description

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu

- i** The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation
 Expert → Diagnostics → Event logbook → Event list

 Event list

Event list

→  209**Event list****Navigation**
 Expert → Diagnostics → Event logbook → Event list
Description

Displays the history of event messages of the category selected in the **Filter options** parameter (0705) (→  208).

User interface

- For a "Category I" event message

Information event, short message, symbol for event recording and operating time when error occurred

- For a "Category F, C, S, M" event message (status signal)

Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The following symbols indicate whether an event has occurred or has ended:

- : Occurrence of the event
- : End of the event

Examples

For the display format:

- I1091 Configuration modified
 24d12h13m00s
-  F271 Main electronic failure
 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.8.3 "Device information" submenu*Navigation*
 Expert → Diagnostics → Device info

 Device information

Device tag (0011)

→  210

Serial number (0009)	→ 211
Firmware version (0010)	→ 211
Device name (0020)	→ 211
Order code (0008)	→ 211
Extended order code 1 (0023)	→ 212
Extended order code 2 (0021)	→ 212
Extended order code 3 (0022)	→ 212
Configuration counter (0233)	→ 213
ENP version (0012)	→ 213

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. It is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Prosonic Flow

Additional information

User interface



1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation Expert → Diagnostics → Device info → Serial number (0009)**Description**

Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation Expert → Diagnostics → Device info → Firmware version (0010)**Description**

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version (0010) is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name

Navigation Expert → Diagnostics → Device info → Device name (0020)**Description**

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Prosonic Flow 500

Order code

**Navigation** Expert → Diagnostics → Device info → Order code (0008)**Description**

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

 The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (0023) (→  212)

Extended order code 3**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information For additional information, see **Extended order code 1** parameter (0023) (→ 212)

Configuration counter

Navigation  Expert → Diagnostics → Device info → Config. counter (0233)

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

ENP version

Navigation  Expert → Diagnostics → Device info → ENP version (0012)

Description Displays the version of the electronic nameplate.

User interface Character string

Factory setting 2.02.00

Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.8.4 "Main electronic module + I/O module 1" submenu

Navigation  Expert → Diagnostics → Main elec.+I/O1

► Main electronic module + I/O
module 1

Firmware version (0072)

→ 214

Build no. software (0079)

→ 214

Bootloader revision (0073)

→ 214

Firmware version

Navigation   Expert → Diagnostics → Main elec.+I/O1 → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation   Expert → Diagnostics → Main elec.+I/O1 → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision


Navigation   Expert → Diagnostics → Main elec.+I/O1 → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.5 "Sensor electronic module (ISEM)" submenu

Navigation   Expert → Diagnostics → Sens. electronic



Firmware version

Navigation  Expert → Diagnostics → Sens. electronic → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.6 "I/O module 2" submenu

Navigation

 Expert → Diagnostics → I/O module 2



I/O module 2 terminal numbers

Navigation  Expert → Diagnostics → I/O module 2 → I/O 2 terminals (3902-2)

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Firmware version

Navigation  Expert → Diagnostics → I/O module 2 → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → I/O module 2 → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → I/O module 2 → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.7 "I/O module 3" submenu

Navigation  Expert → Diagnostics → I/O module 3

► I/O module 3

I/O module 3 terminal numbers (3902-3)	→ 217
Firmware version (0072)	→ 217
Build no. software (0079)	→ 217
Bootloader revision (0073)	→ 217

I/O module 3 terminal numbers

Navigation Expert → Diagnostics → I/O module 3 → I/O 3 terminals (3902-3)

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Firmware version

Navigation Expert → Diagnostics → I/O module 3 → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation Expert → Diagnostics → I/O module 3 → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation Expert → Diagnostics → I/O module 3 → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface	Positive integer
----------------	------------------

3.8.8 "Display module" submenu

Navigation

Expert → Diagnostics → Display module



Firmware version

Navigation

Expert → Diagnostics → Display module → Firmware version (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. software

Navigation

Expert → Diagnostics → Display module → Build no. softw. (0079)

Description

Use this function to display the software build number of the module.

User interface

Positive integer

Bootloader revision

Navigation

Expert → Diagnostics → Display module → Bootloader rev. (0073)

Description

Use this function to display the bootloader revision of the software.

User interface

Positive integer

3.8.9 "Data logging" submenu

Navigation

Expert → Diagnostics → Data logging

▶ Data logging	
Assign channel 1 (0851)	→ 219
Assign channel 2 (0852)	→ 220
Assign channel 3 (0853)	→ 221
Assign channel 4 (0854)	→ 221
Logging interval (0856)	→ 221
Clear logging data (0855)	→ 222
Data logging (0860)	→ 222
Logging delay (0859)	→ 223
Data logging control (0857)	→ 223
Data logging status (0858)	→ 224
Entire logging duration (0861)	→ 224

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ 42).

Description

Use this function to assign a process variable to the logging channel.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density

* Visibility depends on order options or device settings

- Current output 2 *
- Current output 3 *
- Reference density *
- S&W volume flow *
- GSV flow *
- NSV flow *
- API gravity *
- API slope *
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature
- Current output 1
- Profile factor *
- Cross flow factor *

Factory setting Off

Additional information *Description*

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

Assign channel 2



Navigation

  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Use this function to select a process variable for the data logging channel.

Selection

For the picklist, see **Assign channel 1** parameter (0851) (→  219)

Factory setting

Off

* Visibility depends on order options or device settings

Assign channel 3

Navigation	Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (0015) (→ 42).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see Assign channel 1 parameter (0851) (→ 219)
Factory setting	Off

Assign channel 4

Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (0015) (→ 42).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see Assign channel 1 parameter (0851) (→ 219)
Factory setting	Off

Logging interval

Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (0015) (→ 42).
Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	0.1 to 3 600.0 s
Factory setting	1.0 s

Additional information**Description**

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

 The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data**Navigation**

 Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→  42).

Description

Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information**Selection**

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

Data logging**Navigation**

 Expert → Diagnostics → Data logging → Data logging (0860)

Description

Use this function to select the data logging method.

Selection

- Overwriting
- Not overwriting

Factory setting	Overwriting
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ Overwriting The device memory applies the FIFO principle.▪ Not overwriting Data logging is canceled if the measured value memory is full (single shot).

Logging delay



Navigation	Expert → Diagnostics → Data logging → Logging delay (0859)
Prerequisite	In the Data logging parameter (0860) (→ 222), the Not overwriting option is selected.
Description	Use this function to enter the time delay for measured value logging.
User entry	0 to 999 h
Factory setting	0 h
Additional information	<p><i>Description</i></p> <p>Once data logging has been started with the Data logging control parameter (0857) (→ 223), the device does not save any data for the duration of the delay time entered.</p>

Data logging control



Navigation	Expert → Diagnostics → Data logging → Data log.control (0857)
Prerequisite	In the Data logging parameter (0860) (→ 222), the Not overwriting option is selected.
Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none">▪ None▪ Delete + start▪ Stop
Factory setting	None
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ None Initial measured value logging status.▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again.▪ Stop Measured value logging is stopped.

Data logging status

Navigation  Expert → Diagnostics → Data logging → Data log. status (0858)

Prerequisite In the **Data logging** parameter (0860) (→ [222](#)), the **Not overwriting** option is selected.

Description Displays the measured value logging status.

User interface

- Done
- Delay active
- Active
- Stopped

Factory setting Done

Additional information *Selection*

- Done
Measured value logging has been performed and completed successfully.
- Delay active
Measured value logging has been started but the logging interval has not yet elapsed.
- Active
The logging interval has elapsed and measured value logging is active.
- Stopped
Measured value logging is stopped.

Entire logging duration

Navigation  Expert → Diagnostics → Data logging → Logging duration (0861)

Prerequisite In the **Data logging** parameter (0860) (→ [222](#)), the **Not overwriting** option is selected.

Description Displays the total logging duration.

User interface Positive floating-point number

Factory setting 0 s

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation

Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (0015) (→ 42).

One of the following options is selected in the **Assign channel 1** parameter (0851) (→ 219):


- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Current output 2*
- Current output 3*
- Signal strength*
- Signal to noise ratio*
- Acceptance rate*
- Turbulence
- Electronics temperature
- Current output 1

Description

Displays the measured value trend for the logging channel in the form of a chart.

Additional information

Description



A0034352

10 Chart of a measured value trend


- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

* Visibility depends on order options or device settings

"Display channel 2" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 2



Display channel 2

Navigation

Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is specified in the **Assign channel 2** parameter (0851).

Description

See the **Display channel 1** parameter → [225](#)

"Display channel 3" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation

Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is specified in the **Assign channel 3** parameter (0851).

Description

See the **Display channel 1** parameter → [225](#)

"Display channel 4" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite A process variable is specified in the **Assign channel 4** parameter (0851).

Description See the **Display channel 1** parameter →  225

3.8.10 "Heartbeat Technology" submenu

 For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring**: Special Documentation for the device →  7

Navigation

 Expert → Diagnostics → Heartbeat Techn.

 **Heartbeat Technology**

"Heartbeat base settings" submenu

Navigation

 Expert → Diagnostics → Heartbeat Techn. → Base settings

 **Heartbeat base settings**

Plant operator (2754)

→  227

Location (2755)

→  227

Plant operator



Navigation  Expert → Diagnostics → Heartbeat Techn. → Base settings → Plant operator (2754)

Description Use this function to enter the plant operator.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Location



Navigation  Expert → Diagnostics → Heartbeat Techn. → Base settings → Location (2755)

Description Use this function to enter the location.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

"Performing verification" wizard*Navigation*

Expert → Diagnostics → Heartbeat Techn. → Perform.verifyc.

► Performing verification	
Year (2846)	→ 228
Month (2845)	→ 229
Day (2842)	→ 229
Hour (2843)	→ 229
AM/PM (2813)	→ 230
Minute (2844)	→ 230
Verification mode (12105)	→ 230
External device information (12101)	→ 231
Start verification (12127)	→ 231
Progress (2808)	→ 232
Measured values (12102)	→ 232
Output values (12103)	→ 233
Status (12153)	→ 233
Verification result (12149)	→ 233

Year**Navigation**

Expert → Diagnostics → Heartbeat Techn. → Perform.verifyc. → Year (2846)

Prerequisite

Can be edited if Heartbeat Verification is not active.

Description

Use this function to enter the year of recalibration.

User entry 9 to 99

Factory setting 10

Month



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Month (2845)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to select the month of recalibration.

Selection

- January
- February
- March
- April
- May
- June
- July
- August
- September
- October
- November
- December

Factory setting January

Day



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Day (2842)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to enter the day of the month of recalibration.

User entry 1 to 31 d

Factory setting 1 d

Hour



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Hour (2843)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to enter the hour of recalibration.

User entry 0 to 23 h

Factory setting 12 h

AM/PM



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → AM/PM (2813)

Prerequisite Can be edited if Heartbeat Verification is not active.

The **dd.mm.yy hh:mm am/pm** option or the **mm/dd/yy hh:mm am/pm** option is selected in the **Date/time format** parameter (2812) (→ 68).

Description Use this function to select the time entry in the morning (**AM** option) or afternoon (**PM** option) in the case of 12-hour notation.

Selection

- AM
- PM

Factory setting AM

Minute



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Minute (2844)

Prerequisite Can be edited if Heartbeat Verification is not active.

Description Use this function to enter the minutes of recalibration.

User entry 0 to 59 min

Factory setting 0 min

Verification mode



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Verificat. mode (12105)

Prerequisite Can be edited if verification status is not active.

Description Select verification mode.

Standard verification: Verification is performed automatically by the device and without manual checking of external measured variables.

Extended verification: Similar to internal verification but with the entry of external measured variables (see also "Measured values" parameter).

- Selection**
- Standard verification
 - Extended verification

- Factory setting** Standard verification

External device information



- Navigation** Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Ext. device info (12101)

- Prerequisite** With the following conditions:
- The **Extended verification** option is selected in the **Verification mode** parameter (12105) (→ 230).
 - Can be edited if Heartbeat Verification is not active.

- Description** Record measuring equipment for extended verification.

- User entry** Free text entry

- Factory setting** –

Start verification



- Navigation** Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Start verificat. (12127)

- Prerequisite** If using a test kit:
It is necessary to first remove the sensors from the measuring point and mount them on the test kits.

- Description** Start the verification.

To carry out a complete verification, select the selection parameters individually. Once the external measured values have been recorded, verification is started using the **Start** option.

- Selection**
- Cancel
 - Output 1 low value *
 - Output 1 high value *
 - Output 2 low value *
 - Output 2 high value *
 - Output 3 low value *
 - Output 3 high value *
 - Output 4 low value *
 - Output 4 high value *
 - Frequency output 1 *

* Visibility depends on order options or device settings

- Pulse output 1 *
- Frequency output 2 *
- Pulse output 2 *
- Frequency output 3 *
- Double pulse output
- Start
- Start with testkit *

Factory setting

Cancel

Progress**Navigation**
  Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Progress (2808)
Description

The progress of the process is indicated.

User interface

0 to 100 %

Measured values**Navigation**
  Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Measured val. (12102)
Prerequisite

One of the following options is selected in the **Start verification** parameter (12127) (→  231):

- Output 1 low value
- Output 1 high value
- Output 2 low value
- Output 2 high value
- Output 3 low value
- Output 3 high value
- Output 4 low value
- Output 4 high value
- Frequency output 1
- Pulse output 1
- Frequency output 2
- Pulse output 2
- Frequency output 3
- Double pulse output

Description

Use this function to enter the measured values (actual values) for the external measured variables:

- Current output: Output current in [mA]
- Pulse/frequency output: Output frequency in [Hz]
- Double pulse output: Output frequency in [Hz]

User entry

Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	0
------------------------	---

Output values

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Output values (12103)
Description	Displays the simulated output values (target values) for the external measured variables: <ul style="list-style-type: none">▪ Current output: Output current in [mA].▪ Pulse/frequency output: Output frequency in [Hz].
User interface	Signed floating-point number
Factory setting	-

Status

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Status (12153)
Description	Displays the current status of the verification.
User interface	<ul style="list-style-type: none">▪ Done▪ Busy▪ Failed▪ Not done
Factory setting	Not done

Verification result

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Verific. result (12149)
Description	Displays the overall result of the verification.  Detailed description of results classification:
User interface	<ul style="list-style-type: none">▪ Not supported▪ Passed▪ Not done▪ Failed
Factory setting	Not done

"Verification results" submenu**Navigation** Expert → Diagnostics → Heartbeat Techn. → Verific. results

 Verification results	
Date/time (manually entered) (12142)	→  234
Verification ID (12141)	→  234
Operating time (12126)	→  235
Verification result (12149)	→  235
Sensor (12152)	→  235
Sensor electronic module (ISEM) (12151)	→  236
I/O module (12145)	→  236
System status (12109)	→  236

Date/time (manually entered)

Navigation Expert → Diagnostics → Heartbeat Techn. → Verific. results → Date/time (12142)**Prerequisite**

The verification has been performed.

Description

Date and time.

User interface

dd.mmmm.yyyy; hh:mm

Factory setting

1 January 2010; 12:00

Verification ID

Navigation Expert → Diagnostics → Heartbeat Techn. → Verific. results → Verification ID (12141)**Prerequisite**

The verification has been performed.

Description

Displays consecutive numbering of the verification results in the measuring device.

User interface

0 to 65 535

Factory setting

0

Operating time

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Operating time (12126)
Prerequisite	The verification has been performed.
Description	Indicates how long the device has been in operation up to the verification.
User interface	Days (d), hours (h), minutes (m), seconds (s)
Factory setting	–

Verification result

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Verific. result (12149)
Description	Displays the overall result of the verification.  Detailed description of results classification:
User interface	<ul style="list-style-type: none">■ Not supported■ Passed■ Not done■ Failed
Factory setting	Not done

Sensor

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Sensor (12152)
Prerequisite	The Failed option is shown in the Overall result parameter (12149) (→  233).
Description	Displays the result for the sensor.  Detailed description of results classification:
User interface	<ul style="list-style-type: none">■ Not supported■ Passed■ Not done■ Failed
Factory setting	Not done

Sensor electronic module (ISEM)

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Sens. electronic (12151)
Prerequisite	The Failed option is shown in the Overall result parameter (12149) (→  233).
Description	Displays the result for the sensor electronics module (ISEM).  Detailed description of results classification:
User interface	<ul style="list-style-type: none">■ Not supported■ Passed■ Not done■ Failed
Factory setting	Not done

I/O module

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → I/O module (12145)
Prerequisite	The Failed option is shown in the Overall result parameter (12149) (→  233).
Description	Displays the result for I/O module monitoring of the I/O module. <ul style="list-style-type: none">■ For current output: Accuracy of the current■ For pulse output: Accuracy of pulses■ For frequency output: Accuracy of frequency■ Current input: Accuracy of the current■ Double pulse output: Accuracy of the pulses■ Relay output: Number of switching cycles  Detailed description of results classification:
User interface	<ul style="list-style-type: none">■ Not supported■ Passed■ Not done■ Not plugged■ Failed
Factory setting	Not done

System status

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → System status (12109)
Prerequisite	The Failed option is shown in the Overall result parameter (12149) (→  233).

Description Displays the system condition. Tests the measuring device for active errors.

 Detailed description of results classification:

- User interface**
- Not supported
 - Passed
 - Not done
 - Failed

Factory setting Not done

"Monitoring results" submenu

Navigation

  Expert → Diagnostics → Heartbeat Techn. → Monitor. results

 Monitoring results

3.8.11 "Simulation" submenu

Navigation

  Expert → Diagnostics → Simulation

 Simulation

Assign simulation process variable
(1810)

→  238

Process variable value (1811)

→  239

Current input 1 to n simulation
(1608-1 to n)

→  239

Value current input 1 to n
(1609-1 to n)

→  240

Status input 1 to n simulation
(1355-1 to n)

→  240

Input signal level 1 to n (1356-1 to n)

→  241

Current output 1 to n simulation
(0354-1 to n)

→  241

Current output value (0355)

→  241

Frequency output 1 to n simulation
(0472-1 to n)

→  242

Frequency output 1 to n value (0473-1 to n)	→ 242
Pulse output simulation 1 to n (0458-1 to n)	→ 243
Pulse value 1 to n (0459-1 to n)	→ 243
Switch output simulation 1 to n (0462-1 to n)	→ 243
Switch state 1 to n (0463-1 to n)	→ 244
Relay output 1 to n simulation (0802-1 to n)	→ 244
Switch state 1 to n (0803-1 to n)	→ 245
Pulse output simulation (0988)	→ 245
Pulse value (0989)	→ 246
Device alarm simulation (0654)	→ 246
Diagnostic event category (0738)	→ 247
Diagnostic event simulation (0737)	→ 247

Assign simulation process variable**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity*
- Temperature*
- Pressure*
- Density*
- Reference density*
- S&W volume flow*
- GSV flow*

* Visibility depends on order options or device settings

- NSV flow *
- API gravity *
- API slope

Factory setting Off

Additional information *Description*

-  The simulation value of the process variable selected is defined in the **Process variable value** parameter (1811) (→ 239).

Process variable value



Navigation  Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite A process variable is selected in the **Assign simulation process variable** parameter (1810) (→ 238).

Description Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry Depends on the process variable selected

Factory setting 0

Additional information *User entry*

-  The unit of the displayed measured value is taken from the **System units** submenu (→ 61).

Current input 1 to n simulation



Navigation  Expert → Diagnostics → Simulation → Curr.inp 1 to n sim. (1608–1 to n)

Description Option for switching simulation of the current input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

-  The desired simulation value is defined in the **Value current input 1 to n** parameter (1609–1 to n).

Selection

- Off
- On

Factory setting Off

* Visibility depends on order options or device settings

Additional information*Selection*

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value current input 1 to n**Navigation**

Expert → Diagnostics → Simulation → Value curr.inp 1 to n (1609–1 to n)

Prerequisite

In the **Current input 1 to n simulation** parameter (1608–1 to n), the **On** option is selected.

Description

Use this function to enter the current value for the simulation. In this way, users can verify the correct configuration of the current input and the correct function of upstream feed-in units.

User entry

0 to 22.5 mA

Status input 1 to n simulation**Navigation**

Expert → Diagnostics → Simulation → Status inp 1 to n sim (1355–1 to n)

Description

Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Input signal level** parameter (1356) (→ 241).

Selection

- Off
Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Simulation for the status input is active.

Input signal level 1 to n

Navigation	Expert → Diagnostics → Simulation → Signal level 1 to n (1356–1 to n)
Prerequisite	In the Status input simulation parameter (1355) (→ 240), the On option is selected.
Description	Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units.
Selection	<ul style="list-style-type: none"> ▪ High ▪ Low

Current output 1 to n simulation

Navigation	Expert → Diagnostics → Simulation → Curr.outp 1 to n sim. (0354–1 to n)
Description	Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Value current output 1 to n parameter (0355–1 to n).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Current simulation is active.

Current output value

Navigation	Expert → Diagnostics → Simulation → Curr.outp val. (0355)
Prerequisite	In the Current output 1 to n simulation parameter (0354–1 to n), the On option is selected.
Description	Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry 3.59 to 22.5 mA

Additional information *Dependency*

The input range is dependent on the option selected in the **Current span** parameter (0353) (→ 109).

Frequency output 1 to n simulation



Navigation Expert → Diagnostics → Simulation → Freq.outp 1 to n sim. (0472–1 to n)

Prerequisite In the **Operating mode** parameter (0469) (→ 122), the **Frequency** option is selected.

Description Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

The desired simulation value is defined in the **Frequency value 1 to n** parameter (0473–1 to n).

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Frequency output 1 to n value



Navigation Expert → Diagnostics → Simulation → Freq.outp 1 to n val. (0473–1 to n)

Prerequisite In the **Frequency simulation 1 to n** parameter (0472–1 to n), the **On** option is selected.

Description Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 12 500.0 Hz

Pulse output simulation 1 to n**Navigation**

Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n (0458–1 to n)

Prerequisite

In the **Operating mode** parameter (0469) (→ 122), the **Pulse** option is selected.

Description

Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-counting value

Factory setting Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value 1 to n** parameter (0459–1 to n).

Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (0452) (→ 125).
- Down-counting value
The pulses specified in the **Pulse value** parameter (0459) (→ 243) are output.

Pulse value 1 to n**Navigation**

Expert → Diagnostics → Simulation → Pulse value 1 to n (0459–1 to n)

Prerequisite

In the **Pulse output simulation 1 to n** parameter (0458–1 to n), the **Down-counting value** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch output simulation 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch sim. 1 to n (0462–1 to n)

Prerequisite

In the **Operating mode** parameter (0469) (→ 122), the **Switch** option is selected.

Description	Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Switch state 1 to n parameter (0463-1 to n).</p> <p><i>Selection</i></p> <ul style="list-style-type: none">▪ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ On Switch simulation is active.

Switch state 1 to n



Navigation	 Expert → Diagnostics → Simulation → Switch state 1 to n (0463-1 to n)
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	<ul style="list-style-type: none">▪ Open▪ Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none">▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ Closed Switch simulation is active.

Relay output 1 to n simulation



Navigation	 Expert → Diagnostics → Simulation → Relay out. 1 to n sim (0802-1 to n)
Description	Use this function to switch simulation of the relay output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none">▪ Off▪ On

Factory setting Off

Additional information *Description*

 The desired simulation value is defined in the **Switch state 1 to n** parameter (0803-1 to n).

Selection

- Off
Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Relay simulation is active.

Switch state 1 to n



Navigation  Expert → Diagnostics → Simulation → Switch state 1 to n (0803-1 to n)

Prerequisite The **On** option is selected in the **Switch output simulation 1 to n** parameter (0802-1 to n) parameter.

Description Use this function to select a relay value for the simulation. In this way, users can verify the correct adjustment of the relay output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information *Selection*

- Open
Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Closed
Relay simulation is active.

Pulse output simulation



Navigation  Expert → Diagnostics → Simulation → Puls.outp.sim. (0988)

Description Use this function to switch simulation of the double pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-counting value

Factory setting Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value** parameter (0989) (→ 246).

Selection

- Off
Simulation of the double pulse output is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (0986) (→ 150).
- Down-counting value
The pulses specified in the **Pulse value** parameter (0989) (→ 246) are output.

Pulse value**Navigation**

Expert → Diagnostics → Simulation → Pulse value (0989)

Prerequisite

In the **Pulse output simulation** parameter (0988) (→ 245), the **Down-counting value** option is selected.

Description

Use this function to enter a pulse value for simulation of the double pulse output. In this way, users can verify the correct adjustment of the double pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Device alarm simulation**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category**Navigation**

Expert → Diagnostics → Simulation → Event category (0738)

Description

Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (0737) (→ 247).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting

Process

Diagnostic event simulation**Navigation**

Expert → Diagnostics → Simulation → Diagnostic event (0737)

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting

Off

Additional information*Description* For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (0738) (→ 247).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Density	kg/dm ³
Velocity	m/s
Kinematic viscosity	m ² /s
Temperature	°C
Length	mm

4.1.2 Output current span

Output	Current range
Current output 1...n	4 to 20 mA NAMUR

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft ³
Volume flow	ft ³ /min
Density	lb/ft ³
Velocity	ft/s
Kinematic viscosity	cSt
Temperature	°F
Length	in

4.2.2 Output current span

Output	Current range
Current output 1...n	4 to 20 mA US

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Volume	$\text{cm}^3, \text{dm}^3, \text{m}^3$	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	$\text{dm}^3/\text{s}, \text{dm}^3/\text{min}, \text{dm}^3/\text{h}, \text{dm}^3/\text{d}$	Cubic decimeter/time unit
	$\text{m}^3/\text{s}, \text{m}^3/\text{min}, \text{m}^3/\text{h}, \text{m}^3/\text{d}$	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Density	kg/l	Kilogram/liter
Velocity	m/s	Meter/time unit
Kinematic viscosity	m^2/s	Square meter/second
Temperature	$^{\circ}\text{C}, \text{K}$	Celsius, Kelvin
Length	mm	Millimeters
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Volume	ft^3	Cubic foot
Volume flow	$\text{ft}^3/\text{s}, \text{ft}^3/\text{min}, \text{ft}^3/\text{h}, \text{ft}^3/\text{d}$	Cubic foot/time unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Density	lb/ ft^3	Pound/cubic foot
Velocity	ft/s	Foot/time unit
Kinematic viscosity	cSt	Centistokes
Temperature	$^{\circ}\text{F}, ^{\circ}\text{R}$	Fahrenheit, Rankine
Length	in	Inch
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0/4 mA value (Parameter)	104
0% bargraph value 1 (Parameter)	18
0% bargraph value 3 (Parameter)	20
2.4 GHz WLAN channel (Parameter)	193
20 mA value (Parameter)	104
100% bargraph value 1 (Parameter)	18
100% bargraph value 3 (Parameter)	21

A

Acceptance rate (Parameter)	52
Activate SW option (Parameter)	42
Active level (Parameter)	107
Actual diagnostics (Parameter)	201
Administration (Submenu)	38
Alarm delay (Parameter)	29
Alternative pressure value (Parameter)	74
Alternative temperature value (Parameter)	75
AM/PM (Parameter)	230
API commodity group (Parameter)	74
API gravity (Parameter)	50, 72
API slope (Parameter)	51
API table selection (Parameter)	74
Application (Submenu)	195
Apply I/O configuration (Parameter)	101
Arc length deviation (Parameter)	84
Assign behavior of diagnostic no. 019 (Parameter)	31
Assign behavior of diagnostic no. 160 (Parameter)	31
Assign behavior of diagnostic no. 302 (Parameter)	32
Assign behavior of diagnostic no. 441 (Parameter)	32
Assign behavior of diagnostic no. 442 (Parameter)	32
Assign behavior of diagnostic no. 443 (Parameter)	33
Assign behavior of diagnostic no. 444 (Parameter)	34
Assign behavior of diagnostic no. 543 (Parameter)	34
Assign behavior of diagnostic no. 832 (Parameter)	35
Assign behavior of diagnostic no. 833 (Parameter)	35
Assign behavior of diagnostic no. 841 (Parameter)	36
Assign behavior of diagnostic no. 842 (Parameter)	36
Assign behavior of diagnostic no. 870 (Parameter)	36
Assign behavior of diagnostic no. 930 (Parameter)	37
Assign behavior of diagnostic no. 931 (Parameter)	37
Assign behavior of diagnostic no. 941 (Parameter)	33
Assign behavior of diagnostic no. 942 (Parameter)	33
Assign behavior of diagnostic no. 943 (Parameter)	34
Assign behavior of diagnostic no. 953 (Parameter)	37
Assign channel 1 (Parameter)	219
Assign channel 2 (Parameter)	220
Assign channel 3 (Parameter)	221
Assign channel 4 (Parameter)	221
Assign diagnostic behavior (Parameter)	134, 143
Assign flow direction check (Parameter)	138, 142
Assign frequency output (Parameter)	128
Assign limit (Parameter)	135, 142
Assign process variable (Parameter)	88
Assign process variable 1 to n (Parameter)	196
Assign pulse output (Parameter)	124, 149

Assign PV (Parameter)	172
Assign QV (Parameter)	175
Assign simulation process variable (Parameter)	238
Assign SSID name (Parameter)	192
Assign status (Parameter)	138, 144
Assign status input (Parameter)	106
Assign SV (Parameter)	173
Assign TV (Parameter)	174

B

Backlight (Parameter)	25
Backup state (Parameter)	27
Bootloader revision (Parameter)	214, 215, 216, 217, 218
Build no. software (Parameter)	214, 215, 216, 217, 218
Burst command (Parameter)	155
Burst command 1 to n (Parameter)	162
Burst configuration 1 to n (Submenu)	161
Burst mode 1 to n (Parameter)	162
Burst trigger level (Parameter)	167
Burst trigger mode (Parameter)	166
Burst variable 0 (Parameter)	163
Burst variable 1 (Parameter)	164
Burst variable 2 (Parameter)	165
Burst variable 3 (Parameter)	165
Burst variable 4 (Parameter)	165
Burst variable 5 (Parameter)	165
Burst variable 6 (Parameter)	166
Burst variable 7 (Parameter)	166

C

Cable length (Parameter)	79
Calibration (Submenu)	98
Calibration factor (Parameter)	99
Capture mode (Parameter)	154
Clear logging data (Parameter)	222
Communication (Submenu)	153
Comparison result (Parameter)	28
Configuration (Submenu)	153, 159
Configuration backup (Submenu)	26
Configuration counter (Parameter)	213
Configuration management (Parameter)	27
Confirm access code (Parameter)	39
Connection state (Parameter)	194
Contrast display (Parameter)	25
Control Totalizer 1 to n (Parameter)	198
CPL (Parameter)	47
CTL (Parameter)	47
CTPL (Parameter)	48
Current input 1 to n (Submenu)	56, 102
Current input 1 to n simulation (Parameter)	239
Current output 1 to n (Submenu)	107
Current output 1 to n simulation (Parameter)	241
Current output value (Parameter)	241
Current range output (Parameter)	109
Current span (Parameter)	103

D

Damping current output (Parameter)	118
Damping output (Parameter)	131
Data logging (Parameter)	222
Data logging (Submenu)	219
Data logging control (Parameter)	223
Data logging status (Parameter)	224
Date/time (manually entered) (Parameter)	234
Date/time format (Parameter)	68
Day (Parameter)	229
Decimal places 1 (Parameter)	18
Decimal places 2 (Parameter)	19
Decimal places 3 (Parameter)	21
Decimal places 4 (Parameter)	22
Default gateway (Parameter)	178
Define access code (Parameter)	39
Define access code (Wizard)	38
Density (Parameter)	73
Density factor (Parameter)	98
Density offset (Parameter)	98
Density source (Parameter)	92
Density unit (Parameter)	67
Device alarm simulation (Parameter)	246
Device ID (Parameter)	154, 169
Device information (Submenu)	209
Device name (Parameter)	211
Device reset (Parameter)	41
Device revision (Parameter)	168
Device tag (Parameter)	160, 210
Device type (Parameter)	155, 169
DHCP client (Parameter)	177
Diagnostic behavior (Submenu)	29
Diagnostic configuration (Submenu)	179
Diagnostic event category (Parameter)	247
Diagnostic event simulation (Parameter)	247
Diagnostic handling (Submenu)	29
Diagnostic list (Submenu)	203
Diagnostics (Submenu)	200
Diagnostics 1 (Parameter)	204
Diagnostics 2 (Parameter)	204
Diagnostics 3 (Parameter)	205
Diagnostics 4 (Parameter)	206
Diagnostics 5 (Parameter)	207
Direct access	
0/4 mA value	
Current input 1 to n (1606–1 to n)	104
0% bargraph value 1 (0123)	18
0% bargraph value 3 (0124)	20
2.4 GHz WLAN channel (2704)	193
20 mA value	
Current input 1 to n (1607–1 to n)	104
100% bargraph value 1 (0125)	18
100% bargraph value 3 (0126)	21
Acceptance rate (2912)	52
Activate SW option (0029)	42
Active level	
Status input 1 to n (1351–1 to n)	107
Actual diagnostics (0691)	201
Alarm delay (0651)	29

Alternative pressure value

Measuring point 1 (4207–1)	74
--------------------------------------	----

Alternative temperature value

Measuring point 1 (4208–1)	75
--------------------------------------	----

AM/PM (2813)	230
------------------------	-----

API commodity group

Measuring point 1 (4214–1)	74
--------------------------------------	----

API gravity

Measuring point 1 (4203–1)	72
--------------------------------------	----

API gravity (4211)	50
------------------------------	----

API slope (4210)	51
----------------------------	----

API table selection

Measuring point 1 (4209–1)	74
--------------------------------------	----

Apply I/O configuration (3907)	101
--	-----

Arc length deviation

Mounting deviations signal path 1 to n (5876–1 to n)	84
--	----

Assign behavior of diagnostic no. 019 (0635)	31
--	----

Assign behavior of diagnostic no. 160 (0776)	31
--	----

Assign behavior of diagnostic no. 302 (0742)	32
--	----

Assign behavior of diagnostic no. 441 (0657)	32
--	----

Assign behavior of diagnostic no. 442 (0658)	32
--	----

Assign behavior of diagnostic no. 443 (0659)	33
--	----

Assign behavior of diagnostic no. 444 (0740)	34
--	----

Assign behavior of diagnostic no. 543 (0643)	34
--	----

Assign behavior of diagnostic no. 832 (0675)	35
--	----

Assign behavior of diagnostic no. 833 (0676)	35
--	----

Assign behavior of diagnostic no. 841 (0680)	36
--	----

Assign behavior of diagnostic no. 842 (0638)	36
--	----

Assign behavior of diagnostic no. 870 (0726)	36
--	----

Assign behavior of diagnostic no. 930 (0639)	37
--	----

Assign behavior of diagnostic no. 931 (0640)	37
--	----

Assign behavior of diagnostic no. 941 (0783)	33
--	----

Assign behavior of diagnostic no. 942 (0780)	33
--	----

Assign behavior of diagnostic no. 943 (0781)	34
--	----

Assign behavior of diagnostic no. 953 (0636)	37
--	----

Assign channel 1 (0851)	219
-----------------------------------	-----

Assign channel 2 (0852)	220
-----------------------------------	-----

Assign channel 3 (0853)	221
-----------------------------------	-----

Assign channel 4 (0854)	221
-----------------------------------	-----

Assign diagnostic behavior

Pulse/frequency/switch output 1 to n (0482–1 to n)	134
--	-----

Relay output 1 to n (0806–1 to n)	143
---	-----

Assign flow direction check

Pulse/frequency/switch output 1 to n (0484–1 to n)	138
--	-----

Relay output 1 to n (0808–1 to n)	142
---	-----

Assign frequency output

Pulse/frequency/switch output 1 to n (0478–1 to n)	128
--	-----

Assign limit

Pulse/frequency/switch output 1 to n (0483–1 to n)	135
--	-----

Relay output 1 to n (0807–1 to n)	142
---	-----

Assign process variable (1837)	88
--	----

Assign process variable 1 to n (0914–1 to n)	196
--	-----

Assign pulse output	194
Pulse/frequency/switch output 1 to n (0460–1 to n)	124
Assign pulse output (0982)	149
Assign PV (0234)	172
Assign QV (0237)	175
Assign simulation process variable (1810)	238
Assign SSID name (2708)	192
Assign status	
Pulse/frequency/switch output 1 to n (0485–1 to n)	138
Relay output 1 to n (0805–1 to n)	144
Assign status input	
Status input 1 to n (1352–1 to n)	106
Assign SV (0235)	173
Assign TV (0236)	174
Backlight (0111)	25
Backup state (2759)	27
Bootloader revision	
I/O module 2 (0073)	216, 217
I/O module 3 (0073)	216, 217
I/O module 4 (0073)	216, 217
Bootloader revision (0073)	214, 215, 218
Build no. software	
I/O module 2 (0079)	216, 217
I/O module 3 (0079)	216, 217
I/O module 4 (0079)	216, 217
Build no. software (0079)	214, 215, 218
Burst command (7006)	155
Burst command 1 to n (2031–1 to n)	162
Burst mode 1 to n (2032–1 to n)	162
Burst trigger level	
Burst configuration 1 to n (2043–1 to n)	167
Burst trigger mode	
Burst configuration 1 to n (2044–1 to n)	166
Burst variable 0	
Burst configuration 1 to n (2033)	163
Burst variable 1	
Burst configuration 1 to n (2034)	164
Burst variable 2	
Burst configuration 1 to n (2035)	165
Burst variable 3	
Burst configuration 1 to n (2036)	165
Burst variable 4	
Burst configuration 1 to n (2037)	165
Burst variable 5	
Burst configuration 1 to n (2038)	165
Burst variable 6	
Burst configuration 1 to n (2039)	166
Burst variable 7	
Burst configuration 1 to n (2040)	166
Cable length	
Measuring point 1 (2939–1)	79
Calibration factor (2920)	99
Capture mode (7001)	154
Clear logging data (0855)	222
Comparison result (2760)	28
Configuration counter (0233)	213
Configuration management (2758)	27
Connection state (2722)	194
Contrast display (0105)	25
Control Totalizer 1 to n (0912–1 to n)	198
CPL (4192)	47
CTL (4191)	47
CTPL (4193)	48
Current input 1 to n simulation (1608–1 to n)	239
Current output 1 to n simulation (0354–1 to n)	241
Current output value (0355)	241
Current range output	
Current output 1 to n (0353–1 to n)	109
Current span	
Current input 1 to n (1605–1 to n)	103
Damping current output	
Current output 1 to n (0363–1 to n)	118
Damping output	
Pulse/frequency/switch output 1 to n (0477–1 to n)	131
Data logging (0860)	222
Data logging control (0857)	223
Data logging status (0858)	224
Date/time (manually entered) (12142)	234
Date/time format (2812)	68
Day (2842)	229
Decimal places 1 (0095)	18
Decimal places 2 (0117)	19
Decimal places 3 (0118)	21
Decimal places 4 (0119)	22
Default gateway (7210)	178
Density	
Measuring point 1 (4204–1)	73
Density factor (1878)	98
Density offset (1877)	98
Density source (3048)	92
Density unit (0555)	67
Device alarm simulation (0654)	246
Device ID (0221)	169
Device ID (7007)	154
Device name (0020)	211
Device reset (0000)	41
Device revision (0204)	168
Device tag (0011)	210
Device tag (0215)	160
Device type (0209)	169
Device type (7008)	155
DHCP client (7212)	177
Diagnostic event category (0738)	247
Diagnostic event simulation (0737)	247
Diagnostics 1 (0692)	204
Diagnostics 2 (0693)	204
Diagnostics 3 (0694)	205
Diagnostics 4 (0695)	206
Diagnostics 5 (0696)	207
Direct access (0106)	11
Display damping (0094)	23
Display interval (0096)	23
Display language (0104)	15
Energy flow (1851)	46
ENP version (0012)	213

Enter access code (0003)	13	Fixed value (3171)	92
Entire logging duration (0861)	224	Flow damping (1802)	87
Event category 160 (0272)	181	Flow override (1839)	87
Event category 441 (0210)	181	Flow velocity (1852)	45
Event category 442 (0230)	181	FlowDC inlet configuration	
Event category 443 (0231)	182	Measuring point 1 (3049-1)	80
Event category 444 (0211)	182	Format display (0098)	15
Event category 543 (0276)	183	Frequency output 1 to n simulation (0472-1 to n)	
Event category 832 (0218)	183	242
Event category 833 (0225)	183	Frequency output 1 to n value (0473-1 to n)	242
Event category 841 (0267)	184	Gateway IP address (2719)	194
Event category 842 (0295)	184	GSV flow (4157)	48
Event category 870 (0250)	185	Hardware revision (0206)	170
Event category 881 (0268)	185	HART address (0219)	160
Event category 930 (0296)	185	HART date code (0202)	171
Event category 931 (0297)	186	HART descriptor (0212)	170
Event category 941 (0294)	187	HART message (0216)	170
Event category 942 (0302)	187	HART revision (0205)	170
Event category 943 (0301)	187	HART short tag (0220)	160
Event category 953 (0292)	186	Header (0097)	24
Extended order code 1 (0023)	212	Header text (0112)	24
Extended order code 2 (0021)	212	Hour (2843)	229
Extended order code 3 (0022)	212	I/O alteration code (2762)	102
External device information (12101)	231	I/O module (12145)	236
External value (3058)	91	I/O module 1 to n information (3906-1 to n)	100
External value (3060)	92	I/O module 1 to n terminal numbers (3902-1 to n)	100
Failure behavior current output		I/O module 1 to n type (3901-1 to n)	101
Current output 1 to n (0364-1 to n)	118	I/O module 2 terminal numbers (3902-2)	216, 217
Failure current		I/O module 3 terminal numbers (3902-3)	216, 217
Current output 1 to n (0352-1 to n)	119	I/O module 4 terminal numbers (3902-4)	216, 217
Failure frequency		Inlet diameter	
Pulse/frequency/switch output 1 to n (0474-1 to n)	133	Measuring point 1 (3054-1)	81
Failure mode		Inlet run	
Current input 1 to n (1601-1 to n)	104	Measuring point 1 (3050-1)	81
Pulse/frequency/switch output 1 to n (0451-1 to n)	132	Input signal level 1 to n (1356-1 to n)	241
Pulse/frequency/switch output 1 to n (0480-1 to n)	126	Installation direction (1809)	94
Pulse/frequency/switch output 1 to n (0486-1 to n)	139	Installation status (2958)	85
Relay output 1 to n (0811-1 to n)	146	Intermediate pipe length	
Failure mode (0985)	151	Measuring point 1 (2945-1)	80
Failure mode (7011)	157	Invert output signal	
Failure value		Pulse/frequency/switch output 1 to n (0470-1 to n)	140
Current input 1 to n (1602-1 to n)	105	Invert output signal (0993)	152
Failure value (7012)	158	IP address (7209)	178
Fieldbus writing access (0273)	161	IP address domain name server (2720)	194
Filter options (0705)	208	Kinematic viscosity unit (0578)	68
Firmware version		Last backup (2757)	26
I/O module 2 (0072)	216, 217	Length unit (0551)	68
I/O module 3 (0072)	216, 217	Linear expansion coefficient (3153)	93
I/O module 4 (0072)	216, 217	Liner material	
Firmware version (0010)	211	Measuring point 1 (2928-1)	77
Firmware version (0072)	214, 215, 218	Liner sound velocity	
Fixed current		Measuring point 1 (2936-1)	77
Current output 1 to n (0365-1 to n)	111	Liner thickness	
Fixed reference density (3178)	93	Measuring point 1 (2935-1)	78
Fixed value (2925)	91	Location (2755)	227
		Locking status (0004)	12
		Logging delay (0859)	223

Logging interval (0856)	221	Off value low flow cutoff (1804)	89
Login page (7273)	179	On value low flow cutoff (1805)	89
Lower range value output		Operating mode	
Current output 1 to n (0367-1 to n)	111	Pulse/frequency/switch output 1 to n (0469-1 to n)	122
MAC address (7214)	177	Operating time (0652)	26, 40, 203
Manufacturer ID (0259)	169	Operating time (12126)	235
Manufacturer ID (7009)	155	Operating time from restart (0653)	203
Mass flow (1847)	45	Order code (0008)	211
Mass flow factor (1846)	96	Output current	
Mass flow offset (1841)	96	Current output 1 to n (0361-1 to n)	119
Mass flow unit (0554)	65	Value current output 1 to n (0361-1 to n)	57
Mass unit (0574)	65	Output frequency	
Master terminal number (0981)	148	Pulse/frequency/switch output 1 to n (0471-1 to n)	58, 133
Max. switch cycles number		Output values (12103)	233
Relay output 1 to n (0817-1 to n)	60	Phase shift (0992)	150
Max. update period		Pipe circumference	
Burst configuration 1 to n (2041-1 to n)	168	Measuring point 1 (2934-1)	76
Maximum frequency value		Pipe dimensions	
Pulse/frequency/switch output 1 to n (0454-1 to n)	129	Measuring point 1 (2943-1)	76
Measured current		Pipe material	
Current output 1 to n (0366-1 to n)	120	Measuring point 1 (2927-1)	75
Value current output 1 to n (0366-1 to n)	58	Pipe outer diameter	
Measured current 1 to n (1604-1 to n)	56	Measuring point 1 (2910-1)	77
Measured values (12102)	232	Pipe sound velocity	
Measured values 1 to n (1603-1 to n)	56	Measuring point 1 (2933-1)	76
Measuring mode		Pipe wall thickness	
Pulse/frequency/switch output 1 to n (0457-1 to n)	126	Measuring point 1 (2916-1)	77
Pulse/frequency/switch output 1 to n (0479-1 to n)	130	Plant operator (2754)	227
Measuring mode (0984)	150	Powerless relay status	
Measuring mode current output		Relay output 1 to n (0816-1 to n)	147
Current output 1 to n (0351-1 to n)	113	Preset value 1 to n (0913-1 to n)	199
Measuring point configuration		Pressure	
Measuring point 1 (5675-1)	71	Measuring point 1 (4206-1)	73
Measuring value at maximum frequency		Pressure (1872)	46
Pulse/frequency/switch output 1 to n (0475-1 to n)	129	Pressure compensation (3023)	90
Measuring value at minimum frequency		Previous diagnostics (0690)	202
Pulse/frequency/switch output 1 to n (0476-1 to n)	129	Primary variable (PV) (0201)	172
Medium		Process variable current output	
Measuring point 1 (2926-1)	71	Current output 1 to n (0359-1 to n)	109
Medium temperature		Process variable unit 1 to n (0915-1 to n)	197
Measuring point 1 (3053-1)	71	Process variable value (1811)	239
Min. update period		Progress (2808)	232
Burst configuration 1 to n (2042-1 to n)	167	Pulse output	
Minimum frequency value		Pulse/frequency/switch output 1 to n (0456-1 to n)	58, 127
Pulse/frequency/switch output 1 to n (0453-1 to n)	128	Pulse output (0987)	61, 152
Minute (2844)	230	Pulse output simulation (0988)	245
Month (2845)	229	Pulse output simulation 1 to n (0458-1 to n)	243
Mounting type		Pulse scaling	
Measuring point 1 (2938-1)	79	Pulse/frequency/switch output 1 to n (0455-1 to n)	124
Network security (2705)	190	Pulse value (0989)	246
No. of preambles (0217)	160	Pulse value 1 to n (0459-1 to n)	243
Nominal diameter (2807)	99	Pulse width	
NSV flow (4159)	49	Pulse/frequency/switch output 1 to n (0452-1 to n)	125
		Pulse width (0986)	150

Quaternary variable (QV) (0203)	176	Software revision (0224)	171
Received signal strength (2721)	194	Sound velocity	
Reference density		Measuring point 1 (2929-1)	72
Measuring point 1 (4205-1)	73	Sound velocity (1850)	46
Reference density (4212)	51	Sound velocity (2915)	86
Reference density unit (0556)	67	Sound velocity calculation mode	
Reference temperature (3147)	94	Measuring point 1 (4202-1)	72
Relative sensor position		Sound velocity deviation (2986)	86
Measuring point 1 (2985-1)	82	Sound velocity factor (1849)	97
Relay output 1 to n simulation (0802-1 to n) . . .	244	Sound velocity offset (1848)	97
Relay output function		Square expansion coefficient (3172)	93
Relay output 1 to n (0804-1 to n)	141	SSID name (2707)	193
Reset access code (0024)	40	SSID name (2714)	189
Reset all totalizers (2806)	195	Start verification (12127)	231
Response time		Status (7004)	159
Pulse/frequency/switch output 1 to n (0491-1 to n)	131	Status (12153)	233
Response time status input		Status input 1 to n simulation (1355-1 to n) . . .	240
Status input 1 to n (1354-1 to n)	107	Subnet mask (7211)	178
Result path length / arc length		Switch cycles	
Measuring point 1 (3067-1)	83	Relay output 1 to n (0815-1 to n)	60
Result sensor distance / measuring aid		Switch output function	
Measuring point 1 (2947-1)	82	Pulse/frequency/switch output 1 to n (0481-1 to n)	133
Result sensor type / mounting type		Switch output simulation 1 to n (0462-1 to n) . .	243
Measuring point 1 (2946-1)	82	Switch state	
Result sensor type / sensor distance		Pulse/frequency/switch output 1 to n (0461-1 to n)	59, 139
Measuring point 1 (3066-1)	82	Relay output 1 to n (0801-1 to n)	60, 146
S&W correction value (4194)	49	Switch state 1 to n (0463-1 to n)	244
S&W volume flow (4161)	50	Switch state 1 to n (0803-1 to n)	245
Secondary variable (SV) (0226)	173	Switch-off delay	
Security identification (2718)	190	Pulse/frequency/switch output 1 to n (0465-1 to n)	139
Select antenna (2713)	193	Relay output 1 to n (0813-1 to n)	145
Sensor (12152)	235	Switch-off value	
Sensor coupling		Pulse/frequency/switch output 1 to n (0464-1 to n)	137
Measuring point 1 (2957-1)	79	Relay output 1 to n (0809-1 to n)	144
Sensor distance deviation		Switch-on delay	
Mounting deviations signal path 1 to n (5822-1 to n)	83	Pulse/frequency/switch output 1 to n (0467-1 to n)	138
Sensor electronic module (ISEM) (12151)	236	Relay output 1 to n (0814-1 to n)	146
Sensor type		Switch-on value	
Measuring point 1 (2924-1)	78	Pulse/frequency/switch output 1 to n (0466-1 to n)	137
Separator (0101)	25	Relay output 1 to n (0810-1 to n)	145
Serial number (0009)	211	System status (12109)	236
Signal filter		Temperature compensation (3025)	91
Measuring point 1 (3011-1)	78	Temperature factor (1871)	98
Signal mode		Temperature offset (1870)	97
Current input 1 to n (1610-1 to n)	103	Temperature unit (0557)	66
Current output 1 to n (0377-1 to n)	109	Terminal number	
Pulse/frequency/switch output 1 to n (0490-1 to n)	122	Current input 1 to n (1611-1 to n)	103
Signal mode (0991)	148	Current output 1 to n (0379-1 to n)	108
Signal path length deviation		Pulse/frequency/switch output 1 to n (0492-1 to n)	121
Mounting deviations signal path 1 to n (5821-1 to n)	84	Relay output 1 to n (0812-1 to n)	141
Signal strength (2914)	52, 85	Status input 1 to n (1358-1 to n)	105
Signal to noise ratio (2917)	52, 86	Tertiary variable (TV) (0228)	175
Slave terminal number (0990)	148		
Slot number (7010)	156		
Software option overview (0015)	42		

Timeout (7005)	157	Display interval (Parameter)	23
Timestamp (0667)	202	Display language (Parameter)	15
Timestamp (0672)	202	Display module (Submenu)	218
Timestamp (0683)	204	Document	
Timestamp (0684)	205	Design	4
Timestamp (0685)	206	Explanation of the structure of a parameter	
Timestamp (0686)	206	description	6
Timestamp (0687)	207	Function	4
Totalizer 1 to n failure behavior (0901–1 to n) . .	199	Symbols used	6
Totalizer 1 to n operation mode (0908–1 to n) . .	198	Target group	4
Totalizer 1 to n overflow (0910–1 to n)	54	Using the document	4
Totalizer 1 to n value (0911–1 to n)	53	Document function	4
Transition length		Double pulse output (Submenu)	61, 147
Measuring point 1 (3065–1)	81		
Transmitter identifier (2765)	41		
Turbulence (2907)	53		
Upper range value output			
Current output 1 to n (0372–1 to n)	113		
User name (2715)	190		
User role (0005)	13		
Value (7003)	158		
Value 1 display (0107)	17		
Value 2 display (0108)	19		
Value 3 display (0110)	20		
Value 4 display (0109)	22		
Value current input 1 to n (1609–1 to n)	240		
Value per pulse (0983)	149		
Value status input			
Status input 1 to n (1353–1 to n)	106		
Value status input 1 to n (1353–1 to n)	57		
Velocity unit (0566)	66		
Verification ID (12141)	234		
Verification mode (12105)	230		
Verification result (12149)	233, 235		
Viscosity			
Measuring point 1 (2932–1)	75		
Volume flow (1838)	45		
Volume flow factor (1832)	96		
Volume flow offset (1831)	95		
Volume flow unit (0553)	62		
Volume unit (0563)	64		
Web server functionality (7222)	179		
Web server language (7221)	177		
WLAN (2702)	189		
WLAN IP address (2711)	191		
WLAN MAC address (2703)	191		
WLAN mode (2717)	189		
WLAN passphrase (2706)	192		
WLAN password (2716)	191		
WLAN subnet mask (2709)	192		
Year (2846)	228		
Zero point (2921)	99		
Direct access (Parameter)	11		
Display (Submenu)	14		
Display channel 1 (Submenu)	224	F	
Display channel 2 (Submenu)	226	Factory settings	248
Display channel 3 (Submenu)	226	SI units	248
Display channel 4 (Submenu)	226	US units	248
Display damping (Parameter)	23	Failure behavior current output (Parameter)	118

Firmware version (Parameter)	211, 214, 215, 216, 217, 218	IP address domain name server (Parameter)	194
Fixed current (Parameter)	111	K	
Fixed reference density (Parameter)	93	Kinematic viscosity unit (Parameter)	68
Fixed value (Parameter)	91, 92	L	
Flow damping (Parameter)	87	Last backup (Parameter)	26
Flow override (Parameter)	87	Length unit (Parameter)	68
Flow velocity (Parameter)	45	Linear expansion coefficient (Parameter)	93
FlowDC inlet configuration (Parameter)	80	Liner material (Parameter)	77
Format display (Parameter)	15	Liner sound velocity (Parameter)	77
Frequency output 1 to n simulation (Parameter)	242	Liner thickness (Parameter)	78
Frequency output 1 to n value (Parameter)	242	Location (Parameter)	227
Function		Locking status (Parameter)	12
see Parameter		Logging delay (Parameter)	223
G		Logging interval (Parameter)	221
Gateway IP address (Parameter)	194	Login page (Parameter)	179
GSV flow (Parameter)	48	Low flow cut off (Submenu)	88
H		Lower range value output (Parameter)	111
Hardware revision (Parameter)	170	M	
HART address (Parameter)	160	MAC address (Parameter)	177
HART date code (Parameter)	171	Main electronic module + I/O module 1 (Submenu)	213
HART descriptor (Parameter)	170	Manufacturer ID (Parameter)	155, 169
HART input (Submenu)	153	Mass flow (Parameter)	45
HART message (Parameter)	170	Mass flow factor (Parameter)	96
HART output (Submenu)	159	Mass flow offset (Parameter)	96
HART revision (Parameter)	170	Mass flow unit (Parameter)	65
HART short tag (Parameter)	160	Mass unit (Parameter)	65
Header (Parameter)	24	Master terminal number (Parameter)	148
Header text (Parameter)	24	Max. switch cycles number (Parameter)	60
Heartbeat base settings (Submenu)	227	Max. update period (Parameter)	168
Heartbeat Technology (Submenu)	227	Maximum frequency value (Parameter)	129
Hour (Parameter)	229	Measured current (Parameter)	58, 120
I		Measured current 1 to n (Parameter)	56
I/O alteration code (Parameter)	102	Measured values (Parameter)	232
I/O configuration (Submenu)	100	Measured values (Submenu)	44
I/O module (Parameter)	236	Measured values 1 to n (Parameter)	56
I/O module 1 to n information (Parameter)	100	Measuring mode (Parameter)	126, 130, 150
I/O module 1 to n terminal numbers (Parameter)	100	Measuring mode current output (Parameter)	113
I/O module 1 to n type (Parameter)	101	Measuring point (Submenu)	69
I/O module 2 (Submenu)	215	Measuring point configuration (Parameter)	71
I/O module 2 terminal numbers (Parameter)	216, 217	Measuring value at maximum frequency (Parameter)	129
I/O module 3 (Submenu)	216	Measuring value at minimum frequency (Parameter)	129
I/O module 3 terminal numbers (Parameter)	216, 217	Medium (Parameter)	71
I/O module 4 terminal numbers (Parameter)	216, 217	Medium temperature (Parameter)	71
Information (Submenu)	168	Min. update period (Parameter)	167
Inlet diameter (Parameter)	81	Minimum frequency value (Parameter)	128
Inlet run (Parameter)	81	Minute (Parameter)	230
Input (Submenu)	102, 158	Monitoring results (Submenu)	237
Input signal level 1 to n (Parameter)	241	Month (Parameter)	229
Input values (Submenu)	55	Mounting deviations signal path 1 to n (Submenu)	83
Installation direction (Parameter)	94	Mounting type (Parameter)	79
Installation status (Parameter)	85		
Installation status (Submenu)	84		
Intermediate pipe length (Parameter)	80		
Invert output signal (Parameter)	140, 152		
IP address (Parameter)	178		

NSV flow (Parameter)	49	Relative sensor position (Parameter)	82
O		Relay output 1 to n (Submenu)	60, 140
Off value low flow cutoff (Parameter)	89	Relay output 1 to n simulation (Parameter)	244
On value low flow cutoff (Parameter)	89	Relay output function (Parameter)	141
Operating mode (Parameter)	122	Reset access code (Parameter)	40
Operating time (Parameter)	26, 40, 203, 235	Reset access code (Submenu)	39
Operating time from restart (Parameter)	203	Reset all totalizers (Parameter)	195
Order code (Parameter)	211	Response time (Parameter)	131
Output (Submenu)	107, 171	Response time status input (Parameter)	107
Output current (Parameter)	57, 119	Result path length / arc length (Parameter)	83
Output frequency (Parameter)	58, 133	Result sensor distance / measuring aid (Parameter)	82
Output values (Parameter)	233	Result sensor type / mounting type (Parameter)	82
Output values (Submenu)	57	Result sensor type / sensor distance (Parameter)	82
P		S	
Parameter		S&W correction value (Parameter)	49
Structure of description	6	S&W volume flow (Parameter)	50
Performing verification (Submenu)	228	Secondary variable (SV) (Parameter)	173
Petroleum (Submenu)	200	Security identification (Parameter)	190
Phase shift (Parameter)	150	Select antenna (Parameter)	193
Pipe circumference (Parameter)	76	Sensor (Parameter)	235
Pipe dimensions (Parameter)	76	Sensor (Submenu)	43
Pipe material (Parameter)	75	Sensor adjustment (Submenu)	94
Pipe outer diameter (Parameter)	77	Sensor coupling (Parameter)	79
Pipe sound velocity (Parameter)	76	Sensor distance deviation (Parameter)	83
Pipe wall thickness (Parameter)	77	Sensor electronic module (ISEM) (Parameter)	236
Plant operator (Parameter)	227	Sensor electronic module (ISEM) (Submenu)	214
Powerless relay status (Parameter)	147	Sensor type (Parameter)	78
Preset value 1 to n (Parameter)	199	Separator (Parameter)	25
Pressure (Parameter)	46, 73	Serial number (Parameter)	211
Pressure compensation (Parameter)	90	Signal filter (Parameter)	78
Previous diagnostics (Parameter)	202	Signal mode (Parameter)	103, 109, 122, 148
Primary variable (PV) (Parameter)	172	Signal path length deviation (Parameter)	84
Process parameters (Submenu)	86	Signal strength (Parameter)	52, 85
Process variable adjustment (Submenu)	95	Signal to noise ratio (Parameter)	52, 86
Process variable current output (Parameter)	109	Simulation (Submenu)	237
Process variable unit 1 to n (Parameter)	197	Slave terminal number (Parameter)	148
Process variable value (Parameter)	239	Slot number (Parameter)	156
Process variables (Submenu)	44	Software option overview (Parameter)	42
Product identification (Submenu)	200	Software revision (Parameter)	171
Progress (Parameter)	232	Sound velocity (Parameter)	46, 72, 86
Pulse output (Parameter)	58, 61, 127, 152	Sound velocity calculation mode (Parameter)	72
Pulse output simulation (Parameter)	245	Sound velocity deviation (Parameter)	86
Pulse output simulation 1 to n (Parameter)	243	Sound velocity factor (Parameter)	97
Pulse scaling (Parameter)	124	Sound velocity offset (Parameter)	97
Pulse value (Parameter)	246	Square expansion coefficient (Parameter)	93
Pulse value 1 to n (Parameter)	243	SSID name (Parameter)	189, 193
Pulse width (Parameter)	125, 150	Start verification (Parameter)	231
Pulse/frequency/switch output 1 to n (Submenu)		Status (Parameter)	159, 233
.	58, 120	Status input 1 to n (Submenu)	105
Q		Status input 1 to n simulation (Parameter)	240
Quaternary variable (QV) (Parameter)	176	Submenu	
R		Administration	38
Received signal strength (Parameter)	194	Application	195
Reference density (Parameter)	51, 73	Burst configuration 1 to n	161
Reference density unit (Parameter)	67	Calibration	98
Reference temperature (Parameter)	94	Communication	153
		Configuration	153, 159
		Configuration backup	26

Current input 1 to n	56, 102	Verification results	234
Current output 1 to n	107	Web server	176
Data logging	219	Subnet mask (Parameter)	178
Device information	209	Switch cycles (Parameter)	60
Diagnostic behavior	29	Switch output function (Parameter)	133
Diagnostic configuration	179	Switch output simulation 1 to n (Parameter)	243
Diagnostic handling	29	Switch state (Parameter)	59, 60, 139, 146
Diagnostic list	203	Switch state 1 to n (Parameter)	244, 245
Diagnostics	200	Switch-off delay (Parameter)	139, 145
Display	14	Switch-off value (Parameter)	137, 144
Display channel 1	224	Switch-on delay (Parameter)	138, 146
Display channel 2	226	Switch-on value (Parameter)	137, 145
Display channel 3	226	System (Submenu)	13
Display channel 4	226	System status (Parameter)	236
Display module	218	System units (Submenu)	61
Double pulse output	61, 147	System values (Submenu)	51
Event list	208		
Event logbook	208		
External compensation	90		
HART input	153		
HART output	159		
Heartbeat base settings	227		
Heartbeat Technology	227		
I/O configuration	100		
I/O module 2	215		
I/O module 3	216		
Information	168		
Input	102, 158		
Input values	55		
Installation status	84		
Low flow cut off	88		
Main electronic module + I/O module 1	213		
Measured values	44		
Measuring point	69		
Monitoring results	237		
Mounting deviations signal path 1 to n	83		
Output	107, 171		
Output values	57		
Performing verification	228		
Petroleum	200		
Process parameters	86		
Process variable adjustment	95		
Process variables	44		
Product identification	200		
Pulse/frequency/switch output 1 to n	58, 120		
Relay output 1 to n	60, 140		
Reset access code	39		
Sensor	43		
Sensor adjustment	94		
Sensor electronic module (ISEM)	214		
Simulation	237		
Status input 1 to n	105		
System	13		
System units	61		
System values	51		
Totalizer	53		
Totalizer 1 to n	195		
Value current output 1 to n	57		
Value status input 1 to n	56		

T

Target group	4
Temperature compensation (Parameter)	91
Temperature factor (Parameter)	98
Temperature offset (Parameter)	97
Temperature unit (Parameter)	66
Terminal number (Parameter)	103, 105, 108, 121, 141
Tertiary variable (TV) (Parameter)	175
Timeout (Parameter)	157
Timestamp (Parameter)	202, 204, 205, 206, 207
Totalizer (Submenu)	53
Totalizer 1 to n (Submenu)	195
Totalizer 1 to n failure behavior (Parameter)	199
Totalizer 1 to n operation mode (Parameter)	198
Totalizer 1 to n overflow (Parameter)	54
Totalizer 1 to n status (Hex) (Parameter)	55
Totalizer 1 to n status (Parameter)	55
Totalizer 1 to n value (Parameter)	53, 55
Transition length (Parameter)	81
Transmitter identifier (Parameter)	41
Turbulence (Parameter)	53

U

Upper range value output (Parameter)	113
User name (Parameter)	190
User role (Parameter)	13

V

Value (Parameter)	158
Value 1 display (Parameter)	17
Value 2 display (Parameter)	19
Value 3 display (Parameter)	20
Value 4 display (Parameter)	22
Value current input 1 to n (Parameter)	240
Value current output 1 to n (Submenu)	57
Value per pulse (Parameter)	149
Value status input (Parameter)	57, 106
Value status input 1 to n (Submenu)	56
Velocity unit (Parameter)	66
Verification ID (Parameter)	234
Verification mode (Parameter)	230
Verification result (Parameter)	233, 235

Verification results (Submenu)	234
Viscosity (Parameter)	75
Volume flow (Parameter)	45
Volume flow factor (Parameter)	96
Volume flow offset (Parameter)	95
Volume flow unit (Parameter)	62
Volume unit (Parameter)	64

W

Web server (Submenu)	176
Web server functionality (Parameter)	179
Web server language (Parameter)	177
Wizard	
Define access code	38
WLAN settings	188
WLAN (Parameter)	189
WLAN IP address (Parameter)	191
WLAN MAC address (Parameter)	191
WLAN mode (Parameter)	189
WLAN passphrase (Parameter)	192
WLAN password (Parameter)	191
WLAN settings (Wizard)	188
WLAN subnet mask (Parameter)	192

Y

Year (Parameter)	228
----------------------------	-----

Z

Zero point (Parameter)	99
----------------------------------	----



71633425

www.addresses.endress.com
