

Description of Device Parameters

Cerabar PMC71B

Process pressure measurement
HART




Table of contents

1	About this document	4
1.1	Document function	4
1.2	Target group	4
1.3	Using this document	4
1.4	Symbols used	5
1.5	Documentation	5
2	Overview of the operating menu	6
3	Description of device parameters ...	31
3.1	User navigation	31
3.2	"Guidance" menu	34
3.3	"Diagnostics" menu	106
3.4	"Application" menu	131
3.5	"System" menu	162
Index	177

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and parameters that are available when the "Maintenance" option user role is enabled.

 For the operating concept of the operating menus, see the Operating Instructions.

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of Information

Additional information: 

Reference to documentation: 

Operation via local display: 

Operation via operating tool: 

Write-protected parameter: 

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

 The Operating Instructions are available via the Internet: www.endress.com → Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

 The Special Documentation is available via the Internet: www.endress.com → Download

2 Overview of the operating menu

Guidance	→ 31
▶ Commissioning	→ 34
▶ Device identification	→ 34
Device tag	→ 34
Device name	→ 34
Serial number	→ 34
Extended order code 1	→ 35
Extended order code 2	→ 35
Extended order code 3	→ 35
▶ Device identification	→ 36
Locking status	→ 36
▶ Device identification	→ 37
HART short tag	→ 37
HART date code	→ 37
HART descriptor	→ 37
HART message	→ 37
HART address	→ 38
▶ Measurement adjustments	→ 38
Assign PV	→ 38
Damping	→ 38
▶ Measurement adjustments	→ 39
Pressure unit	→ 39
Temperature unit	→ 39
▶ Measurement adjustments	→ 40

Pressure unit	→ 40
Scaled variable unit	→ 40
Free text	→ 41
Temperature unit	→ 41
► Measurement adjustments	→ 42
Zero adjustment	→ 42
Pressure	→ 43
► Output settings	→ 43
Output current transfer function	→ 43
► Output settings	→ 43
Scaled variable transfer function	→ 43
► Output settings	→ 44
Lower Range Limit	→ 44
Upper Range Limit	→ 44
Minimum span	→ 44
► Output settings	→ 45
Pressure	→ 45
Scaled variable	→ 45
► Output settings	→ 45
Lower range value output	→ 45
Upper range value output	→ 45
Lower Range Limit	→ 46
Upper Range Limit	→ 46
Minimum span	→ 46
► Output settings	→ 46

Scaled variable transfer function	→ 46
Pressure value 1	→ 47
Scaled variable value 1	→ 47
Pressure value 2	→ 47
Scaled variable value 2	→ 47
Lower Range Limit	→ 48
Upper Range Limit	→ 48
Minimum span	→ 48
► Output settings	→ 48
Lower range value output	→ 48
Upper range value output	→ 49
Current range output	→ 49
Failure behavior current output	→ 49
Failure current	→ 49
Loop current mode	→ 50
Assign HART variables?	→ 50
► Output settings	→ 50
Process variable output current	→ 50
Current range output	→ 51
Lower range value output	→ 51
Upper range value output	→ 51
Failure behavior current output	→ 51
Failure current	→ 52

Loop current mode	→ 52
Assign HART variables?	→ 52
► Output settings	→ 52
Assign PV	→ 52
Assign SV	→ 53
Assign TV	→ 53
Assign QV	→ 54
► Heartbeat Technology	→ 114
► Heartbeat Verification	→ 55
► Heartbeat Configuration	→ 55
Heartbeat Verification	→ 55
► Mainboard module	→ 55
System status	→ 55
Output current	→ 55
Software integrity	→ 56
RAM check	→ 56
ROM check	→ 56
Loop diagnostics	→ 57
► Sensor module	→ 57
Sensor integrity	→ 57
Membrane integrity	→ 57
Sensor/membrane integrity	→ 58
Statistical Sensor Diagnostics	→ 58
Analog path integrity	→ 58
► Verification result	→ 59

Verification result	→ 59
Save protocol?	→ 59
► Finish	→ 59
Inspector	→ 59
Location	→ 59
Notes	→ 60
Plant operator	→ 60
Operating time (Verification)	→ 60
Date/time Heartbeat Verification	→ 60
► SSD: Statistical Sensor Diagnostics	→ 60
► Configuration	→ 61
Status summary	→ 62
Status summary	→ 62
Status summary	→ 62
Status summary	→ 63
Status summary	→ 63
Status summary	→ 63
System status	→ 64
Signal status	→ 64
Signal noise status	→ 64
Baseline build process	→ 64
Sample rate	→ 65

► Monitoring	→ 66
Signal status	→ 66
Current Baseline signal	→ 66
Baseline Signal Upper Control Line	→ 66
Baseline Signal Control Line	→ 66
Baseline Signal Lower Control Line	→ 67
Signal minimum value	→ 67
Signal maximum value	→ 67
► Monitoring	→ 67
Signal noise status	→ 67
Current Baseline noise	→ 68
Baseline Signal Noise Upper Control Line	→ 68
Baseline Signal Noise Control Line	→ 68
Baseline Signal Noise Lower Control Line	→ 68
Baseline Signal Noise Minimum	→ 69
Signal noise minimum value	→ 69
Signal noise maximum value	→ 69
► Diagnostic settings	→ 69
SSD Monitoring delay time	→ 69
900 Event category	→ 69
900 Event category	→ 69
900 Diagnostic behavior	→ 70
900 Diagnostic behavior	→ 70
SSD Out of range delay time	→ 70

906 Event category	→ 70
906 Event category	→ 70
▶ Activate/Deactivate	→ 71
SSD: Statistical Sensor Diagnostics	→ 71
▶ Loop diagnostics	→ 71
▶ Configuration	→ 71
I have read the warning texts.	→ 71
▶ Configuration	→ 71
Baseline status	→ 71
Baseline build process	→ 72
▶ Configuration	→ 72
Timestamp Baseline	→ 72
Resistance Baseline	→ 72
Supply voltage Baseline	→ 72
Timestamp previous Baseline	→ 73
Resistance previous Baseline	→ 73
Supply voltage previous Baseline	→ 73
▶ Monitoring	→ 73
Tolerated deviation +/-	→ 73
▶ Diagnostic settings	→ 74
806 Event delay	→ 74
806 Event category	→ 74
806 Event category	→ 74

806 Diagnostic behavior	→ 74
806 Diagnostic behavior	→ 74
▶ Activate/Deactivate	→ 75
Loop diagnostics	→ 75
▶ Process window	→ 75
▶ Pressure range	→ 75
500 Process alert pressure	→ 75
Low alert value	→ 75
High alert value	→ 76
Counter underruns of user limit Pmin	→ 76
Counter overruns of user limit Pmax	→ 76
500 Diagnostic behavior	→ 77
500 Diagnostic behavior	→ 77
500 Event category	→ 77
500 Event category	→ 77
▶ Pressure range	→ 77
501 Process alert scaled variable	→ 77
Low alert value	→ 78
High alert value	→ 78
501 Diagnostic behavior	→ 78
501 Diagnostic behavior	→ 78
501 Event category	→ 79
501 Event category	→ 79
▶ Temperature range	→ 79
User temperature process alert	→ 79

Low alert value	→ 79
High alert value	→ 79
Counter underruns of user limit Tmin	→ 80
Counter overruns of user limit Tmax	→ 80
502 Diagnostic behavior	→ 80
502 Diagnostic behavior	→ 80
502 Event category	→ 80
502 Event category	→ 80
► Safety mode	→ 81
► Preparation	→ 81
I have read the warning texts.	→ 81
► Preparation	→ 81
Enter safety unlocking code	→ 81
Locking status	→ 81
► Preparation	→ 83
Character test string	→ 83
Confirm	→ 83
► Preparation	→ 84
Device tag	→ 84
Device name	→ 84
Serial number	→ 85
Firmware version	→ 85
Hardware version	→ 85
Confirm	→ 85
► Preparation	→ 86

CRC device configuration	→ 86
Stored CRC device configuration	→ 86
Timestamp stored CRC device config.	→ 86
Operating time	→ 86
Configuration counter	→ 87
► Confirmation	→ 87
Zero adjustment offset	→ 87
HP/LP swap	→ 87
Damping	→ 88
Sensor pressure range behavior	→ 88
Confirm	→ 88
► Confirmation	→ 88
Output current transfer function	→ 88
Low cutoff	→ 89
Confirm	→ 89
► Confirmation	→ 89
Measuring mode current output	→ 89
Failure behavior current output	→ 89
Current range output	→ 90
Lower range value output	→ 90
Upper range value output	→ 90
Assign PV	→ 90
Confirm	→ 91
► Confirmation	→ 91

Zero adjustment offset	→ 91
Confirm	→ 91
► Locking	→ 91
Enter safety locking code	→ 91
Locking status	→ 92
Save protocol?	→ 92
► Result	→ 93
Inspector	→ 93
Location	→ 93
Date/time	→ 93
Notes	→ 93
Plant operator	→ 94
► Proof test	→ 94
► Preparation Proof test	→ 94
I have read the warning texts.	→ 94
► Preparation Proof test	→ 95
Visual inspection	→ 95
Notes	→ 95
► Preparation Proof test	→ 95
Device tag	→ 95
Device name	→ 96
Serial number	→ 96
Firmware version	→ 96
Hardware version	→ 97

► Preparation Proof test	→ 97
CRC device configuration	→ 97
Stored CRC device configuration	→ 97
Timestamp stored CRC device config.	→ 97
Operating time	→ 98
Configuration counter	→ 98
► Preparation Proof test	→ 99
Select test procedure	→ 99
Safety function?	→ 99
► Simulation and check failure current	→ 99
Failure current (high alarm)	→ 99
Confirm	→ 100
(High) Is safety function triggered?	→ 100
Terminal current (high alarm)	→ 100
Confirm	→ 100
(Low) Is safety function triggered?	→ 101
► Proof test	→ 101
Setpoint 1	→ 101
Pressure 1	→ 101
Terminal current 1	→ 101
Current deviation 1	→ 102
Setpoint 2	→ 102
Pressure 2	→ 102

Terminal current 2	→ 102
Current deviation 2	→ 102
► Finish	→ 103
Active diagnostics	→ 103
Summary	→ 103
Decision of inspector	→ 103
Inspector	→ 104
Location	→ 104
Date/time proof test	→ 104
Notes	→ 104
Plant operator	→ 105
 Diagnostics	→ 106
► Active diagnostics	→ 106
Active diagnostics	→ 106
Timestamp	→ 106
Previous diagnostics	→ 107
Timestamp	→ 107
Operating time from restart	→ 107
Operating time	→ 108
 ► Event logbook	→ 108
Filter options	→ 108
 ► Minimum/maximum values	→ 109
Pressure min	→ 109
Counter limit underruns sensor Pmin	→ 109
Counter underruns of user limit Pmin	→ 109

Minimum sensor temperature	→ 110
Counter limit underruns sensor Tmin	→ 110
Counter underruns of user limit Tmin	→ 110
Minimum terminal voltage	→ 110
Minimum electronics temperature	→ 110
Reset user defined counters P and T	→ 111
Pressure max	→ 111
Counter limit overruns sensor Pmax	→ 111
Counter overruns of user limit Pmax	→ 111
Maximum sensor temperature	→ 111
Counter limit overruns sensor Tmax	→ 112
Counter overruns of user limit Tmax	→ 112
Maximum terminal voltage	→ 112
Maximum electronics temperature	→ 112
► Simulation	→ 113
Simulation	→ 113
Value pressure simulation	→ 113
Value current output	→ 113
Diagnostic event simulation	→ 113
► Heartbeat Technology	→ 114
► Heartbeat Verification	→ 114
Date/time Heartbeat Verification	→ 114
Operating time (Verification)	→ 114
Verification result	→ 114
Status	→ 115

► Loop diagnostics	→ 115
Rebuild baseline	→ 115
Tolerated deviation +/-	→ 115
Baseline status	→ 116
Loop diagnostics	→ 116
Terminal voltage 1	→ 116
Clamping voltage lower threshold	→ 116
Clamping voltage upper threshold	→ 116
806 Event delay	→ 117
► Statistical Sensor Diagnostics	→ 117
SSD: Statistical Sensor Diagnostics	→ 117
System status	→ 117
Signal status	→ 117
Signal noise status	→ 118
► Diagnostic settings	→ 118
► Properties	→ 118
SSD Out of range delay time	→ 118
SSD Monitoring delay time	→ 119
500 Process alert pressure	→ 119
Low alert value	→ 119
High alert value	→ 119
501 Process alert scaled variable	→ 119
Low alert value	→ 120
High alert value	→ 120
User temperature process alert	→ 120

Low alert value	→ 120
High alert value	→ 121
806 Diagnostic behavior	→ 121
806 Diagnostic behavior	→ 121
806 Event category	→ 121
806 Event category	→ 121
806 Event delay	→ 121
► Configuration	→ 61
► Configuration	→ 122
500 Diagnostic behavior	→ 122
500 Event category	→ 122
501 Diagnostic behavior	→ 122
501 Event category	→ 123

502 Diagnostic behavior	→ 123
502 Event category	→ 123
▶ Process	→ 124
806 Diagnostic behavior	→ 124
806 Event category	→ 124
822 Diagnostic behavior	→ 124
822 Event category	→ 125
Sensor pressure range behavior	→ 125
841 Event category	→ 125

900 Event category	→ 126
900 Diagnostic behavior	→ 126
906 Event category	→ 126
Application	→ 131
► Measuring units	→ 131
Pressure unit	→ 131
Decimal places pressure	→ 131
Temperature unit	→ 131
Scaled variable unit	→ 132
Free text	→ 133
Decimal places scaled variable	→ 133

► Measured values	→  134
Pressure	→  134
Scaled variable	→  134
Sensor temperature	→  134
Terminal voltage 1	→  134
Terminal current	→  135
Electronics temperature	→  135
► Sensor	→  135
► Basic settings	→  135
Output current transfer function	→  135
Damping	→  136
► Sensor calibration	→  136
Zero adjustment	→  136
Calibration offset	→  136
Zero adjustment offset	→  137
Sensor Trim Reset	→  137
Lower sensor trim measured value	→  137
Lower sensor trim	→  138
Upper sensor trim measured value	→  138
Upper sensor trim	→  139
► Sensor limits	→  139
Lower Range Limit	→  139
Upper Range Limit	→  139
Minimum span	→  140

Sensor temperature lower range limit	→ 140
Sensor temperature upper range limit	→ 140
► Scaled variable	→ 140
Assign PV	→ 140
Scaled variable unit	→ 141
Free text	→ 141
Pressure	→ 142
Scaled variable transfer function	→ 142
Lower range value output	→ 142
Upper range value output	→ 142
Activate table	→ 143
Pressure value 1	→ 143
Scaled variable value 1	→ 143
Pressure value 2	→ 143
Scaled variable value 2	→ 143
Pressure	→ 144
Scaled variable	→ 144
► Wet calibration	→ 144
Zero	→ 144
Pressure value 1	→ 144
Span	→ 144
Pressure value 2	→ 145
Zero	→ 144
Lower range value output	→ 145

Span	→ 144
Upper range value output	→ 145
► Current output	→ 147
Assign PV	→ 147
Measuring mode current output	→ 147
Current range output	→ 147
Lower range value output	→ 148
Upper range value output	→ 148
Failure behavior current output	→ 148
Failure current	→ 148
Output current	→ 149
Terminal current	→ 149
► HART output	→ 150
► Configuration	→ 150
HART address	→ 150
HART short tag	→ 150
Device tag	→ 150
No. of preambles	→ 151
Loop current mode	→ 151
► HART output	→ 151
Assign PV	→ 151
Primary variable (PV)	→ 151
Assign SV	→ 152
Secondary variable (SV)	→ 152
Assign TV	→ 152

Tertiary variable (TV)	→ 153
Assign QV	→ 153
Quaternary variable (QV)	→ 154
► Burst configuration 1	→ 154
Burst mode 1	→ 154
Burst command 1	→ 155
Burst variable 0	→ 155
Burst variable 1	→ 156
Burst variable 2	→ 156
Burst variable 3	→ 156
Burst variable 4	→ 156
Burst variable 5	→ 157
Burst variable 6	→ 157
Burst variable 7	→ 157
Burst trigger mode	→ 157
Burst trigger level	→ 158
Min. update period	→ 158
Max. update period	→ 158
► Information	→ 159
Device ID	→ 159
Device type	→ 159
Device revision	→ 159
HART short tag	→ 160
HART revision	→ 160
HART descriptor	→ 160

	HART message	→ 160
	HART date code	→ 161
System		→ 162
	► Device management	→ 162
	Device tag	→ 162
	Locking status	→ 162
	Configuration counter	→ 163
	Reset device	→ 163
	► User management	→ 164
	User role	→ 164
	Password	→ 164
	Enter access code	→ 164
	Status password entry	→ 165
	New password	→ 165
	Confirm new password	→ 165
	Status password entry	→ 165
	Old password	→ 165
	New password	→ 165
	Confirm new password	→ 165
	Status password entry	→ 165
	Reset password	→ 166
	Status password entry	→ 165
	Old password	→ 165
	Status password entry	→ 165

► Bluetooth configuration	→ 166
Bluetooth activation	→ 166
► Display	→ 166
Language	→ 166
Format display	→ 167
Value 1 display	→ 167
Value 2 display	→ 168
Value 3 display	→ 168
Value 4 display	→ 169
Contrast display	→ 169
► Geolocation	→ 170
Process Unit Tag	→ 170
Location Description	→ 170
Longitude	→ 170
Latitude	→ 170
Altitude	→ 171
Location method	→ 171
► Information	→ 171
Device name	→ 171
Manufacturer	→ 172
Serial number	→ 172
Order code	→ 172
Firmware version	→ 173
Hardware version	→ 173
Extended order code 1	→ 173

Extended order code 2	→ 173
Extended order code 3	→ 174
Checksum	→ 174
► Software configuration	→ 175
CRC device configuration	→ 175
Stored CRC device configuration	→ 175
Timestamp stored CRC device config.	→ 175
Activate SW option	→ 175
Software option overview	→ 176

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the operating tool.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

3.1 User navigation

The Guidance main menu contains functions which enable users to perform basic tasks swiftly, e.g. commissioning.

These are primarily guided wizards and cross-subject special functions.

Navigation  *Guidance*

3.1.1 Overview of the operating menu

"Guidance" menu

- Commissioning (→  34)
- Heartbeat Technology (→  55)
- Safety mode (→  81)
- Proof test (→  94)

"Diagnostics" menu

- Active diagnostics (→  106)
- Event logbook (→  108)
- Minimum/maximum values (→  109)
- Simulation (→  113)
- Heartbeat Technology (→  114)
- Diagnostic settings (→  69)

"Application" menu

- Measuring units (→  131)
- Measured values (→  134)
- Sensor (→  135)
- Current output (→  147)
- HART output (→  150)

"System" menu

- Device management (→  162)
- User management (→  164)
- Bluetooth configuration (→  166)
- Display (→  166)
- Geolocation (→  170)
- Information (→  159)
- Software configuration (→  175)

3.1.2 Commissioning

Run this wizard to put the device into operation. Enter the appropriate value in each parameter or select the appropriate option.

i If the wizard is canceled before all the necessary parameters have been configured, any settings already made are saved. For this reason, the device may then be in an undefined state!

In such situations, it is advisable to reset the device to the factory default settings.

The following parameters are configured in the Commissioning wizard:

- Device identification (→ [34](#))
 - Device tag (→ [34](#))
 - Device name (→ [34](#))
 - Serial number (→ [34](#))
 - Extended order code 1 (→ [35](#))
 - Extended order code 2 (→ [35](#))
 - Extended order code 3 (→ [35](#))
 - Locking status (→ [36](#))
 - HART short tag (→ [37](#))
 - HART date code (→ [37](#))
 - HART descriptor (→ [37](#))
 - HART message (→ [37](#))
 - HART address (→ [38](#))
- Measurement adjustments (→ [38](#))
 - Assign PV (→ [38](#))
 - Damping (→ [38](#))
 - Pressure unit (→ [39](#))
 - Temperature unit (→ [39](#))
 - Scaled variable unit (→ [40](#))
 - Zero adjustment (→ [42](#))
 - Pressure (→ [43](#))
- Output settings (→ [43](#))
 - Output current transfer function (→ [43](#))
 - Lower Range Limit (→ [44](#))
 - Upper Range Limit (→ [44](#))
 - Minimum span (→ [44](#))
 - Pressure (→ [45](#))
 - Scaled variable (→ [45](#))
 - Lower range value output (→ [45](#))
 - Upper range value output (→ [45](#))
 - Scaled variable transfer function (→ [43](#))
 - Pressure value 1 (→ [47](#))
 - Current range output (→ [49](#))
 - Failure behavior current output (→ [49](#))
 - Failure current (→ [49](#))
 - Loop current mode (→ [50](#))
 - Assign HART variables? (→ [50](#))
 - Process variable output current (→ [50](#))
 - Assign PV (→ [38](#))
 - Assign SV (→ [53](#))
 - Assign TV (→ [53](#))
 - Assign QV (→ [54](#))

3.1.3 Heartbeat Technology

Heartbeat Technology offers diagnostic functionality through continuous self-monitoring, the transmission of additional measured variables to an external Condition Monitoring system and the in-situ verification of measuring devices in the application.
Special Documentation "Heartbeat Monitoring + Verification"



"Heartbeat Verification" wizard

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

"SSD: Statistical Sensor Diagnostics" wizard

Using statistical analysis of the pressure signal, process anomalies such as plugged impulse lines can be detected. This wizard supports the settings and thresholds that should lead to a diagnostic message.

"Loop diagnostics" wizard

Using this wizard, changes in the current-voltage loop characteristics (baseline) can be used to detect unwanted installation anomalies such as creep currents caused by terminal corrosion or a deteriorating power supply that can lead to an incorrect 4-20 mA measured value.

"Process window" wizard

This wizard uses user-defined limits for pressure and temperature to detect unwanted installation or application anomalies.

Applications:

- Defective heat tracer or insulation
- Frozen process connections
- Dynamic pressure peaks etc.

3.1.4 Safety mode

The write protection guards the device settings against overwriting. In addition, it is recommended for safety applications to confirm the safety relevant device settings. This ensures that the correct values have been entered and downloaded to device.

This input can be used as the confirmation sequence instead of manual checklists. After the safety relevant device settings have been confirmed, the device is marked with the property Safety-locked. This indicates that the safety relevant parameter settings have been checked and evaluated as correct.

To unlock the safety locking the sequence needs to be restarted. The safety locking is deactivated when the safety unlocking code (= safety locking code) is entered.

3.1.5 Proof testing

The proof test will simulate the current output.

The safety function is not guaranteed during proof test. Alternative process control in manual must be taken to ensure process safety.

Note: It is only possible to perform a proof test when the device has no alarm and the hardware write protection switch is off.

3.2 "Guidance" menu

Navigation  Guidance

3.2.1 "Commissioning" wizard

Navigation  Guidance → Commissioning

"Device identification" wizard

Navigation  Guidance → Commissioning → Device ident.

Device tag



Navigation  Guidance → Commissioning → Device ident. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Device name

Navigation  Guidance → Commissioning → Device ident. → Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Serial number



Navigation  Guidance → Commissioning → Device ident. → Serial number

Description Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Extended order code 1**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 1

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface

Character string

Factory setting

–

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 2

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

–

Extended order code 3**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 3

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

-

"Device identification" wizard*Navigation*

Guidance → Commissioning → Device ident.

Locking status**Navigation**

Guidance → Commissioning → Device ident. → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

*Selection**Function scope of the "Locking status" parameter*

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

"Device identification" wizard**Navigation**

Guidance → Commissioning → Device ident.

**HART short tag****Navigation**

Guidance → Commissioning → Device ident. → HART short tag

Description

Defines the short tag for the measuring point.

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

**HART date code****Navigation**

Guidance → Commissioning → Device ident. → HART date code

Description

Date of the last configuration change

User entry

Character string comprising numbers, letters and special characters (10)

Additional information

Date format: YYYY-MM-DD

Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

**HART descriptor****Navigation**

Guidance → Commissioning → Device ident. → HART descriptor

Description

Description for the measuring point.

User entry

Character string comprising numbers, letters and special characters (16)

**HART message****Navigation**

Guidance → Commissioning → Device ident. → HART message

Description

A HART message which is sent via the HART protocol when requested by the master.

User entry

Character string comprising numbers, letters and special characters (32)

HART address**Navigation**

█ Guidance → Commissioning → Device ident. → HART address

Description

Define the HART address of the device.

User entry

0 to 63

Additional information

- The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode).
- Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0.
- All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.

"Measurement adjustments" wizard

Navigation █ Guidance → Commissioning → Meas. adjust.

Assign PV**Navigation**

█ Guidance → Commissioning → Meas. adjust. → Assign PV

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Damping**Navigation**

█ Guidance → Commissioning → Meas. adjust. → Damping

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own "Damping" parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry

0 to 999.0 s

"Measurement adjustments" wizard*Navigation*

Guidance → Commissioning → Meas. adjust.

**Pressure unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection*SI units*

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

- psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

**Temperature unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection*SI units*

- °C
- K

US units

- °F

Factory setting

Country-specific:

- °C
- °F

Additional information*Selection*

"Measurement adjustments" wizard*Navigation*

Guidance → Commissioning → Meas. adjust.

**Pressure unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection*SI units*

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

**Scaled variable unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Scaled Unit

Description

Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ %	■ ft	■ gal (imp)	
■ mm	■ in	■ gal/s (imp)	
■ cm	■ ft ³	■ gal/min (imp)	
■ m	■ gal (us)	■ gal/h (imp)	
■ l	■ bbl (us;oil)		
■ hl	■ oz		
■ m ³	■ lb		
■ g	■ STon		
■ kg	■ lb/s		
■ t	■ lb/min		
■ g/s	■ lb/h		
■ kg/s	■ STon/min		
■ kg/min	■ STon/h		
■ kg/h	■ STon/d		
■ t/min	■ ft ³ /s		
■ t/h	■ ft ³ /min		
■ t/d	■ ft ³ /h		
■ m ³ /s	■ ft ³ /d		
■ m ³ /min	■ gal/s (us)		
■ m ³ /h	■ gal/min (us)		
■ m ³ /d	■ gal/h (us)		
■ l/s	■ gal/d (us)		
■ l/min	■ bbl/s (us;oil)		
■ l/h	■ bbl/min (us;oil)		
■ Nm ³ /h	■ bbl/h (us;oil)		
■ NI/h	■ bbl/d (us;oil)		
■ Sm ³ /s	■ Sft ³ /min		
■ Sm ³ /min	■ Sft ³ /h		
■ Sm ³ /h	■ Sft ³ /d		
■ Sm ³ /d			
■ Nm ³ /s			
■ g/cm ³			
■ kg/m ³			
■ Nm ³ /min			
■ Nm ³ /d			

Custom-specific units
Free text

Free text

Navigation Guidance → Commissioning → Meas. adjust. → Free text

User entry Character string comprising numbers, letters and special characters (32)

Temperature unit

Navigation Guidance → Commissioning → Meas. adjust. → Temperature unit

Description Use this function to select the unit for the temperature.

Selection	SI units	US units
	▪ °C	°F
▪ K		

Factory setting	Country-specific:
	▪ °C
	▪ °F

Additional information	<i>Selection</i>
------------------------	------------------

"Measurement adjustments" wizard

Navigation  Guidance → Commissioning → Meas. adjust.

Zero adjustment



Navigation  Guidance → Commissioning → Meas. adjust. → Zero adjustment

Description Due to the mounting position of the measuring instrument, a pressure shift may occur.
The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Pressure

Navigation

 Guidance → Commissioning → Meas. adjust. → Pressure

"Output settings" wizard

Navigation

 Guidance → Commissioning → Output settings

Output current transfer function

Navigation

 Guidance → Commissioning → Output settings → Curr. trans.func

Description

Linear

The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit.

Square root - differential pressure only

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

User interface

- Linear
- Square root *

"Output settings" wizard

Navigation

 Guidance → Commissioning → Output settings

Scaled variable transfer function

Navigation

 Guidance → Commissioning → Output settings → Scaled function

Description

"Linear"

The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.

"Square root" (Deltabar)

The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table"

The output is defined according to the scaled variable / pressure table entered.

* Visibility depends on order options or device settings

Selection

- Linear
- Square root *
- Table

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

Lower Range Limit

Navigation

Guidance → Commissioning → Output settings → LRL

Description

Indicates the lower measuring limit of the sensor.

User interface

Signed floating-point number

Upper Range Limit

Navigation

Guidance → Commissioning → Output settings → URL

Description

Indicates the upper measuring limit of the sensor.

User interface

Signed floating-point number

Minimum span

Navigation

Guidance → Commissioning → Output settings → Minimum span

Description

Specifies the smallest possible measuring span of the sensor.

User interface

Signed floating-point number

* Visibility depends on order options or device settings

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

**Pressure****Navigation**

Guidance → Commissioning → Output settings → Pressure

User entry

Signed floating-point number

**Scaled variable****Navigation**

Guidance → Commissioning → Output settings → Scaled variable

User entry

Signed floating-point number

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

**Lower range value output****Navigation**

Guidance → Commissioning → Output settings → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

**Upper range value output****Navigation**

Guidance → Commissioning → Output settings → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Lower Range Limit

Navigation	 Guidance → Commissioning → Output settings → LRL
Description	Indicates the lower measuring limit of the sensor.
User interface	Signed floating-point number

Upper Range Limit

Navigation	 Guidance → Commissioning → Output settings → URL
Description	Indicates the upper measuring limit of the sensor.
User interface	Signed floating-point number

Minimum span

Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Scaled variable transfer function



Navigation	 Guidance → Commissioning → Output settings → Scaled function
Description	"Linear" The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.
	"Square root" (Deltabar) The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.
	"Table" The output is defined according to the scaled variable / pressure table entered.

Selection	<ul style="list-style-type: none">■ Linear■ Square root *■ Table
------------------	--

Pressure value 1

Navigation	 Guidance → Commissioning → Output settings → Pressure 1
Description	Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.
User entry	Signed floating-point number

Scaled variable value 1

Navigation	 Guidance → Commissioning → Output settings → Scaled 1
Description	Enter value for the first scaling point. This value is allocated to "Pressure value 1".
User interface	Signed floating-point number

Pressure value 2

Navigation	 Guidance → Commissioning → Output settings → Pressure 2
Description	Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.
User entry	Signed floating-point number

Scaled variable value 2

Navigation	 Guidance → Commissioning → Output settings → Scaled 2
Description	Enter value for the second scaling point. This value is allocated to "Pressure value 2".
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Lower Range Limit

Navigation	 Guidance → Commissioning → Output settings → LRL
Description	Indicates the lower measuring limit of the sensor.
User interface	Signed floating-point number

Upper Range Limit

Navigation	 Guidance → Commissioning → Output settings → URL
Description	Indicates the upper measuring limit of the sensor.
User interface	Signed floating-point number

Minimum span

Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Lower range value output



Navigation	 Guidance → Commissioning → Output settings → Low.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

Upper range value output

Navigation Guidance → Commissioning → Output settings → Upp.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Current range output

Navigation Guidance → Commissioning → Output settings → Current range

Description Defines the current range used to transmit the measured or calculated value. In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value ≤ "low saturation", the output current is set to "low saturation". If Measured value ≥ "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Failure behavior current output

Navigation Guidance → Commissioning → Output settings → Failure behav.

Description Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: >21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current

Navigation Guidance → Commissioning → Output settings → Failure current

Description Enter current output value in alarm condition

User entry 21.5 to 23 mA

Loop current mode

Navigation	 Guidance → Commissioning → Output settings → Loop curr mode
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
User interface	<ul style="list-style-type: none">■ Disable■ Enable

Assign HART variables?

Navigation	 Guidance → Commissioning → Output settings → Assign HART var?
Description	Up to four HART variables can be transmitted via the HART protocol. Select "Yes" to show/assign measuring variables to these HART variables.
Selection	<ul style="list-style-type: none">■ No■ Yes

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Process variable output current

Navigation	 Guidance → Commissioning → Output settings → Proc.var.curr.
Description	Determines which process variable is transmitted via the current output.
User interface	<ul style="list-style-type: none">■ Pressure■ Scaled variable

Current range output**Navigation**

Guidance → Commissioning → Output settings → Current range

Description

Defines the current range used to transmit the measured or calculated value.
 In brackets are indicated the "low saturation value" and the "high saturation value".
 If Measured value \leq "low saturation", the output current is set to "low saturation".
 If Measured value \geq "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output**Navigation**

Guidance → Commissioning → Output settings → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**

Guidance → Commissioning → Output settings → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Failure behavior current output**Navigation**

Guidance → Commissioning → Output settings → Failure behav.

Description

Defines which current the output assumes in the case of an error.

Min: < 3.6 mA

Max: > 21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current

Navigation Guidance → Commissioning → Output settings → Failure current

Description Enter current output value in alarm condition

User entry 21.5 to 23 mA

Loop current mode

Navigation Guidance → Commissioning → Output settings → Loop curr mode

Description If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications.
In this mode the output current is fixed.

User interface

- Disable
- Enable

Assign HART variables?

Navigation Guidance → Commissioning → Output settings → Assign HART var?

Description Up to four HART variables can be transmitted via the HART protocol.
Select "Yes" to show/assign measuring variables to these HART variables.

Selection

- No
- Yes

"Output settings" wizard

Navigation Guidance → Commissioning → Output settings

Assign PV

Navigation Guidance → Commissioning → Output settings → Assign PV

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable
------------------	---

Assign SV

Navigation Guidance → Commissioning → Output settings → Assign SV

Description Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable ■ Sensor temperature ■ Sensor pressure ■ Electronics temperature ■ Terminal current * ■ Terminal voltage * ■ Median of pressure signal * ■ Noise of pressure signal * ■ Signal noise detected * ■ Percent of range ■ Loop current ■ Not used
------------------	---

Additional information *Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Assign TV

Navigation Guidance → Commissioning → Output settings → Assign TV

Description Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable ■ Sensor temperature ■ Sensor pressure ■ Electronics temperature ■ Terminal current *
------------------	---

* Visibility depends on order options or device settings

- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Assign QV**Navigation**

█ Guidance → Commissioning → Output settings → Assign QV

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

* Visibility depends on order options or device settings

3.2.2 "Heartbeat Technology" submenu

"Heartbeat Verification" wizard

Navigation



Guidance → Heartbeat Techn. → Heartbeat Verif.

Heartbeat Verification

Navigation

Guidance → Heartbeat Techn. → Heartbeat Verif. → Heartbeat Config → Heartbeat Verif.

Selection

- Start verification
- Show results

"Mainboard module" wizard

Navigation



Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module

System status

Navigation

Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → System status

Description

Checks active measurement device errors at diagnostical behavior "alarm".
If an active error is detected, then verification will be performed but the overall result will always be "Failed".

User interface

- Not done
- Passed
- Not done
- Failed

Output current

Navigation

Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → Output curr.

Description

Checks whether read-back current at the output matches the current set by the device.

User interface

- Not done
- Passed
- Not done
- Failed

Software integrity

Navigation

█ Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → Software integ.

Description

Checks whether the function blocks of the software are executed in the correct order.

User interface

- Not done
- Passed
- Not done
- Failed

RAM check

Navigation

█ Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → RAM check

Description

Checks the correct function of the RAM (Random Access Memory).

User interface

- Not done
- Passed
- Not done
- Failed

ROM check

Navigation

█ Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → ROM check

Description

Checks the correct function of the ROM memory (Read-Only-Memory).

User interface

- Not done
- Passed
- Not done
- Failed

Loop diagnostics

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Mainboard module → Loop diag.
Description	Checks whether the voltage/current values are within range or the voltage/current baseline defined with wizard. "Failed" can indicate faulty power supply or grounding / wiring.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Sensor integrity

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Sensor module → Sensor integrity
Description	Checks the integrity of the sensor. Scope of check depends on sensor type used.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Membrane integrity

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Sensor module → Membrane integr.
Description	Checks the integrity of the membrane. Notice: Not included in the scope of testing for metallic membranes.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Sensor/membrane integrity

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Sensor module → Sensor/membrane
Description	Checks the integrity of the sensor and membrane.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Statistical Sensor Diagnostics

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Sensor module → SSD
Description	Checks whether the actual values are within the defined signal noise thresholds.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Analog path integrity

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Sensor module → Path integrity
Description	Checks if the analog path of the sensor has changed from state of delivery.
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Verification result

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Verific. result → Verific. result
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Save protocol?

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Verific. result → Save protocol?
Description	The Report can be saved for archiving.
Selection	<ul style="list-style-type: none">■ No■ Yes

Inspector

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Inspector
Description	The entered inspector name will be included in the report.
User entry	Character string comprising numbers, letters and special characters (96)

Location

Navigation	 Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Location
Description	The entered value will be included in the report.
User entry	Character string comprising numbers, letters and special characters (96)

Notes

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Notes

Description The entered value will be included in the report.

User entry Character string comprising numbers, letters and special characters (255)

Plant operator

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Plant operator

Description The entered value will be included in the report.

User entry Character string comprising numbers, letters and special characters (96)

Operating time (Verification)

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Operating time

User interface Days (d), hours (h), minutes (m), seconds (s)

Date/time Heartbeat Verification

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif. → Finish → Date/time Heartbeat Verification

Description Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.

User interface Character string comprising numbers, letters and special characters

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	Activate SSD.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	Please wait. Function is not ready.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The signal noise is too small for the teach-in phase. Note: Teach-in is only possible while the process is running. Measures: Check valve position. If necessary, perform the teach-in procedure later while the process is running.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The teach-in phase is completed. Continue or terminate the configuration.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The SSD is not active because the average value of the raw signal is outside the limits. The SSD is reactivated as soon as the average value is within the limits again. Adjust the limits if necessary.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The SSD has detected an event (e.g. blocked impulse line). Check whether maintenance work is required.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The SSD is not active because the process conditions are too dynamic for reliable operation. If necessary, teach in a new baseline or adjust the sampling rate. The SSD is reactivated as soon as the average value of the raw signal is within the limits.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	The current signal noise is too small to activate the SSD.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

Status summary

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Status summary
Description	Baseline could not be created with following reasons: - There is not enough signal noise during building baseline phase. - There is a process change during building baseline phase.
User interface	<ul style="list-style-type: none">■ Deactivated■ Learning phase■ Monitoring inactive■ Monitoring active■ Monitoring active with event■ No baseline

System status

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → System status
User interface	<ul style="list-style-type: none">■ Idle■ No sufficient signal noise■ Stable■ Not stable■ Verify System Dynamics■ Process dynamic too high

Signal status

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Signal status
User interface	<ul style="list-style-type: none">■ Idle■ Building Baseline■ Verifying Baseline■ Verifying baseline failed■ Monitoring■ Out of range■ Monitoring inactive

Signal noise status

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Noise status
User interface	<ul style="list-style-type: none">■ Idle■ Building Baseline■ Verifying Baseline■ Verifying baseline failed■ Monitoring■ Out of range■ Monitoring inactive

Baseline build process

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Baseline process
User interface	0 to 100 %

Sample rate

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Sample rate
Description	Determines the sampling rate depending on the process conditions: "Fast" homogeneous stable process with Gauss distribution. "Medium" dynamic process "Slow" extremely dynamic variable process
Selection	<ul style="list-style-type: none">■ Fast■ Medium■ Slow

Counter Baseline creation SSD

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Counter Baseline
Description	Specifies how often the baseline has been rebuilt.
User interface	Positive integer

Baseline is available

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Configuration → Baseline avail.
Description	Indicates whether a baseline already exists.
User interface	<ul style="list-style-type: none">■ Please select■ No■ Yes

Signal status

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Signal status
User interface	<ul style="list-style-type: none">■ Idle■ Building Baseline■ Verifying Baseline■ Verifying baseline failed■ Monitoring■ Out of range■ Monitoring inactive

Current Baseline signal

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Curr. Baseline
Description	Current average of the raw signal.
User interface	Signed floating-point number

Baseline Signal Upper Control Line

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline S. UCL
Description	Upper limit for the average value of the raw signal. If the average value is above this limit, the SSD is inactive. Note: This parameter should not be greater than "Signal maximum value".
User entry	Signed floating-point number

Baseline Signal Control Line

Navigation	 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline S. CL
Description	Learned-in mean of the raw signal.
User interface	Signed floating-point number

Baseline Signal Lower Control Line

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline S. LCL
Description	Lower limit for the average value of the raw signal. If the average value is below this limit, the SSD is inactive. Note: This parameter should not be less than "Signal minimum value".
User entry	Signed floating-point number

Signal minimum value

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Minimum value
Description	Minimum mean of the raw signal during the learning phase.
User interface	Signed floating-point number

Signal maximum value

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Maximum value
Description	Maximum mean of the raw signal during the learning phase.
User interface	Signed floating-point number

Signal noise status

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Noise status
User interface	<ul style="list-style-type: none">■ Idle■ Building Baseline■ Verifying Baseline■ Verifying baseline failed■ Monitoring■ Out of range■ Monitoring inactive

Current Baseline noise

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Current noise
Description	Current signal noise (standard deviation) of the raw signal.
User interface	Signed floating-point number

Baseline Signal Noise Upper Control Line

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline SN. UCL
Description	Upper limit for the noise of the raw signal. If the noise is above this limit, the SSD is inactive. Note: This parameter should not be greater than "Signal noise maximum value".
User entry	Signed floating-point number

Baseline Signal Noise Control Line

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline SN. CL
Description	Learned-in noise of the raw signal.
User interface	Signed floating-point number

Baseline Signal Noise Lower Control Line

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline SN. LCL
Description	Lower limit for the noise of the raw signal. If the noise is below this limit, the SSD is inactive. Note: This parameter should not be less than "Signal noise minimum value".
User entry	Signed floating-point number

Baseline Signal Noise Minimum

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Baseline SN. Min
Description	Minimum value of the signal noise. Below this value, the SSD cannot be activated.
User entry	Signed floating-point number

Signal noise minimum value

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Min. noise value
Description	Minimum measured signal noise during the learning phase.
User interface	Signed floating-point number

Signal noise maximum value

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Monitoring → Max noise value
Description	Maximum measured signal noise during the learning phase.
User interface	Signed floating-point number

SSD Monitoring delay time

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Diag. settings → SSD Verz. Zeit
User entry	0 to 86 400 s

900 Event category

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Diag. settings → 900Event category
Description	Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior**Navigation**

 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Diag. settings → 900 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

SSD Out of range delay time**Navigation**

 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Diag. settings → SSD Delay time

User entry

0 to 604 800 s

906 Event category**Navigation**

 Guidance → Heartbeat Techn. → Stat. Sens. Diag → Diag. settings → 906Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

SSD: Statistical Sensor Diagnostics

Navigation	Guidance → Heartbeat Techn. → Stat. Sens. Diag → Activ./Deactiv. → Stat. Sens. Diag
Description	Enable or disable SSD. After selecting "Disable", no statistical sensor diagnosis takes place. No diagnostic messages are output.
Selection	<ul style="list-style-type: none">■ Disable■ Enable

I have read the warning texts.

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Configuration → warning texts
Description	The characterization of the electrical loop requires intermediate generation of a current output of 4 mA and 20 mA. Therefore, do not use the device in an active current loop during initialization of the Signal Loop Diagnostics.
Selection	Yes

Baseline status

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Baseline status
Description	"Failed" Means, baseline is not available or creation not possible. "Success" Baseline is available.
User interface	<ul style="list-style-type: none">■ Failed■ Success

Baseline build process

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Baseline process
User interface	0 to 100 %

Timestamp Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Timestamp BL
Description	Time stamp when the baseline was recorded (current-voltage curve). At this time, the upper terminal voltage (U1) was determined at 4 mA and the lower terminal voltage (U2) was determined at 20 mA.
User interface	Character string comprising numbers, letters and special characters

Resistance Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Resistance BL
Description	Displays the resistance value of the baseline (slope of the current-voltage curve).
User interface	Positive floating-point number

Supply voltage Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Supply volt. BL
Description	Displays the point from which the baseline is built (voltage at the point where the current-voltage curve is generated).
User interface	0.0 to 50.0 V

Timestamp previous Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Timestamp pre BL
Description	Time stamp when the previous baseline was recorded (current-voltage curve). At this time, the upper terminal voltage (U1) was determined at 4 mA and the lower terminal voltage (U2) was determined at 20 mA.
User interface	Character string comprising numbers, letters and special characters

Resistance previous Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Resist. pre. BL
Description	Displays the resistance value of the previous baseline (slope of the previous current-voltage curve).
User interface	Positive floating-point number

Supply voltage previous Baseline

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Configuration → Voltage pre. BL
Description	Displays the point from which the previous baseline is built (voltage at the point where the previous current-voltage curve was generated).
User interface	0.0 to 50.0 V

Tolerated deviation +/-

Navigation	 Guidance → Heartbeat Techn. → Loop diagn. → Monitoring → Toler. deviation
Description	A value should be chosen to ensure that normal voltage deviations do not lead to unwanted messages. Default 1.5 V DC
User entry	0.5 to 3.0 V

806 Event delay

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Diag. settings → 806 Event delay
Description	Displays how long the triggering status must be present until an event message is issued. Used to filter out short-term signal interference.
User entry	0 to 60 s

806 Event category

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Diag. settings → 806Event category
Description	Select category for diagnostic message.
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

806 Diagnostic behavior

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Diag. settings → 806 Diag. behav.
Description	Select event behavior "Logbook entry only": no digital or analog transmission of the message. "Warning": Current output unchanged. Message is output digitally (default). If the permissible conditions are reached again, the warning is no longer available in the instrument.
Selection	<ul style="list-style-type: none">■ Warning■ Logbook entry only

Loop diagnostics

Navigation	Guidance → Heartbeat Techn. → Loop diagn. → Activ./Deactiv. → Loop diagn.
Description	Enable/disable loop diagnostics. Note: If the function is disabled, there is no analysis and no event message.
Selection	<ul style="list-style-type: none">■ Disable■ Enable

500 Process alert pressure

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 500 Pressure
Description	Define whether user-defined pressure limits should be set. If "Off" is selected, no analysis will take place and no event message will be generated.
Selection	<ul style="list-style-type: none">■ Off■ On

Low alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → Low alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

High alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → High alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

Counter underruns of user limit Pmin

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → Counter < P user
Description	Counts how many times the value underruns the minimum values defined by the user. User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties menu.
User interface	0 to 65 535

Counter overruns of user limit Pmax

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → Counter > P user
Description	Counts how many times the value overruns the maximum values defined by the user. User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties menu.
User interface	0 to 65 535

500 Diagnostic behavior

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 500 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": no digital or analog transmission of the message</p> <p>"Warning": Current output unchanged. Message is output digitally (default).</p> <p>"Alarm": Current output assumes the set alarm current.</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only

500 Event category

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 500Event category
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)

501 Process alert scaled variable

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 501 Scaled var.
Description	<p>Define whether user-defined limits should be set. If "Off" is selected, no analysis will take place and no event message will be generated.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ On

Low alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → Low alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

High alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → High alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

501 Diagnostic behavior

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 501 Diag. behav.
Description	Select event behavior "Logbook entry only": no digital or analog transmission of the message "Warning": Current output unchanged. Message is output digitally (default). "Alarm": Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only

501 Event category

Navigation	Guidance → Heartbeat Techn. → Process window → Pressure range → 501Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

User temperature process alert

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → UserTemp alert
Description	Define whether the user-defined sensor temperature limits should be set. If "Off" no analysis and therefore no event message will take place.
Selection	<ul style="list-style-type: none">■ Off■ On

Low alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → Low alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	-50 to 150 °C

High alert value

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → High alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	-50 to 150 °C

Counter underruns of user limit Tmin

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → Counter < T user
User interface	0 to 65 535

Counter overruns of user limit Tmax

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → Counter > T user
User interface	0 to 65 535

502 Diagnostic behavior

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → 502 Diag. behav.
Description	Select event behavior "Logbook entry only": no digital or analog transmission of the message "Warning": Current output unchanged. Message is output digitally (default). "Alarm": Current output assumes the set alarm current. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only

502 Event category

Navigation	Guidance → Heartbeat Techn. → Process window → Temp. range → 502Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

3.2.3 "Safety mode" wizard

Navigation



Guidance → Safety mode

"Preparation" wizard

Navigation



Guidance → Safety mode → Preparation

I have read the warning texts.

Navigation



Guidance → Safety mode → Preparation → warning texts

Description

- Prior to using the wizard, read the Functional Safety Manual or the WHG documentation.
- In the wizard, safety-relevant parameter settings of the device will be shown.
- The user must confirm the correctness of these settings.
- By clicking "Finish" at the end of the wizard, the device is safety locked.
- A documentation of the safety-relevant parameter settings can be generated at the end of the wizard.
- The device can be unlocked via this wizard in case the device is safety locked.
- If the wizard is aborted, the device locking status will not be changed!

Selection

Yes

"Preparation" wizard

Navigation



Guidance → Safety mode → Preparation

Enter safety unlocking code



Navigation



Guidance → Safety mode → Preparation → Safe.unlock code

Description

The Safety locking/unlocking code can be found in the corresponding safety manual or the WHG documentation.

User entry

0 to 65 535

Locking status

Navigation



Guidance → Safety mode → Preparation → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

*Selection**Function scope of the "Locking status" parameter*

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

"Preparation" wizard*Navigation*

Guidance → Safety mode → Preparation

Proof test via Bluetooth allowed?**Navigation**

Guidance → Safety lock → Preparation → BLE proof test

Description

After completion of the Safety mode wizard, the device will be write protected via software lock.

To use the proof test wizard (optional), the device does not have to be unlocked.

It must be defined, if the proof test wizard via Bluetooth is allowed.

Selection

- No
- Yes

"Preparation" wizard

Navigation



Guidance → Safety lock → Preparation



Enter safety locking code

Navigation



Guidance → Safety lock → Preparation → Safety code

Description

Enter the locking code to start the SIL/WHG locking sequence.

User entry

0 to 65 535

Additional information

Locking codes

- WHG: 7450
- SIL: 7452
- SIL and WHG: 7454

"Preparation" wizard

Navigation



Guidance → Safety mode → Preparation



Character test string

Navigation



Guidance → Safety mode → Preparation → Char.test string

Description

The following character string is displayed:
0123456789+-,.

Set the "Confirm" parameter to "Yes" if this string is rendered correctly.
Set the "Confirm" parameter to "No" if this string is not rendered correctly. Safety locking is not possible in this case.

User interface

Character string comprising numbers, letters and special characters

Confirm



Navigation



Guidance → Safety mode → Preparation → Confirm

Description

The following character string is displayed:
0123456789+-,.

Set the "Confirm" parameter to "Yes" if this string is rendered correctly.
Set the "Confirm" parameter to "No" if this string is not rendered correctly. Safety locking is not possible in this case.

Selection

- No
- Yes

"Preparation" wizard*Navigation*

Guidance → Safety mode → Preparation

Device tag**Navigation**


Guidance → Safety mode → Preparation → Device tag

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Additional information*User interface*

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Device name**Navigation**

Guidance → Safety mode → Preparation → Device name

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Serial number

Navigation Guidance → Safety mode → Preparation → Serial number

Description Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information *Description*

**Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation Guidance → Safety mode → Preparation → Firmware version

Description Displays the device firmware version that is installed.

User interface Character string in the format xx.yy.zz

Additional information *User interface*



The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Hardware version

Navigation Guidance → Safety mode → Preparation → Hardware version

User interface Character string comprising numbers, letters and special characters

Confirm

Navigation Guidance → Safety mode → Preparation → Confirm

Description Confirm connection to the correct device.

Selection

- No
- Yes

"Preparation" wizard**Navigation**

Guidance → Safety mode → Preparation

CRC device configuration

Navigation

Guidance → Safety mode → Preparation → CRC device conf.

Description

CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.

User interface

0 to 65 535

Stored CRC device configuration

Navigation

Guidance → Safety mode → Preparation → Stored CRC conf.

Description

Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.

User interface

0 to 65 535

Timestamp stored CRC device config.

Navigation

Guidance → Safety mode → Preparation → Time stored CRC

Description

Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.

User interface

Character string comprising numbers, letters and special characters

Operating time

Navigation

Guidance → Safety mode → Preparation → Operating time

Description

Indicates how long the device has been in operation.

Additional information

Maximum time: 9 999 d (≈ 27 years)

Configuration counter

Navigation	 Guidance → Safety mode → Preparation → Config. counter
Description	<p>Displays the counter for changes to the device parameters.</p> <p>Additional information:</p> <ul style="list-style-type: none"> - If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions. - When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset. - Once the counter has reached the value 65535, it restarts at 0.
User interface	0 to 65 535

"Confirmation" wizard

Navigation  Guidance → Safety mode → Confirmation

Zero adjustment offset

Navigation	 Guidance → Safety mode → Confirmation → Zero offset  Guidance → Safety mode → Confirmation → Zero offset
Description	Assigned value of zero adjustment due to mounting position.
User interface	Character string comprising numbers, letters and special characters

HP/LP swap

Navigation	 Guidance → Safety mode → Confirmation → HP/LP swap
Description	Assigned setting high pressure / low pressure.
User interface	<ul style="list-style-type: none"> ■ No ■ Yes

Damping

Navigation  Guidance → Safety mode → Confirmation → Damping

Description Assigned damping value.

User interface Character string comprising numbers, letters and special characters

Sensor pressure range behavior

Navigation  Guidance → Safety mode → Confirmation → P-range behavior

Description Assigned event behavior in case of over/under pressure outside of measuring range.

User interface

- Alarm
- Warning
- Remark
- Special

Confirm



Navigation  Guidance → Safety mode → Confirmation → Confirm

 Guidance → Safety mode → Confirmation → Confirm

Selection

- No
- Yes

"Confirmation" wizard

Navigation  Guidance → Safety mode → Confirmation

Output current transfer function

Navigation  Guidance → Safety mode → Confirmation → Curr. trans.func

Description Assigned transfer function for current output.

NOTE

"Square root" is only available with differential pressure measurement.

User interface

- Linear
- Square root

Low cutoff

Navigation  Guidance → Safety mode → Confirmation → Low cutoff

User interface Character string comprising numbers, letters and special characters

Confirm

Navigation  Guidance → Safety mode → Confirmation → Confirm

Selection

- No
- Yes

**"Confirmation" wizard**

Navigation  Guidance → Safety mode → Confirmation

Measuring mode current output

Navigation  Guidance → Safety mode → Confirmation → Output mode

Description Assigned setting of curve form of current output.

User interface

- Standard
- Inverse
- Bi-directional

Failure behavior current output

Navigation  Guidance → Safety mode → Confirmation → Failure behav.

Description Assigned value of current output in case of an error.

User interface

- Min.
- Max.

Current range output

Navigation	 Guidance → Safety mode → Confirmation → Current range
Description	Assigned current range used to transmit the measured value.
User interface	<ul style="list-style-type: none">■ 4...20 mA (4...20.5 mA)■ 4...20 mA NE (3.8...20.5 mA)■ 4...20 mA US (3.9...20.8 mA)■ Customer specific

Lower range value output

Navigation	 Guidance → Safety mode → Confirmation → Low.range outp
Description	Assigned value 4 mA.
User interface	Character string comprising numbers, letters and special characters

Upper range value output

Navigation	 Guidance → Safety mode → Confirmation → Upp.range outp
Description	Assigned value 20 mA.
User interface	Character string comprising numbers, letters and special characters

Assign PV

Navigation	 Guidance → Safety mode → Confirmation → Assign PV
Description	Identifies the process variable linked with the primary variable. Primary variable is used in HART as current output.
User interface	<ul style="list-style-type: none">■ Pressure■ Scaled variable

Confirm

Navigation Guidance → Safety mode → Confirmation → Confirm

Selection

- No
- Yes

"Confirmation" wizard

Navigation Guidance → Safety mode → Confirmation

Zero adjustment offset

Navigation Guidance → Safety mode → Confirmation → Zero offset

Description Assigned value of zero adjustment due to mounting position.

User interface Character string comprising numbers, letters and special characters

Confirm

Navigation Guidance → Safety mode → Confirmation → Confirm

Selection

- No
- Yes

"Locking" wizard

Navigation Guidance → Safety mode → Locking

Enter safety locking code

Navigation Guidance → Safety mode → Locking → Safety code

Description Enter the locking code to start the SIL/WHG locking sequence.

User entry 0 to 65 535

Additional information**Locking codes**

- WHG: 7450
- SIL: 7452
- SIL and WHG: 7454

Locking status

Navigation

 Guidance → Safety mode → Locking → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

*Selection**Function scope of the "Locking status" parameter*

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Save protocol?

Navigation

 Guidance → Safety mode → Locking → Save protocol?

Description

The Report can be saved for archiving.

Selection

- No
- Yes

"Finish" wizard**Navigation** Guidance → Proof test → Finish

Inspector

Navigation

-  Guidance → Proof test → Finish → Inspector
-  Guidance → Safety mode → Result → Inspector

Description

The entered inspector name will be included in the report.

User entry

Character string comprising numbers, letters and special characters (96)

Location

Navigation

-  Guidance → Proof test → Finish → Location
-  Guidance → Safety mode → Result → Location

Description

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (96)

Date/time

Navigation

-  Guidance → Safety mode → Result → Date/time

User interface

Character string comprising numbers, letters and special characters

Notes

Navigation

-  Guidance → Proof test → Finish → Notes
-  Guidance → Safety mode → Result → Notes

Description

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (255)

Plant operator

- Navigation**
- Guidance → Proof test → Finish → Plant operator
 - Guidance → Safety mode → Result → Plant operator

Description The entered value will be included in the report.

User entry Character string comprising numbers, letters and special characters (96)

3.2.4 "Proof test" wizard

Navigation Guidance → Proof test

"Preparation Proof test" wizard

Navigation Guidance → Proof test → Prep. test

I have read the warning texts.

- Navigation** Guidance → Proof test → Prep. test → warning texts

Description Loss of Safety function of protective system using safety-related output signal 4 to 20 mA
- Read Functional safety manual or WHG documentation.
- Do not use safety-related output signal 4 to 20 mA for Safety function of protective system
- Suitable measures must be taken to guarantee process safety during the proof test

Selection Yes

"Preparation Proof test" wizard**Navigation**

Guidance → Proof test → Prep. test

Visual inspection

Navigation

Guidance → Proof test → Prep. test → Visual inspect.

Description

The visual inspection may include:

- Cable gland
- Wiring
- Terminal block
- Housing/ housing lid
- Mechanical and electrical installation

For further information refer to safety manual or WHG documentation.

Selection

- Please select
- Failed
- Passed

Notes

Navigation

Guidance → Proof test → Prep. test → Notes

Description

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (255)

"Preparation Proof test" wizard**Navigation**

Guidance → Proof test → Prep. test

Device tag

Navigation


Guidance → Proof test → Prep. test → Device tag

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Additional information*User interface*

A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Device name**Navigation**

█ Guidance → Proof test → Prep. test → Device name

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Serial number**Navigation**

█ Guidance → Proof test → Prep. test → Serial number

Description

Displays the serial number of the measuring device.

i The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Description***i Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version**Navigation**

█ Guidance → Proof test → Prep. test → Firmware version

Description

Displays the device firmware version that is installed.

User interface

Character string in the format xx.yy.zz

Additional information*User interface*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Hardware version

Navigation

Guidance → Proof test → Prep. test → Hardware version

User interface

Character string comprising numbers, letters and special characters

"Preparation Proof test" wizard*Navigation*

Guidance → Proof test → Prep. test

CRC device configuration

Navigation

Guidance → Proof test → Prep. test → CRC device conf.

Description

CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.

User interface

0 to 65 535

Stored CRC device configuration

Navigation

Guidance → Proof test → Prep. test → Stored CRC conf.

Description

Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.

User interface

0 to 65 535

Timestamp stored CRC device config.

Navigation

Guidance → Proof test → Prep. test → Time stored CRC

Description

Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.

User interface	Character string comprising numbers, letters and special characters
-----------------------	---

Operating time

Navigation	 Guidance → Proof test → Prep. test → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time: 9 999 d (≈ 27 years)

Configuration counter

Navigation	 Guidance → Proof test → Prep. test → Config. counter
Description	Displays the counter for changes to the device parameters. Additional information: <ul style="list-style-type: none">- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.- Once the counter has reached the value 65 535, it restarts at 0.
User interface	0 to 65 535

"Preparation Proof test" wizard**Navigation**

Guidance → Proof test → Prep. test

Select test procedure

Navigation

Guidance → Proof test → Prep. test → Select test proc

Description

The proof test of the device can be done using the following test procedures:

Test procedure A with wizard (PTC > 90%):

- Simulate and check the min and max alarm current.
- Approach and check the lower and upper measured value.
- Confirm safety function.

Test procedure B with wizard (PTC > 50%):

- Verify the current measured value with a plausibility check.
- Simulate and check the min and max alarm current.
- Confirm safety function.

For additional test procedures without wizard, refer to safety manual.

Selection

- Please select
- Test procedure A
- Test procedure B

Safety function?

Navigation

Guidance → Proof test → Prep. test → Safety function?

Selection

- Please select
- MAX monitoring
- MIN monitoring
- Range monitoring

"Simulation and check failure current" wizard**Navigation**

Guidance → Proof test → Simulation

Failure current (high alarm)

Navigation

Guidance → Proof test → Simulation → Fail. current (high alarm)

Description

Actually set value for high failure current.

User interface	21.5 to 23 mA
----------------	---------------

Confirm

Navigation	 Guidance → Proof test → Simulation → Confirm
------------	--

Description	Confirm that the displayed value corresponds to the set high failure current.
-------------	---

Selection	<ul style="list-style-type: none">■ Please select■ No■ Yes
-----------	--

(High) Is safety function triggered?

Navigation	 Guidance → Proof test → Simulation → (High)Funct. trigg?
------------	--

Description	Confirm that the output current triggers the required safety function.
-------------	--

Selection	Yes
-----------	-----

Terminal current (high alarm)

Navigation	 Guidance → Proof test → Simulation → Term. curr. (HA)
------------	---

Description	Internally readback terminal current (high alarm).
-------------	--

User interface	Signed floating-point number
----------------	------------------------------

Confirm

Navigation	 Guidance → Proof test → Simulation → Confirm
------------	--

Description	Confirm that the readback terminal current corresponds to the set high failure current within tolerance +-0,32mA.
-------------	---

Selection	<ul style="list-style-type: none">■ Please select■ No■ Yes
-----------	--

(Low) Is safety function triggered?

Navigation  Guidance → Proof test → Simulation → (Low)Funct. trigg?

Description Confirm that the output current triggers the required safety function.

Selection Yes

"Proof test" wizard

Navigation

 Guidance → Proof test → Proof test

Setpoint 1

Navigation  Guidance → Proof test → Proof test → Setpoint 1

Description Physically apply a reference pressure for upper range.

User entry Signed floating-point number

Pressure 1

Navigation  Guidance → Proof test → Proof test → Pressure 1

Description Pressure output

User interface Signed floating-point number

Terminal current 1

Navigation  Guidance → Proof test → Proof test → Terminal curr. 1

Description Terminal current for upper range.

User interface 0 to 30 mA

Current deviation 1

Navigation  Guidance → Proof test → Proof test → Curr. deviati 1

Description Decide if the terminal current for upper range corresponding to the applied pressure is within tolerance.

Selection

- Please select
- Failed
- Passed

Setpoint 2

Navigation  Guidance → Proof test → Proof test → Setpoint 2

Description Physically apply a reference pressure for lower range.

User entry Signed floating-point number

Pressure 2

Navigation  Guidance → Proof test → Proof test → Pressure 2

Description Pressure output

User interface Signed floating-point number

Terminal current 2

Navigation  Guidance → Proof test → Proof test → Terminal curr. 2

Description Terminal current for lower range.

User interface 0 to 30 mA

Current deviation 2

Navigation  Guidance → Proof test → Proof test → Curr. deviati 2

Description Decide if the terminal current for lower range corresponding to the applied pressure is within tolerance.

Selection

- Please select
- Failed
- Passed

"Finish" wizard*Navigation*

Guidance → Proof test → Finish

Active diagnostics

Navigation

Guidance → Proof test → Finish → Active diagnos.

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*User interface* Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu.*Example*

For the display format:

☒ F271 Main electronic failure

Summary

Navigation

Guidance → Proof test → Finish → Summary

User interface

- Passed
- Failed
- Unknown

Decision of inspector

Navigation

Guidance → Proof test → Finish → Decision of insp

DescriptionResponsible for the evaluation of the proof test is the inspector.
The summary displayed is not a binding inspection decision.

Selection

- Please select
- Failed
- Passed

Inspector

Navigation

█ Guidance → Proof test → Finish → Inspector

Description

The entered inspector name will be included in the report.

User entry

Character string comprising numbers, letters and special characters (96)

Location

Navigation

█ Guidance → Proof test → Finish → Location

Description

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (96)

Date/time proof test

Navigation

█ Guidance → Proof test → Finish → Date/time

Description

This value is updated with every proof test and with inspector decision „Passed“.

User interface

Character string comprising numbers, letters and special characters

Notes

Navigation

█ Guidance → Proof test → Finish → Notes

Description

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (255)

Plant operator

Navigation Guidance → Proof test → Finish → Plant operator**Description**

The entered value will be included in the report.

User entry

Character string comprising numbers, letters and special characters (96)

3.3 "Diagnostics" menu

Navigation  Diagnostics

3.3.1 "Active diagnostics" submenu

Navigation  Diagnostics → Active diagnos.

Active diagnostics

Navigation   Diagnostics → Active diagnos. → Active diagnos.

Prerequisite A diagnostic event has occurred.

Description Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *User interface*
 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu.

Example

For the display format:
☒ F271 Main electronic failure

Timestamp

Navigation   Diagnostics → Active diagnos. → Timestamp

Description Displays the operating time when the current diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*
 The diagnostic message can be viewed via the **Actual diagnostics** parameter
(→  103).

Example

For the display format:
24d12h13m00s

Previous diagnostics

Navigation	  Diagnostics → Active diagnos. → Prev.diagnostics
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Example</i> For the display format:  F271 Main electronic failure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  107). <i>Example</i> For the display format: 24d12h13m00s

Operating time from restart

Navigation	  Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	  Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time: 9 999 d (≈ 27 years)

3.3.2 "Event logbook" submenu

Navigation  Diagnostics → Event logbook

Filter options

Navigation	 Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the event list of the operating tool.
Selection	<ul style="list-style-type: none">■ All■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ Information (I)■ Not categorized
Additional information	<p><i>Description</i></p> <p> The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none">■ F = Failure■ C = Function Check■ S = Out of Specification■ M = Maintenance Required

Clear event list

Navigation	 Diagnostics → Event logbook → Clear event list
Description	Use this function to process the current values in the event logbook.
Selection	<ul style="list-style-type: none">■ Cancel■ Clear data

Additional information*Description*

Once this function has been executed, the events list is empty and all the events are deleted.



The events list can be exported using an operating tool (e.g. FieldCare).

3.3.3 "Minimum/maximum values" submenu

Navigation

Diagnostics → Min/max val.

Pressure min**Navigation**

Diagnostics → Min/max val. → Pressure min

Description

Minimum or maximum value measured by device.

User interface

Signed floating-point number

Counter limit underruns sensor Pmin**Navigation**

Diagnostics → Min/max val. → Counter P < Pmin

Description

Counts how many times the value underruns the sensor specific minimum values. Sensor specific minimum values are shown in Application/Sensor menu.

User interface

0 to 65 535

Counter underruns of user limit Pmin**Navigation**

Diagnostics → Min/max val. → Counter < P user

Description

Counts how many times the value underruns the minimum values defined by the user. User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties menu.

User interface

0 to 65 535

Minimum sensor temperature

Navigation	 Diagnostics → Min/max val. → Min. sensor temp
Description	Minimum or maximum value measured by device. Users cannot reset this value.
User interface	-273.15 to 9 726.85 °C

Counter limit underruns sensor Tmin

Navigation	 Diagnostics → Min/max val. → Counter T < Tmin
Description	Counts how many times the value underruns/overruns the sensor specific minimum/maximum values. Sensor specific minimum/maximum values are shown in Application/Sensor menu.
User interface	0 to 65 535

Counter underruns of user limit Tmin

Navigation	 Diagnostics → Min/max val. → Counter < T user
User interface	0 to 65 535

Minimum terminal voltage

Navigation	 Diagnostics → Min/max val. → Min.term.volt.
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V

Minimum electronics temperature

Navigation	 Diagnostics → Min/max val. → Min.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Reset user defined counters P and T**Navigation**

Diagnostics → Min/max val. → Reset count. P T

Selection

- Cancel
- Confirm

Pressure max**Navigation**

Diagnostics → Min/max val. → Pressure max

Description

Minimum or maximum value measured by device.

User interface

Signed floating-point number

Counter limit overruns sensor Pmax**Navigation**

Diagnostics → Min/max val. → Counter P > Pmax

DescriptionCounts how many times the value overruns the sensor specific maximum values.
Sensor specific maximum values are shown in Application/Sensor menu.**User interface**

0 to 65 535

Counter overruns of user limit Pmax**Navigation**

Diagnostics → Min/max val. → Counter > P user

DescriptionCounts how many times the value overruns the maximum values defined by the user.
User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties menu.**User interface**

0 to 65 535

Maximum sensor temperature**Navigation**

Diagnostics → Min/max val. → Max. sensor temp

DescriptionMinimum or maximum value measured by device.
Users cannot reset this value.**User interface**

-273.15 to 9 726.85 °C

Counter limit overruns sensor Tmax

Navigation  Diagnostics → Min/max val. → Counter T > Tmax**Description** Counts how many times the value underruns/overruns the sensor specific minimum/maximum values.
Sensor specific minimum/maximum values are shown in Application/Sensor menu.**User interface** 0 to 65 535**Counter overruns of user limit Tmax**

Navigation  Diagnostics → Min/max val. → Counter > T user**User interface** 0 to 65 535**Maximum terminal voltage**

Navigation  Diagnostics → Min/max val. → Max.term.voltage**Description** Minimum or maximum measured terminal (supply) voltage.**User interface** 0.0 to 50.0 V**Maximum electronics temperature**

Navigation  Diagnostics → Min/max val. → Max.electr.temp.**Description** Minimum or maximum measured main electronics temperature.**User interface** Signed floating-point number

3.3.4 "Simulation" submenu

Navigation

█ Diagnostics → Simulation

Simulation



Navigation

█ █ Diagnostics → Simulation → Simulation

Description

Simulates one or more process variables and/or events.

Warning:

Output will reflect the simulated value or event.

Selection

- Off
- Current output
- Diagnostic event simulation
- Pressure

Value pressure simulation



Navigation

█ █ Diagnostics → Simulation → Pressure

User entry

Signed floating-point number

Value current output



Navigation

█ █ Diagnostics → Simulation → Current output

Description

Defines the value of the simulated output current.

User entry

3.59 to 23 mA

Diagnostic event simulation



Navigation

█ █ Diagnostics → Simulation → Diagnostic event

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Additional information*Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter.

3.3.5 "Heartbeat Technology" submenu

Navigation

Diagnostics → Heartbeat Techn.

"Heartbeat Verification" submenu

Navigation

Diagnostics → Heartbeat Techn. → Heartbeat Verif.

Date/time Heartbeat Verification

Navigation

Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification

Description

Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.

User interface

Character string comprising numbers, letters and special characters

Operating time (Verification)

Navigation

Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time

User interface

Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation

Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Verific. result

User interface

- Not done
- Passed
- Not done
- Failed

Status

Navigation   Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status

Description Displays the current status of the verification.

User interface

- Done
- Busy
- Failed
- Not done

"Loop diagnostics" submenu

Navigation   Diagnostics → Heartbeat Techn. → Loop diagn.

Rebuild baseline



Navigation   Diagnostics → Heartbeat Techn. → Loop diagn. → Reb. baseline

Description Notice
The current output is simulated.
Bridge the PLC or take other appropriate measures to prevent an erroneous triggering of alarm messages or changes in the control loop behavior.
The baseline should be rebuilt if planned changes have been made in the loop.

Selection

- No
- Yes

Tolerated deviation +/-



Navigation   Diagnostics → Heartbeat Techn. → Loop diagn. → Toler. deviation

Description A value should be chosen to ensure that normal voltage deviations do not lead to unwanted messages.

Default
1.5 V DC

User entry 0.5 to 3.0 V

Baseline status

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Baseline status

Description
"Failed"
Means, baseline is not available or creation not possible.
"Success"
Baseline is available.

User interface
■ Failed
■ Success

Loop diagnostics



Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Loop diagn.

Description
Enable/disable loop diagnostics.
Note:
If the function is disabled, there is no analysis and no event message.

Selection
■ Disable
■ Enable

Terminal voltage 1

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Terminal volt. 1

Description
Shows the current terminal voltage that is applied at the output

User interface
0.0 to 50.0 V

Clamping voltage lower threshold

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Lower threshold

User interface
0.0 to 50.0 V

Clamping voltage upper threshold

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Upper threshold

User interface
0.0 to 50.0 V

806 Event delay

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → 806 Event delay

Description Displays how long the triggering status must be present until an event message is issued. Used to filter out short-term signal interference.

User entry 0 to 60 s

"Statistical Sensor Diagnostics" submenu

Navigation Diagnostics → Heartbeat Techn. → SSD

SSD: Statistical Sensor Diagnostics

Navigation Diagnostics → Heartbeat Techn. → SSD → Stat. Sens. Diag

Description Enable or disable SSD.

After selecting "Disable", no statistical sensor diagnosis takes place. No diagnostic messages are output.

Selection
■ Disable
■ Enable

System status

Navigation Diagnostics → Heartbeat Techn. → SSD → System status

User interface
■ Idle
■ No sufficient signal noise
■ Stable
■ Not stable
■ Verify System Dynamics
■ Process dynamic too high

Signal status

Navigation Diagnostics → Heartbeat Techn. → SSD → Signal status

User interface
■ Idle
■ Building Baseline
■ Verifying Baseline

- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Signal noise status

Navigation Diagnostics → Heartbeat Techn. → SSD → Noise status**User interface**

- Idle
- Building Baseline
- Verifying Baseline
- Verifying baseline failed
- Monitoring
- Out of range
- Monitoring inactive

Counter Baseline creation SSD

Navigation Diagnostics → Heartbeat Techn. → SSD → Counter Baseline**Description**

Specifies how often the baseline has been rebuilt.

User interface

Positive integer

3.3.6 "Diagnostic settings" submenu

Navigation Diagnostics → Diag. settings

"Properties" submenu

Navigation Diagnostics → Diag. settings → Properties

SSD Out of range delay time

**Navigation** Diagnostics → Diag. settings → Properties → SSD Delay time**User entry**

0 to 604 800 s

SSD Monitoring delay time

Navigation	Diagnostics → Diag. settings → Properties → SSD Verz. Zeit
User entry	0 to 86 400 s

500 Process alert pressure

Navigation	Diagnostics → Diag. settings → Properties → 500 Pressure
Description	Define whether user-defined pressure limits should be set. If "Off" is selected, no analysis will take place and no event message will be generated.
Selection	<ul style="list-style-type: none">■ Off■ On

Low alert value

Navigation	Diagnostics → Diag. settings → Properties → Low alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

High alert value

Navigation	Diagnostics → Diag. settings → Properties → High alert value
Description	Set range. If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.
User entry	Signed floating-point number

501 Process alert scaled variable

Navigation	Diagnostics → Diag. settings → Properties → 501 Scaled var.
Description	Define whether user-defined limits should be set. If "Off" is selected, no analysis will take place and no event message will be generated.

Selection

- Off
- On

Low alert value**Navigation**

█ Diagnostics → Diag. settings → Properties → Low alert value

Description

Set range.

If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry

Signed floating-point number

High alert value**Navigation**

█ Diagnostics → Diag. settings → Properties → High alert value

Description

Set range.

If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry

Signed floating-point number

User temperature process alert**Navigation**

█ Diagnostics → Diag. settings → Properties → UserTemp alert

Description

Define whether the user-defined sensor temperature limits should be set. If "Off" no analysis and therefore no event message will take place.

Selection

- Off
- On

Low alert value**Navigation**

█ Diagnostics → Diag. settings → Properties → Low alert value

Description

Set range.

If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry

-50 to 150 °C

High alert value

Navigation Diagnostics → Diag. settings → Properties → High alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry -50 to 150 °C

806 Diagnostic behavior

Navigation Diagnostics → Diag. settings → Properties → 806 Diag. behav.

Description Select event behavior
"Logbook entry only": no digital or analog transmission of the message.
"Warning": Current output unchanged. Message is output digitally (default).
If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection ■ Warning
■ Logbook entry only

806 Event category

Navigation Diagnostics → Diag. settings → Properties → 806Event category

Description Select category for diagnostic message.

Selection ■ Failure (F)
■ Function check (C)
■ Out of specification (S)
■ Maintenance required (M)
■ No effect (N)

806 Event delay

Navigation Diagnostics → Diag. settings → Properties → 806 Event delay

Description Displays how long the triggering status must be present until an event message is issued.
Used to filter out short-term signal interference.

User entry 0 to 60 s

"Configuration" submenu*Navigation*

Diagnostics → Diag. settings → Configuration → Configuration

500 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 500 Diag. behav.

Description

Select event behavior

"Logbook entry only":

no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

500 Event category**Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 500Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

501 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 501 Diag. behav.

Description

Select event behavior

"Logbook entry only":

no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

501 Event category**Navigation**

■ ■ Diagnostics → Diag. settings → Configuration → Configuration → 501Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

502 Diagnostic behavior**Navigation**

■ ■ Diagnostics → Diag. settings → Configuration → Configuration → 502 Diag. behav.

Description

Select event behavior

"Logbook entry only":
no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

502 Event category**Navigation**

■ ■ Diagnostics → Diag. settings → Configuration → Configuration → 502Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

"Process" submenu**Navigation**

Diagnostics → Diag. settings → Configuration → Process

**806 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

**806 Event category****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

**822 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

User interface

- Alarm
- Warning
- Logbook entry only

822 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 822 Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

Sensor pressure range behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → P-range behavior
Description	Select event behavior "Alarm": Current output adopts the set alarm current. "Warning": Current output unchanged. Message is displayed digitally (factory setting). "Logbook entry only": No digital or analog forwarding of the message. "Special": – Lower sensor limit undercut: Current output < 3.6 mA. – Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.
Selection	<ul style="list-style-type: none">■ Alarm■ Warning■ Logbook entry only■ Special

841 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 841 Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

900 Event category**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 900Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

906 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Warning
- Logbook entry only

906 Event category**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 906Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

"Process" submenu**Navigation**

Diagnostics → Diag. settings → Configuration → Process

**806 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

**806 Event category****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

822 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

User interface

- Alarm
- Warning
- Logbook entry only

822 Event category**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → 822 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Sensor pressure range behavior**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → P-range behavior

Description

Select event behavior

"Alarm":

Current output adopts the set alarm current.

"Warning":

Current output unchanged. Message is displayed digitally (factory setting).

"Logbook entry only":

No digital or analog forwarding of the message.

"Special":

– Lower sensor limit undercut: Current output < 3.6 mA.

– Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.

Selection

- Alarm
- Warning
- Logbook entry only
- Special

841 Event category**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → 841 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 900Event category
Description	Select category for diagnostic message.
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

900 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": no digital or analog transmission of the message.</p> <p>"Warning": Current output unchanged. Message is output digitally (default).</p> <p>If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none">■ Warning■ Logbook entry only

906 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": no digital or analog transmission of the message.</p> <p>"Warning": Current output unchanged. Message is output digitally (default).</p> <p>If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none">■ Off■ Warning■ Logbook entry only

906 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 906Event category
Description	Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

3.4 "Application" menu

Navigation

Application

3.4.1 "Measuring units" submenu

Navigation

Application → Measuring units

Pressure unit



Navigation

Application → Measuring units → Pressure unit

Selection

SI units

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

Decimal places pressure



Navigation

Application → Measuring units → Decimal pressure

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- Automatic

The decimal place is configured automatically.

Example: Unit mbar: one decimal place. Unit bar: four decimal places

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Temperature unit



Navigation

Application → Measuring units → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection	SI units	US units
	<input checked="" type="checkbox"/> °C	°F
	<input checked="" type="checkbox"/> K	
Factory setting	Country-specific: <input checked="" type="checkbox"/> °C <input checked="" type="checkbox"/> °F	
Additional information	<i>Selection</i>	

Scaled variable unit

Navigation Application → Measuring units → Scaled Unit

Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ %	■ ft	■ gal (imp)	
■ mm	■ in	■ gal/s (imp)	
■ cm	■ ft ³	■ gal/min (imp)	
■ m	■ gal (us)	■ gal/h (imp)	
■ l	■ bbl (us;oil)		
■ hl	■ oz		
■ m ³	■ lb		
■ g	■ STon		
■ kg	■ lb/s		
■ t	■ lb/min		
■ g/s	■ lb/h		
■ kg/s	■ STon/min		
■ kg/min	■ STon/h		
■ kg/h	■ STon/d		
■ t/min	■ ft ³ /s		
■ t/h	■ ft ³ /min		
■ t/d	■ ft ³ /h		
■ m ³ /s	■ ft ³ /d		
■ m ³ /min	■ gal/s (us)		
■ m ³ /h	■ gal/min (us)		
■ m ³ /d	■ gal/h (us)		
■ l/s	■ gal/d (us)		
■ l/min	■ bbl/s (us;oil)		
■ l/h	■ bbl/min (us;oil)		
■ Nm ³ /h	■ bbl/h (us;oil)		
■ NI/h	■ bbl/d (us;oil)		
■ Sm ³ /s	■ Sft ³ /min		
■ Sm ³ /min	■ Sft ³ /h		
■ Sm ³ /h	■ Sft ³ /d		
■ Sm ³ /d			
■ Nm ³ /s			
■ g/cm ³			
■ kg/m ³			
■ Nm ³ /min			
■ Nm ³ /d			
<i>Custom-specific units</i>			
Free text			

Free text**Navigation**

Application → Measuring units → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Decimal places scaled variable**Navigation**

Application → Measuring units → Decimal scaled

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

3.4.2 "Measured values" submenu

Navigation

Application → Measured values

Sensor pressure

Navigation

Application → Measured values → Sensor pressure

User interface

Signed floating-point number

Pressure

Navigation

Application → Measured values → Pressure

Scaled variable

Navigation

Application → Measured values → Scaled variable

User interface

Signed floating-point number

Sensor temperature

Navigation

Application → Measured values → Sensor temp.

User interface

-273.15 to 9 726.85 °C

Terminal voltage 1

Navigation

Application → Measured values → Terminal volt. 1

Description

Shows the current terminal voltage that is applied at the output

User interface	0.0 to 50.0 V
-----------------------	---------------

Terminal current

Navigation	 Application → Measured values → Terminal curr.
-------------------	--

Description	Shows the current value of the current output which is currently measured
--------------------	---

User interface	0 to 30 mA
-----------------------	------------

Electronics temperature

Navigation	 Application → Measured values → Electronics temp
-------------------	--

Description	Displays the current temperature of the main electronics.
--------------------	---

User interface	Signed floating-point number
-----------------------	------------------------------

3.4.3 "Sensor" submenu

Navigation  Application → Sensor

"Basic settings" submenu

Navigation  Application → Sensor → Basic settings

Output current transfer function

Navigation	 Application → Sensor → Basic settings → Curr. trans.func
-------------------	--

Description	Linear The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. Square root - differential pressure only The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.
--------------------	--

User interface

- Linear
- Square root *

Damping**Navigation**

Application → Sensor → Basic settings → Damping

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own “Damping” parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry

0 to 999.0 s

"Sensor calibration" submenu**Navigation**

Application → Sensor → Sensor cal.

**Zero adjustment****Navigation**

Application → Sensor → Sensor cal. → Zero adjustment

Description

Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Calibration offset**Navigation**

Application → Sensor → Sensor cal. → Calibr offset

Prerequisite

Absolute pressure sensor

* Visibility depends on order options or device settings

Description Enter the value by which the measured value should be corrected, e.g., a position adjustment for absolute pressure sensors.

User entry Signed floating-point number

Zero adjustment offset



Navigation Application → Sensor → Sensor cal. → Zero offset

User entry Signed floating-point number

Sensor Trim Reset



Navigation Application → Sensor → Sensor cal. → Sen. Trim Reset

Selection
■ No
■ Confirm

Lower sensor trim measured value

Navigation Application → Sensor → Sensor cal. → LowerTrimMeasVal

User interface Signed floating-point number

Lower sensor trim**Navigation**

Application → Sensor → Sensor cal. → LowerSensor trim

Description

These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.

Note:

The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).

Proceed as follows:

- Apply reference pressure for lower range value ("LRV")
- Enter the measured reference pressure at "Lower sensor trim" and confirm
- Apply reference pressure for upper range value ("URV")
- Enter the measured reference pressure at "Upper sensor trim" and confirm
- The sensor is now calibrated

User entry

Signed floating-point number

Upper sensor trim measured value**Navigation**

Application → Sensor → Sensor cal. → UpperTrimMeasVal

User interface

Signed floating-point number

Upper sensor trim**Navigation**

Application → Sensor → Sensor cal. → UpperSensor trim

Description

These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.

Note:

The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).

Proceed as follows:

- Apply reference pressure for lower range value ("LRV")
- Enter the measured reference pressure at "Lower sensor trim" and confirm
- Apply reference pressure for upper range value ("URV")
- Enter the measured reference pressure at "Upper sensor trim" and confirm
- The sensor is now calibrated

User entry

Signed floating-point number

"Sensor limits" submenu**Navigation**

Application → Sensor → Sensor limits

Lower Range Limit**Navigation**

Application → Sensor → Sensor limits → LRL

Description

Indicates the lower measuring limit of the sensor.

User interface

Signed floating-point number

Upper Range Limit**Navigation**

Application → Sensor → Sensor limits → URL

Description

Indicates the upper measuring limit of the sensor.

User interface

Signed floating-point number

Minimum span

Navigation	 Application → Sensor → Sensor limits → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

Sensor temperature lower range limit

Navigation	 Application → Sensor → Sensor limits → Sens.temp.lo.lim
User interface	-273.15 to 9 726.85 °C

Sensor temperature upper range limit

Navigation	 Application → Sensor → Sensor limits → Sens.temp.up.lim
User interface	-273.15 to 9 726.85 °C

"Scaled variable" submenu

Navigation  Application → Sensor → Scaled variable

Assign PV



Navigation   Application → Sensor → Scaled variable → Assign PV

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Scaled variable unit**Navigation**

Application → Sensor → Scaled variable → Scaled Unit

Description

Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection*SI units*

- %
- mm
- cm
- m
- l
- hl
- m³
- g
- kg
- t
- g/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- m³/s
- m³/min
- m³/h
- m³/d
- l/s
- l/min
- l/h
- Nm³/h
- Nl/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

US units

- ft
- in
- ft³
- gal (us)
- bbl (us;oil)
- oz
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)

Custom-specific units

Free text

Free text**Navigation**

Application → Sensor → Scaled variable → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Pressure

Navigation

 Application → Sensor → Scaled variable → Pressure

Scaled variable transfer function



Navigation

 Application → Sensor → Scaled variable → Scaled function

Description

"Linear"

The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.

"Square root" (Deltabar)

The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table"

The output is defined according to the scaled variable / pressure table entered.

Selection

- Linear
- Square root *
- Table

Lower range value output



Navigation

 Application → Sensor → Scaled variable → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output



Navigation

 Application → Sensor → Scaled variable → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

* Visibility depends on order options or device settings

Activate table

Navigation Application → Sensor → Scaled variable → Activate table

Selection

- Disable
- Enable

Pressure value 1

Navigation Application → Sensor → Scaled variable → Pressure 1

Description Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry Signed floating-point number

Scaled variable value 1

Navigation Application → Sensor → Scaled variable → Scaled 1

Description Enter value for the first scaling point. This value is allocated to "Pressure value 1".

User interface Signed floating-point number

Pressure value 2

Navigation Application → Sensor → Scaled variable → Pressure 2

Description Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry Signed floating-point number

Scaled variable value 2

Navigation Application → Sensor → Scaled variable → Scaled 2

Description Enter value for the second scaling point. This value is allocated to "Pressure value 2".

User entry Signed floating-point number

Pressure**Navigation**

Application → Sensor → Scaled variable → Pressure

User entry

Signed floating-point number

Scaled variable**Navigation**

Application → Sensor → Scaled variable → Scaled variable

User entry

Signed floating-point number

"Wet calibration" submenu**Navigation**

Application → Sensor → Wet calibration

Zero**Navigation**

Application → Sensor → Wet calibration → Zero

Selection

- No
- Confirm

Pressure value 1**Navigation**

Application → Sensor → Wet calibration → Pressure 1

Description

Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry

Signed floating-point number

Span**Navigation**

Application → Sensor → Wet calibration → Span

Selection

- No
- Confirm

Pressure value 2

Navigation Application → Sensor → Wet calibration → Pressure 2

Description Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry Signed floating-point number

Lower range value output

Navigation Application → Sensor → Wet calibration → Low.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Upper range value output

Navigation Application → Sensor → Wet calibration → Upp.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

"Wet calibration" submenu

Navigation Application → Sensor → Wet calibration

Zero

Navigation Application → Sensor → Wet calibration → Zero

Selection
■ No
■ Confirm

Pressure value 1**Navigation**

Application → Sensor → Wet calibration → Pressure 1

Description

Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry

Signed floating-point number

Span**Navigation**

Application → Sensor → Wet calibration → Span

Selection

- No
- Confirm

Pressure value 2**Navigation**

Application → Sensor → Wet calibration → Pressure 2

Description

Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry

Signed floating-point number

Lower range value output**Navigation**

Application → Sensor → Wet calibration → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**

Application → Sensor → Wet calibration → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry	Signed floating-point number
------------	------------------------------

3.4.4 "Current output" submenu

Navigation



Application → Curr.output

Assign PV



Navigation



Application → Curr.output → Assign PV

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Measuring mode current output



Navigation



Application → Curr.output → Output mode

Description

Select curve of current output.

Selection

- Standard
- Inverse
- Bi-directional

Current range output



Navigation



Application → Curr.output → Current range

Description

Defines the current range used to transmit the measured or calculated value. In brackets are indicated the “low saturation value” and the “high saturation value”. If Measured value \leq “low saturation”, the output current is set to “low saturation”. If Measured value \geq “high saturation”, the output current is set to “high saturation”.

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output**Navigation**

Application → Curr.output → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**

Application → Curr.output → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Failure behavior current output**Navigation**

Application → Curr.output → Failure behav.

Description

Defines which current the output assumes in the case of an error.

Min: < 3.6 mA

Max: >21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current**Navigation**

Application → Curr.output → Failure current

Description

Enter current output value in alarm condition

User entry

21.5 to 23 mA

Output current

Navigation  Application → Curr.output → Output curr.

Description Shows the value currently calculated for the current output

User interface 3.59 to 23 mA

Terminal current

Navigation  Application → Curr.output → Terminal curr.

Description Shows the current value of the current output which is currently measured

User interface 0 to 30 mA

4 mA trim value

Navigation  Application → Curr.output → 4 mA trim value

Description Enter the trim value for the 4 mA current output.

Note:
Simulation must be active.

User entry 3 to 5 mA

20 mA trim value

Navigation  Application → Curr.output → 20 mA trim value

Description Enter the trim value for the 20 mA current output.

Note:
Simulation must be active.

User entry 18 to 22 mA

3.4.5 "HART output" submenu

Navigation  Application → HART output

"Configuration" submenu

Navigation  Application → HART output → Configuration

HART address



Navigation   Application → HART output → Configuration → HART address

Description Define the HART address of the device.

User entry 0 to 63

Additional information

- The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode).
- Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0.
- All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.

HART short tag



Navigation   Application → HART output → Configuration → HART short tag

Description Defines the short tag for the measuring point.

Maximum length: 8 characters
Allowed characters: A-Z, 0-9, certain special characters

User entry Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

Device tag



Navigation   Application → HART output → Configuration → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

No. of preambles

Navigation Application → HART output → Configuration → No. of preambles

Description Defines the number of preambles in the HART telegram

User entry 5 to 20

Loop current mode

Navigation Application → HART output → Configuration → Loop curr mode

Description If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications.
In this mode the output current is fixed.

Selection

- Disable
- Enable

"HART output" submenu

Navigation Application → HART output → HART output

Assign PV

Navigation Application → HART output → HART output → Assign PV

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Primary variable (PV)

Navigation Application → HART output → HART output → Primary var (PV)

Description Shows the first HART value (PV).

Additional information

Assign SV**Navigation**

Application → HART output → HART output → Assign SV

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current ^{*}
- Terminal voltage ^{*}
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}
- Signal noise detected ^{*}
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Secondary variable (SV)**Navigation**

Application → HART output → HART output → Second.var(SV)

Description

Shows the second HART value (SV).

Assign TV**Navigation**

Application → HART output → HART output → Assign TV

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

* Visibility depends on order options or device settings

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Tertiary variable (TV)**Navigation**
 Application → HART output → HART output → Tertiary var(TV)
Description

Shows the third HART value (TV).

Assign QV**Navigation**
  Application → HART output → HART output → Assign QV
Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *

* Visibility depends on order options or device settings

- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
 - 0 % - Signal noise is within the permissible range.
 - 100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Quaternary variable (QV)

Navigation

Application → HART output → HART output → Quaterna.var(QV)

Description

Shows the fourth value (QV).

"Burst configuration 1" submenu

Navigation Application → HART output → Burst config. 1

Burst mode 1**Navigation**

Application → HART output → Burst config. 1 → Burst mode 1

Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Additional information*Selection*

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Burst command 1**Navigation**

Application → HART output → Burst config. 1 → Burst command 1

Description

Use this function to select the HART command that is sent to the HART master.

Selection

- Primary variable (PV)
- Loop Current and Percent of Range
- Dynamic Variables
- Device variables with status
- Device variables
- Additional device status

Additional information*Selection*

- Command 1
Read out the primary variable.
- Command 2
Read out the current and the main measured value as a percentage.
- Command 3
Read out the dynamic HART variables and the current.
- Command 9
Read out the dynamic HART variables including the related status.
- Command 33
Read out the dynamic HART variables including the related unit.
- Command 48
Read out the complete device diagnostics.

"Command 33" option

The HART device variables are defined via Command 107.

Commands

- Information about the defined details of the command: HART specifications
▪ The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu.

Burst variable 0**Navigation**

Application → HART output → Burst config. 1 → Burst variable 0

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Measured current^{*}
- Terminal voltage 1^{*}
- Median of pressure signal^{*}
- Noise of pressure signal^{*}

* Visibility depends on order options or device settings

- Signal noise detected *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Additional information*Selection*

If a burst message is not configured, the **Not used** option is set.

Burst variable 1**Navigation**

Application → HART output → Burst config. 1 → Burst variable 1

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 2**Navigation**

Application → HART output → Burst config. 1 → Burst variable 2

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 3**Navigation**

Application → HART output → Burst config. 1 → Burst variable 3

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 4**Navigation**

Application → HART output → Burst config. 1 → Burst variable 4

Description

For HART command 9: select the HART device variable or the process variable.

* Visibility depends on order options or device settings

Selection Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 5

Navigation Application → HART output → Burst config. 1 → Burst variable 5

Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 6

Navigation Application → HART output → Burst config. 1 → Burst variable 6

Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→ 155).

Burst variable 7

Navigation Application → HART output → Burst config. 1 → Burst variable 7

Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→ 155).

Burst trigger mode

Navigation Application → HART output → Burst config. 1 → Trigger mode

Description Use this function to select the event that triggers burst message X.

Selection

- Continuous
- Window *
- Rising *
- Falling *
- On change

* Visibility depends on order options or device settings

Additional information*Selection*

- Continuous
The message is sent continuously, at least at intervals corresponding to the time frame specified in the **Burst min period** parameter (→ 158).
- Window
The message is sent if the specified measured value has changed by the value in the **Burst trigger level** parameter (→ 158).
- Rising
The message is sent if the specified measured value exceeds the value in the **Burst trigger level** parameter (→ 158).
- Falling
The message is sent if the specified measured value drops below the value in the **Burst trigger level** parameter (→ 158).
- On change
The message is sent if a measured value changes in the burst message.

Burst trigger level**Navigation**

Application → HART output → Burst config. 1 → Trigger level

Description

Use this function to enter the burst trigger value.

User entry

Signed floating-point number

Additional information*Description*

Together with the option selected in the **Burst trigger mode** parameter (→ 157) the burst trigger value determines the time of burst message X.

Min. update period**Navigation**

Application → HART output → Burst config. 1 → Min. upd. per.

Description

Use this function to enter the minimum time span between two burst commands of burst message X.

User entry

Positive integer

Max. update period**Navigation**

Application → HART output → Burst config. 1 → Max. upd. per.

Description

Use this function to enter the maximum time span between two burst commands of burst message X.

User entry

Positive integer

"Information" submenu**Navigation**

Application → HART output → Information

Device ID

Navigation

Application → HART output → Information → Device ID

Description

Use this function to view the device ID for identifying the measuring device in a HART network.

User interface

6-digit hexadecimal number

Additional information*Description*

In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation

Application → HART output → Information → Device type

Description

Displays the device type with which the measuring device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Factory setting

0x54

Factory setting

0x5A

Additional information*Description*

The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Device revision

Navigation

Application → HART output → Information → Device revision

Description

Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Additional information*Description*

The device revision is needed to assign the appropriate device description file (DD) to the device.

HART short tag**Navigation**

Application → HART output → Information → HART short tag

Description

Defines the short tag for the measuring point.

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

HART revision**Navigation**

Application → HART output → Information → HART revision

Description

Shows the HART revision of the device.

HART descriptor**Navigation**

Application → HART output → Information → HART descriptor

Description

Description for the measuring point.

User entry

Character string comprising numbers, letters and special characters (16)

HART message**Navigation**

Application → HART output → Information → HART message

Description

A HART message which is sent via the HART protocol when requested by the master.

User entry

Character string comprising numbers, letters and special characters (32)

HART date code**Navigation**

Application → HART output → Information → HART date code

Description

Date of the last configuration change

User entry

Character string comprising numbers, letters and special characters (10)

Additional information

Date format: YYYY-MM-DD

Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

3.5 "System" menu

Navigation  System

3.5.1 "Device management" submenu

Navigation  System → Device manag.

Device tag



Navigation   System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Locking status

Navigation   System → Device manag. → Locking status

Description Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information *User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Configuration counter

Navigation
 System → Device manag. → Config. counter

Description

Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65535, it restarts at 0.

User interface

0 to 65 535

Reset device


Navigation
 System → Device manag. → Reset device

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to its factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

* Visibility depends on order options or device settings

3.5.2 "User management" submenu

Navigation

 System → User manag.

User role

Navigation

  System → User manag. → User role

Description

Displays the access authorization to the parameters via the operating tool.

User interface

- Operator
- Maintenance
- Expert

Additional information

Description

 Access authorization can be modified via the **Enter access code** parameter.

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Password

Navigation

 System → User manag. → Password

Description

Enter the password for the "Maintenance" user role to get access to the functionality of this role.

User entry

Character string comprising numbers, letters and special characters (16)

Enter access code



Navigation

 System → User manag. → Ent. access code

Description

Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.

User entry

0 to 9 999

Status password entry

Navigation  System → User manag. → Status pw entry**Description** Use this function to display the status of the password verification.**User interface**

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

New password

Navigation  System → User manag. → New password**Description** Define the new "Maintenance" password.
A new password is valid after it has been confirmed within the "Confirm new password" parameter.
Any valid password consists of 4 to 16 characters and can contain letters and numbers.**User entry** Character string comprising numbers, letters and special characters (16)

Confirm new password

Navigation  System → User manag. → Confirm password**Description** Enter the new password again to confirm.**User entry** Character string comprising numbers, letters and special characters (16)

Old password

Navigation  System → User manag. → Old password**Description** Enter the current password, to subsequently change the existing password.**User entry** Character string comprising numbers, letters and special characters (16)

Reset password

Navigation System → User manag. → Reset password**Description**

Enter a code to reset the current "Maintenance" password.
The code is delivered by your local support.

User entry

Character string comprising numbers, letters and special characters (16)

3.5.3 "Bluetooth configuration" submenu

Navigation

 System → Bluetooth conf.

Bluetooth activation

Navigation System → Bluetooth conf. → Bluetooth active**Description**

If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool.
Reactivating via the SmartBlue app is not possible.

Selection

- Disable
- Enable

3.5.4 "Display" submenu

Navigation

 System → Display

Language

Navigation System → Display → Language**Prerequisite**

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands

- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- Bahasa Indonesia
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting	English (alternatively, the ordered language is preset in the device)
------------------------	---

Format display

Navigation	 System → Display → Format display
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values
Additional information	<p><i>Description</i></p> <p>The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.</p> <p> ■ The Value 1 display parameter (→ 167)...Value 8 display parameter Value 4 display parameter (→ 169) are used to specify which measured values are shown on the local display and in what order.</p> <p>■ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the Display interval parameter.</p>

Value 1 display

Navigation	 System → Display → Value 1 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 167) is used to specify how many measured values are displayed simultaneously and how.

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu.

Value 2 display**Navigation**

  System → Display → Value 2 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

- None
- Pressure
- Scaled variable
- Current output
- Sensor temperature
- Percent of range

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 167) is used to specify how many measured values are displayed simultaneously and how.

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu.

Value 3 display**Navigation**

  System → Display → Value 3 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

- None
- Pressure
- Scaled variable
- Current output
- Sensor temperature
- Percent of range

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 167) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu.

Value 4 display**Navigation**

  System → Display → Value 4 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

- None
- Pressure
- Scaled variable
- Current output
- Sensor temperature
- Percent of range

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 167) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu.

Contrast display**Navigation**

  System → Display → Contrast display

Description

Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)

User entry

20 to 80 %

Factory setting

Depends on the display

Additional information

Set the contrast via the push-buttons:

- Weaker: Press the and buttons simultaneously
- Stronger: Press the and buttons simultaneously

3.5.5 "Geolocation" submenu

Navigation

System → Geolocation

Process Unit Tag**Navigation**

System → Geolocation → Process Unit Tag

Description

Enter the process unit in which the device is installed.

User entry

Character string comprising numbers, letters and special characters (32)

Location Description**Navigation**

System → Geolocation → Location Descr.

Description

Use this function to enter a description of the location so that the device can be located in the plant.

User entry

Character string comprising numbers, letters and special characters (32)

Longitude**Navigation**

System → Geolocation → Longitude

Description

Use this function to enter the longitude coordinates that describe the device location.

User entry

-180 to 180 °

Latitude**Navigation**

System → Geolocation → Latitude

Description

Use this function to enter the latitude coordinates that describe the device location.

User entry -90 to 90 °

Altitude

Navigation System → Geolocation → Altitude

Description Use this function to enter the altitude data that describe the device location.

User entry Signed floating-point number

Location method

Navigation System → Geolocation → Location method

Description Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183.

Selection

- No fix
- GPS or Standard Positioning Service fix
- Differential GPS fix
- Precise positioning service (PPS) fix
- Real Time Kinetic (RTK) fixed solution
- Real Time Kinetic (RTK) float solution
- Estimated dead reckoning
- Manual input mode
- Simulation Mode

3.5.6 "Information" submenu

Navigation System → Information

Device name

Navigation System → Information → Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Manufacturer

Navigation  System → Information → Manufacturer

User interface Character string comprising numbers, letters and special characters

Serial number 

Navigation  System → Information → Serial number

Description Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Order code 

Navigation  System → Information → Order code

Description Shows the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Factory setting –

Additional information *Description*

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Firmware version

Navigation	  System → Information → Firmware version
Description	Displays the device firmware version that is installed.
User interface	Character string in the format xx.yy.zz
Additional information	<i>User interface</i>  The Firmware version is also located: <ul style="list-style-type: none">▪ On the title page of the Operating instructions▪ On the transmitter nameplate

Hardware version

Navigation	  System → Information → Hardware version
User interface	Character string comprising numbers, letters and special characters

Extended order code 1

Navigation	 System → Information → Ext. order cd. 1
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
User interface	Character string
Factory setting	–
Additional information	<i>Description</i> The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2

Navigation	 System → Information → Ext. order cd. 2
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
	 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.
User interface	Character string

Factory setting

–

Extended order code 3**Navigation**

System → Information → Ext. order cd. 3

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.

The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

–

XML build number**Navigation**

System → Information → XML build no.

User interface

Positive integer

Checksum**Navigation**

System → Information → Checksum

Description

Checksum for Firmware version.

User interface

Positive integer

3.5.7 "Software configuration" submenu

Navigation

 System → Softw. config.

CRC device configuration

Navigation

 System → Softw. config. → CRC device conf.

Description

CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.

User interface

0 to 65 535

Stored CRC device configuration

Navigation

 System → Softw. config. → Stored CRC conf.

Description

Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.

User interface

0 to 65 535

Timestamp stored CRC device config.

Navigation

 System → Softw. config. → Time stored CRC

Description

Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.

User interface

Character string comprising numbers, letters and special characters

Activate SW option



Navigation

 System → Softw. config. → Activate SW opt.

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string of numbers.

Factory setting

Depends on the software option ordered

Additional information	Description
	If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.
	<i>User entry</i>
	 To activate a software option subsequently, please contact your Endress+Hauser sales organization.
	NOTE!
	The activation code is linked to the serial number of the measuring device and varies according to the device and software option.
	If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.
	► Before you enter a new activation code, make a note of the current activation code from the parameter protocol.
	► Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
	► If the code entered is incorrect or invalid, enter the old activation code from the parameter protocol.
	► Have the Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options
User interface	<ul style="list-style-type: none">■ SIL■ WHG■ Heartbeat Verification■ Heartbeat Monitoring

Index

Symbols

- (High) Is safety function triggered? (Parameter) 100
 (Low) Is safety function triggered? (Parameter) 101

0 ... 9

- 4 mA trim value (Parameter) 149
 20 mA trim value (Parameter) 149
 500 Diagnostic behavior (Parameter) 77, 122
 500 Event category (Parameter) 77, 122
 500 Process alert pressure (Parameter) 75, 119
 501 Diagnostic behavior (Parameter) 78, 122
 501 Event category (Parameter) 79, 123
 501 Process alert scaled variable (Parameter) 77, 119
 502 Diagnostic behavior (Parameter) 80, 123
 502 Event category (Parameter) 80, 123
 806 Diagnostic behavior (Parameter) 74, 121, 124, 127
 806 Event category (Parameter) 74, 121, 124, 127
 806 Event delay (Parameter) 74, 117, 121
 822 Diagnostic behavior (Parameter) 124, 127
 822 Event category (Parameter) 125, 128
 841 Event category (Parameter) 125, 128
 900 Diagnostic behavior (Parameter) 70, 126, 129
 900 Event category (Parameter) 69, 126, 129
 906 Diagnostic behavior (Parameter) 126, 129
 906 Event category (Parameter) 70, 126, 129

A

- Activate SW option (Parameter) 175
 Activate table (Parameter) 143
 Active diagnostics (Parameter) 103, 106
 Active diagnostics (Submenu) 106
 Altitude (Parameter) 171
 Analog path integrity (Parameter) 58
 Application (Menu) 131
 Assign HART variables? (Parameter) 50, 52
 Assign PV (Parameter) 38, 52, 90, 140, 147, 151
 Assign QV (Parameter) 54, 153
 Assign SV (Parameter) 53, 152
 Assign TV (Parameter) 53, 152

B

- Baseline build process (Parameter) 64, 72
 Baseline is available (Parameter) 65
 Baseline Signal Control Line (Parameter) 66
 Baseline Signal Lower Control Line (Parameter) 67
 Baseline Signal Noise Control Line (Parameter) 68
 Baseline Signal Noise Lower Control Line (Parameter) 68
 Baseline Signal Noise Minimum (Parameter) 69
 Baseline Signal Noise Upper Control Line (Parameter) 68
 Baseline Signal Upper Control Line (Parameter) 66
 Baseline status (Parameter) 71, 116
 Basic settings (Submenu) 135
 Bluetooth activation (Parameter) 166
 Bluetooth configuration (Submenu) 166
 Burst command 1 (Parameter) 155
 Burst configuration 1 (Submenu) 154

- Burst mode 1 (Parameter) 154
 Burst trigger level (Parameter) 158
 Burst trigger mode (Parameter) 157
 Burst variable 0 (Parameter) 155
 Burst variable 1 (Parameter) 156
 Burst variable 2 (Parameter) 156
 Burst variable 3 (Parameter) 156
 Burst variable 4 (Parameter) 156
 Burst variable 5 (Parameter) 157
 Burst variable 6 (Parameter) 157
 Burst variable 7 (Parameter) 157

C

- Calibration offset (Parameter) 136
 Character test string (Parameter) 83
 Checksum (Parameter) 174
 Clamping voltage lower threshold (Parameter) 116
 Clamping voltage upper threshold (Parameter) 116
 Clear event list (Parameter) 108
 Commissioning (Wizard) 34
 Configuration (Submenu) 122, 150
 Configuration counter (Parameter) 87, 98, 163
 Confirm (Parameter) 83, 85, 88, 89, 91, 100
 Confirm new password (Parameter) 165
 Confirmation (Wizard) 87, 88, 89, 91
 Contrast display (Parameter) 169
 Counter Baseline creation SSD (Parameter) 65, 118
 Counter limit overruns sensor Pmax (Parameter) 111
 Counter limit overruns sensor Tmax (Parameter) 112
 Counter limit underruns sensor Pmin (Parameter) 109
 Counter limit underruns sensor Tmin (Parameter) 110
 Counter overruns of user limit Pmax (Parameter) 76, 111
 Counter overruns of user limit Tmax (Parameter) 80, 112
 Counter underruns of user limit Pmin (Parameter) 76, 109
 Counter underruns of user limit Tmin (Parameter) 80, 110
 CRC device configuration (Parameter) 86, 97, 175
 Current Baseline noise (Parameter) 68
 Current Baseline signal (Parameter) 66
 Current deviation 1 (Parameter) 102
 Current deviation 2 (Parameter) 102
 Current output (Submenu) 147
 Current range output (Parameter) 49, 51, 90, 147

D

- Damping (Parameter) 38, 88, 136
 Date/time (Parameter) 93
 Date/time Heartbeat Verification (Parameter) 60, 114
 Date/time proof test (Parameter) 104
 Decimal places pressure (Parameter) 131
 Decimal places scaled variable (Parameter) 133
 Decision of inspector (Parameter) 103
 Description of device parameters 31

Device ID (Parameter)	159
Device identification (Wizard)	34, 36, 37
Device management (Submenu)	162
Device name (Parameter)	34, 84, 96, 171
Device revision (Parameter)	159
Device tag (Parameter)	34, 84, 95, 150, 162
Device type (Parameter)	159
Diagnostic event simulation (Parameter)	113
Diagnostic settings (Submenu)	118
Diagnostics (Menu)	106
Display (Submenu)	166
Document	
Explanation of the structure of a parameter	
description	4
Function	4
Structure	4
Symbols used	5
Target group	4
Using the document	4
Document function	4

E

Electronics temperature (Parameter)	135
Enter access code (Parameter)	164
Enter safety locking code (Parameter)	83, 91
Enter safety unlocking code (Parameter)	81
Event logbook (Submenu)	108
Extended order code 1 (Parameter)	35, 173
Extended order code 2 (Parameter)	35, 173
Extended order code 3 (Parameter)	35, 174

F

Failure behavior current output (Parameter)	
.	49, 51, 89, 148
Failure current (high alarm) (Parameter)	99
Failure current (Parameter)	49, 52, 148
Filter options (Parameter)	108
Finish (Wizard)	93, 103
Firmware version (Parameter)	85, 96, 173
Format display (Parameter)	167
Free text (Parameter)	41, 133, 141
Function	
see Parameter	

G

Geolocation (Submenu)	170
Guidance (Menu)	31, 34

H

Hardware version (Parameter)	85, 97, 173
HART address (Parameter)	38, 150
HART date code (Parameter)	37, 161
HART descriptor (Parameter)	37, 160
HART message (Parameter)	37, 160
HART output (Submenu)	150, 151
HART revision (Parameter)	160
HART short tag (Parameter)	37, 150, 160
Heartbeat Technology (Submenu)	114
Heartbeat Verification (Parameter)	55
Heartbeat Verification (Submenu)	114

Heartbeat Verification (Wizard)	55
High alert value (Parameter)	76, 78, 79, 119, 120, 121
HP/LP swap (Parameter)	87

I

I have read the warning texts. (Parameter)	71, 81, 94
Information (Submenu)	159, 171
Inspector (Parameter)	59, 93, 104

L

Language (Parameter)	166
Latitude (Parameter)	170
Location (Parameter)	59, 93, 104
Location Description (Parameter)	170
Location method (Parameter)	171
Locking (Wizard)	91
Locking status (Parameter)	36, 81, 92, 162
Longitude (Parameter)	170
Loop current mode (Parameter)	50, 52, 151
Loop diagnostics (Parameter)	57, 75, 116
Loop diagnostics (Submenu)	115
Low alert value (Parameter)	75, 78, 79, 119, 120
Low cutoff (Parameter)	89
Lower Range Limit (Parameter)	44, 46, 48, 139
Lower range value output (Parameter)	
.	45, 48, 51, 90, 142, 145, 146, 148
Lower sensor trim (Parameter)	138
Lower sensor trim measured value (Parameter)	137

M

Mainboard module (Wizard)	55
Manufacturer (Parameter)	172
Max. update period (Parameter)	158
Maximum electronics temperature (Parameter)	112
Maximum sensor temperature (Parameter)	111
Maximum terminal voltage (Parameter)	112
Measured values (Submenu)	134
Measurement adjustments (Wizard)	38, 39, 40, 42
Measuring mode current output (Parameter)	89, 147
Measuring units (Submenu)	131
Membrane integrity (Parameter)	57
Menu	

Application	131
Diagnostics	106
Guidance	31, 34
System	162
Min. update period (Parameter)	158
Minimum electronics temperature (Parameter)	110
Minimum sensor temperature (Parameter)	110
Minimum span (Parameter)	44, 46, 48, 140
Minimum terminal voltage (Parameter)	110
Minimum/maximum values (Submenu)	109

N

New password (Parameter)	165
No. of preambles (Parameter)	151
Notes (Parameter)	60, 93, 95, 104

O

Old password (Parameter)	165
------------------------------------	-----

Operating time (Parameter)	86, 98, 108	Sensor (Submenu)	135
Operating time (Verification) (Parameter)	60, 114	Sensor calibration (Submenu)	136
Operating time from restart (Parameter)	107	Sensor integrity (Parameter)	57
Order code (Parameter)	172	Sensor limits (Submenu)	139
Output current (Parameter)	55, 149	Sensor pressure (Parameter)	134
Output current transfer function (Parameter)		Sensor pressure range behavior (Parameter)	
.	43, 88, 135	88, 125, 128
Output settings (Wizard)	43, 44, 45, 46, 48, 50, 52	Sensor temperature (Parameter)	134
P		Sensor temperature lower range limit (Parameter)	140
Parameter		Sensor temperature upper range limit (Parameter)	140
Structure of a parameter description	4	Sensor Trim Reset (Parameter)	137
Password (Parameter)	164	Sensor/membrane integrity (Parameter)	58
Plant operator (Parameter)	60, 94, 105	Serial number (Parameter)	34, 85, 96, 172
Preparation (Wizard)	81, 82, 83, 84, 86	Setpoint 1 (Parameter)	101
Preparation Proof test (Wizard)	94, 95, 97, 99	Setpoint 2 (Parameter)	102
Pressure (Parameter)	43, 45, 134, 142, 144	Signal maximum value (Parameter)	67
Pressure 1 (Parameter)	101	Signal minimum value (Parameter)	67
Pressure 2 (Parameter)	102	Signal noise maximum value (Parameter)	69
Pressure max (Parameter)	111	Signal noise minimum value (Parameter)	69
Pressure min (Parameter)	109	Signal noise status (Parameter)	64, 67, 118
Pressure unit (Parameter)	39, 40, 131	Signal status (Parameter)	64, 66, 117
Pressure value 1 (Parameter)	47, 143, 144, 146	Simulation (Parameter)	113
Pressure value 2 (Parameter)	47, 143, 145, 146	Simulation (Submenu)	113
Previous diagnostics (Parameter)	107	Simulation and check failure current (Wizard)	99
Primary variable (PV) (Parameter)	151	Software configuration (Submenu)	175
Process (Submenu)	124, 127	Software integrity (Parameter)	56
Process Unit Tag (Parameter)	170	Software option overview (Parameter)	176
Process variable output current (Parameter)	50	Span (Parameter)	144, 146
Proof test (Wizard)	94, 101	SSD Monitoring delay time (Parameter)	69, 119
Proof test via Bluetooth allowed? (Parameter)	82	SSD Out of range delay time (Parameter)	70, 118
Properties (Submenu)	118	SSD: Statistical Sensor Diagnostics (Parameter)	71, 117
Q		Statistical Sensor Diagnostics (Parameter)	58
Quaternary variable (QV) (Parameter)	154	Statistical Sensor Diagnostics (Submenu)	117
R		Status (Parameter)	115
RAM check (Parameter)	56	Status password entry (Parameter)	165
Rebuild baseline (Parameter)	115	Status summary (Parameter)	61, 62, 63
Reset device (Parameter)	163	Stored CRC device configuration (Parameter)	86, 97, 175
Reset password (Parameter)	166	Submenu	
Reset user defined counters P and T (Parameter)	111	Active diagnostics	106
Resistance Baseline (Parameter)	72	Basic settings	135
Resistance previous Baseline (Parameter)	73	Bluetooth configuration	166
ROM check (Parameter)	56	Burst configuration 1	154
S		Configuration	122, 150
Safety function? (Parameter)	99	Current output	147
Safety mode (Wizard)	81	Device management	162
Sample rate (Parameter)	65	Diagnostic settings	118
Save protocol? (Parameter)	59, 92	Display	166
Scaled variable (Parameter)	45, 134, 144	Event logbook	108
Scaled variable (Submenu)	140	Geolocation	170
Scaled variable transfer function (Parameter)		HART output	150, 151
.	43, 46, 142	Heartbeat Technology	114
Scaled variable unit (Parameter)	40, 132, 141	Heartbeat Verification	114
Scaled variable value 1 (Parameter)	47, 143	Information	159, 171
Scaled variable value 2 (Parameter)	47, 143	Loop diagnostics	115
Secondary variable (SV) (Parameter)	152	Measured values	134
Select test procedure (Parameter)	99	Measuring units	131
		Minimum/maximum values	109
		Process	124, 127
		Properties	118

Scaled variable	140	Mainboard module	55
Sensor	135	Measurement adjustments	38, 39, 40, 42
Sensor calibration	136	Output settings	43, 44, 45, 46, 48, 50, 52
Sensor limits	139	Preparation	81, 82, 83, 84, 86
Simulation	113	Preparation Proof test	94, 95, 97, 99
Software configuration	175	Proof test	94, 101
Statistical Sensor Diagnostics	117	Safety mode	81
User management	164	Simulation and check failure current	99
Wet calibration	144, 145		
Summary (Parameter)	103		
Supply voltage Baseline (Parameter)	72		
Supply voltage previous Baseline (Parameter)	73		
System (Menu)	162		
System status (Parameter)	55, 64, 117		
T			
Target group	4		
Temperature unit (Parameter)	39, 41, 131		
Terminal current (high alarm) (Parameter)	100		
Terminal current (Parameter)	135, 149		
Terminal current 1 (Parameter)	101		
Terminal current 2 (Parameter)	102		
Terminal voltage 1 (Parameter)	116, 134		
Tertiary variable (TV) (Parameter)	153		
Timestamp (Parameter)	106, 107		
Timestamp Baseline (Parameter)	72		
Timestamp previous Baseline (Parameter)	73		
Timestamp stored CRC device config. (Parameter)			
.	86, 97, 175		
Tolerated deviation +/- (Parameter)	73, 115		
U			
Upper Range Limit (Parameter)	44, 46, 48, 139		
Upper range value output (Parameter)			
.	45, 49, 51, 90, 142, 145, 146, 148		
Upper sensor trim (Parameter)	139		
Upper sensor trim measured value (Parameter)	138		
User management (Submenu)	164		
User role (Parameter)	164		
User temperature process alert (Parameter)	79, 120		
V			
Value 1 display (Parameter)	167		
Value 2 display (Parameter)	168		
Value 3 display (Parameter)	168		
Value 4 display (Parameter)	169		
Value current output (Parameter)	113		
Value pressure simulation (Parameter)	113		
Verification result (Parameter)	59, 114		
Visual inspection (Parameter)	95		
W			
Wet calibration (Submenu)	144, 145		
Wizard			
Commissioning	34		
Confirmation	87, 88, 89, 91		
Device identification	34, 36, 37		
Finish	93, 103		
Heartbeat Verification	55		
Locking	91		



71647905

www.addresses.endress.com
