

Description of Device Parameters

Proline Teqwave M 300

Total solids measurement via microwave transmission
HART




Table of contents

| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----------|--|-----------|---|---|------------|--|--|-----|-----------------------|---|-----|-------------|---|-----|--|---|-----|---|--|-----|--|---|-----|---|-----------------------------------|-----|--|--|-----|---|-----------------------------------|-----|--|---|-----|---|-----------------------------------|-----|--|--|-----|---|-----------------------------------|-----|--|--|-----|--|-----------------------------|-----|---|---------------------------------------|-----|--|-------------------------------------|-----|---|--|-----|--|-----|-----|---|-----|-----|--|-----|-----|---|-----|-----|--|-----|-----|---|-----|-----|--|-----|--|---|-----|-----|--|-----|--|--|-----|-----|-------------------------------------|-----|--|--|-----|-----|-------------------------------------|-----|--|--|-----|--|-------------------------------------|-----|--|--|-----|
| 1 | About this document | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.1 | Document function | 4 | 3.8.4 "Main electronic module + I/O module 1" submenu | 161 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.2 | Target group | 4 | 3.8.5 "Sensor electronic module (ISEM)" submenu | 162 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.3 | Using this document | 4 | 3.8.6 "I/O module 2" submenu | 163 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.3.1 Information on the document structure | 4 | 3.8.7 "I/O module 3" submenu | 164 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.3.2 Structure of a parameter description .. | 6 | 3.8.8 "Display module" submenu | 165 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.4 | Symbols used | 6 | 3.8.9 "Data logging" submenu | 166 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.4.1 Symbols for certain types of information .. | 6 | 3.8.10 "Min/max values" submenu | 174 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.4.2 Symbols in graphics | 7 | 3.8.11 "Heartbeat Technology" submenu ... | 178 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.5 | Documentation | 7 | 3.8.12 "Simulation" submenu | 179 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.5.1 Standard documentation | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1.5.2 Supplementary device-dependent documentation | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Overview of the Expert operating menu | 8 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Description of device parameters ... | 11 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.1 | "System" submenu | 13 | 4 | Country-specific factory settings .. | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.1.1 "Display" submenu | 13 | | 4.1 SI units | 188 | | 3.1.2 "Configuration backup" submenu | 32 | | 4.1.1 System units | 188 | | 3.1.3 "Diagnostic handling" submenu | 35 | | 4.1.2 Output current span | 188 | | 3.1.4 "Administration" submenu | 41 | 3.2 | "Sensor" submenu | 45 | | 4.2 US units | 188 | | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 |
| | 4.1 SI units | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.1.2 "Configuration backup" submenu | 32 | | 4.1.1 System units | 188 | | 3.1.3 "Diagnostic handling" submenu | 35 | | 4.1.2 Output current span | 188 | | 3.1.4 "Administration" submenu | 41 | 3.2 | "Sensor" submenu | 45 | | 4.2 US units | 188 | | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | |
| | 4.1.1 System units | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.1.3 "Diagnostic handling" submenu | 35 | | 4.1.2 Output current span | 188 | | 3.1.4 "Administration" submenu | 41 | 3.2 | "Sensor" submenu | 45 | | 4.2 US units | 188 | | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | |
| | 4.1.2 Output current span | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.1.4 "Administration" submenu | 41 | 3.2 | "Sensor" submenu | 45 | | 4.2 US units | 188 | | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | |
| 3.2 | "Sensor" submenu | 45 | | 4.2 US units | 188 | | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | |
| | 4.2 US units | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.2.1 "Measured values" submenu | 46 | | 4.2.1 System units | 188 | | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4.2.1 System units | 188 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.2.2 "System units" submenu | 54 | | 4.2.2 Output current span | 189 | | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 4.2.2 Output current span | 189 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.2.3 "Process parameters" submenu | 57 | 3.3 | "I/O configuration" submenu | 66 | | | 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.3 | "I/O configuration" submenu | 66 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.4 | "Input" submenu | 68 | | Index | 190 | | 3.4.1 "Current input 1 to n" submenu | 68 | | 3.4.2 "Status input 1 to n" submenu | 71 | 3.5 | "Output" submenu | 73 | | 3.5.1 "Current output 1 to n" submenu | 74 | | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | 3.5.3 "Relay output 1 to n" submenu | 103 | 3.6 | "Communication" submenu | 109 | | 3.6.1 "HART input" submenu | 110 | | 3.6.2 "HART output" submenu | 115 | | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | 3.6.4 "Web server" submenu | 135 | | 3.6.5 "WLAN settings" wizard | 139 | 3.7 | "Application" submenu | 146 | | 3.7.1 "Totalizer 1 to n" submenu | 146 | 3.8 | "Diagnostics" submenu | 150 | | 3.8.1 "Diagnostic list" submenu | 153 | | 3.8.2 "Event logbook" submenu | 155 | | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Index | 190 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.4.1 "Current input 1 to n" submenu | 68 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.4.2 "Status input 1 to n" submenu | 71 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.5 | "Output" submenu | 73 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.5.1 "Current output 1 to n" submenu | 74 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.5.2 "Pulse/frequency/switch output 1 to n" submenu | 85 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.5.3 "Relay output 1 to n" submenu | 103 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.6 | "Communication" submenu | 109 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.6.1 "HART input" submenu | 110 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.6.2 "HART output" submenu | 115 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.6.3 "Diagnostic configuration" submenu .. | 131 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.6.4 "Web server" submenu | 135 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.6.5 "WLAN settings" wizard | 139 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.7 | "Application" submenu | 146 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.7.1 "Totalizer 1 to n" submenu | 146 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3.8 | "Diagnostics" submenu | 150 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.8.1 "Diagnostic list" submenu | 153 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.8.2 "Event logbook" submenu | 155 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3.8.3 "Device information" submenu | 157 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions
- Operating concept of the operating menus: Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

| Complete parameter name | Write-protected parameter =  |
|-------------------------------|--|
| Navigation |  Navigation path to the parameter via the local display or Web browser  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool. |
| Prerequisite | The parameter is only available under these specific conditions |
| Description | Description of the parameter function |
| Options | List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2 |
| User entry | Parameter entry range |
| Display | Display value/data of the parameter |
| Factory setting | Default setting ex works |
| Additional information | Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function |

1.4 Symbols used

1.4.1 Symbols for certain types of information

| Symbol | Meaning |
|---|---|
|  | Tip Indicates additional information. |
|  | Reference to documentation |
|  | Reference to page |
|  | Reference to graphic |
|  | Operation via local display <small>A0028662</small> |
|  | Operation via operating tool <small>A0028663</small> |
|  | Write-protected parameter <small>A0028665</small> |

1.4.2 Symbols in graphics

| Symbol | Meaning |
|--------------------|--------------|
| 1, 2, 3 ... | Item numbers |
| A, B, C, ... | Views |
| A-A, B-B, C-C, ... | Sections |

1.5 Documentation

1.5.1 Standard documentation

Technical information

| Device | Documentation code |
|------------------------|--------------------|
| Proline Teqwave MW 300 | TI01763D |

Operating instructions

| Device | Documentation code |
|-----------------------------|--------------------|
| Proline Teqwave MW 300 HART | BA02320D |

1.5.2 Supplementary device-dependent documentation

Special documentation

| Contents | Documentation code |
|---|--------------------|
| Heartbeat Verification application package (HART) | SD03168D |

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

| Content | Page Reference |
|------------------------------------|----------------|
| ↳ Expert | |
| Locking status | → ↗ 11 |
| User role | → ↗ 12 |
| Enter access code | → ↗ 13 |
| ▶ System | → ↗ 13 |
| ▶ Display | → ↗ 13 |
| ▶ Configuration backup | → ↗ 32 |
| ▶ Diagnostic handling | → ↗ 35 |
| ▶ Administration | → ↗ 41 |
| ▶ Sensor | → ↗ 45 |
| ▶ Measured values | → ↗ 46 |
| ▶ System units | → ↗ 54 |
| ▶ Process parameters | → ↗ 57 |
| ▶ External process variables | → ↗ 61 |
| ▶ Sensor adjustment | → ↗ 62 |
| ▶ Factory adjustment | → ↗ 65 |
| ▶ I/O configuration | → ↗ 66 |
| I/O module 1 to n terminal numbers | → ↗ 66 |
| I/O module 1 to n information | → ↗ 66 |
| I/O module 1 to n type | → ↗ 67 |
| Apply I/O configuration | → ↗ 67 |
| I/O alteration code | → ↗ 68 |

| | |
|--|-------|
| ▶ Input | → 68 |
| ▶ Current input 1 to n | → 68 |
| ▶ Status input 1 to n | → 71 |
| ▶ Output | → 73 |
| ▶ Current output 1 to n | → 74 |
| ▶ Pulse/frequency/switch output 1 to n | → 85 |
| ▶ Relay output 1 to n | → 103 |
| ▶ Communication | → 109 |
| ▶ HART input | → 110 |
| ▶ HART output | → 115 |
| ▶ Web server | → 135 |
| ▶ WLAN settings | → 139 |
| ▶ Application | → 146 |
| Reset all totalizers | → 146 |
| ▶ Totalizer 1 | → 146 |
| ▶ Diagnostics | → 150 |
| Actual diagnostics | → 151 |
| Timestamp | → 151 |
| Previous diagnostics | → 152 |
| Timestamp | → 152 |
| Operating time from restart | → 152 |
| Operating time | → 153 |
| ▶ Diagnostic list | → 153 |
| ▶ Device information | → 157 |

| | |
|---|--------|
| ► Main electronic module + I/O module 1 | → 161 |
| ► Sensor electronic module (ISEM) | → 162 |
| ► I/O module 2 | → 163 |
| ► I/O module 3 | → 164 |
| ► Display module | → 165 |
| ► Data logging | → 166 |
| ► Min/max values | → 174 |
| ► Heartbeat Technology | → 178 |
| ► Simulation | → 179 |

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Navigation

Diagram Expert

| Topic | Page |
|---------------------|-------|
| Locking status | → 11 |
| User role | → 12 |
| Enter access code | → 13 |
| ▶ System | → 13 |
| ▶ Sensor | → 45 |
| ▶ I/O configuration | → 66 |
| ▶ Input | → 68 |
| ▶ Output | → 73 |
| ▶ Communication | → 109 |
| ▶ Application | → 146 |
| ▶ Diagnostics | → 150 |

Locking status

Navigation

Diagram Expert → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Temporarily locked

Additional information*Display*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Options

| Options | Description |
|------------------------------|--|
| None | The access authorization displayed in the Access status parameter (→ 12) applies. Only appears on local display. |
| Hardware locked (priority 1) | The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool). |
| Temporarily locked | Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again. |

User role

Navigation

 Expert → User role

Description

Displays the access authorization to the parameters via the local display, Web browser or operating tool.

User interface

- Maintenance
- Service

Factory setting

Maintenance

Additional information*Description*

 Access authorization can be modified via the **Enter access code** parameter (→ 13).

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Enter access code**Navigation**
 Expert → Ent. access code
Description

Use this function to enter the user-specific release code to remove parameter write protection.

User entry

Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation
 Expert → System

| | |
|-------------------------------|--|
| ► System | |
| ► Display | →  13 |
| ► Configuration backup | →  32 |
| ► Diagnostic handling | →  35 |
| ► Administration | →  41 |

3.1.1 "Display" submenu

Navigation
 Expert → System → Display

| | |
|-----------------------|--|
| ► Display | |
| Format display | →  14 |
| Value 1 display | →  17 |
| 0% bargraph value 1 | →  17 |
| 100% bargraph value 1 | →  18 |
| Decimal places 1 | →  18 |
| Value 2 display | →  19 |
| Decimal places 2 | →  19 |
| Value 3 display | →  20 |

| | |
|-----------------------|-------|
| 0% bargraph value 3 | → 20 |
| 100% bargraph value 3 | → 21 |
| Decimal places 3 | → 21 |
| Value 4 display | → 22 |
| Decimal places 4 | → 22 |
| Display language | → 23 |
| Display interval | → 29 |
| Display damping | → 29 |
| Header | → 30 |
| Header text | → 30 |
| Separator | → 31 |
| Backlight | → 32 |

Format display

Navigation

Expert → System → Display → Format display

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*


The display format (size, bar graph) and number of simultaneously displayed measured values (1 to 8) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→ 17)...**Value 8 display** parameter (→ 28) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (→ 29).


Possible measured values shown on the local display:

"1 value, max. size" option




A0054319

"1 bargraph + 1 value" option




A0054322

"2 values" option




A0054323

"1 value large + 2 values" option



A0054324

"4 values" option



A0054328

Value 1 display**Navigation**

Expert → System → Display → Value 1 display

Prerequisite

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Use this function to select a measured value that is shown on the local display.

Selection

- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity
- Load rate *
- Totalizer 1 *
- Current output 1 *
- Current output 2 *
- Current output 3 *
- Current output 4 *

Factory setting

Total solids

Additional information*Description*

If several measured values are displayed one below the other, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.

The **Format display** parameter (→ 14) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

0% bargraph value 1**Navigation**

Expert → System → Display → 0% bargraph 1

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

0 %TS

* Visibility depends on order options or device settings

| Additional information | Description |
|------------------------|---|
| | <p> The Format display parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.</p> |
| | <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 54).</p> |

100% bargraph value 1



| Navigation |  Expert → System → Display → 100% bargraph 1 |
|------------------------|---|
| Prerequisite | A local display is provided. |
| Description | Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1. |
| User entry | Signed floating-point number |
| Factory setting | Depends on country and nominal diameter |
| Additional information | Description |
| | <p> The Format display parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.</p> |
| | <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 54).</p> |

Decimal places 1



| Navigation |  Expert → System → Display → Decimal places 1 |
|------------------------|--|
| Prerequisite | A measured value is specified in the Value 1 display parameter (→ 17). |
| Description | Use this function to select the number of decimal places for measured value 1. |
| Selection | <ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX |
| Factory setting | X.XX |
| Additional information | Description |
| | <p> This setting does not affect the accuracy of the device for measuring or calculating the value.</p> |

Value 2 display

| | |
|-------------------------------|---|
| Navigation | Expert → System → Display → Value 2 display |
| Prerequisite | <ul style="list-style-type: none"> ■ A local display is provided. ■ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus. |
| Description | Use this function to select a measured value that is shown on the local display. |
| Selection | <ul style="list-style-type: none"> ■ None ■ Total solids ■ Temperature ■ Electronics temperature ■ Conductivity ■ Corrected conductivity ■ Load rate * ■ Totalizer 1 * ■ Current output 1 * ■ Current output 2 * ■ Current output 3 * ■ Current output 4 * |
| Factory setting | None |
| Additional information | <p><i>Description</i></p> <p>If several measured values are displayed one below the other, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 14) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 54).</p> |

Decimal places 2

| | |
|---------------------|---|
| Navigation | Expert → System → Display → Decimal places 2 |
| Prerequisite | A measured value is specified in the Value 2 display parameter (→ 19). |
| Description | Use this function to select the number of decimal places for measured value 2. |
| Selection | <ul style="list-style-type: none"> ■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX |

* Visibility depends on order options or device settings

| | |
|-------------------------------|--------------------|
| Factory setting | x.xx |
| Additional information | <i>Description</i> |



This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 3 display



| | |
|-------------------------------|---|
| Navigation | Expert → System → Display → Value 3 display |
| Prerequisite | <ul style="list-style-type: none">■ A local display is provided.■ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus. |
| Description | Use this function to select a measured value that is shown on the local display. |
| Selection | For the picklist, see Value 1 display parameter (→ 17) |
| Factory setting | None |
| Additional information | <i>Description</i> |

If several measured values are displayed one below the other, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ [14](#)) is used to specify how many measured values are displayed simultaneously and how.

Options



The unit of the displayed measured value is taken from the **System units** submenu (→ [54](#)).

0% bargraph value 3



| | |
|------------------------|--|
| Navigation | Expert → System → Display → 0% bargraph 3 |
| Prerequisite | A selection was made in the Value 3 display parameter (→ 20). |
| Description | Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

Additional information*Description*

The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

100% bargraph value 3**Navigation**

Expert → System → Display → 100% bargraph 3

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 20).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

Decimal places 3**Navigation**

Expert → System → Display → Decimal places 3

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 4 display



Navigation

Expert → System → Display → Value 4 display

Prerequisite

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Use this function to select a measured value that is shown on the local display.

Selection

For the picklist, see **Value 1 display** parameter (→ 17)

Factory setting

None

Additional information

Description

If several measured values are displayed one below the other, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

The **Format display** parameter (→ 14) is used to specify how many measured values are displayed simultaneously and how.

Options

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

Decimal places 4



Navigation

Expert → System → Display → Decimal places 4

Prerequisite

A measured value is specified in the **Value 4 display** parameter (→ 22).

Description

Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information

Description

This setting does not affect the accuracy of the device for measuring or calculating the value.

Display language

Navigation  Expert → System → Display → Display language

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Value 5 display



Navigation  Expert → System → Display → Value 5 display

Prerequisite

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus.

Description Use this function to select a measured value that is shown on the local display.

Selection For the picklist, see **Value 1 display** parameter (→  17)

Factory setting None

Additional information *Description*

If several measured values are displayed one below the other, the measured value selected here will be the fifth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→  14) is used to specify how many measured values are displayed simultaneously and how.

Options

 The unit of the displayed measured value is taken from the **System units** submenu (→  54).

0% bargraph value 5



Navigation

Expert → System → Display → 0% bargraph 5

Prerequisite

An option was selected in the **Value 5 display** parameter (→ 23).

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 5.

User entry

Signed floating-point number

Factory setting

0

Additional information

Description

The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

100% bargraph value 5



Navigation

Expert → System → Display → 100% bargraph 5

Prerequisite

An option was selected in the **Value 5 display** parameter (→ 23).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 5.

User entry

Signed floating-point number

Factory setting

0

Additional information

Description

The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

Decimal places 5



Navigation

Expert → System → Display → Decimal places 5

Prerequisite

A measured value is specified in the **Value 5 display** parameter (→ 23).

Description Use this function to select the number of decimal places for measured value 5.

| | |
|------------------|---|
| Selection | <ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX <input type="checkbox"/> X.XXXXX <input type="checkbox"/> X.XXXXXX |
|------------------|---|

Factory setting X.XX

Additional information *Description*

 This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 6 display



Navigation  Expert → System → Display → Value 6 display

Prerequisite

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.

Description Use this function to select a measured value that is shown on the local display.

Selection For the picklist, see **Value 1 display** parameter (→ [17](#))

Factory setting None

Additional information *Description*

If several measured values are displayed one below the other, the measured value selected here will be the sixth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ [14](#)) is used to specify how many measured values are displayed simultaneously and how.

Options

 The unit of the displayed measured value is taken from the **System units** submenu (→ [54](#)).

Decimal places 6



Navigation  Expert → System → Display → Decimal places 6

Prerequisite A measured value is specified in the **Value 6 display** parameter (→ [25](#)).

Description Use this function to select the number of decimal places for measured value 6.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX
- X.XXXXX
- X.XXXXXX

Factory setting

x.xx

Additional information*Description*

 This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 7 display**Navigation** Expert → System → Display → Value 7 display**Prerequisite**

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus.

Description

Use this function to select a measured value that is shown on the local display.

Selection

For the picklist, see **Value 1 display** parameter (→  17)

Factory setting

None

Additional information*Description*

If several measured values are displayed one below the other, the measured value selected here will be the seventh value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→  14) is used to specify how many measured values are displayed simultaneously and how.

Options

 The unit of the displayed measured value is taken from the **System units** submenu (→  54).

0% bargraph value 7**Navigation** Expert → System → Display → 0% bargraph 7**Prerequisite**

An option was selected in the **Value 7 display** parameter (→  26).

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 7.

User entry

Signed floating-point number

Factory setting 0

Additional information *Description*

 The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

100% bargraph value 7



Navigation  Expert → System → Display → 100% bargraph 7

Prerequisite An option was selected in the **Value 7 display** parameter (→ 26).

Description Use this function to enter the 100% bar graph value to be shown on the display for the measured value 7.

User entry Signed floating-point number

Factory setting 0

Additional information *Description*

 The **Format display** parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→ 54).

Decimal places 7



Navigation  Expert → System → Display → Decimal places 7

Prerequisite A measured value is specified in the **Value 7 display** parameter (→ 26).

Description Use this function to select the number of decimal places for measured value 7.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX
- X.XXXXX
- X.XXXXXX

Factory setting X.XX

| Additional information | Description |
|------------------------|---|
| |  This setting does not affect the accuracy of the device for measuring or calculating the value. |

Value 8 display



Navigation  Expert → System → Display → Value 8 display

Prerequisite

- A local display is provided.
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus.

Description Use this function to select a measured value that is shown on the local display.

Selection For the picklist, see **Value 1 display** parameter (→  17)

Factory setting None

| Additional information | Description |
|------------------------|--|
| | If several measured values are displayed one below the other, the measured value selected here will be the eighth value to be displayed. The value is only displayed during normal operation. |
| |  The Format display parameter (→  14) is used to specify how many measured values are displayed simultaneously and how. |

Options

 The unit of the displayed measured value is taken from the **System units** submenu (→  54).

Decimal places 8



Navigation  Expert → System → Display → Decimal places 8

Prerequisite A measured value is specified in the **Value 8 display** parameter (→  28).

Description Use this function to select the number of decimal places for measured value 8.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX
- X.XXXXX
- X.XXXXXX

Factory setting X.XX

Additional information*Description*

This setting does not affect the accuracy of the device for measuring or calculating the value.

Display interval**Navigation**

Expert → System → Display → Display interval

Prerequisite

A local display is provided.

Description

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry

1 to 10 s

Factory setting

5 s

Additional information*Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 17)...**Value 8 display** parameter (→ 28) are used to specify which measured values are shown on the local display.
- The display format for the measured values displayed is defined in the **Format display** parameter (→ 14).

Display damping**Navigation**

Expert → System → Display → Display damping

Prerequisite

A local display is provided.

Description

Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- At a low time constant, the display reacts quickly to fluctuating measured variables.
- If a high time constant is entered, the display reacts more slowly.



The damping is not active if the value **0** (factory setting) is entered.

1) proportional transmission behavior with first order delay

Header**Navigation**

Expert → System → Display → Header

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

Selection

- Device tag
 - Is defined in the **Device tag** parameter (→ 158).
- Free text
 - Is defined in the **Header text** parameter (→ 30).

Header text**Navigation**

Expert → System → Display → Header text

PrerequisiteThe **Free text** option is selected in the **Header** parameter (→ 30).**Description**

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator



Navigation Expert → System → Display → Separator

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection
■ . (point)
■ , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %


Factory setting Depends on the display

Backlight

| | |
|------------------------|--|
| Navigation | Expert → System → Display → Backlight |
| Prerequisite | <p>One of the following conditions is met:</p> <ul style="list-style-type: none"> ■ Order code for "Display; operation", option F "4-line, illum.; touch control" ■ Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN" ■ Order code for "Display; operation", option O "Remote display 4-line illuminated; 10m/30ft cable; touch control" |
| Description | Use this function to switch the backlight of the local display on and off. |
| Selection | <ul style="list-style-type: none"> ■ Disable ■ Enable |
| Factory setting | Enable |

3.1.2 "Configuration backup" submenu

Navigation Expert → System → Config. backup



Operating time

| | |
|-------------------------------|--|
| Navigation | Expert → System → Config. backup → Operating time |
| Description | Displays the length of time the device has been in operation. |
| User interface | Days (d), hours (h), minutes (m) and seconds (s) |
| Additional information | <p><i>Indication</i></p> <p>Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)</p> |

Last backup**Navigation**
 Expert → System → Config. backup → Last backup
Description

Displays the time since a backup copy of the data was last saved to the device memory.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Configuration management**Navigation**
 Expert → System → Config. backup → Config. managem.
Description

Use this function to select an action to save the data to the device memory.

Selection

- Cancel
- Execute backup
- Restore *
- Compare *
- Clear backup data

Factory setting

Cancel

Additional information*Selection*

| Options | Description |
|-------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| Execute backup | A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device. The following message appears on local display: Backup active, please wait! |
| Restore | The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device. The following message appears on local display: Restore active! Do not interrupt power supply! |
| Compare | The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup. The following message appears on local display: Comparing files The result can be viewed in Comparison result parameter. |
| Clear backup data | The backup copy of the device configuration is deleted from the memory of the device. The following message appears on local display: Deleting file |

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

* Visibility depends on order options or device settings

Backup state

Navigation  Expert → System → Config. backup → Backup state

Description Displays the status of the data backup process.

User interface

- None
- Backup in progress
- Restoring in progress
- Delete in progress
- Compare in progress
- Restoring failed
- Backup failed

Factory setting None

Comparison result

Navigation  Expert → System → Config. backup → Compar. result

Description Displays the last result of the comparison of the data records in the device memory and in the HistoROM.

User interface

- Settings identical
- Settings not identical
- No backup available
- Backup settings corrupt
- Check not done
- Dataset incompatible

Factory setting Check not done

Additional information *Description*

 The comparison is started via the **Compare** option in the **Configuration management** parameter (→  33).

Options

| Options | Description |
|-------------------------|--|
| Settings identical | The current device configuration of the HistoROM is not identical to the backup copy in the device memory. If the transformer configuration of another device has been transmitted to the device via HistoROM in Configuration management parameter, the current device configuration of the HistoROM is only partially identical to the backup copy in the device memory: The settings for the transmitter are not identical. |
| Settings not identical | The current device configuration of the HistoROM is not identical to the backup copy in the device memory. |
| No backup available | There is no backup copy of the device configuration of the HistoROM in the device memory. |
| Backup settings corrupt | The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the device memory. |

| Options | Description |
|----------------------|---|
| Check not done | The device configuration of the HistoROM has not yet been compared to the backup copy in the device memory. |
| Dataset incompatible | The backup copy in the device memory is not compatible with the device. |

HistoROM


A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagnostic handling" submenu

Navigation



Expert → System → Diagn. handling



Alarm delay



Navigation

Expert → System → Diagn. handling → Alarm delay

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information

Effect

This setting affects the following diagnostic messages:

- 832 Electronics temperature too high
- 833 Electronics temperature too low
- 834 Process temperature too high
- 835 Process temperature too low
- 881 Signal to noise ratio too low
- 907 Permittivity out of specification
- 908 Volume fraction out of specification
- 909 Conductivity out of specification

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 36).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

| Options | Description |
|--------------------|---|
| Alarm | The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red. |
| Warning | The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated. |
| Logbook entry only | The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (→ 155) (Event list submenu (→ 156)) and is not displayed in alternating sequence with the operational display. |
| Off | The diagnostic event is ignored, and no diagnostic message is generated or entered. |

 For a list of all the diagnostic events, see the Operating Instructions for the device

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

| ► Diagnostic behavior | |
|---------------------------------------|------|
| Assign behavior of diagnostic no. 441 | → 37 |
| Assign behavior of diagnostic no. 442 | → 37 |
| Assign behavior of diagnostic no. 443 | → 37 |
| Assign behavior of diagnostic no. 444 | → 38 |
| Assign behavior of diagnostic no. 302 | → 38 |
| Assign behavior of diagnostic no. 832 | → 38 |
| Assign behavior of diagnostic no. 833 | → 39 |
| Assign behavior of diagnostic no. 834 | → 39 |
| Assign behavior of diagnostic no. 835 | → 40 |

Assign behavior of diagnostic no. 441 (Current output 1 to n)



| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.441 |
| Description | Use this function to change the diagnostic behavior of the 441 Current output 1 to n diagnostic message. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available: → 36 |

Assign behavior of diagnostic no. 442 (Frequency output 1 to n)



| | |
|-------------------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.442 |
| Prerequisite | The measuring device has a pulse/frequency/switch output. |
| Description | Use this function to change the diagnostic behavior of the 442 Frequency output 1 to n diagnostic message. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only |
| Factory setting | Warning |
| Additional information | For a detailed description of the options available: → 36 |

Assign behavior of diagnostic no. 443 (Pulse output 1 to n)



| | |
|---------------------|--|
| Navigation | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.443 |
| Prerequisite | The measuring device has a pulse/frequency/switch output. |
| Description | Use this function to change the diagnostic behavior of the 443 Pulse output 1 to n diagnostic message. |
| Selection | <ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only |

Factory setting Warning

Additional information  For a detailed description of the options available: → [36](#)

Assign behavior of diagnostic no. 444 (Current input 1 to n)



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.444

Prerequisite The device has one current input.

Description Use this function to change the diagnostic behavior of the **444 Current input 1 to n** diagnostic message.

- Selection**
- Off
 - Alarm
 - Warning
 - Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available: → [36](#)

Assign behavior of diagnostic no. 302



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.302

Description Use this function to change the diagnostic behavior of the **302 Device verification active** diagnostic message.

- Selection**
- Off
 - Warning
 - Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available: → [36](#)

Assign behavior of diagnostic no. 832



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.832

Description Use this function to change the diagnostic behavior of the **832 Electronics temperature too high** diagnostic message.

| | |
|------------------|--|
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only |
|------------------|--|

| | |
|------------------------|---------|
| Factory setting | Warning |
|------------------------|---------|

| | |
|-------------------------------|---|
| Additional information |  For a detailed description of the options available: → 36 |
|-------------------------------|---|

Assign behavior of diagnostic no. 833



| | |
|-------------------------------|---|
| Navigation |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.833 |
| Description | Use this function to change the diagnostic behavior of the 833 Electronics temperature too low diagnostic message. |
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only |
| Factory setting | Warning |
| Additional information |  For a detailed description of the options available: → 36 |

Assign behavior of diagnostic no. 834



| | |
|-------------------------------|---|
| Navigation |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.834 |
| Description | Use this function to change the diagnostic behavior of the 834 Process temperature too high diagnostic message. |
| Selection | <ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only |
| Factory setting | Warning |
| Additional information |  For a detailed description of the options available: → 36 |

Assign behavior of diagnostic no. 835

Navigation Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.835

Description Use this function to change the diagnostic behavior of the **835 Process temperature too low** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information For a detailed description of the options available: → 36

Assign behavior of diagnostic no. 907

Navigation Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.907

Description Use this function to change the diagnostic behavior of the **907 Permittivity out of specification** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information For a detailed description of the options available: → 36

Assign behavior of diagnostic no. 908

Navigation Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no.908

Description Use this function to change the diagnostic behavior of the **908 Volume fraction out of specification** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning


Additional information

For a detailed description of the options available: → [36](#)

3.1.4 "Administration" submenu

Navigation

Expert → System → Administration



"Define access code" wizard




The **Define access code** wizard (→ [41](#)) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code



Define access code



Navigation

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the device configuration against any inadvertent modifications via the local display, Web browser, FieldCare or DeviceCare (via CDI-RJ45 service interface).

User entry Max. 16-digit character string comprising numbers, letters and special characters

Additional information *Description*

The write protection affects all parameters in the document marked with the  symbol.

On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  13).

 If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code



Navigation  Expert → System → Administration → Def. access code → Confirm code


Description Enter the defined release code a second time to confirm the release code.

User entry Max. 16-digit character string comprising numbers, letters and special characters

"Reset access code" submenu

Navigation

 Expert → System → Administration → Reset acc. code



Operating time

Navigation  Expert → System → Administration → Reset acc. code → Operating time

Description Displays the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Indication*

Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

Reset access code

Navigation  Expert → System → Administration → Reset acc. code → Reset acc. code

Description Use this function to enter a reset code to reset the user-specific access codes to the factory setting.

User entry Character string comprising numbers, letters and special characters

Factory setting 0x00

Additional information *Description*

 For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via CDI RJ45 interface)
- Fieldbus

Additional parameters in the "Administration" submenu

Device reset



Navigation  Expert → System → Administration → Device reset

Description Reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *

Factory setting Cancel

* Visibility depends on order options or device settings

Additional information*Selection*

| Options | Description |
|----------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| To delivery settings | Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting. |
| Restart device | The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged. |
| Restore S-DAT backup | Restores the data that is saved on the S-DAT. Additional information: This function can be used to resolve the memory issue "083 Memory content inconsistent" or to restore the S-DAT data when a new S-DAT has been installed.  This option is displayed only in an alarm condition. |

Transmitter identifier**Navigation**
  Expert → System → Administration → Transm. identif.
Description

Select transmitter identifier.

User interface

- Unknown
- 500
- 300

Factory setting

300

Activate SW option**Navigation**
  Expert → System → Administration → Activate SW opt.
Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string of numbers.

Factory setting

Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.
Entering the activation code
 The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ If the code entered is incorrect or invalid, enter the old activation code .
- ▶ Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option EA "Extended HistoROM"

Web browser

 Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation  Expert → System → Administration → SW option overv.

Description Displays all the software options that are enabled in the device.

User interface

Additional information *Description*


Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

3.2 "Sensor" submenu

Navigation  Expert → Sensor



| | |
|----------------------|-------|
| ▶ Sensor adjustment | → 62 |
| ▶ Factory adjustment | → 65 |

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

| | |
|---------------------|-------|
| ▶ Measured values | |
| ▶ Process variables | → 46 |
| ▶ Totalizer | → 48 |
| ▶ Input values | → 49 |
| ▶ Output values | → 50 |

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

| | |
|-------------------------|-------|
| ▶ Process variables | |
| Total solids | → 46 |
| Temperature | → 47 |
| Electronics temperature | → 47 |
| Conductivity | → 47 |
| Corrected conductivity | → 47 |
| Load rate | → 47 |

Total solids

Navigation

Expert → Sensor → Measured val. → Process variab. → Total solids

Description

Shows total solids (fraction of total weight or concentration per volume unit).

User interface

Signed floating-point number

Temperature

| | |
|-----------------------|---|
| Navigation |  Expert → Sensor → Measured val. → Process variab. → Temperature |
| Description | Shows the medium temperature currently measured. |
| User interface | Signed floating-point number |

Electronics temperature

| | |
|-----------------------|--|
| Navigation |  Expert → Sensor → Measured val. → Process variab. → Electronics temp |
| Description | Shows the electronics temperature currently measured. |
| User interface | Signed floating-point number |

Conductivity

| | |
|-----------------------|--|
| Navigation |  Expert → Sensor → Measured val. → Process variab. → Conductivity |
| Description | Shows the conductivity currently measured. |
| User interface | Floating-point number |

Corrected conductivity

| | |
|-----------------------|--|
| Navigation |  Expert → Sensor → Measured val. → Process variab. → CorrConductivity |
| Description | Shows the conductivity measured compensated for temperature. |
| User interface | Floating-point number |

Load rate


| | |
|---------------------|---|
| Navigation |  Expert → Sensor → Measured val. → Process variab. → Load rate |
| Prerequisite | The volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus. |
| Description | Shows the total solids flow rate. |

| | |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

"Totalizer" submenu

Navigation

Expert → Sensor → Measured val. → Totalizer



Totalizer 1 value

Navigation

Expert → Sensor → Measured val. → Totalizer → Tot. 1 value

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information

Description

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to n** parameter if the display range is exceeded.

i In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 149).

Display

i The unit of the selected process variable is defined in the **Unit totalizer** parameter (→ 147) for the totalizer.

Totalizer 1 overflow



Navigation

Expert → Sensor → Measured val. → Totalizer → Tot. 1 overflow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information

Description

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow.

The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to n** parameter.


Display

 The unit of the selected process variable is defined in the **Unit totalizer** parameter (→ [147](#)) for the totalizer.

"Input values" submenu

Navigation


 Expert → Sensor → Measured val. → Input values



"Current input 1 to n" submenu

Navigation

 Expert → Sensor → Measured val. → Input values → Current input 1 to n



Measured values 1 to n

Navigation

 Expert → Sensor → Measured val. → Input values → Current input 1 to n
→ Measured val. 1 to n

Description

Displays the current input value.

User interface

Signed floating-point number

Measured current 1 to n

Navigation

Expert → Sensor → Measured val. → Input values → Current input 1 to n → Measur. curr. 1 to n

Description

Displays the current value of the current input.


User interface

0 to 22.5 mA

"Value status input 1 to n" submenu

Navigation

Expert → Sensor → Measured val. → Input values → Val.stat.inp. 1 to n



Value status input

Navigation

Expert → Sensor → Measured val. → Input values → Val.stat.inp. 1 to n
→ Val.stat.inp.

Description

Displays the current input signal level.


User interface

- High
- Low

"Output values" submenu

Navigation


Expert → Sensor → Measured val. → Output values



"Value current output 1 to n" submenu

Navigation

Expert → Sensor → Measured val. → Output values → Current output 1 to n



Output current

Navigation

Expert → Sensor → Measured val. → Output values → Current output 1 to n
→ Output curr.

Description

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measured current

Navigation

Expert → Sensor → Measured val. → Output values → Current output 1 to n
→ Measur. curr.

Description

Displays the actual measured value of the output current.


User interface

0 to 30 mA

"Pulse/frequency/switch output 1 to n" submenu

Navigation

Expert → Sensor → Measured val. → Output values → PFS output 1 to n




Output frequency

| | |
|-----------------------|--|
| Navigation |  Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Output freq. |
| Prerequisite | In the Operating mode parameter (→ 87), the Frequency option is selected. |
| Description | Displays the actual value of the output frequency which is currently measured. |
| User interface | 0.0 to 12 500.0 Hz |

Pulse output

| | |
|-------------------------------|---|
| Navigation |  Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Pulse output |
| Prerequisite | The Pulse option is selected in the Operating mode parameter (→ 87) parameter. |
| Description | Displays the pulse frequency currently output. |
| User interface | Positive floating-point number |
| Additional information | <p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open collector output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. |



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 103) i.e. the transistor does not conduct for the duration of the pulse.


In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 91)) can be configured.

Switch state

| | |
|-------------------------------|---|
| Navigation | Expert → Sensor → Measured val. → Output values → PFS output 1 to n → Switch state |
| Prerequisite | The Switch option is selected in the Operating mode parameter (→ 87). |
| Description | Displays the current switch status of the status output. |
| User interface | <ul style="list-style-type: none"> ▪ Open ▪ Closed |
| Additional information | <p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive. |

"Relay output 1 to n" submenu

Navigation Expert → Sensor → Measured val. → Output values → Relay output 1 to n



Switch state

| | |
|-------------------------------|---|
| Navigation | Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch state |
| Description | Displays the current status of the relay output. |
| User interface | <ul style="list-style-type: none"> ▪ Open ▪ Closed |
| Additional information | <p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The relay output is not conductive. ▪ Closed The relay output is conductive. |

Switch cycles

| | |
|-----------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Switch cycles |
| Description | Displays all the switch cycles performed. |
| User interface | Positive integer |

Max. switch cycles number

| | |
|-----------------------|---|
| Navigation |   Expert → Sensor → Measured val. → Output values → Relay output 1 to n → Max. cycles no. |
| Description | Displays the maximum number of guaranteed switch cycles. |
| User interface | Positive integer |

3.2.2 "System units" submenu

Navigation   Expert → Sensor → System units

 **System units**

| | |
|-------------------|--|
| Total solids unit | →  55 |
| Density unit | →  55 |
| Mass flow unit | →  55 |
| Mass unit | →  56 |
| Volume flow unit | →  56 |
| Temperature unit | →  56 |
| Conductivity unit | →  57 |
| Date/time format | →  57 |

Total solids unit

Navigation  Expert → Sensor → System units → TotalSolidsUnit

Description Select total solids unit.

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------|----------------------|----------------------|
| | ■ %TS | ■ lb/gal (us) |
| | ■ ppm | ■ lb/ft ³ |
| | ■ g/l | |
| | ■ mg/l | |
| | ■ kg/m ³ | |
| | ■ mg/cm ³ | |

Factory setting Depends on country

Density unit



Navigation  Expert → Sensor → System units → Density unit

Description Select density unit.

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------|----------------------|----------------------|
| | ■ g/l | ■ lb/gal (us) |
| | ■ mg/l | ■ lb/ft ³ |
| | ■ kg/m ³ | |
| | ■ mg/cm ³ | |

Factory setting Depends on country

Mass flow unit



Navigation  Expert → Sensor → System units → Mass flow unit

Prerequisite The volume flow of the medium is read in via the Current input 1 to n (→  49).

Description Select mass flow unit.

| Selection | <i>SI units</i> | <i>US units</i> |
|------------------|-----------------|-----------------|
| | ■ kg/h | ■ oz/h |
| | ■ kg/d | ■ oz/d |
| | ■ t/h | ■ lb/h |
| | ■ t/d | ■ lb/d |
| | | ■ STon/h |
| | | ■ STon/d |

Factory setting Depends on country

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit

Prerequisite

The volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Select mass unit.

Selection*SI units*

- kg
- t

US units

- oz
- lb
- STon

Factory setting

Depends on country

Volume flow unit**Navigation**

Expert → Sensor → System units → Volume flow unit

Prerequisite

The volume flow of the medium is read in via the Current input 1 to n (→ 49).

Description

Select volume flow unit.

Selection*SI units*

- l/h
- l/s
- dm³/min
- m³/h
- m³/s

Factory setting

l/h

Temperature unit**Navigation**

Expert → Sensor → System units → Temperature unit

Description

Select temperature unit.

Selection*SI units*

- °C
- K

US units

- °F
- °R

Factory setting

Depends on country

Conductivity unit

| | |
|------------------------|---|
| Navigation | Expert → Sensor → System units → Conductiv. unit |
| Description | Select conductivity unit. |
| Selection | <p><i>SI units</i></p> <ul style="list-style-type: none"> ▪ nS/cm ▪ μS/cm ▪ μS/m ▪ μS/mm ▪ mS/m ▪ mS/cm ▪ S/cm ▪ S/m |
| Factory setting | μ S/cm |

Date/time format

| | |
|------------------------|--|
| Navigation | Expert → Sensor → System units → Date/time format |
| Description | Select date and time format. |
| Selection | <ul style="list-style-type: none"> ▪ dd.mm.yy hh:mm ▪ dd.mm.yy hh:mm am/pm ▪ mm/dd/yy hh:mm ▪ mm/dd/yy hh:mm am/pm |
| Factory setting | dd.mm.yy hh:mm |

3.2.3 "Process parameters" submenu*Navigation*

Expert → Sensor → Process param.

| | |
|--|-------|
| ► Process parameters | |
| Temperature damping | → 58 |
| Conductivity damping | → 58 |
| Total solids override | → 58 |
| ► Total solids monitoring | → 58 |
| ► Partially filled pipe detection | → 60 |

Temperature damping



Navigation

Expert → Sensor → Process param. → Temp. damping

Description

Enter a time constant for damping (PT1 element) of the temperature measured value. Damping reduces the effect of measured value fluctuations.

User entry

0 to 999.9 s

Factory setting

0 s

Conductivity damping



Navigation

Expert → Sensor → Process param. → Conduct. damping

Description

Enter a time constant for damping (PT1 element) of the conductivity measured value. Damping reduces the effect of measured value fluctuations.

User entry

0 to 999.9 s

Factory setting

0 s

Total solids override



Navigation

Expert → Sensor → Process param. → TotalSolOverride

Description

If suppression of the total solids measurement is enabled (**On** option), zero is output for the measured value. This is suitable for the cleaning processes for the pipeline, for example.

Selection

- Off
- On

Factory setting

Off

"Total solids monitoring" submenu

Navigation

Expert → Sensor → Process param. → TotSolidsMonitor

▶ Total solids monitoring

Assign process variable

→ 59

| | |
|-------------------|-------|
| Lower range limit | → 59 |
| Upper range limit | → 59 |
| Response time | → 60 |

Assign process variable



Navigation Expert → Sensor → Process param. → TotSolidsMonitor → Assign variable

Description Select the process variable for total solids monitoring.

Selection
■ Off
■ Total solids

Factory setting Total solids

Lower range limit



Navigation Expert → Sensor → Process param. → TotSolidsMonitor → LowerRangeLimit

Description Enter the lower limit value for the measuring range of the total solids.

User entry Signed floating-point number

Factory setting -1 %TS

Upper range limit



Navigation Expert → Sensor → Process param. → TotSolidsMonitor → UpperRangeLimit

Description Enter the upper limit value for the measuring range of the total solids.

User entry Signed floating-point number

Factory setting 51 %TS

Response time

Navigation Expert → Sensor → Process param. → TotSolidsMonitor → Response time


Description Enter a delay until the diagnostic message is generated in the event the measuring range is exceeded.

User entry 0 to 100 s

Factory setting 60 s

"Partially filled pipe detection" submenu

Navigation Expert → Sensor → Process param. → Partial pipe det

**Partially filled pipe detection**

Navigation Expert → Sensor → Process param. → Partial pipe det → Partial pipe det

Description If activated, a diagnostic message is generated if the antennas are no longer in full contact with the medium.

Selection

- Off
- On

Factory setting Off

Threshold

Navigation Expert → Sensor → Process param. → Partial pipe det → Threshold

Description Enter threshold for partially filled pipe detection. If the measured value drops below the threshold, a diagnostic message is generated.

User entry Decibel as negative floating point number

Factory setting -6 dB

Response time

Navigation Expert → Sensor → Process param. → Partial pipe det → Response time


Description Enter a delay until the diagnostic message is generated in the event the pipe is detected as partially filled.

User entry 0 to 20.0 s

Factory setting 3 s

3.2.4 "External compensation" submenu

Navigation Expert → Sensor → External comp.



Volume flow source

Navigation Expert → Sensor → ExternalProcVar. → VolumeFlowSource

Description Select the input via which the measured value of the volume flow is read in. The volume flow is used to calculate the load rate.

Selection

- Off
- Current input 1 *
- Current input 2 *
- Current input 3 *
- External value

Factory setting Off

Volume flow

Navigation Expert → Sensor → ExternalProcVar. → Volume flow

Description Shows the volume flow reported by the external measuring device.

* Visibility depends on order options or device settings


User entry

Signed floating-point number

3.2.5 "Sensor adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm.



Measuring interval

**Navigation**

Expert → Sensor → Sensor adjustm. → Measur. interval

Description

Displays the interval between two measuring periods.


User interface

0 to 10 000 ms

"Process variable adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm. → Variable adjust



| | |
|------------------|-------|
| Load rate offset | → 65 |
| Load rate factor | → 65 |

Temperature offset



| | |
|------------------------|--|
| Navigation | Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset |
| Description | Enter the offset by which to shift the zero point for temperature. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

Temperature factor



| | |
|------------------------|--|
| Navigation | Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor |
| Description | Enter the multiplication factor to apply to the temperature value. |
| User entry | Positive floating-point number |
| Factory setting | 1 |

Conductivity offset



| | |
|------------------------|---|
| Navigation | Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset |
| Description | Enter the offset by which to shift the zero point for conductivity. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

Conductivity factor



| | |
|--------------------|---|
| Navigation | Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor |
| Description | Enter the multiplication factor to apply to the conductivity value. |
| User entry | Positive floating-point number |

| | |
|------------------------|---|
| Factory setting | 1 |
|------------------------|---|

Corrected conductivity offset 

| | |
|------------------------|--|
| Navigation |   Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.offset |
| Description | Enter the offset by which to shift the zero point for the corrected conductivity. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

Corrected conductivity factor 

| | |
|------------------------|--|
| Navigation |   Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.factor |
| Description | Enter the multiplication factor to apply to the corrected conductivity value. |
| User entry | Positive floating-point number |
| Factory setting | 1 |

Electronics temperature offset 

| | |
|------------------------|--|
| Navigation |   Expert → Sensor → Sensor adjustm. → Variable adjust → ElectrTempOffset |
| Description | Enter the offset by which to shift the zero point for the electronics temperature. |
| User entry | Signed floating-point number |
| Factory setting | 0 |

Electronics temperature factor 

| | |
|------------------------|--|
| Navigation |   Expert → Sensor → Sensor adjustm. → Variable adjust → ElectrTempFactor |
| Description | Enter the multiplication factor to apply to the electronics temperature. |
| User entry | Positive floating-point number |
| Factory setting | 1 |

Load rate offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Load rate offset

Prerequisite The volume flow of the medium is read in via the Current input 1 to n (→ 49).

Description Enter the offset by which to shift the zero point for the load rate.

User entry Signed floating-point number

Factory setting 0

Load rate factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Load rate factor

Prerequisite The volume flow of the medium is read in via the Current input 1 to n (→ 49).


Description Enter the multiplication factor to apply to the load rate value.

User entry Positive floating-point number

Factory setting 1

3.2.6 "Factory adjustment" submenu

Navigation Expert → Sensor → FactoryAdjustm.

**Nominal diameter**

Navigation Expert → Sensor → FactoryAdjustm. → Nominal diameter

Description Shows the nominal diameter of the sensor.

User interface Character string comprising numbers, letters and special characters

Date/time**Navigation**

Expert → Sensor → FactoryAdjustm. → Date/time

Description

Shows the date and time of the factory adjustment.


User interface

Character string comprising numbers, letters and special characters

3.3 "I/O configuration" submenu

Navigation

Expert → I/O config.



I/O module 1 to n terminal numbers**Navigation**

Expert → I/O config. → I/O 1 to n terminals

Description

Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

I/O module 1 to n information**Navigation**

Expert → I/O config. → I/O 1 to n info

Description

Displays information about the plugged in I/O module.

| | |
|-----------------------|--|
| User interface | <ul style="list-style-type: none"> ■ Not plugged ■ Invalid ■ Not configurable ■ Configurable ■ HART |
|-----------------------|--|

| | |
|-------------------------------|---|
| Additional information | <p><i>"Not plugged"</i> option The I/O module is not plugged in.</p> <p><i>"Invalid"</i> option The I/O module is not plugged correctly.</p> <p><i>"Not configurable"</i> option The I/O module is not configurable.</p> <p><i>"Configurable"</i> option The I/O module is configurable.</p> <p><i>"Fieldbus"</i> option The I/O module is configured for HART.</p> |
|-------------------------------|---|

I/O module 1 to n type



| | |
|------------------------|---|
| Navigation | Expert → I/O config. → I/O 1 to n type |
| Prerequisite | For the following order code: <ul style="list-style-type: none"> ■ "Output; input 2", option D "Configurable I/O initial setting off" ■ "Output; input 3", option D "Configurable I/O initial setting off" |
| Description | Use this function to select the I/O module type for the configuration of the I/O module. |
| Selection | <ul style="list-style-type: none"> ■ Off ■ Current output * ■ Current input * ■ Status input * ■ Pulse/frequency/switch output * ■ Relay output |
| Factory setting | Off |

Apply I/O configuration



| | |
|--------------------|---|
| Navigation | Expert → I/O config. → Apply I/O config |
| Description | Use this function to activate the newly configured I/O module type. |

* Visibility depends on order options or device settings

Selection ■ No
 ■ Yes

Factory setting No

I/O alteration code

Navigation ☰ ☱ Expert → I/O config. → I/O alterat.code

Description Use this function to enter the ordered activation code to activate the I/O configuration change.

User entry Positive integer


Factory setting 0

Additional information *Description*

The I/O configuration is changed in the **I/O module type** parameter (→ ☰ 67).


3.4 "Input" submenu

Navigation ☰ ☱ Expert → Input



3.4.1 "Current input 1 to n" submenu

Navigation ☰ ☱ Expert → Input → Current input 1 to n



| | |
|---------------|--|
| Failure mode | →  71 |
| Failure value | →  71 |

Terminal number

| | |
|-------------------------------|--|
| Navigation |  Expert → Input → Current input 1 to n → Terminal no. |
| Description | Displays the terminal numbers used by the current input module. |
| User interface | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 22-23 (I/O 3) |
| Additional information | <p><i>"Not used"</i> option</p> <p>The current input module does not use any terminal numbers.</p> |

Signal mode



| | |
|------------------------|---|
| Navigation |  Expert → Input → Current input 1 to n → Signal mode |
| Description | Use this function to select the signal mode for the current input. |
| Selection | <ul style="list-style-type: none"> ■ Passive ■ Active * |
| Factory setting | Passive |

Current span



| | |
|--------------------|--|
| Navigation |  Expert → Input → Current input 1 to n → Current span |
| Description | Use this function to select the current range for the process value output and the upper and lower level for signal on alarm. |
| Selection | <ul style="list-style-type: none"> ■ 4...20 mA (4...20.5 mA) ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 0...20 mA (0...20.5 mA) |

* Visibility depends on order options or device settings

Factory setting

Country-specific:
■ 4...20 mA NE (3.8...20.5 mA)
■ 4...20 mA US (3.9...20.8 mA)

Additional information*Examples*

 Sample values for the current range: **Current span** parameter (→ [75](#))

0/4 mA value**Navigation**

  Expert → Input → Current input 1 to n → 0/4 mA value

Description

Enter 4 mA value.

User entry

Signed floating-point number

Factory setting

0 % TS

Additional information*Current input behavior*

The current input behaves differently depending on the settings configured in the following parameters:

- Current span (→ [69](#))
- Failure mode (→ [71](#))

Configuration examples

 Pay attention to the configuration examples for **4 mA value** parameter (→ [77](#)).

20 mA value**Navigation**

  Expert → Input → Current input 1 to n → 20 mA value

Description

Enter 20 mA value.

User entry

Signed floating-point number

Factory setting

12 %TS

Additional information*Configuration examples*

 Pay attention to the configuration examples for **4 mA value** parameter (→ [77](#)).

Failure mode**Navigation**

Expert → Input → Current input 1 to n → Failure mode

Description

Use this function to select the input behavior when measuring a current outside the configured **Current span** parameter (→ [69](#)).

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information*Options*

- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used (**Failure value** parameter (→ [71](#))).

Failure value**Navigation**

Expert → Input → Current input 1 to n → Failure value

Prerequisite

In the **Failure mode** parameter (→ [71](#)), the **Defined value** option is selected.

Description

Use this function to enter the value that the device uses if it does not receive an input signal from the external device, or if the input signal is invalid.

User entry

Signed floating-point number

Factory setting

0

3.4.2 "Status input 1 to n" submenu*Navigation*

Expert → Input → Status input 1 to n

| | |
|------------------------------|----------------------|
| ► Status input 1 to n | |
| Terminal number | → 72 |
| Assign status input | → 72 |
| Value status input | → 73 |

| | |
|----------------------------|-------|
| Active level | → 73 |
| Response time status input | → 73 |

Terminal number

Navigation Expert → Input → Status input 1 to n → Terminal no.

Description Displays the terminal numbers used by the status input module.

- User interface**
- Not used
 - 24-25 (I/O 2)
 - 22-23 (I/O 3)

- Additional information** "Not used" option
The status input module does not use any terminal numbers.

Assign status input



Navigation Expert → Input → Status input 1 to n → Assign stat.inp.

Description Use this function to select the function for the status input.

- Selection**
- Off
 - Reset totalizer 1
 - Flow override

Factory setting Off

- Additional information** Options
- Off
The status input is switched off.
 - Reset totalizer 1
The totalizer is reset.
 - Flow override
The Flow override is activated.
- Note on the Flow override:
 - The Flow override is enabled as long as the level is at the status input (continuous signal).
 - All other assignments react to a change in level (pulse) at the status input.

Value status input

Navigation  Expert → Input → Status input 1 to n → Val.stat.inp.

Description Displays the current input signal level.

User interface

- High
- Low

Active level



Navigation  Expert → Input → Status input 1 to n → Active level

Description Use this function to determine the input signal level at which the assigned function is activated.

Selection

- High
- Low

Factory setting High

Response time status input



Navigation  Expert → Input → Status input 1 to n → Response time

Description Use this function to enter the minimum time period for which the input signal level must be present before the selected function is activated.


User entry 5 to 200 ms

Factory setting 50 ms

3.5 "Output" submenu

Navigation  Expert → Output

 ► Output

 ► Current output 1 to n

→  74

| | |
|---|--------|
| ► Pulse/frequency/switch output 1 to n | → 85 |
| ► Relay output 1 to n | → 103 |

3.5.1 "Current output 1 to n" submenu

Navigation

Expert → Output → Curr.output 1 to n

| | |
|---------------------------------|-------|
| ► Current output 1 to n | |
| Terminal number | → 74 |
| Signal mode | → 75 |
| Process variable current output | → 75 |
| Current range output | → 75 |
| Fixed current | → 76 |
| Lower range value output | → 77 |
| Upper range value output | → 78 |
| Measuring mode current output | → 78 |
| Damping current output | → 83 |
| Failure behavior current output | → 83 |
| Failure current | → 84 |
| Output current | → 84 |
| Measured current | → 85 |

Terminal number

Navigation

Expert → Output → Curr.output 1 to n → Terminal no.

Description

Displays the terminal numbers used by the current output module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information*"Not used" option*

The current output module does not use any terminal numbers.

Signal mode**Navigation**

Expert → Output → Curr.output 1 to n → Signal mode

Description

Use this function to select the signal mode for the current output.

Selection

- Active ^{*}
- Passive ^{*}

Factory setting

Active

Process variable current output**Navigation**

Expert → Output → Curr.output 1 to n → Proc.var. outp

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Use this function to select a process variable for the current output.

Selection

- Off
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity
- Load rate ^{*}

Factory setting

Total solids

Current range output**Navigation**

Expert → Output → Curr.output 1 to n → Curr.range out

Description

Select current range for process value output and upper/lower level for alarm signal.

Selection

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)
- Fixed value

* Visibility depends on order options or device settings

Factory setting

Depends on country:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Additional information*Description*


- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 83).
- The measuring range is specified via the **Lower range value output** parameter (→ 77) and **Upper range value output** parameter (→ 78).

"Fixed current" option

- This option is used for a HART Multidrop network.
- It can only be used for the 4...20 mA HART current output (current output 1).
- The current value is set via the **Fixed current** parameter (→ 76).

Example

Shows the relationship between the current range for the output of the process value and the two signal on alarm levels:



A0034351

- 1 Current range for process value
2 Lower level for signal on alarm
3 Upper level for signal on alarm

Selection

| Selection | 1 | 2 | 3 |
|------------------------------|-------------------|----------|------------|
| 4...20 mA NE (3.8...20.5 mA) | 3.8 to 20.5 mA | < 3.6 mA | > 21.95 mA |
| 4...20 mA US (3.9...20.8 mA) | 3.9 to 20.8 mA US | < 3.6 mA | > 21.95 mA |
| 4...20 mA (4...20.5 mA) | 4 to 20.5 mA | < 3.6 mA | > 21.95 mA |
| 0...20 mA (0...20.5 mA) | 0 to 20.5 mA | 0 mA | > 21.95 mA |

Fixed current**Navigation**

Expert → Output → Curr.output 1 to n → Fixed current

Prerequisite

The **Fixed current** option is selected in the **Current span** parameter (→ 75).

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Lower range value output**Navigation**

Expert → Output → Curr.output 1 to n → Low.range outp

Prerequisite

In **Current span** parameter (→ 75), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a value for the start of measuring range.

User entry

Floating point number with sign

Factory setting

0 %TS

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 75). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **Upper range value output** parameter (→ 78).


Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 75).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 75)
- Failure mode (→ 83)

Configuration examples

Q Flow

I Current

1 Measuring range is exceeded or undershot

Upper range value output



Navigation

Expert → Output → Curr.output 1 to n → Upp.range outp

Prerequisite

In **Current span** parameter (→ 75), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a value for the end of measuring range.

User entry

Floating point number with sign

Factory setting

12 %TS

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 75). In addition, the value can be greater than or smaller than the value assigned for the 0/4 mA current in the **Lower range value output** parameter (→ 77).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 75).

Example

Configuration examples

Pay attention to the configuration examples for the **Lower range value output** parameter (→ 77).

Measuring mode current output



Navigation

Expert → Output → Curr.output 1 to n → Output mode

Prerequisite

The following option is selected in the **Process variable current output** parameter (→ 75):

Load rate

One of the following options is selected in the **Current span** parameter (→ 75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse flow *
- Reverse flow compensation

Factory setting

Forward flow

Additional information*Description*

 The process variable that is assigned to the current output via the **Assign current output** parameter (→ 75) is displayed below the parameter.


"Forward flow" option

The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the **Lower range value output** parameter (→ 77) and the **Upper range value output** parameter (→ 78).

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Both values are defined such that they are not equal to zero flow e.g.:

- Start of measuring range = -50 kg/h
- End of measuring range = 100 kg/h

"Forward/Reverse flow" option

- | | |
|---|--|
| I | Current |
| Q | Flow |
| 1 | Start of measuring range output (0/4 mA) |
| 2 | Forward flow |
| 3 | Reverse flow |

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **Lower range value output** parameter (→ 77) and **Upper range value output** parameter (→ 78) must have the same sign.
- The value for the **Upper range value output** parameter (→ 78) (e.g. reverse flow) corresponds to the mirrored value for the **Upper range value output** parameter (→ 78) (e.g. forward flow).

"Reverse flow compensation" option

The **Reverse flow compensation** option is primarily used to compensate for intermittent reverse flow that can arise with displacement pumps due to wear or high-viscosity medium. The reverse flow is recorded in a buffer memory and offset against the next forward flow.

In the event of prolonged and undesired reverse flow, flow values can accumulate in the buffer memory. Due to the configuration of the current output, these values are not factored in, however, i.e. there is no compensation for the reverse flow.

* Visibility depends on order options or device settings

If this option is set, the measuring device does not smoothen the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1

Defined measuring range: lower range value and upper range value with the **same** sign




Fig 2 Measuring range

I Current

Q Flow

1 Lower range value (Start of measuring range output)

2 Upper range value (end of measuring range output)

With the following flow response:





Fig 3 Flow response

Q Flow

t Time

With **Forward** flow option

The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output:




I Current

t Time

With **Forward/Reverse** flow option


The current output signal is independent of the direction of flow.



I Current
t Time

With Reverse flow compensation option


Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.



I Current
t Time
S Flow components saved
A Balancing of saved flow components


Example 2

Defined measuring range: lower range value and upper range value with **different** signs



4 Measuring range
I Current
Q Flow
 1 Lower range value (Start of measuring range output)
 2 Upper range value (end of measuring range output)

With flow a (–) outside, b (- -) inside the measuring range




A0028098

Q Flow
 t Time
 1 Lower range value (Start of measuring range output)
 2 Upper range value (end of measuring range output)

With **Forward flow** option

- a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output.
- b (---): The current output signal is proportional to the process variable assigned.



A0028100


I Current
 t Time

With **Forward/Reverse flow** option

This option cannot be selected here since the values for the **Lower range value output** parameter (→ 77) and **Upper range value output** parameter (→ 78) have different signs.

With **Reverse flow compensation** option

Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.



A0028101

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping current output**Navigation**

Expert → Output → Curr.output 1 to n → Damp.curr.outp

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ 75) and one of the following options is selected in the **Current span** parameter (→ 75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

1.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element²⁾) for current output damping:

- If a low time constant is entered, the current output reacts quickly to fluctuating measured variables.
- If a high time constant is entered, the current output reacts more slowly.

Damping is switched off if **0** is entered (factory setting).

Failure behavior current output**Navigation**

Expert → Output → Curr.output 1 to n → Failure behav.

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ 75) and one of the following options is selected in the **Current span** parameter (→ 75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Fixed value

Factory setting

Max.

2) proportional transmission behavior with first order delay

Additional information**Description**

 This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  75).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  75).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (→  84).

Failure current**Navigation**

  Expert → Output → Curr.output 1 to n → Fail. current

Prerequisites

The **Defined value** option is selected in the **Failure mode** parameter (→  83).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output current**Navigation**

  Expert → Output → Curr.output 1 to n → Output curr.

Description

Displays the current value currently calculated for the current output.

User interface

3.59 to 22.5 mA

Measured current

Navigation  Expert → Output → Curr.output 1 to n → Measur. curr.

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA

3.5.2 "Pulse/frequency/switch output 1 to n" submenu

Navigation

 Expert → Output → PFS output 1 to n

|  Pulse/frequency/switch output 1 to n | |
|---|--|
| Terminal number | →  86 |
| Signal mode | →  87 |
| Operating mode | →  87 |
| Assign pulse output | →  88 |
| Pulse scaling | →  89 |
| Pulse width | →  89 |
| Measuring mode | →  90 |
| Failure mode | →  91 |
| Pulse output | →  91 |
| Assign frequency output | →  92 |
| Minimum frequency value | →  92 |
| Maximum frequency value | →  93 |
| Measuring value at minimum frequency | →  93 |
| Measuring value at maximum frequency | →  93 |
| Measuring mode | →  94 |

| | |
|-----------------------------|--------|
| Damping output | → 94 |
| Response time | → 95 |
| Failure mode | → 95 |
| Failure frequency | → 96 |
| Output frequency | → 96 |
| Switch output function | → 96 |
| Assign diagnostic behavior | → 97 |
| Assign limit | → 98 |
| Switch-on value | → 100 |
| Switch-off value | → 100 |
| Assign flow direction check | → 101 |
| Assign status | → 101 |
| Switch-on delay | → 101 |
| Switch-off delay | → 102 |
| Failure mode | → 102 |
| Switch state | → 102 |
| Invert output signal | → 103 |

Terminal number

Navigation

Expert → Output → PFS output 1 to n → Terminal no.

Description

Displays the terminal numbers used by the pulse/frequency/switch output module.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information

"Not used" option

The pulse/frequency/switch output module does not use any terminal numbers.

Signal mode**Navigation**

Expert → Output → PFS output 1 to n → Signal mode

Description

Use this function to select the signal mode for the pulse/frequency/switch output.

Selection

- Passive
- Active *
- Passive NE

Factory setting

Passive

Operating mode**Navigation**

Expert → Output → PFS output 1 to n → Operating mode

PrerequisiteIf the **Pulse** option is selected, the **Load rate** option must be selected in the **Assign pulse output** parameter (→ 88).**Description**

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting


Pulse

Additional information*"Pulse" option*

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1000 Impuls/s

* Visibility depends on order options or device settings



5 Quantity-proportional pulse (pulse value) with pulse width to be configured


B Pulse width entered

P Pauses between the individual pulses

"Frequency" option

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz



6 Flow-proportional frequency output

Assign pulse output



Navigation

Expert → Output → PFS output 1 to n → Assign pulse

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Prerequisite

The **Pulse** option is selected in **Operating mode** parameter (→ 87).

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Load rate *

Factory setting

Off

* Visibility depends on order options or device settings

Pulse scaling**Navigation**

Expert → Output → PFS output 1 to n → Pulse scaling

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 87) and a process variable is selected in the **Assign pulse output** parameter (→ 88).

Description

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating point number

Factory setting

Depends on country and nominal diameter

Additional information*User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width**Navigation**

Expert → Output → PFS output 1 to n → Pulse width

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 87) and a process variable is selected in the **Assign pulse output** parameter (→ 88).

Description

Use this function to enter the duration of the output pulse.

User entry


0.05 to 2 000 ms

Factory setting

100 ms

Additional information*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{max} = f_{max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the **443 Pulse output 1 to n** diagnostic message.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation

Expert → Output → PFS output 1 to n → Measuring mode

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Options

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Reverse flow compensation
The flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

i For a detailed description of the options available, see the **Measuring mode** parameter (→ 78)

Examples

i For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 78)

Failure mode**Navigation**

Expert → Output → PFS output 1 to n → Failure mode

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 87) and a process variable is selected in the **Assign pulse output** parameter (→ 88).

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

Options

- Actual value

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

- No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The **Actual value** option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.

Pulse output**Navigation**

Expert → Output → PFS output 1 to n → Pulse output

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 87) parameter.

Description

Displays the pulse frequency currently output.


User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.

This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.



- 0 Non-conductive
- 1 Conductive
- NC NC contact (normally closed)
- NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 103) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 91)) can be configured.

Assign frequency output



Navigation

Expert → Output → PFS output 1 to n → Assign freq.

Prerequisite

- The **Frequency** option is selected in **Operating mode** parameter (→ 87).
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity
- Load rate *

Factory setting

Off

Minimum frequency value



Navigation

Expert → Output → PFS output 1 to n → Min. freq. value

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 87) and a process variable is selected in the **Assign frequency output** parameter (→ 92).

Description

Use this function to enter the minimum frequency.

User entry

0.0 to 10 000.0 Hz

* Visibility depends on order options or device settings

| | |
|-----------------|--------|
| Factory setting | 0.0 Hz |
|-----------------|--------|

Maximum frequency value



| | |
|-----------------|--|
| Navigation | Expert → Output → PFS output 1 to n → Max. freq. value |
| Prerequisite | The Frequency option is selected in the Operating mode parameter (→ 87) and a process variable is selected in the Assign frequency output parameter (→ 92). |
| Description | Use this function to enter the end value frequency. |
| User entry | 0.0 to 10 000.0 Hz |
| Factory setting | 10 000.0 Hz |

Measuring value at minimum frequency



| | |
|------------------------|--|
| Navigation | Expert → Output → PFS output 1 to n → Val. at min.freq |
| Prerequisite | The Frequency option is selected in the Operating mode parameter (→ 87) and a process variable is selected in the Assign frequency output parameter (→ 92). |
| Description | Use this function to enter the measured value for the start value frequency. |
| User entry | Signed floating-point number |
| Factory setting | Depends on country and nominal diameter |
| Additional information | <i>Dependency</i> The entry depends on the process variable selected in the Assign frequency output parameter (→ 92). |

Measuring value at maximum frequency



| | |
|-----------------|--|
| Navigation | Expert → Output → PFS output 1 to n → Val. at max.freq |
| Prerequisite | The Frequency option is selected in the Operating mode parameter (→ 87) and a process variable is selected in the Assign frequency output parameter (→ 92). |
| Description | Use this function to enter the measured value for the end value frequency. |
| User entry | Signed floating-point number |
| Factory setting | Depends on country and nominal diameter |

Additional information*Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

 The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 92).

Measuring mode**Navigation**

  Expert → Output → PFS output 1 to n → Measuring mode

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information*Options*

 For a detailed description of the options available, see the **Measuring mode** parameter (→ 78)

Examples

 For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 78)

Damping output**Navigation**

  Expert → Output → PFS output 1 to n → Damping out.

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element³⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time**Navigation**

Expert → Output → PFS output 1 to n → Response time

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ [87](#)) and an option is selected in the **Assign frequency output** parameter (→ [92](#)).

Description

Shows how quickly the output reaches 63% of a measured value change.

User interface

Positive floating-point number

Factory setting

0 s

Failure mode**Navigation**

Expert → Output → PFS output 1 to n → Failure mode

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ [87](#)) and a process variable is selected in the **Assign frequency output** parameter (→ [92](#)).

Description

Use this function to select the failure mode of the frequency output in the event of a device alarm.

Selection

- Actual value
- Defined value
- 0 Hz

Factory setting

0 Hz

3) proportional transmission behavior with first order delay

Additional information*Options*

■ Actual value

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

■ Defined value

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→ 96) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

■ 0 Hz

In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The **Actual value** option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.

Failure frequency**Navigation**

Expert → Output → PFS output 1 to n → Failure freq.

Prerequisite

In the **Operating mode** parameter (→ 87), the **Frequency** option is selected, in the **Assign frequency output** parameter (→ 92) a process variable is selected, and in the **Failure mode** parameter (→ 95), the **Defined value** option is selected.

Description

Enter frequency output value in alarm condition.

User entry

0.0 to 12 500.0 Hz

Factory setting

0.0 Hz

Output frequency**Navigation**

Expert → Output → PFS output 1 to n → Output freq.

Prerequisite

In the **Operating mode** parameter (→ 87), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Switch output function**Navigation**

Expert → Output → PFS output 1 to n → Switch out funct

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 87).

| | |
|-------------------------------|--|
| Description | Use this function to select a function for the switch output. |
| Selection | <ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diagnostic behavior ▪ Limit ▪ Flow direction check ▪ Status |
| Factory setting | Off |
| Additional information | <ul style="list-style-type: none"> ▪ Off The switch output is permanently switched off (open, non-conductive). ▪ On The switch output is permanently switched on (closed, conductive). ▪ Diagnostic behavior The switch output is switched on (closed, conductive), if there is a pending diagnostic event of the assigned behavioral category. ▪ Limit The switch output is switched on (closed, conductive), if a limit value specified for the process variable is reached. ▪ Flow direction check The switch output is switched on (closed, conductive), when the flow direction changes (forward or reverse flow). ▪ Status The switch output is switched on (closed/conductive) to display the device status for the selected detection method, e.g. empty pipe detection. |

Assign diagnostic behavior



| | |
|------------------------|---|
| Navigation | Expert → Output → PFS output 1 to n → Assign diag. beh |
| Prerequisite | <ul style="list-style-type: none"> ▪ In the Operating mode parameter (→ 87), the Switch option is selected. ▪ In the Switch output function parameter (→ 96), the Diagnostic behavior option is selected. |
| Description | Use this function to select the diagnostic event category that is displayed for the switch output. |
| Selection | <ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning |
| Factory setting | Alarm |

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to n → Assign limit

Prerequisite

- The **Switch** option is selected in **Operating mode** parameter (→ 87).
- The **Limit** option is selected in **Switch output function** parameter (→ 96).
- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity *
- Load rate *
- Totalizer 1 *

Factory setting


Temperature

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive


* Visibility depends on order options or device settings



- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:


- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive



- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value**Navigation**

Expert → Output → PFS output 1 to n → Switch-on value

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 87).
- The **Limit** option is selected in the **Switch output function** parameter (→ 96).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Floating point number with sign

Factory setting

0 °C

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 98).

Switch-off value**Navigation**

Expert → Output → PFS output 1 to n → Switch-off value

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 87).
- The **Limit** option is selected in the **Switch output function** parameter (→ 96).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Floating point number with sign

Factory setting

0 °C

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 98).

Assign flow direction check

**Navigation**

Expert → Output → PFS output 1 to n → Assign dir.check

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 87).
- The **Flow direction check** option is selected in the **Switch output function** parameter (→ 96).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection**Factory setting**

Off

Assign status

**Navigation**

Expert → Output → PFS output 1 to n → Assign status

Prerequisite

- The **Switch** option is selected in **Operating mode** parameter (→ 87).
- The **Status** option is selected in **Switch output function** parameter (→ 96).

Description

Select the device function whose status you want to display.

Selection

- Off
- Partially filled pipe detection

Factory setting

Partially filled pipe detection

Additional information*Options*

When the switch-on point for the selected device function is reached, the output is switched on (closed, conductive). Otherwise, the output is non-conductive.

Switch-on delay

**Navigation**

Expert → Output → PFS output 1 to n → Switch-on delay

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 87).
- The **Limit** option is selected in the **Switch output function** parameter (→ 96).

Description

Use this function to enter a delay time for switching on the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Switch-off delay



Navigation Expert → Output → PFS output 1 to n → Switch-off delay

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 87).
- The **Limit** option is selected in the **Switch output function** parameter (→ 96).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode



Navigation Expert → Output → PFS output 1 to n → Failure mode

Description Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting Open

Additional information *Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch state

Navigation Expert → Output → PFS output 1 to n → Switch state

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (→ 87).

Description Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal**Navigation**

Expert → Output → PFS output 1 to n → Invert outp.sig.

Description

Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting


No

Additional information*Selection*

No option (passive - negative)



Yes option (passive - positive)

**3.5.3 "Relay output 1 to n" submenu***Navigation*

Expert → Output → Relay output 1 to n

| | |
|------------------------------|--------|
| ► Relay output 1 to n | |
| Terminal number | → 104 |
| Relay output function | → 104 |
| Assign flow direction check | → 105 |

| | |
|----------------------------|--------|
| Assign limit | → 105 |
| Assign diagnostic behavior | → 106 |
| Assign status | → 106 |
| Switch-off value | → 107 |
| Switch-off delay | → 107 |
| Switch-on value | → 107 |
| Switch-on delay | → 108 |
| Failure mode | → 108 |
| Switch state | → 109 |
| Powerless relay status | → 109 |

Terminal number

Navigation

Expert → Output → Relay output 1 to n → Terminal no.

Description

Displays the terminal numbers used by the relay output module.

User interface

- Not used
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Additional information

"Not used" option

The relay output module does not use any terminal numbers.

Relay output function



Navigation

Expert → Output → Relay output 1 to n → Relay outp.func.

Description

Use this function to select an output function for the relay output.

Selection

- Closed
- Open
- Diagnostic behavior
- Limit
- Flow direction check
- Status

| | |
|-------------------------------|---|
| Factory setting | Closed |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Closed The relay output is permanently switched on (closed, conductive). ■ Open The relay output is permanently switched off (open, non-conductive). ■ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ■ Flow direction check Indicates the flow direction (forward or reverse flow). ■ Digital Output Indicates the device status depending on whether empty pipe detection or low flow cut off is selected. |

Assign flow direction check



| | |
|------------------------|---|
| Navigation | Expert → Output → Relay output 1 to n → Assign dir.check |
| Prerequisite | The Flow direction check option is selected in the Relay output function parameter (→ 104). |
| Description | Use this function to select a process variable for monitoring the flow direction. |
| Selection | |
| Factory setting | Off |

Assign limit



| | |
|---------------------|--|
| Navigation | Expert → Output → Relay output 1 to n → Assign limit |
| Prerequisite | <ul style="list-style-type: none"> ■ The Limit option is selected in Relay output function parameter (→ 104). ■ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus. |
| Description | Use this function to select a process variable for the limit value function. |
| Selection | <ul style="list-style-type: none"> ■ Off ■ Total solids ■ Temperature ■ Electronics temperature ■ Conductivity |

- Corrected conductivity
- Load rate *
- Totalizer 1 *

Factory setting Temperature

Assign diagnostic behavior



Navigation Expert → Output → Relay output 1 to n → Assign diag. beh

Prerequisite In the **Relay output function** parameter (→ 104), the **Diagnostic behavior** option is selected.

Description Use this function to select the category of the diagnostic events that are displayed for the relay output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting Alarm

Additional information *Description*

If no diagnostic event is pending, the relay output is closed and conductive.

Selection

- Alarm
The relay output signals only diagnostic events in the alarm category.
- Alarm or warning
The relay output signals diagnostic events in the alarm and warning category.
- Warning
The relay output signals only diagnostic events in the warning category.

Assign status



Navigation Expert → Output → Relay output 1 to n → Assign status

Prerequisite In the **Relay output function** parameter (→ 104), the **Digital Output** option is selected.

Description Use this function to select the device status for the relay output.

Selection

- Off
- Partially filled pipe detection

Factory setting Off

* Visibility depends on order options or device settings

Switch-off value

| | |
|-------------------------------|---|
| Navigation | Expert → Output → Relay output 1 to n → Switch-off value |
| Prerequisite | The Limit option is selected in the Relay output function parameter (→ 104). |
| Description | Use this function to enter the measured value for the switch-off point. |
| User entry | Floating point number with sign |
| Factory setting | 0 °C |
| Additional information | <i>Description</i> Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive). When using a hysteresis: Switch-on value > Switch-off value. |
| | <i>Dependency</i> The unit is dependent on the process variable selected in the Assign limit parameter (→ 105). |

Switch-off delay

| | |
|------------------------|--|
| Navigation | Expert → Output → Relay output 1 to n → Switch-off delay |
| Prerequisite | In the Relay output function parameter (→ 104), the Limit option is selected. |
| Description | Use this function to enter a delay time for switching off the switch output. |
| User entry | 0.0 to 100.0 s |
| Factory setting | 0.0 s |

Switch-on value

| | |
|------------------------|---|
| Navigation | Expert → Output → Relay output 1 to n → Switch-on value |
| Prerequisite | The Limit option is selected in the Relay output function parameter (→ 104). |
| Description | Use this function to enter the measured value for the switch-on point. |
| User entry | Floating point number with sign |
| Factory setting | 0 °C |

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit is dependent on the process variable selected in the **Assign limit** parameter (→ 105).

Switch-on delay**Navigation**

Expert → Output → Relay output 1 to n → Switch-on delay

Prerequisite

In the **Relay output function** parameter (→ 104), the **Limit** option is selected.

Description

Use this function to enter a delay time for switching on the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Failure mode**Navigation**

Expert → Output → Relay output 1 to n → Failure mode

Description

Use this function to select the failure mode of the relay output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Selection*

- Actual status

In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the relay output. The **Actual status** option behaves in the same way as the current input value.

- Open

In the event of a device alarm, the relay output's transistor is set to **non-conductive**.

- Closed

In the event of a device alarm, the relay output's transistor is set to **conductive**.

Switch state

Navigation  Expert → Output → Relay output 1 to n → Switch state

Description Displays the current status of the relay output.

User interface

- Open
- Closed

Additional information *User interface*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

Powerless relay status 

Navigation  Expert → Output → Relay output 1 to n → Powerless relay

Description Use this function to select the quiescent state for the relay output.

Selection

- Open
- Closed

Factory setting Open

Additional information *Selection*

- Open
The relay output is not conductive.
- Closed
The relay output is conductive.

3.6 "Communication" submenu


Navigation  Expert → Communication

| | |
|---|---|
|  Communication | |
|  HART input | →  110 |
|  HART output | →  115 |
|  Diagnostic configuration | →  131 |
|  Web server | →  135 |

3.6.1 "HART input" submenu

Navigation


Expert → Communication → HART input



"Configuration" submenu

Navigation

Expert → Communication → HART input → Configuration



Capture mode



Navigation

Expert → Communication → HART input → Configuration → Capture mode

Description

Use this function to select the capture mode via burst or master communication.

Selection

- Off
- Burst network
- Master network

Factory setting

Off

Additional information*"Burst network" option*

The device records data transmitted via burst in the network.

"Master network" option

In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.

Device ID**Navigation**

④⑤ Expert → Communication → HART input → Configuration → Device ID

Prerequisite

The **Master network** option is selected in the **Capture mode** parameter (→ 110).

Description

Use this function to enter the device ID of the HART slave device whose data are to be recorded.

User entry

6-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting

0

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type**Navigation**

④⑤ Expert → Communication → HART input → Configuration → Device type

Prerequisite

In the **Capture mode** parameter (→ 110), the **Master network** option is selected.

Description

Use this function to enter the device type of the HART slave device whose data are to be recorded.

User entry

2-digit hexadecimal number

Factory setting

0x00

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Manufacturer ID**Navigation**

Expert → Communication → HART input → Configuration → Manufacturer ID

Prerequisite

The **Master network** option is selected in the **Capture mode** parameter (→ [110](#)).

Description

Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.

User entry

2-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting

0

Additional information

In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Burst command**Navigation**

Expert → Communication → HART input → Configuration → Burst command

Prerequisite

The **Burst network** option or the **Master network** option are selected in the **Capture mode** parameter (→ [110](#)).

Description

Use this function to select the burst command to be recorded.

Selection

- Command 1
- Command 3
- Command 9
- Command 33

Factory setting

Command 1

Additional information

Selection

- Command 1
Use this function to capture the primary variable.
- Command 3
Use this function to capture the dynamic HART variables and the current.
- Command 9
Use this function to capture the dynamic HART variables including the associated status.
- Command 33
Use this function to capture the dynamic HART variables including the associated unit.

Slot number

Navigation Expert → Communication → HART input → Configuration → Slot number

Prerequisite The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→ 110).

Description Use this function to enter the position of the process variable to be recorded in the burst command.

User entry 1 to 8

Factory setting 1

Additional information *User entry*

| Slot | Command | | | |
|------|---------|----|------------------------|------------------------|
| | 1 | 3 | 9 | 33 |
| 1 | PV | PV | HART variable (slot 1) | HART variable (slot 1) |
| 2 | – | SV | HART variable (slot 2) | HART variable (slot 2) |
| 3 | – | TV | HART variable (slot 3) | HART variable (slot 3) |
| 4 | – | QV | HART variable (slot 4) | HART variable (slot 4) |

Timeout

Navigation Expert → Communication → HART input → Configuration → Timeout

Prerequisite The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→ 110).

Description Use this function to enter the maximum permitted interval between two HART frames.

User entry 1 to 120 s

Factory setting 5 s

Additional information *Description*

If the interval is exceeded, the measuring device displays the **F882 Input signal** diagnostic message.

Failure mode

Navigation Expert → Communication → HART input → Configuration → Failure mode

Prerequisite In the **Capture mode** parameter (→ 110), the **Burst network** option or **Master network** option is selected.

| | |
|-------------------------------|---|
| Description | Use this function to select the device behavior if no data are recorded within the maximum permitted interval. |
| Selection | <ul style="list-style-type: none"> ■ Alarm ■ Last valid value ■ Defined value |
| Factory setting | Alarm |
| Additional information | <p><i>Options</i></p> <ul style="list-style-type: none"> ■ Alarm An error message is set. ■ Last valid value The last valid measured value is used. ■ Defined value A user-defined measured value is used: (Failure value parameter (→ 114)). |

Failure value

Navigation Expert → Communication → HART input → Configuration → Failure value

Prerequisite

The following conditions are met:

- In the **Capture mode** parameter (→ 110), the **Burst network** option or **Master network** option is selected.
- In the **Failure mode** parameter (→ 113), the **Defined value** option is selected.

Description

Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.

User entry

Signed floating-point number

Factory setting

0

"Input" submenu

Navigation

Expert → Communication → HART input → Input

| | | | | |
|--|-------|-------|--------|-------|
| ▶ Input | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">Value</td> <td style="padding: 5px; text-align: right;">→ 115</td> </tr> <tr> <td style="padding: 5px;">Status</td> <td style="padding: 5px; text-align: right;">→ 115</td> </tr> </table> | Value | → 115 | Status | → 115 |
| Value | → 115 | | | |
| Status | → 115 | | | |

Value

Navigation  Expert → Communication → HART input → Input → Value

Description Displays the value of the device variable recorded by the HART input.

User interface Signed floating-point number

Status

Navigation  Expert → Communication → HART input → Input → Status

Description Displays the value of the device variable recorded by the HART input in accordance with the HART specification.


User interface

- Manual/Fixed
- Good
- Poor accuracy
- Bad

3.6.2 "HART output" submenu

Navigation


 Expert → Communication → HART output



"Configuration" submenu

Navigation

 Expert → Communication → HART output → Configuration



| | |
|-------------------------|---|
| HART address | →  116 |
| No. of preambles | →  117 |
| Fieldbus writing access | →  117 |

HART short tag

| | |
|------------------------|---|
| Navigation |   Expert → Communication → HART output → Configuration → HART short tag |
| Description | Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display. |
| User entry | Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %). |
| Factory setting | TEQWAVEM |

Device tag

| | |
|------------------------|---|
| Navigation |   Expert → Communication → HART output → Configuration → Device tag |
| Description | Use this function to enter the name for the measuring point. |
| User entry | Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /). |
| Factory setting | Teqwave M |

HART address

| | |
|-------------------------------|---|
| Navigation |   Expert → Communication → HART output → Configuration → HART address |
| Description | Use this function to enter the address via which the data exchange takes place via HART protocol. |
| User entry | 0 to 63 |
| Factory setting | 0 |
| Additional information | <i>Description</i> For addressing in a HART Multidrop network, the Fixed current option must be set in the Current span parameter (→  75) (current output 1). |

No. of preambles

| | |
|-------------------------------|---|
| Navigation | Expert → Communication → HART output → Configuration → No. of preambles |
| Description | Use this function to enter the number of preambles in the HART protocol. |
| User entry | 2 to 20 |
| Factory setting | 5 |
| Additional information | <p><i>User entry</i></p> <p>As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.</p> |

Fieldbus writing access

| | |
|-------------------------------|--|
| Navigation | Expert → Communication → HART output → Configuration → Fieldb.writ.acc. |
| Description | Use this function to restrict access to the measuring device via fieldbus (HART interface). |
| Selection | <ul style="list-style-type: none"> ■ Read + write ■ Read only |
| Factory setting | Read + write |
| Additional information | <p><i>Description</i></p> <p>If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Read + write The parameters are readable and writable. ■ Read only The parameters are only readable. |

"Burst configuration 1 to n" submenu*Navigation*

Expert → Communication → HART output → Burst config.
→ Burst config. 1 to n

| | | | | |
|--|-------------------|--------|----------------------|--------|
| ► Burst configuration 1 to n | | | | |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px;">Burst mode 1 to n</td> <td style="text-align: right; padding: 5px;">→ 118</td> </tr> <tr> <td style="padding: 5px;">Burst command 1 to n</td> <td style="text-align: right; padding: 5px;">→ 119</td> </tr> </table> | Burst mode 1 to n | → 118 | Burst command 1 to n | → 119 |
| Burst mode 1 to n | → 118 | | | |
| Burst command 1 to n | → 119 | | | |

| | |
|---------------------|--------|
| Burst variable 0 | → 119 |
| Burst variable 1 | → 120 |
| Burst variable 2 | → 120 |
| Burst variable 3 | → 121 |
| Burst variable 4 | → 121 |
| Burst variable 5 | → 121 |
| Burst variable 6 | → 121 |
| Burst variable 7 | → 122 |
| Burst trigger mode | → 122 |
| Burst trigger level | → 123 |
| Min. update period | → 123 |
| Max. update period | → 123 |

Burst mode 1 to n**Navigation**

Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst mode 1 to n

Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
- On

Factory setting

Off

Additional information*Options*

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Burst command 1 to n

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst command 1 to n

Description Use this function to select the HART command that is sent to the HART master.

Selection

- Command 1
- Command 2
- Command 3
- Command 9
- Command 33
- Command 48

Factory setting Command 2

Additional information *Selection*

- Command 1
Read out the primary variable.
- Command 2
Read out the current and the main measured value as a percentage.
- Command 3
Read out the dynamic HART variables and the current.
- Command 9
Read out the dynamic HART variables including the related status.
- Command 33
Read out the dynamic HART variables including the related unit.
- Command 48
Read out the complete device diagnostics.

"Command 33" option

The HART device variables are defined via Command 107.

Commands

- Information about the defined details of the command: HART specifications
▪ The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 73).

Burst variable 0

Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 0

Prerequisite The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Conductivity
- Corrected conductivity
- Temperature
- Electronics temperature

- Total solids*
- Load rate
- Totalizer 1
- Percent of range
- Measured current*
- Current input 1*
- Current input 2*
- Current input 3*
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- HART input
- Not used

Factory setting Total solids

Additional information *Options*

If a burst message is not configured, the **Not used** option is set.

Burst variable 1



| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 1 |
| Description | For HART command 9 and 33: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst variable 2



| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 2 |
| Description | For HART command 9 and 33: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

* Visibility depends on order options or device settings

Burst variable 3

| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 3 |
| Description | For HART command 9 and 33: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst variable 4

| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 4 |
| Description | For HART command 9: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst variable 5

| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 5 |
| Description | For HART command 9: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst variable 6

| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 6 |
| Description | For HART command 9: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst variable 7

| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 7 |
| Description | For HART command 9: select the HART device variable or the process variable. |
| Selection | See the Burst variable 0 parameter (→ 119). |
| Factory setting | Not used |

Burst trigger mode

| | |
|-------------------------------|--|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Trigger mode |
| Description | Use this function to select the event that triggers burst message X. |
| Selection | <ul style="list-style-type: none">▪ Continuous▪ Window *▪ Rising *▪ Falling *▪ On change |
| Factory setting | Continuous |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none">▪ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→ 123).▪ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→ 123).▪ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→ 123).▪ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→ 123).▪ On change The message is sent if a measured value changes in the burst message. |

* Visibility depends on order options or device settings

Burst trigger level



| | |
|-------------------------------|--|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Trigger level |
| Description | For entering the burst trigger value. |
| User entry | Signed floating-point number |
| Additional information | <i>Description</i> Together with the option selected in the Burst trigger mode parameter (→ 122) the burst trigger value determines the time of burst message X. |

Min. update period



| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Min. upd. per. |
| Description | Use this function to enter the minimum time span between two burst commands of burst message X. |
| User entry | Positive integer |
| Factory setting | 1 000 ms |

Max. update period



| | |
|------------------------|---|
| Navigation | Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Max. upd. per. |
| Description | Use this function to enter the maximum time span between two burst commands of burst message X. |
| User entry | Positive integer |
| Factory setting | 2 000 ms |

"Information" submenu**Navigation** Expert → Communication → HART output → Information

|  Information | |
|--|---|
| Device revision | →  124 |
| Device ID | →  125 |
| Device type | →  125 |
| Manufacturer ID | →  125 |
| HART revision | →  125 |
| HART descriptor | →  126 |
| HART message | →  126 |
| Hardware revision | →  126 |
| Software revision | →  126 |
| HART date code | →  127 |

Device revision

Navigation Expert → Communication → HART output → Information → Device revision**Description**

Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Factory setting

1

Additional information**Description**

The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

| | |
|-------------------------------|--|
| Navigation |   Expert → Communication → HART output → Information → Device ID |
| Description | Use this function to view the device ID for identifying the measuring device in a HART network. |
| User interface | 6-digit hexadecimal number |
| Additional information | <i>Description</i>  In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID. |

Device type

| | |
|-------------------------------|--|
| Navigation |   Expert → Communication → HART output → Information → Device type |
| Description | Displays the device type used to register the measuring device with the HART Communication Foundation |
| User interface | Hexadecimal number |
| Factory setting | 11B3 |
| Additional information | <i>Description</i>  The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device. |

Manufacturer ID

| | |
|------------------------|--|
| Navigation |   Expert → Communication → HART output → Information → Manufacturer ID |
| Description | Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation. |
| User interface | 2-digit hexadecimal number |
| Factory setting | 0x11 (for Endress+Hauser) |

HART revision

| | |
|--------------------|--|
| Navigation |   Expert → Communication → HART output → Information → HART revision |
| Description | Use this function to display the HART protocol revision of the measuring device. |

User interface 5 to 7**Factory setting** 7

HART descriptor**Navigation** Expert → Communication → HART output → Information → HART descriptor**Description** Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.**User entry** Max. 16 characters, such as letters, numbers or special characters (e.g. @, %, /)**Factory setting** TEQWAVE M300 500

HART message**Navigation** Expert → Communication → HART output → Information → HART message**Description** Use this function to enter a HART message which is sent via the HART protocol when requested by the master.**User entry** Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)**Factory setting** TEQWAVE M300 500

Hardware revision**Navigation** Expert → Communication → HART output → Information → Hardware rev.**Description** Displays the hardware revision of the measuring device.**User interface** 0 to 255**Factory setting** 1

Software revision**Navigation** Expert → Communication → HART output → Information → Software rev.**Description** Displays the software revision of the measuring device.**User interface** 0 to 255

Factory setting 1**HART date code**

| | |
|-------------------------------|---|
| Navigation | Expert → Communication → HART output → Information → HART date code |
| Description | Use this function to enter the date information for individual use. |
| User entry | Date entry format: yyyy-mm-dd |
| Factory setting | 2009-07-20 |
| Additional information | <i>Example</i> Device installation date |

"Output" submenu*Navigation* Expert → Communication → HART output → Output

| | |
|--------------------------|-------|
| ► Output | |
| Assign PV | → 128 |
| Primary variable (PV) | → 128 |
| Assign SV | → 128 |
| Secondary variable (SV) | → 129 |
| Assign TV | → 129 |
| Tertiary variable (TV) | → 130 |
| Assign QV | → 130 |
| Quaternary variable (QV) | → 131 |

Assign PV**Navigation**

Expert → Communication → HART output → Output → Assign PV

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Off
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity
- Load rate *

Factory setting

Total solids

Primary variable (PV)**Navigation**

Expert → Communication → HART output → Output → Primary var (PV)

Description

Displays the current measured value of the primary dynamic variable (PV).

User interface

Floating point number with sign

Additional information*Display*

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→ [128](#)).

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ [54](#)).

Assign SV**Navigation**

Expert → Communication → HART output → Output → Assign SV

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

* Visibility depends on order options or device settings

| | |
|------------------------|--|
| Selection | <ul style="list-style-type: none"> ■ Conductivity ■ Corrected conductivity ■ Temperature ■ Electronics temperature ■ Total solids ■ Load rate * ■ Volume flow * ■ Totalizer 1 * ■ Current input 1 * ■ Current input 2 * ■ Current input 3 * ■ HART input |
| Factory setting | Temperature |

Secondary variable (SV)

| | |
|-------------------------------|--|
| Navigation |  Expert → Communication → HART output → Output → Second.var(SV) |
| Description | Displays the current measured value of the secondary dynamic variable (SV). |
| User interface | Floating point number with sign |
| Additional information | <p><i>Display</i></p> <p>The measured value displayed depends on the process variable selected in the Assign SV parameter (→  128).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  54).</p> |

Assign TV

| | |
|---------------------|--|
| Navigation |  Expert → Communication → HART output → Output → Assign TV |
| Prerequisite | The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus. |
| Description | Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV). |
| Selection | <ul style="list-style-type: none"> ■ Conductivity ■ Corrected conductivity ■ Temperature ■ Electronics temperature ■ Total solids ■ Load rate * |

* Visibility depends on order options or device settings

- Volume flow *
- Totalizer 1 *
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input

Factory setting Electronics temperature

Tertiary variable (TV)

Navigation  Expert → Communication → HART output → Output → Tertiary var(TV)

Description Displays the current measured value of the tertiary dynamic variable (TV).

User interface Floating point number with sign

Additional information *Display*

The measured value displayed depends on the process variable selected in the **Assign TV** parameter (→  129).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  54).

Assign QV



Navigation  Expert → Communication → HART output → Output → Assign QV

Prerequisite The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→  49) or the fieldbus.

Description Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Conductivity
- Corrected conductivity
- Temperature
- Electronics temperature
- Total solids
- Load rate *
- Volume flow *
- Totalizer 1 *
- Current input 1 *
- Current input 2 *
- Current input 3 *
- HART input

* Visibility depends on order options or device settings

Factory setting Conductivity

Quaternary variable (QV)

Navigation  Expert → Communication → HART output → Output → Quaternary.var(QV)

Description Displays the current measured value of the quaternary dynamic variable (QV).

User interface Floating point number with sign

Additional information *Display*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→  130).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  54).

3.6.3 "Diagnostic configuration" submenu

 For a list of all the diagnostic events, see the Operating Instructions for the device
→  7

Assign a category to the particular diagnostic event:

| Category | Meaning |
|--------------------------|---|
| Failure (F) | A device error has occurred. The measured value is no longer valid. |
| Function check (C) | The device is in the service mode (e.g. during a simulation). |
| Out of specification (S) | The device is being operated: ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value) |
| Maintenance required (M) | Maintenance is required. The measured value remains valid. |
| No effect (N) | Has no effect on the condensed status ¹⁾ . |

1) Condensed status according to NAMUR recommendation NE 107

Navigation



Expert → Communication → Diag. config.

 Diagnostic configuration

Event category 441

→  132

Event category 442

→  132

| | |
|--------------------|--------|
| Event category 443 | → 133 |
| Event category 444 | → 133 |
| Event category 832 | → 134 |
| Event category 833 | → 134 |
| Event category 834 | → 134 |
| Event category 835 | → 135 |

Event category 441 (Current output 1 to n)**Navigation**

Expert → Communication → Diag. config. → Event category 441

Description

Use this function to select a category for the **441 Current output 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

For a detailed description of the event categories available for selection: → 131

Event category 442 (Frequency output 1 to n)**Navigation**

Expert → Communication → Diag. config. → Event category 442

Prerequisite

The pulse/frequency/switch output is available.

Description

Use this function to select a category for the **442 Frequency output 1 to n** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional informationFor a detailed description of the event categories available for selection: → [131](#)**Event category 443 (Pulse output 1 to n)****Navigation**

Expert → Communication → Diag. config. → Event category 443

Prerequisite

The pulse/frequency/switch output is available.

DescriptionUse this function to select a category for the **443 Pulse output 1 to n** diagnostic message.**Selection**

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional informationFor a detailed description of the event categories available for selection: → [131](#)**Event category 444 (Current input 1 to n)****Navigation**

Expert → Communication → Diag. config. → Event category 444

Prerequisite

The current input is available.

DescriptionUse this function to select a category for the **444 Current input 1 to n** diagnostic message.**Selection**

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information*Selection*For a detailed description of the event categories available for selection: → [131](#)

Event category 832 (Electronics temperature too high)**Navigation**

Expert → Communication → Diag. config. → Event category 832

Description

Use this function to select a category for the **832 Electronics temperature too high** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

For a detailed description of the event categories available for selection: → [131](#)

Event category 833 (Electronics temperature too low)**Navigation**

Expert → Communication → Diag. config. → Event category 833

Description

Use this option to select a category for the **833 Electronics temperature too low** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

For a detailed description of the event categories available for selection: → [131](#)

Event category 834 (Process temperature too high)**Navigation**

Expert → Communication → Diag. config. → Event category 834

Description

Use this option to select a category for the **834 Process temperature too high** diagnostic message.

| | |
|-------------------------------|---|
| Selection | <ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N) |
| Factory setting | Out of specification (S) |
| Additional information | <p><i>Selection</i></p>  For a detailed description of the event categories available for selection: → 131 |

Event category 835 (Process temperature too low)

| | |
|-------------------------------|---|
| Navigation |  Expert → Communication → Diag. config. → Event category 835 |
| Description | Use this option to select a category for the 835 Process temperature too low diagnostic message. |
| Selection | <ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N) |
| Factory setting | Out of specification (S) |
| Additional information | <p><i>Selection</i></p>  For a detailed description of the event categories available for selection: → 131 |

3.6.4 "Web server" submenu*Navigation* Expert → Communication → Web server

| | |
|---------------------|-----------------------|
| ► Web server | |
| Web server language | → 136 |
| MAC address | → 136 |
| DHCP client | → 137 |
| IP address | → 137 |
| Subnet mask | → 137 |

| | |
|--------------------------|--------|
| Default gateway | → 138 |
| Web server functionality | → 138 |
| Login page | → 138 |

Web server language

Navigation Expert → Communication → Web server → Webserv.language

Description Use this function to select the language configured for the Web server.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- čeština (Czech)

Factory setting

English

MAC address

Navigation Expert → Communication → Web server → MAC Address

Description Displays the MAC⁴⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

Factory setting Each measuring device is given an individual address.

Additional information *Example*

For the display format
00:07:05:10:01:5F

4) Media Access Control

DHCP client**Navigation**

Expert → Communication → Web server → DHCP client

Description

Use this function to activate and deactivate the DHCP client functionality.

Selection

- Off
- On

Factory setting

On

Additional information*Effect*

If the DHCP client functionality of the web server is selected, the IP address (→ 137), Subnet mask (→ 137) and Default gateway (→ 138) are set automatically.



- Identification is via the MAC address of the measuring device.
- The IP address (→ 137) in the **IP address** parameter (→ 137) is ignored as long as the **DHCP client** parameter (→ 137) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→ 137) in the parameter of the same name is only used if the **DHCP client** parameter (→ 137) is inactive.

IP address**Navigation**

Expert → Communication → Web server → IP address

Description

Display or enter the IP address of the Web server integrated in the measuring device.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

192.168.1.212

Subnet mask**Navigation**

Expert → Communication → Web server → Subnet mask

Description

Display or enter the subnet mask.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

255.255.255.0

Default gateway**Navigation**

Expert → Communication → Web server → Default gateway

Description

Display or enter the Default gateway (→ [138](#)).

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

0.0.0.0

Web server functionality**Navigation**

Expert → Communication → Web server → Webserver funct.

Description

Use this function to switch the Web server on and off.

Selection

- Off
- HTML Off
- On

Factory setting

On

Additional information*Description*

Once disabled, the Web server functionality can only be enabled again via the local display, the FieldCare operating tool or the DeviceCare operating tool.

Selection

| Option | Description |
|----------|---|
| Off | <ul style="list-style-type: none"> ▪ The Web server is completely disabled. ▪ Port 80 is locked. |
| HTML Off | The HTML version of the Web server is not available. |
| On | <ul style="list-style-type: none"> ▪ The complete Web server functionality is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state. |

Login page**Navigation**

Expert → Communication → Web server → Login page

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.6.5 "WLAN settings" wizard

Navigation

Expert → Communication → WLAN settings

| ► WLAN settings | |
|--------------------------|--------|
| WLAN | → 140 |
| WLAN mode | → 140 |
| SSID name | → 140 |
| Network security | → 141 |
| Security identification | → 141 |
| User name | → 141 |
| WLAN password | → 142 |
| WLAN IP address | → 142 |
| WLAN MAC address | → 142 |
| WLAN subnet mask | → 143 |
| WLAN MAC address | → 142 |
| WLAN passphrase | → 143 |
| WLAN MAC address | → 142 |
| Assign SSID name | → 143 |
| SSID name | → 144 |
| 2.4 GHz WLAN channel | → 144 |
| Select antenna | → 144 |
| Connection state | → 144 |
| Received signal strength | → 145 |

| | |
|-------------------------------|--------|
| WLAN IP address | → 142 |
| Gateway IP address | → 145 |
| IP address domain name server | → 145 |

WLAN

Navigation Expert → Communication → WLAN settings → WLAN

Description Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting Enable

WLAN mode

Navigation Expert → Communication → WLAN settings → WLAN mode

Description Use this function to select the WLAN mode.

Selection

- WLAN access point
- WLAN Client

Factory setting WLAN access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security

Description Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.
- EAP-PEAP with MSCHAPv2
Access the WLAN connection with a password-based authentication protocol.
- EAP-PEAP MSCHAPv2 no server authentic.
Access the WLAN connection with a password-based protocol without server authentication.
- EAP-TLS
Access the WLAN connection with a certificate-based, two-way authentication of the client and network.

Security identification

Navigation Expert → Communication → WLAN settings → Sec. identific.

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

User interface

- Trusted issuer certificate
- Device certificate
- Device private key

User name

Navigation Expert → Communication → WLAN settings → User name

Description Use this function to enter the username of the WLAN network.

User entry

—

* Visibility depends on order options or device settings

Factory setting

–

WLAN password**Navigation**  Expert → Communication → WLAN settings → WLAN password**Description** Use this function to enter the WLAN password for the WLAN network.**User entry** –**Factory setting** –**WLAN IP address****Navigation**  Expert → Communication → WLAN settings → WLAN IP address**Description** Use this function to enter the IP address of the measuring device's WLAN connection.**User entry** 4 octet: 0 to 255 (in the particular octet)**Factory setting** 192.168.1.212**WLAN MAC address****Navigation**  Expert → Communication → WLAN settings → WLAN MAC address**Description** Displays the MAC⁵⁾ address of the measuring device.**User interface** Unique 12-digit character string comprising letters and numbers**Factory setting** Each measuring device is given an individual address.**Additional information** *Example*

For the display format

00:07:05:10:01:5F

5) Media Access Control

WLAN subnet mask

| | |
|------------------------|--|
| Navigation | █ Expert → Communication → WLAN settings → WLAN subnet mask |
| | █ Expert → Communication → WLAN settings → WLAN subnet mask |
| | █ █ Expert → Communication → WLAN settings → WLAN subnet mask |
| Description | Use this function to enter the subnet mask. |
| User entry | 4 octet: 0 to 255 (in the particular octet) |
| Factory setting | 255.255.255.0 |

WLAN passphrase

| | |
|------------------------|--|
| Navigation | █ █ Expert → Communication → WLAN settings → WLAN passphrase |
| Prerequisite | The WPA2-PSK option is selected in the Security type parameter (→ 141). |
| Description | Use this function to enter the network key. |
| User entry | 8 to 32-digit character string comprising numbers, letters and special characters (without spaces) |
| Factory setting | Serial number of the measuring device (e.g. L100A802000) |

Assign SSID name

| | |
|-------------------------------|--|
| Navigation | █ █ Expert → Communication → WLAN settings → Assign SSID name |
| Description | Use this function to select which name is used for the SSID ⁶⁾ . |
| Selection | <ul style="list-style-type: none"> ■ Device tag ■ User-defined |
| Factory setting | User-defined |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Device tag The device tag name is used as the SSID. ■ User-defined A user-defined name is used as the SSID. |

6) Service Set Identifier

SSID name**Navigation**

Expert → Communication → WLAN settings → SSID name

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (→ 143).
- The **WLAN access point** option is selected in the **WLAN mode** parameter (→ 140).

Description

Use this function to enter a user-defined SSID name.

User entry

Max. 32-digit character string comprising numbers, letters and special characters

Factory setting**2.4 GHz WLAN channel****Navigation**

Expert → Communication → WLAN settings → WLAN channel

Description

Use this function to enter the 2.4 GHz WLAN channel.

User entry

1 to 11

Factory setting

6

Additional information**Description**

- It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.
- If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna**Navigation**

Expert → Communication → WLAN settings → Select antenna

Description

Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting

Internal antenna

Connection state**Navigation**

Expert → Communication → WLAN settings → Connection state

Description

The connection status is displayed.

User interface ■ Connected
 ■ Not connected

Factory setting Not connected

Received signal strength

Navigation  Expert → Communication → WLAN settings → Rec.sig.strength

Description Displays the signal strength received.

User interface ■ Low
 ■ Medium
 ■ High

Factory setting High

Gateway IP address

Navigation  Expert → Communication → WLAN settings → Gateway IP addr.

Description Use this function to enter the IP address of the gateway.

User interface Character string comprising numbers, letters and special characters

Factory setting 192.168.1.212

IP address domain name server

Navigation  Expert → Communication → WLAN settings → IP address DNS

Description Use this function to enter the IP address of the domain name server.


User interface Character string comprising numbers, letters and special characters

Factory setting 192.168.1.212

3.7 "Application" submenu

Navigation

Expert → Application



Reset all totalizers

Navigation

Expert → Application → Reset all tot.

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the previously aggregated flow values.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information


Selection

| Options | Description |
|------------------|---|
| Cancel | No action is executed and the user exits the parameter. |
| Reset + totalize | Resets the totalizer to 0 and restarts the totaling process. The previously aggregated load quantity is thus deleted. |

3.7.1 "Totalizer 1 to n" submenu

Navigation

Expert → Application → Totalizer 1 to n



| | |
|------------------------------|-----------------------|
| Preset value 1 | → 149 |
| Totalizer 1 failure behavior | → 149 |

Assign process variable 1

**Navigation**

Expert → Application → Totalizer 1 → AssignVariab. 1

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Load rate *

Factory setting

Off

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Options

If the **Off** option is selected, only the **Assign process variable** parameter (→ [147](#)) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Process variable unit 1

**Navigation**

Expert → Application → Totalizer 1 → VariableUnit 1

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ [147](#)) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ [146](#)).

Selection

| | <i>SI units</i> | <i>US units</i> |
|------|-----------------|-----------------|
| ■ kg | ■ oz | |
| ■ t | ■ lb | |
| | ■ STon | |

or

* Visibility depends on order options or device settings

Other units
None *

* Visibility depends on order options or device settings

Factory setting Depends on country

Additional information *Description*

 The unit is selected separately for the totalizer and is independent of the option selected in the **System units** submenu (→ 54).

Options

The selection is dependent on the process variable selected in the **Assign process variable** parameter (→ 147).

Totalizer 1 operation mode



Navigation  Expert → Application → Totalizer 1 → Operat. mode 1

Prerequisite A process variable is selected in the **Assign process variable** parameter (→ 147) of the **Totalizer 1 to n** submenu.

Description Use this function to select how the totalizer summates the flow.

Selection

- Net
- Forward
- Reverse

Factory setting Net

Additional information *Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Totalizer 1 control

Navigation  Expert → Application → Totalizer 1 → Tot. 1 control

Prerequisite A process variable is selected in the **Assign process variable** parameter (→ 147) of the **Totalizer 1 to n** submenu.

Description Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize
- Hold

Factory setting

Totalize

Additional information*Selection*

| Options | Description |
|---------------------------------|---|
| Totalize | The totalizer is started or continues running. |
| Reset + hold | The totaling process is stopped and the totalizer is reset to 0. |
| Preset + hold ¹⁾ | The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter. |
| Reset + totalize | The totalizer is reset to 0 and the totaling process is restarted. |
| Preset + totalize ¹⁾ | The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted. |
| Hold | Totalizing is stopped. |

1) Visible depending on the order options or device settings

Preset value 1**Navigation**
 Expert → Application → Totalizer 1 → Preset value 1
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ [147](#)) of the **Totalizer 1 to n** submenu.

Description

Use this function to enter a start value for the Totalizer 1 to n.

User entry

Signed floating-point number

Factory setting

0 kg

Additional information*User entry*

 The unit of the selected process variable is defined in the **Unit totalizer** parameter (→ [147](#)) for the totalizer.

Totalizer 1 failure behavior**Navigation**
 Expert → Application → Totalizer 1 → FailureBehav. 1
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ [147](#)) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Hold
- Continue
- Last valid value + continue

Factory setting

Hold

Additional information*Description*

-  This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop
The totalizer is stopped in the event of a device alarm.
- Actual value
The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.8 "Diagnostics" submenu

Navigation
 Expert → Diagnostics

| | |
|--|---|
| ► Diagnostics | |
| Actual diagnostics | →  151 |
| Previous diagnostics | →  152 |
| Operating time from restart | →  152 |
| Operating time | →  153 |
| ► Diagnostic list | →  153 |
| ► Event logbook | →  155 |
| ► Device information | →  157 |
| ► Main electronic module + I/O module 1 | →  161 |
| ► Sensor electronic module (ISEM) | →  162 |
| ► I/O module 2 | →  163 |
| ► I/O module 3 | →  164 |

| | |
|------------------------|-------|
| ▶ Display module | → 165 |
| ▶ Data logging | → 166 |
| ▶ Min/max values | → 174 |
| ▶ Heartbeat Technology | → 178 |
| ▶ Simulation | → 179 |

Actual diagnostics

Navigation

Expert → Diagnostics → Actual diagnos.

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 153).

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:

F271 Main electronics failure

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

Display

 The diagnostic message can be viewed via the **Actual diagnostics** parameter (→ 151).

Example

For the display format:

24d12h13m00s

Previous diagnostics

| | |
|-------------------------------|---|
| Navigation |   Expert → Diagnostics → Prev.diagnostics |
| Prerequisite | Two diagnostic events have already occurred. |
| Description | Displays the diagnostic message that occurred before the current message. |
| User interface | Symbol for diagnostic behavior, diagnostic code and short message. |
| Additional information | <i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Example</i> For the display format:  F271 Main electronics failure |

Timestamp

| | |
|-------------------------------|--|
| Navigation |  Expert → Diagnostics → Timestamp |
| Description | Displays the operating time when the last diagnostic message before the current message occurred. |
| User interface | Days (d), hours (h), minutes (m) and seconds (s) |
| Additional information | <i>Display</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  152). <i>Example</i> For the display format: 24d12h13m00s |

Operating time from restart

| | |
|-----------------------|---|
| Navigation |   Expert → Diagnostics → Time fr. restart |
| Description | Use this function to display the time the device has been in operation since the last device restart. |
| User interface | Days (d), hours (h), minutes (m) and seconds (s) |

Operating time

Navigation  Expert → Diagnostics → Operating time

Description Displays the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)


Additional information *Indication*

Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

3.8.1 "Diagnostic list" submenu

Navigation

 Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation  Expert → Diagnostics → Diagnostic list → Diagnostics 1

Description Displays the current diagnostics message with the highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronics failure
-  F276 I/O module failure

Diagnostics 2

| | |
|-------------------------------|---|
| Navigation |   Expert → Diagnostics → Diagnostic list → Diagnostics 2 |
| Description | Displays the current diagnostics message with the second-highest priority. |
| User interface | Symbol for diagnostic behavior, diagnostic code and short message. |
| Additional information | <i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. |
| | <i>Examples</i> For the display format: <ul style="list-style-type: none">▪  F271 Main electronics failure▪  F276 I/O module failure |

Diagnostics 3

| | |
|-------------------------------|---|
| Navigation |   Expert → Diagnostics → Diagnostic list → Diagnostics 3 |
| Description | Displays the current diagnostics message with the third-highest priority. |
| User interface | Symbol for diagnostic behavior, diagnostic code and short message. |
| Additional information | <i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. |
| | <i>Examples</i> For the display format: <ul style="list-style-type: none">▪  F271 Main electronics failure▪  F276 I/O module failure |

Diagnostics 4

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Diagnostic list → Diagnostics 4 |
| Description | Displays the current diagnostics message with the fourth-highest priority. |
| User interface | Symbol for diagnostic behavior, diagnostic code and short message. |

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  F271 Main electronics failure
-  F276 I/O module failure

Diagnostics 5**Navigation**

 Expert → Diagnostics → Diagnostic list → Diagnostics 5

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:


-  F271 Main electronics failure
-  F276 I/O module failure

3.8.2 "Event logbook" submenu**Viewing event messages**

Event messages are displayed in chronological order. The event history includes both diagnostic events and information events. The symbol in front of the timestamp indicates whether the event has started or ended.

Navigation

Expert → Diagnostics → Event logbook



Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information*Description*

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu


The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation

Expert → Diagnostics → Event logbook → Event list

**Event list****Navigation**

Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→ 156).

- User interface**
- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
 - For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

| Additional information | <i>Description</i> |
|------------------------|---|
| | A maximum of 20 event messages are displayed in chronological order. |
| | If the Extended HistoROM application package (order option) is enabled in the device, the event list can contain up to 100 entries . |
| | The following symbols indicate whether an event has occurred or has ended: |

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ⊗F271 Main electronics failure
⊖ 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.8.3 "Device information" submenu

Navigation

◀ ▶ Expert → Diagnostics → Device info

| ► Device information | |
|-----------------------------|--------|
| Device tag | → 158 |
| Serial number | → 158 |
| Firmware version | → 159 |
| Device name | → 159 |
| Order code | → 159 |
| Extended order code 1 | → 159 |
| Extended order code 2 | → 160 |
| Extended order code 3 | → 160 |

| | |
|-----------------------|--------|
| Configuration counter | → 160 |
| ENP version | → 160 |

Device tag


Navigation Expert → Diagnostics → Device info → Device tag

Description Displays a unique name for the measuring point so it can be identified quickly within the plant. It is displayed in the header.

User interface Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Teqwave M

Additional information *User interface*



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation Expert → Diagnostics → Device info → Serial number

Description Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information *Description*

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

| | |
|-------------------------------|---|
| Navigation |   Expert → Diagnostics → Device info → Firmware version |
| Description | Displays the device firmware version installed. |
| User interface | Character string in the format xx.yy.zz |
| Additional information | <p><i>Display</i></p>  The Firmware version is also located: <ul style="list-style-type: none"> ▪ On the title page of the Operating instructions ▪ On the transmitter nameplate |

Device name

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Device info → Device name |
| Description | Displays the name of the transmitter. It can also be found on the nameplate of the transmitter. |
| User interface | Character string comprising numbers, letters and special characters |

Order code



| | |
|-------------------------------|---|
| Navigation |   Expert → Diagnostics → Device info → Order code |
| Description | Displays the device order code. |
| User interface | Character string composed of letters, numbers and certain punctuation marks (e.g. /). |
| Additional information | <p><i>Description</i></p> <p>The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.</p> <p> Uses of the order code</p> <ul style="list-style-type: none"> ▪ To order an identical spare device. ▪ To identify the device quickly and easily, e.g. when contacting Endress+Hauser. |

Extended order code 1



| | |
|--------------------|---|
| Navigation |   Expert → Diagnostics → Device info → Ext. order cd. 1 |
| Description | Displays the first part of the extended order code. |

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface Character string

Additional information *Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2



Navigation Expert → Diagnostics → Device info → Ext. order cd. 2

Description Displays the second part of the extended order code.

User interface Character string

Additional information For additional information, see **Extended order code 1** parameter (→ 159)

Extended order code 3



Navigation Expert → Diagnostics → Device info → Ext. order cd. 3

Description Displays the third part of the extended order code.

User interface Character string

Additional information For additional information, see **Extended order code 1** parameter (→ 159)

Configuration counter

Navigation Expert → Diagnostics → Device info → Config. counter

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

ENP version

Navigation Expert → Diagnostics → Device info → ENP version


Description Displays the version of the electronic nameplate.

| | |
|-------------------------------|--|
| User interface | Character string |
| Factory setting | 2.02.00 |
| Additional information | <p><i>Description</i></p> <p>This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.</p> |

3.8.4 "Main electronic module + I/O module 1" submenu

Navigation

Expert → Diagnostics → Main elec.+I/O1



Firmware version

Navigation

Expert → Diagnostics → Main elec.+I/O1 → Firmware version

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. software

Navigation

Expert → Diagnostics → Main elec.+I/O1 → Build no. softw.

Description

Use this function to display the software build number of the module.

User interface

Positive integer

Bootloader revision


Navigation  Expert → Diagnostics → Main elec.+I/O1 → Bootloader rev.

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.5 "Sensor electronic module (ISEM)" submenu

Navigation  Expert → Diagnostics → Sens. electronic



Firmware version

Navigation  Expert → Diagnostics → Sens. electronic → Firmware version

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Sens. electronic → Build no. softw.

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → Sens. electronic → Bootloader rev.


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.6 "I/O module 2" submenu

Navigation

 Expert → Diagnostics → I/O module 2



I/O module 2 terminal numbers

Navigation  Expert → Diagnostics → I/O module 2 → I/O 2 terminals

Description Displays the terminal numbers used by the I/O module.

User interface

- Not used
- 26-27 (I/O 1)
- 24-25 (I/O 2)
- 22-23 (I/O 3)

Firmware version

Navigation  Expert → Diagnostics → I/O module 2 → Firmware version

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software


| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → I/O module 2 → Build no. softw. |
| Description | Use this function to display the software build number of the module. |
| User interface | Positive integer |

Bootloader revision

| | |
|-----------------------|---|
| Navigation |   Expert → Diagnostics → I/O module 2 → Bootloader rev. |
| Description | Use this function to display the bootloader revision of the software. |
| User interface | Positive integer |

3.8.7 "I/O module 3" submenu

Navigation   Expert → Diagnostics → I/O module 3



I/O module 3 terminal numbers

| | |
|-----------------------|---|
| Navigation |   Expert → Diagnostics → I/O module 3 → I/O 3 terminals |
| Description | Displays the terminal numbers used by the I/O module. |
| User interface | <ul style="list-style-type: none">■ Not used■ 26-27 (I/O 1)■ 24-25 (I/O 2)■ 22-23 (I/O 3) |

Firmware version

Navigation  Expert → Diagnostics → I/O module 3 → Firmware version

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → I/O module 3 → Build no. softw.

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → I/O module 3 → Bootloader rev.

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.8 "Display module" submenu

Navigation

 Expert → Diagnostics → Display module

 **Display module**

Firmware version

→  166

Build no. software

→  166

Bootloader revision

→  166

Firmware version

Navigation  Expert → Diagnostics → Display module → Firmware version

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Display module → Build no. softw.

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision


Navigation  Expert → Diagnostics → Display module → Bootloader rev.

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.8.9 "Data logging" submenu

Navigation  Expert → Diagnostics → Data logging



| | |
|-------------------------|--------|
| Data logging | → 170 |
| Logging delay | → 170 |
| Data logging control | → 170 |
| Data logging status | → 171 |
| Entire logging duration | → 171 |

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1

Prerequisite

- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.
 - The **Extended HistoROM** application package is available.
- The software options currently enabled are displayed in the **Software option overview** parameter (→ 45).

Description

Use this function to assign a process variable to the data logging channel.

Selection

- Off
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity
- Load rate*
- Current output 1*
- Current output 2*
- Current output 3*
- Current output 4*

Factory setting

Off

Additional information

Description

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The log contents are cleared if the option selected is changed.

* Visibility depends on order options or device settings

Assign channel 2



Navigation

Expert → Diagnostics → Data logging → Assign chan. 2

Prerequisite

- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.
 - The **Extended HistoROM** application package is available.
- The software options currently enabled are displayed in the **Software option overview** parameter (→ [45](#)).

Description

Use this function to assign a process variable to the logging channel.

Selection

For the picklist, see **Assign channel 1** parameter (→ [167](#))

Factory setting

Off

Assign channel 3



Navigation

Expert → Diagnostics → Data logging → Assign chan. 3

Prerequisite

- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.
 - The **Extended HistoROM** application package is available.
- The software options currently enabled are displayed in the **Software option overview** parameter (→ [45](#)).

Description

Use this function to assign a process variable to the logging channel.

Selection

For the picklist, see **Assign channel 1** parameter (→ [167](#))

Factory setting

Off

Assign channel 4



Navigation

Expert → Diagnostics → Data logging → Assign chan. 4

Prerequisite

- The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ [49](#)) or the fieldbus.
 - The **Extended HistoROM** application package is available.
- The software options currently enabled are displayed in the **Software option overview** parameter (→ [45](#)).

Description

Use this function to assign a process variable to the logging channel.

Selection

For the picklist, see **Assign channel 1** parameter (→ [167](#))

Factory setting

Off

Logging interval

Navigation Expert → Diagnostics → Data logging → Logging interval

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 45).

Description Use this function to enter the logging interval T_{\log} for data logging.

User entry 0.1 to 3 600.0 s

Factory setting 1.0 s

Additional information *Description*

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data

Navigation Expert → Diagnostics → Data logging → Clear logging

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 45).

Description Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting Cancel

Additional information*Selection*

■ Cancel

The data is not cleared. All the data is retained.

■ Clear data

The logging data is cleared. The logging process starts from the beginning.

Data logging**Navigation**

Expert → Diagnostics → Data logging → Data logging

Description

Use this function to select the data logging method.

Selection

- Overwriting
- Not overwriting

Factory setting

Overwriting

Additional information*Selection*

■ Overwriting

The device memory applies the FIFO principle.

■ Not overwriting

Data logging is canceled if the measured value memory is full (single shot).

Logging delay**Navigation**

Expert → Diagnostics → Data logging → Logging delay

Prerequisite

In the **Data logging** parameter (→ 170), the **Not overwriting** option is selected.

Description

Use this function to enter the time delay for measured value logging.

User entry

0 to 999 h

Factory setting

0 h

Additional information*Description*

Once data logging has been started with the **Data logging control** parameter (→ 170), the device does not save any data for the duration of the delay time entered.

Data logging control**Navigation**

Expert → Diagnostics → Data logging → Data log.control

Prerequisite

In the **Data logging** parameter (→ 170), the **Not overwriting** option is selected.

| | |
|-------------------------------|---|
| Description | Use this function to start and stop measured value logging. |
| Selection | <ul style="list-style-type: none"> ▪ None ▪ Delete + start ▪ Stop |
| Factory setting | None |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ None Initial measured value logging status. ▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again. ▪ Stop Measured value logging is stopped. |

Data logging status

| | |
|-------------------------------|---|
| Navigation |  Expert → Diagnostics → Data logging → Data log. status |
| Prerequisite | In the Data logging parameter (→ 170), the Not overwriting option is selected. |
| Description | Displays the measured value logging status. |
| User interface | <ul style="list-style-type: none"> ▪ Done ▪ Delay active ▪ Active ▪ Stopped |
| Factory setting | Done |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Done Measured value logging has been performed and completed successfully. ▪ Delay active Measured value logging has been started but the logging interval has not yet elapsed. ▪ Active The logging interval has elapsed and measured value logging is active. ▪ Stopped Measured value logging is stopped. |

Entire logging duration

| | |
|---------------------|--|
| Navigation |  Expert → Diagnostics → Data logging → Logging duration |
| Prerequisite | In the Data logging parameter (→ 170), the Not overwriting option is selected. |
| Description | Displays the total logging duration. |

User interface Positive floating-point number

Factory setting 0 s

"Display channel 1" submenu

Navigation ☰ Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation ☰ Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite The **Extended HistoROM** application package is available.

i The software options currently enabled are displayed in the **Software option overview** parameter (→ ☰ 45).

Description Displays the measured value trend for the logging channel in the form of a chart.

Additional information *Description*

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation ☰ Expert → Diagnostics → Data logging → Displ.channel 2



Display channel 2

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite A process variable is specified in the **Assign channel 2** parameter.

Description See the **Display channel 1** parameter →  172

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

 **Display channel 3**

Display channel 3

→  173

Display channel 3

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite A process variable is specified in the **Assign channel 3** parameter.

Description See the **Display channel 1** parameter →  172

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4

 **Display channel 4**

Display channel 4

→  173

Display channel 4

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4


Prerequisite A process variable is specified in the **Assign channel 4** parameter.

| | |
|-------------|--|
| Description | See the Display channel 1 parameter → 172 |
|-------------|--|

3.8.10 "Min/max values" submenu

Navigation


Expert → Diagnostics → Min/max val.



"Electronics temperature" submenu

Navigation

Expert → Diagnostics → Min/max val. → Electronics temp



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Electronics temp → Minimum value

Description

Shows the lowest electronics temperature measured to date.

User interface


Positive floating-point number

Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Electronics temp → Maximum value |
| Description | Shows the highest electronics temperature measured to date. |
| User interface | Positive floating-point number |

"Main electronics temperature" submenu

Navigation   Expert → Diagnostics → Min/max val. → Main elect.temp.




Minimum value

| | |
|-------------------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value |
| Description | Shows the lowest temperature measured to date for the main electronic module. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i>  The unit is taken from the Temperature unit parameter (→ 56) |

Maximum value

| | |
|-------------------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value |
| Description | Shows the highest temperature measured to date for the main electronic module. |
| User interface | Signed floating-point number |
| Additional information | <i>Dependency</i>  The unit is taken from the Temperature unit parameter (→ 56) |

"Sensor electronics temperature (ISEM)" submenu**Navigation** Expert → Diagnostics → Min/max val. → Sensor elec.temp

Minimum value

Navigation Expert → Diagnostics → Min/max val. → Sensor elec.temp → Minimum value**Description**

Shows the lowest temperature measured to date for the sensor electronic module.

User interface

Signed floating-point number


Maximum value

Navigation Expert → Diagnostics → Min/max val. → Sensor elec.temp → Maximum value**Description**

Shows the highest temperature measured to date for the sensor electronic module.

User interface

Signed floating-point number

"Medium temperature" submenu**Navigation** Expert → Diagnostics → Min/max val. → Medium temp.

Minimum value


| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value |
| Description | Shows the lowest medium temperature measured to date. |
| User interface | Positive floating-point number |

Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value |
| Description | Shows the highest medium temperature measured to date. |
| User interface | Positive floating-point number |

"Total solids" submenu

Navigation   Expert → Diagnostics → Min/max val. → Total solids



Maximum value

| | |
|-----------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Total solids → Maximum value |
| Description | Shows the highest total solids value measured to date. |
| User interface | Positive floating-point number |


Minimum value

| | |
|--------------------|--|
| Navigation |   Expert → Diagnostics → Min/max val. → Total solids → Minimum value |
| Description | Shows the lowest total solids value measured to date. |

| | |
|----------------|--------------------------------|
| User interface | Positive floating-point number |
|----------------|--------------------------------|

"Conductivity" submenu

Navigation Expert → Diagnostics → Min/max val. → Conductivity



Maximum value

Navigation Expert → Diagnostics → Min/max val. → Conductivity → Maximum value

Description Shows the highest conductivity measured to date.

User interface Positive floating-point number

Minimum value

Navigation Expert → Diagnostics → Min/max val. → Conductivity → Minimum value

Description Shows the lowest conductivity measured to date.

User interface Positive floating-point number

3.8.11 "Heartbeat Technology" submenu

For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device → [7](#)

Navigation Expert → Diagnostics → Heartbeat Techn.

3.8.12 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation

| ▶ Simulation | |
|------------------------------------|-------|
| Assign simulation process variable | → 180 |
| Process variable value | → 180 |
| Current input 1 to n simulation | → 180 |
| Value current input 1 to n | → 181 |
| Status input 1 to n simulation | → 181 |
| Input signal level 1 to n | → 182 |
| Current output 1 to n simulation | → 182 |
| Current output value | → 182 |
| Frequency output 1 to n simulation | → 183 |
| Frequency output 1 to n value | → 183 |
| Pulse output simulation 1 to n | → 184 |
| Pulse value 1 to n | → 184 |
| Switch output simulation 1 to n | → 184 |
| Switch state 1 to n | → 185 |
| Relay output 1 to n simulation | → 185 |
| Switch state 1 to n | → 186 |
| Device alarm simulation | → 186 |
| Diagnostic event category | → 187 |
| Diagnostic event simulation | → 187 |

Assign simulation process variable**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var.

Prerequisite

The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n (→ 49) or the fieldbus.

Description

Select a process variable for the simulation process that is activated.

Selection

- Off
- Load rate *
- Total solids
- Temperature
- Electronics temperature
- Conductivity
- Corrected conductivity

Factory setting

Off

Process variable value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value

Description

Enter the simulation value for the selected process variable.

User entry

Signed floating-point number

Factory setting

0

Current input 1 to n simulation**Navigation**

Expert → Diagnostics → Simulation → Curr.inp 1 to n sim.

Description

Option for switching simulation of the current input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

The desired simulation value is defined in the **Value current input 1 to n** parameter.

Selection

- Off
- On

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Selection*

■ Off

Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

■ On

Current simulation is active.

Value current input 1 to n**Navigation**

Expert → Diagnostics → Simulation → Value curr.inp 1 to n

Prerequisite

In the **Current input 1 to n simulation** parameter, the **On** option is selected.

Description

Use this function to enter the current value for the simulation. In this way, users can verify the correct configuration of the current input and the correct function of upstream feed-in units.

User entry

0 to 22.5 mA

Status input 1 to n simulation**Navigation**

Expert → Diagnostics → Simulation → Status inp 1 to n sim

Description

Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

■ Off

■ On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Input signal level** parameter (→ 182).

Selection

■ Off

Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.

■ On

Simulation for the status input is active.

Input signal level 1 to n



Navigation

Expert → Diagnostics → Simulation → Signal level 1 to n

Prerequisite

In the **Status input simulation** parameter (→ 181), the **On** option is selected.

Description

Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units.

Selection

- High
- Low

Current output 1 to n simulation



Navigation

Expert → Diagnostics → Simulation → Curr.outp 1 to n sim.

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Value current output 1 to n** parameter.

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Current output value



Navigation

Expert → Diagnostics → Simulation → Curr.outp val.

Prerequisite

In the **Current output 1 to n simulation** parameter, the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

3.59 to 22.5 mA

Additional information*Dependency*

The input range is dependent on the option selected in the **Current span** parameter (→ [75](#)).

Frequency output 1 to n simulation**Navigation**

Expert → Diagnostics → Simulation → Freq.outp 1 to n sim.

Prerequisite

In the **Operating mode** parameter (→ [87](#)), the **Frequency** option is selected.

Description

Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Frequency value 1 to n** parameter.

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Frequency output 1 to n value**Navigation**

Expert → Diagnostics → Simulation → Freq.outp 1 to n val.

Prerequisite

In the **Frequency simulation 1 to n** parameter, the **On** option is selected.

Description

Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry

0.0 to 12 500.0 Hz

Pulse output simulation 1 to n



Navigation

Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n

Prerequisite

In the **Operating mode** parameter (→ 87), the **Pulse** option is selected.

Description

Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-counting value

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Pulse value 1 to n** parameter.

Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 89).
- Down-counting value
The pulses specified in the **Pulse value** parameter (→ 184) are output.

Pulse value 1 to n



Navigation

Expert → Diagnostics → Simulation → Pulse value 1 to n

Prerequisite

In the **Pulse output simulation 1 to n** parameter, the **Down-counting value** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch output simulation 1 to n



Navigation

Expert → Diagnostics → Simulation → Switch sim. 1 to n

Prerequisite

In the **Operating mode** parameter (→ 87), the **Switch** option is selected.

| | |
|-------------------------------|--|
| Description | Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress. |
| Selection | <ul style="list-style-type: none"> ▪ Off ▪ On |
| Factory setting | Off |
| Additional information | <p><i>Description</i></p> <p> The desired simulation value is defined in the Switch state 1 to n parameter.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Switch simulation is active. |

Switch state 1 to n



| | |
|-------------------------------|---|
| Navigation |  Expert → Diagnostics → Simulation → Switch state 1 to n |
| Description | Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units. |
| Selection | <ul style="list-style-type: none"> ▪ Open ▪ Closed |
| Additional information | <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Closed Switch simulation is active. |

Relay output 1 to n simulation



| | |
|------------------------|---|
| Navigation |  Expert → Diagnostics → Simulation → Relay out. 1 to n sim |
| Description | Use this function to switch simulation of the relay output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress. |
| Selection | <ul style="list-style-type: none"> ▪ Off ▪ On |
| Factory setting | Off |

Additional information*Description*

The desired simulation value is defined in the **Switch state 1 to n** parameter.

Selection

- Off

Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- On

Relay simulation is active.

Switch state 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch state 1 to n

Prerequisite

The **On** option is selected in the **Switch output simulation 1 to n** parameter parameter.

Description

Use this function to select a relay value for the simulation. In this way, users can verify the correct adjustment of the relay output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information*Selection*

- Open

Relay simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Closed

Relay simulation is active.

Device alarm simulation**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim.

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category



| | |
|------------------------|--|
| Navigation | Expert → Diagnostics → Simulation → Event category |
| Description | Use this function to select the category of the diagnostic events that are displayed for the simulation in the Diagnostic event simulation parameter (→ 187). |
| Selection | <ul style="list-style-type: none">■ Sensor■ Electronics■ Configuration■ Process |
| Factory setting | Process |

Diagnostic event simulation



| | |
|-------------------------------|---|
| Navigation | Expert → Diagnostics → Simulation → Diagnostic event |
| Description | Use this function to select a diagnostic event for the simulation process that is activated. |
| Selection | <ul style="list-style-type: none">■ Off■ Diagnostic event picklist (depends on the category selected) |
| Factory setting | Off |
| Additional information | <i>Description</i> For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 187). |

4 Country-specific factory settings

4.1 SI units

i The country-specific factory setting in SI units is made for all countries except the USA and Canada.

4.1.1 System units

| Process variable | Unit |
|------------------|-------|
| Total solids | %TS |
| Density | g/l |
| Mass flow | kg/h |
| Mass | kg |
| Volume | l/h |
| Temperature | °C |
| Conductivity | µS/cm |
| Load rate | kg/h |

i For further information on system units, see: **System units** submenu (→ 54)

4.1.2 Output current span

| Output | Current range |
|-----------------------|------------------|
| Current output 1 to n | 4 to 20 mA NAMUR |

i For further information on the current ranges, see: **Current range output** parameter (→ 75)

4.2 US units

i The country-specific factory setting in US units is made for the USA and Canada.

4.2.1 System units

| Process variable | Unit |
|------------------|--------------------|
| Total solids | %TS |
| Density | lb/ft ³ |
| Mass flow | lb/h |
| Mass | lb |
| Volume | l/h |
| Temperature | °F |

| Process variable | Unit |
|------------------|-------|
| Conductivity | µS/cm |
| Load rate | lb/h |

 For further information on system units, see: **System units** submenu (→  54)

4.2.2 Output current span

| Output | Current range |
|-----------------------|---------------|
| Current output 1 to n | 4 to 20 mA US |

 For further information on the current ranges, see: **Current range output** parameter (→  75)

Index

0 ... 9

| | |
|---|-----|
| 0/4 mA value (Parameter) | 70 |
| 0% bargraph value 1 (Parameter) | 17 |
| 0% bargraph value 3 (Parameter) | 20 |
| 0% bargraph value 5 (Parameter) | 24 |
| 0% bargraph value 7 (Parameter) | 26 |
| 2.4 GHz WLAN channel (Parameter) | 144 |
| 20 mA value (Parameter) | 70 |
| 100% bargraph value 1 (Parameter) | 18 |
| 100% bargraph value 3 (Parameter) | 21 |
| 100% bargraph value 5 (Parameter) | 24 |
| 100% bargraph value 7 (Parameter) | 27 |

A

| | |
|---|----------|
| Activate SW option (Parameter) | 44 |
| Active level (Parameter) | 73 |
| Actual diagnostics (Parameter) | 151 |
| Administration (Submenu) | 41 |
| Alarm delay (Parameter) | 35 |
| Application (Submenu) | 146 |
| Apply I/O configuration (Parameter) | 67 |
| Assign behavior of diagnostic no. 302 (Parameter) | 38 |
| Assign behavior of diagnostic no. 441 (Parameter) | 37 |
| Assign behavior of diagnostic no. 442 (Parameter) | 37 |
| Assign behavior of diagnostic no. 443 (Parameter) | 37 |
| Assign behavior of diagnostic no. 444 (Parameter) | 38 |
| Assign behavior of diagnostic no. 832 (Parameter) | 38 |
| Assign behavior of diagnostic no. 833 (Parameter) | 39 |
| Assign behavior of diagnostic no. 834 (Parameter) | 39 |
| Assign behavior of diagnostic no. 835 (Parameter) | 40 |
| Assign behavior of diagnostic no. 907 (Parameter) | 40 |
| Assign behavior of diagnostic no. 908 (Parameter) | 40 |
| Assign channel 1 (Parameter) | 167 |
| Assign channel 2 (Parameter) | 168 |
| Assign channel 3 (Parameter) | 168 |
| Assign channel 4 (Parameter) | 168 |
| Assign diagnostic behavior (Parameter) | 97, 106 |
| Assign flow direction check (Parameter) | 101, 105 |
| Assign frequency output (Parameter) | 92 |
| Assign limit (Parameter) | 98, 105 |
| Assign process variable (Parameter) | 59 |
| Assign process variable 1 (Parameter) | 147 |
| Assign pulse output (Parameter) | 88 |
| Assign PV (Parameter) | 128 |
| Assign QV (Parameter) | 130 |
| Assign simulation process variable (Parameter) | 180 |
| Assign SSID name (Parameter) | 143 |
| Assign status (Parameter) | 101, 106 |
| Assign status input (Parameter) | 72 |
| Assign SV (Parameter) | 128 |
| Assign TV (Parameter) | 129 |

B

| | |
|------------------------------------|----|
| Backlight (Parameter) | 32 |
| Backup state (Parameter) | 34 |

Bootloader revision (Parameter)

| | |
|--|-------------------------|
| | 162, 163, 164, 165, 166 |
| Build no. software (Parameter) | 161, 162, 164, 165, 166 |
| Burst command (Parameter) | 112 |
| Burst command 1 to n (Parameter) | 119 |
| Burst configuration 1 to n (Submenu) | 117 |
| Burst mode 1 to n (Parameter) | 118 |
| Burst trigger level (Parameter) | 123 |
| Burst trigger mode (Parameter) | 122 |
| Burst variable 0 (Parameter) | 119 |
| Burst variable 1 (Parameter) | 120 |
| Burst variable 2 (Parameter) | 120 |
| Burst variable 3 (Parameter) | 121 |
| Burst variable 4 (Parameter) | 121 |
| Burst variable 5 (Parameter) | 121 |
| Burst variable 6 (Parameter) | 121 |
| Burst variable 7 (Parameter) | 122 |

C

| | |
|--|----------|
| Capture mode (Parameter) | 110 |
| Clear logging data (Parameter) | 169 |
| Communication (Submenu) | 109 |
| Comparison result (Parameter) | 34 |
| Conductivity (Parameter) | 47 |
| Conductivity (Submenu) | 178 |
| Conductivity damping (Parameter) | 58 |
| Conductivity factor (Parameter) | 63 |
| Conductivity offset (Parameter) | 63 |
| Conductivity unit (Parameter) | 57 |
| Configuration (Submenu) | 110, 115 |
| Configuration backup (Submenu) | 32 |
| Configuration counter (Parameter) | 160 |
| Configuration management (Parameter) | 33 |
| Confirm access code (Parameter) | 42 |
| Connection state (Parameter) | 144 |
| Contrast display (Parameter) | 31 |
| Corrected conductivity (Parameter) | 47 |
| Corrected conductivity factor (Parameter) | 64 |
| Corrected conductivity offset (Parameter) | 64 |
| Current input 1 to n (Submenu) | 49, 68 |
| Current input 1 to n simulation (Parameter) | 180 |
| Current output 1 to n (Submenu) | 74 |
| Current output 1 to n simulation (Parameter) | 182 |
| Current output value (Parameter) | 182 |
| Current range output (Parameter) | 75 |
| Current span (Parameter) | 69 |

D

| | |
|--|-----|
| Damping current output (Parameter) | 83 |
| Damping output (Parameter) | 94 |
| Data logging (Parameter) | 170 |
| Data logging (Submenu) | 166 |
| Data logging control (Parameter) | 170 |
| Data logging status (Parameter) | 171 |
| Date/time (Parameter) | 66 |
| Date/time format (Parameter) | 57 |

| | | | |
|---|----------|---|-----|
| Decimal places 1 (Parameter) | 18 | Value 8 display | 28 |
| Decimal places 2 (Parameter) | 19 | WLAN | 140 |
| Decimal places 3 (Parameter) | 21 | WLAN IP address | 142 |
| Decimal places 4 (Parameter) | 22 | WLAN MAC address | 142 |
| Decimal places 5 (Parameter) | 24 | WLAN mode | 140 |
| Decimal places 6 (Parameter) | 25 | WLAN passphrase | 143 |
| Decimal places 7 (Parameter) | 27 | WLAN password | 142 |
| Decimal places 8 (Parameter) | 28 | WLAN subnet mask | 143 |
| Default gateway (Parameter) | 138 | Display (Submenu) | 13 |
| Define access code (Parameter) | 41 | Display channel 1 (Submenu) | 172 |
| Define access code (Wizard) | 41 | Display channel 2 (Submenu) | 172 |
| Density unit (Parameter) | 55 | Display channel 3 (Submenu) | 173 |
| Device alarm simulation (Parameter) | 186 | Display channel 4 (Submenu) | 173 |
| Device ID (Parameter) | 111, 125 | Display damping (Parameter) | 29 |
| Device information (Submenu) | 157 | Display interval (Parameter) | 29 |
| Device name (Parameter) | 159 | Display language (Parameter) | 23 |
| Device reset (Parameter) | 43 | Display module (Submenu) | 165 |
| Device revision (Parameter) | 124 | Document | |
| Device tag (Parameter) | 116, 158 | Design | 4 |
| Device type (Parameter) | 111, 125 | Explanation of the structure of a parameter | |
| DHCP client (Parameter) | 137 | description | 6 |
| Diagnostic behavior (Submenu) | 36 | Function | 4 |
| Diagnostic configuration (Submenu) | 131 | Symbols used | 6 |
| Diagnostic event category (Parameter) | 187 | Target group | 4 |
| Diagnostic event simulation (Parameter) | 187 | Using the document | 4 |
| Diagnostic handling (Submenu) | 35 | Document function | 4 |
| Diagnostic list (Submenu) | 153 | | |
| Diagnostics (Submenu) | 150 | | |
| Diagnostics 1 (Parameter) | 153 | | |
| Diagnostics 2 (Parameter) | 154 | | |
| Diagnostics 3 (Parameter) | 154 | | |
| Diagnostics 4 (Parameter) | 154 | | |
| Diagnostics 5 (Parameter) | 155 | | |
| Direct access | | | |
| 0% bargraph value 5 | 24 | E | |
| 0% bargraph value 7 | 26 | Electronics temperature (Parameter) | 47 |
| 2.4 GHz WLAN channel | 144 | Electronics temperature (Submenu) | 174 |
| 100% bargraph value 5 | 24 | Electronics temperature factor (Parameter) | 64 |
| 100% bargraph value 7 | 27 | Electronics temperature offset (Parameter) | 64 |
| Assign SSID name | 143 | ENP version (Parameter) | 160 |
| Connection state | 144 | Enter access code (Parameter) | 13 |
| Decimal places 5 | 24 | Entire logging duration (Parameter) | 171 |
| Decimal places 6 | 25 | Event category 441 (Parameter) | 132 |
| Decimal places 7 | 27 | Event category 442 (Parameter) | 132 |
| Decimal places 8 | 28 | Event category 443 (Parameter) | 133 |
| Gateway IP address | 145 | Event category 444 (Parameter) | 133 |
| IP address domain name server | 145 | Event category 832 (Parameter) | 134 |
| Network security | 141 | Event category 833 (Parameter) | 134 |
| Received signal strength | 145 | Event category 834 (Parameter) | 134 |
| Relay output 1 to n simulation | 185 | Event category 835 (Parameter) | 135 |
| Security identification | 141 | Event list (Submenu) | 156 |
| Select antenna | 144 | Event logbook (Submenu) | 155 |
| SSID name | 140, 144 | Expert (Menu) | 11 |
| Switch state 1 to n | 186 | Extended order code 1 (Parameter) | 159 |
| Timestamp | 151, 152 | Extended order code 2 (Parameter) | 160 |
| User name | 141 | Extended order code 3 (Parameter) | 160 |
| Value 5 display | 23 | External compensation (Submenu) | 61 |
| Value 6 display | 25 | | |
| Value 7 display | 26 | | |

Failure mode (Parameter) 71, 91, 95, 102, 108, 113
 Failure value (Parameter) 71, 114
 Fieldbus writing access (Parameter) 117
 Filter options (Parameter) 156
 Firmware version (Parameter)
 159, 161, 162, 163, 165, 166
 Fixed current (Parameter) 76
 Format display (Parameter) 14
 Frequency output 1 to n simulation (Parameter) 183
 Frequency output 1 to n value (Parameter) 183
 Function
 see Parameter

G

Gateway IP address (Parameter) 145

H

Hardware revision (Parameter) 126
 HART address (Parameter) 116
 HART date code (Parameter) 127
 HART descriptor (Parameter) 126
 HART input (Submenu) 110
 HART message (Parameter) 126
 HART output (Submenu) 115
 HART revision (Parameter) 125
 HART short tag (Parameter) 116
 Header (Parameter) 30
 Header text (Parameter) 30
 Heartbeat Technology (Submenu) 178

I

I/O alteration code (Parameter) 68
 I/O configuration (Submenu) 66
 I/O module 1 to n information (Parameter) 66
 I/O module 1 to n terminal numbers (Parameter) 66
 I/O module 1 to n type (Parameter) 67
 I/O module 2 (Submenu) 163
 I/O module 2 terminal numbers (Parameter) 163, 164
 I/O module 3 (Submenu) 164
 I/O module 3 terminal numbers (Parameter) 163, 164
 I/O module 4 terminal numbers (Parameter) 163, 164
 Information (Submenu) 124
 Input (Submenu) 68, 114
 Input signal level 1 to n (Parameter) 182
 Input values (Submenu) 49
 Invert output signal (Parameter) 103
 IP address (Parameter) 137
 IP address domain name server (Parameter) 145

L

Last backup (Parameter) 33
 Load rate (Parameter) 47
 Load rate factor (Parameter) 65
 Load rate offset (Parameter) 65
 Locking status (Parameter) 11
 Logging delay (Parameter) 170
 Logging interval (Parameter) 169
 Login page (Parameter) 138
 Lower range limit (Parameter) 59
 Lower range value output (Parameter) 77

M

MAC address (Parameter) 136
 Main electronic module + I/O module 1 (Submenu) 161
 Main electronics temperature (Submenu) 175
 Manufacturer ID (Parameter) 112, 125
 Mass flow unit (Parameter) 55
 Mass unit (Parameter) 56
 Max. switch cycles number (Parameter) 54
 Max. update period (Parameter) 123
 Maximum frequency value (Parameter) 93
 Maximum value (Parameter) 175, 176, 177, 178
 Measured current (Parameter) 51, 85
 Measured current 1 to n (Parameter) 50
 Measured values (Submenu) 46
 Measured values 1 to n (Parameter) 49
 Measuring interval (Parameter) 62
 Measuring mode (Parameter) 90, 94
 Measuring mode current output (Parameter) 78
 Measuring value at maximum frequency (Parameter) 93
 Measuring value at minimum frequency (Parameter) 93
 Medium temperature (Submenu) 176
 Menu
 Expert 11
 Min. update period (Parameter) 123
 Min/max values (Submenu) 174
 Minimum frequency value (Parameter) 92
 Minimum value (Parameter) 174, 175, 176, 177, 178

N

Network security (Parameter) 141
 No. of preambles (Parameter) 117
 Nominal diameter (Parameter) 65

O

Operating mode (Parameter) 87
 Operating time (Parameter) 32, 42, 153
 Operating time from restart (Parameter) 152
 Order code (Parameter) 159
 Output (Submenu) 73, 127
 Output current (Parameter) 51, 84
 Output frequency (Parameter) 52, 96
 Output values (Submenu) 50

P

Parameter
 Structure of description 6
 Partially filled pipe detection (Parameter) 60
 Partially filled pipe detection (Submenu) 60
 Powerless relay status (Parameter) 109
 Preset value 1 (Parameter) 149
 Previous diagnostics (Parameter) 152
 Primary variable (PV) (Parameter) 128
 Process parameters (Submenu) 57
 Process variable adjustment (Submenu) 62
 Process variable current output (Parameter) 75
 Process variable unit 1 (Parameter) 147
 Process variable value (Parameter) 180
 Process variables (Submenu) 46
 Pulse output (Parameter) 52, 91

Pulse output simulation 1 to n (Parameter) 184
 Pulse scaling (Parameter) 89
 Pulse value 1 to n (Parameter) 184
 Pulse width (Parameter) 89
 Pulse/frequency/switch output 1 to n (Submenu) 51, 85

Q

Quaternary variable (QV) (Parameter) 131

R

Received signal strength (Parameter) 145
 Relay output 1 to n (Submenu) 53, 103
 Relay output 1 to n simulation (Parameter) 185
 Relay output function (Parameter) 104
 Reset access code (Parameter) 43
 Reset access code (Submenu) 42
 Reset all totalizers (Parameter) 146
 Response time (Parameter) 60, 61, 95
 Response time status input (Parameter) 73

S

Secondary variable (SV) (Parameter) 129
 Security identification (Parameter) 141
 Select antenna (Parameter) 144
 Sensor (Submenu) 45
 Sensor adjustment (Submenu) 62
 Sensor electronic module (ISEM) (Submenu) 162
 Sensor electronics temperature (ISEM) (Submenu) 176
 Separator (Parameter) 31
 Serial number (Parameter) 158
 Signal mode (Parameter) 69, 75, 87
 Simulation (Submenu) 179
 Slot number (Parameter) 113
 Software option overview (Parameter) 45
 Software revision (Parameter) 126
 SSID name (Parameter) 140, 144
 Status (Parameter) 115
 Status input 1 to n (Submenu) 71
 Status input 1 to n simulation (Parameter) 181
 Submenu

 Administration 41
 Application 146
 Burst configuration 1 to n 117
 Communication 109
 Conductivity 178
 Configuration 110, 115
 Configuration backup 32
 Current input 1 to n 49, 68
 Current output 1 to n 74
 Data logging 166
 Device information 157
 Diagnostic behavior 36
 Diagnostic configuration 131
 Diagnostic handling 35
 Diagnostic list 153
 Diagnostics 150
 Display 13
 Display channel 1 172
 Display channel 2 172

Display channel 3 173
 Display channel 4 173
 Display module 165
 Electronics temperature 174
 Event list 156
 Event logbook 155
 External compensation 61
 Factory adjustment 65
 HART input 110
 HART output 115
 Heartbeat Technology 178
 I/O configuration 66
 I/O module 2 163
 I/O module 3 164
 Information 124
 Input 68, 114
 Input values 49
 Main electronic module + I/O module 1 161
 Main electronics temperature 175
 Measured values 46
 Medium temperature 176
 Min/max values 174
 Output 73, 127
 Output values 50
 Partially filled pipe detection 60
 Process parameters 57
 Process variable adjustment 62
 Process variables 46
 Pulse/frequency/switch output 1 to n 51, 85
 Relay output 1 to n 53, 103
 Reset access code 42
 Sensor 45
 Sensor adjustment 62
 Sensor electronic module (ISEM) 162
 Sensor electronics temperature (ISEM) 176
 Simulation 179
 Status input 1 to n 71
 System 13
 System units 54
 Total solids 177
 Total solids monitoring 58
 Totalizer 48
 Totalizer 1 to n 146
 Value current output 1 to n 51
 Value status input 1 to n 50
 Web server 135
 Subnet mask (Parameter) 137
 Switch cycles (Parameter) 54
 Switch output function (Parameter) 96
 Switch output simulation 1 to n (Parameter) 184
 Switch state (Parameter) 53, 102, 109
 Switch state 1 to n (Parameter) 185, 186
 Switch-off delay (Parameter) 102, 107
 Switch-off value (Parameter) 100, 107
 Switch-on delay (Parameter) 101, 108
 Switch-on value (Parameter) 100, 107
 System (Submenu) 13
 System units (Submenu) 54

T

| | |
|--|---------------------|
| Target group | 4 |
| Temperature (Parameter) | 47 |
| Temperature damping (Parameter) | 58 |
| Temperature factor (Parameter) | 63 |
| Temperature offset (Parameter) | 63 |
| Temperature unit (Parameter) | 56 |
| Terminal number (Parameter) | 69, 72, 74, 86, 104 |
| Tertiary variable (TV) (Parameter) | 130 |
| Threshold (Parameter) | 60 |
| Timeout (Parameter) | 113 |
| Timestamp (Parameter) | 151, 152 |
| Total solids (Parameter) | 46 |
| Total solids (Submenu) | 177 |
| Total solids monitoring (Submenu) | 58 |
| Total solids override (Parameter) | 58 |
| Total solids unit (Parameter) | 55 |
| Totalizer (Submenu) | 48 |
| Totalizer 1 control (Parameter) | 148 |
| Totalizer 1 failure behavior (Parameter) | 149 |
| Totalizer 1 operation mode (Parameter) | 148 |
| Totalizer 1 overflow (Parameter) | 48 |
| Totalizer 1 to n (Submenu) | 146 |
| Totalizer 1 value (Parameter) | 48 |
| Transmitter identifier (Parameter) | 44 |

U

| | |
|--|-----|
| Upper range limit (Parameter) | 59 |
| Upper range value output (Parameter) | 78 |
| User name (Parameter) | 141 |
| User role (Parameter) | 12 |

V

| | |
|--|--------|
| Value (Parameter) | 115 |
| Value 1 display (Parameter) | 17 |
| Value 2 display (Parameter) | 19 |
| Value 3 display (Parameter) | 20 |
| Value 4 display (Parameter) | 22 |
| Value 5 display (Parameter) | 23 |
| Value 6 display (Parameter) | 25 |
| Value 7 display (Parameter) | 26 |
| Value 8 display (Parameter) | 28 |
| Value current input 1 to n (Parameter) | 181 |
| Value current output 1 to n (Submenu) | 51 |
| Value status input (Parameter) | 50, 73 |
| Value status input 1 to n (Submenu) | 50 |
| Volume flow unit (Parameter) | 56 |

W

| | |
|--|-----|
| Web server (Submenu) | 135 |
| Web server functionality (Parameter) | 138 |
| Web server language (Parameter) | 136 |
| Wizard | |
| Define access code | 41 |
| WLAN settings | 139 |
| WLAN (Parameter) | 140 |
| WLAN IP address (Parameter) | 142 |
| WLAN MAC address (Parameter) | 142 |
| WLAN mode (Parameter) | 140 |

| | |
|--|-----|
| WLAN passphrase (Parameter) | 143 |
| WLAN password (Parameter) | 142 |
| WLAN settings (Wizard) | 139 |
| WLAN subnet mask (Parameter) | 143 |



71637048

www.addresses.endress.com
