

Operating Instructions

Proline Teqwave MW 300

Total solids measurement via microwave transmission
Modbus RS485



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser sales organization will supply you with current information and updates to this manual.

Table of contents

| | | | | |
|----------|------------------------------------------------------------------------|-----------|--|--|
| 1 | About this document | 6 | | |
| 1.1 | Document function | 6 | | |
| 1.2 | Symbols | 6 | | |
| 1.2.1 | Safety symbols | 6 | | |
| 1.2.2 | Electrical symbols | 6 | | |
| 1.2.3 | Communication-specific symbols | 6 | | |
| 1.2.4 | Tool symbols | 7 | | |
| 1.2.5 | Symbols for certain types of information | 7 | | |
| 1.2.6 | Symbols in graphics | 7 | | |
| 1.3 | Documentation | 8 | | |
| 1.3.1 | Document function | 8 | | |
| 1.4 | Registered trademarks | 8 | | |
| 2 | Safety instructions | 9 | | |
| 2.1 | Requirements for the personnel | 9 | | |
| 2.2 | Intended use | 9 | | |
| 2.3 | Workplace safety | 10 | | |
| 2.4 | Operational safety | 10 | | |
| 2.5 | Product safety | 10 | | |
| 2.6 | IT security | 10 | | |
| 2.7 | Device-specific IT security | 11 | | |
| 2.7.1 | Protecting access via hardware write protection | 11 | | |
| 2.7.2 | Protecting access via a password | 11 | | |
| 2.7.3 | Access via web server | 12 | | |
| 2.7.4 | Access via service interface (CDI- RJ45) | 12 | | |
| 3 | Product description | 13 | | |
| 3.1 | Product design | 13 | | |
| 4 | Incoming acceptance and product identification | 14 | | |
| 4.1 | Incoming acceptance | 14 | | |
| 4.2 | Product identification | 15 | | |
| 4.2.1 | Transmitter nameplate | 16 | | |
| 4.2.2 | Sensor nameplate | 17 | | |
| 4.2.3 | Symbols on the device | 18 | | |
| 5 | Storage and transport | 19 | | |
| 5.1 | Storage conditions | 19 | | |
| 5.2 | Transporting the product | 19 | | |
| 5.2.1 | Measuring devices with lifting lugs | 19 | | |
| 5.3 | Packaging disposal | 20 | | |
| 6 | Mounting procedure | 21 | | |
| 6.1 | Mounting requirements | 21 | | |
| 6.1.1 | Mounting position | 21 | | |
| 6.1.2 | Environmental and process requirements | 25 | | |
| 6.1.3 | Special mounting instructions | 26 | | |
| 6.2 | Mounting the measuring device | 27 | | |
| 6.2.1 | Preparing the measuring device | 27 | | |
| 6.2.2 | Mounting the sensor | 27 | | |
| 6.2.3 | Turning the transmitter housing | 29 | | |
| 6.2.4 | Turning the display module | 30 | | |
| 6.3 | Post-mounting check | 32 | | |
| 7 | Electrical connection | 33 | | |
| 7.1 | Electrical safety | 33 | | |
| 7.2 | Connecting requirements | 33 | | |
| 7.2.1 | Required tools | 33 | | |
| 7.2.2 | Requirements for connection cable | 33 | | |
| 7.2.3 | Terminal assignment | 35 | | |
| 7.2.4 | Shielding and grounding | 35 | | |
| 7.2.5 | Preparing the measuring device | 36 | | |
| 7.3 | Connecting the measuring device | 36 | | |
| 7.3.1 | Connecting the transmitter | 36 | | |
| 7.3.2 | Connecting the remote display and operating module DKX001 | 39 | | |
| 7.4 | Potential equalization | 39 | | |
| 7.4.1 | Requirements | 39 | | |
| 7.5 | Special connection instructions | 40 | | |
| 7.5.1 | Connection examples | 40 | | |
| 7.6 | Hardware settings | 43 | | |
| 7.6.1 | Setting the device address | 43 | | |
| 7.6.2 | Activating the terminating resistor | 43 | | |
| 7.7 | Ensuring the degree of protection | 45 | | |
| 7.8 | Post-connection check | 46 | | |
| 8 | Operation options | 47 | | |
| 8.1 | Overview of operation options | 47 | | |
| 8.2 | Structure and function of the operating menu | 48 | | |
| 8.2.1 | Structure of the operating menu | 48 | | |
| 8.2.2 | Operating philosophy | 49 | | |
| 8.3 | Access to operating menu via local display | 50 | | |
| 8.3.1 | Operational display | 50 | | |
| 8.3.2 | Navigation view | 52 | | |
| 8.3.3 | Editing view | 54 | | |
| 8.3.4 | Operating elements | 56 | | |
| 8.3.5 | Opening the context menu | 56 | | |
| 8.3.6 | Navigating and selecting from list | 58 | | |
| 8.3.7 | Calling up help text | 58 | | |
| 8.3.8 | Changing the parameters | 59 | | |
| 8.3.9 | User roles and related access authorization | 59 | | |
| 8.3.10 | Disabling write protection via access code | 60 | | |
| 8.3.11 | Enabling and disabling the keypad lock | 60 | | |
| 8.4 | Access to operating menu via web browser | 61 | | |
| 8.4.1 | Function range | 61 | | |
| 8.4.2 | Requirements | 61 | | |

| | | | | |
|-----------|------------------------------------------------------------------------|------------|--|--|
| 8.4.3 | Connecting the device | 62 | | |
| 8.4.4 | Logging on | 64 | | |
| 8.4.5 | User interface | 65 | | |
| 8.4.6 | Disabling the Web server | 66 | | |
| 8.4.7 | Logging out | 67 | | |
| 8.5 | Access to the operating menu via the operating tool | 67 | | |
| 8.5.1 | Connecting the operating tool | 67 | | |
| 8.5.2 | FieldCare | 70 | | |
| 8.5.3 | DeviceCare | 71 | | |
| 9 | System integration | 72 | | |
| 9.1 | Overview of device description files | 72 | | |
| 9.1.1 | Current version data for the device | 72 | | |
| 9.1.2 | Operating tools | 73 | | |
| 9.2 | Modbus RS485 information | 74 | | |
| 9.2.1 | Function codes | 74 | | |
| 9.2.2 | Register information | 75 | | |
| 9.2.3 | Response time | 75 | | |
| 9.2.4 | Data types | 75 | | |
| 9.2.5 | Byte transmission sequence | 76 | | |
| 9.2.6 | Modbus data map | 76 | | |
| 10 | Commissioning | 79 | | |
| 10.1 | Post-mounting and post-connection check | 79 | | |
| 10.2 | Switching on the measuring device | 79 | | |
| 10.3 | Connecting via FieldCare | 79 | | |
| 10.4 | Setting the operating language | 79 | | |
| 10.5 | Configuring the measuring device | 80 | | |
| 10.5.1 | Defining the tag name | 81 | | |
| 10.5.2 | Setting the system units | 82 | | |
| 10.5.3 | Configuring the communication interface | 83 | | |
| 10.5.4 | Displaying the I/O configuration | 84 | | |
| 10.5.5 | Configuring the current input | 85 | | |
| 10.5.6 | Configuring the status input | 86 | | |
| 10.5.7 | Configuring the current output | 87 | | |
| 10.5.8 | Configuring the pulse/frequency/ switch output | 89 | | |
| 10.5.9 | Configuring the relay output | 95 | | |
| 10.5.10 | Configuring the local display | 96 | | |
| 10.5.11 | "Total solids commissioning" wizard | 99 | | |
| 10.5.12 | "Total solids adjustment" submenu | 99 | | |
| 10.6 | Advanced settings | 100 | | |
| 10.6.1 | Using the parameter to enter the access code | 101 | | |
| 10.6.2 | Configuring the totalizer | 102 | | |
| 10.6.3 | Carrying out additional display configurations | 103 | | |
| 10.6.4 | WLAN configuration | 107 | | |
| 10.6.5 | Heartbeat Technology application package | 108 | | |
| 10.6.6 | Configuration management | 109 | | |
| 10.6.7 | Using parameters for device administration | 111 | | |
| 10.7 | Simulation | 113 | | |
| 10.8 | Protecting settings from unauthorized access | 116 | | |
| 10.8.1 | Write protection via access code | 116 | | |
| 10.8.2 | Write protection via write protection switch | 117 | | |
| 11 | Operation | 119 | | |
| 11.1 | Reading off the device locking status | 119 | | |
| 11.2 | Adjusting the operating language | 119 | | |
| 11.3 | Configuring the display | 119 | | |
| 11.4 | Adapting the measuring device to the process conditions | 119 | | |
| 11.5 | Reading off measured values | 120 | | |
| 11.5.1 | "Process variables" submenu | 120 | | |
| 11.5.2 | "Input values" submenu | 121 | | |
| 11.5.3 | Output values | 122 | | |
| 11.5.4 | "Totalizer" submenu | 124 | | |
| 11.6 | Performing a totalizer reset | 125 | | |
| 11.6.1 | Function scope of "Control Totalizer" parameter | 125 | | |
| 11.6.2 | Function range of "Reset all totalizers" parameter | 126 | | |
| 11.7 | Displaying the measured value history | 127 | | |
| 11.8 | Adjusting the measured value with the aid of wizards | 130 | | |
| 11.8.1 | Performing the basic settings for the adjustment | 130 | | |
| 11.8.2 | Adjusting the measured value based on the reference value | 130 | | |
| 11.8.3 | Calling up wizards | 132 | | |
| 12 | Diagnosis and troubleshooting | 134 | | |
| 12.1 | General troubleshooting | 134 | | |
| 12.2 | Diagnostic information via LEDs | 137 | | |
| 12.2.1 | Transmitter | 137 | | |
| 12.3 | Diagnostic information on local display | 138 | | |
| 12.3.1 | Diagnostic message | 138 | | |
| 12.3.2 | Calling up remedial measures | 140 | | |
| 12.4 | Diagnostic information in the web browser | 141 | | |
| 12.4.1 | Diagnostic options | 141 | | |
| 12.4.2 | Calling up remedy information | 141 | | |
| 12.5 | Diagnostic information in FieldCare or DeviceCare | 142 | | |
| 12.5.1 | Diagnostic options | 142 | | |
| 12.5.2 | Calling up remedy information | 143 | | |
| 12.6 | Diagnostic information via communication interface | 143 | | |
| 12.6.1 | Reading out diagnostic information | 143 | | |
| 12.6.2 | Configuring error response mode | 143 | | |
| 12.7 | Adapting the diagnostic information | 144 | | |
| 12.7.1 | Adapting the diagnostic behavior | 144 | | |
| 12.8 | Overview of diagnostic information | 145 | | |
| 12.9 | Pending diagnostic events | 149 | | |
| 12.10 | Diagnostics list | 149 | | |
| 12.11 | Event logbook | 151 | | |
| 12.11.1 | Reading out the event logbook | 151 | | |
| 12.11.2 | Filtering the event logbook | 151 | | |
| 12.11.3 | Overview of information events | 152 | | |
| 12.12 | Resetting the measuring device | 154 | | |
| 12.12.1 | Function range of "Device reset" parameter | 154 | | |

| | | |
|------------------------|----------------------------------------------|------------|
| 12.13 | Device information | 154 |
| 12.14 | Firmware history | 156 |
| 13 | Maintenance | 157 |
| 13.1 | Maintenance work | 157 |
| 13.1.1 | Exterior cleaning | 157 |
| 13.2 | Endress+Hauser services | 157 |
| 14 | Repair | 158 |
| 14.1 | General notes | 158 |
| 14.1.1 | Repair and conversion concept | 158 |
| 14.1.2 | Notes for repair and conversion | 158 |
| 14.2 | Spare parts | 158 |
| 14.3 | Endress+Hauser services | 158 |
| 14.4 | Return | 158 |
| 14.5 | Disposal | 159 |
| 14.5.1 | Removing the measuring device | 159 |
| 14.5.2 | Disposing of the measuring device | 159 |
| 15 | Accessories | 160 |
| 15.1 | Device-specific accessories | 160 |
| 15.1.1 | For the transmitter | 160 |
| 15.1.2 | For the sensor | 161 |
| 15.2 | Communication-specific accessories | 161 |
| 15.3 | Service-specific accessories | 162 |
| 15.4 | System components | 162 |
| 16 | Technical data | 163 |
| 16.1 | Application | 163 |
| 16.2 | Function and system design | 163 |
| 16.3 | Input | 163 |
| 16.4 | Output | 166 |
| 16.5 | Power supply | 171 |
| 16.6 | Performance characteristics | 173 |
| 16.7 | Mounting | 174 |
| 16.8 | Environment | 174 |
| 16.9 | Process | 175 |
| 16.10 | Mechanical construction | 176 |
| 16.11 | Display and user interface | 178 |
| 16.12 | Certificates and approvals | 185 |
| 16.13 | Application packages | 186 |
| 16.14 | Supplemental documentation | 187 |
| Index | | 189 |

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Direct current |
|  | Alternating current |
|  | Direct current and alternating current |
|  | Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system. |
|  | Potential equalization connection (PE: protective earth) Ground terminals that must be connected to ground prior to establishing any other connections. The ground terminals are located on the interior and exterior of the device: <ul style="list-style-type: none"> ▪ Interior ground terminal: potential equalization is connected to the supply network. ▪ Exterior ground terminal: device is connected to the plant grounding system. |

1.2.3 Communication-specific symbols

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
|  | Wireless Local Area Network (WLAN) Communication via a wireless, local network. |
|  | LED Light emitting diode is off. |

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|-------------------------------------------------|
|  | LED Light emitting diode is on. |
|  | LED Light emitting diode is flashing. |

1.2.4 Tool symbols

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|------------------------|
|  | Flat-blade screwdriver |
|  | Allen key |
|  | Open-ended wrench |

1.2.5 Symbols for certain types of information

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------|
|  | Permitted Procedures, processes or actions that are permitted. |
|  | Preferred Procedures, processes or actions that are preferred. |
|  | Forbidden Procedures, processes or actions that are forbidden. |
|  | Tip Indicates additional information. |
|  | Reference to documentation |
|  | Reference to page |
|  | Reference to graphic |
|  | Notice or individual step to be observed |
|  | Series of steps |
|  | Result of a step |
|  | Help in the event of a problem |
|  | Visual inspection |

1.2.6 Symbols in graphics

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|-----------------|
| 1, 2, 3, ... | Item numbers |
|  | Series of steps |
| A, B, C, ... | Views |
| A-A, B-B, C-C, ... | Sections |
|  | Hazardous area |

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|--------------------------------|
|  | Safe area (non-hazardous area) |
|  | Flow direction |

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

1.3.1 Document function

The following documentation may be available depending on the version ordered:

| Document type | Purpose and content of the document |
|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Technical Information (TI) | Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device. |
| Brief Operating Instructions (KA) | Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning. |
| Operating Instructions (BA) | Your reference document The Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal. |
| Description of Device Parameters (GP) | Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations. |
| Safety Instructions (XA) | Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. The Safety Instructions are an integral part of the Operating Instructions.  Information on the Safety Instructions (XA) relevant to the device is provided on the nameplate. |
| Supplementary device-dependent documentation (SD/FY) | Always comply strictly with the instructions in the relevant supplementary documentation. The supplementary documentation is an integral part of the device documentation. |

1.4 Registered trademarks

Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for solids content measurement in water-based liquids.

Measuring devices for use in explosive atmospheres are labeled accordingly on the nameplate.

To ensure that the measuring device is in proper condition during the operation period:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Refer to the nameplate to check whether the ordered device can be operated for the intended application in areas requiring specific approvals (e.g. explosion protection, pressure equipment safety).
- ▶ Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ Keep within the specified pressure and temperature range.
- ▶ Keep within the specified ambient temperature range.
- ▶ Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

NOTICE**Verification for borderline cases:**

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks**⚠ CAUTION****Risk of hot or cold burns! The use of media and electronics with high or low temperatures can produce hot or cold surfaces on the device.**

- ▶ Mount suitable touch protection.
- ▶ Use suitable protective equipment.

2.3 Workplace safety

When working on and with the device:

- ▶ Wear the required personal protective equipment as per national regulations.

2.4 Operational safety

Damage to the device!

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

- ▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity..

2.6 IT security

Our warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. The following list provides an overview of the most important functions:

| Function/interface | Factory setting | Recommendation |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|-----------------------------------------------------------|
| Write protection via hardware write protection switch →  11 | Not enabled | On an individual basis following risk assessment |
| Access code (also applies to web server login or FieldCare connection) →  11 | Not enabled (0000) | Assign a customized access code during commissioning |
| WLAN (order option in display module) | Enabled | On an individual basis following risk assessment |
| WLAN security mode | Enabled (WPA2-PSK) | Do not change |
| WLAN passphrase (Password) →  12 | Serial number | Assign an individual WLAN passphrase during commissioning |
| WLAN mode | Access point | On an individual basis following risk assessment |
| Web server →  12 | Enabled | On an individual basis following risk assessment |
| CDI-RJ45 service interface →  12 | – | On an individual basis following risk assessment |

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered →  117.

2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- **User-specific access code**
Protect write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- **WLAN passphrase**
The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- **Infrastructure mode**
When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code (→  116).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface (→  68), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter (→  108).

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning for safety reasons.
- Follow the general rules for generating a secure password when defining and managing the access code and network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see "Write protection via access code" →  116.

2.7.3 Access via web server

→  61 With the integrated web server, the device can be operated and configured via a web browser. The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The web server is enabled when the device is delivered. The web server can be disabled via the **Web server functionality** parameter if necessary (e.g., after commissioning).

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

 For detailed information on device parameters, see: "Description of device parameters" document →  188.

2.7.4 Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.


3 Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design








1 Important components of a measuring device

- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing
- 4 Electronics compartment cover
- 5 Sensor

i Use of the device with the remote display and operating module DKX001 → 39.

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- i** ■ If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations app*: Product identification → 15.

4.2 Product identification


The following options are available for identification of the device:

- Nameplate
- Order code with details of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations app* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations app*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard documentation on the device" and "Supplementary device-dependent documentation" sections
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations app*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Transmitter nameplate




A0029192

2 Example of a transmitter nameplate

- 1 Manufacturer address/certificate holder
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Date of manufacture: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, RCM tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature (T_a)
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

4.2.2 Sensor nameplate



A0051311

- 1 Name of sensor
- 2 Manufacturer address/certificate holder
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Full scale value; nominal diameter of the sensor; pressure rating; nominal pressure; static pressure; medium temperature range; measuring tube material, antennas, temperature sensor and gasket between antenna holder and cast body, antenna ceramic
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Date of manufacture: year-month
- 9 2-D matrix code
- 10 CE mark, RCM-Tick mark
- 11 Document number of safety-related supplementary documentation
- 12 Permitted ambient temperature (T_a)



Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

4.2.3 Symbols on the device

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. Please consult the documentation for the measuring device to discover the type of potential danger and measures to avoid it. |
|  | Reference to documentation Refers to the corresponding device documentation. |
|  | Protective ground connection A terminal that must be connected to the ground prior to establishing any other connections. |

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ▶ Store in a dry and dust-free place.
- ▶ Do not store outdoors.

Storage temperature →  174

5.2 Transporting the product

-  Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices with lifting lugs

Devices with a nominal diameter of DN 200 to 300 mm (8 to 12 in) have two options for mounting lifting lugs (eyebolts) for the purpose of transport. The two upper threaded holes are provided for vertically transporting the device, while the two upper threaded holes and one of the opposite lower threaded holes are provided for horizontal transport.

CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted to the device for transport.
- ▶ The device must always be attached to two lifting lugs when transported vertically and three lifting lugs when transported horizontally.



 3 Vertical and horizontal transport of the device using mounted lifting lugs

A0053150

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Outer packaging of device
 - Stretch wrap made of polymer in accordance with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wood crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62/EC, recyclability confirmed by Resy symbol
- Transport material and fastening fixtures
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material
 - Paper pads

6 Mounting procedure

6.1 Mounting requirements


6.1.1 Mounting position

Installation point

Installation in pipe

Do **not** install the device:


- At the highest point of the pipe (risk of gas bubbles accumulating in the measuring tube)
- Upstream of a free pipe outlet in a down pipe



A0042131

Install the device:


- Ideally in an ascending pipe
- Upstream of an ascending pipe or in areas where the device is filled with medium



A0042317

Installation near valves


Mount the sensor upstream from control valves if possible.



A0041091

Installation near pumps


- Install the device in the direction of flow downstream from the pump.
- Also install pulsation dampers if reciprocating, diaphragm or peristaltic pumps are used.



A0041083

Installation upstream from a down pipe

If installing upstream of down pipes with a length $h \geq 5$ m (16.4 ft): Install a siphon with a vent valve downstream of the device.




A0028981

4 This arrangement prevents the flow of liquid stopping in the pipe and the formation of air pockets.

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe

Installation with partially filled pipes

- Partially filled pipes with a gradient require a drain-type configuration.
- The installation of a cleaning valve is recommended.



A0047712

Installation in event of pipe vibrations


NOTICE

Pipe vibrations can damage the device!

- Do not expose the device to strong vibrations.

i Information on the measuring system's resistance to vibration and shock → 175

Orientation



A0052236

- 1 Vertical orientation
2 Horizontal orientation

Vertical orientation

The device should ideally be installed in a rising pipe:


- To avoid having a partially filled pipe
- To avoid any gas accumulation
- The measuring tube can be completely drained and protected against the buildup of deposits.

i In the case of total solids of $\geq 20\%$ TS:

Install the device vertically. If it is installed horizontally, separating layers can form as a result of sedimentation, separating liquid and solids. This can lead to measurement errors.

Horizontal orientation

The antennas (transmitter and receiver) should be positioned horizontally in order to avoid interference to the measurement signal caused by entrained air bubbles.



A0047713

- 1 Antenna - transmitter
2 Antenna - receiver
3 Temperature sensor

Flow direction


The device can be installed independently of the flow direction.

Inlet and outlet runs

When installing the device, no inlet and outlet runs need to be taken into account. No special precautions need to be taken for fittings that create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs.

Installation with sampling points

To obtain a representative sample, the sampling points should be installed in the immediate vicinity of the device. This also makes it easier to take the sample and run the wizards via the device's local operation.




1 Sampling point

Installation with option for cleaning

Depending on the process conditions (e.g. grease deposits), it may be necessary to clean the device. Additional components can be fitted to avoid any need to remove the device for cleaning:

- Rinse connection
- Cleaning shaft



1 Shutoff valve
2 Shut-off flap for cleaning

i If there is a risk of deposits building up in the measuring tube, as a result of grease for example, a flow velocity of >2 m/s (6.5 ft/s) is recommended.

Dimensions

i For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .-> **187**

6.1.2 Environmental and process requirements

Ambient temperature range

Technical data for the ambient temperature range →  174



If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

A weather protection cover is available as an accessory. →  160

Static pressure


Technical data for the static pressure →  175

Vibration and shock resistance

Technical data for vibration and shock resistance →  175

Thermal insulation

- For very hot media: To reduce energy losses and prevent accidental contact with hot pipes
- In cold environments: To prevent cooling of the pipe wall and the sensor from the outside, which could promote the formation of grease deposits



A0052236


WARNING

Electronics overheating on account of thermal insulation!

- ▶ Do not insulate the transmitter housing.
- ▶ Insulation may be provided as far as the connection between the sensor and the transmitter housing.
- ▶ Maximum permissible temperature at the lower end of the transmitter housing: 75 °C (167 °F)

6.1.3 Special mounting instructions

Weather protection cover



A0029553

5 Unit mm (in)

i A weather protection cover is available as an accessory. → 160

6.2 Mounting the measuring device

6.2.1 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.

6.2.2 Mounting the sensor

⚠ WARNING


Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Secure the gaskets correctly.
- ▶ Apply the correct screw tightening torques and comply with the mounting instructions →  28.


Center the sensor between the pipe flanges and mount it in the measuring path.

-  A mounting kit consisting of screws/mounting bolts, gaskets, nuts and washers can be ordered as an optional extra:
 - Directly with the device: Order code for "Accessory enclosed", option PE
 - Separately as an accessory →  160

1. Position the device or rotate the transmitter housing so that the cable entries do not point upwards.



2. Following the correct screw tightening torques and mounting instructions →  28, mount the sensor between the pipe flanges in the measurement path.



A0047715

6 Mounting the sensor

- 1 Nut
- 2 Washer
- 3 Screw/mounting bolt
- 4 Gasket

Screw tightening torques

NOTICE

Failure to observe screw tightening torques or mounting instructions

The process connection may be overloaded if screw tightening torques are not observed or the mounting instructions cannot be followed. This can produce a leaking process connection from which the medium escapes.

- ▶ Apply the correct screw tightening torques and comply with the mounting instructions.

The following mounting instructions must be observed:

- The specified screw tightening torques only apply when using the mounting kit, which can be ordered as an accessory → 161.
- Nuts, threads and screw head surfaces must be greased before assembly.
- The pipes must be free of tensile stress.
- The screws must be tightened evenly in diagonally opposite sequence.

i The values for the screw tightening torques depend on variables such as seals, screws, lubricants, tightening methods etc. These variables are outside the control of the manufacturer. The values indicated are therefore guideline values only.

Maximum screw tightening torques for EN 1092-1

| Nominal diameter | | Pressure rating | Screws | Max. screw tightening torque |
|------------------|------|-----------------|----------|------------------------------|
| [mm] | [in] | | | |
| 50 | 2 | PN 10 | 4 x M16 | 85 Nm (62.7 lbf ft) |
| | | PN 16 | | |
| 80 | 3 | PN 10 | 8 x M16 | 85 Nm (62.7 lbf ft) |
| | | PN 16 | | |
| 100 | 4 | PN 10 | 8 x M16 | 100 Nm (73.8 lbf ft) |
| | | PN 16 | | |
| 150 | 6 | PN 10 | 8 x M20 | 200 Nm (147.5 lbf ft) |
| | | PN 16 | | |
| 200 | 8 | PN 10 | 8 x M20 | 200 Nm (147.5 lbf ft) |
| | | PN 16 | 12 x M20 | 200 Nm (147.5 lbf ft) |

| Nominal diameter | | Pressure rating | Screws | Max. screw tightening torque |
|------------------|------|-----------------|----------|------------------------------|
| [mm] | [in] | | | |
| 250 | 10 | PN 10 | 12 x M20 | 220 Nm (162.3 lbf ft) |
| | | PN 16 | 12 x M24 | 250 Nm (184.4 lbf ft) |
| 300 | 12 | PN 10 | 12 x M20 | 220 Nm (162.3 lbf ft) |
| | | PN 16 | 12 x M24 | 300 Nm (221.3 lbf ft) |

Maximum screw tightening torques for ASME B16.5


| Nominal diameter | | Pressure rating | Screws | Max. screw tightening torque |
|------------------|------|-----------------|-----------|------------------------------|
| [mm] | [in] | | | |
| 50 | 2 | Class 150 | 4 x 5/8" | 110 Nm (81.1 lbf ft) |
| 80 | 3 | Class 150 | 4 x 5/8" | 130 Nm (95.9 lbf ft) |
| 100 | 4 | Class 150 | 8 x 5/8" | 130 Nm (95.9 lbf ft) |
| 150 | 6 | Class 150 | 8 x 3/4" | 220 Nm (162.3 lbf ft) |
| 200 | 8 | Class 150 | 8 x 3/4" | 250 Nm (184.4 lbf ft) |
| 250 | 10 | Class 150 | 12 x 7/8" | 300 Nm (221.3 lbf ft) |
| 300 | 12 | Class 150 | 12 x 7/8" | 350 Nm (258.2 lbf ft) |

Maximum screw tightening torques for JIS B2220

| Nominal diameter | | Pressure rating | Screws | Max. screw tightening torque |
|------------------|------|-----------------|----------|------------------------------|
| [mm] | [in] | | | |
| 50 | 2 | 10K | 4 x M16 | 90 Nm (66.4 lbf ft) |
| 80 | 3 | 10K | 8 x M16 | 90 Nm (66.4 lbf ft) |
| 100 | 4 | 10K | 8 x M16 | 90 Nm (66.4 lbf ft) |
| 150 | 6 | 10K | 8 x M20 | 200 Nm (147.5 lbf ft) |
| 200 | 8 | 10K | 12 x M20 | 200 Nm (147.5 lbf ft) |
| 250 | 10 | 10K | 12 x M22 | 280 Nm (206.5 lbf ft) |
| 300 | 12 | 10K | 16 x M22 | 280 Nm (206.5 lbf ft) |

6.2.3 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



A0029993

7 Non-Ex housing

1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Loosen the securing screw.
4. Turn the housing to the desired position.
5. Tighten the securing screw.
6. Screw on the connection compartment cover.
7. Depending on the device version: Attach the securing clamp of the connection compartment cover.




A0043150

8 Ex housing

1. Loosen the fixing screws.
2. Turn the housing to the desired position.
3. Tighten the securing screws.

6.2.4 Turning the display module

The display module can be turned to optimize display readability and operability.



A0030035

1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Turn the display module to the desired position: max. $8 \times 45^\circ$ in each direction.
4. Screw on the connection compartment cover.
5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.3 Post-mounting check

| | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| Is the device undamaged (visual inspection)? | <input type="checkbox"/> |
| Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ▪ Process temperature ▪ Pressure (refer to the "Pressure-temperature ratings" section of the "Technical Information" document) ▪ Ambient temperature ▪ Measuring range | <input type="checkbox"/> |
| Has the correct orientation for the sensor been selected? <ul style="list-style-type: none"> ▪ According to sensor type ▪ According to medium temperature ▪ According to medium properties | <input type="checkbox"/> |
| Are the measuring point identification and labeling correct (visual inspection)? | <input type="checkbox"/> |
| Is the device adequately protected against precipitation and direct sunlight? | <input type="checkbox"/> |
| Have the fixing screws been tightened with the correct tightening torque? | <input type="checkbox"/> |

7 Electrical connection

⚠ WARNING

Live parts! Incorrect work performed on the electrical connections can result in an electric shock.

- ▶ Set up a disconnecting device (switch or power-circuit breaker) to easily disconnect the device from the supply voltage.
- ▶ In addition to the device fuse, include an overcurrent protection unit with max. 10 A in the plant installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver ≤ 3 mm (0.12 in)

7.2.2 Requirements for connection cable

The connecting cables provided by the customer must fulfill the following requirements.

Protective grounding cable for the outer ground terminal

Conductor cross-section < 2.1 mm² (14 AWG)

The use of a cable lug enables the connection of larger cross-sections.

The grounding impedance must be less than 2 Ω .

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

| | |
|--------------------------|-------------------------------------------------------------|
| Cable type | A |
| Characteristic impedance | 135 to 165 Ω at a measuring frequency of 3 to 20 MHz |
| Cable capacitance | < 30 pF/m |
| Wire cross-section | > 0.34 mm ² (22 AWG) |

| | |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Cable type | Twisted pairs |
| Loop resistance | ≤110 Ω/km |
| Signal damping | Max. 9 dB over the entire length of the cable cross-section |
| Shield | Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant. |

Current output 0/4 to 20 mA

Standard installation cable is sufficient

Pulse /frequency /switch output

Standard installation cable is sufficient

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient

Status input

Standard installation cable is sufficient

Cable diameter

- Cable glands supplied:
M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules.
Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Requirements for connecting cable – remote display and operating module DKX001

Optionally available connecting cable

A cable is supplied depending on the order option

- Order code for measuring device: order code **030** for "Display; operation", option **O**
or
- Order code for measuring device: order code **030** for "Display; operation", option **M**
and
- Order code for DKX001: order code **040** for "Cable", option **A, B, D, E**

| | |
|---------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Standard cable | 2 × 2 × 0.34 mm ² (22 AWG) PVC cable with common shield (2 pairs, pair-stranded) |
| Flame resistance | According to DIN EN 60332-1-2 |
| Oil resistance | According to DIN EN 60811-2-1 |
| Shield | Tin-plated copper braid, optical cover ≥ 85 % |
| Capacitance: core/shield | ≤ 200 pF/m |
| L/R | ≤ 24 μH/Ω |
| Available cable length | 5 m (15 ft)/10 m (35 ft)/20 m (65 ft)/30 m (100 ft) |
| Operating temperature | When mounted in a fixed position: -50 to +105 °C (-58 to +221 °F); when cable can move freely: -25 to +105 °C (-13 to +221 °F) |

Standard cable - customer-specific cable

With the following order option, no cable is supplied with the device and must be provided by the customer:

Order code for DKX001: Order code **040** for "Cable", option **1** "None, provided by customer, max 300 m"

A standard cable with the following minimum requirements can be used as the connecting cable, even in the hazardous area (Zone 2, Class I, Division 2 and Zone 1, Class I, Division 1):

| | |
|---------------------------------|---------------------------------------------------------------------------------------------------------------|
| Standard cable | 4 wires (2 pairs); pair-stranded with common shield, minimum wire cross-section 0.34 mm ² (22 AWG) |
| Shield | Tin-plated copper braid, optical cover ≥ 85 % |
| Cable impedance (pair) | Minimum 80 Ω |
| Cable length | Maximum 300 m (1 000 ft), maximum loop impedance 20 Ω |
| Capacitance: core/shield | Maximum 1 000 nF for Zone 1, Class I, Division 1 |
| L/R | Maximum 24 μH/Ω for Zone 1, Class I, Division 1 |

7.2.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|------------------------------------------------------------------------|-------|----------------|--------|----------------|--------|----------------|--------|
| 1 (+) | 2 (-) | 26 (B) | 27 (A) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| Device-specific terminal assignment: adhesive label in terminal cover. | | | | | | | |

 Terminal assignment of the remote display and operating module →  39.

7.2.4 Shielding and grounding

Shielding and grounding concept

1. Maintain electromagnetic compatibility (EMC).
2. Take explosion protection into consideration.
3. Pay attention to the protection of persons.
4. Comply with national installation regulations and guidelines.
5. Observe cable specifications .
6. Keep the stripped and twisted lengths of cable shield to the ground terminal as short as possible.
7. Shield cables fully.

Grounding of the cable shield

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- ▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.
- ▶ Insulate the shield that is not connected.

To comply with EMC requirements:

1. Ensure the cable shield is grounded to the potential matching line at multiple points.
2. Connect every local ground terminal to the potential matching line.

7.2.5 Preparing the measuring device

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- ▶ Use suitable cable glands corresponding to the degree of protection.

1. Remove dummy plug if present.
2. If the measuring device is supplied without cable glands:
Provide suitable cable gland for corresponding connection cable.
3. If the measuring device is supplied with cable glands:
Observe the requirements for connection cables.


7.3 Connecting the measuring device

NOTICE

An incorrect connection compromises electrical safety!


- ▶ Only properly trained specialist staff may perform electrical connection work.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ⊕ before connecting additional cables.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.3.1 Connecting the transmitter




A0026781

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45); optional: connection for external WLAN antenna or remote display and operating module DKX001
- 4 Protective earth (PE)




A0029813

1. Loosen the securing clamp of the connection compartment cover.
2. Unscrew the connection compartment cover.
3. Squeeze the tabs of the display module holder together.
4. Remove the display module holder.




A0029814

5. Attach the holder to the edge of the electronics compartment.
6. Open the terminal cover.



A0029815

7. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
9. Connect the protective ground.




A0029816

10. Connect the cable according to the terminal assignment.
 - ↳ **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 - Supply voltage connection terminal assignment:** Adhesive label in the terminal cover or → 35.
11. Firmly tighten the cable glands.
 - ↳ This concludes the cable connection process.
12. Close the terminal cover.
13. Fit the display module holder in the electronics compartment.
14. Screw on the connection compartment cover.
15. Secure the securing clamp of the connection compartment cover.

Removing a cable

To remove a cable from the terminal:



A0029598


9 Engineering unit mm (in)

1. Use a flat-blade screwdriver to press down on the slot between the two terminal holes.
2. Remove the cable end from the terminal.

7.3.2 Connecting the remote display and operating module DKX001

i The remote display and operating module DKX001 is available as an optional extra → 160.

- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



A0027518

- 1 Remote display and operating module DKX001
- 2 Terminal connection for potential equalization (PE)
- 3 Connecting cable
- 4 Measuring device
- 5 Terminal connection for potential equalization (PE)

7.4 Potential equalization

7.4.1 Requirements

For potential equalization:


- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Medium, Connect the sensor and transmitter to the same electric potential ¹⁾
- Use a ground cable with a minimum cross-section of 6 mm² (10 AWG) and a cable lug for potential equalization connections

1)

7.5 Special connection instructions

7.5.1 Connection examples


Current output 4-20 mA



A0028758

10 Connection example for 4-20 mA current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load → 166
- 3 Transmitter




A0028759

11 Connection example for 4-20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load → 166
- 4 Transmitter

Pulse/frequency output




A0028761

12 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC with 10 kΩ pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values → 166

Switch output




A0028760

13 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC with a 10 kΩ pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values → 166

Relay output




A0028760

14 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values → 167


Current input



A0028915

15 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- 3 External device (for reading in the flow rate value in order to calculate the load rate)
- 4 Transmitter

Status input

A0028764

16 Connection example for status input


- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter

7.6 Hardware settings


7.6.1 Setting the device address

The device address must always be configured for a Modbus slave. The valid device addresses are in the range from 1 to 247. Each address may only be assigned once in a Modbus RS485 network. If an address is not configured correctly, the measuring device is not recognized by the Modbus master. All measuring devices are delivered from the factory with the device address 247 and with the "software addressing" address mode.

Hardware addressing



Set the desired device address using the DIP switches in the connection compartment.



To switch addressing from software addressing to hardware addressing: set the DIP switch to **On**.

↳ The change of device address takes effect after 10 seconds.


Software addressing

▶ To switch addressing from hardware addressing to software addressing: set the DIP switch to **Off**.

↳ The device address configured in the **Device address** parameter takes effect after 10 seconds.

7.6.2 Activating the terminating resistor

To avoid incorrect communication transmission caused by impedance mismatch, terminate the Modbus RS485 cable correctly at the start and end of the bus segment.



A0029632

Switch DIP switch no. 3 to **On**.


7.7 Ensuring the degree of protection

The measuring device fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To guarantee the degree of protection IP66/67, Type 4X enclosure, carry out the following steps after electrical connection:

1. Check that the housing seals are clean and fitted correctly.
2. Dry, clean or replace the seals if necessary.
3. Tighten all housing screws and screw covers.
4. Firmly tighten the cable glands.
5. To ensure that moisture does not enter the cable entry:

Route the cable so that it loops down before the cable entry ("water trap").



A0029278


6. The cable glands supplied do not ensure housing protection when not in use. They must therefore be replaced by dummy plus corresponding to the housing protection.

7.8 Post-connection check

| | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------|
| Are cables or the device undamaged (visual inspection)? | <input type="checkbox"/> |
| Do the cables used comply with the requirements →  33? | <input type="checkbox"/> |
| Does the supply voltage match the specifications on the transmitter nameplate →  171? | <input type="checkbox"/> |
| Is the terminal assignment correct →  35? | <input type="checkbox"/> |
| Are the power supply and signal cables correctly connected? | <input type="checkbox"/> |
| Is the protective earthing established correctly? | <input type="checkbox"/> |
| Is the cable type route completely isolated? Without loops and cross-overs? | <input type="checkbox"/> |
| Do the cables have adequate strain relief? Are they routed securely? | <input type="checkbox"/> |
| <ul style="list-style-type: none"> ■ Are all cable glands installed, securely tightened and leak-tight? ■ Cable run with "water trap" →  45? | <input type="checkbox"/> |
| Is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter. | <input type="checkbox"/> |
| Are all housing covers installed and securely tightened? | <input type="checkbox"/> |
| Is the securing clamp securely tightened? | <input type="checkbox"/> |
| Are dummy plugs inserted in unused cable entries and have transportation plugs been replaced with dummy plugs? | <input type="checkbox"/> |

8 Operation options

8.1 Overview of operation options




A0030213

- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Mobile handheld terminal with SmartBlue App
- 4 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device



A0018237-EN

 17 Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (e.g. operator, maintenance etc.). Each user role contains typical tasks within the device life cycle.

| Menu/parameter | | User role and tasks | Content/meaning |
|----------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Language | Task-oriented | Role "Operator", "Maintenance" Tasks during operation: <ul style="list-style-type: none"> ▪ Configuration of the operational display ▪ Reading measured values | <ul style="list-style-type: none"> ▪ Defining the operating language ▪ Defining the Web server operating language ▪ Resetting and controlling totalizers |
| Operation | | | <ul style="list-style-type: none"> ▪ Configuration of the operational display (e.g. display format, display contrast) ▪ Resetting and controlling totalizers |
| Setup | | "Maintenance" role Commissioning: <ul style="list-style-type: none"> ▪ Configuration of the measurement ▪ Configuration of the inputs and outputs ▪ Configuration of the communication interface | Wizards for fast commissioning: <ul style="list-style-type: none"> ▪ Configuring the system units ▪ Displaying the I/O configuration ▪ Configuring the inputs ▪ Configuring the outputs ▪ Configuration of the operational display ▪ Configuring the low flow cut off Advanced setup <ul style="list-style-type: none"> ▪ For more customized configuration of the measurement (adaptation to special measuring conditions) ▪ Configuration of totalizers ▪ Configuration of WLAN settings ▪ Administration (define access code, reset measuring device) |
| Diagnostics | | "Maintenance" role Troubleshooting: <ul style="list-style-type: none"> ▪ Diagnostics and elimination of process and device errors ▪ Measured value simulation | Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ▪ Diagnostic list Contains up to 5 currently pending diagnostic messages. ▪ Event logbook Contains event messages that have occurred. ▪ Device information Contains information for identifying the device ▪ Measured values Contains all current measured values. ▪ Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values ▪ Heartbeat Technology Verification of device functionality on request and documentation of verification results ▪ Simulation Used to simulate measured values or output values. |
| Expert | Function-oriented | Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> ▪ Commissioning measurements under difficult conditions ▪ Optimal adaptation of the measurement to difficult conditions ▪ Detailed configuration of the communication interface ▪ Error diagnostics in difficult cases | Contains all of the device parameters and allows direct access to these by means of an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> ▪ System Contains all higher-level device parameters that do not affect measurement or measured value communication ▪ Sensor Configuration of the measurement. ▪ Input Configuration of the status input ▪ Output Configuration of the analog current outputs as well as the pulse/frequency and switch output ▪ Communication Configuration of the digital communication interface and the Web server ▪ Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer) ▪ Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology. |

8.3 Access to operating menu via local display

8.3.1 Operational display



A0051675

- 1 Operational display
- 2 Device tag
- 3 Status area
- 4 Display range for measured values (up to 4 lines)
- 5 Operating elements


Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 138
 - **F**: Failure
 - **C**: Function check
 - **S**: Out of specification
 - **M**: Maintenance required
- Diagnostic behavior → 139
 - : Alarm
 - : Warning
 - : Locking (the device is locked via the hardware)
 - : Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Appears only if a diagnostics event is present for this measured variable.

Measured variables

| Symbol | Meaning |
|--------|--------------------------|
| | Dry matter concentration |
| | Solids load |

| | |
|-----------------------------------------------------------------------------------|--------------|
|  | Temperature |
|  | Conductivity |

 The number and display format of the measured variables can be configured via the **Format display** parameter (→  97).

Totalizer

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|-----------|
|  | Totalizer |

Output

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Output  The measurement channel number indicates which of the outputs is displayed. |

Input

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|--------------|
|  | Status input |

Measurement channel numbers


| Symbol | Meaning |
|-------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Measurement channel 1 to 4  The measurement channel number is displayed only if more than one channel is present for the same measured variable type . |

Diagnostic behavior

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Alarm <ul style="list-style-type: none"> ▪ Measurement is interrupted. ▪ Signal outputs and totalizers assume the defined alarm condition. ▪ A diagnostic message is generated. |
|  | Warning <ul style="list-style-type: none"> ▪ Measurement is resumed. ▪ The signal outputs and totalizers are not affected. ▪ A diagnostic message is generated. |

 The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.

8.3.2 Navigation view



Navigation path

The navigation path to the current position is displayed at the top left in the navigation view and consists of the following elements:

- The display symbol for the menu/submenu (▶) or the wizard (⚙).
- An omission symbol (/ ../) for operating menu levels in between.
- Name of the current submenu, wizard or parameter

| | Display symbol | Omission symbol | Parameter |
|---------|----------------|-----------------|------------|
| | ↓ | ↓ | ↓ |
| Example | ▶ | / ../ | Indication |

i For more information about the icons in the menu, refer to the "Display area" section → 52

Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
If a diagnostic event is present, the diagnostic behavior and status signal

i For information on the diagnostic behavior and status signal → 138

Display area

Menus

| Symbol | Meaning |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Operation Is displayed: <ul style="list-style-type: none"> ▪ In the menu next to the "Operation" selection ▪ At the left in the navigation path in the Operation menu |

| | |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Setup Is displayed:</p> <ul style="list-style-type: none"> ▪ In the menu next to the "Setup" selection ▪ At the left in the navigation path in the Setup menu |
|  | <p>Diagnosis Is displayed:</p> <ul style="list-style-type: none"> ▪ In the menu next to the "Diagnostics" selection ▪ At the left in the navigation path in the Diagnostics menu |
|  | <p>Expert Is displayed:</p> <ul style="list-style-type: none"> ▪ In the menu next to the "Expert" selection ▪ At the left in the navigation path in the Expert menu |

Submenus, wizards, parameters

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Submenu |
|  | Wizards |
|  | Parameters within a wizard  No display symbol exists for parameters in submenus. |

Locking procedure


| Symbol | Meaning |
|-------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked.</p> <ul style="list-style-type: none"> ▪ By a user-specific access code ▪ By the hardware write protection switch |

Wizards

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------|
|  | Switches to the previous parameter. |
|  | Confirms the parameter value and switches to the next parameter. |
|  | Opens the editing view of the parameter. |

8.3.3 Editing view

Numeric editor




A0034250

18 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 Operating elements

Text editor



A0034114

19 For entering text in parameters (e.g. device tag)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 Operating elements
- 5 Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

Using the operating elements in the editing view

| Operating key | Meaning |
|---------------|----------------------------------------------------------|
| ⊖ | Minus key Move the entry position to the left. |
| ⊕ | Plus key Move the entry position to the right. |

| Operating key | Meaning |
|-----------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Enter key <ul style="list-style-type: none"> Pressing the key briefly confirms your selection. Pressing the key for 2 s confirms your entry. Pressing the key for > 3 s calls up the wizards: Compare measured value with reference value. |
|  | Escape key combination (press keys simultaneously) Close the editing view without accepting a change. |

Input screens

| Symbol | Meaning |
|------------|-----------------------------------------------------------------------------------------------------|
| A.. | Upper case |
| a.. | Lower case |
| 1.. | Numbers |
| +.. | Punctuation marks and special characters: = + - * / ² ³ ¼ ½ ¾ () < > { } |
| @.. | Punctuation marks and special characters: ' " ^ . , ; : ? ! % μ ° € \$ £ ¥ \$ @ # / \ ~ & _ |
| ä.. | Umlauts and accents |

Controlling data entries

| Symbol | Meaning |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------|
|  | Move entry position |
|  | Reject entry |
|  | Confirm entry |
|  | Delete character immediately to the left of the entry position |
| del | Delete character immediately to the right of the entry position |
| C | Clear all the characters entered |

8.3.4 Operating elements

| Operating key | Meaning |
|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>Minus key</p> <p><i>In menu, submenu</i> Moves the selection bar upwards in a picklist</p> <p><i>In wizards</i> Goes to previous parameter</p> <p><i>In the text and numeric editor</i> Move the entry position to the left.</p> |
|  | <p>Plus key</p> <p><i>In menu, submenu</i> Moves the selection bar downwards in a picklist</p> <p><i>In wizards</i> Goes to the next parameter</p> <p><i>In the text and numeric editor</i> Move the entry position to the right.</p> |
|  | <p>Enter key</p> <p><i>In the operational display</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly opens the operating menu. ▪ Pressing the key for > 3 s opens a context menu with the options: <ul style="list-style-type: none"> ▪ Call up the wizards: Compare measured value with reference value ▪ Activate keypad lock <p><i>In menu, submenu</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly: <ul style="list-style-type: none"> ▪ Opens the selected menu, submenu or parameter. ▪ Starts the wizard. ▪ If help text is open, closes the help text of the parameter. ▪ Pressing the key for 2 s in a parameter: <ul style="list-style-type: none"> ▪ If present, opens the help text for the function of the parameter. <p><i>In wizards</i> Opens the editing view of the parameter and confirms the parameter value</p> <p><i>In the text and numeric editor</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly confirms your selection. ▪ Pressing the key for 2 s confirms your entry. |
|  | <p>Escape key combination (press keys simultaneously)</p> <p><i>In menu, submenu</i></p> <ul style="list-style-type: none"> ▪ Pressing the key briefly: <ul style="list-style-type: none"> ▪ Exits the current menu level and takes you to the next higher level. ▪ If help text is open, closes the help text of the parameter. ▪ Pressing the key for 2 s returns you to the operational display ("home position"). <p><i>In wizards</i> Exits the wizard and takes you to the next higher level</p> <p><i>In the text and numeric editor</i> Exits the Editing view without applying the changes.</p> |
|  | <p>Minus/Enter key combination (press and hold down the keys simultaneously)</p> <ul style="list-style-type: none"> ▪ If keypad lock is active: <ul style="list-style-type: none"> ▪ Pressing the key for 3 s deactivates the keypad lock. ▪ If keypad lock is not active: <ul style="list-style-type: none"> ▪ Pressing the key for 3 s opens the context menu including the option for activating the keypad lock. |

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

1. Press the  and  keys for longer than 3 seconds.
 - ↳ The context menu opens.



2. Press  +  simultaneously.
 - ↳ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


1. Open the context menu.
2. Press  to navigate to the desired menu.
3. Press  to confirm the selection.
 - ↳ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

i For an explanation of the navigation view with symbols and operating elements → 52

Example: Setting the number of displayed measured values to "2 values"



A0053525-EN


8.3.7 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press  for 2 s.
 - ↳ The help text for the selected parameter opens.



A0014002-EN

 20 Example: Help text for parameter "Enter access code"


2. Press  +  simultaneously.
 - ↳ The help text is closed.

8.3.8 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.



A0014049-EN

 For a description of the editing view - consisting of the text editor and numeric editor - with symbols →  54, for a description of the operating elements →  56

8.3.9 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access →  116.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
 - ↳ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

| Access code status | Read access | Write access |
|------------------------------------------------------------|-------------|-----------------|
| An access code has not yet been defined (factory setting). | ✓ | ✓ |
| After an access code has been defined. | ✓ | ✓ ¹⁾ |

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

| Access code status | Read access | Write access |
|----------------------------------------|-------------|--------------|
| After an access code has been defined. | ✓ | - 1) |

- 1) Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection as they do not affect the measurement: write protection via access code → ⓘ 116

 The user role with which the user is currently logged on is indicated by the **Access status** parameter. Navigation path: Operation → Access status

8.3.10 Disabling write protection via access code

If the ⓘ-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation → ⓘ 116.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter (→ ⓘ 101) via the respective access option.

1. After you press ⏏, the input prompt for the access code appears.
2. Enter the access code.
 - ↳ The ⓘ-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.11 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

-  The keypad lock is switched on automatically:
 - If the device has not been operated via the display for > 1 minute.
 - Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display. Press the ⏏ and ⏏ keys for 3 seconds.
 - ↳ A context menu appears.
2. In the context menu select the **Keylock on** option.
 - ↳ The keypad lock is switched on.

 If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- ▶ The keypad lock is switched on. Press the ⏏ and ⏏ keys for 3 seconds.
 - ↳ The keypad lock is switched off.

8.4 Access to operating menu via web browser

8.4.1 Function range

With the integrated web server, the device can be operated and configured via a web browser service interface (CDI-RJ45) or WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

8.4.2 Requirements

Computer hardware

| Hardware | Interface | |
|------------|-----------------------------------------------------------|------------------------------------------------|
| | CDI-RJ45 | WLAN |
| Interface | The computer must have a RJ45 interface. ¹⁾ | The operating unit must have a WLAN interface. |
| Connection | Standard Ethernet cable | Connection via Wireless LAN. |
| Screen | Recommended size: ≥12" (depends on the screen resolution) | |

1) Recommended cable: CAT5e, CAT6 or CAT7, with shielded plug (e.g. YAMAICHI product; part no. Y-ConProfixPlug63/Prod. ID: 82-006660)

Computer software

| Software | Interface | |
|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| | CDI-RJ45 | WLAN |
| Recommended operating systems | <ul style="list-style-type: none"> ▪ Microsoft Windows 8 or higher. ▪ Mobile operating systems: <ul style="list-style-type: none"> ▪ iOS ▪ Android  Microsoft Windows XP and Windows 7 is supported. | |
| Web browsers supported | <ul style="list-style-type: none"> ▪ Microsoft Internet Explorer 8 or higher ▪ Microsoft Edge ▪ Mozilla Firefox ▪ Google Chrome ▪ Safari | |

Computer settings

| Settings | Interface | |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|------|
| | CDI-RJ45 | WLAN |
| User rights | Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (e.g. for adjusting the IP address, subnet mask etc.). | |
| Proxy server settings of the web browser | The web browser setting <i>Use a proxy server for your LAN</i> must be disabled . | |

| Settings | Interface | |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| | CDI-RJ45 | WLAN |
| JavaScript | <p>JavaScript must be enabled.</p> <p> If JavaScript cannot be enabled: Enter <code>http://192.168.1.212/servlet/basic.html</code> in the address bar of the web browser. A fully functional but simplified version of the operating menu structure starts in the web browser.</p> <p> When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) under Internet options in the web browser.</p> | <p>JavaScript must be enabled.</p> <p> The WLAN display requires JavaScript support.</p> |
| Network connections | Only use the active network connections to the measuring device. | |
| | Switch off all other network connections such as WLAN for example. | Switch off all other network connections. |

 In the event of connection problems:

Measuring device: Via CDI-RJ45 service interface

| Device | CDI-RJ45 service interface |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Measuring device | The measuring device has an RJ45 interface. |
| Web server | <p>Web server must be enabled; factory setting: ON</p> <p> For information on enabling the Web server →  66</p> |

Measuring device: via WLAN interface

| Device | WLAN interface |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Measuring device | <p>The measuring device has a WLAN antenna:</p> <ul style="list-style-type: none"> ▪ Transmitter with integrated WLAN antenna ▪ Transmitter with external WLAN antenna |
| Web server | <p>Web server and WLAN must be enabled; factory setting: ON</p> <p> For information on enabling the Web server →  66</p> |

8.4.3 Connecting the device

Via service interface (CDI-RJ45)

Preparing the measuring device

1. Depending on the housing version:
Loosen the securing clamp or fixing screw of the housing cover.
2. Depending on the housing version:
Unscrew or open the housing cover.
3. Connect the computer to the RJ45 plug via the standard Ethernet cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

1. Switch on the measuring device.

2. Connect the computer to the RJ45 plug via the standard Ethernet cable →  68.
3. If a 2nd network card is not used, close all the applications on the notebook.
 - ↳ Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
4. Close any open Internet browsers.
5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

| | |
|------------------------|--------------------------------------------------------------------------------------------|
| IP address | 192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 → e.g. 192.168.1.213 |
| Subnet mask | 255.255.255.0 |
| Default gateway | 192.168.1.212 or leave cells empty |

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

- ▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

Note the following to avoid a network conflict:

- ▶ Avoid accessing the measuring device simultaneously from the same mobile terminal via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- ▶ Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH__300_A802000).
2. If necessary, select the WPA2 encryption method.
3. Enter the password:
Serial number of the measuring device ex-works (e.g. L100A802000).
 - ↳ The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.



The serial number can be found on the nameplate.



To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.


Terminating the WLAN connection

- ▶ After configuring the device:
Terminate the WLAN connection between the mobile terminal and measuring device.

Starting the web browser

1. Start the web browser on the computer.

2. Enter the IP address of the web server in the address line of the web browser:
192.168.1.212
↳ The login page appears.



A0053670

- 1 Picture of device
- 2 Device name
- 3 Device tag (→ ⓘ 81)
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code (→ ⓘ 112)

i If a login page does not appear, or if the page is incomplete


8.4.4 Logging on

1. Select the preferred operating language for the Web browser.
2. Enter the user-specific access code.
3. Press **OK** to confirm your entry.

| | |
|--------------------|----------------------------------------------------|
| Access code | 0000 (factory setting); can be changed by customer |
|--------------------|----------------------------------------------------|

i If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



A0053669

- 1 Picture of device
- 2 Device name
- 3 Device tag
- 4 Status signal
- 5 Current measured values
- 6 Function row
- 7 Local display language
- 8 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal → 📄 141
- Current measured values

Function row

| Functions | Meaning |
|------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Adjustment of solids content | Call up the wizards: adjust measured value based on reference value |
| Measured values | Displays the measured values of the device |
| Menu | <ul style="list-style-type: none"> ■ Access to the operating menu from the measuring device ■ The structure of the operating menu is the same as for the local display  Detailed information on the operating menu structure: Description of Device Parameters |
| Device status | Displays the diagnostic messages currently pending, listed in order of priority |

| Functions | Meaning |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Data management | Data exchange between computer and measuring device: <ul style="list-style-type: none"> ▪ Device configuration: <ul style="list-style-type: none"> ▪ Load settings from the device (XML format, save configuration) ▪ Save settings to the device (XML format, restore configuration) ▪ Logbook - Export Event logbook (.csv file) ▪ Documents - Export documents: <ul style="list-style-type: none"> ▪ Export backup data record (.csv file, create documentation of the measuring point configuration) ▪ Verification report (PDF file, only available with the "Heartbeat Verification" application package) ▪ Firmware update - Flashing a firmware version |
| Network | Configuration and checking of all the parameters required for establishing the connection to the measuring device: <ul style="list-style-type: none"> ▪ Network settings (e.g. IP address, MAC address) ▪ Device information (e.g. serial number, firmware version) |
| Logout | End the operation and call up the login page |

Navigation area

The menus, the associated submenus and parameters can be selected in the navigation area.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu → Communication → Web server

Parameter overview with brief description

| Parameter | Description | Selection | Factory setting |
|--------------------------|-----------------------------------|-------------------------------------------------------------------------------------------|-----------------|
| Web server functionality | Switch the Web server on and off. | <ul style="list-style-type: none"> ▪ Off ▪ HTML Off ▪ On | On |

Function scope of the "Web server functionality" parameter

| Option | Description |
|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Off | <ul style="list-style-type: none"> ▪ The Web server is completely disabled. ▪ Port 80 is locked. |
| HTML Off | The HTML version of the Web server is not available. |
| On | <ul style="list-style-type: none"> ▪ The complete Web server functionality is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state. |

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

 Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.
 - ↳ The home page with the Login box appears.
2. Close the Web browser.
3. If no longer needed:
 - Reset the modified properties of the Internet protocol (TCP/IP) →  62.


8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool

Via Modbus RS485 protocol

This communication interface is available in device versions with a Modbus RS485 output.



A0029437

21 Options for remote operation via Modbus RS485 protocol (active)

- 1 Control system (e.g. PLC)
- 2 Computer with web browser (e.g. Microsoft Edge) to access the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 3 Transmitter

Service interface


Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

i An adapter for the RJ45 to the M12 plug is optionally available for the non-hazardous area:

Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 plug mounted in the cable entry. The connection to the service interface can be established via an M12 plug without opening the device.



A0027563


22 Connection via service interface (CDI-RJ45)

- 1 Computer with web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated web server or with "FieldCare" operating tool, "DeviceCare" with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version:

Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A0034570

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

| | |
|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Function | WLAN: IEEE 802.11 b/g (2.4 GHz) |
| Encryption | WPA2-PSK AES-128 (in accordance with IEEE 802.11i) |
| Configurable WLAN channels | 1 to 11 |
| Degree of protection | IP67 |
| Available antennas | <ul style="list-style-type: none"> ▪ Internal antenna ▪ External antenna (optional) <p>In the event of poor transmission/reception conditions at the place of installation.</p> <p> Only 1 antenna is active at any one time!</p> |
| Range | <ul style="list-style-type: none"> ▪ Internal antenna: typically 10 m (32 ft) ▪ External antenna: typically 50 m (164 ft) |
| Materials (external antenna) | <ul style="list-style-type: none"> ▪ Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass ▪ Adapter: Stainless steel and nickel-plated brass ▪ Cable: Polyethylene ▪ Plug: Nickel-plated brass ▪ Angle bracket: Stainless steel |

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

- ▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

Note the following to avoid a network conflict:

- ▶ Avoid accessing the measuring device simultaneously from the same mobile terminal via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- ▶ Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH__300_A802000).
2. If necessary, select the WPA2 encryption method.
3. Enter the password:
Serial number of the measuring device ex-works (e.g. L100A802000).
↳ The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.

 The serial number can be found on the nameplate.

 To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Terminating the WLAN connection

- ▶ After configuring the device:
Terminate the WLAN connection between the mobile terminal and measuring device.

8.5.2 FieldCare**Function range**

FDT-based (Field Device Technology) plant asset management tool from Endress+Hauser. It can configure all smart field units in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- CDI-RJ45 service interface →  68
- WLAN interface →  68

Typical functions:

- Transmitter parameter configuration
- Loading and saving of device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook


-  ▪ Operating Instructions BA00027S
-  ▪ Operating Instructions BA00059S

 Source for device description files →  73

Establishing a connection

-  ▪ Operating Instructions BA00027S
-  ▪ Operating Instructions BA00059S

User interface



A0053667

8.5.3 DeviceCare

Function range

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



Innovation brochure IN01047S



Source for device description files → 73

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

| | | |
|----------------------------------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Firmware version | 01.00.zz | <ul style="list-style-type: none">■ On the title page of the manual■ On the transmitter nameplate■ Firmware version Diagnostics → Device information → Firmware version |
| Release date of firmware version | 03.2024 | --- |



For an overview of the various firmware versions for the device

9.1.2 Operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

| Supported operating tools | Operating unit | Interface | Additional information |
|---------------------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Web browser | Notebook, PC or tablet with web browser | <ul style="list-style-type: none"> ▪ CDI-RJ45 service interface ▪ WLAN interface | Special Documentation for the device →  188 |
| DeviceCare SFE100 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> ▪ CDI-RJ45 service interface ▪ WLAN interface ▪ Fieldbus protocol | Service-specific accessories →  162 Sources for obtaining device descriptions www.endress.com → Download-Area |
| FieldCare SFE500 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> ▪ CDI-RJ45 service interface ▪ WLAN interface ▪ Fieldbus protocol | Service-specific accessories →  162 Sources for obtaining device descriptions www.endress.com → Download-Area |

 Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The related device description files are available: www.endress.com → Download Area

9.2 Modbus RS485 information

9.2.1 Function codes

Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:

| Code | Name | Description | Application |
|------|------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
| 03 | Read holding register | <p>Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes</p> <p> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.</p> | <p>Read device parameters with read and write access</p> <p>Example:</p> |
| 04 | Read input register | <p>Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes</p> <p> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.</p> | <p>Read device parameters with read access</p> <p>Example: Read totalizer value</p> |
| 06 | Write single registers | <p>Master writes a new value to one Modbus register of the measuring device.</p> <p> Use function code 16 to write multiple registers with just 1 telegram.</p> | <p>Write only 1 device parameter</p> <p>Example: reset totalizer</p> |
| 08 | Diagnostics | <p>Master checks the communication connection to the measuring device.</p> <p>The following "Diagnostics codes" are supported:</p> <ul style="list-style-type: none"> ▪ Sub-function 00 = Return query data (loopback test) ▪ Sub-function 02 = Return diagnostics register | |

| Code | Name | Description | Application |
|------|-------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 16 | Write multiple registers | <p>Master writes a new value to multiple Modbus registers of the device. A maximum of 120 consecutive registers can be written with 1 telegram.</p> <p> If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map →  76</p> | Write multiple device parameters |
| 23 | Read/Write multiple registers | <p>Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram. Write access is executed before read access.</p> | <p>Write and read multiple device parameters</p> <p>Example:</p> <ul style="list-style-type: none"> ▪ Read mass flow ▪ Reset totalizer |

 Broadcast messages are only allowed with function codes 06, 16 and 23.

9.2.2 Register information

 For an overview of device parameters and their corresponding Modbus register information, refer to the "Modbus RS485 register information" section in the "Description of device parameters" documentation →  188.

9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to 5 ms

9.2.4 Data types

The measuring device supports the following data types:

| | | | |
|--------------------------------------------------------------------------------------|----------|----------|----------|
| FLOAT (floating point number IEEE 754) Data length = 4 bytes (2 registers) | | | |
| Byte 3 | Byte 2 | Byte 1 | Byte 0 |
| SEEEEEEE | EMMMMMMM | MMMMMMMM | MMMMMMMM |
| S = sign, E = exponent, M = mantissa | | | |

| | |
|------------------------------------------------------|------------------------------|
| INTEGER Data length = 2 bytes (1 register) | |
| Byte 1 | Byte 0 |
| Most significant byte (MSB) | Least significant byte (LSB) |

| | | | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------|---------|-----|--------|------------------------------|
| STRING Data length = depends on the device parameter, e.g. presentation of a device parameter with a data length = 18 bytes (9 registers) | | | | |
| Byte 17 | Byte 16 | ... | Byte 1 | Byte 0 |
| Most significant byte (MSB) | | ... | | Least significant byte (LSB) |

9.2.5 Byte transmission sequence

Byte addressing, i.e. the transmission sequence of the bytes, is not specified in the Modbus specification. For this reason, it is important to coordinate or match the addressing method between the master and slave during commissioning. This can be configured in the measuring device using the **Byte order** parameter.

The bytes are transmitted depending on the selection in the **Byte order** parameter:

| FLOAT | | | | |
|-----------------|----------------------|----------------------|----------------------|----------------------|
| | Sequence | | | |
| Options | 1. | 2. | 3. | 4. |
| 1 - 0 - 3 - 2 * | Byte 1 (MMMMMMMM) | Byte 0 (MMMMMMMM) | Byte 3 (SEEEEEEE) | Byte 2 (EMMMMMMM) |
| 0 - 1 - 2 - 3 | Byte 0 (MMMMMMMM) | Byte 1 (MMMMMMMM) | Byte 2 (EMMMMMMM) | Byte 3 (SEEEEEEE) |
| 2 - 3 - 0 - 1 | Byte 2 (EMMMMMMM) | Byte 3 (SEEEEEEE) | Byte 0 (MMMMMMMM) | Byte 1 (MMMMMMMM) |
| 3 - 2 - 1 - 0 | Byte 3 (SEEEEEEE) | Byte 2 (EMMMMMMM) | Byte 1 (MMMMMMMM) | Byte 0 (MMMMMMMM) |

* = factory setting, S = sign, E = exponent, M = mantissa

| INTEGER | | |
|----------------------------------|-----------------|-----------------|
| | Sequence | |
| Options | 1. | 2. |
| 1 - 0 - 3 - 2 * 3 - 2 - 1 - 0 | Byte 1 (MSB) | Byte 0 (LSB) |
| 0 - 1 - 2 - 3 2 - 3 - 0 - 1 | Byte 0 (LSB) | Byte 1 (MSB) |

* = factory setting, MSB = most significant byte, LSB = least significant byte

| STRING | | | | | |
|---------------------------------------------------------------------------------------|------------------|------------------|-----|-----------------|-----------------|
| Presentation taking the example of a device parameter with a data length of 18 bytes. | | | | | |
| | Sequence | | | | |
| Options | 1. | 2. | ... | 17. | 18. |
| 1 - 0 - 3 - 2 * 3 - 2 - 1 - 0 | Byte 17 (MSB) | Byte 16 | ... | Byte 1 | Byte 0 (LSB) |
| 0 - 1 - 2 - 3 2 - 3 - 0 - 1 | Byte 16 | Byte 17 (MSB) | ... | Byte 0 (LSB) | Byte 1 |

* = factory setting, MSB = most significant byte, LSB = least significant byte

9.2.6 Modbus data map

Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.

Structure of the Modbus data map

The Modbus data map consists of two data sets:

- Scan list: Configuration area
The device parameters to be grouped are defined in a list by entering their Modbus RS485 register addresses in the list.
- Data area
The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.

 For an overview of device parameters and their corresponding Modbus register information, refer to the "Modbus RS485 register information" section in the "Description of device parameters" documentation →  188.

Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

| | |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Max. entries | 16 device parameters |
| Supported device parameters | Only parameters with the following characteristics are supported: <ul style="list-style-type: none"> ■ Access type: read or write access ■ Data type: float or integer |

Configuration of the scan list via FieldCare or DeviceCare

Carried out using the operating menu of the measuring device:
Expert → Communication → Modbus data map → Scan list register 0 to 15

| Scan list | |
|-----------|------------------------|
| No. | Configuration register |
| 0 | Scan list register 0 |
| ... | ... |
| 15 | Scan list register 15 |

Configuration of the scan list via Modbus RS485

Carried out using register addresses 5001 - 5016

| Scan list | | | |
|-----------|-----------------------|-----------|------------------------|
| No. | Modbus RS485 register | Data type | Configuration register |
| 0 | 5001 | Integer | Scan list register 0 |
| ... | ... | Integer | ... |
| 15 | 5016 | Integer | Scan list register 15 |

Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.

| | |
|-----------------------------------|----------------------------------|
| Master access to data area | Via register addresses 5051-5081 |
|-----------------------------------|----------------------------------|

| Data area | | | | |
|---------------------------------|-----------------------|------------------------------|---------------|------------|
| Device parameter value | Modbus RS485 register | | Data type* | Access** |
| | Start register | End register (Float only) | | |
| Value of scan list register 0 | 5051 | 5052 | Integer/float | Read/write |
| Value of scan list register 1 | 5053 | 5054 | Integer/float | Read/write |
| Value of scan list register ... | ... | ... | ... | ... |
| Value of scan list register 15 | 5081 | 5082 | Integer/float | Read/write |

* Data type depends on the device parameters entered in the scan list.
** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area.

10 Commissioning

10.1 Post-mounting and post-connection check

Before commissioning the device:

- ▶ Make sure that the post-installation and post-connection checks have been performed successfully.
- Checklist for "Post-mounting" check → 32
- Checklist for "Post-connection check" → 46

10.2 Switching on the measuring device

- ▶ Switch on the device upon successful completion of the post-mounting and post-connection check.
 - ↳ After a successful startup, the local display switches automatically from the startup display to the operational display.


If nothing appears on the local display or if a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting".

10.3 Connecting via FieldCare

- For connecting FieldCare → 68
- For connecting via FieldCare → 70
- For user interface of FieldCare → 71

10.4 Setting the operating language

Factory setting: English or ordered local language




23 Using the example of the local display

A0053789

10.5 Configuring the measuring device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.



24 Navigation to "Setup" menu using the example of the local display


i The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

| 🔧 Setup | |
|----------------------------------------|------|
| Device tag | |
| ▶ System units | → 82 |
| ▶ Communication | → 83 |
| ▶ I/O configuration | → 84 |
| ▶ Status input 1 to n | → 86 |
| ▶ Current input 1 to n | → 85 |
| ▶ Current output 1 to n | → 87 |
| ▶ Pulse/frequency/switch output 1 to n | → 89 |
| ▶ Relay output 1 to n | → 95 |
| ▶ Display | → 96 |

| | |
|------------------------------|-------|
| ▶ Total solids commissioning | → 99 |
| ▶ Total solids adjustment | → 99 |
| ▶ Advanced setup | → 100 |

10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



A0029422

25 Header of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool → 71

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

| Parameter | Description | User entry | Factory setting |
|------------|-----------------------------------------|------------------------------------------------------------------------------------|-----------------|
| Device tag | Enter the name for the measuring point. | Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /). | Prowirl |


10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

i The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operating Instructions. Instead a description is provided in the Special Documentation for the device ("Supplementary documentation").

Navigation

"Expert" menu → Sensor → System units



Parameter overview with brief description


| Parameter | Prerequisite | Description | Selection | Factory setting |
|-------------------|----------------------------------------------------------------------------------------|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| Total solids unit | – | Select total solids unit. | Unit choose list | Depends on country |
| Density unit | – | Select density unit. | Unit choose list | Depends on country |
| Mass flow unit | The volume flow of the medium is read in via the Current input 1 to n. | Select mass flow unit. | Unit choose list | Depends on country |
| Mass unit | The volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select mass unit. | Unit choose list | Depends on country |
| Volume flow unit | The volume flow of the medium is read in via the Current input 1 to n. | Select volume flow unit. | Unit choose list | l/h |
| Temperature unit | – | Select temperature unit. | Unit choose list | Depends on country |
| Conductivity unit | – | Select conductivity unit. | Unit choose list | µS/cm |
| Date/time format | – | Select date and time format. | <ul style="list-style-type: none"> ▪ dd.mm.yy hh:mm ▪ dd.mm.yy hh:mm am/pm ▪ mm/dd/yy hh:mm ▪ mm/dd/yy hh:mm am/pm | dd.mm.yy hh:mm |

10.5.3 Configuring the communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication



Parameter overview with brief description

| Parameter | Description | User entry / Selection | Factory setting |
|--------------------|-----------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Bus address | Enter device address. | 1 to 247 | 247 |
| Baudrate | Define data transfer speed. | <ul style="list-style-type: none"> ■ 1200 BAUD ■ 2400 BAUD ■ 4800 BAUD ■ 9600 BAUD ■ 19200 BAUD ■ 38400 BAUD ■ 57600 BAUD ■ 115200 BAUD ■ 230400 BAUD | 19200 BAUD |
| Data transfer mode | Select data transfer mode. | <ul style="list-style-type: none"> ■ ASCII ■ RTU | RTU |
| Parity | Select parity bits. | Picklist ASCII option: <ul style="list-style-type: none"> ■ 0 = Even option ■ 1 = Odd option Picklist RTU option: <ul style="list-style-type: none"> ■ 0 = Even option ■ 1 = Odd option ■ 2 = None / 1 stop bit option ■ 3 = None / 2 stop bits option | Even |
| Byte order | Select byte transmission sequence. | <ul style="list-style-type: none"> ■ 0-1-2-3 ■ 3-2-1-0 ■ 1-0-3-2 ■ 2-3-0-1 | 1-0-3-2 |
| Failure mode | Select measured value output behavior when a diagnostic message occurs via Modbus communication. NaN ¹⁾ | <ul style="list-style-type: none"> ■ NaN value ■ Last valid value | NaN value |


1) Not a Number

10.5.4 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu → I/O configuration



Parameter overview with brief description

| Parameter | Description | User interface / Selection / User entry | Factory setting |
|------------------------------------|---------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| I/O module 1 to n terminal numbers | Shows the terminal numbers used by the I/O module. | <ul style="list-style-type: none"> ▪ Not used ▪ 26-27 (I/O 1) ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| I/O module 1 to n information | Shows information of the plugged I/O module. | <ul style="list-style-type: none"> ▪ Not plugged ▪ Invalid ▪ Not configurable ▪ Configurable ▪ MODBUS | – |
| I/O module 1 to n type | Shows the I/O module type. | <ul style="list-style-type: none"> ▪ Off ▪ Current output * ▪ Current input * ▪ Status input * ▪ Pulse/frequency/switch output * ▪ Relay output * | Off |
| Apply I/O configuration | Apply parameterization of the freely configurable I/O module. | <ul style="list-style-type: none"> ▪ No ▪ Yes | No |
| I/O alteration code | Enter the code in order to change the I/O configuration. | Positive integer | 0 |

* Visibility depends on order options or device settings

10.5.5 Configuring the current input

The "Current input" wizard guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation

"Setup" menu → Current input

▶ Current input 1 to n

| | |
|-----------------|--------|
| Terminal number | → ⓘ 85 |
| Signal mode | → ⓘ 85 |
| 0/4 mA value | → ⓘ 85 |
| 20 mA value | → ⓘ 85 |
| Current span | → ⓘ 85 |
| Failure mode | → ⓘ 85 |
| Failure value | → ⓘ 85 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| Terminal number | – | Shows the terminal numbers used by the current input module. | <ul style="list-style-type: none"> ▪ Not used ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| Signal mode | – | Select the signal mode for the current input. | <ul style="list-style-type: none"> ▪ Passive ▪ Active* | Passive |
| 0/4 mA value | – | Enter 4 mA value. | Signed floating-point number | 0 % TS |
| 20 mA value | – | Enter 20 mA value. | Signed floating-point number | 12 %TS |
| Current span | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ▪ 4...20 mA (4...20.5 mA) ▪ 4...20 mA NE (3.8...20.5 mA) ▪ 4...20 mA US (3.9...20.8 mA) ▪ 0...20 mA (0...20.5 mA) | Country-specific: <ul style="list-style-type: none"> ▪ 4...20 mA NE (3.8...20.5 mA) ▪ 4...20 mA US (3.9...20.8 mA) |
| Failure mode | – | Define input behavior in alarm condition. | <ul style="list-style-type: none"> ▪ Alarm ▪ Last valid value ▪ Defined value | Alarm |
| Failure value | In the Failure mode parameter, the Defined value option is selected. | Enter value to be used by the device if input value from external device is missing. | Signed floating-point number | 0 |

* Visibility depends on order options or device settings

10.5.6 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu → Status input 1 to n

▶ Status input 1 to n

| | |
|----------------------------|-------|
| Assign status input | → 86 |
| Terminal number | → 86 |
| Active level | → 86 |
| Terminal number | → 86 |
| Response time status input | → 86 |
| Terminal number | → 86 |

Parameter overview with brief description

| Parameter | Description | Selection / User interface / User entry | Factory setting |
|----------------------------|---------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------|
| Assign status input | Select function for the status input. | <ul style="list-style-type: none"> ▪ Off ▪ Reset totalizer 1 ▪ Flow override | Off |
| Terminal number | Shows the terminal numbers used by the status input module. | <ul style="list-style-type: none"> ▪ Not used ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| Active level | Define input signal level at which the assigned function is triggered. | <ul style="list-style-type: none"> ▪ High ▪ Low | High |
| Response time status input | Define the minimum amount of time the input signal level must be present before the selected function is triggered. | 5 to 200 ms | 50 ms |

10.5.7 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation

"Setup" menu → Current output

▶ Current output 1 to n

| | |
|---------------------------------|-------|
| Terminal number | → 87 |
| Signal mode | → 87 |
| Process variable current output | → 87 |
| Current range output | → 88 |
| Lower range value output | → 88 |
| Upper range value output | → 88 |
| Fixed current | → 88 |
| Damping current output | → 88 |
| Failure behavior current output | → 88 |
| Failure current | → 88 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Terminal number | – | Shows the terminal numbers used by the current output module. | <ul style="list-style-type: none"> ▪ Not used ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| Signal mode | – | Select the signal mode for the current output. | <ul style="list-style-type: none"> ▪ Active * ▪ Passive * | Active |
| Process variable current output | The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the process variable for the current output. | <ul style="list-style-type: none"> ▪ Off ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * | Total solids |

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Current range output | – | Select current range for process value output and upper/lower level for alarm signal. | <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 4...20 mA (4...20.5 mA) ■ 0...20 mA (0...20.5 mA) ■ Fixed value | Depends on country: <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) |
| Lower range value output | In Current span parameter (→  88), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 4...20 mA (4...20.5 mA) ■ 0...20 mA (0...20.5 mA) | Enter lower range value for the measured value range. | Floating point number with sign | 0 %TS |
| Upper range value output | In Current span parameter (→  88), one of the following options is selected: <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 4...20 mA (4...20.5 mA) ■ 0...20 mA (0...20.5 mA) | Enter upper range value for the measured value range. | Floating point number with sign | 12 %TS |
| Fixed current | The Fixed current option is selected in the Current span parameter (→  88). | Defines the fixed output current. | 0 to 22.5 mA | 22.5 mA |
| Damping current output | A process variable is selected in the Assign current output parameter (→  87) and one of the following options is selected in the Current span parameter (→  88): <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 4...20 mA (4...20.5 mA) ■ 0...20 mA (0...20.5 mA) | Enter a time constant for output damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal. | 0.0 to 999.9 s | 1.0 s |
| Failure behavior current output | A process variable is selected in the Assign current output parameter (→  87) and one of the following options is selected in the Current span parameter (→  88): <ul style="list-style-type: none"> ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) ■ 4...20 mA (4...20.5 mA) ■ 0...20 mA (0...20.5 mA) | Select output behavior in the event of a device alarm. | <ul style="list-style-type: none"> ■ Min. ■ Max. ■ Last valid value ■ Actual value ■ Fixed value | Max. |
| Failure current | The Defined value option is selected in the Failure mode parameter. | Enter current output value in alarm condition. | 0 to 22.5 mA | 22.5 mA |

* Visibility depends on order options or device settings

10.5.8 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu → Advanced setup → Pulse/frequency/switch output

► Pulse/frequency/switch output
 1 to n

Operating mode

→ ⓘ 89

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection | Factory setting |
|----------------|-----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|--------------------------------------------------------------------------------------------------|-----------------|
| Operating mode | If the Pulse option is selected, the Load rate option must be selected in the Assign pulse output parameter. | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | Pulse |

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/frequency/switch output
 1 to n

Operating mode

→ ⓘ 90

Terminal number

→ ⓘ 90

Signal mode

→ ⓘ 90

Assign pulse output

→ ⓘ 90

Pulse scaling

→ ⓘ 90

Pulse width

→ ⓘ 90

Failure mode

→ ⓘ 90

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Operating mode | If the Pulse option is selected, the Load rate option must be selected in the Assign pulse output parameter. | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ▪ Pulse ▪ Frequency ▪ Switch | Pulse |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ▪ Not used ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ▪ Passive ▪ Active * ▪ Passive NE | Passive |
| Assign pulse output | The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. The Pulse option is selected in Operating mode parameter. | Select process variable for pulse output. | <ul style="list-style-type: none"> ▪ Off ▪ Load rate * | Off |
| Pulse scaling | The Pulse option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign pulse output parameter (→ 90). | Enter quantity for measured value at which a pulse is output. | Positive floating point number | Depends on country and nominal diameter |
| Pulse width | The Pulse option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign pulse output parameter (→ 90). | Define time width of the output pulse. | 0.05 to 2 000 ms | 100 ms |
| Failure mode | The Pulse option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign pulse output parameter (→ 90). | Select output behavior in the event of a device alarm. | <ul style="list-style-type: none"> ▪ Actual value ▪ No pulses | No pulses |

* Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu → Pulse/frequency/switch output

| | |
|-------------------------------------------|------|
| ▶ Pulse/frequency/switch output 1 to n | |
| Operating mode | → 91 |
| Terminal number | → 91 |
| Signal mode | → 91 |
| Assign frequency output | → 91 |

| | |
|--------------------------------------|------|
| Minimum frequency value | → 91 |
| Maximum frequency value | → 91 |
| Measuring value at minimum frequency | → 92 |
| Measuring value at maximum frequency | → 92 |
| Failure mode | → 92 |
| Failure frequency | → 92 |
| Invert output signal | → 92 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Operating mode | If the Pulse option is selected, the Load rate option must be selected in the Assign pulse output parameter. | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ▪ Pulse ▪ Frequency ▪ Switch | Pulse |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ▪ Not used ▪ 24-25 (I/O 2) ▪ 22-23 (I/O 3) | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ▪ Passive ▪ Active* ▪ Passive NE | Passive |
| Assign frequency output | <ul style="list-style-type: none"> ▪ The Frequency option is selected in Operating mode parameter (→ 89). ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select process variable for frequency output. | <ul style="list-style-type: none"> ▪ Off ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity* ▪ Load rate* | Off |
| Minimum frequency value | The Frequency option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign frequency output parameter (→ 91). | Enter minimum frequency. | 0.0 to 10000.0 Hz | 0.0 Hz |
| Maximum frequency value | The Frequency option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign frequency output parameter (→ 91). | Enter maximum frequency. | 0.0 to 10000.0 Hz | 10000.0 Hz |

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------|-----------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Measuring value at minimum frequency | The Frequency option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign frequency output parameter (→ 91). | Enter measured value for minimum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Measuring value at maximum frequency | The Frequency option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign frequency output parameter (→ 91). | Enter measured value for maximum frequency. | Signed floating-point number | Depends on country and nominal diameter |
| Failure mode | The Frequency option is selected in the Operating mode parameter (→ 89) and a process variable is selected in the Assign frequency output parameter (→ 91). | Select output behavior in the event of a device alarm. | <ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz | 0 Hz |
| Failure frequency | In the Operating mode parameter (→ 89), the Frequency option is selected, in the Assign frequency output parameter (→ 91) a process variable is selected, and in the Failure mode parameter, the Defined value option is selected. | Enter frequency output value in alarm condition. | 0.0 to 12 500.0 Hz | 0.0 Hz |
| Invert output signal | – | Invert the output signal. | <ul style="list-style-type: none"> ▪ No ▪ Yes | No |

* Visibility depends on order options or device settings

Configuring the switch output

Navigation

"Setup" menu → Pulse/frequency/switch output

| ► Pulse/frequency/switch output 1 to n | |
|-------------------------------------------|------|
| Operating mode | → 93 |
| Terminal number | → 93 |
| Signal mode | → 93 |
| Switch output function | → 94 |
| Assign diagnostic behavior | → 94 |
| Assign limit | → 94 |
| Assign status | → 94 |
| Switch-on value | → 94 |
| Switch-off value | → 94 |
| Switch-on delay | → 94 |
| Switch-off delay | → 94 |
| Failure mode | → 94 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|-----------------|-----------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|-----------------|
| Operating mode | If the Pulse option is selected, the Load rate option must be selected in the Assign pulse output parameter. | Define the output as a pulse, frequency or switch output. | <ul style="list-style-type: none"> ■ Pulse ■ Frequency ■ Switch | Pulse |
| Terminal number | – | Shows the terminal numbers used by the PFS output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 22-23 (I/O 3) | – |
| Signal mode | – | Select the signal mode for the PFS output. | <ul style="list-style-type: none"> ■ Passive* ■ Active* ■ Passive NE | Passive |

| Parameter | Prerequisite | Description | Selection / User interface / User entry | Factory setting |
|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------|
| Switch output function | The Switch option is selected in the Operating mode parameter. | Select function for switch output. | <ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diagnostic behavior ▪ Limit ▪ Flow direction check ▪ Status | Off |
| Assign diagnostic behavior | <ul style="list-style-type: none"> ▪ In the Operating mode parameter, the Switch option is selected. ▪ In the Switch output function parameter, the Diagnostic behavior option is selected. | The output is switched on (closed, conductive), if there is a pending diagnostic event of the assigned behavioral category. | <ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning | Alarm |
| Assign limit | <ul style="list-style-type: none"> ▪ The Switch option is selected in Operating mode parameter. ▪ The Limit option is selected in Switch output function parameter. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the variable to monitor in case the specified limit value is exceeded. If a limit value is exceeded, the output is switched on (conductive). | <ul style="list-style-type: none"> ▪ Off ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Totalizer 1 * | Temperature |
| Assign status | <ul style="list-style-type: none"> ▪ The Switch option is selected in Operating mode parameter. ▪ The Status option is selected in Switch output function parameter. | Select the device function for which to display the status. If the switch on point is reached, the output is switched on (closed, conductive). | <ul style="list-style-type: none"> ▪ Off ▪ Partially filled pipe detection | Partially filled pipe detection |
| Switch-on value | <ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter. ▪ The Limit option is selected in the Switch output function parameter. | Enter limit value for switch-on point (process variable > switch-on value = closed, conductive). | Floating point number with sign | 0 °C |
| Switch-off value | <ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter. ▪ The Limit option is selected in the Switch output function parameter. | Enter limit value for switch-off point (process variable < switch-off value = open, nonconductive). | Floating point number with sign | 0 °C |
| Switch-on delay | <ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter. ▪ The Limit option is selected in the Switch output function parameter. | Enter a delay before the output is switched on. | 0.0 to 100.0 s | 0.0 s |
| Switch-off delay | <ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter. ▪ The Limit option is selected in the Switch output function parameter. | Enter a delay before the output is switched off. | 0.0 to 100.0 s | 0.0 s |
| Failure mode | – | Select output behavior in the event of a device alarm. | <ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed | Open |

* Visibility depends on order options or device settings

10.5.9 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu → Relay output 1 to n

▶ **Relay output 1 to n**

| | |
|-----------------------------|--------|
| Terminal number | → ⓘ 95 |
| Relay output function | → ⓘ 95 |
| Assign flow direction check | → ⓘ 96 |
| Assign limit | → ⓘ 96 |
| Assign diagnostic behavior | → ⓘ 96 |
| Assign status | → ⓘ 96 |
| Switch-off value | → ⓘ 96 |
| Switch-off delay | → ⓘ 96 |
| Switch-on value | → ⓘ 96 |
| Switch-on delay | → ⓘ 96 |
| Failure mode | → ⓘ 96 |
| Switch state | → ⓘ 96 |
| Powerless relay status | → ⓘ 96 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------------|--------------|-------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Terminal number | – | Shows the terminal numbers used by the relay output module. | <ul style="list-style-type: none"> ■ Not used ■ 24-25 (I/O 2) ■ 22-23 (I/O 3) | – |
| Relay output function | – | Select the function for the relay output. | <ul style="list-style-type: none"> ■ Closed ■ Open ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status | Closed |

| Parameter | Prerequisite | Description | User interface / Selection / User entry | Factory setting |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Assign flow direction check | The Flow direction check option is selected in the Relay output function parameter. | Select process variable for flow direction monitoring. | | Off |
| Assign limit | <ul style="list-style-type: none"> ▪ The Limit option is selected in Relay output function parameter. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the variable to monitor in case the specified limit value is exceeded. If a limit value is exceeded, the output is switched on (conductive). | <ul style="list-style-type: none"> ▪ Off ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate[*] ▪ Totalizer 1[*] | Temperature |
| Assign diagnostic behavior | In the Relay output function parameter, the Diagnostic behavior option is selected. | The output is switched on (closed, conductive), if there is a pending diagnostic event of the assigned behavioral category. | <ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning | Alarm |
| Assign status | In the Relay output function parameter, the Digital Output option is selected. | Select the device function for which to display the status. If the switch on point is reached, the output is switched on (closed, conductive). | <ul style="list-style-type: none"> ▪ Off ▪ Partially filled pipe detection | Off |
| Switch-off value | The Limit option is selected in the Relay output function parameter. | Enter limit value for switch-off point (process variable < switch-off value = open, nonconductive). | Floating point number with sign | 0 °C |
| Switch-off delay | In the Relay output function parameter, the Limit option is selected. | Enter a delay before the output is switched off. | 0.0 to 100.0 s | 0.0 s |
| Switch-on value | The Limit option is selected in the Relay output function parameter. | Enter measured value for the switch-on point. | Floating point number with sign | 0 °C |
| Switch-on delay | In the Relay output function parameter, the Limit option is selected. | Enter a delay before the output is switched on. | 0.0 to 100.0 s | 0.0 s |
| Failure mode | – | Select output behavior in the event of a device alarm. | <ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed | Open |
| Switch state | – | Indicates the current switch state of the output. | <ul style="list-style-type: none"> ▪ Open ▪ Closed | – |
| Powerless relay status | – | Select quiescent state for relay. | <ul style="list-style-type: none"> ▪ Open ▪ Closed | Open |

* Visibility depends on order options or device settings

10.5.10 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

Navigation

"Setup" menu → Display



| | |
|-----------------------|------------------------------------------------------------------------------------------|
| Format display | →  97 |
| Value 1 display | →  97 |
| 0% bargraph value 1 | →  97 |
| 100% bargraph value 1 | →  97 |
| Value 2 display | →  98 |
| Value 3 display | →  98 |
| 0% bargraph value 3 | →  98 |
| 100% bargraph value 3 | →  98 |
| Value 4 display | →  98 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ▪ 1 value, max. size ▪ 1 bargraph + 1 value ▪ 2 values ▪ 1 value large + 2 values ▪ 4 values | 1 value, max. size |
| Value 1 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Totalizer 1 * ▪ Current output 1 * ▪ Current output 2 * ▪ Current output 3 * ▪ Current output 4 * | Total solids |
| 0% bargraph value 1 | A local display is provided. | Enter 0 % value for bar graph display. | Signed floating-point number | 0 %TS |
| 100% bargraph value 1 | A local display is provided. | Enter 100 % value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Value 2 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ▪ None ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Totalizer 1 * ▪ Current output 1 * ▪ Current output 2 * ▪ Current output 3 * ▪ Current output 4 * | None |
| Value 3 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 97) | None |
| 0% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 0 % value for bar graph display. | Signed floating-point number | 0 |
| 100% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 100 % value for bar graph display. | Signed floating-point number | 0 |
| Value 4 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 97) | None |

* Visibility depends on order options or device settings

10.5.11 "Total solids commissioning" wizard

The **Total solids commissioning** wizard is used to perform the basic settings for adjusting the measured value based on a reference value.

 Wizard description →  130.

Navigation

"Setup" menu → Total solids commissioning



► Total solids commissioning


10.5.12 "Total solids adjustment" submenu

Using the **Total solids adjustment** submenu, you can call up the wizards for adjusting the measured value based on a reference value.

 Description and access to the wizards →  130

Navigation

"Setup" menu → Total solids adjustment



► Total solids adjustment

► 1 - Take a sample


► 2 - Enter lab value

► 3 - Perform adjustment

10.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




i The number of submenus and parameters can vary depending on the device version and the available application packages. These submenus and their parameters are explained in the Special Documentation for the device and not in Operating Instructions.

For detailed information on the parameter descriptions of the application packages, see the Special Documentation for the device. → 188

Navigation

"Setup" menu → Advanced setup



| | |
|------------------------|---------|
| ▶ WLAN settings | → 📄 107 |
| ▶ Heartbeat setup | → 📄 108 |
| ▶ Configuration backup | → 📄 109 |
| ▶ Administration | → 📄 111 |

10.6.1 Using the parameter to enter the access code

Navigation

"Setup" menu → Advanced setup

Parameter overview with brief description

| Parameter | Description | User entry |
|-------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Enter access code | Enter access code to disable write protection of parameters. | Max. 16-digit character string comprising numbers, letters and special characters |

10.6.2 Configuring the totalizer

i The totalizer is used to calculate the total load rate. The **Load rate** option is only available if the volume flow of the medium is read in via the Current input 1 to n.

In the "**Totalizer 1 to n**" submenu, you can configure the totalizer.

Navigation

"Setup" menu → Advanced setup → Totalizer 1 to n

| | |
|------------------------------|-------|
| ▶ Totalizer 1 | |
| Assign process variable 1 | → 102 |
| Process variable unit 1 | → 102 |
| Totalizer 1 operation mode | → 102 |
| Totalizer 1 failure behavior | → 102 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection | Factory setting |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|--------------------|
| Assign process variable 1 | The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select process variable for totalizer. | <ul style="list-style-type: none"> ▪ Off ▪ Load rate * | Off |
| Process variable unit 1 | A process variable is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu. | Select the unit for the process variable of the totalizer. | Unit choose list | Depends on country |
| Totalizer 1 operation mode | A process variable is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu. | Select totalizer operation mode, e.g. only totalize forward flow or only totalize reverse flow. | <ul style="list-style-type: none"> ▪ Net ▪ Forward ▪ Reverse | Net |
| Totalizer 1 failure behavior | A process variable is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu. | Select totalizer behavior in the event of a device alarm. | <ul style="list-style-type: none"> ▪ Hold ▪ Continue ▪ Last valid value + continue | Hold |

* Visibility depends on order options or device settings

10.6.3 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu → Advanced setup → Display

| ► Display | |
|-----------------------|-------|
| Format display | → 104 |
| Value 1 display | → 104 |
| 0% bargraph value 1 | → 104 |
| 100% bargraph value 1 | → 104 |
| Decimal places 1 | → 104 |
| Value 2 display | → 104 |
| Decimal places 2 | → 104 |
| Value 3 display | → 104 |
| 0% bargraph value 3 | → 104 |
| 100% bargraph value 3 | → 104 |
| Decimal places 3 | → 105 |
| Value 4 display | → 105 |
| Decimal places 4 | → 105 |
| Display language | → 105 |
| Display interval | → 105 |
| Display damping | → 105 |
| Header | → 105 |
| Header text | → 105 |
| Separator | → 106 |
| Backlight | → 106 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|
| Format display | A local display is provided. | Select how measured values are shown on the display. | <ul style="list-style-type: none"> ▪ 1 value, max. size ▪ 1 bargraph + 1 value ▪ 2 values ▪ 1 value large + 2 values ▪ 4 values | 1 value, max. size |
| Value 1 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Totalizer 1 * ▪ Current output 1 * ▪ Current output 2 * ▪ Current output 3 * ▪ Current output 4 * | Total solids |
| 0% bargraph value 1 | A local display is provided. | Enter 0 % value for bar graph display. | Signed floating-point number | 0 %TS |
| 100% bargraph value 1 | A local display is provided. | Enter 100 % value for bar graph display. | Signed floating-point number | Depends on country and nominal diameter |
| Decimal places 1 | A measured value is specified in the Value 1 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Value 2 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | <ul style="list-style-type: none"> ▪ None ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Totalizer 1 * ▪ Current output 1 * ▪ Current output 2 * ▪ Current output 3 * ▪ Current output 4 * | None |
| Decimal places 2 | A measured value is specified in the Value 2 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Value 3 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 97) | None |
| 0% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 0 % value for bar graph display. | Signed floating-point number | 0 |
| 100% bargraph value 3 | A selection was made in the Value 3 display parameter. | Enter 100 % value for bar graph display. | Signed floating-point number | 0 |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| Decimal places 3 | A measured value is specified in the Value 3 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Value 4 display | <ul style="list-style-type: none"> ▪ A local display is provided. ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select the measured value that is shown on the local display. | For the picklist, see Value 1 display parameter (→ 97) | None |
| Decimal places 4 | A measured value is specified in the Value 4 display parameter. | Select the number of decimal places for the display value. | <ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx | x.xx |
| Display language | A local display is provided. | Set display language. | <ul style="list-style-type: none"> ▪ English ▪ Deutsch ▪ Français ▪ Español ▪ Italiano ▪ Nederlands ▪ Portuguesa ▪ Polski ▪ русский язык (Russian) ▪ Svenska ▪ Türkçe ▪ 中文 (Chinese) ▪ 日本語 (Japanese) ▪ 한국어 (Korean) ▪ čeština (Czech) | English (alternatively, the ordered language is preset in the device) |
| Display interval | A local display is provided. | Set time measured values are shown on display if display alternates between values. | 1 to 10 s | 5 s |
| Display damping | A local display is provided. | Set display reaction time to fluctuations in the measured value. | 0.0 to 999.9 s | 0.0 s |
| Header | A local display is provided. | Select header contents on local display. | <ul style="list-style-type: none"> ▪ Device tag ▪ Free text | Device tag |
| Header text | The Free text option is selected in the Header parameter. | Enter display header text. | Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /) | ----- |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------|------------------------------------------------------------------------------------|-----------------|
| Separator | A local display is provided. | Select decimal separator for displaying numerical values. | <ul style="list-style-type: none"> ▪ . (point) ▪ , (comma) | . (point) |
| Backlight | One of the following conditions is met: <ul style="list-style-type: none"> ▪ Order code for "Display; operation", option F "4-line, illum.; touch control" ▪ Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN" ▪ Order code for "Display; operation", option O "Remote display 4-line illuminated; 10m/30ft cable; touch control" | Switch the local display backlight on and off. | <ul style="list-style-type: none"> ▪ Disable ▪ Enable | Enable |

* Visibility depends on order options or device settings

10.6.4 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu → Advanced setup → WLAN settings

| ▶ WLAN settings | |
|--------------------------|---------|
| WLAN | → ⓘ 107 |
| WLAN mode | → ⓘ 107 |
| SSID name | → ⓘ 107 |
| Network security | → ⓘ 108 |
| Security identification | → ⓘ 108 |
| User name | → ⓘ 108 |
| WLAN password | → ⓘ 108 |
| WLAN IP address | → ⓘ 108 |
| WLAN MAC address | → ⓘ 108 |
| WLAN passphrase | → ⓘ 108 |
| Assign SSID name | → ⓘ 108 |
| SSID name | → ⓘ 108 |
| Connection state | → ⓘ 108 |
| Received signal strength | → ⓘ 108 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry / User interface | Factory setting |
|-----------|--------------------------|--------------------------------------------------------|----------------------------------------------------------------------------------------------|-------------------|
| WLAN | – | Switch WLAN on and off. | <ul style="list-style-type: none"> ■ Disable ■ Enable | Enable |
| WLAN mode | – | Select WLAN mode. | <ul style="list-style-type: none"> ■ WLAN access point ■ WLAN Client | WLAN access point |
| SSID name | The client is activated. | Enter the user-defined SSID name (max. 32 characters). | – | – |

| Parameter | Prerequisite | Description | Selection / User entry / User interface | Factory setting |
|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|
| Network security | – | Select the security type of the WLAN network. | <ul style="list-style-type: none"> ■ Unsecured ■ WPA2-PSK ■ EAP-PEAP with MSCHAPv2 * ■ EAP-PEAP MSCHAPv2 no server authentic. * ■ EAP-TLS * | WPA2-PSK |
| Security identification | – | Select security settings and download these settings via menu Data management > Security > WLAN. | <ul style="list-style-type: none"> ■ Trusted issuer certificate ■ Device certificate ■ Device private key | – |
| User name | – | Enter user name. | – | – |
| WLAN password | – | Enter WLAN password. | – | – |
| WLAN IP address | – | Enter IP address of the WLAN interface of the device. | 4 octet: 0 to 255 (in the particular octet) | 192.168.1.212 |
| WLAN MAC address | – | Enter MAC address of the WLAN interface of the device. | Unique 12-digit character string comprising letters and numbers | Each measuring device is given an individual address. |
| WLAN passphrase | The WPA2-PSK option is selected in the Security type parameter. | Enter the network key (8 to 32 characters).  The network key supplied with the device should be changed during commissioning for security reasons. | 8 to 32-digit character string comprising numbers, letters and special characters (without spaces) | Serial number of the measuring device (e.g. L100A802000) |
| Assign SSID name | – | Select which name will be used for SSID: device tag or user-defined name. | <ul style="list-style-type: none"> ■ Device tag ■ User-defined | User-defined |
| SSID name | <ul style="list-style-type: none"> ■ The User-defined option is selected in the Assign SSID name parameter. ■ The WLAN access point option is selected in the WLAN mode parameter. | Enter the user-defined SSID name (max. 32 characters).  The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another. | Max. 32-digit character string comprising numbers, letters and special characters | |
| Connection state | – | Displays the connection status. | <ul style="list-style-type: none"> ■ Connected ■ Not connected | Not connected |
| Received signal strength | – | Shows the received signal strength. | <ul style="list-style-type: none"> ■ Low ■ Medium ■ High | High |

* Visibility depends on order options or device settings

10.6.5 Heartbeat Technology application package



For detailed information on the parameter descriptions of the application packages, see the Special Documentation for the device. →  188

Navigation


"Setup" menu → Advanced setup → Heartbeat setup

10.6.6 Configuration management

After commissioning, you can save the current device configuration or restore the previous device configuration. The device configuration is managed via the **Configuration management** parameter.

Navigation

"Setup" menu → Advanced setup → Configuration backup



Parameter overview with brief description

| Parameter | Description | User interface / Selection | Factory setting |
|--------------------------|--------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Operating time | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) | – |
| Last backup | Shows when the last data backup was saved to HistoROM backup. | Days (d), hours (h), minutes (m) and seconds (s) | – |
| Configuration management | Select action for managing the device data in the HistoROM backup. | <ul style="list-style-type: none"> ■ Cancel ■ Execute backup ■ Restore * ■ Compare * ■ Clear backup data | Cancel |
| Backup state | Shows the current status of data saving or restoring. | <ul style="list-style-type: none"> ■ None ■ Backup in progress ■ Restoring in progress ■ Delete in progress ■ Compare in progress ■ Restoring failed ■ Backup failed | None |
| Comparison result | Comparison of current device data with HistoROM backup. | <ul style="list-style-type: none"> ■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible | Check not done |

* Visibility depends on order options or device settings

Function scope of the "Configuration management" parameter

| Options | Description |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cancel | No action is executed and the user exits the parameter. |
| Execute backup | A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device. |
| Restore | The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device. |
| Compare | The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup. |
| Clear backup data | The backup copy of the device configuration is deleted from the memory of the device. |

***HistoROM backup***

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.



While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.6.7 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu → Advanced setup → Administration

▶ Administration

▶ Define access code → ⓘ 111

▶ Reset access code → ⓘ 111

Device reset → ⓘ 112

Using the parameter to define the access code

Complete this wizard to specify an access code for the Maintenance role.

Navigation

"Setup" menu → Advanced setup → Administration → Define access code

▶ Define access code

Define access code → ⓘ 111

Confirm access code → ⓘ 111

Parameter overview with brief description

| Parameter | Description | User entry |
|---------------------|-----------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Define access code | Specify an access code that is required to obtain the access rights for the Maintenance role. | Max. 16-digit character string comprising numbers, letters and special characters |
| Confirm access code | Confirm the access code entered for the Maintenance role. | Max. 16-digit character string comprising numbers, letters and special characters |

Using the parameter to reset the access code

Navigation

"Setup" menu → Advanced setup → Administration → Reset access code

▶ Reset access code

Operating time → ⓘ 112

Reset access code → ⓘ 112

Parameter overview with brief description

| Parameter | Description | User interface / User entry | Factory setting |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------|-----------------|
| Operating time | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) | – |
| Reset access code | <p>Enter the code provided by Endress+Hauser Technical Support to reset the Maintenance code.</p> <p> For a reset code, contact your Endress+Hauser service organization.</p> <p>The reset code can only be entered via:</p> <ul style="list-style-type: none"> ▪ Web browser ▪ DeviceCare, FieldCare (via CDI-RJ45 service interface) ▪ Fieldbus | Character string comprising numbers, letters and special characters | 0x00 |

Using the parameter to reset the device**Navigation**

"Setup" menu → Advanced setup → Administration

Parameter overview with brief description

| Parameter | Description | Selection | Factory setting |
|--------------|-----------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Device reset | Reset the device configuration - either entirely or in part - to a defined state. | <ul style="list-style-type: none"> ▪ Cancel ▪ To delivery settings ▪ Restart device ▪ Restore S-DAT backup * | Cancel |

* Visibility depends on order options or device settings

10.7 Simulation

Via the **Simulation** submenu, it is possible to simulate various process variables in the process and the device alarm mode and verify downstream signal chains (switching valves or closed-control loops). The simulation can be performed without a real measurement (no flow of medium through the device).

Navigation

"Diagnostics" menu → Simulation

| ► Simulation | |
|------------------------------------|-------|
| Assign simulation process variable | → 114 |
| Process variable value | → 114 |
| Current input 1 to n simulation | → 114 |
| Value current input 1 to n | → 114 |
| Status input 1 to n simulation | → 114 |
| Input signal level 1 to n | → 114 |
| Current output 1 to n simulation | → 114 |
| Current output value | → 114 |
| Frequency output 1 to n simulation | → 114 |
| Frequency output 1 to n value | → 114 |
| Pulse output simulation 1 to n | → 114 |
| Pulse value 1 to n | → 114 |
| Switch output simulation 1 to n | → 114 |
| Switch state 1 to n | → 114 |
| Relay output 1 to n simulation | → 114 |
| Switch state 1 to n | → 114 |
| Device alarm simulation | → 114 |
| Diagnostic event category | → 115 |
| Diagnostic event simulation | → 115 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Assign simulation process variable | The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Select a process variable for the simulation process that is activated. | <ul style="list-style-type: none"> ▪ Off ▪ Load rate * ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity | Off |
| Process variable value | – | Enter the simulation value for the selected process variable. | Signed floating-point number | 0 |
| Current input 1 to n simulation | – | Switch simulation of the current input on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Value current input 1 to n | In the Current input 1 to n simulation parameter, the On option is selected. | Enter the current value for simulation. | 0 to 22.5 mA | 0 mA |
| Status input 1 to n simulation | – | Switch simulation of the status input on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Input signal level 1 to n | In the Status input simulation parameter, the On option is selected. | Select the signal level for the simulation of the status input. | <ul style="list-style-type: none"> ▪ High ▪ Low | High |
| Current output 1 to n simulation | – | Switch the simulation of the current output on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Current output value | In the Current output 1 to n simulation parameter, the On option is selected. | Enter the current value for simulation. | 3.59 to 22.5 mA | 3.59 mA |
| Frequency output 1 to n simulation | In the Operating mode parameter, the Frequency option is selected. | Switch the simulation of the frequency output on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Frequency output 1 to n value | In the Frequency simulation 1 to n parameter, the On option is selected. | Enter the frequency value for the simulation. | 0.0 to 12 500.0 Hz | 0.0 Hz |
| Pulse output simulation 1 to n | In the Operating mode parameter, the Pulse option is selected. | Set and switch off the pulse output simulation.  For Fixed value option: Pulse width parameter (→  90) defines the pulse width of the pulses output. | <ul style="list-style-type: none"> ▪ Off ▪ Fixed value ▪ Down-counting value | Off |
| Pulse value 1 to n | In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected. | Enter the number of pulses for simulation. | 0 to 65 535 | 0 |
| Switch output simulation 1 to n | In the Operating mode parameter, the Switch option is selected. | Switch the simulation of the switch output on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Switch state 1 to n | – | Select the status of the status output for the simulation. | <ul style="list-style-type: none"> ▪ Open ▪ Closed | Open |
| Relay output 1 to n simulation | – | Switch simulation of the relay output on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |
| Switch state 1 to n | The On option is selected in the Switch output simulation 1 to n parameter parameter. | Select status of the relay output for the simulation. | <ul style="list-style-type: none"> ▪ Open ▪ Closed | Open |
| Device alarm simulation | – | Switch the device alarm on and off. | <ul style="list-style-type: none"> ▪ Off ▪ On | Off |

| Parameter | Prerequisite | Description | Selection / User entry | Factory setting |
|-----------------------------|--------------|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Diagnostic event category | – | Select a diagnostic event category. | <ul style="list-style-type: none"> ■ Sensor ■ Electronics ■ Configuration ■ Process | Process |
| Diagnostic event simulation | – | Select a diagnostic event to simulate this event. | <ul style="list-style-type: none"> ■ Off ■ Diagnostic event picklist (depends on the category selected) | Off |

* Visibility depends on order options or device settings

10.8 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code → ⓘ 116
- Protect access to local operation via key locking → ⓘ 60
- Protect access to measuring device via write protection switch → ⓘ 117

10.8.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via the local display


1. Navigate to the **Define access code** parameter (→ ⓘ 111).
2. Maximum of 16-digit character string comprising numbers, letters and special characters as the access code.
3. Enter the access code again in the **Confirm access code** parameter (→ ⓘ 111) to confirm.

↳ The ⓘ symbol appears in front of all write-protected parameters.

- i
 - Disabling parameter write protection via access code → ⓘ 60.
 - If the access code is lost: Resetting the access code → ⓘ 117.
 - The user role with which the user is currently logged in is displayed in **Access status** parameter.
 - Navigation path: Operation → Access status
 - User roles and their access rights → ⓘ 59
- The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view.
- The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the web browser

1. Navigate to the **Define access code** parameter (→ ⓘ 111).

2. Define a 16-digit (max.) numeric code as the access code.
 3. Enter the access code again in the **Confirm access code** parameter (→ ⓘ 111) to confirm.
 - ↳ The web browser switches to the login page.
- 
 - Disabling parameter write protection via access code → ⓘ 60.
 - If the access code is lost: Resetting the access code → ⓘ 117.
 - The **Access status** parameter shows which user role the user is currently logged in with.
 - Navigation path: Operation → Access status
 - User roles and their access rights → ⓘ 59

If no action is performed for 10 minutes, the web browser automatically returns to the login page.

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus


-  You can only obtain a reset code from your local Endress+Hauser service organization. The code must be calculated explicitly for every device.
1. Note down the serial number of the device.
 2. Read off the **Operating time** parameter.
 3. Contact the local Endress+Hauser service organization and tell them the serial number and the operating time.
 - ↳ Get the calculated reset code.
 4. Enter the reset code in the **Reset access code** parameter (→ ⓘ 112).
 - ↳ The access code has been reset to the factory setting **0000**. It can be redefined → ⓘ 116.
-  For IT security reasons, the calculated reset code is only valid for 96 hours from the specified operating time and for the specific serial number. If you cannot return to the device within 96 hours, you should either increase the operating time you read out by a few days or switch off the device.

10.8.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via MODBUS RS485 protocol



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

- ↳ In the **Locking status** parameter, the **Hardware locked** option is displayed → 119. In addition, on the local display the  symbol appears in front of the parameters in the header of the operational display and in the navigation view.



2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

- ↳ No option is displayed in the **Locking status** parameter → 119. On the local display, the  symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

11 Operation

11.1 Reading off the device locking status

Device active write protection: **Locking status** parameter

Operation → Locking status

Function scope of the "Locking status" parameter

| Options | Description |
|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| None | The access authorization displayed in the Access status parameter applies →  59. Only appears on local display. |
| Hardware locked | The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) →  117. |
| Temporarily locked | Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again. |

11.2 Adjusting the operating language

 Detailed information:

- To configure the operating language
- For information on the operating languages supported by the measuring device →  178

11.3 Configuring the display

Detailed information:

- On the basic settings for the local display →  96
- On the advanced settings for the local display →  103

11.4 Adapting the measuring device to the process conditions

The following are available for this purpose:


- Basic settings using the **Setup** menu (→  80)
- Advanced settings using the **Advanced setup** submenu (→  100)

11.5 Reading off measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu → Measured values




11.5.1 "Process variables" submenu

The contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables



Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|--------------|--------------|---------------------------------------------------------------------------------|------------------------------|
| Total solids | - | Shows total solids (fraction of total weight or concentration per volume unit). | Signed floating-point number |
| Temperature | - | Shows the medium temperature currently measured. | Signed floating-point number |


| Parameter | Prerequisite | Description | User interface |
|-------------------------|----------------------------------------------------------------------------------------|--------------------------------------------------------------|------------------------------|
| Electronics temperature | – | Shows the electronics temperature currently measured. | Signed floating-point number |
| Conductivity | – | Shows the conductivity currently measured. | Floating-point number |
| Corrected conductivity | – | Shows the conductivity measured compensated for temperature. | Floating-point number |
| Load rate | The volume flow of the medium is read in via the Current input 1 to n or the fieldbus. | Shows the total solids flow rate. | Signed floating-point number |

11.5.2 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu → Measured values → Input values




Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu → Measured values → Input values → Current input 1 to n



Parameter overview with brief description


| Parameter | Description | User interface |
|-------------------------|--------------------------------------------------|------------------------------|
| Measured values 1 to n | Displays the current input value. | Signed floating-point number |
| Measured current 1 to n | Displays the current value of the current input. | 0 to 22.5 mA |

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu → Measured values → Input values → Status input 1 to n



Parameter overview with brief description


| Parameter | Description | User interface |
|--------------------|---------------------------------------|-------------------------------------------------------------------------|
| Value status input | Shows the current input signal level. | <ul style="list-style-type: none"> ▪ High ▪ Low |

11.5.3 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values




Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu → Measured values → Output values → Value current output 1 to n



Parameter overview with brief description

| Parameter | Description | User interface |
|------------------|-------------------------------------------------------------------------|-----------------|
| Output current | Displays the current value currently calculated for the current output. | 3.59 to 22.5 mA |
| Measured current | Displays the current value currently measured for the current output. | 0 to 30 mA |

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu → Measured values → Output values → Pulse/frequency/switch output 1 to n

► **Pulse/frequency/switch output 1 to n**

| | |
|------------------|--------|
| Output frequency | → 123 |
| Pulse output | → 123 |
| Switch state | → 123 |

Parameter overview with brief description

| Parameter | Prerequisite | Description | User interface |
|------------------|---------------------------------------------------------------------------------------|-----------------------------------------------------------------|----------------------------------------------------------------------------|
| Output frequency | In the Operating mode parameter, the Frequency option is selected. | Displays the value currently measured for the frequency output. | 0.0 to 12 500.0 Hz |
| Pulse output | The Pulse option is selected in the Operating mode parameter parameter. | Displays the pulse frequency currently output. | Positive floating-point number |
| Switch state | The Switch option is selected in the Operating mode parameter. | Displays the current switch output status. | <ul style="list-style-type: none"> ■ Open ■ Closed |

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu → Measured values → Output values → Relay output 1 to n

► **Relay output 1 to n**

| | |
|---------------------------|--------|
| Switch state | → 124 |
| Switch cycles | → 124 |
| Max. switch cycles number | → 124 |

Parameter overview with brief description


| Parameter | Description | User interface |
|---------------------------|-------------------------------------------------------|----------------------------------------------------------------------------|
| Switch state | Indicates the current switch state of the output. | <ul style="list-style-type: none"> ▪ Open ▪ Closed |
| Switch cycles | Shows number of all performed switch cycles. | Positive integer |
| Max. switch cycles number | Shows the maximal number of guaranteed switch cycles. | Positive integer |

11.5.4 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer



Parameter overview with brief description

| Parameter | Description | User interface |
|----------------------|-----------------------------------------------|------------------------------|
| Totalizer 1 value | Displays the current totalizer counter value. | Signed floating-point number |
| Totalizer 1 overflow | Displays the current totalizer overflow. | Integer with sign |


11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu → Totalizer handling



Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry / User interface | Factory setting |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Totalizer 1 control | A process variable is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu. | Operate the totalizer. | <ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold | Totalize |
| Preset value 1 | A process variable is selected in the Assign process variable parameter (→ 102) of the Totalizer 1 to n submenu. | Specify start value for totalizer. <i>Dependency</i>  The unit of the selected process variable is defined in the Unit totalizer parameter (→ 102) for the totalizer. | Signed floating-point number | 0 kg |
| Totalizer value | – | Displays the current totalizer counter value. | Signed floating-point number | – |
| Reset all totalizers | – | Reset all totalizers to 0 and start. | <ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize | Cancel |

11.6.1 Function scope of "Control Totalizer" parameter

| Options | Description |
|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Totalize | The totalizer is started or continues running. |
| Reset + hold | The totaling process is stopped and the totalizer is reset to 0. |
| Preset + hold ¹⁾ | The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter. |
| Reset + totalize | The totalizer is reset to 0 and the totaling process is restarted. |

| Options | Description |
|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| Preset + totalize ¹⁾ | The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted. |
| Hold | Totalizing is stopped. |

1) Visible depending on the order options or device settings

11.6.2 Function range of "Reset all totalizers" parameter

| Options | Description |
|------------------|-----------------------------------------------------------------------------------------------------------------------|
| Cancel | No action is executed and the user exits the parameter. |
| Reset + totalize | Resets the totalizer to 0 and restarts the totaling process. The previously aggregated load quantity is thus deleted. |


11.7 Displaying the measured value history

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

-  Data logging is also available via:
 - Plant Asset Management Tool FieldCare →  70.
 - Web browser

Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Measured value trend for each logging channel displayed in the form of a chart



 26 Chart of a measured value trend

A0053802

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

-  If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

▶ **Data logging**

| | |
|--------------------|---------------------------------------------------------------------------------------------|
| Assign channel 1 | →  128 |
| Assign channel 2 | →  128 |
| Assign channel 3 | →  128 |
| Assign channel 4 | →  129 |
| Logging interval | →  129 |
| Clear logging data | →  129 |
| Data logging | →  129 |
| Logging delay | →  129 |

| | |
|-------------------------|-------------------------------------------------------------------------------------------|
| Data logging control | →  129 |
| Data logging status | →  129 |
| Entire logging duration | →  129 |
| ▶ Display channel 1 | |
| ▶ Display channel 2 | |
| ▶ Display channel 3 | |
| ▶ Display channel 4 | |

Parameter overview with brief description

| Parameter | Prerequisite | Description | Selection / User entry / User interface | Factory setting |
|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Assign channel 1 | The Extended HistoROM application package is available. | Assign process variable to logging channel. | <ul style="list-style-type: none"> ▪ Off ▪ Total solids ▪ Temperature ▪ Electronics temperature ▪ Conductivity ▪ Corrected conductivity ▪ Load rate * ▪ Current output 1 * ▪ Current output 2 * ▪ Current output 3 * ▪ Current output 4 * | Off |
| Assign channel 2 | <ul style="list-style-type: none"> ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. ▪ The Extended HistoROM application package is available. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  128) | Off |
| Assign channel 3 | <ul style="list-style-type: none"> ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. ▪ The Extended HistoROM application package is available. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  128) | Off |

| Parameter | Prerequisite | Description | Selection / User entry / User interface | Factory setting |
|-------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Assign channel 4 | <ul style="list-style-type: none"> ▪ The Load rate option is only available if the volume flow of the medium is read in via the Current input 1 to n or the fieldbus. ▪ The Extended HistoROM application package is available. <p> The software options currently enabled are displayed in the Software option overview parameter.</p> | Assign a process variable to logging channel. | For the picklist, see Assign channel 1 parameter (→  128) | Off |
| Logging interval | The Extended HistoROM application package is available. | Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory. | 0.1 to 3 600.0 s | 1.0 s |
| Clear logging data | The Extended HistoROM application package is available. | Clear the entire logging data. | <ul style="list-style-type: none"> ▪ Cancel ▪ Clear data | Cancel |
| Data logging | – | Select the type of data logging. | <ul style="list-style-type: none"> ▪ Overwriting ▪ Not overwriting | Overwriting |
| Logging delay | In the Data logging parameter, the Not overwriting option is selected. | Enter the time delay for measured value logging. | 0 to 999 h | 0 h |
| Data logging control | In the Data logging parameter, the Not overwriting option is selected. | Start and stop measured value logging. | <ul style="list-style-type: none"> ▪ None ▪ Delete + start ▪ Stop | None |
| Data logging status | In the Data logging parameter, the Not overwriting option is selected. | Displays the measured value logging status. | <ul style="list-style-type: none"> ▪ Done ▪ Delay active ▪ Active ▪ Stopped | Done |
| Entire logging duration | In the Data logging parameter, the Not overwriting option is selected. | Displays the total logging duration. | Positive floating-point number | 0 s |

* Visibility depends on order options or device settings

11.8 Adjusting the measured value with the aid of wizards

In practice, the measurement typically needs to be adjusted based a reference value (e.g. lab value) when commissioning the device to ensure optimum measurement performance during subsequent operation. Repeating this adjustment is recommended if there are significant changes to the process conditions or following replacement of the sensor electronics module (ISEM).

The deviation from the value determined by the device can be checked and adjusted if necessary with the aid of manually taken samples of the medium, which are analyzed in the laboratory. The lab value is compared with the measured value of the device for this purpose. The difference between the two values can then be used to decide whether the measurement performance is sufficient or whether the device should be readjusted based on the laboratory value.

The device has four wizards to facilitate this process. After starting each wizard, you are guided through the necessary work steps.

Performing the basic settings for the adjustment:

1. **Commissioning** wizard

Adjusting the measured value based on the reference value:

2. **1 - Take a sample** wizard
3. **2 - Enter lab value** wizard
4. **3 - Perform adjustment** wizard

 Adjustment can be carried out directly via local operation of the device or via the web server.

The process using the wizards is essentially the same for both operation methods, but more options and a graphic display are available when operating via the web server in the **3 - Perform adjustment** wizard. Using the web server is therefore recommended.

Online information



Further information on the procedure for performing an adjustment using wizards is also available online.

11.8.1 Performing the basic settings for the adjustment

 The **Commissioning** wizard is called up via the main menu: Setup → Total solids adjustment → Commissioning

Commissioning

The **Commissioning** wizard is used to:

- set the system time (when using the wizard for the first time or after disconnecting the device from the supply voltage)
- set the unit for the solids content for the measured total solids and the lab value
- enter the solids density

11.8.2 Adjusting the measured value based on the reference value

-  **All three wizards** must be run each time the device is adjusted.
- You can call up the wizard options via the operating menu or during local operation from the operational display by holding down the Enter key  for longer than 3 seconds →  132.

Taking a sample

The **1 - Take a sample** wizard is used to:

- set the system time (if not already defined in the **Commissioning** wizard)
- have the total solids measured by the device
- calculate the value of the medium sample of the device

 The calculated medium sample of the device is the average of the total solids measured by the device between the start and end of the wizard.

- perform a check as to whether the variability is within the permitted limits You can set the upper limit in the **Maximum variance** parameter.
- save the value of the sample calculated by the device (incl. system time and status).

 ▪ At the same time as the total solids in the device are measured, a sample must be taken manually for analysis in the laboratory.

- The installation of sampling points is recommended for taking samples of the medium →  24.

Entering the lab value

The **2 - Enter lab value** wizard is used to:

- select a unit for entering the sample of the medium taken manually.
- select the sample measured by the device that is to be used for the lab value
- enter the lab value of the sample of the medium taken manually
- check whether the lab value is within the value range
- save the lab value (incl. status and min./max. values if applicable)

Performing the adjustment

The **3 - Perform adjustment** wizard is used to:

- display the respective medium sample with the corresponding lab values and the number of adjustments performed.
- select whether a single-point adjustment or a multi-point adjustment is to be performed

 ▪ In the case of a single-point adjustment, the value of the most recent, valid sample taken is always selected automatically.

▪ In the case of a multi-point adjustment, the values of the last ten valid samples are always selected automatically.

- display the current and new factor and offset
- display the current and new value of the total solids
- display the time stamp of the completed process and confirm completion.

 Each completed adjustment is documented: Diagnostics → Event logbook → Event list

Extended functionality when running the wizard via the web server

In the web server, the samples of the medium are displayed in a table (max. 10 out of 32 stored samples). It is also possible to adjust the selection of samples used for the adjustment.

- In the case of a single-point adjustment, the value of the most recent, valid sample taken is always selected automatically. You can determine the most recent sample you want to use by deleting the most recent sample in the table.
- In the case of a multi-point adjustment, the values of the last ten valid samples taken are always automatically selected. You can determine the samples you want to use for the adjustment by deleting samples from the table.

11.8.3 Calling up wizards

- **Commissioning wizard**


The wizard is called up via the main menu: Setup → Total solids adjustment → Commissioning

- **Take a sample wizard, Enter lab value wizard and Assistent Perform adjustment:**

You can call up the wizard options via the operating menu or during local operation from the operational display by holding down the Enter key  for longer than 3 seconds.

Performing the adjustment process via local operation

1. Press the Enter key  for longer than 3 seconds.



A0026785


A selection field appears with adjustment options.

2. Confirm the desired adjustment option in the selection field.
 - ↳ The available wizards are displayed.
3. Select the desired wizard and follow the instructions.

Performing the adjustment process via the web server

 Access the operating menu via web browser - web server →  61.


1. After starting the web server, select **Main menu > Setup** .



A0052630


2. Select **Total solids adjustment**.

↳ The available wizards are displayed.



A0052631

3. Select the desired wizard.
 - ↳ The individual steps of the wizard are displayed.



A0053912

4. Follow the instructions provided by the wizard.
 - ↳ The wizard guides you through the individual steps.

12 Diagnosis and troubleshooting

12.1 General troubleshooting

For local display

| Fault | Possible causes | Remedial action |
|---------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Local display is dark, but signal output is within the valid range | The cable of the display module is not plugged in correctly. | Insert the plug correctly into the main electronics module and display module. |
| Local display dark and no output signals | Supply voltage does not match the voltage specified on the nameplate. | Apply the correct supply voltage . |
| | Supply voltage has incorrect polarity. | Reverse polarity of supply voltage |
| | No contact between connection cables and terminals | Ensure electrical contact between the cable and the terminal. |
| | <ul style="list-style-type: none"> ▪ Terminals are not plugged into the I/O electronics module correctly. ▪ Terminals are not plugged into the main electronics module correctly. | Check terminals. |
| | <ul style="list-style-type: none"> ▪ I/O electronics module is defective. ▪ Main electronics module is defective. | Order spare part → 📄 158. |
| | Local display cannot be read, but signal output is within the valid range | Display is set too bright or too dark. |
| Local display is dark, but signal output is within the valid range | Display module is defective. | Order spare part → 📄 158. |
| Backlighting of local display is red | Diagnostic event with "Alarm" diagnostic behavior has occurred. | Take remedial measures → 📄 145 |
| Text on local display appears in a language that cannot be understood. | The selected operating language cannot be understood. | <ol style="list-style-type: none"> 1. Press + for 2 s ("home position"). 2. Press . 3. Configure the required language in the Display language parameter (→ 📄 105). |
| Message on local display: "Communication Error" "Check Electronics" | Communication between the display module and the electronics is interrupted. | <ul style="list-style-type: none"> ▪ Check the cable and the connector between the main electronics module and display module. ▪ Order spare part → 📄 158. |

For output signals

| Fault | Possible causes | Remedial action |
|---------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Signal output outside the valid range | Main electronics module is defective. | Order spare part → 📄 158. |
| Signal output outside the valid current range (< 3.6 mA or > 22 mA) | Main electronics module is defective. I/O electronics module is defective. | Order spare part → 📄 158. |
| Device shows correct value on local display, but signal output is incorrect, though in the valid range. | Parameter configuration error | Check and adjust parameter configuration. |
| Device measures incorrectly. | Configuration error or device is operated outside the application. | <ol style="list-style-type: none"> 1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data". |
| Unexpected and significant difference with regard to the laboratory value | Formation of buildup on the antennas Buildup usually produces a positive difference with regard to the laboratory value. | <ol style="list-style-type: none"> 1. Remove buildup. 2. Perform a new adjustment → 📄 130. When removing the buildup, make sure that the measuring tube, the antennas and the temperature sensor are neither mechanically damaged nor chemically corroded. |

For access


| Fault | Possible causes | Remedial action |
|--------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Write access to parameters is not possible. | Hardware write protection is enabled. | Set the write protection switch on the main electronics module to the OFF position → 117. |
| | Current user role has limited access authorization. | 1. Check user role → 59. 2. Enter correct customer-specific access code → 60. |
| Connection via Modbus RS485 is not possible. | Modbus RS485 bus cable is connected incorrectly. | Check the terminal assignment . |
| | Modbus RS485 cable is incorrectly terminated. | Check terminating resistor → 43. |
| | Settings for the communication interface are incorrect. | Check the Modbus RS485 configuration → 83. |
| | Web server is disabled. | Using the "FieldCare" or "DeviceCare" operating tool, check whether the web server of the measuring device is enabled, and enable it if necessary → 66. |
| | The Ethernet interface on the PC is incorrectly configured. | <ul style="list-style-type: none"> ▶ Check the properties of the Internet protocol (TCP/IP) → 62. ▶ Check the network settings with the IT manager. |
| | The IP address on the PC is incorrectly configured. | Check the IP address: 192.168.1.212 → 62 |
| | WLAN access data are incorrect. | <ul style="list-style-type: none"> ▪ Check WLAN network status. ▪ Log on to the device again using WLAN access data. ▪ Check that WLAN is enabled on the measuring device and operating unit → 62. |
| WLAN communication is disabled. | – | |
| Unable to connect to web server, FieldCare or DeviceCare. | WLAN network is not available. | <ul style="list-style-type: none"> ▪ Check if WLAN reception is present: LED on display module is lit blue. ▪ Check if WLAN connection is enabled: LED on display module flashes blue. ▪ Switch on instrument function. |
| Network connection not present or unstable | WLAN network is weak. | <ul style="list-style-type: none"> ▪ Operating unit outside reception range: Check network status on operating unit. ▪ To improve network performance, use an external WLAN antenna. |
| | Parallel WLAN and Ethernet communication | <ul style="list-style-type: none"> ▪ Check network settings. ▪ Temporarily enable only the WLAN as an interface. |
| Web browser frozen and operation no longer possible | Data transfer is active. | Wait until data transfer or current action is finished. |
| | Connection lost | <ul style="list-style-type: none"> ▶ Check cable connection and power supply. ▶ Refresh the web browser and restart if necessary. |
| Display of web browser content is difficult to read or incomplete. | Web browser version used is not optimal. | <ul style="list-style-type: none"> ▶ Use correct web browser version → 61. ▶ Empty the web browser cache. ▶ Restart the web browser. |
| | Unsuitable view settings. | Change the font size/display ratio of the Web browser. |
| Incomplete or no display of content in the web browser | <ul style="list-style-type: none"> ▪ JavaScript is not enabled. ▪ JavaScript cannot be enabled. | <ul style="list-style-type: none"> ▶ Enable JavaScript. ▶ Enter http://XXX.XXX.X.XX/servlet/basic.html as the IP address. |

| Fault | Possible causes | Remedial action |
|------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Operation with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000) is not possible. | Firewall of the PC or network is blocking communication. | Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access. |
| Flashing the firmware with FieldCare or DeviceCare via service interface CDI-RJ45 (port 8000 or TFTP ports) is not possible. | Firewall of the PC or network is blocking communication. | Depending on the settings of the firewall used on the PC or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access. |

12.2 Diagnostic information via LEDs

12.2.1 Transmitter

Different LEDs in the transmitter provide information on the device status.



A0029629


- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

| LED | Color/behavior | Meaning |
|------------------------------------|---------------------|---------------------------------------------------------------------|
| 1 Supply voltage | LED off | Supply voltage is off or too low. |
| | Green | Supply voltage is OK. |
| 2 Device status (normal operation) | Off | Firmware error |
| | Green | Device status is OK. |
| | Flashing green | Device is not configured. |
| | Red | A diagnostic event with "Alarm" diagnostic behavior has occurred. |
| | Flashing red | A diagnostic event with "Warning" diagnostic behavior has occurred. |
| 2 Device status (during start-up) | Flashes red slowly | If > 30 seconds: problem with the boot loader. |
| | Flashes red quickly | If > 30 seconds: compatibility problem when reading the firmware. |
| 3 Not used | – | – |
| 4 Communication | LED off | Communication not active. |
| | White | Communication active. |
| 5 Service interface (CDI) | LED off | Not connected or no connection established. |
| | Yellow | Connected and connection established. |
| | Flashing yellow | Service interface active. |

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- i** Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
 - Via parameter → 149
 - Via submenus → 149

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- i** The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


| Symbol | Meaning |
|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| F | Failure A device error has occurred. The measured value is no longer valid. |
| C | Function check The device is in service mode (e.g. during a simulation). |
| S | Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) |
| M | Maintenance required Maintenance is required. The measured value remains valid. |

Diagnostic behavior

| Symbol | Meaning |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Alarm <ul style="list-style-type: none"> ▪ Measurement is interrupted. ▪ Signal outputs and totalizers assume the defined alarm condition. ▪ A diagnostic message is generated. |
|  | Warning <ul style="list-style-type: none"> ▪ Measurement is resumed. ▪ The signal outputs and totalizers are not affected. ▪ A diagnostic message is generated. |

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

| Operating key | Meaning |
|-------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
|  | Plus key <i>In menu, submenu</i> Opens the message about the remedial measures. |
|  | Enter key <i>In menu, submenu</i> Opens the operating menu. <i>If pressed > 3 seconds</i> Displays the available wizards. |

12.3.2 Calling up remedial measures



A0029431-EN

27 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures

1. The user is in the diagnostic message.
Press \oplus (ⓘ symbol).
↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with \oplus or \ominus and press \boxminus .
↳ The message about the remedial measures opens.
3. Press $\ominus + \oplus$ simultaneously.
↳ The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

1. Press \boxminus .
↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press $\ominus + \oplus$ simultaneously.
↳ The message for the remedial measures closes.

12.4 Diagnostic information in the web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



A0031056

- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 📄 149
- Via submenu → 📄 149

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

| Symbol | Meaning |
|--------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| | Failure A device error has occurred. The measured value is no longer valid. |
| | Function check The device is in service mode (e.g. during a simulation). |
| | Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) |
| | Maintenance required Maintenance is required. The measured value remains valid. |

i The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- 1 Status area with status signal → 138
- 2 Diagnostic information → 139
- 3 Remedial measures with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 149
- Via submenu → 149

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
 - ↳ A tool tip with remedy information for the diagnostic event appears.

12.6 Diagnostic information via communication interface

12.6.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270

 For an overview of diagnostic events with diagnosis number and diagnosis code
→  145

12.6.2 Configuring error response mode

The error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

Navigation path

Setup → Communication

Parameter overview with brief description

| Parameter | Meaning | Options | Factory setting |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| Failure mode | Select measured value output behavior when a diagnostic message occurs via Modbus communication.  The effect of this parameter depends on the option selected in the Assign diagnostic behavior parameter. | <ul style="list-style-type: none"> ▪ NaN value ▪ Last valid value  NaN ≙ not a number | NaN value |

12.7 Adapting the diagnostic information

12.7.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

| Options | Description |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Alarm | The device stops measurement. The measured value output via Modbus RS485 and the totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red. |
| Warning | The device continues to measure. The measured value output via Modbus RS485 and the totalizers are not affected. A diagnostic message is generated. |
| Logbook entry only | The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (Event list submenu) and is not displayed in alternating sequence with the operational display. |
| Off | The diagnostic event is ignored, and no diagnostic message is generated or entered. |

12.8 Overview of diagnostic information

 In the case of some items of diagnostic information, the diagnostic behavior can be changed. Adapting the diagnostic information

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|---------------------------------|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|----------------------------------------|
| Diagnostic of sensor | | | | |
| 022 | Temperature sensor defective | 1. Change main electronic module 2. Change sensor | F | Alarm |
| 082 | Data storage inconsistent | Check module connections | F | Alarm |
| 083 | Memory content inconsistent | 1. Restart device 2. Restore S-DAT data 3. Replace S-DAT | F | Alarm |
| 181 | Antenna connection faulty | 1. Check sensor cable and sensor 2. Perform Heartbeat Verification | F | Alarm |
| Diagnostic of electronic | | | | |
| 201 | Electronics faulty | 1. Restart device 2. Replace electronics | F | Alarm |
| 242 | Firmware incompatible | 1. Check firmware version 2. Flash or replace electronic module | F | Alarm |
| 252 | Module incompatible | 1. Check electronic modules 2. Check if correct modules are available (e.g. NEx, Ex) 3. Replace electronic modules | F | Alarm |
| 262 | Module connection interrupted | 1. Check or replace connection cable between sensor electronic module (ISEM) and main electronics 2. Check or replace ISEM or main electronics | F | Alarm |
| 270 | Main electronics defective | 1. Restart device 2. Replace main electronic module | F | Alarm |
| 271 | Main electronics faulty | 1. Restart device 2. Replace main electronic module | F | Alarm |
| 272 | Main electronics faulty | Restart device | F | Alarm |
| 273 | Main electronics defective | 1. Pay attention to display emergency operation 2. Replace main electronics | F | Alarm |
| 275 | I/O module defective | Change I/O module | F | Alarm |
| 276 | I/O module faulty | 1. Restart device 2. Change I/O module | F | Alarm |
| 283 | Memory content inconsistent | Restart device | F | Alarm |
| 302 | Device verification active | Device verification active, please wait. | C | Warning ¹⁾ |
| 303 | I/O 1 to n configuration changed | 1. Apply I/O module configuration (parameter "Apply I/O configuration") 2. Afterwards reload device description and check wiring | M | Warning |
| 311 | Sensor electronics (ISEM) faulty | Maintenance required! Do not reset device | M | Warning |
| 330 | Flash file invalid | 1. Update firmware of device 2. Restart device | M | Warning |

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|------------------------------------|-----------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|----------------------------------------|
| 331 | Firmware update failed | 1. Update firmware of device 2. Restart device | F | Warning |
| 332 | Writing in HistoROM backup failed | 1. Replace user interface board 2. Ex d/XP: replace transmitter | F | Alarm |
| 361 | I/O module 1 to n faulty | 1. Restart device 2. Check electronic modules 3. Change I/O module or main electronics | F | Alarm |
| 372 | Sensor electronics (ISEM) faulty | 1. Restart device 2. Check if failure recurs 3. Replace sensor electronic module (ISEM) | F | Alarm |
| 373 | Sensor electronics (ISEM) faulty | Transfer data or reset device | F | Alarm |
| 375 | I/O- 1 to n communication failed | 1. Restart device 2. Check if failure recurs 3. Replace module rack inclusive electronic modules | F | Alarm |
| 376 | Sensor electronics (ISEM) faulty | 1. Replace sensor electronic module (ISEM) 2. Turn off diagnostic message | F | Alarm |
| 378 | Supply voltage ISEM faulty | 1. If available: Check connection cable between sensor and transmitter 2. Replace main electronic module 3. Replace sensor electronic module (ISEM) | F | Alarm |
| 382 | Data storage | 1. Insert T-DAT 2. Replace T-DAT | F | Alarm |
| 383 | Memory content | Reset device | F | Alarm |
| 387 | HistoROM data faulty | Contact service organization | F | Alarm |
| Diagnostic of configuration | | | | |
| 410 | Data transfer failed | 1. Retry data transfer 2. Check connection | F | Alarm |
| 412 | Processing download | Download active, please wait | C | Warning |
| 431 | Trim 1 to n required | Carry out trim | M | Warning |
| 437 | Configuration incompatible | 1. Update firmware 2. Execute factory reset | F | Alarm |
| 438 | Dataset different | 1. Check dataset file 2. Check device parameterization 3. Download new device parameterization | M | Warning |
| 441 | Current output 1 to n saturated | 1. Check current output settings 2. Check process | S | Warning ¹⁾ |
| 442 | Frequency output 1 to n saturated | 1. Check frequency output settings 2. Check process | S | Warning ¹⁾ |
| 443 | Pulse output 1 to n saturated | 1. Check pulse output settings 2. Check process | S | Warning ¹⁾ |
| 444 | Current input 1 to n saturated | 1. Check current input settings 2. Check connected device 3. Check process | S | Warning ¹⁾ |
| 453 | Flow override active | Deactivate flow override | C | Warning |

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|------------------------------|-------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|----------------------------------|----------------------------------------|
| 484 | Failure mode simulation active | Deactivate simulation | C | Alarm |
| 485 | Process variable simulation active | Deactivate simulation | C | Warning |
| 486 | Current input 1 to n simulation active | Deactivate simulation | C | Warning |
| 491 | Current output 1 to n simulation active | Deactivate simulation | C | Warning |
| 492 | Frequency output 1 to n simulation active | Deactivate simulation frequency output | C | Warning |
| 493 | Pulse output simulation active | Deactivate simulation pulse output | C | Warning |
| 494 | Switch output 1 to n simulation active | Deactivate simulation switch output | C | Warning |
| 495 | Diagnostic event simulation active | Deactivate simulation | C | Warning |
| 496 | Status input 1 to n simulation active | Deactivate status input simulation | C | Warning |
| 520 | I/O 1 to n hardware configuration invalid | 1. Check I/O hardware configuration 2. Replace wrong I/O module | F | Alarm |
| 537 | Configuration | 1. Check IP addresses in network 2. Change IP address | F | Warning |
| 594 | Relay output 1 to n simulation active | Deactivate simulation switch output | C | Warning |
| Diagnostic of process | | | | |
| 803 | Loop current 1 faulty | 1. Check wiring 2. Change I/O module | F | Alarm |
| 832 | Electronics temperature too high | Reduce ambient temperature | S | Warning ¹⁾ |
| 833 | Electronics temperature too low | Increase ambient temperature | S | Warning ¹⁾ |
| 834 | Process temperature too high | Reduce process temperature | S | Warning ¹⁾ |
| 835 | Process temperature too low | Increase process temperature | S | Warning ¹⁾ |
| 844 | Total solids range exceeded | Check range limits | S | Warning ¹⁾ |
| 862 | Partly filled pipe | 1. Verify that the measuring tube is filled with the medium. 2. Verify that build-up does not interfere with antennas. | S | Warning ¹⁾ |
| 881 | Signal to noise ratio too low | 1. Check process conditions 2. Clean measuring tube 3. Replace sensor electronic module (ISEM) | S | Warning ¹⁾ |
| 882 | Input signal faulty | 1. Check input signal parameterization 2. Check external device 3. Check process conditions | F | Alarm |
| 907 | Permittivity out of specification | Check composition of the medium | S | Warning ¹⁾ |

| Diagnostic number | Short text | Remedy instructions | Status signal [from the factory] | Diagnostic behavior [from the factory] |
|-------------------|--------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|----------------------------------------|
| 908 | Volume fraction out of specification | <ol style="list-style-type: none">1. Perform adjustment2. Remove build-up on antennas / temperature sensors3. Check for gas in medium | S | Warning ¹⁾ |
| 909 | Conductivity out of specification | <ol style="list-style-type: none">1. Check process conditions2. Clean measuring tube3. Replace sensor electronic module (ISEM) | S | Warning ¹⁾ |
| 944 | Monitoring failed | Check process conditions for Heartbeat Monitoring | S | Warning |

1) Diagnostic behavior can be changed.

12.9 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

-  To call up the measures to rectify a diagnostic event:
 - Via local display →  140
 - Via web browser →  141
 - Via "FieldCare" operating tool →  143
 - Via "DeviceCare" operating tool →  143

-  Other pending diagnostic events can be displayed in the **Diagnostic list** submenu →  149.

Navigation

"Diagnostics" menu



Parameter overview with brief description


| Parameter | Prerequisite | Description | User interface |
|-----------------------------|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------|
| Actual diagnostics | A diagnostic event has occurred. | Shows the current occurred diagnostic event along with its diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Previous diagnostics | Two diagnostic events have already occurred. | Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information. | Symbol for diagnostic behavior, diagnostic code and short message. |
| Operating time from restart | – | Shows the time the device has been in operation since the last device restart. | Days (d), hours (h), minutes (m) and seconds (s) |
| Operating time | – | Indicates how long the device has been in operation. | Days (d), hours (h), minutes (m) and seconds (s) |

12.10 Diagnostics list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list



A0014006-EN

 28 Using the example of the local display

 To call up the measures to rectify a diagnostic event:

- Via local display →  140
- Via web browser →  141
- Via "FieldCare" operating tool →  143
- Via "DeviceCare" operating tool →  143


12.11 Event logbook

12.11.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu → **Event logbook** submenu → Events list



29 Using the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events → 145
- Information events → 152

In addition to the operating time when the event occurred, each event is also assigned a symbol that indicates whether the event has occurred or is finished:

- Diagnostics event
 - ⌚: Occurrence of the event
 - ⌚: End of the event
- Information event
 - ⌚: Occurrence of the event

i To call up the measures to rectify a diagnostic event:

- Via local display → 140
- Via web browser → 141
- Via "FieldCare" operating tool → 143
- Via "DeviceCare" operating tool → 143

i For filtering the displayed event messages → 151

12.11.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics → **Event logbook** → **Filter options**

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

| Info number | Info name |
|-------------|------------------------------------------|
| I1000 | ----- (Device ok) |
| I1079 | Sensor changed |
| I1089 | Power on |
| I1090 | Configuration reset |
| I1091 | Configuration changed |
| I1092 | HistoROM backup deleted |
| I11359 | Temperature sensor defective |
| I11360 | Temperature sensor defective |
| I11362 | Total solids measurement adjusted |
| I1137 | Electronics changed |
| I1151 | History reset |
| I1155 | Reset electronics temperature |
| I1156 | Memory error trend |
| I1157 | Memory error event list |
| I1256 | Display: access status changed |
| I1264 | Safety sequence aborted |
| I1278 | I/O module restarted |
| I1335 | Firmware changed |
| I1361 | Web server: login failed |
| I1397 | Fieldbus: access status changed |
| I1398 | CDI: access status changed |
| I1444 | Device verification passed |
| I1445 | Device verification failed |
| I1450 | Monitoring off |
| I1451 | Monitoring on |
| I1457 | Measurement error verification failed |
| I1459 | I/O module verification failed |
| I1461 | Sensor verification failed |
| I1462 | Sensor electronic module verific. failed |
| I1512 | Download started |
| I1513 | Download finished |
| I1514 | Upload started |
| I1515 | Upload finished |
| I1554 | Safety sequence started |
| I1555 | Safety sequence confirmed |
| I1556 | Safety mode off |
| I1618 | I/O module 2 replaced |
| I1619 | I/O module 3 replaced |
| I1621 | I/O module 4 replaced |

| Info number | Info name |
|-------------|-----------------------------------------|
| I1622 | Calibration changed |
| I1624 | All totalizers reset |
| I1625 | Write protection activated |
| I1626 | Write protection deactivated |
| I1627 | Web server: login successful |
| I1628 | Display: login successful |
| I1629 | CDI: login successful |
| I1631 | Web server access changed |
| I1632 | Display: login failed |
| I1633 | CDI: login failed |
| I1634 | Reset to factory settings |
| I1635 | Reset to delivery settings |
| I1639 | Max. switch cycles number reached |
| I1649 | Hardware write protection activated |
| I1650 | Hardware write protection deactivated |
| I1712 | New flash file received |
| I1725 | Sensor electronic module (ISEM) changed |
| I1726 | Configuration backup failed |

12.12 Resetting the measuring device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter (→  112).

12.12.1 Function range of "Device reset" parameter

| Options | Description |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cancel | No action is executed and the user exits the parameter. |
| To delivery settings | Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting. |
| Restart device | The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged. |
| Restore S-DAT backup | Restores the data that is saved on the S-DAT. Additional information: This function can be used to resolve the memory issue "083 Memory content inconsistent" or to restore the S-DAT data when a new S-DAT has been installed.  This option is displayed only in an alarm condition. |

12.13 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu → Device information

| ▶ Device information | |
|-----------------------|---------------------------------------------------------------------------------------------|
| Device tag | →  155 |
| Serial number | →  155 |
| Firmware version | →  155 |
| Device name | →  155 |
| Manufacturer | →  155 |
| Order code | →  155 |
| Extended order code 1 | →  155 |
| Extended order code 2 | →  155 |
| Extended order code 3 | →  155 |
| ENP version | →  155 |

Parameter overview with brief description

| Parameter | Description | User interface | Factory setting |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------|-----------------|
| Device tag | Shows name of measuring point. | Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /). | Teqwave M |
| Serial number | Shows the serial number of the measuring device. | Max. 11-digit character string comprising letters and numbers. | – |
| Firmware version | Shows the device firmware version installed. | Character string in the format xx.yy.zz | – |
| Device name | Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter. | Character string comprising numbers, letters and special characters | – |
| Manufacturer | Displays the manufacturer. | Character string comprising numbers, letters and special characters | Endress+Hauser |
| Order code | Shows the device order code. | Character string composed of letters, numbers and certain punctuation marks (e.g. /). | – |
| Extended order code 1 | Shows the 1st part of the extended order code. | Character string | – |
| Extended order code 2 | Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| Extended order code 3 | Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field. | Character string | – |
| ENP version | Shows the version of the electronic nameplate (ENP). | Character string | 2.02.00 |

12.14 Firmware history

| Release date | Firmware version | Order code for "Firmware version" | Firmware Changes | Documentation type | Documentation |
|--------------|------------------|-----------------------------------|-------------------|------------------------|----------------------|
| 03.2024 | 01.00.zz | Option 75 | Original firmware | Operating instructions | BA02321D/06/EN/03.24 |

-  It is possible to flash the firmware to the current version or the previous version using the service interface.
-  For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
-  The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 4W3B
The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance work

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the gaskets.

13.2 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as function checks at the place of manufacture, maintenance service or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and conversion of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ▶ Carry out the repair according to the Installation Instructions.
- ▶ Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document all repairs and conversions and enter the details in Netilion Analytics.

14.2 Spare parts

Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

-  Measuring device serial number:
 - Is located on the nameplate of the device.
 - Can be read out via the **Serial number** parameter (→  155) in the **Device information** submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

-  Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the web page for information:
<https://www.endress.com/support/return-material>
 - ↳ Select the region.
2. If returning the device, pack the device in such a way that it is reliably protected against impact and external influences. The original packaging offers the best protection.

14.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

⚠ WARNING

Danger to persons from process conditions!

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.
2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

⚠ WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ▶ Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

| Accessories | Description |
|--------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Proline 300 transmitter | <p>Transmitter for replacement Use the order code to define the following specifications:</p> <ul style="list-style-type: none"> ▪ Approvals ▪ Output ▪ Input ▪ Display/operation ▪ Housing ▪ Software <p> Order code: 4X3BXX</p> <p> Installation instructions EA01xxxD</p> |
| Remote display and operating module DKX001 | <p>Remote display and operating module DKX001</p> <p>If ordered directly with the device: Order code for "Display; operation", option O "Remote display 4-line, illuminated; 10 m (30 ft) cable; touch control"</p> <p>If the device is ordered separately: Order code for "Display; operation", option M "None, prepared for remote display"</p> <p>If the remote display and operating module is ordered separately: Via the separate product structure DKX001</p> <p>Mounting bracket for DKX001</p> <ul style="list-style-type: none"> ▪ If ordered directly: order code for "Accessory enclosed", option RA "Mounting bracket, pipe 1/2" ▪ If ordered subsequently: order number: 71340960 <p>Optional connecting cable available</p> <p>Cable lengths available for order:</p> <ul style="list-style-type: none"> ▪ If the remote display and operating module DKX001 is ordered together with the device: 10 m (35 ft) ▪ If the remote display and operating module is ordered separately: order code DKX001, option: <ul style="list-style-type: none"> ▪ A: 5 m (15 ft) ▪ B: 10 m (35 ft) ▪ D: 20 m (30 ft) ▪ E: 30 m (100 ft) <p> For further information on display and operating module DKX001, see Special Documentation SD01763D. →  188</p> |

| | |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| External WLAN antenna | <p>External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area". Further information on the WLAN interface →  68</p> <p> Order number: 71351317</p> <p> Installation Instructions EA01238D</p> |
| Weather protection cover | <p>Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.</p> <p> Order number: 71343505</p> <p> Installation Instructions EA01160D</p> |

15.1.2 For the sensor

| Accessories | Description |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mounting kit | <p>Consists of:</p> <ul style="list-style-type: none"> ▪ Screws/mounting bolts ▪ Gaskets ▪ Washers ▪ Nuts <p> Order number: DK4M</p> |

15.2 Communication-specific accessories

| Accessories | Description |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fieldgate FXA42 | <p>Transmission of the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices</p> <p> <ul style="list-style-type: none"> ▪ Technical Information TI01297S ▪ Operating Instructions BA01778S ▪ Product page: www.endress.com/fxa42 </p> |
| Field Xpert SMT50 | <p>The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.</p> <p>This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.</p> <p> <ul style="list-style-type: none"> ▪ Technical Information TI01342S ▪ Operating Instructions BA01709S ▪ Product page: www.endress.com/smt50 </p> |
| Field Xpert SMT70 | <p>The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.</p> <p>This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.</p> <p> <ul style="list-style-type: none"> ▪ Technical Information TI01342S ▪ Operating Instructions BA01709S ▪ Product page: www.endress.com/smt70 </p> |
| Field Xpert SMT77 | <p>The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.</p> <p> <ul style="list-style-type: none"> ▪ Technical Information TI01418S ▪ Operating Instructions BA01923S ▪ Product page: www.endress.com/smt77 </p> |

15.3 Service-specific accessories

| Accessories | Description |
|---------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Applicator | <p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> ▪ Choice of measuring devices for industrial requirements ▪ Graphic display of the calculation results ▪ Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. <p>Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator</p> |
| Netilion | <p>IIoT ecosystem: Unlock knowledge</p> <p>With the Netilion IIoT ecosystem, Endress+Hauser enables you to optimize your plant's performance, digitize workflows, share knowledge and improve collaboration.</p> <p>Drawing on decades of experience in process automation, Endress+Hauser offers process industries an IIoT ecosystem that provides customers with data-driven insights. These insights can be used to optimize processes, thus leading to higher plant availability, efficiency and reliability - and ultimately to greater profitability.</p> <p>www.netilion.endress.com</p> |
| FieldCare | <p>FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> Operating Instructions BA00027S and BA00059S</p> |
| DeviceCare | <p>Tool to connect and configure Endress+Hauser field devices.</p> <p> Innovation brochure IN01047S</p> |
| Retrofit kit for display/WLAN | <p>Retrofitting the device with a display with WLAN</p> <p>The retrofit kit contains all the necessary parts.</p> <p> <ul style="list-style-type: none"> ▪ Order number: DKZ001 ▪ You must state the serial number of the device to be converted when placing the order. </p> |
| Retrofit kit for inputs/outputs | <ul style="list-style-type: none"> ▪ For subsequent switching of the functionality of inputs/outputs 2 and 3 using a serial number-based license code ▪ For subsequent hardware expansion of empty slots for inputs/outputs 2 and 3 using a serial number-based license code and hardware <p> Order number: DKZ004</p> |

15.4 System components

| Accessories | Description |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Proline flowmeter Promag 400 | <p>To calculate the load rate, you need to know the volume flow of the medium. You can measure this value using a flowmeter, e.g. the Proline Promag W 400. The measured value can be read in as an input signal via the 4 to 20 mA current input from the Teqwave MW and used to calculate the load rate. The calculated load rate can be shown on the local display and output as an output signal.</p> <p> Technical Information Proline Promag W 400: TI01046D</p> <p> Order number Proline Promag W 400: 5W4C**-</p> |

16 Technical data

16.1 Application

The measuring device is suitable only for the measurement of solids in water-based liquids.

Depending on the version ordered, the measuring device can also measure potentially explosive media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

| | |
|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Measuring principle | <p>Microwave transmission</p> <p>Total solids measurement via microwave transmission: The device measures the time of flight and absorption of microwave transmission between two antennas facing each other in the measuring tube. Based on these variables, the permittivity of the medium can be calculated, for example.</p> <p>The temperature of the medium is determined in order to calculate the compensation factor due to temperature effects. This signal corresponds to the process temperature and is also available as an output signal.</p> <p>The conductivity of the medium is derived from the change in amplitude and phase of the microwave signal.</p> |
| Measuring system | <p>The device consists of a transmitter and a sensor.</p> <p>The device is available as a compact version: The transmitter and sensor form a mechanical unit.</p> <p>Information on the structure of the device →  13</p> |

16.3 Input

| | |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Measured variable | <p>Direct measured variables</p> <ul style="list-style-type: none"> ■ Total solids ■ Electrical conductivity ■ Medium temperature <p>Calculated measured variables</p> <p><i>Load rate</i></p> <p>The load rate can only be calculated with the volume flow of the medium. This measured value must be read in via a flowmeter →  164.</p> <p>Example of calculation:</p> <ul style="list-style-type: none"> ■ Volume flow read in by flowmeter: 100 l/min ■ Total solids measured by Teqwave MW 300 : 10 g/l <p>Calculated load rate: 1 kg/min</p> |
|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Measuring range

Total solids

0 to 500 g/l (0 to 31 lb/ft³), 0 to 50 %TS

Medium temperature

0 to 80 °C (32 to 176 °F)

Electrical conductivity

 To ensure correct measurement, the electrical conductivity of the medium must not exceed the measuring range of the temperature-compensated electrical conductivity.

Measuring range for temperature-compensated electrical conductivity at 25 °C (77 °F)

| Nominal diameter | | Electrical conductivity |
|------------------|------|-------------------------|
| [mm] | [in] | [mS/cm] |
| 50 | 2 | 0 to 100 |
| 80 | 3 | 0 to 85 |
| 100 | 4 | 0 to 50 |
| 150 | 6 | 0 to 20 |
| 200 | 8 | 0 to 14.5 |
| 250 | 10 | 0 to 14.5 |
| 300 | 12 | 0 to 14.5 |

Input signal

External measured values

To calculate the load rate, you need to know the volume flow of the medium. You can measure this value using a flowmeter, e.g. the Proline Promag W 400.

The volume flow can be read in as an input signal via the 4 to 20 mA current input from the Teqwave MW and used to calculate the load rate.

 The Proline W Promag 400 flowmeter can be ordered from Endress+Hauser →  162.

Current input

Measured variables can be transferred from the automation system to the device via the current input →  164.

Digital communication

Measured variables can be transferred from the automation system to the device via the Modbus RS485.

Current input 4 to 20 mA

| | |
|------------------------------|-----------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option I: 4 to 20 mA input |
| Current input | 0/4 to 20 mA (active/passive) |
| Current range | <ul style="list-style-type: none"> ■ 4 to 20 mA (active) ■ 0/4 to 20 mA (passive) |
| Resolution | 1 µA |
| Voltage drop | Typically: 0.6 to 2 V for 3.6 to 22 mA (passive) |
| Maximum input voltage | ≤ 30 V (passive) |

| | |
|---------------------------------|---------------------------------------------------------|
| Open-circuit voltage | ≤ 28.8 V (active) |
| Possible input variables | Volume flow of the medium for calculating the load rate |

Status input

| | |
|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option J: status input |
| Maximum input values | <ul style="list-style-type: none"> ▪ DC -3 to 30 V ▪ If status input is active (ON): $R_i > 3 \text{ k}\Omega$ |
| Response time | Configurable: 5 to 200 ms |
| Input signal level | <ul style="list-style-type: none"> ▪ Low signal (low): DC -3 to +5 V ▪ High signal (high): DC 12 to 30 V |
| Assignable functions | <ul style="list-style-type: none"> ▪ Disable ▪ Flow override ▪ Reset totalizer (load rate) |

16.4 Output

Output signal

Modbus RS485

| | |
|----------------------|-----------------------------------------------------|
| Order code | "Output; input 1" (020): Option MA: Modbus RS485 |
| Physical interface | RS485 in accordance with EIA/TIA-485 standard |
| Terminating resistor | Integrated, can be activated via DIP switches |

Current output 4 to 20 mA

| | |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option B: current output 4 to 20 mA |
| Signal mode | Can be set to: <ul style="list-style-type: none"> ■ Active ■ Passive |
| Current range | Can be set to: <ul style="list-style-type: none"> ■ 4 to 20 mA NAMUR ■ 4 to 20 mA US ■ 4 to 20 mA ■ 0 to 20 mA (only if the signal mode is active) ■ Fixed current |
| Maximum output values | 22.5 mA |
| Open-circuit voltage | DC 28.8 V (active) |
| Maximum input voltage | DC 30 V (passive) |
| Load | 0 to 700 Ω |
| Resolution | 0.38 μA |
| Damping | Configurable: 0 to 999.9 s |
| Assignable process variables | <ul style="list-style-type: none"> ■ Total solids ■ Conductivity ■ Temperature ■ Electronics temperature ■ Load rate |

Pulse/frequency/switch output

| | |
|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option E: Pulse/frequency/switch output |
| Function | Can be configured as pulse, frequency or switch output |
| Version | Open collector Can be set to: <ul style="list-style-type: none"> ■ Active ■ Passive ■ Passive NAMUR |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Open-circuit voltage | DC 28.8 V (active) |
| Voltage drop | For 22.5 mA: ≤ DC 2 V |
| Pulse output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Maximum output current | 22.5 mA (active) |
| Open-circuit voltage | DC 28.8 V (active) |

| | |
|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pulse width | Configurable: 0.05 to 2 000 ms |
| Maximum pulse rate | 10 000 Impulse/s |
| Pulse value | Configurable |
| Assignable process variables | Totalizer (load rate) |
| Frequency output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Maximum output current | 22.5 mA (active) |
| Open-circuit voltage | DC 28.8 V (active) |
| Output frequency | Configurable: end value frequency 2 to 10 000 Hz ($f_{\max} = 12\,500$ Hz) |
| Damping | Configurable: 0 to 999.9 s |
| Pulse/pause ratio | 1:1 |
| Assignable process variables | <ul style="list-style-type: none"> ▪ Total solids ▪ Conductivity ▪ Temperature ▪ Electronics temperature ▪ Load rate |
| Switch output | |
| Maximum input values | DC 30 V, 250 mA (passive) |
| Open-circuit voltage | DC 28.8 V (active) |
| Switching behavior | Binary, conductive or non-conductive |
| Switching delay | Configurable: 0 to 100 s |
| Number of switching cycles | Unlimited |
| Assignable functions | <ul style="list-style-type: none"> ▪ Disable ▪ On ▪ Diagnostic behavior ▪ Limit value: <ul style="list-style-type: none"> ▪ Total solids ▪ Conductivity ▪ Temperature ▪ Electronics temperature ▪ Partially filled pipe ▪ Totalizer (load rate) ▪ Load rate |

Relay output

| | |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option H: relay output |
| Function | Switch output |
| Version | Relay output, galvanically isolated |
| Switching behavior | Can be set to: <ul style="list-style-type: none"> ▪ NO (normally open), factory setting ▪ NC (normally closed) |

| | |
|---------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Maximum switching capacity (passive) | <ul style="list-style-type: none"> ▪ DC 30 V, 0.1 A ▪ AC 30 V, 0.5 A |
| Assignable functions | <ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diagnostic behavior ▪ Limit value: <ul style="list-style-type: none"> ▪ Total solids ▪ Conductivity ▪ Temperature ▪ Partially filled pipe ▪ Totalizer (load rate) ▪ Load rate |

User-configurable input/output

| | |
|---------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Order code | "Output; input 2" (021) or "Output; input 3" (022): Option D: user-configurable input/output |
| Function | One specific input or output can be assigned to the user-configurable input/output (configurable I/O) when commissioning the device. |
| Possible assignment | <ul style="list-style-type: none"> ▪ Current output 4 to 20 mA ▪ Pulse/frequency/switch output ▪ Current input 0/4 to 20 mA ▪ Status input |
| Technical values of the inputs and outputs | Correspond to the inputs and outputs described in this section |

Signal on alarm

Modbus RS485

| | |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------|
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ NaN value instead of current value ▪ Last valid value |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------|

Current output 0/4 to 20 mA

4 to 20 mA

| | |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ 4 to 20 mA in accordance with NAMUR recommendation NE 43 ▪ 4 to 20 mA in accordance with US ▪ Min. value: 3.59 mA ▪ Max. value: 22.5 mA ▪ Definable value between: 3.59 to 22.5 mA ▪ Actual value ▪ Last valid value |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

0 to 20 mA

| | |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ Maximum alarm: 22 mA ▪ Definable value between: 0 to 20.5 mA |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------|

Pulse/frequency/switch output

| | |
|-------------------------|----------------------------------------------------------------------------------------------------|
| Pulse output | |
| Fault mode | Choose from: <ul style="list-style-type: none"> ▪ Actual value ▪ No pulses |
| Frequency output | |

| | |
|----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| Fault mode | Choose from: <ul style="list-style-type: none"> ▪ Actual value ▪ 0 Hz ▪ Definable value between: 2 to 12 500 Hz |
| Switch output | |
| Fault mode | Choose from: <ul style="list-style-type: none"> ▪ Current status ▪ Open ▪ Closed |

Relay output

| | |
|---------------------|-------------------------------------------------------------------------------------------------------------------|
| Failure mode | Choose from: <ul style="list-style-type: none"> ▪ Current status ▪ Open ▪ Closed |
|---------------------|-------------------------------------------------------------------------------------------------------------------|

Local display

| | |
|---------------------------|-------------------------------------------------|
| Plain text display | With information on cause and remedial measures |
| Backlight | Red lighting indicates a device error. |

 Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication:
 - Modbus RS485
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

| | |
|---------------------------|-------------------------------------------------|
| Plain text display | With information on cause and remedial measures |
|---------------------------|-------------------------------------------------|

Web browser

| | |
|---------------------------|-------------------------------------------------|
| Plain text display | With information on cause and remedial measures |
|---------------------------|-------------------------------------------------|

Light emitting diodes (LED)

| | |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status information | Status indicated by various light emitting diodes The following information is displayed depending on the device version: <ul style="list-style-type: none"> ▪ Supply voltage active ▪ Data transmission active ▪ Device alarm/error has occurred  Diagnostic information via light emitting diodes →  137 |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Load

Output signal →  166

Ex connection data

Safety-related values

Order code for "Output; input 1"

| Option | Output/input type | Safety-related values for output/input 1 | |
|--------|-------------------|------------------------------------------|--------|
| | | 26 (+) | 27 (-) |
| MA | Modbus RS485 | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | |

Order code for "Output; input 2" and "Output; input 3"

| Option | Output/input type | Safety-related values for output/input | | | |
|--------|--------------------------------|------------------------------------------------------------------------------|--------|--------|--------|
| | | 2 | | 3 | |
| | | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| B | Current output 4 to 20 mA | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | | |
| D | User-configurable input/output | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | | |
| E | Pulse/frequency/switch output | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | | |
| H | Relay output | $U_N = 30 V_{DC}$ $I_N = 100 mA_{DC} / 500 mA_{AC}$ $U_M = 250 V_{AC}$ | | | |
| I | Current input 0/4 to 20 mA | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | | |
| J | Status input | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | | |

Galvanic isolation

The outputs are galvanically isolated from one another and from earth (PE).

Protocol-specific data

protocol-specific data

| | |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Protocol | Modbus Applications Protocol Specification V1.1 |
| Response times | <ul style="list-style-type: none"> ▪ Direct data access: typically 25 to 50 ms ▪ Auto-scan buffer (data range): typically 3 to 5 ms |
| Device type | Slave |
| Slave address range | 1 to 247 |
| Broadcast address range | 0 |
| Function codes | <ul style="list-style-type: none"> ▪ 03: Read holding register ▪ 04: Read input register ▪ 06: Write single registers ▪ 08: Diagnostics ▪ 16: Write multiple registers ▪ 23: Read/write multiple registers |
| Broadcast messages | Supported by the following function codes: <ul style="list-style-type: none"> ▪ 06: Write single registers ▪ 16: Write multiple registers ▪ 23: Read/write multiple registers |

| | |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Supported baud rates | <ul style="list-style-type: none"> ▪ 1 200 BAUD ▪ 2 400 BAUD ▪ 4 800 BAUD ▪ 9 600 BAUD ▪ 19 200 BAUD ▪ 38 400 BAUD ▪ 57 600 BAUD ▪ 115 200 BAUD |
| Data transmission mode | <ul style="list-style-type: none"> ▪ ASCII ▪ RTU |
| Data access | <p>Each device parameter can be accessed via Modbus RS485.</p> <p> For Modbus register information, see the description of device parameters →  188.</p> |
| System integration | <p>Information regarding system integration →  72.</p> <ul style="list-style-type: none"> ▪ Modbus RS485 information ▪ Function codes ▪ Register information ▪ Response time ▪ Modbus data map |

16.5 Power supply

Terminal assignment →  35

Available device plugs

 Device plugs may not be used in hazardous areas!

Device plug for connecting to the service interface:

Order code for "Accessory mounted"

Option **NB**, RJ45 M12 adapter (service interface) →  172

Order code for "Accessory mounted", option NB "Adapter RJ45 M12 (service interface)"

| Order code "Accessory mounted" | Cable entry/coupling | |
|-----------------------------------|----------------------|------------------|
| | Cable entry 2 | Cable entry 3 |
| NB | Plug M12 × 1 | - |

Supply voltage

| Order code "Power supply" | Terminal voltage | | Frequency range |
|------------------------------|------------------|------------|-----------------|
| | DC 24 V | ±20% | |
| Option I | DC 24 V | ±20% | - |
| | AC 100 to 240 V | -15...+10% | 50/60 Hz |

Power consumption

Transmitter

Max. 10 W (active power)

| | |
|--------------------------|-----------------------------------------------------|
| switch-on current | Max. 36 A (<5 ms) as per NAMUR Recommendation NE 21 |
|--------------------------|-----------------------------------------------------|

Current consumption

Transmitter

- Max. 400 mA (24 V)
- Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)

Power supply failure

- Totalizer stops at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Overcurrent protection element

The device must be operated with a dedicated circuit breaker, as it does not have an ON/OFF switch of its own.

- The circuit breaker must be easy to reach and labeled accordingly.
- Permitted nominal current of the circuit breaker: 2 A up to maximum 10 A.

Electrical connection → 33

Potential equalization

Requirements

- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Connect the medium and transmitter to the same electrical potential.
- Use a ground cable with a minimum cross-section of 6 mm² (0.0093 in²) and a cable lug for potential equalization connections

Terminals

Spring-loaded terminals: Suitable for strands and strands with ferrules.
Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Cable entries

- Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
 - NPT ½"
 - G ½"
 - M20

Optional: M12 device plug for connection to the service interface
Order code for "Accessories mounted", option NB: "Adapter RJ45 M12 (service interface)" → 172

Pin assignment, device plug

Service interface for pin assignment, device plug
Order code for "Accessories mounted", option **NB**: Adapter RJ45 M12 (service interface)

| | Pin | Assignment | |
|--------|-----|-------------|----|
| | 1 | + | Tx |
| | 2 | + | Rx |
| | 3 | - | Tx |
| | 4 | - | Rx |
| Coding | | Plug/socket | |
| D | | Socket | |

Cable specification → 33

| | | |
|------------------------|-----------------------------------|-------------------------|
| Overvoltage protection | Mains voltage fluctuations | → 171 |
| | Overvoltage category | Overvoltage category II |

| | |
|------------------------------------------|-----------------------------------------------------|
| Short-term, temporary overvoltage | Between cable and ground up to 1200 V, for max. 5 s |
| Long-term, temporary overvoltage | Between cable and ground up to 500 V |

16.6 Performance characteristics

Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

| | |
|-----------------|-------|
| Accuracy | ±5 µA |
|-----------------|-------|

Pulse/frequency output

| | |
|-----------------|--------------------------------------------------------------------------------|
| Accuracy | Max. ±50 ppm of the measured value (over the entire ambient temperature range) |
|-----------------|--------------------------------------------------------------------------------|

Repeatability


Total solids

| Nominal diameter | | Standard deviation of total solids [%TS] |
|------------------|---------|---------------------------------------------|
| [mm] | [in] | |
| 50 to 80 | 2 to 3 | 0.02 |
| 100 to 300 | 4 to 12 | 0.01 |

Medium temperature

± 0.5 °C (± 0.9 °F)

Electrical conductivity



30 Repeatability in % of measured value - electrical conductivity [µS/cm]

A0052544

Influence of ambient temperature

Current output

| | |
|--------------------------------|--------------|
| Temperature coefficient | Max. 1 µA/°C |
|--------------------------------|--------------|

Pulse/frequency output

| | |
|-------------------------|-----------------------|
| Temperature coefficient | No additional effect. |
|-------------------------|-----------------------|

16.7 Mounting

Mounting requirements →  21

16.8 Environment

| | |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ambient temperature range | <p>Transmitter and sensor -20 to +60 °C (-4 to +140 °F)</p> <p> Readability of the display may be impaired at temperatures outside the temperature range.</p> <p>If operating the device outdoors:</p> <ul style="list-style-type: none"> ▪ Install the measuring device in a shady location. ▪ Avoid direct sunlight, particularly in warm climatic regions. ▪ Avoid direct exposure to weather conditions. ▪ Protect the display against impact. ▪ Protect the display from abrasion, e.g. caused by sand in desert areas. <p> A weather protection cover is available as an accessory. →  160</p> |
| Storage temperature | <p>-20 to +60 °C (-4 to +140 °F)</p> <ul style="list-style-type: none"> ▪ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures. ▪ Select a storage location where moisture cannot collect in the measuring device. |
| Relative humidity | The device is suitable for use in outdoor and indoor areas with a relative humidity of 4 to 95%. |
| Operating height | <p>According to EN 61010-1</p> <ul style="list-style-type: none"> ▪ ≤ 2 000 m (6 562 ft) ▪ > 2 000 m (6 562 ft) with additional overvoltage protection (e.g. Endress+Hauser HAW Series) |
| Degree of protection | <p>Measuring device</p> <ul style="list-style-type: none"> ▪ IP66/67, Type 4X enclosure, suitable for pollution degree 4 ▪ When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2 ▪ Display module: IP20, Type 1 enclosure, suitable for pollution degree 2 <p>External WLAN antenna</p> <p>IP67</p> |

| | |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Vibration and shock resistance | <ul style="list-style-type: none"> ■ Sinusoidal vibration according to IEC 60068-2-6 <ul style="list-style-type: none"> ■ 2 to 8.4 Hz, 3.5 mm peak ■ 8.4 to 2 000 Hz, 1 g peak ■ Broadband random vibration according to IEC 60068-2-64 <ul style="list-style-type: none"> ■ 10 to 200 Hz, 0.003 g²/Hz ■ 200 to 2 000 Hz, 0.001 g²/Hz ■ Total: 1.54 g rms ■ Half-sine shocks according to IEC 60068-2-27 6 ms 30 g ■ Rough handling shocks according to IEC 60068-2-31 |
|--------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mechanical load | <p>Transmitter housing:</p> <ul style="list-style-type: none"> ■ Protect against mechanical effects, such as shock or impact. ■ Do not use as a ladder or climbing aid. |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|-------------------------------------|---------------------|
| Electromagnetic compatibility (EMC) | As per IEC/EN 61326 |
|-------------------------------------|---------------------|

16.9 Process

| | |
|--------------------------|------------------------------|
| Medium temperature range | 0 to +80 °C (+32 to +176 °F) |
|--------------------------|------------------------------|

| | |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Electrical conductivity |  To ensure correct measurement, the electrical conductivity of the medium must not exceed the measuring range of the temperature-compensated electrical conductivity. |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Measuring range for temperature-compensated electrical conductivity at 25 °C (77 °F)

| Nominal diameter | | Electrical conductivity |
|------------------|------|-------------------------|
| [mm] | [in] | [mS/cm] |
| 50 | 2 | 0 to 100 |
| 80 | 3 | 0 to 85 |
| 100 | 4 | 0 to 50 |
| 150 | 6 | 0 to 20 |
| 200 | 8 | 0 to 14.5 |
| 250 | 10 | 0 to 14.5 |
| 300 | 12 | 0 to 14.5 |

| | |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pressure/temperature ratings |  For an overview of the pressure-temperature ratings for the process connections, see the Technical Information. →  187 |
|------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flow velocity | If there is a risk of deposits building up in the measuring tube, as a result of grease for example, a flow velocity of >2 m/s (6.5 ft/s) is recommended. |
|---------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|

| | |
|--------------------|------------------------------------------------------------------------------------------|
| Thermal insulation | →  25 |
|--------------------|------------------------------------------------------------------------------------------|

| | |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Static pressure | <p>≥ 1.5 bar (21.8 psi), to avoid outgassing of the medium</p>  Installation near pumps →  22 |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Vibrations

Information on the measuring system's resistance to vibration and shock →  175

16.10 Mechanical construction

Design, dimensions

 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .→  187

Weight

All values: weight without packaging material

Device

| Nominal diameter | | Weight |
|------------------|------|-------------------|
| [mm] | [in] | |
| 50 | 2 | 10.6 kg (23.4 lb) |
| 80 | 3 | 10.9 kg (24.0 lb) |
| 100 | 5 | 12.6 kg (27.7 lb) |
| 150 | 6 | 17.1 kg (37.8 lb) |
| 200 | 8 | 23.9 kg (52.7 lb) |
| 250 | 10 | 32.8 kg (72.3 lb) |
| 300 | 12 | 37.8 kg (83.4 lb) |

Materials

Transmitter

Housing

Order code for "Transmitter housing":


Option A "Aluminum coated": aluminum, AlSi10Mg, coated

Window material

Order code for "Transmitter housing":

Option A "Aluminum, coated": glass

Cable entries/cable glands



A0028352

 31 Possible cable entries/cable glands

1 Female thread M20 × 1.5

2 Cable gland M20 × 1.5

3 Adapter for cable entry with female thread G ½" or NPT ½"

4 Device plug

| Cable entry/cable gland | Material |
|---------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Compression fitting M20 × 1.5 | Order code for "Housing", option A "Aluminum, coated": <ul style="list-style-type: none"> ▪ Non-Ex: plastic ▪ Z2, D2, Ex d/de: brass with plastic |
| | Order code for "Housing", option L "Casting, stainless": Stainless steel, 1.4404 (316L) |
| Adapter for cable entry with female thread G ½" | Nickel-plated brass |
| Adapter for cable entry with female thread NPT ½" | |

Device plug

| Electrical connection | Material |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Plug M12x1 | <ul style="list-style-type: none"> ▪ Socket: Stainless steel, 1.4404 (316L) ▪ Contact housing: Polyamide ▪ Contacts: Gold-plated brass |

Measuring pipe

Stainless steel: 1.4408 as per DIN EN 10213 (CF3M as per ASME A351)

Antennas

- Parts in contact with medium: ceramic
- Antenna bracket: stainless steel: 1.4435 (316L)

Temperature sensor

Stainless steel: 1.4435 (316L)

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylonitrile styrene acrylate) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Mounting kit

For installing the sensor

- Screws/mounting bolts, nuts and washers: stainless steel, 1.4301/304, 1.4306/1.4307
- Gaskets: aramid fibers, with NBR binder

Remote display and operating module DKX001

Housing material: AlSi10Mg, coated

16.11 Display and user interface

Operation concept

Operator-oriented menu structure for user-specific tasks

- Commissioning
- Operation
- Diagnosis
- Expert level

Quick and safe commissioning

- Guided menus ("Make-it-run" wizards) for applications
- Menu guidance with brief descriptions of the individual parameter functions
- Access to the device via web server
- WLAN access to the device via mobile handheld terminal, tablet or smart phone

Reliable operation

- Operation in local language
- Uniform operating philosophy applied to device and operating tools
- Guided menus (wizards) for adjusting the device using medium samples
- If replacing electronic modules, transfer the device configuration via the integrated memory (HistoROM backup) which contains the process and measuring device data and the event logbook. No need to reconfigure.

Efficient diagnostics increase measurement reliability

- Troubleshooting measures can be called up via the device and in the operating tools
- Diverse simulation options, logbook for events that occur and optional line recorder functions

Languages

Can be operated in the following languages:

- Via local operation
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Czech, Swedish
- Via web browser
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese


Local operation

Via display module

Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"

 Information about WLAN interface →  68



A0026785

 32 Operation with touch control

Display elements


- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured

Operating elements

External operation via touch control (3 optical keys) without opening the housing: , , 

Via remote display and operating module DKX001

-  The remote display and operating module DKX001 is available as an optional extra .
- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



A0026786


 33 Operation via remote display and operating module DKX001

| | |
|--------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Display and operating elements | The display and operating elements correspond to those of the display module . |
| Housing material | →  177 |
| Cable entry | Corresponds to the selection of the transmitter housing, order code for "Electrical connection" |
| Connecting cable | |
| Dimensions |  Information on the dimensions: "Mechanical construction" section of the "Technical Information" document. |

Remote operation

Via Modbus RS485 protocol

This communication interface is available in device versions with a Modbus RS485 output.



A0029437

34 Options for remote operation via Modbus RS485 protocol (active)

- 1 Control system (e.g. PLC)
- 2 Computer with web browser (e.g. Microsoft Edge) to access the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 3 Transmitter


Service interface

Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

i An adapter for the RJ45 to the M12 plug is optionally available:
Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 plug mounted in the cable entry. The connection to the service interface can be established via an M12 plug without opening the device.




A0027563

35 Connection via service interface (CDI-RJ45)

- 1 Computer with web browser (e.g. Microsoft Edge) for accessing integrated web server or with "FieldCare" operating tool, "DeviceCare" with COM DTM "CDI Communication TCP/IP" or Modbus DTM
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version:
Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A0052607

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and web browser (e.g. Microsoft Edge) for accessing the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Field Xpert SFX350 or SFX370
- 7 Field Xpert SMT70
- 8 Smartphone or tablet with WLAN interface and web browser (e.g. Microsoft Edge) for accessing the integrated device web server or with operating tool (e.g. FieldCare, DeviceCare)

| | |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Function | WLAN: IEEE 802.11 b/g (2.4 GHz) <ul style="list-style-type: none"> ▪ Access point with DHCP server (factory setting) ▪ Network |
| Encryption | WPA2-PSK AES-128 (in accordance with IEEE 802.11i) |
| Configurable WLAN channels | 1 to 11 |
| Degree of protection | IP67 |
| Available antennas | <ul style="list-style-type: none"> ▪ Internal antenna ▪ External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Available as an accessory .  Only one antenna active in each case! |
| Range | <ul style="list-style-type: none"> ▪ Internal antenna: typically 10 m (32 ft) ▪ External antenna: typically 50 m (164 ft) |
| Materials (external antenna) | <ul style="list-style-type: none"> ▪ Antenna: ASA plastic (acrylonitrile-styrene-acrylic ester) and nickel-plated brass ▪ Adapter: Stainless steel and nickel-plated brass ▪ Cable: Polyethylene ▪ Plug: Nickel-plated brass ▪ Angle bracket: Stainless steel |

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

- ▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE**Note the following to avoid a network conflict:**

- ▶ Avoid accessing the measuring device simultaneously from the same mobile terminal via the service interface (CDI-RJ45) and the WLAN interface.
- ▶ Only activate one service interface (CDI-RJ45 or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- ▶ Enable WLAN on the mobile terminal.

Establishing a WLAN connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH__300_A802000).
2. If necessary, select the WPA2 encryption method.
3. Enter the password:
Serial number of the measuring device ex-works (e.g. L100A802000).
 - ↳ The LED on the display module flashes. It is now possible to operate the measuring device with the web browser, FieldCare or DeviceCare.

 The serial number can be found on the nameplate.

 To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Terminating the WLAN connection

- ▶ After configuring the device:
Terminate the WLAN connection between the mobile terminal and measuring device.

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

| Supported operating tools | Operating unit | Interface | Additional information |
|---------------------------|------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Web browser | Notebook, PC or tablet with web browser | <ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface | Special Documentation for the device →  188 |
| DeviceCare SFE100 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface ■ Fieldbus protocol | Service-specific accessories →  162 Sources for obtaining device descriptions www.endress.com → Download-Area |
| FieldCare SFE500 | Notebook, PC or tablet with Microsoft Windows system | <ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface ■ Fieldbus protocol | Service-specific accessories →  162 Sources for obtaining device descriptions www.endress.com → Download-Area |



Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com

The related device description files are available: www.endress.com → Download Area

Web server

With the integrated web server, the device can be operated and configured via a web browser service interface (CDI-RJ45) or WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is displayed and can be used to monitor device health. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook, for example,) and measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification report (PDF file, only available with the **Heartbeat Verification** application package)
- Flash firmware version for device firmware upgrade, for example
- Download driver for system integration
- Visualize up to 1000 saved measured values (only available with the **Extended HistoROM** application package)

HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.

 When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

| | HistoROM backup | T-DAT | S-DAT |
|-------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Available data | <ul style="list-style-type: none"> ▪ Event logbook, e.g. diagnostic events ▪ Parameter data record backup ▪ Device firmware package | <ul style="list-style-type: none"> ▪ Measured value logging ("Extended HistoROM" order option) ▪ Current parameter data record (used by firmware at run time) ▪ Indicator (minimum/maximum values) ▪ Totalizer value | <ul style="list-style-type: none"> ▪ Sensor data: e.g. nominal diameter ▪ Serial number ▪ Device configuration (e.g. SW options, fixed I/O or multi I/O) |
| Storage location | Fixed on the user interface PC board in the connection compartment | Can be plugged into the user interface PC board in the connection compartment | In the sensor plug in the transmitter neck part |

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
Backup and subsequent restoration of a device configuration in the device memory HistoROM backup
- Data comparison function
Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transmission

Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

Event list**Automatic**

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging**Manual**

If the **Extended HistoROM** application package (order option) is enabled:

- Recording of 1 to 4 channels of up to 1 000 measured values (up to 250 measured values per channel)
- User configurable recording interval
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Current certificates and approvals for the product are available at www.endress.com on the relevant product page:

1. Select the product using the filters and search field.
2. Open the product page.
3. Select **Downloads**.

| | |
|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CE mark | The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark. |
| UKCA marking | The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark. Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com |
| RCM marking | The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)". |
| Ex-approval | The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate. |
| Modbus RS485 certification | The measuring device meets all the requirements of the MODBUS RS485 conformity test and has the "MODBUS RS485 Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out. |

| | |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Radio approval</p> | <p>The measuring device has radio approval.</p> <p> For detailed information on the radio approval, see the Special Documentation →  188</p> |
| <p>Pressure Equipment Directive</p> | <p>Devices with pressure measuring device approval (Pressure Equipment Directive, PED Cat. I/II/III) are optionally available: order code for "Additional approval", option LK</p> |
| <p>Additional certification</p> | <p>Canadian Registration Number (CRN) approval</p> <p>Devices with Canadian Registration Number (CRN) approval are optionally available: order code for "Additional approval", option LD.</p> <p>Tests and certificates</p> <ul style="list-style-type: none"> ■ EN10204-3.1 Material certificate, wetted parts and sensor housing ■ Pressure test, internal procedure, inspection certificate ■ EN10204-2.1 Confirmation of compliance with the order and EN10204-2.2 test report |
| <p>Other standards and guidelines</p> | <ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosures (IP code) ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements ■ EN 61326-1/-2-3 EMC requirements for electrical equipment for measurement, control and laboratory use ■ ETSI EN 301 489-1/-17 Guidelines for 2.4 GHz radio components ■ IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibration (sinusoidal) ■ IEC/EN 60068-2-27 Environmental influences: Test procedure - Test Ea: shocks ■ IEC/EN 60068-2-64 Environmental influences: Test Fh: vibration, broadband random (digital control) ■ IEC/EN 60068-2-31 Environmental influences: Test procedure - Test Ec: rough handling shocks, primarily for devices ■ NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics ■ NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices ■ NAMUR NE 107 Self-monitoring and diagnosis of field devices ■ NAMUR NE 131 Requirements for field devices for standard applications |

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Diagnostic functionality Order code for "Application package", option EA "Extended HistoROM"

Comprises extended functions concerning the event log and the activation of the measured value memory.

Event log:
Memory volume is extended from 20 message entries (standard version) to up to 100 entries.

Data logging (line recorder):

- Memory capacity for up to 1000 measured values is activated.
- 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.
- Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.

 The application package can also be ordered subsequently: order number DK4009.

Heartbeat Technology Order code for "Application package", option EB "Heartbeat Verification"

Heartbeat Verification
Meets the requirement for traceable verification in accordance with DIN ISO 9001:2008 Clause 7.6 a) "Control of monitoring and measuring equipment"

- Functional testing in the installed state without interrupting the process.
- Traceable verification results on request, including a report
- Simple testing process via local operation or other operating interfaces.
- Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.

 For detailed information, see the Special Documentation for the device →  188

 The application package can also be ordered subsequently: order number DK4009.

16.14 Supplemental documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation **Technical information**

| Device | Documentation code |
|------------------------|--------------------|
| Proline Teqwave MW 300 | TI01763D |

Brief Operating Instructions

Brief Operating Instructions for the sensor

| Sensor | Documentation code |
|--------------------|--------------------|
| Proline Teqwave MW | KA01671D |

Brief Operating Instructions for the transmitter

| Transmitter | Documentation code |
|--------------------------|--------------------|
| Proline 300 Modbus RS485 | KA01311D |

Description of device parameters

| Device | Documentation code |
|------------------------------------|--------------------|
| Proline Teqwave M 300 Modbus RS485 | GP01212D |

Supplementary device-dependent documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.

| Contents | Documentation code |
|--------------------------------------------|--------------------|
| ATEX: II3G, IECEx: Zone 2 | XA03186D |
| cCSAus: Class I Zone 2, Class I Division 2 | XA03188D |

Special documentation

| Contents | Documentation code |
|-----------------------------------------------------------------|--------------------|
| Information on the Pressure Equipment Directive | SD01614D |
| Radio approvals for WLAN interface for A309/A310 display module | SD01793D |
| Heartbeat Verification application package | SD03169D |
| Remote display and operating module DKX001 | SD01763D |

Installation instructions

| Contents | Note |
|---------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Installation instructions for spare part sets and accessories | <ul style="list-style-type: none"> ▪ Call up an overview of all available spare part sets available using <i>Device Viewer</i>: www.endress.com/deviceviewer ▪ Accessories available for order with Installation Instructions →  160 |

Index

A

- Access authorization to parameters
 - Read access 59
 - Write access 59
- Access code 59
 - Incorrect input 59
- Accessories 160
- Adapting the diagnostic behavior 144
- Additional certification
 - Canadian Registration Number (CRN) 186
- Ambient conditions
 - Ambient temperature 174
 - Mechanical load 175
 - Operating height 174
 - Relative humidity 174
 - Storage temperature 174
 - Vibration and shock resistance 175
- Ambient temperature
 - Influence 173
- Ambient temperature range 174
- Application 163
- Applicator 162
- Approvals 185
- Auto scan buffer
 - see Modbus RS485 Modbus data map

C

- Cable entries
 - Technical data 172
- Cable entry
 - Degree of protection 45
- Cable specification 172
- CE mark 10, 185
- Certificates 185
- Checklist
 - Post-connection check 46
 - Post-mounting check 32
- Cleaning
 - Exterior cleaning 157
- Commissioning 79
 - Adjusting the measured value based on the reference value 99
 - Advanced settings 100
 - Basic settings for the adjustment 99
 - Configuring the measuring device 80
- Configuring error response mode, Modbus RS485 143
- Connecting cable 34
- Connecting the measuring device 36
- Connecting the signal cables 36
- Connecting the supply voltage cables 36
- Connection
 - see Electrical connection
- Connection cable 33
- Connection preparations 36
- Connection tools 33

Context menu

- Calling up 56
- Closing 56
- Explanation 56
- Current consumption 171

D

- Date of manufacture 16, 17
- Declaration of Conformity 10
- Defining the access code 116
- Degree of protection 45, 174
- Design
 - Measuring device 13
 - Operating menu 48
- Device components 13
- Device description files 72, 73
- Device locking, status 119
- Device name
 - Sensor 17
 - Transmitter 16
- Device repair 158
- Device type code 72
- Device Viewer 15, 158
- Device-specific accessories 160
- DeviceCare 71, 162
 - Device description file 73
- Diagnosis
 - Symbols 138
- Diagnostic behavior
 - Explanation 139
 - Symbols 139
- Diagnostic information
 - Communication interface 143
 - Design, description 139, 142
 - DeviceCare 142
 - FieldCare 142
 - LEDs 137
 - Local display 138
 - Overview 145
 - Remedial measures 145
 - Web browser 141
- Diagnostic message 138
- Diagnostics list 149
- Dimensions 24
- DIP switch
 - see Write protection switch
- Disabling write protection 116
- Display
 - see Local display
- Display and operating module DKX001 179
- Display area
 - For operational display 50
 - In the navigation view 52
- Display values
 - For locking status 119
- Displaying the measured value history 127

| | |
|-------------------------------------------------|----------|
| Disposal | 159 |
| Document | |
| Function | 6 |
| Symbols | 6 |
| Document function | 6 |
| E | |
| Editing view | 54 |
| Input screen | 55 |
| Using operating elements | 54, 55 |
| Electrical conductivity | 164, 175 |
| Electrical connection | |
| Computer with web browser (e.g. Microsoft Edge) | |
| | 67, 179 |
| Degree of protection | 45 |
| Measuring device | 33, 172 |
| Operating tool (e.g. FieldCare, DeviceCare, AMS | |
| Device Manager, SIMATIC PDM) | 67, 179 |
| Operating tools | |
| Via Modbus RS485 protocol | 67, 179 |
| Via service interface (CDI-RJ45) | 68, 180 |
| Via WLAN interface | 68, 180 |
| Web server | 68, 180 |
| WLAN interface | 68, 180 |
| Electromagnetic compatibility | 175 |
| Electronics module | 13 |
| Enabling write protection | 116 |
| Enabling/disabling the keypad lock | 60 |
| Endress+Hauser services | |
| Maintenance | 157 |
| Repair | 158 |
| Error messages | |
| see Diagnostic messages | |
| Event logbook | 151 |
| Events list | 151 |
| Ex connection data | 170 |
| Ex-approval | 185 |
| Extended order code | |
| Sensor | 17 |
| Transmitter | 16 |
| Exterior cleaning | 157 |
| F | |
| Field of application | |
| Residual risks | 10 |
| FieldCare | 70, 162 |
| Device description file | 73 |
| Establishing a connection | 70 |
| Function | 70 |
| User interface | 71 |
| Filtering the event logbook | 151 |
| Firmware | |
| Release date | 72 |
| Version | 72 |
| Firmware history | 156 |
| Flow direction | 23 |
| Flow limit | 175 |
| Function codes | 74 |

| | |
|--------------------------------------------------|-----|
| Functions | |
| see Parameter | |
| G | |
| Galvanic isolation | 170 |
| H | |
| Hardware write protection | 117 |
| Help text | |
| Calling up | 58 |
| Closing | 58 |
| Explanation | 58 |
| HistoROM | 109 |
| I | |
| Identifying the measuring device | 15 |
| Incoming acceptance | 14 |
| Indication | |
| Current diagnostic event | 149 |
| Previous diagnostic event | 149 |
| Influence | |
| Ambient temperature | 173 |
| Information about this document | 6 |
| Inlet runs | 24 |
| Input | 163 |
| Inspection | |
| Connection | 46 |
| Mounting procedure | 32 |
| Received goods | 14 |
| Installation point | 21 |
| Intended use | 9 |
| L | |
| Languages, operation options | 178 |
| Line recorder | 127 |
| Local display | 178 |
| Navigation view | 52 |
| see Diagnostic message | |
| see In alarm condition | |
| see Operational display | |
| Text editor | 54 |
| M | |
| Main electronics module | 13 |
| Maintenance work | 157 |
| Managing the device configuration | 109 |
| Manufacturer ID | 72 |
| Materials | 176 |
| Measured variable | 163 |
| Measuring device | |
| Adjusting the measured value based on the | |
| reference value | 99 |
| Basic settings for the adjustment | 99 |
| Configuring | 80 |
| Conversion | 158 |
| Design | 13 |
| Disposal | 159 |
| Integrating via communication protocol | 72 |
| Mounting the sensor | 27 |
| Screw tightening torques | 28 |

- Preparing for electrical connection 36
- Preparing for mounting 27
- Removing 159
- Repairs 158
- Switching on 79
- Measuring principle 163
- Measuring range 164
- Measuring system 163
- Mechanical load 175
- Medium temperature range 175
- Menu
 - Diagnostics 149
 - Setup 81
- Menus
 - For measuring device configuration 80
 - For specific settings 100
- Modbus RS485
 - Configuring error response mode 143
 - Diagnostic information 143
 - Function codes 74
 - Modbus data map 76
 - Read access 74
 - Reading out data 77
 - Register addresses 75
 - Register information 75
 - Response time 75
 - Scan list 77
 - Write access 74
- Modbus RS485 certification 185
- Mounting dimensions
 - see Dimensions
- Mounting kit 161
- Mounting preparations 27
- Mounting procedure 21
- Mounting requirements
 - Dimensions 24
 - Inlet and outlet runs 24
 - Installation point 21
 - Orientation 23
 - Static pressure 175
 - Thermal insulation 25
 - Vibrations 176
- N**
- Nameplate
 - Sensor 17
 - Transmitter 16
- Navigation path (navigation view) 52
- Navigation view
 - In the submenu 52
 - In the wizard 52
- Netilion 162
- Numeric editor 54
- O**
- Onsite display
 - Numeric editor 54
- Operating elements 56, 139
- Operating height 174
- Operating keys
 - see Operating elements
- Operating menu
 - Design 48
 - Menus, submenus 48
 - Submenus and user roles 49
- Operating philosophy 49
- Operation 119
- Operation options 47
- Operational display 50
- Operational safety 10
- Order code 16, 17
- Orientation (vertical, horizontal) 23
- Outlet runs 24
- Output signal 166
- Output variables 166
- P**
- Packaging disposal 20
- Parameter
 - Changing 59
 - Entering values or text 59
- Parameter settings
 - Administration (Submenu) 112
 - Advanced setup (Submenu) 101
 - Communication (Submenu) 83
 - Configuration backup (Submenu) 109
 - Current input 85
 - Current input (Wizard) 85
 - Current input 1 to n (Submenu) 121
 - Current output 87
 - Current output (Wizard) 87
 - Data logging (Submenu) 127
 - Define access code (Wizard) 111
 - Device information (Submenu) 154
 - Diagnostics (Menu) 149
 - Display (Submenu) 103
 - Display (Wizard) 96
 - I/O configuration 84
 - I/O configuration (Submenu) 84
 - Process variables (Submenu) 120
 - Pulse/frequency/switch output 89
 - Pulse/frequency/switch output (Wizard) 89, 90, 93
 - Pulse/frequency/switch output 1 to n (Submenu) 123
 - Relay output 95
 - Relay output 1 to n (Submenu) 123
 - Relay output 1 to n (Wizard) 95
 - Reset access code (Submenu) 111
 - Setup (Menu) 81
 - Simulation (Submenu) 113
 - Status input 86
 - Status input 1 to n (Submenu) 121
 - Status input 1 to n (Wizard) 86
 - System units (Submenu) 82
 - Totalizer (Submenu) 124
 - Totalizer 1 to n (Submenu) 102
 - Totalizer handling (Submenu) 125
 - Value current output 1 to n (Submenu) 122
 - Web server (Submenu) 66

- WLAN settings (Wizard) 107
 - Performance characteristics 173
 - Post-connection check 79
 - Post-connection check (checklist) 46
 - Post-mounting check 79
 - Post-mounting check (checklist) 32
 - Potential equalization 39, 172
 - Power consumption 171
 - Power supply failure 172
 - Pressure Equipment Directive 186
 - Pressure Equipment Directive (PED) 186
 - Pressure/temperature ratings 175
 - Process conditions
 - Flow limit 175
 - Medium temperature 175
 - Process variable 163
 - Product safety 10
 - Protecting parameter settings 116
- R**
- Radio approval 186
 - RCM marking 185
 - Read access 59
 - Reading off measured values 120
 - Reading out diagnostic information, Modbus RS485 143
 - Registered trademarks 8
 - Remedial measures
 - Calling up 140
 - Closing 140
 - Remote operation 179
 - Repair 158
 - Notes 158
 - Repair of a device 158
 - Repeatability 173
 - Replacement
 - Device components 158
 - Requirements for personnel 9
 - Retrofit kit for display/WLAN 162
 - Retrofit kit for inputs/outputs 162
 - Return 158
- S**
- Safety 9
 - Screw tightening torques 28
 - Sensor
 - Mounting 27
 - Serial number 16, 17
 - Setting the operating language 79
 - Settings
 - Adapting the measuring device to the process conditions 119
 - Administration 111
 - Advanced display configurations 103
 - Communication interface 83
 - Current input 85
 - Current output 87
 - I/O configuration 84
 - Local display 96
 - Managing the device configuration 109
 - Operating language 79
 - Pulse output 89
 - Pulse/frequency/switch output 89, 90
 - Relay output 95
 - Resetting the device 154
 - Resetting the totalizer 125
 - Simulation 113
 - Status input 86
 - Switch output 93
 - System units 82
 - Tag name 81
 - Totalizer 102
 - Totalizer reset 125
 - WLAN 107
 - Signal on alarm 168
 - Software release 72
 - Spare part 158
 - Spare parts 158
 - Special connection instructions 40
 - Standards and guidelines 186
 - Static pressure 175
 - Status area
 - For operational display 50
 - In the navigation view 52
 - Status signals 138, 141
 - Storage concept 184
 - Storage conditions 19
 - Storage temperature 19
 - Storage temperature range 174
 - Submenu
 - Administration 111, 112
 - Advanced setup 100, 101
 - Communication 83
 - Configuration backup 109
 - Current input 1 to n 121
 - Data logging 127
 - Device information 154
 - Display 103
 - Events list 151
 - Heartbeat setup 108
 - I/O configuration 84
 - Input values 121
 - Measured values 120
 - Output values 122
 - Overview 49
 - Process variables 120
 - Pulse/frequency/switch output 1 to n 123
 - Relay output 1 to n 123
 - Reset access code 111
 - Simulation 113
 - Status input 1 to n 121
 - System units 82
 - Total solids adjustment 99
 - Totalizer 124
 - Totalizer 1 to n 102
 - Totalizer handling 125
 - Value current output 1 to n 122
 - Web server 66
 - Supplemental documentation 187

- Supply voltage 171
- Switch output 167
- Symbols
 - Controlling data entries 55
 - For communication 50
 - For diagnostic behavior 50
 - For locking 50
 - For measured variable 50
 - For measurement channel number 50
 - For menus 52
 - For parameters 52
 - For status signal 50
 - For submenu 52
 - For wizards 52
 - In the status area of the local display 50
 - Input screen 55
 - Operating elements 54
- System design
 - Measuring system 163
 - see Measuring device design
- System integration 72
- T**
- Technical data, overview 163
- Temperature range
 - Ambient temperature for display 178
 - Storage temperature 19
- Terminal assignment 35
- Terminals 172
- Text editor 54
- Thermal insulation 25
- Tool tip
 - see Help text
- Tools
 - Electrical connection 33
 - For transport 19
- Totalizer
 - Configuring 102
- Transmitter
 - Turning the display module 30
 - Turning the housing 29
- Transporting the measuring device 19
- Troubleshooting
 - General 134
- Turning the display module 30
- Turning the electronics housing
 - see Turning the transmitter housing
- Turning the transmitter housing 29
- U**
- UKCA marking 185
- Use of measuring device
 - Borderline cases 9
 - Incorrect use 9
 - see Intended use
- User roles 49
- V**
- Vibration and shock resistance 175
- Vibrations 176
- W**
- Weight
 - Compact version
 - SI units 176
 - Transport (notes) 19
- Wizard
 - Current input 85
 - Current output 87
 - Define access code 111
 - Display 96
 - Pulse/frequency/switch output 89, 90, 93
 - Relay output 1 to n 95
 - Status input 1 to n 86
 - Total solids commissioning 99
 - WLAN settings 107
- WLAN settings 107
- Workplace safety 10
- Write access 59
- Write protection
 - Via access code 116
 - Via write protection switch 117
- Write protection switch 117



71637044

www.addresses.endress.com
