

Description of Device Parameters

Cerabar PMC51B

Process pressure measurement
HART




Table of contents

1	About this document	4
1.1	Document function	4
1.2	Target group	4
1.3	Using this document	4
1.4	Symbols used	5
1.5	Documentation	5
2	Overview of the operating menu	6
3	Description of device parameters ...	21
3.1	User navigation	21
3.2	"Guidance" menu	23
3.3	"Diagnostics" menu	44
3.4	"Application" menu	65
3.5	"System" menu	96
Index		110

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and parameters that are available when the **"Maintenance" option** user role is enabled.



For the operating concept of the operating menus, see the Operating Instructions.


1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:


- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function


1.4 Symbols used

1.4.1 Symbols for certain types of Information

Additional information: 

Reference to documentation: 

Operation via local display: 


Operation via operating tool: 

Write-protected parameter: 

1.5 Documentation


1.5.1 Standard documentation

Operating Instructions

























 The Operating Instructions are available via the Internet: www.endress.com →
Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

 The Special Documentation is available via the Internet: www.endress.com →
Download

2 Overview of the operating menu

Guidance	→  21
▶ Commissioning	→  23
▶ Device identification	→  23
Device tag	→  23
Device name	→  23
Serial number	→  23
Extended order code 1	→  24
Extended order code 2	→  24
Extended order code 3	→  24
▶ Device identification	→  25
Locking status	→  25
▶ Device identification	→  26
HART short tag	→  26
HART date code	→  26
HART descriptor	→  26
HART message	→  26
HART address	→  27
▶ Measurement adjustments	→  27
Assign PV	→  27
Damping	→  27
▶ Measurement adjustments	→  28
Pressure unit	→  28
Temperature unit	→  28
▶ Measurement adjustments	→  29

Pressure unit	→ 29
Scaled variable unit	→ 29
Free text	→ 30
Temperature unit	→ 30
► Measurement adjustments	→ 31
Zero adjustment	→ 31
Pressure	→ 32
► Output settings	→ 32
Output current transfer function	→ 32
► Output settings	→ 32
Scaled variable transfer function	→ 32
► Output settings	→ 33
Lower Range Limit	→ 33
Upper Range Limit	→ 33
Minimum span	→ 33
► Output settings	→ 34
Pressure	→ 34
Scaled variable	→ 34
► Output settings	→ 34
Lower range value output	→ 34
Upper range value output	→ 34
Lower Range Limit	→ 35
Upper Range Limit	→ 35
Minimum span	→ 35
► Output settings	→ 35

Scaled variable transfer function	→ 35
Pressure value 1	→ 36
Scaled variable value 1	→ 36
Pressure value 2	→ 36
Scaled variable value 2	→ 36
Lower Range Limit	→ 37
Upper Range Limit	→ 37
Minimum span	→ 37
► Output settings	→ 37
Lower range value output	→ 37
Upper range value output	→ 38
Current range output	→ 38
Failure behavior current output	→ 38
Failure current	→ 38
Loop current mode	→ 39
Assign HART variables?	→ 39
► Output settings	→ 39
Process variable output current	→ 39
Current range output	→ 40
Lower range value output	→ 40
Upper range value output	→ 40
Failure behavior current output	→ 40
Failure current	→ 41

Loop current mode	→ 41
Assign HART variables?	→ 41
► Output settings	→ 41
Assign PV	→ 41
Assign SV	→ 42
Assign TV	→ 42
Assign QV	→ 43
Diagnostics	→ 44
► Active diagnostics	→ 44
Active diagnostics	→ 44
Timestamp	→ 44
Previous diagnostics	→ 45
Timestamp	→ 45
Operating time from restart	→ 45
Operating time	→ 46
► Event logbook	→ 46
Filter options	→ 46
► Minimum/maximum values	→ 47
Pressure min	→ 47
Counter limit underruns sensor Pmin	→ 47
Counter underruns of user limit Pmin	→ 47
Minimum sensor temperature	→ 48
Counter limit underruns sensor Tmin	→ 48
Counter underruns of user limit Tmin	→ 48
Minimum terminal voltage	→ 48

Minimum electronics temperature	→ 48
Reset user defined counters P and T	→ 49
Pressure max	→ 49
Counter limit overruns sensor Pmax	→ 49
Counter overruns of user limit Pmax	→ 49
Maximum sensor temperature	→ 49
Counter limit overruns sensor Tmax	→ 50
Counter overruns of user limit Tmax	→ 50
Maximum terminal voltage	→ 50
Maximum electronics temperature	→ 50
► Simulation	→ 51
Simulation	→ 51
Value pressure simulation	→ 51
Value current output	→ 51
Diagnostic event simulation	→ 51
► Diagnostic settings	→ 52
► Properties	→ 52
SSD Out of range delay time	→ 52
SSD Monitoring delay time	→ 52
500 Process alert pressure	→ 52
Low alert value	→ 53
High alert value	→ 53
501 Process alert scaled variable	→ 53
Low alert value	→ 53
High alert value	→ 54

User temperature process alert	→ 54
Low alert value	→ 54
High alert value	→ 54
806 Diagnostic behavior	→ 55
806 Diagnostic behavior	→ 55
806 Event category	→ 55
806 Event category	→ 55
806 Event delay	→ 55
► Configuration	→ 56
► Configuration	→ 56
500 Diagnostic behavior	→ 56
500 Diagnostic behavior	→ 56
500 Diagnostic behavior	→ 56
500 Diagnostic behavior	→ 56
500 Event category	→ 56
500 Event category	→ 56
500 Event category	→ 56
500 Event category	→ 56
501 Diagnostic behavior	→ 56
501 Diagnostic behavior	→ 56
501 Diagnostic behavior	→ 56
501 Diagnostic behavior	→ 56
501 Event category	→ 57
501 Event category	→ 57
501 Event category	→ 57

501 Event category	→ 57
502 Diagnostic behavior	→ 57
502 Diagnostic behavior	→ 57
502 Diagnostic behavior	→ 57
502 Diagnostic behavior	→ 57
502 Event category	→ 57
502 Event category	→ 57
502 Event category	→ 57
502 Event category	→ 57
► Process	→ 58
806 Diagnostic behavior	→ 58
806 Diagnostic behavior	→ 58
806 Diagnostic behavior	→ 58
806 Diagnostic behavior	→ 58
806 Diagnostic behavior	→ 58
806 Diagnostic behavior	→ 58
806 Event category	→ 58
806 Event category	→ 58
806 Event category	→ 58
806 Event category	→ 58
806 Event category	→ 58
822 Diagnostic behavior	→ 58
822 Event category	→ 59
Sensor pressure range behavior	→ 59

	841 Event category	→ 59
	900 Event category	→ 60
	900 Event category	→ 60
	900 Event category	→ 60
	900 Event category	→ 60
	900 Diagnostic behavior	→ 60
	900 Diagnostic behavior	→ 60
	900 Diagnostic behavior	→ 60
	900 Diagnostic behavior	→ 60
	906 Diagnostic behavior	→ 60
	906 Diagnostic behavior	→ 60
	906 Diagnostic behavior	→ 60
	906 Diagnostic behavior	→ 60
	906 Event category	→ 60
	906 Event category	→ 60
	906 Event category	→ 60
	906 Event category	→ 60
Application		→ 65
► Measuring units		→ 65
Pressure unit		→ 65
Decimal places pressure		→ 65
Temperature unit		→ 65
Scaled variable unit		→ 66
Free text		→ 67
Decimal places scaled variable		→ 67
























▶ Measured values	→ 68
Pressure	→ 68
Scaled variable	→ 68
Sensor temperature	→ 68
Terminal voltage 1	→ 68
Terminal current	→ 69
Electronics temperature	→ 69
▶ Sensor	→ 69
▶ Basic settings	→ 69
Output current transfer function	→ 69
Damping	→ 70
▶ Sensor calibration	→ 70
Zero adjustment	→ 70
Calibration offset	→ 70
Zero adjustment offset	→ 71
Sensor Trim Reset	→ 71
Lower sensor trim measured value	→ 71
Lower sensor trim	→ 72
Upper sensor trim measured value	→ 72
Upper sensor trim	→ 73
▶ Sensor limits	→ 73
Lower Range Limit	→ 73
Upper Range Limit	→ 73
Minimum span	→ 74






Sensor temperature lower range limit	→ 74
Sensor temperature upper range limit	→ 74
► Scaled variable	→ 74
Assign PV	→ 74
Scaled variable unit	→ 75
Free text	→ 75
Pressure	→ 76
Scaled variable transfer function	→ 76
Lower range value output	→ 76
Upper range value output	→ 76
Activate table	→ 77
Pressure value 1	→ 77
Scaled variable value 1	→ 77
Pressure value 2	→ 77
Scaled variable value 2	→ 77
Pressure	→ 78
Scaled variable	→ 78
► Wet calibration	→ 78
Zero	→ 78
Pressure value 1	→ 78
Span	→ 78
Pressure value 2	→ 79
Zero	→ 78
Lower range value output	→ 79

Span	→ 78
Upper range value output	→ 79
► Current output	→ 81
Assign PV	→ 81
Measuring mode current output	→ 81
Current range output	→ 81
Lower range value output	→ 82
Upper range value output	→ 82
Failure behavior current output	→ 82
Failure current	→ 82
Output current	→ 83
Terminal current	→ 83
► HART output	→ 84
► Configuration	→ 84
HART address	→ 84
HART short tag	→ 84
Device tag	→ 84
No. of preambles	→ 85
Loop current mode	→ 85
► HART output	→ 85
Assign PV	→ 85
Primary variable (PV)	→ 85
Assign SV	→ 86
Secondary variable (SV)	→ 86
Assign TV	→ 86

Tertiary variable (TV)	→ 87
Assign QV	→ 87
Quaternary variable (QV)	→ 88
► Burst configuration 1	→ 88
Burst mode 1	→ 88
Burst command 1	→ 89
Burst variable 0	→ 89
Burst variable 1	→ 90
Burst variable 2	→ 90
Burst variable 3	→ 90
Burst variable 4	→ 90
Burst variable 5	→ 91
Burst variable 6	→ 91
Burst variable 7	→ 91
Burst trigger mode	→ 91
Burst trigger level	→ 92
Min. update period	→ 92
Max. update period	→ 92
► Information	→ 93
Device ID	→ 93
Device type	→ 93
Device revision	→ 93
HART short tag	→ 94
HART revision	→ 94
HART descriptor	→ 94

	HART message	→ 94
	HART date code	→ 95
System		→ 96
▶ Device management		→ 96
Device tag		→ 96
Locking status		→ 96
Configuration counter		→ 97
Reset device		→ 97
▶ User management		→ 98
User role		→ 98
Password		→ 98
Enter access code		→ 98
Status password entry		→ 99
New password		→ 99
Confirm new password		→ 99
Status password entry		→ 99
Old password		→ 99
New password		→ 99
Confirm new password		→ 99
Status password entry		→ 99
Reset password		→ 100
Status password entry		→ 99
Old password		→ 99
Status password entry		→ 99
▶ Display		→ 100

Language	→  100
Format display	→  101
Value 1 display	→  101
Value 2 display	→  102
Value 3 display	→  102
Value 4 display	→  103
Contrast display	→  103
► Geolocation	→  104
Process Unit Tag	→  104
Location Description	→  104
Longitude	→  104
Latitude	→  104
Altitude	→  105
Location method	→  105
► Information	→  105
Device name	→  105
Manufacturer	→  106
Serial number	→  106
Order code	→  106
Firmware version	→  107
Hardware version	→  107
Extended order code 1	→  107
Extended order code 2	→  107

Extended order code 3	→  108
Checksum	→  108
► Software configuration	→  108
Activate SW option	→  108
Software option overview	→  109

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the operating tool.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

3.1 User navigation


The Guidance main menu contains functions which enable users to perform basic tasks swiftly, e.g. commissioning.

These are primarily guided wizards and cross-subject special functions.






Navigation  Guidance

3.1.1 Overview of the operating menu






"Guidance" menu

Commissioning (→  23)







"Diagnostics" menu

- Active diagnostics (→  44)
- Event logbook (→  46)
- Minimum/maximum values (→  47)
- Simulation (→  51)
- Diagnostic settings (→  52)

"Application" menu


- Measuring units (→  65)
- Measured values (→  68)
- Sensor (→  69)
- Current output (→  81)
- HART output (→  84)

"System" menu

- Device management (→  96)
- User management (→  98)
- Bluetooth configuration
- Display (→  100)
- Geolocation (→  104)
- Information (→  93)
- Software configuration (→  108)











































3.1.2 Commissioning

Run this wizard to put the device into operation. Enter the appropriate value in each parameter or select the appropriate option.

 If the wizard is canceled before all the necessary parameters have been configured, any settings already made are saved. For this reason, the device may then be in an undefined state!

In such situations, it is advisable to reset the device to the factory default settings.

The following parameters are configured in the Commissioning wizard:

- Device identification (→  23)
 - Device tag (→  23)
 - Device name (→  23)
 - Serial number (→  23)
 - Extended order code 1 (→  24)
 - Extended order code 2 (→  24)
 - Extended order code 3 (→  24)
 - Locking status (→  25)
 - HART short tag (→  26)
 - HART date code (→  26)
 - HART descriptor (→  26)
 - HART message (→  26)
 - HART address (→  27)
- Measurement adjustments (→  27)
 - Assign PV (→  27)
 - Damping (→  27)
 - Pressure unit (→  28)
 - Temperature unit (→  28)
 - Scaled variable unit (→  29)
 - Zero adjustment (→  31)
 - Pressure (→  32)
- Output settings (→  32)
 - Output current transfer function (→  32)
 - Lower Range Limit (→  33)
 - Upper Range Limit (→  33)
 - Minimum span (→  33)
 - Pressure (→  34)
 - Scaled variable (→  34)
 - Lower range value output (→  34)
 - Upper range value output (→  34)
 - Scaled variable transfer function (→  32)
 - Pressure value 1 (→  36)
 - Current range output (→  38)
 - Failure behavior current output (→  38)
 - Failure current (→  38)
 - Loop current mode (→  39)
 - Assign HART variables? (→  39)
 - Process variable output current (→  39)
 - Assign PV (→  27)
 - Assign SV (→  42)
 - Assign TV (→  42)
 - Assign QV (→  43)


3.2 "Guidance" menu

Navigation  Guidance


3.2.1 "Commissioning" wizard

Navigation  Guidance → Commissioning

"Device identification" wizard

Navigation  Guidance → Commissioning → Device ident.


Device tag

Navigation  Guidance → Commissioning → Device ident. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)


Device name


Navigation  Guidance → Commissioning → Device ident. → Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Serial number

Navigation  Guidance → Commissioning → Device ident. → Serial number

Description Displays the serial number of the measuring device.
 The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Extended order code 1**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 1

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface

Character string

Factory setting

–

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 2

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

–

Extended order code 3**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 3

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.




The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface


Character string

Factory setting -

"Device identification" wizard

Navigation  Guidance → Commissioning → Device ident.

Locking status


Navigation  Guidance → Commissioning → Device ident. → Locking status

Description Displays the active write protection.

- User interface**
- Hardware locked
 - Safety locked
 - Temporarily locked

Additional information *User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.


Selection


Function scope of the "Locking status" parameter


Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.



"Device identification" wizard


Navigation  Guidance → Commissioning → Device ident.


HART short tag 


Navigation	 Guidance → Commissioning → Device ident. → HART short tag
Description	Defines the short tag for the measuring point. Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).


HART date code 

Navigation	 Guidance → Commissioning → Device ident. → HART date code
Description	Date of the last configuration change
User entry	Character string comprising numbers, letters and special characters (10)
Additional information	Date format: YYYY-MM-DD  Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

HART descriptor 

Navigation	 Guidance → Commissioning → Device ident. → HART descriptor
Description	Description for the measuring point.
User entry	Character string comprising numbers, letters and special characters (16)

HART message 

Navigation	 Guidance → Commissioning → Device ident. → HART message
Description	A HART message which is sent via the HART protocol when requested by the master.
User entry	Character string comprising numbers, letters and special characters (32)

HART address



Navigation	Guidance → Commissioning → Device ident. → HART address
Description	Define the HART address of the device.
User entry	0 to 63
Additional information	<ul style="list-style-type: none"> ■ The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode). ■ Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0. ■ All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.

"Measurement adjustments" wizard

Navigation Guidance → Commissioning → Meas. adjust.

Assign PV




Navigation	Guidance → Commissioning → Meas. adjust. → Assign PV
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).
Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable

Damping




Navigation	Guidance → Commissioning → Meas. adjust. → Damping
Description	<p>The damping is effective before the measured value is further processed, i.e., before the following processes:</p> <ul style="list-style-type: none"> - Scaling - Limit value monitoring - Forwarding to display - Forwarding to Analog Input Block <p>Note: The Analog Input Block has its own "Damping" parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.</p>
User entry	0 to 999.0 s

"Measurement adjustments" wizard

Navigation  Guidance → Commissioning → Meas. adjust.

Pressure unit

Navigation  Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ MPa ■ kPa ■ Pa ■ bar ■ mbar ■ torr ■ atm ■ kgf/cm² ■ gf/cm² 	<i>US units</i> <ul style="list-style-type: none"> psi 	<i>Other units</i> <ul style="list-style-type: none"> ■ inH2O ■ inH2O (4°C) ■ mmH2O ■ mmH2O (4°C) ■ mH2O ■ mH2O (4°C) ■ ftH2O ■ inHg ■ mmHg
------------------	---	---	--

Temperature unit

Navigation  Guidance → Commissioning → Meas. adjust. → Temperature unit

Description Use this function to select the unit for the temperature.


Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K 	<i>US units</i> <ul style="list-style-type: none"> °F
------------------	---	--

Factory setting Country-specific:

- °C
- °F


Additional information *Selection*

"Measurement adjustments" wizard

Navigation  Guidance → Commissioning → Meas. adjust.

Pressure unit




Navigation  Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ MPa ■ kPa ■ Pa ■ bar ■ mbar ■ torr ■ atm ■ kgf/cm² ■ gf/cm² 	<i>US units</i> <ul style="list-style-type: none"> psi 	<i>Other units</i> <ul style="list-style-type: none"> ■ inH2O ■ inH2O (4°C) ■ mmH2O ■ mmH2O (4°C) ■ mH2O ■ mH2O (4°C) ■ ftH2O ■ inHg ■ mmHg
------------------	---	---	--

Scaled variable unit



Navigation  Guidance → Commissioning → Meas. adjust. → Scaled Unit

Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection	SI units	US units	Imperial units
	<ul style="list-style-type: none"> ■ % ■ mm ■ cm ■ m ■ l ■ hl ■ m³ ■ g ■ kg ■ t ■ g/s ■ kg/s ■ kg/min ■ kg/h ■ t/min ■ t/h ■ t/d ■ m³/s ■ m³/min ■ m³/h ■ m³/d ■ l/s ■ l/min ■ l/h ■ Nm³/h ■ NI/h ■ Sm³/s ■ Sm³/min ■ Sm³/h ■ Sm³/d ■ Nm³/s ■ g/cm³ ■ kg/m³ ■ Nm³/min ■ Nm³/d 	<ul style="list-style-type: none"> ■ ft ■ in ■ ft³ ■ gal (us) ■ bbl (us;oil) ■ oz ■ lb ■ STon ■ lb/s ■ lb/min ■ lb/h ■ STon/min ■ STon/h ■ STon/d ■ ft³/s ■ ft³/min ■ ft³/h ■ ft³/d ■ gal/s (us) ■ gal/min (us) ■ gal/h (us) ■ gal/d (us) ■ bbl/s (us;oil) ■ bbl/min (us;oil) ■ bbl/h (us;oil) ■ bbl/d (us;oil) ■ Sft³/min ■ Sft³/h ■ Sft³/d 	<ul style="list-style-type: none"> ■ gal (imp) ■ gal/s (imp) ■ gal/min (imp) ■ gal/h (imp)
	<p><i>Custom-specific units</i></p> <p>Free text</p>		

Free text



Navigation

Guidance → Commissioning → Meas. adjust. → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Temperature unit



Navigation


Guidance → Commissioning → Meas. adjust. → Temperature unit

Description


Use this function to select the unit for the temperature.

Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K 	<i>US units</i> °F
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ °C ■ °F 	
Additional information	<i>Selection</i>	


"Measurement adjustments" wizard

Navigation  Guidance → Commissioning → Meas. adjust.


Zero adjustment

Navigation	 Guidance → Commissioning → Meas. adjust. → Zero adjustment
Description	Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.
Selection	<ul style="list-style-type: none"> ■ No ■ Confirm

Pressure

Navigation  Guidance → Commissioning → Meas. adjust. → Pressure

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Output current transfer function

Navigation  Guidance → Commissioning → Output settings → Curr. trans.func

Description


Linear
The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit.

Square root - differential pressure only
The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

User interface

- Linear
- Square root *

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Scaled variable transfer function



Navigation  Guidance → Commissioning → Output settings → Scaled function

Description

"Linear"
The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.


"Square root" (Deltabar)
The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table"
The output is defined according to the scaled variable / pressure table entered.


* Visibility depends on order options or device settings

- Selection**
- Linear
 - Square root *
 - Table

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Lower Range Limit

Navigation  Guidance → Commissioning → Output settings → LRL

Description Indicates the lower measuring limit of the sensor.

User interface Signed floating-point number

Upper Range Limit

Navigation  Guidance → Commissioning → Output settings → URL

Description Indicates the upper measuring limit of the sensor.

User interface Signed floating-point number

Minimum span


Navigation  Guidance → Commissioning → Output settings → Minimum span


Description Specifies the smallest possible measuring span of the sensor.


User interface Signed floating-point number

* Visibility depends on order options or device settings


"Output settings" wizard


Navigation  Guidance → Commissioning → Output settings

Pressure 

Navigation  Guidance → Commissioning → Output settings → Pressure


User entry Signed floating-point number

Scaled variable 

Navigation  Guidance → Commissioning → Output settings → Scaled variable

User entry Signed floating-point number

"Output settings" wizard


Navigation  Guidance → Commissioning → Output settings

Lower range value output 

Navigation  Guidance → Commissioning → Output settings → Low.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number


Upper range value output 

Navigation  Guidance → Commissioning → Output settings → Upp.range outp


Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number


Lower Range Limit

Navigation	 Guidance → Commissioning → Output settings → LRL
Description	Indicates the lower measuring limit of the sensor.
User interface	Signed floating-point number


Upper Range Limit

Navigation	 Guidance → Commissioning → Output settings → URL
Description	Indicates the upper measuring limit of the sensor.
User interface	Signed floating-point number


Minimum span

Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

"Output settings" wizard


Navigation  Guidance → Commissioning → Output settings

Scaled variable transfer function

Navigation	 Guidance → Commissioning → Output settings → Scaled function
Description	<p>"Linear" The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.</p> <p>"Square root" (Deltabar) The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.</p> <p>"Table" The output is defined according to the scaled variable / pressure table entered.</p>

- Selection**
- Linear
 - Square root *
 - Table


Pressure value 1

Navigation  Guidance → Commissioning → Output settings → Pressure 1

Description Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry Signed floating-point number


Scaled variable value 1

Navigation  Guidance → Commissioning → Output settings → Scaled 1

Description Enter value for the first scaling point. This value is allocated to "Pressure value 1".

User interface Signed floating-point number


Pressure value 2

Navigation  Guidance → Commissioning → Output settings → Pressure 2

Description Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry Signed floating-point number

Scaled variable value 2


Navigation  Guidance → Commissioning → Output settings → Scaled 2

Description Enter value for the second scaling point. This value is allocated to "Pressure value 2".


User entry Signed floating-point number

* Visibility depends on order options or device settings


Lower Range Limit

Navigation	 Guidance → Commissioning → Output settings → LRL
Description	Indicates the lower measuring limit of the sensor.
User interface	Signed floating-point number


Upper Range Limit

Navigation	 Guidance → Commissioning → Output settings → URL
Description	Indicates the upper measuring limit of the sensor.
User interface	Signed floating-point number

Minimum span


Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number



"Output settings" wizard



Navigation  Guidance → Commissioning → Output settings



Lower range value output





Navigation	 Guidance → Commissioning → Output settings → Low.range outp
Description	Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number


Upper range value output		
Navigation		Guidance → Commissioning → Output settings → Upp.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).	
User entry	Signed floating-point number	

Current range output		
Navigation		Guidance → Commissioning → Output settings → Current range
Description	<p>Defines the current range used to transmit the measured or calculated value. In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value ≤ "low saturation", the output current is set to "low saturation". If Measured value ≥ "high saturation", the output current is set to "high saturation".</p> <p>Note: Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.</p>	
Selection	<ul style="list-style-type: none"> ■ 4...20 mA (4...20.5 mA) ■ 4...20 mA NE (3.8...20.5 mA) ■ 4...20 mA US (3.9...20.8 mA) 	


Failure behavior current output		
Navigation		Guidance → Commissioning → Output settings → Failure behav.
Description	<p>Defines which current the output assumes in the case of an error. Min: < 3.6 mA Max: >21.5 mA</p> <p>Note: The hardware DIP Switch for alarm current has priority over software setting.</p>	
Selection	<ul style="list-style-type: none"> ■ Min. ■ Max. 	

Failure current		
Navigation		Guidance → Commissioning → Output settings → Failure current
Description	Enter current output value in alarm condition	
User entry	21.5 to 23 mA	


Loop current mode

Navigation	 Guidance → Commissioning → Output settings → Loop curr mode
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
User interface	<ul style="list-style-type: none"> ■ Disable ■ Enable


Assign HART variables?


Navigation	 Guidance → Commissioning → Output settings → Assign HART var?
Description	Up to four HART variables can be transmitted via the HART protocol. Select "Yes" to show/assign measuring variables to these HART variables.
Selection	<ul style="list-style-type: none"> ■ No ■ Yes


"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Process variable output current

Navigation	 Guidance → Commissioning → Output settings → Proc.var.curr.
Description	Determines which process variable is transmitted via the current output.
User interface	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable

Current range output


Navigation  Guidance → Commissioning → Output settings → Current range

Description Defines the current range used to transmit the measured or calculated value. In brackets are indicated the “low saturation value” and the “high saturation value”. If Measured value ≤ “low saturation”, the output current is set to “low saturation”. If Measured value ≥ “high saturation”, the output current is set to “high saturation”.

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output


Navigation  Guidance → Commissioning → Output settings → Low.range outp

Description Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).


User entry Signed floating-point number


Upper range value output


Navigation  Guidance → Commissioning → Output settings → Upp.range outp

Description Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Failure behavior current output


Navigation  Guidance → Commissioning → Output settings → Failure behav.

Description Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: >21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current



Navigation	Guidance → Commissioning → Output settings → Failure current
Description	Enter current output value in alarm condition
User entry	21.5 to 23 mA

Loop current mode

Navigation	Guidance → Commissioning → Output settings → Loop curr mode
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
User interface	<ul style="list-style-type: none"> ■ Disable ■ Enable

Assign HART variables?

Navigation	Guidance → Commissioning → Output settings → Assign HART var?
Description	Up to four HART variables can be transmitted via the HART protocol. Select "Yes" to show/assign measuring variables to these HART variables.
Selection	<ul style="list-style-type: none"> ■ No ■ Yes

"Output settings" wizard

Navigation Guidance → Commissioning → Output settings


Assign PV



Navigation	Guidance → Commissioning → Output settings → Assign PV
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

- Selection**
- Pressure
 - Scaled variable

Assign SV

Navigation  Guidance → Commissioning → Output settings → Assign SV


Description Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

- Selection**
- Pressure
 - Scaled variable
 - Sensor temperature
 - Sensor pressure
 - Electronics temperature
 - Terminal current *
 - Terminal voltage *
 - Median of pressure signal *
 - Noise of pressure signal *
 - Signal noise detected *
 - Percent of range
 - Loop current
 - Not used

Additional information *Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Assign TV

Navigation  Guidance → Commissioning → Output settings → Assign TV

Description Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

- Selection**
- Pressure
 - Scaled variable
 - Sensor temperature
 - Sensor pressure
 - Electronics temperature
 - Terminal current *


* Visibility depends on order options or device settings

- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Assign QV**Navigation**

 Guidance → Commissioning → Output settings → Assign QV

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

* Visibility depends on order options or device settings





3.3 "Diagnostics" menu

Navigation  Diagnostics





3.3.1 "Active diagnostics" submenu

Navigation  Diagnostics → Active diagnos.





Active diagnostics

Navigation	  Diagnostics → Active diagnos. → Active diagnos.
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Additional pending diagnostic messages can be viewed in the Diagnostic list submenu.</p> <p><i>Example</i></p> <p>For the display format: F271 Main electronic failure</p>




Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Actual diagnostics parameter (→  44).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>


Previous diagnostics

Navigation	 Diagnostics → Active diagnos. → Prev.diagnostics
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Example</i></p> <p>For the display format:  F271 Main electronic failure</p>


Timestamp

Navigation	 Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p> <p> The diagnostic message can be viewed via the Previous diagnostics parameter (→  45).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Operating time from restart

Navigation	 Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)



Operating time

Navigation	 Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time: 9 999 d (≈ 27 years)


3.3.2 "Event logbook" submenu


Navigation  Diagnostics → Event logbook

Filter options

Navigation	 Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the event list of the operating tool.
Selection	<ul style="list-style-type: none"> ■ All ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Information (I) ■ Not categorized
Additional information	<p><i>Description</i></p> <p> The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none"> ■ F = Failure ■ C = Function Check ■ S = Out of Specification ■ M = Maintenance Required

Clear event list



Navigation	 Diagnostics → Event logbook → Clear event list
Description	Use this function to process the current values in the event logbook.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Clear data

Additional information	<i>Description</i>
	Once this function has been executed, the events list is empty and all the events are deleted.
	 The events list can be exported using an operating tool (e.g. FieldCare).



3.3.3 "Minimum/maximum values" submenu

Navigation  Diagnostics → Min/max val.



Pressure min

Navigation	  Diagnostics → Min/max val. → Pressure min
Description	Minimum or maximum value measured by device.
User interface	Signed floating-point number


Counter limit underruns sensor Pmin

Navigation	  Diagnostics → Min/max val. → Counter P < Pmin
Description	Counts how many times the value underruns the sensor specific minimum values. Sensor specific minimum values are shown in Application/Sensor menu.
User interface	0 to 65 535


Counter underruns of user limit Pmin

Navigation	  Diagnostics → Min/max val. → Counter < P user
Description	Counts how many times the value underruns the minimum values defined by the user. User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties menu.
User interface	0 to 65 535


Minimum sensor temperature

Navigation	 Diagnostics → Min/max val. → Min. sensor temp
Description	Minimum or maximum value measured by device. Users cannot reset this value.
User interface	-273.15 to 9 726.85 °C


Counter limit underruns sensor Tmin

Navigation	 Diagnostics → Min/max val. → Counter T < Tmin
Description	Counts how many times the value underruns/overruns the sensor specific minimum/ maximum values. Sensor specific minimum/maximum values are shown in Application/Sensor menu.
User interface	0 to 65 535


Counter underruns of user limit Tmin

Navigation	 Diagnostics → Min/max val. → Counter < T user
User interface	0 to 65 535

Minimum terminal voltage

Navigation	 Diagnostics → Min/max val. → Min.term.volt.
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V

Minimum electronics temperature

Navigation	 Diagnostics → Min/max val. → Min.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Reset user defined counters P and T



Navigation	Diagnostics → Min/max val. → Reset count. P T
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Confirm

Pressure max

Navigation	Diagnostics → Min/max val. → Pressure max
Description	Minimum or maximum value measured by device.
User interface	Signed floating-point number

Counter limit overruns sensor Pmax

Navigation	Diagnostics → Min/max val. → Counter P > Pmax
Description	Counts how many times the value overruns the sensor specific maximum values. Sensor specific maximum values are shown in Application/Sensor menu.
User interface	0 to 65 535


Counter overruns of user limit Pmax

Navigation	Diagnostics → Min/max val. → Counter > P user
Description	Counts how many times the value overruns the maximum values defined by the user. User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties menu.
User interface	0 to 65 535


Maximum sensor temperature

Navigation	Diagnostics → Min/max val. → Max. sensor temp
Description	Minimum or maximum value measured by device. Users cannot reset this value.
User interface	-273.15 to 9 726.85 °C


Counter limit overruns sensor Tmax

Navigation	 Diagnostics → Min/max val. → Counter T > Tmax
Description	Counts how many times the value underruns/overruns the sensor specific minimum/maximum values. Sensor specific minimum/maximum values are shown in Application/Sensor menu.
User interface	0 to 65 535


Counter overruns of user limit Tmax

Navigation	 Diagnostics → Min/max val. → Counter > T user
User interface	0 to 65 535

Maximum terminal voltage













Navigation	 Diagnostics → Min/max val. → Max.term.voltage
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V

Maximum electronics temperature


Navigation	 Diagnostics → Min/max val. → Max.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

3.3.4 "Simulation" submenu

Navigation  Diagnostics → Simulation

Simulation		
Navigation	  Diagnostics → Simulation → Simulation	
Description	<p>Simulates one or more process variables and/or events.</p> <p>Warning: Output will reflect the simulated value or event.</p>	
Selection	<ul style="list-style-type: none"> ■ Off ■ Current output ■ Diagnostic event simulation ■ Pressure 	
Value pressure simulation		
Navigation	  Diagnostics → Simulation → Pressure	
User entry	Signed floating-point number	
Value current output		
Navigation	  Diagnostics → Simulation → Current output	
Description	Defines the value of the simulated output current.	
User entry	3.59 to 23 mA	
Diagnostic event simulation		
Navigation	  Diagnostics → Simulation → Diagnostic event	
Description	Use this function to select a diagnostic event for the simulation process that is activated.	
Selection	<ul style="list-style-type: none"> ■ Off ■ Diagnostic event picklist (depends on the category selected) 	

Additional information*Description*

 For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter.


3.3.5 "Diagnostic settings" submenu


Navigation  Diagnostics → Diag. settings

"Properties" submenu

Navigation  Diagnostics → Diag. settings → Properties


SSD Out of range delay time




Navigation  Diagnostics → Diag. settings → Properties → SSD Delay time

User entry 0 to 604 800 s


SSD Monitoring delay time




Navigation  Diagnostics → Diag. settings → Properties → SSD Verz. Zeit

User entry 0 to 86 400 s

500 Process alert pressure



Navigation  Diagnostics → Diag. settings → Properties → 500 Pressure

Description Define whether user-defined pressure limits should be set.
If "Off" is selected, no analysis will take place and no event message will be generated.

Selection

- Off
- On

Low alert value

**Navigation**

Diagnostics → Diag. settings → Properties → Low alert value

Description

Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry

Signed floating-point number

High alert value

**Navigation**

Diagnostics → Diag. settings → Properties → High alert value

Description

Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry

Signed floating-point number

501 Process alert scaled variable

**Navigation**

Diagnostics → Diag. settings → Properties → 501 Scaled var.

Description

Define whether user-defined limits should be set.
If "Off" is selected, no analysis will take place and no event message will be generated.

Selection

- Off
- On

Low alert value

**Navigation**

Diagnostics → Diag. settings → Properties → Low alert value


Description

Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry


Signed floating-point number


High alert value 

Navigation  Diagnostics → Diag. settings → Properties → High alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry Signed floating-point number

User temperature process alert 


Navigation  Diagnostics → Diag. settings → Properties → UserTemp alert

Description Define whether the user-defined sensor temperature limits should be set. If "Off" no analysis and therefore no event message will take place.

Selection

- Off
- On


Low alert value 

Navigation  Diagnostics → Diag. settings → Properties → Low alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry -50 to 150 °C

High alert value 

Navigation  Diagnostics → Diag. settings → Properties → High alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry -50 to 150 °C

806 Diagnostic behavior

**Navigation**

Diagnostics → Diag. settings → Properties → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

806 Event category

**Navigation**

Diagnostics → Diag. settings → Properties → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

806 Event delay

**Navigation**

Diagnostics → Diag. settings → Properties → 806 Event delay


Description

Displays how long the triggering status must be present until an event message is issued. Used to filter out short-term signal interference.

User entry

0 to 60 s

"Configuration" submenu

Navigation  Diagnostics → Diag. settings → Configuration → Configuration

500 Diagnostic behavior 

Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 500 Diag. behav.

Description Select event behavior
 "Logbook entry only":
 no digital or analog transmission of the message
 "Warning": Current output unchanged. Message is output digitally (default).
 "Alarm": Current output assumes the set alarm current.
 Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

500 Event category 

Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 500Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

501 Diagnostic behavior 

Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 501 Diag. behav.

Description Select event behavior
 "Logbook entry only":
 no digital or analog transmission of the message
 "Warning": Current output unchanged. Message is output digitally (default).
 "Alarm": Current output assumes the set alarm current.
 Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Off
 - Alarm
 - Warning
 - Logbook entry only

501 Event category

Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 501Event category

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

502 Diagnostic behavior

Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 502 Diag. behav.

Description

Select event behavior

"Logbook entry only":
no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.


- Selection**
- Off
 - Alarm
 - Warning
 - Logbook entry only

502 Event category



Navigation   Diagnostics → Diag. settings → Configuration → Configuration → 502Event category

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

"Process" submenu

Navigation  Diagnostics → Diag. settings → Configuration → Process


806 Diagnostic behavior 



Navigation   Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description Select event behavior
 "Logbook entry only": no digital or analog transmission of the message.
 "Warning": Current output unchanged. Message is output digitally (default).
 If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

806 Event category 


Navigation   Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

822 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

User interface

- Alarm
- Warning
- Logbook entry only

822 Event category

**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 822 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Sensor pressure range behavior

**Navigation**

Diagnostics → Diag. settings → Configuration → Process → P-range behavior

Description

Select event behavior

"Alarm":

Current output adopts the set alarm current.

"Warning":

Current output unchanged. Message is displayed digitally (factory setting).

"Logbook entry only":

No digital or analog forwarding of the message.

"Special":

– Lower sensor limit undercut: Current output < 3.6 mA.

– Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.

Selection

- Alarm
- Warning
- Logbook entry only
- Special

841 Event category

**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 841 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Event category



Navigation Diagnostics → Diag. settings → Configuration → Process → 900Event category

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior



Navigation Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.

Description Select event behavior
"Logbook entry only": no digital or analog transmission of the message.
"Warning": Current output unchanged. Message is output digitally (default).
If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

906 Diagnostic behavior



Navigation Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.

Description Select event behavior
"Logbook entry only": no digital or analog transmission of the message.
"Warning": Current output unchanged. Message is output digitally (default).
If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Warning
- Logbook entry only

906 Event category





Navigation Diagnostics → Diag. settings → Configuration → Process → 906Event category



Description Select category for diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

"Process" submenu

Navigation  Diagnostics → Diag. settings → Configuration → Process

806 Diagnostic behavior 

Navigation   Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description


Select event behavior



"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

806 Event category 


Navigation   Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description

Select category for diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)


822 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

- User interface**
- Alarm
 - Warning
 - Logbook entry only

822 Event category




Navigation  Diagnostics → Diag. settings → Configuration → Process → 822 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Sensor pressure range behavior



Navigation  Diagnostics → Diag. settings → Configuration → Process → P-range behavior

Description

Select event behavior

"Alarm":
Current output adopts the set alarm current.

"Warning":
Current output unchanged. Message is displayed digitally (factory setting).

"Logbook entry only":
No digital or analog forwarding of the message.

"Special":
– Lower sensor limit undercut: Current output < 3.6 mA.
– Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting.


Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.

Selection

- Alarm
- Warning
- Logbook entry only
- Special

841 Event category




Navigation  Diagnostics → Diag. settings → Configuration → Process → 841 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Event category



Navigation  Diagnostics → Diag. settings → Configuration → Process → 900Event category


Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior



Navigation  Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.

Description Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).


If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

906 Diagnostic behavior



Navigation  Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.

Description Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).


If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Warning
- Logbook entry only

906 Event category



Navigation  Diagnostics → Diag. settings → Configuration → Process → 906Event category

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

3.4 "Application" menu



Navigation  Application

3.4.1 "Measuring units" submenu

Navigation  Application → Measuring units

Pressure unit

Navigation

  Application → Measuring units → Pressure unit

Selection

SI units

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units


- psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

Decimal places pressure

Navigation

 Application → Measuring units → Decimal pressure

Description



This selection does not affect the measurement and calculation accuracy of the device.

Selection

- Automatic
The decimal place is configured automatically.
Example: Unit mbar: one decimal place. Unit bar: four decimal places
- x
- x.x
- x.xx
- x.xxx
- x.xxxx

Temperature unit

Navigation

  Application → Measuring units → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection	<i>SI units</i> <ul style="list-style-type: none">■ °C■ K	<i>US units</i> <ul style="list-style-type: none">°F
Factory setting	Country-specific: <ul style="list-style-type: none">■ °C■ °F	
Additional information	<i>Selection</i>	

Scaled variable unit

Navigation  Application → Measuring units → Scaled Unit

Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	<ul style="list-style-type: none"> ▪ % ▪ mm ▪ cm ▪ m ▪ l ▪ hl ▪ m³ ▪ g ▪ kg ▪ t ▪ g/s ▪ kg/s ▪ kg/min ▪ kg/h ▪ t/min ▪ t/h ▪ t/d ▪ m³/s ▪ m³/min ▪ m³/h ▪ m³/d ▪ l/s ▪ l/min ▪ l/h ▪ Nm³/h ▪ NI/h ▪ Sm³/s ▪ Sm³/min ▪ Sm³/h ▪ Sm³/d ▪ Nm³/s ▪ g/cm³ ▪ kg/m³ ▪ Nm³/min ▪ Nm³/d 	<ul style="list-style-type: none"> ▪ ft ▪ in ▪ ft³ ▪ gal (us) ▪ bbl (us;oil) ▪ oz ▪ lb ▪ STon ▪ lb/s ▪ lb/min ▪ lb/h ▪ STon/min ▪ STon/h ▪ STon/d ▪ ft³/s ▪ ft³/min ▪ ft³/h ▪ ft³/d ▪ gal/s (us) ▪ gal/min (us) ▪ gal/h (us) ▪ gal/d (us) ▪ bbl/s (us;oil) ▪ bbl/min (us;oil) ▪ bbl/h (us;oil) ▪ bbl/d (us;oil) ▪ Sft³/min ▪ Sft³/h ▪ Sft³/d 	<ul style="list-style-type: none"> ▪ gal (imp) ▪ gal/s (imp) ▪ gal/min (imp) ▪ gal/h (imp)
	<p><i>Custom-specific units</i></p> <p>Free text</p>		

Free text 

Navigation   Application → Measuring units → Free text

User entry Character string comprising numbers, letters and special characters (32)

Decimal places scaled variable 

Navigation  Application → Measuring units → Decimal scaled

Description This selection does not affect the measurement and calculation accuracy of the device.

Selection	<ul style="list-style-type: none"> ■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX
------------------	---

3.4.2 "Measured values" submenu

Navigation  Application → Measured values

Sensor pressure

Navigation   Application → Measured values → Sensor pressure

User interface Signed floating-point number

Pressure

Navigation   Application → Measured values → Pressure

Scaled variable

Navigation   Application → Measured values → Scaled variable


User interface Signed floating-point number

Sensor temperature

Navigation   Application → Measured values → Sensor temp.

User interface -273.15 to 9 726.85 °C

Terminal voltage 1

Navigation   Application → Measured values → Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V


Terminal current

Navigation  Application → Measured values → Terminal curr.

Description Shows the current value of the current output which is currently measured

User interface 0 to 30 mA

Electronics temperature

Navigation  Application → Measured values → Electronics temp

Description Displays the current temperature of the main electronics.

User interface Signed floating-point number

3.4.3 "Sensor" submenu

Navigation  Application → Sensor

"Basic settings" submenu

Navigation  Application → Sensor → Basic settings

Output current transfer function

Navigation  Application → Sensor → Basic settings → Curr. trans.func

Description Linear
The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit.

Square root - differential pressure only

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

- User interface**
- Linear
 - Square root *

Damping



Navigation Application → Sensor → Basic settings → Damping

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:
The Analog Input Block has its own “Damping” parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry 0 to 999.0 s

"Sensor calibration" submenu

Navigation Application → Sensor → Sensor cal.

Zero adjustment



Navigation Application → Sensor → Sensor cal. → Zero adjustment

Description

Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

- Selection**
- No
 - Confirm

Calibration offset



Navigation Application → Sensor → Sensor cal. → Calibr offset

Prerequisite Absolute pressure sensor

* Visibility depends on order options or device settings

Description Enter the value by which the measured value should be corrected, e.g., a position adjustment for absolute pressure sensors.

User entry Signed floating-point number

Zero adjustment offset

Navigation   Application → Sensor → Sensor cal. → Zero offset

User entry Signed floating-point number

Sensor Trim Reset

Navigation  Application → Sensor → Sensor cal. → Sen. Trim Reset

Selection

- No
- Confirm

Lower sensor trim measured value

Navigation  Application → Sensor → Sensor cal. → LowerTrimMeasVal

User interface Signed floating-point number

Lower sensor trim
**Navigation**

Application → Sensor → Sensor cal. → LowerSensor trim

Description

These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.

Note:

The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).

Proceed as follows:

- Apply reference pressure for lower range value ("LRV")
- Enter the measured reference pressure at "Lower sensor trim" and confirm
- Apply reference pressure for upper range value ("URV")
- Enter the measured reference pressure at "Upper sensor trim" and confirm
- The sensor is now calibrated

User entry

Signed floating-point number

Upper sensor trim measured value
Navigation

Application → Sensor → Sensor cal. → UpperTrimMeasVal

User interface

Signed floating-point number

**Upper sensor trim****Navigation**

Application → Sensor → Sensor cal. → UpperSensor trim

Description

These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.

Note:

The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).

Proceed as follows:

- Apply reference pressure for lower range value ("LRV")
- Enter the measured reference pressure at "Lower sensor trim" and confirm
- Apply reference pressure for upper range value ("URV")
- Enter the measured reference pressure at "Upper sensor trim" and confirm
- The sensor is now calibrated

User entry

Signed floating-point number

"Sensor limits" submenu

Navigation Application → Sensor → Sensor limits

Lower Range Limit**Navigation**

Application → Sensor → Sensor limits → LRL

Description

Indicates the lower measuring limit of the sensor.

User interface

Signed floating-point number

Upper Range Limit**Navigation**

Application → Sensor → Sensor limits → URL


Description

Indicates the upper measuring limit of the sensor.


User interface

Signed floating-point number


Minimum span

Navigation	 Application → Sensor → Sensor limits → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

Sensor temperature lower range limit

Navigation	 Application → Sensor → Sensor limits → Sens.temp.lo.lim
User interface	-273.15 to 9 726.85 °C

Sensor temperature upper range limit



Navigation	 Application → Sensor → Sensor limits → Sens.temp.up.lim
User interface	-273.15 to 9 726.85 °C

"Scaled variable" submenu

Navigation  Application → Sensor → Scaled variable

Assign PV



Navigation	  Application → Sensor → Scaled variable → Assign PV
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).
Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable

Scaled variable unit



Navigation

Application → Sensor → Scaled variable → Scaled Unit

Description

Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection

SI units

- %
- mm
- cm
- m
- l
- hl
- m³
- g
- kg
- t
- g/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- m³/s
- m³/min
- m³/h
- m³/d
- l/s
- l/min
- l/h
- Nm³/h
- NI/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

US units

- ft
- in
- ft³
- gal (us)
- bbl (us;oil)
- oz
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)

Custom-specific units

Free text

Free text



Navigation


Application → Sensor → Scaled variable → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Pressure

Navigation  Application → Sensor → Scaled variable → Pressure

Scaled variable transfer function 

Navigation  Application → Sensor → Scaled variable → Scaled function


Description "Linear"
The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.


"Square root" (Deltabar)
The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table"
The output is defined according to the scaled variable / pressure table entered.

Selection


- Linear
- Square root *
- Table


Lower range value output 

Navigation  Application → Sensor → Scaled variable → Low.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Upper range value output 

Navigation  Application → Sensor → Scaled variable → Upp.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

* Visibility depends on order options or device settings

Activate table

**Navigation**

Application → Sensor → Scaled variable → Activate table

Selection

- Disable
- Enable

Pressure value 1

**Navigation**

Application → Sensor → Scaled variable → Pressure 1

Description

Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry

Signed floating-point number

Scaled variable value 1

Navigation

Application → Sensor → Scaled variable → Scaled 1

Description

Enter value for the first scaling point. This value is allocated to "Pressure value 1".

User interface

Signed floating-point number

Pressure value 2

**Navigation**

Application → Sensor → Scaled variable → Pressure 2

Description

Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry

Signed floating-point number

Scaled variable value 2

**Navigation**


Application → Sensor → Scaled variable → Scaled 2

Description

Enter value for the second scaling point. This value is allocated to "Pressure value 2".

User entry

Signed floating-point number

Pressure 

Navigation  Application → Sensor → Scaled variable → Pressure

User entry Signed floating-point number

Scaled variable 

Navigation  Application → Sensor → Scaled variable → Scaled variable

User entry Signed floating-point number

"Wet calibration" submenu

Navigation  Application → Sensor → Wet calibration

Zero 

Navigation   Application → Sensor → Wet calibration → Zero

Selection

- No
- Confirm

Pressure value 1 

Navigation  Application → Sensor → Wet calibration → Pressure 1

Description Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry Signed floating-point number

Span 

Navigation   Application → Sensor → Wet calibration → Span

Selection

- No
- Confirm

Pressure value 2



Navigation	Application → Sensor → Wet calibration → Pressure 2
Description	Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.
User entry	Signed floating-point number

Lower range value output



Navigation	Application → Sensor → Wet calibration → Low.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

Upper range value output



Navigation	Application → Sensor → Wet calibration → Upp.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

"Wet calibration" submenu


Navigation Application → Sensor → Wet calibration


Zero





Navigation	Application → Sensor → Wet calibration → Zero
Selection	<ul style="list-style-type: none"> ■ No ■ Confirm


Pressure value 1 

Navigation	 Application → Sensor → Wet calibration → Pressure 1
Description	Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.
User entry	Signed floating-point number


Span 

Navigation	  Application → Sensor → Wet calibration → Span
Selection	<ul style="list-style-type: none"> ▪ No ▪ Confirm


Pressure value 2 

Navigation	 Application → Sensor → Wet calibration → Pressure 2
Description	Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.
User entry	Signed floating-point number

Lower range value output 


Navigation	 Application → Sensor → Wet calibration → Low.range outp
Description	Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

Upper range value output 

Navigation	 Application → Sensor → Wet calibration → Upp.range outp
Description	Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

3.4.4 "Current output" submenu

Navigation  Application → Curr.output

Assign PV

Navigation  Application → Curr.output → Assign PV

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Measuring mode current output

Navigation   Application → Curr.output → Output mode

Description Select curve of current output.

Selection

- Standard
- Inverse
- Bi-directional

Current range output

Navigation   Application → Curr.output → Current range

Description Defines the current range used to transmit the measured or calculated value. In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value ≤ "low saturation", the output current is set to "low saturation". If Measured value ≥ "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output

**Navigation**

Application → Curr.output → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output

**Navigation**

Application → Curr.output → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Failure behavior current output

**Navigation**

Application → Curr.output → Failure behav.

Description

Defines which current the output assumes in the case of an error.

Min: < 3.6 mA

Max: >21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current

**Navigation**

Application → Curr.output → Failure current


Description

Enter current output value in alarm condition


User entry

21.5 to 23 mA

Output current


Navigation	 Application → Curr.output → Output curr.
Description	Shows the value currently calculated for the current output
User interface	3.59 to 23 mA

Terminal current


Navigation	 Application → Curr.output → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA


4 mA trim value



Navigation	 Application → Curr.output → 4 mA trim value
Description	Enter the trim value for the 4 mA current output. Note: Simulation must be active.
User entry	3 to 5 mA

20 mA trim value












Navigation	 Application → Curr.output → 20 mA trim value
Description	Enter the trim value for the 20 mA current output. Note: Simulation must be active.
User entry	18 to 22 mA












3.4.5 "HART output" submenu

Navigation  Application → HART output

"Configuration" submenu

Navigation  Application → HART output → Configuration

HART address 	
Navigation	  Application → HART output → Configuration → HART address
Description	Define the HART address of the device.
User entry	0 to 63
Additional information	<ul style="list-style-type: none"> ■ The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode). ■ Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0. ■ All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.
HART short tag 	
Navigation	  Application → HART output → Configuration → HART short tag
Description	<p>Defines the short tag for the measuring point.</p> <p>Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters</p>
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).
Device tag 	
Navigation	  Application → HART output → Configuration → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (32)

No. of preambles		
Navigation	  Application → HART output → Configuration → No. of preambles	
Description	Defines the number of preambles in the HART telegram	
User entry	5 to 20	
Loop current mode		
Navigation	  Application → HART output → Configuration → Loop curr mode	
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.	
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable 	
"HART output" submenu		
	<i>Navigation</i>	 Application → HART output → HART output
Assign PV		
Navigation	  Application → HART output → HART output → Assign PV	
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).	
Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable 	
Primary variable (PV)		
Navigation	 Application → HART output → HART output → Primary var (PV)	
Description	Shows the first HART value (PV).	
Additional information		

Assign SV

**Navigation**

Application → HART output → HART output → Assign SV

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Secondary variable (SV)

Navigation

Application → HART output → HART output → Second.var(SV)

Description

Shows the second HART value (SV).

Assign TV

**Navigation**

Application → HART output → HART output → Assign TV

Description


Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

* Visibility depends on order options or device settings



- Selection**
- Pressure
 - Scaled variable
 - Sensor temperature
 - Sensor pressure
 - Electronics temperature
 - Terminal current^{*}
 - Terminal voltage^{*}
 - Median of pressure signal^{*}
 - Noise of pressure signal^{*}
 - Signal noise detected^{*}
 - Percent of range
 - Loop current
 - Not used

- Additional information** *Selection*
- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
 - **Terminal current** option
The terminal current is the read-back current on terminal block.
 - **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
 - **Loop current** option
The loop current is the output current set by the applied pressure.

Tertiary variable (TV)

- Navigation**  Application → HART output → HART output → Tertiary var(TV)
- Description** Shows the third HART value (TV).

Assign QV


- Navigation**   Application → HART output → HART output → Assign QV
- Description** Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).
- Selection**
- Pressure
 - Scaled variable
 - Sensor temperature
 - Sensor pressure
 - Electronics temperature
 - Terminal current^{*}
 - Terminal voltage^{*}
 - Median of pressure signal^{*}
 - Noise of pressure signal^{*}
 - Signal noise detected^{*}

* Visibility depends on order options or device settings


- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Quaternary variable (QV)**Navigation**
 Application → HART output → HART output → Quaterna.var(QV)
Description

Shows the fourth value (QV).

"Burst configuration 1" submenu
Navigation  Application → HART output → Burst config. 1
Burst mode 1**Navigation**
 Application → HART output → Burst config. 1 → Burst mode 1
Description

Use this function to select whether to activate the HART burst mode for burst message X.

Selection

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Additional information*Selection*

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

**Burst command 1**

Navigation	Application → HART output → Burst config. 1 → Burst command 1
Description	Use this function to select the HART command that is sent to the HART master.
Selection	<ul style="list-style-type: none"> ■ Primary variable (PV) ■ Loop Current and Percent of Range ■ Dynamic Variables ■ Device variables with status ■ Device variables ■ Additional device status
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Command 1 Read out the primary variable. ■ Command 2 Read out the current and the main measured value as a percentage. ■ Command 3 Read out the dynamic HART variables and the current. ■ Command 9 Read out the dynamic HART variables including the related status. ■ Command 33 Read out the dynamic HART variables including the related unit. ■ Command 48 Read out the complete device diagnostics. <p><i>"Command 33" option</i></p> <p>The HART device variables are defined via Command 107.</p> <p><i>Commands</i></p> <ul style="list-style-type: none"> ■ Information about the defined details of the command: HART specifications ■ The measured variables (HART device variables) are assigned to the dynamic variables in the Output submenu.

**Burst variable 0**

Navigation	Application → HART output → Burst config. 1 → Burst variable 0
Description	For HART command 9 and 33: select the HART device variable or the process variable.
Selection	<ul style="list-style-type: none"> ■ Pressure ■ Scaled variable ■ Sensor temperature ■ Sensor pressure ■ Electronics temperature ■ Measured current * ■ Terminal voltage 1 * ■ Median of pressure signal * ■ Noise of pressure signal *

* Visibility depends on order options or device settings

- Signal noise detected *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Additional information*Selection*

If a burst message is not configured, the **Not used** option is set.

Burst variable 1**Navigation**

Application → HART output → Burst config. 1 → Burst variable 1

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 89).

Burst variable 2**Navigation**

Application → HART output → Burst config. 1 → Burst variable 2

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 89).

Burst variable 3**Navigation**

Application → HART output → Burst config. 1 → Burst variable 3

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 89).


Burst variable 4**Navigation**

Application → HART output → Burst config. 1 → Burst variable 4


Description

For HART command 9: select the HART device variable or the process variable.


* Visibility depends on order options or device settings

Selection Please refer to the **Burst variable 0** parameter (→  89).


Burst variable 5

Navigation  Application → HART output → Burst config. 1 → Burst variable 5


Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→  89).


Burst variable 6

Navigation  Application → HART output → Burst config. 1 → Burst variable 6


Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→  89).


Burst variable 7

Navigation  Application → HART output → Burst config. 1 → Burst variable 7

Description For HART command 9: select the HART device variable or the process variable.

Selection Please refer to the **Burst variable 0** parameter (→  89).

Burst trigger mode





Navigation  Application → HART output → Burst config. 1 → Trigger mode

Description Use this function to select the event that triggers burst message X.


Selection

- Continuous
- Window^{*}
- Rising^{*}
- Falling^{*}
- On change

* Visibility depends on order options or device settings


Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→  92). ▪ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→  92). ▪ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→  92). ▪ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→  92). ▪ On change The message is sent if a measured value changes in the burst message.
-------------------------------	---

Burst trigger level



Navigation  Application → HART output → Burst config. 1 → Trigger level

Description Use this function to enter the burst trigger value.

User entry Signed floating-point number

Additional information *Description*
Together with the option selected in the **Burst trigger mode** parameter (→  91) the burst trigger value determines the time of burst message X.


Min. update period


Navigation  Application → HART output → Burst config. 1 → Min. upd. per.

Description Use this function to enter the minimum time span between two burst commands of burst message X.

User entry Positive integer


Max. update period


Navigation  Application → HART output → Burst config. 1 → Max. upd. per.

Description Use this function to enter the maximum time span between two burst commands of burst message X.

User entry Positive integer

"Information" submenu

Navigation  Application → HART output → Information

Device ID

Navigation  Application → HART output → Information → Device ID

Description Use this function to view the device ID for identifying the measuring device in a HART network.

User interface 6-digit hexadecimal number

Additional information *Description*



In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation  Application → HART output → Information → Device type

Description Displays the device type with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x54


Factory setting 0x5A

Additional information *Description*



The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Device revision

Navigation  Application → HART output → Information → Device revision

Description Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Additional information*Description*

The device revision is needed to assign the appropriate device description file (DD) to the device.

HART short tag**Navigation**

Application → HART output → Information → HART short tag

Description

Defines the short tag for the measuring point.

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

HART revision**Navigation**

Application → HART output → Information → HART revision

Description

Shows the HART revision of the device.

HART descriptor**Navigation**

Application → HART output → Information → HART descriptor

Description

Description for the measuring point.

User entry

Character string comprising numbers, letters and special characters (16)

HART message**Navigation**

Application → HART output → Information → HART message

Description

A HART message which is sent via the HART protocol when requested by the master.

User entry

Character string comprising numbers, letters and special characters (32)

HART date code

**Navigation**

Application → HART output → Information → HART date code

Description

Date of the last configuration change

User entry

Character string comprising numbers, letters and special characters (10)

Additional information

Date format: YYYY-MM-DD



Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

3.5 "System" menu

Navigation  System

3.5.1 "Device management" submenu

Navigation  System → Device manag.

Device tag

Navigation   System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Locking status

Navigation   System → Device manag. → Locking status

Description Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information *User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Configuration counter

Navigation

System → Device manag. → Config. counter

Description

Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65535, it restarts at 0.

User interface

0 to 65 535

Reset device

Navigation

System → Device manag. → Reset device

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to its factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting. This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

* Visibility depends on order options or device settings

3.5.2 "User management" submenu

Navigation  System → User manag.

User role


Navigation   System → User manag. → User role


Description Displays the access authorization to the parameters via the operating tool.

User interface


- Operator
- Maintenance
- Expert

Additional information *Description*


 Access authorization can be modified via the **Enter access code** parameter.

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Password

Navigation  System → User manag. → Password

Description Enter the password for the "Maintenance" user role to get access to the functionality of this role.

User entry Character string comprising numbers, letters and special characters (16)


Enter access code

Navigation  System → User manag. → Ent. access code


Description Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.

User entry 0 to 9999


Status password entry

Navigation	 System → User manag. → Status pw entry
Description	Use this function to display the status of the password verification.
User interface	<ul style="list-style-type: none"> ■ ----- ■ Wrong password ■ Password rule violated ■ Password accepted ■ Permission denied ■ Confirm PW mismatch ■ Reset password accepted ■ Invalid user role ■ Wrong sequence of entry


New password

Navigation	 System → User manag. → New password
Description	<p>Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers.</p>
User entry	Character string comprising numbers, letters and special characters (16)


Confirm new password

Navigation	 System → User manag. → Confirm password
Description	Enter the new password again to confirm.
User entry	Character string comprising numbers, letters and special characters (16)

Old password

Navigation	 System → User manag. → Old password
Description	Enter the current password, to subsequently change the existing password.
User entry	Character string comprising numbers, letters and special characters (16)



Reset password

Navigation	 System → User manag. → Reset password
Description	Enter a code to reset the current "Maintenance" password. The code is delivered by your local support.
User entry	Character string comprising numbers, letters and special characters (16)





3.5.3 "Display" submenu

Navigation  System → Display

Language





Navigation	  System → Display → Language
Prerequisite	A local display is provided.
Description	Use this function to select the configured language on the local display.
Selection	<ul style="list-style-type: none"> ▪ English ▪ Deutsch ▪ Français ▪ Español ▪ Italiano ▪ Nederlands ▪ Portuguesa ▪ Polski ▪ русский язык (Russian) ▪ Svenska ▪ Türkçe ▪ 中文 (Chinese) ▪ 日本語 (Japanese) ▪ 한국어 (Korean) ▪ Bahasa Indonesia ▪ tiếng Việt (Vietnamese) ▪ čeština (Czech)
Factory setting	English (alternatively, the ordered language is preset in the device)








Format display






Navigation	 System → Display → Format display
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	<ul style="list-style-type: none"> ▪ 1 value, max. size ▪ 1 bargraph + 1 value ▪ 2 values
Additional information	<p><i>Description</i></p> <p>The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.</p> <p> ▪ The Value 1 display parameter (→  101)...Value 8 display parameter Value 4 display parameter (→  103) are used to specify which measured values are shown on the local display and in what order.</p> <ul style="list-style-type: none"> ▪ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the Display interval parameter.

Value 1 display



Navigation	 System → Display → Value 1 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ▪ Pressure ▪ Scaled variable ▪ Current output ▪ Sensor temperature ▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  101) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>

Value 2 display 	
Navigation	  System → Display → Value 2 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ▪ None ▪ Pressure ▪ Scaled variable ▪ Current output ▪ Sensor temperature ▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  101) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>
Value 3 display 	

Navigation	  System → Display → Value 3 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ▪ None ▪ Pressure ▪ Scaled variable ▪ Current output ▪ Sensor temperature ▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  101) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>



Value 4 display



Navigation	System → Display → Value 4 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ■ None ■ Pressure ■ Scaled variable ■ Current output ■ Sensor temperature ■ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 101) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>

Contrast display

Navigation	System → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)
User entry	20 to 80 %
Factory setting	Depends on the display
Additional information	<p> Set the contrast via the push-buttons:</p> <ul style="list-style-type: none"> ■ Weaker: Press the and buttons simultaneously ■ Stronger: Press the and buttons simultaneously

3.5.4 "Geolocation" submenu

Navigation  System → Geolocation

Process Unit Tag 	
Navigation	 System → Geolocation → Process Unit Tag
Description	Enter the process unit in which the device is installed.
User entry	Character string comprising numbers, letters and special characters (32)
Location Description 	
Navigation	 System → Geolocation → Location Descr.
Description	Use this function to enter a description of the location so that the device can be located in the plant.
User entry	Character string comprising numbers, letters and special characters (32)
Longitude 	
Navigation	 System → Geolocation → Longitude
Description	Use this function to enter the longitude coordinates that describe the device location.
User entry	-180 to 180 °
Latitude 	
Navigation	 System → Geolocation → Latitude
Description	Use this function to enter the latitude coordinates that describe the device location.
User entry	-90 to 90 °

Altitude

**Navigation**

System → Geolocation → Altitude

Description

Use this function to enter the altitude data that describe the device location.

User entry

Signed floating-point number

Location method

**Navigation**

System → Geolocation → Location method

Description

Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183.

Selection

- No fix
- GPS or Standard Positioning Service fix
- Differential GPS fix
- Precise positioning service (PPS) fix
- Real Time Kinetic (RTK) fixed solution
- Real Time Kinetic (RTK) float solution
- Estimated dead reckoning
- Manual input mode
- Simulation Mode

3.5.5 "Information" submenu

Navigation System → Information

Device name

Navigation









System → Information → Device name

Description



Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface


Max. 32 characters such as letters or numbers.

Manufacturer	
Navigation	 System → Information → Manufacturer
User interface	Character string comprising numbers, letters and special characters
Serial number 	
Navigation	 System → Information → Serial number
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number <ul style="list-style-type: none"> ▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer
Order code 	
Navigation	 System → Information → Order code
Description	Shows the device order code.
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).
Factory setting	–
Additional information	<i>Description</i> The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.  Uses of the order code <ul style="list-style-type: none"> ▪ To order an identical spare device. ▪ To identify the device quickly and easily, e.g. when contacting Endress+Hauser.


Firmware version


Navigation	 System → Information → Firmware version
Description	Displays the device firmware version that is installed.
User interface	Character string in the format xx.yy.zz
Additional information	<p><i>User interface</i></p> <p> The Firmware version is also located:</p> <ul style="list-style-type: none"> ■ On the title page of the Operating instructions ■ On the transmitter nameplate

Hardware version


Navigation	 System → Information → Hardware version
User interface	Character string comprising numbers, letters and special characters



Extended order code 1



Navigation	 System → Information → Ext. order cd. 1
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
User interface	Character string
Factory setting	–
Additional information	<p><i>Description</i></p> <p>The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.</p>


Extended order code 2




Navigation	 System → Information → Ext. order cd. 2
Description	<p>The extended order code is an alphanumeric code containing all information to identify the device and its options.</p> <p> The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.</p>
User interface	Character string

Factory setting –

Extended order code 3

Navigation  System → Information → Ext. order cd. 3

Description The extended order code is an alphanumeric code containing all information to identify the device and its options.

 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface Character string

Factory setting –

XML build number

Navigation   System → Information → XML build no.

User interface Positive integer

Checksum

Navigation   System → Information → Checksum

Description Checksum for Firmware version.

User interface Positive integer


3.5.6 "Software configuration" submenu

Navigation  System → Softw. config.


Activate SW option

Navigation   System → Softw. config. → Activate SW opt.

Description Use this function to enter an activation code to enable an additional, ordered software option.

User entry	Max. 10-digit string of numbers.
Factory setting	Depends on the software option ordered
Additional information	<p><i>Description</i></p> <p>If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.</p> <p><i>User entry</i></p> <p> To activate a software option subsequently, please contact your Endress+Hauser sales organization.</p> <p>NOTE!</p> <p>The activation code is linked to the serial number of the measuring device and varies according to the device and software option.</p> <p>If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.</p> <ul style="list-style-type: none"> ▶ Before you enter a new activation code, make a note of the current activation code from the parameter protocol. ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered. ▶ If the code entered is incorrect or invalid, enter the old activation code from the parameter protocol. ▶ Have the Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again. <p><i>Example for a software option</i></p> <p>Order code for "Application package", option EA "Extended HistoROM"</p>

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options
User interface	<ul style="list-style-type: none"> ■ SIL ■ WHG ■ Heartbeat Verification ■ Heartbeat Monitoring

Index

- 0 ... 9**
- 4 mA trim value (Parameter) 83
 - 20 mA trim value (Parameter) 83
 - 500 Diagnostic behavior (Parameter) 56
 - 500 Event category (Parameter) 56
 - 500 Process alert pressure (Parameter) 52
 - 501 Diagnostic behavior (Parameter) 56
 - 501 Event category (Parameter) 57
 - 501 Process alert scaled variable (Parameter) 53
 - 502 Diagnostic behavior (Parameter) 57
 - 502 Event category (Parameter) 57
 - 806 Diagnostic behavior (Parameter) 55, 58, 61
 - 806 Event category (Parameter) 55, 58, 61
 - 806 Event delay (Parameter) 55
 - 822 Diagnostic behavior (Parameter) 58, 61
 - 822 Event category (Parameter) 59, 62
 - 841 Event category (Parameter) 59, 62
 - 900 Diagnostic behavior (Parameter) 60, 63
 - 900 Event category (Parameter) 60, 63
 - 906 Diagnostic behavior (Parameter) 60, 63
 - 906 Event category (Parameter) 60, 63
- A**
- Activate SW option (Parameter) 108
 - Activate table (Parameter) 77
 - Active diagnostics (Parameter) 44
 - Active diagnostics (Submenu) 44
 - Altitude (Parameter) 105
 - Application (Menu) 65
 - Assign HART variables? (Parameter) 39, 41
 - Assign PV (Parameter) 27, 41, 74, 81, 85
 - Assign QV (Parameter) 43, 87
 - Assign SV (Parameter) 42, 86
 - Assign TV (Parameter) 42, 86
- B**
- Basic settings (Submenu) 69
 - Burst command 1 (Parameter) 89
 - Burst configuration 1 (Submenu) 88
 - Burst mode 1 (Parameter) 88
 - Burst trigger level (Parameter) 92
 - Burst trigger mode (Parameter) 91
 - Burst variable 0 (Parameter) 89
 - Burst variable 1 (Parameter) 90
 - Burst variable 2 (Parameter) 90
 - Burst variable 3 (Parameter) 90
 - Burst variable 4 (Parameter) 90
 - Burst variable 5 (Parameter) 91
 - Burst variable 6 (Parameter) 91
 - Burst variable 7 (Parameter) 91
- C**
- Calibration offset (Parameter) 70
 - Checksum (Parameter) 108
 - Clear event list (Parameter) 46
 - Commissioning (Wizard) 23
 - Configuration (Submenu) 56, 84
 - Configuration counter (Parameter) 97
 - Confirm new password (Parameter) 99
 - Contrast display (Parameter) 103
 - Counter limit overruns sensor Pmax (Parameter) 49
 - Counter limit overruns sensor Tmax (Parameter) 50
 - Counter limit underruns sensor Pmin (Parameter) 47
 - Counter limit underruns sensor Tmin (Parameter) 48
 - Counter overruns of user limit Pmax (Parameter) 49
 - Counter overruns of user limit Tmax (Parameter) 50
 - Counter underruns of user limit Pmin (Parameter) 47
 - Counter underruns of user limit Tmin (Parameter) 48
 - Current output (Submenu) 81
 - Current range output (Parameter) 38, 40, 81
- D**
- Damping (Parameter) 27, 70
 - Decimal places pressure (Parameter) 65
 - Decimal places scaled variable (Parameter) 67
 - Description of device parameters 21
 - Device ID (Parameter) 93
 - Device identification (Wizard) 23, 25, 26
 - Device management (Submenu) 96
 - Device name (Parameter) 23, 105
 - Device revision (Parameter) 93
 - Device tag (Parameter) 23, 84, 96
 - Device type (Parameter) 93
 - Diagnostic event simulation (Parameter) 51
 - Diagnostic settings (Submenu) 52
 - Diagnostics (Menu) 44
 - Display (Submenu) 100
 - Document
 - Explanation of the structure of a parameter
 - description 4
 - Function 4
 - Structure 4
 - Symbols used 5
 - Target group 4
 - Using the document 4
 - Document function 4
- E**
- Electronics temperature (Parameter) 69
 - Enter access code (Parameter) 98
 - Event logbook (Submenu) 46
 - Extended order code 1 (Parameter) 24, 107
 - Extended order code 2 (Parameter) 24, 107
 - Extended order code 3 (Parameter) 24, 108
- F**
- Failure behavior current output (Parameter) 38, 40, 82
 - Failure current (Parameter) 38, 41, 82
 - Filter options (Parameter) 46
 - Firmware version (Parameter) 107
 - Format display (Parameter) 101
 - Free text (Parameter) 30, 67, 75

- Function
 see Parameter
- G**
Geolocation (Submenu) 104
Guidance (Menu) 21, 23
- H**
Hardware version (Parameter) 107
HART address (Parameter) 27, 84
HART date code (Parameter) 26, 95
HART descriptor (Parameter) 26, 94
HART message (Parameter) 26, 94
HART output (Submenu) 84, 85
HART revision (Parameter) 94
HART short tag (Parameter) 26, 84, 94
High alert value (Parameter) 53, 54
- I**
Information (Submenu) 93, 105
- L**
Language (Parameter) 100
Latitude (Parameter) 104
Location Description (Parameter) 104
Location method (Parameter) 105
Locking status (Parameter) 25, 96
Longitude (Parameter) 104
Loop current mode (Parameter) 39, 41, 85
Low alert value (Parameter) 53, 54
Lower Range Limit (Parameter) 33, 35, 37, 73
Lower range value output (Parameter)
. 34, 37, 40, 76, 79, 80, 82
Lower sensor trim (Parameter) 72
Lower sensor trim measured value (Parameter) 71
- M**
Manufacturer (Parameter) 106
Max. update period (Parameter) 92
Maximum electronics temperature (Parameter) 50
Maximum sensor temperature (Parameter) 49
Maximum terminal voltage (Parameter) 50
Measured values (Submenu) 68
Measurement adjustments (Wizard) 27, 28, 29, 31
Measuring mode current output (Parameter) 81
Measuring units (Submenu) 65
Menu
 Application 65
 Diagnostics 44
 Guidance 21, 23
 System 96
Min. update period (Parameter) 92
Minimum electronics temperature (Parameter) 48
Minimum sensor temperature (Parameter) 48
Minimum span (Parameter) 33, 35, 37, 74
Minimum terminal voltage (Parameter) 48
Minimum/maximum values (Submenu) 47
- N**
New password (Parameter) 99
- No. of preambles (Parameter) 85
- O**
Old password (Parameter) 99
Operating time (Parameter) 46
Operating time from restart (Parameter) 45
Order code (Parameter) 106
Output current (Parameter) 83
Output current transfer function (Parameter) 32, 69
Output settings (Wizard) 32, 33, 34, 35, 37, 39, 41
- P**
Parameter
 Structure of a parameter description 4
Password (Parameter) 98
Pressure (Parameter) 32, 34, 68, 76, 78
Pressure max (Parameter) 49
Pressure min (Parameter) 47
Pressure unit (Parameter) 28, 29, 65
Pressure value 1 (Parameter) 36, 77, 78, 80
Pressure value 2 (Parameter) 36, 77, 79, 80
Previous diagnostics (Parameter) 45
Primary variable (PV) (Parameter) 85
Process (Submenu) 58, 61
Process Unit Tag (Parameter) 104
Process variable output current (Parameter) 39
Properties (Submenu) 52
- Q**
Quaternary variable (QV) (Parameter) 88
- R**
Reset device (Parameter) 97
Reset password (Parameter) 100
Reset user defined counters P and T (Parameter) 49
- S**
Scaled variable (Parameter) 34, 68, 78
Scaled variable (Submenu) 74
Scaled variable transfer function (Parameter) 32, 35, 76
Scaled variable unit (Parameter) 29, 66, 75
Scaled variable value 1 (Parameter) 36, 77
Scaled variable value 2 (Parameter) 36, 77
Secondary variable (SV) (Parameter) 86
Sensor (Submenu) 69
Sensor calibration (Submenu) 70
Sensor limits (Submenu) 73
Sensor pressure (Parameter) 68
Sensor pressure range behavior (Parameter) 59, 62
Sensor temperature (Parameter) 68
Sensor temperature lower range limit (Parameter) 74
Sensor temperature upper range limit (Parameter) 74
Sensor Trim Reset (Parameter) 71
Serial number (Parameter) 23, 106
Simulation (Parameter) 51
Simulation (Submenu) 51
Software configuration (Submenu) 108
Software option overview (Parameter) 109
Span (Parameter) 78, 80
SSD Monitoring delay time (Parameter) 52

SSD Out of range delay time (Parameter) 52
 Status password entry (Parameter) 99
 Submenu
 Active diagnostics 44
 Basic settings 69
 Burst configuration 1 88
 Configuration 56, 84
 Current output 81
 Device management 96
 Diagnostic settings 52
 Display 100
 Event logbook 46
 Geolocation 104
 HART output 84, 85
 Information 93, 105
 Measured values 68
 Measuring units 65
 Minimum/maximum values 47
 Process 58, 61
 Properties 52
 Scaled variable 74
 Sensor 69
 Sensor calibration 70
 Sensor limits 73
 Simulation 51
 Software configuration 108
 User management 98
 Wet calibration 78, 79
 System (Menu) 96

T

Target group 4
 Temperature unit (Parameter) 28, 30, 65
 Terminal current (Parameter) 69, 83
 Terminal voltage 1 (Parameter) 68
 Tertiary variable (TV) (Parameter) 87
 Timestamp (Parameter) 44, 45

U

Upper Range Limit (Parameter) 33, 35, 37, 73
 Upper range value output (Parameter)
 34, 38, 40, 76, 79, 80, 82
 Upper sensor trim (Parameter) 73
 Upper sensor trim measured value (Parameter) 72
 User management (Submenu) 98
 User role (Parameter) 98
 User temperature process alert (Parameter) 54

V

Value 1 display (Parameter) 101
 Value 2 display (Parameter) 102
 Value 3 display (Parameter) 102
 Value 4 display (Parameter) 103
 Value current output (Parameter) 51
 Value pressure simulation (Parameter) 51

W

Wet calibration (Submenu) 78, 79
 Wizard
 Commissioning 23

Device identification 23, 25, 26
 Measurement adjustments 27, 28, 29, 31
 Output settings 32, 33, 34, 35, 37, 39, 41

X

XML build number (Parameter) 108

Z

Zero (Parameter) 78, 79
 Zero adjustment (Parameter) 31, 70
 Zero adjustment offset (Parameter) 71



71647903

www.addresses.endress.com
