

Description of Device Parameters

Deltabar PMD55B

Differential pressure measurement
HART




Table of contents

1	About this document	4
1.1	Document function	4
1.2	Target group	4
1.3	Using this document	4
1.4	Symbols used	5
1.5	Documentation	5
2	Overview of the operating menu	6
3	Description of device parameters ...	21
3.1	User navigation	21
3.2	"Guidance" menu	23
3.3	"Diagnostics" menu	45
3.4	"Application" menu	66
3.5	"System" menu	97
Index	111

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and parameters that are available when the "Maintenance" option user role is enabled.

 For the operating concept of the operating menus, see the Operating Instructions.

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of Information

Additional information: 

Reference to documentation: 

Operation via local display: 

Operation via operating tool: 

Write-protected parameter: 

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

 The Operating Instructions are available via the Internet: www.endress.com → Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

 The Special Documentation is available via the Internet: www.endress.com → Download

2 Overview of the operating menu

Guidance	→ 21
▶ Commissioning	→ 23
▶ Device identification	→ 23
Device tag	→ 23
Device name	→ 23
Serial number	→ 23
Extended order code 1	→ 24
Extended order code 2	→ 24
Extended order code 3	→ 24
▶ Device identification	→ 25
Locking status	→ 25
▶ Device identification	→ 26
HART short tag	→ 26
HART date code	→ 26
HART descriptor	→ 26
HART message	→ 26
HART address	→ 27
▶ Measurement adjustments	→ 27
Assign PV	→ 27
Damping	→ 27
▶ Measurement adjustments	→ 28
Pressure unit	→ 28
Temperature unit	→ 28
▶ Measurement adjustments	→ 29

Pressure unit	→ 29
Scaled variable unit	→ 29
Free text	→ 30
Temperature unit	→ 30
► Measurement adjustments	→ 31
Zero adjustment	→ 31
Pressure	→ 32
► Output settings	→ 32
Output current transfer function	→ 32
Low flow cut off	→ 32
► Output settings	→ 33
Scaled variable transfer function	→ 33
Low flow cut off	→ 33
► Output settings	→ 33
Lower Range Limit	→ 33
Upper Range Limit	→ 34
Minimum span	→ 34
► Output settings	→ 34
Pressure	→ 34
Scaled variable	→ 34
► Output settings	→ 35
Lower range value output	→ 35
Upper range value output	→ 35
Lower Range Limit	→ 35

Upper Range Limit	→ 35
Minimum span	→ 36
► Output settings	→ 36
Scaled variable transfer function	→ 36
Pressure value 1	→ 36
Scaled variable value 1	→ 37
Pressure value 2	→ 37
Scaled variable value 2	→ 37
Lower Range Limit	→ 37
Upper Range Limit	→ 37
Minimum span	→ 38
► Output settings	→ 38
Lower range value output	→ 38
Upper range value output	→ 38
Current range output	→ 38
Failure behavior current output	→ 39
Failure current	→ 39
Loop current mode	→ 39
Assign HART variables?	→ 39
► Output settings	→ 40
Process variable output current	→ 40
Current range output	→ 40
Lower range value output	→ 40
Upper range value output	→ 41
Failure behavior current output	→ 41

Failure current	→ 41
Loop current mode	→ 41
Assign HART variables?	→ 42
► Output settings	→ 42
Assign PV	→ 42
Assign SV	→ 42
Assign TV	→ 43
Assign QV	→ 44
Diagnostics	→ 45
► Active diagnostics	→ 45
Active diagnostics	→ 45
Timestamp	→ 45
Previous diagnostics	→ 46
Timestamp	→ 46
Operating time from restart	→ 46
Operating time	→ 47
► Event logbook	→ 47
Filter options	→ 47
► Minimum/maximum values	→ 48
Pressure min	→ 48
Counter limit underruns sensor Pmin	→ 48
Counter underruns of user limit Pmin	→ 48
Minimum sensor temperature	→ 49
Counter limit underruns sensor Tmin	→ 49
Counter underruns of user limit Tmin	→ 49

Minimum terminal voltage	→ 49
Minimum electronics temperature	→ 49
Reset user defined counters P and T	→ 50
Pressure max	→ 50
Counter limit overruns sensor Pmax	→ 50
Counter overruns of user limit Pmax	→ 50
Maximum sensor temperature	→ 50
Counter limit overruns sensor Tmax	→ 51
Counter overruns of user limit Tmax	→ 51
Maximum terminal voltage	→ 51
Maximum electronics temperature	→ 51
► Simulation	→ 52
Simulation	→ 52
Value pressure simulation	→ 52
Value current output	→ 52
Diagnostic event simulation	→ 52
► Diagnostic settings	→ 53
► Properties	→ 53
SSD Out of range delay time	→ 53
SSD Monitoring delay time	→ 53
500 Process alert pressure	→ 53
Low alert value	→ 54
High alert value	→ 54
501 Process alert scaled variable	→ 54
Low alert value	→ 54

High alert value	→ 55
User temperature process alert	→ 55
Low alert value	→ 55
High alert value	→ 55
806 Diagnostic behavior	→ 56
806 Diagnostic behavior	→ 56
806 Event category	→ 56
806 Event category	→ 56
806 Event delay	→ 56
▶ Configuration	→ 57
▶ Configuration	→ 57
500 Diagnostic behavior	→ 57
500 Event category	→ 57
501 Diagnostic behavior	→ 57
501 Event category	→ 58
501 Event category	→ 58

501 Event category	→ 58
501 Event category	→ 58
502 Diagnostic behavior	→ 58
502 Event category	→ 58
► Process	→ 59
806 Diagnostic behavior	→ 59
806 Event category	→ 59
822 Diagnostic behavior	→ 59
822 Event category	→ 60

Sensor pressure range behavior	→ 60
841 Event category	→ 60
900 Event category	→ 61
900 Diagnostic behavior	→ 61
906 Event category	→ 61
Application	→ 66
► Measuring units	→ 66
Pressure unit	→ 66
Decimal places pressure	→ 66
Temperature unit	→ 66
Scaled variable unit	→ 67

Free text	→ 68
Decimal places scaled variable	→ 68
► Measured values	→ 69
Pressure	→ 69
Scaled variable	→ 69
Sensor temperature	→ 69
Terminal voltage 1	→ 69
Terminal current	→ 70
Electronics temperature	→ 70
► Sensor	→ 70
► Basic settings	→ 70
Output current transfer function	→ 70
Damping	→ 71
HP/LP swap	→ 71
Low flow cut off	→ 71
► Sensor calibration	→ 72
Zero adjustment	→ 72
Calibration offset	→ 72
Zero adjustment offset	→ 72
Sensor Trim Reset	→ 72
Lower sensor trim measured value	→ 73
Lower sensor trim	→ 73
Upper sensor trim measured value	→ 73
Upper sensor trim	→ 74

▶ Sensor limits	→ 74
Lower Range Limit	→ 74
Upper Range Limit	→ 74
Minimum span	→ 75
Sensor temperature lower range limit	→ 75
Sensor temperature upper range limit	→ 75
▶ Scaled variable	→ 75
Assign PV	→ 75
Scaled variable unit	→ 76
Free text	→ 76
Pressure	→ 77
Scaled variable transfer function	→ 77
Lower range value output	→ 77
Upper range value output	→ 77
Activate table	→ 78
Pressure value 1	→ 78
Scaled variable value 1	→ 78
Pressure value 2	→ 78
Scaled variable value 2	→ 78
Low flow cut off	→ 79
Pressure	→ 79
Scaled variable	→ 79
▶ Wet calibration	→ 79
Zero	→ 79
Pressure value 1	→ 79

Span	→ ↗ 80
Pressure value 2	→ ↗ 80
Zero	→ ↗ 79
Lower range value output	→ ↗ 80
Span	→ ↗ 80
Upper range value output	→ ↗ 80
► Current output	→ ↗ 82
Assign PV	→ ↗ 82
Measuring mode current output	→ ↗ 82
Current range output	→ ↗ 83
Lower range value output	→ ↗ 83
Upper range value output	→ ↗ 83
Failure behavior current output	→ ↗ 83
Failure current	→ ↗ 84
Output current	→ ↗ 84
Terminal current	→ ↗ 84
► HART output	→ ↗ 85
► Configuration	→ ↗ 85
HART address	→ ↗ 85
HART short tag	→ ↗ 85
Device tag	→ ↗ 85
No. of preambles	→ ↗ 86
Loop current mode	→ ↗ 86
► HART output	→ ↗ 86
Assign PV	→ ↗ 86

Primary variable (PV)	→ 87
Assign SV	→ 87
Secondary variable (SV)	→ 87
Assign TV	→ 88
Tertiary variable (TV)	→ 88
Assign QV	→ 88
Quaternary variable (QV)	→ 89
► Burst configuration 1	
Burst mode 1	→ 89
Burst command 1	→ 90
Burst variable 0	→ 91
Burst variable 1	→ 91
Burst variable 2	→ 91
Burst variable 3	→ 92
Burst variable 4	→ 92
Burst variable 5	→ 92
Burst variable 6	→ 92
Burst variable 7	→ 92
Burst trigger mode	→ 93
Burst trigger level	→ 93
Min. update period	→ 93
Max. update period	→ 94
► Information	
Device ID	→ 94
Device type	→ 94

	Device revision	→ 95
	HART short tag	→ 95
	HART revision	→ 95
	HART descriptor	→ 95
	HART message	→ 96
	HART date code	→ 96
System		→ 97
	► Device management	→ 97
	Device tag	→ 97
	Locking status	→ 97
	Configuration counter	→ 98
	Reset device	→ 98
	► User management	→ 99
	User role	→ 99
	Password	→ 99
	Enter access code	→ 99
	Status password entry	→ 100
	New password	→ 100
	Confirm new password	→ 100
	Status password entry	→ 100
	Old password	→ 100
	New password	→ 100
	Confirm new password	→ 100
	Status password entry	→ 100
	Reset password	→ 101

Status password entry	→ 100
Old password	→ 100
Status password entry	→ 100
► Display	→ 101
Language	→ 101
Format display	→ 102
Value 1 display	→ 102
Value 2 display	→ 103
Value 3 display	→ 103
Value 4 display	→ 104
Contrast display	→ 104
► Geolocation	→ 105
Process Unit Tag	→ 105
Location Description	→ 105
Longitude	→ 105
Latitude	→ 105
Altitude	→ 106
Location method	→ 106
► Information	→ 106
Device name	→ 106
Manufacturer	→ 107
Serial number	→ 107
Order code	→ 107
Firmware version	→ 108
Hardware version	→ 108

Extended order code 1	→ 108
Extended order code 2	→ 108
Extended order code 3	→ 109
Checksum	→ 109
► Software configuration	→ 109
Activate SW option	→ 109
Software option overview	→ 110

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the operating tool.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

3.1 User navigation

The Guidance main menu contains functions which enable users to perform basic tasks swiftly, e.g. commissioning.

These are primarily guided wizards and cross-subject special functions.

Navigation  *Guidance*

3.1.1 Overview of the operating menu

"Guidance" menu

Commissioning (→  23)

"Diagnostics" menu

- Active diagnostics (→  45)
- Event logbook (→  47)
- Minimum/maximum values (→  48)
- Simulation (→  52)
- Diagnostic settings (→  53)

"Application" menu

- Measuring units (→  66)
- Measured values (→  69)
- Sensor (→  70)
- Current output (→  82)
- HART output (→  85)

"System" menu

- Device management (→  97)
- User management (→  99)
- Bluetooth configuration
- Display (→  101)
- Geolocation (→  105)
- Information (→  94)
- Software configuration (→  109)

3.1.2 Commissioning

Run this wizard to put the device into operation. Enter the appropriate value in each parameter or select the appropriate option.

i If the wizard is canceled before all the necessary parameters have been configured, any settings already made are saved. For this reason, the device may then be in an undefined state!

In such situations, it is advisable to reset the device to the factory default settings.

The following parameters are configured in the Commissioning wizard:

- Device identification (→ [23](#))
 - Device tag (→ [23](#))
 - Device name (→ [23](#))
 - Serial number (→ [23](#))
 - Extended order code 1 (→ [24](#))
 - Extended order code 2 (→ [24](#))
 - Extended order code 3 (→ [24](#))
 - Locking status (→ [25](#))
 - HART short tag (→ [26](#))
 - HART date code (→ [26](#))
 - HART descriptor (→ [26](#))
 - HART message (→ [26](#))
 - HART address (→ [27](#))
- Measurement adjustments (→ [27](#))
 - Assign PV (→ [27](#))
 - Damping (→ [27](#))
 - Pressure unit (→ [28](#))
 - Temperature unit (→ [28](#))
 - Scaled variable unit (→ [29](#))
 - Zero adjustment (→ [31](#))
 - Pressure (→ [32](#))
- Output settings (→ [32](#))
 - Output current transfer function (→ [32](#))
 - Low flow cut off (→ [32](#))
 - Lower Range Limit (→ [33](#))
 - Upper Range Limit (→ [34](#))
 - Minimum span (→ [34](#))
 - Pressure (→ [34](#))
 - Scaled variable (→ [34](#))
 - Lower range value output (→ [35](#))
 - Upper range value output (→ [35](#))
 - Scaled variable transfer function (→ [33](#))
 - Pressure value 1 (→ [36](#))
 - Current range output (→ [38](#))
 - Failure behavior current output (→ [39](#))
 - Failure current (→ [39](#))
 - Loop current mode (→ [39](#))
 - Assign HART variables? (→ [39](#))
 - Process variable output current (→ [40](#))
 - Assign PV (→ [27](#))
 - Assign SV (→ [42](#))
 - Assign TV (→ [43](#))
 - Assign QV (→ [44](#))

3.2 "Guidance" menu

Navigation  Guidance

3.2.1 "Commissioning" wizard

Navigation  Guidance → Commissioning

"Device identification" wizard

Navigation  Guidance → Commissioning → Device ident.

Device tag



Navigation  Guidance → Commissioning → Device ident. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Device name

Navigation  Guidance → Commissioning → Device ident. → Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Serial number



Navigation  Guidance → Commissioning → Device ident. → Serial number

Description Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Extended order code 1**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 1

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface

Character string

Factory setting

–

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 2

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

–

Extended order code 3**Navigation**

Guidance → Commissioning → Device ident. → Ext. order cd. 3

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

-

"Device identification" wizard*Navigation*

Guidance → Commissioning → Device ident.

Locking status**Navigation**

Guidance → Commissioning → Device ident. → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

*Selection**Function scope of the "Locking status" parameter*

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

"Device identification" wizard**Navigation**

Guidance → Commissioning → Device ident.

HART short tag**Navigation**

Guidance → Commissioning → Device ident. → HART short tag

Description

Defines the short tag for the measuring point.

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

HART date code**Navigation**

Guidance → Commissioning → Device ident. → HART date code

Description

Date of the last configuration change

User entry

Character string comprising numbers, letters and special characters (10)

Additional information

Date format: YYYY-MM-DD

Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

HART descriptor**Navigation**

Guidance → Commissioning → Device ident. → HART descriptor

Description

Description for the measuring point.

User entry

Character string comprising numbers, letters and special characters (16)

HART message**Navigation**

Guidance → Commissioning → Device ident. → HART message

Description

A HART message which is sent via the HART protocol when requested by the master.

User entry

Character string comprising numbers, letters and special characters (32)

HART address**Navigation**

Guidance → Commissioning → Device ident. → HART address

Description

Define the HART address of the device.

User entry

0 to 63

Additional information

- The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode).
- Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0.
- All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.

"Measurement adjustments" wizard*Navigation* Guidance → Commissioning → Meas. adjust.

Assign PV**Navigation**

Guidance → Commissioning → Meas. adjust. → Assign PV

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Damping**Navigation**

Guidance → Commissioning → Meas. adjust. → Damping

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own "Damping" parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry

0 to 999.0 s

"Measurement adjustments" wizard*Navigation*

Guidance → Commissioning → Meas. adjust.

Pressure unit**Navigation**

Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection*SI units*

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

Temperature unit**Navigation**

Guidance → Commissioning → Meas. adjust. → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection*SI units*

- °C
- K

US units

°F

Factory setting

Country-specific:

- °C
- °F

Additional information*Selection*

"Measurement adjustments" wizard*Navigation*

Guidance → Commissioning → Meas. adjust.

**Pressure unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Pressure unit

Selection*SI units*

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

- psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

**Scaled variable unit****Navigation**

Guidance → Commissioning → Meas. adjust. → Scaled Unit

Description

Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection

SI units

- %
- mm
- cm
- m
- l
- hl
- m³
- g
- kg
- t
- g/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- m³/s
- m³/min
- m³/h
- m³/d
- l/s
- l/min
- l/h
- Nm³/h
- NI/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

US units

- ft
- in
- ft³
- gal (us)
- bbl (us;oil)
- oz
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)

Custom-specific units

Free text

Free text**Navigation**

Guidance → Commissioning → Meas. adjust. → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Temperature unit**Navigation**

Guidance → Commissioning → Meas. adjust. → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection	<i>SI units</i>	<i>US units</i>
	■ °C	°F
	■ K	
Factory setting	Country-specific:	
	■ °C	
	■ °F	
Additional information	<i>Selection</i>	

"Measurement adjustments" wizard

Navigation



Guidance → Commissioning → Meas. adjust.

Zero adjustment



Navigation Guidance → Commissioning → Meas. adjust. → Zero adjustment

Description Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Pressure

Navigation

█ Guidance → Commissioning → Meas. adjust. → Pressure

"Output settings" wizard

Navigation

█ Guidance → Commissioning → Output settings

Output current transfer function

Navigation

█ Guidance → Commissioning → Output settings → Curr. trans.func

Description

Linear

The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit.

Square root - differential pressure only

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

User interface

- Linear
- Square root *

Low flow cut off



Navigation

█ Guidance → Commissioning → Output settings → Low flow cut off

Description

When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.

User entry

0.0 to 50.0 %

* Visibility depends on order options or device settings

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

**Scaled variable transfer function****Navigation**

Guidance → Commissioning → Output settings → Scaled function

Description**"Linear'**

The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.

"Square root" (Deltabar)

The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table'

The output is defined according to the scaled variable / pressure table entered.

Selection

- Linear
- Square root *
- Table

**Low flow cut off****Navigation**

Guidance → Commissioning → Output settings → Low flow cut off

Description

When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.

User entry

0.0 to 50.0 %

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

**Lower Range Limit****Navigation**

Guidance → Commissioning → Output settings → LRL

Description

Indicates the lower measuring limit of the sensor.

* Visibility depends on order options or device settings

User interface Signed floating-point number

Upper Range Limit

Navigation  Guidance → Commissioning → Output settings → URL

Description Indicates the upper measuring limit of the sensor.

User interface Signed floating-point number

Minimum span

Navigation  Guidance → Commissioning → Output settings → Minimum span

Description Specifies the smallest possible measuring span of the sensor.

User interface Signed floating-point number

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Pressure



Navigation  Guidance → Commissioning → Output settings → Pressure

User entry Signed floating-point number

Scaled variable



Navigation  Guidance → Commissioning → Output settings → Scaled variable

User entry Signed floating-point number

"Output settings" wizard**Navigation**

Guidance → Commissioning → Output settings

**Lower range value output****Navigation**

Guidance → Commissioning → Output settings → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

**Upper range value output****Navigation**

Guidance → Commissioning → Output settings → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Lower Range Limit**Navigation**

Guidance → Commissioning → Output settings → LRL

Description

Indicates the lower measuring limit of the sensor.

User interface

Signed floating-point number

Upper Range Limit**Navigation**

Guidance → Commissioning → Output settings → URL

Description

Indicates the upper measuring limit of the sensor.

User interface

Signed floating-point number

Minimum span

Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Scaled variable transfer function

Navigation	 Guidance → Commissioning → Output settings → Scaled function
Description	<p>"Linear" The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.</p> <p>"Square root" (Deltabar) The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.</p> <p>"Table" The output is defined according to the scaled variable / pressure table entered.</p>
Selection	<ul style="list-style-type: none">■ Linear■ Square root *■ Table

Pressure value 1

Navigation	 Guidance → Commissioning → Output settings → Pressure 1
Description	Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Scaled variable value 1

Navigation  Guidance → Commissioning → Output settings → Scaled 1

Description Enter value for the first scaling point. This value is allocated to "Pressure value 1".

User interface Signed floating-point number

Pressure value 2

Navigation  Guidance → Commissioning → Output settings → Pressure 2

Description Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry Signed floating-point number

Scaled variable value 2

Navigation  Guidance → Commissioning → Output settings → Scaled 2

Description Enter value for the second scaling point. This value is allocated to "Pressure value 2".

User entry Signed floating-point number

Lower Range Limit

Navigation  Guidance → Commissioning → Output settings → LRL

Description Indicates the lower measuring limit of the sensor.

User interface Signed floating-point number

Upper Range Limit

Navigation  Guidance → Commissioning → Output settings → URL

Description Indicates the upper measuring limit of the sensor.

User interface Signed floating-point number

Minimum span

Navigation	 Guidance → Commissioning → Output settings → Minimum span
Description	Specifies the smallest possible measuring span of the sensor.
User interface	Signed floating-point number

"Output settings" wizard

Navigation  Guidance → Commissioning → Output settings

Lower range value output

Navigation	 Guidance → Commissioning → Output settings → Low.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

Upper range value output

Navigation	 Guidance → Commissioning → Output settings → Upp.range outp
Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
User entry	Signed floating-point number

Current range output

Navigation	 Guidance → Commissioning → Output settings → Current range
Description	Defines the current range used to transmit the measured or calculated value. In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value ≤ "low saturation", the output current is set to "low saturation". If Measured value ≥ "high saturation", the output current is set to "high saturation".
<p>Note: Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.</p>	

Selection	<ul style="list-style-type: none">■ 4...20 mA (4...20.5 mA)■ 4...20 mA NE (3.8...20.5 mA)■ 4...20 mA US (3.9...20.8 mA)
------------------	---

Failure behavior current output



Navigation	Guidance → Commissioning → Output settings → Failure behav.
-------------------	---

Description	Defines which current the output assumes in the case of an error.
--------------------	---

Min: < 3.6 mA

Max: > 21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection	<ul style="list-style-type: none">■ Min.■ Max.
------------------	---

Failure current



Navigation	Guidance → Commissioning → Output settings → Failure current
-------------------	--

Description	Enter current output value in alarm condition
--------------------	---

User entry	21.5 to 23 mA
-------------------	---------------

Loop current mode

Navigation	Guidance → Commissioning → Output settings → Loop curr mode
-------------------	---

Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
--------------------	--

User interface	<ul style="list-style-type: none">■ Disable■ Enable
-----------------------	--

Assign HART variables?

Navigation	Guidance → Commissioning → Output settings → Assign HART var?
-------------------	---

Description	Up to four HART variables can be transmitted via the HART protocol.
--------------------	---

Select "Yes" to show/assign measuring variables to these HART variables.

Selection

- No
- Yes

"Output settings" wizard*Navigation*

Guidance → Commissioning → Output settings

Process variable output current**Navigation**

Guidance → Commissioning → Output settings → Proc.var.curr.

Description

Determines which process variable is transmitted via the current output.

User interface

- Pressure
- Scaled variable

Current range output**Navigation**

Guidance → Commissioning → Output settings → Current range

Description

Defines the current range used to transmit the measured or calculated value.
In brackets are indicated the "low saturation value" and the "high saturation value".
If Measured value \leq "low saturation", the output current is set to "low saturation".
If Measured value \geq "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output**Navigation**

Guidance → Commissioning → Output settings → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current ", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output

Navigation Guidance → Commissioning → Output settings → Upp.range outp

Description Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry Signed floating-point number

Failure behavior current output

Navigation Guidance → Commissioning → Output settings → Failure behav.

Description Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: > 21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection
■ Min.
■ Max.

Failure current

Navigation Guidance → Commissioning → Output settings → Failure current

Description Enter current output value in alarm condition

User entry 21.5 to 23 mA

Loop current mode

Navigation Guidance → Commissioning → Output settings → Loop curr mode

Description If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications.
In this mode the output current is fixed.

User interface
■ Disable
■ Enable

Assign HART variables?

Navigation

■ Guidance → Commissioning → Output settings → Assign HART var?

Description

Up to four HART variables can be transmitted via the HART protocol.

Select "Yes" to show/assign measuring variables to these HART variables.

Selection

- No
- Yes

"Output settings" wizard

Navigation

■ Guidance → Commissioning → Output settings

Assign PV

**Navigation**

■ Guidance → Commissioning → Output settings → Assign PV

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Assign SV

**Navigation**

■ Guidance → Commissioning → Output settings → Assign SV

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current ^{*}
- Terminal voltage ^{*}
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}
- Signal noise detected

* Visibility depends on order options or device settings

- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Assign TV**Navigation**

Guidance → Commissioning → Output settings → Assign TV

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

* Visibility depends on order options or device settings

Assign QV**Navigation**

Guidance → Commissioning → Output settings → Assign QV

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current ^{*}
- Terminal voltage ^{*}
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}
- Signal noise detected ^{*}
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

* Visibility depends on order options or device settings

3.3 "Diagnostics" menu

Navigation



Diagnostics

3.3.1 "Active diagnostics" submenu

Navigation



Diagnostics → Active diagnos.

Active diagnostics

Navigation

Diagnostics → Active diagnos. → Active diagnos.

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

User interface

Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu.

Example

For the display format:

F271 Main electronic failure

Timestamp

Navigation

Diagnostics → Active diagnos. → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

The diagnostic message can be viewed via the **Actual diagnostics** parameter (→ 45).

Example

For the display format:

24d12h13m00s

Previous diagnostics

Navigation	  Diagnostics → Active diagnos. → Prev.diagnostics
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Example</i> For the display format:  F271 Main electronic failure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  46).
	<i>Example</i> For the display format: 24d12h13m00s

Operating time from restart

Navigation	  Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	  Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time: 9 999 d (≈ 27 years)

3.3.2 "Event logbook" submenu

Navigation  Diagnostics → Event logbook

Filter options

Navigation	 Diagnostics → Event logbook → Filter options
Description	Use this function to select the category whose event messages are displayed in the event list of the operating tool.
Selection	<ul style="list-style-type: none"> ■ All ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Information (I) ■ Not categorized
Additional information	<p><i>Description</i></p> <p> The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none"> ■ F = Failure ■ C = Function Check ■ S = Out of Specification ■ M = Maintenance Required

Clear event list

Navigation	 Diagnostics → Event logbook → Clear event list
Description	Use this function to process the current values in the event logbook.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Clear data

Additional information*Description*

Once this function has been executed, the events list is empty and all the events are deleted.



The events list can be exported using an operating tool (e.g. FieldCare).

3.3.3 "Minimum/maximum values" submenu

Navigation

Diagnostics → Min/max val.

Pressure min**Navigation**

Diagnostics → Min/max val. → Pressure min

Description

Minimum or maximum value measured by device.

User interface

Signed floating-point number

Counter limit underruns sensor Pmin**Navigation**

Diagnostics → Min/max val. → Counter P < Pmin

Description

Counts how many times the value underruns the sensor specific minimum values. Sensor specific minimum values are shown in Application/Sensor menu.

User interface

0 to 65 535

Counter underruns of user limit Pmin**Navigation**

Diagnostics → Min/max val. → Counter < P user

Description

Counts how many times the value underruns the minimum values defined by the user. User defined minimum values are shown in Diagnostic/Diagnostic settings/Properties menu.

User interface

0 to 65 535

Minimum sensor temperature

Navigation	 Diagnostics → Min/max val. → Min. sensor temp
Description	Minimum or maximum value measured by device. Users cannot reset this value.
User interface	-273.15 to 9 726.85 °C

Counter limit underruns sensor Tmin

Navigation	 Diagnostics → Min/max val. → Counter T < Tmin
Description	Counts how many times the value underruns/overruns the sensor specific minimum/maximum values. Sensor specific minimum/maximum values are shown in Application/Sensor menu.
User interface	0 to 65 535

Counter underruns of user limit Tmin

Navigation	 Diagnostics → Min/max val. → Counter < T user
User interface	0 to 65 535

Minimum terminal voltage

Navigation	 Diagnostics → Min/max val. → Min.term.volt.
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V

Minimum electronics temperature

Navigation	 Diagnostics → Min/max val. → Min.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Reset user defined counters P and T**Navigation**

Diagnostics → Min/max val. → Reset count. P T

Selection

- Cancel
- Confirm

Pressure max**Navigation**

Diagnostics → Min/max val. → Pressure max

Description

Minimum or maximum value measured by device.

User interface

Signed floating-point number

Counter limit overruns sensor Pmax**Navigation**

Diagnostics → Min/max val. → Counter P > Pmax

DescriptionCounts how many times the value overruns the sensor specific maximum values.
Sensor specific maximum values are shown in Application/Sensor menu.**User interface**

0 to 65 535

Counter overruns of user limit Pmax**Navigation**

Diagnostics → Min/max val. → Counter > P user

DescriptionCounts how many times the value overruns the maximum values defined by the user.
User defined maximum values are shown in Diagnostic/Diagnostic settings/Properties menu.**User interface**

0 to 65 535

Maximum sensor temperature**Navigation**

Diagnostics → Min/max val. → Max. sensor temp

DescriptionMinimum or maximum value measured by device.
Users cannot reset this value.**User interface**

-273.15 to 9 726.85 °C

Counter limit overruns sensor Tmax

Navigation Diagnostics → Min/max val. → Counter T > Tmax**Description**

Counts how many times the value underruns/overruns the sensor specific minimum/maximum values.
Sensor specific minimum/maximum values are shown in Application/Sensor menu.

User interface

0 to 65 535

Counter overruns of user limit Tmax

Navigation Diagnostics → Min/max val. → Counter > T user**User interface**

0 to 65 535

Maximum terminal voltage

Navigation Diagnostics → Min/max val. → Max.term.voltage**Description**

Minimum or maximum measured terminal (supply) voltage.

User interface

0.0 to 50.0 V

Maximum electronics temperature

Navigation Diagnostics → Min/max val. → Max.electr.temp.**Description**

Minimum or maximum measured main electronics temperature.

User interface

Signed floating-point number

3.3.4 "Simulation" submenu

Navigation

█ Diagnostics → Simulation

Simulation



Navigation

█ █ Diagnostics → Simulation → Simulation

Description

Simulates one or more process variables and/or events.

Warning:

Output will reflect the simulated value or event.

Selection

- Off
- Current output
- Diagnostic event simulation
- Pressure

Value pressure simulation



Navigation

█ █ Diagnostics → Simulation → Pressure

User entry

Signed floating-point number

Value current output



Navigation

█ █ Diagnostics → Simulation → Current output

Description

Defines the value of the simulated output current.

User entry

3.59 to 23 mA

Diagnostic event simulation



Navigation

█ █ Diagnostics → Simulation → Diagnostic event

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Additional information*Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter.

3.3.5 "Diagnostic settings" submenu

Navigation

Diagnostics → Diag. settings

"Properties" submenu

Navigation

Diagnostics → Diag. settings → Properties

SSD Out of range delay time

**Navigation**

Diagnostics → Diag. settings → Properties → SSD Delay time

User entry

0 to 604 800 s

SSD Monitoring delay time

**Navigation**

Diagnostics → Diag. settings → Properties → SSD Verz. Zeit

User entry

0 to 86 400 s

500 Process alert pressure

**Navigation**

Diagnostics → Diag. settings → Properties → 500 Pressure

Description

Define whether user-defined pressure limits should be set.

If "Off" is selected, no analysis will take place and no event message will be generated.

Selection

- Off
- On

Low alert value **Navigation**  Diagnostics → Diag. settings → Properties → Low alert value**Description** Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.**User entry** Signed floating-point number

High alert value **Navigation**  Diagnostics → Diag. settings → Properties → High alert value**Description** Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.**User entry** Signed floating-point number

501 Process alert scaled variable **Navigation**  Diagnostics → Diag. settings → Properties → 501 Scaled var.**Description** Define whether user-defined limits should be set.
If "Off" is selected, no analysis will take place and no event message will be generated.**Selection**

- Off
- On

Low alert value **Navigation**  Diagnostics → Diag. settings → Properties → Low alert value**Description** Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.**User entry** Signed floating-point number

High alert value

Navigation Diagnostics → Diag. settings → Properties → High alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry Signed floating-point number

User temperature process alert

Navigation Diagnostics → Diag. settings → Properties → UserTemp alert

Description Define whether the user-defined sensor temperature limits should be set. If "Off" no analysis and therefore no event message will take place.

Selection

- Off
- On

Low alert value

Navigation Diagnostics → Diag. settings → Properties → Low alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry -50 to 150 °C

High alert value

Navigation Diagnostics → Diag. settings → Properties → High alert value

Description Set range.
If this limit value is exceeded or undercut, a diagnostic event is generated. There is no hysteresis.

User entry -50 to 150 °C

806 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Properties → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

806 Event category**Navigation**

Diagnostics → Diag. settings → Properties → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

806 Event delay**Navigation**

Diagnostics → Diag. settings → Properties → 806 Event delay

Description

Displays how long the triggering status must be present until an event message is issued.
Used to filter out short-term signal interference.

User entry

0 to 60 s

"Configuration" submenu*Navigation*

Diagnostics → Diag. settings → Configuration → Configuration

**500 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 500 Diag. behav.

Description

Select event behavior

"Logbook entry only":

no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

**500 Event category****Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 500Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

**501 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 501 Diag. behav.

Description

Select event behavior

"Logbook entry only":

no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

501 Event category**Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 501Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

502 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Configuration → 502 Diag. behav.

Description

Select event behavior

"Logbook entry only":
no digital or analog transmission of the message

"Warning": Current output unchanged. Message is output digitally (default).

"Alarm": Current output assumes the set alarm current.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

502 Event category**Navigation**


Diagnostics → Diag. settings → Configuration → Configuration → 502Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

"Process" submenu**Navigation**

Diagnostics → Diag. settings → Configuration → Process

**806 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

**806 Event category****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

**822 Diagnostic behavior****Navigation**

Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

User interface

- Alarm
- Warning
- Logbook entry only

822 Event category**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → 822 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Sensor pressure range behavior**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → P-range behavior

Description

Select event behavior

"Alarm":

Current output adopts the set alarm current.

"Warning":

Current output unchanged. Message is displayed digitally (factory setting).

"Logbook entry only":

No digital or analog forwarding of the message.

"Special":

– Lower sensor limit undercut: Current output < 3.6 mA.

– Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting.

Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.

Selection

- Alarm
- Warning
- Logbook entry only
- Special

841 Event category**Navigation**

█ Diagnostics → Diag. settings → Configuration → Process → 841 Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 900Event category
Description	Select category for diagnostic message.
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Function check (C)▪ Out of specification (S)▪ Maintenance required (M)▪ No effect (N)

900 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": no digital or analog transmission of the message.</p> <p>"Warning": Current output unchanged. Message is output digitally (default).</p> <p>If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none">▪ Warning▪ Logbook entry only

906 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": no digital or analog transmission of the message.</p> <p>"Warning": Current output unchanged. Message is output digitally (default).</p> <p>If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none">▪ Off▪ Warning▪ Logbook entry only

906 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 906Event category
Description	Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

"Process" submenu**Navigation**

Diagnostics → Diag. settings → Configuration → Process

806 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

806 Event category**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 806Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

822 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Configuration → Process → 822 Diag. behav.

User interface

- Alarm
- Warning
- Logbook entry only

822 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 822 Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

Sensor pressure range behavior

Navigation	Diagnostics → Diag. settings → Configuration → Process → P-range behavior
Description	<p>Select event behavior</p> <p>"Alarm": Current output adopts the set alarm current.</p> <p>"Warning": Current output unchanged. Message is displayed digitally (factory setting).</p> <p>"Logbook entry only": No digital or analog forwarding of the message.</p> <p>"Special": – Lower sensor limit undercut: Current output < 3.6 mA. – Upper sensor limit exceeded: Current output 21 to 23 mA, depending on the setting. Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning message disappears.</p>
Selection	<ul style="list-style-type: none">■ Alarm■ Warning■ Logbook entry only■ Special

841 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 841 Event category
Selection	<ul style="list-style-type: none">■ Failure (F)■ Function check (C)■ Out of specification (S)■ Maintenance required (M)■ No effect (N)

900 Event category**Navigation**

Diagram: Diagnostics → Diag. settings → Configuration → Process → 900Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior**Navigation**

Diagram: Diagnostics → Diag. settings → Configuration → Process → 900 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

906 Diagnostic behavior**Navigation**

Diagram: Diagnostics → Diag. settings → Configuration → Process → 906 Diag. behav.

Description

Select event behavior

"Logbook entry only": no digital or analog transmission of the message.

"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Off
- Warning
- Logbook entry only

906 Event category**Navigation**

Diagram: Diagnostics → Diag. settings → Configuration → Process → 906Event category

Description

Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

3.4 "Application" menu

Navigation  Application

3.4.1 "Measuring units" submenu

Navigation  Application → Measuring units

Pressure unit



Navigation   Application → Measuring units → Pressure unit

Selection

SI units

- MPa
- kPa
- Pa
- bar
- mbar
- torr
- atm
- kgf/cm²
- gf/cm²

US units

psi

Other units

- inH₂O
- inH₂O (4°C)
- mmH₂O
- mmH₂O (4°C)
- mH₂O
- mH₂O (4°C)
- ftH₂O
- inHg
- mmHg

Decimal places pressure



Navigation  Application → Measuring units → Decimal pressure

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- Automatic

The decimal place is configured automatically.

Example: Unit mbar: one decimal place. Unit bar: four decimal places

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Temperature unit



Navigation   Application → Measuring units → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection	<i>SI units</i> ■ °C ■ K	<i>US units</i> °F
Factory setting	Country-specific: ■ °C ■ °F	
Additional information	<i>Selection</i>	

Scaled variable unit

Navigation Application → Measuring units → Scaled Unit

Description Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection

SI units

- %
- mm
- cm
- m
- l
- hl
- m³
- g
- kg
- t
- g/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- m³/s
- m³/min
- m³/h
- m³/d
- l/s
- l/min
- l/h
- Nm³/h
- NI/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

Custom-specific units
Free text

US units

- ft
- in
- ft³
- gal (us)
- bbl (us;oil)
- oz
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)

Free text**Navigation**

Application → Measuring units → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Decimal places scaled variable**Navigation**

Application → Measuring units → Decimal scaled

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

3.4.2 "Measured values" submenu

Navigation

Application → Measured values

Sensor pressure

Navigation

Application → Measured values → Sensor pressure

User interface

Signed floating-point number

Pressure

Navigation

Application → Measured values → Pressure

Scaled variable

Navigation

Application → Measured values → Scaled variable

User interface

Signed floating-point number

Sensor temperature

Navigation

Application → Measured values → Sensor temp.

User interface

-273.15 to 9 726.85 °C

Terminal voltage 1

Navigation

Application → Measured values → Terminal volt. 1

Description

Shows the current terminal voltage that is applied at the output

User interface	0.0 to 50.0 V
----------------	---------------

Terminal current

Navigation	  Application → Measured values → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA

Electronics temperature

Navigation	  Application → Measured values → Electronics temp
Description	Displays the current temperature of the main electronics.
User interface	Signed floating-point number

3.4.3 "Sensor" submenu

Navigation  Application → Sensor

"Basic settings" submenu

Navigation  Application → Sensor → Basic settings

Output current transfer function

Navigation	  Application → Sensor → Basic settings → Curr. trans.func
Description	<p>Linear The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit.</p> <p>Square root - differential pressure only The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.</p>

User interface	<ul style="list-style-type: none">■ Linear■ Square root *
-----------------------	--

Damping



Navigation	Application → Sensor → Basic settings → Damping
-------------------	---

Description	The damping is effective before the measured value is further processed, i.e., before the following processes: - Scaling - Limit value monitoring - Forwarding to display - Forwarding to Analog Input Block
--------------------	--

Note:

The Analog Input Block has its own “Damping” parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry	0 to 999.0 s
-------------------	--------------

HP/LP swap



Navigation	Application → Sensor → Basic settings → HP/LP swap
-------------------	--

Description	With this parameter the high and low pressure side of the differential pressure transmitter can be interchanged.
--------------------	--

Selection	<ul style="list-style-type: none">■ No■ Yes
------------------	--

Low flow cut off



Navigation	Application → Sensor → Basic settings → Low flow cut off
-------------------	--

Description	When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.
--------------------	--

User entry	0.0 to 50.0 %
-------------------	---------------

* Visibility depends on order options or device settings

"Sensor calibration" submenu**Navigation**

Application → Sensor → Sensor cal.

Zero adjustment**Navigation**

Application → Sensor → Sensor cal. → Zero adjustment

Description

Due to the mounting position of the measuring instrument, a pressure shift may occur. The pressure shift can be corrected with the zero adjustment.

Selection

- No
- Confirm

Calibration offset**Navigation**

Application → Sensor → Sensor cal. → Calibr offset

Prerequisite

Absolute pressure sensor

Description

Enter the value by which the measured value should be corrected, e.g., a position adjustment for absolute pressure sensors.

User entry

Signed floating-point number

Zero adjustment offset**Navigation**

Application → Sensor → Sensor cal. → Zero offset

User entry

Signed floating-point number

Sensor Trim Reset**Navigation**

Application → Sensor → Sensor cal. → Sen. Trim Reset

Selection

- No
- Confirm

Lower sensor trim measured value

Navigation	 Application → Sensor → Sensor cal. → LowerTrimMeasVal
User interface	Signed floating-point number

Lower sensor trim

Navigation	 Application → Sensor → Sensor cal. → LowerSensor trim
Description	<p>These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).</p> <p>There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.</p> <p>Note:</p> <p>The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).</p> <p>Proceed as follows:</p> <ul style="list-style-type: none">- Apply reference pressure for lower range value ("LRV")- Enter the measured reference pressure at "Lower sensor trim" and confirm- Apply reference pressure for upper range value ("URV")- Enter the measured reference pressure at "Upper sensor trim" and confirm- The sensor is now calibrated
User entry	Signed floating-point number

Upper sensor trim measured value

Navigation	 Application → Sensor → Sensor cal. → UpperTrimMeasVal
User interface	Signed floating-point number

Upper sensor trim



Navigation

Application → Sensor → Sensor cal. → UpperSensor trim

Description

These two parameters allow a recalibration of the sensor, i.e., if you want to fit the sensor to the measuring range. The highest accuracy is obtained when the value for the "Lower sensor trim" is as close as possible to "LRV" (lower range value) and the value for "Upper sensor trim" as close as possible to "URV" (upper range value).

There must be a known reference pressure when setting a new lower or upper sensor characteristic curve value. The more accurate the reference pressure is during recalibration, the higher the accuracy of the pressure transmitter later. A new value is assigned to the applied pressure using "Lower sensor trim" and "Upper sensor trim" parameters.

Note:

The value entered can be at maximum "Sensor pressure" +/- 10 % of the permitted maximum pressure (URL).

Proceed as follows:

- Apply reference pressure for lower range value ("LRV")
- Enter the measured reference pressure at "Lower sensor trim" and confirm
- Apply reference pressure for upper range value ("URV")
- Enter the measured reference pressure at "Upper sensor trim" and confirm
- The sensor is now calibrated

User entry

Signed floating-point number

"Sensor limits" submenu

Navigation

Application → Sensor → Sensor limits

Lower Range Limit

Navigation

Application → Sensor → Sensor limits → LRL

Description

Indicates the lower measuring limit of the sensor.

User interface

Signed floating-point number

Upper Range Limit

Navigation

Application → Sensor → Sensor limits → URL

Description

Indicates the upper measuring limit of the sensor.

User interface

Signed floating-point number

Minimum span

Navigation  Application → Sensor → Sensor limits → Minimum span

Description Specifies the smallest possible measuring span of the sensor.

User interface Signed floating-point number

Sensor temperature lower range limit

Navigation  Application → Sensor → Sensor limits → Sens.temp.lo.lim

User interface -273.15 to 9 726.85 °C

Sensor temperature upper range limit

Navigation  Application → Sensor → Sensor limits → Sens.temp.up.lim

User interface -273.15 to 9 726.85 °C

"Scaled variable" submenu

Navigation  Application → Sensor → Scaled variable

Assign PV

Navigation   Application → Sensor → Scaled variable → Assign PV

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Scaled variable unit**Navigation**

Application → Sensor → Scaled variable → Scaled Unit

Description

Use "Free text", first selection, if the desired unit is not available in the selection list. It is possible to define a customer specific unit with another parameter.

Selection*SI units*

- %
- mm
- cm
- m
- l
- hl
- m³
- g
- kg
- t
- g/s
- kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- m³/s
- m³/min
- m³/h
- m³/d
- l/s
- l/min
- l/h
- Nm³/h
- Nl/h
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm³/s
- g/cm³
- kg/m³
- Nm³/min
- Nm³/d

US units

- ft
- in
- ft³
- gal (us)
- bbl (us;oil)
- oz
- lb
- STon
- lb/s
- lb/min
- lb/h
- STon/min
- STon/h
- STon/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- Sft³/min
- Sft³/h
- Sft³/d

Imperial units

- gal (imp)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)

Custom-specific units

Free text

Free text**Navigation**

Application → Sensor → Scaled variable → Free text

User entry

Character string comprising numbers, letters and special characters (32)

Pressure**Navigation**
 Application → Sensor → Scaled variable → Pressure
Scaled variable transfer function**Navigation**
 Application → Sensor → Scaled variable → Scaled function
Description

"Linear"

The linear pressure signal is used for the output signal. The flow must be calculated in the evaluation unit.

"Square root" (Deltabar)

The root flow signal is used for the output signal. The "Flow (square root)" output signal is indicated on the on-site display with a root symbol.

"Table"

The output is defined according to the scaled variable / pressure table entered.

Selection

- Linear
- Square root *
- Table

Lower range value output**Navigation**
 Application → Sensor → Scaled variable → Low.range outp
Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**
 Application → Sensor → Scaled variable → Upp.range outp
Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

* Visibility depends on order options or device settings

Activate table**Navigation**

Application → Sensor → Scaled variable → Activate table

Selection

- Disable
- Enable

Pressure value 1**Navigation**

Application → Sensor → Scaled variable → Pressure 1

Description

Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry

Signed floating-point number

Scaled variable value 1**Navigation**

Application → Sensor → Scaled variable → Scaled 1

Description

Enter value for the first scaling point. This value is allocated to "Pressure value 1".

User interface

Signed floating-point number

Pressure value 2**Navigation**

Application → Sensor → Scaled variable → Pressure 2

Description

Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry

Signed floating-point number

Scaled variable value 2**Navigation**

Application → Sensor → Scaled variable → Scaled 2

Description

Enter value for the second scaling point. This value is allocated to "Pressure value 2".

User entry

Signed floating-point number

Low flow cut off

Navigation Application → Sensor → Scaled variable → Low flow cut off

Description When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.

User entry 0.0 to 50.0 %

Pressure

Navigation Application → Sensor → Scaled variable → Pressure

User entry Signed floating-point number

Scaled variable

Navigation Application → Sensor → Scaled variable → Scaled variable

User entry Signed floating-point number

"Wet calibration" submenu

Navigation Application → Sensor → Wet calibration

Zero

Navigation Application → Sensor → Wet calibration → Zero

Selection
■ No
■ Confirm

Pressure value 1

Navigation Application → Sensor → Wet calibration → Pressure 1

Description Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry	Signed floating-point number
------------	------------------------------

Span	
------	---

Navigation	 Application → Sensor → Wet calibration → Span
------------	---

Selection	<ul style="list-style-type: none">■ No■ Confirm
-----------	--

Pressure value 2	
------------------	---

Navigation	 Application → Sensor → Wet calibration → Pressure 2
------------	---

Description	Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.
-------------	--

User entry	Signed floating-point number
------------	------------------------------

Lower range value output	
--------------------------	---

Navigation	 Application → Sensor → Wet calibration → Low.range outp
------------	---

Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
-------------	---

User entry	Signed floating-point number
------------	------------------------------

Upper range value output	
--------------------------	---

Navigation	 Application → Sensor → Wet calibration → Upp.range outp
------------	---

Description	Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).
-------------	---

User entry	Signed floating-point number
------------	------------------------------

"Wet calibration" submenu*Navigation*

Application → Sensor → Wet calibration

**Zero****Navigation**

Application → Sensor → Wet calibration → Zero

Selection

- No

- Confirm

**Pressure value 1****Navigation**

Application → Sensor → Wet calibration → Pressure 1

Description

Enter pressure for the first scaling point. "Scaled variable value 1" will be allocated to this pressure.

User entry

Signed floating-point number

**Span****Navigation**

Application → Sensor → Wet calibration → Span

Selection

- No

- Confirm

**Pressure value 2****Navigation**

Application → Sensor → Wet calibration → Pressure 2

Description

Enter pressure for the second scaling point. "Scaled variable value 2" will be allocated to this pressure.

User entry

Signed floating-point number

Lower range value output**Navigation**

Application → Sensor → Wet calibration → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**

Application → Sensor → Wet calibration → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

3.4.4 "Current output" submenu

Navigation Application → Curr.output

Assign PV**Navigation**

Application → Curr.output → Assign PV

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Pressure
- Scaled variable

Measuring mode current output**Navigation**

Application → Curr.output → Output mode

Description

Select curve of current output.

Selection

- Standard
- Inverse
- Bi-directional

Current range output**Navigation**

Application → Curr.output → Current range

Description

Defines the current range used to transmit the measured or calculated value. In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value \leq "low saturation", the output current is set to "low saturation". If Measured value \geq "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4...20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Lower range value output**Navigation**

Application → Curr.output → Low.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Upper range value output**Navigation**

Application → Curr.output → Upp.range outp

Description

Depending on which variable has been selected as "Process variable output current", define the related lower (4 mA) and upper range values (20 mA).

User entry

Signed floating-point number

Failure behavior current output**Navigation**

Application → Curr.output → Failure behav.

Description

Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: > 21.5 mA

Note: The hardware DIP Switch for alarm current has priority over software setting.

Selection

- Min.
- Max.

Failure current

Navigation	Application → Curr.output → Failure current
Description	Enter current output value in alarm condition
User entry	21.5 to 23 mA

Output current

Navigation	Application → Curr.output → Output curr.
Description	Shows the value currently calculated for the current output
User interface	3.59 to 23 mA

Terminal current

Navigation	Application → Curr.output → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA

4 mA trim value

Navigation	Application → Curr.output → 4 mA trim value
Description	Enter the trim value for the 4 mA current output. Note: Simulation must be active.
User entry	3 to 5 mA

20 mA trim value

Navigation	Application → Curr.output → 20 mA trim value
Description	Enter the trim value for the 20 mA current output. Note: Simulation must be active.

User entry	18 to 22 mA
-------------------	-------------

3.4.5 "HART output" submenu

Navigation



Application → HART output

"Configuration" submenu

Navigation



Application → HART output → Configuration

HART address



Navigation	Application → HART output → Configuration → HART address
-------------------	--

Description	Define the HART address of the device.
--------------------	--

User entry	0 to 63
-------------------	---------

Additional information	<ul style="list-style-type: none"> ■ The measured value can only be transmitted via the current value if the address is set to "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode). ■ Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0. ■ All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and higher.
-------------------------------	---

HART short tag



Navigation	Application → HART output → Configuration → HART short tag
-------------------	--

Description	Defines the short tag for the measuring point.
--------------------	--

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).
-------------------	--

Device tag



Navigation	Application → HART output → Configuration → Device tag
-------------------	--

Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
--------------------	--

User entry	Character string comprising numbers, letters and special characters (32)
-------------------	--

No. of preambles	
-------------------------	---

Navigation	 Application → HART output → Configuration → No. of preambles
-------------------	--

Description	Defines the number of preambles in the HART telegram
--------------------	--

User entry	5 to 20
-------------------	---------

Loop current mode	
--------------------------	---

Navigation	 Application → HART output → Configuration → Loop curr mode
-------------------	--

Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
--------------------	--

Selection	<ul style="list-style-type: none">■ Disable■ Enable
------------------	--

"HART output" submenu

Navigation  Application → HART output → HART output

Assign PV	
------------------	---

Navigation	 Application → HART output → HART output → Assign PV
-------------------	---

Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).
--------------------	---

Selection	<ul style="list-style-type: none">■ Pressure■ Scaled variable
------------------	--

Primary variable (PV)

Navigation  Application → HART output → HART output → Primary var (PV)

Description Shows the first HART value (PV).

Additional information

Assign SV

Navigation   Application → HART output → HART output → Assign SV

Description Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected *
- Percent of range
- Loop current
- Not used

Additional information

Selection

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Secondary variable (SV)

Navigation  Application → HART output → HART output → Second.var(SV)

Description Shows the second HART value (SV).

* Visibility depends on order options or device settings

Assign TV**Navigation**

Application → HART output → HART output → Assign TV

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current ^{*}
- Terminal voltage ^{*}
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}
- Signal noise detected ^{*}
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Tertiary variable (TV)**Navigation**

Application → HART output → HART output → Tertiary var(TV)

Description

Shows the third HART value (TV).

Assign QV**Navigation**

Application → HART output → HART output → Assign QV

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

* Visibility depends on order options or device settings

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Terminal current *
- Terminal voltage *
- Median of pressure signal *
- Noise of pressure signal *
- Signal noise detected
- Percent of range
- Loop current
- Not used

Additional information*Selection*

- **Sensor pressure** option
Sensor Pressure is the raw signal from sensor before damping and position adjustment.
- **Terminal current** option
The terminal current is the read-back current on terminal block.
- **Signal noise detected** option
0 % - Signal noise is within the permissible range.
100 % - Signal noise is outside of the permissible range.
- **Loop current** option
The loop current is the output current set by the applied pressure.

Quaternary variable (QV)**Navigation**

 Application → HART output → HART output → Quaterna.var(QV)

Description

Shows the fourth value (QV).

"Burst configuration 1" submenu

Navigation  Application → HART output → Burst config. 1

Burst mode 1**Navigation**

 Application → HART output → Burst config. 1 → Burst mode 1

Description

Use this function to select whether to activate the HART burst mode for burst message X.

* Visibility depends on order options or device settings

Selection

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Additional information*Selection*

- Off
The measuring device transmits data only when requested by the HART master.
- On
The measuring device transmits data regularly without being requested.

Burst command 1**Navigation**

Application → HART output → Burst config. 1 → Burst command 1

Description

Use this function to select the HART command that is sent to the HART master.

Selection

- Primary variable (PV)
- Loop Current and Percent of Range
- Dynamic Variables
- Device variables with status
- Device variables
- Additional device status

Additional information*Selection*

- Command 1
Read out the primary variable.
- Command 2
Read out the current and the main measured value as a percentage.
- Command 3
Read out the dynamic HART variables and the current.
- Command 9
Read out the dynamic HART variables including the related status.
- Command 33
Read out the dynamic HART variables including the related unit.
- Command 48
Read out the complete device diagnostics.

"Command 33" option

The HART device variables are defined via Command 107.

Commands

- Information about the defined details of the command: HART specifications
■ The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu.

Burst variable 0

Navigation Application → HART output → Burst config. 1 → Burst variable 0

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Pressure
- Scaled variable
- Sensor temperature
- Sensor pressure
- Electronics temperature
- Measured current ^{*}
- Terminal voltage 1 ^{*}
- Median of pressure signal ^{*}
- Noise of pressure signal ^{*}
- Signal noise detected ^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Additional information *Selection*

If a burst message is not configured, the **Not used** option is set.

Burst variable 1

Navigation Application → HART output → Burst config. 1 → Burst variable 1

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst variable 2

Navigation Application → HART output → Burst config. 1 → Burst variable 2

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

* Visibility depends on order options or device settings

Burst variable 3**Navigation**

Application → HART output → Burst config. 1 → Burst variable 3

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst variable 4**Navigation**

Application → HART output → Burst config. 1 → Burst variable 4

Description

For HART command 9: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst variable 5**Navigation**

Application → HART output → Burst config. 1 → Burst variable 5

Description

For HART command 9: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst variable 6**Navigation**

Application → HART output → Burst config. 1 → Burst variable 6

Description

For HART command 9: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst variable 7**Navigation**

Application → HART output → Burst config. 1 → Burst variable 7

Description

For HART command 9: select the HART device variable or the process variable.

Selection

Please refer to the **Burst variable 0** parameter (→ 91).

Burst trigger mode

Navigation	Application → HART output → Burst config. 1 → Trigger mode
Description	Use this function to select the event that triggers burst message X.
Selection	<ul style="list-style-type: none"> ■ Continuous ■ Window [*] ■ Rising [*] ■ Falling [*] ■ On change
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→ 93). ■ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→ 93). ■ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→ 93). ■ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→ 93). ■ On change The message is sent if a measured value changes in the burst message.

Burst trigger level

Navigation	Application → HART output → Burst config. 1 → Trigger level
Description	Use this function to enter the burst trigger value.
User entry	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>Together with the option selected in the Burst trigger mode parameter (→ 93) the burst trigger value determines the time of burst message X.</p>

Min. update period

Navigation	Application → HART output → Burst config. 1 → Min. upd. per.
Description	Use this function to enter the minimum time span between two burst commands of burst message X.

* Visibility depends on order options or device settings

User entry	Positive integer
------------	------------------

Max. update period

Navigation Application → HART output → Burst config. 1 → Max. upd. per.

Description Use this function to enter the maximum time span between two burst commands of burst message X.

User entry	Positive integer
------------	------------------

"Information" submenu

Navigation Application → HART output → Information

Device ID

Navigation Application → HART output → Information → Device ID

Description Use this function to view the device ID for identifying the measuring device in a HART network.

User interface 6-digit hexadecimal number

Additional information *Description*

In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation Application → HART output → Information → Device type

Description Displays the device type with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x54

Factory setting 0x5A

Additional information*Description*

The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Device revision**Navigation**

Application → HART output → Information → Device revision

Description

Displays the device revision with which the device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Additional information*Description*

The device revision is needed to assign the appropriate device description file (DD) to the device.

HART short tag**Navigation**

Application → HART output → Information → HART short tag

Description

Defines the short tag for the measuring point.

Maximum length: 8 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

HART revision**Navigation**

Application → HART output → Information → HART revision

Description

Shows the HART revision of the device.

HART descriptor**Navigation**

Application → HART output → Information → HART descriptor

Description

Description for the measuring point.

User entry

Character string comprising numbers, letters and special characters (16)

HART message**Navigation**

Application → HART output → Information → HART message

Description

A HART message which is sent via the HART protocol when requested by the master.

User entry

Character string comprising numbers, letters and special characters (32)

HART date code**Navigation**

Application → HART output → Information → HART date code

Description

Date of the last configuration change

User entry

Character string comprising numbers, letters and special characters (10)

Additional information

Date format: YYYY-MM-DD

Make sure you adhere to this format when entering the date. Otherwise errors may occur in individual HART commands.

3.5 "System" menu

Navigation  System

3.5.1 "Device management" submenu

Navigation  System → Device manag.

Device tag



Navigation   System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Locking status

Navigation   System → Device manag. → Locking status

Description Displays the active write protection.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Additional information *User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Configuration counter

Navigation

  System → Device manag. → Config. counter

Description

Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65535, it restarts at 0.

User interface

0 to 65 535

Reset device



Navigation

  System → Device manag. → Reset device

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to its factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.  This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

* Visibility depends on order options or device settings

3.5.2 "User management" submenu

Navigation  System → User manag.

User role

Navigation   System → User manag. → User role

Description Displays the access authorization to the parameters via the operating tool.

User interface

- Operator
- Maintenance
- Expert

Additional information *Description*

 Access authorization can be modified via the **Enter access code** parameter.

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Password

Navigation  System → User manag. → Password

Description Enter the password for the "Maintenance" user role to get access to the functionality of this role.

User entry Character string comprising numbers, letters and special characters (16)

Enter access code



Navigation  System → User manag. → Ent. access code

Description Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.

User entry 0 to 9 999

Status password entry

Navigation  System → User manag. → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

New password



Navigation  System → User manag. → New password

Description Define the new "Maintenance" password.

A new password is valid after it has been confirmed within the "Confirm new password" parameter.

Any valid password consists of 4 to 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (16)

Confirm new password



Navigation  System → User manag. → Confirm password

Description Enter the new password again to confirm.

User entry Character string comprising numbers, letters and special characters (16)

Old password



Navigation  System → User manag. → Old password

Description Enter the current password, to subsequently change the existing password.

User entry Character string comprising numbers, letters and special characters (16)

Reset password

Navigation  System → User manag. → Reset password**Description** Enter a code to reset the current "Maintenance" password.
The code is delivered by your local support.**User entry** Character string comprising numbers, letters and special characters (16)

3.5.3 "Display" submenu*Navigation*  System → Display

Language

Navigation   System → Display → Language**Prerequisite** A local display is provided.**Description** Use this function to select the configured language on the local display.**Selection**

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- Bahasa Indonesia
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation	 System → Display → Format display
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	<ul style="list-style-type: none">▪ 1 value, max. size▪ 1 bargraph + 1 value▪ 2 values
Additional information	<i>Description</i> The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.  <ul style="list-style-type: none">▪ The Value 1 display parameter (→  102)...Value 8 display parameter Value 4 display parameter (→  104) are used to specify which measured values are shown on the local display and in what order.▪ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the Display interval parameter.

Value 1 display



Navigation	 System → Display → Value 1 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">▪ Pressure▪ Scaled variable▪ Current output▪ Sensor temperature▪ Percent of range
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.  The Format display parameter (→  102) is used to specify how many measured values are displayed simultaneously and how. <i>Dependency</i>  The unit of the displayed measured value is taken from the System units submenu.

Value 2 display

Navigation	System → Display → Value 2 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">▪ None▪ Pressure▪ Scaled variable▪ Current output▪ Sensor temperature▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 102) is used to specify how many measured values are displayed simultaneously and how.</p>
	<p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>

Value 3 display

Navigation	System → Display → Value 3 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">▪ None▪ Pressure▪ Scaled variable▪ Current output▪ Sensor temperature▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 102) is used to specify how many measured values are displayed simultaneously and how.</p>
	<p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>

Value 4 display

Navigation	System → Display → Value 4 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">▪ None▪ Pressure▪ Scaled variable▪ Current output▪ Sensor temperature▪ Percent of range
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 102) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu.</p>

Contrast display

Navigation	System → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)
User entry	20 to 80 %
Factory setting	Depends on the display
Additional information	<p> Set the contrast via the push-buttons:</p> <ul style="list-style-type: none">▪ Weaker: Press the and buttons simultaneously▪ Stronger: Press the and buttons simultaneously

3.5.4 "Geolocation" submenu

Navigation

System → Geolocation

Process Unit Tag



Navigation

System → Geolocation → Process Unit Tag

Description

Enter the process unit in which the device is installed.

User entry

Character string comprising numbers, letters and special characters (32)

Location Description



Navigation

System → Geolocation → Location Descr.

Description

Use this function to enter a description of the location so that the device can be located in the plant.

User entry

Character string comprising numbers, letters and special characters (32)

Longitude



Navigation

System → Geolocation → Longitude

Description

Use this function to enter the longitude coordinates that describe the device location.

User entry

-180 to 180 °

Latitude



Navigation

System → Geolocation → Latitude

Description

Use this function to enter the latitude coordinates that describe the device location.

User entry

-90 to 90 °

Altitude**Navigation**

System → Geolocation → Altitude

Description

Use this function to enter the altitude data that describe the device location.

User entry

Signed floating-point number

Location method**Navigation**

System → Geolocation → Location method

Description

Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183.

Selection

- No fix
- GPS or Standard Positioning Service fix
- Differential GPS fix
- Precise positioning service (PPS) fix
- Real Time Kinetic (RTK) fixed solution
- Real Time Kinetic (RTK) float solution
- Estimated dead reckoning
- Manual input mode
- Simulation Mode

3.5.5 "Information" submenu

Navigation

System → Information

Device name**Navigation**

System → Information → Device name

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Manufacturer

Navigation  System → Information → Manufacturer**User interface** Character string comprising numbers, letters and special characters

Serial number

Navigation  System → Information → Serial number**Description** Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.**Additional information** *Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Order code

Navigation  System → Information → Order code**Description** Shows the device order code.**User interface** Character string composed of letters, numbers and certain punctuation marks (e.g. /).**Factory setting** –**Additional information** *Description***Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Firmware version

Navigation	  System → Information → Firmware version
Description	Displays the device firmware version that is installed.
User interface	Character string in the format xx.yy.zz
Additional information	<i>User interface</i>  The Firmware version is also located: <ul style="list-style-type: none">▪ On the title page of the Operating instructions▪ On the transmitter nameplate

Hardware version

Navigation	  System → Information → Hardware version
User interface	Character string comprising numbers, letters and special characters

Extended order code 1

Navigation	 System → Information → Ext. order cd. 1
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
User interface	Character string
Factory setting	–
Additional information	<i>Description</i> The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

Extended order code 2

Navigation	 System → Information → Ext. order cd. 2
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.
User interface	Character string

Factory setting

-

Extended order code 3**Navigation**

System → Information → Ext. order cd. 3

Description

The extended order code is an alphanumeric code containing all information to identify the device and its options.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User interface

Character string

Factory setting

-

XML build number**Navigation**

System → Information → XML build no.

User interface

Positive integer

Checksum**Navigation**

System → Information → Checksum

Description

Checksum for Firmware version.

User interface

Positive integer

3.5.6 "Software configuration" submenu

Navigation

System → Softw. config.

Activate SW option**Navigation**

System → Softw. config. → Activate SW opt.

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry	Max. 10-digit string of numbers.
Factory setting	Depends on the software option ordered
Additional information	<p><i>Description</i></p> <p>If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.</p>
	<p><i>User entry</i></p> <p> To activate a software option subsequently, please contact your Endress+Hauser sales organization.</p>
	<p>NOTE!</p> <p>The activation code is linked to the serial number of the measuring device and varies according to the device and software option.</p> <p>If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.</p> <ul style="list-style-type: none">▶ Before you enter a new activation code, make a note of the current activation code from the parameter protocol.▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.▶ If the code entered is incorrect or invalid, enter the old activation code from the parameter protocol.▶ Have the Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.
	<p><i>Example for a software option</i></p> <p>Order code for "Application package", option EA "Extended HistoROM"</p>

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options
User interface	<ul style="list-style-type: none">■ SIL■ WHG■ Heartbeat Verification■ Heartbeat Monitoring

Index

0 ... 9

4 mA trim value (Parameter)	84
20 mA trim value (Parameter)	84
500 Diagnostic behavior (Parameter)	57
500 Event category (Parameter)	57
500 Process alert pressure (Parameter)	53
501 Diagnostic behavior (Parameter)	57
501 Event category (Parameter)	58
501 Process alert scaled variable (Parameter)	54
502 Diagnostic behavior (Parameter)	58
502 Event category (Parameter)	58
806 Diagnostic behavior (Parameter)	56, 59, 62
806 Event category (Parameter)	56, 59, 62
806 Event delay (Parameter)	56
822 Diagnostic behavior (Parameter)	59, 62
822 Event category (Parameter)	60, 63
841 Event category (Parameter)	60, 63
900 Diagnostic behavior (Parameter)	61, 64
900 Event category (Parameter)	61, 64
906 Diagnostic behavior (Parameter)	61, 64
906 Event category (Parameter)	61, 64

A

Activate SW option (Parameter)	109
Activate table (Parameter)	78
Active diagnostics (Parameter)	45
Active diagnostics (Submenu)	45
Altitude (Parameter)	106
Application (Menu)	66
Assign HART variables? (Parameter)	39, 42
Assign PV (Parameter)	27, 42, 75, 82, 86
Assign QV (Parameter)	44, 88
Assign SV (Parameter)	42, 87
Assign TV (Parameter)	43, 88

B

Basic settings (Submenu)	70
Burst command 1 (Parameter)	90
Burst configuration 1 (Submenu)	89
Burst mode 1 (Parameter)	89
Burst trigger level (Parameter)	93
Burst trigger mode (Parameter)	93
Burst variable 0 (Parameter)	91
Burst variable 1 (Parameter)	91
Burst variable 2 (Parameter)	91
Burst variable 3 (Parameter)	92
Burst variable 4 (Parameter)	92
Burst variable 5 (Parameter)	92
Burst variable 6 (Parameter)	92
Burst variable 7 (Parameter)	92

C

Calibration offset (Parameter)	72
Checksum (Parameter)	109
Clear event list (Parameter)	47
Commissioning (Wizard)	23

Configuration (Submenu)	57, 85
Configuration counter (Parameter)	98
Confirm new password (Parameter)	100
Contrast display (Parameter)	104
Counter limit overruns sensor Pmax (Parameter)	50
Counter limit overruns sensor Tmax (Parameter)	51
Counter limit underruns sensor Pmin (Parameter)	48
Counter limit underruns sensor Tmin (Parameter)	49
Counter overruns of user limit Pmax (Parameter)	50
Counter overruns of user limit Tmax (Parameter)	51
Counter underruns of user limit Pmin (Parameter)	48
Counter underruns of user limit Tmin (Parameter)	49
Current output (Submenu)	82
Current range output (Parameter)	38, 40, 83

D

Damping (Parameter)	27, 71
Decimal places pressure (Parameter)	66
Decimal places scaled variable (Parameter)	68
Description of device parameters	21
Device ID (Parameter)	94
Device identification (Wizard)	23, 25, 26
Device management (Submenu)	97
Device name (Parameter)	23, 106
Device revision (Parameter)	95
Device tag (Parameter)	23, 85, 97
Device type (Parameter)	94
Diagnostic event simulation (Parameter)	52
Diagnostic settings (Submenu)	53
Diagnostics (Menu)	45
Display (Submenu)	101
Document	
Explanation of the structure of a parameter	
description	4
Function	4
Structure	4
Symbols used	5
Target group	4
Using the document	4
Document function	4

E

Electronics temperature (Parameter)	70
Enter access code (Parameter)	99
Event logbook (Submenu)	47
Extended order code 1 (Parameter)	24, 108
Extended order code 2 (Parameter)	24, 108
Extended order code 3 (Parameter)	24, 109

F

Failure behavior current output (Parameter)	39, 41, 83
Failure current (Parameter)	39, 41, 84
Filter options (Parameter)	47
Firmware version (Parameter)	108
Format display (Parameter)	102
Free text (Parameter)	30, 68, 76

Function
see Parameter

G

Geolocation (Submenu) 105
Guidance (Menu) 21, 23

H

Hardware version (Parameter) 108
HART address (Parameter) 27, 85
HART date code (Parameter) 26, 96
HART descriptor (Parameter) 26, 95
HART message (Parameter) 26, 96
HART output (Submenu) 85, 86
HART revision (Parameter) 95
HART short tag (Parameter) 26, 85, 95
High alert value (Parameter) 54, 55
HP/LP swap (Parameter) 71

I

Information (Submenu) 94, 106

L

Language (Parameter) 101
Latitude (Parameter) 105
Location Description (Parameter) 105
Location method (Parameter) 106
Locking status (Parameter) 25, 97
Longitude (Parameter) 105
Loop current mode (Parameter) 39, 41, 86
Low alert value (Parameter) 54, 55
Low flow cut off (Parameter) 32, 33, 71, 79
Lower Range Limit (Parameter) 33, 35, 37, 74
Lower range value output (Parameter)
..... 35, 38, 40, 77, 80, 82, 83
Lower sensor trim (Parameter) 73
Lower sensor trim measured value (Parameter) 73

M

Manufacturer (Parameter) 107
Max. update period (Parameter) 94
Maximum electronics temperature (Parameter) 51
Maximum sensor temperature (Parameter) 50
Maximum terminal voltage (Parameter) 51
Measured values (Submenu) 69
Measurement adjustments (Wizard) 27, 28, 29, 31
Measuring mode current output (Parameter) 82
Measuring units (Submenu) 66
Menu
Application 66
Diagnostics 45
Guidance 21, 23
System 97
Min. update period (Parameter) 93
Minimum electronics temperature (Parameter) 49
Minimum sensor temperature (Parameter) 49
Minimum span (Parameter) 34, 36, 38, 75
Minimum terminal voltage (Parameter) 49
Minimum/maximum values (Submenu) 48

N

New password (Parameter) 100
No. of preambles (Parameter) 86

O

Old password (Parameter) 100
Operating time (Parameter) 47
Operating time from restart (Parameter) 46
Order code (Parameter) 107
Output current (Parameter) 84
Output current transfer function (Parameter) 32, 70
Output settings (Wizard) 32, 33, 34, 35, 36, 38, 40, 42

P

Parameter
Structure of a parameter description 4
Password (Parameter) 99
Pressure (Parameter) 32, 34, 69, 77, 79
Pressure max (Parameter) 50
Pressure min (Parameter) 48
Pressure unit (Parameter) 28, 29, 66
Pressure value 1 (Parameter) 36, 78, 79, 81
Pressure value 2 (Parameter) 37, 78, 80, 81
Previous diagnostics (Parameter) 46
Primary variable (PV) (Parameter) 87
Process (Submenu) 59, 62
Process Unit Tag (Parameter) 105
Process variable output current (Parameter) 40
Properties (Submenu) 53

Q

Quaternary variable (QV) (Parameter) 89

R

Reset device (Parameter) 98
Reset password (Parameter) 101
Reset user defined counters P and T (Parameter) 50

S

Scaled variable (Parameter) 34, 69, 79
Scaled variable (Submenu) 75
Scaled variable transfer function (Parameter) 33, 36, 77
Scaled variable unit (Parameter) 29, 67, 76
Scaled variable value 1 (Parameter) 37, 78
Scaled variable value 2 (Parameter) 37, 78
Secondary variable (SV) (Parameter) 87
Sensor (Submenu) 70
Sensor calibration (Submenu) 72
Sensor limits (Submenu) 74
Sensor pressure (Parameter) 69
Sensor pressure range behavior (Parameter) 60, 63
Sensor temperature (Parameter) 69
Sensor temperature lower range limit (Parameter) 75
Sensor temperature upper range limit (Parameter) 75
Sensor Trim Reset (Parameter) 72
Serial number (Parameter) 23, 107
Simulation (Parameter) 52
Simulation (Submenu) 52
Software configuration (Submenu) 109

Software option overview (Parameter)	110
Span (Parameter)	80, 81
SSD Monitoring delay time (Parameter)	53
SSD Out of range delay time (Parameter)	53
Status password entry (Parameter)	100
Submenu	
Active diagnostics	45
Basic settings	70
Burst configuration 1	89
Configuration	57, 85
Current output	82
Device management	97
Diagnostic settings	53
Display	101
Event logbook	47
Geolocation	105
HART output	85, 86
Information	94, 106
Measured values	69
Measuring units	66
Minimum/maximum values	48
Process	59, 62
Properties	53
Scaled variable	75
Sensor	70
Sensor calibration	72
Sensor limits	74
Simulation	52
Software configuration	109
User management	99
Wet calibration	79, 81
System (Menu)	97

T

Target group	4
Temperature unit (Parameter)	28, 30, 66
Terminal current (Parameter)	70, 84
Terminal voltage 1 (Parameter)	69
Tertiary variable (TV) (Parameter)	88
Timestamp (Parameter)	45, 46

U

Upper Range Limit (Parameter)	34, 35, 37, 74
Upper range value output (Parameter)	
.	35, 38, 41, 77, 80, 82, 83
Upper sensor trim (Parameter)	74
Upper sensor trim measured value (Parameter)	73
User management (Submenu)	99
User role (Parameter)	99
User temperature process alert (Parameter)	55

V

Value 1 display (Parameter)	102
Value 2 display (Parameter)	103
Value 3 display (Parameter)	103
Value 4 display (Parameter)	104
Value current output (Parameter)	52
Value pressure simulation (Parameter)	52

W

Wet calibration (Submenu)	79, 81
Wizard	
Commissioning	23
Device identification	23, 25, 26
Measurement adjustments	27, 28, 29, 31
Output settings	32, 33, 34, 35, 36, 38, 40, 42

X

XML build number (Parameter)	109
--	-----

Z

Zero (Parameter)	79, 81
Zero adjustment (Parameter)	31, 72
Zero adjustment offset (Parameter)	72



71647904

www.addresses.endress.com
