Safety Instructions **Proline Promag 300**

EAC: Zone 2







Proline Promag 300

Table of contents

| About this document | 4 |
|---|----|
| Associated documentation | 4 |
| Manufacturer's certificates | 4 |
| Manufacturer address | 5 |
| Extended order code | 5 |
| Safety instructions: General | 8 |
| afety instructions: Installation | 9 |
| Cemperature tables | 11 |
| Explosion hazards arising from gas and dust | 14 |
| Connection values: Signal circuits | 16 |

About this document



The document number of these Safety Instructions (XA) must match the information on the nameplate.

Associated documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter serial number from nameplate.
- Endress+Hauser Operations app: Enter serial number from nameplate or scan matrix code on nameplate.

| Measuring instrument | Documentation code | | | | | |
|----------------------|--------------------------|----------|-------------|-------------|--|--|
| | HART FOUNDATION Fieldbus | | PROFIBUS PA | PROFIBUS DP | | |
| Promag H 300 | BA01392D | BA01477D | BA01396D | BA01865D | | |
| Promag P 300 | BA01393D | BA01478D | BA01397D | BA01853D | | |
| Promag W 300 | BA01918D | BA01938D | BA01928D | BA01940D | | |

| Measuring instrument | Documentation code | | | | | |
|----------------------|--------------------|-------------|----------|------------------------------|--|--|
| | Modbus RS485 | EtherNet/IP | PROFINET | PROFINET mit Ethernet-APL | | |
| Promag H 300 | BA01394D | BA01716D | BA01718D | BA02106D | | |
| Promag P 300 | BA01395D | BA01717D | BA01719D | BA02105D | | |
| Promag W 300 | BA01939D | BA01937D | BA01941D | BA02104D | | |

Additional documentation

| Contents | Document type | Documentation code |
|-------------------------------------|-----------------------|--------------------|
| Remote display and operating module | Special documentation | SD01763D |
| DKX001 | Safety Instructions | XA01665D |
| | 2Ex ec IIC T6 Gc | |
| Explosion Protection | Brochure | CP00021Z/11 |
| Ethernet-APL Installation Drawing | Installation Drawing | HE_01622 |

Please note the documentation associated with the device.

Manufacturer's certificates

Measuring instruments meet the fundamental health and safety requirements for the design and construction of devices and protective

systems intended for use in potentially explosive atmospheres in accordance with TR CU 012/2011.

Certification body

LLP "T-Standard"

Certificate number

EA9C KZ 7500525.01.01.01597

Affixing the certificate number certifies conformity with the standards (depending on the device version).

- ΓΟCT 31610.0-2019 (IEC 60079-0:2017)
- ΓΟCT 31610.7-2017 (IEC 60079-7:2015)
- ΓΟCT 31610.11-2014 (IEC 60079-11:2011)
- FOCT 31610.15-2014 (IEC 60079-15:2010)

Manufacturer address

Endress+Hauser Flowtec AG 35, rue de l'Europe 68700 Cernay France

Endress+Hauser Flowtec (India) Pvt. Ltd. M-171/176, Waluj Industrial Area, MIDC IN-431 136 Aurangabad India

Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

Structure of the extended order code



* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

Device type

The device and the device design is defined in the "Device type" section (Product root).

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Device type

| Position | Order code for | Option selected | Description |
|----------|-------------------|---|--|
| 1 | Instrument family | 5 | Electromagnetic flowmeter |
| 2 | Sensor | H, P, W 1) | Sensor type |
| 3 | Transmitter | 3 | Transmitter type: 4-wire, compact version |
| 4 | Generation index | В | Platform generation |
| 5, 6 | Nominal diameter | Examples: 02, 04, 40, 50, 1H, 1Z, T0, E4 ^{2) 3)} | Nominal diameter of sensor |

- 1) For replacement transmitter only: X
- 2) For the exact specification of the nominal diameter, see nameplate
- 3) For replacement transmitter only: XX

Basic specifications

| Position 1, 2 Order code for "Approval" Option selected | Position 4, 5 Order code for "Output, input 1" Option selected | Type of protection Transmitter | Sensor |
|---|--|------------------------------------|-------------------------|
| GS, BS | BA, BB, GA, LA, MA, NA, RA, SA, MB, RB | 2Ex ec nC ic IIC T5T1 Gc X | 2Ex ec ic IIC T5T1 Gc X |
| | HA, TA, MC, RC | 2Ex ec nC ic [ic] IIC T5T1 Gc X | |

| Position | Order code for | Option selected | Description |
|----------|-----------------|-----------------|--|
| 4, 5 | Output, input 1 | BA | 4-20mA HART |
| | | GA | PROFIBUS PA |
| | | НА | PROFIBUS PA Ex-i |
| | | LA | PROFIBUS DP |
| | | MA | Modbus RS485 |
| | | MB | Modbus TCP with Ethernet-APL |
| | | MC | Modbus TCP with Ethernet-APL Ex i |
| | | NA | EtherNet/IP 2-port switch integrated |
| | | RA | PROFINET IO 2-port switch integrated |
| | | RB | PROFINET with Ethernet-APL |
| | | RC | PROFINET with Ethernet-APL Ex i |
| | | SA | FOUNDATION Fieldbus |
| | | TA | FOUNDATION Fieldbus Ex-i |
| 6 | Output, input 2 | A | W/o |
| | | В | 4-20mA |
| | | С | 4-20mA Ex-i passive |
| | | D | Configurable I/O initial setting off |
| | | Е | Pulse/frequency/switch output |
| | | F | Pulse output, phase-shifted |
| | | G | Pulse/frequency/switch output Ex-i passive |
| | | Н | Relay |
| | | I | 4-20mA input |
| | | J | Status input |
| 7 | Output, input 3 | A | W/o |
| | | В | 4-20mA |
| | | С | 4-20mA Ex-i passive |
| | | D | Configurable I/O initial setting off |
| | | Е | Pulse/frequency/switch output |
| | | F | Pulse output, phase-shifted |
| | | G | Pulse/frequency/switch output Ex-i passive |
| | | Н | Relay |
| | | I | 4-20mA input |
| | | J | Status input |

| Position | Order code for | Option selected | Description |
|----------|--------------------|-----------------|---|
| 8 | Display; Operation | A | W/o; via communication |
| | | F | 4-line, illuminated; touch control |
| | | G | 4-line, illuminated; touch control + WLAN |
| | | M | Without; prepared for remote display DKX001 1) |
| | | 0 | Separate, with remote display DKX001 $^{1)}$, 4-line, illuminated; 10 m / 30 ft cable; touch control |
| 9 | Housing | A | Alu, coated |
| | | В | Stainless, hygienic |
| 11 | Liner | A | PFA |
| | | В | PFA High-temperature |
| | | E | PTFE |
| | | Н | Hard rubber |
| | | Q | PTFE 90°C |
| | | U | Polyurethane |
| 17, 18 | Device Model | A1 | 1 |
| | | A2 | 2 |

1) DKX001 is separately approved.

Optional specifications

| 1 | ID Order code for Option selected | | Option selected | Description | | |
|---|-----------------------------------|----------------------|-----------------|--|--|--|
| | Cx Sensor option CG | | CG | Extended neck for insulation ¹⁾ | | |
| į | Px | Enclosed accessories | Р8 | Wireless antenna, wide area (external WLAN antenna) 2) | | |

- 1) Only for Promag W and Promag P available
- 2) The external WLAN antenna is available with the order code for "Accessory Enclosed", option P8.

Safety instructions: General

- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations or guidelines (e.g. FOCT IEC 60079-14-2013)
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.

 Only use the device in media to which the wetted materials have sufficient durability.

- Refer to the temperature tables for the relationship between the permitted ambient temperature for the sensor and/or transmitter, depending on the range of application, and the temperature classes.
- Alterations to the device can affect the explosion protection and must be carried out by staff authorized to perform such work by Endress+Hauser.
- Observe all the technical data of the device (see nameplate).

Safety instructions: Installation

- In the case of a horizontal orientation and the order code for "Housing", option B "Stainless, hygienic": install the transmitter at the side of or below the sensor.
- The following applies for devices with order code for "Housing",
 Option B "Stainless, hygienic": Thermal insulation is not allowed.
- Continuous service temperature of the connecting cable: -40 to +80 °C; but at least according to the operating temperature range of the application plus allowance for process conditions ($T_{a, min}$ and $T_{a, max} + 20$ K).
- Only use certified cable glands suitable for the application. Observe selection criteria as per FOCT IEC 60079-14-2013.
- When the measuring device is connected, attention must be paid to the type of protection at the transmitter.
- Turning the transmitter housing
 - Loosen both hexagon socket screws until the transmitter housing can be turned.
 - Turn transmitter housing to desired position (mechanically limited); if necessary turn 270° in other direction.
 - Tighten both hexagon socket screws with a maximum of 7 Nm.
- In potentially explosive atmospheres:
 - Do not disconnect the electrical connection of the power supply circuit when energized.
 - Do not open the connection compartment cover when the device is energized.

Ex ec type of protection

- In potentially explosive atmospheres: Do not disconnect the electrical connection of the power supply circuit when energized.
- Seal unused entry glands with approved sealing plugs that correspond to the type of protection.
- Only use certified cable entries or sealing plugs.
- Equipment in type of protection Ex ec, shall be installed using a transient protection not exceeding 140% of the peak rated voltage value at the power supply terminals and IO terminals.
- For measuring devices with order code "Housing", option B "Stainless, hygienic":
 - To close the connection compartment cover, first hand-tight the cover and then tighten it further 45° (corresponds to 15 Nm).
 - In combination with order code "Display; Operation", option F or G "4-line illum.": Prevent electrostatic charge. Clean only with moist cloth

Optional external WLAN antenna

- Connect the antenna bushing H337 to the transmitter housing and tighten by hand.
- Use only external antennas supplied by Endress+Hauser.
- Connect antenna or antenna cable with plug-in connector type N (MIL-STD-348) to antenna bushing H337.

Intrinsic safety

Observe the guidelines for interconnecting intrinsically safe circuits (e.g. Γ OCT IEC 60079-14-2013 , proof of intrinsic safety).



- When using the remote display and operating module DKX001 the internal display and operating module must be removed.
- When using the separate approved, remote display and operating module DKX001, only use the following variants:
 Basic specification of the remote display and operating module DKX001, order code "Approval", option GS, BS

Potential equalization

- Integrate the device into the potential equalization .
- If the ground connection has been established via the pipe as specified, it is also possible to integrate the sensor into the potential equalization system via the pipe.
- The antenna bushing H337 of the external antenna must be integrated into the potential equalization system. This is the case if the sensor is connected in accordance with the regulations via the coupling.

Temperature tables

Ambient temperature

Minimum ambient temperature

 $T_{a. min} = -40 \,^{\circ}\text{C}$

Maximum ambient temperature

 $T_{\text{a, max}}$ = +60 $^{\circ}\text{C}$ depending on the medium temperature and temperature class.

Medium temperature

Minimum medium temperature

 $T_{\text{m, min}} = -40$ to 0 $^{\circ}\text{C}$ depending on the selected device version (see nameplate!)

Maximum medium temperature

 $T_{\text{m, max}}$ for T5...T1 depending on the maximum ambient temperature $T_{\text{a, max}}$

Maximum medium temperature with or without thermal insulation according to Endress+Hauser specifications

Promag H

| DN | T _{a, max} | T _{m, max} [°C] | | | | | | |
|--------------|---------------------|--------------------------|------------------|---------------|---------------|----------------|---------------|--|
| | [°C] | T6 [85 °C] | T5 [100°C] | T4 [135 ℃] | T3 [200 ℃] | T2 [300 °C] | T1 [450°C] | |
| Without ther | mal insulatio | n | • | | | | | |
| 2 to 150 | 50 | - | 95 ¹⁾ | 130 | 150 | 150 | 150 | |
| | 55 ²⁾ | - | 80 1) | 130 | 150 | 150 | 150 | |
| | 60 ²⁾ | - | _ | 100 | 100 | 100 | 100 | |

¹⁾ The maximum admissible ambient temperature changes for devices with order code for "Housing", Option B "Stainless, hygienic" in connection with temperature class T5: $T_a = T_a - 3$ K

Promag P

| DN | Liner | T _{a, max} | | | ıax [℃] | | | | |
|--------------|----------------------------|---------------------|--------------|---------------|---------------|---------------|---------------|---------------|--|
| | | [°C] | T6 [85 ℃] | T5 [100°C] | T4 [135 ℃] | T3 [200°C] | T2 [300°C] | T1 [450 ℃] | |
| Without ther | Without thermal insulation | | | | | | | | |
| 15 to 600 | PTFE | 50 | - | 90 | 130 | 130 | 130 | 130 | |
| | | 55 | - | - | 130 | 130 | 130 | 130 | |
| | | 60 | - | - | 100 | 100 | 100 | 100 | |

²⁾ $T_{a. max} = 50$ °C for optional specification, ID Cx (Sensor option) = CI (Fluid Temperature Probe)

| DN | Liner | T _{a, max} | | | T _{m, m} | ax [°C] | | | | | |
|--------------|---|---------------------|-----------------|-----------------|-------------------|-----------------|----------------|---------------|--|--|--|
| | | [°C] | T6 [85 ℃] | T5 [100 °C] | T4 [135 ℃] | T3 [200°C] | T2 [300 °C] | T1 [450 ℃] | | | |
| 25 to 200 | PFA | 40 | _ | _ | - | 150 | 150 | 150 | | | |
| | | 45 | - | 95 | 130 | 130 | 130 | 130 | | | |
| | | 50 | - | 90 | 130 | 130 | 130 | 130 | | | |
| | | 60 | - | - | 100 | 100 | 100 | 100 | | | |
| Extended neo | k for insulatio | n (Optional | specification | ı, ID Cx (Senso | or Option) = Co | G), with or wit | hout thermal | insulation | | | |
| 15 to 300 | PTFE | 50 | - | 90 | 130 | 130 | 130 | 130 | | | |
| | | 55 | - | - | 130 | 130 | 130 | 130 | | | |
| | | 60 | - | - | 100 | 100 | 100 | 100 | | | |
| 25 to 200 | PFA | 40 | - | - | - | 150 | 150 | 150 | | | |
| | | 45 | - | 95 | 130 | 130 | 130 | 130 | | | |
| | | 50 | - | 90 | 130 | 130 | 130 | 130 | | | |
| | | 60 | _ | _ | 100 | 100 | 100 | 100 | | | |
| High-tempera | ature version (| Order code | for "Liner", op | otion B) witho | ut thermal ins | sulation | | | | | |
| 25 to 200 | PFA | 45 | - | 95 | 130 | 180 | 180 | 180 | | | |
| | | 50 | - | 90 | 130 | 160 | 160 | 160 | | | |
| | | 60 | - | - | 100 | 100 | 100 | 100 | | | |
| High-temper | High-temperature version (Order code for "Liner", option B) with thermal insulation | | | | | | | | | | |
| 25 to 200 | PFA | 45 | - | 95 | 130 | 170 | 170 | 170 | | | |
| | | 50 | - | 90 | 130 | 160 | 160 | 160 | | | |
| | | 60 | - | - | 100 | 100 | 100 | 100 | | | |

Promag W

| DN | Liner | T _{a, max} T _{m, max} [°C] | | | | | | | | |
|--------------|----------------------------|--|--------------|---------------|---------------|---------------|---------------|---------------|--|--|
| | | | T6 [85 ℃] | T5 [100 ℃] | T4 [135 ℃] | T3 [200°C] | T2 [300°C] | T1 [450 ℃] | | |
| Without ther | Without thermal insulation | | | | | | | | | |
| 25 to 300 | PTFE | 50 | - | 90 | 90 | 90 | 90 | 90 | | |
| | | 55 | - | - | 90 | 90 | 90 | 90 | | |
| | | 60 | - | - | 90 | 90 | 90 | 90 | | |
| 50 to 3000 | Hard rubber | 50 | - | 80 | 80 | 80 | 80 | 80 | | |


| DN | Liner | T _{a, max} | | $T_{m, max}$ [°C] | | | | | | | |
|--------------|---|---------------------|--------------|-------------------|---------------|----------------|----------------|---------------|--|--|--|
| | | [°C] | T6 [85 ℃] | T5 [100°C] | T4 [135 ℃] | T3 [200 °C] | T2 [300 °C] | T1 [450 ℃] | | | |
| | | 60 | _ | - | 80 | 80 | 80 | 80 | | | |
| 25 to 1200 | PU | 50 | _ | 50 | 50 | 50 | 50 | 50 | | | |
| Extended neo | Extended neck for insulation (Optional specification, ID Cx (Sensor Option) = CG), with or without thermal insulation | | | | | | | | | | |
| 25 to 300 | PTFE | 50 | - | 90 | 90 | 90 | 90 | 90 | | | |
| | | 55 | - | - | 90 | 90 | 90 | 90 | | | |
| | | 60 | - | - | 90 | 90 | 90 | 90 | | | |
| 50 to 300 | Hard rubber | 50 | - | 80 | 80 | 80 | 80 | 80 | | | |
| | | 60 | - | - | 80 | 80 | 80 | 80 | | | |
| 25 to 1200 | PU | 50 | - | 50 | 50 | 50 | 50 | 50 | | | |

With thermal insulation without Endress+Hauser specifications NOTICE

The following applies for devices with order code for "Housing", Option B "Stainless, hygienic":

▶ Thermal insulation is not allowed.

The specified reference temperature T_{ref} and the maximum medium temperature $T_{m.\,max}$ for each temperature class must not be exceeded.



A0038947

- High-temperature version or extension neck for insulation: position of reference point for temperature measurement
- 1 Reference point (T_{ref})

Reference temperature T_{ref}

| T6 | T5 | T4 | T3 | T2 | T1 |
|---------|---------|---------|---------|---------|----------|
| [85 °C] | [100°C] | [135 ℃] | [200 ℃] | [300 ℃] | [450 °C] |
| - | 62.2 | 74,0 | 75.6 | 75.6 | 75.6 |


Explosion hazards arising from gas and dust

Determining the temperature class and surface temperature with the temperature table $% \left(\mathbf{r}\right) =\left(\mathbf{r}\right)$

- In the case of gas: Determine the temperature class as a function of the maximum ambient temperature $T_{a,\,max}$ and the maximum medium temperature $T_{m,\,max}$.
- In the case of dust: Determine the maximum surface temperature as a function of the maximum ambient temperature $T_{a,\,max}$ and the maximum medium temperature $T_{m,\,max}$.

Example

- Measured maximum ambient temperature: $T_{a, max} = 63 \, ^{\circ}\text{C}$
- \blacksquare Measured maximum medium temperature: $T_{\text{m, max}}$ = 108 °C



A0031267

- 2 Procedure for determining the temperature class and surface temperature
 - 1. In the column for the maximum ambient temperature $T_{a,\,max}$ select the temperature that is immediately greater than or equal to the maximum ambient temperature $T_{a,\,max}$ that is present.
 - $T_{a, max} = 60 \, ^{\circ}C$. The row showing the maximum medium temperature is determined.
- 2. Select the maximum medium temperature $T_{m,\,max}$ of this row, which is immediately greater than or equal to the maximum medium temperature $T_{m,\,max}$ that is present.
 - The column with the temperature class for gas is determined: $108 \,^{\circ}\text{C} < 130 \,^{\circ}\text{C} \rightarrow T4$.
- 3. The maximum temperature of the temperature class determined corresponds to the maximum surface temperature for dust: T4 = 135 °C.

Connection values: Signal circuits

The following tables contain specifications which are dependent on the transmitter type and its input and output assignment. Compare the following specifications with those on the nameplate of the transmitter.

Terminal assignment

Transmitter: supply voltage, input/outputs

HART

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|----------------|-------|----------------|---------------|----------------|---------------------|----------------|----------|
| 1 (+) | 2 (-) | 26 (+) | 27 (-) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | Device-s | specific term | , | nent: adhes rer. | ive label in | terminal |

FOUNDATION Fieldbus

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|----------------|-------|----------------|---------------|---------------------|---------------------|----------------|----------|
| 1 (+) | 2 (-) | 26 (A) | 27 (B) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | Device-s | specific term | inal assignr cov | nent: adhes rer. | ive label in | terminal |

PROFIBUS DP

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|----------------|-------|----------------|--------------|---------------------|--------|----------------|----------|
| 1 (+) | 2 (-) | 26 (B) | 27 (A) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | Device-s | pecific term | inal assignr cov | | ive label in | terminal |

PROFIBUS PA

| : | Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|---|----------------|-------|----------------|--------------|---------------------|--------|----------------|----------|
| 1 | L (+) | 2 (-) | 26 (B) | 27 (A) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | | Device-s | pecific term | inal assignr cov | | ive label in | terminal |

Modbus RS485

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|----------------|-------|----------------|---------------|---------------------|--------|----------------|----------|
| 1 (+) | 2 (-) | 26 (B) | 27 (A) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | Device-s | specific term | inal assignr cov | | ive label in | terminal |

Modbus TCP with Ethernet-APL

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | |
|----------------|-------|----------------|---------------|---------------------|--------|----------------|----------|
| 1 (+) | 2 (-) | 26 (+) | 27 (-) | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| | | Device-s | specific term | inal assignr cov | | ive label in | terminal |

PROFINET

| Suppl | y voltage | Input/output 1 | Input/output 2 | | Input/output 3 | |
|-------|-----------|------------------------------|----------------|---|----------------|--|
| 1 (+) | 2 (-) | PROFINET (RJ45 connector) | Device | 25 (–) -specific ter esive label ir | | |


PROFINET with Ethernet-APL

| Supply voltage | | Input/output 1 | | Input/output 2 | | Input/output 3 | | |
|----------------|-------|----------------|---|----------------|--------|----------------|--------|--|
| 1 (+) | 2 (-) | 26 (+) | 27 (-) | 24 (+) | 25 (-) | 22 (+) | 23 (-) | |
| | | Device-s | Device-specific terminal assignment: adhesive label in terminal | | | | | |
| | | | | COA | er. | | | |

EtherNet/IP

| Supply voltage | | Input/output 1 | Input/output 2 | | Input/output 3 | |
|----------------|-------|---------------------------------|---|--|----------------|--|
| 1 (+) | 2 (-) | EtherNet/IP (RJ45 connector) | 24 (+) 25 (-) 22 Device-specific terminal adhesive label in term | | - | |

Remote display and operating module DKX001



A0027518

- 1 Remote display and operating module DKX001
- 2 Protective earth (PE)
- 3 Connecting cable
- 4 Measuring device
- 5 Protective earth (PE)

Safety-related values

| Order code "Output; input 1" | Output type | Safety-related values "Output; input 1" | | |
|---------------------------------|-----------------------------------|--|--|--|
| | | 26 (+) 27 (-) | | |
| Option BA | Current output 4 to 20 mA HART | $U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$ | | |
| Option GA | PROFIBUS PA | $U_{N} = 32 V_{DC}$ $U_{M} = 250 V_{AC}$ | | |
| Option LA | PROFIBUS DP | $U_{N} = 32 V_{DC}$ $U_{M} = 250 V_{AC}$ | | |
| Option MA | Modbus RS485 | $U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$ | | |
| Option MB | Modbus TCP with Ethernet-APL | APL port profile SLAX SPE PoDL classes 10, 11, 12 $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | |
| Option SA | FOUNDATION Fieldbus | $U_{N} = 32 V_{DC}$ $U_{M} = 250 V_{AC}$ | | |
| Option NA | EtherNet/IP | $\begin{array}{c} U_N = 30 \ V_{DC} \\ U_M = 250 \ V_{AC} \end{array}$ | | |

| Order code "Output; input 1" | Output type | Safety-related values "Output; input 1" | | |
|---------------------------------|-------------------------------|--|--|--|
| | | 26 (+) 27 (-) | | |
| Option RA | PROFINET | $U_N = 30 V_{DC}$ $U_M = 250 V_{AC}$ | | |
| Option RB | PROFINET with Ethernet-APL | APL port profile SLAX SPE PoDL classes 10, 11, 12 $U_N = 30 \ V_{DC}$ $U_M = 250 \ V_{AC}$ | | |

| Order code | Output type | Safety-related values | | | |
|--------------------------------------|-----------------------------------|--|--------|---------|---------|
| "Output; input 2"; "Output; input 3" | | Output; input 2 | | Output; | input 3 |
| | | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| Option B | Current output 4 to 20 mA | $\begin{array}{l} U_N = 30 \ V_{DC} \\ U_M = 250 \ V_{AC} \end{array}$ | | | |
| Option D | User-configurable input/output | $U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$ | | | |
| Option E | Pulse/frequency/ switch output | $\begin{array}{c} U_N = 30 \ V_{DC} \\ U_M = 250 \ V_{AC} \end{array}$ | | | |
| Option F | Double pulse output | $U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$ | | | |
| Option H | Relay output | $U_{N} = 30 V_{DC}$ $I_{N} = 100 \text{ mA}_{DC} / 500 \text{ mA}_{AC}$ $U_{M} = 250 V_{AC}$ | | | |
| Option I | Current input 4 to 20 mA | $U_{N} = 30 V_{DC}$ $U_{M} = 250 V_{AC}$ | | | |
| Option J | Status input | $\begin{aligned} &U_N = 30 \ V_{DC} \\ &U_M = 250 \ V_{AC} \end{aligned}$ | | | |

Intrinsically safe values

| Order code for "Output; input 1" | Output type | Intrinsically safe values "Output; input 1" | |
|----------------------------------|--|--|--|
| | | 26 (+) | 27 (-) |
| Option HA | PROFIBUS PA Ex i (STANDARD + FISCO) | $\begin{split} &U_{i} = 32 \ V \\ &I_{i} = 570 \ mA \\ &P_{i} = 8.5 \ W \\ &L_{i} = 10 \ \mu H \\ &C_{i} = 5 \ nF \end{split}$ | |
| Option MC | Modbus TCP with Ethernet-APL Ex i | 2-WISE power load, A | APL port profile |
| Option RC | PROFINET with Ethernet-APL Ex i | $\begin{aligned} &\textbf{Ex ic} \\ &\textbf{U}_i = 17.5 \text{ V} \\ &\textbf{I}_i = 380 \text{ mA} \\ &\textbf{P}_i = 5.32 \text{ W} \\ &\textbf{L}_i = 10 \text{ μH} \\ &\textbf{C}_i = 5 \text{ nF} \end{aligned}$ $\begin{aligned} &\textbf{Cable specifications a} \\ &\textbf{R}_c = 15 \text{ to } 150 \Omega / \text{km} \\ &\textbf{L}_c = 0.4 \text{ to } 1 \text{ mH/km} \end{aligned}$ $&\textbf{C}_c = 45 \text{ to } 200 \text{ nF/km} \end{aligned}$ $&\textbf{C}_c = C_c \text{ line/line } + O_c \text{ lines are floating, or } \\ &\textbf{C}_c = C_c \text{ line/line } + C_c lis screen is connected to Length of cable (not in line section of the line section of $ | C _c line/screen, if both ne/screen, if the one line ncluding cable stubs): |
| Option TA | FOUNDATION Fieldbus Ex i (STANDARD + FISCO) | $\begin{split} &U_{i} = 32 \text{ V} \\ &I_{i} = 570 \text{ mA} \\ &P_{i} = 8.5 \text{ W} \\ &L_{i} = 10 \mu\text{H} \\ &C_{i} = 5 \text{ nF} \end{split}$ | |

1) For further options see Ethernet-APL Installation Drawing HE_01622 .

| Order code for | Output type | Intrinsically safe values | | | |
|--------------------------------------|---|---|--------|-----------------|--------|
| "Output; input 2"; "Output; input 3" | | Output; input 2 | | Output; input 3 | |
| | | 24 (+) | 25 (-) | 22 (+) | 23 (-) |
| Option C | Current output 4 to 20 mA Ex i passive | $U_{i} = 30 \text{ V}$ $l_{i} = 100 \text{ m.}$ $P_{i} = 1.25 \text{ V}$ $L_{i} = 0$ $C_{i} = 0$ | | | |
| Option G | Pulse/frequency/ switch output Ex i passive | $\begin{aligned} &U_i = 30 \text{ V} \\ &l_i = 100 \text{ mz} \\ &P_i = 1.25 \text{ V} \\ &L_i = 0 \\ &C_i = 0 \end{aligned}$ | | | |

Remote display DKX001

| Basic specification, position 1, 2 Approval | Terminal assignment | Basic specification, position 8 Display; operation Option O |
|--|---------------------|---|
| Option GS , BS | 81, 82, 83, 84 | $U_n = 3.3 \text{ V}$ |
| Option d3, B3 | | I _n = 150 mA |





71647209

www.addresses.endress.com