

Description of Device Parameters

Proline Prosonic Flow I 400

Ultrasonic time-of-flight flowmeter
Modbus RS485




Table of contents

1	About this document	4			
1.1	Document function	4			
1.2	Target group	4			
1.3	Using this document	4			
1.3.1	Information on the document structure	4			
1.3.2	Structure of a parameter description . .	6			
1.4	Symbols used	6			
1.4.1	Symbols for certain types of information	6			
1.4.2	Symbols in graphics	7			
1.5	Documentation	7			
1.5.1	Standard documentation	7			
1.5.2	Supplementary device-dependent documentation	7			
2	Overview of the Expert operating menu	8			
3	Description of device parameters	10			
3.1	"System" submenu	12			
3.1.1	"Display" submenu	12			
3.1.2	"Diagnostic handling" submenu	25			
3.1.3	"Administration" submenu	32			
3.2	"Sensor" submenu	37			
3.2.1	"Measured values" submenu	37			
3.2.2	"System units" submenu	45			
3.2.3	"Measuring point " submenu	52			
3.2.4	"Installation status" submenu	58			
3.2.5	"Process parameters" submenu	60			
3.2.6	"External compensation" submenu	64			
3.2.7	"Sensor adjustment" submenu	68			
3.2.8	"Calibration" submenu	73			
3.3	"Output" submenu	74			
3.3.1	"Current output 1" submenu	74			
3.3.2	"Pulse/frequency/switch output 1 to n" submenu	87			
3.4	"Communication" submenu	104			
3.4.1	"Modbus configuration" submenu	105			
3.4.2	"Modbus information" submenu	109			
3.4.3	"Modbus data map" submenu	110			
3.4.4	"Web server" submenu	111			
3.4.5	"WLAN settings" wizard	114			
3.5	"Application" submenu	121			
3.5.1	"Totalizer 1 to n" submenu	121			
3.5.2	"Inventory counter" submenu	126			
3.6	"Diagnostics" submenu	126			
3.6.1	"Diagnostic list" submenu	131			
3.6.2	"Device information" submenu	136			
3.6.3	"Main electronic module + I/O module 1" submenu	139			
3.6.4	"Sensor electronic module (ISEM)" submenu	140			
3.6.5	"Display module" submenu	141			
3.6.6	"Data logging" submenu	142			
3.6.7	"Heartbeat Technology" submenu	150			
3.6.8	"Simulation" submenu	160			
4	Country-specific factory settings	168			
4.1	SI units	168			
4.1.1	System units	168			
4.1.2	Output current span	168			
4.2	US units	168			
4.2.1	System units	168			
4.2.2	Output current span	168			
5	Explanation of abbreviated units	169			
5.1	SI units	169			
5.2	US units	169			
5.3	Imperial units	170			
6	Modbus RS485 register information	171			
6.1	Notes	171			
6.1.1	Structure of the register information	171			
6.1.2	Address model	171			
6.2	Overview of the Expert operating menu	172			
6.3	Register information	183			
6.3.1	"System" submenu	183			
6.3.2	"Sensor" submenu	186			
6.3.3	"Output" submenu	194			
6.3.4	"Communication" submenu	196			
6.3.5	"Application" submenu	199			
6.3.6	"Diagnostics" submenu	201			
	Index	206			

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:


- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→  8), which is displayed when the "**Maintenance**" user role is enabled.






1 Sample graphic for the schematic layout of the operating menu

- Additional information regarding:
- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions
 - Operating concept of the operating menus: Operating Instructions








1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code) or web browser  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Parameter entry range
Display	Display value/data of the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ For individual options ▪ For display value/data ▪ For the input range ▪ For the factory setting ▪ For the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
 A0028662	Operation via local display
 A0028663	Operation via operating tool
 A0028665	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning
1, 2, 3 ...	Item numbers
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Prosonic Flow I 400	BA02303D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Content	Documentation code
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Heartbeat Technology	SD03132D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert		
▶ System		→ 12
▶ Display		→ 12
▶ Diagnostic handling		→ 25
▶ Administration		→ 32
▶ Sensor		→ 37
▶ Measured values		→ 37
▶ System units		→ 45
▶ Measuring point 1		→ 52
▶ Installation status		→ 58
▶ Process parameters		→ 60
▶ External compensation		→ 64
▶ Sensor adjustment		→ 68
▶ Calibration		→ 73
▶ Output		→ 74
▶ Current output 1		→ 74
▶ Pulse/frequency/switch output 1 to n		→ 87
▶ Communication		→ 104
▶ Modbus configuration		→ 105
▶ Modbus information		→ 109
▶ Modbus data map		→ 110

▶ Web server	→ 111
▶ WLAN settings	→ 114
▶ Application	→ 121
Reset all totalizers (2806)	→ 121
▶ Totalizer 1 to n	→ 121
▶ Diagnostics	→ 126
Actual diagnostics (0691)	→ 130
Previous diagnostics (0690)	→ 130
Operating time from restart (0653)	→ 131
Operating time (0652)	→ 131
▶ Diagnostic list	→ 131
▶ Device information	→ 136
▶ Main electronic module	→ 139
▶ Sensor electronic module (ISEM)	→ 140
▶ Display module	→ 141
▶ Data logging	→ 142
▶ Heartbeat Technology	→ 150
▶ Simulation	→ 160

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
User role (0005)	→ 11
Enter access code (0003)	→ 12
▶ System	→ 12
▶ Sensor	→ 37
▶ Output	→ 74
▶ Communication	→ 104
▶ Application	→ 121
▶ Diagnostics	→ 126

Direct access



Navigation

Expert → Direct access (0106)

Description

Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.


User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



A0029414

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter 00914 → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign process variable** parameter

Locking status

Navigation  Expert → Locking status (0004)


Description Displays the active write protection.

User interface


- Hardware locked
- Temporarily locked

Additional information *Display*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Options

Options	Description
None	The access authorization displayed in the Access status display parameter (→  24) applies . Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) .
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

User role

Navigation  Expert → User role (0005)


Description Displays the access authorization to the parameters via the operating tool or Web browser.


User interface

- Operator
- Maintenance


Factory setting Maintenance

Additional information*Description*


 Access authorization can be modified via the **Enter access code** parameter (→  12).

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

Enter access code**Navigation**

 Expert → Ent. access code (0003)

Description

Use this function to enter the user-specific release code to remove parameter write protection.




User entry

Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu


Navigation




 Expert → System

▶ System	
▶ Display	→  12
▶ Diagnostic handling	→  25
▶ Administration	→  32

3.1.1 "Display" submenu



Navigation

 Expert → System → Display

▶ Display	
Display language (0104)	→  13
Format display (0098)	→  14
Value 1 display (0107)	→  16

0% bargraph value 1 (0123)	→  16
100% bargraph value 1 (0125)	→  17
Decimal places 1 (0095)	→  17
Value 2 display (0108)	→  18
Decimal places 2 (0117)	→  18
Value 3 display (0110)	→  19
0% bargraph value 3 (0124)	→  19
100% bargraph value 3 (0126)	→  20
Decimal places 3 (0118)	→  20
Value 4 display (0109)	→  20
Decimal places 4 (0119)	→  21
Display interval (0096)	→  21
Display damping (0094)	→  22
Header (0097)	→  22
Header text (0112)	→  23
Separator (0101)	→  23
Contrast display (0105)	→  24
Backlight (0111)	→  24

Display language

Navigation   Expert → System → Display → Display language (0104)

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.


Selection

- English
- Deutsch
- Français

- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation  Expert → System → Display → Format display (0098)

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.





Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting 1 value, max. size


Additional information *Description*

The display format (size, bar graph) and number of simultaneously displayed measured values (1 to 4) can be configured. This setting only applies to normal operation.

-  ▪ The **Value 1 display** parameter (→  16)...**Value 4 display** parameter (→  20) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (→  21).


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option



A0016530


"2 values" option



A0016531


2

"1 value large + 2 values" option











A0016532

"4 values" option





A0016533

Value 1 display 	
Navigation	 Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select a measured value that is shown on the local display.
Selection	<ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Flow velocity ▪ Sound velocity ▪ Temperature ▪ Density ▪ Electronics temperature ▪ Signal strength* ▪ Signal to noise ratio* ▪ Acceptance rate* ▪ Turbulence* ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed one below the other, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  14) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  45).</p>



0% bargraph value 1 	
Navigation	 Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-specific

* Visibility depends on order options or device settings

Additional information*Description*

 The **Format display** parameter (→  14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→  45).

100% bargraph value 1**Navigation**

  Expert → System → Display → 100% bargraph 1 (0125)

Prerequisite

A local display is provided.

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.



User entry

Signed floating-point number



Factory setting

Depends on country and nominal diameter

Additional information*Description*

 The **Format display** parameter (→  14) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→  45).

Decimal places 1**Navigation**

  Expert → System → Display → Decimal places 1 (0095)

Prerequisite

A measured value is specified in the **Value 1 display** parameter (→  16).

Description

Use this function to select the number of decimal places for measured value 1.


Selection










- x
- x.X
- x.XX
- x.XXX
- x.XXXX






Factory setting

x.XX

Additional information*Description*

 This setting does not affect the accuracy of the device for measuring or calculating the value.

Value 2 display 	
Navigation	  Expert → System → Display → Value 2 display (0108)
Prerequisite	A local display is provided.
Description	Use this function to select a measured value that is shown on the local display.
Selection	For the picklist, see Value 1 display parameter (→  16) or For the picklist, see Value 1 display parameter (→  16)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed one below the other, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  14) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  45).</p>









Decimal places 2 	
Navigation	  Expert → System → Display → Decimal places 2 (0117)
Prerequisite	A measured value is specified in the Value 2 display parameter (→  18).
Description	Use this function to select the number of decimal places for measured value 2.
Selection	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the accuracy of the device for measuring or calculating the value.</p>






Value 3 display





Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select a measured value that is shown on the local display.
Selection	For the picklist, see Value 1 display parameter (→ 16)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed one below the other, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 14) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Options</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 45).</p>






0% bargraph value 3


Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 19).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 14) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 45).</p>





100% bargraph value 3		
Navigation	  Expert → System → Display → 100% bargraph 3 (0126)	
Prerequisite	A selection was made in the Value 3 display parameter (→  19).	
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.	
User entry	Signed floating-point number	
Factory setting	0	
Additional information	<i>Description</i>	
	 The Format display parameter (→  14) is used to specify that the measured value is to be displayed as a bar graph.	
	<i>User entry</i>	
	 The unit of the displayed measured value is taken from the System units submenu (→  45).	

Decimal places 3		
Navigation	  Expert → System → Display → Decimal places 3 (0118)	
Prerequisite	A measured value is specified in the Value 3 display parameter (→  19).	
Description	Use this function to select the number of decimal places for measured value 3.	
Selection	<ul style="list-style-type: none"> ▪ X ▪ X.X ▪ X.XX ▪ X.XXX ▪ X.XXXX 	
Factory setting	x.xx	
Additional information	<i>Description</i>	
	 This setting does not affect the accuracy of the device for measuring or calculating the value.	



Value 4 display		
Navigation	  Expert → System → Display → Value 4 display (0109)	
Prerequisite	A local display is provided.	
Description	Use this function to select a measured value that is shown on the local display.	





Selection	For the picklist, see Value 1 display parameter (→  16)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed one below the other, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→  14) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Options</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→  45).</p>

Decimal places 4




Navigation	  Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (→  20).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	<ul style="list-style-type: none"> ▪ x ▪ x.x ▪ x.xx ▪ x.xxx ▪ x.xxxx
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the accuracy of the device for measuring or calculating the value.</p>

Display interval



Navigation	  Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s
Factory setting	5 s

Additional information	<p><i>Description</i></p> <p>This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.</p> <ul style="list-style-type: none">  <ul style="list-style-type: none"> ▪ The Value 1 display parameter (→  16)...Value 4 display parameter (→  20) are used to specify which measured values are shown on the local display. ▪ The display format for the measured values displayed is defined in the Format display parameter (→  14).
-------------------------------	---


Display damping

Navigation	  Expert → System → Display → Display damping (0094)
Prerequisite	A local display is provided.
Description	Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	0.0 s
Additional information	<p><i>User entry</i></p> <p>Use this function to enter a time constant (PT1 element ¹⁾) for display damping:</p> <ul style="list-style-type: none"> ▪ At a low time constant, the display reacts quickly to fluctuating measured variables. ▪ If a high time constant is entered, the display reacts more slowly. <p> The damping is not active if the value 0 (factory setting) is entered.</p>

Header

Navigation	  Expert → System → Display → Header (0097)
Prerequisite	A local display is provided.
Description	Use this function to select the contents of the header of the local display.
Selection	<ul style="list-style-type: none"> ▪ Device tag ▪ Free text
Factory setting	Device tag
Additional information	<p><i>Description</i></p> <p>The header text only appears during normal operation.</p>

1) proportional transmission behavior with first order delay



A0029422

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 136).
- Free text
Is defined in the **Header text** parameter (→ 23).

Header text

Navigation

Expert → System → Display → Header text (0112)

Prerequisite

The **Free text** option is selected in the **Header** parameter (→ 22).

Description

Use this function to enter a customer-specific text for the header of the local display.

User entry


Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information

Description

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation

Expert → System → Display → Separator (0101)

Prerequisite

A local display is provided.



Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation   Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting 50 %

Backlight

Navigation   Expert → System → Display → Backlight (0111)

Prerequisite A local display is provided.



Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

Access status display

Navigation   Expert → System → Display → Access stat.disp (0091)

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.


User interface



- Operator
- Maintenance


Factory setting Operator


Additional information

Description


If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.

 Access authorization can be modified via the **Enter access code** parameter (→  12).

 For information about the **Enter access code** parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device


 If additional write protection is active, this restricts the current access authorization even further.

User interface



 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device

3.1.2 "Diagnostic handling" submenu


Navigation   Expert → System → Diagn. handling



Alarm delay 

Navigation   Expert → System → Diagn. handling → Alarm delay (0651)


Description Use this function to enter the time interval until the device generates a diagnostic message.

 The diagnostic message is reset without a time delay.

User entry 0 to 60 s

Factory setting 0 s

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→  25).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The measured value output via Modbus RS485 and the totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The measured value output via Modbus RS485 and the totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (Event list submenu) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.





For a list of all the diagnostic events, see the Operating Instructions for the device → 7





Navigation

Expert → System → Diagn. handling → Diagn. behavior





► Diagnostic behavior	
Assign behavior of diagnostic no. 019 (0635)	→ 27
Assign behavior of diagnostic no. 160 (0776)	→ 27
Assign behavior of diagnostic no. 302 (0742)	→ 27
Assign behavior of diagnostic no. 441 (0657)	→ 28
Assign behavior of diagnostic no. 442 (0658)	→ 28
Assign behavior of diagnostic no. 443 (0659)	→ 29
Assign behavior of diagnostic no. 832 (0675)	→ 29
Assign behavior of diagnostic no. 833 (0676)	→ 29
Assign behavior of diagnostic no. 841 (0680)	→ 30
Assign behavior of diagnostic no. 842 (0638)	→ 30
Assign behavior of diagnostic no. 870 (0726)	→ 30

Assign behavior of diagnostic no. 930 (0639)	→  31
Assign behavior of diagnostic no. 931 (0640)	→  31



Assign behavior of diagnostic no. 019 (Device initialization active)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 019 (0635)
Description	Use this function to change the diagnostic behavior of the △S019 Device initialization active diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 160 (Signal path switched off)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)
Description	Use this function to change the diagnostic behavior of the 160 Signal path switched off diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available: →  26





Assign behavior of diagnostic no. 302 (Device verification active)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0742)
Description	Use this function to change the diagnostic behavior of the 302 Device verification active diagnostic message.

Selection	<ul style="list-style-type: none"> ■ Off ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available: →  26





Assign behavior of diagnostic no. 441 (Current output 1 to n)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)
Description	Use this function to change the diagnostic behavior of the 441 Current output 1 to n diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	<i>Selection</i>  For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 442 (Frequency output 1 to n)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the 442 Frequency output 1 to n diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 443 (Pulse output)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the 443 Pulse output diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	<i>Selection</i> For a detailed description of the options available: → 26

Assign behavior of diagnostic no. 832 (Electronics temperature too high)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)
Description	Use this function to change the diagnostic behavior of the 832 Electronics temperature too high diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available: → 26



Assign behavior of diagnostic no. 833 (Electronics temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
Description	Use this function to change the diagnostic behavior of the 833 Electronics temperature too low diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only

Factory setting Warning

Additional information *Selection*

 For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 841



Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 841 (0680)

Description Use this function to change the diagnostic behavior of the **△S841 Flow velocity too high** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 842 (Process limit)

Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)

Description Use this function to change the diagnostic behavior of the **842 Process limit** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only



Factory setting Off

Additional information  For a detailed description of the options available: →  26





Assign behavior of diagnostic no. 870 (Measuring inaccuracy increased)

Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 870 (0726)





Description Use this function to change the diagnostic behavior of the **870 Measuring inaccuracy increased** diagnostic message.

Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Off
Additional information	<i>Selection</i>  For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 930 (Process fluid)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 930 (0639)
Description	Use this function to change the diagnostic behavior of the Δ S930 Process fluid diagnostic message.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Alarm
Additional information	 For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 931 (Process fluid)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 931 (0640)
Description	Use this function to change the diagnostic behavior of the Δ S931 Process fluid diagnostic message.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Alarm
Additional information	 For a detailed description of the options available: →  26

Assign behavior of diagnostic no. 953 (Asymmetry noise signal too high path 1 to n)


Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 953 (0636)
Description	Use this function to change the diagnostic behavior of the △M953 Asymmetry noise signal too high path 1 to n diagnostic message.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available: → 26

3.1.3 "Administration" submenu


Navigation Expert → System → Administration

▶ Administration	
▶ Define access code	→ 32
▶ Reset access code	→ 34
Device reset (0000)	→ 35
Activate SW option (0029)	→ 35
Software option overview (0015)	→ 36


"Define access code" wizard


The **Define access code** wizard (→ 32) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.


Navigation  Expert → System → Administration → Def. access code

▶ Define access code

→  33

→  33



Define access code

Navigation  Expert → System → Administration → Def. access code → Def. access code



Description Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry 0 to 9999

Factory setting 0

Additional information *Description*
 The write protection affects all parameters in the document marked with the  symbol. On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  12).

 If you lose the access code, please contact your Endress+Hauser sales organization.


User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the **"Maintenance"** role.

Confirm access code

Navigation  Expert → System → Administration → Def. access code → Confirm code


Description Enter the defined release code a second time to confirm the release code.

User entry 0 to 9999

Factory setting 0

"Reset access code" submenu

Navigation  Expert → System → Administration → Reset acc. code



Operating time


Navigation  Expert → System → Administration → Reset acc. code → Operating time (0652)

Description Displays the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Indication*
Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)

Reset access code

Navigation  Expert → System → Administration → Reset acc. code → Reset acc. code (0024)

Description Use this function to enter a reset code to reset the user-specific access codes to the factory setting .

User entry Character string comprising numbers, letters and special characters

Factory setting 0x00

Additional information

Description



For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via CDI RJ45 interface)
- Fieldbus

Additional parameters in the "Administration" submenu

Device reset 									
Navigation	Expert → System → Administration → Device reset (0000)								
Description	Reset the device configuration - either entirely or in part - to a defined state.								
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ To delivery settings ▪ Restart device ▪ Restore S-DAT backup * 								
Factory setting	Cancel								
Additional information	<i>Selection</i>								
	<table border="1"> <thead> <tr> <th style="text-align: left;">Options</th> <th style="text-align: left;">Description</th> </tr> </thead> <tbody> <tr> <td>Cancel</td> <td>No action is executed and the user exits the parameter.</td> </tr> <tr> <td>To delivery settings</td> <td>Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.</td> </tr> <tr> <td>Restart device</td> <td>The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.</td> </tr> </tbody> </table>	Options	Description	Cancel	No action is executed and the user exits the parameter.	To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.	Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Options	Description								
Cancel	No action is executed and the user exits the parameter.								
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.								
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.								

Activate SW option 	
Navigation	Expert → System → Administration → Activate SW opt. (0029)
Description	Use this function to enter an activation code to enable an additional, ordered software option.
User entry	Max. 10-digit string of numbers.


* Visibility depends on order options or device settings

Factory setting


Depends on the software option ordered

Additional information*Description*


If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

Entering the activation code


 The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.


- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→  36).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- ▶ If the code entered is incorrect or invalid, enter the old activation code .
- ▶ Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

 The software options currently enabled are displayed in the **Software option overview** parameter (→  36).

Web browser

 Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation

  Expert → System → Administration → SW option overv. (0015)

Description

Displays all the software options that are enabled in the device.

User interface

or

- Extended HistoROM
- 4-20mA, 2x pulse/freq./switch output
- Heartbeat Verification
- Heartbeat Monitoring

Additional information

Description

Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"Heartbeat Verification" option and "Heartbeat Monitoring" option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

3.2 "Sensor" submenu


Navigation

  Expert → Sensor

▶ Sensor	
▶ Measured values	→ 37
▶ System units	→ 45
▶ Measuring point 1	→ 52
▶ Installation status	→ 58
▶ Process parameters	→ 60
▶ External compensation	→ 64
▶ Sensor adjustment	→ 68
▶ Calibration	→ 73

3.2.1 "Measured values" submenu







Navigation

  Expert → Sensor → Measured val.


▶ Measured values	
▶ Process variables	→ 38
▶ System values	→ 40
▶ Totalizer	→ 41
▶ Output values	→ 43

"Process variables" submenu

Navigation  Expert → Sensor → Measured val. → Process variab.



▶ Process variables	
Volume flow (1838)	→  38
Mass flow (1847)	→  38
Flow velocity (1852)	→  39
Sound velocity (1850)	→  39
Density (1851)	→  39
Temperature (1853)	→  39

Volume flow


Navigation  Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description Displays the volume flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*
 The unit is taken from the **Volume flow unit** parameter (→  46)

Mass flow




Navigation  Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description Displays the mass flow that is currently calculated.




User interface Signed floating-point number

Additional information *Dependency*
 The unit is taken from the **Mass flow unit** parameter (→  48)




Flow velocity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Flow velocity (1852)
Description	Displays the average flow velocity that is currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Velocity unit parameter (→  49)


Sound velocity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Sound velocity (1850)
Description	Displays the sound velocity that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Velocity unit parameter (→  49)

Temperature

Navigation	 Expert → Sensor → Measured val. → Process variab. → Temperature (1853)
Prerequisite	Temperature is not entered as a fixed value.
Description	Displays the medium temperature that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  50)

Density

Navigation	 Expert → Sensor → Measured val. → Process variab. → Density (1851)
Prerequisite	A fixed density is not entered.
Description	Displays the density that is currently calculated.


User interface Signed floating-point number

Additional information *Dependency*



 The unit is taken from the **Density unit** parameter (→  50)

"System values" submenu

Navigation   Expert → Sensor → Measured val. → System values



Signal strength

Navigation   Expert → Sensor → Measured val. → System values → Signal strength (2914)

Description Displays the current signal strength.

User interface Signed floating-point number

Additional information *Description*

A drop in the signal strength over time can be an indicator of process changes, such as the development of deposits in the measuring pipe at the measuring point. , e.g. buildup of deposits in the measuring pipe at the measuring point. This can only be quantified by performing a direct process comparison with different deposit layer thicknesses and associated signal strengths.

Signal to noise ratio



Navigation   Expert → Sensor → Measured val. → System values → SNR (2917)

Description Displays the current signal to noise ratio.

User interface Signed floating-point number

Additional information *Description*
 A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality.



Acceptance rate

Navigation   Expert → Sensor → Measured val. → System values → Acceptance rate (2912)

Description Displays the ratio of the number of ultrasonic signals accepted for flow calculation and the total number of ultrasonic signals emitted.
 Multipath measuring devices only: Displays the minimum of all acceptance rates measured.

User interface 0 to 100 %

Turbulence



Navigation   Expert → Sensor → Measured val. → System values → Turbulence (2907)


Description Displays the current turbulence.

User interface Signed floating-point number


Additional information *Description*
 A high turbulence value indicates a disturbance in the flow profile.

"Totalizer" submenu

Navigation   Expert → Sensor → Measured val. → Totalizer




Totalizer 1 to n value

Navigation	 Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n value (0911–1 to n)
Description	Displays the current totalizer counter value.
User interface	Signed floating-point number
Factory setting	01


Totalizer 1 to n overflow




Navigation	 Expert → Sensor → Measured val. → Totalizer → Tot. 1 to n overflow (0910–1 to n)
Description	Displays the current totalizer overflow.
User interface	–32 000.0 to 32 000.0
Factory setting	0

"Input values" submenu

Navigation  Expert → Sensor → Measured val. → Input values











Value status input

Navigation	 Expert → Sensor → Measured val. → Input values → Val. status inp. (1353)
Prerequisite	For the following order code: "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"
Description	Displays the current input signal level.
User interface	<ul style="list-style-type: none"> ▪ High ▪ Low



"Output values" submenu

Navigation   Expert → Sensor → Measured val. → Output values

▶ **Output values**

Output current (0361)	→  43
Measured current (0366)	→  43
Pulse output (0456)	→  44
Output frequency (0471)	→  44
Switch state (0461)	→  45
Output frequency (0471)	→  44
Pulse output (0456)	→  44
Switch state (0461)	→  45



Output current

Navigation   Expert → Sensor → Measured val. → Output values → Output curr. (0361)

Description Displays the current value currently calculated for the current output.

User interface 0 to 22.5 mA






Measured current


Navigation   Expert → Sensor → Measured val. → Output values → Measur. curr. (0366)

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA


Pulse output 1 to n


Navigation	 Expert → Sensor → Measured val. → Output values → Pulse output (0456)  Expert → Sensor → Measured val. → Output values → Pulse output (0456)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  88) parameter.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ▪ The pulse output is an open collector output. ▪ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ▪ The Value per pulse parameter (→  90) and Pulse width parameter (→  91) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.






A0028726

0 Non-conductive
 1 Conductive
 NC Normally closed
 NO Normally opened




The output behavior can be reversed via the **Invert output signal** parameter (→  104) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→  92)) can be configured.


Output frequency 1 to n











Navigation	 Expert → Sensor → Measured val. → Output values → Output freq. (0471)  Expert → Sensor → Measured val. → Output values → Output freq. (0471)
Prerequisite	In the Operating mode parameter (→  88), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz

Switch state 1 to n

Navigation	 Expert → Sensor → Measured val. → Output values → Switch state (0461)  Expert → Sensor → Measured val. → Output values → Switch state (0461)
Prerequisite	In the Operating mode parameter (→  88), the Switch option is selected.
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation  Expert → Sensor → System units

▶ System units	
Volume flow unit (0553)	→  46
Volume unit (0563)	→  47
Mass flow unit (0554)	→  48
Mass unit (0574)	→  49
Velocity unit (0566)	→  49
Temperature unit (0557)	→  50
Density unit (0555)	→  50
Kinematic viscosity unit (0578)	→  51
Length unit (0551)	→  51
Date/time format (2812)	→  51

Volume flow unit
**Navigation**

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection

- cm³/s
- cm³/min
- cm³/h
- cm³/d
- dm³/s
- dm³/min
- dm³/h
- dm³/d
- m³/s
- m³/min
- m³/h
- m³/d
- ml/s
- ml/min
- ml/h
- ml/d
- l/s
- l/min
- l/h
- l/d
- hl/s
- hl/min
- hl/h
- hl/d
- Ml/s
- Ml/min
- Ml/h
- Ml/d
- af/s
- af/min
- af/h
- af/d
- ft³/s
- ft³/min
- ft³/h
- ft³/d
- Mft³/s
- Mft³/min
- Mft³/h
- Mft³/d
- fl oz/s (us)
- fl oz/min (us)
- fl oz/h (us)
- fl oz/d (us)
- gal/s (us)
- gal/min (us)
- gal/h (us)
- gal/d (us)
- Mgal/s (us)
- Mgal/min (us)
- Mgal/h (us)
- Mgal/d (us)

- bbl/s (us;liq.)
- bbl/min (us;liq.)
- bbl/h (us;liq.)
- bbl/d (us;liq.)
- bbl/s (us;beer)
- bbl/min (us;beer)
- bbl/h (us;beer)
- bbl/d (us;beer)
- bbl/s (us;oil)
- bbl/min (us;oil)
- bbl/h (us;oil)
- bbl/d (us;oil)
- bbl/s (us;tank)
- bbl/min (us;tank)
- bbl/h (us;tank)
- bbl/d (us;tank)
- gal/s (imp)
- gal/min (imp)
- gal/h (imp)
- gal/d (imp)
- Mgal/s (imp)
- Mgal/min (imp)
- Mgal/h (imp)
- Mgal/d (imp)
- bbl/s (imp;beer)
- bbl/min (imp;beer)
- bbl/h (imp;beer)
- bbl/d (imp;beer)
- bbl/s (imp;oil)
- bbl/min (imp;oil)
- bbl/h (imp;oil)
- bbl/d (imp;oil)
- kgal/s (us)
- kgal/min (us)
- kgal/h (us)
- kgal/d (us)


Factory setting

Country-specific:

- m³/h
- ft³/min

Additional information*Result*



The selected unit applies to:

Volume flow parameter (→  38)*Selection*
 For an explanation of the abbreviated units: →  169
Volume unit**Navigation**  Expert → Sensor → System units → Volume unit (0563)**Description**


Use this function to select the unit for the volume.

Selection	<ul style="list-style-type: none"> ■ cm³ ■ dm³ ■ m³ ■ ml ■ l ■ hl ■ Ml ■ af ■ ft³ ■ Mft³ ■ fl oz (us) ■ gal (us) ■ kgal (us) ■ Mgal (us) ■ bbl (us;oil) ■ bbl (us;liq.) ■ bbl (us;beer) ■ bbl (us;tank) ■ gal (imp) ■ Mgal (imp) ■ bbl (imp;beer) ■ bbl (imp;oil)
------------------	--

Factory setting	Country-specific: <ul style="list-style-type: none"> ■ m³ ■ ft³
------------------------	---

Additional information	<i>Selection</i>  For an explanation of the abbreviated units: →  169
-------------------------------	--

Mass flow unit

Navigation	 Expert → Sensor → System units → Mass flow unit (0554)
-------------------	--

Description	Use this function to select the unit for the mass flow.
--------------------	---

Selection	<table style="width: 100%; border: none;"> <thead> <tr> <th style="text-align: left;"><i>SI units</i></th> <th style="text-align: left;"><i>US units</i></th> </tr> </thead> <tbody> <tr><td>■ g/s</td><td>■ oz/s</td></tr> <tr><td>■ g/min</td><td>■ oz/min</td></tr> <tr><td>■ g/h</td><td>■ oz/h</td></tr> <tr><td>■ g/d</td><td>■ oz/d</td></tr> <tr><td>■ kg/s</td><td>■ lb/s</td></tr> <tr><td>■ kg/min</td><td>■ lb/min</td></tr> <tr><td>■ kg/h</td><td>■ lb/h</td></tr> <tr><td>■ kg/d</td><td>■ lb/d</td></tr> <tr><td>■ t/s</td><td>■ STon/s</td></tr> <tr><td>■ t/min</td><td>■ STon/min</td></tr> <tr><td>■ t/h</td><td>■ STon/h</td></tr> <tr><td>■ t/d</td><td>■ STon/d</td></tr> </tbody> </table>	<i>SI units</i>	<i>US units</i>	■ g/s	■ oz/s	■ g/min	■ oz/min	■ g/h	■ oz/h	■ g/d	■ oz/d	■ kg/s	■ lb/s	■ kg/min	■ lb/min	■ kg/h	■ lb/h	■ kg/d	■ lb/d	■ t/s	■ STon/s	■ t/min	■ STon/min	■ t/h	■ STon/h	■ t/d	■ STon/d
<i>SI units</i>	<i>US units</i>																										
■ g/s	■ oz/s																										
■ g/min	■ oz/min																										
■ g/h	■ oz/h																										
■ g/d	■ oz/d																										
■ kg/s	■ lb/s																										
■ kg/min	■ lb/min																										
■ kg/h	■ lb/h																										
■ kg/d	■ lb/d																										
■ t/s	■ STon/s																										
■ t/min	■ STon/min																										
■ t/h	■ STon/h																										
■ t/d	■ STon/d																										

Factory setting	Country-specific: <ul style="list-style-type: none"> ■ kg/h ■ lb/min
------------------------	--

Additional information*Result*

The selected unit applies to:
Mass flow parameter

Selection

For an explanation of the abbreviated units: → 169

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → 169

Velocity unit**Navigation**

Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection*SI units*

m/s

US units

ft/s

Factory setting

Depends on country:

- m/s
- ft/s

Additional information*Effect*

The selected unit applies to:

- Flow velocity (→ 39)
- Sound velocity (→ 39)

Options

For an explanation of the abbreviated units: → 169

Temperature unit


Navigation Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
<ul style="list-style-type: none"> ■ °C ■ K 	<ul style="list-style-type: none"> ■ °F ■ °R

Factory setting Country-specific:

- °C
- °F

Additional information *Result*

The selected unit applies to:

- Temperature (→ 39)
- Electronic temperature
- External temperature
- Reference temperature

Selection

For an explanation of the abbreviated units: → 169

Density unit


Navigation Expert → Sensor → System units → Density unit (0555)

Description Use this function to select the unit for the density.

Selection

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
<ul style="list-style-type: none"> ■ g/cm³ ■ g/m³ ■ kg/l ■ kg/dm³ ■ kg/m³ ■ SD4°C ■ SD15°C ■ SD20°C ■ SG4°C ■ SG15°C ■ SG20°C 	<ul style="list-style-type: none"> ■ lb/ft³ ■ lb/gal (us) ■ lb/bbl (us;liq.) ■ lb/bbl (us;beer) ■ lb/bbl (us;oil) ■ lb/bbl (us;tank) 	<ul style="list-style-type: none"> ■ lb/gal (imp) ■ lb/bbl (imp;beer) ■ lb/bbl (imp;oil)

Factory setting Country-specific:

- kg/dm³
- lb/ft³

Additional information *Selection*

For an explanation of the abbreviated units: → 169

Kinematic viscosity unit



Navigation	Expert → Sensor → System units → Kin. visc. unit (0578)
Description	Use this function to select the unit for the kinematic viscosity.
Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ cSt ■ St ■ mm²/s ■ m²/s
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ m²/s ■ cSt

Length unit





Navigation	Expert → Sensor → System units → Length unit (0551)				
Description	Use this function to select the unit of length of.				
Selection	<table style="width: 100%; border: none;"> <tr> <td style="width: 50%; vertical-align: top;"><i>SI units</i></td> <td style="width: 50%; vertical-align: top;"><i>US units</i></td> </tr> <tr> <td style="vertical-align: top;"> <ul style="list-style-type: none"> ■ m ■ mm </td> <td style="vertical-align: top;"> <ul style="list-style-type: none"> ■ ft ■ in </td> </tr> </table>	<i>SI units</i>	<i>US units</i>	<ul style="list-style-type: none"> ■ m ■ mm 	<ul style="list-style-type: none"> ■ ft ■ in
<i>SI units</i>	<i>US units</i>				
<ul style="list-style-type: none"> ■ m ■ mm 	<ul style="list-style-type: none"> ■ ft ■ in 				
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ mm ■ in 				
Additional information	<i>Selection</i> For an explanation of the abbreviated units: → 169				

Date/time format



















Navigation	Expert → Sensor → System units → Date/time format (2812)
Description	Use this function to select the desired time format for calibration history.
Selection	<ul style="list-style-type: none"> ■ dd.mm.yy hh:mm ■ dd.mm.yy hh:mm am/pm ■ mm/dd/yy hh:mm ■ mm/dd/yy hh:mm am/pm
Factory setting	dd.mm.yy hh:mm

Additional information*Options*

 For an explanation of the abbreviated units: →  169

3.2.3 "Measuring point " submenu*Navigation*

  Expert → Sensor → Meas. point

► Measuring point 1	
Measuring point configuration (5675-1)	→  53
Medium (2926-1)	→  53
Medium temperature (3053-1)	→  53
Sound velocity (2929-1)	→  54
Viscosity (2932-1)	→  54
Pipe dimensions (2943-1)	→  54
Pipe circumference (2934-1)	→  54
Pipe outer diameter (2910-1)	→  55
Pipe wall thickness (2916-1)	→  55
Liner thickness (2935-1)	→  55
Signal filter (3011-1)	→  56
Cable length (2939-1)	→  56
Intermediate pipe length (2945-1)	→  56
Result sensor type / sensor distance (3066-1)	→  56
Result path length / arc length (3067-1)	→  57
► Mounting deviations signal path 1 to n	→  57

Measuring point configuration


Navigation	Expert → Sensor → Meas. point 1 → Meas. pt config. (5675-1)
Description	Use this function to enter the measuring point configuration.
Selection	<ul style="list-style-type: none"> ▪ 1 measuring point - signal path 1 ▪ 1 measuring point - signal path 2 * ▪ 1 measuring point - 2 signal paths *
Factory setting	Depending on the sensor version

Medium





Navigation	Expert → Sensor → Meas. point 1 → Medium (2926-1)
Description	Select the medium.
Selection	<ul style="list-style-type: none"> ▪ Water ▪ Sea water ▪ Distilled water ▪ Ammonia NH₃ ▪ Benzene ▪ Ethanol ▪ Glycol ▪ Milk ▪ Methanol ▪ User-specific liquid
Factory setting	Water

Medium temperature




Navigation	Expert → Sensor → Meas. point 1 → Medium temp. (3053-1)
Description	Enter the medium temperature for the installation.
User entry	-200 to 550 °C
Factory setting	20 °C

* Visibility depends on order options or device settings


Sound velocity 


Navigation	 Expert → Sensor → Meas. point 1 → Sound velocity (2929-1)
Prerequisite	The User-specific liquid option is selected in Medium parameter (→  53).
Description	<p>Enter the sound velocity of the medium.</p> <p> If the sound velocity is not known, it can be determined with the following tools:</p> <ul style="list-style-type: none"> ▪ Endress+Hauser sound velocity sensor sets ▪ Prosonic Flow 93T with sound velocity sensors ▪ Iterative measurement of sound velocity and distance adjustment of sensor distance using flow sensors
User entry	200 to 3 000 m/s
Factory setting	1 482.4 m/s



Viscosity 

Navigation	 Expert → Sensor → Meas. point 1 → Viscosity (2932-1)
Prerequisite	The User-specific liquid option is selected in Medium parameter (→  53).
Description	Enter medium viscosity at installation temperature.
User entry	0.01 to 10 000 mm ² /s
Factory setting	1 mm ² /s

Pipe dimensions 

Navigation	 Expert → Sensor → Meas. point 1 → Pipe dimensions (2943-1)
Description	Select if pipe dimensions are defined by diameter or circumference.
Selection	<ul style="list-style-type: none"> ▪ Diameter ▪ Pipe circumference
Factory setting	Diameter

Pipe circumference 

Navigation	 Expert → Sensor → Meas. point 1 → Pipe circumfer. (2934-1)
Prerequisite	The Pipe circumference option is selected in the Pipe dimensions parameter (→  54).

Description	Define the pipe circumference.
User entry	30 to 62 800 mm
Factory setting	314.159 mm

Pipe outer diameter


Navigation	Expert → Sensor → Meas. point 1 → Pipe outer diam. (2910-1)
Prerequisite	The Diameter option is selected in Pipe dimensions parameter (→ 54).
Description	Define the outer diameter of the pipe.
User entry	0 to 20 000 mm
Factory setting	100 mm

Pipe wall thickness


Navigation	Expert → Sensor → Meas. point 1 → Wall thickness (2916-1)
Description	Enter the pipe wall thickness.
User entry	Positive floating point number
Factory setting	3 mm

Liner thickness


Navigation	Expert → Sensor → Meas. point 1 → Liner thickness (2935-1)
Description	Define the thickness of liner.
User entry	0 to 100 mm
Factory setting	0 mm

Signal filter



Navigation	Expert → Sensor → Meas. point 1 → Signal filter (3011-1)
Description	Switch the signal filter on or off. The signal filter is an adaptive filter that is applied to the raw flow signal.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On

Cable length



Navigation	Expert → Sensor → Meas. point 1 → Cable length (2939-1)
Description	Enter length of sensor cables.
User entry	0 to 200 000 mm
Factory setting	As per order

Intermediate pipe length



Navigation	Expert → Sensor → Meas. point 1 → Interm. pipe l. (2945-1)
Prerequisite	The 1 measuring point - 2 signal paths option is selected in Measuring point configuration parameter (→ 53).
Description	Enter the length of the intermediate pipe between the two bends.
User entry	Positive floating-point number
Factory setting	0 mm

Result sensor type / sensor distance

Navigation	Expert → Sensor → Meas. point 1 → Sens. type/dist. (3066-1)
Description	Shows the sensor type and sensor distance calculated for installation.
User interface	e.g. I-100-A / 500 mm
Factory setting	-

Result path length / arc length

Navigation	🔍📄 Expert → Sensor → Meas. point 1 → Path/arc length (3067-1)
Description	Shows the path length calculated and (if applicable) the calculated arc length.
User interface	e.g. 1085 mm / 257.56 mm
Factory setting	-

"Mounting deviations signal path 1 to n" submenu

Navigation 🔍📄 Expert → Sensor → Meas. point 1 → Deviat. path 1 to n

▶ **Mounting deviations signal path 1 to n**

Sensor distance deviation (5822-1 to n)	→ 📄 57
Arc length deviation (5876-1 to n)	→ 📄 58
Signal path length deviation (5821-1 to n)	→ 📄 58

Sensor distance deviation



Navigation	🔍📄 Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Sens. dist. dev. (5822-1 to n)
Description	Enter the deviation between the nominal sensor distance and the welded position.
User entry	Signed floating-point number
Factory setting	0 mm
Additional information	<p><i>Description</i></p> <p>If the welded position is greater than the nominal sensor distance, enter a positive deviation (e.g. 5 mm (0.20 in)). If the welded position is smaller than the nominal sensor distance, enter a negative deviation (e.g. -5 mm (-0.20 in)).</p>

Arc length deviation

Navigation	Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Arc length dev. (5876-1 to n)
Description	Enter the radial deviation between given radial distance and the real mounting position of the sensor.
User entry	Signed floating-point number
Factory setting	0 mm
Additional information	<p><i>Description</i></p> <p>If the actual radial distance is greater than the nominal value, enter a positive deviation (e.g. 5 mm (0.20 in)). If the actual radial distance is smaller than the nominal value, enter a negative deviation (e.g. -5 mm (-0.20 in)).</p>

Signal path length deviation

Navigation	Expert → Sensor → Meas. point 1 → Deviat. path 1 to n → Path length dev. (5821-1 to n)
Description	Enter the deviation between the nominal signal path length and the welded position.
User entry	Signed floating-point number
Factory setting	0 mm
Additional information	<p><i>Description</i></p> <p>If the actual signal path length is greater than the nominal value, enter a positive deviation (e.g. 5 mm (0.20 in)). If the actual signal path length is smaller than the nominal value, enter a negative deviation (e.g. -5 mm (-0.20 in)).</p>

3.2.4 "Installation status" submenu

Navigation Expert → Sensor → Install. status

► Installation status	
Installation status (2958)	→ 59
Signal strength (2914)	→ 59
Signal to noise ratio (2917)	→ 60

Sound velocity (2915)	→ ⓘ 60
Sound velocity deviation (2986)	→ ⓘ 60

Installation status

Navigation

🏠📄 Expert → Sensor → Install. status → Install. status (2958)

Description

Displays the device status after installation according to the displayed measured values.

- **Good** option: No further optimization required
Signal strength > 40 dB, SNR > 35, sound velocity deviation (measured to expected) < 2%
- **Acceptable** option: Measuring performance ok, optimize if possible. You should always aim for the status **Good** option.
Signal strength > 25 dB, SNR > 35, sound velocity deviation (measured to expected) < 3%
- **Bad** option: Optimization is required. Poor and unstable measuring performance.



Check the following points to optimize the sensor installation:

- Number of traverses, change if necessary (e.g. from 2 traverses to 1 traverse)
- Sensor distance
- Alignment of sensors
- Sufficient coupling medium available (coupling pad or coupling gel)
- Check the measuring point parameters in the configuration

User interface

- Good
- Acceptable
- Bad

Factory setting

Good

Signal strength

Navigation

🏠📄 Expert → Sensor → Install. status → Signal strength (2914)

Description

Displays the current signal strength.

User interface



Signed floating-point number

Additional information



Description

A drop in the signal strength over time can be an indicator of process changes, such as the development of deposits in the measuring pipe at the measuring point. , e.g. buildup of deposits in the measuring pipe at the measuring point. This can only be quantified by performing a direct process comparison with different deposit layer thicknesses and associated signal strengths.



Signal to noise ratio

Navigation	  Expert → Sensor → Install. status → SNR (2917)
Description	Displays the current signal to noise ratio.
User interface	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality.</p>

Sound velocity



Navigation	  Expert → Sensor → Install. status → Sound velocity (2915)
Description	<p>Displays the sound velocity that is currently measured.</p> <p>The difference between the configured sound velocity and the measured sound velocity should not be > 2%.</p>
User interface	Signed floating-point number

Sound velocity deviation

Navigation	  Expert → Sensor → Install. status → SoundVelocDeviat (2986)
Description	Shows the deviation of the installation sound velocity from the measured sound velocity.
User interface	Signed floating-point number
Factory setting	0 %





3.2.5 "Process parameters" submenu

Navigation   Expert → Sensor → Process param.



▶ Process parameters	
Flow override (1839)	→  61
Flow damping (1802)	→  61

Sound velocity damping (1888)	→ 62
Density damping (1889)	→ 62
Temperature damping (1886)	→ 62
▶ Low flow cut off	→ 63

Flow override

Navigation	  Expert → Sensor → Process param. → Flow override (1839)
Description	Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Effect</i></p> <p> This setting affects all the functions and outputs of the measuring device.</p> <p><i>Description</i></p> <p>Flow override is active</p> <ul style="list-style-type: none"> ▪ The 453 Flow override diagnostic message is output. ▪ Output values <ul style="list-style-type: none"> ▪ Output: value at zero flow ▪ Temperature: continues to be output ▪ Sound velocity: continues to be output ▪ Totalizer 1...3: stop being totalized <p> The Flow override option can also be activated in the Status input submenu: Assign status input parameter.</p>

Flow damping


Navigation	  Expert → Sensor → Process param. → Flow damping (1802)
Description	Use this function to enter a time constant for flow damping (PT1 element). Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.
User entry	0 to 999.9 s
Factory setting	1 s

Additional information*Description*

 The damping is performed by a PT1 element ²⁾.




User entry

- Value = 0: no damping
- Value > 0: damping is increased



 Damping is switched off if **0** is entered (factory setting).

Effect

 The damping affects the following variables of the device:

- Outputs →  74
- Low flow cut off →  63
- Totalizers →  121

Sound velocity damping**Navigation**

  Expert → Sensor → Process param. → Sound vel. damp. (1888)

Description

Use this function to enter the time constant for sound velocity damping. Reduction of the variability of the measured sound velocity or sound velocity measured value (in relation to interference). For this purpose, the depth of the sound velocity filter is adjusted: when the filter setting increases, the reaction time of the device also increases.



User entry

0 to 999.9 s

Factory setting

1 s

Density damping**Navigation**

  Expert → Sensor → Process param. → Density damping (1889)

Description

Use this function to enter the time constant for density damping.



User entry

0 to 999.9 s

Factory setting

0 s

Temperature damping**Navigation**

  Expert → Sensor → Process param. → Temp. damping (1886)

Description

Use this function to enter the time constant for temperature damping.




2) Proportional behavior with first-order lag

User entry	0 to 999.9 s
Factory setting	10 s



"Low flow cut off" submenu

Navigation   Expert → Sensor → Process param. → Low flow cut off





▶ **Low flow cut off**

Assign process variable (1837)	→  63
On value low flow cutoff (1805)	→  63
Off value low flow cutoff (1804)	→  64

Assign process variable

Navigation	  Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description	Use this function to select the process variable for low flow cutoff detection.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Flow velocity
Factory setting	Flow velocity

On value low flow cutoff

Navigation	  Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite	A process variable is selected in the Assign process variable parameter (→  63).
Description	Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  64.
User entry	Positive floating-point number
Factory setting	0.3 m/s

Additional information*Dependency*

The unit depends on the process variable selected in the **Assign process variable** parameter (→ 63).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 63).

Description


Use this function to enter a switch-off value for low flow cut off. The switch-off value is entered as a positive hysteresis from the switch-on value → 63.

User entry

0 to 100.0 %

Factory setting

50 %

Additional information*Example*

A0012887








- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.6 "External compensation" submenu*Navigation*

Expert → Sensor → External comp.




▶ External compensation

Temperature compensation (3025)	→ 65
External value (3058)	→ 66
Fixed value (2925)	→ 65

Density source (3048)	→  66
External value (3060)	→  66
Fixed density (3171)	→  66
Linear expansion coefficient (3153)	→  67
Square expansion coefficient (3172)	→  67
Fixed reference density (3178)	→  67
Reference temperature (3147)	→  68




Temperature compensation





Navigation	  Expert → Sensor → External comp. → Temp. compensat. (3025)
Prerequisite	The Calculated value option is selected in the Density source parameter (→  66).
Description	Select temperature mode for temperature compensation.
Selection	<ul style="list-style-type: none"> ■ Fixed value ■ External value
Factory setting	Fixed value

Fixed value






Navigation	  Expert → Sensor → External comp. → Fixed value (2925)
Prerequisite	The Fixed value option is selected in Temperature compensation parameter (→  65).
Description	Enter a fixed value for the process temperature.
User entry	-50 to 550 °C
Factory setting	20 °C

External value




Navigation	  Expert → Sensor → External comp. → External value (3058)
Description	Shows the process temperature read from the external device.
User entry	-273.15 to 99 999 °C
Factory setting	-

Density source







Navigation	  Expert → Sensor → External comp. → Density source (3048)
Description	Select the density source for the mass calculation.
Selection	<ul style="list-style-type: none"> ■ Fixed value ■ External density ■ Calculated value
Factory setting	Fixed value


External value




Navigation	  Expert → Sensor → External comp. → External value (3060)
Prerequisite	The External density option is selected in the Density source parameter (→  66).
Description	Shows the density read from the external device.
User entry	Positive floating-point number
Factory setting	0 kg/m ³


Fixed density






Navigation	  Expert → Sensor → External comp. → Fixed density (3171)
Prerequisite	The Fixed density option is selected in the Density source parameter (→  66).
Description	Enter fixed value for medium density.
User entry	0.01 to 15 000 kg/m ³
Factory setting	1 000 kg/m ³




Linear expansion coefficient


Navigation	  Expert → Sensor → External comp. → Linear exp coeff (3153)
Prerequisite	The Calculated value option is selected in the Density source parameter (→  66).
Description	Use this function to enter a linear, medium-specific expansion coefficient for calculating the density.
User entry	$1.0 \cdot 10^{-6}$ to $2.0 \cdot 10^{-3}$
Factory setting	$2.06 \cdot 10^{-4}$

Square expansion coefficient



Navigation	  Expert → Sensor → External comp. → Square exp coeff (3172)
Prerequisite	The Calculated value option is selected in the Density source parameter (→  66).
Description	For media with a non-linear expansion pattern: use this function to enter a quadratic, medium-specific expansion coefficient for calculating the density.
User entry	$1.0 \cdot 10^{-6}$ to $2.0 \cdot 10^{-3}$
Factory setting	$2.06 \cdot 10^{-4}$

Fixed reference density


Navigation	  Expert → Sensor → External comp. → Fix ref.density (3178)
Prerequisite	The Calculated value option is selected in the Density source parameter (→  66).
Description	Use this function to enter a fixed value for the reference density.
User entry	0.01 to 15 000 kg/m ³
Factory setting	1 000 kg/m ³
Additional information	<i>Reference density calculation</i>




$$\rho = \rho_N \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0044558

- ρ : currently used density for mass flow calculation
- ρ_N : reference density
- t : currently read-in or fixed temperature according to the setting in the **Temperature compensation** parameter (→  65)



- t_N : reference temperature at which the reference density applies (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the medium, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the medium, unit = [1/K²]

Reference temperature



Navigation	  Expert → Sensor → External comp. → Ref. temperature (3147)
Prerequisite	The Calculated value option is selected in the Density source parameter (→  66).
Description	Enter the reference temperature at which the reference density applies.
User entry	-200 to 450 °C
Factory setting	20 °C

3.2.7 "Sensor adjustment" submenu



Navigation   Expert → Sensor → Sensor adjustm.











▶ Sensor adjustment	
Installation direction (1809)	→  68
▶ Process variable adjustment	→  69

Installation direction

Navigation	  Expert → Sensor → Sensor adjustm. → Install. direct. (1809)
Description	Use this function to change the sign of the medium flow direction.
Selection	<ul style="list-style-type: none"> ▪ Forward flow ▪ Reverse flow
Factory setting	Forward flow




"Process variable adjustment" submenu

Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust

► Process variable adjustment	
Volume flow offset (1831)	→  69
Volume flow factor (1832)	→  70
Mass flow offset (1841)	→  70
Mass flow factor (1846)	→  70
Sound velocity offset (1848)	→  71
Sound velocity factor (1849)	→  71
Density offset (1866)	→  71
Density factor (1867)	→  72
Temperature offset (1870)	→  72
Temperature factor (1871)	→  72

Volume flow offset



Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)
Description	Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m ³ /s. The value is entered in the selected volume flow unit.
User entry	Signed floating-point number
Factory setting	0 m ³ /h
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>

Volume flow factor 


Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

 Corrected value = (factor × value) + offset

Mass flow offset 


Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/h. The value is entered in the selected mass flow unit.

User entry Signed floating-point number

Factory setting 0 kg/h

Additional information *Description*

 Corrected value = (factor × value) + offset

Mass flow factor 


Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)













Description Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

 Corrected value = (factor × value) + offset

Sound velocity offset 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. offset (1848)
Description	Use this function to enter the zero point shift for the sound velocity trim. The sound velocity unit on which the shift is based is m/s. The value is entered in the selected velocity unit.
User entry	Signed floating-point number
Factory setting	0 m/s
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>
Sound velocity factor 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → S. veloc. factor (1849)
Description	Use this function to enter a quantity factor (without time) for the sound velocity. This multiplication factor is applied over the sound velocity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>
Density offset 	
Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Density offset (1866)
Description	Use this function to enter the zero point shift for the energy flow trim. The energy flow unit on which the shift is based is 1 W.
User entry	Signed floating-point number
Factory setting	0 kg/m ³
Additional information	<p><i>Description</i></p> <p> Corrected value = (factor × value) + offset</p>

Density factor 


Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Density factor (1867)

Description Use this function to enter a quantity factor (without time) for the energy flow. This multiplication factor is applied over the energy flow range.



User entry Positive floating-point number



Factory setting 1

Additional information *Description*

 Corrected value = (factor × value) + offset

Temperature offset 

Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1870)


Prerequisite The **Calculated value** option is selected in the **Density source** parameter (→  66) and the **External value** option is selected in the **Temperature compensation** parameter (→  65).


Description Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is K.



User entry Signed floating-point number



Factory setting 0

Additional information *Description*

 Corrected value = (factor × value) + offset

Temperature factor 

Navigation   Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1871)

Prerequisite The **Calculated value** option is selected in the **Density source** parameter (→  66) and the **External value** option is selected in the **Temperature compensation** parameter (→  65).

Description Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in K.

User entry Positive floating-point number


Factory setting 1

Additional information*Description*

Corrected value = (factor × value) + offset

3.2.8 "Calibration" submenu*Navigation*

Expert → Sensor → Calibration

**Calibration factor****Navigation**

Expert → Sensor → Calibration → Cal. factor (2920)

Description

Displays the current calibration factor for the sensor.

User interface

Signed floating-point number

Factory setting

1

Zero point**Navigation**

Expert → Sensor → Calibration → Zero point (2921)

Description

Displays the current zero point correction value for the sensor.

User interface

Signed floating-point number

Factory setting

0

Nominal diameter**Navigation**

Expert → Sensor → Calibration → Nominal diameter (2807)

Description



Displays the nominal diameter of the sensor.

User interface -----

Factory setting -----












3.3 "Output" submenu

Navigation   Expert → Output

▶ Output	
▶ Current output 1	→  74
▶ Pulse/frequency/switch output 1 to n	→  87

3.3.1 "Current output 1" submenu

Navigation   Expert → Output → Curr.output 1

▶ Current output 1	
Process variable current output (0359-1)	→  75
Current range output (0353-1)	→  75
Fixed current (0365-1)	→  76
Lower range value output (0367-1)	→  77
Upper range value output (0372-1)	→  78
Measuring mode current output (0351-1)	→  79
Damping current output (0363-1)	→  83
Failure behavior current output (0364-1)	→  84
Failure current (0352-1)	→  85
Output current (0361-1)	→  85
Measured current (0366-1)	→  86

Process variable current output


Navigation Expert → Output → Curr.output 1 → Proc.var. outp (0359-1)

Description Use this function to select a process variable for the current output.

Selection

- Off *
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity
- Temperature
- Density
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature

Factory setting Volume flow

Current range output


Navigation Expert → Output → Curr.output 1 → Curr.range out (0353-1)

Description Select current range for process value output and upper/lower level for alarm signal.

Selection




- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)
- Fixed value

Factory setting Depends on country:


- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

* Visibility depends on order options or device settings

Additional information*Description*


- i** In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→  84).
- If the measured value is outside the measuring range, the **△S441 Current output 1** diagnostic message is displayed.
- The measuring range is specified via the **0/4 mA value** parameter (→  77) and **20 mA value** parameter (→  78).

"Fixed current" option

The current value is set via the **Fixed current** parameter (→  76).

Example

Shows the relationship between the current range for the output of the process value and the two signal on alarm levels:



A0034351

- 1 Current range for process value
- 2 Lower level for signal on alarm
- 3 Upper level for signal on alarm

Selection


Selection	1	2	3
4...20 mA NE (3.8...20.5 mA)	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US (3.9...20.8 mA)	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA (4...20.5 mA)	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA (0...20.5 mA)	0 to 20.5 mA	0 mA	> 21.95 mA

- i** If the flow exceeds or falls below the upper or lower signal on alarm level, the **△S441 Current output 1** diagnostic message is displayed.

Fixed current**Navigation**

  Expert → Output → Curr.output 1 → Fixed current (0365-1)

Prerequisite

The **Fixed current** option is selected in the **Current span** parameter (→  75).

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Lower range value output
**Navigation**

Expert → Output → Curr.output 1 → Low.range outp (0367-1)

Prerequisite

In **Current span** parameter (→ 75), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a value for the 0/4 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country:

- m³/h
- ft³/h

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 75). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 78).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 75).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 75)
- Measuring mode (→ 79)
- Failure mode (→ 84)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measurement mode with **Forward flow** option

- **0/4 mA value** parameter (→ 77) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 78) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




A0013757

Q Flow
 I Current
 1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **0/4 mA value** parameter (→ [☰ 77](#)) and **20 mA value** parameter (→ [☰ 78](#)). If the effective flow exceeds or falls below this operational range, the **△S441 Current output 1** diagnostic message is output.

Configuration example B

Measurement mode with **Forward/Reverse flow** option



- I* Current
Q Flow
 1 Value assigned to 0/4 mA current
 2 Forward flow
 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ [☰ 77](#)) and **20 mA value** parameter (→ [☰ 78](#)) must have the same algebraic sign. The value for the **20 mA value** parameter (→ [☰ 78](#)) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ [☰ 78](#)) (e.g. flow).

Configuration example C

Measurement mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → [☰ 79](#).

Upper range value output



Navigation

Expert → Output → Curr.output 1 → Upp.range outp (0372-1)

Prerequisite

In **Current span** parameter (→ [☰ 75](#)), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a value for the 20 mA current..

User entry

Signed floating-point number


Factory setting

Depends on country and nominal diameter

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ [☰ 75](#)). In addition, the value can be greater




than or smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→  77).

Dependency



 The unit depends on the process variable selected in the **Assign current output** parameter (→  75).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse flow** option is selected in the **Measuring mode** parameter (→  79), different algebraic signs cannot be entered for the values for the **0/4 mA value** parameter (→  77) and **Upper range value output** parameter (→  78). The **△S441 Current output 1** diagnostic message is displayed.

Configuration examples


 Observe the configuration examples for the **0/4 mA value** parameter (→  77).

Measuring mode current output

Navigation

  Expert → Output → Curr.output 1 → Output mode (0351-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→  75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the measuring mode for the current output.

Selection



- Forward flow
- Forward/Reverse flow *
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Description

 The process variable that is assigned to the current output via the **Assign current output** parameter (→  75) is displayed below the parameter.

"Forward flow" option

The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.


* Visibility depends on order options or device settings

The flow components outside the scaled measuring range are taken into account for signal output as follows:

Both values are defined such that they are not equal to zero flow e.g.:

- 0/4 mA current value = $-5 \text{ m}^3/\text{h}$
- 20 mA current value = $10 \text{ m}^3/\text{h}$

"Forward/Reverse flow" option



A0013758

- I Current
- Q Flow
- 1 Value assigned to 0/4 mA current
- 2 Forward flow
- 3 Reverse flow

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 77) and **20 mA value** parameter (→ 78) must have the same sign.
- The value for the **20 mA value** parameter (→ 78) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 78) (e.g. forward flow).

"Reverse flow compensation" option

The **Reverse flow compensation** option is primarily used to compensate for intermittent reverse flow that can arise with displacement pumps due to wear or high-viscosity medium. The reverse flow is recorded in a buffer memory and offset against the next forward flow.


In the event of prolonged and undesired reverse flow, flow values can accumulate in the buffer memory. Due to the configuration of the current output, these values are not factored in, however, i.e. there is no compensation for the reverse flow.

If this option is set, the measuring device does not smoothen the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1

Defined measuring range: lower range value and upper range value with the **same** sign




A0028084

3 Measuring range

- I* Current
- Q* Flow
- 1 Lower range value (Value assigned to 0/4 mA current)
- 2 Upper range value (end of measuring range output)

With the following flow response:




A0028091

4 Flow response

- Q* Flow
- t* Time

With **Forward flow** option

The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output.




A0028092

- I* Current
- t* Time

With **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.




A0028093

- I* Current
- t* Time

With **Reverse flow compensation** option

Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.




A0028094

- I* Current
- t* Time
- S* Flow components saved
- A* Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different** signs




A0028095

5 Measuring range

- I* Current
- Q* Flow
- 1 Lower range value (Value assigned to 0/4 mA current)
- 2 Upper range value (end of measuring range output)

With flow a (–) outside, b (– –) inside the measuring range




A0028098

- Q* Flow
- t* Time
- 1 Lower range value (Value assigned to 0/4 mA current)
- 2 Upper range value (end of measuring range output)

With **Forward flow** option

- a (–): The flow components outside the scaled measuring range cannot be taken into account for signal output.
- b (– –): The current output signal is proportional to the process variable assigned.



A0028100


I Current
t Time

With **Forward/Reverse flow** option

This option cannot be selected here since the values for the **0/4 mA value** parameter (→ ☰ 77) and **20 mA value** parameter (→ ☰ 78) have different signs.

With **Reverse flow compensation** option

Flow components outside the measuring span are buffered, balanced and output after a maximum delay of 60 s.



A0028101

I Current
t Time
S Flow components saved
A Balancing of saved flow components

Damping current output



Navigation

☰☰ Expert → Output → Curr.output 1 → Damp.curr.outp (0363-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ ☰ 75) and one of the following options is selected in the **Current span** parameter (→ ☰ 75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s


Factory setting

1.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element³⁾) for current output damping:



- If a low time constant is entered, the current output reacts quickly to fluctuating measured variables.
- If a high time constant is entered, the current output reacts more slowly.

 Damping is switched off if **0** is entered (factory setting).

Failure behavior current output**Navigation**

 Expert → Output → Curr.output 1 → Failure behav. (0364-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (→  75) and one of the following options is selected in the **Current span** parameter (→  75):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4...20.5 mA)
- 0...20 mA (0...20.5 mA)

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Fixed value

Factory setting

Max.

3) proportional transmission behavior with first order delay

Additional information*Description*

This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.



The signal on alarm level is defined via the **Current span** parameter (→ 75).

"Max." option

The current output adopts the value of the upper level for signal on alarm.



The signal on alarm level is defined via the **Current span** parameter (→ 75).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.



The measured value is defined via the **Failure current** parameter (→ 85).

Failure current

**Navigation**

Expert → Output → Curr.output 1 → Fail. current (0352-1)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (→ 84).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output current 1

Navigation

Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)



Description

Displays the current value currently calculated for the current output.

User interface



0 to 22.5 mA

Measured current

Navigation	  Expert → Output → Curr.output 1 → Measur. curr. (0366-1)
Description	Displays the actual measured value of the output current.
User interface	0 to 30 mA



Trim



Navigation	  Expert → Output → Curr.output 1 → Trim (0362-1)
Description	Select adjustment mode for trim.
Selection	<ul style="list-style-type: none"> ■ Off ■ 4 mA ■ 20 mA ■ Calculate ■ Reset
Factory setting	Off



20 mA trim value





Navigation	  Expert → Output → Curr.output 1 → 20 mA trim value (0356-1)
Description	Enter upper measured value for trim (around 20 mA).
User entry	18 to 22 mA
Factory setting	20 mA

4 mA trim value

















Navigation	  Expert → Output → Curr.output 1 → 4 mA trim value (0357-1)
Description	Enter lower measured value for the trim (around 4 mA).
User entry	3 to 5 mA
Factory setting	4 mA






Status

Navigation	  Expert → Output → Curr.output 1 → Status (0360-1)
Description	Shows the status of the last output current (OutValue).
User interface	0 to 255
Factory setting	0

3.3.2 "Pulse/frequency/switch output 1 to n" submenu



Navigation   Expert → Output → PFS output 1 to n

► Pulse/frequency/switch output 1 to n	
Operating mode (0469-1 to n)	→  88
Assign pulse output (0460-1 to n)	→  90
Pulse scaling (0455-1 to n)	→  90
Pulse width (0452-1 to n)	→  91
Measuring mode (0457-1 to n)	→  91
Failure mode (0480-1 to n)	→  92
Pulse output (0456-1 to n)	→  93
Assign frequency output (0478-1 to n)	→  93
Minimum frequency value (0453-1 to n)	→  94
Maximum frequency value (0454-1 to n)	→  94
Measuring value at minimum frequency (0476-1 to n)	→  94
Measuring value at maximum frequency (0475-1 to n)	→  95
Measuring mode (0479-1 to n)	→  95
Damping output (0477-1 to n)	→  95

Response time (0491-1 to n)	→  96
Failure mode (0451-1 to n)	→  96
Failure frequency (0474-1 to n)	→  97
Output frequency (0471-1 to n)	→  97
Switch output function (0481-1 to n)	→  97
Assign diagnostic behavior (0482-1 to n)	→  98
Assign limit (0483-1 to n)	→  99
Switch-on value (0466-1 to n)	→  101
Switch-off value (0464-1 to n)	→  101
Assign flow direction check (0484-1 to n)	→  102
Assign status (0485-1 to n)	→  102
Switch-on delay (0467-1 to n)	→  102
Switch-off delay (0465-1 to n)	→  103
Failure mode (0486-1 to n)	→  103
Switch state (0461-1 to n)	→  103
Invert output signal (0470-1 to n)	→  104

Operating mode

Navigation

  Expert → Output → PFS output 1 to n → Operating mode (0469-1 to n)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse^{*}
- Frequency^{*}
- Switch^{*}

Factory setting

Pulse

* Visibility depends on order options or device settings


Additional information*"Pulse" option*

Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass or volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s



A0026883

6 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, mass flow, temperature, sound velocity, flow velocity, acceptance rate, turbulence, signal strength or signal to noise ratio.

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz



A0026886


7 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




A0026884

8 No alarm, high level

Example

Alarm response in case of alarm



A0026885

9 Alarm, low level

Assign pulse output



Navigation

Expert → Output → PFS output 1 to n → Assign pulse (0460-1 to n)

Prerequisite

The **Pulse** option is selected in **Operating mode** parameter (→ 88).

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow

Factory setting

Off

Pulse scaling



Navigation

Expert → Output → PFS output 1 to n → Pulse scaling (0455-1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 88) and a process variable is selected in the **Assign pulse output** parameter (→ 90).

Description

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating point number

Factory setting

Depends on country and nominal diameter

Additional information

User entry

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width



Navigation

Expert → Output → PFS output 1 to n → Pulse width (0452-1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 88) and a process variable is selected in the **Assign pulse output** parameter (→ 90).

Description

Use this function to enter the duration of the output pulse.

User entry

0.05 to 2 000 ms


Factory setting

100 ms

Additional information

Description

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the **443 Pulse output 1 to n** diagnostic message.



A0026882

B Pulse width entered

P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation





Expert → Output → PFS output 1 to n → Measuring mode (0457-1 to n)

Description






Use this function to select the measuring mode for the pulse output.


Selection	<ul style="list-style-type: none"> ■ Forward flow ■ Forward/Reverse flow ■ Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Forward flow Positive flow is output, negative flow is not output. ■ Forward/Reverse flow Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow. ■ Reverse flow Negative flow is output, positive flow is not output. ■ Reverse flow compensation The flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

Failure mode

Navigation	  Expert → Output → PFS output 1 to n → Failure mode (0480–1 to n)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  88) and a process variable is selected in the Assign pulse output parameter (→  90).
Description	Use this function to select the failure mode of the pulse output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Actual value ■ No pulses
Factory setting	No pulses
Additional information	<p><i>Description</i></p> <p>The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> ■ Actual value In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored. ■ No pulses In the event of a device alarm, the pulse output is "switched off". <p>NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The Actual value option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.</p>


Pulse output


Navigation	  Expert → Output → PFS output 1 to n → Pulse output (0456-1 to n)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  88) parameter.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open collector output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ■ The Value per pulse parameter (→  90) and Pulse width parameter (→  91) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0028726




0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→  104) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→  92)) can be configured.

Assign frequency output







Navigation	  Expert → Output → PFS output 1 to n → Assign freq. (0478-1 to n)
Prerequisite	The Frequency option is selected in Operating mode parameter (→  88).
Description	Use this function to select the process variable for the frequency output.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Flow velocity ■ Sound velocity ■ Temperature ■ Density ■ Electronics temperature

- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *

Factory setting Off

Minimum frequency value

Navigation   Expert → Output → PFS output 1 to n → Min. freq. value (0453-1 to n)



Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→  88) and a process variable is selected in the **Assign frequency output** parameter (→  93).



Description Use this function to enter the minimum frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 0.0 Hz

Maximum frequency value

Navigation   Expert → Output → PFS output 1 to n → Max. freq. value (0454-1 to n)



Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→  88) and a process variable is selected in the **Assign frequency output** parameter (→  93).



Description Use this function to enter the end value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 10 000.0 Hz

Measuring value at minimum frequency

Navigation   Expert → Output → PFS output 1 to n → Val. at min.freq (0476-1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→  88) and a process variable is selected in the **Assign frequency output** parameter (→  93).

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

* Visibility depends on order options or device settings

Factory setting Depends on country and nominal diameter

Additional information *Dependency*



The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 93).

Measuring value at maximum frequency



Navigation Expert → Output → PFS output 1 to n → Val. at max.freq (0475-1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 88) and a process variable is selected in the **Assign frequency output** parameter (→ 93).

Description Use this function to enter the measured value for the end value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency



The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 93).

Measuring mode



Navigation Expert → Output → PFS output 1 to n → Measuring mode (0479-1 to n)

Description Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting Forward flow

Damping output



Navigation Expert → Output → PFS output 1 to n → Damping out. (0477-1 to n)

Description Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry 0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element ⁴⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time

Navigation Expert → Output → PFS output 1 to n → Response time (0491-1 to n)

Description Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches 63 % of 100 % of the measured value change when the measured value changes.

User interface Positive floating-point number

Additional information *Description*



The response time is made up of the time specified for the following dampings:

- Damping of pulse/frequency/switch output → 83
and
- Depending on the measured variable assigned to the output.
Flow damping

Failure mode



Navigation Expert → Output → PFS output 1 to n → Failure mode (0451-1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 88) and a process variable is selected in the **Assign frequency output** parameter (→ 93).


Description Use this function to select the failure mode of the frequency output in the event of a device alarm.

Selection






- Actual value
- Defined value
- 0 Hz

Factory setting 0 Hz




4) proportional transmission behavior with first order delay

Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored. ■ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→  97) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm. ■ 0 Hz In the event of a device alarm, the frequency output is "switched off". <p>NOTICE! A device alarm indicates a serious fault with the measuring device. The measurement quality may possibly be influenced and may no longer be guaranteed. The Actual value option is only recommended if it is ensured that all possible alarm conditions do not influence the measurement quality.</p>
-------------------------------	--




Failure frequency

Navigation	  Expert → Output → PFS output 1 to n → Failure freq. (0474-1 to n)
Prerequisite	In the Operating mode parameter (→  88), the Frequency option is selected, in the Assign frequency output parameter (→  93) a process variable is selected, and in the Failure mode parameter (→  96), the Defined value option is selected.
Description	Enter frequency output value in alarm condition.
User entry	0.0 to 12 500.0 Hz
Factory setting	0.0 Hz

Output frequency





Navigation	  Expert → Output → PFS output 1 to n → Output freq. (0471-1 to n)
Prerequisite	In the Operating mode parameter (→  88), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz


Switch output function





Navigation	  Expert → Output → PFS output 1 to n → Switch out funct (0481-1 to n)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  88).

Description	Use this function to select a function for the switch output.
Selection	<ul style="list-style-type: none"> ■ Off ■ On ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status
Factory setting	Off
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Off The switch output is permanently switched off (open, non-conductive). ■ On The switch output is permanently switched on (closed, conductive). ■ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ■ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ■ Status Displays the device status low flow cut off is selected.


Assign diagnostic behavior

Navigation	  Expert → Output → PFS output 1 to n → Assign diag. beh (0482-1 to n)
Prerequisite	<ul style="list-style-type: none"> ■ In the Operating mode parameter (→  88), the Switch option is selected. ■ In the Switch output function parameter (→  97), the Diagnostic behavior option is selected.
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none"> ■ Alarm ■ Alarm or warning ■ Warning
Factory setting	Alarm

Additional information	<p><i>Description</i></p> <p> If no diagnostic event is pending, the switch output is closed and conductive.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Alarm The switch output signals only diagnostic events in the alarm category. ▪ Alarm or warning The switch output signals diagnostic events in the alarm and warning category. ▪ Warning The switch output signals only diagnostic events in the warning category.
-------------------------------	---

Assign limit	
Navigation	 Expert → Output → PFS output 1 to n → Assign limit (0483-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in Operating mode parameter (→  88). ▪ The Limit option is selected in Switch output function parameter (→  97).
Description	Use this function to select a process variable for the limit function.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Flow velocity ▪ Sound velocity ▪ Temperature ▪ Density ▪ Electronics temperature[*] ▪ Signal strength[*] ▪ Signal to noise ratio[*] ▪ Acceptance rate[*] ▪ Turbulence[*] ▪ Totalizer 1 ▪ Totalizer 2 ▪ Totalizer 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>Behavior of status output when Switch-on value > Switch-off value:</p> <ul style="list-style-type: none"> ▪ Process variable > Switch-on value: transistor is conductive ▪ Process variable < Switch-off value: transistor is non-conductive

* Visibility depends on order options or device settings




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



A0026893


- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output





Switch-on value


Navigation	Expert → Output → PFS output 1 to n → Switch-on value (0466-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→ 88). ▪ The Limit option is selected in the Switch output function parameter (→ 97).
Description	Use this function to enter the measured value for the switch-on point.
User entry	Signed floating-point number
Factory setting	Depends on country
Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p> <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign limit parameter (→ 99).</p>





Switch-off value


Navigation	Expert → Output → PFS output 1 to n → Switch-off value (0464-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→ 88). ▪ The Limit option is selected in the Switch output function parameter (→ 97).
Description	Use this function to enter the measured value for the switch-off point.
User entry	Signed floating-point number
Factory setting	Depends on country
Additional information	<p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).</p> <p> When using a hysteresis: Switch-on value > Switch-off value.</p> <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign limit parameter (→ 99).</p>





Assign flow direction check 

Navigation	  Expert → Output → PFS output 1 to n → Assign dir.check (0484-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→  88). ▪ The Flow direction check option is selected in the Switch output function parameter (→  97).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	
Factory setting	Volume flow

Assign status 

Navigation	  Expert → Output → PFS output 1 to n → Assign status (0485-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in Operating mode parameter (→  88). ▪ The Status option is selected in Switch output function parameter (→  97).
Description	Select the device function whose status you want to display.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Low flow cut off
Factory setting	Low flow cut off
Additional information	<p><i>Options</i></p> <p>When the switch-on point for the selected device function is reached, the output is switched on (closed, conductive). Otherwise, the output is non-conductive.</p>

Switch-on delay 

Navigation	  Expert → Output → PFS output 1 to n → Switch-on delay (0467-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→  88). ▪ The Limit option is selected in the Switch output function parameter (→  97).
Description	Use this function to enter a delay time for switching on the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Switch-off delay



Navigation	Expert → Output → PFS output 1 to n → Switch-off delay (0465-1 to n)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→ 88). ▪ The Limit option is selected in the Switch output function parameter (→ 97).
Description	Use this function to enter a delay time for switching off the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Failure mode



Navigation	Expert → Output → PFS output 1 to n → Failure mode (0486-1 to n)
Description	Use this function to select a failsafe mode for the switch output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual status ▪ Open ▪ Closed
Factory setting	Open
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Actual status In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The Actual status option behaves in the same way as the current input value. ▪ Open In the event of a device alarm, the switch output's transistor is set to non-conductive. ▪ Closed In the event of a device alarm, the switch output's transistor is set to conductive.

Switch state

Navigation	Expert → Output → PFS output 1 to n → Switch state (0461-1 to n)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 88).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed

Additional information *User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal**Navigation**

Expert → Output → PFS output 1 to n → Invert outp.sig. (0470-1 to n)

Description

Use this function to select whether to invert the output signal.

Selection

- No
- Yes


Factory setting

No

Additional information


Selection

No option (passive - negative)



A0026693

Yes option (passive - positive)



A0026692

3.4 "Communication" submenu

Navigation




Expert → Communication

▶ **Communication**

- ▶ Modbus configuration → 105
- ▶ Modbus information → 109
- ▶ Modbus data map → 110


▶ Web server	→ 111
▶ WLAN settings	→ 114

3.4.1 "Modbus configuration" submenu


Navigation  Expert → Communication → Modbus config.

▶ Modbus configuration	
Bus address	→ 105
Baudrate	→ 105
Data transfer mode	→ 106
Parity	→ 106
Byte order	→ 107
Telegram delay	→ 108
Failure mode	→ 108
Fieldbus writing access	→ 109

Bus address

Navigation	 Expert → Communication → Modbus config. → Bus address (7112)
Description	For entering the device address.
User entry	1 to 247
Factory setting	247



Baudrate

Navigation	 Expert → Communication → Modbus config. → Baudrate (7111)
Description	Use this function to select a transmission rate.

Selection	<ul style="list-style-type: none"> ■ 1200 BAUD ■ 2400 BAUD ■ 4800 BAUD ■ 9600 BAUD ■ 19200 BAUD ■ 38400 BAUD ■ 57600 BAUD ■ 115200 BAUD ■ 230400 BAUD
------------------	--

Factory setting 19200 BAUD

Data transfer mode

Navigation   Expert → Communication → Modbus config. → Data trans. mode (7115)

Description Use this function to select the data transmission mode.

Selection

- ASCII
- RTU

Factory setting RTU

Additional information *Options*

- ASCII
Transmission of data in the form of readable ASCII characters. Error protection via LRC.
- RTU
Transmission of data in binary form. Error protection via CRC16.

Parity

Navigation   Expert → Communication → Modbus config. → Parity (7122)

Description Use this function to select the parity bit.

Selection

- Odd
- Even
- None / 1 stop bit
- None / 2 stop bits

Factory setting Even



Additional information *Options*

Picklist **ASCII** option:

- 0 = **Even** option
- 1 = **Odd** option

- Picklist **RTU** option:
- 0 = **Even** option
 - 1 = **Odd** option
 - 2 = **None / 1 stop bit** option
 - 3 = **None / 2 stop bits** option

Byte order 

Navigation   Expert → Communication → Modbus config. → Byte order (7113)


Description Use this function to select the sequence in which the bytes are transmitted. The transmission sequence must be coordinated with the Modbus master.

- Selection**
- 0-1-2-3
 - 3-2-1-0
 - 1-0-3-2
 - 2-3-0-1

Factory setting 1-0-3-2


Additional information *Description*


The byte sequence is not standardized by the Modbus protocol. However, if the host system and the measuring device do not use the same byte sequence, correct data exchange is not possible.

Changing the byte sequence in the host system often requires a extensive knowledge and significant programming efforts. Endress+Hauser introduced the **Byte order** parameter (→  107) for this reason.

This makes it possible to use the standard settings of the host system and change the byte sequence on the measuring device by trial and error. If correct data exchange cannot be achieved by changing the byte sequence, the settings for the byte sequence of the host system must be adapted accordingly.

Byte transmission sequence

Byte addressing, i.e. the transmission sequence of the bytes, is not specified in the Modbus specification. For this reason, it is important to coordinate or match the addressing method between the master and slave during commissioning. This can be configured in the measuring device using the **Byte order** parameter (→  107).

The bytes are transmitted depending on the selection in the **Byte order** parameter (→  107):

FLOAT				
	Sequence			
Options	1.	2.	3.	4.
1 - 0 - 3 - 2 *	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)
0 - 1 - 2 - 3	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)
2 - 3 - 0 - 1	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)

3 - 2 - 1 - 0	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMMM)	Byte 1 (MMMMMMMMM)	Byte 0 (MMMMMMMMM)
* = factory setting, S = sign, E = exponent, M = mantissa				

INTEGER		
	Sequence	
Options	1.	2.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 1 (MSB)	Byte 0 (LSB)
0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 0 (LSB)	Byte 1 (MSB)
* = factory setting, MSB = most significant byte, LSB = least significant byte		

STRING					
Presentation taking the example of a device parameter with a data length of 18 bytes.					
	Sequence				
Options	1.	2.	...	17.	18.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 17 (MSB)	Byte 16	...	Byte 1	Byte 0 (LSB)
0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 16	Byte 17 (MSB)	...	Byte 0 (LSB)	Byte 1
* = factory setting, MSB = most significant byte, LSB = least significant byte					

Telegram delay

Navigation

  Expert → Communication → Modbus config. → Telegram delay (7146)

Description

Use this function to enter a delay time after which the measuring device replies to the request telegram of the Modbus master. This allows communication to be adapted to slow Modbus RS485 masters.

User entry

0 to 100 ms

Factory setting

6 ms

Failure mode

Navigation

  Expert → Communication → Modbus config. → Failure mode (7116)

Description

Use this function to select the measured value output in the event of a diagnostic message via Modbus communication.

Selection

- NaN value
- Last valid value


Factory setting

NaN value

Additional information

Options

- NaN value
The device outputs the NaN value ⁵⁾.
- Last valid value
The device outputs the last valid measured value before the fault occurred.

 This effect of this parameter depends on the option selected in the **Assign diagnostic behavior** parameter.

Fieldbus writing access

Navigation

 Expert → Communication → Modbus config. → Fieldb.writ.acc. (7156)

Description

Use this function to restrict access to the measuring device via fieldbus (Modbus protocol).

Selection

- Read + write
- Read only


Factory setting

Read + write

Additional information

Description

If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.


 This does not affect cyclic measured value transmission to the higher-order system, which is always guaranteed.

Selection



- Read + write
The parameters are read and write parameters.
- Read only
- The parameters are read only parameters.

3.4.2 "Modbus information" submenu

Navigation


 Expert → Communication → Modbus info

▶ **Modbus information**


Device ID (7153)	→  110
Device revision (7154)	→  110

5) Not a Number


Device ID


Navigation	 Expert → Communication → Modbus info → Device ID (7153)
Description	Displays the device ID for identifying the measuring device.
User interface	4-digit hexadecimal number

Device revision

Navigation	 Expert → Communication → Modbus info → Device revision (7154)
Description	Displays the device revision.
User interface	4-digit hexadecimal number


3.4.3 "Modbus data map" submenu

Navigation  Expert → Communication → Modbus data map












Scan list register 0 to 15




Navigation	 Expert → Communication → Modbus data map → Scan list reg.0 to 15 (7114)
Description	Use this function to enter the scan list register. By entering the register address (1-based), up to 16 device parameters can be grouped by assigning them to the scan list registers 0 to 15. The data of the device parameters assigned here are read out via the register addresses 5051 to 5081.
User entry	1 to 65 535
Factory setting	1

3.4.4 "Web server" submenu

Navigation  Expert → Communication → Web server

► Web server	
Web server language (7221)	→  111
MAC address (7214)	→  112
DHCP client (7212)	→  112
IP address (7209)	→  112
Subnet mask (7211)	→  113
Default gateway (7210)	→  113
Web server functionality (7222)	→  113
Login page (7273)	→  114

Web server language

Navigation  Expert → Communication → Web server → Webserv.language (7221)


Description Use this function to select the language configured for the Web server.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- čeština (Czech)











Factory setting English

MAC address

Navigation	 Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁶⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format 00:07:05:10:01:5F


DHCP client



Navigation	 Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On
Additional information	<p><i>Effect</i></p> <p>If the DHCP client functionality of the web server is selected, the IP address (→  112), Subnet mask (→  113) and Default gateway (→  113) are set automatically.</p> <ul style="list-style-type: none">  Identification is via the MAC address of the measuring device. ■ The IP address (→  112) in the IP address parameter (→  112) is ignored as long as the DHCP client parameter (→  112) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→  112) in the parameter of the same name is only used if the DHCP client parameter (→  112) is inactive.

IP address



Navigation	 Expert → Communication → Web server → IP address (7209)
Description	Display or enter the IP address of the Web server integrated in the measuring device.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

6) Media Access Control

Subnet mask



- Navigation** Expert → Communication → Web server → Subnet mask (7211)
- Description** Display or enter the subnet mask.
- User entry** 4 octet: 0 to 255 (in the particular octet)
- Factory setting** 255.255.255.0

Default gateway



- Navigation** Expert → Communication → Web server → Default gateway (7210)
- Description** Display or enter the Default gateway (→ 113).
- User entry** 4 octet: 0 to 255 (in the particular octet)
- Factory setting** 0.0.0.0

Web server functionality




- Navigation** Expert → Communication → Web server → Webserver funct. (7222)
- Description** Use this function to switch the Web server on and off.
- Selection**
 - Off
 - On
- Factory setting** On
- Additional information**

Description

Once disabled, the Web server functionality can only be enabled again via the FieldCare operating tool or the DeviceCare operating tool.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ▪ The Web server is completely disabled. ▪ Port 80 is locked.
On	<ul style="list-style-type: none"> ▪ The complete Web server functionality is available. ▪ JavaScript is used. ▪ The password is transferred in an encrypted state. ▪ Any change to the password is also transferred in an encrypted state.

Login page**Navigation** Expert → Communication → Web server → Login page (7273)**Description**

Use this function to select the format of the login page.

Selection
















- Without header
- With header

Factory setting

With header

3.4.5 "WLAN settings" wizard*Navigation*

Expert → Communication → WLAN settings

▶ WLAN settings	
WLAN (2702)	→  115
WLAN mode (2717)	→  115
SSID name (2714)	→  115
Network security (2705)	→  116
Security identification (2718)	→  116
User name (2715)	→  117
WLAN password (2716)	→  117
WLAN IP address (2711)	→  117
WLAN MAC address (2703)	→  117
WLAN subnet mask (2709)	→  118
WLAN MAC address (2703)	→  117
WLAN passphrase (2706)	→  118
WLAN MAC address (2703)	→  117
Assign SSID name (2708)	→  118
SSID name (2707)	→  119

2.4 GHz WLAN channel (2704)	→ ⓘ 119
Select antenna (2713)	→ ⓘ 119
Connection state (2722)	→ ⓘ 119
Received signal strength (2721)	→ ⓘ 120
WLAN IP address (2711)	→ ⓘ 117
Gateway IP address (2719)	→ ⓘ 120
IP address domain name server (2720)	→ ⓘ 120

WLAN



Navigation	Expert → Communication → WLAN settings → WLAN (2702)
Description	Use this function to enable and disable the WLAN connection.
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Enable

WLAN mode



Navigation	Expert → Communication → WLAN settings → WLAN mode (2717)
Description	Use this function to select the WLAN mode.
Selection	WLAN access point
Factory setting	WLAN access point

SSID name





Navigation	Expert → Communication → WLAN settings → SSID name (2714)
Prerequisite	The client is activated.
Description	Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation   Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection



- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.
- EAP-PEAP with MSCHAPv2
Access the WLAN connection with a password-based authentication protocol.
- EAP-PEAP MSCHAPv2 no server authentic.
Access the WLAN connection with a password-based protocol without server authentication.
- EAP-TLS
Access the WLAN connection with a certificate-based, two-way authentication of the client and network.

Security identification

Navigation   Expert → Communication → WLAN settings → Sec. identific. (2718)

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

User interface

- Trusted issuer certificate
- Device certificate
- Device private key

* Visibility depends on order options or device settings

User name



Navigation	Expert → Communication → WLAN settings → User name (2715)
Description	Use this function to enter the username of the WLAN network.
User entry	-
Factory setting	-

WLAN password



Navigation	Expert → Communication → WLAN settings → WLAN password (2716)
Description	Use this function to enter the WLAN password for the WLAN network.
User entry	-
Factory setting	-

WLAN IP address



Navigation	Expert → Communication → WLAN settings → WLAN IP address (2711)
Description	Use this function to enter the IP address of the measuring device's WLAN connection.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

WLAN MAC address



Navigation	Expert → Communication → WLAN settings → WLAN MAC address (2703)
Description	Displays the MAC ⁷⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format

7) Media Access Control

00:07:05:10:01:5F




WLAN subnet mask



Navigation	  Expert → Communication → WLAN settings → WLAN subnet mask (2709)
Description	Use this function to enter the subnet mask.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	255.255.255.0



WLAN passphrase








Navigation	  Expert → Communication → WLAN settings → WLAN passphrase (2706)
Prerequisite	The WPA2-PSK option is selected in the Security type parameter (→  116).
Description	Use this function to enter the network key.
User entry	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)
Factory setting	Serial number of the measuring device (e.g. L100A802000)





Assign SSID name







Navigation	  Expert → Communication → WLAN settings → Assign SSID name (2708)
Description	Use this function to select which name is used for the SSID ⁸⁾ .
Selection	<ul style="list-style-type: none"> ■ Device tag ■ User-defined
Factory setting	User-defined
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Device tag The device tag name is used as the SSID. ■ User-defined A user-defined name is used as the SSID.

8) Service Set Identifier

SSID name		
Navigation	  Expert → Communication → WLAN settings → SSID name (2707)	
Prerequisite	<ul style="list-style-type: none"> ▪ The User-defined option is selected in the Assign SSID name parameter (→  118). ▪ The WLAN access point option is selected in the WLAN mode parameter (→  115). 	
Description	Use this function to enter a user-defined SSID name.	
User entry	Max. 32-digit character string comprising numbers, letters and special characters	
Factory setting	EH_device designation_last 7 digits of the serial number (e.g. EH_Prosonic_Flow_400_A802000)	

2.4 GHz WLAN channel		
Navigation	  Expert → Communication → WLAN settings → WLAN channel (2704)	
Description	Use this function to enter the 2.4 GHz WLAN channel.	
User entry	1 to 11	
Factory setting	6	
Additional information	<p><i>Description</i></p> <p> It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.</p> <ul style="list-style-type: none"> ▪ If just one measuring device is in use, it is recommended to keep the factory setting. 	


Select antenna		
Navigation	  Expert → Communication → WLAN settings → Select antenna (2713)	
Description	Use this function to select whether the external or internal antenna is used for reception.	
Selection	<ul style="list-style-type: none"> ▪ External antenna ▪ Internal antenna 	
Factory setting	Internal antenna	

Connection state		
Navigation	 Expert → Communication → WLAN settings → Connection state (2722)	
Description	The connection status is displayed.	

User interface ▪ Connected
 ▪ Not connected

Factory setting Not connected

Received signal strength

Navigation  Expert → Communication → WLAN settings → Rec.sig.strength (2721)

Description Displays the signal strength received.

User interface ▪ Low
 ▪ Medium
 ▪ High

Factory setting High

Gateway IP address


Navigation  Expert → Communication → WLAN settings → Gateway IP addr. (2719)

Description Use this function to enter the IP address of the gateway.

User interface Character string comprising numbers, letters and special characters

Factory setting 192.168.1.212

IP address domain name server

Navigation  Expert → Communication → WLAN settings → IP address DNS (2720)

Description Use this function to enter the IP address of the domain name server.

User interface Character string comprising numbers, letters and special characters


Factory setting 192.168.1.212

3.5 "Application" submenu


Navigation  Expert → Application

▶ Application


Reset all totalizers (2806)

→  121

▶ Totalizer 1 to n

→  121

Reset all totalizers

Navigation  Expert → Application → Reset all tot. (2806)

Description Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the previously aggregated flow values.

Selection


- Cancel
- Reset + totalize

Factory setting Cancel

Additional information Selection


Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the previously aggregated flow values.

3.5.1 "Totalizer 1 to n" submenu


Navigation  Expert → Application → Totalizer 1 to n

▶ Totalizer 1 to n


Assign process variable 1 to n
(0914-1 to n)

→  122


Process variable unit 1 to n
(0915-1 to n)



→  122

Totalizer 1 to n operation mode
(0908-1 to n)





→  123

Totalizer 1 to n control (0912-1 to n)





→  124

Preset value 1 to n (0913-1 to n)	→  124
Totalizer 1 to n failure behavior (0901-1 to n)	→  125

Assign process variable 1 to n

Navigation	  Expert → Application → Totalizer 1 to n → AssignVariab. 1 to n (0914-1 to n)
Description	Use this function to select a process variable for the Totalizer 1 to n.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p> If the option selected is changed, the device resets the totalizer to 0.</p> <p><i>Options</i></p> <p>If the Off option is selected, only the Assign process variable parameter (→  122) is still displayed in the Totalizer 1 to n submenu. All other parameters in the submenu are hidden.</p>

Process variable unit 1 to n

Navigation	  Expert → Application → Totalizer 1 to n → VariableUnit 1 to n (0915-1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (→  122) of the Totalizer 1 to n submenu.
Description	Use this function to select the process variable unit for the Totalizer 1 to n (→  121).
Selection	<ul style="list-style-type: none"> ▪ g[*] ▪ kg[*] ▪ t[*] ▪ oz[*] ▪ lb[*] ▪ STon[*] ▪ cm^{3*} ▪ dm^{3*} ▪ m^{3*} ▪ ml[*] ▪ l[*]

* Visibility depends on order options or device settings

- hl *
- Ml Mega *
- af *
- ft³ *
- Mft³ *
- Mft³ *
- fl oz (us) *
- gal (us) *
- kgal (us) *
- Mgal (us) *
- bbl (us;liq.) *
- bbl (us;beer) *
- bbl (us;oil) *
- bbl (us;tank) *
- gal (imp) *
- Mgal (imp) *
- bbl (imp;beer) *
- bbl (imp;oil) *
- None *

Factory setting

Depends on country:

- m³
- ft³

Additional information

Description



The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 45).

Options

The selection is dependent on the process variable selected in the **Assign process variable** parameter (→ 122).

Totalizer 1 to n operation mode
**Navigation**

Expert → Application → Totalizer 1 to n → Operat. mode 1 to n (0908-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 122) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net
- Forward
- Reverse


Factory setting


Net flow total

* Visibility depends on order options or device settings

Additional information*Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Totalizer 1 to n control**Navigation**
 Expert → Application → Totalizer 1 to n → Tot. 1 to n control (0912-1 to n)
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→  122) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize
- Hold


Factory setting


Totalize

Additional information*Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold ¹⁾	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize ¹⁾	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.



1) Visible depending on the order options or device settings

Preset value 1 to n**Navigation**
 Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913-1 to n)
Prerequisite





A process variable is selected in the **Assign process variable** parameter (→  122) of the **Totalizer 1 to n** submenu.

Description


Use this function to enter a start value for the Totalizer 1 to n.


User entry	Signed floating-point number
Factory setting	Depends on country: <ul style="list-style-type: none"> ■ 0 m³ ■ 0 ft³
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is defined in the Unit totalizer parameter (→  122) for the totalizer.</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Totalizer 1 to n failure behavior


Navigation	  Expert → Application → Totalizer 1 to n → FailureBehav. 1 to n (0901-1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (→  122) of the Totalizer 1 to n submenu.
Description	Use this function to select how a totalizer behaves in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Hold ■ Continue ■ Last valid value + continue
Factory setting	Stop
Additional information	<p><i>Description</i></p> <p> This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Stop The totalizer is stopped in the event of a device alarm. ■ Actual value The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored. ■ Last valid value The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.5.2 "Inventory counter" submenu

Navigation  Expert → Application → Inventory count.



Unit


Navigation  Expert → Application → Inventory count. → Unit (0974)

Description Displays the unit of the inventory counter.

User interface


<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
▪ cm ³	▪ ft ³	▪ gal (imp)
▪ dm ³	▪ af	▪ Mgal (imp)
▪ m ³	▪ fl oz (us)	▪ bbl (imp;beer)
▪ ml	▪ gal (us)	▪ bbl (imp;oil)
▪ l	▪ kgal (us)	
▪ hl	▪ Mgal (us)	
▪ Ml Mega	▪ bbl (us;oil)	
	▪ bbl (us;liq.)	
	▪ bbl (us;beer)	
	▪ bbl (us;tank)	


























Additional information *Description*

 The parameter cannot be configured or reset.

3.6 "Diagnostics" submenu









Navigation  Expert → Diagnostics










► Diagnostic list	→  131
Diagnostics 1 (0692)	→  132
Diagnostics 2 (0693)	→  132
Diagnostics 3 (0694)	→  133
Diagnostics 4 (0695)	→  134
Diagnostics 5 (0696)	→  135
► Device information	→  136
Device tag (0011)	→  136
Serial number (0009)	→  137
Firmware version (0010)	→  137
Device name (0013)	→  137
Order code (0008)	→  138
Extended order code 1 (0023)	→  138
Extended order code 2 (0021)	→  138
Extended order code 3 (0022)	→  139
ENP version (0012)	→  139
► Main electronic module	→  139
Firmware version (0072)	→  140
Build no. software (0079)	→  140
Bootloader revision (0073)	→  140
► Sensor electronic module (ISEM)	→  140
Firmware version (0072)	→  141
Build no. software (0079)	→  141
Bootloader revision (0073)	→  141
► Display module	→  141

Firmware version (0072)	→ 142
Build no. software (0079)	→ 142
Bootloader revision (0073)	→ 142
► Data logging	→ 142
Assign channel 1 (0851)	→ 143
Assign channel 2 (0852)	→ 144
Assign channel 3 (0853)	→ 144
Assign channel 4 (0854)	→ 144
Logging interval (0856)	→ 145
Clear logging data (0855)	→ 145
Data logging (0860)	→ 146
Logging delay (0859)	→ 146
Data logging control (0857)	→ 146
Data logging status (0858)	→ 147
Entire logging duration (0861)	→ 147
► Heartbeat Technology	→ 150
► Heartbeat base settings	→ 150
Plant operator (2754)	→ 150
Location (2755)	→ 151
► Performing verification	→ 151
Year (2846)	→ 152
Month (2845)	→ 152
Day (2842)	→ 152
Hour (2843)	→ 153
AM/PM (2813)	→ 153



Minute (2844)	→ 153
Verification mode (12105)	→ 154
External device information (12101)	→ 154
Start verification (12127)	→ 154
Progress (2808)	→ 155
Measured values (12102)	→ 155
Output values (12103)	→ 156
Status (12153)	→ 156
Verification result (12149)	→ 156
► Verification results	→ 157
Date/time (manually entered) (12142)	→ 157
Verification ID (12141)	→ 157
Operating time (12126)	→ 158
Verification result (12149)	→ 158
Sensor (12152)	→ 158
Sensor electronic module (ISEM) (12151)	→ 159
I/O module (12145)	→ 159
System status (12109)	→ 159
► Simulation	→ 160
Assign simulation process variable (1810)	→ 161
Process variable value (1811)	→ 161
Current output 1 simulation (0354-1)	→ 162
Current output value (0355)	→ 163
Frequency output 1 to n simulation (0472-1 to n)	→ 163




Frequency output 1 to n value (0473-1 to n)	→  164
Pulse output simulation 1 to n (0458-1 to n)	→  164
Pulse value 1 to n (0459-1 to n)	→  165
Switch output simulation 1 to n (0462-1 to n)	→  165
Switch state 1 to n (0463-1 to n)	→  166
Device alarm simulation (0654)	→  166
Diagnostic event category (0738)	→  167
Diagnostic event simulation (0737)	→  167

Actual diagnostics



Navigation	  Expert → Diagnostics → Actual diagnos. (0691)
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Additional pending diagnostic messages can be viewed in the Diagnostic list submenu (→  131).</p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Example</i></p> <p>For the display format: F271 Main electronic failure</p>

Previous diagnostics



Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.

Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Example</i></p> <p>For the display format:  F271 Main electronic failure</p>

Operating time from restart


Navigation	  Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)



Operating time

Navigation	  Expert → Diagnostics → Operating time (0652)
Description	Displays the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Indication</i></p> <p>Maximum number of days: 9 999 (corresponds to approx. 27 years and 5 months)</p>







3.6.1 "Diagnostic list" submenu

Navigation   Expert → Diagnostics → Diagnostic list






Diagnostics 4 (0695)	→  134
Diagnostics 5 (0696)	→  135



Diagnostics 1





Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Displays the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  S442 Frequency output ▪  F276 I/O module failure

Timestamp 1




Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 1 parameter (→  132).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Diagnostics 2






Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.

User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  S442 Frequency output ▪  F276 I/O module failure




Timestamp 2

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the second-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 2 parameter (→  132).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>







Diagnostics 3

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Displays the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  S442 Frequency output ▪  F276 I/O module failure


Timestamp 3












Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 3 parameter (→  133).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  S442 Frequency output ▪  F276 I/O module failure










Timestamp 4

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 4 parameter (→  134).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>
<hr/>	
Diagnostics 5	
<hr/>	
Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)
Description	Displays the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> ▪  S442 Frequency output ▪  F276 I/O module failure
<hr/>	
Timestamp 5	
<hr/>	
Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fifth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 5 parameter (→  135).</p> <p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>


3.6.2 "Device information" submenu

Navigation  Expert → Diagnostics → Device info

► Device information	
Device tag (0011)	→  136
Serial number (0009)	→  137
Firmware version (0010)	→  137
Device name (0013)	→  137
Order code (0008)	→  138
Extended order code 1 (0023)	→  138
Extended order code 2 (0021)	→  138
Extended order code 3 (0022)	→  139
ENP version (0012)	→  139

Device tag

Navigation

 Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. It is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Prosonic Flow

Additional information

User interface






1 Position of the header text on the display



A0029422

The number of characters displayed depends on the characters used.



Serial number

Navigation	 Expert → Diagnostics → Device info → Serial number (0009)
Description	Displays the serial number of the measuring device.  The number can be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number <ul style="list-style-type: none"> ▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer





Firmware version

Navigation	 Expert → Diagnostics → Device info → Firmware version (0010)
Description	Displays the device firmware version installed.
User interface	Character string in the format xx.yy.zz
Additional information	<i>Display</i>  The Firmware version is also located: <ul style="list-style-type: none"> ▪ On the title page of the Operating instructions ▪ On the transmitter nameplate




Device name

Navigation	 Expert → Diagnostics → Device info → Device name (0013)
Description	Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter.
User interface	Max. 32 characters such as letters or numbers.
Factory setting	Pros. Flow400 MB




Order code 

Navigation	  Expert → Diagnostics → Device info → Order code (0008)
Description	Displays the device order code
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).
Additional information	<p><i>Description</i></p> <p> The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.</p> <p>The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.</p> <p> Uses of the order code</p> <ul style="list-style-type: none"> ▪ To order an identical spare device. ▪ To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1 

Navigation	  Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)
Description	<p>Displays the first part of the extended order code</p> <p>On account of length restrictions, the extended order code is split into a maximum of 3 parameters.</p>
User interface	Character string
Additional information	<p><i>Description</i></p> <p>The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.</p> <p> The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.</p>

Extended order code 2 

Navigation	  Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)
Description	Displays the second part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→  138)

Extended order code 3



Navigation	Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)
Description	Displays the third part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→ 138)

Configuration counter


Navigation	Expert → Diagnostics → Device info → Config. counter (0233)
Description	Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.
User interface	0 to 65 535



ENP version

Navigation	Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
User interface	Character string
Factory setting	2.02.00
Additional information	<i>Description</i> This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.



3.6.3 "Main electronic module + I/O module 1" submenu

Navigation Expert → Diagnostics → Mainboard module





Build no. software (0079)	→  140
Bootloader revision (0073)	→  140



Firmware version

Navigation	  Expert → Diagnostics → Main elec. mod. → Firmware version (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer



Build no. software




Navigation	  Expert → Diagnostics → Main elec. mod. → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader revision



Navigation	  Expert → Diagnostics → Main elec. mod. → Bootloader rev. (0073)
Description	Use this function to display the bootloader revision of the software.
User interface	Positive integer

3.6.4 "Sensor electronic module (ISEM)" submenu



Navigation   Expert → Diagnostics → Sens. electronic

▶ Sensor electronic module (ISEM)	
Firmware version (0072)	→  141
Build no. software (0079)	→  141
Bootloader revision (0073)	→  141



Firmware version

Navigation	  Expert → Diagnostics → Sens. electronic → Firmware version (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer



Build no. software




Navigation	  Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader revision



Navigation	  Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)
Description	Use this function to display the bootloader revision of the software.
User interface	Positive integer

3.6.5 "Display module" submenu



Navigation   Expert → Diagnostics → Display module

▶ Display module	
Firmware version (0072)	→  142
Build no. software (0079)	→  142
Bootloader revision (0073)	→  142



Firmware version

Navigation	  Expert → Diagnostics → Display module → Firmware version (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

Build no. software







Navigation	  Expert → Diagnostics → Display module → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer






Bootloader revision

Navigation	  Expert → Diagnostics → Display module → Bootloader rev. (0073)
Description	Use this function to display the bootloader revision of the software.
User interface	Positive integer

3.6.6 "Data logging" submenu

Navigation   Expert → Diagnostics → Data logging

► Data logging	
Assign channel 1 (0851)	→  143
Assign channel 2 (0852)	→  144
Assign channel 3 (0853)	→  144
Assign channel 4 (0854)	→  144
Logging interval (0856)	→  145
Clear logging data (0855)	→  145

Data logging (0860)	→  146
Logging delay (0859)	→  146
Data logging control (0857)	→  146
Data logging status (0858)	→  147
Entire logging duration (0861)	→  147


Assign channel 1

Navigation

  Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  36).

Description

Use this function to assign a process variable to the data logging channel.

Selection

- Off
- Volume flow
- Mass flow
- Flow velocity
- Sound velocity
- Temperature
- Density
- Signal strength *
- Signal to noise ratio *
- Acceptance rate *
- Turbulence *
- Electronics temperature
- Current output 1

Factory setting

Off


Additional information

Description







A total of 1000 measured values can be logged. This means:






- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used







Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

* Visibility depends on order options or device settings

Assign channel 2 	
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  36).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→  143)
Factory setting	Off

Assign channel 3 	
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  36).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→  143)
Factory setting	Off

Assign channel 4 	
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  36).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→  143)
Factory setting	Off

Logging interval




Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 36).
Description	Use this function to enter the logging interval T_{\log} for data logging.
User entry	0.1 to 3 600.0 s
Factory setting	1.0 s
Additional information	<p><i>Description</i></p> <p>This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log}:</p> <ul style="list-style-type: none"> ▪ If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$ ▪ If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$ ▪ If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$ ▪ If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$ <p>Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).</p> The log contents are cleared if the length of the logging interval is changed. <p><i>Example</i></p> <p>If 1 logging channel is used:</p> <ul style="list-style-type: none"> ▪ $T_{\log} = 1000 \times 1 \text{ s} = 1\,000 \text{ s} \approx 15 \text{ min}$ ▪ $T_{\log} = 1000 \times 10 \text{ s} = 10\,000 \text{ s} \approx 3 \text{ h}$ ▪ $T_{\log} = 1000 \times 80 \text{ s} = 80\,000 \text{ s} \approx 1 \text{ d}$ ▪ $T_{\log} = 1000 \times 3\,600 \text{ s} = 3\,600\,000 \text{ s} \approx 41 \text{ d}$

Clear logging data






Navigation	Expert → Diagnostics → Data logging → Clear logging (0855)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 36).
Description	Use this function to clear the entire logging data.
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Clear data
Factory setting	Cancel

Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Cancel The data is not cleared. All the data is retained. ■ Clear data The logging data is cleared. The logging process starts from the beginning.
-------------------------------	--




Data logging

Navigation	  Expert → Diagnostics → Data logging → Data logging (0860)
Description	Use this function to select the data logging method.
Selection	<ul style="list-style-type: none"> ■ Overwriting ■ Not overwriting
Factory setting	Overwriting
Additional information	<i>Selection</i> <ul style="list-style-type: none"> ■ Overwriting The device memory applies the FIFO principle. ■ Not overwriting Data logging is canceled if the measured value memory is full (single shot).

Logging delay




Navigation	  Expert → Diagnostics → Data logging → Logging delay (0859)
Prerequisite	In the Data logging parameter (→  146), the Not overwriting option is selected.
Description	Use this function to enter the time delay for measured value logging.
User entry	0 to 999 h
Factory setting	0 h
Additional information	<i>Description</i> <p>Once data logging has been started with the Data logging control parameter (→  146), the device does not save any data for the duration of the delay time entered.</p>

Data logging control




Navigation	  Expert → Diagnostics → Data logging → Data log.control (0857)
Prerequisite	In the Data logging parameter (→  146), the Not overwriting option is selected.

Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none"> ■ None ■ Delete + start ■ Stop
Factory setting	None
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ None Initial measured value logging status. ■ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again. ■ Stop Measured value logging is stopped.

Data logging status

Navigation	  Expert → Diagnostics → Data logging → Data log. status (0858)
Prerequisite	In the Data logging parameter (→  146), the Not overwriting option is selected.
Description	Displays the measured value logging status.
User interface	<ul style="list-style-type: none"> ■ Done ■ Delay active ■ Active ■ Stopped
Factory setting	Done
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Done Measured value logging has been performed and completed successfully. ■ Delay active Measured value logging has been started but the logging interval has not yet elapsed. ■ Active The logging interval has elapsed and measured value logging is active. ■ Stopped Measured value logging is stopped.


Entire logging duration


Navigation	  Expert → Diagnostics → Data logging → Logging duration (0861)
Prerequisite	In the Data logging parameter (→  146), the Not overwriting option is selected.
Description	Displays the total logging duration.

User interface Positive floating-point number


Factory setting 0 s

"Display channel 1" submenu



Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1


Navigation  Expert → Diagnostics → Data logging → Displ.channel 1


Prerequisite The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  36).

Description Displays the measured value trend for the logging channel in the form of a chart.

Additional information *Description*




 10 *Chart of a measured value trend*


A0034352

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2


**Display channel 2****Navigation**

 Expert → Diagnostics → Data logging → Displ.channel 2


Prerequisite

A process variable is specified in the **Assign channel 2** parameter.


Description

See the **Display channel 1** parameter →  148

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3


**Display channel 3****Navigation**

 Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is specified in the **Assign channel 3** parameter.

Description



See the **Display channel 1** parameter →  148

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4







Display channel 4

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 4
Prerequisite	A process variable is specified in the Assign channel 4 parameter.
Description	See the Display channel 1 parameter →  148


3.6.7 "Heartbeat Technology" submenu



 For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring**: Special Documentation for the device →  7

Navigation  Expert → Diagnostics → Heartbeat Techn.

▶ Heartbeat Technology	
▶ Heartbeat base settings	→  150
▶ Performing verification	→  151
▶ Verification results	→  157



"Heartbeat base settings" submenu

Navigation   Expert → Diagnostics → Heartbeat Techn. → Base settings

▶ Heartbeat base settings	
Plant operator (2754)	→  150
Location (2755)	→  151

Plant operator



Navigation	  Expert → Diagnostics → Heartbeat Techn. → Base settings → Plant operator (2754)
Description	Use this function to enter the plant operator.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Location**Navigation**

Expert → Diagnostics → Heartbeat Techn. → Base settings → Location (2755)

Description

Use this function to enter the location.

User entry



Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

"Performing verification" wizard



Navigation Expert → Diagnostics → Heartbeat Techn. → Perform.verific.


► Performing verification	
Year (2846)	→ 152
Month (2845)	→ 152
Day (2842)	→ 152
Hour (2843)	→ 153
AM/PM (2813)	→ 153
Minute (2844)	→ 153
Verification mode (12105)	→ 154
External device information (12101)	→ 154
Start verification (12127)	→ 154
Progress (2808)	→ 155
Measured values (12102)	→ 155
Output values (12103)	→ 156
Status (12153)	→ 156
Verification result (12149)	→ 156



Year 











Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Year (2846)
Prerequisite	 Can be edited if Heartbeat Verification is not active.
Description	Use this function to enter the year of recalibration.
User entry	9 to 99
Factory setting	21

Month 



Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Month (2845)
Prerequisite	 Can be edited if Heartbeat Verification is not active.
Description	Use this function to select the month of recalibration.
Selection	<ul style="list-style-type: none"> ▪ January ▪ February ▪ March ▪ April ▪ May ▪ June ▪ July ▪ August ▪ September ▪ October ▪ November ▪ December
Factory setting	January

Day 




Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Day (2842)
Prerequisite	 Can be edited if Heartbeat Verification is not active.
Description	Use this function to enter the day of the month of recalibration.
User entry	1 to 31 d
Factory setting	1 d

Hour 	
Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Hour (2843)
Prerequisite	 Can be edited if Heartbeat Verification is not active.
Description	Use this function to enter the hour of recalibration.
User entry	0 to 23 h
Factory setting	12 h
AM/PM 	
Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → AM/PM (2813)
Prerequisite	 Can be edited if Heartbeat Verification is not active. The dd.mm.yy hh:mm am/pm option or the mm/dd/yy hh:mm am/pm option is selected in the Date/time format parameter (2812) (→  51).
Description	Use this function to select the time entry in the morning (AM option) or afternoon (PM option) in the case of 12-hour notation.
Selection	<ul style="list-style-type: none"> ▪ AM ▪ PM
Factory setting	AM
Minute 	
Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Minute (2844)
Prerequisite	 Can be edited if Heartbeat Verification is not active.
Description	Use this function to enter the minutes of recalibration.
User entry	0 to 59 min
Factory setting	0 min



Verification mode 

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Verificat. mode (12105)
Prerequisite	Can be edited if the verification status is not active.
Description	Select verification mode. Standard verification: Verification is performed automatically by the device and without manual checking of external measured variables. Extended verification: Similar to internal verification but with the entry of external measured variables (see also "Measured values" parameter).
Selection	<ul style="list-style-type: none"> ■ Standard verification ■ Extended verification
Factory setting	Standard verification

External device information 


Navigation	  Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Ext. device info (12101)
Prerequisite	With the following conditions: <ul style="list-style-type: none"> ■ The Extended verification option is selected in the Verification mode parameter (→  154). ■ Can be edited if Heartbeat Verification is not active.
Description	Record measuring equipment for extended verification.
User entry	Free text entry
Factory setting	–

Start verification 



Navigation	  Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Start verificat. (12127)
Description	Start the verification. To carry out a complete verification, select the selection parameters individually. Once the external measured values have been recorded, verification is started using the Start option.

Selection	<ul style="list-style-type: none"> ■ Cancel ■ Output 1 low value * ■ Output 1 high value * ■ Frequency output 1 * ■ Pulse output 1 * ■ Frequency output 2 * ■ Pulse output 2 * ■ Start ■ Start with testkit *
Factory setting	Cancel

Progress


Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Progress (2808)
Description	The progress of the process is indicated.
User interface	0 to 100 %

Measured values


Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Measured val. (12102)
Prerequisite	One of the following options is selected in the Start verification parameter (→  154): <ul style="list-style-type: none"> ■ Output 1 low value ■ Output 1 high value ■ Output 2 low value ■ Output 2 high value ■ Frequency output 1 ■ Pulse output 1 ■ Frequency output 2 ■ Pulse output 2
Description	Use this function to enter the measured values (actual values) for the external measured variables:. <ul style="list-style-type: none"> ■ Current output: Output current in [mA] ■ Pulse/frequency output: Output frequency in [Hz]
User entry	Signed floating-point number
Factory setting	0

* Visibility depends on order options or device settings



Output values

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Output values (12103)
Description	Displays the simulated output values (target values) for the external measured variables.: Pulse/frequency output: Output frequency in [Hz].
User interface	Signed floating-point number
Factory setting	0



Status









Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Status (12153)
Description	Displays the current status of the verification.
User interface	<ul style="list-style-type: none"> ▪ Done ▪ Busy ▪ Failed ▪ Not done
Factory setting	Done

Verification result



Navigation	 Expert → Diagnostics → Heartbeat Techn. → Perform.verific. → Verific. result (12149)
Description	Displays the overall result of the verification.  Detailed description of the classification of the results:
User interface	<ul style="list-style-type: none"> ▪ Not supported ▪ Passed ▪ Not done ▪ Failed
Factory setting	Not done

"Verification results" submenu



Navigation   Expert → Diagnostics → Heartbeat Techn. → Verific. results

► Verification results	
Date/time (manually entered) (12142)	→  157
Verification ID (12141)	→  157
Operating time (12126)	→  158
Verification result (12149)	→  158
Sensor (12152)	→  158
Sensor electronic module (ISEM) (12151)	→  159
I/O module (12145)	→  159
System status (12109)	→  159


Date/time (manually entered)

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Date/time (12142)
Prerequisite	The verification has been performed.
Description	Date and time.
User interface	dd.mmmm.yyyy; hh:mm
Factory setting	1 January 2010; 12:00



Verification ID

Navigation	  Expert → Diagnostics → Heartbeat Techn. → Verific. results → Verification ID (12141)
Prerequisite	The verification has been performed.
Description	Displays consecutive numbering of the verification results in the measuring device.
User interface	0 to 65 535
Factory setting	0




Operating time

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → Operating time (12126)
Prerequisite	The verification has been performed.
Description	Indicates how long the device has been in operation up to the verification.
User interface	Days (d), hours (h), minutes (m), seconds (s)
Factory setting	–



Verification result

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → Verific. result (12149)
Description	Displays the overall result of the verification.  Detailed description of the classification of the results:
User interface	<ul style="list-style-type: none"> ▪ Not supported ▪ Passed ▪ Not done ▪ Failed
Factory setting	Not done





Sensor

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → Sensor (12152)
Prerequisite	The Failed option was shown in the Overall result parameter (→  156).
Description	Displays the result for the sensor.  Detailed description of the classification of the results:
User interface	<ul style="list-style-type: none"> ▪ Not supported ▪ Passed ▪ Not done ▪ Failed
Factory setting	Not done




Sensor electronic module (ISEM)

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → Sens. electronic (12151)
Prerequisite	In the Overall result parameter (→  156), the Failed option was displayed.
Description	Shows the overall result for the “sensor electronic module” test group.
User interface	<ul style="list-style-type: none"> ▪ Not supported ▪ Passed ▪ Not done ▪ Failed
Factory setting	Not done

I/O module

Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → I/O module (12145)
Prerequisite	The Failed option was shown in the Overall result parameter (→  156).
Description	<p>Displays the result for I/O module monitoring of the I/O module.</p> <ul style="list-style-type: none"> ▪ For pulse output: Accuracy of pulses (for external verification only) ▪ For frequency output: Accuracy of frequency (for external verification only) <p> Heartbeat Verification does not check the digital inputs and outputs and does not issue a result for this.</p> <p> Detailed description of the classification of the results:</p>
User interface	<ul style="list-style-type: none"> ▪ Not supported ▪ Passed ▪ Not done ▪ Failed
Factory setting	Not done

System status














Navigation	 Expert → Diagnostics → Heartbeat Techn. → Verific. results → System status (12109)
Prerequisite	The Failed option was shown in the Overall result parameter (→  156).
Description	<p>Displays the system condition. Tests the measuring device for active errors.</p> <p> Detailed description of the classification of the results:</p>

User interface	<ul style="list-style-type: none"> ■ Not supported ■ Passed ■ Not done ■ Failed
-----------------------	---

Factory setting	Not done
------------------------	----------

3.6.8 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation

▶ Simulation	
Assign simulation process variable (1810)	→  161
Process variable value (1811)	→  161
Current output 1 simulation (0354-1)	→  162
Current output value (0355)	→  163
Frequency output 1 to n simulation (0472-1 to n)	→  163
Frequency output 1 to n value (0473-1 to n)	→  164
Pulse output simulation 1 to n (0458-1 to n)	→  164
Pulse value 1 to n (0459-1 to n)	→  165
Switch output simulation 1 to n (0462-1 to n)	→  165
Switch state 1 to n (0463-1 to n)	→  166
Device alarm simulation (0654)	→  166
Diagnostic event category (0738)	→  167
Diagnostic event simulation (0737)	→  167

Assign simulation process variable


Navigation	Expert → Diagnostics → Simulation → Assign proc.var. (1810)
Description	Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Flow velocity ■ Sound velocity ■ Temperature ■ Density
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The simulation value of the process variable selected is defined in the Process variable value parameter (→ 161).</p>

Process variable value


Navigation	Expert → Diagnostics → Simulation → Proc. var. value (1811)
Prerequisite	A process variable is selected in the Assign simulation process variable parameter (→ 161).
Description	Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.
User entry	Depends on the process variable selected
Factory setting	0
Additional information	<p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 45).</p>

Simulation status input


Navigation	Expert → Diagnostics → Simulation → Sim. status inp. (1355)
Prerequisite	For the following order code: "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"


Description Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting Off

Additional information *Description*


 The desired simulation value is defined in the **Input signal level** parameter (→  162).

Selection

- Off
Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Simulation for the status input is active.

Value status input

Navigation  Expert → Diagnostics → Simulation → Val. status inp. (1356)

Prerequisite In the **Simulation status input** parameter (→  161), the **On** option is selected.

Description Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units.

Selection

- High
- Low

Current output 1 simulation



Navigation  Expert → Diagnostics → Simulation → Curr.outp 1 sim. (0354-1)

Description Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.




Selection

- Off
- On



Factory setting Off







Additional information	<p><i>Description</i></p> <p> The desired simulation value is specified in the Value current output 1 parameter (→  163).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Current simulation is active.
-------------------------------	---









Value current output 1


Navigation	<p> Expert → Diagnostics → Simulation → Curr.outp val. (0355)</p> <p> Expert → Diagnostics → Simulation → Value curr.out 1 (0355-1)</p>
Prerequisite	In the Current output 1 simulation parameter, the On option is selected.
Description	Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.
User entry	0 to 22.5 mA
Additional information	<p><i>User entry</i></p> <p> The value must be entered with a period (.) as the separator.</p>

Frequency output 1 to n simulation


Navigation	 Expert → Diagnostics → Simulation → Freq.outp 1 to n sim. (0472-1 to n)
Prerequisite	In the Operating mode parameter (→  88), the Frequency option is selected.
Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off

Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Frequency value 1 to n parameter.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Off Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ On Frequency simulation is active.
<hr/>	
Frequency output 1 to n value 	
Navigation	 Expert → Diagnostics → Simulation → Freq.outp 1 to n val. (0473-1 to n)
Prerequisite	In the Frequency simulation 1 to n parameter, the On option is selected.
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.
User entry	0.0 to 12 500.0 Hz
<hr/>	
Pulse output simulation 1 to n 	
Navigation	 Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n (0458-1 to n)
Prerequisite	In the Operating mode parameter (→  88), the Pulse option is selected.
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ■ Off ■ Fixed value ■ Down-counting value
Factory setting	Off


Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Pulse value 1 to n parameter.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Fixed value Pulses are continuously output with the pulse width specified in the Pulse width parameter (→  91). ▪ Down-counting value The pulses specified in the Pulse value parameter (→  165) are output.
<hr/>	
Pulse value 1 to n 	
Navigation	 Expert → Diagnostics → Simulation → Pulse value 1 to n (0459-1 to n)
Prerequisite	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.
Description	Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.
User entry	0 to 65 535
<hr/>	
Switch output simulation 1 to n 	
Navigation	 Expert → Diagnostics → Simulation → Switch sim. 1 to n (0462-1 to n)
Prerequisite	In the Operating mode parameter (→  88), the Switch option is selected.
Description	Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off

Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Switch state 1 to n parameter.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Switch simulation is active.
-------------------------------	--

Switch state 1 to n

Navigation	 Expert → Diagnostics → Simulation → Switch state 1 to n (0463-1 to n)
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Closed Switch simulation is active.

Device alarm simulation

Navigation	 Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)
Description	Use this function to switch the device alarm on and off.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p>The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.</p>

Diagnostic event category
**Navigation**

Expert → Diagnostics → Simulation → Event category (0738)

Description

Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (→ 167).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting

Process

Diagnostic event simulation
**Navigation**

Expert → Diagnostics → Simulation → Diagnostic event (0737)

Description

Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting

Off

Additional information

Description



For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→ 167).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Velocity	m/s
Temperature	°C

4.1.2 Output current span

Output	Current range
Current output 1	4 to 20 mA NAMUR

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft ³
Volume flow	ft ³ /min
Velocity	ft/s
Temperature	°F

4.2.2 Output current span

Output	Current range
Current output 1	4 to 20 mA US

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Density	kg/l	Kilogram/liter
Velocity	m/s	Meter/time unit
Kinematic viscosity	m ² /s	Square meter/second
Temperature	°C, K	Celsius, Kelvin
Length	mm	Millimeters
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Volume	ft ³	Cubic foot
Volume flow	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Density	lb/ft ³	Pound/cubic foot
Velocity	ft/s	Foot/time unit
Kinematic viscosity	cSt	Centistokes
Temperature	°F, °R	Fahrenheit, Rankine
Length	in	Inch
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

6 Modbus RS485 register information

6.1 Notes

6.1.1 Structure of the register information

The individual parts of a parameter description are described in the following section:

Navigation: navigation path to the parameter					
Parameter	Register	Data type	Access type	User interface/ Selection/User entry	→
Name of parameter	Indicated in decimal numerical format	<ul style="list-style-type: none"> ▪ Float length = 4 byte ▪ Integer length = 2 byte ▪ String length, depending on parameter 	Possible type of access to parameter: <ul style="list-style-type: none"> ▪ Read access via function codes 03, 04 or 23 ▪ Write access via function codes 06, 16 or 23 	Options List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2 ▪ Option 3 ⁽⁺⁾ ⁽⁺⁾ = Factory setting depends on country, order options or device settings User entry Specific value or input range for the parameter	Page number information and cross-reference to the standard parameter description

NOTICE

If non-volatile device parameters are modified via the MODBUS RS485 function codes 06, 16 or 23, the change is saved in the EEPROM of the measuring device.

The number of writes to the EEPROM is technically restricted to a maximum of 1 million.

- ▶ Make sure to comply with this limit since, if it is exceeded, data loss and measuring device failure will result.
- ▶ Avoid constantly writing non-volatile device parameters via the MODBUS RS485.

6.1.2 Address model

The Modbus RS485 register addresses of the measuring device are implemented in accordance with the "Modbus Applications Protocol Specification V1.1".

In addition, systems are used that work with the register address model "Modicon Modbus Protocol Reference Guide (PI-MBUS-300 Rev. J)".

Depending on the function code used, a number is added at the start of the register address with this specification:

- "3" → "Read" access
- "4" → "Write" access

Function code	Access type	Register in accordance with "Modbus Applications Protocol Specification"	Register in accordance with "Modicon Modbus Protocol Reference Guide"
03 04 23	Read	XXXX Example: mass flow = 2007	3XXXX Example: mass flow = 32007
06 16 23	Write	XXXX Example: reset totalizer = 6401	4XXXX Example: reset totalizer = 46401
























6.2 Overview of the Expert operating menu

























The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.
























Navigation  Expert
























Expert		
Direct access (0106)		→ 183
Locking status (0004)		→ 183
User role (0005)		→ 183
Enter access code (0003)		→ 183
► System		→ 183
	► Display	→ 183
	Display language (0104)	→ 183
	Format display (0098)	→ 183
	Value 1 display (0107)	→ 184
	0% bargraph value 1 (0123)	→ 184
	100% bargraph value 1 (0125)	→ 184
	Decimal places 1 (0095)	→ 184
	Value 2 display (0108)	→ 184
	Decimal places 2 (0117)	→ 184
	Value 3 display (0110)	→ 184
	0% bargraph value 3 (0124)	→ 184
	100% bargraph value 3 (0126)	→ 184
	Decimal places 3 (0118)	→ 184
	Value 4 display (0109)	→ 184
	Decimal places 4 (0119)	→ 184

Display interval (0096)	→ 184
Display damping (0094)	→ 184
Header (0097)	→ 184
Header text (0112)	→ 184
Separator (0101)	→ 184
Contrast display (0105)	→ 185
Backlight (0111)	→ 185
▶ Diagnostic handling	→ 185
Alarm delay (0651)	→ 185
▶ Diagnostic behavior	→ 185
▶ Administration	→ 186
▶ Define access code	→ 186
▶ Reset access code	→ 186
Device reset (0000)	→ 186
Activate SW option (0029)	→ 186
Software option overview (0015)	→ 186
▶ Sensor	→ 186
▶ Measured values	→ 186
▶ Process variables	→ 186
▶ System values	→ 187
▶ Totalizer	→ 187
▶ Output values	→ 187
▶ System units	→ 188
Volume flow unit (0553)	→ 188
Volume unit (0563)	→ 189

Mass flow unit (0554)	→  190
Mass unit (0574)	→  190
Velocity unit (0566)	→  190
Temperature unit (0557)	→  190
Density unit (0555)	→  190
Kinematic viscosity unit (0578)	→  190
Length unit (0551)	→  191
Date/time format (2812)	→  191
► Measuring point 1	→  191
Measuring point configuration (5675-1)	→  191
Medium (2926-1)	→  191
Medium temperature (3053-1)	→  191
Sound velocity (2929-1)	→  191
Viscosity (2932-1)	→  191
Pipe dimensions (2943-1)	→  191
Pipe circumference (2934-1)	→  191
Pipe outer diameter (2910-1)	→  191
Pipe wall thickness (2916-1)	→  191
Liner thickness (2935-1)	→  191
Signal filter (3011-1)	→  191
Cable length (2939-1)	→  191
Intermediate pipe length (2945-1)	→  191
Result sensor type / sensor distance (3066-1)	→  191

Result path length / arc length (3067-1)	→  191
► Mounting deviations signal path 1 to n	→  192
► Installation status	→  192
Installation status (2958)	→  192
Signal strength (2914)	→  192
Signal to noise ratio (2917)	→  192
Sound velocity (2915)	→  192
Sound velocity deviation (2986)	→  192
► Process parameters	→  192
Flow override (1839)	→  192
Flow damping (1802)	→  192
Sound velocity damping (1888)	→  192
Density damping (1889)	→  192
Temperature damping (1886)	→  192
► Low flow cut off	→  192
► External compensation	→  193
Temperature compensation (3025)	→  193
External value (3058)	→  193
Fixed value (2925)	→  193
Density source (3048)	→  193
External value (3060)	→  193
Fixed density (3171)	→  193
Linear expansion coefficient (3153)	→  193
Square expansion coefficient (3172)	→  193


























Fixed reference density (3178)	→  193
Reference temperature (3147)	→  193
► Sensor adjustment	→  193
Installation direction (1809)	→  193
► Process variable adjustment	→  193
► Calibration	→  193
Calibration factor (2920)	→  193
Zero point (2921)	→  193
Nominal diameter (2807)	→  193
► Output	→  194
► Current output 1	→  194
Process variable current output (0359-1)	→  194
Current range output (0353-1)	→  194
Fixed current (0365-1)	→  194
Lower range value output (0367-1)	→  194
Upper range value output (0372-1)	→  194
Measuring mode current output (0351-1)	→  194
Damping current output (0363-1)	→  194
Failure behavior current output (0364-1)	→  194
Failure current (0352-1)	→  194
Output current (0361-1)	→  194
Measured current (0366-1)	→  194
► Pulse/frequency/switch output 1 to n	→  194

Operating mode (0469-1 to n)	→  194
Assign pulse output (0460-1 to n)	→  194
Pulse scaling (0455-1 to n)	→  194
Pulse width (0452-1 to n)	→  194
Measuring mode (0457-1 to n)	→  195
Failure mode (0480-1 to n)	→  195
Pulse output (0456-1 to n)	→  195
Assign frequency output (0478-1 to n)	→  195
Minimum frequency value (0453-1 to n)	→  195
Maximum frequency value (0454-1 to n)	→  195
Measuring value at minimum frequency (0476-1 to n)	→  195
Measuring value at maximum frequency (0475-1 to n)	→  195
Measuring mode (0479-1 to n)	→  195
Damping output (0477-1 to n)	→  195
Response time (0491-1 to n)	→  195
Failure mode (0451-1 to n)	→  195
Failure frequency (0474-1 to n)	→  195
Output frequency (0471-1 to n)	→  195
Switch output function (0481-1 to n)	→  195
Assign diagnostic behavior (0482-1 to n)	→  195
Assign limit (0483-1 to n)	→  196
Switch-on value (0466-1 to n)	→  196
Switch-off value (0464-1 to n)	→  196

Assign flow direction check (0484-1 to n)	→ 196
Assign status (0485-1 to n)	→ 196
Switch-on delay (0467-1 to n)	→ 196
Switch-off delay (0465-1 to n)	→ 196
Failure mode (0486-1 to n)	→ 196
Switch state (0461-1 to n)	→ 196
Invert output signal (0470-1 to n)	→ 196
► Communication	→ 196
► Modbus configuration	→ 196
Bus address (7112)	→ 196
Baudrate (7111)	→ 196
Data transfer mode (7115)	→ 196
Parity (7122)	→ 197
Byte order (7113)	→ 197
Telegram delay (7146)	→ 197
Failure mode (7116)	→ 197
Fieldbus writing access (7156)	→ 197
► Modbus information	→ 197
Device ID (7153)	→ 197
Device revision (7154)	→ 197
► Modbus data map	→ 197
Scan list register 0 to 15 (7114)	→ 197
► Web server	→ 198
Web server language (7221)	→ 198

MAC address (7214)	→ 198
DHCP client (7212)	→ 198
IP address (7209)	→ 198
Subnet mask (7211)	→ 198
Default gateway (7210)	→ 198
Web server functionality (7222)	→ 198
Login page (7273)	→ 198
▶ WLAN settings	→ 198
WLAN (2702)	→ 198
WLAN mode (2717)	→ 198
SSID name (2714)	→ 198
Network security (2705)	→ 198
Security identification (2718)	→ 198
User name (2715)	→ 198
WLAN password (2716)	→ 198
WLAN IP address (2711)	→ 198
WLAN MAC address (2703)	→ 198
WLAN subnet mask (2709)	→ 198
WLAN MAC address (2703)	→ 199
WLAN passphrase (2706)	→ 199
WLAN MAC address (2703)	→ 199
Assign SSID name (2708)	→ 199
SSID name (2707)	→ 199
2.4 GHz WLAN channel (2704)	→ 199
Select antenna (2713)	→ 199

Connection state (2722)	→ 199
Received signal strength (2721)	→ 199
WLAN IP address (2711)	→ 199
Gateway IP address (2719)	→ 199
IP address domain name server (2720)	→ 199
► Application	→ 199
Reset all totalizers (2806)	→ 199
► Totalizer 1 to n	→ 200
Assign process variable 1 to n (0914-1 to n)	→ 200
Process variable unit 1 to n (0915-1 to n)	→ 200
Totalizer 1 to n operation mode (0908-1 to n)	→ 200
Totalizer 1 to n control (0912-1 to n)	→ 200
Preset value 1 to n (0913-1 to n)	→ 200
Totalizer 1 to n failure behavior (0901-1 to n)	→ 200
► Diagnostics	→ 201
Actual diagnostics (0691)	→ 201
Previous diagnostics (0690)	→ 201
Operating time from restart (0653)	→ 201
Operating time (0652)	→ 201
► Diagnostic list	→ 201
Diagnostics 1 (0692)	→ 201
Diagnostics 2 (0693)	→ 201
Diagnostics 3 (0694)	→ 201

Diagnostics 4 (0695)	→  201
Diagnostics 5 (0696)	→  201
▶ Device information	→  201
Device tag (0011)	→  201
Serial number (0009)	→  201
Firmware version (0010)	→  201
Device name (0013)	→  201
Order code (0008)	→  201
Extended order code 1 (0023)	→  201
Extended order code 2 (0021)	→  201
Extended order code 3 (0022)	→  201
ENP version (0012)	→  201
▶ Main electronic module	→  202
Firmware version (0072)	→  202
Build no. software (0079)	→  202
Bootloader revision (0073)	→  202
▶ Sensor electronic module (ISEM)	→  202
Firmware version (0072)	→  202
Build no. software (0079)	→  202
Bootloader revision (0073)	→  202
▶ Display module	→  202
Firmware version (0072)	→  202
Build no. software (0079)	→  202
Bootloader revision (0073)	→  202
▶ Data logging	→  202

Assign channel 1 (0851)	→ 📖 202
Assign channel 2 (0852)	→ 📖 202
Assign channel 3 (0853)	→ 📖 202
Assign channel 4 (0854)	→ 📖 202
Logging interval (0856)	→ 📖 202
Clear logging data (0855)	→ 📖 202
Data logging (0860)	→ 📖 202
Logging delay (0859)	→ 📖 203
Data logging control (0857)	→ 📖 203
Data logging status (0858)	→ 📖 203
Entire logging duration (0861)	→ 📖 203
▶ Heartbeat Technology	→ 📖 203
▶ Heartbeat base settings	→ 📖 203
▶ Performing verification	→ 📖 203
▶ Verification results	→ 📖 204
▶ Simulation	→ 📖 205
Assign simulation process variable (1810)	→ 📖 205
Process variable value (1811)	→ 📖 205
Current output 1 simulation (0354-1)	→ 📖 205
Current output value (0355)	→ 📖 205
Frequency output 1 to n simulation (0472-1 to n)	→ 📖 205
Frequency output 1 to n value (0473-1 to n)	→ 📖 205
Pulse output simulation 1 to n (0458-1 to n)	→ 📖 205

Pulse value 1 to n (0459-1 to n)	→ 205
Switch output simulation 1 to n (0462-1 to n)	→ 205
Switch state 1 to n (0463-1 to n)	→ 205
Device alarm simulation (0654)	→ 205
Diagnostic event category (0738)	→ 205
Diagnostic event simulation (0737)	→ 205






6.3 Register information


Navigation: Expert					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 205
Direct access (0106)	3878	Integer	Read / Write	0 to 65 535	10
Locking status (0004)	4918	Integer	Read	256 = Hardware locked 512 = Temporarily locked	11
User role (0005)	2178	Integer	Read	0 = Operator 1 = Maintenance	11
Enter access code (0003)	2177	Integer	Read / Write	Max. 16-digit character string comprising numbers, letters and special characters	12

6.3.1 "System" submenu

"Display" submenu


Navigation: Expert → System → Display					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 205
Display language (0104)	3673	Integer	Read / Write	0 = English 1 = Deutsch 2 = Français 3 = Español 4 = Italiano 5 = Nederlands 8 = Svenska 11 = 日本語 (Japanese) 12 = Portuguesa 13 = Polski 14 = русский язык (Russian) 15 = čeština (Czech) 16 = 中文 (Chinese) 18 = Türkçe 20 = 한국어 (Korean)	13
Format display (0098)	3625	Integer	Read / Write	0 = 1 value, max. size 1 = 1 bargraph + 1 value 2 = 2 values 3 = 1 value large + 2 values 4 = 4 values	14

Navigation: Expert → System → Display					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Value 1 display (0107)	3963	Integer	Read / Write	1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 5 = Totalizer 1 6 = Totalizer 2 7 = Totalizer 3 8 = Temperature 14 = Density 15 = Signal strength * 16 = Signal to noise ratio * 17 = Turbulence * 20 = Acceptance rate * 39 = Electronics temperature	16
0% bargraph value 1 (0123)	4136 to 4137	Float	Read / Write	Signed floating-point number	16
100% bargraph value 1 (0125)	4142 to 4143	Float	Read / Write	Signed floating-point number	17
Decimal places 1 (0095)	3365	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = x.xxxx	17
Value 2 display (0108)	3964	Integer	Read / Write	For the picklist, see Value 1 display parameter (→  16) For the picklist, see Value 1 display parameter (→  16)	18
Decimal places 2 (0117)	4049	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = x.xxxx	18
Value 3 display (0110)	3966	Integer	Read / Write	For the picklist, see Value 1 display parameter (→  16)	19
0% bargraph value 3 (0124)	4138 to 4139	Float	Read / Write	Signed floating-point number	19
100% bargraph value 3 (0126)	4140 to 4141	Float	Read / Write	Signed floating-point number	20
Decimal places 3 (0118)	4050	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = x.xxxx	20
Value 4 display (0109)	3965	Integer	Read / Write	For the picklist, see Value 1 display parameter (→  16)	20
Decimal places 4 (0119)	4051	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = x.xxxx	21
Display interval (0096)	3604 to 3605	Float	Read / Write	1 to 10 s	21
Display damping (0094)	3554 to 3555	Float	Read / Write	0.0 to 999.9 s	22
Header (0097)	3624	Integer	Read / Write	0 = Device tag 1 = Free text	22
Header text (0112)	3968 to 3973	String	Read / Write	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	23
Separator (0101)	3671	Integer	Read / Write	▪ . (point) ▪ , (comma)	23

Navigation: Expert → System → Display					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Contrast display (0105)	3674 to 3675	Float	Read / Write	20 to 80 %	24
Backlight (0111)	3967	Integer	Read / Write	0 = Disable 1 = Enable	24


* Visibility depends on order options or device settings

"Diagnostic handling" submenu


Navigation: Expert → System → Diagnostic handling					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Alarm delay (0651)	6808 to 6809	Float	Read / Write	0 to 60 s	25

"Diagnostic behavior" submenu

Navigation: Expert → System → Diagnostic handling → Diagnostic behavior					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign behavior of diagnostic no. 019 (0635)	48299	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	27
Assign behavior of diagnostic no. 160 (0776)	2873	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	27
Assign behavior of diagnostic no. 302 (0742)	6484	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning	27
Assign behavior of diagnostic no. 441 (0657)	4742	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	28
Assign behavior of diagnostic no. 442 (0658)	4919	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	28
Assign behavior of diagnostic no. 443 (0659)	5000	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	29
Assign behavior of diagnostic no. 832 (0675)	6440	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	29
Assign behavior of diagnostic no. 833 (0676)	6439	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	29
Assign behavior of diagnostic no. 841 (0680)	2434	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	30
Assign behavior of diagnostic no. 842 (0638)	9661	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	30

Navigation: Expert → System → Diagnostic handling → Diagnostic behavior					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign behavior of diagnostic no. 870 (0726)	33279	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	30
Assign behavior of diagnostic no. 930 (0639)	30668	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	31
Assign behavior of diagnostic no. 931 (0640)	30930	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	31


"Administration" submenu

Navigation: Expert → System → Administration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Device reset (0000)	6817	Integer	Read / Write	0 = Cancel 1 = Restart device 2 = To delivery settings 25 = Restore S-DAT backup *	35
Activate SW option (0029)	2795	Integer	Read / Write	Max. 10-digit string of numbers.	35
Software option overview (0015)	2902	Integer	Read	1 = Extended HistoROM 8 = 4-20mA, 2x pulse/freq./switch output 16384 = Heartbeat Monitoring 32768 = Heartbeat Verification	36

* Visibility depends on order options or device settings

"Define access code" wizard


"Reset access code" submenu


Navigation: Expert → System → Administration → Reset access code					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Operating time (0652)	2631	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	34
Reset access code (0024)	8880 to 8895	String	Read / Write	Character string comprising numbers, letters and special characters	34

6.3.2 "Sensor" submenu


"Measured values" submenu

"Process variables" submenu


Navigation: Expert → Sensor → Measured values → Process variables					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Volume flow (1838)	2007 to 2008	Float	Read	Signed floating-point number	38
Mass flow (1847)	2009 to 2010	Float	Read	Signed floating-point number	38
Flow velocity (1852)	2015 to 2016	Float	Read	Signed floating-point number	39

Navigation: Expert → Sensor → Measured values → Process variables					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Sound velocity (1850)	2013 to 2014	Float	Read	Signed floating-point number	39
Density (1851)	2011 to 2012	Float	Read	Signed floating-point number	39
Temperature (1853)	2017 to 2018	Float	Read	Signed floating-point number	39


"System values" submenu

Navigation: Expert → Sensor → Measured values → System values					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Signal strength (2914)	4959 to 4960	Float	Read	Signed floating-point number	40
Signal to noise ratio (2917)	4983 to 4984	Float	Read	Signed floating-point number	40
Acceptance rate (2912)	4551 to 4552	Float	Read	0 to 100 %	41
Turbulence (2907)	22772 to 22773	Float	Read	Signed floating-point number	41


"Totalizer" submenu


Navigation: Expert → Sensor → Measured values → Totalizer					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Totalizer 1 to n value (0911-1 to n)	1: 2610 to 2611 2: 2810 to 2811 3: 3010 to 3011	Float	Read	Signed floating-point number	42
Totalizer 1 to n overflow (0910-1 to n)	1: 2612 to 2613 2: 2812 to 2813 3: 3012 to 3013	Float	Read	-32 000.0 to 32 000.0	42


"Output values" submenu


Navigation: Expert → Sensor → Measured values → Output values					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Output current (0361)	--	Float	Read		
Measured current (0366)	--	Float	Read		
Pulse output (0456)	--	Float	Read		
Output frequency (0471)	--	Float	Read		
Switch state (0461)	--	Integer	Read		
Output frequency (0471)	--	Float	Read		
Pulse output (0456)	--	Float	Read		
Switch state (0461)	--	Integer	Read		

"System units" submenu


Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Volume flow unit (0553)	2103	Integer	Read / Write	= = = = 0 = cm ³ /s 1 = cm ³ /min 2 = cm ³ /h 3 = cm ³ /d 4 = dm ³ /s 5 = dm ³ /min 6 = dm ³ /h 7 = dm ³ /d 8 = m ³ /s 9 = m ³ /min 10 = m³/h (*) 11 = m ³ /d 12 = ml/s 13 = ml/min 14 = ml/h 15 = ml/d 16 = l/s 17 = l/min 18 = l/h 19 = l/d 20 = hl/s 21 = hl/min 22 = hl/h 23 = hl/d 24 = Ml/s 25 = Ml/min 26 = Ml/h 27 = Ml/d 32 = af/s 33 = af/min 34 = af/h 35 = af/d 36 = ft ³ /s 37 = ft ³ /min 38 = ft ³ /h 39 = ft ³ /d 40 = fl oz/s (us) 41 = fl oz/min (us) 42 = fl oz/h (us) 43 = fl oz/d (us) 44 = gal/s (us) 45 = gal/min (us) 46 = gal/h (us) 47 = gal/d (us) 48 = Mgal/s (us) 49 = Mgal/min (us) 50 = Mgal/h (us) 51 = Mgal/d (us) 52 = bbl/s (us;liq.) 53 = bbl/min (us;liq.) 54 = bbl/h (us;liq.) 55 = bbl/d (us;liq.) 56 = bbl/s (us;beer) 57 = bbl/min (us;beer) 58 = bbl/h (us;beer) 59 = bbl/d (us;beer) 60 = bbl/s (us;oil) 61 = bbl/min (us;oil) 62 = bbl/h (us;oil) 63 = bbl/d (us;oil) 64 = bbl/s (us;tank)	46

Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
				65 = bbl/min (us;tank) 66 = bbl/h (us;tank) 67 = bbl/d (us;tank) 68 = gal/s (imp) 69 = gal/min (imp) 70 = gal/h (imp) 71 = gal/d (imp) 72 = Mgal/s (imp) 73 = Mgal/min (imp) 74 = Mgal/h (imp) 75 = Mgal/d (imp) 76 = bbl/s (imp;beer) 77 = bbl/min (imp;beer) 78 = bbl/h (imp;beer) 79 = bbl/d (imp;beer) 80 = bbl/s (imp;oil) 81 = bbl/min (imp;oil) 82 = bbl/h (imp;oil) 83 = bbl/d (imp;oil) 88 = kgal/s (us) 89 = kgal/min (us) 90 = kgal/h (us) 91 = kgal/d (us)	
Volume unit (0563)	2104	Integer	Read / Write	= = 0 = cm ³ 1 = dm ³ 2 = m ³ (*) 3 = ml 4 = l 5 = hl 8 = af 9 = ft ³ 10 = fl oz (us) 11 = gal (us) 12 = Mgal (us) 13 = bbl (us;liq.) 14 = bbl (us;beer) 15 = bbl (us;oil) 16 = bbl (us;tank) 17 = gal (imp) 18 = Mgal (imp) 19 = bbl (imp;beer) 20 = bbl (imp;oil) 22 = kgal (us)	47

Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Mass flow unit (0554)	2101	Integer	Read / Write	0 = g/s 1 = g/min 2 = g/h 3 = g/d 4 = kg/s 5 = kg/min 6 = kg/h⁽⁺⁾ 7 = kg/d 8 = t/s 9 = t/min 10 = t/h 11 = t/d 12 = oz/s 13 = oz/min 14 = oz/h 15 = oz/d 16 = lb/s 17 = lb/min 18 = lb/h 19 = lb/d 20 = STon/s 21 = STon/min 22 = STon/h 23 = STon/d	48
Mass unit (0574)	2102	Integer	Read / Write	50 = g 51 = kg⁽⁺⁾ 52 = t 53 = oz 54 = lb 55 = STon	49
Velocity unit (0566)	2600	Integer	Read / Write	20 = ft/s 21 = m/s⁽⁺⁾	49
Temperature unit (0557)	2109	Integer	Read / Write	0 = °C⁽⁺⁾ 1 = K 2 = °F 3 = °R	50
Density unit (0555)	2107	Integer	Read / Write	0 = g/cm ³ 2 = kg/dm³⁽⁺⁾ 3 = kg/l 4 = kg/m ³ 5 = SD4°C 6 = SD15°C 7 = SD20°C 8 = SG4°C 9 = SG15°C 10 = SG20°C 11 = lb/ft ³ 12 = lb/gal (us) 13 = lb/bbl (us;liq.) 14 = lb/bbl (us;beer) 15 = lb/bbl (us;oil) 16 = lb/bbl (us;tank) 17 = lb/gal (imp) 18 = lb/bbl (imp;beer) 19 = lb/bbl (imp;oil) 21 = g/m ³	50
Kinematic viscosity unit (0578)	2112	Integer	Read / Write	0 = m²/s⁽⁺⁾ 2 = cSt 3 = St 240 = mm ² /s	51


Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Length unit (0551)	2087	Integer	Read / Write	44 = ft 45 = m 47 = in 49 = mm (+)	51
Date/time format (2812)	2150	Integer	Read / Write	0 = dd.mm.yy hh:mm 1 = mm/dd/yy hh:mm am/pm 2 = dd.mm.yy hh:mm am/pm 3 = mm/dd/yy hh:mm	51

"Measuring point 1" submenu


Navigation: Expert → Sensor → Measuring point 1					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Measuring point configuration (5675-1)	4285	Integer	Read / Write	0 = 1 measuring point - signal path 1 1 = 1 measuring point - 2 signal paths * 2 = 1 measuring point - signal path 2 *	53
Medium (2926-1)	5049	Integer	Read / Write	0 = Water 1 = Distilled water 2 = Sea water 3 = Ammonia NH3 4 = Benzene 6 = Ethanol 7 = Glycol 9 = Milk 10 = Methanol 255 = User-specific liquid	53
Medium temperature (3053-1)	36110 to 36111	Float	Read / Write	-200 to 550 °C	53
Sound velocity (2929-1)	5171 to 5172	Float	Read / Write	200 to 3 000 m/s	54
Viscosity (2932-1)	5223 to 5224	Float	Read / Write	0.01 to 10 000 mm ² /s	54
Pipe dimensions (2943-1)	5114	Integer	Read / Write	0 = Diameter 1 = Pipe circumference	54
Pipe circumference (2934-1)	5334 to 5335	Float	Read / Write	30 to 62 800 mm	54
Pipe outer diameter (2910-1)	4971 to 4972	Float	Read / Write	0 to 20 000 mm	55
Pipe wall thickness (2916-1)	4975 to 4976	Float	Read / Write	Positive floating point number	55
Liner thickness (2935-1)	5338 to 5339	Float	Read / Write	0 to 100 mm	55
Signal filter (3011-1)	52344	Integer	Read / Write	0 = Off 1 = On	56
Cable length (2939-1)	5346 to 5347	Float	Read / Write	0 to 200 000 mm	56
Intermediate pipe length (2945-1)	32808 to 32809	Float	Read / Write	Positive floating-point number	56
Result sensor type / sensor distance (3066-1)	44416 to 44428	String	Read	e.g. I-100-A / 500 mm	56
Result path length / arc length (3067-1)	44450 to 44462	String	Read	e.g. 1 085 mm / 257.56 mm	57

* Visibility depends on order options or device settings


"Mounting deviations signal path 1 to n" submenu

Navigation: Expert → Sensor → Measuring point 1 → Mounting deviations signal path 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Sensor distance deviation (5822-1 to n)	1: 5667 to 5668 2: 5669 to 5670	Float	Read / Write	Signed floating-point number	57
Arc length deviation (5876-1 to n)	1: 36007 to 36008 2: 36009 to 36010	Float	Read / Write	Signed floating-point number	58
Signal path length deviation (5821-1 to n)	1: 5663 to 5664 2: 5665 to 5666	Float	Read / Write	Signed floating-point number	58


"Installation status" submenu

Navigation: Expert → Sensor → Installation status					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Installation status (2958)	27532	Integer	Read	0 = Bad 1 = Acceptable 128 = Good	59
Signal strength (2914)	4959 to 4960	Float	Read	Signed floating-point number	59
Signal to noise ratio (2917)	4983 to 4984	Float	Read	Signed floating-point number	60
Sound velocity (2915)	4967 to 4968	Float	Read	Signed floating-point number	60
Sound velocity deviation (2986)	46176 to 46177	Float	Read	Signed floating-point number	60


"Process parameters" submenu

Navigation: Expert → Sensor → Process parameters					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Flow override (1839)	5503	Integer	Read / Write	0 = Off 1 = On	61
Flow damping (1802)	5510 to 5511	Float	Read / Write	0 to 999.9 s	61
Sound velocity damping (1888)	25344 to 25345	Float	Read / Write	0 to 999.9 s	62
Density damping (1889)	25492 to 25493	Float	Read / Write	0 to 999.9 s	62
Temperature damping (1886)	2483 to 2484	Float	Read / Write	0 to 999.9 s	62


"Low flow cut off" submenu

Navigation: Expert → Sensor → Process parameters → Low flow cut off					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign process variable (1837)	5101	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow 3 = Flow velocity	63
On value low flow cutoff (1805)	5138 to 5139	Float	Read / Write	Positive floating-point number	63
Off value low flow cutoff (1804)	5104 to 5105	Float	Read / Write	0 to 100.0 %	64


"External compensation" submenu

Navigation: Expert → Sensor → External compensation					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Temperature compensation (3025)	28563	Integer	Read / Write	1 = Fixed value 10 = External value	65
External value (3058)	28647 to 28648	Float	Read / Write	-273.15 to 99999 °C	66
Fixed value (2925)	4979 to 4980	Float	Read / Write	-50 to 550 °C	65
Density source (3048)	21485	Integer	Read / Write	0 = Fixed value 1 = External density 2 = Calculated value	66
External value (3060)	36025 to 36026	Float	Read / Write	Positive floating-point number	66
Fixed density (3171)	25234 to 25235	Float	Read / Write	0.01 to 15 000 kg/m ³	66
Linear expansion coefficient (3153)	26402 to 26403	Float	Read / Write	$1.0 \cdot 10^{-6}$ to $2.0 \cdot 10^{-3}$	67
Square expansion coefficient (3172)	36021 to 36022	Float	Read / Write	$1.0 \cdot 10^{-6}$ to $2.0 \cdot 10^{-3}$	67
Fixed reference density (3178)	27177 to 27178	Float	Read / Write	0.01 to 15 000 kg/m ³	67
Reference temperature (3147)	26383 to 26384	Float	Read / Write	-200 to 450 °C	68


"Sensor adjustment" submenu

Navigation: Expert → Sensor → Sensor adjustment					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Installation direction (1809)	5501	Integer	Read / Write	0 = Forward flow 1 = Reverse flow	68

"Process variable adjustment" submenu


Navigation: Expert → Sensor → Sensor adjustment → Process variable adjustment					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Volume flow offset (1831)	5521 to 5522	Float	Read / Write	Signed floating-point number	69
Volume flow factor (1832)	5519 to 5520	Float	Read / Write	Positive floating-point number	70
Mass flow offset (1841)	5525 to 5526	Float	Read / Write	Signed floating-point number	70
Mass flow factor (1846)	5523 to 5524	Float	Read / Write	Positive floating-point number	70
Sound velocity offset (1848)	5529 to 5530	Float	Read / Write	Signed floating-point number	71
Sound velocity factor (1849)	5527 to 5528	Float	Read / Write	Positive floating-point number	71
Density offset (1866)	2044 to 2045	Float	Read / Write	Signed floating-point number	71
Density factor (1867)	2076 to 2077	Float	Read / Write	Positive floating-point number	72
Temperature offset (1870)	5533 to 5534	Float	Read / Write	Signed floating-point number	72
Temperature factor (1871)	5531 to 5532	Float	Read / Write	Positive floating-point number	72

"Calibration" submenu

Navigation: Expert → Sensor → Calibration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Calibration factor (2920)	4559 to 4560	Float	Read	Signed floating-point number	73
Zero point (2921)	4963 to 4964	Float	Read	Signed floating-point number	73
Nominal diameter (2807)	2048 to 2057	String	Read	-----	73


6.3.3 "Output" submenu


"Current output 1" submenu


Navigation: Expert → Output → Current output 1					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Process variable current output (0359-1)	5927	Integer	Read / Write	0 = Off * 1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 8 = Temperature 14 = Density 15 = Signal strength * 16 = Signal to noise ratio * 17 = Turbulence * 20 = Acceptance rate * 39 = Electronics temperature	75
Current range output (0353-1)	5923	Integer	Read / Write	0 = 4...20 mA (4...20.5 mA) 1 = 4...20 mA US (3.9...20.8 mA) 2 = 4...20 mA NE (3.8...20.5 mA) 3 = 0...20 mA (0...20.5 mA) 4 = Fixed value	75
Fixed current (0365-1)	5987 to 5988	Float	Read / Write	0 to 22.5 mA	76
Lower range value output (0367-1)	6195 to 6196	Float	Read / Write	Signed floating-point number	77
Upper range value output (0372-1)	5915 to 5916	Float	Read / Write	Signed floating-point number	78
Measuring mode current output (0351-1)	5899	Integer	Read / Write	0 = Forward flow 2 = Reverse flow compensation 13 = Forward/Reverse flow *	79
Damping current output (0363-1)	5903 to 5904	Float	Read / Write	0.0 to 999.9 s	83
Failure behavior current output (0364-1)	5911	Integer	Read / Write	0 = Min. 1 = Max. 4 = Actual value 5 = Last valid value 6 = Fixed value	84
Failure current (0352-1)	5979 to 5980	Float	Read / Write	0 to 22.5 mA	85
Output current (0361-1)	5931 to 5932	Float	Read	0 to 22.5 mA	85
Measured current (0366-1)	5779 to 5780	Float	Read	0 to 30 mA	86

* Visibility depends on order options or device settings

"Pulse/frequency/switch output 1 to n" submenu

Navigation: Expert → Output → Pulse/frequency/switch output 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Operating mode (0469-1 to n)	1: 4479 2: 4480	Integer	Read / Write	0 = Pulse * 1 = Switch * 53 = Frequency *	88
Assign pulse output (0460-1 to n)	1: 2461 2: 2462	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow	90
Pulse scaling (0455-1 to n)	1: 3034 to 3035 2: 3036 to 3037	Float	Read / Write	Positive floating point number	90
Pulse width (0452-1 to n)	1: 2836 to 2837 2: 2838 to 2839	Float	Read / Write	0.05 to 2 000 ms	91


Navigation: Expert → Output → Pulse/frequency/switch output 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Measuring mode (0457-1 to n)	1: 2394 2: 2395	Integer	Read / Write	0 = Forward flow 1 = Reverse flow 2 = Reverse flow compensation 13 = Forward/Reverse flow	91
Failure mode (0480-1 to n)	1: 2948 2: 2949	Integer	Read / Write	0 = Actual value 1 = No pulses	92
Pulse output (0456-1 to n)	1: 3082 to 3083 2: 3084 to 3085	Float	Read	Positive floating-point number	93
Assign frequency output (0478-1 to n)	1: 2614 2: 2615	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 8 = Temperature 14 = Density 15 = Signal strength * 16 = Signal to noise ratio * 17 = Turbulence * 20 = Acceptance rate * 39 = Electronics temperature	93
Minimum frequency value (0453-1 to n)	1: 3526 to 3527 2: 3528 to 3529	Float	Read / Write	0.0 to 10000.0 Hz	94
Maximum frequency value (0454-1 to n)	1: 2996 to 2997 2: 2998 to 2999	Float	Read / Write	0.0 to 10000.0 Hz	94
Measuring value at minimum frequency (0476-1 to n)	1: 5887 to 5888 2: 5889 to 5890	Float	Read / Write	Signed floating-point number	94
Measuring value at maximum frequency (0475-1 to n)	1: 3514 to 3515 2: 3516 to 3517	Float	Read / Write	Signed floating-point number	95
Measuring mode (0479-1 to n)	1: 2922 2: 2923	Integer	Read / Write	0 = Forward flow 2 = Reverse flow compensation 13 = Forward/Reverse flow	95
Damping output (0477-1 to n)	1: 3522 to 3523 2: 3524 to 3525	Float	Read / Write	0 to 999.9 s	95
Response time (0491-1 to n)	1: 5875 to 5876 2: 5877 to 5878	Float	Read	Positive floating-point number	96
Failure mode (0451-1 to n)	1: 2367 2: 2368	Integer	Read / Write	0 = Actual value 1 = 0 Hz 2 = Defined value	96
Failure frequency (0474-1 to n)	1: 3510 to 3511 2: 3512 to 3513	Float	Read / Write	0.0 to 12 500.0 Hz	97
Output frequency (0471-1 to n)	1: 3462 to 3463 2: 3464 to 3465	Float	Read	0.0 to 12 500.0 Hz	97
Switch output function (0481-1 to n)	1: 3022 2: 3023	Integer	Read / Write	0 = Off 1 = On 2 = Diagnostic behavior 3 = Flow direction check 4 = Limit 5 = Status	97
Assign diagnostic behavior (0482-1 to n)	1: 3096 2: 3097	Integer	Read / Write	0 = Alarm 1 = Warning 2 = Alarm or warning	98


Navigation: Expert → Output → Pulse/frequency/switch output 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign limit (0483-1 to n)	1: 3184 2: 3185	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 5 = Totalizer 1 6 = Totalizer 2 7 = Totalizer 3 8 = Temperature 14 = Density 15 = Signal strength * 16 = Signal to noise ratio * 17 = Turbulence * 20 = Acceptance rate * 39 = Electronics temperature	99
Switch-on value (0466-1 to n)	1: 3242 to 3243 2: 3244 to 3245	Float	Read / Write	Signed floating-point number	101
Switch-off value (0464-1 to n)	1: 3234 to 3235 2: 3236 to 3237	Float	Read / Write	Signed floating-point number	101
Assign flow direction check (0484-1 to n)	1: 3363 2: 3364	Integer	Read / Write		102
Assign status (0485-1 to n)	1: 3374 2: 3375	Integer	Read / Write	0 = Off 1 = Low flow cut off	102
Switch-on delay (0467-1 to n)	1: 6247 to 6248 2: 6249 to 6250	Float	Read / Write	0.0 to 100.0 s	102
Switch-off delay (0465-1 to n)	1: 6239 to 6240 2: 6241 to 6242	Float	Read / Write	0.0 to 100.0 s	103
Failure mode (0486-1 to n)	1: 3384 2: 3385	Integer	Read / Write	0 = Actual status 1 = Open 6 = Closed	103
Switch state (0461-1 to n)	1: 2485 2: 2486	Integer	Read	1 = Open 6 = Closed	103
Invert output signal (0470-1 to n)	1: 2583 2: 2584	Integer	Read / Write	0 = Yes 1 = No	104

* Visibility depends on order options or device settings


6.3.4 "Communication" submenu

"Modbus configuration" submenu


Navigation: Expert → Communication → Modbus configuration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Bus address (7112)	4910	Integer	Read / Write	1 to 247	105
Baudrate (7111)	4912	Integer	Read / Write	0 = 1200 BAUD 1 = 2400 BAUD 2 = 4800 BAUD 3 = 9600 BAUD 4 = 19200 BAUD 5 = 38400 BAUD 6 = 57600 BAUD 7 = 115200 BAUD 8 = 230400 BAUD	105
Data transfer mode (7115)	4913	Integer	Read / Write	0 = RTU 1 = ASCII	106

Navigation: Expert → Communication → Modbus configuration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Parity (7122)	4914	Integer	Read / Write	0 = Even 1 = Odd 2 = None / 2 stop bits 3 = None / 1 stop bit	106
Byte order (7113)	4915	Integer	Read / Write	0 = 0-1-2-3 1 = 3-2-1-0 2 = 2-3-0-1 3 = 1-0-3-2	107
Telegram delay (7146)	4916 to 4917	Float	Read / Write	0 to 100 ms	108
Failure mode (7116)	4920	Integer	Read / Write	1 = Last valid value 255 = NaN value	108
Fieldbus writing access (7156)	6807	Integer	Read / Write	0 = Read + write 1 = Read only	109


"Modbus information" submenu

Navigation: Expert → Communication → Modbus information					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Device ID (7153)	2547	Integer	Read	4-digit hexadecimal number	110
Device revision (7154)	4481	Integer	Read	4-digit hexadecimal number	110


"Modbus data map" submenu


Navigation: Expert → Communication → Modbus data map					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Scan list register 0 to 15 (7114)	0: 5001 1: 5002 2: 5003 3: 5004 4: 5005 5: 5006 6: 5007 7: 5008 8: 5009 9: 5010 10: 5011 11: 5012 12: 5013 13: 5014 14: 5015 15: 5016	Integer	Read / Write	1 to 65535	110

"Web server" submenu

Navigation: Expert → Communication → Web server					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Web server language (7221)	4219	Integer	Read / Write	0 = English 1 = Deutsch 2 = Français 3 = Español 4 = Italiano 5 = Nederlands 8 = Svenska 11 = 日本語 (Japanese) 12 = Portuguesa 13 = Polski 14 = русский язык (Russian) 15 = čeština (Czech) 16 = 中文 (Chinese) 18 = Türkçe 20 = 한국어 (Korean)	111
MAC address (7214)	4210 to 4218	String	Read	Unique 12-digit character string comprising letters and numbers	112
DHCP client (7212)	21781	Integer	Read / Write	0 = Off 1 = On	112
IP address (7209)	4155 to 4162	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	112
Subnet mask (7211)	4163 to 4170	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	113
Default gateway (7210)	4171 to 4178	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	113
Web server functionality (7222)	4220	Integer	Read / Write	0 = Off 1 = On	113
Login page (7273)	5802	Integer	Read / Write	0 = Without header 1 = With header	114


"WLAN settings" wizard

Navigation: Expert → Communication → WLAN settings					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
WLAN (2702)	6178	Integer	Read / Write	0 = Disable 1 = Enable	115
WLAN mode (2717)	28777	Integer	Read / Write	0 = WLAN access point	115
SSID name (2714)	28940 to 28955	String	Read / Write	–	115
Network security (2705)	6206	Integer	Read / Write	0 = Unsecured 1 = WPA2-PSK 2 = EAP-PEAP with MSCHAPv2 * 3 = EAP-TLS * 4 = EAP-PEAP MSCHAPv2 no server authentic. *	116
Security identification (2718)	28817	Integer	Read	1 = Trusted issuer certificate 2 = Device certificate 4 = Device private key	116
User name (2715)	28956 to 28971	String	Read / Write	–	117
WLAN password (2716)	28972 to 28987	String	Read / Write	–	117
WLAN IP address (2711)	8643 to 8650	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	117
WLAN MAC address (2703)	8602 to 8610	String	Read	Unique 12-digit character string comprising letters and numbers	117
WLAN subnet mask (2709)	8651 to 8658	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	118


Navigation: Expert → Communication → WLAN settings					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
WLAN MAC address (2703)	8602 to 8610	String	Read	Unique 12-digit character string comprising letters and numbers	117
WLAN passphrase (2706)	8611 to 8626	String	Read / Write	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	118
WLAN MAC address (2703)	8602 to 8610	String	Read	Unique 12-digit character string comprising letters and numbers	117
Assign SSID name (2708)	6218	Integer	Read / Write	0 = Device tag 1 = User-defined	118
SSID name (2707)	8627 to 8642	String	Read / Write	Max. 32-digit character string comprising numbers, letters and special characters	119
2.4 GHz WLAN channel (2704)	6182	Integer	Read / Write	1 to 11	119
Select antenna (2713)	6102	Integer	Read / Write	0 = External antenna 1 = Internal antenna	119
Connection state (2722)	29221	Integer	Read	0 = Not connected 1 = Connected	119
Received signal strength (2721)	28818	Integer	Read	0 = Low 1 = High 2 = Medium	120
WLAN IP address (2711)	8643 to 8650	String	Read / Write	4 octet: 0 to 255 (in the particular octet)	117
Gateway IP address (2719)	29227 to 29234	String	Read	Character string comprising numbers, letters and special characters	120
IP address domain name server (2720)	29283 to 29290	String	Read	Character string comprising numbers, letters and special characters	120

* Visibility depends on order options or device settings

6.3.5 "Application" submenu


Navigation: Expert → Application					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Reset all totalizers (2806)	2609	Integer	Read / Write	0 = Cancel 1 = Reset + totalize	121

"Totalizer 1 to n" submenu


Navigation: Expert → Application → Totalizer 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign process variable 1 to n (0914-1 to n)	1: 2601 2: 2801 3: 3001	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow	122
Process variable unit 1 to n (0915-1 to n)	1: 4604 2: 4605 3: 4606	Integer	Read / Write	0 = cm ³ * 1 = dm ³ * 2 = m ³ * 3 = ml * 4 = l * 5 = hl * 6 = Ml Mega * 8 = af * 9 = ft ³ * 10 = fl oz (us) * 11 = gal (us) * 12 = Mgal (us) * 13 = bbl (us;liq.) * 14 = bbl (us;beer) * 15 = bbl (us;oil) * 16 = bbl (us;tank) * 17 = gal (imp) * 18 = Mgal (imp) * 19 = bbl (imp;beer) * 20 = bbl (imp;oil) * 22 = kgal (us) * 23 = Mft ³ * 50 = g * 51 = kg * 52 = t * 53 = oz * 54 = lb * 55 = STon * 111 = Mft ³ * 251 = None *	122
Totalizer 1 to n operation mode (0908-1 to n)	1: 2605 2: 2805 3: 3005	Integer	Read / Write	0 = Net 1 = Forward 2 = Reverse	123
Totalizer 1 to n control (0912-1 to n)	1: 2608 2: 2808 3: 3008	Integer	Read / Write	0 = Totalize 1 = Reset + totalize 2 = Preset + hold 3 = Reset + hold 4 = Preset + totalize 5 = Hold	124
Preset value 1 to n (0913-1 to n)	1: 2590 to 2591 2: 2592 to 2593 3: 2594 to 2595	Float	Read / Write	Signed floating-point number	124
Totalizer 1 to n failure behavior (0901-1 to n)	1: 2606 2: 2806 3: 3006	Integer	Read / Write	0 = Hold 1 = Continue 2 = Last valid value + continue	125

* Visibility depends on order options or device settings


6.3.6 "Diagnostics" submenu

Navigation: Expert → Diagnostics					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Actual diagnostics (0691)	2732	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	130
Previous diagnostics (0690)	2734	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	130
Operating time from restart (0653)	2624	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	131
Operating time (0652)	--	String	Read		


"Diagnostic list" submenu

Navigation: Expert → Diagnostics → Diagnostic list					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Diagnostics 1 (0692)	2736	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	132
Diagnostics 2 (0693)	2738	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	132
Diagnostics 3 (0694)	2740	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	133
Diagnostics 4 (0695)	2742	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	134
Diagnostics 5 (0696)	2744	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	135


"Device information" submenu

Navigation: Expert → Diagnostics → Device information					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Device tag (0011)	2026 to 2041	String	Read	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	136
Serial number (0009)	7003 to 7008	String	Read	Max. 11-digit character string comprising letters and numbers.	137
Firmware version (0010)	7277 to 7280	String	Read	Character string in the format xx.yy.zz	137
Device name (0013)	7263 to 7270	String	Read	Max. 32 characters such as letters or numbers.	137
Order code (0008)	2058 to 2067	String	Read	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	138
Extended order code 1 (0023)	2212 to 2221	String	Read	Character string	138
Extended order code 2 (0021)	2222 to 2231	String	Read	Character string	138
Extended order code 3 (0022)	2232 to 2241	String	Read	Character string	139
ENP version (0012)	4003 to 4010	String	Read	Character string	139


"Main electronic module" submenu

Navigation: Expert → Diagnostics → Main electronic module					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Firmware version (0072)	7039	Integer	Read	Positive integer	140
Build no. software (0079)	2326	Integer	Read	Positive integer	140
Bootloader revision (0073)	2264	Integer	Read	Positive integer	140





"Sensor electronic module (ISEM)" submenu


Navigation: Expert → Diagnostics → Sensor electronic module (ISEM)					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Firmware version (0072)	7039	Integer	Read	Positive integer	141
Build no. software (0079)	2326	Integer	Read	Positive integer	141
Bootloader revision (0073)	2264	Integer	Read	Positive integer	141

"Display module" submenu

Navigation: Expert → Diagnostics → Display module					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Firmware version (0072)	7039	Integer	Read	Positive integer	142
Build no. software (0079)	2326	Integer	Read	Positive integer	142
Bootloader revision (0073)	2264	Integer	Read	Positive integer	142

"Data logging" submenu


Navigation: Expert → Diagnostics → Data logging					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign channel 1 (0851)	2445	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 8 = Temperature 14 = Density 15 = Signal strength * 16 = Signal to noise ratio * 17 = Turbulence * 20 = Acceptance rate * 39 = Electronics temperature 121 = Current output 1	143
Assign channel 2 (0852)	2446	Integer	Read / Write	For the picklist, see Assign channel 1 parameter (→  143)	144
Assign channel 3 (0853)	2548	Integer	Read / Write	For the picklist, see Assign channel 1 parameter (→  143)	144
Assign channel 4 (0854)	4286	Integer	Read / Write	For the picklist, see Assign channel 1 parameter (→  143)	144
Logging interval (0856)	4288 to 4289	Float	Read / Write	0.1 to 3 600.0 s	145
Clear logging data (0855)	4287	Integer	Read / Write	0 = Cancel 2 = Clear data	145
Data logging (0860)	5950	Integer	Read / Write	0 = Overwriting 1 = Not overwriting	146

Navigation: Expert → Diagnostics → Data logging					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Logging delay (0859)	5938	Integer	Read / Write	0 to 999 h	146
Data logging control (0857)	5930	Integer	Read / Write	0 = None 1 = Stop 2 = Delete + start	146
Data logging status (0858)	5937	Integer	Read	0 = Done 1 = Stopped 2 = Active 3 = Delay active	147
Entire logging duration (0861)	2827 to 2828	Float	Read	Positive floating-point number	147


* Visibility depends on order options or device settings


"Heartbeat Technology" submenu

"Heartbeat base settings" submenu

Navigation: Expert → Diagnostics → Heartbeat Technology → Heartbeat base settings					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Plant operator (2754)	3414 to 3429	String	Read / Write	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)	150
Location (2755)	3430 to 3445	String	Read / Write	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)	151


"Performing verification" submenu

Navigation: Expert → Diagnostics → Heartbeat Technology → Performing verification					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Year (2846)	2495	Integer	Read / Write	9 to 99	152
Month (2845)	2494	Integer	Read / Write	0 = January 1 = February 2 = March 3 = April 4 = May 5 = June 6 = July 7 = August 8 = September 9 = October 10 = November 11 = December	152
Day (2842)	2493	Integer	Read / Write	1 to 31 d	152
Hour (2843)	2492	Integer	Read / Write	0 to 23 h	153
AM/PM (2813)	2496	Integer	Read / Write	0 = AM 1 = PM	153
Minute (2844)	2467	Integer	Read / Write	0 to 59 min	153
Verification mode (12105)	2366	Integer	Read / Write	0 = Standard verification 1 = Extended verification	154
External device information (12101)	20493 to 20508	String	Read / Write	Free text entry	154


Navigation: Expert → Diagnostics → Heartbeat Technology → Performing verification					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Start verification (12127)	2270	Integer	Read / Write	0 = Cancel 1 = Start 3 = Start with testkit * 10 = Output 1 low value * 11 = Output 1 high value * 20 = Pulse output 1 * 21 = Frequency output 1 * 22 = Pulse output 2 * 23 = Frequency output 2 *	154
Progress (2808)	6797	Integer	Read	0 to 100 %	155
Measured values (12102)	5512 to 5513	Float	Read / Write	Signed floating-point number	155
Output values (12103)	5516 to 5517	Float	Read	Signed floating-point number	156
Status (12153)	2079	Integer	Read	0 = Failed 1 = Done 3 = Not done 8 = Busy	156
Verification result (12149)	2355	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	156

* Visibility depends on order options or device settings

"Verification results" submenu

Navigation: Expert → Diagnostics → Heartbeat Technology → Verification results					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Date/time (manually entered) (12142)	2372 to 2381	String	Read	dd.mmmm.yyyy; hh:mm	157
Verification ID (12141)	2315	Integer	Read	0 to 65 535	157
Operating time (12126)	3346	String	Read	Days (d), hours (h), minutes (m), seconds (s)	158
Verification result (12149)	2355	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	158
Sensor (12152)	2384	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	158
Sensor electronic module (ISEM) (12151)	2385	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	159
I/O module (12145)	2386	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	159
System status (12109)	5790	Integer	Read	0 = Failed 2 = Passed 3 = Not done 250 = Not supported	159

"Simulation" submenu

Navigation: Expert → Diagnostics → Simulation					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Assign simulation process variable (1810)	6813	Integer	Read / Write	0 = Off 1 = Mass flow 2 = Volume flow 3 = Flow velocity 4 = Sound velocity 8 = Temperature 14 = Density	161
Process variable value (1811)	6814 to 6815	Float	Read / Write	Depends on the process variable selected	161
Current output 1 simulation (0354-1)	5939	Integer	Read / Write	0 = Off 1 = On	162
Current output value (0355)	5995 to 5996	Float	Read / Write	0 to 22.5 mA	163
Frequency output 1 to n simulation (0472-1 to n)	1: 6203 2: 6204	Integer	Read / Write	0 = Off 1 = On	163
Frequency output 1 to n value (0473-1 to n)	1: 6207 to 6208 2: 6209 to 6210	Float	Read / Write	0.0 to 12 500.0 Hz	164
Pulse output simulation 1 to n (0458-1 to n)	1: 6215 2: 6216	Integer	Read / Write	0 = Off 1 = Down-counting value 2 = Fixed value	164
Pulse value 1 to n (0459-1 to n)	1: 6219 2: 6220	Integer	Read / Write	0 to 65 535	165
Switch output simulation 1 to n (0462-1 to n)	1: 6223 2: 6224	Integer	Read / Write	0 = Off 1 = On	165
Switch state 1 to n (0463-1 to n)	1: 6227 2: 6228	Integer	Read / Write	1 = Open 6 = Closed	166
Device alarm simulation (0654)	6812	Integer	Read / Write	0 = Off 1 = On	166
Diagnostic event category (0738)	4261	Integer	Read / Write	0 = Sensor 1 = Electronics 2 = Configuration 3 = Process	167
Diagnostic event simulation (0737)	4259	Integer	Read / Write	<ul style="list-style-type: none"> ■ Off ■ Diagnostic event picklist (depends on the category selected) 	167

Index

- 0 ... 9**
- 0% bargraph value 1 (Parameter) 16
 - 0% bargraph value 3 (Parameter) 19
 - 2.4 GHz WLAN channel (Parameter) 119
 - 4 mA trim value (Parameter) 86
 - 20 mA trim value (Parameter) 86
 - 100% bargraph value 1 (Parameter) 17
 - 100% bargraph value 3 (Parameter) 20
- A**
- Acceptance rate (Parameter) 41
 - Access status display (Parameter) 24
 - Activate SW option (Parameter) 35
 - Actual diagnostics (Parameter) 130
 - Administration (Submenu) 32
 - Alarm delay (Parameter) 25
 - AM/PM (Parameter) 153
 - Application (Submenu) 121
 - Arc length deviation (Parameter) 58
 - Assign behavior of diagnostic no. 019 (Parameter) . . . 27
 - Assign behavior of diagnostic no. 160 (Parameter) . . . 27
 - Assign behavior of diagnostic no. 302 (Parameter) . . . 27
 - Assign behavior of diagnostic no. 441 (Parameter) . . . 28
 - Assign behavior of diagnostic no. 442 (Parameter) . . . 28
 - Assign behavior of diagnostic no. 443 (Parameter) . . . 29
 - Assign behavior of diagnostic no. 832 (Parameter) . . . 29
 - Assign behavior of diagnostic no. 833 (Parameter) . . . 29
 - Assign behavior of diagnostic no. 841 (Parameter) . . . 30
 - Assign behavior of diagnostic no. 842 (Parameter) . . . 30
 - Assign behavior of diagnostic no. 870 (Parameter) . . . 30
 - Assign behavior of diagnostic no. 930 (Parameter) . . . 31
 - Assign behavior of diagnostic no. 931 (Parameter) . . . 31
 - Assign behavior of diagnostic no. 953 (Parameter) . . . 32
 - Assign channel 1 (Parameter) 143
 - Assign channel 2 (Parameter) 144
 - Assign channel 3 (Parameter) 144
 - Assign channel 4 (Parameter) 144
 - Assign diagnostic behavior (Parameter) 98
 - Assign flow direction check (Parameter) 102
 - Assign frequency output (Parameter) 93
 - Assign limit (Parameter) 99
 - Assign process variable (Parameter) 63
 - Assign process variable 1 to n (Parameter) 122
 - Assign pulse output (Parameter) 90
 - Assign simulation process variable (Parameter) 161
 - Assign SSID name (Parameter) 118
 - Assign status (Parameter) 102
- B**
- Backlight (Parameter) 24
 - Baudrate (Parameter) 105
 - Bootloader revision (Parameter) 141, 142
 - Build no. software (Parameter) 141, 142
 - Bus address (Parameter) 105
 - Byte order (Parameter) 107
- C**
- Cable length (Parameter) 56
 - Calibration (Submenu) 73
 - Calibration factor (Parameter) 73
 - Clear logging data (Parameter) 145
 - Communication (Submenu) 104
 - Configuration counter (Parameter) 139
 - Confirm access code (Parameter) 33
 - Connection state (Parameter) 119
 - Contrast display (Parameter) 24
 - Current output 1 (Submenu) 74
 - Current output 1 simulation (Parameter) 162
 - Current output value (Parameter) 163
 - Current range output (Parameter) 75
- D**
- Damping current output (Parameter) 83
 - Damping output (Parameter) 95
 - Data logging (Parameter) 146
 - Data logging (Submenu) 142
 - Data logging control (Parameter) 146
 - Data logging status (Parameter) 147
 - Data transfer mode (Parameter) 106
 - Date/time (manually entered) (Parameter) 157
 - Date/time format (Parameter) 51
 - Day (Parameter) 152
 - Decimal places 1 (Parameter) 17
 - Decimal places 2 (Parameter) 18
 - Decimal places 3 (Parameter) 20
 - Decimal places 4 (Parameter) 21
 - Default gateway (Parameter) 113
 - Define access code (Parameter) 33
 - Define access code (Wizard) 32
 - Density (Parameter) 39
 - Density damping (Parameter) 62
 - Density factor (Parameter) 72
 - Density offset (Parameter) 71
 - Density source (Parameter) 66
 - Density unit (Parameter) 50
 - Device alarm simulation (Parameter) 166
 - Device ID (Parameter) 110
 - Device information (Submenu) 136
 - Device name (Parameter) 137
 - Device reset (Parameter) 35
 - Device revision (Parameter) 110
 - Device tag (Parameter) 136
 - DHCP client (Parameter) 112
 - Diagnostic behavior (Submenu) 25
 - Diagnostic event category (Parameter) 167
 - Diagnostic event simulation (Parameter) 167
 - Diagnostic handling (Submenu) 25
 - Diagnostic list (Submenu) 131
 - Diagnostics (Submenu) 126
 - Diagnostics 1 (Parameter) 132
 - Diagnostics 2 (Parameter) 132
 - Diagnostics 3 (Parameter) 133

- Diagnostics 4 (Parameter) 134
- Diagnostics 5 (Parameter) 135
- Direct access
 - 0% bargraph value 1 (0123) 16
 - 0% bargraph value 3 (0124) 19
 - 2.4 GHz WLAN channel (2704) 119
 - 4 mA trim value
 - Current output 1 (0357-1) 86
 - 20 mA trim value
 - Current output 1 (0356-1) 86
 - 100% bargraph value 1 (0125) 17
 - 100% bargraph value 3 (0126) 20
 - Acceptance rate (2912) 41
 - Access status display (0091) 24
 - Activate SW option (0029) 35
 - Actual diagnostics (0691) 130
 - Alarm delay (0651) 25
 - AM/PM (2813) 153
 - Arc length deviation
 - Mounting deviations signal path 1 to n (5876-1 to n) 58
 - Assign behavior of diagnostic no. 019 (0635) 27
 - Assign behavior of diagnostic no. 160 (0776) 27
 - Assign behavior of diagnostic no. 302 (0742) 27
 - Assign behavior of diagnostic no. 441 (0657) 28
 - Assign behavior of diagnostic no. 442 (0658) 28
 - Assign behavior of diagnostic no. 443 (0659) 29
 - Assign behavior of diagnostic no. 832 (0675) 29
 - Assign behavior of diagnostic no. 833 (0676) 29
 - Assign behavior of diagnostic no. 841 (0680) 30
 - Assign behavior of diagnostic no. 842 (0638) 30
 - Assign behavior of diagnostic no. 870 (0726) 30
 - Assign behavior of diagnostic no. 930 (0639) 31
 - Assign behavior of diagnostic no. 931 (0640) 31
 - Assign behavior of diagnostic no. 953 (0636) 32
 - Assign channel 1 (0851) 143
 - Assign channel 2 (0852) 144
 - Assign channel 3 (0853) 144
 - Assign channel 4 (0854) 144
 - Assign diagnostic behavior
 - Pulse/frequency/switch output 1 to n (0482-1 to n) 98
 - Assign flow direction check
 - Pulse/frequency/switch output 1 to n (0484-1 to n) 102
 - Assign frequency output
 - Pulse/frequency/switch output 1 to n (0478-1 to n) 93
 - Assign limit
 - Pulse/frequency/switch output 1 to n (0483-1 to n) 99
 - Assign process variable (1837) 63
 - Assign process variable 1 to n (0914-1 to n) 122
 - Assign pulse output
 - Pulse/frequency/switch output 1 to n (0460-1 to n) 90
 - Assign simulation process variable (1810) 161
 - Assign SSID name (2708) 118
- Assign status
 - Pulse/frequency/switch output 1 to n (0485-1 to n) 102
- Backlight (0111) 24
- Baudrate (7111) 105
- Bootloader revision (0073) 141, 142
- Build no. software (0079) 141, 142
- Bus address (7112) 105
- Byte order (7113) 107
- Cable length
 - Measuring point 1 (2939-1) 56
- Calibration factor (2920) 73
- Clear logging data (0855) 145
- Configuration counter (0233) 139
- Connection state (2722) 119
- Contrast display (0105) 24
- Current output 1 simulation (0354-1) 162
- Current output value (0355) 163
- Current range output
 - Current output 1 (0353-1) 75
- Damping current output
 - Current output 1 (0363-1) 83
- Damping output
 - Pulse/frequency/switch output 1 to n (0477-1 to n) 95
- Data logging (0860) 146
- Data logging control (0857) 146
- Data logging status (0858) 147
- Data transfer mode (7115) 106
- Date/time (manually entered) (12142) 157
- Date/time format (2812) 51
- Day (2842) 152
- Decimal places 1 (0095) 17
- Decimal places 2 (0117) 18
- Decimal places 3 (0118) 20
- Decimal places 4 (0119) 21
- Default gateway (7210) 113
- Density (1851) 39
- Density damping (1889) 62
- Density factor (1867) 72
- Density offset (1866) 71
- Density source (3048) 66
- Density unit (0555) 50
- Device alarm simulation (0654) 166
- Device ID (7153) 110
- Device name (0013) 137
- Device reset (0000) 35
- Device revision (7154) 110
- Device tag (0011) 136
- DHCP client (7212) 112
- Diagnostic event category (0738) 167
- Diagnostic event simulation (0737) 167
- Diagnostics 1 (0692) 132
- Diagnostics 2 (0693) 132
- Diagnostics 3 (0694) 133
- Diagnostics 4 (0695) 134
- Diagnostics 5 (0696) 135
- Direct access (0106) 10
- Display damping (0094) 22

- Display interval (0096) 21
- Display language (0104) 13
- ENP version (0012) 139
- Enter access code (0003) 12
- Entire logging duration (0861) 147
- Extended order code 1 (0023) 138
- Extended order code 2 (0021) 138
- Extended order code 3 (0022) 139
- External device information (12101) 154
- External value (3058) 66
- External value (3060) 66
- Failure behavior current output
 - Current output 1 (0364-1) 84
- Failure current
 - Current output 1 (0352-1) 85
- Failure frequency
 - Pulse/frequency/switch output 1 to n (0474-1 to n) 97
- Failure mode
 - Pulse/frequency/switch output 1 to n (0451-1 to n) 96
 - Pulse/frequency/switch output 1 to n (0480-1 to n) 92
 - Pulse/frequency/switch output 1 to n (0486-1 to n) 103
- Failure mode (7116) 108
- Fieldbus writing access (7156) 109
- Firmware version (0010) 137
- Firmware version (0072) 141, 142
- Fixed current
 - Current output 1 (0365-1) 76
- Fixed density (3171) 66
- Fixed reference density (3178) 67
- Fixed value (2925) 65
- Flow damping (1802) 61
- Flow override (1839) 61
- Flow velocity (1852) 39
- Format display (0098) 14
- Frequency output 1 to n simulation (0472-1 to n) 163
- Frequency output 1 to n value (0473-1 to n) 164
- Gateway IP address (2719) 120
- Header (0097) 22
- Header text (0112) 23
- Hour (2843) 153
- I/O module (12145) 159
- Installation direction (1809) 68
- Installation status (2958) 59
- Intermediate pipe length
 - Measuring point 1 (2945-1) 56
- Invert output signal
 - Pulse/frequency/switch output 1 to n (0470-1 to n) 104
- IP address (7209) 112
- IP address domain name server (2720) 120
- Kinematic viscosity unit (0578) 51
- Length unit (0551) 51
- Linear expansion coefficient (3153) 67
- Liner thickness
 - Measuring point 1 (2935-1) 55
- Location (2755) 151
- Locking status (0004) 11
- Logging delay (0859) 146
- Logging interval (0856) 145
- Login page (7273) 114
- Lower range value output
 - Current output 1 (0367-1) 77
- MAC address (7214) 112
- Mass flow (1847) 38
- Mass flow factor (1846) 70
- Mass flow offset (1841) 70
- Mass flow unit (0554) 48
- Mass unit (0574) 49
- Maximum frequency value
 - Pulse/frequency/switch output 1 to n (0454-1 to n) 94
- Measured current
 - Current output 1 (0366-1) 86
- Measured current (0366) 43
- Measured values (12102) 155
- Measuring mode
 - Pulse/frequency/switch output 1 to n (0457-1 to n) 91
 - Pulse/frequency/switch output 1 to n (0479-1 to n) 95
- Measuring mode current output
 - Current output 1 (0351-1) 79
- Measuring point configuration
 - Measuring point 1 (5675-1) 53
- Measuring value at maximum frequency
 - Pulse/frequency/switch output 1 to n (0475-1 to n) 95
- Measuring value at minimum frequency
 - Pulse/frequency/switch output 1 to n (0476-1 to n) 94
- Medium
 - Measuring point 1 (2926-1) 53
- Medium temperature
 - Measuring point 1 (3053-1) 53
- Minimum frequency value
 - Pulse/frequency/switch output 1 to n (0453-1 to n) 94
- Minute (2844) 153
- Month (2845) 152
- Network security (2705) 116
- Nominal diameter (2807) 73
- Off value low flow cutoff (1804) 64
- On value low flow cutoff (1805) 63
- Operating mode
 - Pulse/frequency/switch output 1 to n (0469-1 to n) 88
- Operating time (0652) 34, 131
- Operating time (12126) 158
- Operating time from restart (0653) 131
- Order code (0008) 138
- Output current (0361) 43
- Output current 1 (0361-1) 85

- Output frequency
 - Pulse/frequency/switch output 1 to n (0471-1 to n) 97
- Output frequency (0471) 44
- Output values (12103) 156
- Parity (7122) 106
- Pipe circumference
 - Measuring point 1 (2934-1) 54
- Pipe dimensions
 - Measuring point 1 (2943-1) 54
- Pipe outer diameter
 - Measuring point 1 (2910-1) 55
- Pipe wall thickness
 - Measuring point 1 (2916-1) 55
- Plant operator (2754) 150
- Preset value 1 to n (0913-1 to n) 124
- Previous diagnostics (0690) 130
- Process variable current output
 - Current output 1 (0359-1) 75
- Process variable unit 1 to n (0915-1 to n) 122
- Process variable value (1811) 161
- Progress (2808) 155
- Pulse output
 - Pulse/frequency/switch output 1 to n (0456-1 to n) 93
- Pulse output (0456) 44
- Pulse output simulation 1 to n (0458-1 to n) 164
- Pulse scaling
 - Pulse/frequency/switch output 1 to n (0455-1 to n) 90
- Pulse value 1 to n (0459-1 to n) 165
- Pulse width
 - Pulse/frequency/switch output 1 to n (0452-1 to n) 91
- Received signal strength (2721) 120
- Reference temperature (3147) 68
- Reset access code (0024) 34
- Reset all totalizers (2806) 121
- Response time
 - Pulse/frequency/switch output 1 to n (0491-1 to n) 96
- Result path length / arc length
 - Measuring point 1 (3067-1) 57
- Result sensor type / sensor distance
 - Measuring point 1 (3066-1) 56
- Scan list register 0 to 15 (7114) 110
- Security identification (2718) 116
- Select antenna (2713) 119
- Sensor (12152) 158
- Sensor distance deviation
 - Mounting deviations signal path 1 to n (5822-1 to n) 57
- Sensor electronic module (ISEM) (12151) 159
- Separator (0101) 23
- Serial number (0009) 137
- Signal filter
 - Measuring point 1 (3011-1) 56
- Signal path length deviation
 - Mounting deviations signal path 1 to n (5821-1 to n) 58
- Signal strength (2914) 40, 59
- Signal to noise ratio (2917) 40, 60
- Simulation status input (1355) 161
- Software option overview (0015) 36
- Sound velocity
 - Measuring point 1 (2929-1) 54
- Sound velocity (1850) 39
- Sound velocity (2915) 60
- Sound velocity damping (1888) 62
- Sound velocity deviation (2986) 60
- Sound velocity factor (1849) 71
- Sound velocity offset (1848) 71
- Square expansion coefficient (3172) 67
- SSID name (2707) 119
- SSID name (2714) 115
- Start verification (12127) 154
- Status
 - Current output 1 (0360-1) 87
- Status (12153) 156
- Subnet mask (7211) 113
- Switch output function
 - Pulse/frequency/switch output 1 to n (0481-1 to n) 97
- Switch output simulation 1 to n (0462-1 to n) 165
- Switch state
 - Pulse/frequency/switch output 1 to n (0461-1 to n) 103
- Switch state (0461) 45
- Switch state 1 to n (0463-1 to n) 166
- Switch-off delay
 - Pulse/frequency/switch output 1 to n (0465-1 to n) 103
- Switch-off value
 - Pulse/frequency/switch output 1 to n (0464-1 to n) 101
- Switch-on delay
 - Pulse/frequency/switch output 1 to n (0467-1 to n) 102
- Switch-on value
 - Pulse/frequency/switch output 1 to n (0466-1 to n) 101
- System status (12109) 159
- Telegram delay (7146) 108
- Temperature (1853) 39
- Temperature compensation (3025) 65
- Temperature damping (1886) 62
- Temperature factor (1871) 72
- Temperature offset (1870) 72
- Temperature unit (0557) 50
- Timestamp 132, 133, 134, 135
- Totalizer 1 to n control (0912-1 to n) 124
- Totalizer 1 to n failure behavior (0901-1 to n) 125
- Totalizer 1 to n operation mode (0908-1 to n) 123
- Totalizer 1 to n overflow (0910-1 to n) 42
- Totalizer 1 to n value (0911-1 to n) 42

- Trim
 - Current output 1 (0362-1) 86
- Turbulence (2907) 41
- Unit (0974) 126
- Upper range value output
 - Current output 1 (0372-1) 78
- User name (2715) 117
- User role (0005) 11
- Value 1 display (0107) 16
- Value 2 display (0108) 18
- Value 3 display (0110) 19
- Value 4 display (0109) 20
- Value current output 1 (0355-1) 163
- Value status input (1353) 42
- Value status input (1356) 162
- Velocity unit (0566) 49
- Verification ID (12141) 157
- Verification mode (12105) 154
- Verification result (12149) 156, 158
- Viscosity
 - Measuring point 1 (2932-1) 54
- Volume flow (1838) 38
- Volume flow factor (1832) 70
- Volume flow offset (1831) 69
- Volume flow unit (0553) 46
- Volume unit (0563) 47
- Web server functionality (7222) 113
- Web server language (7221) 111
- WLAN (2702) 115
- WLAN IP address (2711) 117
- WLAN MAC address (2703) 117
- WLAN mode (2717) 115
- WLAN passphrase (2706) 118
- WLAN password (2716) 117
- WLAN subnet mask (2709) 118
- Year (2846) 152
- Zero point (2921) 73
- Direct access (Parameter) 10
- Display (Submenu) 12
- Display channel 1 (Submenu) 148
- Display channel 2 (Submenu) 149
- Display channel 3 (Submenu) 149
- Display channel 4 (Submenu) 149
- Display damping (Parameter) 22
- Display interval (Parameter) 21
- Display language (Parameter) 13
- Display module (Submenu) 141
- Document
 - Design 4
 - Explanation of the structure of a parameter
 - description 6
 - Function 4
 - Symbols used 6
 - Target group 4
 - Using the document 4
- Document function 4
- E**
 - ENP version (Parameter) 139
- Enter access code (Parameter) 12
- Entire logging duration (Parameter) 147
- Expert (Menu) 172
- Extended order code 1 (Parameter) 138
- Extended order code 2 (Parameter) 138
- Extended order code 3 (Parameter) 139
- External compensation (Submenu) 64
- External device information (Parameter) 154
- External value (Parameter) 66
- F**
 - Factory settings 168
 - SI units 168
 - US units 168
 - Failure behavior current output (Parameter) 84
 - Failure current (Parameter) 85
 - Failure frequency (Parameter) 97
 - Failure mode (Parameter) 92, 96, 103, 108
 - Fieldbus writing access (Parameter) 109
 - Firmware version (Parameter) 137, 141, 142
 - Fixed current (Parameter) 76
 - Fixed density (Parameter) 66
 - Fixed reference density (Parameter) 67
 - Fixed value (Parameter) 65
 - Flow damping (Parameter) 61
 - Flow override (Parameter) 61
 - Flow velocity (Parameter) 39
 - Format display (Parameter) 14
 - Frequency output 1 to n simulation (Parameter) 163
 - Frequency output 1 to n value (Parameter) 164
 - Function
 - see Parameter
- G**
 - Gateway IP address (Parameter) 120
- H**
 - Header (Parameter) 22
 - Header text (Parameter) 23
 - Heartbeat base settings (Submenu) 150
 - Heartbeat Technology (Submenu) 150
 - Hour (Parameter) 153
- I**
 - I/O module (Parameter) 159
 - Input values (Submenu) 42
 - Installation direction (Parameter) 68
 - Installation status (Parameter) 59
 - Installation status (Submenu) 58
 - Intermediate pipe length (Parameter) 56
 - Inventory counter (Submenu) 126
 - Invert output signal (Parameter) 104
 - IP address (Parameter) 112
 - IP address domain name server (Parameter) 120
- K**
 - Kinematic viscosity unit (Parameter) 51
- L**
 - Length unit (Parameter) 51

Linear expansion coefficient (Parameter)	67
Liner thickness (Parameter)	55
Location (Parameter)	151
Locking status (Parameter)	11
Logging delay (Parameter)	146
Logging interval (Parameter)	145
Login page (Parameter)	114
Low flow cut off (Submenu)	63
Lower range value output (Parameter)	77

M

MAC address (Parameter)	112
Mainboard module (Submenu)	139
Mass flow (Parameter)	38
Mass flow factor (Parameter)	70
Mass flow offset (Parameter)	70
Mass flow unit (Parameter)	48
Mass unit (Parameter)	49
Maximum frequency value (Parameter)	94
Measured current (Parameter)	43, 86
Measured values (Parameter)	155
Measured values (Submenu)	37
Measuring mode (Parameter)	91, 95
Measuring mode current output (Parameter)	79
Measuring point (Submenu)	52
Measuring point configuration (Parameter)	53
Measuring value at maximum frequency (Parameter)	95
Measuring value at minimum frequency (Parameter)	94
Medium (Parameter)	53
Medium temperature (Parameter)	53
Menu	
Expert	172
Minimum frequency value (Parameter)	94
Minute (Parameter)	153
Modbus configuration (Submenu)	105
Modbus data map (Submenu)	110
Modbus information (Submenu)	109
Month (Parameter)	152
Mounting deviations signal path 1 to n (Submenu)	57

N

Network security (Parameter)	116
Nominal diameter (Parameter)	73

O

Off value low flow cutoff (Parameter)	64
On value low flow cutoff (Parameter)	63
Operating mode (Parameter)	88
Operating time (Parameter)	34, 131, 158
Operating time from restart (Parameter)	131
Order code (Parameter)	138
Output (Submenu)	74
Output current (Parameter)	43
Output current 1 (Parameter)	85
Output frequency (Parameter)	44, 97
Output values (Parameter)	156
Output values (Submenu)	43

P

Parameter	
Structure of description	6
Parity (Parameter)	106
Performing verification (Submenu)	151
Pipe circumference (Parameter)	54
Pipe dimensions (Parameter)	54
Pipe outer diameter (Parameter)	55
Pipe wall thickness (Parameter)	55
Plant operator (Parameter)	150
Preset value 1 to n (Parameter)	124
Previous diagnostics (Parameter)	130
Process parameters (Submenu)	60
Process variable adjustment (Submenu)	69
Process variable current output (Parameter)	75
Process variable unit 1 to n (Parameter)	122
Process variable value (Parameter)	161
Process variables (Submenu)	38
Progress (Parameter)	155
Pulse output (Parameter)	44, 93
Pulse output simulation 1 to n (Parameter)	164
Pulse scaling (Parameter)	90
Pulse value 1 to n (Parameter)	165
Pulse width (Parameter)	91
Pulse/frequency/switch output 1 to n (Submenu)	87

R

Received signal strength (Parameter)	120
Reference temperature (Parameter)	68
Reset access code (Parameter)	34
Reset access code (Submenu)	34
Reset all totalizers (Parameter)	121
Response time (Parameter)	96
Result path length / arc length (Parameter)	57
Result sensor type / sensor distance (Parameter)	56

S

Scan list register 0 to 15 (Parameter)	110
Security identification (Parameter)	116
Select antenna (Parameter)	119
Sensor (Parameter)	158
Sensor (Submenu)	37
Sensor adjustment (Submenu)	68
Sensor distance deviation (Parameter)	57
Sensor electronic module (ISEM) (Parameter)	159
Sensor electronic module (ISEM) (Submenu)	140
Separator (Parameter)	23
Serial number (Parameter)	137
Signal filter (Parameter)	56
Signal path length deviation (Parameter)	58
Signal strength (Parameter)	40, 59
Signal to noise ratio (Parameter)	40, 60
Simulation (Submenu)	160
Simulation status input (Parameter)	161
Software option overview (Parameter)	36
Sound velocity (Parameter)	39, 54, 60
Sound velocity damping (Parameter)	62
Sound velocity deviation (Parameter)	60
Sound velocity factor (Parameter)	71

- Sound velocity offset (Parameter) 71
 - Square expansion coefficient (Parameter) 67
 - SSID name (Parameter) 115, 119
 - Start verification (Parameter) 154
 - Status (Parameter) 87, 156
 - Submenu
 - Administration 32
 - Application 121
 - Calibration 73
 - Communication 104
 - Current output 1 74
 - Data logging 142
 - Device information 136
 - Diagnostic behavior 25
 - Diagnostic handling 25
 - Diagnostic list 131
 - Diagnostics 126
 - Display 12
 - Display channel 1 148
 - Display channel 2 149
 - Display channel 3 149
 - Display channel 4 149
 - Display module 141
 - External compensation 64
 - Heartbeat base settings 150
 - Heartbeat Technology 150
 - Input values 42
 - Installation status 58
 - Inventory counter 126
 - Low flow cut off 63
 - Mainboard module 139
 - Measured values 37
 - Measuring point 52
 - Modbus configuration 105
 - Modbus data map 110
 - Modbus information 109
 - Mounting deviations signal path 1 to n 57
 - Output 74
 - Output values 43
 - Performing verification 151
 - Process parameters 60
 - Process variable adjustment 69
 - Process variables 38
 - Pulse/frequency/switch output 1 to n 87
 - Reset access code 34
 - Sensor 37
 - Sensor adjustment 68
 - Sensor electronic module (ISEM) 140
 - Simulation 160
 - System 12
 - System units 45
 - System values 40
 - Totalizer 41
 - Totalizer 1 to n 121
 - Verification results 157
 - Web server 111
 - Subnet mask (Parameter) 113
 - Switch output function (Parameter) 97
 - Switch output simulation 1 to n (Parameter) 165
 - Switch state (Parameter) 45, 103
 - Switch state 1 to n (Parameter) 166
 - Switch-off delay (Parameter) 103
 - Switch-off value (Parameter) 101
 - Switch-on delay (Parameter) 102
 - Switch-on value (Parameter) 101
 - System (Submenu) 12
 - System status (Parameter) 159
 - System units (Submenu) 45
 - System values (Submenu) 40
- ## T
- Target group 4
 - Telegram delay (Parameter) 108
 - Temperature (Parameter) 39
 - Temperature compensation (Parameter) 65
 - Temperature damping (Parameter) 62
 - Temperature factor (Parameter) 72
 - Temperature offset (Parameter) 72
 - Temperature unit (Parameter) 50
 - Timestamp (Parameter) 132, 133, 134, 135
 - Totalizer (Submenu) 41
 - Totalizer 1 to n (Submenu) 121
 - Totalizer 1 to n control (Parameter) 124
 - Totalizer 1 to n failure behavior (Parameter) 125
 - Totalizer 1 to n operation mode (Parameter) 123
 - Totalizer 1 to n overflow (Parameter) 42
 - Totalizer 1 to n value (Parameter) 42
 - Trim (Parameter) 86
 - Turbulence (Parameter) 41
- ## U
- Unit (Parameter) 126
 - Upper range value output (Parameter) 78
 - User name (Parameter) 117
 - User role (Parameter) 11
- ## V
- Value 1 display (Parameter) 16
 - Value 2 display (Parameter) 18
 - Value 3 display (Parameter) 19
 - Value 4 display (Parameter) 20
 - Value current output 1 (Parameter) 163
 - Value status input (Parameter) 42, 162
 - Velocity unit (Parameter) 49
 - Verification ID (Parameter) 157
 - Verification mode (Parameter) 154
 - Verification result (Parameter) 156, 158
 - Verification results (Submenu) 157
 - Viscosity (Parameter) 54
 - Volume flow (Parameter) 38
 - Volume flow factor (Parameter) 70
 - Volume flow offset (Parameter) 69
 - Volume flow unit (Parameter) 46
 - Volume unit (Parameter) 47
- ## W
- Web server (Submenu) 111
 - Web server functionality (Parameter) 113
 - Web server language (Parameter) 111

Wizard	
Define access code	32
WLAN settings	114
WLAN (Parameter)	115
WLAN IP address (Parameter)	117
WLAN MAC address (Parameter)	117
WLAN mode (Parameter)	115
WLAN passphrase (Parameter)	118
WLAN password (Parameter)	117
WLAN settings (Wizard)	114
WLAN subnet mask (Parameter)	118
Y	
Year (Parameter)	152
Z	
Zero point (Parameter)	73



www.addresses.endress.com
