


Description of Device Parameters

Liquiphant FTL43

Vibronic
HART



1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Document structure

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.


The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating tool**.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** (→  60) they are logged in with. This document lists the submenus and their parameters that are available to the User role **Maintenance**.



The operating menu is dynamic and adapts the choice of parameters to the selected options.





For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:

1	Simulation					7
2	Navigation	 	Diagnostics → Simulation → Simulation			
3	Prerequisite		Options marked with *: The corresponding device function must be available and configured.			
4	Description		Simulates one or more process variables and/or events. Warning: - Output will reflect the simulated value or event.			
5	Selection		<ul style="list-style-type: none"> ■ Off ■ Distance ■ Level ■ Level linearized * ■ Current output ■ Diagnostic event simulation ■ Foam index * ■ Build-up index * 			
6	Factory setting		Off			

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected

1	Timestamp				
2	Navigation	 	Diagnostics → Active diagnos. → Timestamp		
3	Description		Displays the timestamp for the currently active diagnostic message.		
4	User interface		Days (d), hours (h), minutes (m), seconds (s)		
5	Factory setting				
6	Additional information		Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: - 		

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:
Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

⚠ WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.






⚠ CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.


NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of Information

-  Indicates additional information
-  Reference to documentation
-  Operation via local display
-  Operation via operating tool
-  Write-protected parameter

1.6 Documentation
























-  For an overview of the scope of the associated Technical Documentation, refer to the following:
 - *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu

Navigation

 Operating tool

Guidance	→  14
▶ Commissioning	→  14
▶ Heartbeat Technology	→  15
▶ Heartbeat Verification	→  16
▶ Loop diagnostics	→  16
▶ Process window	→  16
▶ Safety mode	→  16
▶ Proof test	→  16
▶ Import / Export	→  17
▶ Compare	→  17
Diagnostics	→  18
▶ Active diagnostics	→  18
Active diagnostics	→  18
Timestamp	→  18
Previous diagnostics	→  18
Timestamp	→  19
Operating time from restart	→  19
Operating time	→  19
▶ Diagnostic list	→  19
▶ Event logbook	→  19
▶ Minimum/maximum values	→  20
Minimum fork frequency	→  20
Maximum fork frequency	→  20

Minimum temp. of sensor electronics	→ 20
Maximum temp. of sensor electronics	→ 21
Minimum terminal voltage	→ 21
Maximum terminal voltage	→ 21
Minimum electronics temperature	→ 21
Maximum electronics temperature	→ 21
► Simulation	→ 22
Simulation	→ 22
Frequency simulation value	→ 22
Fork state simulation value	→ 23
Diagnostic event simulation	→ 23
Value current output	→ 23
► Heartbeat Technology	→ 24
► Heartbeat Verification	→ 24
Date/time Heartbeat Verification	→ 24
Operating time (Verification)	→ 24
Verification result	→ 24
Status	→ 25
► Frequency history	→ 25
Date 1 ... 16	→ 25
Sensor frequency 1 ... 16	→ 25
► Loop diagnostics	→ 26
Rebuild baseline	→ 26
Tolerated deviation +/-	→ 26
Baseline status	→ 26


























Loop diagnostics	→ 27
Terminal voltage 1	→ 27
Clamping voltage lower threshold	→ 27
Clamping voltage upper threshold	→ 27
806 Event delay	→ 27
► Process window	→ 28
Frequency of vibrating fork	→ 28
High alert value	→ 28
901 Alarm delay	→ 28
901 Process alert frequency too high	→ 29
Low alert value	→ 29
900 Alarm delay	→ 29
900 Process alert frequency too low	→ 29
► Proof test	→ 30
Date/time proof test	→ 30
Operating time of proof test on device	→ 30
► Diagnostic settings	→ 31
► Properties	→ 31
49 Corrosion warning	→ 31
Upper warning frequency	→ 31
825 Electronics temperature	→ 31
826 Temperature of sensor electronics	→ 32
946 Advanced sensor monitoring	→ 32
806 Diagnostic behavior	→ 32

806 Event category	→ 33
806 Event delay	→ 33
► Configuration	→ 33
► Sensor	→ 33
49 Diagnostic behavior	→ 33
49 Event category	→ 34
► Process	→ 34
806 Diagnostic behavior	→ 34
806 Event category	→ 34
826 Diagnostic behavior	→ 35
826 Event category	→ 35
900 Diagnostic behavior	→ 35
900 Event category	→ 36
901 Diagnostic behavior	→ 36
901 Event category	→ 36
Application	→ 37
► Measuring units	→ 37
Temperature unit	→ 37
► Measured values	→ 37
Frequency of vibrating fork	→ 37
State of vibrating fork	→ 37
Receiving signal strength of fork	→ 38
Temperature of sensor electronics	→ 38
Terminal voltage 1	→ 38
Terminal current	→ 38

Electronics temperature	→ 38
Output current	→ 39
► Sensor	→ 39
► Basic settings	→ 39
Mode of medium detection	→ 39
Mode of operation	→ 39
Safety function	→ 40
Density setting	→ 40
Damping	→ 40
Switching delay uncovered to covered	→ 41
Customer delay to covered	→ 41
Switching delay covered to uncovered	→ 41
Customer delay to uncovered	→ 42
► Sensor calibration	→ 42
Lower switching point at density	→ 42
Upper switching point at density	→ 42
Frequency at delivery status	→ 43
Upper warning frequency	→ 43
Upper alarm frequency	→ 43
► Stored frequency	→ 44
Stored uncovered frequency	→ 44
Stored covered frequency	→ 44
► Current output	→ 44
Assign PV	→ 44
Current range output	→ 45

Lower range value output	→ 45
Upper range value output	→ 45
Failure behavior current output	→ 46
Failure current	→ 46
Output current	→ 46
Terminal current	→ 46
► HART output	→ 47
► Configuration	→ 47
HART address	→ 47
HART short tag	→ 47
Device tag	→ 47
No. of preambles	→ 48
Loop current mode	→ 48
► HART output	→ 48
Assign PV	→ 48
Primary variable (PV)	→ 49
Assign SV	→ 49
Secondary variable (SV)	→ 49
Assign TV	→ 49
Tertiary variable (TV)	→ 50
Assign QV	→ 50
Quaternary variable (QV)	→ 50
► Burst configuration 1	→ 51
Burst mode 1	→ 51
Burst command 1	→ 51

Burst variable 0	→ 51
Burst variable 1	→ 52
Burst variable 2	→ 52
Burst variable 3	→ 53
Burst variable 4	→ 53
Burst variable 5	→ 54
Burst variable 6	→ 54
Burst variable 7	→ 55
Burst trigger mode	→ 55
Burst trigger level	→ 56
Min. update period	→ 56
Max. update period	→ 56
► Information	→ 56
Device ID	→ 56
Device type	→ 57
Device revision	→ 57
HART short tag	→ 57
HART revision	→ 57
HART descriptor	→ 58
HART message	→ 58
HART date code	→ 58
System	→ 59
► Device management	→ 59
Device tag	→ 59
Locking status	→ 59


Configuration counter	→  60
Reset device	→  60
► User management	→  60
User role	→  60
Change user role	→  61
Password	→  61
Enter access code	→  61
Status password entry	→  61
Define password	→  62
New password	→  62
Confirm new password	→  62
Status password entry	→  61
Change password	→  62
Old password	→  63
New password	→  62
Confirm new password	→  62
Status password entry	→  61
Delete password	→  63
Old password	→  63
Status password entry	→  61
Forgot password?	→  63
Reset password	→  63
Status password entry	→  61
► Bluetooth configuration	→  64
Bluetooth activation	→  64

► Geolocation	→ 64
Process Unit Tag	→ 64
Location Description	→ 64
Longitude	→ 65
Latitude	→ 65
Altitude	→ 65
Location method	→ 65
► Information	→ 66
Device name	→ 66
Manufacturer	→ 66
Serial number	→ 66
Order code	→ 67
Firmware version	→ 67
Hardware version	→ 67
Extended order code 1 ... 3	→ 67
Checksum	→ 68
► Software configuration	→ 72
CRC device configuration	→ 72
Stored CRC device configuration	→ 73
Timestamp stored CRC device config.	→ 73
Activate SW option	→ 73
Software option overview	→ 73

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of guided wizards and cross-thematic special functions.

Navigation  Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - Loop diagnostics
 - Process window
- Safety mode
- Proof test
- Import / Export
- Compare

3.1.2 Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

WARNING

If the wizard is canceled before all the necessary parameters have been configured, any settings already set are saved.

The device may be in an undefined state!

- ▶ Reset the device to factory settings.

Navigation

Guidance → Commissioning

Parameters for the "Commissioning" wizard

The following parameters are configured in this wizard:

- **Device identification**
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - HART short tag
 - HART date code
 - HART descriptor
 - HART message
 - HART address
- **Measurement adjustments**
 - Temperature unit
 - Mode of medium detection
 - 946 Advanced sensor monitoring
 - Mode of operation
 - Safety function
 - Density setting
 - Switching delay covered to uncovered
 - Customer delay to uncovered
 - Switching delay uncovered to covered
 - Customer delay to covered
 - 49 Corrosion warning
 - Frequency of vibrating fork
 - Stored covered frequency
 - Frequency at delivery status
 - Stored uncovered frequency
- **Output settings**
 - Process variable output current
 - Current range output
 - Lower range value output
 - Upper range value output
 - Failure behavior current output
 - Failure current
 - Loop current mode
 - Assign HART variables?
 - Assign PV
 - Assign SV
 - Assign TV
 - Assign QV


3.1.3 Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application




Special Documentation on Heartbeat Technology is available via the Internet:
www.endress.com → Download

Navigation  Guidance → Heartbeat Techn.


Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif.


Loop diagnostics

Using this wizard, changes in the current-voltage loop characteristics (baseline) can be used to detect unwanted installation anomalies such as creep currents caused by terminal corrosion or a deteriorating power supply that can lead to an incorrect 4-20 mA measured value.

Navigation  Guidance → Heartbeat Techn. → Loop diagn.

Process window

This wizard can be used to monitor the sensor frequency for frequencies that are too low or too high. This can be used for early detection of buildup or corrosion.

Navigation  Guidance → Heartbeat Techn. → Process window

3.1.4 Safety mode

The write protection guards the device settings against overwriting. In addition, it is recommended for safety applications to confirm the safety relevant device settings. This ensures that the correct values have been entered and downloaded to device.

This input can be used as the confirmation sequence instead of manual checklists. After the safety relevant device settings have been confirmed, the device is marked with the property Safety-locked. This indicates that the safety relevant parameter settings have been checked and evaluated as correct.

To unlock the safety locking the sequence needs to be restarted. The safety locking is deactivated when the safety unlocking code (= safety locking code) is entered.

Navigation  Guidance → Safety mode

3.1.5 Proof test

The proof test will simulate the current output. The safety function is not guaranteed during proof test. Alternative process control in manual must be taken to ensure process safety.

Note: It is only possible to perform a proof test when the device has no alarm and the hardware write protection switch is off.

Note: Only available in "Mode of operation" "Level limit detection".

Navigation   Guidance → Proof test

3.1.6 Import / Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create documentation

Device documentation can be saved in PDF format under **Create documentation**. This device documentation contains the following general device information:

- Information on device parameters
- Event list
- Diagnostic list

Navigation  Guidance → Import / Export

3.1.7 Compare

Compare datasets

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import / Export
- Datasets with the configuration currently in the device

Navigation  Guidance → Compare


3.2 Diagnostics

Navigation  Diagnostics

3.2.1 Active diagnostics

Navigation  Diagnostics → Active diagnos.

Active diagnostics


Navigation  Diagnostics → Active diagnos. → Active diagnos.

Description Displays the currently active diagnostic message.
If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.

User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure


Timestamp

Navigation  Diagnostics → Active diagnos. → Timestamp

Description Displays the timestamp for the currently active diagnostic message.

User interface Days (d), hours (h), minutes (m), seconds (s)

Previous diagnostics


Navigation  Diagnostics → Active diagnos. → Prev.diagnostics

Description Displays the diagnostic message for the last diagnostic event that has ended.


User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure


Timestamp

Navigation	 Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time from restart

Navigation	 Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	 Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
User interface	Days (d), hours (h), minutes (m), seconds (s)


3.2.2 Diagnostic list

Navigation   Diagnostics → Diagnostic list

3.2.3 Event logbook

Navigation   Diagnostics → Event logbook

Clear event list


Navigation	 Diagnostics → Event logbook → Clear event list
Description	Delete all entries of the event list.

Selection	<ul style="list-style-type: none"> ■ Cancel ■ Clear data
Factory setting	Cancel
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert


3.2.4 Minimum/maximum values

Navigation   Diagnostics → Min/max val.


Minimum fork frequency

Navigation	 Diagnostics → Min/max val. → Min. frequency
Description	Minimum or maximum measured fork frequency.
User interface	Signed floating-point number


Maximum fork frequency

Navigation	 Diagnostics → Min/max val. → Max. frequency
Description	Minimum or maximum measured fork frequency.
User interface	Signed floating-point number


Minimum temp. of sensor electronics

Navigation	 Diagnostics → Min/max val. → Min.TSensElectr.
Description	Minimum or maximum measured temperature of sensor electronics.
User interface	Signed floating-point number


Maximum temp. of sensor electronics

Navigation	 Diagnostics → Min/max val. → Max.TSensElectr.
Description	Minimum or maximum measured temperature of sensor electronics.
User interface	Signed floating-point number


Minimum terminal voltage

Navigation	 Diagnostics → Min/max val. → Min.term.volt.
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V


Maximum terminal voltage

Navigation	 Diagnostics → Min/max val. → Max.term.voltage
Description	Minimum or maximum measured terminal (supply) voltage.
User interface	0.0 to 50.0 V

Minimum electronics temperature

Navigation	 Diagnostics → Min/max val. → Min.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Maximum electronics temperature

Navigation	 Diagnostics → Min/max val. → Max.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

3.2.5 Simulation

Navigation  Diagnostics → Simulation

Simulation

Navigation  Diagnostics → Simulation → Simulation

Description By activating the simulation, the following can be simulated:

- State of vibrating fork
- Sensor frequency
- Current output
- Diagnostic event simulation


The simulation can affect the output current.

Selection

- Off
- State of vibrating fork
- Sensor frequency
- Current output
- Diagnostic event simulation

Factory setting Off

Frequency simulation value

Navigation  Diagnostics → Simulation → Freq. simulation

Description Enter the frequency value to be simulated.


Note:


Prerequisite for the simulation to have an effect on the output:
Select "Sensor frequency" in the "Mode of operation" parameter in the Application > Sensor > Basic settings menu.

The simulated frequency value has no effect on the displayed state of the vibrating fork ("Fork uncovered", "Fork covered").


User entry 0 to 10 000 Hz

Factory setting 0 Hz


Fork state simulation value


Navigation	 Diagnostics → Simulation → Fork. simul.val.
Description	Select the state of the vibrating fork to be simulated. Note: Prerequisite for the simulation to have an effect on the output: Select "Level limit detection" in the "Mode of operation" parameter in the Application > Sensor > Basic settings menu. The simulated state of the vibrating fork has no affect on the displayed sensor frequency.
Selection	<ul style="list-style-type: none"> ■ Fork covered ■ Fork uncovered
Factory setting	Fork uncovered

Diagnostic event simulation


Navigation	 Diagnostics → Simulation → Diagnostic event
Description	Select the diagnostic event to be simulated. Note: To terminate the simulation, select "Off".
Selection	<ul style="list-style-type: none"> ■ Off ■ Drop-down list of diagnostic events
Factory setting	Off


Value current output


Navigation	 Diagnostics → Simulation → Current output
Description	Defines the value of the simulated output current.
User entry	3.59 to 23 mA
Factory setting	3.59 mA


3.2.6 Heartbeat Technology

Navigation  Diagnostics → Heartbeat Techn.


Heartbeat Verification

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif.


Date/time Heartbeat Verification

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification
Description	Date and time of last Heartbeat Verification. This value is updated with every Heartbeat verification. Note: If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.
User interface	Character string comprising numbers, letters and special characters
Factory setting	01.01.1970 00:00:00


Operating time (Verification)

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time
Description	Value of the operating hours counter at the time of verification.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Verific. result
Description	Result of Heartbeat Verification.
User interface	<ul style="list-style-type: none"> ■ Not done ■ Passed ■ Not done ■ Failed
Factory setting	Not done

Status


Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status
Description	Shows the actual status.
User interface	<ul style="list-style-type: none"> ▪ Done ▪ Busy ▪ Failed ▪ Not done
Factory setting	Not done

Frequency history


List of the last 16 sensor frequencies saved in the previous Heartbeat Verification.

Navigation  Diagnostics → Heartbeat Techn. → Freq. history


Date 1 ... 16


Navigation	 Diagnostics → Heartbeat Techn. → Freq. history → Date 1
User interface	Character string comprising numbers, letters and special characters
Factory setting	1970-01-01 00:00:00


Sensor frequency 1 ... 16

Navigation	 Diagnostics → Heartbeat Techn. → Freq. history → Frequency 1
User interface	Signed floating-point number
Factory setting	0 Hz

Loop diagnostics

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn.

Rebuild baseline 

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Reb. baseline


Description Notice
 The current output is simulated.
 Bridge the PLC or take other appropriate measures to prevent an erroneous triggering of alarm messages or changes in the control loop behavior.
 The baseline should be rebuilt if planned changes have been made in the loop.

Selection

- No
- Yes

Factory setting No

Tolerated deviation +/- 


Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Toler. deviation

Description A value should be chosen to ensure that normal voltage deviations do not lead to unwanted messages.

Default
 1.5 V DC

User entry 0.5 to 3.0 V

Baseline status 

Navigation  Diagnostics → Heartbeat Techn. → Loop diagn. → Baseline status

Description "Failed"
 Means, baseline is not available or creation not possible.
 "Success"
 Baseline is available.

User interface

- Failed
- Success

Factory setting Failed

Loop diagnostics



Navigation	Diagnostics → Heartbeat Techn. → Loop diagn. → Loop diagn.
Description	Enable/disable loop diagnostics. Note: If the function is disabled, there is no analysis and no event message.
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable
Factory setting	Disable
Additional information	The parameter is visible if the baseline has been created.

Terminal voltage 1

Navigation	Diagnostics → Heartbeat Techn. → Loop diagn. → Terminal volt. 1
Description	Shows the current terminal voltage that is applied at the output
User interface	0.0 to 50.0 V

Clamping voltage lower threshold

Navigation	Diagnostics → Heartbeat Techn. → Loop diagn. → Lower threshold
User interface	0.0 to 50.0 V

Clamping voltage upper threshold

Navigation	Diagnostics → Heartbeat Techn. → Loop diagn. → Upper threshold
User interface	0.0 to 50.0 V

806 Event delay




Navigation	Diagnostics → Heartbeat Techn. → Loop diagn. → 806 Event delay
Description	Displays how long the triggering status must be present until an event message is issued. Used to filter out short-term signal interference.

User entry 0 to 60 s

Factory setting 1 s

Process window

Navigation  Diagnostics → Heartbeat Techn. → Process window

Frequency of vibrating fork

Navigation  Diagnostics → Heartbeat Techn. → Process window → Fork frequency

Description Displays the actual frequency of the vibrating fork.

User interface 0 to 10 000 Hz

High alert value

Navigation  Diagnostics → Heartbeat Techn. → Process window → High alert value

Description Enter the upper limit value.
If this limit value is exceeded, an event is generated. There is no hysteresis.

User entry 0 to 2 000 Hz

Factory setting 0 Hz

901 Alarm delay

Navigation  Diagnostics → Heartbeat Techn. → Process window → 901Alarm delay

Description Enter the duration (integer) that the triggering status must be active before the alarm is generated.
A warning is generated.

User entry 0 to 300 s

Factory setting 60 s

901 Process alert frequency too high

Navigation	Diagnostics → Heartbeat Techn. → Process window → 901 Freq. high
Description	Note: With the MIN safety function, no event for "Process alert frequency too high" is triggered if the fork is uncovered.
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable
Factory setting	Disable

Low alert value

Navigation	Diagnostics → Heartbeat Techn. → Process window → Low alert value
Description	Enter the lower limit value. If this limit value is undercut, an event is generated. There is no hysteresis.
User entry	0 to 2 000 Hz
Factory setting	0 Hz

900 Alarm delay

Navigation	Diagnostics → Heartbeat Techn. → Process window → 900Alarm delay
Description	Enter the duration (integer) that the triggering status must be active before the alarm is generated. A warning is generated.
User entry	0 to 300 s
Factory setting	60 s

900 Process alert frequency too low

Navigation	Diagnostics → Heartbeat Techn. → Process window → 900 Freq. too low
Description	Note: With the MAX safety function, no event for "Process alert frequency too low" is triggered if the fork is covered.
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable

Factory setting Disable

3.2.7 **Proof test**

Navigation  Diagnostics → Proof test

Date/time proof test

Navigation  Diagnostics → Proof test → Date/time

Description This value is updated with every proof test and with inspector decision „Passed“.

User interface Character string comprising numbers, letters and special characters

Factory setting 01.01.1970 00:00:00

Operating time of proof test on device

Navigation  Diagnostics → Proof test → Op.TimeProofTest

Description Displays operating time when the proof test was activated on site at the device.
Value is not displayed in the proof test protocol.


User interface Character string comprising numbers, letters and special characters

Factory setting


3.2.8 Diagnostic settings

Navigation  Diagnostics → Diag. settings

Properties

Navigation  Diagnostics → Diag. settings → Properties

49 Corrosion warning

Navigation  Diagnostics → Diag. settings → Properties → 49Corr. warning


Description Enable or disable the corrosion warning.
The corrosion warning is set if the sensor frequency exceeds frequency at delivery status by 5 %.
If turned on, the event category can be set in menu -> Diagnostics -> Diagnostic settings -> Configuration
The diagnostic behaviour can be changed to "Logbook entry only" in the same menu.

Selection

- Off
- On

Factory setting On

Upper warning frequency


Navigation  Diagnostics → Diag. settings → Properties → U. warning freq.

Description If the sensor frequency is currently higher than the upper warning frequency, a warning is generated. The switch output remains in the current state. It is recommended to remove the sensor and check for corrosion or abrasion.

User interface 0 to 10 000 Hz

Factory setting Device-specific

825 Electronics temperature

Navigation  Diagnostics → Diag. settings → Properties → 825Electr. temp


Description Activates the monitoring of the temperature of the main electronics.
The limit values are fixed.

Selection

- Off
- On

Factory setting On

826 Temperature of sensor electronics


Navigation  Diagnostics → Diag. settings → Properties → 826TSensElectr.

Description Displays the actual temperature of the main electronics.

Selection ■ Off
 ■ On

Factory setting On

946 Advanced sensor monitoring



Navigation  Diagnostics → Diag. settings → Properties → 946Adv.Sens.Mon.

Description Enable/disable advanced sensor monitoring to detect high external vibrations and other sensor errors (e.g. caused by pumps, agitators, turbulent flows, high flow rates, etc.).

Selection ■ Enable
 ■ Disable

Factory setting Enable

806 Diagnostic behavior

Navigation   Diagnostics → Diag. settings → Properties → 806Diag. behav.

Description Select event behavior.
 "Logbook entry only": no digital or analog transmission of the message.
 "Warning": Current output unchanged. Message is output digitally (default).
 If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection ■ Warning
 ■ Logbook entry only

Factory setting Warning

806 Event category

Navigation Diagnostics → Diag. settings → Properties → 806Event categ.

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Maintenance required (M)

806 Event delay

Navigation Diagnostics → Diag. settings → Properties → 806 Event delay

Description Displays how long the triggering status must be present until an event message is issued. Used to filter out short-term signal interference.

User entry 0 to 60 s

Factory setting 1 s

Configuration

Navigation Diagnostics → Diag. settings → Configuration

Sensor

Navigation Diagnostics → Diag. settings → Configuration → Sensor

49 Diagnostic behavior

Navigation Diagnostics → Diag. settings → Configuration → Sensor → 49Diag. behav.

Description Select event behavior.

"Logbook entry only": no digital or analog transmission of the message.


"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning



49 Event category

Navigation  Diagnostics → Diag. settings → Configuration → Sensor → 49Event categ.



- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Maintenance required (M)

Process

Navigation   Diagnostics → Diag. settings → Configuration → Process

806 Diagnostic behavior

Navigation   Diagnostics → Diag. settings → Configuration → Process → 806Diag. behav.

Description

Select event behavior.

"Logbook entry only": no digital or analog transmission of the message.



"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning

806 Event category


Navigation   Diagnostics → Diag. settings → Configuration → Process → 806Event categ.

Description Select category for diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Maintenance required (M)

826 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Configuration → Process → 826Diag. behav.

Description

Select event behavior.

"Logbook entry only": no digital or analog transmission of the message.


"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning



826 Event category

Navigation  Diagnostics → Diag. settings → Configuration → Process → 826Event categ.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

900 Diagnostic behavior

Navigation   Diagnostics → Diag. settings → Configuration → Process → 900Diag. behav.

Description

Select event behavior.

"Logbook entry only": no digital or analog transmission of the message.



"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning



900 Event category

Navigation   Diagnostics → Diag. settings → Configuration → Process → 900Event categ.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Maintenance required (M)

901 Diagnostic behavior

Navigation   Diagnostics → Diag. settings → Configuration → Process → 901Diag. behav.

Description

Select event behavior.

"Logbook entry only": no digital or analog transmission of the message.



"Warning": Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning

901 Event category

Navigation   Diagnostics → Diag. settings → Configuration → Process → 901Event categ.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Maintenance required (M)


3.3 Application

Navigation  Application

3.3.1 Measuring units

Navigation  Application → Measuring units


Temperature unit

Navigation	 Application → Measuring units → Temperature unit						
Description	Select the temperature unit.						
Selection	<table> <tr> <td><i>SI units</i></td> <td><i>US units</i></td> </tr> <tr> <td>■ °C</td> <td>°F</td> </tr> <tr> <td>■ K</td> <td></td> </tr> </table>	<i>SI units</i>	<i>US units</i>	■ °C	°F	■ K	
<i>SI units</i>	<i>US units</i>						
■ °C	°F						
■ K							
Factory setting	°C						


3.3.2 Measured values

Navigation  Application → Measured values


Frequency of vibrating fork

Navigation	 Application → Measured values → Fork frequency
Description	Displays the actual frequency of the vibrating fork.
User interface	0 to 10 000 Hz


State of vibrating fork

Navigation	 Application → Measured values → Fork state
Description	Displays the actual status of the vibrating fork.
User interface	<ul style="list-style-type: none"> ■ Fork covered ■ Fork uncovered


Receiving signal strength of fork

Navigation	 Application → Measured values → Sign.Str.Fork
Description	Displays the receiving signal strength of the vibrating fork to the sensor electronics in percent. The value indicates how much oscillation energy comes back from the vibrating fork. Energy loss occurs due to e.g. viscous medium, external vibrations or mechanical tensioning of the sensor.
User interface	-200 to 1 000 %


Temperature of sensor electronics

Navigation	 Application → Measured values → T sens.electr.
Description	Displays the actual temperature of the main electronics.
User interface	Signed floating-point number


Terminal voltage 1

Navigation	 Application → Measured values → Terminal volt. 1
Description	Shows the current terminal voltage that is applied at the output
User interface	0.0 to 50.0 V

Terminal current

Navigation	 Application → Measured values → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA

Electronics temperature

Navigation	 Application → Measured values → Electronics temp
Description	Displays the current temperature of the main electronics.

User interface Signed floating-point number

Output current

Navigation  Application → Measured values → Output curr.

Description Displays the value currently calculated for the current output

User interface 3.59 to 23 mA

3.3.3 Sensor

Navigation   Application → Sensor

Basic settings

Navigation  Application → Sensor → Basic settings

Mode of medium detection

Navigation  Application → Sensor → Basic settings → Medium detection


Description Select the mode of medium detection.

Selection

- Standard
- Detect foam
(only visible with order option Heartbeat Verification + Monitoring)
- Ignore foam
(only visible with order option Heartbeat Verification + Monitoring)

Factory setting Standard

Mode of operation

Navigation  Application → Sensor → Basic settings → Mode of operat.

Description Select mode of operation.
 Level limit detection: Switching mode, output is either 8 mA (demand) or 16 mA (good).
 Sensor frequency : Continuous mode, output between 4 mA and 20 mA proportional to frequency of vibrating fork.

Selection ■ Level limit detection
 ■ Sensor frequency

Factory setting Level limit detection

Safety function

Navigation  Application → Sensor → Basic settings → Safety function

Description Select "MIN" or "MAX" as safety function.
 - Select "MIN" for dry-run protection.
 - Select "MAX" for overflow protection.

Selection ■ MIN
 ■ MAX

Factory setting MAX

Density setting

Navigation  Application → Sensor → Basic settings → Density setting

Description Select the density of the medium.
 ■ > 0.4 g/cm³ (> 25.0 lb/ft³)
 For liquids with a density of 0.4 ... 0.6 g/cm³ (25.0 ... 37.5 lb/ft³).
 ■ > 0.5 g/cm³ (> 31.2 lb/ft³)
 For liquids with a density of 0.5 ... 0.8 g/cm³ (31.2 ... 49.9 lb/ft³).
 ■ > 0.7 g/cm³ (> 43.7 lb/ft³)
 Standardsetting for liquids with a density > 0.7 g/cm³ (> 43.7 lb/ft³).

Selection ■ > 0.4 g/cm³ (> 25.0 lb/ft³)
 ■ > 0.5 g/cm³ (> 31.2 lb/ft³)
 ■ > 0.7 g/cm³ (> 43.7 lb/ft³)

Factory setting Depends on the order option

Damping


Navigation  Application → Sensor → Basic settings → Damping

Description Enter a value between 0 s and 999 s.
 Damping reduces the effect of fluctuations in the measured value on the output signal.
 Damping has an effect only on mode of operation "Sensor frequency".
 It does not affect the mode of operation "Level limit detection" and "State of vibrating fork"
 ("Fork uncovered " or "Fork covered ").

User entry 0 to 999 s

Factory setting 1 s

Switching delay uncovered to covered

Navigation  Application → Sensor → Basic settings → Delay to covered

Description Select the delay time for switching from "Fork uncovered " to "Fork covered ".
The value determines the delay time until the switching output switches after a change of state is detected.


Choose between predefined values or select "Customer specific" to enter an integer between 1 s and 60 s.

Selection

- 0.25 s
- 0.50 s
- 1.00 s
- 1.50 s
- 5.00 s
- Customer specific

Factory setting Depends on the order option

Customer delay to covered

Navigation  Application → Sensor → Basic settings → Cust. delay cov.

Description Enter the delay time for switching from "Fork uncovered " to "Fork covered ".
The value determines the delay time until the switching output switches after a change of state is detected.
Enter an integer between 1 s and 60 s.

User entry 1 to 60 s

Factory setting 1 s

Switching delay covered to uncovered

Navigation  Application → Sensor → Basic settings → Delay to uncov.

Description Select the delay time for switching from "Fork covered " to "Fork uncovered ".
The value determines the delay time until the switching output switches after a change of state is detected.

Choose between predefined values or select "Customer specific" to enter an integer between 1 s and 60 s.

Selection	<ul style="list-style-type: none"> ■ 0.25 s ■ 0.50 s ■ 1.00 s ■ 1.50 s ■ 5.00 s ■ Customer specific
Factory setting	Depends on the order option

Customer delay to uncovered


Navigation	Application → Sensor → Basic settings → Cust. delay unc.
Description	<p>Enter the delay time for switching from "Fork covered " to "Fork uncovered ".</p> <p>The value determines the delay time until the switching output switches after a change of state is detected.</p> <p>Enter an integer between 1 s and 60 s.</p>
User entry	1 to 60 s
Factory setting	1 s

Sensor calibration

Navigation Application → Sensor → Sensor cal.

Lower switching point at density


Navigation	Application → Sensor → Sensor cal. → Lower sw. point
Description	Displays the sensor frequency at which the status of the vibrating fork changes to "Fork covered " (depending on the density selected).
User interface	0 to 2 000 Hz
Factory setting	Depends on density setting

Upper switching point at density


Navigation	Application → Sensor → Sensor cal. → Upper sw. point
Description	Displays the sensor frequency at which the status of the vibrating fork changes to "Fork uncovered " (depending on the density selected).

User interface	0 to 2 000 Hz
Factory setting	Depends on density setting


Frequency at delivery status

Navigation	 Application → Sensor → Sensor cal. → Freq. delivery
Description	Sensor frequency at delivery status. The individually determined oscillation frequency in air is in the range of 900 to 1 200 Hz.
User interface	0 to 10 000 Hz
Factory setting	Device-specific

Upper warning frequency

Navigation	 Application → Sensor → Sensor cal. → U. warning freq.
Description	If the sensor frequency is currently higher than the upper warning frequency, a warning is generated. The switch output remains in the current state. It is recommended to remove the sensor and check for corrosion or abrasion.
User interface	0 to 10 000 Hz
Factory setting	Device-specific


Upper alarm frequency

Navigation	 Application → Sensor → Sensor cal. → Upper alarm f.
Description	If the actual sensor frequency is higher than the upper alarm frequency, then an alarm is generated. The switching output switches to the fail-safe state.
User interface	0 to 10 000 Hz
Factory setting	Device-specific

Stored frequency

Navigation  Application → Sensor → Stored frequency

Stored uncovered frequency

Navigation  Application → Sensor → Stored frequency → Stored uncov. f.

Description The actual sensor frequency can be saved in this parameter.
This is only possible when the fork is uncovered.
The value is displayed in the Heartbeat Technology verification report.

Note:
Save the frequency in a reproducible state in order to use it as a reference for further/
future analyses.

User interface 0 to 10 000 Hz

Stored covered frequency



Navigation  Application → Sensor → Stored frequency → Stored cov. f.

Description The actual sensor frequency can be saved in this parameter.
This is only possible when the fork is covered.
The value is displayed in the Heartbeat Technology verification report.

Note:
Save the frequency in a reproducible state in order to use it as a reference for further/
future analyses.

User interface 0 to 10 000 Hz

3.3.4 Current output

Navigation   Application → Curr.output

Assign PV

Navigation  Application → Curr.output → Assign PV

Description Assign a measured variable to the primary dynamic variable (PV).
Additional information:
The assigned measured variable is also used by the current output.

User interface ▪ Level limit detection
 ▪ Sensor frequency

Factory setting Level limit detection

Current range output

Navigation  Application → Curr.output → Current range

Description Defines the current range used to transmit the measured or calculated value. In brackets are indicated the “low saturation value” and the “high saturation value”. If Measured value \leq “low saturation”, the output current is set to “low saturation”. If Measured value \geq “high saturation”, the output current is set to “high saturation”.
 Note:
 Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection ▪ 4...20 mA (4...20.5 mA)
 ▪ 4...20 mA NE (3.8...20.5 mA)
 ▪ 4...20 mA US (3.9...20.8 mA)

Factory setting 4...20 mA NE (3.8...20.5 mA)

Additional information Only visible if Sensor frequency is selected as the Mode of operation.

Lower range value output

Navigation  Application → Curr.output → Low.range outp

Description Depending on which variable has been selected as Process variable output current, specify the relevant start of the measuring range (4 mA).

User entry Signed floating-point number

Factory setting Depends on the device setting

Upper range value output

Navigation  Application → Curr.output → Upp.range outp

Description Depending on which variable has been selected as Process variable output current, specify the relevant end of the measuring range (20 mA).

User entry Signed floating-point number

Factory setting Depends on the device setting

Failure behavior current output


Navigation	Application → Curr.output → Failure behav.
Description	<p>Defines which current the output assumes in the case of an error.</p> <p>Min: < 3.6 mA</p> <p>Max: >21.5 mA</p> <p>Note: The hardware DIP Switch for alarm current (if available) has priority over software setting.</p>
Selection	<ul style="list-style-type: none"> ■ Min. ■ Max.
Factory setting	Min.

Failure current


Navigation	Application → Curr.output → Failure current
Description	Enter current output value in alarm condition
User entry	21.5 to 23 mA
Factory setting	22.5 mA

Output current

Navigation	Application → Curr.output → Output curr.
Description	Displays the value currently calculated for the current output
User interface	3.59 to 23 mA

Terminal current

Navigation	Application → Curr.output → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA


3.3.5 HART output

Navigation  Application → HART output


Configuration

Navigation  Application → HART output → Configuration


HART address

Navigation	 Application → HART output → Configuration → HART address
Description	Enter the address to exchange data via the HART protocol.
User entry	0 to 63
Factory setting	0

HART short tag

Navigation	 Application → HART output → Configuration → HART short tag
Description	Defines the short tag for the measuring point. Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Character string comprising numbers, letters and special characters (8)
Factory setting	Customized

Device tag

Navigation	 Application → HART output → Configuration → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	Customized

No. of preambles



Navigation Application → HART output → Configuration → No. of preambles

Description Defines the number of preambles in the HART telegram

User entry 5 to 20

Factory setting 5

Loop current mode



Navigation Application → HART output → Configuration → Loop curr mode

Description If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.

Selection

- Disable
- Enable

Factory setting Enable

HART output

Navigation Application → HART output → HART output

Assign PV

Navigation Application → HART output → HART output → Assign PV


Description Assign a measured variable to the primary dynamic variable (PV).
Additional information:
The assigned measured variable is also used by the current output.

User interface


- Level limit detection
- Sensor frequency

Factory setting Level limit detection


Primary variable (PV)

Navigation	 Application → HART output → HART output → Primary var (PV)
Description	Shows the current measured value of the primary dynamic variable (PV)
User interface	4 to 23 mA


Assign SV

Navigation	 Application → HART output → HART output → Assign SV
Description	Assign a measured variable to the second dynamic variable (SV).
Selection	<ul style="list-style-type: none"> ■ Level limit detection ■ Sensor frequency ■ State of vibrating fork ■ Sensor temperature ■ Electronics temperature ■ Measured current[*] ■ Terminal voltage[*] ■ Not used
Factory setting	Sensor frequency

Secondary variable (SV)

Navigation	 Application → HART output → HART output → Second.var(SV)
Description	Shows the current measured value of the secondary dynamic variable (SV)
User interface	0 to 10 000 Hertz

Assign TV


Navigation	 Application → HART output → HART output → Assign TV
Description	Assign a measured variable to the tertiary dynamic variable (TV).
Selection	<ul style="list-style-type: none"> ■ Level limit detection ■ Sensor frequency ■ State of vibrating fork ■ Sensor temperature

* Visibility depends on order options or device settings

- Electronics temperature
- Measured current^{*}
- Terminal voltage^{*}
- Not used

Factory setting State of vibrating fork

Tertiary variable (TV)

Navigation  Application → HART output → HART output → Tertiary var(TV)


Description Shows the current measured value of the tertiary (third) dynamic variable (TV)

User interface 0 to 1.0 ManufacturerNoUnit

Factory setting 0 ManufacturerNoUnit

Assign QV




Navigation  Application → HART output → HART output → Assign QV

Description Assign a measured variable to the quaternary dynamic variable (QV).

- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current^{*}
 - Terminal voltage^{*}
 - Not used

Factory setting Sensor temperature

Quaternary variable (QV)



Navigation  Application → HART output → HART output → Quaterna.var(QV)


Description Shows the current measured value of the quaternary (fourth) dynamic variable (QV)


User interface Signed floating-point number

* Visibility depends on order options or device settings

Burst configuration 1

Navigation   Application → HART output → Burst config. 1

Burst mode 


Navigation  Application → HART output → Burst config. 1 → Burst mode 1


Description Switch HART burst mode for burst message on

Selection

- Off
- On

Factory setting Depends on the order option

Burst command 


Navigation  Application → HART output → Burst config. 1 → Burst command 1


Description Select the HART command that is sent to the HART master

Selection

- Primary variable (PV)
- Loop Current and Percent of Range
- Dynamic Variables
- Device variables with status
- Device variables
- Additional device status

Factory setting Loop Current and Percent of Range

Burst variable 0 

Navigation  Application → HART output → Burst config. 1 → Burst variable 0

Description For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection


- Level limit detection
- Sensor frequency
- State of vibrating fork
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage 1 *
- Percent of range

* Visibility depends on order options or device settings

- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Not used

Burst variable 1


Navigation  Application → HART output → Burst config. 1 → Burst variable 1

Description For HART command 9 and 33, assign a HART device variable or process variable to burst variable

- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current *
 - Terminal voltage 1 *
 - Percent of range
 - Measured current
 - Primary variable (PV)
 - Secondary variable (SV)
 - Tertiary variable (TV)
 - Quaternary variable (QV)
 - Not used

Factory setting Not used

Burst variable 2

Navigation  Application → HART output → Burst config. 1 → Burst variable 2

Description For HART command 9 and 33, assign a HART device variable or process variable to burst variable

- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current *
 - Terminal voltage 1 *
 - Percent of range

* Visibility depends on order options or device settings

- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Not used

Burst variable 3



Navigation Application → HART output → Burst config. 1 → Burst variable 3

Description For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- State of vibrating fork
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage 1 *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Not used

Burst variable 4



Navigation Application → HART output → Burst config. 1 → Burst variable 4

Description For HART command 33, assign a HART device variable or process variable to burst variable

Selection


- Level limit detection
- Sensor frequency
- State of vibrating fork
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage 1 *
- Percent of range
- Measured current

* Visibility depends on order options or device settings

- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Not used

Burst variable 5


Navigation  Application → HART output → Burst config. 1 → Burst variable 5

Description For HART command 33, assign a HART device variable or process variable to burst variable

- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current *
 - Terminal voltage 1 *
 - Percent of range
 - Measured current
 - Primary variable (PV)
 - Secondary variable (SV)
 - Tertiary variable (TV)
 - Quaternary variable (QV)
 - Not used

Factory setting Not used

Burst variable 6

Navigation  Application → HART output → Burst config. 1 → Burst variable 6

Description For HART command 33, assign a HART device variable or process variable to burst variable


- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current *
 - Terminal voltage 1 *
 - Percent of range
 - Measured current
 - Primary variable (PV)
 - Secondary variable (SV)

* Visibility depends on order options or device settings

- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Not used

Burst variable 7


Navigation  Application → HART output → Burst config. 1 → Burst variable 7

Description For HART command 33, assign a HART device variable or process variable to burst variable

- Selection**
- Level limit detection
 - Sensor frequency
 - State of vibrating fork
 - Sensor temperature
 - Electronics temperature
 - Measured current *
 - Terminal voltage 1 *
 - Percent of range
 - Measured current
 - Primary variable (PV)
 - Secondary variable (SV)
 - Tertiary variable (TV)
 - Quaternary variable (QV)
 - Not used

Factory setting Not used

Burst trigger mode


Navigation  Application → HART output → Burst config. 1 → Trigger mode


Description Select the event that triggers the burst message


- Selection**
- Continuous
 - Window *
 - Rising *
 - Falling *
 - On change


Factory setting Continuous

* Visibility depends on order options or device settings


Burst trigger level 

Navigation	 Application → HART output → Burst config. 1 → Trigger level
Description	Enter the burst trigger value that determines together with the option selected in "Burst trigger mode" parameter the time of burst message
User entry	Signed floating-point number



Min. update period 

Navigation	 Application → HART output → Burst config. 1 → Min. upd. per.
Description	Enter the minimum time span between two burst responses of one burst message
User entry	Positive integer
Factory setting	1 000 ms


Max. update period 

Navigation	 Application → HART output → Burst config. 1 → Max. upd. per.
Description	Enter the maximum time span between two burst responses of one burst message
User entry	Positive integer
Factory setting	2 000 ms


Information

Navigation   Application → HART output → Information


Device ID

Navigation	 Application → HART output → Information → Device ID
Description	Shows the device ID for identifying the device in a HART network
Factory setting	Device-specific


Device type


Navigation	 Application → HART output → Information → Device type
Description	Displays the device type with which the device is registered with the HART FieldComm Group.
Factory setting	0x91DF01

Device revision


Navigation	 Application → HART output → Information → Device revision
Description	Displays the device revision with which the device is registered with the HART FieldComm Group.
User interface	0 to 255
Factory setting	1

HART short tag




Navigation	 Application → HART output → Information → HART short tag
Description	Defines the short tag for the measuring point. Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Character string comprising numbers, letters and special characters (8)
Factory setting	Customized

HART revision

Navigation	 Application → HART output → Information → HART revision
Description	Displays the revision of the HART protocol for the device.
User interface	5 to 7
Factory setting	7


HART descriptor



Navigation	 Application → HART output → Information → HART descriptor
Description	Use this function to define a description for the measuring point. Maximum length: 16 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Character string comprising numbers, letters and special characters (16)
Factory setting	43/60


HART message



Navigation	 Application → HART output → Information → HART message
Description	Use this function to define a HART message which is sent via the HART protocol when requested by the master. Maximum length: 32 characters Allowed characters: A-Z, 0-9, certain special characters
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	43/60

HART date code




Navigation	 Application → HART output → Information → HART date code
Description	Enter date of the last configuration change. Use this format yyyy-mm-dd
User entry	Character string comprising numbers, letters and special characters (10)


3.4 System

Navigation  System


3.4.1 Device management

Navigation  System → Device manag.


Device tag	
-------------------	---

Navigation	 System → Device manag. → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	43/60

Locking status	
-----------------------	--


Navigation	 System → Device manag. → Locking status
Description	<p>Indicates the type of locking.</p> <p>"Safety locked" (SW) Unlock the device by entering the appropriate access code in "Enter safety unlocking code".</p> <p>"Temporarily locked" (SW) The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.</p>
User interface	<ul style="list-style-type: none"> ■ Safety locked ■ Temporarily locked

Configuration counter

Navigation	 System → Device manag. → Config. counter
Description	<p>Displays the counter for changes to the device parameters.</p> <p>Additional information:</p> <ul style="list-style-type: none"> - If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions. - When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset. - Once the counter has reached the value 65535, it restarts at 0.
User interface	0 to 65 535
Factory setting	0

Reset device




Navigation	 System → Device manag. → Reset device
Description	Reset the device configuration - either entirely or in part - to a defined state
Selection	<ul style="list-style-type: none"> ■ Cancel ■ To factory defaults * ■ To delivery settings * ■ Restart device
Factory setting	Cancel

3.4.2 User management

Navigation  System → User manag.

User role

Navigation	 System → User manag. → User role
Description	Shows the access authorization to the parameters via the operating tool

* Visibility depends on order options or device settings

User interface

- Operator
- Maintenance
- Expert

Factory setting Maintenance


Change user role

Navigation  System → User manag. → Change user role

Description It is possible to change the user role.
If the actual role is 'Maintenance', the 'Enter access code' will be prompted.
If the actual role is 'Operator', a 'Maintenance' password will be required.

User entry Character string comprising numbers, letters and special characters (1)

Password

Navigation  System → User manag. → Password

Description Enter the password for the "Maintenance" user role to get access to the functionality of this role.

User entry Character string comprising numbers, letters and special characters (16)

Enter access code

Navigation  System → User manag. → Ent. access code

Description For authorized service personnel only.

User entry 0 to 9999

Factory setting 0

Status password entry

Navigation   System → User manag. → Status pw entry

Description Use this function to display the status of the password verification.

User interface	<ul style="list-style-type: none"> ■ ----- ■ Wrong password ■ Password rule violated ■ Password accepted ■ Permission denied ■ Confirm PW mismatch ■ Reset password accepted ■ Invalid user role ■ Wrong sequence of entry
-----------------------	---

Factory setting	-----
------------------------	-------

Define password

Navigation	 System → User manag. → Define password
-------------------	--

User entry	Character string comprising numbers, letters and special characters (1)
-------------------	---


New password

Navigation	  System → User manag. → New password
-------------------	---

Description	<p>Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers.</p>
--------------------	---

User entry	Character string comprising numbers, letters and special characters (16)
-------------------	--


Confirm new password

Navigation	  System → User manag. → Confirm password
-------------------	---

Description	Enter the new password again to confirm.
--------------------	--



User entry	Character string comprising numbers, letters and special characters (16)
-------------------	--

Change password

Navigation	 System → User manag. → Change password
-------------------	--

Description	Changes the 'Maintenance' password.
--------------------	-------------------------------------


User entry	Character string comprising numbers, letters and special characters (1)
-------------------	---

Old password	
Navigation	 System → User manag. → Old password
Description	Enter the current password, to subsequently change the existing password.
User entry	Character string comprising numbers, letters and special characters (16)
Delete password	
Navigation	 System → User manag. → Delete password
Description	Deletes the 'Maintenance' password. After deleting, the 'Operator' role will be no more available. All users have read/write access rights.
User entry	Character string comprising numbers, letters and special characters (1)
Forgot password?	
Navigation	 System → User manag. → Forgot password?
User entry	Character string comprising numbers, letters and special characters (1)
Reset password	
Navigation	 System → User manag. → Reset password
Description	Enter a code to reset the current "Maintenance" password. The code is delivered by your local support.
User entry	Character string comprising numbers, letters and special characters (16)

3.4.3 Bluetooth configuration

Navigation  System → Bluetooth conf.


Bluetooth activation

Navigation	 System → Bluetooth conf. → Bluetooth active
Description	If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool. Reactivating via the SmartBlue app is not possible.
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable
Factory setting	Depends on the order option


3.4.4 Geolocation

Navigation  System → Geolocation

Process Unit Tag

Navigation	 System → Geolocation → Process Unit Tag
Description	Enter the process unit in which the device is installed.
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	Process Unit Tag

Location Description

Navigation	 System → Geolocation → Location Descr.
Description	Use this function to enter a description of the location so that the device can be located in the plant.
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	somewhere

Longitude



Navigation	System → Geolocation → Longitude
Description	Use this function to enter the longitude coordinates that describe the device location.
User entry	-180 to 180 °
Factory setting	0 °

Latitude



Navigation	System → Geolocation → Latitude
Description	Use this function to enter the latitude coordinates that describe the device location.
User entry	-90 to 90 °
Factory setting	0 °

Altitude



Navigation	System → Geolocation → Altitude
Description	Use this function to enter the altitude data that describe the device location.
User entry	Signed floating-point number
Factory setting	0 m

Location method



Navigation	System → Geolocation → Location method
Description	Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183.
Selection	<ul style="list-style-type: none"> ■ No fix ■ GPS or Standard Positioning Service fix ■ Differential GPS fix ■ Precise positioning service (PPS) fix ■ Real Time Kinetic (RTK) fixed solution ■ Real Time Kinetic (RTK) float solution


- Estimated dead reckoning
- Manual input mode
- Simulation Mode

Factory setting No fix

3.4.5 Information

Navigation  System → Information

Device name

Navigation  System → Information → Device name

Description Use this function to display the device name. It can also be found on the nameplate.

User interface Character string comprising numbers, letters and special characters

Factory setting 43/60

Manufacturer

Navigation  System → Information → Manufacturer

Description Displays the manufacturer.

User interface Character string comprising numbers, letters and special characters

Factory setting Endress+Hauser


Serial number

Navigation  System → Information → Serial number


Description The serial number is a unique alphanumeric code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.

User interface Character string comprising numbers, letters and special characters


Order code 

Navigation	 System → Information → Order code
Description	Shows the device order code.
User interface	Character string comprising numbers, letters and special characters
Factory setting	- none -
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: Expert


Firmware version

Navigation	 System → Information → Firmware version
Description	Displays the device firmware version installed.
User interface	Character string comprising numbers, letters and special characters


Hardware version

Navigation	 System → Information → Hardware version
User interface	Character string comprising numbers, letters and special characters


Extended order code 1 ... 3 

Navigation	 System → Information → Ext. order cd. 1
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: Expert


XML build number

Navigation	 System → Information → XML build no.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Checksum

Navigation	 System → Information → Checksum
Description	Checksum for Firmware version.
User interface	Positive integer


3.4.6 Additional information

Navigation  System → Additional info


Sensor

Navigation  System → Additional info → Sensor


Serial number

Navigation	 System → Additional info → Sensor → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Sensor → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Build no. software

Navigation	 System → Additional info → Sensor → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Hardware version


Navigation	 System → Additional info → Sensor → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Checksum


Navigation	 System → Additional info → Sensor → Checksum
Description	Checksum for Firmware version.
User interface	Positive integer
Factory setting	0

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---


Electronics

Navigation  System → Additional info → Electronics


Serial number

Navigation	 System → Additional info → Electronics → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Electronics → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Build no. software

Navigation	 System → Additional info → Electronics → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Hardware version

Navigation	 System → Additional info → Electronics → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Display/Bluetooth

Navigation  System → Additional info → Displ./Bluetooth


Serial number

Navigation	 System → Additional info → Displ./Bluetooth → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Displ./Bluetooth → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Build no. software

Navigation	 System → Additional info → Displ./Bluetooth → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Hardware version

Navigation	 System → Additional info → Displ./Bluetooth → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


3.4.7 Software configuration

Navigation   System → Softw. config.


CRC device configuration

Navigation	 System → Softw. config. → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535
Factory setting	65 535
Additional information	A CRC code (Cyclic Redundancy Check) for measuring instruments is an error detection method that is used to ensure the integrity of data.

Stored CRC device configuration


Navigation	 System → Softw. config. → Stored CRC conf.
Description	Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.
User interface	0 to 65 535
Factory setting	65 535

Timestamp stored CRC device config.


Navigation	 System → Softw. config. → Time stored CRC
Description	Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.
User interface	Character string comprising numbers, letters and special characters

Activate SW option



Navigation	 System → Softw. config. → Activate SW opt.
Description	Enter the application package code or code of another re-ordered functionality to enable it
User entry	Positive integer

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options
User interface	<ul style="list-style-type: none"> ■ WHG ■ Heartbeat Verification ■ Heartbeat Monitoring ■ Bluetooth



71682103

www.addresses.endress.com
