


Description of Device Parameters **Micropilot FMR60B, FMR62B, FMR63B, FMR66B, FMR67B**

Free-space radar
PROFIBUS PA



1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Document structure

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.


The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating tool**.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** (→  79) they are logged in with. This document lists the submenus and their parameters that are available to the User role **Maintenance**.

The operating menu is dynamic and adapts the choice of parameters to the selected options.



For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:

1	Simulation	
2	Navigation	Diagnostics → Simulation → Simulation
3	Prerequisite	Options marked with *: The corresponding device function must be available and configured.
4	Description	Simulates one or more process variables and/or events. Warning: - Output will reflect the simulated value or event.
5	Selection	<ul style="list-style-type: none"> ■ Off ■ Distance ■ Level ■ Level linearized * ■ Current output ■ Diagnostic event simulation ■ Foam index * ■ Build-up index *
6	Factory setting	Off

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected

1	Timestamp	
2	Navigation	Diagnostics → Active diagnos. → Timestamp
3	Description	Displays the timestamp for the currently active diagnostic message.
4	User interface	Days (d), hours (h), minutes (m), seconds (s)
5	Factory setting	
6	Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: -

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:
Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

⚠ WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.






⚠ CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.


📄 NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of Information

-  Indicates additional information
-  Reference to documentation
-  Operation via local display
-  Operation via operating tool
-  Write-protected parameter


1.6 Documentation
























-  For an overview of the scope of the associated Technical Documentation, refer to the following:
 - *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu

Navigation

 Operating tool

Guidance	→  16
▶ Commissioning	→  16
▶ Heartbeat Technology	→  17
▶ Heartbeat Verification	→  18
▶ Foam detection	→  18
▶ Buildup detection	→  18
▶ WHG mode	→  18
▶ Import / Export	→  18
▶ Compare	→  19
Diagnostics	→  19
▶ Active diagnostics	→  19
Active diagnostics	→  19
Timestamp	→  20
Previous diagnostics	→  20
Timestamp	→  20
Operating time from restart	→  20
Operating time	→  21
▶ Diagnostic list	→  21
▶ Event logbook	→  21
▶ Minimum/maximum values	→  22
Min. level value	→  22
Time min. level	→  22
Max. level value	→  22

Time max. level	→ 22
Max. draining speed	→ 22
Max. filling speed	→ 23
Counter underfilling	→ 23
Counter overfilling	→ 23
Minimum sensor temperature	→ 23
Time min. sensor temperature	→ 23
Maximum sensor temperature	→ 24
Time max. sensor temperature	→ 24
Minimum terminal voltage	→ 24
Maximum terminal voltage	→ 24
Minimum electronics temperature	→ 24
Maximum electronics temperature	→ 25
Reset min./max.	→ 25
► Simulation	→ 25
Simulation	→ 25
Simulation distance	→ 26
Buildup index	→ 26
Foam index	→ 26
Process variable value	→ 26
Diagnostic event simulation	→ 27
► Heartbeat Technology	→ 28
► Heartbeat Verification	→ 28
Date/time Heartbeat Verification	→ 28
Operating time (Verification)	→ 28

Verification result	→ 29
Status	→ 29
► Foam detection	→ 29
Foam detection	→ 29
Foam index	→ 30
Foam detec. threshold	→ 30
Foam detec. threshold value	→ 30
Lower level range limit	→ 30
Upper level range limit	→ 31
Distance at foam zero adjustment	→ 31
0% foam value	→ 31
► Buildup detection	→ 31
Buildup detection	→ 31
Buildup index	→ 32
Buildup detection threshold	→ 32
Buildup detection threshold value	→ 32
Minimum distance for buildup detection	→ 32
Maximum distance for buildup detection	→ 33
0 % buildup value	→ 33
Area of incoupling	→ 33
Limit offset for buildup detection	→ 33
► Echo curve	→ 34
Save reference curve	→ 34

Time reference curve	→ 34
Reference curve active	→ 34
▶ Diagnostic settings	→ 35
▶ Properties	→ 35
941 Diagnostic behavior	→ 35
941 Event category	→ 35
Value echo lost	→ 36
Ramp at echo lost	→ 36
Delay time echo lost	→ 37
942 Diagnostic behavior	→ 38
942 Event category	→ 38
Safety distance	→ 39
Acknowledge alarm	→ 39
▶ Configuration	→ 39
▶ Sensor	→ 39
168 Diagnostic behavior	→ 39
168 Event category	→ 40
▶ Process	→ 40
941 Diagnostic behavior	→ 40
941 Event category	→ 41
942 Diagnostic behavior	→ 41
942 Event category	→ 41
952 Diagnostic behavior	→ 41
952 Event category	→ 42
Application	→ 42

























▶ Measuring units	→ 42
Level unit	→ 42
Distance unit	→ 43
Temperature unit	→ 43
▶ Measured values	→ 43
Level linearized	→ 43
Level	→ 44
Distance	→ 44
Unfiltered distance	→ 44
Sensor temperature	→ 44
Terminal voltage 1	→ 45
Electronics temperature	→ 45
▶ Sensor	→ 45
▶ Basic settings	→ 45
Tank type	→ 45
Bin type	→ 46
Empty calibration	→ 46
Full calibration	→ 46
Maximum draining speed solid	→ 47
Maximum filling speed solid	→ 47
Maximum draining speed liquid	→ 48
Maximum filling speed liquid	→ 48
Tank/silo height	→ 49
Damping output	→ 49
Distance	→ 49

Confirm distance	→ 50
Record map	→ 50
Mapping end point	→ 50
Active map	→ 52
► Additional settings	→ 52
Medium type	→ 52
Medium group	→ 53
Medium property	→ 53
Upper blank out	→ 54
Output mode	→ 54
Level limit mode	→ 55
High limit	→ 55
Low limit	→ 55
Level correction	→ 56
► Echo evaluation	→ 56
Tank bottom range	→ 59
Evaluation mode	→ 60
Reset evaluation	→ 60
► Linearization	→ 63
Linearization type	→ 63
Unit after linearization	→ 63
Free text	→ 64
Level linearized	→ 64
Maximum value	→ 64
Diameter	→ 64

Intermediate height	→ 65
Table mode	→ 65
Table number	→ 65
Level	→ 66
Level	→ 66
Customer value	→ 66
Activate table	→ 67
▶ Signal information	→ 67
Signal quality	→ 67
Absolute echo amplitude	→ 67
Relative echo amplitude	→ 68
▶ Profibus	→ 69
▶ Configuration	→ 69
Device tag	→ 69
Ident number selector	→ 69
PROFIBUS ident number	→ 69
Address mode	→ 70
Device address	→ 70
▶ Analog input	→ 70
▶ Analog input 1 to 6	→ 70
Out value	→ 70
Out status	→ 71
Out unit text	→ 71
Channel	→ 71
PV filter time	→ 72

	Simulate enabled	→ 72
	Simulate value	→ 72
	Simulate status	→ 72
▶ Digital input		→ 73
▶ Digital input 1 to 2		→ 73
	Out value	→ 73
	Out status	→ 73
	Channel	→ 73
	Simulate enabled	→ 74
	Simulate value	→ 74
	Simulate status	→ 74
▶ Analog output		→ 75
▶ Analog output 1		→ 75
	Out value	→ 75
	Out status	→ 75
	Out unit	→ 75
	Fail-safe type	→ 76
	Fail-safe time	→ 76
	Fail-safe value	→ 76

▶ Information	→ 76
Device ID	→ 76
Profile version	→ 77
▶ Statistics	→ 77
CRC Count OK	→ 77
CRC Count Failed	→ 77
System	→ 78
▶ Device management	→ 78
Device tag	→ 78
Locking status	→ 78
Static revision	→ 78
Reset device	→ 79
▶ User management	→ 79
User role	→ 79
Change user role	→ 79
Password	→ 80
Enter access code	→ 80
Status password entry	→ 80
Define password	→ 80
New password	→ 81
Confirm new password	→ 81
Status password entry	→ 80
Change password	→ 81
Old password	→ 81
New password	→ 81

Confirm new password	→  81
Status password entry	→  80
Delete password	→  82
Old password	→  81
Status password entry	→  80
Forgot password?	→  82
Reset password	→  82
Status password entry	→  80
▶ Bluetooth configuration	→  82
Bluetooth activation	→  82
▶ Display	→  83
Language	→  83
Format display	→  83
Value 1 display	→  84
Value 2 ... 4 display	→  84
Decimal places 1 ... 4	→  85
Contrast display	→  85
▶ Information	→  85
Device name	→  85
Manufacturer	→  86
Serial number	→  86
Order code	→  86
Firmware version	→  86
Hardware version	→  87

Extended order code 1 ... 3	→ 87
Checksum	→ 87
► Software configuration	→ 92
CRC device configuration	→ 92
Activate SW option	→ 92
Software option overview	→ 92

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of guided wizards and cross-thematic special functions.

Navigation  Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - Foam detection
 - Buildup detection
- WHG mode
- Import / Export
- Compare

3.1.2 Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

WARNING

If the wizard is canceled before all the necessary parameters have been configured, any settings already set are saved.

The device may be in an undefined state!

- ▶ Reset the device to factory settings.

Navigation

Guidance → Commissioning

Parameters for the "Commissioning" wizard

The following parameters are configured in this wizard:

- **Device identification**
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - Device ID
 - Device address
- **Measurement adjustments**
 - Level unit
 - Distance unit
 - Temperature unit
 - Bin type
 - Tank type
 - Medium group
 - Empty calibration
 - Full calibration
 - Level
 - Displayed level/distance correct?
 - Show possible signals in?
 - Distance
 - Level
 - Is a linearization required?
 - Linearization type
 - Unit after linearization
 - Maximum value
 - Diameter
 - Intermediate height
 - Level linearized
 - Table mode
 - Table number
 - Level
 - Customer value
 - Activate table
- **Output settings**
 - Channel


3.1.3 Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application




Special Documentation on Heartbeat Technology is available via the Internet:
www.endress.com → Download

Navigation  Guidance → Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif.


Foam detection

This wizard configures the automatic foam detection.

Foam detection can be linked to an output variable or status information e.g. to control a sprinkler used to dissolve the foam. It is also possible to monitor the foam increase in a so called foam index. The foam index can also be linked to an output variable and can be shown on the display.

Preparation:

The Foam monitoring initialization should only be done without or less foam.

Navigation  Guidance → Heartbeat Techn. → Foam detection

Buildup detection

This wizard configures the build-up detection.


Basic idea:

The build-up detection can, for example, be linked to a compressed-air system to clean the antenna.

With the build-up monitoring the maintenance cycles can be optimized.

Preparation:

The build-up monitoring initialization should only be done without or less build-up.

Navigation  Guidance → Heartbeat Techn. → Buildup detect.

3.1.4 WHG mode

For WHG applications, the device can be protected against manipulation using the WHG wizard. After using this confirmation, the device is marked as WHG locked to indicate the device mode.

To unlock the WHG locking the sequence needs to be restarted. After entering the safety unlocking code (= Safety locking code) the device is unlocked.

Navigation  Guidance → WHG mode

3.1.5 Import / Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create configuration report

Device documentation can be saved in PDF format under Create configuration report. This device documentation contains the following general device information:

- Information on device parameters
- Information on Linearization
- Echo curve
- Event list
- Diagnostic list

Navigation  Guidance → Import / Export

3.1.6 Compare**Compare datasets**

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import / Export
- Datasets with the configuration currently in the device

Navigation  Guidance → Compare

3.2 Diagnostics



Navigation   Diagnostics

3.2.1 Active diagnostics

Navigation   Diagnostics → Active diagnos.

Active diagnostics

Navigation

  Diagnostics → Active diagnos. → Active diagnos.

Description



Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.



User interface

- Operating time of the device until the event occurs
- Symbol for diagnostic behavior
- Code for diagnostic behavior
- Event text
- Corrective measure



Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp for the currently active diagnostic message.
User interface	Date, time



Previous diagnostics

Navigation	  Diagnostics → Active diagnos. → Prev.diagnostics
Description	Displays the diagnostic message for the last diagnostic event that has ended.
User interface	<ul style="list-style-type: none"> ▪ Operating time of the device until the event occurs ▪ Symbol for diagnostic behavior ▪ Code for diagnostic behavior ▪ Event text ▪ Corrective measure


Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended.
User interface	Date, time

Operating time from restart

Navigation	  Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	 Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
User interface	Days (d), hours (h), minutes (m), seconds (s)


3.2.2 Diagnostic list

Navigation  Diagnostics → Diagnostic list

3.2.3 Event logbook

Navigation  Diagnostics → Event logbook



Clear event list

Navigation	 Diagnostics → Event logbook → Clear event list
Description	Delete all entries of the event list.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Clear data
Factory setting	Cancel
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

3.2.4 Minimum/maximum values

Navigation   Diagnostics → Min/max val.

Min. level value

Navigation   Diagnostics → Min/max val. → Min. level value

Description Minimum or maximum value measured by device.


User interface Signed floating-point number

Time min. level

Navigation   Diagnostics → Min/max val. → Time min. level

User interface Character string comprising numbers, letters and special characters


Max. level value

Navigation   Diagnostics → Min/max val. → Max. level value

Description Minimum or maximum value measured by device.



User interface Signed floating-point number

Time max. level

Navigation   Diagnostics → Min/max val. → Time max. level

User interface Character string comprising numbers, letters and special characters


Max. draining speed

Navigation   Diagnostics → Min/max val. → Max.drain.speed


User interface Positive floating-point number

Factory setting 0.0 %/min


Max. filling speed

Navigation	 Diagnostics → Min/max val. → Max. fill. speed
User interface	Positive floating-point number
Factory setting	0.0 %/min


Counter underfilling

Navigation	 Diagnostics → Min/max val. → Count underfill.
User interface	0 to 65 535
Factory setting	0


Counter overfilling

Navigation	 Diagnostics → Min/max val. → Count overfill.
User interface	0 to 65 535
Factory setting	0


Minimum sensor temperature

Navigation	 Diagnostics → Min/max val. → Min. sensor temp
User interface	-150 to 200 °C

Time min. sensor temperature


Navigation	 Diagnostics → Min/max val. → Time min s. temp
User interface	Character string comprising numbers, letters and special characters

Maximum sensor temperature

Navigation  Diagnostics → Min/max val. → Max. sensor temp


User interface -150 to 200 °C

Time max. sensor temperature

Navigation  Diagnostics → Min/max val. → Time max s. temp

User interface Character string comprising numbers, letters and special characters


Minimum terminal voltage

Navigation  Diagnostics → Min/max val. → Min.term.volt.

Description Minimum or maximum measured terminal (supply) voltage.

User interface 0.0 to 50.0 V


Maximum terminal voltage

Navigation  Diagnostics → Min/max val. → Max.term.voltage

Description Minimum or maximum measured terminal (supply) voltage.

User interface 0.0 to 50.0 V



Minimum electronics temperature

Navigation  Diagnostics → Min/max val. → Min.electr.temp.

Description Minimum or maximum measured main electronics temperature.



User interface Signed floating-point number

Maximum electronics temperature

Navigation	  Diagnostics → Min/max val. → Max.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Reset min./max.





Navigation	  Diagnostics → Min/max val. → Reset min/max
Description	Resets the drag indicator of the selected process variable.
Selection	<ul style="list-style-type: none"> ■ None ■ Drain/fill speed ■ Level ■ Reset all
Factory setting	None

3.2.5 Simulation

Navigation   Diagnostics → Simulation

Simulation



Navigation	  Diagnostics → Simulation → Simulation
Prerequisite	<p>Selection options marked with *:</p> <p>The corresponding device function must be available and configured.</p>
Description	<p>Simulates one or more process variables and/or events.</p> <p>Warning: Output will reflect the simulated value or event.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ Distance ■ Level ■ Level linearized *

* Visibility depends on order options or device settings

- Diagnostic event simulation
- Foam index *
- Buildup index *

Factory setting Off

Simulation distance

Navigation   Diagnostics → Simulation → Sim distance

Prerequisite Simulation = Distance (→  44)

User entry -999 900 to 999 900 mm

Factory setting 0 mm

Buildup index

Navigation   Diagnostics → Simulation → Buildup index

Prerequisite Simulation = Buildup index

User entry 0 to 100.0 %

Factory setting 0 %

Foam index

Navigation   Diagnostics → Simulation → Foam index


Prerequisite Simulation = Foam index (→  30)

User entry 0 to 100.0 %

Factory setting 0 %

Process variable value



Navigation   Diagnostics → Simulation → Proc. var. value

Prerequisite Simulation = Level linearized (→  43)

* Visibility depends on order options or device settings

Description	Defines the value of the selected variable. The outputs assume values or states according to this value.
User entry	Signed floating-point number
Factory setting	0

Diagnostic event simulation

Navigation	  Diagnostics → Simulation → Diagnostic event
Prerequisite	Simulation = Diagnostic event simulation
Description	Select the diagnostic event to be simulated. Note: To terminate the simulation, select "Off".
Selection	<ul style="list-style-type: none"> Buildup detected Foam detected Record map Dataset different Data storage inconsistent Data transfer failed Date/time incorrect Processing download Echo lost Real time clock defective Electronics and HistoROM defective Electronics temperature Firmware incompatible Firmware update failed Level limited Main electronics defective Main electronics faulty In safety distance Configuration incompatible Configuration Sensor Unit invalid Linearization faulty Module incompatible Trim required Sensor electronic failure Sensor temperature out of range Sensor connection faulty


Diagnostic event simulation active
 Simulation distance
 Failure mode simulation active
 Process variable simulation active
 Memory content inconsistent
 Supply voltage too high
 Supply voltage too low

Factory setting Off


3.2.6 Heartbeat Technology

Navigation  Diagnostics → Heartbeat Techn.


Heartbeat Verification

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif.


Date/time Heartbeat Verification

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification
Description	Date and time of last Heartbeat Verification. This value is updated with every Heartbeat verification. Note: If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.
User interface	Character string comprising numbers, letters and special characters
Factory setting	01.01.1970 00:00:00


Operating time (Verification)

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time
Description	Value of the operating hours counter at the time of verification.
User interface	Days (d), hours (h), minutes (m), seconds (s)


Verification result

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Verific. result
Description	Result of Heartbeat Verification.
User interface	<ul style="list-style-type: none"> ■ Not done ■ Passed ■ Not done ■ Failed
Factory setting	Not done


Status

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status
Description	Shows the actual status.
User interface	<ul style="list-style-type: none"> ■ Done ■ Busy ■ Failed ■ Not done
Factory setting	Not done


Foam detection

Navigation  Diagnostics → Heartbeat Techn. → Foam detection


Foam detection


Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → Foam detection
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

Foam index


Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → Foam index
Description	Foam index 0 % means: no foam. Foam index 100 % means: maximum detectable foam.
User interface	0 to 100 %
Factory setting	0 %


Foam detec. threshold




Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → Foam threshold
Description	Enter the threshold for the foam detection. As soon as the foam index has reached the preset switching point, an event is triggered.
Selection	<ul style="list-style-type: none"> ■ Sensitive (20%) ■ Middle (40%) ■ Insensitive (80%) ■ User defined (xx%)
Factory setting	Middle (40%)


Foam detec. threshold value



Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → Foam detect val.
Description	User-defined threshold value for the foam detection.
User entry	0 to 100.0 %
Factory setting	40 %

Lower level range limit



Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → LLR limit
Description	Assign lower limit of foam monitoring area.
Factory setting	0 %

Upper level range limit



Navigation	Diagnostics → Heartbeat Techn. → Foam detection → ULR limit
Description	Assign upper limit of foam monitoring area.
Factory setting	100.0 %

Distance at foam zero adjustment



Navigation	Diagnostics → Heartbeat Techn. → Foam detection → Dist. @zero foam
User entry	Signed floating-point number
Factory setting	0 mm

0% foam value



Navigation	Diagnostics → Heartbeat Techn. → Foam detection → 0% foam value
User entry	-999 999.9 to 999 999.9 dB
Factory setting	0 dB

Buildup detection


Navigation Diagnostics → Heartbeat Techn. → Buildup detect.

Buildup detection




Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup detect.
Description	Activate or deactivate build-up detection.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

Buildup index

Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup index
Description	Build-up index 0% means: no build-up. Build-up index 100% means: maximum detectable build-up.
User interface	0 to 100 %
Factory setting	0 %


Buildup detection threshold



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup detec.
Description	Enter the threshold for the build-up detection. As soon as the build-up index has reached the preset switching point, an event is triggered.
Selection	<ul style="list-style-type: none"> ■ Sensitive (20%) ■ Middle (40%) ■ Insensitive (80%) ■ User defined (xx%)
Factory setting	Middle (40%)


Buildup detection threshold value



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup value
Description	User-defined threshold value for the build-up detection.
User entry	0 to 100.0 %
Factory setting	40 %

Minimum distance for buildup detection



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Min dist buildup
User entry	-999 900 to 999 900 mm
Factory setting	0 mm

Maximum distance for buildup detection



Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Max dist buildup
User entry	-999 900 to 999 900 mm
Factory setting	1 000 mm

0 % buildup value



Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → 0 % buildup val
User entry	Positive floating-point number
Factory setting	0

Area of incoupling

Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Area incoupling
Description	Ring integral within the detection area.
User interface	Positive floating-point number
Factory setting	0.0

Limit offset for buildup detection




Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Offset buildup
User entry	-999 999.9 to 999 999.9 dB
Factory setting	10 dB


3.2.7 Echo curve

Navigation  Diagnostics → Echo curve


Save reference curve

Navigation	 Diagnostics → Echo curve → Save ref. curve
Selection	<ul style="list-style-type: none"> ■ Customer reference curve ■ Not active
Factory setting	Not active
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Maintenance ■ Write access: Maintenance

Time reference curve

Navigation	 Diagnostics → Echo curve → Time ref. curve
User interface	Days (d), hours (h), minutes (m), seconds (s)
Additional information	Timestamp of the recording of the reference curve. Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: -


Reference curve active

Navigation	 Diagnostics → Echo curve → Ref.curve active
User interface	<ul style="list-style-type: none"> ■ Delivery reference curve available ■ Customer reference curve available
Factory setting	Customer reference curve available
Additional information	The delivery reference curve is recorded at the factory before delivery. A customer reference curve is recorded as standard at the end of the Guidance → Commissioning . These reference curves can be used for diagnosing problems when troubleshooting. Access: <ul style="list-style-type: none"> ■ Read access: Maintenance ■ Write access: -


3.2.8 Diagnostic settings

Navigation  Diagnostics → Diag. settings

Properties

Navigation  Diagnostics → Diag. settings → Properties

941 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Properties → 941Diag. behav.

Description Defines the behavior of the output in case of an echo loss.

"Last valid value"
Last valid value is kept.

"Ramp at echo lost"
Output value is continuously shifted towards 0 % or 100 %.

"Value echo lost"
Output assumes a defined value.


"Alarm"
Device generates an alarm.

Selection

- Last valid value
- Ramp at echo lost
- Value echo lost
- Alarm

Factory setting Last valid value










941 Event category

Navigation  Diagnostics → Diag. settings → Properties → 941Event categ.


Selection



- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)

Factory setting Out of specification (S)


Value echo lost 	
Navigation	  Diagnostics → Diag. settings → Properties → Value echo lost
Description	Value of the output in case of an echo loss.
User entry	Signed floating-point number
Factory setting	0 %
Ramp at echo lost 	
Navigation	  Diagnostics → Diag. settings → Properties → Ramp echo lost
Description	Slope of the ramp in the case of an echo loss. Note: If the slope is positive (+), the output increases until it reaches 100%. If the slope is negative (-), the output decreases until it reaches 0%.
User entry	Signed floating-point number
Factory setting	0.0 %/min
Jump delay echo lost 	
Navigation	  Diagnostics → Diag. settings → Properties → Jump del. echol.
Description	Activate or deactivate the delay time in case of echo loss. After an echo loss, the device allows the delay time to pass before the reaction defined in parameter "941 Diagnostic behavior" occurs. This way it can be avoided that temporary disturbances interrupt the measurement unnecessarily.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert



Delay time echo lost




Navigation	  Diagnostics → Diag. settings → Properties → Delay echo lost
Description	Time between the echo loss and the reaction defined for the output.
User entry	0 to 99 999.9 s
Factory setting	900 s



Echo jump delay




Navigation	  Diagnostics → Diag. settings → Properties → Echo jump delay
User entry	0 to 99 999.9 s
Factory setting	60.0 s
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert



Echo lost window right



Navigation	  Diagnostics → Diag. settings → Properties → Echo l.win.right
User entry	0 to 99 900 mm
Factory setting	4 000 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo lost window left



Navigation	  Diagnostics → Diag. settings → Properties → Echo l.win.left
User entry	0 to 99 000 mm
Factory setting	4 000 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Draining speed



Navigation	Diagnostics → Diag. settings → Properties → Draining speed
User entry	Signed floating-point number
Factory setting	100 cm/min
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

Filling speed



Navigation	Diagnostics → Diag. settings → Properties → Filling speed
User entry	Signed floating-point number
Factory setting	100 cm/min
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

942 Diagnostic behavior



Navigation	Diagnostics → Diag. settings → Properties → 942Diag. behav.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Self holding
Factory setting	Warning

942 Event category



Navigation	Diagnostics → Diag. settings → Properties → 942Event categ.
Selection	<ul style="list-style-type: none"> ▪ Failure (F) ▪ Function check (C) ▪ Out of specification (S) ▪ Maintenance required (M)
Factory setting	Out of specification (S)

Safety distance



Navigation	Diagnostics → Diag. settings → Properties → Safety distance
User entry	-200 000 to 125 000 mm
Factory setting	0 mm

Acknowledge alarm



Navigation	Diagnostics → Diag. settings → Properties → Acknowl. alarm
Selection	<ul style="list-style-type: none"> ■ No ■ Yes
Factory setting	No

Configuration

Navigation Diagnostics → Diag. settings → Configuration

Sensor

Navigation Diagnostics → Diag. settings → Configuration → Sensor

168 Diagnostic behavior



Navigation	Diagnostics → Diag. settings → Configuration → Sensor → 168Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": No forwarding of the message via the fieldbus.</p> <p>"Warning": Warning message is transmitted via the fieldbus (default setting).</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning

168 Event category

Navigation Diagnostics → Diag. settings → Configuration → Sensor → 168Event categ.

Description**Selection**

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)

Factory setting

Maintenance required (M)

Process

Navigation Diagnostics → Diag. settings → Configuration → Process

941 Diagnostic behavior

Navigation Diagnostics → Diag. settings → Configuration → Process → 941Diag. behav.

Description

Defines the behavior of the output in case of an echo loss.

"Last valid value"

Last valid value is kept.

"Ramp at echo lost"

Output value is continuously shifted towards 0 % or 100 %.

"Value echo lost"

Output assumes a defined value.

"Alarm"

Device generates an alarm.

Selection



- Last valid value
- Ramp at echo lost
- Value echo lost
- Alarm

Factory setting

Last valid value



941 Event category



Navigation	  Diagnostics → Diag. settings → Configuration → Process → 941Event categ.
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M)
Factory setting	Out of specification (S)



942 Diagnostic behavior



Navigation	  Diagnostics → Diag. settings → Configuration → Process → 942Diag. behav.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Self holding
Factory setting	Warning



942 Event category



Navigation	  Diagnostics → Diag. settings → Configuration → Process → 942Event categ.
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M)
Factory setting	Out of specification (S)



952 Diagnostic behavior





Navigation	  Diagnostics → Diag. settings → Configuration → Process → 952Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": No forwarding of the message via the fieldbus.</p> <p>"Warning": Warning message is transmitted via the fieldbus (default setting).</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>

Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning

952 Event category

Navigation	  Diagnostics → Diag. settings → Configuration → Process → 952Event categ.
Description	Display diagnostic message category.
Selection	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M)
Factory setting	Out of specification (S)



3.3 Application

Navigation   Application

3.3.1 Measuring units

Navigation   Application → Measuring units

Level unit

Navigation	  Application → Measuring units → Level unit				
Description	Used to display the level.				
Selection	<table style="width: 100%; border: none;"> <tr> <td style="vertical-align: top;"><i>SI units</i></td> <td style="vertical-align: top;"><i>US units</i></td> </tr> <tr> <td> <ul style="list-style-type: none"> ■ % ■ m ■ mm </td> <td> <ul style="list-style-type: none"> ■ ft ■ in </td> </tr> </table>	<i>SI units</i>	<i>US units</i>	<ul style="list-style-type: none"> ■ % ■ m ■ mm 	<ul style="list-style-type: none"> ■ ft ■ in
<i>SI units</i>	<i>US units</i>				
<ul style="list-style-type: none"> ■ % ■ m ■ mm 	<ul style="list-style-type: none"> ■ ft ■ in 				
Factory setting	%				

Distance unit



Navigation	Application → Measuring units → Distance unit	
Description	Select the length unit for distance measurement. It is used, e.g., for the basic calibration ("Empty calibration" or "Full calibration").	
Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ mm ■ m 	<i>US units</i> <ul style="list-style-type: none"> ■ ft ■ in
Factory setting	mm	

Temperature unit



Navigation	Application → Measuring units → Temperature unit	
Description	Select the temperature unit.	
Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ °C ■ K 	<i>US units</i> <ul style="list-style-type: none"> °F
Factory setting	°C	


3.3.2 Measured values

Navigation Application → Measured values


Level linearized

Navigation	Application → Measured values → Level linearized
Description	Displays the linearized level.
User interface	Signed floating-point number
Factory setting	0 %


Level

Navigation	 Application → Measured values → Level
Description	Displays the actual measured level.
User interface	-99 999.9 to 200 000.0 %
Factory setting	0.0 %


Distance

Navigation	 Application → Measured values → Distance
Description	Distance from lower edge of device flange to product surface.
User interface	Signed floating-point number
Factory setting	0 mm


Unfiltered distance

Navigation	 Application → Measured values → Unfiltered dist.
User interface	Signed floating-point number
Factory setting	0 mm


Sensor temperature

Navigation	 Application → Measured values → Sensor temp.
Description	Displays the current temperature of the sensor electronics.
User interface	-150 to 200 °C
Factory setting	-150 °C

Terminal voltage 1

Navigation	 Application → Measured values → Terminal volt. 1
Description	Shows the current terminal voltage that is applied at the output
User interface	0.0 to 50.0 V

Electronics temperature

Navigation	 Application → Measured values → Electronics temp
Description	Displays the current temperature of the main electronics.
User interface	Signed floating-point number
Factory setting	0 °C

3.3.3 Sensor


Navigation  Application → Sensor

Basic settings

Navigation  Application → Sensor → Basic settings

Tank type



Navigation	 Application → Sensor → Basic settings → Tank type
Description	Optimizes the signal filters for the respective tank type. Note: "Workbench test" deactivates all filters. This option should exclusively be used for tests.
Selection	<ul style="list-style-type: none"> ■ Stilling well ■ Workbench test ■ Open channel ■ Sphere ■ Storage vessel ■ Process vessel standard ■ Process vessel with agitator
Factory setting	Process vessel standard

Bin type 

Navigation   Application → Sensor → Basic settings → Bin type

Description Optimizes the signal filters for the respective bin type.
 Note:
 "Workbench test" deactivates all filters. This option should exclusively be used for tests.

Selection

- Buffer silo (fast)
- Bin/Pile
- Crusher/belt
- Silo
- Workbench test

Factory setting Silo

Empty calibration 

Navigation   Application → Sensor → Basic settings → Empty calibr.

Description Distance between process connection and minimum level (0 %).

User entry 0 to 125 000 mm

Factory setting 20 000 mm

Full calibration 

Navigation   Application → Sensor → Basic settings → Full calibr.

Description Distance between minimum level (0 %) and maximum level (100 %).

User entry 1 to 125 000 mm

Factory setting 20 000 mm

Maximum draining speed solid

**Navigation**

Application → Sensor → Basic settings → Max.drain solid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- Very slow < 0.5 m (1.6 ft)/h
- Slow < 1 m (3.3 ft)/h
- Standard < 2m (6,5ft) /h
- Medium < 4m (13ft) /h
- Fast < 8 m (26 ft)/h
- Very fast > 8 m (26 ft)/h
- No filter/test

Factory setting

No filter/test

Maximum filling speed solid

**Navigation**

Application → Sensor → Basic settings → Max. fill. solid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/ test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- Very slow < 0.5 m (1.6 ft)/h
- Slow < 1 m (3.3 ft)/h
- Standard < 2m (6,5ft) /h
- Medium < 4m (13ft) /h
- Fast < 8 m (26 ft)/h
- Very fast > 8 m (26 ft)/h
- No filter/test

Factory setting

No filter/test

Maximum draining speed liquid

**Navigation**

Application → Sensor → Basic settings → Max drain liquid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- Slow < 1 cm (0.4 in)/min
- Medium < 10 cm (4 in)/min
- Standard < 1 m (40 in)/min
- Fast < 2 m (80 in)/min
- Very fast > 2 m (80 in)/min
- No filter/test

Factory setting

Standard < 1 m (40 in)/min

Maximum filling speed liquid

**Navigation**

Application → Sensor → Basic settings → Max. fill liquid

Description

By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the "No filter/test" option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- Slow < 1 cm (0.4 in)/min
- Medium < 10 cm (4 in)/min
- Standard < 1 m (40 in)/min
- Fast < 2 m (80 in)/min
- Very fast > 2 m (80 in)/min
- No filter/test

Factory setting

Standard < 1 m (40 in)/min

Tank/silo height



Navigation	Application → Sensor → Basic settings → Tank/silo height
Description	<p>If the parametrized measuring range (Empty calibration) differs significantly from the tank or silo height, it is recommended to enter the tank or silo height in this parameter.</p> <p>Example: Continuous level monitoring in the upper third of a tank or silo.</p> <p>Note: For tanks with conical outlet, this parameter should not be changed as in this type of applications "Empty calibration" is usually not << the tank or silo height.</p>
User entry	0 to 125 000 mm
Factory setting	20 000 mm

Damping output



Navigation	Application → Sensor → Basic settings → Damping out.
Description	<p>The damping is effective before the measured value is further processed, i.e., before the following processes:</p> <ul style="list-style-type: none"> - Scaling - Limit value monitoring - Forwarding to display - Forwarding to Analog Input Block <p>Note: The Analog Input Block has its own "Damping" parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.</p>
User entry	0.0 to 1 200.0 s
Factory setting	0.0 s

Distance

Navigation	Application → Sensor → Basic settings → Distance
Description	Distance from lower edge of device flange to product surface.
User interface	Signed floating-point number
Factory setting	0 mm

Confirm distance

**Navigation**

Application → Sensor → Basic settings → Confirm distance

Selection

- Modify map
- Distance ok
- Distance unknown
- Tank empty

Factory setting

Distance unknown

Record map

**Navigation**

Application → Sensor → Basic settings → Record map

Selection

- No
- Overlay map
- Delete cust map

Factory setting

No

Mapping start point

**Navigation**

Application → Sensor → Basic settings → Map. start point

User entry

-999 900 to 999 900 mm

Factory setting

-250 mm

Additional information

Access:

- Read access: Expert
- Write access: Expert

Mapping end point

**Navigation**

Application → Sensor → Basic settings → Map. end point

Description

Defines up to which distance the new mapping has to be recorded.
 Remark: Make sure the level signal is not covered by the mapping.

User entry

0.1 to 125 mm

Factory setting

100 mm

Mapping overlay time



Navigation	Application → Sensor → Basic settings → Map overlay time
User entry	1 to 600 s
Factory setting	5 s
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Map gap



Navigation	Application → Sensor → Basic settings → Map gap
User entry	0 to 100 000 mm
Factory setting	235 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

End of mapping



Navigation	Application → Sensor → Basic settings → End of mapping
Description	Defines the behavior of the mapping curve in the tank bottom area.
Selection	<ul style="list-style-type: none"> ■ Adjustable ■ Last map value
Factory setting	Adjustable
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

End map. ampl.



Navigation	Application → Sensor → Basic settings → End map. ampl.
Description	Amplitude of the mapping curve in the tank bottom area.



User entry -99 999.0 to 99 999.0 dB

Factory setting -100 dB

Additional information **Access:**

- Read access: Expert
- Write access: Expert

Active map

Navigation   Application → Sensor → Basic settings → Active map

Description Select the mapping curve that is to be active. Alternatively, the option "No map" can be selected.

Selection


- Factory map
- Customer map
- No map

Factory setting Factory map

Additional information

- **Factory map:** The device activates the mapping curve recorded in the factory. This curve cannot be edited or deleted.
- **Customer map:** If a customer map has been recorded, this can be activated in order to minimize distortions in the application. This curve can be edited.
- **No map**

Additional settings

Navigation   Application → Sensor → Add. settings

Medium type

Navigation   Application → Sensor → Add. settings → Medium type

Description Select whether the measured medium is liquid or solid.

Selection

- Liquid
- Solid

Factory setting Liquid

Medium group



Navigation	Application → Sensor → Add. settings → Medium group
Description	<p>Rough specification of the dielectric constant (DC).</p> <p>This parameter presets the "Medium property" parameter as follows:</p> <p>"Others" ->"Medium property" = "Unknown"</p> <p>"Water based (DC >= 4)" -> "Medium property" = "DC 4 ... 7"</p> <p>Note: If "Medium property" is changed afterwards, "Medium group" retains its value. Only "Medium property" is relevant for the signal evaluation.</p> <p>Note: The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.</p>
Selection	<ul style="list-style-type: none"> ■ Others ■ Water based (DC >= 4)
Factory setting	Others

Medium property



Navigation	Application → Sensor → Add. settings → Medium property
Description	<p>Specify the dielectric constant (DC) of the medium.</p> <p>Note: For multiple-phase systems this value refers to the upper medium.</p>
Selection	<ul style="list-style-type: none"> ■ Unknown ■ DC 1.2 ... 1.6 ■ DC 1.6 ... 1.9 ■ DC 1.9 ... 2.5 ■ DC 2.5 ... 4 ■ DC 4 ... 7 ■ DC 7 ... 15 ■ DC > 15
Factory setting	DC 1.9 ... 2.5

Upper blank out



Navigation	Application → Sensor → Add. settings → Upper blank out
Description	This parameter describes a line segment between reference point and close to maximum level (100%). The value is calculated by the device to blanket potentially disturbing signals coming from this space. The value can be adapted manually.
User entry	0 to 125 000 mm
Factory setting	50 mm

Output mode



Navigation	Application → Sensor → Add. settings → Output mode
Description	Select output mode between: Ullage = The remaining space in the tank or silo is indicated. or Level linearized = The level is indicated (more precisely: the linearized value if a linearization has been activated).
Selection	<ul style="list-style-type: none"> ▪ Ullage ▪ Level linearized
Factory setting	Level linearized

L max. drain speed



Navigation	Application → Sensor → Add. settings → L max draining
User entry	0.0 to 50 000.0 %/min
Factory setting	0.0 %/min
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

L max. fill speed



Navigation	Application → Sensor → Add. settings → L max.fill speed
User entry	0.0 to 50 000.0 %/min
Factory setting	0.0 %/min
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Level limit mode



Navigation	Application → Sensor → Add. settings → Level limit mode
Description	Determines whether the output value is limited by an upper or lower limit (or by both).
Selection	<ul style="list-style-type: none"> ■ Off ■ Low limit ■ High limit ■ Low and High Limit
Factory setting	Low limit

High limit



Navigation	Application → Sensor → Add. settings → High limit
Description	Defines the upper limit of the output value.
User entry	Signed floating-point number
Factory setting	0 %

Low limit



Navigation	Application → Sensor → Add. settings → Low limit
Description	Defines the lower limit of the output value.
User entry	-200 000.0 to 200 000.0 %
Factory setting	0.0 %

Level correction



Navigation Application → Sensor → Add. settings → Level correction

Description The measured level is corrected by this value to compensate for a constant level error.
Level correction > 0:
The level is increased by this value.
Level correction < 0:
The level is decreased by this value.

User entry -200 000.0 to 200 000.0 %

Factory setting 0.0 %

Echo evaluation

Navigation Application → Sensor → Add. settings → Echo evaluation

Echo curve statistic



Navigation Application → Sensor → Add. settings → Echo evaluation → Ec. curve stat.

Description Activate or deactivate the weighted echo curve statistics.

Selection

- Off
- On

Factory setting On

Additional information **Access:**

- Read access: Expert
- Write access: Expert

Echo curve statistics up



Navigation Application → Sensor → Add. settings → Echo evaluation → EC. stat. up



Description Enter the number of measuring cycles to define the weighting of the last echo curve for ascending signals.

User entry 0 to 30



Factory setting 3

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--



Echo curve statistic down


Navigation	  Application → Sensor → Add. settings → Echo evaluation → ECS in down
Description	Enter the number of measuring cycles to define the weighting of the last echo curve for descending signals.
User entry	0 to 30
Factory setting	5
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo curve smoothing mode

Navigation	  Application → Sensor → Add. settings → Echo evaluation → EC. smooth.mode
Selection	<ul style="list-style-type: none"> ■ Off ■ SG smoothing ■ Symmetric smoothing ■ Asymmetric smoothing
Factory setting	Symmetric smoothing
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo curve smoothing

Navigation	  Application → Sensor → Add. settings → Echo evaluation → EC. smoothing
User entry	0 to 9 900 mm
Factory setting	0 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

FAC offset 

Navigation   Application → Sensor → Add. settings → Echo evaluation → FAC offset

Description Enter offset of the weighting curve.

User entry -9 999.0 to 9 999.0 dB

Factory setting 12 dB

Additional information **Access:**
 ■ Read access: Expert
 ■ Write access: Expert

FAC window size 

Navigation   Application → Sensor → Add. settings → Echo evaluation → FAC window size

Description Enter width of the weighting curve window.

User entry 0 to 9 900 mm

Factory setting 1 600 mm

Additional information **Access:**
 ■ Read access: Expert
 ■ Write access: Expert

Max Value EWC 

Navigation   Application → Sensor → Add. settings → Echo evaluation → Max Value EWC

Description Enter maximum amplitude of the weighting curve.

User entry -9 999.0 to 9 999.0 dB

Factory setting 100 dB

Additional information **Access:**
 ■ Read access: Expert
 ■ Write access: Expert

First echo factor



Navigation Application → Sensor → Add. settings → Echo evaluation → First echo fact.

Description Enter width of the first echo band.

User entry 0.0 to 100.0 dB

Factory setting 10 dB

Additional information **Access:**
▪ Read access: Expert
▪ Write access: Expert

Parabolic fit window size



Navigation Application → Sensor → Add. settings → Echo evaluation → Parab fit window

User entry 0 to 9 900 mm

Factory setting 120 mm

Additional information **Access:**
▪ Read access: Expert
▪ Write access: Expert

Tank bottom range



Navigation Application → Sensor → Add. settings → Echo evaluation → TB range

Description Determines the range in which the physical bottom echo is searched for. The bottom range extends downwards and starts at level 0 % "Empty calibration". It ends at the entered value.

Note: If the level 0 % "Empty calibration" is far above the physical bottom, the bottom range starts at the entered "Tank/silo height".

User entry 0 to 312 500 mm

Factory setting 15 000 mm

Min. amplitude TBD



Navigation Application → Sensor → Add. settings → Echo evaluation → Min. ampl. TBD

Description Enter the minimum amplitude for tank bottom detection.

User entry	0 to 9 999.0 dB
Factory setting	3 dB
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Lower level area


Navigation	Application → Sensor → Add. settings → Echo evaluation → Lower level area
Description	<p>Enter lower level area.</p> <p>In this defined range, the first echo band is lowered to the weighting curve.</p>
User entry	0 to 125 000 mm
Factory setting	1 000 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Evaluation mode


Navigation	Application → Sensor → Add. settings → Echo evaluation → Evaluation mode
Description	Defines the evaluation mode for the echo tracking.
Selection	<ul style="list-style-type: none"> ■ FlexTracking ■ FlexTracking - Weak signals ■ FixTracking ■ FixTracking - Weak signals
Factory setting	FlexTracking

Reset evaluation


Navigation	Application → Sensor → Add. settings → Echo evaluation → Reset evaluation
Description	Restarts level determination.
Selection	<ul style="list-style-type: none"> ■ Reset done ■ Yes
Factory setting	Reset done

Window size tracking



Navigation	Application → Sensor → Add. settings → Echo evaluation → Wind.size track.
User entry	0 to 20 500 mm
Factory setting	500 mm
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Maximal track counter



Navigation	Application → Sensor → Add. settings → Echo evaluation → Max track count
User entry	0 to 100
Factory setting	2
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Debug parameter index



Navigation	Application → Sensor → Add. settings → Echo evaluation → Debug parm. idx
User entry	0 to 65 535
Factory setting	2
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert



Debug array index



Navigation	Application → Sensor → Add. settings → Echo evaluation → Debug array indx
User entry	0 to 255
Factory setting	0

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--

Status

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Status
-------------------	---

User entry	0 to 255
-------------------	----------

Factory setting	0
------------------------	---

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--

Debug value

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Debug value
-------------------	--

User interface	Signed floating-point number
-----------------------	------------------------------

Factory setting	4.0
------------------------	-----

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Debug value integer32

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Debug val. int32
-------------------	---


User interface	Positive integer
-----------------------	------------------


Factory setting	0
------------------------	---


Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---


Linearization

Navigation  Application → Sensor → Linearization

Linearization type 

Navigation	 Application → Sensor → Linearization → Lineariz. type
Description	Select type of linearization.
Selection	<ul style="list-style-type: none"> ■ None ■ Linear ■ Table ■ Pyramid bottom ■ Conical bottom ■ Angled bottom ■ Horizontal cylinder ■ Sphere
Factory setting	None

Unit after linearization 

Navigation	 Application → Sensor → Linearization → Unit lineariz.		
Description	Defines the unit of the linearized value. Note: The selected unit is only used to be indicated on the display. The measured value is not transformed according to the selected unit. Note: If "Free text" is selected, an additional parameter "Free text" appears in which the designation of the unit can be defined.		
Selection	<i>SI units</i> <ul style="list-style-type: none"> ■ STon ■ t ■ kg ■ cm³ ■ dm³ ■ m³ ■ hl ■ l ■ % ■ mm ■ m <i>Custom-specific units</i> Free text	<i>US units</i> <ul style="list-style-type: none"> ■ lb ■ UsGal ■ ft³ ■ ft ■ in 	<i>Imperial units</i> impGal
Factory setting	%		

Free text 

Navigation   Application → Sensor → Linearization → Free text

User entry Character string comprising numbers, letters and special characters (32)

Factory setting Free text

Level linearized



Navigation   Application → Sensor → Linearization → Level linearized

Description Displays the linearized level.

User interface Signed floating-point number

Factory setting 0 %

Maximum value 

Navigation   Application → Sensor → Linearization → Maximum value

Description Linearized value corresponding to a level of 100 %.

User entry -200 000 to 200 000.0 %

Factory setting 100.0 %

Diameter 

Navigation   Application → Sensor → Linearization → Diameter

Description Diameter of the spherical tank or horizontal cylinder tank.

User entry 0.001 to 125 000 mm

Factory setting 20 000 mm

Intermediate height



Navigation	Application → Sensor → Linearization → Intermed. height
Description	Height of the pyramid, conical or angled bottom
User entry	0 to 125 000 mm
Factory setting	0 mm

Table mode



Navigation	Application → Sensor → Linearization → Table mode
Description	<p>Defines the editing mode of the linearization table.</p> <p>"Manual" The level and the associated linearized value are entered manually for each linearization point.</p> <p>"Semiautomatic" The level is measured by the device for each linearization point. The associated linearized value is entered manually.</p> <p>"Clear table" Deletes the existing linearization table.</p> <p>"Sort table" Rearranges the linearization points into an ascending order.</p> <p>Note: DeviceCare and FieldCare contain a graphical tool for the easy creation of a linearization table. Device Care: "Additional functions" -> "Linearization table" FieldCare: "Device Operation" -> "Device Functions" -> "Additional functions" -> "Linearization table"</p>
Selection	<ul style="list-style-type: none"> ■ Manual ■ Semiautomatic * ■ Clear table ■ Sort table *
Factory setting	Manual

Table number



Navigation	Application → Sensor → Linearization → Table number
Description	Enter or change the table point.

* Visibility depends on order options or device settings

User entry 1 to 32

Factory setting 1

Level

Navigation   Application → Sensor → Linearization → Level

Description Enter level value of the table point (value before linearization).

User entry Signed floating-point number

Factory setting 0 %

Level

Navigation   Application → Sensor → Linearization → Level

Description Displays measured level (value before linearization). This value is transmitted to the table.

User interface Signed floating-point number

Factory setting 0.0 %

Customer value

Navigation   Application → Sensor → Linearization → Customer value

Description Enter linearized value for the table point.

User entry Signed floating-point number

Factory setting 0 %

Activate table



Navigation	Application → Sensor → Linearization → Activate table
Description	<p>Activate or deactivate table. The table can only be activated if the table values:</p> <ul style="list-style-type: none"> - are present in at least 2 value pairs - do not exceed the sensor limits - represent a function which is monotonically ascending or descending
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Disable

Signal information

Navigation Application → Sensor → Signal inform.


Signal quality

Navigation	Application → Sensor → Signal inform. → Signal quality
Description	Shows the quality of the evaluated level signal.
User interface	<ul style="list-style-type: none"> ▪ Strong ▪ Medium ▪ Weak ▪ No signal
Factory setting	Strong


Absolute echo amplitude

Navigation	Application → Sensor → Signal inform. → Abs. echo ampl.
Description	Shows the absolute amplitude of the evaluated level signal.
User interface	-150.0 to 32.0 dB
Factory setting	0.0 dB


Relative echo amplitude

Navigation	 Application → Sensor → Signal inform. → Relat.echo ampl.
Description	Shows the relative amplitude (i.e. the distance to the evaluation curve) of the evaluated level signal.
User interface	0.0 to 150.0 dB
Factory setting	0.0 dB

Sensor cycle time

Navigation	 Application → Sensor → Signal inform. → Sens. cycle time
User interface	0 to 65 535 ms
Factory setting	0 ms
Additional information	Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: -

Actual IF gain






Navigation	 Application → Sensor → Signal inform. → Actual IF gain
User interface	0 to 1 000
Factory setting	0
Additional information	Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: -

3.3.4 Profibus


Navigation  Application → Profibus

Configuration

Navigation  Application → Profibus → Configuration


Device tag	
Navigation	 Application → Profibus → Configuration → Device tag
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	Micropilot 6xB
Ident number selector	
Navigation	 Application → Profibus → Configuration → Ident num select
Description	In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the general station description (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.
Selection	<ul style="list-style-type: none"> ■ 0x9700 (1AI) ■ FMR6xB 0x1568 ■ Automatic mode
Factory setting	Automatic mode
PROFIBUS ident number	
Navigation	 Application → Profibus → Configuration → Ident number
Description	Shows the Profibus Ident number of the device. Which Ident number is used can be defined in the parameter Ident number selector.
User interface	0 to 65 535
Factory setting	5 480
Endress+Hauser	

Address mode

Navigation	 Application → Profibus → Configuration → Address mode
Description	Shows the address mode that applies to the device address, e.g. 'Hardware' if set via DIP switch
User interface	<ul style="list-style-type: none"> ■ Hardware ■ Software
Factory setting	Software

Device address



Navigation	 Application → Profibus → Configuration → Device address
Description	<p>The device address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered ex works with device address 126 and software addressing.</p> <p>The address can only be written here if it has not already been set via the DIP switches.</p>
User entry	0 to 126
Factory setting	126


Analog input

Navigation  Application → Profibus → Analog input

Analog input 1 to 6

Navigation  Application → Profibus → Analog input → Analog input 1 to 6

Out value

Navigation	 Application → Profibus → Analog input → Analog input 1 to 6 → Out value
Description	Shows the process value reported to the controller for further processing
User entry	Signed floating-point number

Factory setting 0

Out status

Navigation  Application → Profibus → Analog input → Analog input 1 to 6 → Out status


Description Shows the status of the measured value reported to the controller for further processing (Hex). Writeable in Manual mode.

User entry 0 to 255

Factory setting 128

Out unit text



Navigation  Application → Profibus → Analog input → Analog input 1 to 6 → Out unit text

Description If a specific unit of OUT parameter is not in the code list the user has the possibility to write the specific text into this parameter. The unit code is then equal to "textual unit definition".

User entry Character string comprising numbers, letters and special characters (16)

Factory setting %

Channel



Navigation  Application → Profibus → Analog input → Analog input 1 to 6 → Channel



Description Assigns a measured variable to the AI block.

- Selection**
- Level
 - Level linearized
 - Distance
 - Terminal voltage
 - Electronics temperature
 - Sensor temperature
 - Absolute echo amplitude
 - Relative echo amplitude
 - Area of incoupling
 - Buildup index^{*}
 - Foam index^{*}

Factory setting Level

* Visibility depends on order options or device settings

PV filter time 



Navigation   Application → Profibus → Analog input → Analog input 1 to 6 → PV filter time

Description Enter time constant for input damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.

User entry Positive floating-point number

Factory setting 0

Simulate enabled 

Navigation   Application → Profibus → Analog input → Analog input 1 to 6 → Simulate enabled

Description The simulation is used to bypass the physical I/O channel. In this way the block remains in the normal mode and using the simulated discrete I/O channel during operation.

Selection

- Disable
- Enable

Factory setting Disable

Simulate value 

Navigation   Application → Profibus → Analog input → Analog input 1 to 6 → Simulate value

Description The simulation value is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and using the simulated value during operation.

User entry Signed floating-point number

Factory setting 0

Simulate status 

Navigation   Application → Profibus → Analog input → Analog input 1 to 6 → Simulate status

Description To simulate a process status for this block. Possible input values can be taken from the PA profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD"

0x24 (decimal 36) for status "BAD"


User entry 0 to 255

Factory setting 0

Digital input

Navigation  Application → Profibus → Digital input

Digital input 1 to 2

Navigation  Application → Profibus → Digital input → Digital input 1 to 2

Out value

Navigation  Application → Profibus → Digital input → Digital input 1 to 2 → Out value

Description Shows the state of the device function, which is transmitted to the controller for further processing.

User entry 0 to 255

Factory setting 0

Out status

Navigation  Application → Profibus → Digital input → Digital input 1 to 2 → Out status

Description Shows the status of the device function state reported to the controller (Hex). Writeable in Manual mode.

User entry 0 to 255

Factory setting 128

Channel



Navigation  Application → Profibus → Digital input → Digital input 1 to 2 → Channel



Description Select the device function

Selection

- None
- Buildup detected^{*}
- Foam detected^{*}

Factory setting None

Simulate enabled



Navigation   Application → Profibus → Digital input → Digital input 1 to 2 → Simulate enabled

Selection

- Disable
- Enable

Factory setting Disable

Simulate value



Navigation   Application → Profibus → Digital input → Digital input 1 to 2 → Simulate value

Description The simulation value is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and using the simulated value during operation.

User entry 0 to 255

Factory setting 0

Simulate status

Navigation   Application → Profibus → Digital input → Digital input 1 to 2 → Simulate status

Description To simulate a process status for this block. Possible input values can be taken from the PA profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD"


0x24 (decimal 36) for status "BAD"

User entry 0 to 255


Factory setting 0

* Visibility depends on order options or device settings


Analog output

Navigation  Application → Profibus → Analog output


Analog output 1

Navigation  Application → Profibus → Analog output → Analog output 1


Out value

Navigation	 Application → Profibus → Analog output → Analog output 1 → Out value
Description	Shows an analog output value (AO) that is output from the controller to the device and can be shown on the local display. To show the AO on the local display, it must be assigned to a display output parameter as a value. This assignment is made in the menu under "System-Display".
User entry	Signed floating-point number
Factory setting	0

Out status

Navigation	 Application → Profibus → Analog output → Analog output 1 → Out status
Description	Shows the status of the external compensation value reported to the measuring device for further processing (Hex). Writeable in Manual mode.
User entry	0 to 255
Factory setting	128

Out unit

Navigation	 Application → Profibus → Analog output → Analog output 1 → Out unit
User entry	0 to 65 535
Factory setting	1997

Fail-safe type

Navigation	Application → Profibus → Analog output → Analog output 1 → Fail-safe type
Description	Select fail-safe behavior in the event of a failure (value with status 'Bad')
Selection	<ul style="list-style-type: none"> ■ Fixed value ■ Last valid value ■ Off
Factory setting	Last valid value

Fail-safe time

Navigation	Application → Profibus → Analog output → Analog output 1 → Fail-safe time
Description	Enter a delay until in the event of a failure (value with status 'Bad') the fail-safe behavior specified applies
User entry	0 to 999.0
Factory setting	0

Fail-safe value

Navigation	Application → Profibus → Analog output → Analog output 1 → Fail-safe value
Description	Enter value to report in the event of a failure (value with status 'Bad')
User entry	Signed floating-point number
Factory setting	0

Information

Navigation Application → Profibus → Information

Device ID

Navigation	Application → Profibus → Information → Device ID
Description	Shows the device ID used by the manufacturer to identify the measuring device type

User interface Character string comprising numbers, letters and special characters

Factory setting Micropilot 6xB

Profile version

Navigation  Application → Profibus → Information → Profile version

Description Shows the profile version

User interface Character string comprising numbers, letters and special characters

Factory setting 3.02

Statistics

Navigation  Application → Profibus → Statistics

CRC Count OK

Navigation  Application → Profibus → Statistics → CRC Count OK

Description Indicates how often the checksum test of the cyclic data telegram was successful.

User interface Positive integer

Factory setting 0

CRC Count Failed

Navigation  Application → Profibus → Statistics → CRC Count Failed

Description Indicates how often the checksum test of the cyclic data telegram detected an error.

User interface Positive integer

Factory setting 0

3.4 System

Navigation  System

3.4.1 Device management

Navigation  System → Device manag.

Device tag

Navigation  System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Factory setting Micropilot 6xB

Locking status

Navigation  System → Device manag. → Locking status

Description Indicates the type of locking.
 "Hardware locked" (HW)
 The device is locked by the "WP" switch on the main electronics module. To unlock, set the switch into the OFF position.
 "WHG locked" (SW)
 Unlock the device by entering the appropriate access code in "Enter safety unlocking code".
 "Temporarily locked" (SW)
 The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.

User interface

- Hardware locked
- WHG locked
- Temporarily locked

Static revision

Navigation  System → Device manag. → Static revision

Description Shows the number of changes made to static parameters (e.g. configuration parameters)

User interface 0 to 65 535

Factory setting 0

Reset device

Navigation   System → Device manag. → Reset device

Description Reset the device configuration - either entirely or in part - to a defined state

Selection

- Cancel
- To factory defaults *
- To delivery settings *
- Restart device

Factory setting Cancel

3.4.2 User management

Navigation  System → User manag.

User role

Navigation   System → User manag. → User role

Description Shows the access authorization to the parameters via the operating tool

User interface

- Operator
- Maintenance
- Expert

Factory setting Maintenance

Change user role


Navigation  System → User manag. → Change user role

Description It is possible to change the user role.
If the actual role is 'Maintenance', the 'Enter access code' will be prompted.
If the actual role is 'Operator', a 'Maintenance' password will be required.

User entry Character string comprising numbers, letters and special characters (1)


* Visibility depends on order options or device settings

Password



Navigation	 System → User manag. → Password
Description	Enter the password for the "Maintenance" user role to get access to the functionality of this role.
User entry	Character string comprising numbers, letters and special characters (16)

Enter access code







Navigation	 System → User manag. → Ent. access code
Description	For authorized service personnel only.
User entry	0 to 9 999
Factory setting	0




Status password entry



Navigation	  System → User manag. → Status pw entry
Description	Use this function to display the status of the password verification.
User interface	<ul style="list-style-type: none"> ■ ----- ■ Wrong password ■ Password rule violated ■ Password accepted ■ Permission denied ■ Confirm PW mismatch ■ Reset password accepted ■ Invalid user role ■ Wrong sequence of entry
Factory setting	-----




Define password

Navigation	 System → User manag. → Define password
User entry	Character string comprising numbers, letters and special characters (1)

New password		
Navigation	  System → User manag. → New password	
Description	Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers.	
User entry	Character string comprising numbers, letters and special characters (16)	

Confirm new password		
Navigation	  System → User manag. → Confirm password	
Description	Enter the new password again to confirm.	
User entry	Character string comprising numbers, letters and special characters (16)	

Change password		
Navigation	 System → User manag. → Change password	
Description	Changes the 'Maintenance' password.	
User entry	Character string comprising numbers, letters and special characters (1)	

Old password		
Navigation	  System → User manag. → Old password	
Description	Enter the current password, to subsequently change the existing password.	
User entry	Character string comprising numbers, letters and special characters (16)	

Delete password

**Navigation**

System → User manag. → Delete password

Description

Deletes the 'Maintenance' password.
After deleting, the 'Operator' role will be no more available.
All users have read/write access rights.

User entry

Character string comprising numbers, letters and special characters (1)

Forgot password?

Navigation

System → User manag. → Forgot password?

User entry

Character string comprising numbers, letters and special characters (1)

Reset password

Navigation

System → User manag. → Reset password

Description

Enter a code to reset the current "Maintenance" password.
The code is delivered by your local support.

User entry

Character string comprising numbers, letters and special characters (16)

3.4.3 Bluetooth configuration

Navigation System → Bluetooth conf.

Bluetooth activation

Navigation

System → Bluetooth conf. → Bluetooth active

Description

If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool.
Reactivating via the SmartBlue app is not possible.

Selection

- Disable
- Enable

Factory setting Depends on the order option

3.4.4 Display

Navigation  System → Display

Language

Navigation  System → Display → Language


Description Set display language

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting English

Format display

Navigation  System → Display → Format display

Description Select how measured values are shown on the display



Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values

* Visibility depends on order options or device settings

Factory setting 1 value, max. size

Value 1 display

Navigation   System → Display → Value 1 display

Description Select the measured value that is shown on the local display

Selection

- Level
- Level linearized
- Distance
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Buildup index^{*}
- Foam index^{*}
- Terminal voltage
- Electronics temperature
- Sensor temperature
- Unfiltered distance
- Analog output 1

Factory setting Level

Value 2 ... 4 display

Navigation   System → Display → Value 2 display

Description Select the measured value that is shown on the local display

Selection

- None
- Level
- Level linearized
- Distance
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Buildup index^{*}
- Foam index^{*}
- Terminal voltage
- Electronics temperature
- Sensor temperature
- Analog output 1

Factory setting None

* Visibility depends on order options or device settings

Decimal places 1 ... 4



Navigation	System → Display → Decimal places 1
Description	This selection does not affect the measurement and calculation accuracy of the device.
Selection	<ul style="list-style-type: none"> ■ x ■ x.X ■ x.XX ■ x.XXX ■ x.XXXX
Factory setting	x.xx

Contrast display

Navigation	System → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)
User entry	20 to 80 %
Factory setting	30 %


3.4.5 Information

Navigation System → Information


Device name

Navigation	System → Information → Device name
Description	Use this function to display the device name. It can also be found on the nameplate.
User interface	Character string comprising numbers, letters and special characters
Factory setting	Micropilot 6xB

Manufacturer


Navigation	 System → Information → Manufacturer
User interface	Character string comprising numbers, letters and special characters
Factory setting	Endress+Hauser

Serial number


Navigation	 System → Information → Serial number
Description	The serial number is a unique alphanumeric code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.
User interface	Character string comprising numbers, letters and special characters

Order code



Navigation	 System → Information → Order code
Description	Shows the device order code.
User interface	Character string comprising numbers, letters and special characters
Factory setting	- none -
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: Expert

Firmware version

Navigation	 System → Information → Firmware version
Description	Displays the device firmware version installed.
User interface	Character string comprising numbers, letters and special characters

Hardware version

Navigation  System → Information → Hardware version

User interface Character string comprising numbers, letters and special characters

Extended order code 1 ... 3



Navigation  System → Information → Ext. order cd. 1

Description The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**

- Read access: Operator
- Write access: Expert

XML build number

Navigation  System → Information → XML build no.

User interface Positive integer

Additional information **Access:**

- Read access: Expert
- Write access: -

Checksum

Navigation  System → Information → Checksum

Description Checksum for Firmware version.

User interface Positive integer


3.4.6 Additional information

Navigation  System → Additional info


Sensor

Navigation  System → Additional info → Sensor


Serial number

Navigation	 System → Additional info → Sensor → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Sensor → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Build no. software

Navigation	 System → Additional info → Sensor → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Hardware version

Navigation	 System → Additional info → Sensor → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Checksum

Navigation	 System → Additional info → Sensor → Checksum
Description	Checksum for Firmware version.
User interface	Positive integer
Factory setting	0
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Electronics

Navigation  System → Additional info → Electronics


Serial number

Navigation	 System → Additional info → Electronics → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Electronics → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none">▪ Read access: Expert▪ Write access: -


Build no. software

Navigation	 System → Additional info → Electronics → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none">▪ Read access: Expert▪ Write access: -


Hardware version

Navigation	 System → Additional info → Electronics → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none">▪ Read access: Expert▪ Write access: -


Display/Bluetooth

Navigation  System → Additional info → Displ./Bluetooth


Serial number

Navigation	 System → Additional info → Displ./Bluetooth → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Firmware version

Navigation	 System → Additional info → Displ./Bluetooth → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Build no. software

Navigation	 System → Additional info → Displ./Bluetooth → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -


Hardware version

Navigation	 System → Additional info → Displ./Bluetooth → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: -

3.4.7 Software configuration


Navigation  System → Softw. config.

CRC device configuration


Navigation	 System → Softw. config. → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535

Activate SW option



Navigation	 System → Softw. config. → Activate SW opt.
Description	Enter the application package code or code of another re-ordered functionality to enable it
User entry	Positive integer

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options

User interface

- SIL
- WHG
- Heartbeat Verification
- Heartbeat Monitoring



71687792

www.addresses.endress.com
