

Operating Instructions Micropilot FMR51, FMR52 PROFIBUS PA

Free space radar










Table of contents

1	Wichtige Hinweise zum	6.4	Installation in vessel (free space)	
	Dokument		6.4.1 Horn antenna (FMR51)	26
1.1	Document function 5		through plastic walls (FMR50/	
1.2	Symbols		FMR51)	28
	1.2.1 Safety symbols		(FMR52)	29
	1.2.3 Tool symbols 5	6.5		30
	1.2.4 Symbols for		6.5.1 Recommendations for the stilling	20
	certain types of information 6 1.2.5 Symbols in graphics 6		well	30
	1.2.6 Symbols at the device			31
1.3	Additional documentation 7	6.6	Installation in bypass	32
1.4 1.5	Terms and abbreviations		6.6.1 Recommendations for the bypass	32
1.5	Registered trademarks		6.6.2 Example for the construction of a	
2	Basic safety instructions 10	6.7	J 1	33 34
2.1	Requirements for the personnel	6.8		34
2.2 2.3	Designated use	6.9	Turning the display	35
2.4	Workplace safety		6.9.1 Opening cover	
2.5	Product safety		6.9.2 Turning the display module6.9.3 Closing electronics compartment	35
	2.5.1 CE mark		3	36
2.6	2.5.2 EAC conformity	6.10	Post-installation check	36
0	5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	7	Electrical connection	37
-≺	Product description 15			
3	Product description	7.1	Connection conditions	37
3.1	Product design	7.1	7.1.1 Terminal assignment	37
	Product design	7.1	7.1.1 Terminal assignment	37 39
	Product design	7.1	7.1.1 Terminal assignment	37 39 40
	Product design	7.1	7.1.1 Terminal assignment	37 39 40
	Product design	7.1	7.1.1 Terminal assignment	37 39 40 41 41
3.1	Product design		7.1.1 Terminal assignment	37 39 40 41 41 42
3.1	Product design		7.1.1 Terminal assignment	37 39 40 41 42 42
3.1 4	Product design 15 3.1.1 Micropilot FMR51 15 3.1.2 Micropilot FMR52 15 3.1.3 Electronics housing 16 Incoming acceptance and product identification 17 Incoming acceptance 17 Product identification 17		7.1.1 Terminal assignment	37 39 40 41 42 42 43
3.1 4 4.1	Product design		7.1.1 Terminal assignment	37 39 40 41 42 42 43 43
3.1 4 4.1	Product design 15 3.1.1 Micropilot FMR51 15 3.1.2 Micropilot FMR52 15 3.1.3 Electronics housing 16 Incoming acceptance and product identification 17 Incoming acceptance 17 Product identification 17 4.2.1 Nameplate 18		7.1.1 Terminal assignment	37 39 40 41 42 42 43 43
3.1 4 4.1 4.2	Product design 15 3.1.1 Micropilot FMR51 15 3.1.2 Micropilot FMR52 15 3.1.3 Electronics housing 16 Incoming acceptance and product identification 17 Incoming acceptance 17 Product identification 17 4.2.1 Nameplate 18	7.2 7.3	7.1.1 Terminal assignment	37 39 40 41 42 43 43 44 44
3.1 4 4.1 4.2 5	Product design 15 3.1.1 Micropilot FMR51 15 3.1.2 Micropilot FMR52 15 3.1.3 Electronics housing 16 Incoming acceptance and product identification 17 Incoming acceptance 17 Product identification 17 4.2.1 Nameplate 18 Storage, Transport 19	7.2 7.3 8	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options	37 39 40 41 42 42 43 43 44 46
3.1 4 4.1 4.2 5 5.1 5.2	Product design	7.2 7.3	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview	37 39 40 41 42 43 43 44 46 46
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation	37 39 40 41 42 43 43 44 46 46
3.1 4 4.1 4.2 5 5.1 5.2	Product design	7.2 7.3 8	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview	37 40 41 42 43 44 44 46 46
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8 8.1	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation 8.1.2 Operation with remote display and operating module FHX50 8.1.3 Remote operation	37 40 41 42 43 44 46 46 46
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation 8.1.2 Operation with remote display and operating module FHX50 8.1.3 Remote operation Structure and function of the operating	379401442 4234 444 46 447
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8 8.1	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation 8.1.2 Operation with remote display and operating module FHX50 8.1.3 Remote operation Structure and function of the operating menu	37 39 41 42 42 43 44 46 46 47
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8 8.1	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation 8.1.2 Operation with remote display and operating module FHX50 8.1.3 Remote operation Structure and function of the operating menu 8.2.1 Structure of the operating menu 8.2.2 User roles and related access	33904142 4233 444 46 46 47 49
3.1 4 4.1 4.2 5 5.1 5.2 6	Product design	7.2 7.3 8 8.1	7.1.1 Terminal assignment 7.1.2 Cable specification 7.1.3 Device plug connectors 7.1.4 Supply voltage 7.1.5 Overvoltage protection Connecting the measuring device 7.2.1 Opening connection compartment cover 7.2.2 Connecting 7.2.3 Plug-in spring-force terminals 7.2.4 Closing connection compartment cover Post-connection check Operation options Overview 8.1.1 Local operation 8.1.2 Operation with remote display and operating module FHX50 8.1.3 Remote operation Structure and function of the operating menu 8.2.1 Structure of the operating menu 8.2.2 User roles and related access authorization	3794414 424343 444 46 447 49

3.3	Display and operating module	56		14.1.3 Replacement of an electronics	86
	8.3.2 Operating elements	59 60			86 86
	8.3.4 Opening the context menu		14.2		87
	8.3.5 Envelope curve on the display and	02	14.3	* *	87
	operating module	63	14.4		87
9	Integration into a PROFIBUS		15		88
	network	64	15.1	*	88
9.1	Overview of the device database files (GSD)	64		15.1.1 Weather protection cover	88
9.2	Set device address	64		15.1.2 Remote display FHX50	89 90
	9.2.1 Hardware adressing	64		15.1.4 Horn protection for horn antenna	90
	9.2.2 Software addressing	64		with variable antenna extension	91
				15.1.5 Overvoltage protection	92
10	Commissioning via wizard	66		15.1.6 Gas-tight feedthrough	92
					93
11	Commissioning via operating		15.2	1	94
	menu	67	15.3 15.4	*	94
11.1	Installation and function check		15.4	System components	94
11.2	Setting the operating language		16	Operating many	05
11.3	Configuration of a level measurement	68		Operating menu	כפ
11.4	Recording the reference curve	70	16.1	Overview of the operating menu (display	٥٢
11.5	Configuration of the on-site display	71	16.2	module)	95
	11.5.1 Factory settings of the on-site	71	10.2		L02
	display	71 71	16.3		109
11.6	Configuration management	72			L17
11.7	Protection of the settings against	, _		<i>3</i> 1	119
	unauthorized changes	73	16.	<u> </u>	121
			16.4	3	L62 L64
12	Diagnostics and troubleshooting	74		3	165
12.1	General trouble shooting	74		3	166
	12.1.1 General errors			16.4.4 "Measured values" submenu 1	
	12.1.2 Parametrization errors	74		3 1	L70
12.2	Diagnostic information on local display			55 5	L72
	12.2.1 Diagnostic message	76			L75
12.3	12.2.2 Calling up remedial measures Diagnostic event in the operating tool	78 79			L79 L81
12.4	Diagnostic list	80		10.4.) Heartbeat Submenu	101
12.5	Overview of diagnostic events		Inde	x 1	82
12.6	Event logbook		muez	· · · · · · · · · · · · · · · · · · ·	OZ
	12.6.1 Event history				
	12.6.2 Filtering the event logbook				
12.7	12.6.3 Overview of information events Firmware history				
13	Maintenance	85			
13.1	Exterior cleaning				
13.2	Replacing seals	85			
14	Repairs	86			
14.1	General information on repairs	86			
	14.1.1 Repair concept	86			

1 Wichtige Hinweise zum Dokument

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

Symbol	Meaning
▲ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
▲ WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
A CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
===	Direct current
~	Alternating current
$\overline{\sim}$	Direct current and alternating current
-	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device: Inner ground terminal: Connects the protectiv earth to the mains supply. Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Tool symbols

Symbol	Meaning
A0013442	Torx screwdriver
	Flat blade screwdriver

Symbol	Meaning
A0011219	Cross-head screwdriver
A0011219	Allen key
A0011222	Hexagon wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning
✓	Permitted Procedures, processes or actions that are permitted.
✓ ✓	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation.
A=	Reference to page.
	Reference to graphic.
>	Notice or individual step to be observed.
1., 2., 3	Series of steps.
L	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3	Item numbers
1., 2., 3	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area Indicates a hazardous area.
×	Safe area (non-hazardous area) Indicates the non-hazardous area.

1.2.6 Symbols at the device

Symbol	Meaning
$\triangle \rightarrow \square$	Safety instructions Observe the safety instructions contained in the associated Operating Instructions.
	Temperature resistance of the connection cables Specifies the minimum value of the temperature resistance of the connection cables.

Additional documentation 1.3

Document	Purpose and content of the document				
Technical Information TI01040F (FMR51, FMR52)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.				
Brief Operating Instructions KA01129F (FMR51/FMR52, PROFIBUS PA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.				
Description of Device Parameters GP01018F (FMR5x, PROFIBUS PA)	Reference for your parameters The document provides a detailed explanation of each individual parameter in the operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.				
Special documentation SD01087F	Functional Safety Manual The document is part of the Operating Instructions and serves as a reference for application-specific parameters and notes.				
Special documentation SD01870F	Manual for Heartbeat Verification and Heartbeat Monitoring The document contains descriptions of the additional parameters and technical data which are available with the Heartbeat Verification and Heartbeat Monitoring application packages.				

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The W@M Device Viewer: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

1.4 Terms and abbreviations

Term/abbreviation	Explanation
BA	Document type "Operating Instructions"
KA	Document type "Brief Operating Instructions"
TI	Document type "Technical Information"
SD	Document type "Special Documentation"
XA	Document type "Safety Instructions"
PN	Nominal pressure
MWP	Maximum Working Pressure The MWP can also be found on the nameplate.
ToF	Time of Flight
FieldCare	Scalable software tool for device configuration and integrated plant asset management solutions
DeviceCare	Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices
DTM	Device Type Manager
DD	Device Description for HART communication protocol
$\epsilon_{\rm r}$ (DC value)	Relative dielectric constant
Operating tool	The term "operating tool" is used in place of the following operating software: FieldCare / DeviceCare, for operation via HART communication and PC SmartBlue (app), for operation using an Android or iOS smartphone or tablet.
BD	Blocking Distance; no signals are analyzed within the BD.
PLC	Programmable Logic Controller
CDI	Common Data Interface
PFS	Pulse Frequence Status (Switching output)

1.5 Registered trademarks

PROFIBUS®

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple[®]

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ®, VITON®

Registered trademark of DuPont Performance Elastomers L.L.C., Wilmington, USA

TEFLON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI CLAMP®

Registered trademark of Alfa Laval Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use

Application and measured materials

The measuring device described in these Operating Instructions is intended for the continuous, contactless level measurement of liquids, pastes and sludge. The device can also be freely mounted outside closed metal vessels (e.g. above basins, open channels or open piles) because of its operating frequency of about 26 GHz, a maximum radiated pulsed power of 5.7 mW and an average power output of 0.015 mW (for the version with advanced dynamics: maximum pulse power: $23.3 \, \text{mW}$; average power: $0.076 \, \text{mW}$). Operation is completely harmless to humans and animals.

Observing the limit values specified in the "Technical data" and listed in the Operating Instructions and supplementary documentation, the measuring device may be used for the following measurements only:

- ► Measured process variables: level, distance, signal strength
- ► Calculated process variables: Volume or mass in arbitrarily shaped vessels; flow through measuring weirs or flumes (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Use the measuring device only for measured materials against which the processwetted materials are adequately resistant.
- ▶ Observe the limit values in "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-designated use.

Verification for borderline cases:

► For special measured materials and cleaning agents, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of wetted materials, but does not accept any warranty or liability.

Residual risk

The electronics housing and its built-in components such as display module, main electronics module and I/O electronics module may heat to 80 $^{\circ}$ C (176 $^{\circ}$ F) during operation through heat transfer from the process as well as power dissipation within the electronics. During operation the sensor may assume a temperature near the temperature of the measured material.

Danger of burns due to heated surfaces!

► For high process temperatures: Install protection against contact in order to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from the manufacturer only.

Hazardous area

To eliminate a danger for persons or for the facility when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area.
- ▶ Observe the specifications in the separate supplementary documentation that is an integral part of these Instructions.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

▶ If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 **CE mark**

The measuring system meets the legal requirements of the applicable EC guidelines. These are listed in the corresponding EC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity

The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the EAC mark.

2.6 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

Feature	Approval	Available for	Feature 020 "Power Supply; Output"				
010			A 1)	B 2)	C ₃₎	E ⁴⁾ /G ⁵⁾	K 6)/L 7)
BA	ATEX: II 1 G Ex ia IIC T6-T1 Ga	FMR51FMR52	XA00677F	XA00677F	XA00677F	XA00685F	-
BB	ATEX: II 1/2 G Ex ia IIC T6-T1 Ga/Gb	FMR51FMR52	XA00677F	XA00677F	XA00677F	XA00685F	-
ВС	ATEX: II 1/2 G Ex d [ia] IIC T6-T1 Ga/Gb	FMR51FMR52	XA00680F	XA00680F	XA00680F	XA00688F	XA00680F
BD	ATEX: II 1/2/3 G Ex ic [ia Ga] IIC T6-T1 Ga/Gb/Gc	FMR51FMR52	XA00678F	XA00678F	XA00678F	XA00686F	XA00678F
BG	ATEX: II 3 G Ex nA IIC T6-T1 Gc	FMR51FMR52	XA00679F	XA00679F	XA00679F	XA00687F	XA00679F
ВН	ATEX: II 3 G Ex ic IIC T6-T1 Gc	FMR51FMR52	XA00679F	XA00679F	XA00679F	XA00687F	XA00679F
BL	ATEX: II 1/2/3 G Ex nA [ia Ga] IIC T6-T1 Ga/Gb/Gc	FMR51FMR52	XA00678F	XA00678F	XA00678F	XA00686F	XA00678F
B2	ATEX: II 1/2 G Ex ia IIC T6-T1 Ga/Gb ATEX: II 1/2 D Ex ia IIIC Txx°C Da/Db	FMR51FMR52	XA00683F	XA00683F	XA00683F	XA00691F	-
В3	ATEX: II 1/2 G Ex d [ia] IIC T6-T1 Ga/Gb ATEX: II 1/2 D Ex ta IIIC Txx°C Da/Db	FMR51FMR52	XA00684F	XA00684F	XA00684F	XA00692F	XA00684F
B4	ATEX:II 1/2 G Ex ia IIC T6-T1 Ga/Gb ATEX: II 1/2 G Ex d [ia] IIC T6-T1 Ga/Gb	FMR51FMR52	XA00681F	XA00681F	XA00681F	XA00689F	-
CD	CSA C/US DIP Cl.II,III Div.1 Gr.E-G	FMR51	XA01113F	XA01113F	XA01113F	XA01115F	XA01113F
C2	CSA C/US IS Cl.I,II,III Div.1 Gr.A-G, NI Cl.1 Div. 2, Ex ia	FMR51FMR52	XA01112F	XA01112F	XA01112F	XA01114F	-
C3	CSA C/US XP Cl.I,II,III Div.1 Gr.A-G, NI Cl.1 Div.2, Ex d	FMR51FMR52	XA01113F	XA01113F	XA01113F	XA01115F	XA01113F
FB	FM IS Cl.I,II,III Div.1 Gr.A-G, AEx ia, NI Cl.1 Div.2	FMR51FMR52	XA01116F	XA01116F	XA01116F	XA01118F	-
FD	FM XP Cl.I,II,III Div.1 Gr.A-G, AEx d, NI Cl.1 Div.2	FMR51FMR52	XA01117F	XA01117F	XA01117F	XA01119F	XA01117F
FE	FM DIP Cl.II,III Div.1 Gr.E-G	FMR51	XA01117F	XA01117F	XA01117F	XA01119F	XA01117F
IA	IECEx: Ex ia IIC T6-T1 Ga	FMR51FMR52	XA00677F	XA00677F	XA00677F	XA00685F	-
IB	IECEx: Ex ia IIC T6-T1 Ga/Gb	FMR51FMR52	XA00677F	XA00677F	XA00677F	XA00685F	-
IC	IECEx: Ex d [ia] IIC T6-T1 Ga/Gb	FMR51FMR52	XA00680F	XA00680F	XA00680F	XA00688F	XA00680F
ID	IECEx: Ex ic [ia Ga] IIC T6-T1 Ga/Gb/Gc	FMR51FMR52	XA00678F	XA00678F	XA00678F	XA00686F	XA00678F

Feature	Approval Avai	Available for		Feature 02	0 "Power Supp	ly; Output"	
010			A 1)	B ²⁾	C 3)	E ⁴⁾ /G ⁵⁾	K ⁶⁾ /L ⁷⁾
IG	IECEx: Ex nA IIC T6-T1 Gc	FMR51FMR52	XA00679F	XA00679F	XA00679F	XA00687F	XA00679F
IH	IECEx: Ex ic IIC T6-T1 Gc	FMR51FMR52	XA00679F	XA00679F	XA00679F	XA00687F	XA00679F
IL	IECEx: Ex nA [ia Ga] IIC T6-T1 Ga/Gb/Gc	FMR51FMR52	XA00678F	XA00678F	XA00678F	XA00686F	XA00678F
I2	IECEx: Ex ia IIC T6-T1 Ga/Gb IECEx: Ex ia IIIC Txx°C Da/Db	FMR51FMR52	XA00683F	XA00683F	XA00683F	XA00691F	-
I3	IECEx: Ex d [ia] IIC T6-T1 Ga/Gb IEXEx: Ex ta IIIC Txx°C Da/Db	FMR51FMR52	XA00684F	XA00684F	XA00684F	XA00692F	XA00684F
I4	IECEx: Ex ia IIC T6-T1 Ga/Gb IECEx: Ex d [ia] IIC T6-T1 Ga/Gb	FMR51FMR52	XA00681F	XA00681F	XA00681F	XA00689F	-
JA	JPN Ex d ia IIC T4 Ga/Gb	FMR51FMR52	XA01716F	XA01716F	-	-	-
JC	JPN Ex d [ia] IIC T4 Ga/Gb	FMR51FMR52	XA01717F	XA01717F	-	-	-
JD	JPN Ex d [ia] IIC T1 Ga/Gb	FMR51	XA01717F	XA01717F	-	-	-
JE	JPN Ex d [ia] IIC T2 Ga/Gb	FMR51	XA01717F	XA01717F			
JF	JPN Ex d [ia] IIC T3 Ga/Gb	FMR52	XA01717F	XA01717F	-	-	-
KA	KC Ex ia IIC T6 Ga	FMR51FMR52	XA01045F	XA01045F	XA01045F	XA01047F	-
KB	KC Ex ia IIC T6 Ga/Gb	FMR51FMR52	XA01045F	XA01045F	XA01045F	XA01047F	-
KC	KC Ex d[ia] IIC T6	FMR51FMR52	XA01046F	XA01046F	XA01046F	XA01048F	XA01046F
MA	INMETRO: Ex ia IIC T6 Ga	FMR51FMR52	XA01286F	XA01287F	XA01288F	XA01296F	-
MC	INMETRO: Ex d[ia] IIC T6 Ga/Gb	FMR51FMR52	XA01292F	XA01292F	XA01293F	XA01298F	XA01294F
МН	INMETRO: Ex ic IIC T6 Gc	FMR51FMR52	XA01289F	XA01290F	XA01291F	XA01297F	-
NA	NEPSI Ex ia IIC T6 Ga	FMR51FMR52	XA01199F	XA01199F	XA01199F	XA01208F	-
NB	NEPSI Ex ia IIC T6 Ga/Gb	FMR51FMR52	XA01199F	XA01199F	XA01199F	XA01208F	-
NC	NEPSI Ex d[ia] IIC T6 Ga/Gb	FMR51FMR52	XA01202F	XA01202F	XA01202F	XA01211F	XA01202F
NG	NEPSI Ex nA II T6 Gc	FMR51FMR52	XA01201F	XA01201F	XA01201F	XA01210F	XA01201F
NH	NEPSI Ex ic IIC T6 Gc	FMR51FMR52	XA01201F	XA01201F	XA01201F	XA01210F	XA01201F
N2	NEPSI Ex ia IIC T6 Ga/Gb, Ex iaD 20/21 T85 90oC	FMR51FMR52	XA01205F	XA01205F	XA01205F	XA01214F	-

Endress+Hauser

Feature	Approval	Available for	ilable for Feature 020 "Power Supply; Output"				
010		A 1)	B 2)	C 3)	E ⁴⁾ /G ⁵⁾	K ⁶⁾ /L ⁷⁾	
N3	NEPSI Ex d[ia] IIC T6 Ga/Gb, DIP A20/21 T8590oC IP66	FMR51FMR52	XA01206F	XA01206F	XA01206F	XA01215F	XA01206F
8A	FM/CSA IS+XP Cl.I,II,III Div.1 Gr.A-G	• FMR51 • FMR52	XA01113FXA01116F	XA01112FXA01113FXA01116FXA01117F	XA01113FXA01116F	XA01115FXA01118F	

- 1) 2-wire; 4-20mA HART
- 2) 2-wire; 4-20mA HART, switch output
- 3) 2-wire; 4-20mA HART, 4-20mA
- 4) 2-wire; FOUNDATION Fieldbus, switch output
- 5) 2-wire; PROFIBUS PA, switch output
- 6) 4-wire 90-253VAC; 4-20mA HART
- 7) 4-wire 10.4-48VDC; 4-20mA HART

For certified devices the relevant Safety Instructions (XA) are indicated on the nameplate.

If the device is prepared for the remote display FHX50 (product structure: feature 030: Display, Operation", option L or M), the Ex marking of some certificates changes according to the following table $^{1)}$:

Feature 010 ("Approval")	Feature 030 ("Display, Operation")	Ex marking
BG	L, M or N	ATEX II 3G Ex nA [ia Ga] IIC T6-T1 Gc
ВН	L, M or N	ATEX II 3G Ex ic [ia Ga] IIC T6-T1 Gc
В3	L, M or N	ATEX II 1/2G Ex d [ia] IIC T6-T1 Ga/Gb, ATEX II 1/2D Ex ta [ia Db] IIIC Txx°C Da/Db
IG	L, M or N	IECEx Ex nA [ia Ga] IIC T6-T1 Gc
IH	L, M or N	IECEx Ex ic [ia Ga] IIC T6-T1 Gc
I3	L, M or N	IECEx Ex d [ia] IIC T6-T1 Ga/Gb, IECEx Ex ta [ia Db] IIIC Txx°C Da/Db
МН	L, M or N	Ex ic [ia Ga] IIC T6 Gc
NG	L, M or N	NEPSI Ex nA [ia Ga] IIC T6-T1 Gc
NH	L, M or N	NEPSI Ex ic [ia Ga] IIC T6-T1 Gc
N3	L, M or N	NEPSI Ex d [ia] IIC T6-T1 Ga/Gb, DIP A20/21 [ia D] TA, Txx°C IP6X


14

¹⁾ The marking of certificates not mentioned in this table are not affected by the FHX50.

Product description 3


3.1 Product design

3.1.1 Micropilot FMR51




- **■** 1 Design of the Micropilot FMR51 (26 GHz)
- Electronics housing
- Process connection (Thread) 2
- Horn antenna
- Flange
- Antenna extension

Micropilot FMR52 3.1.2



- **₽** 2 Design of the Micropilot FMR52 (26 GHz)
- Electronics housing
- Tri-Clamp process connection
- Dairy coupling
- PTFE cladding
- Flange

3.1.3 **Electronics housing**



₽ 3 Design of the electronics housing

- ${\it Electronics\ compartment\ cover}$
- Display module 2
- Main electronics module 3
- Cable glands (1 or 2, depending on instrument version)
- Nameplate
- I/O electronics module
- Terminals (pluggable spring terminals)
 Connection compartment cover
- Grounding terminal

16

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Upon receipt of the goods check the following:

- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- Is the DVD with the operating tool present?
 If required (see nameplate): Are the Safety Instructions (XA) present?
- If one of these conditions is not satisfied, contact your Endress+Hauser Sales Center.

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Extended order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Nameplate



• 4 Nameplate of the Micropilot

- 1 Device name
- 2 Address of manufacturer
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Antenna length (only for FMR51 with antenna extension)
- 8 Certificate symbol
- 9 Certificate and approval relevant data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 Data Matrix Code
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Temperature resistance of the cable
- 16 Device revision
- 17 Additional information about the device version (certificates, approvals, communication): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 Profibus PA: Profil-Version; FOUNDATION Fieldbus: Device ID
- 21 Material in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the thread of the cable glands
- 24 Maximum process temperature
- 25 Signal outputs
- 26 Operating voltage
- Only 33 digits of the extended order code can be indicated on the nameplate. If the extended order code exceeds 33 digits, the rest will not be shown. However, the complete extended order code can be viewed in the operating menu of the device: **Extended order code 1 to 3** parameter

5 Storage, Transport

5.1 Storage conditions


- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use the original packaging.

5.2 Transport product to the measuring point

NOTICE

Housing or antenna horn may be damaged or break away. Risk of injury!

- ► Transport the measuring device to the measuring point in its original packaging or at the process connection.
- ▶ Do not fasten lifting devices (hoisting slings, lifting eyes etc.) at the housing or the antenna horn but at the process connection. Take into account the mass center of the device in order to avoid unintended tilting.
- ► Comply with the safety instructions, transport conditions for devices over 18kg (39.6lbs) (IEC61010).




A0016875

6 Installation


6.1 Installation conditions

6.1.1 Mounting position




- Recommended distance A from wall to outer edge of nozzle: ~ 1/6 of tank diameter.
 - Nevertheless the device should not be installed closer than $15\ cm\ (5.91\ in)$ to the tank wall.
- Not in the center (2), as interference can cause signal loss.
- Not above the fill stream (3).
- It is recommended to us a weather protection cover (1) in order to protect the device from direct sun or rain.

6.1.2 Vessel installations




6.1.3 Reduction of interference echoes



Metallic screens mounted at a slope spread the radar signal and can, therefore, reduce interference echoes.

6.1.4 Measurement in a plastic vessel

If the outer wall of the vessel is made of a non-conductive material (e.g. GRP), microwaves can also be reflected off interfering installations outside the vessel (e.g. metallic pipes (1), ladders (2), grates (3), ...). Therefore, there should be no such interfering installations in the signal beam. Please contact Endress+Hauser for further information.



A0017123

6.1.5 Optimization options

Antenna size


Mapping

The measurement can be optimized by means of electronic suppression of interference

See the **Confirm distance** parameter ($\Rightarrow \implies 114$) for details.

- Antenna alignment
 - Take into account the marker on the flange or threaded connection.
- Stilling well
 - A stilling well can be applied to avoid interferences $\rightarrow \blacksquare 30$.
- Metallic screens mounted at a slope
 - They spread the radar signals and can, therefore, reduce interference echoes.

6.1.6 Beam angle



 \blacksquare 5 Relationship between beam angle α , distance D and beamwidth diameter W

The beam angle is defined as the angle α where the energy density of the radar waves reaches half the value of the maximum energy density (3-dB-width). Microwaves are also emitted outside the signal beam and can be reflected off interfering installations.

Beam diameter W as a function of beam angle α and measuring distance \boldsymbol{D} :

FMR51						
Antenna size	40 mm (1½ in)	50 mm (2 in)	80 mm (3 in)	100 mm (4 in)		
Beam angle α	23°	18°	10°	8°		
Measuring distance (D)		Beamwidth dia	ameter W			
3 m (9.8 ft)	1.22 m (4 ft)	0.95 m (3.1 ft)	0.53 m (1.7 ft)	0.42 m (1.4 ft)		
6 m (20 ft)	2.44 m (8 ft)	1.9 m (6.2 ft)	1.05 m (3.4 ft)	0.84 m (2.8 ft)		
9 m (30 ft)	3.66 m (12 ft)	2.85 m (9.4 ft)	1.58 m (5.2 ft)	1.26 m (4.1 ft)		
12 m (39 ft)	4.88 m (16 ft)	3.80 m (12 ft)	2.1 m (6.9 ft)	1.68 m (5.5 ft)		
15 m (49 ft)	6.1 m (20 ft)	4.75 m (16 ft)	2.63 m (8.6 ft)	2.10 m (6.9 ft)		
20 m (66 ft)	8.14 m (27 ft)	6.34 m (21 ft)	3.50 m (11 ft)	2.80 m (9.2 ft)		
25 m (82 ft)	10.17 m (33 ft)	7.92 m (26 ft)	4.37 m (14 ft)	3.50 m (11 ft)		
30 m (98 ft)	-	9.50 m (31 ft)	5.25 m (17 ft)	4.20 m (14 ft)		
35 m (115 ft)	-	11.09 m (36 ft)	6.12 m (20 ft)	4.89 m (16 ft)		
40 m (131 ft)	-	12.67 m (42 ft)	7.00 m (23 ft)	5.59 m (18 ft)		
45 m (148 ft)	-	-	7.87 m (26 ft)	6.29 m (21 ft)		
60 m (197 ft)	-	-	10.50 m (34 ft)	8.39 m (28 ft)		
70 m (230 ft)	-	-	-	9.79 m (32 ft)		


FMR52				
Antenna size	50 mm (2 in)	80 mm (3 in)		
Beam angle α	18°	10°		
Measuring distance (D)	Beamwidth d	iameter W		
3 m (9.8 ft)	0.95 m (3.1 ft)	0.53 m (1.7 ft)		
6 m (20 ft)	1.9 m (6.2 ft)	1.05 m (3.4 ft)		
9 m (30 ft)	2.85 m (9.4 ft)	1.58 m (5.2 ft)		
12 m (39 ft)	3.80 m (12 ft)	2.1 m (6.9 ft)		
15 m (49 ft)	4.75 m (16 ft)	2.63 m (8.6 ft)		
20 m (66 ft)	6.34 m (21 ft)	3.50 m (11 ft)		
25 m (82 ft)	7.92 m (26 ft)	4.37 m (14 ft)		
30 m (98 ft)	9.50 m (31 ft)	5.25 m (17 ft)		
35 m (115 ft)	11.09 m (36 ft)	6.12 m (20 ft)		
40 m (131 ft)	12.67 m (42 ft)	7.00 m (23 ft)		
45 m (148 ft)	-	7.87 m (26 ft)		
60 m (197 ft)	-	10.50 m (34 ft)		

6.2 Measuring conditions

- In case of **boiling surfaces**, **bubbling** or tendency for **foaming** use FMR53 or FMR54. Depending on its consistence, foam can either absorb microwaves or reflect them off the foam surface. Measurement is possible under certain conditions. For FMR50, FMR51 and FMR52, the additional option "Advanced dynamics" is recommended in these cases (feature 540: "Application Package", option EM).
- In case of heavy steam development or condensate, the maximum measuring range of FMR50, FMR51 and FMR52 may decrease depending on density, temperature and composition of the steam → use FMR53 or FMR54.
- For the measurement of absorbing gases such as **ammonia NH**₃ or some **fluorocarbons** ²⁾, please use Levelflex or Micropilot FMR54 in a stilling well.
- The measuring range begins, where the beam hits the tank bottom. Particularly with dish bottoms or conical outlets the level cannot be detected below this point.
- In stilling well applications, the electromagnetic waves do not propagate completely outside the tube. It must be taken into account that the accuracy may be reduced in the area **C**. In order to guarantee the required accuracy in these cases, it is recommended to position the zero-point at a distance **C** above the end of the tube (see figure).
- In case of media with a low dielectric constant $(\epsilon_r = 1.5 \text{ to } 4)^{3)}$ the tank bottom can be visible through the medium at low levels (low height \mathbf{C}). Reduced accuracy has to be expected in this range. If this is not acceptable, we recommend positioning the zero point at a distance \mathbf{C} (see figure) above the tank bottom in these applications.
- In principle it is possible to measure up to the tip of the antenna with FMR51, FMR53 and FMR54. However, due to considerations regarding corrosion and build-up, the end of the measuring range should not be chosen any closer than **A** (see figure) to the tip of the antenna.
- When using FMR54 with planar antenna, especially for media with low dielectric constants, the end of the measuring range should not be closer than A: 1 m (3.28 ft) to the flange.
- The smallest possible measuring range **B** depends on the antenna version (see figure).
- The tank height should be at least **H** (see table).

²⁾ Affected compounds are e.g. R134a, R227, Dymel 152a.

³⁾ Dielectric constants of important media commonly used in various industries are summarized in the DC manual (CP01076F) and in the Endress +Hauser "DC Values App" (available for Android and iOS).



Device	A [mm (in)]	B [m (ft)]	C [mm (in)]	H [m (ft)]
FMR51	50(1.97)	> 0.2 (0.7)	50 to 250 (1.97 to 9.84)	> 0.3 (1.0)
FMR52	200(7.87)	/ U.Z (U.7)	JU tu 2JU (1.97 tu 9.04)	/ 0.3 (1.0)

6.3 Mounting cladded flanges

- Use flange screws according to the number of flange holes.
 - Tighten the screws with the required torque (see table).
 - Retighten the screws after 24 hours or after the first temperature cycle.
 - Depending on process pressure and process temperature check and retighten the screws at regular intervals.
- Usually, the PTFE flange cladding also serves as a seal between the nozzle and the device flange.

Flange size	Number of screws	Recommended torque [Nm]	
		minimum	maximum
EN			
DN50/PN16	4	45	65
DN80/PN16	8	40	55
DN100/PN16	8	40	60
DN150/PN16	8	75	115
ASME			
2"/150lbs	4	40	55
3"/150lbs	4	65	95
4"/150lbs	8	45	70
6"/150lbs	8	85	125


Flange size	Number of screws	Recommended torque [Nm]	
		minimum maximum	
JIS			
10K 50A	4	40	60
10K 80A	8	25	35
10K 100A	8	35	55
10K 100A	8	75	115

6.4 Installation in vessel (free space)

6.4.1 Horn antenna (FMR51)

Alignment


- Align the antenna vertically to the product surface.
 The maximum range may be reduced if the horn antenna is not vertically aligned.
- A marking at the flange (somewhere between the flange holes) or the boss enables alignment of the antenna. This marking must be aligned towards the tank wall as well as possible.



Depending on the device version the marking may be a circle or two short parallel lines.

Nozzle mounting

For optimum measurement, the tip of the antenna should extend below the nozzle. Depending on the antenna size this is achieved by the following maximum nozzle heights:




■ 6 Nozzle height for horn antenna (FMR51)

Antenna 1)	Maximum nozzle height H_{max}
BA: Horn 40mm/1-1/2"	86 mm (3.39 in)
BB: Horn 50mm/2"	115 mm (4.53 in)
BC: Horn 80mm/3"	211 mm (8.31 in)
BD Horn 100mm/4"	282 mm (11.1 in)

1) Feature 070 of the product structure

Conditions for longer nozzles

If the medium has good reflective properties, higher nozzles can be accepted. In this case the maximum nozzle height, H_{max} , is dependent on the nozzle diameter, D:



A0023611

Nozzle diameter D		Recommended antenna ¹⁾
40 mm (1.5 in)	100 mm (3.9 in)	BA: Horn 40mm/1-1/2"
50 mm (2 in)	150 mm (5.9 in)	BB: Horn 50mm/2"
80 mm (3 in)	250 mm (9.8 in)	BC: Horn 80mm/3"

Nozzle diameter D		Recommended antenna ¹⁾
100 mm (4 in)	500 mm (19.7 in)	BD: Horn 100mm/4"
150 mm (6 in)	800 mm (31.5 in)	BD: Horn 100mm/4"

- 1) Feature 070 of the product structure
- If the antenna doesn't extend below the nozzle, observe the following:
 - The nozzle end must be smooth and free of burrs. If possible its edge should be rounded.
 - An interference echo suppression must be performed.
 - Please contact Endress+Hauser for applications with higher nozzles than those indicated in the table.
- For mounting in heigh nozzles the device is available in a version with an antenna extension of up to 1000 mm (39.4 in) 4)
 - The antenna extension may cause interference echoes in the near range. In this case it may occur that the maximum measurable level is reduced.

Threaded connection

- For devices with a threaded connection it may be necessary depending on the antenna size to unmount the horn before fastening the device and to mount it again afterwards.
- Tighten with the hexagonal nut only.
- Tool: 55 mm hexagonal wrench
- Maximum permissible torque: 60 Nm (44 lbf ft)

6.4.2 Measurement from the outside through plastic walls (FMR50/FMR51)

- Dielectric constant of the medium: $\varepsilon_r > 10$
- If possible, use an antenna 100 mm (4 in).
- The distance from the lower edge of the antenna to the tank ceiling should be about 100 mm (4 in).
- If possible, avoid mounting locations where condensation or build-up might occur.
- In case of outdoor mounting, the space between antenna and vessel has to be protected from the elements.
- Do not mount any potential reflectors (e.g. pipes) outside the tank in the signal beam.

Suitable thickness of the tank ceiling:

Penetrated material	PE	PTFE	PP	Perspex
DK / ε _r	2.3	2.1	2.3	3.1
Optimum thickness 1)	3.8 mm (0.15 in)	4.0 mm (0.16 in)	3.8 mm (0.15 in)	3.3 mm (0.13 in)

 Other possible values for the thickness are multiples of the values listed (e.g. for PE: 7,6 mm (0.3 in), 11,4 mm (0.45 in)


28

⁴⁾ Feature 610 "Accessory mounted" of the product structure.

6.4.3 Horn antenna, flush mount (FMR52)


Alignment

- Align the antenna vertically to the product surface.
 The maximum range may be reduced if the horn antenna is not vertically aligned.
- A marking at the flange (somwhere between the flange holes) or the boss enables alignment of the antenna. This marking must be aligned towards the tank wall as well as possible.



Depending on the device version the marking may be a circle or two short parallel lines.

Nozzle mounting



■ 7 Nozzle height for horn antenna, flush mount (FMR52)


Antenna 1)	Maximum nozzle height H_{max}
BO: Horn 50mm/2"	500 mm (19.7 in)
BP: Horn 80mm/3"	500 mm (19.7 in)

- 1) Feature 070 of the product structure
- Please contact Endress+Hauser for applications with higher nozzle.
- For flanges with PTFE cladding: Observe the notes on the mounting of cladded flanges $\rightarrow \stackrel{\triangle}{=} 25$.
 - Usually, the PTFE flange cladding also serves as a seal between the nozzle and the device flange.

Endress+Hauser 29

A0016819

6.5 Installation in stilling well



■ 8 Installation in stilling well


Marking for antenna alignment

- For horn antenna: Align the marking towards the slots of the stilling well.
- Measurements can be performed through an open full bore ball valve without any problems.

6.5.1 Recommendations for the stilling well


- Metal (no enamel coating; plastic on request).
- Constant diameter.
- Diameter of stilling well not larger than antenna diameter.
- Diameter difference between horn antenna and inner diameter of the stilling well as small as possible.
- Weld seam as smooth as possible and on the same axis as the slots.
- Slots offset 180° (not 90°).
- Slot width or diameter of holes max. 1/10 of pipe diameter, de-burred. Length and number do not have any influence on the measurement.
- Select horn antenna as big as possible. For intermedaite sizes (e.g. 180 mm (7 in)) select next larger antenna and adapt it mechanically (for horn antennas)
- At any transition (i.e. when using a ball valve or mending pipe segments), no gap may be left exceeding 1 mm (0.04 in).
- The stilling well must be smooth on the inside (average roughness $R_z \leq$ 6.3 µm (248 µin)). Use extruded or parallel welded metal pipe. An extension of the pipe is possible with welded flanges or pipe sleeves. Flange and pipe have to be properly aligned at the inside.
- Do not weld through the pipe wall. The inside of the stilling well must remain smooth. In case of unintentional welding through the pipe, the weld seam and any unevenness on the inside need to be carefully removed and smoothened. Otherwise, strong interference echoes will be generated and material build-up will be promoted.
- In the case of smaller nominal widths flanges must be welded to the pipe such that they allow for a correct orientation (marker aligned toward slots).

6.5.2 Examples for the construction of stilling wells



- Micropilot FMR50/FMR51: Horn 40mm(1½")
- B Micropilot FMR50/FMR51/FMR52/FMR54: Horn 80mm(3")
- C Stilling well with slots
- D Full bore ball valve
- 1 Marking for axial alignment
- 2 Threaded connection
- 3 e.g. welding neck flange DIN2633
- 4 ϕ hole max. $1/10 \phi$ stilling well
- Φ hole max. 1/10 Φ stilling well; single sided or drilled through
- 6 Inside of holes deburred
- 7 Diameter of opening of ball valve must always be equivalent to pipe diameter; avoid edges and constrictions.

6.6 Installation in bypass



Installation in bypass


- 1 Marking for antenna alignment
- 2 Tank connectors
- Align the marker perpendicular (90°) to the tank connectors.
- Measurements can be performed through an open full bore ball valve without any problems.
- After mounting, the housing can be turned 350° in order to facilitate access to the display and the terminal compartment →

 34.

6.6.1 Recommendations for the bypass pipe


- Metal (no plastic or enamel coating).
- Constant diameter.
- Select horn antenna as big as possible. For intermediate sizes (e.g. 95 mm (3.5 in)) select next larger antenna and adapt it mechanically (for horn antennas).
- Diameter difference between horn antenna and inner diameter of the bypass as small as possible.
- At any transition (i.e. when using a ball valve or mending pipe segments), no gap may be created exceeding 1 mm (0.04 in).
- In the area of the tank connections ($\sim \pm 20$ cm (7.87 in)) a reduced accuracy of the measurement has to be expected.

6.6.2 Example for the construction of a bypass



- A Micropilot FMR50/FMR51/FMR52/FMR54: Horn 80mm(3")
- B Full bore ball valve
- C Minimum distance to upper connection pipe: 400 mm (15,7 in)
- 1 Marking for axial alignment
- 2 e.g. welding neck flange DIN2633
- 3 Diameter of the connection pipes as small as possible
- 4 Do not weld through the pipe wall; the inside of the bypass must remain smooth.
- 5 Diameter of opening of ball valve must always be equivalent to pipe diameter. Avoid edges and constrictions.


6.7 Container with heat insulation



If process temperatures are high, the device should be included in the usual container insulation system (2) to prevent the electronics from heating as a result of thermal radiation or convection. The insulation should not be higher than the neck of the device (1).

Turning the transmitter housing 6.8


To provide easier access to the connection compartment or display module, the transmitter housing can be turned:



- 1. Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- 3. Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).


6.9 Turning the display

6.9.1 Opening cover




- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90° counterclockwise.
- 2. Unscrew cover and check lid gasket, replace if necessary.

6.9.2 Turning the display module



- 1. Pull out the display module with a gentle rotational movement.
- 2. Rotate the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 3. Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

6.9.3 Closing electronics compartment cover



A002145

- 1. Screw back firmly electronics compartment cover.
- 2. Turning securing clamp 90 $^{\circ}$ clockwise and tighten the clamp with 2.5 Nm using the Allen key (3 mm).

6.10 Post-installation check


☐ Is the device undamaged (visual inspection)?	
Does the device conform to the measuring point specifications? For example: Process temperature Process pressure (refer to the chapter on "Material load curves" of the "Technical Information" document) Ambient temperature range Measuring range	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

7 Electrical connection

7.1 Connection conditions

7.1.1 Terminal assignment

Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})



 \blacksquare 10 Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})


- 1 Connection 4-20 mA HART (active): terminals 3 and 4
- 2 Connection supply voltage: terminals 1 and 2
- 3 Terminal for cable screen

A CAUTION

To ensure electrical safety:

- ▶ Do not disconnect the protective connection.
- ▶ Disconnect the supply voltage before disconnecting the protective earth.
- Connect protective earth to the internal ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the external ground terminal.
- In order to ensure electromagnetic compatibility (EMC): Do **not** only ground the device via the protective earth conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).


Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus



 $\blacksquare 11$ Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus

- A Without integrated overvoltage protection
- B With integrated overvoltage protection
- 1 Connection PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection switch output (Open Collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection switch output (Open Collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable screen


Block diagram PROFIBUS PA / FOUNDATION Fieldbus



A003653

- 12 Block diagram PROFIBUS PA / FOUNDATION Fieldbus
- 1 Cable screen; observe cable specifications
- 2 Connection PROFIBUS PA / FOUNDATION Fieldbus
- 3 Measuring device
- 4 Switch output (open collector)

Connection examples for the switch output



For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or Pull-up resistor) of $< 1000 \Omega$.

7.1.2 Cable specification

- Devices without integrated overvoltage protection
 Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection
 Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_{IJ} \ge 60 \,^{\circ}\text{C}$ (140 $^{\circ}\text{F}$): use cable for temperature $T_{IJ} + 20 \,^{\circ}\text{K}$.

PROFIBUS


Use a twisted, screened two-wire cable, preferably cable type A.

For further information on the cable specifications, see Operating Instructions BA00034S "PROFIBUS DP/PA: Guidelines for planning and commissioning", PNO Guideline 2.092 "PROFIBUS PA User and Installation Guideline" and IEC 61158-2 (MBP).


7.1.3 **Device plug connectors**

For the versions with fieldbus plug connector (M12 or 7/8"), the signal line can be connected without opening the housing.

Pin assignment of the M12 plug connector



Pin assignment of the 7/8" plug connector



7.1.4 Supply voltage

PROFIBUS PA, FOUNDATION Fieldbus

"Power supply; Output" 1)	"Approval" 2)	Terminal voltage
E: 2-wire; FOUNDATION Fieldbus, switch output G: 2-wire; PROFIBUS PA, switch output	 Non-Ex Ex nA Ex nA(ia) Ex ic Ex ic(ia) Ex d(ia) / XP Ex ta / DIP CSA GP 	9 to 32 V ³⁾
	Ex ia / ISEx ia + Ex d(ia) / IS + XP	9 to 30 V ³⁾

- 1) Feature 020 of the product structure
- 2) Feature 010 of the product structure
- 3) Input voltages up to 35 V will not spoil the device.

Polarity sensitive	No
FISCO/FNICO compliant according to IEC 60079-27	Yes

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse 8/20 μs), an overvoltage protection module has to be installed.

Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	2 × 0.5 Ω max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 μs)	10 kA	

External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.

7.2 Connecting the measuring device

WARNING


Risk of explosion!

- ▶ Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ► Use specified cable glands only.
- ► Check to ensure that the power supply matches the information on the nameplate.
- ► Switch off the power supply before connecting the device.
- ► Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:

- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.


7.2.1 Opening connection compartment cover



A0021490


- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° clockwise.
- 2. Afterwards unscrew connection compartment cover and check lid gasket, replace if necessary.

7.2.2 Connecting



■ 15 Dimensions: mm (in)


- 1. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- 3. Strip the cable ends over a length of 10 mm (0.4 in). In the case of stranded cables, also fit ferrules.
- 4. Firmly tighten the cable glands.
- 5. Connect the cable in accordance with the terminal assignment.



6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

In the case of devices without integrated overvoltage protection, electrical connection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.




■ 16 Dimensions: mm (in)

To remove cables from the terminal:

- 1. Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

7.2.4 Closing connection compartment cover



A0021491

- 1. Screw back firmly connection compartment cover.
- 2. Turning securing clamp 90 ° counterclockwise and tighten the clamp with 2.5 Nm (1.84 lbf ft) again using the Allen key (3 mm).

7.3 Post-connection check

Is the device or cable undamaged (visual check)?
Do the cables comply with the requirements ?
Do the cables have adequate strain relief?
Are all cable glands installed, securely tightened and leak-tight?
Does the supply voltage match the specifications on the nameplate?
Is the terminal assignment correct?

If required: Has protective ground connection been established ?
If supply voltage is present, is the device ready for operation and do values appear on the display module?
Are all housing covers installed and securely tightened?
Is the securing clamp tightened correctly?


8 Operation options

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"
Display	A0036312 4-line display	A0036313 4-line display
elements		white background lighting; switches to red in event of device error
	Format for displaying measured variables and status variables can be individually configured	
	Permitted ambient temperature for the display: The readability of the display may be impaired a range.	
Operating elements	local operation with 3 push buttons (⊕, ⊡, 區)	external operation via touch control; 3 optical keys: ⊕, ⊡, 區
	Operating elements also accessible in various hazardous areas	
Additional functionality	Data backup function The device configuration can be saved in the display module.	
	Data comparison function The device configuration saved in the display module can be compared to the current device configuration.	
	Data transfer function The transmitter configuration can be transmitte	ed to another device using the display module.

8.1.2 Operation with remote display and operating module FHX50




■ 17 FHX50 operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover
- 2 Display and operating module SD02, push buttons; cover must be removed

8.1.3 Remote operation


Via PROFIBUS PA protocol



 \blacksquare 18 Options for remote operation via PROFIBUS PA protocol

- Segment coupler
- 2 Computer with Profiboard/Proficard and operating tool (e.g. DeviceCare/FieldCare
- 3 PLC (Progrommable Logic Controller)
- 4 Transmitter
- 5 Additional functions (valves etc.)

DeviceCare/FieldCare via service interface (CDI)



- DeviceCare/FieldCare via service interface (CDI)
- Service interface (CDI) of the instrument (= Endress+Hauser Common Data Interface) Commubox FXA291
- 3 Computer with DeviceCare/FieldCare operating tool

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the on-site display
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	Once values have been set for these parameters, the measurement should generally be completely configured.
	Advanced setup	Contains additional submenus and parameters: to adapt the device to special measuring conditions. to process the measured value (scaling, linearization). to configure the signal output.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat 4)	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert ⁵⁾ Contains all parameters of the device (including those that are already in one of the other menus). This menu is organized	System	Contains all higher-order device parameters that do not concern the measurement or measured value communication.
according to the function blocks of the device. The parameters of the Expert menu are described in: GP01018F (PROFIBUS PA)	Sensor	Contains all parameters needed to configure the measurement.
	Output	Contains all parameters needed to configure the switch output (PFS).

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

- 1) If operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup \rightarrow Advanced setup → Display"

 Only if operating via an FDT/DTM system only available with local operation
- 2)
- 3)
- 4) 5) only available if operating via DeviceCare or FieldCare
 On entering the "Expert" menu, an access code is always requested. If a customer specific access code has not been defined, "0000" has to be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access $\rightarrow \triangleq 51$.

Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	~	V	V	
Maintenance	V	V	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.



The user role with which the user is currently logged on is indicated by the **Access status display** parameter (for display operation) or **Access status tooling** parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the same code in **Confirm access code** parameter.
 - ► The 🗈-symbol appears in front of all write-protected parameters.

Define access code via operating tool (e.g. FieldCare)

- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - **▶** Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, they can always be modified, even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the measured value display mode from the navigation and editing view.



- In the "Description of Device Parameters" documents, each write-protected parameter is identified with the 🗈-symbol.

Disabling write protection via access code

If the \square -symbol appears on the local display in front of a parameter, the parameter is write-protected by a device-specific access code and its value cannot be changed at the moment using the local display $\rightarrow \square$ 51.

The locking of the write access via local operation can be disabled by entering the device-specific access code.

- 1. After you press E, the input prompt for the access code appears.
- 2. Enter the access code.
 - The \(\mathbb{O}\)-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Enter **0000**.
- 3. Repeat **0000** in **Confirm access code** parameter.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via PROFIBUS PA protocol




A0026157

- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.



A0036086

- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter. In addition, on the local display the
 ⑤-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If the hardware write protection is disabled: No option is displayed in the **Locking status** parameter. On the local display, the 🛍-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

For the SD03 display only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock off** option.
 - ► The keypad lock is switched off.


Bluetooth® wireless technology

Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue app
- Only one point-to-point connection between one sensor and one smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display appearance



■ 20 Appearance of the display and operation module for on-site operation

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (1 bargraph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Representation of a parameter (here: a parameter with selection list)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Selection list; \square marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

56

Display symbols for the submenus

Symbol	Meaning
A0018367	Display/operation Is displayed: in the main menu next to the selection "Display/operation" in the header, if you are in the "Display/operation" menu
A0018364	Setup Is displayed: ■ in the main menu next to the selection "Setup" ■ in the header, if you are in the "Setup" menu
A0018365	Expert Is displayed: in the main menu next to the selection "Expert" in the header, if you are in the "Expert" menu
A0018366	Diagnostics Is displayed: in the main menu next to the selection "Diagnostics" in the header, if you are in the "Diagnostics" menu

Status signals

A0032902	"Failure" A device error is present. The measured value is no longer valid.
C	"Function check" The device is in service mode (e.g. during a simulation).
S	 "Out of specification" The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration carried out by the user (e.g. level outside configured span)
N	"Maintenance required" Maintenance is required. The measured value is still valid.

Display symbols for the locking state

Symbol	Meaning
A0013148	Display parameter Marks display-only parameters which can not be edited.
A0013150	 ■ In front of a parameter name: The device is locked via software and/or hardware. ■ In the header of the measured value screen: The device is locked via hardware.


Measured value symbols

Symbol Meaning					
Measured values					
~~		Level			
A	.0032892				
⊢→	.0032893	Distance			
(-)		Current output			
A	.0032908				
(A)		Measured current			
A	.0032894				
(Terminal voltage			
A	.0032895				
		Temperature of the electronics or the sensor			
A	.0032896				
Measuring chann	els				
1		Measuring channel 1			
A	.0032897				
2		Measuring channel 2			
A	.0032898				
Status of the mea	sured	value			
		Status "Alarm" The measurment is interrupted. The output assumes the defined alarm value. A			
A	.0018361	diagnostic message is generated.			
\wedge		Status "Warning"			
Z • A	.0018360	The device continues measuring. A diagnostic message is generated.			

8.3.2 Operating elements

Key	Key Meaning	
	Minus key	
	For menu, submenu Moves the selection bar upwards in a picklist.	
A0018330	For text and numeric editor In the input mask, moves the selection bar to the left (backwards).	
	Plus key	
+	For menu, submenu Moves the selection bar downwards in a picklist.	
A0018329	For text and numeric editor In the input mask, moves the selection bar to the right (forwards).	
	Enter key	
	For measured value display ■ Pressing the key briefly opens the operating menu. ■ Pressing the key for 2 s opens the context menu.	
E)	For menu, submenu Pressing the key briefly Opens the selected menu, submenu or parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter.	
	For text and numeric editor ■ Pressing the key briefly - Opens the selected group. - Carries out the selected action. ■ Pressing the key for 2 s confirms the edited parameter value.	
	Escape key combination (press keys simultaneously)	
—++ A0032909	For menu, submenu ■ Pressing the key briefly - Exits the current menu level and takes you to the next higher level. - If help text is open, closes the help text of the parameter. ■ Pressing the key for 2 s returns you to the measured value display ("home position").	
	For text and numeric editor Closes the text or numeric editor without applying changes.	
-+E	Minus/Enter key combination (press and hold down the keys simultaneously)	
A0032910	Reduces the contrast (brighter setting).	
Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).		

8.3.3 Entering numbers and text



Input mask


The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor symbols

Symbol	Meaning			
0	Selection of numbers from 0 to 9.			
9 A0013998				
A0016619	Inserts decimal separator at the input position.			
A0016620	Inserts minus sign at the input position.			
A0013985	Confirms selection.			
A0016621	Moves the input position one position to the left.			
X A0013986	Exits the input without applying the changes.			
C	Clears all entered characters.			

Text editor symbols

Symbol	Meaning
ABCXYZ	Selection of letters from A to Z
Aa1 @	Toggle Between upper-case and lower-case letters For entering numbers For entering special characters



Correction symbols under \nearrow

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
4	Moves the input position one position to the left.
A0018326	
₹ ×	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Env.curve
- Keylock on

Opening and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
 - └ The context menu opens.



A0033110-EN

- 2. Press \Box + \pm simultaneously.
 - └ The context menu is closed and the operational display appears.


Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press ± to navigate to the desired menu.
- 3. Press **E** to confirm the selection.
 - ► The selected menu opens.

62

8.3.5 Envelope curve on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be displayed:




9 Integration into a PROFIBUS network

9.1 Overview of the device database files (GSD)

Manufacturer ID	17 (0x11)
Ident number	0x1559
Profile version	3.02
GSD file	Information and files under:
GSD file version	www.endress.comwww.profibus.org

9.2 Set device address




■ 21 Address switches in terminal compartment

9.2.1 Hardware adressing

- 1. Set switch 8 to "OFF".
- 2. Define the address with switches 1 to 7 according to the table below.

The address change becomes effective after 10 seconds. The device restarts automatically.


Switch	1	2	3	4	5	6	7
Value in position "ON"	1	2	4	8	16	32	64
Value in position "OFF"		0	0	0	0	0	0



 \blacksquare 22 Example of hardware addressing: switch 8 is in position "OFF"; switches 1 to 7 define the address.

9.2.2 Software addressing

- 1. Set switch 8 to "ON".
- 2. The device restarts automatically. The address remains the same as before (factory setting: 126).
- 3. Set the required address via the operating menu: Setup \rightarrow Device address




■ 23 Example of software addressing; switch 8 is in position "ON"; the address is defined in the operating menu (Setup \rightarrow Device address)

10 Commissioning via wizard

A wizard guiding the user through the initial setup is available in FieldCare and DeviceCare ⁵⁾.

- 1. Connect the device to FieldCare or DeviceCare $\rightarrow \triangleq 47$.
- 2. Open the device in FieldCare or DeviceCare.
 - └ The dashboard (home page) of the device appears:



1 "Commissioning" button calls up the wizard.

- 3. Click on "Commissioning" to call up the wizard.
- 4. Enter or select the appropriate value for each parameter. These values are immediately written to the device.
- 5. Click "Next" to switch to the next page.
- 6. After finishing the last page, click "End of sequence" to close the wizard.
- If the wizard is cancelled before all necessary parameters have been set, the device may be in an undefined state. A reset to the default settings is recommended in this case.

⁵⁾ DeviceCare is available for download at www.software-products.endress.com. The download requires a registration in the Endress+Hauser software portal.

11 Commissioning via operating menu


11.1 Installation and function check

Make sure that all final checks have been completed before you start up your measuring point:

- Checklist "Post-installation check" → 🖺 36
- Checklist "Post-connection check" → 🖺 44


11.2 Setting the operating language

Factory setting: English or ordered local language



 \blacksquare 24 Using the example of the local display

11.3 Configuration of a level measurement



A0016933

- 25 Configuration parameters for level measurements in liquids
- *R* Reference point of the measurement
- D Distance
- L Level
- E Empty calibration (= zero)
- F Full calibration (= span)
- 1. Navigate to: Setup → Device tag
 - ► Enter tag for measuring point.
- 2. Navigate to: Setup → Device address
 - ► Enter bus address of the device (only in case of software addressing).
- 3. Navigate to: Setup → Distance unit
 - ► Select distance unit.
- 4. Navigate to: Setup → Tank type
 - ► Select tank type.
- 5. For **Tank type** parameter = Bypass / pipe:

Navigate to: Setup → Tube diameter

- ► Enter the diameter of the stilling well or bypass.
- 6. Navigate to: Setup → Medium group
 - Specify medium group: (Water based (DC >= 4) or Others)
- 7. Navigate to: Setup → Empty calibration
 - ► Enter empty distance E (Distance from reference point R to the 0% level) 6).
- 8. Navigate to: Setup \rightarrow Full calibration
 - ► Enter full distance F (Distance from the 0% to the 100% level).
- 9. Navigate to: Setup → Level
 - Indicates the measrued level L.
- 10. Navigate to: Setup \rightarrow Distance
 - Indicates the measured distance from the reference point R to the level L.

⁶⁾ If, for example, the measuring range covers only an upper part of the tank (E << tank height), it is mandatory to enter the acutal tank height into the "Setup \rightarrow Advanced Setup \rightarrow Level \rightarrow Tank/silo height" parameter.

- 11. Navigate to: Setup \rightarrow Signal quality
 - ► Indicates the quality of the evaluated level echo.
- 12. When operating via local display:

Navigate to: Setup → Mapping → Confirm distance

- Compare distance indicated on the display to real distance in order to start the recording of an interference echo map.
- 13. When operating via operating tool:

Navigate to: Setup → Confirm distance

- Compare distance indicated on the display to real distance in order to start the recording of an interference echo map.
- 14. Navigate to: Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level unit
 - ► Select level unit: %, m, mm, ft, in (Factory setting: %)
- The response time of the device is preset by the **Tank type** parameter ($\rightarrow \implies 110$). More detailed settings are possible in the **Advanced setup** submenu.

11.4 Recording the reference curve

After the configuration of the measurement it is recommended to record the current envelope curve as a reference curve. The reference curve can be used later on in the process for diagnostic purposes. To record the reference curve use the **Save reference curve** parameter.

Navigation in the menu

Expert \rightarrow Diagnostics \rightarrow Envelope diagnostics \rightarrow Save reference curve

Meaning of the options

- No
 - No action
- Yes

The current envelope curve is saved as reference curve.

- In devices which have been delivered with software version 01.00.zz, this submenu is only visible for the "Service" user role.
- The reference curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. This is performed by the "Load Reference Curve" function in FieldCare.



■ 26 The "Load Reference Curve" function

11.5 Configuration of the on-site display

11.5.1 Factory settings of the on-site display

Parameter	Factory setting
Format display	1 value, max. size
Value 1 display	Level linearized
Value 2 display	None
Value 3 display	None
Value 4 display	None

11.5.2 Adjustment of the on-site display

The on-site display can be adjusted in the following submenu: Setup \rightarrow Advanced setup \rightarrow Display

11.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and its options.

Navigation path in the operating menu

Setup → Advanced setup → Configuration backup display → Configuration management

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device. The backup copy comprises the transmitter and sensor data of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter and sensor data of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset → 159 will not restore the original status..

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

11.7 Protection of the settings against unauthorized changes

There are two ways to protect the settings against unauthorized changes:

- Via locking switch (hardware locking) → 🖺 52

12 Diagnostics and troubleshooting

12.1 General trouble shooting

12.1.1 General errors

Error	Possible cause	Remedial action
Device does not respond.	Supply voltage not connected.	Connect the correct voltage.
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ± and E simultaneously. Decrease contrast by pressing □ and E simultaneously.
	The plug of the display cable is not connected correctly.	Connect the plut correctly.
	Display is defective.	Replace display.
"Communication error" is indicated	Electromagnetic interference	Check grounding of the device.
on the display when starting the device or connecting the display	Broken display cable or display plug.	Exchange display.
Duplicating of the parameters from one device to another via the display doesn't work. Only the "Save" and "Abort" options are available.	Display with backup is not recognized if no data backup has been performed at the device before.	Connect display (with the backup) and restart the device.
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.
Device measures incorrectly.	Parametrization error	Check and adjust parameterization.

12.1.2 Parametrization errors


Error	Possible cause	Remdy
Measured value incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	 Check and adjust Empty calibration parameter (→ ≧ 111) if necessary. Check and adjust Full calibration parameter (→ ≧ 112) if necessary. Check and adjust linearization if necessary (Linearization submenu (→ ≧ 130)).
	For measurements in bypasses / stilling well: Wrong tank type Wrong tube diameter	■ Select Tank type (→ 🗎 110) = Bypass / pipe. ■ Enter correct diamter in Tube diameter parameter (→ 🖺 110).
	Wrong level correction	Enter correct value in Level correction parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
	If measured distance (Setup → Distance) does not match the real distance: Interference echo	Carry out tank mapping (Confirm distance parameter (→ 114).

Error	Possible cause	Remdy
No change of measured value on filling / emptying	Interference echo from installations, nozzle or build-up on the antenna.	 Carry out tank mapping (Confirm distance parameter (→ 🖺 114)). If necessary, clean antenna If necessary, selet better mopunting position
If the surface is not calm (e.g. filling, emptying, agitator running), the measured value jumps sporadically to a higher level	Signal is weakened by the rough surface - the interference echoes are sometimes stronger.	 Carry out tank mapping (Confirm distance parameter (→ ≦ 114)). Select Tank type (→ ≦ 110) = Process vessel with agitator. Increase integration time (Expert → Sensor → Distance → Integration time) Optimize orientation of the antenna If necessary, select a better mounting position and/or larger antenna.
During filling/emptying the measxured value jumps downwards	Multiple echoes	 Check Tank type parameter (→ □ 110). If possible, do not select central installation position. If appropriate, use a stilling well.
Error message F941 or S941 "Echo lost"	Level echo is too weak.	Check Medium group parameter (→ ≧ 110). If necessary, select a more detailed setting in Medium property parameter (→ ≧ 123). Optimize alignment of antenna If necessary, select a better installation position and/or larger antenna.
	Level echo suppressed.	Delete mapping and record it again.
Device displays a level when the tank is empty.	Interference echo	Carry out mapping over entire measuring range when the tank is empty (Confirm distance parameter (→ 🖺 114)).
Wrong slope of the level in the entire measuring range	Wrong tank type selected.	Set Tank type parameter (→ 🗎 110) correctly.

12.2 Diagnostic information on local display

12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


A0032902	"Failure (F)" option A device error is present. The measured value is no longer valid.
C	"Function check (C)" option The device is in service mode (e.g. during a simulation).
S	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration carried out by the user (e.g. level outside configured span)
N	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs take on the defined alarm condition. A diagnostic message is generated.
\triangle	"Warning" status The device continues to measure. A diagnostic message is generated.

Diagnostics event and event text

The fault can be identified using the diagnostics event. The event text helps you by providing information about the fault. In addition, the corresponding symbol is displayed before the diagnostics event.



If two or more diagnostic messages are pending simultaneously, only the message with the highest priority is shown. Additional pending diagnostic messages can be shown in the **Diagnostic list** submenu.




Past diagnostic messages that are no longer pending are shown as follows:

- On the local display:
- in the **Event logbook** submenu
- In FieldCare: via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu			
+	Plus key Opens the message about the remedial measures.		
E	Enter key Opens the operating menu.		

12.2.2 Calling up remedial measures



A0029431-EN

- 27 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (①-Symbol).
 - **→ Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \blacksquare .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in **Diagnostic list** submenu or in **Previous diagnostics**.

- 1. Press E.
 - └─ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.


12.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)


A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
 - In the **Actual diagnostics** parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.




A tool tip with remedial measures for the diagnostic event appears.

B: Via the "Create documentation" function




Select the "Create documentation" function.



Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.



Select the "Load Eventlist" function.

The list of events, including remedy information, is shown in the "Data overview" window.

12.4 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list

Calling up and closing the remedial measures

- 1. Press E.
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

80

12.5 Overview of diagnostic events

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of e	electronic			
242	Software incompatible	Check software Flash or change main electronics module	F	Alarm
252	Modules incompatible	Check electronic modules Change I/O or main electronic module	F	Alarm
261	Electronic modules	Restart device Check electronic modules Change I/O Modul or main electronics	F	Alarm
262	Module connection	Check module connections Change electronic modules	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	Restart device Change main electronic module	F	Alarm
272	Main electronic failure	Restart device Contact service	F	Alarm
273	Main electronic failure	Emergency operation via display Change main electronics	F	Alarm
275	I/O module failure	Change I/O module	F	Alarm
276	I/O module failure	Restart device Change I/O module	F	Alarm
282	Data storage	Restart device Contact service	F	Alarm
283	Memory content	Transfer data or reset device Contact service	F	Alarm
311	Electronic failure	Transfer data or reset device Contact service	F	Alarm
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	М	Warning
Diagnostic of o	configuration			
410	Data transfer	Check connection Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
412	Processing Download	Download active, please wait	С	Warning
435	Linearization	Check linearization table	F	Alarm
437	Configuration incompatible	Restart device Contact service	F	Alarm
438	Dataset	Check data set file Check device configuration Up- and download new configuration	М	Warning
482	Block in OOS	Set Block in AUTO mode	F	Alarm
484	Simulation failure mode	Deactivate simulation	С	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
485	Simulation measured value	Deactivate simulation	С	Warning
494	Switch output simulation	Deactivate simulation switch output	С	Warning
495	Simulation diagnostic event	Deactivate simulation	С	Warning
497	Simulation block output	Deactivate simulation	С	Warning
585	Simulation distance	Deactivate simulation	С	Warning
586	Record map Recording of mapping please wait		С	Warning
Diagnostic of p	rocess			
801	Energy too low	Increase supply voltage	S	Warning
825	Operating temperature	Check ambient temperature	S	Warning
825	Operating temperature	2. Check process temperature	F	Alarm
921	Change of reference	Check reference configuration Check pressure Check sensor	S	Warning
941	Echo lost	Check parameter 'DC value'	F	Alarm 1)
942	In safety distance	Check level Check safety distance Reset self holding	S	Alarm 1)
943	In blocking distance	Reduced accuracy Check level	S	Warning
950	Advanced diagnostic 1 to 2 occured	Maintain your diagnostic event	М	Warning 1)

¹⁾ Diagnostic behavior can be changed.

12.6 Event logbook

12.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu $^{7)}$.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

82

⁷⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - €: Event has occurred
 - ⊖: Event has ended
- Information event
 - €: Event has occurred

Calling up and closing the remedial measures

- 1. Press E
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

12.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

Navigation path

Diagnostics → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

12.6.3 Overview of information events

Info number	Info name
I1000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Trend data deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared

Info number	Info name		
I1256	Display: access status changed		
I1264	Safety sequence aborted		
I1335	Firmware changed		
I1397	Fieldbus: access status changed		
I1398	CDI: access status changed		
I1512	Download started		
I1513	Download finished		
I1514	Upload started		
I1515	Upload finished		

12.7 Firmware history

Date	Firmware	Modifications	Documentation (FMR51/FMR52, PROFIBUS PA)			
	version		Operating Instructions	Description of Parameters	Technical Information	
04.2013	01.00.zz	Original software	BA01125F/00/EN/01.13	GP01018F/00/EN/01.13	TI01040F/00/EN/02.13	
03.2015	01.01.zz	 additional languages HistoROM functionality enhanced Improvements and bugfixes 	BA01125F/00/EN/02.14 BA01125F/00/EN/03.16 ¹⁾	GP01018F/00/EN/02.14	TI01040F/00/EN/05.14 TI01040F/00/EN/07.16 ¹⁾	

¹⁾ Contains information on the Heartbeat wizards which are available in the latest DTM version for DeviceCare and FieldCare.

The firmware version can explicitly be ordered via the product structure. In this way it is possible to ensure compatibility of the firmware version with an existing or planned system integration.

13 Maintenance

The measuring device requires no special maintenance.

13.1 Exterior cleaning

When exterior-cleaning the device, always use cleaning agents that do not attack the surface of the hosuing and the seals.

13.2 Replacing seals

The process seals of the sensors (at the process connection) must be replaced periodically, particularly if molded seals (aseptic construction) are used. The period between changes depends on the frequency of cleaning cycles and on the temperature of the measured substance and the cleaning temperature.

14 Repairs

14.1 General information on repairs

14.1.1 Repair concept

The Endress+Hauser repair concept assumes that the devices have a modular design and that repairs can be done by the Endress+Hauser service or specially trained customers.

Spare parts are contained in suitable kits. They contain the related replacement instructions.

For more information on service and spare parts, contact the Service Department at Endress+Hauser.

14.1.2 Repairs to Ex-approved devices

When carrying out repairs to Ex-approved devices, please note the following:

- Repairs to Ex-approved devices may only be carried out by trained personnel or by the Endress+Hauser Service.
- Comply with the prevailing standards, national Ex-area regulations, safety instructions (XA) and certificates.
- Only use original spare parts from Endress+Hauser.
- When ordering a spare part, please note the device designation on the nameplate. Only replace parts with identical parts.
- Carry out repairs according to the instructions. On completion of repairs, carry out the specified routine test on the device.
- Only Endress+Hauser Service may convert a certified device into a different certified variant.
- Document all repair work and conversions.

14.1.3 Replacement of an electronics module

If an electronics module has been replaced, it is not necessary to perform a new basic setup as the calibration parameters are stored in the HistoROM which is located in the housing. However, after exchanging the main electronics module it may be necessary to record a new mapping (interference echo suppression).

14.1.4 Replacement of a device

After a complete device or electronic module has been replaced, the parameters can be downloaded into the instrument again in one of the following ways:


- Via the display module
 Condition: The configuration of the old device has been saved in the display module
 → ≅ 156.
- Via FieldCare

Condition: The configuration of the old device has been saved to the computer via FieldCare.

You can continue to measure without carrying out a new setup. Only a linearization and a tank map (interference echo suppression) have to be recorded again.

14.2 Spare parts

- A few interchangeable measuring device components are identified by a spare part nameplate. This contains information about the spare part.
- The connection compartment cover of the device contains a spare part nameplate that includes the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL for the W@M Device Viewer (www.endress.com/deviceviewer):
 There, all spare parts for the measuring device are listed, including the order code, and can be ordered. If available, the corresponding Installation Instructions can also be downloaded there.



■ 28 Example for spare part nameplate in connection compartment cover

Measuring device serial number:

- Is located on the device and spare part nameplate.
- Can be read out via the "Serial number" parameter in the "Device information" submenu.

14.3 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at http://www.endress.com/support/return-material

14.4 Disposal

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.


Endress+Hauser 87

A0014979


15 Accessories

15.1 Device-specific accessories

15.1.1 Weather protection cover



15.1.2 Remote display FHX50




1) This range is valid if option JN "Ambient temperature transmitter -50 °C (-58 °F)" has been selected in ordering feature 580 "Test, Certificate". If the temperature is permanently below -40 °C (-40 °F), failure rates may be increased.

15.1.3 Horn protection for horn antenna

- This section is **not** valid for the following options of ordering feature 610 "Accessory Mounted".
 - OU: ...mm antenna extension
 - OV: ... inch antenna extension

For these cases: $\rightarrow \implies 91$



Horn protection for FMR51

Antenna 1)	Order code horn	Dimensions antenna + horn protection		
	protection	L ²⁾	Ød	ØD
BC: Horn 80mm/3"	71105890	238 mm (9.4 in)	96 mm (3.78 in)	≥ DN100
BD: Horn 100mm/4"	71105889	302 mm (11.9 in)	116 mm (4.57 in)	≥ DN150


- 1) Feature 070 of the product structure
- 2) A different length is valid for antennas with variable antenna extension (ordering feature 610, option OU or OV).
 - The horn protection can also be ordered together with the device. Product structure: Feature 610 "Accessory Mounted", option OW "Horn protection, PTFE".

15.1.4 Horn protection for horn antenna with variable antenna extension

This section is valid for the following options of ordering feature 610 "Accdessory Mounted".

- OU: ...mm antenna extension
- OV: ... inch antenna extension

For any other device version: $\rightarrow \implies 90$



Horn protection for FMR51 with variable antenna extension

Antenna 1)	Order code horn	Dimension	s antenna + horn protection	
	protection	L	Ød	ØD
BC: Horn 80mm/3"	71105890	203 mm (8 in)	96 mm (3.78 in)	≥ DN100
BD: Horn 100mm/4"	71105889	267 mm (10.5 in)	116 mm (4.57 in)	≥ DN150

1) Feature 070 of the product structure

15.1.5 Overvoltage protection

Accessory	Description
Overvoltage protection for 2-wire-devices OVP10 (1 channel) OVP20 (2 channel)	A0021734
	Technical data
	 Resistance per channel: 2 * 0.5 Ω_{max} Threshold DC voltage: 400 to 700 V Threshold impulse voltage: < 800 V Capacitance at 1 MHz: < 1.5 pF Nominal arrest impulse voltage (8/20 μs): 10 kA Suited for wire cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)
	Ordering with device The overvoltage protection module is preferably ordered with the device. See product structure, feature 610 "Accessory mounted", option NA "Overvoltage protection". Separate ordering of the module is only necessary if a device is to retrofitted with the overvoltage protection.
	Order code for retrofitting For 1-channel devices (feature 020, option A) OVP10: 71128617 For 2-channel devices (feature 020, option B, C, E or G) OVP20: 71128619
	Hosuing lid for retrofitting In order to keep the necessary safety distances, the housing lid needs to be replaced if the device is retrofitted with the overvoltage protection. Depending on the housing type, the order code of the suitable lid is as follows: GT18 housing: Lid 71185516 GT20 housing: Lid 71185516
	Restrictions for retrofitting Depending on the approval of the transmitter the usage of the OVP module may be restricted. A device may only be retrofitted with an OVP module if the option NA (overvoltage protection) is quoted unter Optional Specifications in the Safety Instructions (XA) pertaining to the device.
	For details refer to SD01090F.

15.1.6 Gas-tight feedthrough

Accessory	Description
Gas-tight feedthrough	Chemically inert glass feedthrough; prevents migration of gases into the electronics housing. To be ordered with the device: product structure, feature 610 "Accessory Mounted", option NC "Gas-tight feedthrough"

15.1.7 Bluetooth module for HART devices

Accessory	Description
Bluetooth module	A036493
	 Quick and easy commissioning via SmartBlue (app) No additional tools or adapters required Signal curve via SmartBlue (app) Encrypted single point-to-point data transmission (tested by Fraunhofer institue) and password protected communication via Bluetooth® wireless technology Range under reference conditions: 10 m (33 ft)
	When using the Bluetooth module the minimum supply voltage increases by up to 3 V. Ordering with device The Bluetooth module is preferably ordered with the device. See product structure, feature 610 "Accessory Mounted", option NF "Bluetooth". A separate order is only necessary in case of retrofitting.
	Order code for retrofitting Bluetooth module (BT10): 71377355
	Restrictions in case of retrofitting Depending on the approval of the transmitter, application of the Bluetooth module may be restricted. A device may only be retrofitted with a Bluetooth module if the option NF (Bluetooth) is listed in the associated Safety Instructions (XA) under Optional specifications.
	For details refer to SD02252F.

15.2 Communication-specific accessories

Accessory	Description
Commubox FXA291	Connects Endress+Hauser field devices with CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a computer. Order code: 51516983 For details refer to Technical Information TI00405C

15.3 Service-specific accessories


Accessory	Description
DeviceCare SFE100	Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus devices
	Technical Information TI01134S
	 DeviceCare is available for download at www.software-products.endress.com. The download requires a registration in the Endress+Hauser software portal. Alternatively, a DeviceCare DVD can be ordered with the device. Product structure: Feature 570 "Service", Option IV "Tooling DVD (DeviceCare Setup)".
FieldCare SFE500	FDT-based Plant Asset Management tool. Helps to configure and maintain all field devices of your plant. By supplying status information it also supports the diagnosis of the devices. Technical Information TI00028S

15.4 System components

uphic data manager Memograph M provides information on all the relevant variables. Measured values are recorded correctly, limit values are red and measuring points analyzed. The data are stored in the 256 MB I memory and also on an SD card or USB stick. or details refer to Technical Information TI00133R and Operating astructions BA00247R
r

16 Operating menu

16.1 Overview of the operating menu (display module)



► Analog inputs			
	► Analog input 1 t	to 6	→ 🖺 119
		Channel	→ 🖺 119
		PV filter time	→ 🖺 119
		Fail safe type	→ 🖺 120
		Fail safe value	→ 🖺 120
► Advanced setup			→ 🖺 121
	Locking status		→ 🖺 121
	Access status displa	ау	→ 🖺 122
	Enter access code		→ 🖺 122
	► Level		→ 🖺 123
		Medium type	→ 🖺 123
		Medium property	→ 🖺 123
		Max. filling speed liquid	→ 🖺 124
		Max. draining speed liquid	→ 🖺 124
		Advanced process conditions	→ 🖺 125
		Level unit	→ 🖺 126
		Blocking distance	→ 🖺 126
		Level correction	→ 🖺 127
		Tank/silo height	→ 🖺 127
	► Linearization		→ 🖺 130
		Linearization type	→ 🖺 132
		Unit after linearization	→ 🖺 133
		Free text	→ 🖺 134
		Maximum value	→ 🗎 135

	Diameter	→ 🖺 135
	Intermediate height	→ 🖺 135
	Table mode	→ 🖺 136
	► Edit table	
	Level	→ 🖺 137
	Customer value	→ 🖺 138
	Activate table	→ 🖺 138
► Safety s		→ 🖺 139
P Safety S	ecungs	/ 🖨 137
	Output echo lost	→ 🖺 139
	Value echo lost	→ 🖺 139
	Ramp at echo lost	→ 🖺 140
	Blocking distance	→ 🖺 126
► WHG co	onfirmation	→ 🖺 142
► Deactiv	ate WHG	→ 🖺 143
	Reset write protection	→ 🖺 143
	Code incorrect	→ 🖺 143
► Switch	output	→ 🖺 144
Switch		
	Switch output function	→ 🖺 144
	Assign status	→ 🖺 144
	Assign limit	→ 🖺 145
	Assign diagnostic behavior	→ 🖺 145
	Switch-on value	→ 🖺 146
	Switch-on delay	→ 🖺 147
	Switch-off value	→ 🖺 147
	Switch-off delay	→ 🖺 148

	Failure mode	→ 🖺 148
	Switch status	→ 🖺 148
	Invert output signal	→ 🖺 148
▶ Display		→ 🖺 150
	Language	→ 🖺 150
	Format display	→ 🖺 150
	Value 1 to 4 display	→ 🖺 152
	Decimal places 1 to 4	→ 🖺 152
	Display interval	→ 🖺 152
	Display damping	→ 🖺 153
	Header	→ 🖺 153
	Header text	→ 🖺 153
	Separator	→ 🖺 154
	Number format	→ 🖺 154
	Decimal places menu	→ 🖺 154
	Backlight	→ 🖺 155
	Contrast display	→ 🖺 155
► Configuration b	ackup display	→ 🖺 156
	Operating time	→ 🖺 156
	Last backup	→ 🖺 156
	Zace Sacrap	, = 170


		Configuration management	→ 🖺 156
		Comparison result	→ 🗎 157
	► Administration		→ 🖺 159
		▶ Define access code	→ 🗎 161
		Define access code	→ 🖺 161
		Confirm access code	→ 🖺 161
		Device reset	→ 🖺 159
억 Diagnostics]		→ 🖺 162
Actual diagnostics			→ 🖺 162
Previous diagnostic	S		→ 🖺 162
Operating time from			→ 🖺 163
	ii restart]	
Operating time			→ 🖺 156
► Diagnostic list			→ 🗎 164
	Diagnostics 1 to 5		→ 🖺 164
► Event logbook			→ 🖺 165
	Filter options		→ 🖺 165
	► Event list		→ 🖺 165
► Device informat	ion		→ 🖺 166
	Device tag		→ 🖺 166
	Serial number		→ 🗎 166
	Firmware version		→ 🖺 166
	Device name		→ 🖺 166
	Order code		→ 🗎 167
	Extended order cod	a 1 to 3	→ 1 67
	Evremen order con	C 1 (0)	/ 🗏 10/

	Status PROFIBUS M	aster Config	→ 🖺 16
	PROFIBUS ident nu	mber	→ 🗎 16
► Measured value	es		→ 🖺 16
		J	
	Distance		→ 🖺 11
	Level linearized		→ 🖺 13
	Terminal voltage 1		→ 🖺 16
	Switch status		→ 🗎 14
	Electronic temperat	ure	→ 🖺 16
► Analog inputs			
	► Analog input 1 t	o 6	→ 🖺 17
		Channel	→ 🖺 11
		Out value	→ 🖺 17
		Out status	→ 🖺 17
		Out status HEX	→ 🖺 17
► Data logging			→ 🗎 17
	Assign channel 1 to	4	→ 🖺 17
	Logging interval		→ 🖺 17
	Clear logging data		→ 🖺 17
	▶ Display channel	1 to 4	→ 🖺 17
► Simulation			→ 🖺 17
	Assign measuremen	nt variable	→ 🖺 17
	Value process varia	ble	→ 🖺 17
	Value process varia		
			 → 🖺 17 → 🖺 17 → 🖺 17

	Diagnostic event category	
	Simulation diagnostic event	→ 🖺 178
	Simulation diagnostic event	→ 🖺 178
► Device check		→ 🖺 179
	Start device check	→ 🗎 179
	Result device check	→ 🖺 179
	Last check time	→ 🖺 179
	Level signal	→ 🖺 180

16.2 Overview of the operating menu (operating tool)

Navigation © Operating menu



102

Fail safe type \rightarrow \bigsim 120 Fail safe value \rightarrow \bigsim 120 ▶ Advanced setup \rightarrow \bigsim 121 Locking status \rightarrow \bigsim 121 Access status tooling \rightarrow \bigsim 121 Enter access code \rightarrow \bigsim 122
▶ Advanced setup → 🖺 121 Locking status → 🖺 121 Access status tooling Access status tooling
Locking status \rightarrow \cong 121 Access status tooling \rightarrow \cong 121
Access status tooling → 🖺 121
Enter access code → 🖺 122
▶ Level → 🖺 123
Medium type → 🖺 123
Medium property → 🖺 123
Max. draining speed liquid → 🖺 124
Advanced process conditions → 🖺 125
Level unit → 🗎 126
Blocking distance → 🖺 126
Level correction → 🗎 127
Tank/silo height → 🖺 127
► Linearization → 🖺 130
Linearization type → 🖺 132
Unit after linearization → 🖺 133
Free text → 🖺 134
Level linearized → 🖺 134
Maximum value → 🖺 135
Diameter → 🖺 135
Intermediate height → 🖺 135
Table mode → 🖺 136

	Table number	→ 🗎 137
	Level	→ 🖺 137
	Level	→ 🖺 138
	Customer value	→ 🖺 138
	Activate table	→ 🖺 138
► Safety settings		→ 🖺 139
	Output echo lost	→ 🖺 139
	Value echo lost	→ 🖺 139
	Ramp at echo lost	→ 🖺 140
	Blocking distance	→ 🖺 126
► WHG confirmat	ion	→ 🖺 142
► Deactivate WHO	3	→ 🗎 143
	Reset write protection	→ 🖺 143
	Code incorrect	→ 🗎 143
► Switch output		→ 🗎 144
	Switch output function	→ 🗎 144
	Assign status	→ 🖺 144
	Assign limit	→ 🗎 145
	Assign diagnostic behavior	→ 🗎 145
	Switch-on value	→ 🖺 146
	Switch-on delay	→ 🗎 147
	Switch-off value	→ 🗎 147
	Switch-off delay	→ 🗎 148
	Failure mode	→ 🖺 148

→ 🖺 148
→ 🖺 150
→ 🖺 150
→ 🖺 150
→ 🖺 152
→ 🖺 152
→ 🖺 152
→ 🗎 153
→ 🖺 153
→ 🗎 153
→ 🗎 154
→ 🗎 154
→ 🖺 154
→ 🖺 155
→ 🖺 155
→ 🖺 156
→ 🖺 156
→ 🖺 156
→ 🖺 156

		Backup state	→ 🖺 157
		Comparison result	→ 🗎 157
	► Administration		→ 🖺 159
		Define access code	→ 🖺 161
		Device reset	→ 🖺 159
♥ Diagnostics			→ 🖺 162
Actual diagnostics			→ 🖺 162
Timestamp			→ 🖺 162
Previous diagnostic	S		→ 🖺 162
Timestamp			→ 🖺 163
Operating time from	n restart		→ 🖺 163
Operating time			→ 🖺 156
▶ Diagnostic list			→ 🗎 164
	Diagnostics 1 to 5		→ 🖺 164
	Timestamp 1 to 5		→ 🗎 164
▶ Device informat	ion		→ 🖺 166
	Device tag		→ 🖺 166
	Serial number		→ 🗎 166
	Firmware version		→ 🗎 166
	Device name		→ 🖺 166
	Order code		→ 🗎 167
	Extended order cod	e 1 to 3	→ 🖺 167
	Status PROFIBUS M	laster Config	→ 🖺 167
	PROFIBUS ident nu	mber	→ 🗎 167

► Measured values		→ 🖺 168
Distance		→ 🖺 113
Level linearized		→ 🖺 134
Terminal voltage 1	L	→ 🖺 169
Switch status		→ 🖺 148
Electronic tempera	ature	→ 🖺 169
► Analog inputs		
► Analog input 1	to 6	→ 🖺 170
	Channel	→ 🖺 119
	Out value	→ 🖺 170
	Out status	→ 🖺 171
	Out status HEX	→ 🖺 171
▶ Data logging		→ 🖺 172
Assign channel 1 to	0 4	→ 🖺 172
Logging interval		→ 🖺 172
Clear logging data		→ 🖺 173
► Simulation		→ 🖺 176
Assign measureme	ent variable	→ 🖺 177
Value process varia	able	→ 🖺 177
Switch output simu	ılation	→ 🖺 177
Switch status		→ 🖺 178
Simulation device a	alarm	→ 🖺 178
Simulation diagnos	stic event	→ 🖺 178
Simulation diagnos	stic event	→ 🖺 178

▶ Device check	→ 🖺 179
Start device check	→ 🖺 179
Result device check	→ 🖺 179
Last check time	→ 🖺 179
Level signal	→ 🖺 180
► Heartbeat	→ 🖺 181

108

"Setup" menu 16.3



- 🗐 : Marks the navigation path to the parameter via the display and operating module.
 - : Marks the navigation path to the parameter via an operating tool (e.g. FieldCare).
 - 🗈 : Marks parameters which can be locked via the software locking.

Navigation ■ ■ Setup

Device tag		
Navigation	Setup → Device tag	
Description	Enter tag for measuring point.	
User entry	Up to 32 alphanumerical characters	
Factory setting	FMR5x	
Device address		a
Navigation	Setup → Device address	
Description	 for Address mode = Software: Enter bus address. for Address mode = Hardware: Displays bus address. 	
User entry	0 to 126	

Distance unit	<u> </u>

Navigation	Setup → Distance unit	
Description	Length unit for distance calcu	ılation.
Selection	SI units mm m	US units ■ ft ■ in

126

Factory setting m

Factory setting

Tank type

Prerequisite Medium type (→ 🖺 123) = Liquid

Description Select tank type.

Selection Bypass / pipe

- Stilling wellWorkbench testOpen channel
- Sphere
- Storage vessel
- Process vessel standardProcess vessel with agitatorWave quide antenna

Factory setting Depending on the antenna

Additional information Depending on the antenna some of the options mentioned above may not be available or

there may be additional options.

Tube diameter

Navigation $\blacksquare \Box$ Setup \rightarrow Tube diameter

Prerequisite Tank type ($\rightarrow \equiv 110$) = Bypass / pipe

Description Specify diameter of bypass or stilling well.

User entry 0 to 9.999 m

Factory setting 0 m

Medium group

Navigation $\blacksquare \Box$ Setup \rightarrow Medium group

Prerequisite Medium type (→ 🖺 123) = Liquid

Description Select medium group.

Selection • Others

■ Water based (DC >= 4)

Factory setting Others

Additional information

This parameter roughly specifies the dielectric constant (DC) of the medium. For a more detailed definition of the DC use the **Medium property** parameter ($\rightarrow \square$ 123).

The **Medium group** parameter presets the **Medium property** parameter ($\rightarrow \implies 123$) as follows:

Medium group	Medium property (→ 🖺 123)
Others	Unknown
Water based (DC >= 4)	DC 4 7

- The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.
- The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.


Empty calibration	Â

Description Distance process connection to min. level.

User entry Depending on the antenna

Factory setting Depending on the antenna

Additional information



 \blacksquare 30 Empty calibration (E) for level measurements in liquids

The measuring range starts at the point at which the radar beam hits the tank or silo bottom. In the case of dished boiler ends or conical outlets levels below this point can not be measured.


Full calibration

Description Span: max. level - min level.

User entry Depending on the antenna

Factory setting Depending on the antenna

Additional information




 \blacksquare 31 Full calibration (F) for level measurements in liquids

Level

Description Displays measured level L (before linearization).

Additional information



■ 32 Level in case of liquid measurements

The unit is defined in the **Level unit** parameter ($\rightarrow \triangleq 126$).


Distance

Navigation

Description

Displays the measured distance D between the reference point (lower edge of the flange or threaded connection) and the level.

Additional information



■ 33 Distance for liquid measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 109$).

Signal quality

Navigation

Setup → Signal quality

Description

Displays the signal quality of the level echo.

Additional information

Meaning of the display options

Strong

The evaluated echo exceeds the threshold by at least 10 dB.

■ Mediun

The evaluated echo exceeds the threshold by at least 5 dB.

Weak

The evaluated echo exceeds the threshold by less than 5 dB.

No signal

The device does not find a usable echo.

The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level echo or the tank bottome echo. To differentiate between these two, the quality of the tank bottom echo echo is always displayed in brackets.



In case of a lost echo (**Signal quality = No signal**) the device generates the following error message:

- F941, for Output echo lost (\rightarrow 🗎 139) = Alarm.
- S941, if another option has been selected in **Output echo lost** (→ 🖺 **139**).

Confirm distance

Navigation

Description

Specify, whether the measured distance matches the real distance.

Depending on the selection the device automatically sets the range of mapping.

Selection

- Manual map
- Distance ok
- Distance unknown
- Distance too small *
- Distance too big
- Tank empty
- Factory map

Factory setting

Distance unknown

Additional information

Meaning of the options

Manual map

To be selected if the range of mapping is to be defined manually in the **Mapping end point** parameter ($\rightarrow \equiv 115$). In this case it is not necessary to confirm the distance.

■ Distance ok

To be selected if the measured distance matches the actual distance. The device performs a mapping.

Distance unknown

To be selected if the actual distance is unknown. A mapping can not be performed in this case.

^{*} Visibility depends on order options or device settings

■ Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

■ Distance too big 8)

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range as defined by the **Tank/silo height** parameter ($\rightarrow \boxminus 127$). By default, **Tank/silo height** = **Empty calibration**. Take into account that in case of conical outlets, for example, a measurement is only possible up to the point at which the radar hits the bottom of the tank or silo. If the **Tank empty** option is used, **Empty calibration** ($\rightarrow \boxminus 111$) and **Tank/silo height** may not reach below this point as otherwise the empty signal is suppressed.

Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

- When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.
- If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.

Present mapping		
Navigation	Setup → Present mapping	
Description	Indicates up to which distance a mapping has already been recorded.	
Mapping end point		
Navigation	Setup → Mapping end point	
Prerequisite	Confirm distance (→ 🖺 114) = Manual map or Distance too small	
Description	Specify new end of the mapping.	
User entry	0.1 to 999 999.9 m	
Factory setting	0.1 m	

⁸⁾ Only available for "Expert \rightarrow Sensor \rightarrow Echo tracking \rightarrow **Evaluation mode** parameter" = "Short time history" or "Long time history"

Additional information

This parameter defines up to which distance the new mapping is to be recorded. The distance is measured from the reference point, i.e. from the lower edge of the mounting flange or the threaded connection.



For reference purposes the **Present mapping** parameter ($\Rightarrow \triangleq 115$) is displayed together with this parameter. It indicates up to which distance a mapping has already been recorded.

Record map			<u> </u>
Navigation		Setup → Record map	
Prerequisite	Confi	rm distance (→ 🗎 114) = Manual map or Distance too small	
Description	Start 1	recording of the map.	

Selection

- No
- Record map Overlay map Factory map ■ Delete partial map

Factory setting

No

Additional information

Meaning of the options

The map is not recorded.

Record map

The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing \square .

Overlay map

The new mapping curve is generated by overlaying the old and the current envelope curves.

Factory map

The factory map stored in the ROM of the device is used.

■ Delete partial map

The mapping curve is deleted up to **Mapping end point** ($\rightarrow \square 115$).

16.3.1 "Mapping" wizard

The **Mapping** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the **Setup** menu (→ ≅ 109).

In the **Mapping** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Confirm distance		A
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🖺 114	
Mapping end point		
Navigation	Setup → Mapping → Mapping end point	
Description	→ 🖺 115	
Record map		
Navigation		
Description	→ 🖺 116	
Distance		
Navigation	Setup → Mapping → Distance	
Description	→ 🗎 113	

Prepare recording map

Navigation Setup \rightarrow Mapping \rightarrow Prepare recording map

Description Indicates the progress of the recording of the map.

User interface

- Init. recordingIn progressFinished

16.3.2 "Analog input 1 to 6" submenu

i

There is an **Analog input** submenu for each AI block of the device. The AI block is used to configure the measured value transmission to the bus.

Only the most basic properties of the AI blocks can be configured in this submenu. For a detailed configuration of the AI blocks refer to Expert \rightarrow Analog inputs \rightarrow Analog input 1 to 6.

Navigation \square Expert \rightarrow Analog inputs \rightarrow Analog input 1 to 6

Channel **Navigation** Expert \rightarrow Analog inputs \rightarrow Analog input 1 to 6 \rightarrow Channel Description Standard parameter **CHANNEL** of the Analog Input Block according to the PROFIBUS Profile. Selection Level linearized Distance ■ Terminal voltage ■ Electronic temperature Absolute echo amplitude ■ Relative echo amplitude Sensor debug Analog output adv. diagnostics 1 Analog output adv. diagnostics 2 Factory setting Level linearized

PV filter time

Navigation \blacksquare Expert \rightarrow Analog inputs \rightarrow Analog input 1 to 6 \rightarrow PV filter time

Allocates a measured value to the AI block.

Description Standard parameter **PV_FTIME** of the Analog Input Block according to the PROFIBUS

profile.

User entry Positive floating-point number

Factory setting 0

Additional information

Additional information This parameter defines the damping constant τ (in seconds) for the output of the Analog

Input Block.

Fail safe type

Description Standard parameter **FSAFE_TYPE** of the Analog Input Block according to the PROFIBUS

profile.

Selection • Fail safe value

■ Fallback value

■ Off

Factory setting Off

Additional information Meaning of the options

This parameter specifies the output value of the Analog Input block in the event of an $\,$

error.

■ Fail safe value

The output value in the event of an error is defined in the **Fail safe value** parameter

(→ 🗎 120). ■ Fallback value

The last output value that was valid before the error occurred is retained.

Off

The output value follows the current measured value. The status is set to BAD.

Fail safe value

Navigation \blacksquare Expert \rightarrow Analog input 1 to 6 \rightarrow Fail safe value

Prerequisite Fail safe type ($\rightarrow \triangleq 120$) = Fail safe value

Description Standard parameter **FSAFE VALUE** of the Analog Input Block according to the PROFIBUS

profile.

User entry Signed floating-point number

Factory setting 0

Additional information This parameter defines the output value of the Analog Input Block in case of an error.

16.3.3 "Advanced setup" submenu

Navigation \square Setup \rightarrow Advanced setup

Locking status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Locking status

Description Indicates the write protection with the highest priority that is currently active.

User interface ■ Hardware locked

- SIL locked
- WHG locked
- Temporarily locked

Additional information

Meaning and priorities of the types of write protection

■ Hardware locked (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.

■ SIL locked (priority 2)

The SIL mode is activated. Writing access to the relevant parameters is denied.

WHG locked (priority 3)

The WHG mode is activated. Writing access to the relevant parameters is denied.

Temporarily locked (priority 4)

Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.

On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

Access status tooling

Navigation \square Setup \rightarrow Advanced setup \rightarrow Access status tooling

Description Shows the access authorization to the parameters via the operating tool.

Additional information

The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \implies 122)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 121$).

Access status display

Navigation

Setup → Advanced setup → Access status display

Prerequisite

The device has a local display.

Description

Indicates access authorization to parameters via local display.

Additional information

The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \implies 122)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 121$).

Enter access code

Navigation

Description

Enter access code to disable write protection of parameters.

User entry

0 to 9999

Additional information

- If an incorrect access code is entered, the user retains his current access authorization.
- The write protection affects all parameters marked with the ♠-symbol in this document. On the local display, the ♠-symbol in front of a parameter indicates that the parameter is write-protected.
- If no key is pressed for 10 min, or the user switches from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after another 60 s.
- Please contact your Endress+Hauser Sales Center if you lose your access code.

"Level" submenu

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Level

Medium type

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium type

Description Specify type of medium.

User interface ■ Liquid ■ Solid

Additional information

Selection

Factory setting FMR50, FMR51, FMR52, FMR53, FMR54: **Liquid**

111110 0, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1, 111110 1,

This parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended **not to change** the factory setting.

Medium property

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium property

Description Specify relative dielectric constant ε_r of the medium.

Unknown
DC 1.4 ... 1.6
DC 1.6 ... 1.9
DC 1.9 ... 2.5
DC 2.5 ... 4

DC 2.5 ... 4
DC 4 ... 7
DC 7 ... 15
DC > 15

Factory setting Dependent on Medium type ($\rightarrow \triangleq 123$) and Medium group ($\rightarrow \triangleq 110$).

Additional information Dependency on "Medium type" and "Medium group"

Medium type (→ 🗎 123)	Medium group (→ 🖺 110)	Medium property
Solid		Unknown
Liquid	Water based (DC >= 4)	DC 4 7
	Others	Unknown

For dielectric constants (DC values) of many media commonly used in various industries refer to:

- the Endress+Hauser DC manual (CP01076F)
- the Endress+Hauser "DC Values App" (available for Android and iOS)

Max. filling speed liquid

Navigation

Prerequisite

Medium type (→ 🖺 123) = Liquid

Description

Select expected maximum filling speed.

Selection

- Slow < 1cm (0,4in) /min
- Medium < 10cm (4in) /min
- Standard < 1m (40in) /min
- Fast < 2m (80in) /min
- Very fast > 2m (80in) /min
- No filter / test

Factory setting

Depending on the **Tank type** parameter ($\rightarrow \equiv 110$)

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

Max. filling speed liquid	Step response time / s
Slow < 1cm (0,4in) /min	90
Medium < 10cm (4in) /min	50
Standard < 1m (40in) /min	20
Fast < 2m (80in) /min	8
Very fast > 2m (80in) /min	5
No filter / test	< 1

i

Max. filling speed liquid is preset by Tank type ($\rightarrow \boxminus 110$). It can, however, be adjusted to the process in the vessel at any time. If Tank type ($\rightarrow \boxminus 110$) is changed again at a later point of time, it may be necessary to repeat the fine adjustment.

Max. draining speed liquid

Navigation

Prerequisite

Medium type (→ 🗎 123) = Liquid

Description

Select expected maximum draining speed.

Selection

- Slow < 1cm (0,4in) /min
- Medium < 10cm (4in) /min
- Standard < 1m (40in) /min
- Fast < 2m (80in) /min
- Very fast > 2m (80in) /min
- No filter / test

Factory setting

Depending on the **Tank type** parameter ($\rightarrow \implies 110$)

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

Max. draining speed liquid (→ 🖺 124)	Step response time / s
Slow < 1cm (0,4in) /min	90
Medium < 10cm (4in) /min	50
Standard < 1m (40in) /min	20
Fast < 2m (80in) /min	8
Very fast > 2m (80in) /min	5
No filter / test	< 1

Max. draining speed liquid (→ 🗎 124) is preset by Tank type (→ 🗎 110). It can, however, be adjusted to the process in the vessel at any time. If Tank type (→ 🖺 110) is changed again at a later point of time, it may be necessary to repeat the fine adjustment.

Advanced process conditions

Navigation

Description

Specify additional process conditions (if required).

Selection

- Foam (>5cm/0,16ft)
- Changing DC values
- Small tanks (< 1m/3ft)

Factory setting

None

Additional information

"Foam (>5cm/0,16ft)" option

This option makes sure that no tank history is used which has been recorded while foam was present at the surface and thus is no reliable map of the tank property. To achieve this, the setting **Evaluation mode** = **Long time history** is deactivated.

The **Foam (>5cm/0,16ft)** option is only available for liquid applications (FMR50, FMR51, FMR52, FMR53, FMR54).

"Changing DC values" option

A tank history which has been recorded with **Evaluation mode** = **Long time history** is only valid for a fixed dielectric constant. The **Changing DC values** option disables the setting **Evaluation mode** = **Long time history** and thus avoids wrong measuring values in the case of a changing dielectric constant.

The **Changing DC values** option is only available for liquid applications (FMR50, FMR51, FMR52, FMR53, FMR54).

"Small tanks (< 1m/3ft)" option

This option provides a simple possibility to reduce the echo width of the sensor module. This enables an improved detection of superimposed echos - especially in the near field. Internally, all paramters related to the echo width are adjusted by this option.

The **Small tanks (< 1m/3ft)** option is only available for liquid measurements with 26 GHz HF module (FMR50, FMR51, FMR52).

Level unit

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level unit

Description Select level unit.

Selection $SI \ units$ $US \ units$ $\bullet \ \%$

■ m ■ mm

Factory setting %

Additional information The level unit may differ from the distance unit defined in the **Distance unit** parameter $(\rightarrow \implies 109)$:

■ in

- The unit defined in the **Distance unit** parameter is used for the basic calibration (**Empty calibration** ($\rightarrow \boxminus 111$) and **Full calibration** ($\rightarrow \boxminus 112$)).
- The unit defined in the **Level unit** parameter is used to display the (unlinearized) level.

Blocking distance

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Blocking distance

Description Specify blocking distance BD.

User entry 0 to 200 m

Factory setting • FMR50, FMR51, FMR53, FMR54: antenna length

• FMR52: antenna length + 200 mm (7.9 in)

Additional information


Signals in the blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

This behavior is only valid if the following two conditions are met:

- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history
- Expert → Sensor → Gas phase compensation → GPC mode= **On**, **Without correction** or **External correction**

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



₹ 34 Blocking distance (BD) for liquid measurements

Level correction

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level correction

Description Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

Factory setting 0.0 %

Additional information The value specified in this parameter is added to the measured level (before linearization).

Tank/silo height

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Tank/silo height

Description Specify total height of the tank or silo as measured from the process connection.


User entry -999.9999 to 999.9999 m

Factory setting Empty calibration ($\rightarrow \equiv 111$)

Additional information If the parametrized measuring range (**Empty calibration** ($\rightarrow \equiv 111$)) differs significantly

from the tank or silo height, it is recommended to enter the tank or silo height. Example:

Continuous level monitoring in the upper third of a tank or silo.




E Empty calibration (\rightarrow 🖺 111)

H Tank/silo height (\rightarrow \boxminus 127)

For tanks with conical outlet, **Tank/silo height** should not be changed as in this type of applications **Empty calibration** (→ 🖺 111) is usually **not** << the tank or silo height.

"Linearization" submenu




₹ 36 Linearization: Transformation of the level and (if relevant) the interface height into a volume or weight; the transformation is dependent on the shape of the vessel.

- Selection of linearization type and unit
- Configuration of the linearization 2
- Linearization type ($\rightarrow \triangleq 132$) = None Linearization type ($\rightarrow \triangleq 132$) = Linear Α
- В
- С Linearization type ($\rightarrow \blacksquare 132$) = Table
- Linearization type ($\rightarrow = 132$) = Pyramid bottom
- Linearization type ($\Rightarrow \triangleq 132$) = Conical bottom Е
- F Linearization type ($\rightarrow \equiv 132$) = Angled bottom
- G Linearization type ($\rightarrow \equiv 132$) = Horizontal cylinder
- Н Linearization type ($\rightarrow \equiv 132$) = Sphere
- Level before linearization (measured in distance units) L
- Ľ
- Μ Maximum value (→ 🖺 135)
- *Diameter* (→ **135**) d
- *Intermediate height (→ 🖺 135)*


Structure of the submenu on the display module

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization



Structure of the submenu in an operating tool (e.g. FieldCare)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization



Description of parameters

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Linearization

Linearization type

Navigation Setup \rightarrow Advanced setup \rightarrow Linearization type

Description Select linearization type.


Selection ■ None

- Linear
- Table
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

Factory setting

None

Additional information



■ 37 Linearization types

- A None
- B Table
- C Pyramid bottom
- D Conical bottom
- E Angled bottom
- F Sphere
- G Horizontal cylinder

Meaning of the options

None

The level is transmitted in the level unit without linearization.

■ Linear

The output value (volume/weight) is directly proportional to the level L. This is valid, for example, for vertical cylinders. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value (→** 🖺 **135)**: Maximum volume or weight

Table

The relationship between the measured level L and the output value (volume/weight) is given by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight", respectively. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- Table mode (→ 🗎 136)
- For each table point: **Level** (\rightarrow $\stackrel{\triangle}{=}$ **137**)
- For each table point: **Customer value** (→ 🖺 **138**)

Pyramid bottom

The output value corresponds to the volume or weight in a silo with pyramid bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value** (→ 🗎 **135**): Maximum volume or weight
- **Intermediate height (→ 135)**: The height of the pyramid

Conical bottom

The output value corresponds to the volume or weight in a tank with conical bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value** (→ 🖺 **135**): Maximum volume or weight
- **Intermediate height (→ 135)**: The height of the conical part of the tank

Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value** (→ 🖺 **135**): Maximum volume or weight
- **Intermediate height (→ 135)**: Height of the angled bottom

Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value** (→ 🗎 **135**): Maximum volume or weight
- Diameter (→ 🖺 135)

Sphere

The output value corresponds to the volume or weight in a spherical tank. The following additional parameters have to be specified:

- Unit after linearization (→ 🗎 133)
- **Maximum value** (→ 🖺 **135**): Maximum volume or weight

Unit after linearization

Navigation Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Unit after linearization

Prerequisite Linearization type (\rightarrow \cong 132) \neq None

Description Select unit of the lineaized value.

SelectionSI unitsUS unitsImperial units• STon• IbimpGal• t• UsGal

■ ft³

■ kg ■ cm³

■ dm³

■ m³

■ hl

- 1

• %

Custom-specific units

Free text

Factory setting

%

Additional information

The selected unit is only used to be indicated on the display. The measured value is **not** transformed according to the selected unit.

It is also possible to configure a distance-to-distance linearization, i.e. a transformation from the level unit to a different distance unit. To do so, select the **Linear** linearization mode. In order to define the new level unit, select the **Free text** option in the **Unit after linearization** parameter and enter the required unit into the **Free text** parameter ($\rightarrow \implies 134$).

Free text

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Free text

Prerequisite Unit after linearization (→ 🗎 133) = Free text

Description Enter unit symbol.

User entry Up to 32 alphanumerical characters (letters, numbers, special characters)

Factory setting Free text

Level linearized

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level linearized

Description Displays linearized level.

Additional information The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 133$.

Maximum value Navigation Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Maximum value Prerequisite

Linearization type ($\rightarrow \triangleq 132$) has one of the following values:

■ Linear

Pyramid bottom Conical bottom Angled bottom ■ Horizontal cylinder

Sphere

-50 000.0 to 50 000.0 % User entry

Factory setting 100.0 %

Diameter

Navigation Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Diameter

Linearization type ($\rightarrow \Box$ 132) has one of the following values: Prerequisite

Horizontal cylinder

■ Sphere

0 to 9999.999 m User entry

2 m **Factory setting**

Additional information The unit is defined in the **Distance unit** parameter ($\rightarrow \equiv 109$).

Intermediate height

Navigation


Prerequisite **Linearization type** ($\rightarrow \equiv 132$) has one of the following values:

> Pyramid bottom Conical bottom Angled bottom

0 to 200 m User entry

Factory setting $0 \, \mathrm{m}$

Additional information



H Intermediate height

The unit is defined in the **Distance unit** parameter ($\Rightarrow \triangleq 109$).

Table mode

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Table mode

Prerequisite Linearization type (→ 🗎 132) = Table

Description Select editing mode of the linearization table.

Selection • Manual

- Semiautomatic*
- Clear table
- Sort table

Factory setting Manual

Additional information

Meaning of the options

Manual

The level and the associated linearized value are entered manually for each linearization point.

Semiautomatic

The level is measured by the device for each linearization point. The associated linearized value is entered manually.

Clear table

Deletes the existing linearization table.

Sort table

Rearranges the linerization points into an ascending order.

^{*} Visibility depends on order options or device settings

Description

User entry

Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.
- Before entering a linearization table, the values for **Empty calibration** ($\rightarrow \equiv 111$) and **Full calibration** ($\rightarrow \equiv 112$) must be set correctly.

How to enter the table

Via FieldCare

The table points can be entered via the **Table number** ($\rightarrow \triangleq 137$), **Level** ($\rightarrow \triangleq 137$) and **Customer value** ($\rightarrow \triangleq 138$) parameters. As an alternative, the graphic table editor may be used: Device Operation \rightarrow Device Functions \rightarrow Additional Functions \rightarrow Linearization (Online/Offline)

- Via local display
 Select the Edit table submenu to call up the graphic table editor. The table is displayed and can be edited line by line.
- The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter $(\rightarrow \stackrel{\triangle}{=} 126)$ beforehand.

Table number		
Navigation		
Prerequisite	Linearization type (→ 🖺 132) = Table	
Description	Select table point you are going to enter or change.	
User entry	1 to 32	
Factory setting	1	
Level (Manual)		a
Navigation		
Prerequisite	 Linearization type (→ □ 132) = Table Table mode (→ □ 136) = Manual 	

Endress+Hauser 137

Signed floating-point number

Enter level value of the table point (value before linearization).

Factory setting 0 %

Level (Semiautomatic)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level

Prerequisite • Linearization type ($\rightarrow = 132$) = Table

■ Table mode (→ 🗎 136) = Semiautomatic

Description Displays measured level (value before linearization). This value is transmitted to the table.

Customer value

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Customer value

Prerequisite Linearization type (→ 🖺 132) = Table

Description Enter linearized value for the table point.

User entry Signed floating-point number

Factory setting 0 %

Activate table

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Activate table

Prerequisite Linearization type ($\rightarrow \triangleq 132$) = Table

Description Activate (enable) or deactivate (disable) the linearization table.

Selection ■ Disable

Enable

Factory setting Disable

Additional information Meaning of the options

Disable
 The measured level is not linearized.

If **Linearization type** (\rightarrow \cong **132)** = **Table** at the same time, the device issues error message F435.

■ Enable

The measured level is linearized according to the table.

When editing the table, the **Activate table** parameter is automatically reset to **Disable** and must be reset to **Enable** after the table has been entered.

"Safety settings" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Safety settings

Output echo lost

Navigation Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Output echo lost

Description Output signal in case of a lost echo.

Selection • Last valid value

Ramp at echo lostValue echo lost

Alarm

Factory setting Last valid value

Additional information Meaning of the options

Last valid value

The last valid value is kept in the case of a lost echo.

Ramp at echo lost ⁹⁾

In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the **Ramp at echo lost** parameter ($\rightarrow \triangleq 140$).

Value echo lost 9)

In the case of a lost echo the output assumes the value defined in the **Value echo lost** parameter ($\Rightarrow \triangleq 139$).

Alarm

In the case of a lost echo the device generates an alarm; see the **Failure mode** parameter

Value echo lost

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Value echo lost

Prerequisite Output echo lost $(\rightarrow \triangle 139) =$ Value echo lost

Description Output value in case of a lost echo

User entry 0 to 200 000.0 %

Factory setting 0.0 %

Additional information Use the unit which has been defined for the measured value output:

• without linearization: Level unit (\rightarrow \cong 126)

⁹⁾ Only visible if "Linearization type ($\rightarrow \triangleq 132$)" = "None"

Ramp at echo lost

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Ramp at echo lost


Prerequisite Output echo lost (→ 🖺 139) = Ramp at echo lost

Description Slope of the ramp in the case of a lost echo

User entry Signed floating-point number

Factory setting 0.0 %/min

Additional information



- A Delay time echo lost
- *B* Ramp at echo lost ($\rightarrow \blacksquare 140$) (positive value)
- *C* Ramp at echo lost ($\Rightarrow \triangle 140$) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuously increased until it reaches 100%.

Blocking distance

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety settings \rightarrow Blocking distance

Description Specify blocking distance BD.

User entry 0 to 200 m

Factory setting • FMR50, FMR51, FMR53, FMR54: antenna length

■ FMR52: antenna length + 200 mm (7.9 in)


Additional information Signals in the blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a

level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- This behavior is only valid if the following two conditions are met:
 - Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history
 - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 38 Blocking distance (BD) for liquid measurements

"WHG confirmation" wizard



The **WHG confirmation** wizard is only available for devices with WHG approval (Feature 590: "Additional Approval", option LC: "WHG overfill prevention") which are currently not in the WHG-locked state.

The **WHG** confirmation wizard is used to lock the device according to WHG. For details refer to the "Functional Safety Manual" of the respective device, which describes the locking procedure and the parameters of the sequence.

Navigation

"Deactivate WHG" wizard

The **Deactivate WHG** wizard ($\rightarrow \boxminus 143$) is only visible if the device is WHG-locked. For details refer to the "Functional Safety Manual" of the respective device.

 Reset write protection

 Navigation
 Setup → Advanced setup → Deactivate WHG → Reset write protection

 Description
 Enter unlocking code.

 User entry
 0 to 65 535

 Factory setting
 0

Description Indicates that a wrong unlocking code has been entered. Select procedure.

Selection • Reenter code

Abort sequence

Factory setting Reenter code

Code incorrect

Navigation

"Switch output" submenu

The **Switch output** submenu ($\rightarrow \implies 144$) is only visible for devices with switch output. ¹⁰⁾

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output

Switch output function

Navigation Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch output function

Description Select function for switch output.

Selection ■ Off

- On
 - Diagnostic behavior
 - Limit
 - Digital Output

Factory setting Off

Additional information Meaning of the options

Off

The output is always open (non-conductive).

On

The output is always closed (conductive).

Diagnostic behavior

The output is normally closed and is only opened if a diagnostic event is present. The **Assign diagnostic behavior** parameter ($\rightarrow \implies 145$) determines for which type of event the output is opened.

Limit

The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters:

- Assign limit (→ 🖺 145)
- Switch-on value (\rightarrow $\stackrel{\triangle}{=}$ 146)
- Switch-off value (→

 147)
- Digital Output

The switching state of the output tracks the output value of a DI function block. The function block is selected in the **Assign status** parameter ($\rightarrow \implies 144$).

The **Off** and **On** options can be used to simulate the switch output.

Assign status

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign status

Prerequisite Switch output function (→ 🗎 144) = Digital Output

Description Select device status for switch output.

10) Ordering feature 020 "Power supply; Output", option B, E or G

Selection ■ Off

> ■ Digital output AD 1 ■ Digital output AD 2 ■ Digital output 1 ■ Digital output 2 ■ Digital output 3 ■ Digital output 4

Factory setting Off

Additional information The Digital output AD 1 and Digital output AD 2 options refer to the Advanced

Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the

switch output.

Assign limit

Navigation

Prerequisite Switch output function (→ 🗎 144) = Limit

Selection Off

 Level linearized Distance

■ Terminal voltage

 Electronic temperature ■ Relative echo amplitude

Area of incoupling

Factory setting Off

Assign diagnostic behavior

Setup → Advanced setup → Switch output → Assign diagnostic behavior **Navigation**

Prerequisite Switch output function ($\rightarrow \equiv 144$) = Diagnostic behavior

Description Select diagnostic behavior for switch output.

Selection Alarm

Alarm or warning

Warning

Factory setting Alarm

Switch-on value

Navigation

Prerequisite Switch output function (→ 🗎 144) = Limit

Description Enter measured value for the switch-on point.


User entry Signed floating-point number

0 **Factory setting**

Additional information The switching behavior depends on the relative position of the **Switch-on value** and **Switch-off value** parameters:

Switch-on value > Switch-off value


- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.



- Switch-on value
- В Switch-off value
- С Output closed (conductive)
- Output opened (non-conductive)

Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on delay

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-on delay

Prerequisite ■ Switch output function (→ 🖺 144) = Limit

■ Assign limit (→ 🖺 145) ≠ Off

Description Define delay for the switch-on of status output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Switch-off value

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off value

Prerequisite Switch output function (→ 🗎 144) = Limit

Description Enter measured value for the switch-off point.

User entry Signed floating-point number

Factory setting 0

Additional information The switching behavior depends on the relative position of the **Switch-on value** and

Switch-off value parameters; description: see the Switch-on value parameter

(→ 🖺 146).

Switch-off delay			
Navigation	Setup → Advanced setup → Switch output → Switch-off delay		
Prerequisite	 Switch output function (→ 🗎 144) = Limit Assign limit (→ 🖺 145) ≠ Off 		
Description	Define delay for the switch-off of status output.		
User entry	0.0 to 100.0 s		
Factory setting	0.0 s		
Failure mode			
Navigation	Setup → Advanced setup → Switch output → Failure mode		
Prerequisite	Switch output function (→ 🗎 144) = Limit or Digital Output		
Description	Define output behavior in alarm condition.		
Selection	Actual statusOpenClosed		
Factory setting	Open		
Additional information			
Switch status			
Navigation			
Description	Shows the current switch output status.		
Invert output signal			
Navigation			
Description	Invert the output signal.		
Selection	■ No ■ Yes		

Factory setting

No

Additional information

Meaning of the options

■ No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

"Display" submenu

The **Display** submenu is only visible if a display module is connected to the device.

Navigation

Language

Navigation

Description

Set display language.

Selection

- English
- Deutsch *
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- **■** русский язык (Russian) *
- Svenska
- Türkçe
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
 Bahasa Indonesia *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting

The language selected in feature 500 of the product structure.

If no language has been selected: English

Additional information

Format display

Navigation

Description

Select how measured values are shown on the display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting


1 value, max. size

Visibility depends on order options or device settings


Additional information




■ 39 "Format display" = "1 value, max. size"




"Format display" = "1 bargraph + 1 value" € 40



₽ 41 "Format display" = "2 values"



■ 42 "Format display" = "1 value large + 2 values"



"Format display" = "4 values"

- The Value 1 to 4 display \rightarrow \implies 152 parameters specify which measured values are shown on the display and in which order.
 - If more measured values are specified than the current display mode permits, the values alternate on the device display. The display time until the next change is configured in the **Display interval** parameter ($\rightarrow \implies 152$).

Value 1 to 4 display		
Navigation		
Description	Select the measured value that is shown on the local display.	
Selection	 Level linearized Distance Terminal voltage Electronic temperature Absolute echo amplitude Relative echo amplitude Analog output adv. diagnostics 1 Analog output adv. diagnostics 2 Analog output 1 Analog output 2 Analog output 3 Analog output 4 Area of incoupling 	
Factory setting	Value 1 display: Level linearizedValue 2 display: None	

Value 3 display: NoneValue 4 display: None

1 to 10 s

Decimal places 1 to 4		
Navigation		
Description	Select the number of decimal places for the display value.	
Selection	■ X ■ X.X ■ X.XX ■ X.XXX	
Factory setting	X.XX	
Additional information	The setting does not affect the measuring or computational accuracy of the device.	
Display interval		
Navigation		
Description	Set time measured values are shown on display if display alternates between values.	

152

User entry

Factory setting 5 s

Additional information This parameter is only relevant if the number of selected measuring values exceeds the

number of values the selected display format can display simultaneously.

Display damping

Navigation Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display damping

Description Set display reaction time to fluctuations in the measured value.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Header

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header


Description Select header contents on local display.

Selection ■ Device tag

■ Free text

Factory setting Device tag

Additional information



Position of the header text on the display

Meaning of the options

Device tag

Is defined in the **Device tag** parameter

■ Free text

Is defined in the **Header text** parameter ($\rightarrow \triangleq 153$)

Header text

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header text

Prerequisite Header ($\rightarrow \triangleq 153$) = Free text

Description Enter display header text.

Factory setting ------

Additional information The number of characters which can be displayed depends on the characters used.

Separator

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Separator

Description Select decimal separator for displaying numerical values.

Selection • .

■ ,

Factory setting .

Number format

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Number format

Description Choose number format for the display.

Selection • Decimal

■ ft-in-1/16"

Factory setting Decimal

Additional information The **ft-in-1/16"** option is only valid for distance units.

Decimal places menu

Navigation Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Decimal places menu

Description Select number of decimal places for the representation of numbers within the operating

menu.

Selection • x

■ X.X

x.xxx.xxx

x.xxxx

Factory setting x.xxxx

Additional information

- Is only valid for numbers in the operating menu (e.g. **Empty calibration**, **Full calibration**), but not for the measured value display. The number of decimal places for the measured value display is defined in the **Decimal places 1 to 4** \rightarrow $\stackrel{\triangle}{=}$ 152 parameters.
- The setting does not affect the accuracy of the measurement or the calculations.

Backlight

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Backlight

Prerequisite The device has the SD03 local display (with optical keys).

Description Switch the local display backlight on and off.

Selection • Disable

■ Enable

Factory setting Disable

Additional information Meaning of the options

Disable

Switches the backlight off.

Enable

Switches the backlight on.

Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Contrast display

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

Factory setting Dependent on the display.

Additional information Setting the contrast via push-buttons:

- Darker: press the 🔘 🖲 buttons simultaneously.
- Brighter: press the 🕒 📵 buttons simultaneously.

"Configuration backup display" submenu

i

This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Configuration backup display

Operating time		
Navigation		
Description	Indicates how long the device has been in operation.	
Additional information	Maximum time 9999 d (≈ 27 years)	
Last backup		
Navigation		
Description	Indicates when the last data backup was saved to the display module.	
Configuration manageme	ent	
Navigation		

Select action for managing the device data in the display module.

Factory setting Cancel

Cancel

RestoreDuplicateCompare

■ Execute backup

■ Clear backup data

Description

Selection

Additional information

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ($\rightarrow \implies 157$).

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state		
Navigation		
Description	Displays which backup action is currently in progress.	
Comparison result		
Navigation		
Description	Comparison between present device data and display backup.	

Additional information

Meaning of the display options

Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

■ No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

■ Dataset incompatible

The data sets are incompatible and can not be compared.

- To start the comparison, set **Configuration management** ($\rightarrow \equiv 156$) = **Compare**.
- If the transmitter configuration has been duplicated from a different device by Configuration management (→ 🗎 156) = Duplicate, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be Settings not identical.

"Administration" submenu

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration

Define access code

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

Description Define release code for write access to parameters.

User entry 0 to 9 999

Factory setting 0

Additional information

- If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the configuration data of the device can then always be modified. The user is logged on in the *Maintenance* role.
- The write protection affects all parameters marked with the symbol in this document. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.
- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \)$
- Please contact your Endress+Hauser Sales Center if you lose your access code.
- For display operation: The new access code is only valid after it has been confirmed in the **Confirm access code** parameter ($\rightarrow \equiv 161$).

Device reset

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset

Description Reset the device configuration - either entirely or in part - to a defined state.

Selection • Cancel

To factory defaultsTo delivery settingsOf customer settings

■ To transducer defaults

Restart device

Factory setting Cancel

Additional information

Meaning of the options

Cancel

No action

■ To factory defaults

All parameters are reset to the order-code specific factory setting.

■ To delivery settings

All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered.

This option is only visible if customer specific settings have been ordered.

Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

■ To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

"Define access code" wizard

The **Define access code** wizard is only available when operating via the local display. When operating via an operating tool, the **Define access code** parameter is located directly in the **Administration** submenu. The **Confirm access code** parameter is not available for operation via operating tool.

Navigation

 $\mathsf{Setup} \to \mathsf{Advanced} \ \mathsf{setup} \to \mathsf{Administration} \to \mathsf{Define} \ \mathsf{access}$ code

Define access code		
Navigation		Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code \rightarrow Define access code
Description	→ 	159
Confirm access code		
Navigation		$Setup \to Advanced \ setup \to Administration \to Define \ access \ code \to Confirm \ access \ code$

Confirm the entered access code. Description

0 to 9999 User entry

Factory setting 0

16.4 "Diagnostics" menu

Actual diagnostics		
Navigation	□ Diagnostics → Actual diagnostics	
Description	Displays current diagnostic message.	
Additional information	The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence Event text	
	If several messages are active at the same time, the messages with the highest priority is displayed.	
	Information on what is causing the message, and remedy measures, can be viewed via the ① symbol on the display.	
Timestamp		
Navigation	□ Diagnostics → Timestamp	
Previous diagnostics		
Navigation	□ Diagnostics → Previous diagnostics	
Description	Displays the last diagnostic message which has been active before the current message.	
Additional information	The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence Event text	
	The condition displayed may still apply. Information on what is causing the message, and remedy measures, can be viewed via the ① symbol on the display.	

162

Timestamp

Navigation □ Diagnostics → Timestamp

Operating time from restart

Description Displays the time the device has been in operation since the last device restart.

Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

16.4.1 "Diagnostic list" submenu

Navigation \square Diagnostics \rightarrow Diagnostic list

Diagnostics 1 to 5

Navigation \Box Diagnostics \rightarrow Diagnostic list \rightarrow Diagnostics 1

Description Display the current diagnostics messages with the highest to fifth-highest priority.

Additional information The display consists of:

- Symbol for event behaviorCode for diagnostic behaviorOperating time of occurrence
- Event text

Timestamp 1 to 5

Navigation □ Diagnostics → Diagnostic list → Timestamp

16.4.2 "Event logbook" submenu



The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Navigation

■ Diagnostics → Event logbook

Filter options

Navigation

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information



- This parameter is only used for operation via the local display.
- The status signals are categorized according to NAMUR NE 107.

"Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ($\rightarrow \implies 165$). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- 🕒: Event has ended
- Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation \square Diagnostics \rightarrow Event logbook \rightarrow Event list

16.4.3 "Device information" submenu

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device information

Device tag

Navigation \Box Diagnostics \rightarrow Device information \rightarrow Device tag

Description Enter the name for the measuring point.

Factory setting FMR5x

Serial number

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device information \rightarrow Serial number

Description Shows the serial number of the measuring device.

Additional information

- Uses of the serial number
 - To identify the device quickly, e.g. when contacting Endress+Hauser.
 - To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer
- The serial number is also indicated on the nameplate.

Firmware version

Navigation \blacksquare Diagnostics \rightarrow Device information \rightarrow Firmware version

Description Shows the device firmware version installed.

User interface xx.yy.zz

Additional information For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.

Device name

Navigation \blacksquare Diagnostics \rightarrow Device information \rightarrow Device name

Description Shows the name of the transmitter.

Order code

Navigation \blacksquare Diagnostics \rightarrow Device information \rightarrow Order code

Description Shows the device order code.

Additional information The order code is generated from the extended roder code, which defines all device

features of the product structure. In contrast, the device features can not be read directly

from the order code.

Extended order code 1 to 3

Navigation \blacksquare Diagnostics \rightarrow Device information \rightarrow Extended order code 1

Description Display the three parts of the extended order code.

Additional information The extended order code indicates the version of all the features of the product structure

and thus uniquely identifies the device.

Status PROFIBUS Master Config

Navigation \Box Diagnostics \rightarrow Device information \rightarrow Status PROFIBUS Master Config

Description Indicates whether the cyclic data exchange with the master is currently active.

User interface ■ Active

Not active

PROFIBUS ident number

Navigation \blacksquare Diagnostics \rightarrow Device information \rightarrow PROFIBUS ident number

Description Indicates the ident number of the device.

Additional information The **Ident number selector** parameter can be used to define which ident number is used.

16.4.4 "Measured values" submenu

Navigation \Box Diagnostics \rightarrow Measured values


Distance

Navigation $\blacksquare \Box$ Diagnostics \Rightarrow Measured values \Rightarrow Distance

Description Displays the measured distance D between the reference point (lower edge of the flange or

threaded connection) and the level.

Additional information



■ 44 Distance for liquid measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 109$).

Level linearized

Navigation \Box Diagnostics \rightarrow Measured values \rightarrow Level linearized

Description Displays linearized level.

Additional information The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 133$.

168

Terminal voltage 1

Navigation \Box Diagnostics \rightarrow Measured values \rightarrow Terminal voltage 1

Switch status

Description Shows the current switch output status.

Electronic temperature

Description Displays the current temperature of the electronics.

Additional information The unit is defined in the **Temperature unit** parameter.

"Analog input 1 to 6" submenu 16.4.5

There is an **Analog input** submenu for each Analog Input Block of the device. Only the most important parameters of the respective block are available at this position of the operating menu. For a complete list of the block parameters refer to: Diagnostics → Analog inputs → Analog input 1 to 6

 □ Diagnostics → Analog inputs → Analog input 1 to 6 Navigation

Channel		
Navigation		
Description	Standard parameter CHANNEL of the Analog Input Block according to the PROFIBUS Profile.	
Selection	 Level linearized Distance Terminal voltage Electronic temperature Absolute echo amplitude Relative echo amplitude Sensor debug Analog output adv. diagnostics 1 Analog output adv. diagnostics 2 	
Factory setting	Level linearized	
Additional information	Allocates a measured value to the AI block.	
Out value		_
Navigation		
Description	Element Value of the standard parameter OUT in the Analog Input Block according to the PROFIBUS Profile.	
User entry	Signed floating-point number	
Factory setting	0	
Additional information	 For Mode block actual = Man: Enter the output value of the Analog Input Block. Else: Displays the output value of the Analog Input Block. 	

Out status

Navigation Diagnostics \rightarrow Analog input 1 to 6 \rightarrow Out status

Description Element **Status** of the standard parameter **OUT** in the Analog Input Block according to

the PROFIBUS Profile.

User interface ■ Good

Uncertain

■ Bad

Additional information

Only the two quality bits are evaluated in this parameter.

Out status HEX

Navigation Diagnostics \rightarrow Analog input 1 to 6 \rightarrow Out status HEX

Description Element **Status** of the standard parameter **OUT** in the Analog Input Block according to the

PROFIBUS Profile.

User entry 0 to 255

Factory setting 128

Additional information The complete status byte is displayed in the form of a two-digit hexadecimal number in

this parameter.

16.4.6 "Data logging" submenu

Assign channel 1 to 4

Navigation

Selection

- Off
- Level linearized
- Distance
- Terminal voltage
- Electronic temperature
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2

Factory setting

Off

Additional information

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).



The logged data are deleted if a new option is selected in this parameter.

Logging interval

Navigation

□ Diagnostics → Data logging → Logging interval

User entry

1.0 to 3600.0 s

Factory setting

30.0 s

Additional information

This parameter defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log} :

- If 1 logging channel is used: T $_{log}$ = 1000 · t $_{log}$
- If 2 logging channels are used: $T_{log} = 500 \cdot t_{log}$
- If 3 logging channels are used: $T_{log} = 333 \cdot t_{log}$
- If 4 logging channels are used: $T_{log} = 250 \cdot t_{log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T $_{log}$ always remains in the memory (ring memory principle).

The logged data are deleted if this parameter is changed.

Example

Cancel

When using 1 logging channel

- T_{log} = 1000 · 1 s = 1000 s ≈ 16.5 min T_{log} = 1000 · 10 s = 1000 s ≈ 2.75 h T_{log} = 1000 · 80 s = 80000 s ≈ 22 h T_{log} = 1000 · 3600 s = 3600000 s ≈ 41 d

Clear logging data		
Navigation	Diagnostics \rightarrow Data logging \rightarrow Clear logging data	

■ Clear data

Factory setting Cancel


Selection

"Display channel 1 to 4" submenu



The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.
- To return to the operating menu, press \pm and \Box simultaneaously.

Navigation

16.4.7 "Simulation" submenu


The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.

Conditions which can be simulated

Condition to be simulated	Associated parameters	
Specific value of a process variable	 Assign measurement variable (→ 🗎 177) Value process variable (→ 🖺 177) 	
Specific state of the switch output	 Switch output simulation (→ □ 177) Switch status (→ □ 178) 	
Existence of an alarm	Simulation device alarm (→ 🖺 178)	

Structure of the submenu

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation



Description of parameters

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation

Assign measurement variable

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Assign measurement variable

Selection ■ Off

Level

Level linearized

Factory setting Off

Additional information

■ The value of the variable to be simulated is defined in the **Value process variable**

parameter ($\rightarrow \triangleq 177$).

■ If **Assign measurement variable** ≠ **Off**, a simulation is active. This is indicated by a

diagnotic message of the *Function check (C)* category.

Value process variable

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Value process variable

Prerequisite Assign measurement variable ($\rightarrow \triangleq 177$) $\neq 0$ ff

User entry Signed floating-point number

Factory setting 0

Additional information Downstream measured value processing and the signal output use this simulation value. In

this way, users can verify whether the measuring device has been configured correctly.

Switch output simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch output simulation

Description Switch the simulation of the switch output on and off.

Selection ■ Off

■ On

Factory setting Off

Switch status

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch status

Prerequisite Switch output simulation ($\rightarrow \stackrel{\triangle}{=} 177$) = On

Description Select the status of the status output for the simulation.

Selection ■ Open

Closed

Factory setting Open

Additional information The switch status assumes the value defined in this parameter. This helps to check correct

operation of connected control units.

Simulation device alarm

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Simulation device alarm

Description Switch the device alarm on and off.

Selection ■ Off ■ On

Factory setting Off

Additional information When selecting the **On** option, the device generates an alarm. This helps to check the

correct output behavior of the device in the case of an alarm.

An active simulation is indicated by the diagnostic message **♦ C484 Simulation failure**

mode.

Simulation diagnostic event

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation diagnostic event

Description Select a diagnostic event for the simulation process that is activated.

Factory setting Off

Additional information When operated via the local display, the selection list can be filtered according to the event

categories (Diagnostic event category parameter).

16.4.8 "Device check" submenu

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device check

Start device check

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Start device check

Description Start a device check.

Selection ■ No

Yes

Factory setting No

Additional information In the case of a lost echo a device check can not be performed.

Result device check

Navigation Diagnostics \rightarrow Device check \rightarrow Result device check

Description Displays the result of the device check.

Additional information Me

Meaning of the display options

Installation ok

Measurement possible without restrictions.

Accuracy reduced

A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes.

■ Measurement capability reduced

A measurement is currently possible. However, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.

Check not done

No device check has been performed.

Last check time

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Last check time

Description Displays the operating time at which the last device check has been performed.

Level signal

Navigation \square Diagnostics \rightarrow Device check \rightarrow Level signal

Prerequisite Device check has been performed.

Displays result of the device check for the level signal. Description

User interface ■ Check not done

> ■ Check not OK ■ Check OK

For **Level signal** = **Check not OK**: Check the mounting position of the device and the dielectric constant of the medium. Additional information

16.4.9 "Heartbeat" submenu

The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

Detailed description SD01871F

Navigation \square Diagnostics \rightarrow Heartbeat

Index

A	Device address (Parameter) 109
Access authorization to parameters	Device check (Submenu) 179
Read access	Device information (Submenu) 166
Write access	Device name (Parameter) 166
Access code	Device replacement
Incorrect input	Device reset (Parameter) 159
Access status display (Parameter)	Device tag (Parameter) 109, 166
Access status tooling (Parameter)	Diagnostic event
Accessories	In the operating tool
Communication specific	Diagnostic events
Service specific	Diagnostic list
Activate table (Parameter)	Diagnostic list (Submenu) 164
Actual diagnostics (Parameter)	Diagnostic message
Administration (Submenu)	Diagnostics
Advanced process conditions (Parameter) 125	Symbols
Advanced setup (Submenu)	Diagnostics (Menu)
Analog input 1 to 6 (Submenu) 119, 170	Diagnostics 1 (Parameter) 164
Application	Diagnostics event
Residual risk	Diameter (Parameter)
Assign channel 1 to 4 (Parameter) 172	DIP switch
Assign diagnostic behavior (Parameter) 145	see Write protection switch
Assign limit (Parameter)	Display (Submenu)
Assign measurement variable (Parameter) 177	Display and operating module FHX50 47
Assign status (Parameter)	Display channel 1 to 4 (Submenu) 174
	Display damping (Parameter) 153
В	Display interval (Parameter) 152
Backlight (Parameter)	Display module
Backup state (Parameter)	Display symbols for submenus 57
Blocking distance (Parameter) 126, 140	Display symbols for the locking state 57
	Disposal
C	Distance (Parameter)
CE mark	Distance unit (Parameter) 109
Channel (Parameter)	Document
Cleaning	Function
Clear logging data (Parameter)	Document function
Code incorrect (Parameter)	r
Comparison result (Parameter)	E
Configuration backup display (Submenu)	Electronic temperature (Parameter) 169
Configuration management (Parameter) 156	Electronics housing
Configuration of a level measurement	Design
Confirm access code (Parameter)	Empty calibration (Parameter)
Confirm distance (Parameter)	Enter access code (Parameter)
Context menu	Envelope curve display
Contrast display (Parameter)	Event history
Customer value (Parameter)	Event level
D	Explanation
	Symbols
Data logging (Submenu)	Event list (Submenu)
Decimal places 1 (Parameter)	Event logbook (Submenu)
Decimal places menu (Parameter)	Event text
Declaration of Conformity	Events list
Define access code	Extended order code 1 (Parameter)
Define access code (Parameter)	Exterior cleaning
Define access code (Wizard)	F
Designated use	Fail safe type (Parameter)
Designated use	i an oute type (i arameter)

Fail safe value (Parameter)	Medium property (Parameter)
Filter options (Parameter)	Diagnostics
Format display (Parameter)	Number format (Parameter)
н	Operating elements
	Diagnostics message
Hardware write protection	Operating module
Header text (Parameter)	Operating time (Parameter)
Heartbeat (Submenu)	Operating time from restart (Parameter) 163
Housing	Operational safety
Design	Order code (Parameter)
Turning	Out status (Parameter)
_	Out status HEX (Parameter)
I	Out value (Parameter)
Input mask	Output echo lost (Parameter)
Intermediate height (Parameter)	Overvoltage protection
Invert output signal (Parameter)	General information 41
K	P
Keypad lock	Prepare recording map (Parameter)
Disabling	Present mapping (Parameter)
Switching on	Previous diagnostics (Parameter)
•	Product safety
L	PROFIBUS ident number (Parameter) 167
Language (Parameter)	PV filter time (Parameter)
Last backup (Parameter)	R
Level (Parameter)	Ramp at echo lost (Parameter)
Level (Submenu)	Read access
Level correction (Parameter)	Record map (Parameter)
Level linearized (Parameter)	Registered trademarks
Level measurement configuration 68	Remedial measures
Level signal (Parameter)	Calling up
Level unit (Parameter)	Closing
Linearization (Submenu) 130, 131, 132	Remote operation
Linearization type (Parameter)	Repair concept
Local display	Replacing a device
see Diagnostics message see In alarm condition	Requirements for personnel
Locking status (Parameter)	Result device check (Parameter)
Logging interval (Parameter)	Return
M	S
Maintenance	Safety instructions
Manage device configuration	Basic
Mapping (Wizard)	Safety Instructions (XA)
Max. draining speed liquid (Parameter)	Separator (Parameter)
Max. filling speed liquid (Parameter)	Serial number (Parameter)
Maximum value (Parameter)	Service interface (CDI)
Measured materials	Setting the operating language 67
Measured value symbols	Settings
Measured values (Submenu)	Manage device configuration 72
Medium group (Parameter)	Operating language 67

Setup (Menu)		109
Signal quality (Parameter)		114
Simulation (Submenu)	176,	177
Simulation device alarm (Parameter)		
Simulation diagnostic event (Parameter)		178
Spare parts		
Nameplate		. 87
Start device check (Parameter)		179
Status PROFIBUS Master Config (Parameter)		
Status signals	. 57	7, 76
Submenu		
Administration		
Advanced setup		
Analog input 1 to 6		
Configuration backup display		156
Data logging		172
Device check		179
Device information		
Diagnostic list		164
Display		
Display channel 1 to 4		174
Event list		
Event logbook		165
Events list		
Heartbeat		
Level		123
Linearization		
Measured values		168
Safety settings		139
Simulation		
Switch output		
Switch output (Submenu)		
Switch output function (Parameter)		
Switch output simulation (Parameter)		
Switch status (Parameter) 148,		
Switch-off delay (Parameter)		
Switch-off value (Parameter)		
Switch-on delay (Parameter)		
Switch-on value (Parameter)		140
Symbols For correction		60
In the text and numeric editor		
System components		
System components		. 14
T		
– Table mode (Parameter)		136
Table number (Parameter)		
Tank type (Parameter)		
Tank/silo height (Parameter)		
Terminal voltage 1 (Parameter)		
Timestamp (Parameter) 162,		
Transmitter	,	
Turning the display		35
Turning the display module		
Transmitter housing		
Turning	 .	. 34
Trouble shooting		
Tube diameter (Parameter)		
Turning the display		

Turning the display module	35
U Unit after linearization (Parameter)	3
V Value 1 display (Parameter)	39
W W@M Device Viewer	12 13 15 17 12
Write access	51 51 52
Z Zubehör Gerätespezifisch	88



www.addresses.endress.com