
Valid as of version 01.01.zz (Device firmware) Products

Solutions Services

# Operating Instructions Proline Promag H 500 PROFIBUS PA

Electromagnetic flowmeter







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

# Table of contents

1	About this document	6	6	Installation	23
1.1	Symbols used	6 6 6 7 7	6.1	Installation conditions	23 25 27 27 27 28
1.3	Documentation	8 8		6.2.4 Mounting the transmitter housing: Proline 500 – digital	30
1.4	documentation	8		Proline 500	
2	Basic safety instructions	9		6.2.7 Turning the display module: Proline	33
2.1 2.2	Designated use	9	6.3	500	
2.3 2.4	Workplace safety	.0	7	Electrical connection	35
2.5		.0	7.1	Connection conditions	35
2.6 2.7	IT security	.1		3	35 38
	protection			7.1.4 Device plugs available	39
	J 1	.1 .2 .3		<ul> <li>7.1.5 Pin assignment of device plug</li> <li>7.1.6 Shielding and grounding</li> <li>7.1.7 Preparing the measuring device</li> <li>7.1.8 Preparing the connecting cable:</li> </ul>	39 39 40
3	Product description 1	4		Proline 500 – digital	42
3.1	Product design		<b>7</b> 0	Proline 500	42
J.1	3.1.1 Proline 500 – digital	.4	7.2	Connecting the measuring device: Proline 500 - digital	44 44
4	Incoming acceptance and product				49
	identification 1	6	7.3	Connecting the measuring device: Proline	
4.1 4.2	Incoming acceptance    1      Product identification    1	.6 .6 .7		<ul><li>7.3.1 Connecting the connecting cable</li><li>7.3.2 Connecting the signal cable and the</li></ul>	51 51
	4.2.2 Sensor nameplate 1	9	7.4	supply voltage cable	54 56 56
5	Storage and transport 2	1		7.4.2 Connection example, standard scenario	56
5.1	Storage conditions			7.4.3 Connection example in special	
5.2	Transporting the product	1	7.5	situations	58
	<ul><li>5.2.2 Measuring devices with lifting lugs 2</li><li>5.2.3 Transporting with a fork lift 2</li></ul>		7.6	Hardware settings	61 61
5.3	Packaging disposal 2	2	7.7	Ensuring the degree of protection	

7.8	Post-connection check	. 64	9.4	Using the GSD modules of the previous model	. 95
8	Operation options	65		9.4.1 Using the CONTROL_BLOCK module	
	<u> </u>			in the previous model	
8.1 8.2	Overview of operation options	. 65	9.5	Cyclic data transmission	
0.2	1 3	66		9.5.1 Block model	
	menu			9.5.2 Description of the modules	. 97
	8.2.1 Structure of the operating menu				
0.0	8.2.2 Operating philosophy	67	10	Commissioning	103
8.3	Access to the operating menu via the local	60		_	
	display	68	10.1	Function check	
	8.3.1 Operational display		10.2	Switching on the measuring device	
	8.3.2 Navigation view		10.3	Connecting via FieldCare	
	8.3.3 Editing view		10.4	Configuring the device address via software.	103
	8.3.4 Operating elements		10.5	10.4.1 PROFIBUS network	103
	8.3.5 Opening the context menu		10.5	Setting the operating language	
	8.3.6 Navigating and selecting from list		10.6	Configuring the measuring device	104
	8.3.7 Calling the parameter directly			10.6.1 Defining the tag name	
	8.3.8 Calling up help text			10.6.2 Setting the system units	106
	8.3.9 Changing the parameters	77		10.6.3 Configuring communication	105
	8.3.10 User roles and related access	70		interface	107
	authorization	78		10.6.4 Configuring the analog inputs	109
	8.3.11 Disabling write protection via access	70		10.6.5 Displaying the I/O configuration	109
	code	. 78		10.6.6 Configuring the current input	110
	8.3.12 Enabling and disabling the keypad	70		10.6.7 Configuring the status input	111
0 /	lock	79		10.6.8 Configuring the current output	112
8.4	Access to the operating menu via the Web	70		10.6.9 Configuring the pulse/frequency/	
	browser			switch output	115
	8.4.1 Function range			10.6.10 Configuring the relay output	121
	8.4.2 Prerequisites			10.6.11 Configuring the local display	123
	8.4.3 Establishing a connection			10.6.12 Configuring the low flow cut off	
	8.4.4 Logging on		10.7	10.6.13 Configuring empty pipe detection	126
	8.4.5 User interface		10.7	Advanced settings	127
	8.4.6 Disabling the Web server			10.7.1 Carrying out a sensor adjustment	
0 -	8.4.7 Logging out	. 85		10.7.2 Configuring the totalizer	128
8.5	Access to the operating menu via the	0.6		10.7.3 Carrying out additional display	100
	operating tool			configurations	
	8.5.1 Connecting the operating tool			10.7.4 Performing electrode cleaning	
	8.5.2 FieldCare			10.7.5 WLAN configuration	
	8.5.3 DeviceCare			10.7.6 Configuration management	134
	8.5.4 SIMATIC PDM	. 91		10.7.7 Using parameters for device	100
			10.0	administration	136
9	System integration	92	10.8	Simulation	137
9.1	Overview of device description files	. 92	10.9	Protecting settings from unauthorized	1 /. 0
· · ·	9.1.1 Current version data for the device			access	140
	9.1.2 Operating tools			10.9.1 Write protection via access code	140
9.2	Device master file (GSD)			10.9.2 Write protection via write protection	1 /. 7
	9.2.1 Manufacturer-specific GSD			switch	142
	9.2.2 Profile GSD				
9.3	Compatibility with earlier model		11	Operation	144
	9.3.1 Automatic identification (factory		11.1	Reading the device locking status	144
	setting)	. 94	11.2	Adjusting the operating language	
	9.3.2 Manual setting		11.3	Configuring the display	144
	9.3.3 Replacing the measuring devices		11.4	Reading measured values	144
	without changing the GSD file or			11.4.1 "Process variables" submenu	
	restarting the controller	. 94		11.4.2 Totalizer	
				11.4.3 "Input values" submenu	147
				11.4.4 Output values	148
				<u>T</u>	

11.5	Adapting the measuring device to the process	150
11 (	conditions	150
11.6	Performing a totalizer reset	150
11.7	Showing data logging	151
12	Diagnostics and troubleshooting	155
12.1	General troubleshooting	155
12.2	Diagnostic information via light emitting	
	diodes	158
	12.2.1 Transmitter	158
	12.2.2 Sensor connection housing	159
12.3	Diagnostic information on local display $\dots$	161
	12.3.1 Diagnostic message	161
	12.3.2 Calling up remedial measures	163
12.4	Diagnostic information in the Web browser .	163
	12.4.1 Diagnostic options	163
	12.4.2 Calling up remedy information	164
12.5	Diagnostic information in FieldCare or	
	DeviceCare	164
	12.5.1 Diagnostic options	164
	12.5.2 Calling up remedy information	165
12.6	Adapting the diagnostic information	166
	12.6.1 Adapting the diagnostic behavior $\dots$	166
12.7	Overview of diagnostic information	169
	12.7.1 Diagnostic of sensor	169
	12.7.2 Diagnostic of electronic	171
	12.7.3 Diagnostic of configuration	180
	12.7.4 Diagnostic of process	188
12.8	Pending diagnostic events	192
12.9	Diagnostic list	193
12.10	Event logbook	193
	12.10.1 Reading out the event logbook	193
	12.10.2 Filtering the event logbook	194
	12.10.3 Overview of information events	194
12.11	Resetting the measuring device	195
	12.11.1 Function scope of the "Device reset"	106
10.10	parameter	196
	Device information	196
12.13	Firmware history	198
13	Maintenance	199
13.1	Maintenance tasks	199
	13.1.1 Exterior cleaning	199
	13.1.2 Interior cleaning	199
	13.1.3 Replacing seals	199
13.2	Measuring and test equipment	199
13.3	Endress+Hauser services	199
14	Repairs	200
14.1	General notes	200
	14.1.1 Repair and conversion concept	200
1/ 2	14.1.2 Notes for repair and conversion	200
14.2	Spare parts	200
14.3	Endress+Hauser services	200
14.4 14.5	Return	200 201
14.)	Disposal	201
	TION TO THE THE WAR WELL THE WAR WAS A TO THE TANK THE TA	$_{1}$

	$14.5.2\ \ \ Disposing of the measuring device$	201
15	Accessories	202
15.1	Device-specific accessories	202
	15.1.1 For the transmitter	202
15.2	15.1.2 For the sensor	203 204
15.3	System components	204
16	Technical data	205
16.1	Application	205
16.2	Function and system design	205
16.3	Input	205
16.4	Output	209
16.5	Power supply	213
16.6	Performance characteristics	214
16.7	Installation	216
16.8	Environment	216
16.9	Process	217
16.10	Mechanical construction	219
	Operability	223
	Certificates and approvals	227
16.13	Application packages	229
16.14	Accessories	230
16.15	Supplementary documentation	230
Index	· · · · · · · · · · · · · · · · · · ·	232

### 1 About this document

### 1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

# 1.2 Symbols used

### 1.2.1 Safety symbols

Symbol	Meaning
<b>⚠</b> DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
<b>A</b> WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
<b>▲</b> CAUTION	CAUTION!  This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	<b>NOTE!</b> This symbol contains information on procedures and other facts which do not result in personal injury.

### 1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
~	Alternating current
$\overline{\sim}$	Direct current and alternating current
<del>-</del>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device:  Inner ground terminal: Connects the protectiv earth to the mains supply.  Outer ground terminal: Connects the device to the plant grounding system.

### 1.2.3 Communication symbols

Symbol	Meaning
<b></b>	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
•	LED Light emitting diode is off.

Symbol	Meaning
<del>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</del>	<b>LED</b> Light emitting diode is on.
	<b>LED</b> Light emitting diode is flashing.

# 1.2.4 Tool symbols

Symbol	Meaning
0	Torx screwdriver
96	Phillips head screwdriver
Ó	Open-ended wrench

# 1.2.5 Symbols for certain types of information

Symbol	Meaning
<b>✓</b>	Permitted Procedures, processes or actions that are permitted.
<b>✓ ✓</b>	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
Ţ <u>i</u>	Reference to documentation.
A	Reference to page.
	Reference to graphic.
<b>•</b>	Notice or individual step to be observed.
1., 2., 3	Series of steps.
L	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

# 1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
×	Safe area (non-hazardous area)
≋➡	Flow direction

### 1.3 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
  - *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
  - Endress+Hauser Operations App: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate
- Detailed list of the individual documents along with the documentation code  $\Rightarrow \stackrel{\cong}{=} 230$

### 1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device  The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.
	<ul> <li>Incoming acceptance and product identification</li> <li>Storage and transport</li> <li>Installation</li> </ul>
Transmitter Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).
	<ul> <li>Product description</li> <li>Installation</li> <li>Electrical connection</li> <li>Operation options</li> <li>System integration</li> <li>Commissioning</li> <li>Diagnostic information</li> </ul>
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

### 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

# 1.4 Registered trademarks

### **PROFIBUS®**

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

# 2 Basic safety instructions

### 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

### 2.2 Designated use

### Application and media

The measuring device described in these Brief Operating Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5  $\mu$ S/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ► Keep within the specified pressure and temperature range.
- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ► Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation.  $\rightarrow \blacksquare 8$
- ► Protect the measuring device permanently against corrosion from environmental influences.

### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

### **A** WARNING

### Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

### **NOTICE**

#### Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### Residual risks

### **A** WARNING

# The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

### **A** WARNING

### Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

► Take precautions to prevent injury and material damage if the rupture disk is actuated.

# 2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

▶ Due to the increased risk of electric shock, gloves must be worn.

# 2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

#### Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

### Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

# 2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

### 2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

### 2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater inoperation safety if used correctly. An overview of the most important functions is provided in the following section.

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	Not enabled.	On an individual basis following risk assessment.
Access code (also applies for Web server login or FieldCare connection) → 🖺 12	Not enabled (0000).	Assign a customized access code during commissioning.
WLAN (order option in display module)	Enabled.	On an individual basis following risk assessment.
WLAN security mode	Enabled (WPA2- PSK)	Do not change.
WLAN passphrase (password) → 🖺 12	Serial number	Assign a customized access code during commissioning.
WLAN mode	Access Point	On an individual basis following risk assessment.
Web server→ 🗎 12	Enabled.	On an individual basis following risk assessment.
CDI-RJ45 service interface → 🖺 13	-	On an individual basis following risk assessment.

### 2.7.1 Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

### 2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code
  - Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- WLAN passphrase
  - The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode
  - When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

### User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ( $\rightarrow \cong 140$ ).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

### WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface ( $\rightarrow \boxminus 87$ ), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter  $(\rightarrow \implies 134)$ .

#### Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

### General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, see the "Write protection via access code" section → 🖺 140

### 2.7.3 Access via Web server

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

### 2.7.4 Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

# **3** Product description

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

### 3.1 Product design

Two versions of the transmitter are available.

### **3.1.1 Proline 500 – digital**


Signal transmission: digital

Order code for "Integrated ISEM electronics", option A "Sensor"

For use in applications not required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the sensor, the device is ideal: For simple transmitter replacement.

- A standard cable can be used as the connecting cable.
- Not sensitive to external EMC interference.



A00295

 $\blacksquare$  1 Important components of a measuring device

- 1 Electronics compartment cover
- 2 Display module
- 3 Transmitter housing
- 4 Sensor connection housing with integrated ISEM electronics: connecting cable connection
- 5 Sensoi

### 3.1.2 Proline 500


Signal transmission: analog

Order code for "Integrated ISEM electronics", option **B** "Transmitter"

For use in applications required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the transmitter, the device is ideal in the event of:

- Sensor operation in underground installations.
- Permanent sensor immersion in water.




Δ002958

 $\blacksquare \ 2$  Important components of a measuring device

- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing with integrated ISEM electronics
- 4 Electronics compartment cover
- 5 Sensor
- 6 Sensor connection housing: connecting cable connection
- 7 Connection compartment cover: connecting cable connection

# 4 Incoming acceptance and product identification

### 4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
  - Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section → 

    17.

### 4.2 Product identification

The following options are available for identification of the device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in the *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the device is displayed.
- Enter the serial number from nameplates in the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate using the *Endress+Hauser Operations App*: All information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard documentation on the device" → 🖺 8 and "Supplementary device-dependent documentation" → 🖺 8 sections
- The *W@M Device Viewer*: enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

### 4.2.1 Transmitter nameplate


### Proline 500 - digital



■ 3 Example of a transmitter nameplate

- 1 Name of the transmitter
- 2 Manufacturing location
- 3 Space for approvals: use in hazardous areas
- 4 Degree of protection
- 5 Electrical connection data: available inputs and outputs
- 6 Permitted ambient temperature  $(T_a)$
- 7 2-D matrix code
- 8 Space for approvals and certificates: e.g. CE mark, C-Tick
- 9 Permitted temperature range for cable
- 10 Manufacturing date: year-month
- 11 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 12 Document number of safety-related supplementary documentation
- 13 Space for additional information in the case of special products
- 14 Available inputs and outputs, supply voltage
- 15 Electrical connection data: supply voltage
- 16 Extended order code (ext. ord. cd.)
- 17 Serial number (ser. no.)
- 18 Order code

### Proline 500




A0029192

### ■ 4 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Manufacturing date: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, C-Tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature  $(T_a)$
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

18

### 4.2.2 Sensor nameplate



■ 5 Example of sensor nameplate

- 1 Name of the sensor
- 2 *Manufacturing location*
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Flow; nominal diameter of the sensor; pressure rating; nominal pressure; system pressure; fluid temperature range; material of liner and electrodes
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Flow direction
- 9 2-D matrix code
- 10 Manufacturing date: year-month
- 11 Document number of safety-related supplementary documentation
- 12 CE mark, C-Tick
- 13 Permitted ambient temperature  $(T_a)$

## Order code

The measuring device is reordered using the order code.

### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

# 4.2.3 Symbols on measuring device

Symbol	Meaning
Δ	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
<u> </u>	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

# 5 Storage and transport

### 5.1 Storage conditions


Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ► Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- ▶ Store in a dry and dust-free place.
- ▶ Do not store outdoors.

Storage temperature → 🗎 216

### 5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A002925

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


### 5.2.1 Measuring devices without lifting lugs

### **WARNING**

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ► Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A002921

### 5.2.2 Measuring devices with lifting lugs

### **A** CAUTION

### Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ► The device must always be secured at two lifting lugs at least.


### 5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

### **A** CAUTION

### Risk of damaging the magnetic coil

- ► If transporting by forklift, do not lift the sensor by the metal casing.
- ► This would buckle the casing and damage the internal magnetic coils.



A0029319

### 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:

- Outer packaging of device
   Polymer stretch wrap that complies with EU Directive 2002/95/EC (RoHS)
- Packaging
  - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
  - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Filler material


Paper pads

#### Installation 6

#### 6.1 **Installation conditions**

#### 6.1.1 Mounting position


### Mounting location



Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow:  $h \ge 2 \times DN$ 

### Installation in down pipes


Install a siphon with a vent valve downstream of the sensor in down pipes whose length h  $\geq$  5 m (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.



- € 6 Installation in a down pipe
- Vent valve
- 2 Pipe siphon
- Length of down pipe

### Installation in partially filled pipes

A partially filled pipe with a gradient necessitates a drain-type configuration.



### Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orientation			Recommendation
A	Vertical orientation	•	<b>₩</b>
В	Horizontal orientation, transmitter at	A0015591	<b>✓</b> ✓ 1)
	top	A0015589	
С	Horizontal orientation, transmitter at bottom		2) 3)
D	Horizontal orientation, transmitter at	A0015590	×
	side	A0015592	<u></u>

- Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- To prevent the electronics module from overheating in the case of a sharp rise in temperature (e.g. CIP or SIP processes), install the device with the transmitter component pointing downwards.

### Horizontal

- Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.
- Empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.




A0028998

- EPD electrode for empty pipe detection (available from DN > 15 mm ( $\frac{1}{2}$  in))
- 2 Measuring electrodes for signal detection
- Measuring devices with a nominal diameter < DN 15 mm ( $\frac{1}{2}$  in) do not have an EPD electrode. In this case, empty pipe detection is performed via the measuring electrodes.

### Inlet and outlet runs

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows. Observe the following inlet and outlet runs to comply with accuracy specifications:



Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.

### 6.1.2 Environment- and process-related requirements


### Ambient temperature range

Transmitter	■ Standard: -40 to +60 °C (-40 to +140 °F) ■ Optional: -50 to +60 °C (-58 to +140 °F) (order code for "Test, certificate", option <b>JN</b> "Ambient temperature of transmitter -50 °C (-58 °F)")
Local display	-20 to $+60$ °C ( $-4$ to $+140$ °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	-20 to +60 °C (-4 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner .

### If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

### System pressure



A002877


Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.

Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

Information on the liner's resistance to partial vacuum → ⊇ 218
Information on the shock resistance of the measuring system → ⊇ 217

■ Information on the vibration resistance of the measuring system  $\rightarrow$   $\stackrel{\triangle}{=}$  217

### **Vibrations**



 $\blacksquare$  7 *Measures to avoid device vibrations (L > 10 m (33 ft))* 


In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

Information on the shock resistance of the measuring system  $\rightarrow$   $\stackrel{\triangle}{=}$  217 Information on the vibration resistance of the measuring system  $\rightarrow$   $\stackrel{\triangle}{=}$  217

### **Adapters**

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.

- The nomogram only applies to liquids with a viscosity similar to that of water.
   If the medium has a high viscosity, a larger measuring tube diameter can be considered in order to reduce pressure loss.
- 1. Calculate the ratio of the diameters d/D.
- 2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.




A002900


26

### 6.1.3 Special mounting instructions

### Protective cover



■ 8 Weather protection cover for Proline 500 – digital



Weather protection cover for Proline 500

# 6.2 Mounting the measuring device

### 6.2.1 Required tools

### For transmitter

For mounting on a post:

- Proline 500 digital transmitter
  - Open-ended wrench AF 10
  - Torx screwdriver TX 25
- Proline 500 transmitter Open-ended wrench AF 13

For wall mounting: Drill with drill bit  $\emptyset$  6.0 mm

### For sensor

For flanges and other process connections: Corresponding mounting tools

### 6.2.2 Preparing the measuring device


- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

### 6.2.3 Mounting the sensor

### **A** WARNING

### Danger due to improper process sealing!

- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the gaskets are clean and undamaged.
- ► Install the gaskets correctly.
- 1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
- 2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
- 3. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



A002926

The sensor is supplied to order, with or without pre-installed process connections. Pre-installed process connections are firmly secured to the sensor by 4 or 6 hexagonal-headed bolts.

- ► Depending on the application and pipe length: Support the sensor or secure it additionally.
- ► If using plastic process connections: It is absolutely essential to secure the sensor.
- An appropriate wall mounting kit can be ordered separately as an accessory from Endress+Hauser  $\rightarrow \stackrel{\triangle}{=} 230$ .

### Welding the sensor into the pipe (welding connections)

### **MARNING**

### Risk of destroying the electronics!

- ▶ Make sure that the welding system is not grounded via the sensor or transmitter.
- 2. Release the screws on the process connection flange and remove the sensor, along with the seal, from the pipe.
- 3. Weld the process connection into the pipe.

- 4. Reinstall the sensor in the pipe, and in doing so make sure that the seal is clean and in the right position.
- ► If thin-walled pipes carrying food are welded correctly:

  Disassemble the sensor and seal even if the seal is not damaged by the heat when mounted.
- It must be possible to open the pipe by at least 8 mm (0.31 in) to permit disassembly.

### Mounting the seals

Comply with the following instructions when installing seals:

- 1. In the case of metal process connections, the screws must be tightened securely. The process connection forms a metal connection with the sensor, which ensures a defined compression of the seal.
- 2. In the case of plastic process connections, observe the maximum torques for lubricated threads: 7 Nm (5.2 lbf ft); always insert a seal between the connection and the counterflange in the case of plastic flanges.
- 3. Depending on the application the seals should be replaced periodically, particularly if gasket seals are used (aseptic version)! The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature. Replacement seals can be ordered as an accessory → ≅ 230.


### Mounting grounding rings (DN 2 to 25 (1/12 to 1"))

Pay attention to the information on potential equalization .

In the case of plastic process connections (e.g. flange connections or adhesive fittings), additional ground rings must be used to ensure potential matching between the sensor and the medium. If grounding rings are not installed, this can affect the measuring accuracy or cause the destruction of the sensor as a result of the electrochemical decomposition of the electrodes.

- Depending on the option ordered, plastic disks are used instead of grounding rings on some process connections. These plastic disks only act as "spacers" and do not have any potential matching function. Furthermore, they also perform a significant sealing function at the sensor/process connection interface. Therefore, in the case of process connections without metal grounding rings, these plastic disks/seals should never be removed and should always be installed!

  - Grounding rings, including seals, are mounted inside the process connections. Therefore the installation length is not affected.



A002897

■ 10 Installing grounding rings

- 1 Hexagonal-headed bolts of process connection
- 2 O-ring seals
- 3 Grounding ring or plastic disk (spacer)
- 4 Sensor
- 1. Release the 4 or 6 hexagonal-headed bolts (1) and remove the process connection from the sensor (4).
- 2. Remove the plastic disk (3), along with the two O-ring seals (2), from the process connection.
- 3. Place the first O-ring seal (2) back into the groove of the process connection.
- 4. Fit the metal grounding ring (3) in the process connection as illustrated.
- 5. Place the second O-ring seal (2) into the groove of the grounding ring.
- 6. Mount the process connection back on the sensor. When doing so, make sure to observe the maximum screw tightening torques for lubricated threads: 7 Nm (5.2 lbf ft)

### 6.2.4 Mounting the transmitter housing: Proline 500 – digital

### **A** CAUTION

### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature  $\rightarrow$   $\stackrel{\triangle}{=}$  25.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

### **A** CAUTION

### Excessive force can damage the housing!

► Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

### Post mounting


### **A** WARNING

### Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.


► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)

30



■ 11 Engineering unit mm (in)

### Wall mounting



■ 12 Engineering unit mm (in)

L Depends on order code for "Transmitter housing"

Order code for "Transmitter housing"

- Option **A**, aluminum coated: L =14 mm (0.55 in)
- Option **D**, polycarbonate: L = 13 mm (0.51 in)
- 1. Drill the holes.
- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the securing screws slightly at first.
- 4. Fit the transmitter housing over the securing screws and mount in place.
- 5. Tighten the securing screws.

### 6.2.5 Mounting the transmitter housing: Proline 500

### **A** CAUTION

### Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature  $\rightarrow$   $\stackrel{\triangle}{=}$  25.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

### **A** CAUTION


### Excessive force can damage the housing!

► Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

### Wall mounting




■ 13 Engineering unit mm (in)

- 1. Drill the holes.
- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the securing screws slightly at first.
- 4. Fit the transmitter housing over the securing screws and mount in place.
- 5. Tighten the securing screws.

32


### Post mounting



Engineering unit mm (in)

#### 6.2.6 Turning the transmitter housing: Proline 500


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Release the fixing screw.
- 4. Turn the housing to the desired position.
- 5. Firmly tighten the securing screw.
- 6. Screw on the connection compartment cover
- 7. Depending on the device version: Attach the securing clamp of the connection compartment cover.

#### 6.2.7 Turning the display module: Proline 500

The display module can be turned to optimize display readability and operability.



A003003

- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Turn the display module to the desired position: max.  $8 \times 45^{\circ}$  in each direction.
- 4. Screw on the connection compartment cover.
- 5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

### 6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring device conform to the measuring point specifications?  For example:  Process temperature  Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)  Ambient temperature  Measuring range	
Has the correct orientation for the sensor been selected?  According to sensor type  According to medium temperature  According to medium properties (outgassing, with entrained solids)	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ?	
Are the measuring point identification and labeling correct (visual inspection)?	
Have the fixing screws been tightened with the correct tightening torque?	

#### **Electrical connection** 7

### NOTICE

The measuring device does not have an internal circuit breaker.

- ▶ For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- ▶ Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 10 A) should be integrated into the system installation.

#### 7.1 Connection conditions

#### 7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver ≤ 3 mm (0.12 in)

#### 7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

### **Electrical safety**

In accordance with applicable federal/national regulations.

### Protective ground cable

Cable  $\geq 2.08 \text{ mm}^2 \text{ (14 AWG)}$ 

The grounding impedance must be less than 1  $\Omega$ .

### Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.


### Power supply cable

Standard installation cable is sufficient.

### Signal cable

PROFIBUS PA

Twisted, shielded two-wire cable. Cable type A is recommended.



For further information on planning and installing PROFIBUS networks see:

- Operating Instructions "PROFIBUS DP/PA: Guidelines for planning and commissioning" (BA00034S)
- PNO Directive 2.092 "PROFIBUS PA User and Installation Guideline"
- IEC 61158-2 (MBP)

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

*Pulse/frequency/switch output* 

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient.

Status input


Standard installation cable is sufficient.

### Cable diameter

- Cable glands supplied:  $M20 \times 1.5$  with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm<sup>2</sup> (24 to 12 AWG).

### Choice of connecting cable between the transmitter and sensor

Depends on the type of transmitter and the installation zones



- Proline 500 digital transmitter
- Proline 500 transmitter 2
- 3 Promag sensor
- Non-hazardous area
- Hazardous area: Zone 2; Class I, Division 2
- Hazardous area: Zone 1; Class I, Division 1
- Standard cable to 500 digital transmitter → 🖺 37 Transmitter installed in the non-hazardous area or hazardous area: Zone 2; Class I, Division 2 / sensor installed in the hazardous area: Zone 2; Class I, Division 2 or Zone 1; Class I, Division 1
- Signal cable to 500 transmitter  $\rightarrow \implies 37$ Transmitter and sensor installed in the hazardous area: Zone 2; Class I, Division 2 oder Zone 1; Class I, Division 1

# A: Connecting cable between sensor and transmitter: Proline 500 – digital Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4 cores (2 pairs); uninsulated stranded CU wires; pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover $\geq$ 85 %
Cable length	Maximum 300 m (1000 ft), see the following table.

	Cable lengths for use in			
Cross-section	Non-hazardous area, Hazardous area: Zone 2; Class I, Division 2	Hazardous area: Zone 1; Class I, Division 1		
0.34 mm <sup>2</sup> (AWG 22)	80 m (270 ft)	50 m (165 ft)		
0.50 mm <sup>2</sup> (AWG 20)	120 m (400 ft)	60 m (200 ft)		
0.75 mm <sup>2</sup> (AWG 18)	180 m (600 ft)	90 m (300 ft)		
1.00 mm <sup>2</sup> (AWG 17)	240 m (800 ft)	120 m (400 ft)		
1.50 mm <sup>2</sup> (AWG 15)	300 m (1000 ft)	180 m (600 ft)		
2.50 mm <sup>2</sup> (AWG 13)	300 m (1000 ft)	300 m (1000 ft)		

#### Optionally available connecting cable

Design	$2 \times 2 \times 0.34~\text{mm}^2$ (AWG 22) PVC cable $^{1)}$ with common shield (2 pairs, uninsulated stranded CU wires; pair-stranded)	
Flame resistance	According to DIN EN 60332-1-2	
Oil-resistance	According to DIN EN 60811-2-1	
Shielding	Tin-plated copper-braid, optical cover $\geq$ 85 %	
Operating temperature	When mounted in a fixed position: $-50$ to $+105$ °C ( $-58$ to $+221$ °F); when cable can move freely: $-25$ to $+105$ °C ( $-13$ to $+221$ °F)	
Available cable length	Fixed: 20 m (65 ft); variable: up to maximum 50 m (165 ft)	


 $1) \qquad \text{UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.}$ 

# B: Connecting cable between sensor and transmitter: Proline 500 Signal cable

Design	$3\times0.38~mm^2$ (20 AWG) with common, braided copper shield (Ø $\sim$ 9.5 mm (0.37 in)) and individual shielded cores
Conductor resistance	≤50 Ω/km (0.015 Ω/ft)
Capacitance: core/shield	<420 pF/m (128 pF/ft)
Cable length (max.)	Depends on the medium conductivity, max. 200 m (656 ft)
Cable lengths (available for order)	5 m (15 ft), 10 m (32 ft), 20 m (65 ft) or variable length up to max. 200 m (656 ft)
Operating temperature	−20 to +80 °C (−68 to +176 °F)

0 11			1 1	1
$I \cap II$	currer	nt c	กทเ	0

Design	$3\times0.75~mm^2$ (18 AWG) with common, braided copper shield (Ø $\sim$ 9 mm (0.35 in)) and individual shielded cores
Conductor resistance	<37 Ω/km (0.011 Ω/ft)
Capacitance: core/core, shield grounded	≤120 pF/m (37 pF/ft)
Cable length (max.)	Depends on the medium conductivity, max. 200 m (656 ft)
Cable lengths (available for order)	5 m (15 ft), 10 m (32 ft), 20 m (65 ft) or variable length up to max. 200 m (656 ft)
Operating temperature	−20 to +80 °C (−68 to +176 °F)
Test voltage for cable insulation	≤ AC 1433 V rms 50/60 Hz or ≥ DC 2026 V



A002915

■ 15 Cable cross-section

- a Electrode cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Operation in zones of severe electrical interference

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.

## 7.1.3 Terminal assignment

#### Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply	voltage	Input/output 1		Input/output 2		Input/output 3		Input/output 4	
1 (+)	2 (-)	26 (B) 27 (A)		24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)
			Device-specific terminal assignment: adhesive label in terminal cover.						

#### Transmitter and sensor connection housing: connecting cable

The sensor and transmitter, which are mounted in separate locations, are interconnected by a connecting cable. The cable is connected via the sensor connection housing and the transmitter housing.

Terminal assignment and connection of the connecting cable:

- Proline 500 digital → 🖺 44
- Proline  $500 \rightarrow \blacksquare 51$

### 7.1.4 Device plugs available

Povice plugs may not be used in hazardous areas!

#### Order code for "Input; output 1", option GA "PROFIBUS PA"

Order code for	Cable entry.	/connection
"Electrical connection"	2	3
L, N, P, U	Connector M12 × 1	-

#### 7.1.5 Pin assignment of device plug

		Pin		Assignment	Coding	Plug/socket
2 / 5	73	1	+	PROFIBUS PA +	А	Plug
	<u>/</u> 4	2		Grounding		
		3	-	PROFIBUS PA -		
		4		Not assigned		

## 7.1.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 %is ideal.

- 1. To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus quaranteed.

- 1. Observe national installation requirements and quidelines during installation.
- 2. Where there are large differences in potential between the individual grounding points,

connect only one point of the shielding directly to the reference ground.


3. In systems without potential equalization, the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

#### NOTICE

# In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- ▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.
- ▶ Insulate the shield that is not connected.



■ 16 Connection example for PROFIBUS PA

- 1 Control system (e.g. PLC)
- 2 PROFIBUS PA segment coupler
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

### 7.1.7 Preparing the measuring device

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Connection housing, sensor: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

#### **NOTICE**

#### Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- ▶ Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.


- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- 3. If the measuring device is supplied with cable glands:
  Observe requirements for connecting cables → 

  35.

## 7.1.8 Preparing the connecting cable: Proline 500 – digital

When terminating the connecting cable, pay attention to the following points:

► For cables with fine-wire cores (stranded cables): Fit the cores with ferrules.



Engineering unit mm (in)

A = Terminate the cable

B = Fit ferrules on cables with fine-wire cores (stranded cables)


 $1 = \text{Red ferrules}, \phi 1.0 \text{ mm } (0.04 \text{ in})$ 


#### 7.1.9 Preparing the connecting cable: Proline 500

When terminating the connecting cable, pay attention to the following points:

- In the case of the electrode cable:
   Make sure that the ferrules do not touch the core shields on the sensor side.
   Minimum distance = 1 mm (exception: green "GND" cable)
- 2. In the case of the coil current cable:
  Insulate one core of the three-core cable at the level of the core reinforcement. You only require two cores for the connection.
- 3. For cables with fine-wire cores (stranded cables): Fit the cores with ferrules.

A0029439





Engineering unit mm (in) A = Terminate the cable

- B = Fit ferrules on cables with fine-wire cores (stranded cables)
- 1 = Red ferrules,  $\phi$  1.0 mm (0.04 in)
- 2 =White ferrules,  $\phi$  0.5 mm (0.02 in)

Endress+Hauser 43

A0029438

# 7.2 Connecting the measuring device: Proline 500 - digital

#### NOTICE

#### Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by appropriately trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.


## 7.2.1 Connecting the connecting cable

#### **A** WARNING

#### Risk of damaging the electronic components!

- ► Connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.
- ▶ Ground the connection housing of the sensor via the external screw terminal.

#### Connecting cable terminal assignment



A002819

- 1 Cable entry for cable on transmitter housing
- 2 Protective earth (PE)
- 3 Connecting cable ISEM communication
- 4 Grounding via ground connection; on device plug versions grounding is through the plug itself
- 5 Cable entry for cable or connection of device plug on sensor connection housing
- 6 Protective earth (PE)


#### Connecting the connecting cable to the sensor connection housing

- Connection via connectors with order code for "Sensor connection housing":
   Option C "Ultra-compact hygienic, stainless" → 월 47

#### Connecting the connecting cable to the transmitter

#### Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing": Option  ${\bf A}$  "Aluminum coated"



A0029616

- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - ► This concludes the process for connecting the connecting cable.


#### **A** WARNING

#### Housing degree of protection voided due to insufficient sealing of the housing.

- ► Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- 9. Tighten the securing clamp of the housing cover.

#### Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing": Option  ${\bf B}$  "Stainless, hygienic"




A002961

- 1. Release the securing screw of the housing cover.
- 2. Open the housing cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- **6.** Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - ightharpoonup This concludes the process for connecting the connecting cable.
- 8. Close the housing cover.
- 9. Tighten the securing screw of the housing cover.

#### Connecting the sensor connection housing via the connector


For the device version with the order code for "Sensor connection housing": Option  ${\bf C}$  "Ultra-compact hygienic, stainless"



A002961

- 1. Connect the protective ground.
- 2. Connect the connector.

## Connecting the connecting cable to the transmitter




A00295

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 8. Firmly tighten the cable glands.
  - This concludes the process for connecting the connecting cable.
- 9. Close the housing cover.
- 10. Tighten the securing screw of the housing cover.
- 11. After connecting the connecting cable:Connect the signal cable and the supply voltage cable → 


  49.

#### 7.2.2 Connecting the signal cable and the supply voltage cable



A0028200

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output
- 4 Terminal connection for connecting cable between sensor and transmitter
- 5 Terminal connection for signal transmission, input/output; optional: connection for external WLAN antenna
- 6 Protective earth (PE)



A002959

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 7. Connect the cable in accordance with the terminal assignment .
  - ► **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

**Supply voltage terminal assignment:** Adhesive label in the terminal cover or  $\rightarrow \implies 38$ .

- 8. Firmly tighten the cable glands.
  - ► This concludes the cable connection process.
- 9. Close the terminal cover.
- 10. Close the housing cover.

#### **A** WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

► Screw in the screw without using any lubricant.


#### **MARNING**

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- ► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)
- 11. Tighten the 4 fixing screws on the housing cover.

#### Removing a cable



A00295

- 17 Engineering unit mm (in)
- 1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

50

#### 7.3 Connecting the measuring device: Proline 500

#### NOTICE

#### Limitation of electrical safety due to incorrect connection!

- Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ⊕ before connecting additional cables.
- ▶ For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.


#### 7.3.1 Connecting the connecting cable

#### **A** WARNING

#### Risk of damaging the electronic components!

- ▶ Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

#### Connecting cable terminal assignment



- Protective earth (PE)
- 2 Cable entry for coil current cable on transmitter connection housing
- 3 Coil current cable
- Cable entry for signal cable on transmitter connection housing
- Signal cable
- Cable entry for signal cable on sensor connection housing
- Protective earth (PE)
- Cable entry for coil current cable on sensor connection housing

#### Connecting the connecting cable to the sensor connection housing


Connection via terminals with order code for "Sensor connection housing": Option **B** "Stainless, hygienic"→ 🖺 52

#### Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals  $\rightarrow \triangleq 53$ .

#### Connecting the sensor connection housing via terminals


For the device version, order code for "Sensor connection housing": Option **B**: stainless, hygienic



A00296

- 1. Release the securing screw of the housing cover.
- 2. Open the housing cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
  - └─ This concludes the process for connecting the connecting cables.
- 8. Close the housing cover.
- 9. Tighten the securing screw of the housing cover.

# Connecting the connecting cable to the transmitter




A002959

- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment  $\rightarrow \implies 51$ .
- 7. Firmly tighten the cable glands.
  - This concludes the process for connecting the connecting cables.
- 8. Screw on the connection compartment cover.
- 9. Tighten the securing clamp of the connection compartment cover.
- 10. After connecting the connecting cables:Connect the signal cable and the supply voltage cable → 


  54.

## 7.3.2 Connecting the signal cable and the supply voltage cable




A0026781

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45)
- 4 Protective earth (PE)




A0029813

- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.




A0029814

- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.




- 7. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9. Connect the protective ground.



- A002981
- 10. Connect the cable in accordance with the terminal assignment.
  - ► **Signal cable terminal assignment:** The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

- 11. Firmly tighten the cable glands.
  - ► This concludes the cable connection process.
- 12. Close the terminal cover.
- 13. Fit the display module holder in the electronics compartment.
- 14. Screw on the connection compartment cover.
- 15. Secure the securing clamp of the connection compartment cover.

#### Removing a cable



■ 18 Engineering unit mm (in)

- 1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

## 7.4 Ensuring potential equalization

## 7.4.1 Requirements

#### **A** CAUTION

#### Electrode damage can result in the complete failure of the device!

- ► Same electrical potential for the fluid and sensor
- ► Company-internal grounding concepts
- ▶ Pipe material and grounding

#### 7.4.2 Connection example, standard scenario

#### Metal process connections

Potential equalization is generally via the metal process connections that are in contact with the medium and mounted directly on the sensor. Therefore there is generally no need for additional potential equalization measures.

#### 7.4.3 Connection example in special situations


#### Plastic process connections

In the case of plastic process connections, additional grounding rings or process connections with an integrated grounding electrode must be used to ensure potential matching between the sensor and the fluid. If there is no potential matching, this can affect the measuring accuracy or cause the destruction of the sensor as a result of the electrochemical decomposition of the electrodes.

Note the following when using grounding rings:


- Depending on the option ordered, plastic disks are used instead of grounding rings on some process connections. These plastic disks only act as "spacers" and do not have any potential matching function. Furthermore, they also perform a significant sealing function at the sensor/connection interface. Therefore, in the case of process connections without metal grounding rings, these plastic disks/seals should never be removed and should always be installed!
- Grounding rings can be ordered separately as an accessory from Endress+Hauser . When ordering make sure that the grounding rings are compatible with the material used for the electrodes, as otherwise there is the danger that the electrodes could be destroyed by electrochemical corrosion!
- Grounding rings, including seals, are mounted inside the process connections. Therefore the installation length is not affected.

#### Potential equalization via additional grounding ring



- Hexagonal-headed bolts of process connection
- 2 O-ring seals
- Plastic disk (spacer) or grounding ring
- Sensor

#### Potential equalization via grounding electrodes on process connection




- Hexagonal-headed bolts of process connection
- $Integrated\ grounding\ electrodes$
- O-ring seal
- Sensor

## 7.5 Special connection instructions

## 7.5.1 Connection examples


#### **PROFIBUS PA**



■ 19 Connection example for PROFIBUS PA


- 1 Control system (e.g. PLC)
- 2 PROFIBUS PA segment coupler
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line

#### Current output 4-20 mA




■ 20 Connection example for 4-20 mA current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load
- 3 Transmitter




- 21 Connection example for 4-20 mA current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load
- 4 Transmitter

#### Pulse/frequency output



- 22 Connection example for pulse/frequency output (passive)
- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values → 🖺 209

#### Switch output




- 23 Connection example for switch output (passive)
- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: Observe input values → 🖺 209

Endress+Hauser 59

AUU2876U


#### Relay output



■ 24 Connection example for relay output (passive)

- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- *3* Transmitter: Observe input values → 🖺 210


#### **Current input**



■ 25 Connection example for 4 to 20 mA current input

- 1 Power supply
- 2 Terminal box
- 3 External measuring device (for reading in pressure or temperature, for instance)
- 4 Transmitter

## Status input



■ 26 Connection example for status input

- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter

#### 7.6 Hardware settings

#### 7.6.1 Setting the device address


The address must always be configured for a PROFIBUS DP/PA device. The valid address range is between 1 and 126. In a PROFIBUS DP/PA network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.

Risk of electric shock when opening the transmitter housing.

- ▶ Before opening the transmitter housing:
- Disconnect the device from the power supply.

#### Proline 500 - digital transmitter

Hardware addressing




- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.
- 4. Set the desired device address using the DIP switches.
- 5. To switch addressing from software addressing to hardware addressing: set the DIP switch to On.
  - └ The change of device address takes effect after 10 seconds. The device is restarted.

#### Software addressing


- ► To switch addressing from hardware addressing to software addressing: set DIP switch No. 4 to **Off**.
  - The device address configured in the **Device address** parameter ( $\Rightarrow \implies 108$ ) takes effect after 10 seconds. The device is restarted.

#### Proline 500 transmitter

Hardware addressing



Set the desired device address using the DIP switches in the connection compartment.



To switch addressing from software addressing to hardware addressing: set the DIP switch to  $\mathbf{On}$ .

The change of device address takes effect after 10 seconds. The device is restarted.

#### Software addressing

- ► To switch addressing from hardware addressing to software addressing: set DIP switch No. 4 to **Off**.
  - The device address configured in the **Device address** parameter ( $\Rightarrow \implies 108$ ) takes effect after 10 seconds. The device is restarted.


## 7.6.2 Activating the default IP address

The default IP address 192.168.1.212 can be activated by DIP switch.

#### Activating the default IP address by DIP switch: Proline 500 - digital

Risk of electric shock when opening the transmitter housing.

- ▶ Before opening the transmitter housing:
- ▶ Disconnect the device from the power supply.




A003450

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Set DIP switch No. 2 on the I/O electronics module from **OFF**  $\rightarrow$  **ON**.
- 5. Reverse the removal procedure to reassemble the transmitter.
- 6. Reconnect the device to the power supply.
  - ► The default IP address is used once the device is restarted.

#### Activating the default IP address via the DIP switch: Proline 500

Risk of electric shock when opening the transmitter housing.

- ▶ Before opening the transmitter housing:
- ▶ Disconnect the device from the power supply.



A003449

- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary.
- 3. Set DIP switch No. 2 on the I/O electronics module from **OFF**  $\rightarrow$  **ON**.
- 4. Reverse the removal procedure to reassemble the transmitter.
- 5. Reconnect the device to the power supply.
  - → The default IP address is used once the device is restarted.


## 7.7 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.
- 5. To ensure that moisture does not enter the cable entry:

  Route the cable so that it loops down before the cable entry ("water trap").



A00292


6. Insert dummy plugs into unused cable entries.

### 7.8 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables used meet the requirements?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" → 🖺 64?	
Is the potential equalization established correctly ?	

## **8** Operation options

## 8.1 Overview of operation options




A0026E12

- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Control system (e.g. PLC)

## 8.2 Structure and function of the operating menu

## 8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: "Description of Device Parameters" document supplied with the device→ ≅ 230



 $\blacksquare$  27 Schematic structure of the operating menu

## 8.2.2 Operating philosophy


The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu	ı/parameter	User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuring the operational	<ul> <li>Defining the operating language</li> <li>Defining the Web server operating language</li> <li>Resetting and controlling totalizers</li> </ul>
Operation		display  Reading measured values	<ul> <li>Configuring the operational display (e.g. display format, display contrast)</li> <li>Resetting and controlling totalizers</li> </ul>
Setup		"Maintenance" role Commissioning:  Configuration of the measurement  Configuration of the inputs and outputs  Configuration of the communication interface	Wizards for fast commissioning:  Set the system units  Display I/O/configuration  Configure the inputs  Configure the outputs  Configuring the operational display  Define the output conditioning  Set the low flow cut off  Configure empty pipe detection  Advanced setup  For more customized configuration of the measurement (adaptation to special measuring conditions)  Configuration of totalizers  Configuration of electrode cleaning (optional)  Configure the WLAN settings  Administration (define access code, reset measuring device)
Diagnostics		"Maintenance" role Fault elimination:  Diagnostics and elimination of process and device errors  Measured value simulation	Contains all parameters for error detection and analyzing process and device errors:  Diagnostic list Contains up to 5 currently pending diagnostic messages.  Event logbook Contains event messages that have occurred.  Device information Contains information for identifying the device.  Measured values Contains all current measured values.  Analog inputs Is used to display the analog input.  Data logging submenu with "Extended HistoROM" order option Storage and visualization of measured values  Heartbeat The functionality of the device is checked on demand and the verification results are documented.  Simulation Is used to simulate measured values or output values.

Men	u/parameter	User role and tasks	Content/meaning
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device:  Commissioning measurements under difficult conditions  Optimal adaptation of the measurement to difficult conditions  Detailed configuration of the communication interface  Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device:  System  Contains all higher-order device parameters which do not concern the measurement or the communication interface.  Sensor  Configuration of the measurement.  Output  Configure the pulse/frequency/switch output.  Input  Configuring the status input.  Output  Configuring of the analog current outputs as well as the pulse/frequency and switch output.  Communication  Configuration of the digital communication interface and the Web server.  Submenus for function blocks (e.g. "Analog Inputs")  Configuration of function blocks.  Application  Configure the functions that go beyond the actual measurement (e.g. totalizer).  Diagnostics  Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

## 8.3 Access to the operating menu via the local display

## 8.3.1 Operational display



A002934

- 1 Operational display
- 2 Device tag  $\rightarrow 105$
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements→ 🖺 74


#### Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 161
  - **F**: Failure
  - C: Function check
  - **S**: Out of specification
  - **M**: Maintenance required
- Diagnostic behavior → 🗎 162
  - 🔉: Alarm
  - <u>M</u>: Warning
- 🛱: Locking (the device is locked via the hardware )
- ←: Communication (communication via remote operation is active)

#### Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Appears only if a diagnostics event is present for this measured variable.

#### Measured values

Symbol	Meaning
Ü	Volume flow
G	Conductivity
ṁ	Mass flow
Σ	Totalizer  The measurement channel number indicates which of the three totalizers is displayed.
€	Status input

#### Measurement channel numbers


Symbol	Meaning
14	Measurement channel 1 to 4

The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).

#### Diagnostic behavior


The number and display format of the measured values can be configured via the **Format display** parameter ( $\Rightarrow \triangleq 123$ ).

#### 8.3.2 Navigation view



#### Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



#### Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
  - The direct access code for the parameter you are navigating to (e.g. 0022-1)
  - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal

## Display area

#### Menus

Symbol	Meaning
P	Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu
۶	Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
્યું.	Diagnostics Appears: ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the Diagnostics menu
₹.	Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

### Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
55.	Wizard
Ø.	Parameters within a wizard  No display symbol exists for parameters in submenus.

## Locking


Symbol	Meaning
û	Parameter locked  When displayed in front of a parameter name, indicates that the parameter is locked.  ■ By a user-specific access code  ■ By the hardware write protection switch

### Wizard operation

Symbol	Meaning
<b>←</b>	Switches to the previous parameter.
4	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

#### 8.3.3 **Editing view**


#### Numeric editor



■ 28 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- Operating elements

#### Text editor



- For entering text in parameters (e.g. tag name)
- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- Operating elements
- Move entry position 5
- 6 Delete entry
- Reject or confirm entry

*Using the operating elements in the editing view* 

Operating key(s)	Meaning
	Minus key Move the entry position to the left.
+	Plus key Move the entry position to the right.

Operating key(s)	Meaning
E	<ul> <li>Enter key</li> <li>Press the key briefly: confirm your selection.</li> <li>Press the key for 2 s: confirm the entry.</li> </ul>
-++	Escape key combination (press keys simultaneously) Close the editing view without accepting the changes.

# *Input screens*

Symbol	Meaning
Α	Upper case
a	Lower case
1	Numbers
+*	Punctuation marks and special characters: = + - * / $^2$ $^3$ $^1$ /4 $^1$ /2 $^3$ /4 ( ) [ ] < > { }
0	Punctuation marks and special characters: ' " ` ^. , ; : ? ! % $\mu$ ° $\in$ \$ £ ¥ § @ # / \ I ~ & _
ä	Umlauts and accents

# Controlling data entries

Symbol	Meaning
<b>←→</b>	Move entry position
X	Reject entry
4	Confirm entry
<b>4</b> X	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

# 8.3.4 Operating elements

Operating key(s)	Meaning
	Minus key In a menu, submenu Moves the selection bar upwards in a picklist. With a Wizard Confirms the parameter value and goes to the previous parameter. With a text and numeric editor Move the entry position to the left.
<b>(+)</b>	Plus key In a menu, submenu Moves the selection bar downwards in a picklist. With a Wizard Confirms the parameter value and goes to the next parameter. With a text and numeric editor Move the entry position to the right.
E	Enter key  For operational display Pressing the key briefly opens the operating menu.  In a menu, submenu  Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter.  With a Wizard Opens the editing view of the parameter.  With a text and numeric editor Press the key briefly: confirm your selection. Press the key for 2 s: confirm the entry.
(a)+(+)	Escape key combination (press keys simultaneously)  In a menu, submenu  Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position").  With a Wizard Exits the wizard and takes you to the next higher level.  With a text and numeric editor Close the editing view without accepting the changes.
-+E	<ul> <li>Minus/Enter key combination (press the keys simultaneously)</li> <li>If the keypad lock is active:     Press the key for 3 s: deactivate the keypad lock.</li> <li>If the keypad lock is not active:     Press the key for 3 s: the context menu opens along with the option for activating the keypad lock.</li> </ul>

# 8.3.5 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:


- Setup
- Data backup
- Simulation

74

# Calling up and closing the context menu

The user is in the operational display.

- 1. Press the  $\square$  and  $\square$  keys for longer than 3 seconds.
  - └ The context menu opens.



A0034608-F

- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The context menu is closed and the operational display appears.

# Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
  - ► The selected menu opens.

# 8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements  $\Rightarrow \stackrel{\square}{\Rightarrow} 70$ 

Example: Setting the number of displayed measured values to "2 values"



# 8.3.7 Calling the parameter directly


A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

# Navigation path

Expert → Direct access

76

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
   Example: Enter 00914 → Assign process variable parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.

Example: Enter **00914-2** → **Assign process variable** parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


# 8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

#### Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

- 1. Press E for 2 s.
  - ► The help text for the selected parameter opens.



A0014002-EI

- 30 Example: Help text for parameter "Enter access code"
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The help text is closed.

# 8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.

Ent. access code Invalid or out of range input value Min:0 Max:9999

A0014049-E

For a description of the editing view - consisting of the text editor and numeric editor - with symbols  $\rightarrow \stackrel{\triangle}{=} 72$ , for a description of the operating elements  $\rightarrow \stackrel{\triangle}{=} 74$ 

#### 8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access  $\rightarrow \blacksquare 140$ .

#### Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
  - The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	<b>✓</b> 1)

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	1)

- Despite the defined access code, certain parameters can always be modified and thus are excepted from
  the write protection, as they do not affect the measurement. Refer to the "Write protection via access code"
  section
- The user role with which the user is currently logged on is indicated by the **Access** status parameter. Navigation path: Operation  $\rightarrow$  Access status

# 8.3.11 Disabling write protection via access code

If the  $\widehat{\boxtimes}$ -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation  $\rightarrow \cong 140$ .

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter via the respective access option.

1. After you press E, the input prompt for the access code appears.

- 2. Enter the access code.
  - The \( \bar{\text{\mathbb{\modebota\modebot{\mathbb{\matha\modebot{\mathbb{\mathbb{\matha\modebota\mathbb{\mathbb{\mathbb{\mathbb{\mat

# 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

#### Switching on the keypad lock

- The keypad lock is switched on automatically:
  - If the device has not been operated via the display for > 1 minute.
  - Each time the device is restarted.

#### To activate the keylock manually:

- 1. The device is in the measured value display.

  Press the □ and □ keys for 3 seconds.
  - ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
  - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

### Switching off the keypad lock

- ► The keypad lock is switched on.

  Press the □ and □ keys for 3 seconds.
  - └ The keypad lock is switched off.

# 8.4 Access to the operating menu via the Web browser

#### 8.4.1 Function range

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option  $\mathbf{G}$  "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device

# 8.4.2 Prerequisites

# Computer hardware

Hardware	Interface		
	CDI-RJ45	WLAN	
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.	
Connection	Standard Ethernet cable with RJ45 connector.	Connection via Wireless LAN.	
Screen	Recommended size: ≥12" (depends on the screen resolution)		

# Computer software

Software	Interface	
	CDI-RJ45	WLAN
Recommended operating systems	<ul> <li>Microsoft Windows 7 or higher.</li> <li>Mobile operating systems:         <ul> <li>iOS</li> <li>Android</li> </ul> </li> <li>Microsoft Windows XP is supported</li> </ul>	
Web browsers supported	<ul> <li>Microsoft Internet Explorer 8 or higher</li> <li>Microsoft Edge</li> <li>Mozilla Firefox</li> <li>Google Chrome</li> <li>Safari</li> </ul>	

# Computer settings

Settings	Interface	
	CDI-RJ45	WLAN
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).	
Proxy server settings of the Web browser	The Web browser setting <i>Use a Proxy Server for Your LAN</i> must be <b>deselected</b> .	
JavaScript	JavaScript must be enabled.	
	1	c.html in the address line of the Web nplified version of the operating menu er.
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under <b>Internet options</b> .	
Network connections	Only the active network connections to the measuring device should be used.	
	Switch off all other network connections such as WLAN.	Switch off all other network connections.

 $\blacksquare$  In the event of connection problems:  $\rightarrow$   $\blacksquare$  156

#### Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface
Measuring device	The measuring device has an RJ45 interface.
Web server	Web server must be enabled; factory setting: ON
	For information on enabling the Web server $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

#### Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna:  Transmitter with integrated WLAN antenna Transmitter with external WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ON  For information on enabling the Web server →   85

# 8.4.3 Establishing a connection

# Via service interface (CDI-RJ45)

Preparing the measuring device

Proline 500 - digital

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 connector via the standard Ethernet connecting cable .

#### Proline 500

- 1. Depending on the housing version:

  Release the securing clamp or securing screw of the housing cover.
- 2. Depending on the housing version: Unscrew or open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 connector via the standard Ethernet connecting cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- 2. Connect to the computer using a cable  $\rightarrow \triangleq 86$ .
- 3. If a 2nd network card is not used, close all the applications on the notebook.
  - Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 $\rightarrow$ e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

#### Via WLAN interface

Configuring the Internet protocol of the mobile terminal

#### **NOTICE**

If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

#### NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- ▶ Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

► Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal:

  Select the measuring device using the SSID (e.g. EH\_Promag\_500\_A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
- 🚹 The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

#### Disconnecting


► After configuring the device:

Terminate the WLAN connection between the operating unit and measuring device.

#### Starting the Web browser

1. Start the Web browser on the computer.

- 2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212
  - ► The login page appears.



- 1 Picture of device
- 2 Device name
- 3 Device tag
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code ( $\rightarrow \equiv 137$ )
- If a login page does not appear, or if the page is incomplete  $\rightarrow \triangleq 156$


# 8.4.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (factory setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

# 8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

#### Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal → 🖺 164
- Current measured values

# **Function row**

Functions	Meaning
Measured values	Displays the measured values of the measuring device
Menu	<ul> <li>Access to the operating menu from the measuring device</li> <li>The structure of the operating menu is the same as for the local display</li> <li>For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device</li> </ul>
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	Data exchange between PC and measuring device:  ■ Device configuration:  — Load settings from the device (XML format, save configuration)  — Save settings to the device (XML format, restore configuration)  ■ Logbook - Export Event logbook (.csv file)  ■ Documents - Export documents:  — Export backup data record (.csv file, create documentation of the measuring point configuration)  — Verification report (PDF file, only available with the "Heartbeat Verification" application package)  ■ File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring device: PROFIBUS PA: GSD file  ■ Firmware update - Flashing a firmware version
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the measuring device:  Network settings (e.g. IP address, MAC address)  Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

#### Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

#### Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

# 8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

### **Navigation**

"Expert" menu  $\rightarrow$  Communication  $\rightarrow$  Web server

#### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	<ul><li>Off</li><li>HTML Off</li><li>On</li></ul>	On

# Function scope of the "Web server functionality" parameter

Option	Description
Off	<ul><li>The web server is completely disabled.</li><li>Port 80 is locked.</li></ul>
HTML Off	The HTML version of the web server is not available.
On	<ul> <li>The complete functionality of the web server is available.</li> <li>JavaScript is used.</li> <li>The password is transferred in an encrypted state.</li> <li>Any change to the password is also transferred in an encrypted state.</li> </ul>

# Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

# 8.4.7 Logging out

- Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.
- 1. Select the **Logout** entry in the function row.
  - ► The home page with the Login box appears.
- 2. Close the Web browser.

3. If no longer needed:

Reset modified properties of the Internet protocol (TCP/IP)  $\rightarrow$   $\boxtimes$  81.


# 8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

# 8.5.1 Connecting the operating tool

#### Via PROFIBUS PA network

This communication interface is available in device versions with PROFIBUS PA.



■ 31 Options for remote operation via PROFIBUS PA network

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Segment coupler PROFIBUS DP/PA
- 5 PROFIBUS PA network
- 6 T-box
- 7 Measuring device

### Service interface


Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

An adapter for RJ45 and the M12 connector is optionally available: Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.


# *Proline* 500 – digital transmitter



■ 32 Connection via service interface (CDI-RJ45)

- l Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

#### Proline 500 transmitter




A0027563

■ 33 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 connector
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

# Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A003456

- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device
- 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antennas	<ul> <li>Internal antenna</li> <li>External antenna (optional)         In the event of poor transmission/reception conditions at the place of installation.     </li> <li>Only one antenna active in each case!</li> </ul>
Max. range	50 m (164 ft)
Materials: External WLAN antenna	<ul> <li>Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass</li> <li>Adapter: Stainless steel and nickel-plated brass</li> <li>Cable: Polyethylene</li> <li>Connector: Nickel-plated brass</li> <li>Angle bracket: Stainless steel</li> </ul>

Configuring the Internet protocol of the mobile terminal

# **NOTICE**

If the WLAN connection is lost during the configuration, settings made may be lost.

► Make sure that the WLAN connection is not disconnected while configuring the device.

### NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- ▶ Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

► Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- In the WLAN settings of the mobile terminal: Select the measuring device using the SSID (e.g. EH\_Promag\_500\_A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
  - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
- The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

#### Disconnecting

► After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

#### 8.5.2 FieldCare

#### **Function scope**

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

### Access is via:

- PROFIBUS PA protocol → 86
- CDI-RJ45 service interface → 🖺 86
- WLAN interface > 87

#### Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook
- For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S


#### Source for device description files

See information  $\rightarrow$   $\stackrel{\triangle}{=}$  92

# Establishing a connection

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
  - ► The **Add device** window opens.
- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.
  - The **CDI Communication TCP/IP (Configuration)** window opens.
- 6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
- 7. Establish the online connection to the device.
- For additional information, see Operating Instructions BA00027S and BA00059S

#### User interface



- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal→ 🖺 164
- Display area for current measured values 6
- Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- Working area
- 10 Range of action
- 11 Status area

90

# 8.5.3 DeviceCare

#### **Function scope**

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure INO1047S

# Source for device description files

See information  $\rightarrow$   $\bigcirc$  92

# 8.5.4 SIMATIC PDM

# **Function scope**

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via PROFIBUS PA protocol.

# Source for device description files

See data → 🗎 92

# 9 System integration

# 9.1 Overview of device description files

#### 9.1.1 Current version data for the device

Firmware version	01.01.zz	<ul> <li>On the title page of the Operating instructions</li> <li>On the transmitter nameplate</li> <li>Firmware version         Diagnostics → Device information → Firmware         version</li> </ul>
Release date of firmware version	11.2018	
Manufacturer ID	0x11	Manufacturer ID Diagnostics → Device information → Manufacturer ID
Device type ID	0x156C	Device type Diagnostics → Device information → Device type
Profile version	3.02	

For an overview of the different firmware versions for the device  $\rightarrow \triangleq 198$ 

# 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via PROFIBUS protocol	Sources for obtaining device descriptions
FieldCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>
DeviceCare	<ul> <li>www.endress.com → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>
SIMATIC PDM (Siemens)	www.endress.com → Download Area

# 9.2 Device master file (GSD)

In order to integrate field devices into a bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate.

These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned. In addition device bit maps, which appear as icons in the network structure, can also be integrated.

With the Profile 3.02 device master file (GSD) it is possible to exchange field devices made by different manufacturers without having to reconfigure.

Generally speaking, it is possible to use two different GSDs with Profile 3.02 and higher: the manufacturer-specific GSD and the Profile GSD.

 Before configuring, the user must decide which GSD should be used to operate the system.

■ The setting can be changed via a Class 2 master.

#### 9.2.1 Manufacturer-specific GSD

This GSD quarantees the unrestricted functionality of the measuring device. Device-specific process parameters and functions are therefore available.

Manufacturer-specific GSD	ID number	File name
PROFIBUS PA	0x156C	EH3x156C.gsd

#### Use manufacturer-specific GSD

Assignment is performed in the **Ident number selector** parameter via the **Manufacturer** option.



Sources of supply for the manufacturer-specific GSD:

- Export directly from the device via the integrated web server: Data management → Documents → Export GSD file
- Download via the Endress+Hauser website: www.endress.com → Download-Area

#### 9.2.2 **Profile GSD**

Differs in terms of the number of Analog Input blocks (AI) and the measured values. If a system is configured with a Profile GSD, it is possible to exchange devices made by different manufacturers. However, it is essential to ensure that the order of the cyclic process values is correct.

ID number	Supported blocks	Supported channels
0x9740	<ul><li>1 Analog Input</li><li>1 Totalizer</li></ul>	<ul><li>Channel Analog Input: volume flow</li><li>Channel totalizer: volume flow</li></ul>
0x9741	<ul><li>2 Analog Input</li><li>1 Totalizer</li></ul>	<ul> <li>Channel Analog Input 1: volume flow</li> <li>Channel Analog Input 2: mass flow</li> <li>Channel totalizer: volume flow</li> </ul>
0x9742	<ul><li>3 Analog Input</li><li>1 Totalizer</li></ul>	<ul> <li>Channel Analog Input 1: volume flow</li> <li>Channel Analog Input 2: mass flow</li> <li>Channel Analog Input 3: corrected volume flow</li> <li>Channel totalizer: volume flow</li> </ul>

# Use profile GSD

Assignment is performed in the **Ident number selector** parameter:

- ID number 0x9740: **1 AI, 1 Totalizer (0x9740)** option
- ID number 0x9741: **2 AI, 1 Totalizer (0x9741)** option
- ID number 0x9742: **Profile** option

# 9.3 Compatibility with earlier model

If the device is replaced, the measuring device Promag 500 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promag 500 GSD file.

Earlier models:

Promag 50PROFIBUS PA

- ID No.: 1525 (hex)

Extended GSD file: EH3x1525.gsdStandard GSD file: EH3 1525.gsd

■ Promag 53PROFIBUS PA

- ID No.: 1527 (hex)

Extended GSD file: EH3x1527.gsdStandard GSD file: EH3 1527.gsd

# 9.3.1 Automatic identification (factory setting)

The Promag 500 PROFIBUS PA automatically recognizes the measuring device configured in the automation system (Promag 50 PROFIBUS PA oder Promag 53 PROFIBUS PA) and makes the same input and output data and measured value status information available for cyclic data exchange.

Automatic identification is set in the **Ident number selector** parameter using the **Automatic mode** option (factory setting).

# 9.3.2 Manual setting

The manual setting is made in the **Ident number selector** parameter via the **Promag 50** (0x1525) option or **Promag 53** (0x1527) option.

Afterwards the Promag 500 PROFIBUS PA makes the same input and output data and measured value status information available for cyclic data exchange.

- If the Promag 500 PROFIBUS PA is acyclically configured via an operating program (Class 2 master), access is directly via the block structure or the parameters of the measuring device.
- If parameters have been changed in the device to be replaced (Promag 50 PROFIBUS PA or Promag 53 PROFIBUS PA) (parameter setting no longer corresponds to the original factory setting), these parameters must be changed accordingly in the new replacement Promag 500 PROFIBUS PA via an operating program (Class 2 master).

#### Example

The setting for low flow cut off has been changed from mass flow (factory setting) to corrected volume flow in a Promag 50 PROFIBUS PA currently in operation. This device is now replaced by a Promag 500 PROFIBUS PA.

After replacing the device, the assignment for the low flow cut off must also be changed manually in the Promag 500 PROFIBUS PA, i.e. to corrected volume flow, to ensure the measuring device behaves identically.

# 9.3.3 Replacing the measuring devices without changing the GSD file or restarting the controller

In the procedure described below, the device can be replaced without interrupting ongoing operation or restarting the controller. However with this procedure the measuring device is not fully integrated!

1. Replace the measuring device Promag 50 PROFIBUS PA or Promag 53 PROFIBUS PA with a Promag 500 PROFIBUS PA.

- 2. Set the device address: The same device address that was set for the Promag 50 or Promag 53 PROFIBUS PA must be used.
- 3. Connect the measuring device Promag 500 PROFIBUS PA.

If the factory setting had been changed on the replaced device (Promag 50 PROFIBUS PA or Promag 53 PROFIBUS PA), the following settings may need to be changed:

- 1. Configuration of the application-specific parameters.
- 2. Choice of process variables to be transmitted via the **Channel** parameter in the Analog Input or Totalizer function block.
- 3. Setting of the units for the process variables.

# 9.4 Using the GSD modules of the previous model

In the compatibility mode, all the modules already configured in the automation system are generally supported during cyclic data transmission. However, Promag 500 does not perform further processing for the following modules, i.e. the function is not executed:

- DISPLAY VALUE
- BATCHING QUANTITY
- BATCHING FIX COMP QUANTITY

If the device is replaced, the Promag 500 device supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promag 500 GSD file.

The diagnostic messages transmitted to the distributed control system with the GSD of the previous model may differ from the diagnostic messages of the device. The diagnostic messages of the device are critical.

# 9.4.1 Using the CONTROL BLOCK module in the previous model

If the CONTROL\_BLOCK module is used in the previous model, the control variables are processed further if relevant functionalities can be assigned for the Promag 500.

The functions are supported as follows depending on the previous model:

Previous model: Promag 50 PROFIBUS PA

Control variable	Function	Support	
0 → 2	Positive zero return: ON	Yes	
0 → 3	Positive zero return: OFF	Yes	
0 → 8	Measuring mode: UNIDIRECTIONAL	No	
0 → 9	Measuring mode: BIDIRECTIONAL	Cause: The Profile Transducer Block Flow is no longer supported.	
		To continue to use the functionality: Use the Totalizer operation mode parameter in the Totalizer function block.	
0 → 24	UNIT TO BUS	No	
		Cause: Functionality is no longer required as the unit is adopted automatically.	

Previous model: Promag 53 PROFIBUS PA

Control variable	Function	Support
0 → 2	Positive zero return: ON	Yes
0 → 3	Positive zero return: OFF	Yes

Control variable	Function	Support	
0 → 5	Electrode cleaning circuit (ECC): OFF	Yes	
0 → 6	Electrode cleaning circuit (ECC): ON	Yes	
0 → 8	Measuring mode: UNIDIRECTIONAL	No	
0 → 9	Measuring mode: BIDIRECTIONAL	Cause: The Profile Transducer Block Flow is no longer supported.	
		To continue to use the functionality: Use the Totalizer operation mode parameter in the Totalizer function block.	
0 → 24	UNIT TO BUS	No  Cause: Functionality is no longer required as the unit is adopted automatically.	

96

# 9.5 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

#### 9.5.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a PROFIBUS master (Class 1), e.g. a control system.

	Measuring device				Control system
	Analog Input block 1 to 4	→ 🖺 98	Output value AI	$\rightarrow$	
			Output value TOTAL	$\rightarrow$	
	Totalizer block 1 to 3	→ 🖺 98	Controller SETTOT	<b>←</b>	
Flow			Configuration MODETOT	+	
Block	Analog Output block 1 to 2	→ 🖺 100	Input values AO	+	PROFIBUS PA
	Discrete Input block 1 to 2	→ 🖺 101	Output values DI	$\rightarrow$	
	Discrete Output block 1 to 3	→ 🖺 101	Input values DO	+	

#### Defined order of modules

The measuring device works as a modular PROFIBUS slave. In contrast to a compact slave, a modular slave has a variable design and consists of several individual modules. The device master file (GSD) contains a description of the individual modules (input and output data) along with their individual properties.

The modules are permanently assigned to the slots, i.e. when configuring the modules, the order and the arrangement of the modules must be respected.

Slot	Module	Function block
14	AI	Analog Input block 1 to 4
5	TOTAL or	Totalizer block 1
6	SETTOT_TOTAL or SETOT MODETOT TOTAL	Totalizer block 2
7		Totalizer block 3
89	AO	Analog Output block 1 to 2
1011	DI	Discrete Input block 1 to 2
1214	DO	Discrete Output block 1 to 3

To optimize the data throughput rate of the PROFIBUS network, it is advisable to only configure modules that are processed in the PROFIBUS master system. If this results in gaps between the configured modules, these gaps must be assigned to the EMPTY\_MODULE.

# 9.5.2 Description of the modules

The data structure is described from the perspective of the PROFIBUS master:

- Input data: Are sent from the measuring device to the PROFIBUS master.
- Output data: Are sent from the PROFIBUS master to the measuring device.

# AI module (Analog Input)

Transmit an input variable from the measuring device to the PROFIBUS master (Class 1).

The selected input variable, along with the status, is cyclically transmitted to the PROFIBUS Master (Class 1) via the AI module. The input variable is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the input variable.

Four Analog Input blocks are available (slot 1 to 4).

Selection: input variable

Input variable
Volume flow
Mass flow
Corrected volume flow
Flow velocity
Conductivity
Corrected conductivity
Temperature
Electronic temperature
Current input 1
Current input 2
Current input 3

# Factory setting

Function block	Factory setting
AI 1	Volume flow
AI 2	Mass flow
AI 3	Corrected volume flow
AI 4	Flow velocity

#### Data structure

#### Input data of Analog Input

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status

#### TOTAL module

Transmit a totalizer value from the measuring device to the PROFIBUS master (Class 1).

A selected totalizer value, along with the status, is cyclically transmitted to a PROFIBUS Master (Class 1) via the TOTAL module. The totalizer value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the totalizer value.

Three Totalizer blocks are available (slot 5 to 7).

Selection: totalizer value

Input variable
Volume flow
Mass flow
Corrected volume flow

#### Data structure

# Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status

# SETTOT\_TOTAL module

The module combination consists of the SETTOT and TOTAL functions:

- SETTOT: Control the totalizers via the PROFIBUS master.
- TOTAL: Transmit totalizer value, along with the status, to the PROFIBUS master.

Three Totalizer blocks are available (slot 5 to 7).

Selection: control totalizer

Value SETTOT	Control totalizer
0	Totalize
1	Resetting
2	Adopt totalizer initial setting

#### Factory setting

Function block	Factory setting: Value SETTOT (meaning)
Totalizer 1, 2 and 3	0 (totalizing)

#### Data structure

# Output data of SETTOT

Byte 1
Control variable 1

# Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	d value: floating	point number (IE	EEE 754)	Status

# SETTOT\_MODETOT\_TOTAL module

The module combination consists of the SETTOT, MODETOT and TOTAL functions:

- SETTOT: Control the totalizers via the PROFIBUS master.
- MODETOT: Configure the totalizers via the PROFIBUS master.
- TOTAL: Transmit totalizer value, along with the status, to the PROFIBUS master.

Three Totalizer blocks are available (slot 5 to 7).

#### Selection: totalizer configuration

MODETOT value	Totalizer configuration
0	Balancing
1	Balance the positive flow
2	Balance the negative flow
3	Stop totalizing

#### Factory setting

Function block	Factory setting: Value MODETOT (meaning)
Totalizer 1, 2 and 3	0 (balancing)

#### Data structure

#### Output data of SETTOT and MODETOT

Byte 1	Byte 2	
Control variable 1: SETTOT	Control variable 2: MODETOT	

# Input data of TOTAL

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measured value: floating point number (IEEE 754)		Status		

# AO module (Analog Output)

Transmit a compensation value from the PROFIBUS master (Class 1) to the measuring device.

A compensation value, along with the status, is cyclically transmitted from the PROFIBUS Master (Class 1) to the measuring device via the AO module. The compensation value is depicted in the first four bytes in the form of a floating point number as per the IEEE 754 standard. The fifth byte contains standardized status information pertaining to the compensation value.

Two Analog Output blocks are available (slot 8 to 9).

#### Assigned compensation values

A compensation value is permanently assigned to the individual Analog Output blocks.

Function block	Compensation value	
AO 1	External temperature <sup>1)</sup>	
AO 2	External density	

1) The compensation values must be transmitted to the device in the SI basic unit

The selection is made via: Expert  $\rightarrow$  Sensor  $\rightarrow$  External compensation

#### Data structure

# Output data of Analog Output

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5
Measure	Measured value: floating point number (IEEE 754)		Status	

#### DI module (Discrete Input)

Transmit discrete input values from the measuring device to the PROFIBUS master (Class 1). Discrete input values are used by the measuring device to transmit the state of device functions to the PROFIBUS master (Class 1).

The DI module cyclically transmits the discrete input value, along with the status, to the PROFIBUS Master (Class 1). The discrete input value is depicted in the first byte. The second byte contains standardized status information pertaining to the input value.

Two Discrete Input blocks are available (slot 10 to 11).

Selection: device function

Device function	Factory setting: Status (meaning)
Empty pipe detection	0 (device function not active)
Low flow cut off	■ 1 (device function active)
Status verification <sup>1)</sup>	<ul> <li>Bit 0: Verification status - Check not done</li> <li>Bit 1: Verification status - Failed</li> <li>Bit 2: Verification status - Busy</li> <li>Bit 3: Verification status - Ready</li> <li>Bit 4: Verification overall result - Failed</li> <li>Bit 5: Verification overall result - Passed</li> <li>Bit 6: Verification overall result - Check not done</li> <li>Bit 7: Not used</li> </ul>

1) Only available with the Heartbeat Verification application package

#### Factory setting

Function block	Factory setting
DI 1	Empty pipe detection
DI 2	Low flow cut off

# Data structure

### Input data of Discrete Input

Byte 1	Byte 2
Discrete	Status

# **DO module (Discrete Output)**

Transmit discrete output values from the PROFIBUS master (Class 1) to the measuring device. Discrete output values are used by the PROFIBUS master (Class 1) to enable and disable device functions.

The DO module cyclically transmits the discrete output value, along with the status, to the measuring device. The discrete output value is depicted in the first byte. The second byte contains standardized status information pertaining to the output value.

Three Discrete Output blocks are available (slot 12 to 14).

# Assigned device functions

A device function is permanently assigned to the individual Discrete Output blocks.

Function block	Device function	Values: control (meaning)	
DO 1	Flow override	■ 0 (disable device function)	
DO 2	Start verification 1)	■ 1 (enable device function)	
DO 3	Relay output or switch output of the pulse/ frequency/switch output	<ul><li>0 (non-conductive)</li><li>1 (conductive)</li></ul>	

1) Only available with the Heartbeat Verification application package

#### Data structure

# Output data of Discrete Output

Byte 1	Byte 2
Discrete	Status

#### EMPTY\_MODULE module

This module is used to assign empty spaces arising from modules not being used in the slots .

The measuring device works as a modular PROFIBUS slave. In contrast to a compact slave, a modular PROFIBUS slave has a variable design and consists of several individual modules. The GSD file contains a description of the individual modules along with their individual properties.

The modules are permanently assigned to the slots. When configuring the modules, it is absolutely essential to observe the sequence/arrangement of the modules. Any gaps between the configured modules must be filled with the EMPTY MODULE.

# 10 Commissioning

# 10.1 Function check

Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist → 🗎 34
- "Post-connection check" checklist → 🖺 64

# 10.2 Switching on the measuring device

- ▶ After a successful function check, switch on the measuring device.
  - After a successful startup, the local display switches automatically from the startup display to the operational display.

# 10.3 Connecting via FieldCare

- For FieldCare → 🖺 86 connection
- For connecting via FieldCare → 🗎 90
- For the FieldCare → 🗎 90 user interface

# 10.4 Configuring the device address via software

In the "Communication" submenu the device address can be set.


#### **Navigation**

"Setup" menu  $\rightarrow$  Communication  $\rightarrow$  Device address

#### 10.4.1 PROFIBUS network


At time of delivery, the measuring device has the following factory setting:

Device address	126	
----------------	-----	--



# 10.5 Setting the operating language


Factory setting: English or ordered local language



■ 34 Taking the example of the local display

10.6 Configuring the measuring device

- The Setup menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu




■ 35 Taking the example of the local display

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.


# Navigation

"Setup" menu



# 10.6.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



 $\blacksquare$  36 Header of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool  $\rightarrow \triangleq 90$ 

# **Navigation**

"Setup" menu → Device tag

# Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag 500 PA


# 10.6.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

# Navigation

"Setup" menu → System units



# Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	-	Select volume flow unit.  Result  The selected unit applies for:  Output  Low flow cut off  Simulation process variable	Unit choose list	Country-specific:  l/h gal/min (us)
Volume unit	-	Select volume unit.	Unit choose list	Country-specific:  m³ gal (us)

Parameter	Prerequisite	Description	Selection	Factory setting
Conductivity unit	The <b>On</b> option is selected in the <b>Conductivity measurement</b> parameter parameter.	Select conductivity unit.  Effect  The selected unit applies for: Simulation process variable	Unit choose list	μS/cm
Temperature unit	-	Select temperature unit.  Result  The selected unit applies for:  Temperature parameter  Maximum value parameter  Minimum value parameter  External temperature parameter  Maximum value parameter  Minimum value parameter  Minimum value parameter	Unit choose list	Country-specific:
Mass flow unit	-	Select mass flow unit.  Result  The selected unit applies for:  Output  Low flow cut off Simulation process variable	Unit choose list	Country-specific:  kg/h  lb/min
Mass unit	-	Select mass unit.	Unit choose list	Country-specific:  kg lb
Density unit	-	Select density unit.  Result  The selected unit applies for:  Output Simulation process variable	Unit choose list	Country-specific:  • kg/l  • lb/ft <sup>3</sup>
Corrected volume flow unit	-	Select corrected volume flow unit.  Result  The selected unit applies for:  Corrected volume flow parameter (→   145)	Unit choose list	Country-specific: NI/h Sft³/h
Corrected volume unit	-	Select corrected volume unit.	Unit choose list	Country-specific: Nm³ Sft³

# 10.6.3 Configuring communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

# Navigation

"Setup" menu  $\rightarrow$  Communication



# Parameter overview with brief description


Parameter	Description	User entry	Factory setting
Device address	Enter device address.	0 to 126	126

## 10.6.4 Configuring the analog inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

#### Navigation

"Setup" menu  $\rightarrow$  Analog inputs



## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Channel	_	Select the process variable.	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity*</li> <li>Corrected conductivity</li> <li>Temperature</li> <li>Electronic temperature</li> <li>Current input 1*</li> <li>Current input 2*</li> <li>Current input 3*</li> </ul>	Volume flow
PV filter time	-	Specify the time to suppress signal peaks. During the specified time the analog input does not respond to an erratic increase in the process variable.	Positive floating- point number	0
Fail safe type	-	Select the failure mode.	<ul><li>Fail-safe value</li><li>Fallback value</li><li>Off</li></ul>	Off
Fail-safe value	In <b>Fail safe type</b> parameter, the <b>Fail-safe value</b> option is selected.	Specify the values to be output when an error occurs.	Signed floating-point number	0


Visibility depends on order options or device settings

# 10.6.5 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

## Navigation

"Setup" menu  $\rightarrow$  I/O configuration



## Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry	Factory setting
I/O module 1 to n terminal numbers	Shows the terminal numbers used by the I/O module.	<ul> <li>Not used</li> <li>26-27 (I/O 1)</li> <li>24-25 (I/O 2)</li> </ul>	-
I/O module 1 to n information	Shows information of the plugged I/O module.	<ul><li>Not plugged</li><li>Invalid</li><li>Not configurable</li><li>Configurable</li><li>Profibus PA</li></ul>	-
I/O module 1 to n type	Shows the I/O module type.	<ul> <li>Off</li> <li>Current output*</li> <li>Current input*</li> <li>Status input*</li> <li>Pulse/frequency/switch output*</li> </ul>	Off
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	■ No ■ Yes	No
Alteration code	Enter the code in order to change the I/O configuration.	Positive integer	0

<sup>\*</sup> Visibility depends on order options or device settings

## 10.6.6 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

## Navigation

"Setup" menu  $\rightarrow$  Current input

► Current input 1 to n

Terminal number → 🖺 111

Signal mode	→ 🖺 111
0/4 mA value	→ 🖺 111
20 mA value	→ 🗎 111
Current span	→ 🖺 111
Failure mode	→ 🖺 111
Failure value	→ 🖺 111

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	_
Signal mode	The measuring device is <b>not</b> approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	• Passive • Active*	Active
0/4 mA value	-	Enter 4 mA value.	Signed floating-point number	0
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	<ul> <li>420 mA</li> <li>420 mA NAMUR</li> <li>420 mA US</li> <li>020 mA</li> </ul>	Country-specific:  420 mA NAMUR  420 mA US
Failure mode	-	Define input behavior in alarm condition.	<ul><li>Alarm</li><li>Last valid value</li><li>Defined value</li></ul>	Alarm
Failure value	In the <b>Failure mode</b> parameter, the <b>Defined value</b> option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

<sup>\*</sup> Visibility depends on order options or device settings

# 10.6.7 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

## Navigation

"Setup" menu → Status input



Terminal number	→ 🖺 112
Active level	→ 🖺 112
Terminal number	→ 🖺 112
Response time status input	→ 🖺 112
Terminal number	→ 🖺 112

Parameter	Description	User interface / Selection / User entry	Factory setting
Terminal number	Shows the terminal numbers used by the status input module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Assign status input	Select function for the status input.	<ul> <li>Off</li> <li>Reset totalizer 1</li> <li>Reset totalizer 2</li> <li>Reset totalizer 3</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>	Off
Active level	Define input signal level at which the assigned function is triggered.	■ High ■ Low	High
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms	50 ms

# 10.6.8 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

## Navigation

"Setup" menu  $\rightarrow$  Current output

► Current output 1 to n	
Terminal number	→ 🖺 113
Signal mode	→ 🖺 113
Assign current output 1 to n	→ 🗎 113
Current span	→ 🗎 113
0/4 mA value	→ 🖺 113
20 mA value	→ 🖺 113
Fixed current	→ 🗎 113

Damping output 1 to n	→ 🖺 113
Failure mode	→ 🖺 114
Failure current	→ 🖺 114

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	_
Signal mode	-	Select the signal mode for the current output.	Passive * Active *	Active
Assign current output 1 to n	-	Select process variable for current output.	Off*     Volume flow     Mass flow     Corrected volume flow     Flow velocity     Conductivity*     Corrected conductivity     Temperature*     Electronic temperature	Volume flow
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	<ul> <li>420 mA NAMUR</li> <li>420 mA US</li> <li>420 mA</li> <li>020 mA</li> <li>Fixed current</li> </ul>	Country-specific: 420 mA NAMUR 420 mA US
0/4 mA value	One of the following options is selected in the <b>Current span</b> parameter (→ 🖺 113):  • 420 mA NAMUR  • 420 mA US  • 420 mA  • 020 mA	Enter 4 mA value.	Signed floating-point number	Country-specific:  • 0 l/h  • 0 gal/min (us)
20 mA value	One of the following options is selected in the <b>Current span</b> parameter (→ 🖺 113):  • 420 mA NAMUR  • 420 mA US  • 420 mA  • 020 mA	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Fixed current	The <b>Fixed current</b> option is selected in the <b>Current span</b> parameter (→ 🖺 113).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA
Damping output 1 to n	A process variable is selected in the <b>Assign current output</b> parameter (→ 🗎 113) and one of the following options is selected in the <b>Current span</b> parameter (→ 🖺 113):  • 420 mA NAMUR  • 420 mA US  • 420 mA  • 020 mA	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	1.0 s

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Failure mode	A process variable is selected in the <b>Assign current output</b> parameter (→ 🖹 113) and one of the following options is selected in the <b>Current span</b> parameter (→ 🖺 113):  • 420 mA NAMUR  • 420 mA US  • 420 mA  • 020 mA	Define output behavior in alarm condition.	<ul><li>Min.</li><li>Max.</li><li>Last valid value</li><li>Actual value</li><li>Defined value</li></ul>	Max.
Failure current	The <b>Defined value</b> option is selected in the <b>Failure mode</b> parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA


<sup>\*</sup> Visibility depends on order options or device settings

## 10.6.9 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Pulse/frequency/switch output




## Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	Pulse

## Configuring the pulse output

#### Navigation

"Setup" menu → Pulse/frequency/switch output



Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	Passive
Assign pulse output 1 to n	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Select process variable for pulse output.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li><li> Corrected volume flow</li></ul>	Off
Value per pulse	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 115) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🖺 116).	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 115) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🗎 116).	Define time width of the output pulse.	0.05 to 2 000 ms	100 ms
Failure mode	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 115) and a process variable is selected in the <b>Assign pulse output</b> parameter (→ 🗎 116).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>No pulses</li></ul>	No pulses
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	No

# Configuring the frequency output

# Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/frequency/switch output 1 to n	
Operating mode	→ 🖺 117
Terminal number	→ 🖺 117
Signal mode	→ 🖺 117
Assign frequency output	→ 🖺 117
Minimum frequency value	→ 🗎 117

Maximum frequency value	→ 🖺 117
Measuring value at minimum frequency	→ 🖺 118
Measuring value at maximum frequency	→ 🖺 118
Failure mode	→ 🖺 118
Failure frequency	→ 🖺 118
Invert output signal	→ 🖺 118

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	Passive
Assign frequency output	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 115) parameter.	Select process variable for frequency output.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity*</li> <li>Corrected conductivity*</li> <li>Temperature*</li> <li>Electronic temperature</li> </ul>	Off
Minimum frequency value	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 115) and a process variable is selected in the <b>Assign frequency output</b> parameter (→ 🖺 117).	Enter minimum frequency.	0.0 to 10 000.0 Hz	0.0 Hz
Maximum frequency value	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🖺 115) and a process variable is selected in the <b>Assign frequency output</b> parameter (→ 🖺 117).	Enter maximum frequency.	0.0 to 10 000.0 Hz	10 000.0 Hz

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Measuring value at minimum frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter ( $\rightarrow \implies 115$ ) and a process variable is selected in the <b>Assign frequency output</b> parameter ( $\rightarrow \implies 117$ ).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 🗎 115) and a process variable is selected in the <b>Assign frequency output</b> parameter (→ 🖺 117).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The <b>Frequency</b> option is selected in the <b>Operating</b> mode parameter ( $\rightarrow \triangleq 115$ ) and a process variable is selected in the <b>Assign</b> frequency output parameter ( $\rightarrow \triangleq 117$ ).	Define output behavior in alarm condition.	<ul><li>Actual value</li><li>Defined value</li><li>0 Hz</li></ul>	0 Hz
Failure frequency	The <b>Frequency</b> option is selected in the <b>Operating</b> mode parameter ( $\rightarrow \triangleq 115$ ) and a process variable is selected in the <b>Assign</b> frequency output parameter ( $\rightarrow \triangleq 117$ ).	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	0.0 Hz
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	No

Visibility depends on order options or device settings

118

# Configuring the switch output

# Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/fre	quency/switch output	
	Operating mode	→ 🖺 119
	Terminal number	→ 🖺 119
	Signal mode	→ 🖺 119
	Switch output function	→ 🖺 120
	Assign diagnostic behavior	→ 🖺 120
	Assign limit	→ 🖺 120
	Assign flow direction check	→ 🖺 120
	Assign status	→ 🖺 120
	Switch-on value	→ 🖺 120
	Switch-off value	→ 🖺 120
	Switch-on delay	→ 🖺 120
	Switch-off delay	→ 🖺 121
	Failure mode	→ 🖺 121
	Invert output signal	→ 🖺 121

## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	<ul><li>Pulse</li><li>Frequency</li><li>Switch</li></ul>	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Signal mode	-	Select the signal mode for the PFS output.	<ul><li>Passive</li><li>Active</li></ul>	Passive

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Select function for switch output.	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Status</li> </ul>	Off
Assign diagnostic behavior	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Diagnostic behavior option is selected.</li> </ul>	Select diagnostic behavior for switch output.	<ul><li>Alarm</li><li>Alarm or warning</li><li>Warning</li></ul>	Alarm
Assign limit	<ul> <li>The Switch option is selected in the Operating mode parameter parameter.</li> <li>The Limit option is selected in the Switch output function parameter parameter.</li> </ul>	Select process variable for limit function.	Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Totalizer 1 Totalizer 2 Totalizer 3 Temperature Electronic temperature	Volume flow
Assign flow direction check	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Flow direction check option is selected in the Switch output function parameter.</li> </ul>	Select process variable for flow direction monitoring.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> </ul>	Volume flow
Assign status	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Status option is selected in the Switch output function parameter.</li> </ul>	Select device status for switch output.	<ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> <li>Digital output 3*</li> </ul>	Partially filled pipe detection
Switch-on value	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Limit option is selected.</li> </ul>	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific:  0 1/h  0 gal/min (us)
Switch-off value	<ul> <li>In the Operating mode parameter, the Switch option is selected.</li> <li>In the Switch output function parameter, the Limit option is selected.</li> </ul>	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific:  0 1/h  0 gal/min (us)
Switch-on delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off delay	<ul> <li>The Switch option is selected in the Operating mode parameter.</li> <li>The Limit option is selected in the Switch output function parameter.</li> </ul>	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	Open
Invert output signal	-	Invert the output signal.	<ul><li>No</li><li>Yes</li></ul>	No


<sup>\*</sup> Visibility depends on order options or device settings

## 10.6.10 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

## Navigation

"Setup" menu  $\rightarrow$  Relay output 1 to n



Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Relay output function	-	Select the function for the relay output.	<ul> <li>Closed</li> <li>Open</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Flow direction check</li> <li>Digital Output</li> </ul>	Closed
Terminal number	-	Shows the terminal numbers used by the relay output module.	<ul><li>Not used</li><li>24-25 (I/O 2)</li></ul>	-
Assign flow direction check	In the Relay output function parameter, the Flow direction check option is selected.	Select process variable for flow direction monitoring.	<ul><li>Off</li><li>Volume flow</li><li>Mass flow</li><li>Corrected volume flow</li></ul>	Volume flow
Assign limit	The <b>Limit</b> option is selected in the <b>Relay output function</b> parameter parameter.	Select process variable for limit function.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity*</li> <li>Corrected conductivity</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Temperature</li> <li>Electronic temperature</li> </ul>	Volume flow
Assign diagnostic behavior	In the <b>Relay output function</b> parameter, the <b>Diagnostic behavior</b> option is selected.	Select diagnostic behavior for switch output.	<ul><li>Alarm</li><li>Alarm or warning</li><li>Warning</li></ul>	Alarm
Assign status	In the <b>Relay output function</b> parameter, the <b>Digital Output</b> option is selected.	Select device status for switch output.	<ul> <li>Partially filled pipe detection</li> <li>Low flow cut off</li> <li>Digital output 3*</li> </ul>	Partially filled pipe detection
Switch-off value	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific:  Ol/h  Ogal(us)/min
Switch-off delay	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Switch-on value	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific:  0 l/h 0 gal(us)/min
Switch-on delay	In the <b>Relay output function</b> parameter, the <b>Limit</b> option is selected.	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	Open

<sup>\*</sup> Visibility depends on order options or device settings

122

# 10.6.11 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

## Navigation

"Setup" menu  $\rightarrow$  Display



## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Corrected conductivity*</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Current output 1*</li> <li>Temperature*</li> <li>Electronic temperature</li> </ul>	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  • 0 l/h  • 0 gal/min (us)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter ( $\rightarrow \stackrel{ riangle}{ riangle}$ 123)	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter (→ 🖺 123)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  • 0 1/h  • 0 gal/min (us)
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter (→ 🖺 123)	None


<sup>\*</sup> Visibility depends on order options or device settings

# 10.6.12 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

## Navigation

"Setup" menu  $\rightarrow$  Low flow cut off



## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	<ul><li> Off</li><li> Volume flow</li><li> Mass flow</li><li> Corrected volume flow</li></ul>	Volume flow
On value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \blacksquare$ 124).	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Off value low flow cutoff	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \implies 124$ ).	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	A process variable is selected in the <b>Assign process variable</b> parameter ( $\rightarrow \square$ 124).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

# 10.6.13 Configuring empty pipe detection

The **Empty pipe detection** submenu contains parameters that must be configured for the configuration of empty pipe detection.

## Navigation

"Setup" menu  $\rightarrow$  Empty pipe detection



## Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	-	Switch empty pipe detection on and off.	Off On	Off
New adjustment	The <b>On</b> option is selected in the <b>Empty pipe detection</b> parameter.	Select type of adjustment.	<ul><li>Cancel</li><li>Empty pipe adjust</li><li>Full pipe adjust</li></ul>	Cancel
Progress	The <b>On</b> option is selected in the <b>Empty pipe detection</b> parameter.	Shows the progress.	<ul><li>Ok</li><li>Busy</li><li>Not ok</li></ul>	-
Switch point empty pipe detection	The <b>On</b> option is selected in the <b>Empty pipe detection</b> parameter.	Enter hysteresis in %, below this value the measuring tube will detected as empty.	0 to 100 %	10 %
Response time empty pipe detection	A process variable is selected in the <b>Assign process variable</b> parameter (→ 🖺 126).	Enter the time before diagnostic message S862 'Pipe empty' is displayed for empty pipe detection.	0 to 100 s	1 s

126

# 10.7 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.


Navigation to the "Advanced setup" submenu




The number of submenus can vary depending on the device version. Some submenus are not dealt with in the Operating Instructions. These submenus and the parameters they contain are explained in the Special Documentation for the device.

#### Navigation

"Setup" menu  $\rightarrow$  Advanced setup





## 10.7.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

#### **Navigation**

"Setup" menu → Advanced setup → Sensor adjustment



## Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<ul><li>Flow in arrow direction</li><li>Flow against arrow direction</li></ul>	Flow in arrow direction

## 10.7.2 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Totalizer 1 to n



Parameter	Description	Selection	Factory setting
Assign process variable	Select process variable for totalizer.	<ul><li>Volume flow</li><li>Mass flow</li><li>Corrected volume flow</li></ul>	Volume flow
Unit totalizer	Select the unit for the process variable of the totalizer.	Unit choose list	Country-specific:  • m³  • ft³
Control Totalizer 1 to n	Control totalizer value.	<ul><li>Totalize</li><li>Reset + hold</li><li>Preset + hold</li></ul>	Totalize
Totalizer operation mode	Select totalizer calculation mode.	<ul> <li>Net flow total</li> <li>Forward flow total</li> <li>Reverse flow total</li> <li>Last valid value</li> </ul>	Net flow total
Failure mode	Define the totalizer behavior in the event of a device alarm.	<ul><li>Stop</li><li>Actual value</li><li>Last valid value</li></ul>	Actual value

# 10.7.3 Carrying out additional display configurations

In the Display submenu you can set all the parameters associated with the configuration of the local display.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Display

► Display			
Form	nat display	<u></u>	<b>131 131</b>
Value	e 1 display	<i>,</i> 	<b>131 131</b>
0% b	argraph value 1	,   →	<b>131 131 1</b>
100%	% bargraph value 1	)   →	<b>131 131</b>
Decir	mal places 1	→	<b>131</b> ■ 131
	e 2 display	→	<b>□</b> 131
	mal places 2		□ 131
	e 3 display		□ 131 □ 131
	argraph value 3		131
	% bargraph value 3		₿ 131
Decir	mal places 3	<del>)</del>	₿ 131
Value	e 4 display	<b>→</b>	₿ 132
Decir	nal places 4	<b>→</b>	₿ 132
Displ	ay language	<b>→</b>	₿ 132
Displ	ay interval	<b>→</b>	🗎 132
Displ	ay damping	<b>→</b>	₿ 132
Head	ler	<u>}</u>	₿ 132
Head	ler text	<b>→</b>	<b>1</b> 32 <b>□</b>
Sepa	rator	<b>→</b>	₿ 132
Back	light	<b>→</b>	<b>1</b> 32 ■

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Corrected conductivity*</li> <li>Totalizer 1</li> <li>Totalizer 2</li> <li>Totalizer 3</li> <li>Current output 1*</li> <li>Temperature*</li> <li>Electronic temperature</li> </ul>	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  • 0 l/h  • 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the <b>Value 1 display</b> parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter (→ 🖺 123)	None
Decimal places 2	A measured value is specified in the <b>Value 2 display</b> parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the <b>Value 1 display</b> parameter (→ 🖺 123)	None
0% bargraph value 3	A selection was made in the <b>Value 3 display</b> parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific:  0 l/h 0 gal/min (us)
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	A measured value is specified in the <b>Value 3 display</b> parameter.	Select the number of decimal places for the display value.	<ul><li> x</li><li> x.x</li><li> x.xx</li><li> x.xx</li><li> x.xxx</li></ul>	x.xx

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🖺 123)	None
Decimal places 4	A measured value is specified in the <b>Value 4 display</b> parameter.	Select the number of decimal places for the display value.	- X - X.X - X.XX - X.XXX	x.xx
Display language	A local display is provided.	Set display language.	<ul> <li>English</li> <li>Deutsch</li> <li>Français</li> <li>Español</li> <li>Italiano</li> <li>Nederlands</li> <li>Portuguesa</li> <li>Polski</li> <li>pусский язык (Russian)</li> <li>Svenska</li> <li>Türkçe</li> <li>中文 (Chinese)</li> <li>日本語 (Japanese)</li> <li>한국어 (Korean)</li> <li>Bahasa Indonesia</li> <li>tiếng Việt (Vietnamese)</li> <li>čeština (Czech)</li> </ul>	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	<ul><li>Device tag</li><li>Free text</li></ul>	Device tag
Header text	In the <b>Header</b> parameter, the <b>Free text</b> option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	<ul><li>. (point)</li><li>, (comma)</li></ul>	. (point)
Backlight	One of the following conditions is met:  Order code for "Display; operation", option <b>F</b> "4-line, illum.; touch control"  Order code for "Display; operation", option <b>G</b> "4-line, illum.; touch control +WLAN"	Switch the local display backlight on and off.	<ul><li>Disable</li><li>Enable</li></ul>	Enable

<sup>\*</sup> Visibility depends on order options or device settings

# 10.7.4 Performing electrode cleaning


The **Electrode cleaning circuit** submenu contains parameters that must be configured for the configuration of electrode cleaning.

The submenu is only available if the device was ordered with electrode cleaning.

132

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Electrode cleaning circuit



## Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning circuit	For the following order code: "Application package", option EC "ECC electrode cleaning"	Enable the cyclic electrode cleaning circuit.	• Off • On	Off
ECC duration	For the following order code: "Application package", option EC "ECC electrode cleaning"	Enter the duration of electrode cleaning in seconds.	0.01 to 30 s	2 s
ECC recovery time	For the following order code: "Application package", option EC "ECC electrode cleaning"	Define recovery time after electrode cleaning. During this time the current output values will be held at last valid value.	1 to 600 s	60 s
ECC cleaning cycle	For the following order code: "Application package", option EC "ECC electrode cleaning"	Enter the pause duration between electrode cleaning cycles.	0.5 to 168 h	0.5 h
ECC Polarity	For the following order code: "Application package", option EC "ECC electrode cleaning"	Select the polarity of the electrode cleaning circuit.	<ul><li>Positive</li><li>Negative</li></ul>	Depends on the electrode material: • Platinum: • Negative option • Tantalum, Alloy C22, stainless steel: Positive option

## 10.7.5 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  WLAN Settings



Security type	→ 🖺 134
WLAN passphrase	→ 🗎 134
Assign SSID name	→ 🖺 134
SSID name	→ 🗎 134
Apply changes	→ 🖺 134

Parameter	Prerequisite	Description	User entry / Selection	Factory setting
WLAN IP address	-	Enter IP address of the device WLAN interface.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Network security	-	Select the security type of the WLAN network.	<ul> <li>Unsecured</li> <li>WPA2-PSK</li> <li>EAP-PEAP with MSCHAPv2*</li> <li>EAP-PEAP MSCHAPv2 no server authentic.*</li> <li>EAP-TLS*</li> </ul>	WPA2-PSK
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters).  The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user-defined name.	<ul><li>Device tag</li><li>User-defined</li></ul>	User-defined
SSID name	<ul> <li>The User-defined option is selected in the Assign SSID name parameter parameter.</li> <li>The WLAN access point option is selected in the WLAN mode parameter parameter.</li> </ul>	Enter the user-defined SSID name (max. 32 characters).  The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Promag_500_A 802000)
Apply changes	-	Use changed WLAN settings.	<ul><li>Cancel</li><li>Ok</li></ul>	Cancel

Visibility depends on order options or device settings


# 10.7.6 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup** submenu.

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Configuration backup



## Parameter overview with brief description

Parameter	Description	User interface / Selection	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Last backup	Shows when the last data backup was saved to HistoROM backup.	Days (d), hours (h), minutes (m) and seconds (s)	-
Configuration management	Select action for managing the device data in the HistoROM backup.	<ul> <li>Cancel</li> <li>Execute backup</li> <li>Restore *</li> <li>Compare *</li> <li>Clear backup data</li> </ul>	Cancel
Backup state	Shows the current status of data saving or restoring.	<ul> <li>None</li> <li>Backup in progress</li> <li>Restoring in progress</li> <li>Delete in progress</li> <li>Compare in progress</li> <li>Restoring failed</li> <li>Backup failed</li> </ul>	None
Comparison result	Comparison of current device data with HistoROM backup.	<ul> <li>Settings identical</li> <li>Settings not identical</li> <li>No backup available</li> <li>Backup settings corrupt</li> <li>Check not done</li> <li>Dataset incompatible</li> </ul>	Check not done

<sup>\*</sup> Visibility depends on order options or device settings

## Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.

Options	Description
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.

HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.


While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

## 10.7.7 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

#### **Navigation**

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration



#### Using the parameter to define the access code

#### Navigation

"Setup" menu → Advanced setup → Administration → Define access code




#### Parameter overview with brief description

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the entered access code.	Max. 16-digit character string comprising numbers, letters and special characters

## Using the parameter to reset the access code

## **Navigation**

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration  $\rightarrow$  Reset access code



## Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Reset access code	Reset access code to factory settings.  For a reset code, contact your Endress+Hauser service organization.	Character string comprising numbers, letters and special characters	0x00
	<ul> <li>The reset code can only be entered via:</li> <li>Web browser</li> <li>DeviceCare, FieldCare (via service interface CDI-RJ45)</li> <li>Fieldbus</li> </ul>		

## Using the parameter to reset the device

## Navigation

"Setup" menu  $\rightarrow$  Advanced setup  $\rightarrow$  Administration

#### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul> <li>Cancel</li> <li>To delivery settings</li> <li>Restart device</li> <li>Restore S-DAT backup *</li> </ul>	Cancel

<sup>\*</sup> Visibility depends on order options or device settings

## 10.8 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

 $\begin{tabular}{ll} \textbf{Navigation} \\ "Diagnostics" menu $\rightarrow$ Simulation \\ \end{tabular}$ 

► Simulation		
> Simulation		
	Assign simulation process variable	→ 🗎 139
	Process variable value	→ 🖺 139
	Status input simulation	→ 🖺 139
	Input signal level	→ 🖺 139
	Current input 1 to n simulation	→ 🗎 139
	Value current input 1 to n	→ 🖺 139
	Current output 1 to n simulation	→ 🖺 139
	Value current output 1 to n	→ 🗎 139
	Frequency output simulation 1 to n	→ 🖺 139
	Frequency value 1 to n	→ 🖺 139
	Pulse output simulation 1 to n	→ 🖺 139
	Pulse value 1 to n	→ 🖺 139
	Switch output simulation 1 to n	→ 🗎 139
	Switch status 1 to n	→ 🗎 139
	Relay output 1 to n simulation	→ 🖺 139
	Switch status 1 to n	→ 🖺 140
	Device alarm simulation	→ 🖺 140
	Diagnostic event category	→ 🖺 140
	Diagnostic event simulation	→ 🖺 140

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	<ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity*</li> <li>Corrected conductivity</li> <li>Temperature</li> </ul>	Off
Process variable value	A process variable is selected in the <b>Assign simulation process variable</b> parameter (→ 🖺 139).	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Status input simulation	-	Switch simulation of the status input on and off.	<ul><li>Off</li><li>On</li></ul>	Off
Input signal level	In the <b>Status input simulation</b> parameter, the <b>On</b> option is selected.	Select the signal level for the simulation of the status input.	<ul><li>High</li><li>Low</li></ul>	High
Current input 1 to n simulation	-	Switch simulation of the current input on and off.	Off On	Off
Value current input 1 to n	In the <b>Current input 1 to n simulation</b> parameter, the <b>On</b> option is selected.	Enter the current value for simulation.	0 to 22.5 mA	0 mA
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	Off On	Off
Value current output 1 to n	In the <b>Current output 1 to n simulation</b> parameter, the <b>On</b> option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA	3.59 mA
Frequency output simulation 1 to n	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Switch the simulation of the frequency output on and off.	Off On	Off
Frequency value 1 to n	In the <b>Frequency output simulation 1 to n</b> parameter, the <b>On</b> option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz	0.0 Hz
Pulse output simulation 1 to n	In the <b>Operating mode</b> parameter, the <b>Pulse</b> option is selected.	Set and switch off the pulse output simulation.  For Fixed value option: Pulse width parameter (> \equiv 116) defines the pulse width of the pulses output.	<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>	Off
Pulse value 1 to n	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation 1 to n	In the <b>Operating mode</b> parameter, the <b>Switch</b> option is selected.	Switch the simulation of the switch output on and off.	Off On	Off
Switch status 1 to n	_	Select the status of the status output for the simulation.	<ul><li>Open</li><li>Closed</li></ul>	Open
Relay output 1 to n simulation	-	Switch simulation of the relay output on and off.	<ul><li>Off</li><li>On</li></ul>	Off

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Switch status 1 to n	The <b>On</b> option is selected in the <b>Switch output simulation 1 to n</b> parameter parameter.	Select status of the relay output for the simulation.	<ul><li>Open</li><li>Closed</li></ul>	Open
Pulse output simulation	-	Set and switch off the pulse output simulation.  For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	<ul><li>Off</li><li>Fixed value</li><li>Down-counting value</li></ul>	Off
Pulse value	In the <b>Pulse output</b> simulation parameter, the <b>Down-counting value</b> option is selected.	Set and switch off the pulse output simulation.	0 to 65 535	0
Device alarm simulation	-	Switch the device alarm on and off.	Off On	Off
Diagnostic event category	-	Select a diagnostic event category.	<ul><li>Sensor</li><li>Electronics</li><li>Configuration</li><li>Process</li></ul>	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	Off     Diagnostic event picklist (depends on the category selected)	Off
Logging interval	-	Define the logging interval tlog for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	-

Visibility depends on order options or device settings

# 10.9 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to measuring device via write protection switch → 🖺 142

## 10.9.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

## Defining the access code via local display


- 1. Navigate to the **Define access code** parameter ( $\rightarrow \triangleq 136$ ).
- 2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.

- 3. Enter the access code again in the **Confirm access code** parameter ( $\Rightarrow \implies 136$ ) to confirm the code.
  - ► The 🗈-symbol appears in front of all write-protected parameters.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

#### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



#### Defining the access code via the Web browser

- 1. Navigate to the **Define access code** parameter ( $\rightarrow \equiv 136$ ).
- 2. Define a max. 16-digit numeric code as an access code.
- 3. Enter the access code again in the **Confirm access code** parameter (→ 🗎 136) to confirm the code.
  - ► The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
- - The user role with which the user is currently logged on via Web browser is indicated by the Access status parameter. Navigation path: Operation → Access status

## Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

#### Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

- For a reset code, contact your Endress+Hauser service organization.
- 1. Navigate to the **Reset access code** parameter ( $\rightarrow \triangleq 137$ ).

- 2. Enter the reset code.
  - The access code has been reset to the factory setting **0000**. It can be redefined  $\rightarrow \boxminus 140$ .

## 10.9.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.

The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via PROFIBUS PA protocol


## Proline 500 - digital

## **A** WARNING

## Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)



A002967

- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.
- 4. Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.
  - In the **Locking status** parameter the **Hardware locked** option is displayed  $\rightarrow \stackrel{\triangle}{=} 144$ . In addition, on the local display the  $\stackrel{\triangle}{=}$ -symbol appears in front of the parameters in the header of the operational display and in the navigation view.




A0029425

142


- 5. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
  - ► No option is displayed in the **Locking status** parameter → 🗎 144. On the local display, the 🖻-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

#### Proline 500



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

In the **Locking status** parameter the **Hardware locked** option is displayed  $\rightarrow \boxminus$  144. In addition, on the local display the  $\boxdot$ -symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0029425

- 2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

# 11 Operation

## 11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation → Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the <b>Access status</b> parameter applies $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) .
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

# 11.2 Adjusting the operating language



Detailed information:

- To configure the operating language → 🖺 103
- $\bullet$  For information on the operating languages supported by the measuring device  $\rightarrow \; \cong \; 223$

# 11.3 Configuring the display

Detailed information:


- On the advanced settings for the local display  $\rightarrow \triangleq 130$

# 11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

#### **Navigation**

"Diagnostics" menu  $\rightarrow$  Measured values




### 11.4.1 "Process variables" submenu

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Process variables



### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Volume flow	-	Displays the volume flow currently measured.	Signed floating-point number
		Dependency The unit is taken from the Volume flow unit parameter ( $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
Mass flow	-	Displays the mass flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the <b>Mass flow</b> unit parameter (→ 🖺 107).	
Corrected volume flow	-	Displays the corrected volume flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Corrected volume flow unit parameter (→ 🖺 107).	
Flow velocity	-	Displays the flow velocity currently calculated.	Signed floating-point number
Conductivity	-	Displays the conductivity currently measured.	Signed floating-point number
		Dependency The unit is taken from the Conductivity unit parameter ( $\rightarrow \triangleq 107$ ).	


Parameter	Prerequisite	Description	User interface
Corrected conductivity	One of the following conditions is met:  Order code for "Sensor option", option CI "Medium temperature measurement" or  The temperature is read into the flowmeter from an external device.	Displays the conductivity currently corrected.  Dependency The unit is taken from the Conductivity unit parameter (→ 🖺 107).	Positive floating-point number
Temperature	One of the following conditions is met:  Order code for "Sensor option", option CI "Medium temperature measurement" or  The temperature is read into the flowmeter from an external device.	Displays the temperature currently calculated.  Dependency The unit is taken from the  Temperature unit parameter (→ 🖺 107).	Positive floating-point number
Density	-	Displays the current fixed density or density read in from an external device.  Dependency The unit is taken from the Density unit parameter.	Signed floating-point number

### 11.4.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Totalizer 1 to n



### Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign process variable	-	Select process variable for totalizer.	<ul><li>Volume flow</li><li>Mass flow</li><li>Corrected volume flow</li></ul>	Volume flow
Totalizer value 1 to n	In the Assign process variable parameter one of the following options is selected:  Volume flow  Mass flow  Corrected volume flow  Total mass flow  Condensate mass flow  Energy flow  Heat flow difference	Displays the current totalizer counter value.	Signed floating-point number	0 m³
Totalizer status 1 to n	-	Displays the current totalizer status.	<ul><li>Good</li><li>Uncertain</li><li>Bad</li></ul>	_
Totalizer status (Hex) 1 to n	In <b>Target mode</b> parameter, the <b>Auto</b> option is selected.	Displays the current status value (hex) of the totalizer.	0 to 0xFF	-

### 11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

#### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values




### Input values of current input

The Current input 1 to n submenu contains all the parameters needed to display the current measured values for every current input.

### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values  $\rightarrow$  Current input 1 to n



### Parameter overview with brief description

Parameter	Description	User interface
Measured values 1 to n	Displays the current input value.	Signed floating-point number
Measured current 1 to n	Displays the current value of the current input.	0 to 22.5 mA

### Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

#### **Navigation**

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Input values  $\rightarrow$  Status input 1 to n



#### Parameter overview with brief description


Parameter	Description	User interface
Value status input	Shows the current input signal level.	■ High ■ Low

### 11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

### Navigation

"Diagnostics" menu → Measured values → Output values




### Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

### **Navigation**

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Value current output 1 to n



#### Parameter overview with brief description


Parameter	Description	User interface
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

### Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

### Navigation

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Pulse/frequency/switch output 1 to n



### Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Output frequency 1 to n	In the <b>Operating mode</b> parameter, the <b>Frequency</b> option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output 1 to n	The <b>Pulse</b> option is selected in the <b>Operating mode</b> parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch status 1 to n	The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter.	Displays the current switch output status.	■ Open ■ Closed

### Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

### **Navigation**

"Diagnostics" menu  $\rightarrow$  Measured values  $\rightarrow$  Output values  $\rightarrow$  Relay output 1 to n



### Parameter overview with brief description

Parameter	Description	User interface
Switch status	Shows the current relay switch status.	<ul><li>Open</li><li>Closed</li></ul>
Switch cycles	Shows number of all performed switch cycles.	Positive integer
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer

# 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu ( $\rightarrow$  🖺 104)
- Advanced settings using the Advanced setup submenu (→ 🗎 127)

### 11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu: Control Totalizer

Function scope of the "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value 1 to n</b> parameter.

### Navigation

"Operation" menu → Totalizer handling



150

Preset value 1 to n	→ 🖺 151
Reset all totalizers	→ 🖺 151

#### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	-	Control totalizer value.	<ul><li>Totalize</li><li>Reset + hold</li><li>Preset + hold</li></ul>	Totalize
Preset value 1 to n	In the Assign process variable parameter one of the following options is selected:  Volume flow  Mass flow  Corrected volume flow  Total mass flow  Condensate mass flow  Energy flow  Heat flow difference	Specify start value for totalizer.	Signed floating-point number	0 m <sup>3</sup>
Reset all totalizers	-	Reset all totalizers to 0 and start.	<ul><li>Cancel</li><li>Reset + totalize</li></ul>	Cancel

### 11.7 Showing data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.




Data logging is also available via:

- Plant Asset Management Tool FieldCare → 89.
- Web browser

### Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



A003435

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.
- If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

 $\begin{tabular}{ll} \textbf{Navigation} \\ \begin{tabular}{ll} \textbf{Diagnostics''} menu \rightarrow \textbf{Data logging} \\ \end{tabular}$ 

▶ Data logging	
Assign channel 1	→ 🖺 153
Assign channel 2	→ 🖺 153
Assign channel 3	→ 🖺 153
Assign channel 4	→ 🗎 153
Logging interval	→ 🖺 153
Clear logging data	→ 🖺 153
Data logging	→ 🖺 153
Logging delay	→ 🖺 153
Data logging control	→ 🖺 153
Data logging status	→ 🖺 154
Entire logging duration	→ 🖺 154
▶ Display channel 1	
▶ Display channel 2	
► Display channel 3	
▶ Display channel 4	

### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The <b>Extended HistoROM</b> application package is available.	Assign process variable to logging channel.	Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Electronic temperature Current output 1* Temperature*	Off
Assign channel 2	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> channel 1 parameter (→ 🖺 153)	Off
Assign channel 3	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> channel 1 parameter (→ 🖺 153)	Off
Assign channel 4	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see <b>Assign</b> channel 1 parameter (→ 🖺 153)	Off
Logging interval	The <b>Extended HistoROM</b> application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3 600.0 s	1.0 s
Clear logging data	The <b>Extended HistoROM</b> application package is available.	Clear the entire logging data.	Cancel Clear data	Cancel
Data logging	-	Select the data logging method.	<ul><li>Overwriting</li><li>Not overwriting</li></ul>	Overwriting
Logging delay	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Start and stop measured value logging.	<ul><li>None</li><li>Delete + start</li><li>Stop</li></ul>	None

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Data logging status	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the measured value logging status.	<ul><li>Done</li><li>Delay active</li><li>Active</li><li>Stopped</li></ul>	Done
Entire logging duration	In the <b>Data logging</b> parameter, the <b>Not overwriting</b> option is selected.	Displays the total logging duration.	Positive floating- point number	0 s

<sup>\*</sup> Visibility depends on order options or device settings

## 12 Diagnostics and troubleshooting

### 12.1 General troubleshooting

For local display

Error	Possible causes	Solution
Local display dark and no output signals	Supply voltage does not match the value indicated on the nameplate.	Apply the correct supply voltage .
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.  Main electronics module is defective.	Order spare part → 🖺 200.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	Check the connection of the electrode cable and correct if necessary.     Check the connection of the coil current cable and correct if necessary.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul> <li>Set the display brighter by simultaneously pressing</li></ul>
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🖺 200.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press □ + ₺ for 2 s ("home position"). 2. Press 팁. 3. Set the desired language in the <b>Display language</b> parameter (→ 🖺 132).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul> <li>Check the cable and the connector between the main electronics module and display module.</li> <li>Order spare part →   200.</li> </ul>

### For output signals

Error	Possible causes	Solution
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🖺 200.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration.     Observe limit values specified in the "Technical Data".

### For access

Error	Possible causes	Solution
No write access to parameters	Hardware write protection enabled	Set the write protection switch on main electronics module to the <b>OFF</b> position → 142.
No write access to parameters	Current user role has limited access authorization	<ol> <li>Check user role → ₱ 78.</li> <li>Enter correct customer-specific access code → ₱ 78.</li> </ol>
No connection via PROFIBUS PA	Device plug connected incorrectly	Check the pin assignment of the connector .
No connection via PROFIBUS PA	PROFIBUS PA cable incorrectly terminated	Check terminating resistor .
Not connecting to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary → 🖺 85.
	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) → 🖺 81. 2. Check the network settings with the IT manager.
Not connecting to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 → 🖺 81
Not connecting to Web server	Incorrect WLAN access data	<ul> <li>Check WLAN network status.</li> <li>Log on to the device again using WLAN access data.</li> <li>Verify that WLAN is enabled on the measuring device and operating device .</li> </ul>
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	<ul> <li>Check if WLAN reception is present: LED on display module is lit blue</li> <li>Check if WLAN connection is enabled: LED on display module flashes blue</li> <li>Switch on instrument function.</li> </ul>
Network connection not present or unstable	WLAN network is weak.	<ul> <li>Operating device is outside of reception range: Check network status on operating device.</li> <li>To improve network performance, use an external WLAN antenna.</li> </ul>
	Parallel WLAN and Ethernet communication	<ul><li>Check network settings.</li><li>Temporarily enable only the WLAN as an interface.</li></ul>


Error	Possible causes	Solution
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	Check cable connection and power supply.     Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	Use the correct Web browser version .     Clear the Web browser cache and restart the Web browser.
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	<ul><li> JavaScript not enabled</li><li> JavaScript cannot be enabled</li></ul>	Enable JavaScript.     Enter http://XXX.XXX.X.XXX/     basic.html as the IP address.
Operation with FieldCare or DeviceCare via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.

### 12.2 Diagnostic information via light emitting diodes

### 12.2.1 Transmitter

### Proline 500 - digital

Different LEDs in the transmitter provide information on the device status.



A00296


- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active, Ethernet Link/Activity
- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.

LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is ok.
2	Device status	Off	Firmware error
		Green	Device status is ok.
		Flashing green	Device is not configured.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red/green	The device restarts.
3	Not used	_	-
4	Communication	Off	Device does not receive any Profibus data.
		White	Device receives Profibus data.

LED	)	Color	Meaning
5	Service interface (CDI),	Off	Not connected or no connection established.
	Ethernet Link/Activity	Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

#### Proline 500

Different LEDs in the transmitter provide information on the device status.



A0029629


- Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active, Ethernet Link/Activity

LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is ok.
2	Device status	Off	Firmware error
		Green	Device status is ok.
		Flashing green	Device is not configured.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Flashing red/green	The device restarts.
3	Not used	_	-
4	Communication	Off	Device does not receive any Profibus data.
		White	Device receives Profibus data.
5	Service interface (CDI),	Off	Not connected or no connection established.
	Ethernet Link/Activity	Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

### 12.2.2 Sensor connection housing

### Proline 500 - digital

Various light emitting diodes (LED) on the ISEM electronics (Intelligent Sensor Electronic Module) in the sensor connection housing provide information on the device status.




- 1 Communication
- 2 Device status
- 3 Supply voltage

LED		Color	Meaning
1	Communication	White	Communication active
2	Device status	Red	Error
		Flashing red	Warning
3	Supply voltage	Green	Supply voltage is ok
		Off	Supply voltage is off or too low

### 12.3 Diagnostic information on local display

### 12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
  - Via parameter

#### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning	
F	Failure A device error has occurred. The measured value is no longer valid.	
С	Function check The device is in service mode (e.g. during a simulation).	
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)	
М	Maintenance required Maintenance is required. The measured value remains valid.	

### Diagnostic behavior

Symbol	Meaning
8	<ul> <li>Alarm</li> <li>Measurement is interrupted.</li> <li>Signal outputs and totalizers assume the defined alarm condition.</li> <li>A diagnostic message is generated.</li> </ul>
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### Operating elements

Key	Meaning
<b>(+)</b>	Plus key In a menu, submenu Opens the message about remedy information.
E	Enter key  In a menu, submenu Opens the operating menu.

### XXXXXXXX AS XXXXXXXX **AS801** Supply voltage x ① 1. $(\mathbf{+})$ Diagnostic list $\Delta$ S Diagnostics 1 <u>A</u> S801 Supply voltage Diagnostics 2 **Diagnostics 3** 2. Œ Supply voltage (ID:203) △ S801 0d00h02m25s **—** 5 Increase supply voltage (a) + (b) 3.

### 12.3.2 Calling up remedial measures

A0029431-EN

- 37 Message about remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures
- 1. The user is in the diagnostic message.

Press ± (① symbol).

- The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with  $\pm$  or  $\Box$  and press  $\Box$ .
  - ► The message about the remedial measures opens.
- 3. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

- 1. Press E.
  - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - ► The message for the remedial measures closes.

### 12.4 Diagnostic information in the Web browser

### 12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information→ 🖺 162
- 3 Remedy information with Service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
  - Via parameter
  - Via submenu → 🖺 193

#### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
8	Failure A device error has occurred. The measured value is no longer valid.
<b>W</b>	Function check The device is in service mode (e.g. during a simulation).
<u>^</u>	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
<b>&amp;</b>	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


### 12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

### 12.5 Diagnostic information in FieldCare or DeviceCare

### 12.5.1 Diagnostic options


Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



- 1 Status area with status signal → 161
- 2 *Diagnostic information* → 🖺 162
- 3 Remedy information with Service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
  - Via parameter
  - Via submenu → 🖺 193

#### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



### 12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
   Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
  - ► A tool tip with remedy information for the diagnostic event appears.


### 12.6 Adapting the diagnostic information

### 12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Diagnostic behavior in accordance with Specification PROFIBUS PA Profile 3.02, Condensed Status.

Expert  $\rightarrow$  System  $\rightarrow$  Diagnostic handling  $\rightarrow$  Diagnostic behavior



A0019179-E


#### Available diagnostic behaviors

The following diagnostic behaviors can be assigned:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The measured value output via PROFIBUS and the totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the <b>Event logbook</b> submenu ( <b>Event list</b> submenu) and not in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

#### Displaying the measured value status

If the Analog Input, Digital Input and Totalizer function blocks are configured for cyclic data transmission, the device status is coded as per PROFIBUS PA Profile 3.02 Specification and transmitted along with the measured value to the PROFIBUS Master (Class 1) via the coding byte (byte 5). The coding byte is split into three segments: Quality, Quality Substatus and Limits.



■ 38 Structure of the coding byte

The content of the coding byte depends on the configured failsafe mode in the particular function block. Depending on which failsafe mode has been configured, status information in accordance with PROFIBUS PA Profile Specification 3.02 is transmitted to the PROFIBUS Master (Class 1) via the coding byte .

#### Determining the measured value status and device status via the diagnostic behavior

When the diagnostic behavior is assigned, this also changes the measured value status and device status for the diagnostic information. The measured value status and device status depend on the choice of diagnostic behavior and on the group in which the diagnostic information is located.

The diagnostic information is grouped as follows:

- Diagnostic information pertaining to the sensor: diagnostic number 000 to 199
   → 167
- Diagnostic information pertaining to the electronics: diagnostic number 200 to 399
   → 

  168
- Diagnostic information pertaining to the configuration: diagnostic number 400 to 599  $\rightarrow$   $\stackrel{ riangle}{=}$  168
- Diagnostic information pertaining to the process: diagnostic number 800 to 999  $\rightarrow$   $\stackrel{ o}{=}$  168

Depending on the group in which the diagnostic information is located, the following measured value status and device status are firmly assigned to the particular diagnostic behavior:

Diagnostic information pertaining to the sensor: diagnostic number 000 to 199

Diagnostic behavior	N	leasured value st	Device diagnosis		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Maintenance alarm	0x24 to 0x27	F (Failure)	Maintenance alarm
Warning	GOOD	Maintenance demanded	0xA8 to 0xAB	M (Maintenance)	Maintenance demanded
Logbook entry only	GOOD	ok	0x80 to 0x8E	_	_
Off	ОООД	OK .	OXOU TO OXOE	_	_

Diagnostic information pertaining to the electronics: diagnostic number 200 to 399

Diagnostic number 200 to 301, 303 to 399

Diagnostis habarian	IV.	leasured value sta	Device dia succia		
Diagnostic behavior (configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	Device diagnosis (fixed assignment)
Alarm	BAD	Maintenance	0x24 to 0x27	F	Maintenance
Warning	DAD	alarm	0.24 (0.0.27	(Failure)	alarm
Logbook entry only	COOD	GOOD ok	000 +- 005		
Off	GOOD		0x80 to 0x8E	_	_

### Diagnostic information 302

Diagnostic hohovior	N	leasured value st	Device diagnosis		
Diagnostic behavior (configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Function check, local override	0x24 to 0x27	С	Function check
Warning	GOOD	Function check	0xBC to 0xBF	-	_

Diagnostic information 302 (device verification active) is output during internal or external Heartbeat verification.

- Signal status: Function check
- Choice of diagnostic behavior: alarm or warning (factory setting)

When Heartbeat verification starts, data logging is interrupted, the last valid measured value is output and the totalizers are stopped.

Diagnostic information pertaining to the configuration: diagnostic number 400 to 599

Diagnostic behavior	M	leasured value sta	Device diagnosis		
(configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTA IN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition
Logbook entry only	GOOD	-1-	0x80 to 0x8E	_	_
Off	GOOD	ok	OXOU 10 UXOE	_	_

Diagnostic information pertaining to the process: diagnostic number 800 to 999

Dingnostic hohovion	M	leasured value st	Dovino dio anonio		
Diagnostic behavior (configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	Device diagnosis (fixed assignment)
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTA IN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition

Diagnostic behavior	N	leasured value st	Device diagnosis		
Diagnostic behavior (configurable)	Quality	Quality Substatus	Coding (hex)	Category (NE107)	(fixed assignment)
Logbook entry only	GOOD	ok	0x80 to 0x8E	_	_
Off	GOOD	OK.	OXOU TO OXOE	_	_

### 12.7 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- In the case of some items of diagnostic information, the diagnostic behavior can be changed. Change the diagnostic information  $\Rightarrow \triangleq 166$

### 12.7.1 Diagnostic of sensor

No.	Diagnos 	stic information Short text	Remedy instructions	Influenced measured variables
043	43 Sensor short circuit  Maggued variable status [from the factory] 1)	Check sensor cable and sensor     Execute Heartbeat Verification     Replace sensor cable or sensor	<ul><li>Conductivity</li><li>Corrected conductivity</li><li>Density</li></ul>	
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Uncertain  Maintenance demanded  0x68 to 0x6B  S  Warning		<ul> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	Short text		variables
082			1. Check module connections	<ul> <li>Conductivity</li> </ul>
			2. Contact service	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		Flow velocity  Low flow cut off
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnosti	c information	Remedy instructions	Influenced measured
No.		Short text		variables
083	Memory content		1. Restart device	<ul><li>Conductivity</li></ul>
	Measured variable status		2. Restore HistoROM S-DAT backup ('Device reset' parameter)	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad 3. Replace HistoROM S-DAT	3. Replace HistoROM S-DAT	<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
169	Conductivity measurement fail	ed	1. Check grounding conditions	<ul><li>Conductivity</li></ul>
	Measured variable status	2. Deactivate conductivity measurement	<ul><li>Corrected conductivity</li><li>Electronic temperature</li></ul>	
	Quality	Bad		Empty pipe detection
	Quality substatus	Maintenance alarm		<ul><li>Flow velocity</li><li>Low flow cut off</li></ul>
	Coding (hex)	Coding (hex) 0x24 to 0x27		<ul><li>Mass flow</li><li>Corrected volume flow</li></ul>
	Status signal	М		<ul> <li>Temperature</li> </ul>
	Diagnostic behavior	Warning		<ul><li>Status</li><li>Volume flow</li></ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
170	170 Coil resistance	Check ambient and process temperature	■ Conductivity	
	Measured variable status			<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Bad		<ul> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	o. Short text			variables
180	0 Temperature sensor defective		1. Check sensor connections	<ul><li>Conductivity</li></ul>
	Measured variable status		Replace sensor cable or sensor     Turn off temperature measurement	<ul> <li>Corrected conductivity</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> </ul>
	Quality	Bad		
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		Reference density
	Diagnostic behavior	Warning		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
181			Check sensor cable and sensor     Execute Heartbeat Verification	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measureu variable status		3. Replace sensor cable or sensor	<ul> <li>Density</li> </ul>
	Quality	Bad		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Quality substatus	Maintenance alarm		Flow velocity
	Coding (hex)	0x24 to 0x27		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	F		Reference density     Corrected volume flow
	Diagnostic behavior	Alarm		<ul> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

### 12.7.2 Diagnostic of electronic

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
201	Device failure		1. Restart device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Contact service	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		Flow velocity  Low flow cut off
	Diagnostic behavior	Alarm		<ul> <li>Low how cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	5	Short text		variables
242	Software incompatible		1. Check software	<ul> <li>Conductivity</li> </ul>
	Measured variable status		Flash or change main electronics     module	<ul> <li>Corrected conductivity</li> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> </ul>
	Quality	Bad		
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		<ul> <li>Flow velocity</li> </ul>
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
252	Modules incompatible		1. Check electronic modules	<ul> <li>Conductivity</li> </ul>
	Measured variable status		Check if correct modules are available     (e.g. NEx, Ex)	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad	3. Replace electronic modules	<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	Short text		variables
252	Modules incompatible		1. Check if correct electronic modul is	<ul> <li>Conductivity</li> </ul>
	Measured variable status		plugged  2. Replace electronic module	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	S	Short text		variables
262	Sensor electronic connection i	faulty	1. Check or replace connection cable	<ul><li>Conductivity</li></ul>
	Measured variable status		between sensor electronic module (ISEM) and main electronics	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad	2. Check or replace ISEM or main electronics	<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
270	Main electronic failure  Measured variable status		Change main electronic module	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Quality  Quality substatus	Bad Maintenance alarm		<ul> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> </ul>
	Coding (hex) Status signal	0x24 to 0x27		<ul> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> </ul>
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
271	Main electronic failure		1. Restart device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Change main electronic module	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	2	Short text		variables
272	Main electronic failure		1. Restart device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Contact service	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
273	Main electronic failure  Measured variable status		Change electronic	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Quality Quality substatus	Bad Maintenance alarm		<ul> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> </ul>
	Coding (hex) Status signal	0x24 to 0x27 F		<ul> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> </ul>
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
275	I/O module 1 to n defective		Change I/O module	<ul> <li>Conductivity</li> </ul>
	Measured variable status			<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
276	1		1. Restart device	<ul> <li>Conductivity</li> </ul>
			2. Change I/O module	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Measured values 3</li><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
283	Memory content		1. Reset device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Contact service	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	Short text		variables
302	Device verification active		Device verification active, please wait.	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measured variable status [fr	om the factory] 1)		<ul> <li>Measured values 1</li> </ul>
	Quality	Good		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	С		■ Flow velocity
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
303	I/O 1 to n configuration changed	1. Apply I/O module configuration	-	
	Measured variable status		(parameter 'Apply I/O configuration')  2. Afterwards reload device description and check wiring	
	Quality	Bad		
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	M		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.		Short text		variables
311	Electronic failure		1. Do not reset device	■ Conductivity
	Measured variable status		2. Contact service	<ul> <li>Corrected conductivity</li> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> </ul>
	Quality	Bad		
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	M		■ Flow velocity
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
332	Writing in HistoROM backup f	ailed	Replace user interface board	■ Conductivity
	Measured variable status		Ex d/XP: replace transmitter	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	Short text		variables
361	I/O module 1 to n faulty		1. Restart device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		Check electronic modules     Change I/O Modul or main electronics	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
372	Sensor electronic (ISEM) faulty	I	1. Restart device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		Check if failure recurs     Replace sensor electronic module	<ul> <li>Corrected conductivity</li> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> </ul>
	Quality	Bad	(ISEM)	
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	S	hort text		variables
373	Sensor electronic (ISEM) fault	I	1. Transfer data or reset device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Contact service	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	2	Short text		variables
375	I/O- 1 to n communication fai	iled	1. Restart device	<ul> <li>Conductivity</li> </ul>
-	Management reminble status		Check if failure recurs     Replace module rack inclusive electronic	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	F		Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

Diagnostic information		Remedy instructions	Influenced measured	
No.	:	Short text		variables
376	Sensor electronic (ISEM) faulty		Replace sensor electronic module (ISEM)     Turn off diagnostic message	<ul><li>Conductivity</li><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Measured variable status [from the factory] 1)			
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	S		<ul> <li>Flow velocity</li> </ul>
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

Diagnostic information		Remedy instructions	Influenced measured	
No.	Short text			variables
377	377 Sensor electronic (ISEM) faulty		Check sensor cable and sensor     Perform Heartbeat Verification     Replace sensor cable or sensor	<ul><li>Conductivity</li></ul>
	Measured variable status [from the factory] 1)			<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Bad		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Quality substatus	Maintenance alarm		■ Flow velocity
	Coding (hex)	0x24 to 0x27		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	S		Reference density
	Diagnostic behavior	Warning		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

Diagnostic information		Remedy instructions	Influenced measured	
No.		Short text		variables
382	Data storage		Insert T-DAT     Replace T-DAT	<ul> <li>Conductivity</li> </ul>
	Measured variable status			<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Measured values 3</li><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

Diagnostic information		Remedy instructions	Influenced measured	
No.	S	hort text		variables
383	Memory content		Restart device     Delete T-DAT via 'Reset device'     parameter	<ul><li>Conductivity</li><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Measured variable status			
	Quality	Bad	3. Replace T-DAT	<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		Density
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		■ Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

Diagnostic information		Remedy instructions	Influenced measured	
No.	S	hort text		variables
387	HistoROM backup failed		Contact service organization	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measured variable status			<ul> <li>Measured values 1</li> </ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality substatus	Maintenance alarm		<ul><li>Density</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		Flow velocity
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
Sensor electronic (ISEM) faulty  Measured variable status  Quality  Bad  Quality substatus  Coding (hex)  Status signal  F  Diagnostic behavior  Alarm	,	1. Check ECC recovery time 2. Turn off ECC  Conductivity Corrected conductivity	Corrected conductivity	
	Quality Quality substatus Coding (hex)	Maintenance alarm 0x24 to 0x27		<ul> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> </ul>
	3	_		<ul> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

### 12.7.3 Diagnostic of configuration

Diagnostic information		Remedy instructions	Influenced measured	
No.		Short text		variables
330	Flash file invalid		1. Update firmware of device	<ul> <li>Conductivity</li> </ul>
	Measured variable status		2. Restart device	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	M		■ Flow velocity
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

Diagnostic information		Remedy instructions	Influenced measured	
No.	S	hort text		variables
331	Firmware update failed		1. Update firmware of device	<ul><li>Conductivity</li></ul>
	Measured variable status		2. Restart device	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>
	Quality	Bad		<ul> <li>Measured values 2</li> <li>Measured values 3</li> </ul>
	Quality substatus	Maintenance alarm		Density
	Coding (hex)	0x24 to 0x27		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Status signal	F		Flow velocity
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured	
No.		Short text		variables	
410	Data transfer		1. Check connection	<ul> <li>Conductivity</li> </ul>	
	Measured variable status		2. Retry data transfer	<ul><li>Corrected conductivity</li><li>Measured values 1</li></ul>	
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li></ul>	
	Quality substatus	Maintenance alarm		■ Density	
	Coding (hex)	0x24 to 0x27		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>	
	Status signal	F		<ul> <li>Flow velocity</li> <li>Low flow cut off</li> </ul>	
	Diagnostic behavior	Alarm		<ul> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>	

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
412	Processing download		Download active, please wait	<ul> <li>Conductivity</li> </ul>
	Measured variable status			<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Uncertain		Electronic temperature
	Quality substatus	Initial value		<ul><li>Empty pipe detection</li><li>Flow velocity</li></ul>
	Coding (hex)	0x4C to 0x4F		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	С		Reference density     Corrected volume flow
	Diagnostic behavior	Warning		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
431	Trim 1 to n		Carry out trim	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured	
No.	Short text			variables	
437	7 Configuration incompatible		1. Restart device	Conductivity	
Quality Quality	Measured variable status		2. Contact service	<ul> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Measured values 1</li> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>	
	Quality	Bad		<ul><li>Measured values 3</li><li>Density</li><li>Electronic temperature</li></ul>	
	Quality substatus	Maintenance alarm			
	Coding (hex)	0x24 to 0x27			
	Status signal	F		■ Flow velocity	
	Diagnostic behavior	Alarm		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>	

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
438	Management variable status		Check data set file     Check device configuration     Up- and download new configuration	Conductivity     Corrected conductivity     Measured values 1
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Uncertain  Maintenance demanded  0x68 to 0x6B  M  Warning	- S. op and download new configuration	<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	<b>Diagnostic</b>	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
441	Current output 1 to n		1. Check process	_
	Measured variable status [from the factory] 1)	2. Check current output settings		
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	S		
	Diagnostic behavior	Warning		

182

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
442	Frequency output 1 to n		1. Check process	_
	Measured variable status [fro	om the factory] 1)	2. Check frequency output settings	
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	S		
	Diagnostic behavior	Warning		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
443	I .		1. Check process	-
	Measured variable status [from the factory] 1)		2. Check pulse output settings	
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	S		
	Diagnostic behavior	Warning		

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
444	Current input 1 to n		1. Check process	Measured values 1
	Measured variable status [fro	om the factory] 1)	2. Check current input settings	<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	S		
	Diagnostic behavior	Warning		

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	<b>Diagnostic</b> i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
453	Flow override		Deactivate flow override	■ Conductivity
	Measured variable status			<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Good		<ul> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> </ul>
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		<ul> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	<b>Diagnostic</b>	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
463	] 3 1	1. Check module/channel configuration	Measured values 1	
	Measured variable status		2. Check I/O module configuration	<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality	Bad		
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
482	FB not Auto/Cas		Set Block in AUTO mode	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Ok		
	Coding (hex)	0x80 to 0x83		
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
484	Failure mode simulation		Deactivate simulation	<ul><li>Conductivity</li></ul>
	Measured variable status			<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Bad		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Quality substatus	Function check		■ Flow velocity
	Coding (hex)	0x3C to 0x3F		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	С		Reference density
	Diagnostic behavior	Alarm		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
485	Measured variable simulation  Measured variable status		Deactivate simulation	<ul><li>Conductivity</li><li>Corrected conductivity</li><li>Density</li></ul>
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Good Function check  0xBC to 0xBF  C  Warning		<ul> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
486	Current input 1 to n simulation		Deactivate simulation	Measured values 1
	Measured variable status			<ul><li>Measured values 2</li><li>Measured values 3</li></ul>
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	o. Short text			variables
491	Current output 1 to n simulation	on	Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
492	92 Simulation frequency output 1 to n		Deactivate simulation frequency output	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	<b>Diagnostic</b>	information	Remedy instructions	Influenced measured
No.	Short text			variables
493	Simulation pulse output 1 to n		Deactivate simulation pulse output	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	OxBC to OxBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
494	Switch output simulation 1 to 1	n	Deactivate simulation switch output	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
495	Diagnostic event simulation		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Ok		
	Coding (hex)	0x80 to 0x83		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
496	Status input simulation		Deactivate simulation status input	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	С		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
497	Simulation block output		Deactivate simulation	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Ok		
	Coding (hex)	0x80 to 0x83		
	Status signal	С		
	Diagnostic behavior	Warning		

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
511	ISEM settings faulty		1. Check measuring period and integration	<ul><li>Conductivity</li></ul>
	Measured variable status		time 2. Check sensor properties	<ul><li>Corrected conductivity</li><li>Density</li></ul>
	Quality	Bad		Electronic temperature
	Quality substatus	Maintenance alarm		<ul><li>Empty pipe detection</li><li>Flow velocity</li></ul>
	Coding (hex)	0x24 to 0x27		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	С		Reference density
	Diagnostic behavior	Alarm		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.	. Short text			variables
520	g		Check I/O hardware configuration	-
	Measured variable status		2. Replace wrong I/O module 3. Plug the module of double pulse output	
	Quality	Bad	on correct slot	
	Quality substatus	Function check		
	Coding (hex)	0x3C to 0x3F		
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
530	0 Electrode cleaning is running		Turn off ECC	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measured variable status			<ul><li>Density</li></ul>
	Quality	Good		<ul><li>Electronic temperature</li><li>Empty pipe detection</li></ul>
	Quality substatus	Function check		Flow velocity
	Coding (hex)	0xBC to 0xBF		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	С		Reference density
	Diagnostic behavior	Warning		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
531	Empty pipe adjustment faulty		Execute EPD adjustment	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measured variable status [fro	om the factory] 1)		Empty pipe detection
	Quality	Bad		<ul><li>Flow velocity</li><li>Low flow cut off</li></ul>
	Quality substatus	Maintenance alarm		<ul> <li>Mass flow</li> </ul>
	Coding (hex)	0x24 to 0x27		<ul><li>Corrected volume flow</li><li>Status</li></ul>
	Status signal	S		<ul><li>Volume flow</li></ul>
	Diagnostic behavior	Warning		

	Diagnostic	information	Remedy instructions	Influenced measured
No.	S	hort text		variables
537			1. Check IP addresses in network	_
	Measured variable status		2. Change IP address	
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	0xBC to 0xBF		
	Status signal	F		
	Diagnostic behavior	Warning		

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
594	Relay output simulation		Deactivate simulation switch output	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Function check		
	Coding (hex)	OxBC to OxBF		
	Status signal	С		
	Diagnostic behavior	Warning		

# 12.7.4 Diagnostic of process

	Diagnostic information		Remedy instructions	Influenced measured
No.	s	hort text		variables
803	1 -		1. Check wiring – 2. Change I/O module	_
	Measured variable status			
	Quality	Bad		
	Quality substatus	Process related		
	Coding (hex)	0x28 to 0x2B		
	Status signal	F		
	Diagnostic behavior	Alarm		

	Diagnostic information		Remedy instructions	Influenced measured
No.		Short text		variables
832	1 5		Reduce ambient temperature	<ul><li>Conductivity</li><li>Corrected conductivity</li></ul>
	Measured variable status	[from the factory] */		<ul> <li>Measured values 1</li> </ul>
	Quality	Bad		<ul><li>Measured values 2</li><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Process related		
	Coding (hex)	0x28 to 0x2B		<ul><li> Electronic temperature</li><li> Empty pipe detection</li></ul>
	Status signal	S		■ Flow velocity
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

	Diagnostic information		Remedy instructions	Influenced measured
No.		Short text		variables
833	Electronic temperature too low  Measured variable status [from the factory] 1)		Increase ambient temperature	<ul> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Measured values 1</li> </ul>
	Quality Quality substatus	Bad Process related		<ul> <li>Measured values 2</li> <li>Measured values 3</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> </ul>
	Coding (hex) Status signal	0x28 to 0x2B		
	Diagnostic behavior	Warning		<ul> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured
No.	Short text			variables
834	4 Process temperature too high		Reduce process temperature	■ Conductivity
	Measured variable status [fro	om the factory] <sup>1)</sup>		<ul><li>Corrected conductivity</li><li>Electronic temperature</li></ul>
	Quality	Uncertain		<ul><li>Empty pipe detection</li><li>Flow velocity</li></ul>
	Quality substatus	Process related		<ul> <li>Low flow cut off</li> </ul>
	Coding (hex)	0x78 to 0x7B		<ul><li>Mass flow</li><li>Corrected volume flow</li></ul>
	Status signal	S		■ Temperature
	Diagnostic behavior	Warning		<ul><li>Status</li><li>Volume flow</li></ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	Short text			variables
835	Process temperature too low		Increase process temperature	<ul><li>Conductivity</li></ul>
	Measured variable status [fr	om the factory] 1)		<ul><li>Corrected conductivity</li><li>Electronic temperature</li></ul>
	Quality	Uncertain		<ul><li> Empty pipe detection</li><li> Flow velocity</li><li> Low flow cut off</li></ul>
	Quality substatus	Process related		
	Coding (hex)	0x78 to 0x7B		<ul><li>Mass flow</li><li>Corrected volume flow</li></ul>
	Status signal	S		<ul><li>Temperature</li><li>Status</li></ul>
	Diagnostic behavior	Warning		<ul><li>Status</li><li>Volume flow</li></ul>

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	hort text		variables
842	2 Process limit		Low flow cut off active!	Flow velocity
	Measured variable status [fro	om the factory] 1)	Check low flow cut off configuration	<ul><li>Mass flow</li><li>Corrected volume flow</li><li>Status</li></ul>
	Quality	Uncertain		<ul><li>Status</li><li>Volume flow</li></ul>
	Quality substatus	Process related		
	Coding (hex)	0x78 to 0x7B		
	Status signal	S		
	Diagnostic behavior	Warning		

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	5	Short text		variables
882	1 5		1. Check input configuration	Corrected conductivity
	Measured variable status		2. Check external device or process conditions  • Measured val  • Measured val  • Measured val	
	Quality	Bad		<ul><li>Measured values 3</li><li>Density</li></ul>
	Quality substatus	Maintenance alarm		Empty pipe detection
	Coding (hex)	0x24 to 0x27		<ul><li>Flow velocity</li><li>Low flow cut off</li></ul>
	Status signal	F		<ul><li>Mass flow</li><li>Reference density</li></ul>
	Diagnostic behavior	Alarm		<ul> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
937	Sensor symmetry		1. Eliminate external magnetic field near	<ul><li>Conductivity</li></ul>
	Measured variable status [	from the factory] 1)	sensor 2. Turn off diagnostic message	<ul> <li>Corrected conductivity</li> <li>Density</li> <li>Electronic temperature</li> <li>Empty pipe detection</li> </ul>
	Quality	Bad		
	Quality substatus	Maintenance alarm		■ Flow velocity
	Coding (hex)	0x24 to 0x27		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Status signal	S		Reference density
	Diagnostic behavior	Warning		<ul><li>Corrected volume flow</li><li>Temperature</li><li>Status</li><li>Volume flow</li></ul>

No.	Diagnostic information  No. Short text		Remedy instructions	Influenced measured variables
938	Measured variable status [from the factory] 1)		Check ambient conditions regarding     EMC influence     Turn off diagnostic message	<ul><li>Conductivity</li><li>Corrected conductivity</li><li>Density</li></ul>
	Quality Quality substatus Coding (hex) Status signal Diagnostic behavior	Bad Maintenance alarm 0x24 to 0x27 F Alarm		<ul> <li>Electronic temperature</li> <li>Empty pipe detection</li> <li>Flow velocity</li> <li>Low flow cut off</li> <li>Mass flow</li> <li>Reference density</li> <li>Corrected volume flow</li> <li>Temperature</li> <li>Status</li> <li>Volume flow</li> </ul>

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	. Short text			variables
961	Electrode potential out of specification		1. Check process conditions	<ul><li>Empty pipe detection</li><li>Low flow cut off</li><li>Mass flow</li></ul>
	Measured variable status [from the factory] 1)		2. Check ambient conditions	
	Quality	Bad		<ul><li>Status</li><li>Volume flow</li></ul>
	Quality substatus	Maintenance alarm		
	Coding (hex)	0x24 to 0x27		
	Status signal	S		
	Diagnostic behavior	Warning		

1) Diagnostic behavior can be changed. This causes the overall status of the measured variable to change.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	Short text			variables
962	Pipe empty		1. Perform full pipe adjustment	<ul> <li>Conductivity</li> </ul>
	Measured variable status [from the factory] 1)		Perform empty pipe adjustment     Turn off empty pipe detection	<ul><li>Corrected conductivity</li><li>Flow velocity</li></ul>
	Quality	Bad		<ul><li>Low flow cut off</li><li>Mass flow</li></ul>
	Quality substatus	Process related		Corrected volume flow
	Coding (hex)	0x28 to 0x2B		<ul><li>Status</li><li>Volume flow</li></ul>
	Status signal	S		
	Diagnostic behavior	Warning		


# 12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event:
- Via local display → 163
  - Via Web browser → 🖺 164
  - Via "FieldCare" operating tool → 🖺 165
  - Via "DeviceCare" operating tool → 🗎 165
- Other pending diagnostic events can be displayed in the **Diagnostic list** submenu  $\rightarrow \stackrel{\cong}{=} 193$

### Navigation

"Diagnostics" menu



### Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	event along with its diagnostic be		Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.


Parameter	Prerequisite	Description	User interface
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

#### 12.9 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the Diagnostic list submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

## Navigation path

Diagnostics → Diagnostic list



Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display → 🗎 163
  - Via Web browser → 🖺 164


# 12.10 Event logbook

## 12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the Events list submenu.

#### Navigation path

**Diagnostics** menu → **Event logbook** submenu → Event list



€ 40 Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events  $\rightarrow$  🗎 169
- Information events  $\rightarrow$  🗎 194

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - €: Occurrence of the event
  - ⊖: End of the event
- Information event
  - €: Occurrence of the event
- To call up the measures to rectify a diagnostic event:
  - Via local display → 🖺 163
    - Via Web browser → 🖺 164
  - Via "FieldCare" operating tool → 🖺 165
- For filtering the displayed event messages → 🗎 194

# 12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

#### Navigation path

Diagnostics → Event logbook → Filter options

### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

# 12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name	
I1000	(Device ok)	
I1079	Sensor changed	
I1089	Power on	
I1090	Configuration reset	
I1091	Configuration changed	
I1092	HistoROM backup deleted	
I1137	Electronic changed	
I1151	History reset	
I1155	Reset electronic temperature	
I1156	Memory error trend	
I1157	Memory error event list	
I1184	Display connected	
I1256	Display: access status changed	
I1278	I/O module reset detected	
I1335	Firmware changed	
I1351	Empty pipe detection adjustment failure	

Info number	Info name	
I1353	Empty pipe detection adjustment ok	
I1361	Web server: login failed	
I1397	Fieldbus: access status changed	
I1398	CDI: access status changed	
I1443	Coating thickness not determined	
I1444	Device verification passed	
I1445	Device verification failed	
I1457	Measured error verification failed	
I1459	I/O module verification failed	
I1461	Sensor verification failed	
I1462	Sensor electronic module verific. failed	
I1512	Download started	
I1513	Download finished	
I1514	Upload started	
I1515	Upload finished	
I1618	I/O module 2 replaced	
I1619	I/O module 3 replaced	
I1621	I/O module 4 replaced	
I1622	Calibration changed	
I1624	Reset all totalizers	
I1625	Write protection activated	
I1626	Write protection deactivated	
I1627	Web server: login successful	
I1628	Display: login successful	
I1629	CDI: login successful	
I1631	Web server access changed	
I1632	Display: login failed	
I1633	CDI: login failed	
I1634	Reset to factory settings	
I1635	Reset to delivery settings	
I1636	Fieldbus address reset	
I1639	Max. switch cycles number reached	
I1649	Hardware write protection activated	
I1650	Hardware write protection deactivated	
I1712	New flash file received	
I1725	Sensor electronic module (ISEM) changed	
I1726	Configuration backup failed	

# 12.11 Resetting the measuring device

Using the **Device reset** parameter ( $\rightarrow \boxminus 137$ ) it is possible to reset the entire device configuration or some of the configuration to a defined state.

# 12.11.1 Function scope of the "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Restore S-DAT backup	Restore the data that are saved on the S-DAT. The data record is restored from the electronics memory to the S-DAT.  This option is displayed only in an alarm condition.

# 12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

# Navigation

"Diagnostics" menu  $\rightarrow$  Device information

▶ Device informa	tion	
	Device tag	→ 🖺 197
	Serial number	→ 🖺 197
	Firmware version	→ 🖺 197
	Device name	→ 🖺 197
	Order code	→ 🖺 197
	Extended order code 1	→ 🖺 197
	Extended order code 2	→ 🖺 197
	Extended order code 3	→ 🖺 197
	ENP version	→ 🖺 197
	PROFIBUS ident number	→ 🖺 197
	Status PROFIBUS Master Config	→ 🖺 197

# Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag 500 PA
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name	Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter.	Promag 300/500	-
Order code	Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	_
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 3  Shows the 3rd part of the extended order code.  The extended order code can also b found on the nameplate of the sens and transmitter in the "Ext. ord. cd." field.		Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00
PROFIBUS ident number	Displays the PROFIBUS identification 0 to FFFF 0x156C number.		0x156C
Status PROFIBUS Master Config	Displays the status of the PROFIBUS Master configuration.	<ul><li>Active</li><li>Not active</li></ul>	Not active

# 12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
08.2016	01.00.zz	Option <b>70</b>	Original firmware	Operating Instructions	BA01404D/06/EN/01.16
11.2018	01.01.zz	Option 68	Local display - enhanced performance and data entry via text editor  Optimized keypad lock for local display  Web server feature update - Support for trend data function - Heartbeat function enhanced to include detailed results (page 3/4 of the report) - Device configuration as PDF (parameter log, similar to FDT print)  Network capability of Ethernet (service) interface Comprehensive Heartbeat feature update  Local display - support for WLAN infrastructure mode Implementation of reset code	Operating Instructions	BA01404D/06/EN/02.18

- It is possible to flash the firmware to the current version or the previous version using the service interface.
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
  - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
  - Specify the following details:
    - Product root: e.g. 5H5B
       The product root is the first part of the order code: see the nameplate on the device.
    - Text search: Manufacturer's information
    - Media type: Documentation Technical Documentation

# 13 Maintenance

# 13.1 Maintenance tasks

No special maintenance work is required.

## 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

## 13.1.2 Interior cleaning

#### Cleaning with pigs

It is essential to take the internal diameters of the measuring tube and process connection into account when cleaning with pigs. All the dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document.

## 13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.

The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory part)  $\rightarrow \triangleq 230$ 

# 13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment:  $\rightarrow \triangleq 202$ 

### 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

# 14 Repairs

# 14.1 General notes

# 14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

## 14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ► Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document every repair and each conversion and enter them into the *W@M* life cycle management database.

# 14.2 Spare parts

*W@M Device Viewer* (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

- i
  - Measuring device serial number:
  - Is located on the nameplate of the device.
  - Can be read out via the Serial number parameter (→ 197) in the Device information submenu.

### 14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

# 14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at <a href="http://www.endress.com/support/return-material">http://www.endress.com/support/return-material</a>

# 14.5 Disposal

# 14.5.1 Removing the measuring device

1. Switch off the device.

## **▲** WARNING

### Danger to persons from process conditions.

- ► Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

# 14.5.2 Disposing of the measuring device

### **A** WARNING

## Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ► Ensure proper separation and reuse of the device components.

# 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

# 15.1 Device-specific accessories

## 15.1.1 For the transmitter

Accessories	Description	
Transmitter Proline 500 – digital Proline 500	Transmitter for replacement or storage. Use the order code to define the following specifications:  Approvals Output Input Display/operation Housing Software  Proline 500 – digital transmitter: Order code: 5X5BXX-XXXXXXXXXA Proline 500 transmitter: Order code: 5X5BXX-XXXXXXXXX	
	Proline 500 transmitter for replacement: It is essential to specify the serial number of the current transmitter when ordering. Based on the serial number, the device-specific data (e.g., calibration factors) of the replacement device can be used for the new transmitter.  Proline 500 – digital transmitter: Installation Instructions EA01151	
	Proline 500 transmitter: Installation Instructions EA01152	
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Enclosed accessories", option P8 "Wireless antenna wide area".  ■ The external WLAN antenna is not suitable for use in hygienic applications.  ■ Further information on the WLAN interface → ■ 87.  ■ Order number: 71351317  ■ Installation Instructions EA01238D	
Pipe mounting set	Pipe mounting set for transmitter.  Proline 500 – digital transmitter Order number: 71346427  Proline 500 transmitter Order number: 71346428	
Protective cover Transmitter Proline 500 – digital Proline 500	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.  Proline 500 – digital transmitter Order number: 71343504 Proline 500 transmitter Order number: 71343505  Installation Instructions EA01160	

202

Display guard Proline 500 – digital	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight.  Order number: 71228792
	For details, see Installation Instructions EA01093
Connecting cable Proline 500 – digital	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection) or as an accessory (order number DK5012).
Sensor – Transmitter	The following cable lengths are available: order code for "Cable, sensor connection"  Option B: 20 m (65 ft)  Option E: User configurable up to max. 50 m  Option F: User configurable up to max. 165 ft
	Maximum possible cable length for a Proline 500 – digital connecting cable: 300 m (1000 ft)
Connecting cable Proline 500	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection) or as an accessory (order number DK5012).
Sensor – Transmitter	The following cable lengths are available: order code for "Cable, sensor connection"  Option 1: 5 m (16 ft)  Option 2: 10 m (32 ft)  Option 3: 20 m (65 ft)  Option 4: User configurable cable length (m)  Option 5: User configurable cable length (ft)
	Possible cable length for a Proline 500 connecting cable: depends on the medium conductivity, max. 200 m (660 ft)

# 15.1.2 For the sensor

Accessories	Description
Adapter set	Adapter connections for installing a Promag H instead of a Promag 30/33 A or Promag 30/33 H (DN 25).
	Consists of:  2 process connections Screws Seals
Seal set	For the regular replacement of seals for the sensor.
Spacer	If replacing a DN $80/100$ sensor in an existing installation, a spacer is needed if the new sensor is shorter.
Welding jig	Welding nipple as process connection: welding jig for installation in pipe.
Grounding rings	Are used to ground the medium in lined measuring tubes to ensure proper measurement.
	For details, see Installation Instructions EA00070D
Ground disks	Are used to ground the medium in lined measuring tubes to ensure proper measurement.
	For details, see Installation Instructions EA00070D
Mounting kit	Consists of:     2 process connections     Screws     Seals
Wall mounting kit	Wall mounting kit for measuring device (only DN 2 to 25 (1/12 to 1"))

# 15.2 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices:  Choice of measuring devices for industrial requirements  Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy.  Graphic illustration of the calculation results  Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.  Applicator is available:  Via the Internet: https://portal.endress.com/webapp/applicator
W@M	■ As a downloadable DVD for local PC installation.  W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle.  W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime.  Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, visit www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices.  Innovation brochure IN01047S

# 15.3 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.  Technical Information TI00133R Operating Instructions BA00247R

# 16 Technical data

# 16.1 Application

The measuring device is only suitable for flow measurement of liquids with a minimum conductivity of 5  $\mu S/cm$ .

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

# 16.2 Function and system design

#### Measuring principle

Electromagnetic flow measurement on the basis of Faraday's law of magnetic induction.

#### Measuring system

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

For information on the structure of the device  $\rightarrow \implies 14$ 

# **16.3** Input

#### Measured variable

#### Direct measured variables

- Volume flow (proportional to induced voltage)
- Temperature <sup>1)</sup>
- Electrical conductivity

#### Calculated measured variables

- Mass flow
- Corrected volume flow
- Corrected electrical conductivity 1)

#### Measuring range

Typically v = 0.01 to 10 m/s (0.03 to 33 ft/s) with the specified accuracy

Flow characteristic values in SI units: DN 2 to 125 (1/12 to 5")

Nominal Recommended diameter flow		Factor	y settings		
min./max. full scale value (v ~ 0.3/10 m/s)			Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[mm] [in] [dm³/min]		[dm³/min]	[dm³/min]	[dm³]	[dm³/min]
2	1/12	0.06 to 1.8	0.5	0.005	0.01
4	5/32	0.25 to 7	2	0.025	0.05

<sup>1)</sup> Only available for nominal diameters DN 15 to 150 (½ to 6") and with the order code for "Sensor option", option CI: "Medium temperature measurement".

Nominal Recommended Factory		y settings			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[mm]	[in]	[dm³/min]	[dm³/min]	[dm³]	[dm³/min]
8	5/16	1 to 30	8	0.1	0.1
15	1/2	4 to 100	25	0.2	0.5
25	1	9 to 300	75	0.5	1
40	1 ½	25 to 700	200	1.5	3
50	2	35 to 1100	300	2.5	5
65	-	60 to 2 000	500	5	8
80	3	90 to 3 000	750	5	12
100	4	145 to 4700	1200	10	20
125	5	220 to 7 500	1850	15	30

# Flow characteristic values in SI units: DN 150 (6")

	ninal neter	Recommended flow	Factor	ry settings	
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[mm] [in]		[m³/h]	[m <sup>3</sup> /h]	[m³]	[m <sup>3</sup> /h]
150	6	20 to 600	150	0.03	2.5

# Flow characteristic values in US units

	ninal neter	Recommended flow	ed Factory settings		
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
1/12	2	0.015 to 0.5	0.1	0.001	0.002
5/32	4	0.07 to 2	0.5	0.005	0.008
5/16	8	0.25 to 8	2	0.02	0.025
1/2	15	1 to 27	6	0.05	0.1
1	25	2.5 to 80	18	0.2	0.25
1 ½	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4
5	125	60 to 1950	450	5	7
6	150	90 to 2 650	600	5	12

#### Recommended measuring range

"Flow limit" section  $\rightarrow$   $\stackrel{ riangle}{ riangle}$  218



For custody transfer, the applicable approval determines the permitted measuring range, the pulse value and the low flow cut off.

### Operable flow range

Over 1000:1




For custody transfer, the operable flow range is 100 : 1 to 250 : 1, depending on the nominal diameter. Further details are specified by the applicable approval.

#### Input signal

#### External measured values

To increase the accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring device:

- Medium temperature to increase the accuracy of the electrical conductivity (e.g. iTEMP)
- Reference density for calculating the corrected volume flow



It is recommended to read in external measured values to calculate the corrected volume flow.

#### Current input

The measured values are written from the automation system to the measuring device via the current input  $\Rightarrow \triangleq 207$ .

#### Digital communication

The measured values are written from the automation system to the measuring device via PROFIBUS PA.

#### Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)
Current span	<ul><li>4 to 20 mA (active)</li><li>0/4 to 20 mA (passive)</li></ul>
Resolution	1 μΑ
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	≤ 30 V (passive)
Open-circuit voltage	≤ 28.8 V (active)
Possible input variables	<ul><li>Pressure</li><li>Temperature</li><li>Density</li></ul>

## Status input

Maximum input values	■ DC −3 to 30 V ■ If status input is active (ON): R <sub>i</sub> >3 kΩ
Response time	Adjustable: 5 to 200 ms

Input signal level	<ul> <li>Low signal: DC -3 to +5 V</li> <li>High signal: DC 12 to 30 V</li> </ul>
Assignable functions	<ul> <li>Off</li> <li>Reset the individual totalizers separately</li> <li>Reset all totalizers</li> <li>Flow override</li> </ul>

208

# 16.4 Output

# Output signal

# **PROFIBUS PA**

PROFIBUS PA	In accordance with EN 50170 Volume 2, IEC 61158-2 (MBP), galvanically isolated
Data transmission	31.25 kbit/s
Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

# Current output 0/4 to 20 mA

Current output	0/4 to 20 mA
Maximum output values	22.5 mA
Current span	Can be set to:  4 to 20 mA (active)  0/4 to 20 mA (passive)  Ex-i, passive
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 $\Omega$
Resolution	0.38 μΑ
Damping	Adjustable: 0.07 to 999 s
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Temperature</li> <li>Electronic temperature</li> </ul>

# Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector
	Can be set to: Active Passive  Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)

Pulse width	Adjustable: 0.05 to 2000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	<ul><li>Volume flow</li><li>Mass flow</li><li>Corrected volume flow</li></ul>
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to $10000$ Hz (f $_{max}$ = $12500$ Hz)
Damping	Adjustable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	<ul> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Temperature</li> <li>Electronic temperature</li> </ul>
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value: <ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Totalizer 1-3</li> <li>Temperature</li> <li>Electronic temperature</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status <ul> <li>Empty pipe detection</li> <li>Low flow</li> </ul> </li> </ul>

# Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: NO (normally open), factory setting NC (normally closed)

Maximum switching capacity (passive)	■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A
Assignable functions	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit value:         <ul> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> <li>Corrected volume flow</li> <li>Flow velocity</li> <li>Conductivity</li> <li>Corrected conductivity</li> <li>Totalizer 1-3</li> <li>Temperature</li> <li>Electronic temperature</li> </ul> </li> <li>Flow direction monitoring</li> <li>Status</li> <li>Empty pipe detection</li> <li>Low flow</li> </ul>

#### User configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

The technical values correspond to those of the inputs and outputs described in this section.

#### Signal on alarm

Depending on the interface, failure information is displayed as follows:

### PROFIBUS PA

Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02
Failure current FDE (Fault Disconnection Electronic)	0 mA

### Current output 0/4 to 20 mA

## 4 to 20 mA

Failure mode	Choose from:  4 to 20 mA in accordance with NAMUR recommendation NE 43  4 to 20 mA in accordance with US  Min. value: 3.59 mA  Max. value: 22.5 mA  Freely definable value between: 3.59 to 22.5 mA  Actual value  Last valid value
	- Last value

### 0 to 20 mA

Failure mode	Choose from:
	■ Maximum alarm: 22 mA
	■ Freely definable value between: 0 to 20.5 mA

# Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from:  Actual value No pulses
Frequency output	
Failure mode	Choose from:  Actual value  O Hz  Defined value (f max 2 to 12 500 Hz)
Switch output	
Failure mode	Choose from:  Current status  Open Closed

# Relay output

Failure mode	Choose from:
	<ul><li>Current status</li></ul>
	■ Open
	■ Closed

# Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

# Interface/protocol

- Via digital communication: PROFIBUS PA
- Via service interface
  - CDI-RJ45 service interface
  - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	---

#### Web server

Plain text display	With information on cause and remedial measures
--------------------	---

# Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	The following information is displayed depending on the device version:  Supply voltage active  Data transmission active  Device alarm/error has occurred  Diagnostic information via light emitting diodes

Low flow cut off	The switch points for low flow cut off are user-selectable.		
Galvanic isolation	The outputs are galvanically isolated from one another and from earth (PE).		
Protocol-specific data	Manufacturer ID	0x11	
	Ident number	0x156C	
	Profile version	3.02	
	Device description files (GSD, DTM, DD)	Information and files under:  www.endress.com www.profibus.org	
	Supported functions	<ul> <li>Identification &amp; Maintenance         Simplest device identification on the part of the control system and         nameplate</li> <li>PROFIBUS upload/download         Reading and writing parameters is up to ten times faster with PROFIBUS         upload/download</li> <li>Condensed status         Simplest and self-explanatory diagnostic information by categorizing         diagnostic messages that occur</li> </ul>	
	Configuration of the device address	<ul> <li>DIP switches on the I/O electronics module</li> <li>Local display</li> <li>Via operating tools (e.g. FieldCare)</li> </ul>	
	Compatibility with earlier model	If the device is replaced, the measuring device Promag 500 supports the compatibility of the cyclic data with previous models. It is not necessary to adjust the engineering parameters of the PROFIBUS network with the Promag 500 GSD file.	
		Earlier models:  Promag 50 PROFIBUS PA  ID No.: 1525 (hex)  Extended GSD file: EH3x1525.gsd  Standard GSD file: EH3_1525.gsd  Promag 53 PROFIBUS PA  ID No.: 1527 (hex)  Extended GSD file: EH3x1527.gsd  Standard GSD file: EH3x1527.gsd	
	System integration	Information regarding system integration →   □ 97.  □ Cyclic data transmission  □ Block model  □ Description of the modules	

# 16.5 Power supply

Terminal assignment	→ 🗎 38
Device plugs available	→ 🖺 39
Pin assignment, device plug	→ 🗎 39

_	1		1 /
Sun	nıv	VO	ltage

Order code for "Power supply"	terminal voltage		Frequency range
Option <b>D</b>	DC24 V	±20%	-
Option <b>E</b>	AC100 to 240 V	-15+10%	50/60 Hz, ±4 Hz

Order code for "Power supply"	terminal voltage		Frequency range
Option I	DC24 V	±20%	_
Option I	AC100 to 240 V	-15+10%	50/60 Hz, ±4 Hz

#### Power consumption

#### Transmitter

Max. 10 W (active power)

switch-on current	Max. 36 A (as per NAMUR Recommendation NE21)
-------------------	--

#### Current consumption

#### **Transmitter**

- Max. 400 mA (24 V)
- Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)

#### Power supply failure

- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

#### Electrical connection

→ 🖺 51

#### Potential equalization

→ 🖺 56

## terminals

Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to  $2.5~\text{mm}^2$  (24 to 12~AWG).

#### Cable entries

- Cable gland: M20  $\times$  1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
  - NPT ½"
  - G ½"
  - M20
- Device plug for digital communication: M12
- Device plug for connecting cable: M12

A device plug is always used for the device version with the order code for "Sensor connection housing", option  $\bf C$  "Ultra-compact, hygienic, stainless".

#### Cable specification

→ 🖺 35

# 16.6 Performance characteristics

# Reference operating conditions

- Error limits following DIN EN 29104, in future ISO 20456
- Water, typically: +15 to +45 °C (+59 to +113 °F); 0.5 to 7 bar (73 to 101 psi)
- Data as indicated in the calibration protocol
- Accuracy based on accredited calibration rigs according to ISO 17025
- Reference temperature for conductivity measurement: 25 °C (77 °F)

#### Maximum measured error


### Error limits under reference operating conditions

o.r. = of reading

#### Volume flow

- $\bullet$  ±0.5 % o.r. ± 1 mm/s (0.04 in/s)
- Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s)

Fluctuations in the supply voltage do not have any effect within the specified range.



■ 41 Maximum measured error in % o.r.

#### **Temperature**

±3 °C (±5.4 °F)

#### **Electrical conductivity**

Max. measured error not specified.

### Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA

#### Pulse/frequency output

o.r. = of reading

Accuracy	Max. ±50 ppm o.r. (over the entire ambient temperature range)
----------	---

#### Repeatability

o.r. = of reading

# Volume flow

Max.  $\pm 0.1$  % o.r.  $\pm 0.5$  mm/s (0.02 in/s)

#### **Temperature**

±0.5 °C (±0.9 °F)

### **Electrical conductivity**

- Max. ±5 % o.r.
- Max.  $\pm 1$  % o.r. for DN 15 to 150 in conjunction with stainless steel process connections, 1.4404 (F316L)

Temperature measurement
response time

 $T_{90} < 15 \text{ s}$ 

# Influence of ambient temperature

#### **Current output**

Temperature coefficient	Max. 1 μA/°C
-------------------------	--------------

#### Pulse/frequency output

Temperature coefficient	No additional effect. Included in accuracy.
-------------------------	---


# 16.7 Installation


## 16.8 Environment

# Ambient temperature range

→ 🖺 25

#### Temperature tables





#### Storage temperature

- Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.
- If protection caps or protective covers are mounted these should never be removed before installing the measuring device.

#### Degree of protection

#### Transmitter

- As standard: IP66/67, type 4X enclosure
- When housing is open: IP20, type 1 enclosure
- Display module: IP20, type 1 enclosure

#### Sensor

- As standard: IP66/67, type 4X enclosure
- With the order code for "Sensor options", option **CM**: IP69 can also be ordered


#### External WLAN antenna

IP67

Vibration resistance	<ul> <li>■ Vibration, sinusoidal according to IEC 60068-2-6         <ul> <li>2 to 8.4 Hz, 7.5 mm peak</li> <li>8.4 to 2 000 Hz, 2 g peak</li> </ul> </li> <li>■ Vibration broad-band random, according to IEC 60068-2-64         <ul> <li>10 to 200 Hz, 0.01 g²/Hz</li> <li>200 to 2 000 Hz, 0.003 g²/Hz</li> <li>Total: 2.70 g rms</li> </ul> </li> </ul>
Shock resistance	Shock, half-sine according to IEC 60068-2-27 6 ms 50 g
Shock resistance	Shock due to rough handling following IEC 60068-2-31
Mechanical load	<ul> <li>Protect the transmitter housing against mechanical effects, such as shock or impact.</li> <li>Never use the transmitter housing as a ladder or climbing aid.</li> </ul>
Interior cleaning	<ul> <li>Cleaning in place (CIP)</li> <li>Sterilization in place (SIP)</li> </ul>
Electromagnetic compatibility (EMC)	As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)  Details are provided in the Declaration of Conformity.

#### 16.9 **Process**


-20 to +150 °C (-4 to +302 °F) Medium temperature range



■ 42 Promag 500 – digital

 $T_A$  Ambient temperature range

T<sub>F</sub> Fluid temperature



Promag 500

Ambient temperature range

Fluid temperature

Conductivity

 $\geq$  5 µS/cm for liquids in general. Stronger filter damping is required for very low conductivity values.



The necessary minimum conductivity also depends on the cable length.

## Pressure-temperature ratings



€ 43

An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document

Pressure tightness

Liner: PFA

Nominal	diameter	Limit values for absolute pressure in [mbar] ([psi]) for medium temperat		temperatures:		
[mm]	[in]	+25 ℃ (+77 ℉)	+80 °C (+176 °F)	+100 °C (+212 °F)	+130 °C (+266 °F)	+150 °C (+302 °F)
2 to 150	½ to 6	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)

Flow limit


The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:

- v < 2 m/s (6.56 ft/s): for low conductivity values
- v > 2 m/s (6.56 ft/s): for fluids producing buildup (e.g. milk with a high fat content)
- A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.
- For an overview of the full scale values for the measuring range, see the "Measuring range" section  $\rightarrow \triangleq 205$


Pressure loss

- No pressure loss occurs as of nominal diameter DN 8 (5/16") if the sensor is installed in a pipe with the same nominal diameter.
- Pressure losses for configurations incorporating adapters according to DIN EN 545 → 🖺 26

218



■ 44 Pressure loss DN 50 to 80 (2 to 3") in the case of order code for "Design", option C "Insertion length short ISO/DVGW to DN300, without inlet/outlet runs, constricted meas.tube"



■ 45 Pressure loss DN 100 to 300 (4 to 12") in the case of order code for "Design", option C "Insertion length short ISO/DVGW to DN300, without inlet/outlet runs, constricted meas.tube"

System pressure  $\rightarrow \ \ \ \, \Rightarrow \ \ \, 25$ Vibrations  $\rightarrow \ \ \, \implies \ \ \, 26$ 

## 16.10 Mechanical construction

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.

Weight

All values (weight exclusive of packaging material) refer to devices for standard pressure ratings.

## Transmitter

- Proline 500 digital polycarbonate: 1.4 kg (3.1 lbs)
- Proline 500 digital aluminum: 2.4 kg (5.3 lbs)
- Proline 500 aluminum: 6.5 kg (14.3 lbs)

#### Sensor

Sensor with aluminum connection housing version: see the information in the following table

Nominal diameter		Weight	
[mm]	[in]	[kg]	[lbs]
2	1/12	2.00	4.41
4	5/32	2.00	4.41
8	5/16	2.00	4.41
15	1/2	1.90	4.19
25	1	2.80	6.17
40	1 ½	4.10	9.04
50	2	4.60	10.1
65	_	5.40	11.9
80	3	6.00	13.2
100	4	7.30	16.1
125	5	12.7	28.0
150	6	15.1	33.3

# Measuring tube specification

Nominal diameter		ninal diameter Pressure rating 1) Pressure rating 1) Pressure rating 1)		rocess connection internal diameter	
[mm]	[in]	[bar]	[mm]	[in]	
2	1/12	PN 16/40	2.25	0.09	
4	5/32	PN 16/40	4.5	0.18	
8	5/16	PN 16/40	9.0	0.35	
15	1/2	PN 16/40	16.0	0.63	
_	1	PN 16/40	22.6	0.89	
25	_	PN 16/40	26.0	1.02	

<sup>1)</sup> Depending on process connection and seals used

#### Materials

## Transmitter housing

Housing of Proline 500 – digital transmitter

Order code for "Transmitter housing":

- Option A "Aluminum coated": aluminum, AlSi10Mq, coated
- Option **D** "Polycarbonate": polycarbonate

Housing of Proline 500 transmitter

Order code for "Transmitter housing":

Option A "Aluminum coated": aluminum, AlSi10Mg, coated

## Window material

Order code for "Transmitter housing":


- Option **A** "Aluminum, coated": glass
- Option **D** "Polycarbonate": plastic

## Sensor connection housing

Order code for "Sensor connection housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option B "Stainless, hygienic": Stainless steel 1.4301 (304)
- Option C "Ultra-compact hygienic, stainless": Stainless steel 1.4301 (304)

## Cable entries/cable glands



A0028352

## ■ 46 Possible cable entries/cable glands

- 1 Female thread  $M20 \times 1.5$
- 2 Cable gland M20 × 1.5
- 3 Adapter for cable entry with internal thread G ½" or NPT ½"
- 4 Device plugs

Cable entries and adapters	Material
Cable gland M20 × 1.5	Plastic
■ Adapter for cable entry with internal thread G ½" ■ Adapter for cable entry with internal thread NPT ½"	Nickel-plated brass
Only available for certain device versions:  Order code for "Transmitter housing":  Option A "Aluminum, coated"  Option D "Polycarbonate"  Order code for "Sensor connection housing":  Proline 500 – digital: Option A "Aluminum coated" Option B "Stainless"  Proline 500: Option C "Stainless, hygienic"	
Adapter for device plug	Stainless steel, 1.4404 (316L)
<ul> <li>Device plug for digital communication:         Only available for certain device versions .</li> <li>Device plug for connecting cable:         A device plug is always used for the device version, order code for "Sensor connection housing", option C (ultracompact, hygienic, stainless).</li> </ul>	

## Device plug

Electrical connection	Material
Plug M12x1	<ul> <li>Socket: Stainless steel, 1.4404 (316L)</li> <li>Contact housing: Polyamide</li> <li>Contacts: Gold-plated brass</li> </ul>


### Connecting cable

Connecting cable for sensor - Proline 500 - digital transmitter

PVC cable with copper shield

Connecting cable for sensor - Proline 500 transmitter

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket



## Sensor housing

Stainless steel 1.4301 (304)

#### Measuring tubes

Stainless steel 1.4301 (304)

Liner

PFA (USP Class VI, FDA 21 CFR 177.1550, 3A)

### **Process connections**

- Stainless steel, 1.4404 (F316L)
- PVDF
- PVC adhesive sleeve

#### **Electrodes**

Standard: 1.4435 (316L)

## Seals

- O-ring seal, DN 2 to 25 (1/12 to 1"): EPDM, FKM, Kalrez
- Aseptic gasket seal, DN 2 to 150 (1/12 to 6"): EPDM <sup>2)</sup>, FKM, silicone <sup>2)</sup>

#### Accessories

Protective cover

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

USP Class VI, FDA 21 CFR 177.2600, 3A

## *Grounding* rings

Standard: 1.4435 (316L)Optional: Alloy C22, tantalum

Wall mounting kit

Stainless steel 1.4301 (304)

Spacer

1.4435 (F316L)

#### Fitted electrodes

- 2 measuring electrodes for signal detection
- 1 empty pipe detection electrode for empty pipe detection/temperature measurement (only DN 15 to 150 (½ to 6"))

#### Process connections

With O-ring seal:

- Welding nipple (DIN EN ISO 1127, ODT/SMS, ISO 2037)
- Flange (EN (DIN), ASME, JIS)
- Flange from PVDF (EN (DIN), ASME, JIS)
- External thread
- Internal thread
- Hose connection
- PVC adhesive sleeve

With aseptic molded seal:

- Coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145)
- Flange DIN 11864-2

## Surface roughness

Stainless steel electrodes, 1.4435 (316L); Alloy C22, 2.4602 (UNS N06022); platinum; tantalum:

 $\leq 0.3$  to 0.5 µm (11.8 to 19.7 µin)

(All data relate to parts in contact with fluid)

Liner with PFA:

 $\leq 0.4 \ \mu m \ (15.7 \ \mu in)$ 

(All data relate to parts in contact with fluid)

Stainless steel process connections:

- With O-ring seal:  $\leq 1.6 \, \mu \text{m}$  (63  $\mu \text{in}$ )
- With aseptic seal:  $\leq 0.8 \ \mu m \ (31.5 \ \mu in)$ Optional:  $\leq 0.38 \ \mu m \ (15 \ \mu in)$

(All data relate to parts in contact with fluid)

## 16.11 Operability

## Languages

Can be operated in the following languages:


- Via local operation
  - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via Web browser
  - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

## Local operation

## Via display module

#### Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"
- Information about WLAN interface → 🖺 87



47 Operation with touch control

- 1 Proline 500 digital
- 2 Proline 500

## Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.

## Operating elements

via a variety of interfaces.

- External operation via touch control (3 optical keys) without opening the housing:  $\boxdot$ ,  $\boxdot$ ,
- Operating elements also accessible in the various zones of the hazardous area

Remote operation	→ 🗎 86
Service interface	→ 🖺 86
Supported operating tools	Different operating tools can be used for local or remote access to the measuring device.  Depending on the operating tool used, access is possible with different operating units and

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li></ul>	Special Documentation for device
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 204
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	<ul><li>CDI-RJ45 service interface</li><li>WLAN interface</li><li>Fieldbus protocol</li></ul>	→ 🖺 204

- Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
  - FactoryTalk AssetCentre (FTAC) by Rockwell Automation → www.rockwellautomation.com
  - Process Device Manager (PDM) by Siemens → www.siemens.com
  - Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
  - FieldMate by Yokogawa → www.yokogawa.com
  - PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com  $\rightarrow$  Downloads

## Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option  $\bf G$  "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

## Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration
- Visualize up to 1000 saved measured values (only available with the **Extended HistoROM** application package  $\rightarrow \stackrel{\triangle}{=} 229$ )

 $\bigcirc$  Web server special documentation  $\rightarrow$   $\bigcirc$  231

HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

## Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	<ul> <li>Event logbook such as diagnostic events for example</li> <li>Parameter data record backup</li> <li>Device firmware package</li> <li>Driver for system integration for exporting via Web server, e.g: GSD for PROFIBUS PA</li> </ul>	<ul> <li>Measured value logging ("Extended HistoROM" order option)</li> <li>Current parameter data record (used by firmware at run time)</li> <li>Peakhold indicator (min/max values)</li> <li>Totalizer values</li> </ul>	<ul> <li>Sensor data: nominal diameter etc.</li> <li>Serial number</li> <li>Calibration data</li> <li>Device configuration (e.g. SW options, fixed I/O or multi I/O)</li> </ul>
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

## Data backup

#### **Automatic**

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

#### Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
   Backup and subsequent restoration of a device configuration in the device memory
   HistoROM backup
- Data comparison function
   Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

#### Data transfer

#### Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.:
   GSD for PROFIBUS PA

#### **Event list**

#### Automatic

- Chronological display of up to 20 event messages in the events list
- If the Extended HistoROM application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

#### Data logging

#### Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

#### 16.12 Certificates and approvals



Currently available certificates and approvals can be called up via the product configurator.

#### CE mark

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

## C-Tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

### Ex approval

The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.

## Sanitary compatibility

■ 3-A approval

Only devices with the order code for "Additional approval", option **LP** "3A" have 3-A approval.

EHEDG-tested

Only devices with the order code for "Additional approval", option LT "EHEDG" have been tested and meet the requirements of the EHEDG.

To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy Cleanable Pipe Couplings and Process Connections" (www.ehedg.org).

- FDA
- Food Contact Materials Regulation (EC) 1935/2004

FDA-compliant (apart from Kalrez seals)

## Pharmaceutical compatibility

- FDA
- USP Class VI
- TSE/BSE Certificate of Suitability

#### Certification PROFIBUS

#### **PROFIBUS** interface

The measuring device is certified and registered by the PNO (PROFIBUS User Organization Organization). The measuring system meets all the requirements of the following specifications:

- Certified in accordance with PROFIBUS PA Profile 3.02
- The device can also be operated with certified devices of other manufacturers (interoperability)

## Radio approval

The measuring device has radio approval.



For detailed information on the radio approval, see the Special Documentation

## Pressure Equipment Directive

- With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU.
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU.

# Measuring instrument approval

The measuring device is qualified to OIML R117 and has an OIML Certificate of Conformity (optional).

#### Additional certification

#### **PWIS-free**

PWIS = paint-wetting impairment substances

Order code for "Service":

- Option **HC**: PWIS-free (version A)
- Option **HD**: PWIS-free (version B)
- Option **HE**: PWIS-free (version C)



For more information on PWIS-free certification, see "Test specification" document TS01028D

# Other standards and guidelines

■ EN 60529

Degrees of protection provided by enclosures (IP code)

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements  $\,$ 

■ IEC/EN 61326

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

■ NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

- NAMUR NE 105
- Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107
  - Self-monitoring and diagnosis of field devices
- NAMUR NE 131

Requirements for field devices for standard applications

## **16.13** Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

## Diagnostics functions

Package	Description
Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	Data logging (line recorder):  Memory capacity for up to 1000 measured values is activated.  250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.  Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.

## Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".  Functional testing in the installed state without interrupting the process.  Traceable verification results on request, including a report.  Simple testing process via local operation or other operating interfaces.  Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications.  Extension of calibration intervals according to operator's risk assessment.
	Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:  Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time.  Schedule servicing in time.  Monitor the process or product quality, e.g. gas pockets.

01		
1 1	annna	
١.,	eaning	

Package	Description
Electrode cleaning circuit (ECC)	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe $_3$ O $_4$ ) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to AVOID build up of highly conductive matter and thin layers (typical of magnetite).

## 16.14 Accessories



Overview of accessories available for order  $\rightarrow \triangleq 202$ 

#### Supplementary documentation 16.15

- For an overview of the scope of the associated Technical Documentation, refer to the following:
  - *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
  - Endress+Hauser Operations App: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

#### Standard documentation

## **Brief Operating Instructions**

## *Brief Operating Instructions for the sensor*

Measuring device	Documentation code
Proline Promag H	KA01289D

## Brief Operating Instructions for transmitter

Measuring device	Documentation code
Proline 500 – digital	KA01407D
Proline 500	KA01406D

## **Technical Information**

Measuring device	Documentation code
Promag H 500	TI01225D

## Description of device parameters

Measuring device	Documentation code
Promag 500	GP01056D

## Device-dependent additional documentation

## Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex i	XA01522D
ATEX/IECEx Ex ec	XA01523D
cCSAus IS	XA01524D
cCSAus Ex e ia/Ex d ia	XA01525D
cCSAus Ex nA	XA01526D
INMETRO Ex i	XA01527D
INMETRO Ex ec	XA01528D
NEPSI Ex i	XA01529D
NEPSI Ex nA	XA01530D

230

Contents	Documentation code
EAC Ex i	XA01658D
EAC Ex nA	XA01659D
JPN	XA01776D

## **Special Documentation**

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D

Contents	Documentation code
Heartbeat Technology	SD01747D
Web server	SD01660D

## **Installation Instructions**

Contents	Comment
Installation instructions for spare part sets and accessories	<ul> <li>Access the overview of all the available spare part sets via W@MDevice Viewer → □ 200</li> <li>Accessories available for order with Installation Instructions → □ 202</li> </ul>

## Index

A
About this document 6
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Adapters
Adapting the diagnostic behavior 166
Additional certification
Ambient temperature
Influence
Ambient temperature range
Analog Input module
Analog Output module
Application
Applicator
Approvals
С
_
C-Tick symbol
Cable entries
Technical data
Cable entry
Degree of protection
CE mark
Certificates
Certification PROFIBUS
Checklist Post-connection check
Post-installation check
Cleaning Exterior cleaning
Interior cleaning
Cleaning in place (CIP)
Commissioning
Advanced settings
Configuring the measuring device
Compatibility with earlier model
Conductivity
Connecting cable
Connecting the connecting cable
Proline 500 – digital transmitter 48
Proline 500 terminal assignment 51
Proline 500 transmitter
Sensor connection housing, Proline 500 51
Sensor connection housing, Proline 500 - digital 44
Terminal assignment of Proline 500 - digital 44
Connecting the measuring device
Proline 500
Proline 500 – digital
Connecting the signal cable/supply voltage cable
Proline 500 – digital transmitter 49
Proline 500 transmitter 54
Connection
see Electrical connection

Connection examples, potential equalization Connection preparations	
Connection tools	
Context menu	
Calling up	74
Closing	74
Explanation	. , . 72
Current consumption	
Cyclic data transmission	
D	
-	1.0
Declaration of Conformity	
Define access code	
Degree of protection	
Designated use	
Device description files	
Device description files	22
Supplementary documentation	c
Device locking, status	
Device master file	144
GSD	ar
Device name	22
Sensor	10
Transmitter	
Device repair	
Device type ID	
Device Care	
Device description file	
Diagnostic behavior	. , , , ,
Explanation	167
Symbols	
Diagnostic information	102
Design, description	165
DeviceCare	
FieldCare	
Light emitting diodes	
	161
1 3	169
	169
	163
	193
5	161
Diagnostics	
Symbols	161
DIP switch	
see Write protection switch	
Direct access	76
Direct access code	
Disabling write protection	
Discrete Input module	
Discrete Output module	
Display	
see Onsite display	
Display area	
For operational display	69

In the navigation view	Firmware
Display values	Release date
For locking status	Version
Disposal	Firmware history
Document	Fitted electrodes
Function 6	Flow direction
Symbols used 6	Flow limit
Document function	Function check
Down pipe	Function scope
E	SIMATIC PDM
ECC	see Parameters
Editing view	See I diameters
Input screen	G
Using operating elements 72, 73	Galvanic isolation
Electrical connection	
Degree of protection 64	H
Measuring device	Hardware write protection
Operating tools	Help text
Via PROFIBUS PA network	Calling up
Via service interface (CDI-RJ45)	Closing
Via WLAN interface87Web server86	HistoROM
WLAN interface	110000001111111111111111111111111111111
Electromagnetic compatibility	I
Electronics module	Identifying the measuring device
EMPTY_MODULE module	Incoming acceptance
Enabling write protection	Influence
Enabling/disabling the keypad lock 79	Ambient temperature
Endress+Hauser services	Inlet runs
Maintenance	Input
Repair	Inspection Installation
Environment	Received goods
Ambient temperature range	Inspection check
Shock resistance	Connection
Storage temperature	Installation
Vibration resistance	Installation conditions
Error messages	Adapters
see Diagnostic messages	Down pipe
Event list	Inlet and outlet runs
Event logbook	Installation dimensions
Ex approval	Orientation
Extended order code	Partially filled pipe
Sensor       19         Transmitter       17	System pressure
Exterior cleaning	Vibrations
Exterior cleaning	Installation dimensions
F	Interior cleaning
FDA	т
Field of application	L Language and the continue of
Residual risks	Languages, operation options
FieldCare	Line recorder        151         Local display        224
Device description file	Navigation view
Establishing a connection	see Diagnostic message
User interface	see In alarm condition
Filtering the event logbook	see Operational display
g g	Low flow cut off

M	N	
Main electronics module	Nameplate	
Maintenance tasks	Sensor	19
Replacing seals	Transmitter	17
Managing the device configuration 134	Navigation path (navigation view)	70
Manufacturer ID	Navigation view	
Manufacturing date	In the submenu	70
Materials	In the wizard	70
Maximum measured error	Numeric editor	72
Measured values		
Calculated	0	
Measured	Onsite display	
see Process variables	Numeric editor	
Measuring and test equipment	Text editor	
Measuring device	Operable flow range	. 207
Configuration	Operating elements	4, 162
Conversion	Operating keys	
Disposal	see Operating elements	
Integrating via communication protocol 92	Operating menu	
Mounting the sensor 28	Menus, submenus	
Cleaning with pigs	Structure	66
Mounting grounding rings 29	Submenus and user roles	67
Mounting the seals 29	Operating philosophy	67
Welding nipple 28	Operation	. 144
Preparing for electrical connection 40	Operation options	65
Preparing for mounting	Operational display	68
Removing	Operational safety	
Repairs	Order code	17, 19
Structure	Orientation (vertical, horizontal)	24
Switch-on	Outlet runs	24
Measuring instrument approval 228	Output	. 209
Measuring principle 205	Output signal	. 209
Measuring range	_	
Measuring system	P	
Measuring tube specification	Packaging disposal	22
Mechanical load	Parameter	
Medium temperature range 217	Changing	
Menu	Entering values or text	77
Diagnostics	Parameter settings	
Setup	Administration (Submenu)	
Menus	Analog inputs (Submenu)	
For measuring device configuration 104	Communication (Submenu)	
For specific settings	Configuration backup (Submenu)	
Module	Current input	
Analog input	Current input (Wizard)	
Analog output	Current input 1 to n (Submenu)	
Discrete Input	Current output	
Discrete Output	Current output (Wizard)	
EMPTY MODULE	Data logging (Submenu)	
Totalizer	Define access code (Wizard)	
SETTOT_MODETOT_TOTAL 99	Device information (Submenu)	
SETTOT TOTAL	Diagnostics (Menu)	
TOTAL 98	Display (Submenu)	
Mounting dimensions	Display (Wizard)	
see Installation dimensions	Electrode cleaning circuit (Submenu)	
Mounting location	Empty pipe detection (Wizard)	
Mounting preparations	I/O configuration	
Mounting tools	I/O configuration (Submenu)	
<u> </u>	Low flow cut off (Wizard)	. 124

234

Pulse/frequency/switch output (Wizard) 115, 116, 116, 117, 116, 117, 116, 117, 116, 117, 116, 117, 117	Process variables (Submenu)	Remedial measures
Pulse/frequency/switch output 1 to n (Submenu) 149 Relay output 1 to n (Submenu) 149 Relay output 1 to n (Wazard) 121 Reseat access code (Submenu) 127 Sensor adjustment (Submenu) 128 Setup (Menu) 105 Simulation (Submenu) 137 Sensor adjustment (Submenu) 137 Status input (Submenu) 137 Status input (Submenu) 148 System units (Submenu) 128, 146 Totalizer 1 to n (Submenu) 128, 146 Totalizer 1 to n (Submenu) 150 Value current output 1 to n (Submenu) 150 Value current output 1 to n (Submenu) 150 Parlardly filled pipe 23 Parlormance characteristics 214 Parlamaceutical compatibility 227 Post-connection check (checklist) 64 Parlamaceutical compatibility 227 Post-connection check (checklist) 64 Power supply failure 214 Pressure Equipment Directive 228 Power supply failure 214 Pressure Equipment Directive 228 Pressure tightness 218 Process conditions 218 Conductivity 18 Flow limit 218 Flow limit 328 Flow lim	· · · · · · · · · · · · · · · · · · ·	
116		
Pulse/Trequency/switch output 1 to n (Submenu) 1.49 Relay output 1 to n (Submenu) 1.49 Relay output 1 to n (Wizard) 1.21 Relay output 1 to n (Wizard) 1.21 Resest access code (Submenu) 1.49 Relay output 1 to n (Wizard) 1.21 Resest access code (Submenu) 1.37 Sensor adjustment (Submenu) 1.37 Status input (Submenu) 1.37 Status input (Submenu) 1.31 Status input (Submenu) 1.48 System units (Submenu) 1.60 Totalizer 1 to n (Submenu) 1.60 Totalizer handling (Submenu) 1.80 Value current output 1 to n (Submenu) 1.80 Web server (Submenu) 1.33 Performance characteristics 1.34 Post-tinstallation check (checklist) 3.4 Portential equalization 5.6 Power consumption 1.214 Power supply failure 1.214 Power supply failure 1.214 Power supply failure 1.214 Power supply failure 1.214 Pressure Equipment Directive 2.28 Pressure loss 1.28 Pressure temperature ratings 1.28 Pressure temperature ratings 1.28 Pressure temperature ratings 1.28 Pressure tightness 1.28 Pressure tightness 1.28 Pressure tightness 1.28 Process conditions 1.24 Probline 500 - digital transmitter 1.28 Connecting the signal cable/supply voltage cable 1.49 Proline 500 - digital transmitter 1.28 Connecting the signal cable/supply voltage cable 1.49 Proline 500 - digital transmitter 1.28 Connecting the signal cable/supply voltage cable 1.49 Proline 500 connecting cable terminal assignment 1.28 Readio approval 1.49 Repairability 1.27 Totalizer reset 1.40 WIAN Serial mumber 1.21 Votation 1.214 Current output 1.29 Performance characteristics 1.214 Device resec 1.224 De		5
Relay output 1 to n (Submenu)         149           Relay output 1 to n (Wizard)         121           Rest access code (Submenu)         137           Sensor adjustment (Submenu)         128           Setup (Menu)         105           Simulation (Submenu)         137           Status input         111           Status input (Submenu)         111           Status input (Submenu)         111           System units (Submenu)         106           Totalizer 1 to n (Submenu)         150           Value current output 1 to n (Submenu)         150           Value current output 1 to n (Submenu)         150           WLAN Settings (Submenu)         150           Mula Metrings (Submenu)         150           Performance characteristics         214           Pharmaceutical compatibility         23           Performance characteristics         214           Post-installation check (checklist)         64           Post-installation of the ck (checklist)         34           Post-installation of the ck (checklist)         34           Power supply failur         214           Pressure Equipment Directive         28           Pressure temperature ratings         218	′	
Relay output 1 to n (Submenu) 149 Resort access code (Submenu) 137 Sensor adjustment (Submenu) 137 Sensor adjustment (Submenu) 105 Simulation (Submenu) 105 Simulation (Submenu) 137 Status input (Submenu) 137 Status input (Submenu) 148 System units (Submenu) 148 System units (Submenu) 150 Value current output 1 to n (Submenu) 150 Value current output 150 Value current output 150 Value current output 150 Value current output 150 Value current outpu		-
Respace scored (Submenu)		
Reset access code (Submenu)   137   Replacement		
Sensor adjustment (Submenu) 1.28 Setup (Menu) 1.05 Simulation (Submenu) 1.37 Status input (Submenu) 1.111 Status input 1 to n (Submenu) 1.111 Status input 1 to n (Submenu) 1.111 Status input 1 to n (Submenu) 1.06 Totalizer bandling (Submenu) 1.06 Totalizer to n (Submenu) 1.06 Totalizer bandling (Submenu) 1.05 WLAN Settings (Submenu) 1.05 WLAN Settings (Submenu) 1.03 Partially filled pipe 2.03 Performance characteristics 1.04 Performance characteristics 1.04 Paramaceutical compatibility 2.07 Post- connection check (checklist) 64 Post- installation check 1.03 Post- installation check 1.03 Post- installation check (checklist) 56 Power consumption 2.14 Power supply failure 1.14 Power supply failure 2.14 Pressure gliptness 2.18 Pressure tightness 2.18 Process conditions 2.19 Profile version 2.29 Proline 500 onnecting cable terminal assignment Sensor connection housing 7- Profile version 2.29 Proline 500 onnecting cable terminal assignment Sensor connection housing 7- Profile version 2.24 Radio approval 2.28 Radio approval 2.28 Radio approval 2.28 Reading measured values 4.144 Recalibration Pagicaria compatibility 2.27 Profile version 2.28 Radio approval 2.28 Readia general access 7.78 Radio approval 2.28 Reading measured values 4.144 Recalibration Pagicaria compatibility 5.25 Safety 5.25 Safety 5.25 Safety 5.25 Safety 5.25 Safety 5.25 Sanitary compatibility 5.25 Sanitary compatibility 5.25 Sanitary compatibility 5.25 Safety 5.25 Safety 5.25 Sanitary 5.25 Safety 5.25 Sanitary 5.25 Sanitary 5.25 Safety 6.25 Sanitary 5.25 Safety 6.25 Sa		<u> </u>
Setting (Memu)   105   Simulation (Submenu)   137   Status input (Submenu)   137   Status input (Submenu)   148   System units (Submenu)   106   Safety   Sanitary compatibility   Sanitary compatibility   Sanitary compatibility   Sensor Value current output 1 ton (Submenu)   150   Value current output 1 ton (Submenu)   150   Value current output 1 ton (Submenu)   188   Web server (Submenu)   189   Safety   Sanitary compatibility   Sensor Value current output 1 ton (Submenu)   189   Sensor Variable pipe   23   Settings (Submenu)   133   Settings (Submenu)   133   Settings (Submenu)   133   Settings (Submenu)   134   Sensor Variable pipe   23   Settings (Submenu)   136   Settings (Submenu)   137   Sensor Variable pipe   23   Settings (Submenu)   138   Settings (Submenu)   139   Settings (Submenu)   139   Settings (Submenu)   130   Settings (Submen	, ,	
Simulation (Submenu) 137 Status input (Submenu) 111 Status input (Submenu) 111 Status input (Submenu) 148 System units (Submenu) 106 Totalizer 1 to n (Submenu) 128, 146 Web server (Submenu) 185 Walna Settings (Submenu) 188 Web server (Submenu) 188 Web server (Submenu) 188 Web server (Submenu) 188 Performance characteristics 114 Pharmaceutical compatibility 227 Post- connection check (checklist) 44 Pharmaceutical compatibility 227 Post- connection check (checklist) 44 Post- installation check (checklist) 34 Potential equalization . 56 Power consumption 214 Power supply failure 214 Pressure Jupiment Directive 228 Pressure loss 218 Pressure loss 218 Process conditions 219 Profile version 2217 Pressure latin 2217 Pressure latin 2217 Pressure latin 2217 Pressure latin 2218 Process connection selection (selection (EPD) Profile post nammitter 2217 Pressure tightness 218 Process connection selection select		
Status input (Submenu)		
Status input I to n (Submenu) 148 System units (Submenu) 106 Totalizer 1 to n (Submenu) 150 Value current output 1 to n (Submenu) 150 Value current output 1 to n (Submenu) 150 Web server (Submenu) 133 Partially filled pipe 23 Performance characteristics 214 Pharmaceutical compatibility 227 Post- connection check (checklist) 44 Post-installation check 103 Post-installation check (checklist) 34 Post-installation check (checklist) 34 Post-installation check (checklist) 34 Power supply failure 214 Pressure Equipment Directive 228 Pressure Idynament Directive 228 Pressure Idynament Directive 228 Pressure temperature ratings 218 Process conditions Conductivity 218 Flow limit 218 Flow limit 218 Process connections 223 Proflice rations 223 Proflice rations 223 Proflice rations 223 Proflice for ansmitter 227 Connecting the signal cable/supply voltage cable 49 Proflie resion 92 Proflice for ansmitter 227 Connecting the signal cable/supply voltage cable 49 Proflice for ansmitter 227 Radio approval 228 Radio approval 228 Read access 78 Reading measured values 144 Reacilibration . 199 Reference operating conditions 244 Reacilibration . 199 Reference operating conditions 244 Registered trademarks 8 Flunction . 199 Reference operating conditions 244 Registered trademarks 8 Flunction . 199 Reference operating conditions 244 Registered trademarks 8 Flunction . 199 Reference operating conditions 244 Flunction . 199 Reference operating conditions 8 Flunction . 199 Reference operating conditions 8 Flunction . 199 Reference operating conditions . 144 Registered trademarks . 8		
Status input 1 ton (Submenu) 148 System units (Submenu) 106 Totalizer I ton (Submenu) 128, 146 Totalizer I ton (Submenu) 150 Value current output 1 ton (Submenu) 150 Walve current output 1 ton (Submenu) 150 WLAN Settings (Submenu) 133 Partially filled pipe 233 Partially filled pipe 227 Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check (checklist) 34 Potential equalization 56 Power consumption 214 Power supply failure 214 Power supply failure 214 Pressure Equipment Directive 228 Pressure loss 218 Pressure itiphtness 218 Pressure tiphtness 218 Process conditions 218 Flow limit 218 Flow		Return
System units (Submenu) 106 Totalizer 1 ton (Submenu) 128, 146 Value current output 1 ton (Submenu) 150 Value current output 1 ton (Submenu) 185 Web server (Submenu) 85 WLAN Settings (Submenu) 133 Partially filled pipe 233 Performance characteristics 214 Pharmaceutical compatibility 227 Post- connection check (checklist) 64 Post- installation check 103 Post- inst		c
Totalizer 1 to n (Submenu)		
Totalizer handling (Submenu) 150 Value current output 1 ton (Submenu) 148 Web server (Submenu) 85 WLAN Settings (Submenu) 133 Partially filled pipe 23 Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check (checklist) 34 Post-installation check (checklist) 34 Postential equalization 56 Power consumption 214 Pressure Equipment Directive 228 Pressure tightness 218 Pressure tightness 218 Pressure tightness 218 Flow limit 218 Process connections 223 Process connections 223 Process connections 223 Process connections 223 Proconceting the signal cable/supply voltage cable 49 Proline 500 connecting cable terminal assignment Sensor connection bousing 514 Protecting parameter settings 149 Radio approval 88 Reading measured values 144 Regalibration 399 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 199 Reference operating conditions 214 Registered trademarks 88 Function 9 Registered trademarks 88 Function 219 Registered trademarks 88 Residence (Submenu) 219 Registered trademarks 88 Function 9 Registered trademarks 88 Function 9 Registered trademarks 88 Residence (Submenu) 219 Regis		
Value current output 1 to n (Submenu) 148 Web server (Submenu) 85 WLAN Settlings (Submenu) 133 Partially filled pipe 23 Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check (checklist) 34 Porential equalization 56 Power consumption 56 Power consumption 214 Power supply failure 214 Pressure Equipment Directive 228 Pressure lightness 218 Pressure tightness 218 Process conditions Conductivity 218 Flow limit 218 Flow limit 218 Process conditions 223 Process conditions 223 Process conditions 223 Process conditions 224 Prossure tightness 218 Pressure tightness 218 Pressure tightness 218 Processor distons 223 Profile experiment of the process 223 Process conditions 224 Profile version 225 Profile 500 o digital transmitter 227 Connecting the signal cable/supply voltage cable 24 Protecting parameter settings 140 Radia approval 228 Radia approval 228 Read access 78 Read access 78 Read access 78 Readiang measured values 144 Regealibration 199 Reference operating conditions 214 Registered trademarks 88 Function 92 Function 92 Foline 500 regarding conditions 244 Regealibration 199 Reference operating conditions 244 Registered trademarks 88 Finction 92 Foline 500 regarding conditions 244 Registered trademarks 88 Finction 92 Finding 400		· · · · · · · · · · · · · · · · · · ·
Web server (Submenu)		
Setting the operating language Partially filled pipe 23 Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check 103 Post-installation check 103 Post-installation check (checklist) 64 Power consumption 214 Power supply failure 214 Power supply failure 214 Poressure loss 218 Pressure Equipment Directive 228 Pressure tightness 218 Pressure tightness 218 Pressure temperature ratings 218 Process conditions 219 Pressure temperature ratings 210 Pressure loss 2118 Process conditions 210 Current input 211 Current output 212 Device reset 213 Pressure tightness 214 Electrode cleaning circuit (ECC) Empty pipe detection (EPD) 1/0 configuration 217 Pressure loss 218 Pressure loss 218 Pressure tightness 218 Pressure tightness 218 Pressure tightness 218 Process conditions 219 Profile version 223 Profile version 223 Profile version 224 Proline 500 connecting abele/supply voltage cable Proline 500 connecting the signal cable/supply voltage cable Protecting parameter settings 228 R Radio approval R Radio approval Read access 378 Read access 384 Read access 378 Read access 384 Reading measured values 384 Protential equalization 34 Adaministration Analog input Cu		
Partially filled pipe 23 Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check (checklist) 34 Potential equalization . 56 Power consumption . 214 Pressure Equipment Directive . 228 Pressure Equipment Directive . 228 Pressure tightness . 218 Pressure tightness . 218 Process conditions Conductivity . 218 Flow limit . 218 Fluid temperature . 217 Pressure boss . 218 Pressure tightness . 218 Pressure ightness . 218 Process connections . 223 Proflice sconnection founding . 214 Product safety . 10 Profile version . 92 Proline 500 connecting cable terminal assignment Sensor connection housing . 51 Proline 500 connecting the signal cable/supply voltage cable . 49 Protecting parameter settings . 228 Radio approval . 228 Read access		
Performance characteristics 214 Pharmaceutical compatibility 227 Post-connection check (checklist) 64 Post-installation check (checklist) 34 Post-installation check (checklist) 34 Potential equalization 56 Power consumption 214 Power supply failure 214 Power supply failure 214 Poressure Equipment Directive 228 Pressure Equipment Directive 228 Pressure tightness 218 Process conditions Conductivity 218 Flow limit 218 Flow limit 218 Flow limit 218 Process conditions 218 Pressure tightness 218 Pressure tightness 218 Pressure tightness 218 Process conditions 219 Profile signal cable supply voltage cable 249 Proline 500 connecting cable terminal assignment 25 Sensor connection housing 310 Profile soft connecting the signal cable/supply voltage cable 249 Proline 500 connecting cable terminal assignment 25 Sensor connection housing 310 Profile soft connecting cable terminal assignment 25 Sensor connection housing 310 Profile soft connecting cable terminal assignment 25 Sensor connecting the signal cable/supply voltage cable 249 Proline 500 connecting cable terminal assignment 25 Sensor connecting the signal cable/supply voltage cable 249 Protecting parameter settings 310 Profile soft connecting cable terminal assignment 25 Sensor connection supplied the confidence and the supplied cable 35 Senting and an alarm 35 Shock resistance 35 Shock resistance 35 Shock resistance 35 Shock resistance 35 Showing data logging 35 Signal on alarm 35 Signal		5 1 5 5 5
Pharmaceutical compatibility. 227 Post-connection check (checklist) 64 Post-installation check . 103 Post-installation check (checklist) 34 Potential equalization . 56 Power consumption 214 Power supply failure 214 Power supply failure 214 Pressure Equipment Directive 228 Pressure lightness 218 Pressure tightness 218 Pressure-temperature ratings 218 Process condictions Conductivity 218 Flow limit 218 Fluid temperature 217 Pressure loss 218 Pressure loss 218 Pressure los 218 Pressure sightness 218 Process connections 218 Process connections 221 Product safety 10 Profile version 92 Proline 500 connecting cable terminal assignment Sensor connection housing 51 Proline 500 transmitter Connecting the signal cable/supply voltage cable 54 Protecting parameter settings 140  R Radio approval 8 Read access 78 Reading measured values 144 Regeistered trademarks 8 R Registered trademarks 8 Funding and Advanced display configuration Advanced display 4naloge diput. Administration Advanced display configuration Communication interface Current input Current output Durure lourne interface Current input Current output Durit pevice tag Device reset Provice tag Device reset Provice tag Device tag Device tag Electrode cleaning circuit (ECC) Empty pipe detection (EPD) 1/O configuration Local display Loc		
Post-connection check (checklist) 64 Post-installation check 103 Post-installation check (checklist) 34 Potential equalization 56 Power consumption 214 Pressure Equipment Directive 228 Pressure tightness 218 Pressure temperature ratings 218 Process conditions Conductivity 218 Flow limit 218 Pressure loss 218 Pressure loss 218 Pressure tightness 218 Pressure tightness 218 Process conditions Conductivity 218 Flow limit 218 Process connection s 218 Process connections 218 Profile version 92 Proline 500 connecting cable terminal assignment Sensor connecting the signal cable/supply voltage cable 54 Protecting parameter settings 140  R  R  Radio approval 228 Read access 78 Reading measured values 144 Regeistered trademarks 8 R  Registered trademarks 8 R  Administration Advanced display configurations Analog input Communication interface . Comrett input . Communication interface . Communication interface . Comrett input . Communication interface . Communication interface . Courrent input . Communication interface . Courrent input . Communication interface . Courrent input . Communication interface . Current input . Communication interface . Current input . Communication interface . Current input . Communication interface . Communication interface . Current input . Communication interface . Current input . Communication interface . Current input . Comition interfa		
Post-installation check		
Post-installation check (checklist) 34 Potential equalization 56 Power consumption 214 Power supply failure 214 Pressure Equipment Directive 228 Pressure lightness 218 Pressure-temperature ratings 218 Process conditions Conductivity 218 Flow limit 218 Flud temperature 217 Pressure loss 218 Pressure tightness 218 Pressure tightness 218 Pressure tightness 218 Pressure tightness 218 Process connection s 223 Process connections 223 Profile version 92 Profile version 92 Proline 500 connecting cable terminal assignment Sensor connection housing 51 Protecting parameter settings 140  R  R  R  R  Radio approval 228 Read access 78 Reading measured values 144 Registered trademarks 8  R  Reference operating conditions 214 Registered trademarks 8  Analog input Communication interface Course in current output Current output Current output Eucret Equation interface Communication interface Current input Current output Current output Eucret Equation interface Current input Current output Eucret Equation interface Current input Current output Eucret Equation interface Current input Current output Current output Eucret Equation interface Current input Curreit in pevice against pevice tag. Pevice tag. Pevice tag. Pev		
Potential equalization		
Power consumption		
Pressure Equipment Directive 228 Pressure Iguipment Directive 228 Pressure Lightness 218 Pressure-temperature ratings 218 Pressure-temperature ratings 218 Process conditions Conductivity 218 Flow limit 218 Fluid temperature 217 Pressure loss 218 Pressure tightness 218 Process connections 223 Product safety 10 Profile version 92 Proline 500 - digital transmitter Connecting the signal cable/supply voltage cable 49 Proline 500 connecting cable terminal assignment Sensor connection housing 51 Protecting parameter settings 140  R R Radio approval 228 Read access 78 Reading measured values 144 Registered trademarks 8 R Reference operating conditions 214 Registered trademarks 8 R Current output Device reset . Device tag . Electrode cleaning circuit (ECC) Empty pipe detection (EPD) I/O configuration . Local display . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O configuration . Local display . Empty pipe detection (EPD) I/O	Potential equalization	
Pressure Equipment Directive	Power consumption	
Pressure loss		
Pressure tightness	Pressure Equipment Directive	
Pressure-temperature ratings 218 Process conditions Conductivity 218 Flow limit 218 Fluid temperature 217 Pressure loss 218 Pressure tightness 218 Process connections 223 Product safety 10 Profile version 92 Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable 9Protecting parameter settings 140  Radio approval 228 Reading measured values 144 Recalibration 20 Reference operating conditions 214 Registered trademarks 218 Empty pipe detection (EPD) I/O configuration 20 Local display 1 Local disp	Pressure loss	Device tag
Process conditions  Conductivity 218 Flow limit 218 Fluid temperature 217 Pressure loss 218 Process connections 223 Product safety 10 Profile version 92 Proline 500 - digital transmitter Connecting the signal cable/supply voltage cable 49 Proline 500 transmitter Connecting the signal cable/supply voltage cable 54 Protecting parameter settings 140  Reading approval 228 Reading measured values 144 Recalibration 199 Reference operating conditions 214 Registered trademarks 8  I/O configuration 1 Local display 1 Lova flow cut off 1 Managing the device configuration 0 Poperating language 1 Pulse output 1 Pulse output 1 Pulse output 2 Pulse/frequency/switch output 115, 115, 115, 115, 115, 115, 115, 115	Pressure tightness	Electrode cleaning circuit (ECC)
Process conditions Conductivity 218 Flow limit 218 Flow limit 218 Fluid temperature 217 Pressure loss 218 Pressure tightness 218 Process connections 223 Product safety 10 Profile version 92 Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable 49 Proline 500 connection housing 51 Proline 500 transmitter Connecting parameter settings 140  Readin approval 228 Reading measured values 144 Recalibration 199 Reference operating conditions 214 Registered trademarks 8  I/O configuration Local display . Managing the device configuration . Deparating language . Pulse output . Sensor adjustment . Sensor adjustment . Simulation . Status input . Switch output . System units . Totalizer . Totalizer . Totalizer reset . WLAN . SETTOT_MODETOT_TOTAL module . Secure TOTAL module . Shock resistance . Showing data logging . Simalon alarm . Simulation . Simulation . Status input . Switch output . System units . Soutch output . Shock resistance . Showing data logging . Simulation . Simulation . Status input . Sensor adjustment . Simulation . Sensor adjustment . Sensor adjustm	Pressure-temperature ratings 218	Empty pipe detection (EPD) 126
Flow limit	Process conditions	I/O configuration
Fluid temperature 217 Pressure loss 218 Pressure tightness 218 Process connections 223 Product safety 10 Profile version 92 Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable 50 Proline 500 transmitter Connecting the signal cable/supply voltage cable 50 Protecting parameter settings 140  Radio approval 228 Read access 78 Reading measured values 144 Registered trademarks 8  Managing the device configuration Operating language Pulse output Pulse output Pulse output Pulse/frequency/switch output 115, Relay output Sesetting the totalizer Sensor adjustment Simulation Status input Switch output System units Totalizer Totalizer Totalizer Totalizer Totalizer reset WLAN SETTOT_MODETOT_TOTAL module SETTOT_TOTAL module Signal on alarm Signal on alarm Signal on alarm SimATIC PDM Function	Conductivity	Local display
Fluid temperature	Flow limit	Low flow cut off
Pressure loss 218 Pressure tightness 218 Process connections 223 Product safety 100 Profile version 92 Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable 49 Proline 500 connection housing 51 Proline 500 transmitter Connecting the signal cable/supply voltage cable 54 Protecting parameter settings 140  Radio approval 228 Read access 78 Read access 78 Read access 78 Read and access 78 Read access 78 Reading measured values 144 Registered trademarks 8  Operating language Pulse output Pulse output Pulse output Pulse output Suesetting the totalizer Sensor adjustment Sensor adjustment Sensor adjustment Simulation Status input Switch output System units Totalizer Totalizer Totalizer reset WLAN SETTOT_MODETOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module Secondary Signal on alarm SIMATIC PDM Function	Fluid temperature	Managing the device configuration 134
Pressure tightness		Operating language 103
Process connections 223 Product safety 10 Profile version 92 Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable 49 Proline 500 connecting cable terminal assignment Sensor connection housing 51 Proline 500 transmitter Connecting the signal cable/supply voltage cable 54 Protecting parameter settings 140  Readio approval 228 Read access 78 Reading measured values 144 Recalibration 199 Reference operating conditions 214 Registered trademarks 8  Pulse/frequency/switch output 15, Relay output 15 Resetting the totalizer 15 Sensor adjustment 15 Simulation 15 Switch output 15 Switch output 15 System units 15 Totalizer 15 Totalize		Pulse output
Product safety	Process connections	Pulse/frequency/switch output 115, 116
Profile version		Relay output
Proline 500 – digital transmitter Connecting the signal cable/supply voltage cable . 49 Proline 500 connecting cable terminal assignment Sensor connection housing . 51 Proline 500 transmitter Connecting the signal cable/supply voltage cable . 54 Protecting the signal cable/supply voltage cable . 54 Protecting parameter settings . 140  R Radio approval . 228 Read access . 78 Reading measured values . 144 Recalibration . 199 Reference operating conditions . 214 Registered trademarks . 8  Sensor adjustment . Simulation . Status input . Switch output . System units . Totalizer . Totalizer . Totalizer reset . WLAN . SETTOT_MODETOT_TOTAL module . SETTOT_MODETOT_TOTAL module . Shock resistance . Showing data logging . Signal on alarm . Simulation . Simulation . Status input . Switch output . System units . Totalizer . Totalizer . Totalizer . Totalizer . Totalizer reset . WLAN . SETTOT_MODETOT_TOTAL module . SetTOT_TOTAL module . Shock resistance . Showing data logging . Signal on alarm . Simulation . Simulation . Simulation . Simulation . Status input . Switch output . Switch	Profile version	Resetting the totalizer
Connecting the signal cable/supply voltage cable . 49 Proline 500 connecting cable terminal assignment Sensor connection housing . 51 Proline 500 transmitter Connecting the signal cable/supply voltage cable . 54 Protecting parameter settings . 140  Radio approval . 228 Read access . 78 Read access . 78 Reading measured values . 144 Recalibration . 199 Reference operating conditions . 214 Registered trademarks . 8  Simulation . Status input . Switch output . System units . Totalizer . Totalizer . Totalizer . System units . System units . Totalizer . Totalizer reset . WLAN . SETTOT_MODETOT_TOTAL module . SETTOT_TOTAL module . Shock resistance . Showing data logging . Signal on alarm . Signal on alarm . SIMATIC PDM . Function . Function .		Sensor adjustment
Proline 500 connecting cable terminal assignment Sensor connection housing	<u> </u>	Simulation
Sensor connection housing		Status input
Proline 500 transmitter Connecting the signal cable/supply voltage cable . 54 Protecting parameter settings . 140  R Radio approval . 228 Read access . 78 Reading measured values . 144 Recalibration . 199 Reference operating conditions . 214 Registered trademarks . 8  System units . Totalizer .  Totalizer . Settings . 140  SETTOT_MODETOT_TOTAL module . SETTOT_TOTAL module . Shock resistance . Showing data logging . Signal on alarm . Signal on alarm . Signal on alarm . SIMATIC PDM . Function . 8		Switch output
Connecting the signal cable/supply voltage cable . 54 Protecting parameter settings . 140  R Radio approval . 228 Read access . 78 Reading measured values . 144 Recalibration . 199 Reference operating conditions . 214 Registered trademarks . 8  Totalizer . Totalizer reset . WLAN . SETTOT_MODETOT_TOTAL module . SETTOT_TOTAL module . Shock resistance . Showing data logging . Signal on alarm . Signal on alarm . Signal on alarm . SIMATIC PDM . Function . 8		
Protecting parameter settings		Totalizer
WLAN SETTOT_MODETOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module SETTOT_TOTAL module Shock resistance Shock resistance Showing data logging Signal on alarm Seference operating conditions SIMATIC PDM SEGISTERED SIMATIC PDM SETTOT_MODETOT_TOTAL module SHOW SETTOT_MODETOT_TOTAL module SHOW SHOW SHOW SHOW SHOW SHOW SHOW SHOW		Totalizer reset
RSETTOT_MODETOT_TOTAL moduleRadio approval228SETTOT_TOTAL moduleRead access78Shock resistanceReading measured values144Showing data loggingRecalibration199Signal on alarmReference operating conditions214SIMATIC PDMRegistered trademarks8Function	roteeting parameter bettings	
Radio approval228SETTOT_TOTAL moduleRead access.78Shock resistanceReading measured values.144Showing data loggingRecalibration.199Signal on alarmReference operating conditions.214SIMATIC PDMRegistered trademarks.8Function	R	
Read access78Shock resistanceReading measured values144Showing data loggingRecalibration199Signal on alarmReference operating conditions214SIMATIC PDMRegistered trademarks8Function		
Reading measured values144Showing data loggingRecalibration199Signal on alarmReference operating conditions214SIMATIC PDMRegistered trademarks8Function		
Recalibration199Signal on alarmSignal on alarmReference operating conditions214SIMATIC PDMRegistered trademarks8Function		
Reference operating conditions214SIMATIC PDMRegistered trademarks8Function		
Registered trademarks 8 Function		
<del>z</del>		
opace pate		
· ·		-r

Spare parts	For status signal
Special connection instructions	For submenu
Standards and guidelines	For wizard
Status area	In the status area of the local display 69
For operational display 69	Input screen
In the navigation view	Operating elements
Status signals	System design
Sterilization in place (SIP)	Measuring system
Storage concept	see Measuring device design
Storage conditions	System integration
Storage temperature	System pressure
Storage temperature range	-
Structure	T
Measuring device	Technical data, overview 205
Operating menu	Temperature measurement response time 216
Submenu	Temperature range
Administration	Ambient temperature range for display 224
Advanced setup	Storage temperature
Analog inputs	Terminal assignment
Communication	Terminal assignment of connecting cable for Proline
Configuration backup	500- digital
Current input 1 to n	Sensor connection housing
Data logging	terminals
Device information	Text editor
Display	Tool tip
	see Help text
Electrode cleaning circuit	Tools
Event list	Electrical connection
I/O configuration	For mounting
Input values	Transport
Measured values	TOTAL module
Output values	Totalizer
Overview	Assign process variable
Process variables	Configuration
Pulse/frequency/switch output 1 to n	
Relay output 1 to n	Operation
Reset access code	Reset
Sensor adjustment	
Simulation	Turning the display module
Status input	Turning the housing
Status input 1 to n	Transporting the measuring device
System units	Troubleshooting
Totalizer 1 to n	General
Totalizer handling	TSE/BSE Certificate of Suitability
Value current output 1 to n	Turning the display module
Web server	Turning the electronics housing
WLAN Settings	see Turning the transmitter housing
Supplementary documentation 230	Turning the transmitter housing
Supply voltage	TT
Surface roughness	U
Switch output	Use of the measuring device
Symbols	Borderline cases
Controlling data entries	Incorrect use
For communication 69	see Designated use
For diagnostic behavior 69	User interface
For locking	Current diagnostic event
For measured variable 69	Previous diagnostic event 192
For measurement channel number 69	User roles
For menus	USP Class VI
For parameters	
-	l .

236

V
Vibration resistance
Vibrations
W
W@M 199, 200
W@M Device Viewer 16, 200
Weight
Transport (notes)
Wizard
Current input
Current output
Define access code
Display
Empty pipe detection
Low flow cut off
Pulse/frequency/switch output 115, 116, 119
Relay output 1 to n
WLAN settings
Workplace safety
Write access
Write protection
Via access code
Via write protection switch 142
Write protection switch



